

SECTION **BT**

CONTENTS

PRECAUTIONS	3	ROOF TRIM	35
Service Notice.....	3	Removal and Installation	35
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	BACK DOOR TRIM	37
CLIP AND FASTENER	4	Removal and Installation	37
Description	4	EXTERIOR	38
CHASSIS AND BODY MAINTENANCE	6	Removal and Installation	38
Checking Body Corrosion.....	6	FRONT SEAT	46
BODY FRONT END	7	Removal and Installation	46
Removal and Installation	7	MANUAL SEAT.....	47
FRONT BUMPER ASSEMBLY	7	Heated Seat.....	48
BODY REAR END AND OPENER	10	Active Head Restraint.....	48
Removal and Installation	10	OPERATION OUTLINE	48
REAR BUMPER ASSEMBLY	10	REAR SEAT	49
DOOR	13	Removal and Installation	49
Adjustment	13	REAR OUTSIDE SEAT.....	49
STRIKER ADJUSTMENT	13	REAR CENTER SEAT.....	50
Front Door Glass	14	SUNROOF	51
FRONT DOOR GLASS AND REGULATOR.....	14	Adjustment	51
Front Door Limit Switch Reset (Driver side only).....	15	Removal.....	51
RESET CONDITIONS	15	Trouble Diagnoses.....	55
RESET PROCEDURES	15	DIAGNOSTIC TABLE.....	55
Rear Door Glass.....	16	WIND DEFLECTOR (WHERE FITTED).....	55
REAR DOOR GLASS AND REGULATOR	16	ADJUSTMENT	56
Front Door Lock.....	18	DRAIN HOSES	57
OUTSIDE HANDLE ROD ADJUSTMENT	18	WEATHERSTRIP	57
REMOVAL.....	18	LINK AND WIRE ASSEMBLY.....	58
Rear Door Lock	20	WINDSHIELD AND WINDOWS	59
OUTSIDE HANDLE ROD ADJUSTMENT	20	Removal and Installation	59
REMOVAL.....	21	REMOVAL.....	59
INSTRUMENT PANEL ASSEMBLY	22	INSTALLATION.....	59
Removal and Installation	22	WINDSHIELD	60
SIDE AND FLOOR TRIM	28	SIDE WINDOW.....	61
Removal and Installation	28	BACK DOOR WINDOW.....	62
LUGGAGE ROOM TRIM	31	DOOR MIRROR	63
Removal and Installation	31	Removal and Installation	63
DOOR TRIM	32	REAR VIEW MIRROR	64
Removal and Installation	32	Removal and Installation	64
		REMOVAL.....	64

CONTENTS (Cont'd)

INSTALLATION.....	64	ENGINE COMPARTMENT.....	66
BODY (ALIGNMENT)	65	UNDERBODY.....	68
Alignment.....	65		

PRECAUTIONS

Service Notice

Service Notice

NLBT0001

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NLBT0002

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER” used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL V10 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), front seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), side air bag (satellite) sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.
















CLIP AND FASTENER

Description

Description













NLBT0003

- Clips and fasteners in BT section correspond to the following numbers and symbols.
- Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
<p>C101</p> 	 <p style="text-align: right;">SBF302H</p>	<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p>  <p style="text-align: right;">SBF367BA</p>
<p>C103</p> 	 <p style="text-align: right;">SBT095</p>	 <p>Removal: Remove with a clip remover.</p> <p style="text-align: right;">SBF423H</p>
<p>C203</p> 	 <p style="text-align: right;">SBF258G</p>	<p>Push center pin to catching position. (Do not remove center pin by hitting it.)</p>  <p>Installation:</p> <p style="text-align: right;">SBF708E</p>
<p>C205</p> 	 <p style="text-align: right;">MBT080A</p>	<p>Removal:</p>  <p style="text-align: right;">SBF638CA</p>
<p>C206</p> 	 <p style="text-align: right;">MBF519B</p>	 <p style="text-align: right;">MBF520B</p>

CLIP AND FASTENER

Description (Cont'd)

Symbol No.	Shapes	Removal & Installation
<p>CE103</p> 		<p>Removal:</p>  <p style="text-align: right;">SBF147B</p>
<p>CF110</p> 		<p>Removal:</p>  <p style="text-align: right;">SBF649B</p>
<p>CF118</p> 		<p>Removal:</p>  <p style="text-align: right;">SBF259G</p>
<p>CR103</p> 		<p>Removal: Holder portion of clip must be spread out to remove rod.</p>  <p style="text-align: right;">SBF770B</p>

CHASSIS AND BODY MAINTENANCE

Checking Body Corrosion

Checking Body Corrosion

NLBT0033

Visually check the body sheet metal panel for corrosion, paint damage (scratches, chipping, rubbing, etc.) or damage to the anti-corrosion materials. In particular, check the following locations.

Hemmed portion

Hood front end, door lower end, trunk lid rear end, etc.

Panel joint

Side sill of rear fender and center pillar, rear wheel housing of rear fender, around strut tower in engine compartment, etc.

Panel edge

Trunk lid opening, sunroof opening, fender wheelarch flange, fuel filler lid flange, around holes in panel, etc.

Parts contact

Waist molding, windshield molding, bumper, etc.

Protectors

Damage or condition of mudguard, fender protector, chipping protector, etc.

Anti-corrosion materials

Damage or separation of anti-corrosion materials under the body.

Drain holes

Condition of drain holes at door and side sill.

When repairing corroded areas, refer to the Corrosion Repair Manual.

Removal and Installation

NLBT0004

- When removing or installing hood, place a cloth or other padding on hood. This prevents vehicle body from being scratched.
- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood locks engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so increases effort required to unlock hood.

FRONT BUMPER ASSEMBLY

NLBT0004S01

1. Remove clips securing front grille, then remove front grille. **A**
2. Remove clips and screws securing left and right sides of fender protectors. **C**
3. Remove clips and screws securing left and right sides of fender protectors in wheelhouse. **D**
4. Remove screws securing left and right front fenders to bumper fascia. **E**
5. Remove bolts securing radiator core support lower to bumper fascia and remove clips securing lower side of bumper fascia. **F**
6. Remove clips securing radiator core support upper to bumper fascia. **G**
7. Extract bumper fascia assembly. Then disconnect harness connectors. (Models with fog lamp assembly) **T**
8. Remove bolts securing left and right side of bumper lower bracket. **H**
9. Remove energy absorber.
10. Remove bolts and hooks securing the headlamp assembly, then disconnect harness connectors. **J**
In case of headlamp bracket breakage, repair of the headlamp unit is possible by means of the bracket repair kit.

Headlamp bracket repair kit part number:


KE260-BU125 (RH side)

KE260-BU025 (LH side)

11. Remove nuts securing bumper reinforcement to left and right bumper stays. **K**
12. Extract bumper reinforcement.
13. Remove bolts securing bumper upper retainer, then remove bumper upper retainer. **L S**
14. Remove bolts securing bumper stays, then remove the bumper stays. **M**

Fog lamp assembly (Models with fog lamp assembly)

15. Remove screw securing fog lamp assembly. **N**
16. Extract fog lamp assembly.




★ : Bumper assembly mounting bolts.

NBT137

BODY FRONT END











Removal and Installation (Cont'd)



NBT138

BODY FRONT END

Removal and Installation (Cont'd)



Q Bumper rubber adjustment

- Remove hood lock. Rotate bumper rubber so that hood is 1 to 1.5 mm (0.039 to 0.059 in) lower than fender.
- Temporarily tighten hood lock. After making sure that there is no striker free play, tighten hood lock securing bolts to specified torque.
- Adjust bumper rubber so that hood is flush with fender, or the surface difference between the two is 0 mm (0 in).

R Hood lock adjustment

- Move hood lock either to the left or right so that striker center is vertically aligned with hood lock center (when viewed from vehicle front).
- Allow hood to close under its own weight from a height of approximately 200 mm (7.87 in) or push it down with a force of approximately 29 N (3 kg, 7lb). Make sure that secondary latch properly engages with secondary striker when hood is lowered all the way.
- CAUTION: Do not allow hood to close from a height of more than 300 mm (11.81 in).**
- Close hood. Move hood lock up or down as required so that striker properly engages with hood lock.
- After adjusting hood lock, tighten hood lock securing bolts to specified torque.

(The number of bolts, nuts and clips may not be the same as shown in the figure.)

21 - 26 (2.1 - 2.7, 16 - 19)

★ : Bumper assembly mounting bolts, nuts and clips
(The number of bolts, nuts and clips may not be the same as shown in the figure.)

: N·m (kg·m, ft·lb)

NBT167

BODY REAR END AND OPENER

Removal and Installation

Removal and Installation







NLBT0034

- When removing or installing back door, place a cloth or other padding on back door. This prevents vehicle body from being scratched.
- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Back door adjustment: Adjust at hinge-back door portion for proper back door fit.
- Back door lock system adjustment: Adjust striker so that it is in the center of the lock. After adjustment, check back door lock operation.
- After installation, make sure that back door and fuel filler lid open smoothly.

REAR BUMPER ASSEMBLY

NLBT0034S01

1. Remove clips securing left and right chipping protectors. **A**
2. Remove screws securing left and right rear fenders to bumper fascia. **B**
3. Remove clips securing bumper fascia assembly. **C**
4. Remove bolts securing left and right rear body to bumper fascia. **D**
5. Open the bumper fascia side outward to disengage from side clips. **E**
6. Extract bumper fascia assembly.
7. Remove nuts securing bumper reinforcement to left and right bumper stays. **F**
8. Remove bolts securing bumper stays, then remove the bumper stays. **G**




★ : Bumper assembly mounting screws and clips (The number of bolts, nuts and clips may not be the same as shown in the figure.)

NBT168

BODY REAR END AND OPENER











Removal and Installation (Cont'd)



NBT169

BODY REAR END AND OPENER

Removal and Installation (Cont'd)



: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)




NBT170

DOOR


Adjustment

Adjustment

NLBT0006



Front door




Rear door

Unit : mm (in)

: N·m (kg·m, ft·lb)

NBT085



STRIKER ADJUSTMENT

Adjust striker so that it is parallel with advancing direction of door lock.

NLBT0006S01

DOOR

Front Door Glass


Front Door Glass

=NLBT0007


- Make sure that door glass is positioned in glass run groove.
- Make sure that there is no abnormality when door glass is raised or lowered.

FRONT DOOR GLASS AND REGULATOR

NLBT0007S01




- For removal of front door finisher, refer to “DOOR TRIM”, BT-32.
- Remove sealing screen.




1. Using power window main switch, raise or lower door glass until carrier plate securing bolts are visible.
2. Remove bolts securing carrier plate.

DOOR


Front Door Glass (Cont'd)



3. Hold door glass with both hands. While raising rear end of door glass, remove door glass from sash and away from outside the door.



4. Disconnect regulator assembly connector.
5. Remove bolts securing regulator assembly and guide rail, then remove regulator assembly and guide rail.



Inspection

Check regulator assembly for the following parts. Replace faulty parts with new ones. NLBT0007S0101

- Wire for wear
- Regulator for deformation
- Sliding parts for lubrication

Front Door Limit Switch Reset (Driver side only)

RESET CONDITIONS

After each of the following operations are performed, reset the limit switch (with built-in motor). NLBT0008

- Regulator removal and installation
- Removal of motor from regulator
- Operation of regulator as a single unit
- Door glass removal and installation
- Glass run removal and installation


RESET PROCEDURES

After installing parts, proceed as follows: NLBT0008S01

1. Close the door window completely.
2. Press the reset switch and open the door window completely.
3. Release the reset switch. After making sure the reset switch has returned to the original position, close the door window completely.
4. The limit switch is now reset.

CAUTION:

Be sure to manually open or close the door window. (Do not use the automatic open-close procedures.) NLBT0008S02



DOOR

Rear Door Glass


Rear Door Glass

NLBT0009


- Make sure that door glass is positioned in glass run groove.
- Make sure that there is no abnormality when door glass is raised or lowered.

REAR DOOR GLASS AND REGULATOR

NLBT0009S01




- For removal of rear door finisher, refer to “DOOR TRIM”, BT-32.
- For removal of door outside molding, refer to “EXTERIOR”, BT-38.
- Remove sealing screen.




1. Remove bolts securing lower sash rear, then remove lower sash rear.
2. Using power window main switch, raise or lower door glass until carrier plate securing bolts are visible.
3. Remove bolts securing main channel.

DOOR


Rear Door Glass (Cont'd)




4. Disconnect regulator assembly connector.
5. Remove bolts securing regulator assembly, then remove regulator assembly.




6. Remove corner inner cover.



7. Remove nut securing lower sash rear.



8. Remove bolt securing under of lower sash rear.
9. Remove door glass from glass run and away from outside the door.



Inspection

NLBT0009S0101

Check regulator assembly for the following parts. Replace faulty parts with new ones.

- Wire for wear
- Regulator for deformation
- Sliding parts for lubrication


DOOR

Front Door Lock


Front Door Lock

NLBT0010

SEC. 805



- For removal of front door finisher, refer to "DOOR TRIM", BT-32.
- Remove sealing screen.




OUTSIDE HANDLE ROD ADJUSTMENT

NLBT0010S02

Rotate rod holder so that rod-to-holder clearance is adjusted as shown in the figure at left.

CAUTION:

Make sure that rod-to-holder clearance is not "0" mm (0 in), and that rod is not held pressed.




REMOVAL

NLBT0010S03


- For removal of front door finisher, refer to "DOOR TRIM", BT-32.
 - Remove sealing screen.
 - For removal of front door glass, refer to "Front Door Glass", BT-14.
1. Remove lower rear sash (unitized with glass run) securing bolts. Remove lower rear sash from door panel and away from door lock.

DOOR

Front Door Lock (Cont'd)



2. Remove inside handle escutcheon A.
3. Remove screw securing inside handle.
4. Detach bell crank at lock knob joining area.
5. Detach inside handle rod on the door lock assembly side.
6. Slide inside handle backward and remove inside handle.
7. Remove rod from inside handle.




8. Detach key lock rod and outside handle rod at joining area (on the outside handle side).
9. Disconnect door lock actuator connector.
10. Remove screws securing door lock assembly, then remove door lock assembly.
11. Remove bolts securing outside handle, then remove outside handle assembly.

DOOR


Rear Door Lock

Rear Door Lock

=NLBT0011



- For removal of rear door finisher, refer to "DOOR TRIM", BT-32.
- Remove sealing screen.



OUTSIDE HANDLE ROD ADJUSTMENT

NLBT0011S01



Rotate rod holder so that rod-to-holder clearance is adjusted as shown in the figure at left.

CAUTION:

Make sure that rod-to-holder clearance is not "0" mm (0 in), and that rod is not held pressed.

DOOR

Rear Door Lock (Cont'd)



REMOVAL

- For removal of rear door finisher, refer to "DOOR TRIM"^{=NLBT0011S02}, BT-32.
 - Remove sealing screen.
 - Set the door glass in the full-close position.
1. Remove inside handle escutcheon A.
 2. Remove screw securing inside handle.
 3. Detach inside handle rod on the door lock assembly side.
 4. Detach lock knob rod (on the door lock assembly side).
 5. Using a flat-bladed screwdriver, expand rod holder. Remove rod from rod holder.
 6. Slide inside handle backward and remove inside handle.
 7. Remove rod from inside handle.
 8. Disconnect door lock actuator connector.
 9. Remove screws securing door lock assembly, then remove door lock assembly.
 10. Remove bolts securing outside handle, then remove outside handle.

INSTRUMENT PANEL ASSEMBLY

Removal and Installation

Removal and Installation


NLBT0012

CAUTION:

- Disconnect ground terminal from battery in advance.
- Disconnect air bag system line in advance.
- Never tamper with or force air bag lid open, as this may adversely affect air bag performance.
- Be careful not to scratch pad and other parts.

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



NBT133

*1 RS-24

*2 BT-28

*3 RS-27

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)

a

c

- 19 A/C control unit assembly
• Remove screws then disconnect harness connectors.

- 20 Instrument finisher B
• Remove screws.

L

- 21 Passenger air bag module
• Refer to "Front Passenger Air Bag Module" for details. (*3)

M

- 22 Front pillar garnish
• Refer to "SIDE AND FLOOR TRIM" for details. (*2)

- 23 Instrument panel and pad assembly
• Remove instrument panel mask.
• Remove bolts and nuts.

N

NBT134


*2 BT-28

*3 RS-27

BT-24

INSTRUMENT PANEL ASSEMBLY












Removal and Installation (Cont'd)



NBT171

INSTRUMENT PANEL ASSEMBLY





Removal and Installation (Cont'd)



NBT172

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



SIDE AND FLOOR TRIM

Removal and Installation

Removal and Installation





NLBT0013

CAUTION:

- **Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.**
1. Remove front and rear seats. Refer to "FRONT SEAT" and "REAR SEAT" for details, BT-46 and BT-49.
 2. Remove front and rear seat belts. Refer to RS-5 and RS-7, "Front Seat Belt" and "Rear Seat Belt" for details.
 3. Remove carpet rear finish, front seat mounting cover and rear seat mounting cover. Refer to "LUGGAGE ROOM TRIM" for details, BT-31.
 4. Remove front and rear outer kicking plates. **B C**
 5. Remove front and rear inner kicking plates.
 6. Remove dash side finishers. **D**
 7. Remove front and rear body side welts.
 8. Remove front pillar garnishes. **E**
 9. Remove center pillar lower garnishes. **F G**
 10. Remove center pillar upper garnishes. **F G**
 11. Remove front and rear room carpet.
 12. Remove rear pillar garnish. **H**
 13. Remove rear parcel shelf side finish.
 14. Remove luggage room carpet.
 15. Remove luggage room rear plate. **I**
 16. Remove luggage room rear side plate.
 17. Remove luggage room rear side lower finish.

SIDE AND FLOOR TRIM







Removal and Installation (Cont'd)



NBT107

SIDE AND FLOOR TRIM

Removal and Installation (Cont'd)



NBT108




LUGGAGE ROOM TRIM

Removal and Installation

Removal and Installation

NLBT0016

SEC. 678•749•769•799



NBT181

DOOR TRIM

Removal and Installation

Removal and Installation

NLBT0014

Front door finisher


1. Open the window.
2. Remove inside handle escutcheon. **A**
3. Remove screw securing pull handle.
4. Remove screw securing door finisher.
5. Remove clips securing front door finisher.
6. Lift out front door finisher. **B**
7. Remove power window switch by pushing from backside, then disconnect the connectors. **C**

Rear door finisher


8. Remove inside handle escutcheon. **D**
9. Remove screw securing power window switch finisher, then disconnect the connector. (Power window model) **E**
10. Remove screw securing pull handle. (Manual window model)
11. Remove window regulator handle. (Manual window model)
12. Remove clips securing rear door finisher.
13. Lift out rear door finisher. **F**

DOOR TRIM


Removal and Installation (Cont'd)



Manual model




Manual window regulator handle Remove



Squeeze the regulator handle clip in place with screwdriver and remove the regulator handle from regulator shaft. Set the regulator handle clip as shown in figure ①.

Installation









Push the regulator handle to install it into the regulator shaft. Install the regulator handle in place as shown in the figure with the window completely closed.

NBT173

DOOR TRIM

Removal and Installation (Cont'd)



NBT174


ROOF TRIM

Removal and Installation

Removal and Installation

NLBT0015


1. Remove rear seat.
2. Remove shoulder anchor bolts. Refer to RS-5, "Front Seat Belt" for details.
3. Remove front pillar garnishes, center pillar upper garnishes, center pillar lower garnishes and rear pillar garnishes. Refer to "SIDE AND FLOOR TRIM" for details, BT-28.
4. Push back the front seat back.
5. Remove sunroof switch, then disconnect connectors. (Model with sunroof) **A**
6. Remove front personal light then disconnect connector (Model without sunroof) **B**
7. Remove sunroof welt. (Model with sunroof)
8. Remove interior lamp assembly, then disconnect connectors. **C**
9. Remove sun visors.
10. Remove assist grips.
11. Remove clips securing headlining, then remove headlining from vehicle through back door side.



NBT113

ROOF TRIM

Removal and Installation (Cont'd)



NBT114

BT-36




BACK DOOR TRIM

Removal and Installation

Removal and Installation

NLBT0035

1. Remove back door upper finisher.
2. Remove high-mounted stop lamp.
3. Remove back door side finisher.
4. Remove back door finisher.




NBT115

EXTERIOR

Removal and Installation



Removal and Installation

NLBT0017



① Radiator core support sealing rubber

② ③ Cowl top seal and cowl grille



④ Windshield side molding
Mounted with screws.


NBT175

EXTERIOR

Removal and Installation (Cont'd)


⑤ Windshield upper molding

SEC. 720




⑧ Body side welt

SEC. 767




⑥ Sunroof lid weatherstrip

SEC. 736




⑨ Front door parting seal

SEC. 800




⑦ Drip weatherstrip

SEC. 767



⑩ Door weatherstrip

SEC. 800•820




NBT176

EXTERIOR


Removal and Installation (Cont'd)

11 Door outside molding

SEC. 800•820



12 Back door weatherstrip




NBT119

EXTERIOR

Removal and Installation (Cont'd)

13 Licence plate finisher

SEC. 900




NBT120


EXTERIOR

Removal and Installation (Cont'd)

14 Rear combination lamp



15 Side guard molding




NBT121

EXTERIOR

Removal and Installation (Cont'd)

16 Center mud guard




NBT122


EXTERIOR

Removal and Installation (Cont'd)

17 Roof rail




18 Door sash molding




NBT123

19 Roof side molding



20 Front fender finisher



FRONT SEAT

Removal and Installation

Removal and Installation

NLBT0018

- When removing or installing the seat trim, carefully handle it to keep dirt out and avoid damage.

CAUTION:


- Before removing the front seat, turn the ignition switch off, disconnect both battery cables and wait at least 3 minutes (models with side airbag).
- Do not drop, tilt, or bump the side air bag module installed in the seat. Always handle it with care.
- Disconnect the side air bag harness connector and heated seat harness connector from under the seat before removing the seat.
- Disconnect the side air bag harness connector before removing the seat back. Refer to RS-27, "Front Side Air Bag Module" for details.

FRONT SEAT

Removal and Installation (Cont'd)

MANUAL SEAT

NLBT0018S07




FRONT SEAT

Heated Seat

Heated Seat

NLBT0036

★ For Wiring Diagram, refer to EL-234, "HEATED SEAT" for details.




Active Head Restraint

NLBT0032

The active head restraint system is designed so that the headrest instantaneously moves towards the front upper direction by utilizing the force at the seatback during a rear-end collision.

As a result, the occupant's head is protected from being overextended, reducing the chance for neck injury as much as possible.

Seat with active head restraint have the labels shown in figures at left.



OPERATION OUTLINE

NLBT0032S01

When the seatback receives a sharp backward force during a rear-end collision, the input plate moves with the link rotating center as a pivot. The headrest will then move towards the front upper direction with the center of the sliding roller as a pivot.

As the backward force on the seat back is eliminated, spring tension returns the headrest to its original position.

REAR SEAT


Removal and Installation

Removal and Installation

NLBT0019

NLBT0019S02

REAR OUTSIDE SEAT



NBT178





BT-49

REAR SEAT

Removal and Installation (Cont'd)

REAR CENTER SEAT

NLBT0019S03



: N·m (Kg-m, ft-lb)

NBT128


BT-50

Adjustment

NLBT0020

Install motor & limit SW assembly and sunroof rail assembly in the following sequence:

1. Arrange equal lengths of link and wire assemblies on both sides of sunroof opening.
2. Connect sunroof connector to sunroof switch and positive (+) power supply.
3. Set lid assembly to fully closed position **A** by operating OPEN switch and TILT switch.
4. Fit outer side of lid assembly to the surface of roof on body outer panel.
5. Remove motor, and keep OPEN switch pressed until motor pinion gear reaches the end of its rotating range.
6. Install motor.
7. Check that motor drive gear fits properly in wires.
8. Press TILT-UP switch to check lid assembly for normal tilting.
9. Check sunroof lid assembly for normal operations (tilt-up, tilt-down, open, and close).



SBF920F

Removal

NLBT0021


- After any adjustment, check sunroof operation and lid alignment.
- Handle finisher plate and glass lid with care so not to cause damage.
- It is desirable for easy installation to mark each point before removal.

CAUTION:

Always work with a helper.

SUNROOF

Removal (Cont'd)



For wiring Diagram, refer to (*2), "POWER SUNROOF" for details.


NBT179

*1 BT-35

*2 EL-238

SUNROOF

Removal (Cont'd)




: N·m (kg·m, in·lb)


NBT180

SUNROOF


Removal (Cont'd)




A Record the number of shims placed between glass lid assembly and link and wire assembly. Remove securing screws and glass lid assembly.



B Remove shade stoppers (2 points) from rear end of sunroof frame assembly. Remove sun shade from rear end of sunroof frame assembly.



C Remove screws from left and right sides of each wind deflector holder. Then remove left and right sides of wind deflector holder. Remove screws from front end of sunroof unit. Then remove wind deflector from frame assembly. (If wind deflector is equipped).



D

CAUTION:

- Before removing sunroof motor, make sure that sunroof is fully closed.
- After removing sunroof motor, never attempt to rotate sunroof motor as a single unit.

Trouble Diagnoses DIAGNOSTIC TABLE

=NLBT0022


NLBT0022S01

NOTE:

For diagnosing electric problem, refer to “ELECTRIC SUNROOF” in EL section.

		Check items (Components)				
		Wind deflector (where fitted)	Adjustment	Drain hoses	Weatherstrip	Link and wire assembly
	Reference page	BT-55	BT-56	BT-57	BT-57	BT-58
Symptom	Excessive wind noise	1	2		3	
	Water leaks		1	2	3	
	Sunroof rattles		1	4	2	3
	Excessive operation noise		1		2	3


The numbers in this table mean checking order.



WIND DEFLECTOR (WHERE FITTED)

NLBT0022S02

1. Open lid.
2. Check visually for proper installation.
3. Check to ensure a proper amount of petroleum jelly has been applied to wind deflector connection points; apply if necessary.
4. Check that wind deflector is properly retracted by hand. If it is not, remove and visually check condition. (Refer to removal procedures, BT-51.) If wind deflector is damaged, replace with new one. If wind deflector is not damaged, re-install properly.





SUNROOF

Trouble Diagnoses (Cont'd)

ADJUSTMENT

NLBT0022S03

SEC. 736



A - A (When sunroof is tilted up)

Unit: mm (in)

NBT150

If any height difference between glass lid and roof is found, check glass lid fit and adjust as follows:


Height Difference Adjustment

NLBT0022S0302


1. Tilt glass lid up and down.
2. Check height difference between roof panel and glass lid to see if it is as "A-A" as shown in the figure above.
3. If necessary, adjust it by using one of following procedures.
 - Adjust by adding or removing adjustment shim(s) between glass lid and link assembly.
 - If glass lid protrudes above roof panel, add shim(s) or plain washer(s) at sunroof mounting bracket or stud bolt locations to adjust sunroof installation as required.

DRAIN HOSES


NLBT0022S04



SBT005A



NBT151



NBT152

1. Remove headlining to access drain hose connections. (Refer to "ROOF TRIM", BT-35, for detail.)
2. Check visually for proper connections, damage or deterioration. **A** (The figure shows only the front side.)
3. If leakage occurs around luggage room, remove luggage room side trim and check connecting area. Check for proper connection, damage or tear. **B**
4. Remove drain hoses and check visually for any damage, cracks, or deterioration.
5. Pour water into drain hoses and find damaged portion.
 - If any damaged portion is found at each step, replace the damaged part.

WEATHERSTRIP

NLBT0022S05

- In the case of leakage around glass lid, close glass lid and pour water over glass lid to find damaged or gap portion.
1. Remove glass lid assembly. (Refer to removal procedures, BT-51, for details.)
 2. Visually check weatherstrip for proper installation. If a gap exists between glass lid and weatherstrip, check for sufficient amount of butyl seal. If required, remove weatherstrip and apply butyl seal.
Refer to "EXTERIOR", BT-38, for details.

SUNROOF

Trouble Diagnoses (Cont'd)

3. Check weatherstrip visually for any damage, deterioration, or flattening.
 - If any damage is found, replace weatherstrip.

CAUTION:

Do not remove weatherstrip except when replacing, or filling up butyl seal.

LINK AND WIRE ASSEMBLY

NLBT0022S06


NOTE:

Before replacing a suspect part, carefully ensure it is the source of noise being experienced.

1. Check link to determine if coating film has peeled off to such an extent that substrate is visible. Check also to determine if link is the source of noise. If it is, replace it.
2. Visually check to determine if a sufficient amount of petroleum jelly has been applied to wire or rail groove. If not, add petroleum jelly as required.
3. Check wire for any damage or deterioration. If any damage is found, remove rear guide (refer to removal procedures, BT-51, for details), then replace wire.

WINDSHIELD AND WINDOWS

Removal and Installation



Removal and Installation

NLBT0023

REMOVAL

NLBT0023S01


After removing moldings, remove glass using piano wire or power cutting tool and an inflatable pump bag.

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

CAUTION:

- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.



INSTALLATION

NLBT0023S02


- Use a genuine Nissan Urethane Adhesive Kit or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- The molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the windshield in case of an accident.

CAUTION:

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.




WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidities. The curing time will increase under higher temperatures and lower humidities.

WINDSHIELD

NLBT0023S03



NBT129

Repairing Water Leaks for Windshield

NLBT0023S0301

Leaks can be repaired without removing and reinstalling glass. **If water is leaking between the urethane adhesive material and body or glass, determine the extent of leakage. This can be done by applying water to the windshield area while pushing glass outward.**







To stop the leak, apply primer (if necessary) and then urethane adhesive to the leak point.

WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

SIDE WINDOW

NLBT0023S04



NBT130






WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

BACK DOOR WINDOW

NLBT0023S05

- Structure and removal/reinstallation method of back door window are basically the same as for the windshield.



DOOR MIRROR

Removal and Installation

Removal and Installation


NLBT0024

CAUTION:

Be careful not to scratch door rearview mirror body.

★ For Wiring Diagram, refer to EL-241, "DOOR MIRROR" for details.

1. Remove front corner of door inner cover.
2. Disconnect door mirror harness connector.
3. Remove bolts securing door mirror assembly.
4. Remove the mirror glass. Do not insert flat-bladed screwdriver too far.



REAR VIEW MIRROR


Removal and Installation

Removal and Installation

REMOVAL


NLBT0025

NLBT0025S01



NBT059

Mounting bracket location



NBT157

INSTALLATION

NLBT0025S02

1. Install mirror base as follows:
 - a. Determine mirror base position on windshield by measuring from top of windshield to top of mirror base as shown in the figure.
 - b. Mark location on outside of windshield with wax pencil or equivalent.
 - c. Clean attaching point on inside of windshield with an alcohol-saturated panel towel.
 - d. Sand bonding surface of mirror base with sandpaper (No. 320 or No. 360).
 - e. Clean bonding surface of mirror base with an alcohol-saturated paper towel.
 - f. Apply Loctite Adhesive 11067-2 or equivalent to bonding surface of mirror base.
 - g. Install mirror base at premarked position and press mirror base against glass for 30 to 60 seconds.
 - h. After five minutes, wipe off excess adhesive with an alcohol-moistened paper towel.
2. Install rearview mirror.


BODY (ALIGNMENT)

Alignment

Alignment

NLBT0026

- All dimensions indicated in figures are actual ones.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



SBF874GB


BODY (ALIGNMENT)

Alignment (Cont'd)

ENGINE COMPARTMENT Measurement

NLBT0026S01

NLBT0026S0101










NBT153

BODY (ALIGNMENT)

Alignment (Cont'd)

Measurement Points

NLBT0026S0102



NBT154


BODY (ALIGNMENT)

Alignment (Cont'd)

UNDERBODY Measurement

NLBT0026S02

NLBT0026S0201



Unit: mm

NBT155

BODY (ALIGNMENT)

Alignment (Cont'd)

NLBT0026S0202

Measurement Points

Measurement Points

Coordinates

(A)	(G), (g)
X: 280	X: 600
Y: -607	Y: 2,035
Z: 186.8	Z: 254
(a)	(H), (h)
X: -285	X: 536.8
Y: -609	Y: 2,393
Z: 186.8	Z: 513.6
(B)	(I)
X: 477	X: 145
Y: -450	Y: 2,444.5
Z: 355	Z: 241
(b)	(J), (j)
X: -492	X: 400
Y: -450	Y: 2,509
Z: 355	Z: 390
(C), (c)	(K), (k)
X: 460	X: 470
Y: 71.5	Y: 2,790
Z: 300.3	Z: 355
(D), (d)	(L)
X: 283.5	X: 490
Y: 423	Y: 3,075
Z: 126.5	Z: 352.2
(E), (e)	(l)
X: 395	X: -490
Y: 600	Y: 3,095
Z: 127.8	Z: 352.2
(F)	
X: 400	
Y: 1,230	
Z: 120.6	
(f)	
X: -405	
Y: 1,230	
Z: 120.6	


Front and rear strut tower centers

Coordinates:

(M), (m)
X: 550
Y: 28.6
Z: 774.8


(N), (n)

X: 484.6
Y: 2,467.9
Z: 527.7



Front: **(M), (m)** 87 dia.
Rear: **(N), (n)** 68 dia.

Unit: mm



NBT156

BODY (ALIGNMENT)

Alignment (Cont'd)
