

HEATER & AIR CONDITIONER

SECTION HA

CONTENTS

| | | | |
|--|----|--|-----|
| PRECAUTIONS | 2 | Intake Door | 43 |
| Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 2 | Mode Door | 47 |
| Precautions for Working with HFC-134a (R-134a) | 2 | Air Mix Door | 49 |
| General Refrigerant Precautions | 2 | Max Hot Door (For Scandinavia and Cold Spec Models) | 51 |
| Precautions for Refrigerant Connection | 3 | Blower Motor | 55 |
| Precautions for Servicing Compressor | 5 | Magnet Clutch | 62 |
| Precautions for Service Equipment | 6 | Insufficient Cooling | 75 |
| Wiring Diagrams and Trouble Diagnosis | 8 | Insufficient Heating | 83 |
| PREPARATION | 9 | Noise | 84 |
| Special Service Tools | 9 | SERVICE PROCEDURE | 85 |
| HFC-134a (R-134a) Service Tools and Equipment | 10 | HFC-134a (R-134a) Service Procedure | 85 |
| DESCRIPTION | 12 | Maintenance of Lubricant Quantity in Compressor | 87 |
| Refrigeration System | 12 | Compressor | 90 |
| CSV613 Variable Displacement Compressor | 13 | Compressor Clutch - CSV613 (CALSONIC make) | 92 |
| Component Layout | 17 | Heater & Cooling Unit (Heater Core) | 95 |
| Control Operation | 18 | A/C Evaporator | 96 |
| Discharge Air Flow | 19 | Blower Unit | 97 |
| System Description | 20 | Refrigerant Lines | 98 |
| TROUBLE DIAGNOSES | 21 | Belt | 102 |
| Component Location | 21 | Idle Air Control Valve (IACV) - Auxiliary Air Control (AAC) Valve | 103 |
| Wiring Diagram - Heater | 23 | Ventilation Air Filter | 103 |
| Circuit Diagram - Air Conditioner | 26 | SERVICE DATA AND SPECIFICATIONS (SDS) | 104 |
| Wiring Diagram - A/C, M - | 27 | Manual | 104 |
| How to Perform Trouble Diagnoses for Quick and Accurate Repair | 40 | | |
| Operational Check | 41 | | |

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NLHA0190

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL V10 is as follows (The composition varies according to the destination and optional equipment.):

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), front seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), side air bag (satellite) sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for Working with HFC-134a (R-134a)

NLHA0113

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. If the refrigerants are mixed, compressor failure is likely to occur.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a) When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b) When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - c) Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d) Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system, using certified service equipment meeting requirements of R-134a recycling equipment, or R-134a recovery equipment. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e) Do not allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

General Refrigerant Precautions

NLHA0114

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.

PRECAUTIONS

General Refrigerant Precautions (Cont'd)

- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and R-134a have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.

Precautions for Refrigerant Connection

NLHA0115


A new type refrigerant connection has been introduced to all refrigerant lines except the following portion.

- Expansion valve to cooling unit

FEATURES OF NEW TYPE REFRIGERANT CONNECTION

NLHA0115S01

- The O-ring has been relocated. It has also been provided with a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.
- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.




PRECAUTIONS

Precautions for Refrigerant Connection (Cont'd)

O-RING AND REFRIGERANT CONNECTION

NLHA0115S02



CAUTION:

The new and former refrigerant connections in some systems use different O-ring configurations. Do not confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.

O-Ring Part Numbers and Specifications

NLHA0115S0201

| | Connection type | O-ring size | Part number | D mm (in) | W mm (in) |
|--|-----------------|-------------|-------------|--------------|---------------|
| | | New | 8 | 92471 N8210 | 6.8 (0.268) |
| | New | 12 | 92472 N8210 | 10.9 (0.429) | 2.43 (0.0957) |
| | Former | | 92475 71L00 | 11.0 (0.433) | 2.40 (0.0945) |
| | New | 16 | 92473 N8210 | 13.6 (0.535) | 2.43 (0.0957) |
| | Former | | 92475 72L00 | 14.3 (0.563) | 2.30 (0.0906) |
| | New | 19 | 92474 N8210 | 16.5 (0.650) | 2.43 (0.0957) |

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:


When replacing or cleaning refrigerant cycle components, observe the following.

- When the compressor is removed, store it in the same position as it is when mounted on the car. Failure to do so will cause lubricant to enter the low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.

PRECAUTIONS

Precautions for Refrigerant Connection (Cont'd)

- When installing an air conditioner in the vehicle, connect the pipes as the final stage of the operation. Do not remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to circle of the O-rings shown in illustration. Be careful not to apply lubricant to threaded portion.
Lubricant name: Nissan A/C System Oil Type R for DKV-11G compressor
Part number: KLH00-PAGR0
Lubricant name: Nissan A/C System Oil Type S for CSV613 compressor
Part number: KLH00-PAGS0
- O-ring must be closely attached to dented portion of tube.
- When replacing the O-ring, be careful not to damage O-ring and tube.
- Connect tube until you hear it click, then tighten the nut or bolt by hand until snug. Make sure that the O-ring is installed to tube correctly.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



Precautions for Servicing Compressor

NLHA0116

- Plug all openings to prevent moisture and foreign matter from entering.
- When the compressor is removed, store it in the same position as it is when mounted on the car.
- When replacing or repairing compressor, follow "Maintenance of Lubricant Quantity in Compressor" exactly. Refer to HA-87.
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with lubricant, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

PRECAUTIONS

Precautions for Service Equipment RECOVERY/RECYCLING EQUIPMENT

NLHA0117

NLHA0117S01

Follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

NLHA0117S02

Follow the manufacturer's instructions for tester operation and tester maintenance.

VACUUM PUMP


NLHA0117S03

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched off after evacuation (vacuuming) and hose is connected to it.

To prevent this migration, use a manual valve situated near the hose-to-pump connection, as follows.

- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut off valve, disconnect the hose from the pump: as long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.



MANIFOLD GAUGE SET

NLHA0117S04


Be certain that the gauge face indicates R-134a or 134a. Make sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) along with specified lubricant.



SERVICE HOSES


NLHA0117S05

Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.



PRECAUTIONS

Precautions for Service Equipment (Cont'd)




SERVICE COUPLERS

NLHA0117S06

Never attempt to connect HFC-134a (R-134a) service couplers to an CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.

| Shut-off valve rotation | A/C service valve |
|-------------------------|-------------------|
| Clockwise | Open |
| Counterclockwise | Close |



REFRIGERANT WEIGHT SCALE

NLHA0117S07

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. If the scale controls refrigerant flow electronically, the hose fitting must be 1/2"-16 ACME.

CALIBRATING ACR4 WEIGHT SCALE

NLHA0117S09

Calibrate the scale every three months.

To calibrate the weight scale on the ACR4:

1. Press **Shift/Reset** and **Enter** at the same time.
2. Press **8787**. "A1" will be displayed.
3. Remove all weight from the scale.
4. Press **0**, then press **Enter**. "0.00" will be displayed and change to "A2".
5. Place a known weight (dumbbell or similar weight), between 4.5 and 36.3 kg (10 and 80 lb) on the center of the weight scale.
6. Enter the known weight using four digits. (Example 10 lb = "10.00", 10.5 lb = "10.50")
7. Press **Enter** — the display returns to the vacuum mode.
8. Press **Shift/Reset** and **Enter** at the same time.
9. Press **6** — the known weight on the scale is displayed.
10. Remove the known weight from the scale. "0.00" will be displayed.
11. Press **Shift/Reset** to return the ACR4 to the program mode.

CHARGING CYLINDER

NLHA0117S08

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

PRECAUTIONS

Wiring Diagrams and Trouble Diagnosis

NLHA0118

When you read wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS"
- EL-10, "Wiring Diagram — POWER —".

When you perform trouble diagnosis, refer to the following:

- GI-32, "HOW TO FOLLOW TROUBLE DIAGNOSES"
- GI-21, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"






PREPARATION

Special Service Tools

Special Service Tools CSV613 COMPRESSOR

NLHA0119

NLHA0119S02

| Tool number Tool name | Description |
|----------------------------------|---|
| KV99106100 Clutch disc wrench | <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;">  <p>NT232</p>  <p>When replacing the magnet clutch in the above compressor, use a clutch disc wrench with the pin side on the clutch disc to remove it.</p>  <p style="margin-left: 100px;">Pin</p> <p style="margin-left: 150px;">Clutch disc wrench</p> <p>NT378</p> </div> <div style="width: 50%; text-align: right;"> <p>Removing center bolt</p> </div> </div> |
| KV99232340 Clutch disc puller | <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;">  <p>NT376</p> </div> <div style="width: 50%; text-align: right;"> <p>Removing clutch disc</p> </div> </div> |
| KV99106200 Pulley installer | <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;">  <p>NT235</p> </div> <div style="width: 50%; text-align: right;"> <p>Installing pulley</p> </div> </div> |

PREPARATION

HFC-134a (R-134a) Service Tools and Equipment

HFC-134a (R-134a) Service Tools and Equipment






=NLHA0120

Never mix HFC-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.

Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.





Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricant.

Adapters that convert one size fitting to another must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

| Tool number Tool name | Description |
|--|---|
| HFC-134a (R-134a) refrigerant | <div style="display: flex; justify-content: space-between; align-items: center;">  <div style="text-align: right;"> <p>Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size</p> <ul style="list-style-type: none"> ● Large container 1/2"-16 ACME </div> </div> <p style="text-align: center;">NT196</p> |
| KLH00-PAGR0 Nissan A/C System Oil Type R KLH00-PAGS0 Nissan A/C System Oil Type S | <div style="display: flex; justify-content: center; align-items: center;">  <div style="text-align: right;"> <p>Type: Poly alkylene glycol oil (PAG), type R Application: HFC-134a (R-134a) vane rotary compressors (Nissan only) Type S Application: HFC-134a (R-134a) swash plate compressors (Nissan only) Lubricity: 40 ml (1.4 Imp fl oz)</p> </div> </div> <p style="text-align: center;">NT197</p> |
| Recovery/Recycling Recharging equipment (ACR4) | <div style="display: flex; justify-content: center; align-items: center;">  <div style="text-align: right;"> <p>Function: Refrigerant Recovery and Recycling and Recharging</p> </div> </div> <p style="text-align: center;">NT195</p> |
| Electrical leak detector | <div style="display: flex; justify-content: center; align-items: center;">  <div style="text-align: right;"> <p>Power supply:</p> <ul style="list-style-type: none"> ● DC 12V (Cigarette lighter) </div> </div> <p style="text-align: center;">NT198</p> |
| Manifold gauge set (with hoses and couplers) | <div style="display: flex; justify-content: center; align-items: center;">  <div style="text-align: right;"> <p>Identification:</p> <ul style="list-style-type: none"> ● The gauge face indicates R-134a. <p>Fitting size: Thread size</p> <ul style="list-style-type: none"> ● 1/2"-16 ACME </div> </div> <p style="text-align: center;">NT199</p> |

PREPARATION

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

| Tool number Tool name | Description | |
|---|---|---|
| Service hoses <ul style="list-style-type: none"> ● High side hose ● Low side hose ● Utility hose |  | Hose color: <ul style="list-style-type: none"> ● Low hose: Blue with black stripe ● High hose: Red with black stripe ● Utility hose: Yellow with black stripe or green with black stripe Hose fitting to gauge: <ul style="list-style-type: none"> ● 1/2"-16 ACME |
| Service couplers <ul style="list-style-type: none"> ● High side coupler ● Low side coupler |  | Hose fitting to service hose: <ul style="list-style-type: none"> ● M14 x 1.5 fitting is optional or permanently attached. |
| Refrigerant weight scale |  | For measuring of refrigerant Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME |
| Vacuum pump (Including the isolator valve) |  | Capacity: <ul style="list-style-type: none"> ● Air displacement: 4 CFM ● Micron rating: 20 microns ● Oil capacity: 482 g (17 oz) Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME |

DESCRIPTION

Refrigeration System

REFRIGERATION CYCLE

Refrigerant Flow

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the liquid tank, through the evaporator, and back to the compressor. The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the heater & cooling unit.

NLHA0121

NLHA0121S01

Freeze Protection

The compressor cycles go on and off to maintain the evaporator temperature within a specified range. When the evaporator coil temperature falls below a specified point, the thermo control amplifier interrupts the compressor operation. When the evaporator coil temperature rises above the specification, the thermo control amplifier allows compressor operation.

NLHA0121S02

Refrigerant System Protection

Refrigerant Pressure Sensor

The refrigerant system is protected against excessively high or low pressures by the refrigerant pressure sensor, located on the liquid tank. If the system pressure rises above, or falls below the specifications, the refrigerant pressure sensor detects the pressure inside the refrigerant line and sends the voltage signal to the ECM. ECM makes the A/C relay go OFF and stops the compressor when pressure on the high pressure side detected by refrigerant pressure sensor is over about 2,746 kPa (27.5 bar, 28 kg/cm², 398 psi) or below about 137 kPa (1.37 bar, 1.4 kg/cm², 20 psi).

NLHA0121S03

NLHA0121S0303

Dual-pressure Switch


The refrigerant system is protected against excessively high or low pressures by the dual-pressure switch, located on the liquid tank. If the pressure falls out of specifications, the switch opens to interrupt compressor operation.

NLHA0121S0304

Pressure Relief Valve

The refrigerant system is also protected by a pressure relief valve, located in the rear head of the compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (37.3 bar, 38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.

NLHA0121S0302



RHA682H

DESCRIPTION

CSV613 Variable Displacement Compressor

CSV613 Variable Displacement Compressor

GENERAL INFORMATION

NLHA0206

1. The CSV613 compressor differs from previous units. The vent temperatures of the CSV613 compressor do not drop too far below 5°C (41°F) when:
 - evaporator intake air temperature is less than 20°C (68°F)
 - engine is running at speeds less than 1,500 rpm.This is because the CSV613 compressor provides a means of “capacity” control.
2. The CSV613 compressor provides refrigerant control under varying conditions. During cold winters, it may not produce high refrigerant pressure discharge (compared to previous units) when used with air conditioning systems.
3. A “clanking” sound may occasionally be heard during refrigerant charge. The sound indicates that the tilt angle of the swash plate has changed and is not a problem.
4. For air conditioning systems with the CSV613 compressor, the clutch remains engaged unless: the system main switch, fan switch or ignition switch is turned OFF. When ambient (outside) temperatures are low or when the amount of refrigerant is insufficient, the clutch is disengaged to protect the compressor.
5. A constant range of suction pressure is maintained when engine speed is greater than a certain value. It normally ranges from 147 to 177 kPa (1.47 to 1.77 bar, 1.5 to 1.8 kg/cm², 21 to 26 psi) under varying conditions.
In previous compressors, however, suction pressure was reduced with increases in engine speed.

DESCRIPTION

CSV613 Variable Displacement Compressor (Cont'd)

DESCRIPTION


General

=NLHA0207

NLHA0207S01

The variable compressor is basically a swash plate type that changes piston stroke in response to the required cooling capacity.

The tilt of the swash plate allows the piston's stroke to change so that refrigerant discharge can be continuously changed from 6.0 to 125 cm³ (0.366 to 7.628 cu in).



RHA854H

DESCRIPTION

CSV613 Variable Displacement Compressor (Cont'd)

Operation

1. Operation Control Valve

=NLHA0207S02

Operation control valve is located in the suction port (low-pressure) side, and opens or closes in response to changes in refrigerant suction pressure.

NLHA0207S0201

Operation of the valve controls the internal pressure of the crankcase.

The angle of the swash plate is controlled between the crankcase's internal pressure and the piston cylinder pressure.

2. Maximum Cooling

NLHA0207S0202


Refrigerant pressure on the low-pressure side increases with an increase in heat loads.

When this occurs, the control valve's bellows compress to open the low-pressure side valve and close the high-pressure side valve.

This causes the following pressure changes:

- the crankcase's internal pressure to equal the pressure on the low-pressure side;
- the cylinder's internal pressure to be greater than the crankcase's internal pressure.

Under this condition, the swash plate is set to the maximum stroke position.



RHA473C


DESCRIPTION

CSV613 Variable Displacement Compressor (Cont'd)

3. Capacity Control

=NLHA0207S0203

- Refrigerant pressure on suction side is low during high speed driving or when ambient or interior temperature is low.
- The bellows expands when refrigerant pressure on the suction pressure side drops below approximately 177 kPa (1.77 bar, 1.8 kg/cm², 26 psi).
Since suction pressure is low, it makes the suction port close and the discharge port open. Thus, crankcase pressure becomes high as high pressure enters the crankcase.
- The force acts around the journal pin near the swash plate, and is generated by the pressure difference before and behind the piston.
The drive lug and journal pin are located where the piston generates the highest pressure. Piston pressure is between suction pressure P_s and discharge pressure P_d , which is near suction pressure P_s . If crankcase pressure P_c rises due to capacity control, the force around the journal pin makes the swash plate angle decrease and also the piston stroke decrease. In other words, crankcase pressure increase triggers pressure difference between the piston and the crankcase. The pressure difference changes the angle of the swash plate.




RHA474C

DESCRIPTION

Component Layout

NLHA0122

SEC. 270•271•272•273



This illustration is for LHD models.


NHA367

DESCRIPTION

Control Operation

Control Operation

NLHA0123



NHA370

FAN CONTROL SWITCH

This switch turns the fan ON and OFF, and controls fan speed.

NLHA0123S01

MODE CONTROL KNOB

This knob controls the outlet air flow.

NLHA0123S02

TEMPERATURE CONTROL KNOB

This knob allows you to adjust the temperature of the discharge air.

NLHA0123S03

REAR WINDOW DEFOGGER SWITCH

When illumination is ON, rear window is defogged.

NLHA0123S07

AIR CONDITIONER (A/C) SWITCH

The air conditioner switch controls the A/C system. When the switch is depressed with the fan ON, the compressor will turn ON. The indicator lamp will also light.

NLHA0123S05

The air conditioner cooling function operates only when the engine is running.

RECIRCULATION (REC) SWITCH

Recirculation (REC) position: Interior air is recirculated inside the vehicle. (The indicator lamp will light.)
Fresh (FRE) position: Outlet air is drawn into the passenger compartment.



NLHA0123S08

DESCRIPTION


Discharge Air Flow

Discharge Air Flow


NLHA0124




Ventilation
(Recirculation  position)




D/F



Bi-level
(Fresh  position)



Defrost



- ① : To face
- ② : To foot
- ③ : To defrost

*: LHD models
For air flow %, refer to "Operational Check"
"TROUBLE DIAGNOSES".

NHA371

DESCRIPTION

System Description

System Description SWITCHES AND THEIR CONTROL FUNCTIONS

NLHA0125


NLHA0125S01

| Knob/Switch | Knob/Switch position | | | | | | | | Compressor |
|-------------|----------------------|------|-----|------|-----|-----|-----|-----|------------|
| | A/C | VENT | B/L | FOOT | D/F | DEF | REC | FRE | |
| A/C | ○ | | | | | | | | ON*1 |
| Mode | ☰ | ○ | | | | | | | — |
| | ☷ | | ○ | | | | | | — |
| | ☱ | | | ○ | | | | | — |
| | ☲ | | | | ○ | | | | — |
| | ☵ | | | | | ○ | | | — |
| Intake | ☰ | | | | | | ○ | | — |
| | ☷ | | | | | | | ○ | — |

*1: Compressor is operated by ECM.

MAX HOT DOOR AND REAR FOOT DOOR FUNCTION FOR SCANDINAVIA AND COLD SPEC MODELS

NLHA0125S02



NHA389




Component Location

ENGINE COMPARTMENT


NLHA0126

NLHA0126S01

A/C relay **E9**



Compressor **E25**



Refrigerant pressure sensor
or dual-pressure switch **E50**
E51


NHA372

TROUBLE DIAGNOSES

Component Location (Cont'd)

PASSENGER COMPARTMENT

NLHA0126S02



NHA461

TROUBLE DIAGNOSES




Wiring Diagram — Heater

MODELS WITH ECM IN ENGINE COMPARTMENT

NLHA0202

NLHA0202S04

HA-HEATER-01



REFER TO THE FOLLOWING.
 (M2) , (M3) - FUSE BLOCK-
 JUNCTION BOX (J/B)

TROUBLE DIAGNOSES

Wiring Diagram — Heater (Cont'd)


MODELS WITH ECM IN CABIN

NLHA0202S05

HA-HEATER-01




⬡ : LHD MODELS
⬢ : RHD MODELS

REFER TO EL-POWER.



REFER TO THE FOLLOWING.

Ⓜ3 - FUSE BLOCK-
JUNCTION BOX (J/B)




YHA345

TROUBLE DIAGNOSES


Wiring Diagram — Heater (Cont'd)

HA-HEATER-02



- ◊ L : LHD MODELS
 - ◊ R : RHD MODELS
 - ◊ MH : WITH MAX HOT DOOR MOTOR
 - ◊ OM : WITHOUT MAX HOT DOOR MOTOR
- *1 1: ◊ L
2: ◊ R
- *2 2: ◊ L
1: ◊ R

- HEATER CONTROL PANEL
- ◊ N11 : MH
 - ◊ M62 : OM



REFER TO THE FOLLOWING.
 (M2) - FUSE BLOCK-JUNCTION BOX (J/B)


TROUBLE DIAGNOSES

Circuit Diagram — Air Conditioner

Circuit Diagram — Air Conditioner

NLHA0127

- (G) : Gasoline engine models
- (D) : Diesel engine models
- (MH) : With max hot door motor
- (AC) : With air conditioner
- (DF) : With dealer fitted air conditioner



YHA347

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M —

Wiring Diagram — A/C, M —

MODELS WITH ECM IN ENGINE CABIN
Models with Gasoline Engine




NLHA0128

NLHA0128S03

NLHA0128S0301

HA-A/C, M-01

MH : WITH MAX HOT DOOR MOTOR
OM : WITHOUT MAX HOT DOOR MOTOR




REFER TO THE FOLLOWING.

M3 - FUSE BLOCK- JUNCTION BOX (J/B)


TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-03



- L** : LHD MODELS
 - R** : RHD MODELS
 - MH** : WITH MAX HOT DOOR MOTOR
 - OM** : WITHOUT MAX HOT DOOR MOTOR
- *1** 1: **L**
2: **R**
- *2** 2: **L**
1: **R**
- HEATER CONTROL PANEL
- M34** : **MH**
- M62** : **OM**



REFER TO THE FOLLOWING.
F3 -ELECTRICAL UNITS

YHA326




TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

Models with Diesel Engine

NLHA0128S0302

HA-A/C, M-04



REFER TO THE FOLLOWING.



M3 - FUSE BLOCK-JUNCTION BOX (J/B)

YHA327

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-05



YHA328





TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-06

- L : LHD MODELS
- R : RHD MODELS
- MH : WITH MAX HOT DOOR MOTOR
- OM : WITHOUT MAX HOT DOOR MOTOR

- *1 1: L
- 2: R
- *2 2: L
- 1: R



YHA329

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)



MODELS WITH ECM IN CABIN Models with Gasoline Engine

NLHA0128S04

NLHA0128S0401

HA-A/C, M-01

- ⬡ : LHD MODELS
- ⬢ : RHD MODELS
- ⬤ : WITH MAX HOT DOOR MOTOR
- ⬥ : WITHOUT MAX HOT DOOR MOTOR



REFER TO THE FOLLOWING.



(M3) - FUSE BLOCK-
JUNCTION BOX (J/B)

YHA348

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-02






REFER TO THE FOLLOWING.
 (M2), (E109) - FUSE BLOCK-JUNCTION BOX (J/B)
 (F3) - ELECTRICAL UNITS

YHA349

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-03






REFER TO THE FOLLOWING.
 (F3) -ELECTRICAL UNITS

YHA350

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-04



YHA351



TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

Models with Diesel Engine

NLHA0128S0402

HA-A/C, M-05





REFER TO THE FOLLOWING.
 (M2), (M3), (E109)
 - FUSE BLOCK -
 JUNCTION BOX (J/B)

YHA352

TROUBLE DIAGNOSES

Wiring Diagram — A/C, M — (Cont'd)

HA-A/C, M-06



REFER TO THE FOLLOWING.
(F18) , (F20) -ELECTRICAL UNITS

YHA353


TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair

How to Perform Trouble Diagnoses for Quick and Accurate Repair WORK FLOW

NLHA0129

NLHA0129S01



SHA900E

*1: HA-41

SYMPTOM TABLE

NLHA0129S02

| Symptom | Reference page | |
|--|---|-------|
| ● Intake door does not change. | ● Go to Trouble Diagnosis Procedure for Intake Door. | HA-43 |
| ● Air outlet does not change. | ● Go to Trouble Diagnosis Procedure for mode door. | HA-47 |
| ● Air mix door does not change. | ● Go to Trouble Diagnosis Procedure for Air mix door. | HA-49 |
| ● Max hot door does not change. | ● Go to Trouble Diagnosis Procedure for Max Hot Door. | HA-51 |
| ● Blower motor does not rotate at all. | ● Go to Trouble Diagnosis Procedure for Blower Motor. | HA-55 |
| ● Magnet clutch does not engage when A/C switch and fan switch are ON. | ● Go to Trouble Diagnosis Procedure for Magnet Clutch. | HA-62 |
| ● Insufficient cooling. | ● Go to Trouble Diagnosis Procedure for Insufficient cooling. | HA-75 |
| ● Insufficient heating. | ● Go to Trouble Diagnosis Procedure for Insufficient heating. | HA-83 |
| ● Noise | ● Go to Trouble Diagnosis Procedure for Noise. | HA-84 |

Operational Check

=NLHA0130

The purpose of the operational check is to confirm that the system operates properly.

CONDITIONS:

NLHA0130S01

- Engine running and at normal operating temperature.

PROCEDURE:

NLHA0130S02

1. Check Blower

NLHA0130S0201

1. Turn fan switch to 1-speed.
Blower should operate on 1-speed.
2. Then turn fan switch to 2-speed, and continue checking blower speed until all speeds are checked.
3. Leave blower on 4-speed.

If NG, go to trouble diagnosis procedure for blower motor (HA-55).
If OK, continue with next check.

2. Check Discharge Air

NLHA0130S0202



1. Turn mode control knob to each position.

2. Confirm that discharge air comes out according to the air distribution table at left.

Refer to "Discharge Air Flow", HA-19.

If NG, go to trouble diagnosis procedure for mode door motor (HA-47).

If OK, continue with next check.



Discharge air flow


| Mode door position | Air outlet/distribution | | |
|--------------------|-------------------------|--------------|---------------|
| | Face | Foot | Defroster |
| | 100% | — | — |
| | 60% | 40% | — |
| | — (15%) | 80% (65%) | 20% |
| | — (15%) | 65% (55%) | 35% (30%) |
| | — (15%) | — | 100% (85%) |

() : LHD models face air from SIDE VENT only

NHA376

TROUBLE DIAGNOSES

Operational Check (Cont'd)




3. Check Recirculation

NLHA0130S0203

- 1) Press the Recirculation (REC) switch. Recirculation indicator should illuminate.
- 2) Listen for intake door position change.

If NG, go to trouble diagnosis procedure for intake door (HA-43).
If OK, continue with next check.




4. Check Temperature Decrease

NLHA0130S0204

1. Turn the temperature control knob to full cold.
2. Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient cooling (HA-75).
If OK, continue with next check.




5. Check Temperature Increase

NLHA0130S0205

1. Turn the temperature control knob to full hot.
2. Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient heating (HA-83).



6. Check Air Conditioner Switch

NLHA0130S0206

Turn the fan control switch to the desired (1 to 4 speed) position and push the A/C switch to turn ON the air conditioner.

The indicator lamp should come on when air conditioner is ON.
If NG, go to trouble diagnosis procedure for magnet clutch (HA-62).

TROUBLE DIAGNOSES

Intake Door

Intake Door


TROUBLE DIAGNOSIS PROCEDURE FOR INTAKE DOOR

=NLHA0133

SYMPTOM:

- Intake door does not change.

INSPECTION FLOW



NHA381


*1: HA-41

*2: HA-40

*3: HA-40

TROUBLE DIAGNOSES

Intake Door (Cont'd)



COMPONENT DESCRIPTION

Intake Door Motor

NLHA0209

NLHA0209S01

The intake door motor is attached to the intake unit. It rotates so that air is drawn from inlets set by the heater control panel. Motor rotation is conveyed to a lever which activates the intake door.

DIAGNOSTIC PROCEDURE FOR INTAKE DOOR MOTOR CIRCUIT

NLHA0210







| | |
|--|--|
| 1 | CHECK POWER SUPPLY FOR HEATER CONTROL PANEL |
| Do approx. 12 volts exist between heater control panel harness terminal No. 1 and body ground? | |
| | |
| <p>Models without max hot door Models with max hot door</p> <p>Yes or No</p> | |
| Yes | ▶ GO TO 2. |
| No | ▶ Check 10A (No. 15) fuse at fuse block. Refer to EL-10, "Wiring Diagram — POWER —". |







NHA462

| | |
|-----------------|---|
| 2 | CHECK RECIRCULATION (REC) SWITCH |
| Refer to HA-46. | |
| OK or NG | |
| OK | ▶ GO TO 3. |
| NG | ▶ Replace recirculation (REC) switch. |

TROUBLE DIAGNOSES

Intake Door (Cont'd)

| | | |
|--|--|------------------------------|
| 3 | CHECK GROUND CIRCUIT FOR RECIRCULATION (REC) SWITCH | |
| <p>Check circuit continuity between heater control panel harness terminal No. 5 and body ground.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Heater control panel connector (M62)</p>   <p>Models without max hot door</p> </div> <div style="text-align: center;">  <p>Heater control panel connector (M34) or (N11)</p>   <p>Models with max hot door</p> </div> </div> <p style="text-align: right;">NHA464</p> <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 4. |
| Ng | ▶ | Repair harness or connector. |

| | | |
|---|---|----------------------------|
| 4 | CHECK POWER SUPPLY FOR INTAKE DOOR MOTOR | |
| <p>Do approx. 12 volts exist between intake door motor harness terminal No. 1, 2 and body ground?</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Intake door motor connector (M44)</p>   <p>R/Y</p> </div> <div style="text-align: center;">  <p>Intake door motor connector (M44)</p>   <p>R/B</p> </div> </div> <p style="text-align: right;">NHA401</p> <p style="text-align: center;">Yes or No</p> | | |
| Yes | ▶ | Replace intake door motor. |
| No | ▶ | GO TO 5. |

TROUBLE DIAGNOSES

Intake Door (Cont'd)

| | |
|--|--|
| 5 | CHECK CIRCUIT CONTINUITY BETWEEN HEATER CONTROL PANEL AND INTAKE DOOR MOTOR |
| <p>Check circuit continuity between heater control panel harness terminal No. 10 (11) and intake door motor harness terminal No. 2 (1)</p> | |
| | |
| <p>Continuity should exist. If OK, check harness for short.</p> | |
| OK or NG | |
| OK | ▶ Replace heater control panel. |
| NG | ▶ Repair harness or connector. |

NHA465

NHA466

ELECTRICAL COMPONENT INSPECTION

NLHA0216

Recirculation (REC) Switch

NLHA0216S01

Check continuity between terminals.

| Terminals | REC switch | Continuity |
|-----------|------------|------------|
| 1 - 5 | ON | Yes |
| | OFF | No |

NHA405

Intake Door Motor

NLHA0216S02

Supply 12V direct current to intake door motor terminal No. 1 and 2.

| 12V direct current supply terminals | | Intake door position |
|-------------------------------------|---|----------------------|
| + | - | |
| 1 | 2 | FRE |
| 2 | 1 | REC |

TROUBLE DIAGNOSES

Mode Door

TROUBLE DIAGNOSIS PROCEDURE FOR MODE DOOR


=NLHA0137

SYMPTOM:

- Air outlet does not change.

INSPECTION FLOW

1. Confirm symptom by performing the following operation.



Discharge air flow

| Mode control knob | Air outlet/distribution | | |
|-------------------|-------------------------|--------------|--------------|
| | Face | Foot | Defroster |
| | 100% | — | — |
| | 60% | 40% | — |
| | — (15%) | 80% (65%) | 20% |
| | — (15%) | 65% (55%) | 35% (30%) |
| | — (15%) | — | 100% |

OPERATIONAL CHECK - Mode door

- a. Turn the mode control knob to each position.
- b. Confirm that discharge air comes out according to the distribution table at left.
Refer to "Discharge Air Flow", (*1)

() : LHD models face air from SIDE VENT only

2. Check for any service bulletins.

3. Check mode door control cable. (*3)

OK

4. If the symptom still exists, perform a complete operational check (*2) and check for other symptoms. [Refer to symptom table, (*4).] Does another symptom exist?

Yes → Go to Trouble Diagnosis for related symptom.
[Another symptom exists.]

No

INSPECTION END

NHA382

*1: HA-19



*3: HA-48

*4: HA-40

*2: HA-41

TROUBLE DIAGNOSES

Mode Door (Cont'd)



CONTROL LINKAGE ADJUSTMENT

NLHA0139

Mode Door

NLHA0139S01

1. Turn the mode control knob to VENT position.
2. Move side link by hand and hold mode door in VENT position.
3. Pull on the cable cover in the direction of the arrow, then clamp it.

After positioning control cable, check that it operates properly.

TROUBLE DIAGNOSES

Air Mix Door

TROUBLE DIAGNOSIS PROCEDURE FOR AIR MIX DOOR

=NLHA0140

SYMPTOM:

- Air mix door does not change.

INSPECTION FLOW


1. Confirm symptom by performing the following operational check.

OPERATIONAL CHECK - Temperature decrease and Increase

1. Check Temperature Decrease
 - 1) Turn temperature control lever to full cold.
 - 2) Check for cold air at discharge air outlets.

2. Check Temperature Increase
 - 1) Turn temperature control lever to full hot.
 - 2) Check for hot air at discharge air outlets.

If OK (symptom cannot be duplicated). Perform complete operational check. (*3)
If NG (symptom is confirmed), continue with STEP-2 following.



NHA383



*1: HA-50
*2: HA-41

*3: HA-41

*4: HA-40

TROUBLE DIAGNOSES

Air Mix Door (Cont'd)



CONTROL LINKAGE ADJUSTMENT

Air Mix Door

NLHA0143

NLHA0143S01

1. Turn the temperature control knob to full hot position.
2. Move air mix door lever by hand and hold it at the full hot position.
3. Pull on the cable cover in the direction of the arrow, then clamp it.

After positioning control cable, check that it operates properly.

TROUBLE DIAGNOSES

Max Hot Door (For Scandinavia and Cold Spec Models)

Max Hot Door (For Scandinavia and Cold Spec Models)

TROUBLE DIAGNOSIS FOR MAX HOT DOOR


=NLHA0223

SYMPTOM:

- Max hot door does not change.

INSPECTION FLOW


1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Max hot door operation

1. Check closed position
 - 1) Turn temperature control dial to full cold.
 - 2) Turn mode control dial to VENT, B/L or DEF.
 - 3) Check for cold air at discharge air outlets.
2. Check open position
 - 1) Turn temperature control dial to full hot.
 - 2) Turn mode control dial to FOOT or D/F.
 - 3) Check for hot air at discharge air outlets.

If OK (symptom cannot be duplicated). Perform complete operational check. (*3)
If NG (symptom is confirmed), continue with STEP-2 following.



RHA915H

*1: HA-52


*3: HA-41

*4: HA-40

*2: HA-41

TROUBLE DIAGNOSES

Max Hot Door (For Scandinavia and Cold Spec Models) (Cont'd)



COMPONENT DESCRIPTION

Max Hot Door Motor

NLHA0217

NLHA0217S01

The max hot door motor is attached to the heater & cooling unit.

| Mode door position | Temperature control position | Max hot door position |
|--------------------|------------------------------|-----------------------|
| FOOT, D/F | Full hot | OPEN |
| | All except full hot | SHUT |
| VENT, B/L, DEF | Full hot | SHUT |
| | All except full hot | SHUT |


DIAGNOSTIC PROCEDURE FOR MAX HOT DOOR MOTOR CIRCUIT


NLHA0218

| 1 | CHECK SIGNAL FOR OPEN OPERATION |
|------------------|---|
| | <p>1. Turn ignition switch to ON position.</p> <p>2. Set temperature dial to "FULL COLD" position, and mode control dial to the "DEF (🌀)", "VENT (🌀)" or "BI-LEVEL (🌀)" position.</p> <p>3. Set temperature dial to "FULL HOT" position, and mode control dial to the "FOOT (👤)" or "FOOT/DEF (👤)" position. At this time, does an approx. 12 volts exist between the max hot door motor harness connector terminal 7 and the body ground until the max hot door is fully opened?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA467</p> |
| Yes or No | |
| Yes | <p>▶ GO TO 2.</p> <p>[If max hot door motor does not operate even if approx. 12 volts exist, then replace max hot door motor. (Before replacing the motor, check for smooth operation of the door.)]</p> |
| No | <p>▶ GO TO 3.</p> |

TROUBLE DIAGNOSES

Max Hot Door (For Scandinavia and Cold Spec Models) (Cont'd)

| 2 | CHECK SIGNAL FOR CLOSE OPERATION |
|--|---|
| <p>1. Turn ignition switch to ON position.</p> <p>2. Set temperature dial to "FULL HOT" position, and mode control dial to the "FOOT (👤)" or "FOOT/DEF (👤)" position</p> <p>3. Set temperature dial to "FULL COLD" position, and the mode control dial to the "DEF (👤)", "VENT (👤)" or "BI-LEVEL (👤)" position. At this time, does an approx. 12 volts exist between the max hot door motor harness connector terminal 6 and the body ground until the max hot door is fully closed?</p> | |
|  | |
| NHA468 | |
| Yes or No | |
| Yes | <p>▶ INSPECTION END. (Max hot door motor is OK.)</p> <p>[If max hot door motor does not operate even if approx. 12 volts exist, then replace the max hot door motor. (Before replacing the motor, check for smooth operation of the door.)]</p> |
| No | ▶ GO TO 3. |


| 3 | CHECK SIGNAL CIRCUIT |
|--|--|
| <p>1. Disconnect heater control panel harness connector and max hot door motor harness connector.</p> <p>2. Check for continuity between heater control panel harness connector terminal 19 and max hot door motor harness connector terminal 6, heater control panel harness connector terminal 21 and max hot door motor harness connector terminal 7.</p> | |
|  | |
| NHA469 | |
| <p>Continuity should exist.</p> <p>If OK, check harness for short.</p> | |
| Yes or No | |
| Yes | ▶ GO TO 4. |
| No | ▶ Repair harness or connector. If harness and connector are OK, replace heater control panel. |

TROUBLE DIAGNOSES

Max Hot Door (For Scandinavia and Cold Spec Models) (Cont'd)

| 4 | CHECK SIGNAL FOR POSITION SWITCH | | | | | | | | | | | | | | | | |
|---|---|---|------------|-----------------------|--|--|-----------|---|------------|-------------|-----|-----|----|-------------|----|-----|-----|
| <p>1. Connect the heater control panel harness connector and the max hot door motor harness connector.</p> <p>2. Check the voltage between the heater control panel harness connector terminal 20 and body ground, heater control panel harness connector terminal 22 and body ground as shown in the condition below.</p> | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th rowspan="2">Terminals</th> <th colspan="3">Max hot door position</th> </tr> <tr> <th>Full open</th> <th style="text-align: center;">↔</th> <th>Full close</th> </tr> </thead> <tbody> <tr> <td>20 - Ground</td> <td style="text-align: center;">12V</td> <td style="text-align: center;">12V</td> <td style="text-align: center;">0V</td> </tr> <tr> <td>22 - Ground</td> <td style="text-align: center;">0V</td> <td style="text-align: center;">12V</td> <td style="text-align: center;">12V</td> </tr> </tbody> </table> | | | Terminals | Max hot door position | | | Full open | ↔ | Full close | 20 - Ground | 12V | 12V | 0V | 22 - Ground | 0V | 12V | 12V |
| Terminals | Max hot door position | | | | | | | | | | | | | | | | |
| | Full open | ↔ | Full close | | | | | | | | | | | | | | |
| 20 - Ground | 12V | 12V | 0V | | | | | | | | | | | | | | |
| 22 - Ground | 0V | 12V | 12V | | | | | | | | | | | | | | |
| NHA470 | | | | | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | | | | | |
| OK | ▶ | Position switch (max hot door motor) is OK. | | | | | | | | | | | | | | | |
| NG | ▶ | GO TO 5. | | | | | | | | | | | | | | | |

| 5 | CHECK POSITION SWITCH (BUILT-IN MAX HOT DOOR MOTOR) | | | | | | | | | | | | |
|---|--|--|-----------|-----------------------|--|-----------|-------------|-------|------------------------------|--------------------------|-------|--------------------------|------------------------------|
| <p>Check continuity between max hot door motor terminals 1 and 5, 4 and 5 as shown in the condition below.</p> | | | | | | | | | | | | | |
| | | | | | | | | | | | | | |
| <table border="1" style="margin: auto;"> <thead> <tr> <th rowspan="2">Terminals</th> <th colspan="2">Max hot door position</th> </tr> <tr> <th>Full open</th> <th>Full closed</th> </tr> </thead> <tbody> <tr> <td>1 - 5</td> <td style="text-align: center;">Continuity should not exist.</td> <td style="text-align: center;">Continuity should exist.</td> </tr> <tr> <td>4 - 5</td> <td style="text-align: center;">Continuity should exist.</td> <td style="text-align: center;">Continuity should not exist.</td> </tr> </tbody> </table> | | | Terminals | Max hot door position | | Full open | Full closed | 1 - 5 | Continuity should not exist. | Continuity should exist. | 4 - 5 | Continuity should exist. | Continuity should not exist. |
| Terminals | Max hot door position | | | | | | | | | | | | |
| | Full open | Full closed | | | | | | | | | | | |
| 1 - 5 | Continuity should not exist. | Continuity should exist. | | | | | | | | | | | |
| 4 - 5 | Continuity should exist. | Continuity should not exist. | | | | | | | | | | | |
| NHA471 | | | | | | | | | | | | | |
| OK or NG | | | | | | | | | | | | | |
| OK | ▶ | INSPECTION END. (Position switch is OK.) | | | | | | | | | | | |
| NG | ▶ | <p>Check harness for open or short between:</p> <ul style="list-style-type: none"> ● Heater control panel harness connector terminals 20, 22 and max hot door harness connector terminals 1, 4. ● Max hot door motor harness connector terminal 5 and body ground. | | | | | | | | | | | |



CONTROL LINKAGE ADJUSTMENT

Max Hot Door

1. Install max hot door motor on heater unit. Ensure that the max hot door lever is fitted into the slit portion of max hot door link.
2. Connect the max hot door motor harness connector.
3. Turn ignition switch to "ON" position.
4. Turn the temperature control knob to full hot.
5. Check that max hot door operates properly when the mode control knob is turned to FOOT or D/F, and other positions.

NLHA0219

NLHA0219S01

TROUBLE DIAGNOSES

Blower Motor


TROUBLE DIAGNOSIS PROCEDURE FOR BLOWER MOTOR

=NLHA0145

SYMPTOM:

- Blower motor does not rotate at all.

INSPECTION FLOW



NHA385

*1: HA-56
*2: HA-41

*3: HA-40

*4: HA-41

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

BLOWER MOTOR CIRCUIT

=NLHA0147

SYMPTOM:

- Blower motor does not rotate.

| Symptom table No. | INCIDENT |
|-------------------|---------------------------------|
| 1 | Fan fails to rotate. |
| 2 | Fan does not rotate at 1-speed. |
| 3 | Fan does not rotate at 2-speed. |
| 4 | Fan does not rotate at 3-speed. |
| 5 | Fan does not rotate at 4-speed. |

| 1 | DIAGNOSTIC PROCEDURE | |
|--|----------------------|-----------|
| Check if blower motor rotates properly at each fan speed. Conduct checks as per symptom table at above. | | |
| 1 | ▶ | GO TO 2. |
| 2, 3, 4 | ▶ | GO TO 8. |
| 5 | ▶ | GO TO 10. |

| 2 | CHECK POWER SUPPLY FOR BLOWER MOTOR | |
|--|-------------------------------------|--|
| 1. Disconnect blower motor harness connector. 2. Do approx. 12 volts exist between blower motor harness terminal No. 1 and body ground? | | |
| | | |
| NHA411 | | |
| Yes | ▶ | GO TO 3. |
| No | ▶ | Check 15A (Nos. 14 and 16) fuses at fuse block. Refer to EL-14 , "Wiring Diagram — POWER —". |

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

| | | |
|--|--|--|
| 3 | CHECK CIRCUIT CONTINUITY FOR BLOWER MOTOR | |
| <p>1. Turn fan control knob to any position except OFF. 2. Check circuit continuity between blower motor harness terminal No. 2 and body ground.</p> <div style="text-align: center;"> <p style="text-align: center;">Blower motor connector (M53)</p> </div> <p style="color: blue;">Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 4. |
| NG | ▶ | Reconnect blower motor harness connector. GO TO 5. |

NHA412

| | | |
|---|---------------------------|-----------------------|
| 4 | CHECK BLOWER MOTOR | |
| <p>(Refer to Electrical Components Inspection.) (HA-61)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | INSPECTION END |
| NG | ▶ | Replace blower motor. |

| | | |
|--|---|---|
| 5 | CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND RESISTOR | |
| <p>Do approx. 12 volts exist between fan resistor harness terminal No. 1 and body ground?</p> <div style="text-align: center;"> <p style="text-align: center;">Fan resistor connector (M52)</p> </div> <p style="text-align: center;">Yes or No</p> | | |
| Yes | ▶ | Disconnect fan switch harness connector. GO TO 7. |
| No | ▶ | Disconnect blower motor and resistor harness connectors. GO TO 6. |

NHA413

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

| | | |
|---|---|---|
| 6 | CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND RESISTOR | |
| Check circuit continuity between blower motor harness terminal No. 2 and fan resistor harness terminal No. 1. | | |
| | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">NHA414</p> | | |
| OK or NG | | |
| OK | ▶ | Poor contact between the resistor and blower motor connector. |
| NG | ▶ | Repair harness or connector. |

| | | |
|---|--|------------------------------|
| 7 | CHECK GROUND CIRCUIT FOR HEATER CONTROL PANEL | |
| Check circuit continuity between fan switch harness terminal No. 13 and body ground. | | |
| | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">NHA415</p> | | |
| OK or NG | | |
| OK | ▶ | GO TO 8. |
| NG | ▶ | Repair harness or connector. |

| | | |
|---|--|-------------------|
| 8 | CHECK RESISTOR AFTER DISCONNECTING IT | |
| (Refer to Electrical Components Inspection.) (HA-61) | | |
| OK or NG | | |
| OK | ▶ | GO TO 9. |
| NG | ▶ | Replace resistor. |

| | | |
|---------------------------------------|---|-----------|
| 9 | CHECK RESISTOR HARNESS CONNECTOR | |
| Reconnect resistor harness connector. | | |
| OK or NG | | |
| 1 | ▶ | GO TO 12. |
| 2, 3, 4 | ▶ | GO TO 10. |

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

| | | | |
|---|---------------------------------|-------------|-------------|
| 10 | CHECK FAN SWITCH CIRCUIT | | |
| Do approx. 12 volts exist between each fan switch harness terminal and body ground? | | | |
| | | | |
| Symptom table No. | Terminal No. | | Voltage |
| | (+) | (-) | |
| 2 | 14 | Body ground | Approx. 12V |
| 3 | 15 | | |
| 4 | 16 | | |
| 5 | 17 | | |
| Yes or No | | | |
| Yes | ▶ | GO TO 13. | |
| No | ▶ | GO TO 11. | |

NHA416

| | | |
|---|---|------------------------------|
| 11 | CHECK CIRCUIT CONTINUITY BETWEEN HEATER CONTROL PANEL AND RESISTOR | |
| Check circuit continuity between heater control panel harness terminals and fan resistor harness terminals. | | |
| | | |
| Terminal No. | | Continuity |
| Heater control panel | Resistor | |
| 14 | 4 | Yes |
| 15 | 3 | |
| 16 | 2 | |
| Continuity should exist. | | |
| If OK, check harness for short. | | |
| OK or NG | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair harness or connector. |

NHA417

TROUBLE DIAGNOSES


Blower Motor (Cont'd)

| | | |
|---|---|------------------------------|
| 12 | CHECK CIRCUIT CONTINUITY BETWEEN HEATER CONTROL PANEL AND BLOWER MOTOR | |
| <p>Check circuit continuity between heater control panel harness terminal No. 17 and blower motor harness terminal No. 2.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA418</p> | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Repair harness or connector. |

| | | |
|---|--|---------------------|
| 13 | CHECK FAN SWITCH AFTER DISCONNECTING IT | |
| <p>(Refer to Electrical Components Inspection.) (HA-61)</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | INSPECTION END |
| NG | ▶ | Replace fan switch. |

TROUBLE DIAGNOSES

Blower Motor (Cont'd)



ELECTRICAL COMPONENTS INSPECTION

=NLHA0146

Fan Switch

NLHA0146S01

Check continuity between terminals at each switch position.


| KNOB POSITION | Continuity between terminals |
|---------------|------------------------------|
| OFF | No continuity |
| 1 | 13 — 14 — 18 |
| 2 | 13 — 15 — 18 |
| 3 | 13 — 16 — 18 |
| 4 | 13 — 17 — 18 |

Blower Motor

NLHA0146S02

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.



Blower Resistor

NLHA0146S03

Check resistance between terminals.

| Terminal No. | | Resistance |
|--------------|-----|----------------------|
| (+) | (-) | |
| 4 | 1 | Approx. 2.4 - 2.8Ω |
| 3 | | Approx. 0.58 - 0.7Ω |
| 2 | | Approx. 0.22 - 0.26Ω |

TROUBLE DIAGNOSES

Magnet Clutch

Magnet Clutch


TROUBLE DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

=NLHA0155

SYMPTOM:

- Magnet clutch does not operate when A/C switch and fan switch are ON.

INSPECTION FLOW



NHA387

*1: HA-100

*3: HA-41

*5: EM-17 (QG), EM-166 (YD), EM-86 (SR)

*2: HA-63

*4: HA-40

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

MAGNET CLUTCH CIRCUIT (FOR QG AND SR ENGINE) =NLHA0156

SYMPTOM:

- Magnet clutch does not engage when A/C switch and fan switch are ON.


| | |
|--|--|
| 1 | CHECK POWER SUPPLY FOR COMPRESSOR |
| <p>Disconnect compressor harness connector. Do approx. 12 volts exist between compressor harness terminal No. 1 and body ground?</p> <div style="text-align: center;"> <p>Compressor connector (E32)</p> <p>L/R</p> <p>V</p> <p>0 1 2 3 4</p> <p>A/C</p> </div> <p style="text-align: right;">NHA419</p> <p style="text-align: center;">Yes or No</p> | |
| Yes | ▶ GO TO 2. |
| No | ▶ Disconnect A/C relay. GO TO 3. |

| | |
|-----------------|---|
| 2 | CHECK MAGNET CLUTCH COIL |
| OK or NG | |
| NG | ▶ Replace magnet clutch. Refer to HA-92 |


| | |
|--|--|
| 3 | CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR HARNESS |
| <p>Check circuit continuity between A/C relay harness terminal No. 3 and compressor harness terminal No. 1.</p> <div style="text-align: center;"> <p>Compressor connector (E32)</p> <p>L/R</p> <p>Ω</p> <p>L/R</p> <p>A/C relay connector (E9)</p> <p>3 1</p> </div> <p style="text-align: right;">NHA420</p> <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair harness or connector. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|--|---|---|
| 4 | CHECK POWER SUPPLY FOR A/C RELAY | |
| <p>Disconnect A/C relay. Do approx. 12 volts exist between A/C relay harness terminal Nos. 1, 5 and body ground?</p> | | |
|  | | |
| RHA635H | | |
| Yes or No | | |
| Yes | ▶ | GO TO 5. |
| No | ▶ | Check power supply circuit and 10A (No. 15) fuse at fuse block. Refer to EL-10, "Wiring Diagram — POWER —". |

| | | |
|-----------------|---|-------------------------------|
| 5 | CHECK A/C RELAY AFTER DISCONNECTING IT | |
| Refer to HA-73. | | |
| OK or NG | | |
| OK | ▶ | Reconnect A/C relay. GO TO 6. |
| NG | ▶ | Replace A/C relay. |

| | | |
|--|---|--|
| 6 | CHECK COIL SIDE CIRCUIT OF A/C RELAY | |
| Do approx. 12 volts exist between ECM harness terminal No. 23 and body ground? | | |
|  | | |
| NHA421 | | |
| Yes or No | | |
| Yes | ▶ | GO TO 8. |
| No | ▶ | Disconnect A/C relay. Disconnect ECM harness connector. GO TO 7. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|--|---|--|
| 7 | CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND ECM HARNESS | |
| <p>Check circuit continuity between A/C relay harness terminal No. 2 and ECM harness terminal No. 23.</p> <div style="text-align: center;"> </div> <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">NHA422</p> | | |
| OK or NG | | |
| OK | ▶ | Check ECM. Refer to EC-133 (QG), EC-657 (SR), "ECM Terminals and Reference Value". |
| NG | ▶ | Repair harness or connector. |

| | | |
|---|------------------------------|--|
| 8 | CHECK VOLTAGE FOR ECM | |
| <p>Do approx. 12 volts exist between ECM harness terminal No. 51 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA423</p> | | |
| Yes or No | | |
| Yes | ▶ | GO TO 9. |
| No | ▶ | Check ECM. Refer to EC-133 (QG), EC-657 (SR), "ECM Terminals and Reference Value". |

| | | |
|---|--|--------------------------------------|
| 9 | CHECK REFRIGERANT PRESSURE SENSOR | |
| <p>Refer to HA-74.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 10. |
| NG | ▶ | Replace refrigerant pressure sensor. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| 10 | CHECK POWER SUPPLY FOR HEATER CONTROL PANEL (A/C SWITCH) |
|---|---|
| <p>Do approx. 12 volts exist between heater control panel harness terminal No. 7 and body ground?</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Heater control panel connector (M62)</p> <p>Models without max hot door</p> </div> <div style="text-align: center;"> <p>Heater control panel connector (M34) or (N11)</p> <p>Models with max hot door</p> </div> </div> <p style="text-align: center;">Yes or No</p> | |
| Yes | ▶ GO TO 12. |
| No | ▶ ● For Europe: GO TO 11. |

NHA472

| 11 | CHECK CIRCUIT CONTINUITY BETWEEN HEATER CONTROL PANEL AND ECM |
|--|--|
| <p>Check circuit continuity between heater control panel harness terminal No. 7 and ECM harness terminal No. 44.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Heater control panel connector (M34) or (N11)</p> <p>Models with max hot door</p> </div> <div style="text-align: center;"> <p>Heater control panel connector (M62)</p> <p>Models without max hot door</p> </div> <div style="text-align: center;"> <p>ECM connector (F3)</p> <p>ECM CONNECTOR</p> <p>44</p> </div> </div> <p style="text-align: center;">Continuity should exist.</p> <p style="text-align: center;">If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ Check ECM. Refer to EC-134 (QG), EC-659 (SR), "ECM Terminals and Reference Value". |
| NG | ▶ Repair harness or connector. |

NHA473

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|---|---|------------------------------|
| 12 | CHECK HEATER CONTROL PANEL CIRCUIT | |
| Check circuit continuity between heater control panel harness terminal No. 8 and 18. | | |
| | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Repair harness or connector. |

NHA474

| | | |
|---|--|------------------------------|
| 13 | CHECK CIRCUIT CONTINUITY BETWEEN ECM AND HEATER CONTROL PANEL | |
| Check circuit continuity between ECM harness terminal No. 51 and heater control panel harness terminal No. 18. | | |
| | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Repair harness or connector. |

NHA427

| | | |
|------------------|-------------------------|-------------------------------|
| 14 | CHECK FAN SWITCH | |
| Refer to HA-61. | | |
| Yes or No | | |
| Yes | ▶ | GO TO 15. |
| No | ▶ | Replace heater control panel. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|---|----------------------------------|------------------------------|
| 15 | CHECK BODY GROUND CIRCUIT | |
| <p>Check circuit continuity between heater control panel harness terminal No. 13 and body ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA428</p> | | |
| <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | INSPECTION END |
| NG | ▶ | Repair harness or connector. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

MAGNET CLUTCH CIRCUIT (FOR YD ENGINE)

=NLHA0203

SYMPTOM:

- Magnet clutch does not engage when A/C switch and fan switch are ON.


| | |
|--|--|
| 1 | CHECK POWER SUPPLY FOR COMPRESSOR |
| <p>Disconnect compressor harness connector. Do approx. 12 volts exist between compressor harness terminal No. 1 and body ground?</p> <div style="text-align: center;"> <p>Compressor connector (E32)</p> <p>L/R</p> <p>V</p> <p>A/C</p> <p>Yes or No</p> </div> <p style="text-align: right;">NHA419</p> | |
| Yes | ▶ GO TO 2. |
| No | ▶ Disconnect A/C relay. GO TO 3. |

| | |
|-----------------|---|
| 2 | CHECK MAGNET CLUTCH COIL |
| OK or NG | |
| NG | ▶ Replace magnet clutch. Refer to HA-92 |


| | |
|---|--|
| 3 | CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR HARNESS |
| <p>Check circuit continuity between A/C relay harness terminal No. 3 and compressor harness terminal No. 1.</p> <div style="text-align: center;"> <p>Compressor connector (E32)</p> <p>L/R</p> <p>A/C relay connector (E9)</p> <p>Ω</p> <p>L/R</p> </div> <p style="text-align: right;">NHA420</p> <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | |
| OK | ▶ GO TO 4. |
| NG | ▶ Repair harness or connector. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|--|---|---|
| 4 | CHECK POWER SUPPLY FOR A/C RELAY | |
| <p>Disconnect A/C relay. Do approx. 12 volts exist between A/C relay harness terminal Nos. 1, 5 and body ground?</p> | | |
|  | | |
| RHA635H | | |
| Yes or No | | |
| Yes | ▶ | GO TO 5. |
| No | ▶ | Check power supply circuit and 10A (No. 15) fuse at fuse block. Refer to EL-10, "Wiring Diagram — POWER —". |

| | | |
|-----------------|---|-------------------------------|
| 5 | CHECK A/C RELAY AFTER DISCONNECTING IT | |
| Refer to HA-73. | | |
| OK or NG | | |
| OK | ▶ | Reconnect A/C relay. GO TO 6. |
| NG | ▶ | Replace A/C relay. |

| | | |
|--|---|--|
| 6 | CHECK COIL SIDE CIRCUIT OF A/C RELAY | |
| Do approx. 12 volts exist between ECM harness terminal No. 204 and body ground? | | |
|  | | |
| NHA429 | | |
| Yes or No | | |
| Yes | ▶ | GO TO 8. |
| No | ▶ | Disconnect A/C relay. Disconnect ECM harness connector. GO TO 7. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|---|---|--|
| 7 | CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND ECM HARNESS | |
| <p>Check circuit continuity between A/C relay harness terminal No. 2 and ECM harness terminal No. 204.</p> <div style="text-align: center;"> </div> <p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">NHA430</p> | | |
| OK or NG | | |
| OK | ▶ | Check ECM. Refer to EC-1129 (YD), "ECM Terminals and Reference Value". |
| NG | ▶ | Repair harness or connector. |

| | | |
|--|------------------------------|--|
| 8 | CHECK VOLTAGE FOR ECM | |
| <p>Do approx. 12 volts exist between ECM harness terminal No. 403 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA431</p> | | |
| Yes or No | | |
| Yes | ▶ | GO TO 9. |
| No | ▶ | Check ECM. Refer to EC-1129 (YD), "ECM Terminals and Reference Value". |

| | | |
|---|--|------------------------------|
| 9 | CHECK POWER SUPPLY FOR DUAL-PRESSURE SWITCH | |
| <p>Do approx. 12 volts exist between dual-pressure switch harness terminal No. 2 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">NHA432</p> | | |
| Yes or No | | |
| Yes | ▶ | GO TO 10. |
| No | ▶ | Repair harness or connector. |

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|-----------------|-----------------------------------|-------------------------------|
| 10 | CHECK DUAL-PRESSURE SWITCH | |
| Refer to HA-74. | | |
| OK or NG | | |
| OK | ▶ | GO TO 11. |
| No | ▶ | Replace dual-pressure switch. |

| | | |
|---|--|------------------------------|
| 11 | CHECK CIRCUIT CONTINUITY BETWEEN DUAL-PRESSURE SWITCH AND HEATER CONTROL PANEL (A/C SWITCH) | |
| Check circuit continuity between dual-pressure switch harness terminal No. 1 and heater control panel harness terminal No. 7. | | |
| | | |
| <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 12. |
| NG | ▶ | Repair harness or connector. |


| | | |
|-----------------|-------------------------|---------------------|
| 12 | CHECK A/C SWITCH | |
| Refer to HA-74. | | |
| OK or NG | | |
| OK | ▶ | GO TO 13. |
| NG | ▶ | Replace A/C switch. |

| | | |
|---|---|------------------------------|
| 13 | CHECK HEATER CONTROL PANEL CIRCUIT | |
| Check circuit continuity between heater control panel harness terminal No. 8 and No. 18. | | |
| | | |
| <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> | | |
| OK | ▶ | GO TO 14. |
| NG | ▶ | Repair harness or connector. |


TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

| | | |
|-----------------|-------------------------|---------------------|
| 14 | CHECK FAN SWITCH | |
| Refer to HA-61. | | |
| OK or NG | | |
| OK | ▶ | GO TO 15. |
| NG | ▶ | Replace fan switch. |

| | | |
|---|----------------------------------|------------------------------|
| 15 | CHECK BODY GROUND CIRCUIT | |
| Check circuit continuity between heater control panel harness terminal No. 13 and body ground. | | |
|  <p style="text-align: center;">Heater control panel connector (M35)</p> | | |
| <p style="color: blue;">Continuity should exist.</p> <p>If OK, check harness for short.</p> | | |
| OK or NG | | |
| OK | ▶ | INSPECTION END. |
| NG | ▶ | Repair harness or connector. |

NHA428



ELECTRICAL COMPONENT INSPECTION A/C Relay

NLHA0192

NLHA0192S01


Check continuity between terminal Nos. 3 and 5.

| Conditions | Continuity |
|---|------------|
| 12V direct current supply between terminal Nos. 1 and 2 | Yes |
| No current supply | No |

If NG, replace relay.

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)





Refrigerant Pressure Sensor

NLHA0192S02

Make sure that the A/C refrigerant pressure and the sensor output voltage are within the specified range as shown in the A/C operating condition figure.


Check voltage between ECM harness terminal No. 74 and body ground.



Dual-pressure Switch

NLHA0192S03

| | ON kPa (bar, kg/cm ² , psi) | OFF kPa (bar, kg/cm ² , psi) |
|--------------------|---|---|
| Low-pressure side | Increasing to 157 - 216 (1.57 - 2.16, 1.6 - 2.2, 23 - 31) | Decreasing to 157 - 196 (1.57 - 1.96, 1.6 - 2.0, 23 - 28) |
| High-pressure side | Decreasing to 1,863 - 2,256 (18.6 - 22.6, 19 - 23, 270 - 327) | Increasing to 2,452 - 2,844 (24.5 - 28.4, 25 - 29, 356 - 412) |



A/C Switch

NLHA0192S04

Check continuity between terminals.

| A/C switch | Terminals | Continuity |
|------------|-----------|------------|
| ON | 1 - 7 | Yes |
| | 1 - 8 | |
| OFF | 1 - 7 | No |
| | 1 - 8 | |

TROUBLE DIAGNOSES

Insufficient Cooling

Insufficient Cooling


TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

=NLHA0148

SYMPTOM:

- Insufficient Cooling.

INSPECTION FLOW



NHA390

- *1: HA-49
- *2: HA-79
- *3: HA-76

- *4: HA-41
- *5: HA-40
- *6: HA-90


- *7: EM-17 (QG), EM-86 (SR), EM-166 (YD)
- *8: EC-373 (QG), EC-882 (SR), EC-1202 (YD)

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

PERFORMANCE TEST DIAGNOSES

NLHA0149



*1: HA-78
*2: HA-78


*3: HA-79

*4: HA-50

SHA419F

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)



SHA361FA

*1: —

*2: HA-55

*3: EM-17 (QG), EM-86 (SR), EM-166 (YD)

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

PERFORMANCE CHART

=NLHA0150

Test Condition

NLHA0150S01

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well-ventilated place)
 Doors: Closed
 Door window: Open
 Hood: Open
 TEMP.: Max. COLD
 Discharge Air: Face Vent
 REC switch: (Recirculation) set
 FAN speed: High speed
 Engine speed: Idle speed
 Operate the air conditioning system for 10 minutes before taking measurements.

Test Reading

NLHA0150S02

Recirculating-to-discharge Air Temperature Table

NLHA0150S0201

| Inside air (Recirculating air) at blower assembly inlet | | Discharge air temperature at center ventiator °C (°F) |
|---|----------------------------|--|
| Relative humidity % | Air temperature °C (°F) | |
| 50 - 60 | 20 (68) | 6.0 - 8.8 (43 - 48) |
| | 25 (77) | 9.5 - 12.8 (49 - 55) |
| | 30 (86) | 14.1 - 17.7 (57 - 64) |
| 60 - 70 | 20 (68) | 8.8 - 11.6 (48 - 53) |
| | 25 (77) | 12.8 - 16.2 (55 - 61) |
| | 30 (86) | 17.7 - 21.1 (64 - 70) |

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

Ambient Air Temperature-to-operating Pressure Table

=NLHA0150S0202

| Ambient air | | High-pressure (Discharge side) kPa (bar, kg/cm ² , psi) | Low-pressure (Suction side) kPa (bar, kg/cm ² , psi) |
|------------------------|----------------------------|---|--|
| Relative humidity % | Air temperature °C (°F) | | |
| 50 - 70 | 20 (68) | 659 - 805 (6.590 - 8.052, 6.72 - 8.21, 95.6 - 116.7) | 171 - 214 (1.706 - 213.8, 1.74 - 2.18, 24.7 - 31.0) |
| | 25 (77) | 799 - 980 (7.993 - 9.797, 8.15 - 9.99, 115.9 - 142.1) | 185 - 220 (1.854 - 2.197, 1.89 - 2.24, 26.9 - 31.9) |
| | 30 (86) | 953 - 1,170 (9.532 - 11.700, 9.72 - 11.93, 138.2 - 169.6) | 199 - 240 (1.991 - 2.403, 2.03 - 2.45, 2.89 - 34.8) |
| | 35 (95) | 1,121 - 1,363 (11.209 - 13.632, 11.43 - 13.90, 162.5 - 197.7) | 228 - 282 (2.275 - 2.824, 2.32 - 2.88, 33.0 - 41.0) |
| | 40 (104) | 1,298 - 1,584 (12.984 - 15.838, 13.24 - 16.15, 188.3 - 229.7) | 273 - 333 (2.726 - 3.334, 2.78 - 34.0, 39.5 - 48.3) |

TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE

NLHA0151


Whenever system's high and/or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-79 ("Ambient air temperature-to-operating pressure table").

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)


Both High and Low-pressure Sides are Too High.

NLHA0151S01

| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|--|---|--|--|
| <p>Both high and low-pressure sides are too high.</p> <p>A</p>  <p style="text-align: right;">AC359A</p> | <ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. | <p>Excessive refrigerant charge in refrigeration cycle</p> | <p>Reduce refrigerant until specified pressure is obtained.</p> |
| | <p>Air suction by cooling fan is insufficient.</p> | <p>Insufficient condenser cooling performance</p> <p style="text-align: center;">↓</p> <ol style="list-style-type: none"> Condenser fins are clogged. Improper fan rotation of cooling fan | <ul style="list-style-type: none"> Clean condenser. Check and repair cooling fan as necessary. |
| | <ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2.0 bar, 2 kg/cm², 28 psi). It then decreases gradually thereafter. | <p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p style="text-align: center;">↓</p> <p>Air in refrigeration cycle</p> | <p>Evacuate repeatedly and recharge system.</p> |
| | <p>Engine tends to overheat.</p> | <p>Engine cooling systems malfunction.</p> | <p>Check and repair each engine cooling system.</p> |
| | <ul style="list-style-type: none"> An area of the low-pressure pipe is colder than areas near the evaporator outlet. Plates are sometimes covered with frost. | <ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. <p style="text-align: center;">↓</p> <ol style="list-style-type: none"> Improper thermal valve installation Improper expansion valve adjustment | <p>Replace expansion valve.</p> |

High-pressure Side is Too High and Low-pressure Side is Too Low.

NLHA0151S02


| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|--|--|---|---|
| <p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p style="text-align: right;">AC360A</p> | <p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p> | <p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p> | <ul style="list-style-type: none"> Check and repair or replace malfunctioning parts. Check lubricant for contamination. |

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)


High-pressure Side is Too Low and Low-pressure Side is Too High.

NLHA0151S03

| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|--|---|--|---------------------|
| High-pressure side is too low and low-pressure side is too high. C  | High and low-pressure sides become equal soon after compressor operation stops. | Compressor pressure operation is improper. ↓ Damaged inside compressor packings | Replace compressor. |
| | No temperature difference between high and low-pressure sides | Compressor pressure operation is improper. ↓ Damaged inside compressor packings. | Replace compressor. |

Both High- and Low-pressure Sides are Too Low.

NLHA0151S04


| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|---|--|---|---|
| Both high- and low-pressure sides are too low. D  | <ul style="list-style-type: none"> There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. | Liquid tank inside is slightly clogged. | <ul style="list-style-type: none"> Replace liquid tank. Check lubricant for contamination. |
| | <ul style="list-style-type: none"> Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high-pressure side | High-pressure pipe located between receiver drier and expansion valve is clogged. | <ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination. |
| | <ul style="list-style-type: none"> Expansion valve and liquid tank are warm or only cool when touched. | Low refrigerant charge ↓ Leaking fittings or components | Check refrigerant for leaks. Refer to "Checking Refrigerant Leaks", HA-100. |
| | There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted. | Expansion valve closes a little compared with the specification. ↓ 1. Improper expansion valve adjustment 2. Malfunctioning thermal valve 3. Outlet and inlet may be clogged. | <ul style="list-style-type: none"> Remove foreign particles by using compressed air. Check lubricant for contamination. |
| | An area of the low-pressure pipe is colder than areas near the evaporator outlet. | Low-pressure pipe is clogged or crushed. | <ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination. |
| | Air flow volume is not enough or is too low. | Evaporator is frozen. | <ul style="list-style-type: none"> Check thermo control amp. operation. Replace compressor. |
| | | | |

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)


Low-pressure Side Sometimes Becomes Negative.

NLHA0151S05

| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|---|--|--|--|
| <p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p style="text-align: right;">AC354A</p> | <ul style="list-style-type: none"> • Air conditioning system does not function and does not cyclically cool the compartment air. • The system constantly functions for a certain period of time after compressor is stopped and restarted. | <p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p> | <ul style="list-style-type: none"> • Drain water from refrigerant or replace refrigerant. • Replace liquid tank. |

Low-pressure Side Becomes Negative.

NLHA0151S06

| Gauge indication | Refrigerant cycle | Probable cause | Corrective action |
|--|--|---|---|
| <p>Low-pressure side becomes negative.</p> <p>F</p>  <p style="text-align: right;">AC362A</p> | <p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p> | <p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p> | <p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> • If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. • If due to foreign particles, remove expansion valve and remove particles with dry and compressed air (not shop air). • If either of the above methods cannot correct the problem, replace expansion valve. • Replace liquid tank. • Check lubricant for contamination. |

TROUBLE DIAGNOSES

Insufficient Heating


Insufficient Heating

TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT HEATING

=NLHA0152

SYMPTOM: Insufficient heating.

INSPECTION FLOW



*1: LC-19 (QG), LC-38 (SR),
LC-59 (YD)

*3: LC-15 (QG), LC-35 (SR),
LC-57 (YD)

*5: HA-40

*2: LC-12 (QG), LC-32 (SR),
LC-54 (YD)

*4: LC-20 (QG), LC-38,
LC-60

NHA391

TROUBLE DIAGNOSES

Noise

Noise


TROUBLE DIAGNOSIS PROCEDURE FOR NOISE

=NLHA0158

SYMPTOM:

- Noise

INSPECTION FLOW



NHA395

- *1: —
- *2: —
- *3: HA-87

- *4: EM-17 (QG), EM-86 (SR), EM-166 (YD)

- *5: LC-19 (QG), LC-38 (SR), LC-59 (YD)

SERVICE PROCEDURE

HFC-134a (R-134a) Service Procedure

HFC-134a (R-134a) Service Procedure

NLHA0159

SETTING OF SERVICE TOOLS AND EQUIPMENT


NLHA0159S01

Discharging Refrigerant

NLHA0159S0101


WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from A/C system using certified service equipment meeting requirements of HFC-134a (R-134a) recycling equipment or HFC-134a (R-134a) recovery equipment. If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.



Evacuating System and Charging Refrigerant


NLHA0159S0102



SERVICE PROCEDURE

HFC-134a (R-134a) Service Procedure (Cont'd)

Recovered lubricant. Refer to "CHECKING AND ADJUSTING", *1.



Note: 1 Before charging refrigerant, ensure engine is off.
 Note: 2 Before checking for leaks, start engine to activate air conditioning system then turn engine off. Service valve caps must be installed to prevent leakage.

*1: HA-87
 *2: HA-100

*3: HA-101

*4: HA-76

SHA383F

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor

Maintenance of Lubricant Quantity in Compressor

NLHA0160

The lubricant in the compressor circulates through the system with the refrigerant. Add lubricant to compressor when replacing any component or after a large gas leakage occurred. It is important to maintain the specified amount.

If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)

LUBRICANT

NLHA0160S01

Name: Nissan A/C System Oil Type S for CSV613 compressor
Part number: KLH00-PAGS0

CHECKING AND ADJUSTING

NLHA0160S02

Adjust the lubricant quantity according to the test group shown below.

| | | |
|--|-----------------------------------|----------|
| 1 | LUBRICANT RETURN OPERATION | |
| Can lubricant return operation be performed? | | |
| <ul style="list-style-type: none"> ● A/C system works properly. ● There is no evidence of a large amount of lubricant leakage. | | |
| Yes or No | | |
| Yes | ▶ | GO TO 2. |
| No | ▶ | GO TO 3. |

| | | |
|--|--|----------|
| 2 | PERFORM LUBRICANT RETURN OPERATION, PROCEEDING AS FOLLOWS | |
| 1. Start engine, and set the following conditions: <ul style="list-style-type: none"> ● Test condition Engine speed: Idling to 1,200 rpm A/C or AUTO switch: ON Blower speed: Max. position Temp. control: Optional [Set so that intake air temperature is 25 to 30°C (77 to 86°F).] | | |
| 2. Perform lubricant return operation for about 10 minutes. | | |
| 3. Stop engine. | | |
| CAUTION: | | |
| If excessive lubricant leakage is noted, do not perform the lubricant return operation. | | |
| ▶ | | GO TO 3. |

| | | |
|------------------------------------|-------------------------|--------------|
| 3 | CHECK COMPRESSOR | |
| Should the compressor be replaced? | | |
| Yes or No | | |
| Yes | ▶ | GO TO HA-89. |
| No | ▶ | GO TO 4. |

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)

| | | |
|---|-----------------------|-------------------------------------|
| 4 | CHECK ANY PART | |
| Is there any part to be replaced? (Evaporator, condenser, liquid tank or in case there is evidence of a large amount of lubricant leakage.) | | |
| Yes or No | | |
| Yes | ▶ | GO TO HA-89. |
| No | ▶ | Carry out the A/C performance test. |

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)

Lubricant Adjusting Procedure for Components Replacement Except Compressor

—NLHA0160S0201

After replacing any of the following major components, add the correct amount of lubricant to the system.

Amount of lubricant to be added

| Part replaced | Lubricant to be added to system | Remarks |
|-----------------------------|---------------------------------------|---------------------------------------|
| | Amount of lubricant mℓ (Imp fl oz) | |
| Evaporator | 75 (2.6) | — |
| Condenser | 75 (2.6) | — |
| Liquid tank | 5 (0.2) | Add if compressor is not replaced. *1 |
| In case of refrigerant leak | 30 (1.1) | Large leak |
| | — | Small leak *2 |

*1: If compressor is replaced, addition of lubricant is included in the table.

*2: If refrigerant leak is small, no addition of lubricant is needed.

Lubricant Adjustment Procedure for Compressor Replacement


—NLHA0160S0202

1. Discharge refrigerant into the refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
2. Drain the lubricant from the “old” (removed) compressor into a graduated container and recover the amount of lubricant drained.
3. Drain the lubricant from the “new” compressor into a separate, clean container.
4. Measure an amount of new lubricant installed equal to amount drained from “old” compressor. Add this lubricant to “new” compressor through the suction port opening.
5. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to “new” compressor through the suction port opening.
6. If the liquid tank also needs to be replaced, add an additional 5 mℓ (0.2 Imp fl oz) of lubricant at this time.

Do not add this 5 mℓ (0.2 Imp fl oz) of lubricant if only replacing the compressor.


SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)



Compressor REMOVAL AND INSTALLATION


NLHA0161



SERVICE PROCEDURE


Compressor (Cont'd)

YD engine models



NHA393

SR engine models SEC. 274-275





NHA394

SERVICE PROCEDURE

Compressor Clutch — CSV613 (CALSONIC make)

Compressor Clutch — CSV613 (CALSONIC make) OVERHAUL


=NLHA0211



REMOVAL


- When removing center bolt, hold clutch disc with clutch disc wrench.

NLHA0212




SERVICE PROCEDURE


Compressor Clutch — CSV613 (CALSONIC make) (Cont'd)




- Remove the clutch disc using the clutch disc puller. Insert the holder's three pins into the holes in the clutch disc. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the clutch disc. After removing the clutch disc, remove the shims from either the drive shaft or the clutch disc.




- Remove the snap ring using external snap ring pliers.



- Pulley removal
Position the center pulley puller on the end of the drive shaft, and remove the pulley assembly using any commercially available pulley puller.
To prevent the pulley groove from being deformed, the puller claws should be positioned onto the edge of the pulley assembly.




- Remove the connector from the connector bracket.



- Remove the snap ring using external snap ring pliers.

SERVICE PROCEDURE

Compressor Clutch — CSV613 (CALSONIC make) (Cont'd)



INSPECTION

Clutch Disc

NLHA0213

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

NLHA0213S01

Pulley


NLHA0213S02

Check the appearance of the pulley assembly. If the contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil

NLHA0213S03


Check coil for loose connection or cracked insulation.




INSTALLATION

NLHA0214

- Install the field coil.
Be sure to align the coil's pin with the hole in the compressor's front head.
- Install the field coil harness clip using a screwdriver.




- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.




- Install the clutch disc on the drive shaft, together with the original shim(s). Press the clutch disc down by hand.

SERVICE PROCEDURE

Compressor Clutch — CSV613 (CALSONIC make) (Cont'd)



- Using the holder to prevent clutch disc rotation, tighten the bolt to 14 N·m (1.4 kg·m, 10 ft·lb) torque.
After tightening the bolt, check that the pulley rotates smoothly.



- Check clearance around the entire periphery of clutch disc.
Disc-to-pulley clearance:
0.3 - 0.6 mm (0.012 - 0.024 in)
If the specified clearance is not obtained, replace adjusting spacer and readjust.


Break-in Operation

NLHA0214S01

When replacing compressor clutch assembly, always carry out the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.

Heater & Cooling Unit (Heater Core) REMOVAL

NLHA0193



SERVICE PROCEDURE

Heater & Cooling Unit (Heater Core) (Cont'd)


1. Drain the cooling system. Refer to LC-19 (QG), LC-38 (SR), LC-59 (YD), "Changing Engine Coolant".
2. Discharge the A/C system. Refer to HA-85.
3. Disconnect the two heater hoses from inside the engine compartment.
4. Remove the blower unit. Refer to HA-97.
5. Remove the steering member assembly. Refer to BT-22, "Instrument Panel Assembly".
6. Remove the heater unit.
7. Separate the heater & cooling unit case, and remove the heater core.

INSTALLATION

Install in the reverse order of removal.

NLHA0194

When filling radiator with coolant, refer to LC-20 (QG), LC-38 (SR), LC-60 (YD), "Refilling Engine Coolant".
Recharge the A/C system. Refer to HA-85.




A/C Evaporator

REMOVAL

NLHA0204

1. Discharge the A/C system. Refer to HA-85.
2. Disconnect the two refrigerant lines from the engine compartment.
Cap the A/C lines to prevent moisture from entering the system.
3. Remove the grommet cover, grommet and expansion valve cover from the engine compartment.
4. Remove the glove box, instrument lower assist panel and instrument lower cover. Refer to BT-22.
5. Remove the five screws fixed heater & cooling unit lower cover.
6. Slide the A/C evaporator to rear side.
7. Slide the heater & cooling unit lower cover to rear side and then remove it.
8. Slide the A/C evaporator to the front side and then remove the A/C evaporator.



INSTALLATION


Install in the reverse order of removal.

NLHA0205

Recharge the A/C system. Refer to HA-85.

Blower Unit REMOVAL

NLHA0195



1. Remove the instrument panel assembly. Refer to BT-22, "Instrument Panel Assembly".
2. Disconnect the blower motor and resistor connector.
3. Remove blower unit.

INSTALLATION

Install in the reverse order of removal.

NLHA0196

SERVICE PROCEDURE

Refrigerant Lines


REMOVAL AND INSTALLATION

=NLHA0167

- Refer to page HA-3 reading "Precautions for Refrigerant Connection".

SEC. 271•274 LHD MODELS WITH QG & SR ENGINES

The heater & cooling unit layout for RHD models is symmetrically opposite.




NHA397

SERVICE PROCEDURE

SEC. 271-274

LHD MODELS WITH YD ENGINE

The heater & cooling unit layout for RHD models is symmetrically opposite.



NHA396

- Refer to page HA-3 regarding "Precautions for Refrigerant Connection".

SERVICE PROCEDURE

Refrigerant Lines (Cont'd)


CHECKING REFRIGERANT LEAKS

=NLHA0168

Preliminary Check

NLHA0168S01

Perform a visual inspection of all refrigeration parts, fittings, hoses, and components for signs of A/C lubricant leakage, damage and corrosion. Take note of the areas with A/C lubricant leakage to allow extra time in these areas with electronic leak detector.




Precautions for Handling Leak Detector

NLHA0168S02


When performing a refrigerant leak check, use an A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.

The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.

Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean. Clean with a dry cloth or blow off with shop air. Do not allow the sensor tip of the detector to contact with any substance. This can also cause false readings and may damage the detector.




1. Position probe approximately 5 mm (3/16 in) away from point to be checked.



2. When testing, circle each fitting completely with probe.

SERVICE PROCEDURE

Refrigerant Lines (Cont'd)



3. Move probe along component approximately 25 to 50 mm (1 to 2 in)/sec.

Checking Procedure

NLHA0168S03
To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals, or cigarette smoke in the vicinity of the vehicle. Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

1. Turn engine off.
2. Connect a suitable A/C manifold gauge set to the A/C service ports.
3. Check if the A/C refrigerant pressure is at least 345.2 kPa (3.45 bar, 3.52 kg/cm², 50.1 psi) above 16°C (61°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

NOTE:

At temperatures below 16°C (61°F), leaks may not be detected since the system may not reach 345.2 kPa (3.45 bar, 3.52 kg/cm², 50.1 psi).

4. Conduct the leak test from the high side (compressor discharge **a** to evaporator inlet **g**) to the low side (evaporator drain hose **h** to shaft seal **k**). Refer to HA-98. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector probe completely around the connection/component.

- **Compressor**
Check the fitting of high and low pressure hoses, relief valve and shaft seal.
- **Liquid tank**
Check the pressure switch, refrigerant pressure sensor, tube fitting, weld seams and the fusible plug mount.
- **Service valves**
Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

NOTE:


After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

- **Cooling unit (Evaporator)**
With engine OFF, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose. Keep the probe inserted for at least ten seconds. Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

SERVICE PROCEDURE

Refrigerant Lines (Cont'd)

5. If a leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components. If no leaks are found, perform steps 7 - 10.
7. Start engine.
8. Set the heater A/C control as follows:
 - 1) A/C switch ON.
 - 2) Face mode
 - 3) Recirculation position
 - 4) Max cold temperature
 - 5) Fan speed high
9. Run engine at 1,500 rpm for at least 2 minutes.
10. Turn engine off and perform leak check again following steps 4 through 6 above.



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high pressure side will gradually drop after refrigerant circulation stops and pressure on the low pressure side will gradually rise, as shown in the graph. Some leaks are more easily detected when pressure is high.

11. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
12. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
13. Conduct A/C performance test to ensure system works properly.

Belt

TENSION ADJUSTMENT

- Refer to EM-17 (QG), EM-86 (SR), EM-166 (YD), ^{NLHA0169}“Checking Drive Belt”.

SERVICE PROCEDURE


Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve

INSPECTION

- Refer to EC-466 (QG), EC-996 (SR) “System Description”.

NLHA0199




Ventilation Air Filter

FUNCTION

Air inside passenger compartment is kept clean at either recirculation or fresh mode by installing ventilation air filter into cooling unit.

NLHA0171




REPLACEMENT TIMING

Replace ventilation air filter.

Refer to MA-9, “PERIODIC MAINTENANCE”.

Caution label is fixed inside the glove box.

NLHA0172



REPLACEMENT PROCEDURE

- Remove glove box.
- Remove filter cover.
- Take out the ventilation air filter from blower unit.
- Replace with new one and reinstall on blower unit.
- Reinstall glove box.

NLHA0173

SERVICE DATA AND SPECIFICATIONS (SDS)

Manual

Manual

COMPRESSOR

NLHA0174

| | |
|---|---|
| Model | CALSONIC make CSV613 |
| Type | Swash plate (Variable displacement) |
| Displacement cm ³ (cu in)/rev. | 6.0 - 125 (0.37 - 7.63) |
| Direction of rotation | Clockwise (viewed from drive end) |
| Drive belt | SR-QG engine model: Poly V YD engine model: Type A |

LUBRICANT

NLHA0175

| | | |
|----------------------------|---|-----------|
| Model | CALSONIC make CSV613 | |
| Name | Nissan A/C System Oil Type S | |
| Part number | KLH00-PAGS0 | |
| Capacity mℓ (Imp fl oz) | Total in system | 200 (7.0) |
| | Compressor (Service part) charging amount | 200 (7.0) |

REFRIGERANT

NLHA0176

| | |
|------------------|---------------------------|
| Type | HFC-134a (R-134a) |
| Capacity kg (lb) | 0.45 - 0.55 (0.99 - 1.21) |

ENGINE IDLING SPEED (WHEN A/C IS ON)

NLHA0177

- Refer to EC-547 (QG), EC-1062 (SR) EC-1305 (YD), "Idle Speed and Ignition Timing".

BELT TENSION

NLHA0178

- Refer to EM-17 (QG), EM-86 (SR) EM-166 (YD), "Checking Drive Belts".