

SECTION **EL**

CONTENTS

PRECAUTIONS	2	System Description.....	43
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....	2	Wiring Diagram — F/FOG —	44
Wiring Diagrams and Trouble Diagnosis.....	2	Aiming Adjustment.....	45
HARNESS CONNECTOR	3	TURN SIGNAL AND HAZARD WARNING LAMPS	46
Description	3	System Description.....	46
STANDARDIZED RELAY	5	Wiring Diagram — TURN —	48
Description	5	Trouble Diagnoses.....	50
POWER SUPPLY ROUTING	7	Electrical Components Inspection	50
Schematic	7	ILLUMINATION	51
Wiring Diagram — POWER —	8	System Description.....	51
Inspection.....	15	Schematic	52
GROUND	16	Wiring Diagram — ILL —	53
Ground Distribution.....	16	INTERIOR ROOM LAMP	56
COMBINATION SWITCH	25	System Description.....	56
Check.....	25	Wiring Diagram — ROOM/L —	58
Replacement.....	26	VANITY MIRROR AND TRUNK ROOM LAMPS	60
STEERING SWITCH	27	System Description.....	60
Check.....	27	Wiring Diagram — INT/L —	61
HEADLAMP (FOR USA)	28	METERS AND GAUGES	62
System Description.....	28	Component Parts and Harness Connector	
Wiring Diagram — H/LAMP —	29	Location	62
Trouble Diagnoses.....	30	System Description.....	62
Bulb Replacement	31	Combination Meter	64
Aiming Adjustment.....	31	Wiring Diagram — METER —	65
HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —	33	Meter/Gauge Operation and Odo/Trip Meter	
System Description.....	33	Segment Check in Diagnosis Mode.....	66
Wiring Diagram — DTRL —	35	Flexible Print Circuit (FPC).....	67
Trouble Diagnoses.....	37	Trouble Diagnoses.....	68
Bulb Replacement	38	Electrical Components Inspection	73
Aiming Adjustment.....	38	WARNING LAMPS	75
PARKING, LICENSE AND TAIL LAMPS	39	Schematic	75
Wiring Diagram — TAIL/L —	39	Wiring Diagram — WARN —	76
STOP LAMP	41	Electrical Components Inspection	80
Wiring Diagram — STOP/L —	41	A/T INDICATOR	81
BACK-UP LAMP	42	Wiring Diagram — AT/IND —	81
Wiring Diagram — BACK/L —	42	WARNING CHIME	82
FRONT FOG LAMP	43	Component Parts and Harness Connector	
		Location	82
		System Description.....	82

CONTENTS (Cont'd)

Wiring Diagram — CHIME —.....	84	Schematic.....	137
Trouble Diagnoses.....	85	Wiring Diagram — WINDOW —	138
FRONT WIPER AND WASHER	88	Trouble Diagnoses.....	141
System Description.....	88	POWER DOOR LOCK	142
Wiring Diagram — WIPER —	90	Component Parts and Harness Connector	
Removal and Installation	91	Location	142
Washer Nozzle Adjustment	92	System Description.....	142
Washer Tube Layout	92	Schematic	143
HORN	93	Wiring Diagram — D/LOCK —.....	144
Wiring Diagram — HORN —.....	93	Trouble Diagnoses.....	147
CIGARETTE LIGHTER	94	MULTI-REMOTE CONTROL SYSTEM	154
Wiring Diagram — CIGAR —.....	94	Component Parts and Harness Connector	
REAR WINDOW DEFOGGER	95	Location	154
Component Parts and Harness Connector		System Description.....	154
Location	95	Wiring Diagram — MULTI —.....	156
System Description.....	95	Trouble Diagnoses.....	158
Wiring Diagram — DEF —.....	97	ID Code Entry Procedure	166
Trouble Diagnoses.....	98	Remote Controller Battery Replacement.....	167
Electrical Components Inspection	99	THEFT WARNING SYSTEM	168
Filament Check.....	100	Component Parts and Harness Connector	
Filament Repair	100	Location	168
AUDIO	102	System Description.....	169
System Description.....	102	Schematic	172
Wiring Diagram — AUDIO —.....	103	Wiring Diagram — THEFT —.....	173
Trouble Diagnoses.....	105	Trouble Diagnoses.....	177
Inspection.....	106	SMART ENTRANCE CONTROL UNIT	190
AUDIO ANTENNA	107	Description	190
System Description.....	107	Schematic	192
Wiring Diagram — P/ANT —.....	108	Smart Entrance Control Unit Inspection Table	194
Trouble Diagnoses.....	109	INTEGRATED HOMELINK TRANSMITTER	195
Location of Antenna.....	109	Wiring Diagram — TRNSMT —	195
Antenna Rod Replacement	109	Trouble Diagnoses.....	196
POWER SUNROOF	111	ELECTRICAL UNITS LOCATION	197
Wiring Diagram — SROOF —	111	Engine Compartment.....	197
DOOR MIRROR	112	Passenger Compartment.....	198
Wiring Diagram — MIRROR —.....	112	HARNESS LAYOUT	200
POWER SEAT	113	How to Read Harness Layout.....	200
Wiring Diagram — SEAT —	113	Outline.....	201
HEATED SEAT	114	Main Harness.....	202
Wiring Diagram — HSEAT —.....	114	Engine Room Harness	204
AUTOMATIC SPEED CONTROL DEVICE (ASCD) ... 115		Engine Control Harness	207
Component Parts and Harness Connector		Body Harness	208
Location	115	Body No. 2 Harness	209
System Description.....	116	Tail & Tail No. 2 Harness.....	210
Schematic	118	Engine Harness	211
Wiring Diagram — ASCD —	119	Room Lamp Harness.....	212
Fail-safe System.....	123	Air Bag Harness	213
Trouble Diagnoses.....	124	Front Door Harness.....	214
Electrical Component Inspection	133	Rear Door Harness.....	215
ASCD Wire Adjustment	134	BULB SPECIFICATIONS	216
POWER WINDOW	135	Headlamp.....	216
System Description.....	135	Exterior Lamp	216

CONTENTS (Cont'd)

Interior Lamp.....	216
WIRING DIAGRAM CODES (CELL CODES)	217
SUPER MULTIPLE JUNCTION (SMJ)	Foldout
Installation.....	Foldout
Terminal Arrangement.....	Foldout
FUSE BLOCK — JUNCTION BOX (J/B)	Foldout
Terminal Arrangement.....	Foldout

FUSE AND FUSIBLE LINK BOX	Foldout	GI
Terminal Arrangement.....	Foldout	
ELECTRICAL UNITS	Foldout	MA
Terminal Arrangement.....	Foldout	
JOINT CONNECTOR (J/C)	Foldout	EM
Terminal Arrangement.....	Foldout	

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NCEL0001

The Supplemental Restraint System "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.

In addition to the supplemental air bag modules for a frontal collision, the supplemental side air bag used along with the seat belt helps to reduce the risk or severity of injury to the driver and front passenger in a side collision. The supplemental side air bag consists of air bag modules (located in the outer side of front seats), satellite sensor, diagnosis sensor unit (which is one of components of supplemental air bags for a frontal collision), wiring harness, warning lamp (which is one of components of supplemental air bags for a frontal collision). Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses (except "SEAT BELT PRE-TENSIONER" connector) can be identified with yellow harness connector (and with yellow harness protector or yellow insulation tape before the harness connectors).

Wiring Diagrams and Trouble Diagnosis

NCEL0002

When you read wiring diagrams, refer to the followings:

- "HOW TO READ WIRING DIAGRAMS" in GI section
- "POWER SUPPLY ROUTING" for power distribution circuit in EL section

When you perform trouble diagnosis, refer to the followings:

- "HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS" in GI section
- "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" in GI section

Check for any Service bulletins before servicing the vehicle.

HARNESS CONNECTOR

Description

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

NCEL0003

NCEL0003S01


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SEL769DA

HARNESS CONNECTOR

Description (Cont'd)

HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


=NCEL0003S02

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



STANDARDIZED RELAY

Description

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NCEL0004

NCEL0004S01

GI

MA

EM

LC

EC

FE

CL

MT

SEL881H

AT

NCEL0004S02

AX

SU

BR

ST

RS

BT


HA

SC

SEL882H


EL

IDX















TYPE OF STANDARDIZED RELAYS

1M	1 Make	2M	2 Make
1T	1 Transfer	1M·1B	1 Make 1 Break



STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL661TA

POWER SUPPLY ROUTING

Wiring Diagram — POWER —



Wiring Diagram — POWER —

BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION

NCEL0006

NCEL0006S01

EL-POWER-01




Refer to last page (Foldout page).

(M6), (E75)



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX






TEL877A


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-03



Refer to last page (Foldout page).



TEL878A


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" OR "ON"

NCEL0006S02

EL-POWER-04



1	3	5
6	2	4

(E76)
W

Refer to last page (Foldout page).

(M1), (M4), (E71), (E73)				
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL879A


POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

NCCL0006503

EL-POWER-05



1	3	5
6	2	4

(E76)
W

Refer to last page (Foldout page).

(M1)	(M2)	(M3)	(M4)	
(E71)	(E72)	(E73)		
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		


TEL880A

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06

⬡ A : With AT
 ⬡ HE : With heated seat



Refer to last page (Foldout page).

M2, M4, E72, B1				
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		


TEL881A

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-07




1	3	5
6	2	4

(E76)
W

Refer to last page (Foldout page).

M2	M3	E71	E72	
1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

TEL882A



Inspection

NCEL0007

FUSE

NCEL0007S01


- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.

GI

MA

EM

LC



FUSIBLE LINK

NCEL0007S02

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

EC

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

FE

CL


MT

AT

AX

SU

BR



CIRCUIT BREAKER

NCEL0007S03

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

ST

RS

BT

HA

SC

EL


IDX

GROUND

Ground Distribution

Ground Distribution

NCEL0008




CEL931



GROUND

Ground Distribution (Cont'd)

Preceding page



CON-NECTOR NUMBER	CONNECT TO
M48	A/T device (Terminal No. 2)
M52	Fan switch (With manual A/C)
M53	Push control unit (With manual A/C)
M55	A/C auto amp. (With auto A/C) (Terminal No. 32)
M79	Power steering oil pressure switch
M81	Front wiper motor
M82	Ashtray illumination
M85	PTC (With manual A/C)
D24	Door mirror actuator (Passenger side)
D27	Front door key cylinder switch (Passenger side)
D28	Front door lock actuator (Passenger side)





CON-NECTOR NUMBER	CONNECT TO
M48	A/T device (Terminal No. 6)
M58	Rear window defogger switch (Terminal No. 2)
M58	Rear window defogger switch (Terminal No. 4)
M61	Cigarette lighter
M65	Fan control amp. (With auto A/C)
M66	Intake door motor
M67	Glove box lamp
M84	Air mix door motor (With manual A/C)
R2	Vanity mirror lamp (Passenger side)
R3	Map lamp
R4	Sunroof switch
R6	Vanity mirror lamp (Driver side)
R6	Integrated homelink transmitter
Z1	Air bag diagnosis sensor unit

CEL932

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

GROUND


Ground Distribution (Cont'd)




CEL933

GROUND

Ground Distribution (Cont'd)



CON-NECTOR NUMBER	CONNECT TO
E85	ABS control unit (Terminal No. 28)
E85	ABS control unit (Terminal No. 29)
E85	ABS control unit (Terminal No. 39)







CON-NECTOR NUMBER	CONNECT TO
E5	Front wheel sensor LH (Shield wire)
E51	Front wheel sensor RH (Shield wire)
B105	Rear wheel sensor RH
B108	Rear wheel sensor LH

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CEL934

GROUND


Ground Distribution (Cont'd)



CEL935

GROUND

Ground Distribution (Cont'd)




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX

CEL936

GROUND



Ground Distribution (Cont'd)



CEL937

GROUND

Ground Distribution (Cont'd)




CON-NECTOR NUMBER	CONNECT TO
(B107)	Fuel tank gauge unit
(B106)	Fuel pump
(B112)	Power antenna
(B114)	BOSE speaker amp.
(B118)	High-mounted stop lamp (Without rear spoiler)
(T52)	Rear combination lamp RH (Trunk lid) • Stop/Tail • Back-up
(T53)	Trunk lid key cylinder switch
(T54)	High-mounted stop lamp (With rear spoiler)
(T55)	Trunk room lamp switch
(T56)	License lamp
(T57)	Rear combination lamp LH (Trunk lid) • Stop/Tail • Back-up

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CEL938

GROUND

Ground Distribution (Cont'd)





CEL939

COMBINATION SWITCH


Check

Check

NCEL0009



FRONT WIPER AND WASHER SWITCH



VARIABLE INTERMITTENT WIPER VOLUME



LIGHTING SWITCH

	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5			<input type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	
7				<input type="checkbox"/>			<input type="checkbox"/>		
8		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	
9			<input type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
10				<input type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>	
11		<input type="checkbox"/>			<input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>	
12			<input type="checkbox"/>			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	

FRONT FOG LAMP SWITCH

	OFF	ON
31	<input type="checkbox"/>	<input type="checkbox"/>
32	<input type="checkbox"/>	<input type="checkbox"/>

TURN SIGNAL SWITCH




	L	N	R
1	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CEL940

COMBINATION SWITCH

Replacement



Replacement

NCEL0010

For removal and installation of spiral cable, refer to RS section ["Installation — Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

- Each switch can be replaced without removing combination switch base.

- To remove combination switch base, remove base attaching screw.


- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

STEERING SWITCH


Check

Check

NCEL0011



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



CEL941

HEADLAMP (FOR USA)

System Description

System Description

NCEL0012

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 8
- through 15A fuse (No. 32, located in the fuse and fusible link box), and
- to lighting switch terminal 5
- through 15A fuse (No. 33, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

NCEL0012S01

- from lighting switch terminal 10
- to terminal 3 of the headlamp LH, and
- from lighting switch terminal 7
- to terminal 3 of the headlamp RH.

Terminal 2 of each headlamp supplies ground through body grounds E9 and E28. With power and ground supplied, the low beams will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

NCEL0012S02

- from lighting switch terminal 6
- to terminal 1 of each headlamp RH, and
- from lighting switch terminal 9
- to terminal 1 of each headlamp LH, and
- to combination meter terminal 29 for the high beam indicator.

Ground is supplied to terminal 27 of the combination meter through body grounds M15, M71 and M76. Terminal 2 of each headlamp supplies ground through body grounds E9 and E28. With power and ground supplied, the high beams and the high beam indicator illuminate.

THEFT WARNING SYSTEM

The theft warning system will flash the high beams if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-169).

NCEL0012S03



HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP —

Wiring Diagram — H/LAMP —

NCEL0013

EL-H/LAMP-01



Refer to last page (Foldout page).
M6, E75

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL883A


HEADLAMP (FOR USA)

Trouble Diagnoses

Trouble Diagnoses

NCEL0014

Symptom	Possible cause	Repair order
Headlamp LH do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E9 and E28 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E9 and E28. 3. Check 15A fuse (No. 32, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch.
Headlamp RH do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E9 and E28 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E9 and E28. 3. Check 15A fuse (No. 33, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch.
High beam LH do not operate, but low beam LH operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in high beam LH circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check the wire between lighting switch terminal 9 and headlamp LH terminal 1 for an open circuit. 3. Check lighting switch.
Low beam LH does not operate, but high beam LH operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in low beam LH circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the wire between lighting switch terminal 10 and headlamp LH terminal 3 for an open circuit. 3. Check lighting switch.
High beam RH do not operate, but low beam RH operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in high beam RH circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check the wire between lighting switch terminal 6 and headlamp RH terminal 1 for an open circuit. 3. Check lighting switch.
Low beam RH does not operate, but high beam RH operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in low beam RH circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check the wire between lighting switch terminal 7 and headlamp RH terminal 3 for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M15, M71 and M76 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M15, M71 and M76. 3. Check the wire between lighting switch terminal 9 and combination meter terminal 29 for an open circuit.



Bulb Replacement

NCEL0015

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

● **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Aiming Adjustment

NCEL0016

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle and tester on one and same flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

HEADLAMP (FOR USA)


Aiming Adjustment (Cont'd)



LOW BEAM

NCCL0016S02

1. Turn headlamp low beam on.
 2. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- **Basic illuminating area for adjustment should be within the range shown at left. Adjust headlamps accordingly.**

System Description

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 32, located in the fuse and fusible link box)
- to daytime light control unit terminal 3 and
- to lighting switch terminal 8.

Power is also supplied at all times

- through 15A fuse (No. 33, located in the fuse and fusible link box)
- to daytime light control unit terminal 2 and
- to lighting switch terminal 5.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to daytime light control unit terminal 12.

With the ignition switch in the START position, power is supplied

- through 10A fuse [No. 26, located in the fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied to daytime light control unit terminal 9 through body grounds E9 and E28.

HEADLAMP OPERATION

Low Beam Operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 7
- to headlamp RH terminal 3
- to daytime light control unit terminal 4.

Ground is supplied to headlamp RH terminal 2 through body grounds E9 and E28.

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to headlamp LH terminal 3.

Ground is supplied

- to headlamp LH terminal 2
- from daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through body grounds E9 and E28.

With power and ground supplied, the low beam headlamps illuminate.

High Beam Operation/Flash-to-pass Operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal 6
- to terminal 1 of headlamp RH.

Also, when the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, power is supplied

- from lighting switch terminal 9
- to daytime light control terminal 5
- to combination meter terminal 29 for the high beam indicator
- through daytime light control terminal 6
- to terminal 1 of headlamp LH.

Ground is supplied in the same manner as low beam operation.

Ground is supplied to terminal 27 of the combination meter through body grounds M15, M71 and M76.

With power and ground supplied, the high beam headlamps and HI BEAM indicator illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

NCELO017S01 AT

NCELO017S0101 AX

SU

BR

ST

RS

BT

NCELO017S0102 HA

SC

EL

IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

DAYTIME LIGHT OPERATION

NCELO017S02

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- to daytime light control unit terminal 3
- through daytime light control unit terminal 6
- to terminal 1 of headlamp LH
- through terminal 2 of headlamp LH
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to terminal 1 of headlamp RH.

Ground is supplied to terminal 2 of headlamp RH through body grounds E9 and E28.

Because the high beam headlamps are now wired in series, they operate at half illumination.

OPERATION

NCELO017S03

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	O	X	X	O	O	X	O	Δ*	Δ*	O	Δ*	Δ*	O	O	X	O
	Low beam	X	X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

A: "HIGH BEAM" position

B: "LOW BEAM" position

C: "FLASH TO PASS" position

O: Lamp "ON"

X: Lamp "OFF"

Δ: Lamp dims. (Added functions)

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.



HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

Wiring Diagram — DTRL —

NCEL0020

EL-DTRL-01



Refer to last page (Foldout page).
(M6, E75)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

TEL884A





HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).



HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —











Trouble Diagnoses

Trouble Diagnoses

NCEL0021

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE








NCEL0021S01

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)
1	B/Y	Start signal	 When turning ignition switch to "ST"	Battery voltage
			 When turning ignition switch to "ON" from "ST"	Less than 1V
			 When turning ignition switch to "OFF"	Less than 1V
2	R	Power source	 When turning ignition switch to "ON"	Battery voltage
			 When turning ignition switch to "OFF"	Battery voltage
3	R/W	Power source	 When turning ignition switch to "ON"	Battery voltage
			 When turning ignition switch to "OFF"	Battery voltage
4	P/L	Lighting switch (Low beam)	When lighting switch is turned to the 2ND position with "LOW BEAM" position	Battery voltage
5	R/B	Lighting switch (High beam)	When turning lighting switch to "HIGH BEAM"	Battery voltage
			When turning lighting switch to "FLASH TO PASS"	Battery voltage
6	OR/L	High beam LH	When turning lighting switch to "HIGH BEAM"	Battery voltage
			 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
7	OR/B	Headlamp LH control (ground)	When lighting switch is turned to the 2ND position with "LOW BEAM" position	Less than 1V
			 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
8	R/G	High beam RH	When lighting switch is turned to the 2ND position with "HIGH BEAM" position	Battery voltage
			 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Terminal No.	Wire color	Item	Condition		Voltage (Approximate values)
9	B	Ground		—	—
10	Y/B	Parking brake switch		When parking brake is released	Battery voltage
				When parking brake is set	Less than 1.5V
11	Y/R	Alternator		When turning ignition switch to "ON"	Less than 1V
				When engine is running	Battery voltage
				When turning ignition switch to "OFF"	Less than 1V
12	LG/B	Power source		When turning ignition switch to "ON"	Battery voltage
				When turning ignition switch to "ST"	Battery voltage
				When turning ignition switch to "OFF"	Less than 1V

Bulb Replacement

Refer to "HEADLAMP (FOR USA)" (EL-31).

NCEL0022

Aiming Adjustment

Refer to "HEADLAMP (FOR USA)" (EL-31).

NCEL0023


PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

Wiring Diagram — TAIL/L —


NCEL0024

EL-TAIL/L-01



Refer to EL-POWER.

Next page



Refer to last page (Foldout page).






- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

TEL886A

PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



TEL887A


STOP LAMP

Wiring Diagram — STOP/L —

Wiring Diagram — STOP/L —


NCEL0025

EL-STOP/L-01



RS : With rear spoiler
OR : Without rear spoiler

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT



Refer to last page (Foldout page).

M4

HA
SC
EL
IDX

TEL888A


BACK-UP LAMP

Wiring Diagram — BACK/L —

Wiring Diagram — BACK/L —

NCEL0026

EL-BACK/L-01



TEL889A

System Description

NCEL0027

Power is supplied at all times to fog lamp relay terminal 3 through:

- 15A fuse (No. 43, located in the fuse and fusible link box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 15A fuse (No. 33, located in the fuse and fusible link box).
- to lighting switch terminal 5
- through terminal 7 of the lighting switch
- to fog lamp relay terminal 1.

FOG LAMP OPERATION

NCEL0027S01

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal 2
- through the fog lamp switch and body grounds E9 and E28.

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal 5
- to terminal 1 of each fog lamp.

Ground is supplied to terminal 2 of each fog lamp through body grounds E9 and E28.

With power and ground supplied, the fog lamps illuminate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



FRONT FOG LAMP

Wiring Diagram — F/FOG —

Wiring Diagram — F/FOG —


NCEL0028

EL-F/FOG-01



FRONT FOG LAMP

Aiming Adjustment




Aiming Adjustment


Before performing aiming adjustment, make sure of the following. NCEL0029

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the fog lamp lens as shown at left.
2. Remove front fog lamp rim. For detail, refer to "BODY END" in BT section.
3. Turn front fog lamps ON.



4. Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description

System Description

NCEL0030

TURN SIGNAL OPERATION

NCEL0030S01

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4 and M66.

LH Turn

NCEL0030S0101

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 1
- side turn signal lamp LH terminal 1
- combination meter terminal 30
- rear combination lamp LH terminal 1.

Ground is supplied to the front turn signal lamp LH terminal 2 and the side turn signal lamp LH terminal 2 through body grounds E9 and E28.

Ground is supplied to the rear combination lamp LH terminal 2 through body grounds T6 and T7.

Ground is supplied to combination meter terminal 27 through body grounds M15, M71 and M76.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH Turn

NCEL0030S0102

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 1
- side turn signal lamp RH terminal 1
- combination meter terminal 28
- rear combination lamp RH terminal 1.

Ground is supplied to the front turn signal lamp RH terminal 2 and the side turn signal lamp terminal 2 through body grounds E9 and E28.

Ground is supplied to the rear combination lamp RH terminal 2 through body grounds T6 and T7.

Ground is supplied to combination meter terminal 27 through body grounds M15, M71 and M76.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

NCEL0030S02

Power is supplied at all times to hazard switch terminal 3 through:

- 10A fuse [No. 20, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M15, M71 and M76.

Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 1
- side turn signal lamp LH terminal 1
- combination meter terminal 30
- rear combination lamp LH terminal 1.

Power is supplied through terminal 6 of the hazard switch to

- front turn signal lamp RH terminal 1
- side turn signal lamp RH terminal 1

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

- combination meter terminal 28
- rear combination lamp RH terminal 1.

Ground is supplied to terminal 2 of each front turn signal lamp through body grounds E9 and E28.

Ground is supplied to terminal 2 of each side turn signal lamp through body grounds E9 and E28.

Ground is supplied to terminal 2 of each rear combination lamp through body grounds T6 and T7.

Ground is supplied to combination meter terminal 27 through body grounds M15, M71 and M76.

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

EM

MULTI-REMOTE CONTROL SYSTEM OPERATION

NCLE0030S03

Power is supplied at all times

- through 10A fuse [No. 20, located in the fuse block (J/B)]
- to multi-remote control relay terminals 1, 3 and 6.

LC

Ground is supplied to multi-remote control relay terminal 2, when the multi-remote control system is triggered through the smart entrance control unit.

Refer to "MULTI-REMOTE CONTROL SYSTEM", EL-154.

The multi-remote control relay is energized.

Power is supplied through terminal 7 of the multi-remote control relay

- to front turn signal lamp LH terminal 1
- side turn signal lamp LH terminal 1
- to combination meter terminal 30
- to rear combination lamp LH terminal 1.

EC

FE

CL

MT

Power is supplied through terminal 5 of the multi-remote control relay

- to front turn signal lamp RH terminal 1
- side turn signal lamp RH terminal 1
- to combination meter terminal 28
- to rear combination lamp RH terminal 1.

AT

AX

Ground is supplied to terminal 2 of each front turn signal lamp through body grounds E9 and E28.

Ground is supplied to terminal 2 of each side turn signal lamp through body grounds E9 and E28.

Ground is supplied to terminal 2 of each rear combination lamp through body grounds T6 and T7.

Ground is supplied to combination meter terminal 27 through body grounds M15, M71 and M76.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

SU

BR

ST

RS

BT

HA

SC

EL

IDX


TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —






Wiring Diagram — TURN —

NCEL0032

EL-TURN-01



Next page



Refer to last page (Foldout page).

(M6) (E75)








(M2)

(M4)

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)

EL-TURN-02



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEL892A


TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Trouble Diagnoses

NCEL0033

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 12, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check the wire between combination flasher unit terminal 3 and turn signal switch terminal 1 for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 20, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch. 2. Check hazard switch. 3. Check the wire between combination flasher unit terminal 3 and hazard switch terminal 4 for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E9 and E28 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E9 and E28.
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds T6 and T7 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds T6 and T7.
Side turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E9 and E28 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E9 and E28.
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Ground 	<ol style="list-style-type: none"> 1. Check grounds M15, M71 and M76.
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.



Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NCEL0034

NCEL0034S01

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

ILLUMINATION

System Description

System Description

NCEL0035

Power is supplied at all times

- through 10A fuse [No. 34, located in the fuse block (J/B)]
- to lighting switch terminal 11.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M29	1	3
Combination meter	M40	33, 37	34
A/T indicator	M48	3	4
Ashtray	M82	1	2
Grove box lamp	M67	1	2
ASCD main switch	M28	5	6
Rear window defogger switch	M58	5	6
Power window main switch	D6	4	13
Audio	M50	8	7
Hazard switch	M57	7	8
Push control unit	M53, M54	15	16
A/C auto amp.	M55	24	25

The ground for all of the components except for grove box lamp and ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M15, M71 and M76.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ILLUMINATION

Schematic

NCEL0036

Schematic



TEL893A


ILLUMINATION

Wiring Diagram — ILL —


Wiring Diagram — ILL —

NCEL0037

EL-ILL-01



AA : With auto A/C
 MA : With manual A/C



Refer to last page (Foldout page).
 M1
 M4
 E72


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX







TEL894A

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02

 : With A/T




TEL895A

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Refer to EL-POWER.

⬡ A1 : With ashtray illumination

COMBINATION METER (M40)

GLOVE BOX LAMP (M67)

ASHTRAY ILLUMINATION (M82) : ⬡ A1

36	37	38	39	40	41	42		
27	28	29	30	31	32	33	34	35

M40
BR

M67
B

M82
W

Refer to last page (Foldout page).
M2

TEL896A

INTERIOR ROOM LAMP

System Description

System Description

NCELO162

NCELO162S01

POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 30A fusible link (Letter **d**, located in the fuse and fusible link box)
- to circuit breaker-1 terminal 1
- through circuit breaker-1 terminal 2
- to smart entrance control unit terminal 11.

Power is supplied at all times:

- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to key switch terminal 1 and
- to smart entrance control unit terminal 10.

When the key is removed from ignition key cylinder, power is interrupted:

- through terminal key switch 2
- to smart entrance control unit terminal 32.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to smart entrance control unit terminal 33.

Ground is supplied:

- to smart entrance control unit terminal 16
- through body grounds terminal M15, M71 and M76.

When the front driver side door is opened, ground is supplied:

- through body grounds B7 and B24
- to front door switch (driver side) terminal 3
- from front door switch (driver side) terminal 2
- to smart entrance control unit terminal 29.

When the front passenger side door is opened, ground is supplied:

- through case ground of front door switch (passenger side)
- from front door switch (passenger side) terminal 1
- to smart entrance control unit terminal 40.

When any other door (except front passenger side) is opened ground is supplied to smart entrance control unit terminal 28 in the same manner as the front door switch (front passenger side).

When the front passenger side door is unlocked, the smart entrance control unit receives a ground signal:

- through body grounds terminal M15, M71 and M76
- to front door lock actuator (driver side) (unlock sensor) terminal 2
- from front door lock actuator (driver side) (unlock sensor) terminal 4
- to smart entrance control unit terminal 36.

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 8
- to interior room lamp terminal 2.

With power and ground supplied, the interior room lamp illuminates.

SWITCH OPERATION

When the room lamp switch is ON, ground is supplied:

- through case grounds of interior room lamp
- from interior room lamp terminal 1
- to smart entrance control unit terminal 17.

When the map lamp (LH and/or RH) is ON, ground is supplied:

- through body grounds M15, M71 and M76
- to map lamp terminal 2
- from map lamp terminal 1
- to smart entrance control unit terminal 17.

With power and ground supplied, the room lamp turns ON.

NCELO162S03

INTERIOR ROOM LAMP TIMER OPERATION

NCEL0162S04

When the room lamp switch is in the "DOOR" position, the smart entrance control unit keeps the interior room lamp illuminated for about 30 seconds when:

- unlock signal is supplied from multi-remote controller (Models with multi-remote control system)
- key is removed from ignition key cylinder while driver's door is closed
- driver's door is opened and then closed while ignition switch is not in the ON position.

The timer is canceled, and interior room lamp turns off when:

- driver's door is locked with remote controller, or
- ignition switch is turned ON.

The smart entrance control unit will shut off the room light (interior room lamp and/or map lamp) if left on for 10 minutes.

For details, refer to "BATTERY SAVER", EL-190.

ON-OFF CONTROL

NCEL0162S05

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

When any door is opened and then closed while the ignition switch is not in the ON position, the interior room lamp timer operates.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L —




Wiring Diagram — ROOM/L —

NCFL0163

EL-ROOM/L-01

Refer to EL-POWER.

SMART
ENTRANCE
CONTROL
UNIT
(M23, M24)





Refer to last page (Foldout page).

- (M6), (E75)
- (M2)
- (M3)
- (E72)

INTERIOR ROOM LAMP

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL898A

VANITY MIRROR AND TRUNK ROOM LAMPS

System Description

System Description

TRUNK ROOM LAMP

NCEL003B

Power is supplied at all times

NCEL003B501

- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to trunk room lamp terminal 1,

With trunk room lamp switch ON, ground is supplied to turn trunk room lamp ON.

When trunk room lamp switch is opened, ground is supplied to trunk room lamp terminal 2 through body grounds B109 and B110.

VANITY MIRROR LAMP

NCEL003B504

Power is supplied at all times

- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to each vanity mirror lamp terminal 1.

With the vanity mirror lamp switch in the ON position, the vanity mirror lamp turns ON.



VANITY MIRROR AND TRUNK ROOM LAMPS

Wiring Diagram — INT/L —

Wiring Diagram — INT/L —

NCEL0040

EL-INT/L-01



Refer to last page (Foldout page).



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX


TEL899A

METERS AND GAUGES

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL0041



SEL832V

System Description

NCEL0042


UNIFIED CONTROL METER

NCEL004206

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit combined with speedometer.
- Digital meter is adopted for odo/trip meter.*
*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NCEL0042S07



SEL253V

NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

POWER SUPPLY AND GROUND CIRCUIT

NCEL0042S08

Power is supplied at all times

- through 7.5A fuse [No. 5, located in the fuse block (J/B)]
- to combination meter terminal 1.

GI

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 11, located in the fuse block (J/B)]
- to combination meter terminal 37.

MA

Ground is supplied

- to combination meter terminal 3
- through body grounds M15, M71 and M76.

EM

LC

WATER TEMPERATURE GAUGE

NCEL0042S01

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

EC

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 5 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

FE

TACHOMETER

NCEL0042S02

The tachometer indicates engine speed in revolutions per minute (rpm).

CL

The tachometer is regulated by a signal

- from terminal 3 of the ECM
- to combination meter terminal 16 for the tachometer.

MT

FUEL GAUGE

NCEL0042S03

The fuel gauge indicates the approximate fuel level in the fuel tank.

AT

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 6 for the fuel gauge
- from terminal 4 of the fuel tank gauge unit
- through terminal 1 of the fuel tank gauge unit and
- through body grounds B109 and B110.

AX

SU

SPEEDOMETER

NCEL0042S04

The combination meter provides a voltage signal to the vehicle speed sensor for the speedometer.

BR

The voltage is supplied

- from combination meter terminal 15 for the speedometer
- to terminal 1 of the vehicle speed sensor.

ST

The speedometer converts the voltage into the vehicle speed displayed.

RS

BT

HA

SC

EL

IDX

METERS AND GAUGES



Combination Meter

Combination Meter

NCEL0043

U : ABS U : BRAKE
 C : (ABS) C : (D)

U : For U.S.A.
 C : For Canada



CEL942









METERS AND GAUGES

Wiring Diagram — METER —

Wiring Diagram — METER —

NCEL0045

EL-METER-01



Refer to last page (Foldout page).

- M6, E75
- M2
- M5
- F26

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL900A

METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NCEL0151

DIAGNOSIS FUNCTION


NCEL0151S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.

HOW TO ALTERNATE DIAGNOSIS MODE

NCEL0151S02

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Confirm that trip meter indicates "000.0".
5. Push odo/trip meter switch more than three times within 5 seconds.




6. All odo/trip meter segments should be turned on.

NOTE:

If some segments are not turned on, speedometer (unified meter control unit) with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.



7. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

NOTE:

It takes about 1 minute for indication of fuel gauge to become stable.

Flexible Print Circuit (FPC)

=NCELO152

Tachometer, fuel gauge and water temperature gauge are connected with unified meter control unit (speedometer) by Flexible Print Circuit (FPC) connector. When replace or remove and install unified control unit (speedometer), disconnect and connect FPC connector according to the following steps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX




SEL109V

DISCONNECT

NCELO152S01

1. Open connector cover.
2. Release connector lock by holding both ends of it and pulling it up.
3. Disconnect FPC by pulling it up.



SEL114V

CONNECT

NCELO152S02

1. Insert FPC into connector and lock connector pushing FPC downward.
2. Check secure connection of FPC.
3. Check continuity of check land terminal for secure connection of FPC.

Resistance: 0Ω

4. Close connector cover.


METERS AND GAUGES

Trouble Diagnoses

Trouble Diagnoses PRELIMINARY CHECK

NCEI 0046

NCEL0046S04



MEL474H

*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-66)

*2: METER/GAUGE RESISTANCE CHECK (EL-73)

*3: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-70)

*4: Flexible Print Circuit (FPC) (EL-67)

*5: Symptom Chart 1 (EL-69)

*6: Symptom Chart 2 (EL-69)

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

Symptom Chart 1 (Malfunction is Indicated in Diagnosis Mode)

NCEL0046S10

NCEL0046S1001

Symptom	Possible causes	Repair order
Speedometer and/or odo/ trip meter indicate(s) malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Speedometer (Unified meter control unit) 	<ul style="list-style-type: none"> Replace speedometer (unified meter control unit).
Multiple meter/gauge indicate malfunction in Diagnosis mode.		
One of tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode.	<ul style="list-style-type: none"> Meter/Gauge Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check resistance of meter/gauge indicating malfunction. If the resistance is NG, replace the meter/gauge. Refer to "METER/GAUGE RESISTANCE CHECK", EL-73. If the resistance is OK, replace speedometer (unified meter control unit).

Symptom Chart 2 (No Malfunction is Indicated in Diagnosis Mode)

NCEL0046S1002

Symptom	Possible causes	Repair order
Speedometer and odo/trip meter are malfunctioning.	<ol style="list-style-type: none"> Sensor <ul style="list-style-type: none"> Speedometer, Odo/Trip meter FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check vehicle speed sensor. INSPECTION/VEHICLE SPEED SENSOR (Refer to EL-71.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-67. Replace speedometer (unified meter control unit).
Multiple meter/gauge are malfunctioning. (except speedometer, odo/trip meter)	<ol style="list-style-type: none"> FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-67. Replace speedometer (unified meter control unit).
One of tachometer/fuel gauge/water temp. gauge is malfunctioning.	<ol style="list-style-type: none"> Sensor/Engine revolution signal <ul style="list-style-type: none"> Tachometer Fuel gauge Water temp. gauge FPC connector Speedometer (Unified meter control unit) 	<ol style="list-style-type: none"> Check the sensor for malfunctioning meter/gauge. INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-71.) INSPECTION/FUEL TANK GAUGE UNIT (Refer to EL-72.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-72.) Check FPC connector. Refer to "Flexible Print Circuit (FPC)", EL-67. Replace speedometer (unified meter control unit).

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-68.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SJ

BR

ST

RS

BT

HA



SC

EL

IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)



POWER SUPPLY AND GROUND CIRCUIT CHECK

=NCEL0046S07

Power Supply Circuit Check

NCEL0046S0701

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
1	Ground	Battery voltage	Battery voltage	Battery voltage
37	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 5, located in fuse block (J/B)]
- 10A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter

Ground Circuit Check

NCEL0046S0702

Terminals	Continuity
3 - Ground	Yes

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/VEHICLE SPEED SENSOR

=NCEL0046S03

1	CHECK VEHICLE SPEED SENSOR OUTPUT
<p>1. Remove vehicle speed sensor from transmission. 2. Check voltage between combination meter terminals 3 and 16 while quickly turning speed sensor pinion.</p>	
<p>NOTE: Vehicle speed sensor connector should remain connected.</p>	
SEL774V	
Voltage: Approx. 0.5V	
OK or NG	
OK	▶ Vehicle speed sensor is OK.
NG	▶ GO TO 2.

2	CHECK VEHICLE SPEED SENSOR
<p>Check resistance between vehicle speed sensor terminals 1 and 2.</p>	
SEL776V	
Resistance: Approx. 250Ω	
OK or NG	
OK	▶ Check harness or connector between speedometer and vehicle speed sensor.
NG	▶ Replace vehicle speed sensor.

INSPECTION/ENGINE REVOLUTION SIGNAL

NCEL0046S02

1	CHECK ECM OUTPUT
<p>1. Start engine. 2. Check voltage between combination meter terminals 16 and ground at idle and 2,000 rpm.</p>	
SEL775V	
<p>Higher rpm = Higher voltage Lower rpm = Lower voltage Voltage should change with rpm.</p>	
OK or NG	
OK	▶ Engine revolution signal is OK.
NG	▶ Harness for open or short between ECM and combination meter

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

METERS AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/FUEL TANK GAUGE UNIT

-NCEL0046S08

1	CHECK GROUND CIRCUIT FOR FUEL TANK GAUGE UNIT
Check harness continuity between fuel tank gauge unit terminal 1 and ground.	
<p>Fuel tank gauge unit connector (B107)</p>	
SEL777V	
Does continuity exist?	
Yes	▶ GO TO 2.
No	▶ Repair harness or connector.

2	CHECK GAUGE UNITS
Refer to "FUEL TANK GAUGE UNIT CHECK" (EL-73).	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace fuel tank gauge unit.

3	CHECK HARNESS FOR OPEN OR SHORT
<ol style="list-style-type: none"> 1. Disconnect combination meter connector and fuel tank gauge unit connector. 2. Check continuity between combination meter terminal 6 and fuel tank gauge unit terminal 4. Continuity should exist. 3. Check continuity between combination meter terminal 6 and ground. Continuity should not exist. 	
SEL778V	
OK or NG	
OK	▶ Fuel tank gauge unit is OK.
NG	▶ Repair harness or connector.

INSPECTION/THERMAL TRANSMITTER

NCEL0046S09

1	CHECK THERMAL TRANSMITTER
Refer to "THERMAL TRANSMITTER CHECK" (EL-74).	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Replace.

2	CHECK HARNESS FOR OPEN OR SHORT
<ol style="list-style-type: none"> 1. Disconnect combination meter connector and thermal transmitter connector. 2. Check continuity between combination meter terminal 5 and thermal transmitter terminal 1. Continuity should exist. 3. Check continuity between combination meter terminal 5 and ground. Continuity should not exist. 	
SEL779V	
OK or NG	
OK	▶ Thermal transmitter is OK.
NG	▶ Repair harness or connector.

Electrical Components Inspection



=NCEL0047

METER/GAUGE RESISTANCE CHECK

NCEL0047S04

1. Disconnect FPC connector. Refer to "Flexible Print Circuit (FPC)" (EL-67).
2. Check resistance between installation screws of meter/gauge.

Screws		Resistance Ω
Tachometer	Fuel/Temp. gauge	
A - C	A - C	Approx. 190 - Approx. 260
B - D	B - C	Approx. 230 - Approx. 310



FUEL TANK GAUGE UNIT CHECK

NCEL0047S01


- For removal, refer to FE section.
- Check the resistance between terminals 3 and 2.

Ohmmeter		Float position mm (in)		Resistance value (Ω)
(+)	(-)			
4	1	*1	Full 45 (1.77)	Approx. 4 - 6
		*2	1/2 101 (3.98)	
		*3	Empty 160 (6.30)	

*1 and *3: When float rod is in contact with stopper.

METERS AND GAUGES

Electrical Components Inspection (Cont'd)




THERMAL TRANSMITTER CHECK

NCEL0047S02

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω



VEHICLE SPEED SENSOR SIGNAL CHECK

NCEL0047S03


1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage across 1 and 2.

WARNING LAMPS

Schematic

NCEL0049

Schematic



(A) : With A/T
 (LM) : With daytime light system
 or M/T with auto A/C
 (XL) : Except for (LM)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX

TEL902A



WARNING LAMPS

Wiring Diagram — WARN —

Wiring Diagram — WARN —

NCEL0050


EL-WARN-01



WARNING LAMPS



Wiring Diagram — WARN — (Cont'd)

EL-WARN-02





COMBINATION METER (M40, M41)

A : With A/T



Refer to last page (Foldout page).
M6, E75, E85




GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL904A





WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



LM : With daytime light system or M/T with auto A/C
XL : Except for LM



Refer to last page (Foldout page).



(M6), (E75)
(F26)

TEL905A

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)


EL-WARN-04



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL906A

WARNING LAMPS



Electrical Components Inspection FUEL WARNING LAMP OPERATION CHECK

NCEL0051

NCEL0051S01


1. Turn ignition switch "OFF".
2. Disconnect fuel tank gauge unit harness connector B107.
3. Connect a resistor (80Ω) between fuel tank gauge unit harness connector terminals 1 and 4.
4. Turn ignition switch "ON".

The fuel warning lamp should come on.

NOTE:

ECM might store the 1st trip DTC P0180 during this inspection. If the DTC is stored in ECM memory, erase the DTC after reconnecting fuel tank gauge unit harness connector.

Refer to "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" "Emission-related Diagnostic Information" "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION" in EC section.




OIL PRESSURE SWITCH CHECK

NCEL0051S02

	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.




DIODE CHECK

NCEL0051S03

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE:

Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.
- For location of diodes, refer to Combination Meter, EL-64.


A/T INDICATOR

Wiring Diagram — AT/IND —



Wiring Diagram — AT/IND —

NCEL0159

EL-AT/IND-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT



Refer to last page (Foldout page).
M6, E75
E72

HA
SC
EL
IDX


TEL901A

WARNING CHIME

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL0052



SEL834V

System Description

NCEL0053

The warning chime is controlled by the smart entrance control unit.

The warning chime is located in the smart entrance control unit.

Power is supplied at all times

- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to key switch terminal 1.

Power is supplied at all times

- through 10A fuse [No. 34, located in the fuse block (J/B)]
- to lighting switch terminal 11.

Power is supplied at all times

- through 30A fusible link (letter d, located in the fuse and fusible link box).
- to smart entrance control unit terminal 11.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to smart entrance control unit terminal 33.

Ground is supplied to smart entrance control unit terminal 16 through body grounds M15, M71 and M76.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

IGNITION KEY WARNING CHIME

NCEL0053S01

With the key in the ignition switch in the OFF or ACC position, and the driver's door open, the warning chime will sound. Power is supplied

- from key switch terminal 2
- to smart entrance control unit terminal 32.

Ground is supplied

- from front door switch (driver side) terminal 2
- to smart entrance control unit terminal 29.

Front door switch (driver side) terminal 3 is grounded through body grounds B7 and B24.

LIGHT WARNING CHIME

NCEL0053S02

With ignition switch OFF or ACC, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied.

- from lighting switch terminal 12

WARNING CHIME

System Description (Cont'd)

- to smart entrance control unit terminal 34.

Ground is supplied

- from front door switch (driver side) terminal 2
- to smart entrance control unit terminal 29.

Front door switch (driver side) terminal 3 is grounded through body grounds B7 and B24.

GI

MA

SEAT BELT WARNING CHIME

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

NCEL0053S03

EM

Ground is supplied

- from seat belt switch terminal 1
- to smart entrance control unit terminal 22.

LC

Seat belt switch terminal 2 is grounded through body grounds B7 and B24.

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WARNING CHIME



Wiring Diagram — CHIME —

Wiring Diagram — CHIME —

NCEL0054

EL-CHIME-01

Refer to EL-POWER.



Refer to last page (Foldout page).

- (M6), (E75)
- (M3)
- (M4)
- (E72)

TEL907A

WARNING CHIME

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NCEL0055

NCEL0055S01

REFERENCE PAGE (EL-)	85	86	86	87	87
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	LIGHTING SWITCH INPUT SIGNAL CHECK	KEY SWITCH (INSERT) CHECK	SEAT BELT BUCKLE SWITCH CHECK	DRIVER SIDE DOOR SWITCH CHECK
Light warning chime does not activate.	X	X			X
Ignition key warning chime does not activate.	X		X		X
Seat belt warning chime does not activate.	X			X	
All warning chimes do not activate.	X				X

GI

MA

EM


LC

EC

FE

CL

MT



POWER SUPPLY AND GROUND CIRCUIT CHECK

NCEL0055S02

Power Supply Circuit Check

NCEL0055S0201

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
11	Ground	Battery voltage	Battery voltage	Battery voltage
33	Ground	0V	0V	Battery voltage

AT

AX

SU


BR

ST

RS

BT

HA



Ground Circuit Check

NCEL0055S0202

Terminals	Continuity
16 - Ground	Yes

SC

EL

IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)

LIGHTING SWITCH INPUT SIGNAL CHECK

=NCEL0055S03

1	CHECK LIGHTING SWITCH INPUT SIGNAL
Check voltage between control unit terminal 34 and ground.	
Voltage [V]: Condition of lighting switch: 1ST or 2ND Approx. 12 Condition of lighting switch: OFF 0	
OK or NG	
OK	▶ Lighting switch is OK.
NG	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse (No. 34, located in the fuse and fusible link box) • Harness for open or short between control unit and lighting switch

KEY SWITCH (INSERT) CHECK

NCEL0055S04

1	CHECK KEY SWITCH INPUT SIGNAL
Check voltage between control unit terminal 32 and ground.	
Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0	
OK or NG	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
Check continuity between terminals 1 and 2.	
Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is removed. No	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse [No. 24, located in fuse block (J/B)] • Harness for open or short between key switch and fuse • Harness for open or short between control unit and key switch
NG	▶ Replace key switch.

WARNING CHIME

Trouble Diagnoses (Cont'd)

SEAT BELT BUCKLE SWITCH CHECK

#NCEL0055305

1	CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL
<p>1. Turn ignition switch "ON". 2. Check voltage between control unit terminal 22 and ground.</p>	
<p>Smart entrance control unit connector (M24)</p> <p style="text-align: right;">SEL785V</p>	
<p>Voltage [V]: Condition of seat belt buckle switch: Fastened Approx. 12 Condition of seat belt buckle switch: Unfastened 0</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Seat belt buckle switch is OK.
NG	▶ GO TO 2.

2	CHECK SEAT BELT BUCKLE SWITCH
<p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.</p>	
<p>Seat belt buckle switch connector (B13)</p> <p style="text-align: right;">SEL298VB</p>	
<p>Continuity: Seat belt is fastened. No Seat belt is unfastened. Yes</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check the following. <ul style="list-style-type: none"> • Seat belt buckle switch ground circuit • Harness for open or short between control unit and seat belt buckle switch
NG	▶ Replace seat belt buckle switch.

DRIVER SIDE DOOR SWITCH CHECK

NCEL0055306

1	CHECK DOOR SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 29 and ground.</p>	
<p>Smart entrance control unit connector (M24)</p> <p style="text-align: right;">SEL786V</p>	
<p>Voltage [V]: Condition of driver's door: CLOSED Approx. 12 Condition of driver's door: OPENED 0</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Driver side door switch is OK.
NG	▶ GO TO 2.

2	CHECK DRIVER SIDE DOOR SWITCH
<p>Check continuity between terminals 2 and 3, 3 and ground.</p>	
<p>Door switch driver side connector (B4)</p> <p style="text-align: right;">SEL844V</p>	
<p>Continuity: Door switch is pushed. No Door switch is released. Yes</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check the following. <ul style="list-style-type: none"> • Door switch ground circuit • Harness for open or short between control unit and door switch
NG	▶ Replace driver side door switch.

FRONT WIPER AND WASHER

System Description

System Description

NCEL0057

NCEL0057S01

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to wiper motor terminal 6.

Low and High Speed Wiper Operation

NCEL0057S0101

Ground is supplied to wiper switch terminal 17 through body grounds E9 and E28.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 2.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 1.

With power and ground supplied, the wiper motor operates at high speed.

Auto Stop Operation

NCEL0057S0102

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 2, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper motor terminal 5
- through terminal 4 of the wiper motor, and
- through body grounds M15, M71 and M76.

When wiper arms reach base of windshield, wiper motor terminals 5 and 6 are connected instead of terminals 4 and 5. Wiper motor will then stop wiper arms at the STOP position.

Intermittent Operation

NCEL0057S0103

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 3 to 13 seconds. This feature is controlled by the wiper amplifier (INT SW) combined with wiper switch.

When the wiper switch is placed in the INT position, ground is supplied to wiper amplifier.

The desired interval time is input to wiper amplifier (INT VR) from wiper volume switch combined with wiper switch.

Then intermittent ground is supplied

- to wiper motor terminal 2
- from terminal 14 of wiper switch
- through wiper amplifier (OUTPUT).

The wiper motor operates at low speed at the desired interval.

WASHER OPERATION

NCEL0057S02

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal 2, and
- from terminal 18 of the wiper switch
- through terminal 17 of the wiper switch, and

FRONT WIPER AND WASHER

System Description (Cont'd)

- through body grounds E9 and E28.

With power and ground supplied, the washer motor operates.

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



FRONT WIPER AND WASHER

Wiring Diagram — WIPER —

Wiring Diagram — WIPER —

NCEL0058

EL-WIPER-01




Refer to last page (Foldout page).
 (M6) (E75)
 (E71)

FRONT WIPER AND WASHER

Removal and Installation

NCEL0060

NCEL0060S01



Removal and Installation

WIPER ARMS

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
 - Clearance "L₁": 18.5 - 33.5 mm (0.728 - 1.319 in)
 - Clearance "L₂": 19.5 - 34.5 mm (0.768 - 1.358 in)
- Tighten wiper arm nuts to specified torque.
 - Front wiper: 17 - 23 N·m (1.7 - 2.3 kg·m, 12 - 17 ft·lb)

GI

MA

EM


LC

EC

FE

CL

MT



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

AT


AX

SU

BR

WIPER LINKAGE

NCEL0060S02



ST

RS

BT

HA

SC

EL

IDX

FRONT WIPER AND WASHER

Removal and Installation (Cont'd)

Removal

NCEL0060S0201

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation

NCEL0060S0202



- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

Washer Nozzle Adjustment

NCEL0061

- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range: $\pm 10^\circ$




Unit: mm (in)

*1	330 (12.99)	*5	115 (4.53)
*2	185 (7.28)	*6	175 (6.89)
*3	320 (12.60)	*7	370 (14.57)
*4	175 (6.89)	*8	440 (17.32)

*: The diameters of these circles are less than 80 mm (3.15 in).

Washer Tube Layout

NCEL0062



HORN

Wiring Diagram — HORN —

Wiring Diagram — HORN —

NCEL0071

EL-HORN-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA




SC

EL

IDX



Refer to EL-POWER.



Refer to last page (Foldout page).



*: This connector is not shown in "HARNESS LAYOUT", EL section.

TEL909A



CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

Wiring Diagram — CIGAR —

NCEL0156

EL-CIGAR-01



Refer to last page (Foldout page).



REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL0072

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



SEL835V

System Description

NCEL0073

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 20A fuse (No. 39, located in the fuse and fusible link box) and
- to rear window defogger relay terminal 6
- through 20A fuse (No. 40, located in the fuse and fusible link box).

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to the rear window defogger relay terminal 1 and
- to smart entrance control unit terminal 33.

Ground is supplied to terminal 2 of the rear window defogger switch through body grounds M15, M71 and M76.

When the rear window defogger switch is turned ON, ground is supplied

- through terminal 1 of the rear window defogger switch
- to smart entrance control unit terminal 39.

Terminal 2 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay

REAR WINDOW DEFOGGER

System Description (Cont'd)

- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch
- from terminal 5 of the rear window defogger relay.


Terminal 4 of the rear window defogger switch is grounded through body grounds M15, M71 and M76.

REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

Wiring Diagram — DEF —

NCEL0074



EL-DEF-01

Refer to EL-POWER.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



M16


M72



M17



M36



M37

Refer to last page (Foldout page).

M6, E75

M1


M3



M58




M73




D5

D24



M23



M24

B



*: This connector is not shown in "HARNESS LAYOUT", EL section.

TEL911A

REAR WINDOW DEFOGGER

Trouble Diagnoses

Trouble Diagnoses DIAGNOSTIC PROCEDURE SYMPTOM: Rear window defogger does not activate, or does not go off after activating.

NCEL0075

NCEL0075S01

1	CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL
<p>1. Turn ignition switch to ON position. 2. Check voltage between smart entrance control unit harness terminal 2 and ground.</p>	
<p style="text-align: right;">SEL787V</p>	
<p>Voltage [V]: Rear window defogger switch is "OFF". Approx. 12 Rear window defogger switch is "ON". 0</p> <p style="text-align: center;">OK or NG</p>	
OK	<p>▶ Check the following.</p> <ul style="list-style-type: none"> • Rear window defogger relay (Refer to EL-99.) • Rear window defogger circuit • Rear window defogger filament (Refer to EL-100.)
NG	▶ GO TO 2.

3	CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL
<p>Check continuity between smart entrance control unit terminal 39 and ground.</p>	
<p style="text-align: right;">SEL789V</p>	
<p>Continuity: Rear window defogger switch is pushed. Yes Rear window defogger switch is released. No</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> • Rear window defogger switch (Refer to EL-99.) • Harness for open or short between control unit and rear window defogger switch • Rear window defogger switch ground circuit

2	CHECK DEFOGGER RELAY COIL SIDE CIRCUIT
<p>1. Disconnect control unit connector. 2. Turn ignition switch to ON position. 3. Check voltage between smart entrance control unit terminal 2 and ground.</p>	
<p style="text-align: right;">SEL788V</p>	
<p>Does battery voltage exist?</p>	
Yes	▶ GO TO 3.
No	<p>▶ Check the following.</p> <ul style="list-style-type: none"> • 10A fuse [No. 8, located in the fuse block (J/B)] • Rear window defogger relay • Harness for open or short between rear window defogger relay and control unit

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

4
CHECK IGNITION INPUT SIGNAL

Check voltage between smart entrance control unit terminal 33 and ground.

Smart entrance control unit connector (M24)

SEL790V

Voltage [V]:
 Ignition switch is "ON".
 Approx. 12
 Ignition switch is "OFF".
 0

OK or NG

OK	▶	GO TO 5.
NG	▶	Check the following. <ul style="list-style-type: none"> 10A fuse [No. 8, located in the fuse block (J/B)] Harness for open or short between control unit and fuse

5
CHECK CONTROL UNIT GROUND CIRCUIT

Check continuity between smart entrance control unit terminal 16 and ground.


Smart entrance control unit connector (M23)

SEL791V

Does continuity exist?

Yes	▶	Replace control unit.
No	▶	Repair harness or connectors.

GI
MA
EM
LC
EC
FE



Electrical Components Inspection REAR WINDOW DEFOGGER RELAY


NCEL0076

Check continuity between terminals 3 and 5, 6 and 7.

NCEL0076S01

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

ST
RS
BT
HA



REAR WINDOW DEFOGGER SWITCH

NCEL0076S02


Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No

SC
EL
IDX

REAR WINDOW DEFOGGER


Filament Check




Filament Check

NCEL0077

1. Attach probe circuit tester (in volt range) to middle portion of each filament.



2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

Filament Repair

NCEL0078


REPAIR EQUIPMENT

NCEL0078S01

- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth

REAR WINDOW DEFOGGER

Filament Repair (Cont'd)



REPAIRING PROCEDURE

NCELO078S02


1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.


3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUDIO

System Description

System Description

NCEL0079

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse [No. 38, located in the fuse block (J/B)]
- to speaker amp. terminal 11, and
- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to audio terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 10, located in the fuse block (J/B)]
- to audio terminal 10.

Ground is supplied through the case of the audio.

Ground is supplied

- to speaker amp. terminal 23,
- through body grounds B109 and B110.

Audio signals are supplied

- through audio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to speaker amp. terminals 4, 5, 6, 7, 17, 18, 19 and 20.

Audio signals are amplified by the speaker amp.

The amplified audio signals are supplied

- through speaker amp. terminals 1, 2, 12, 13, 14, 15, 25 and 26
- to terminals 1 and 2 of the front door speaker LH and RH
- to terminals 1 and 2 of the tweeter LH and RH
- to terminals 1 and 2 of the rear speaker LH and RH.






AUDIO

Wiring Diagram — AUDIO —

Wiring Diagram — AUDIO —

NCEL0081

EL-AUDIO-01



Refer to last page (Foldout page).




GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL912A

AUDIO

Wiring Diagram — AUDIO — (Cont'd)

EL-AUDIO-02



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M16) W
(M72) W



(M18) BR
(M69) BR

(D3) BR
(D22) BR

10	8	4	2
9	7	6	5

(M50) W

1	2	3	4
5	6	7	8

(M74) G

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

(M75) W

1	2	4	5	6	7	9	11	12	13
14	15	17	18	19	20	23	25	26	

(B114) GY

AUDIO

Trouble Diagnoses

Trouble Diagnoses

NCEL0082

NCEL0082501

RADIO

Symptom	Possible causes	Repair order	
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Poor radio case ground 3. Radio 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 10, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of radio. 2. Check radio case ground. 3. Remove radio for repair. 	GI MA EM
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 1. 10A fuse 2. Radio 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 24, located in fuse block (J/B)] and verify that battery positive voltage is present at terminal 6 of radio. 2. Remove radio for repair. 	LC EC
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> 1. Antenna 2. Poor radio ground 3. Radio 	<ol style="list-style-type: none"> 1. Check antenna. 2. Check radio ground. 3. Remove radio for repair. 	FE CL
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> 1. Window antenna 2. Radio 	<ol style="list-style-type: none"> 1. Check window antenna. 2. Remove radio for repair. 	MT AT
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> 1. Poor radio ground 2. Loose or missing ground bonding straps 3. Ignition condenser or rear window defogger noise suppressor condenser 4. Alternator 5. Ignition coil or secondary wiring 6. Radio 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check ground bonding straps. 3. Replace ignition condenser or rear window defogger noise suppressor condenser. 4. Check alternator. 5. Check ignition coil and secondary wiring. 6. Remove radio for repair. 	AX SU
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> 1. Poor radio ground 2. Antenna 3. Accessory ground 4. Faulty accessory 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check antenna. 3. Check accessory ground. 4. Replace accessory. 	BR ST RS
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> 1. 10A fuse 2. Radio output 3. Radio 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of speaker amp. 2. Check radio output voltage (Terminal 12). 3. Remove radio for repair. 	BT HA
All speakers are inoperative.	<ol style="list-style-type: none"> 1. Speaker amp. ground 2. Amp. ON signal 	<ol style="list-style-type: none"> 1. Check speaker amp. 2. Check speaker amp. ground (Terminal 23). 3. Turn ignition switch ACC and radio ON. Verify battery positive voltage is present at terminal 9 of speaker amp. 	SC EL
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none"> 1. Speaker 2. Speaker amp. output 3. Speaker circuit 4. Radio 	<ol style="list-style-type: none"> 1. Check speaker. 2. Check speaker amp. output. 3. Check wires for open or short between radio/amp. and speakers. 4. Remove radio for repair. 	HA SC EL

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUDIO

Inspection

Inspection

RADIO AND AMP.

=NCEL0083

NCEL0083S01

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amps. connected (If radio or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

ANTENNA

NCEL0083S02

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface).
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

AUDIO ANTENNA

System Description

System Description

NCEL0084

Power is supplied at all times

- through 10A fuse [No. 24, located in the fuse block (J/B)]
- to power antenna terminal 6.

Ground is supplied to the power antenna terminal 2 through body grounds B109 and B110.

When the audio is turned to the ON position, battery positive voltage is supplied

- through audio terminal 5
- to power antenna terminal 4.

The antenna raises and is held in the extended position.

When the audio is turned to the OFF position, battery positive voltage is interrupted

- from audio terminal 5
- to power antenna terminal 4.

The antenna retracts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX






AUDIO ANTENNA

Wiring Diagram — P/ANT —

Wiring Diagram — P/ANT —

NCEL0085

EL-P/ANT-01



Refer to last page (Foldout page).



AUDIO ANTENNA

Trouble Diagnoses

Trouble Diagnoses

NCEL0086


NCEL0086S01

POWER ANTENNA


Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 10A fuse Radio signal Grounds B109 and B110 	<ol style="list-style-type: none"> Check 10A fuse [No. 24, located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal 6 of power antenna. Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal 4 of power antenna. Check grounds B109 and B110.

Location of Antenna

NCEL0087



MEL294H



MEL295H

Antenna Rod Replacement REMOVAL

1. Remove antenna nut and antenna base.

NCEL0088

NCEL0088S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)



2. Withdraw antenna rod while raising it by operating antenna motor.



INSTALLATION

NCEL0088S02

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut [Tightening torque: 2.0 - 3.9 N·m (0.2 - 0.4 kg·m, 17.4 - 34.7 in-lb)] and base.



POWER SUNROOF

Wiring Diagram — SROOF —

Wiring Diagram — SROOF —

NCEL0089

EL-SROOF-01



Refer to last page (Foldout page).

(M6), (E75)
(M2)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TEL915A


DOOR MIRROR

Wiring Diagram — MIRROR —

Wiring Diagram — MIRROR —

NCEL0090

EL-MIRROR-01




1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M16) W
(M72) W

2	3		1
5	7	4	6

(M27) GY



Refer to last page (Foldout page).

(M1)



POWER SEAT

Wiring Diagram — SEAT —

Wiring Diagram — SEAT —

NCEL0092


EL-SEAT-01



(M7)
W



(M14) (B14)
W W



(EL1)*
W

(EL2)*
B

(EL3)*
W

Refer to last page (Foldout page).

(M6) (E75)

*: This connector is not shown in "HARNESS LAYOUT", EL section.

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

TEL918A


HEATED SEAT

Wiring Diagram — HSEAT —

Wiring Diagram — HSEAT —


NCELD093

EL-HSEAT-01



Refer to EL-POWER.

Refer to last page (Foldout page).



*: This connector is not shown in "HARNES LAYOUT", EL section.


TEL919A

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL0094










Fuse block (J/B)

1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23		
24	25	26		
27	28	29		

Front

Fuse and fusible link box



SEL836V

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description

System Description

NCEL0095

Refer to Owner's Manual for ASCD operating instructions.

POWER SUPPLY AND GROUND

NCEL0095S03

When ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to ASCD hold relay terminal 5 and
- to ASCD main switch terminal 1.

When ASCD main switch is in ON position, power is supplied

- from ASCD main switch terminal 3
- to ASCD hold relay terminal 2.

Ground is supplied

- to ASCD hold relay terminal 1
- through body grounds M15, M71 and M76.

With power and ground is supplied, the ASCD hold relay is energized, then power is supplied

- from ASCD hold relay terminal 3
- to ASCD control unit terminal 4 and
- to ASCD main switch terminal 2.

After the ASCD main switch is released, power remains supplied

- to the coil circuit of ASCD hold relay
- through ASCD main switch terminals 2 and 3.

This power supply is kept until any of following conditions exist.

- Ignition switch is returned to the ACC or OFF position.
- ASCD main switch is turned to OFF position.

During ASCD hold relay is energized power is also supplied to ASCD control unit terminal 5

- through ASCD brake switch, ASCD hold relay and park/neutral position relay, (A/T models) or
- through ASCD hold relay, ASCD clutch switch and ASCD brake switch, (M/T models).

Ground is supplied

- to ASCD control unit terminal 3
- through body grounds M15, M71 and M76.

INPUTS

NCEL0095S01

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- park/neutral position relay (A/T models)
- ASCD brake switch.
- ASCD clutch switch (M/T models)

A vehicle speed input signal is supplied

- to ASCD control unit terminal 7
- from terminal 32 of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal 1
- through 15A fuse [No. 14, located in the fuse block (J/B)].

When the brake pedal is depressed, power is supplied

- from terminal 2 of the stop lamp switch
- to ASCD control unit terminal 11.

Power is supplied at all times

- through 10A fuse [No. 36, located in the fuse and fusible link box]
- to horn low relay terminal 2 and
- through 10A fuse [No. 41, located in the fuse and fusible link box]

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

- to horn high relay terminal 2
- through terminal 1 of each horn relay
- to ASCD steering switch terminal 21.

GI

When the SET/COAST switch is depressed, power is supplied

- from terminal 23 of the ASCD steering switch
- to ASCD control unit terminal 2.

MA

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal 22 of the ASCD steering switch
- to ASCD control unit terminal 1.

EM

When the system is activated, power is supplied

- to ASCD control unit terminal 5.

LC

Power is interrupted when

- the selector lever is placed in P or N or
- the ASCD brake switch is depressed or
- the ASCD clutch switch is depressed (M/T models).

EC

FE

OUTPUTS

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. NCEL0095S02

CL

The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal 8 of the ASCD control unit
- to ASCD pump terminal 1.

MT

Ground is supplied to the vacuum motor

- from terminal 9 of the ASCD control unit
- to ASCD pump terminal 4.

AT

Ground is supplied to the air valve

- from terminal 10 of the ASCD control unit
- to ASCD pump terminal 2.

AX

Ground is supplied to the release valve

- from terminal 14 of the ASCD control unit
- to ASCD pump terminal 3.

SU

BR

When the system is activated, power is supplied

- from terminal 13 of the ASCD control unit
- to combination meter terminal 40 and
- to TCM (Transmission control module) terminal 18.

ST

Ground is supplied

- to combination meter terminal 39
- through body grounds M15, M71 and M76.

RS

BT

With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed, a signal is sent

- from terminal 12 of the ASCD control unit
- to TCM (Transmission control module) terminal 24.

HA

When this occurs, the TCM (Transmission control module) cancels overdrive.

SC

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

EL


IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic

NCEL0096

Schematic



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —

FIG. 1



Wiring Diagram — ASCD —

NCEL0097

NCEL0097S01

EL-ASCD-01

⬡ A : With A/T
⬡ M : With M/T



Refer to last page (Foldout page).

⬡ M2

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 2

NCEL0097502

EL-ASCD-02




Refer to EL-POWER.

⊖ A : With A/T

⊖ M : With M/T

Refer to last page (Foldout page).



TEL923A


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)


FIG. 3

NCEL0097503

EL-ASCD-03



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX



Refer to last page (Foldout page).
 M6, E75

*: This connector is not shown in "HARNES LAYOUT", EL section.

TEL924A





AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

FIG. 4

NCEL0097504

EL-ASCD-04




Refer to last page (Foldout page).

(M6) (E75)
(M2)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Fail-safe System



Fail-safe System

DESCRIPTION

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

NCEL0098

NCEL0098S01

GI

MA

EM

LC

MALFUNCTION DETECTION CONDITIONS

NCEL0098S02

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. Vacuum motor ground circuit or power circuit is open or shorted. Air valve ground circuit or power circuit is open or shorted. Release valve ground circuit or power circuit is open or shorted. Vehicle speed sensor is faulty. ASCD control unit internal circuit is malfunctioning. 	<ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is canceled.
<ul style="list-style-type: none"> ASCD brake switch or stop lamp switch is faulty. 	<ul style="list-style-type: none"> ASCD is deactivated. Vehicle speed memory is not canceled.

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NCEL0099

NCEL0099S01

PROCEDURE	Diagnostic procedure								
REFERENCE PAGE (EL-)	125	126	127	128	129	130	131	131	132
SYMPTOM	FAIL-SAFE SYSTEM CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	ASCD MAIN SWITCH CHECK	ASCD HOLD RELAY CHECK	ASCD BRAKE/STOP LAMP SWITCH CHECK	ASCD STEERING SWITCH CHECK	VEHICLE SPEED SENSOR CHECK	ASCD PUMP CIRCUIT CHECK	ASCD ACTUATOR/PUMP CHECK
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)		X	X	X		X	X		
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X				X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.						X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2						X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.						X			X
System is not released after CANCEL switch (steering) has been pressed.						X			X
Large difference between set speed and actual vehicle speed.									X
Deceleration is greatest immediately after ASCD has been set.									X

★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "FAIL-SAFE SYSTEM CHECK" (EL-125) to verify repairs.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)


—NCEL0099S02



CRUISE


SEL174V

SET/COAST
switch "ON"



SEL767P

Brake pedal



SAT797A

FAIL-SAFE SYSTEM CHECK

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the "cruise indicator" blinks.

If the indicator lamp blinks, check the following.

- ASCD steering switch. Refer to EL-130.

3. Drive the vehicle at more than 48 km/h (30 MPH) and push SET/COAST switch.

If the indicator lamp blinks, check the following.

- Vehicle speed sensor. Refer to EL-131.
- ASCD pump circuit. Refer to EL-131.
- Replace control unit.

4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

If the indicator lamp blinks, check the following.

- ASCD brake/stop lamp switch. Refer to EL-129.

5. END. (System is OK.)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

#NCEL0099S03

1	OPERATION CHECK	
1. Turn ignition switch ON. 2. Turn ASCD main switch "ON".		
Does ASCD indicator illuminate?		
Yes	▶	GO TO 2.
No	▶	Go to ASCD MAIN SWITCH CHECK. Refer to EL-127.

2	CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT	
1. Disconnect ASCD control unit connector. 2. Turn ignition switch ON. 3. Turn ASCD main switch "ON". 4. Check voltage between control unit connector terminal 4 and ground.		
ASCD control unit connector (M19)		
		
SEL289UJ		
Refer to wiring diagram in EL-119.		
Does battery voltage exist?		
Yes	▶	GO TO 3.
No	▶	Go to ASCD HOLD RELAY CHECK. Refer to EL-128.


3	CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT	
Check continuity between ASCD control unit harness terminal 3 and body ground.		
		
SEL764UE		
Refer to wiring diagram in EL-122.		
Does continuity exist?		
Yes	▶	Power supply and ground circuit is OK.
No	▶	Repair harness.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD MAIN SWITCH CHECK

=NCEL0099S04

1	CHECK POWER SUPPLY FOR ASCD MAIN SWITCH
<p>1. Disconnect main switch connector. 2. Check voltage between main switch terminals 1 and 4.</p> <div style="text-align: center;">  <p>ASCD main switch connector (M28)</p> </div> <p>Refer to wiring diagram in EL-119.</p> <p style="text-align: right;">MEL842FD</p>	
Does battery voltage exist?	
Yes	▶ GO TO 2.
No	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse (No. 11, located in the fuse block) ● Harness for open or short between fuse and ASCD main switch ● Ground circuit for ASCD main switch

2	CHECK ASCD MAIN SWITCH
Refer to "Electrical Component Inspection" (EL-133).	
OK or NG	
OK	▶ Go to ASCD HOLD RELAY CHECK. Refer to EL-128.
NG	▶ Replace ASCD main switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD HOLD RELAY CHECK

=NCEL0099S05

1	CHECK POWER SUPPLY CIRCUIT FOR ASCD HOLD RELAY
<p>1. Disconnect ASCD hold relay. 2. Check voltage between ASCD hold relay terminal 5 and body ground.</p>	
(A) : With A/T (M) : With M/T SEL865V	
<p>Refer to wiring diagram in EL-119.</p> <p style="text-align: center;">Does battery voltage exist?</p>	
Yes	▶ GO TO 2.
No	<p style="text-align: center;">Check the following.</p> <ul style="list-style-type: none"> ● 7.5A fuse (No. 11, located in the fuse block) ● Harness for open or short between fuse and ASCD hold relay

2	CHECK GROUND CIRCUIT FOR ASCD HOLD RELAY
<p>Check continuity between ASCD hold relay terminal 1 and ground.</p>	
(A) : With A/T (M) : With M/T SEL866V	
Does continuity exist?	
Yes	▶ GO TO 3.
No	▶ Repair harness.

3	CHECK ASCD HOLD RELAY
<p>Check ASCD hold relay.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ Replace ASCD hold relay.

4	CHECK ASCD MAIN SWITCH
<p>Refer to "Electrical Component Inspection" (EL-133).</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Replace ASCD main switch.

5	CHECK ASCD HOLD RELAY OPEN OR SHORT CIRCUIT
<p>1. Connect ASCD main switch. 2. Check continuity between ASCD hold relay terminals 2 and 3.</p>	
(A) : With A/T (M) : With M/T SEL867V	
Continuity should exist.	
<p>3. Check continuity between ASCD hold relay terminal 2 and ground.</p>	
(A) : With A/T (M) : With M/T SEL868V	
Continuity should not exist.	
OK or NG	
OK	▶ ASCD hold relay is OK.
NG	▶ Repair harness.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ASCD BRAKE/STOP LAMP SWITCH CHECK

#NCEL0099S06

1	CHECK ASCD BRAKE SWITCH CIRCUIT
<p>1. Disconnect control unit connector. 2. Turn ignition switch ON. 3. Turn ASCD main switch "ON". 4. Check voltage between control unit connector terminal 5 and ground.</p> <p>When brake pedal is depressed or A/T selector lever is in "N" or "P" range: Approx. 0V</p> <p>When both brake pedal is released and A/T selector lever is not in "N" or "P" range: Battery voltage should exist.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL765UJ</p>	
Refer to wiring diagram in EL-120.	
OK or NG	
OK	▶ GO TO 2.
NG	<p>Check the following.</p> <ul style="list-style-type: none"> ● ASCD brake switch Refer to "Electrical Component Inspection" (EL-133). ● Inhibitor switch Refer to "Electrical Component Inspection" (EL-133). ● ASCD hold relay ● Harness for open or short

2	CHECK STOP LAMP SWITCH CIRCUIT
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 11 and ground.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SEL759UG</p>	
<p>Voltage [V]: Stop lamp switch: Depressed Approx. 12 Stop lamp switch: Released 0</p> <p>Refer to wiring diagram in EL-121.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ ASCD brake/stop lamp switch is OK.
NG	<p>Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 14, located in the fuse block (J/B)] ● Harness for open or short between ASCD control unit and stop lamp switch ● Stop lamp switch Refer to "Electrical Component Inspection" (EL-133).


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)

ASCD STEERING SWITCH CHECK

=NCEL0099S07

1	CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT																												
<p>1. Disconnect control unit connector. 2. Check voltage between control unit harness terminals and ground.</p>																													
 <p>ASCD control unit connector (M19)</p>																													
SEL760UG																													
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminal No.</th> <th colspan="2">Switch condition</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>Pressed</th> <th>Released</th> </tr> </thead> <tbody> <tr> <td>SET/COAST SW</td> <td>2</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td>RESUME/ACC SW</td> <td>1</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td rowspan="2">CANCEL SW</td> <td>2</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> <tr> <td>1</td> <td>ground</td> <td>12V</td> <td>0V</td> </tr> </tbody> </table>			Terminal No.		Switch condition		(+)	(-)	Pressed	Released	SET/COAST SW	2	ground	12V	0V	RESUME/ACC SW	1	ground	12V	0V	CANCEL SW	2	ground	12V	0V	1	ground	12V	0V
	Terminal No.		Switch condition																										
	(+)	(-)	Pressed	Released																									
SET/COAST SW	2	ground	12V	0V																									
RESUME/ACC SW	1	ground	12V	0V																									
CANCEL SW	2	ground	12V	0V																									
	1	ground	12V	0V																									
MTBL0002																													
Refer to wiring diagram in EL-121.																													
OK or NG																													
OK	▶ ASCD steering switch is OK.																												
NG	▶ GO TO 2.																												

2	CHECK POWER SUPPLY FOR ASCD STEERING SWITCH
Does horn work?	
Yes	▶ GO TO 3.
No	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse (No. 54, located in the relay box) ● Horn relay ● Harness for open or short between horn and fuse

3	CHECK ASCD STEERING SWITCH																						
<p>1. Disconnect ASCD steering switch. 2. Check continuity between terminals by pushing each switch.</p>																							
 <p>ASCD steering switch (RS3)</p>																							
SEL869V																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Switch</th> <th colspan="3">Terminal</th> </tr> <tr> <th>21</th> <th>22</th> <th>23</th> </tr> </thead> <tbody> <tr> <td>SET/COAST</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td>RESUME/ACCEL</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td rowspan="2">CANCEL</td> <td style="text-align: center;">○</td> <td style="text-align: center;">▶</td> <td style="text-align: center;">○</td> </tr> <tr> <td style="text-align: center;">○</td> <td style="text-align: center;">▶</td> <td style="text-align: center;">○</td> </tr> </tbody> </table>		Switch	Terminal			21	22	23	SET/COAST	○	○	○	RESUME/ACCEL	○	○	○	CANCEL	○	▶	○	○	▶	○
Switch	Terminal																						
	21	22	23																				
SET/COAST	○	○	○																				
RESUME/ACCEL	○	○	○																				
CANCEL	○	▶	○																				
	○	▶	○																				
MTBL0149																							
OK or NG																							
OK	▶ Check harness for open or short between ASCD steering switch and ASCD control unit.																						
NG	▶ Replace ASCD steering switch.																						


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

VEHICLE SPEED SENSOR CHECK


=NCEL0099S08

1	CHECK SPEEDOMETER OPERATION	
Refer to wiring diagram in EL-122.		
Does speedometer operate normally?		
Yes	▶	GO TO 2.
No	▶	Check speedometer and vehicle speed sensor circuit. Refer to EL-68.

2	CHECK VEHICLE SPEED INPUT	
<ol style="list-style-type: none"> 1. Apply wheel chocks and jack up drive wheel. 2. Disconnect control unit connector. 3. Check voltage between control unit terminal 7 and ground with turning drive wheel slowly. 		
		
SEL347VA		
Does voltage pointer deflect?		
Yes	▶	Vehicle speed sensor is OK.
No	▶	Check harness for open or short between ASCD control unit terminal 7 and combination meter terminal 36.

ASCD PUMP CIRCUIT CHECK

NCEL0099S09

1	CHECK ASCD PUMP										
<ol style="list-style-type: none"> 1. Disconnect ASCD pump connector. 2. Measure resistance between ASCD pump terminals 1 and 2, 3, 4. 											
											
SEL870V											
Refer to wiring diagram in EL-122.											
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 15%;">Terminals</th> <th style="width: 15%;">Resistance [Ω]</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">1</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Approx. 3</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approx. 65</td> </tr> <tr> <td style="text-align: center;">2</td> <td style="text-align: center;">Approx. 65</td> </tr> </tbody> </table>			Terminals	Resistance [Ω]	1	4	Approx. 3	3	Approx. 65	2	Approx. 65
Terminals	Resistance [Ω]										
1	4	Approx. 3									
	3	Approx. 65									
	2	Approx. 65									
MTBL0150											
OK or NG											
OK	▶	Check harness for open or short between ASCD pump and ASCD control unit.									
NG	▶	Replace ASCD pump.									


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)



ASCD ACTUATOR/PUMP CHECK

=NCEL0099S10

1	CHECK VACUUM HOSE
Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.	
	
MEL402G	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace hose.


2	CHECK ASCD WIRE
Check wire for improper installation, rust formation or breaks.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-134).

3	CHECK ASCD ACTUATOR
<ol style="list-style-type: none"> 1. Disconnect vacuum hose from ASCD actuator. 2. Apply -40 kPa (-0.41 kg/cm², -5.8 psi) vacuum to ASCD actuator with hand vacuum pump. ASCD wire should move to pull throttle drum. 3. Wait 10 seconds and check for decrease in vacuum pressure. 	
	
MEL403G	
Vacuum pressure decrease:	
Less than 2.7 kPa (0.028 kg/cm², 0.39 psi)	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace ASCD actuator.

4	CHECK ASCD PUMP																				
<ol style="list-style-type: none"> 1. Disconnect vacuum hose from ASCD pump and ASCD pump connector. 2. If necessary remove ASCD pump. 3. Connect vacuum gauge to ASCD pump. 4. Apply 12V direct current to ASCD pump and check operation. 																					
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">12V direct current supply terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Air valve</td> <td rowspan="4" style="text-align: center; vertical-align: middle;">1</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Close</td> </tr> <tr> <td>Release valve</td> <td style="text-align: center;">3</td> <td style="text-align: center;">Close</td> </tr> <tr> <td>Vacuum motor</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Operate</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>			12V direct current supply terminals		Operation	(+)	(-)	Air valve	1	2	Close	Release valve	3	Close	Vacuum motor	4	Operate				
	12V direct current supply terminals		Operation																		
	(+)	(-)																			
Air valve	1	2	Close																		
Release valve		3	Close																		
Vacuum motor		4	Operate																		
MTBL0151																					
																					
																					
SEL871V																					
A vacuum pressure of at least -40 kPa (-0.41 kg/cm², -5.8 psi) should be generated.																					
OK or NG																					
OK	▶ INSPECTION END																				
NG	▶ Replace ASCD pump.																				

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Electrical Component Inspection




Electrical Component Inspection

NCEL0100

ASCD MAIN SWITCH

NCEL0100S01

Check continuity between terminals by pushing switch to each position.




ASCD BRAKE SWITCH AND STOP LAMP SWITCH

NCEL0100S02

Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


Check each switch after adjusting brake pedal — refer to BR section.



ASCD CLUTCH SWITCH (FOR M/T MODELS)

NCEL0100S04

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes



PARK/NEUTRAL POSITION SWITCH (FOR A/T MODELS)

NCEL0100S03

A/T selector lever position	Continuity
	Between terminals 1 and 2
"P"	Yes
"N"	Yes
Except "P" and "N"	No


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

ASCD Wire Adjustment

ASCD Wire Adjustment

NCEL0107



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
3. Tighten adjusting nut just until throttle drum starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

System Description

NCEL0102

Power is supplied at all times

- from 30A fusible link (letter **d**, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3.

GI

MA

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to power window relay terminal 1.

EM

Ground is supplied to power window relay terminal 2

- through body grounds M15, M71 and M76.

LC

Then power window relay is energized and power is supplied

- through power window relay terminal 5
- to power window main switch terminal 1,
- to front power window sub-switch terminal 5.

EC

FE

MANUAL OPERATION

Front Door LH

NCEL0102S01

CL

NCEL0102S0101

Ground is supplied

- to power window main switch terminal 3
- through body grounds M15, M71 and M76.

MT

WINDOW UP

When the front LH switch in the power window main switch is pulled in the up position, power is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

AT

AX

Ground is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

SU

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to front power window regulator LH terminal 1
- through power window main switch terminal 8.

BR

ST

Ground is supplied

- to front power window regulator LH terminal 2
- through power window main switch terminal 9.

RS

Then, the motor lowers the window until the switch is released.

Front Door RH

NCEL0102S0102

BT

Ground is supplied

- to power window main switch terminal 3
- through body grounds M15, M71 and M76.

HA

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

SC

POWER WINDOW MAIN SWITCH OPERATION

Power is supplied

- through power window main switch 5 or 6
- to front power window switch (passenger side) 4 or 3.

EL

IDX

The subsequent operation is the same as the sub-switch operation.

POWER WINDOW SWITCH OPERATION

Power is supplied

- through front power window switch (passenger side) 2 or 1

POWER WINDOW

System Description (Cont'd)

- to front power window regulator (passenger side) 2 or 1.

Ground is supplied

- to front power window regulator (passenger side) 1 or 2
- through front power window switch (passenger side) 1 or 2
- to front power window switch (passenger side) 3 or 4
- through power window main switch 6 or 5.

Then, the motor raises or lowers the window until the switch is released.

Rear Door

Rear door windows will raise and lower in the same manner as front door RH window.

NCEL0102S0103

AUTO OPERATION

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

NCEL0102S02

The AUTO feature only operates on the driver's window downward movement.

POWER WINDOW LOCK

The power window lock is designed to lock operation of all windows except for driver's door window.

NCEL0102S03

When the lock switch is pressed to lock position, ground of the power window switches in the power window main switch is disconnected. This prevents the power window motors from operating.


POWER WINDOW

Schematic

NCEL0103

Schematic

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



TEL926A







POWER WINDOW

Wiring Diagram — WINDOW —

Wiring Diagram — WINDOW —

NCEL0104

EL-WINDOW-01




Refer to last page (Foldout page).

M6, E75, M2

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-02



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

M16 W M72 W

1	2
3	4
5	6

M17 W

8	9	4	6	5	3
13	15	16	1	11	10
14	7				

D6 W

4	1	3	2	5
---	---	---	---	---

D25 W

1	2
---	---

D26 B







- CI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

TEL928A

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-03



POWER WINDOW

Trouble Diagnoses

Trouble Diagnoses

NCELO105

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> 10A fuse, 30A fusible link and M13 circuit breaker Grounds M15, M71 and M76 Power window relay Open/short in power window main switch circuit 	<ol style="list-style-type: none"> Check 10A fuse [No. 8, located in fuse block (J/B)] 30A fusible link (letter d, located in fuse and fusible link box) and M13 circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminal 1 of power window main switch and terminal 5 of each power window switch. Check grounds M15, M71 and M76. Check power window relay. Check the wire between power window relay terminal 5 and power window main switch terminal 1 for open/short circuit.
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> Driver side power window regulator circuit Driver side power window regulator 	<ol style="list-style-type: none"> Check harness between power window main switch and power window regulator for open or short circuit. Check driver side power window regulator.
Passenger power window cannot be operated.	<ol style="list-style-type: none"> Power window switches Passenger side power window regulators Power window main switch Power window circuit 	<ol style="list-style-type: none"> Check power window switch. Check passenger side power window regulator. Check power window main switch. Check the following. <ol style="list-style-type: none"> Check harnesses between power window main switch and power window switch for open/short circuit. Check harnesses between power window switch and power window regulator for open/short circuit.
Passenger power window cannot be operated using power window main switch but can be operated by power window switch.	<ol style="list-style-type: none"> Power window main switch 	<ol style="list-style-type: none"> Check power window main switch.
Driver side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> Power window main switch 	<ol style="list-style-type: none"> Check power window main switch.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

POWER DOOR LOCK

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL0106



SEL837V

System Description

NCEL0107

NCEL0107S04

OPERATION


- The lock/unlock switch on driver's door trim can lock and unlock all doors.
- With the lock knob on front LH or RH door set to "LOCK", all doors are locked. (Signals from front door unlock sensor)
- With the door key inserted in the key cylinder on front LH or RH, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from door key cylinder switch)
- If the ignition key is in the ignition key cylinder and one or more of the front doors are open, setting the lock/unlock switch, lock knob, or the door key to "LOCK" locks the doors once but then immediately unlock them. (Combination signals from key switch, front LH or RH door switch and LH or RH door unlock sensor) - (KEY REMINDER DOOR SYSTEM)

POWER DOOR LOCK

Schematic

NCEL0108

Schematic



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL**
- IDX

TEL930A

POWER DOOR LOCK

Wiring Diagram — D/LOCK —


Wiring Diagram — D/LOCK —

NCEL0109

NCEL0109S01

FIG. 1


EL-D/LOCK-01



SMART ENTRANCE CONTROL UNIT (M23, M24)

Refer to EL-POWER.

Refer to last page (Foldout page).





POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 2

NCEL0109S02

EL-D/LOCK-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL932A

POWER DOOR LOCK



Wiring Diagram — D/LOCK — (Cont'd)

FIG. 3

NCEL0109S03

EL-D/LOCK-03

SMART
ENTRANCE
CONTROL
UNIT
M23, M24



TEL933A

POWER DOOR LOCK


Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NCEL0110

NCEL0110S01

REFERENCE PAGE (EL-)	147	148	149	150	151	152	153
SYMPTOM	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	FRONT DOOR SWITCH CHECK	KEY SWITCH (INSERT) CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	FRONT DOOR KEY CYLINDER SWITCH CHECK	FRONT DOOR UNLOCK SENSOR CHECK	DOOR LOCK ACTUATOR CHECK
Key reminder door system does not operate properly.	X	X	X			X	X
Specific door lock actuator does not operate.	X						X
Power door lock does not operate with door lock and unlock switch on power window main switch.	X			X			
Power door lock does not operate with front door key cylinder operation.	X				X		
Power door lock does not operate with front door lock knob switch.	X					X	



MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

NCEL0110S02


Main Power Supply Circuit Check

NCEL0110S0201

Terminal		Ignition switch		
(+)	(-)	OFF	ACC	ON
11	Ground	Battery voltage	Battery voltage	Battery voltage

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)



Ground Circuit Check

NCELO110S0202

Terminals	Continuity
16 - Ground	Yes

FRONT DOOR SWITCH CHECK

NCELO110S06

1	CHECK DOOR SWITCH INPUT SIGNAL																					
Check voltage between control unit terminals 15 or 35 and ground.																						
	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">29</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">Front RH door switch</td> <td rowspan="2">40</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> </tbody> </table>		Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door switch	29	ground	Open	0	Closed	Approx. 12	Front RH door switch	40	ground	Open	0	Closed	Approx. 12
	Terminals		Condition	Voltage [V]																		
	(+)	(-)																				
Front LH door switch	29	ground	Open	0																		
			Closed	Approx. 12																		
Front RH door switch	40	ground	Open	0																		
			Closed	Approx. 12																		
<p>Smart entrance control unit connector (M24)</p> <p>29</p> <p>40</p> <p>R/L</p> <p>SB</p> <p>V</p> <p>H.S. CONNECT</p> <p>OFF</p> <p>MTBL0152</p> <p>SEL882V</p>																						
Refer to wiring diagram in EL-144.																						
OK or NG																						
OK	▶ Door switch is OK.																					
NG	▶ GO TO 2.																					

2	CHECK DOOR SWITCH
Check continuity between terminals 2 and 3.	
<p>Door switch connector</p> <p>Front LH (B4)</p> <p>Front RH (B22)</p> <p>2</p> <p>3</p> <p>Ω</p> <p>T.S. DISCONNECT</p> <p>SEL883V</p>	
Continuity: Door switch is pushed. No Door switch is released. Yes	
OK or NG	
OK	▶ Check the following. ● Door switch ground circuit ● Harness for open or short between control unit and door switch
NG	▶ Replace door switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK

=NCEL0110S06

1	CHECK KEY SWITCH INPUT SIGNAL
Check voltage between control unit terminal 32 and ground.	
Refer to wiring diagram in EL-144.	
Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0	
OK or NG	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
Check continuity between terminals 1 and 2.	
Continuity:	
Condition of key switch: Key is inserted.	
Yes	
Condition of key switch: Key is removed.	
No	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> ● 10A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between control unit and key switch
NG	▶ Replace key switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DOOR LOCK/UNLOCK SWITCH CHECK

=NCEL0110903

1	CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL	
<p>1. Disconnect control unit connector. 2. Check continuity between control unit terminal 23 or 35 and ground.</p>		
Terminals	Door lock/unlock switch (LH or RH) condition	Continuity
23 - ground	Lock	Yes
	N and Unlock	No
35 - ground	Unlock	Yes
	N and Lock	No

MTBL0153

Smart entrance control unit connector (M24)

DISCONNECT

SEL875V

Refer to wiring diagram in EL-144.

OK or NG

OK	▶	Door lock/unlock switch is OK.
NG	▶	GO TO 2.

2	CHECK DOOR LOCK/UNLOCK SWITCH		
<p>1. Disconnect door lock/unlock switch connector. 2. Check continuity between each door lock/unlock switch terminals.</p> <ul style="list-style-type: none"> Power window main switch (Door lock/unlock switch LH) 			
Condition	Terminals		
	3	14	7
Unlock	○	○	○
N	No continuity		
Lock	○	○	○

MTBL0154

Door lock/unlock switch driver side

DISCONNECT

P/W main switch connector (D6)

SEL876V

OK or NG

OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> Ground circuit for door lock/unlock switch Harness for open or short between door lock/unlock switch and control unit connector
NG	▶	Replace door lock/unlock switch.

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

FRONT DOOR KEY CYLINDER SWITCH CHECK

=NCEL0110S07

1	CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																		
Check voltage between control unit terminals 30 or 41 and ground.																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">41</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Lock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">30</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>		Terminals		Key position	Voltage [V]	(+)	(-)	41	Ground	Neutral	Approx. 12	Lock	0	30	Ground	Neutral	Approx. 12	Unlock	0
Terminals		Key position	Voltage [V]																
(+)	(-)																		
41	Ground	Neutral	Approx. 12																
		Lock	0																
30	Ground	Neutral	Approx. 12																
		Unlock	0																
MTBL0155																			
SEL878V																			
Refer to wiring diagram in EL-145.																			
OK or NG																			
OK	▶ Door key cylinder switch is OK.																		
NG	▶ GO TO 2.																		

2	CHECK DOOR KEY CYLINDER SWITCH															
<ol style="list-style-type: none"> Disconnect door key cylinder switch connector. Check continuity between door key cylinder switch terminals. 																
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>LH: 3 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td>RH: 1 - 2</td> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td>LH: 1 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td>RH: 3 - 2</td> <td style="text-align: center;">Lock</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table>		Terminals	Key position	Continuity	LH: 3 - 2	Neutral	No	RH: 1 - 2	Unlock	Yes	LH: 1 - 2	Neutral	No	RH: 3 - 2	Lock	Yes
Terminals	Key position	Continuity														
LH: 3 - 2	Neutral	No														
RH: 1 - 2	Unlock	Yes														
LH: 1 - 2	Neutral	No														
RH: 3 - 2	Lock	Yes														
MTBL0156																
SEL880UA																
OK or NG																
OK	▶ Check the following. <ul style="list-style-type: none"> ● Door key cylinder switch ground circuit ● Harness for open or short between control unit and door key cylinder switch 															
NG	▶ Replace door key cylinder switch.															

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

POWER DOOR LOCK


Trouble Diagnoses (Cont'd)

FRONT DOOR UNLOCK SENSOR CHECK

=NCEL0110S09

1	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL			
Check voltage between control unit terminals 12 or 13 and ground.				
	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door	36	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	37	Ground	Locked	Approx. 12
			Unlocked	0

MTBL0157





SEL877V

Refer to wiring diagram in EL-146.

OK or NG

OK	▶	Door unlock sensor is OK.
NG	▶	GO TO 2.

2	CHECK DOOR UNLOCK SENSOR		
<ol style="list-style-type: none"> 1. Disconnect door unlock sensor connector. 2. Check continuity between door unlock sensor terminals 4 and 2. 			
<p>Door lock actuator connectors</p> <p>Front LH : (D9)</p> <p>Front RH : (D28)</p>			
			
			
SEL247VB			
<p>Continuity:</p> <p>Condition: Locked</p> <p style="padding-left: 20px;">No</p> <p>Condition: Unlocked</p> <p style="padding-left: 20px;">Yes</p>			
OK or NG			
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> ● Door unlock sensor ground circuit ● Harness for open or short between control unit and door unlock sensor 	
NG	▶	Replace door unlock sensor.	

DOOR LOCK ACTUATOR CHECK

=NCEL0110304

1 CHECK DOOR LOCK ACTUATOR CIRCUIT

Check voltage for door lock actuator.

- Door lock actuator front LH

SEL879V

Door lock/unlock switch condition	Terminal No.		Voltage (V)
	(+)	(-)	
Lock	15	ground	Approx. 12
Unlock	13	ground	

MTBL0192

- Door lock actuator front RH and rear

SEL880V

Door lock/unlock switch condition	Terminal No.		Voltage (V)
	(+)	(-)	
Lock	15	ground	Approx. 12
Unlock	14	ground	

MTBL0193

Refer to wiring diagram in EL-146.

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace smart entrance control unit. (Before replacing control unit, perform "DOOR LOCK/UNLOCK SWITCH CHECK".)

2 CHECK DOOR LOCK ACTUATOR

- Disconnect door lock actuator connector.
- Apply 12V direct current to door lock actuator and check operation.

- Door lock actuator operation:

SEL736UC

Door lock actuator connector

Front LH: (D9)

Front RH: (D28)

Rear LH: (D44)

Rear RH: (D64)

Terminals between (+): 3 and (-): 1
Unlocked → Locked

Terminals between (+): 1 and (-): 3
Locked → Unlocked

OK	▶	Check harness for open or short between control unit connector and door lock actuator.
NG	▶	Replace door lock actuator.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCEL011



SEL838V

System Description

INPUTS

Power is supplied at all times

- to key switch terminal 1
- through 10A fuse [No. 24, located in the fuse block (J/B)].

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 32.

When the front door switch (driver side) is OPEN, ground is supplied

- to smart entrance control unit terminal 29
- through front door switch (driver side) terminal 2
- to front door switch (driver side) terminal 3
- through body grounds B7 and B24.

When the front door switch (passenger side) is OPEN, ground is supplied

- to smart entrance control unit terminal 40
- through front door switch (passenger side) terminal 1
- through the front door switch RH case ground.

When the each door switch is OPEN, ground is supplied

- to smart entrance control unit terminal 28
- through each door switch case ground.

NCEL0112

NCEL0112S01

MULTI-REMOTE CONTROL SYSTEM

System Description (Cont'd)

When the front door lock actuator (driver side) (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal 36
- through door lock actuator (driver side) (door unlock sensor) terminal 4
- to door lock actuator (driver side) (door unlock sensor) terminal 2
- through body grounds M15, M71 and M76.

GI

When the front door lock actuator (passenger side) (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 37 in the same manner as front door lock actuator (driver side).

MA

When the rear door lock actuator LH or RH (door unlock sensor) is UNLOCKED, ground is supplied to smart entrance control unit terminal 26 in the same manner as other door lock actuator.

EM

Remote controller signal is inputted to smart entrance control unit (the antenna of the system is combined with smart entrance control unit).

LC

Then smart entrance control unit supplies power and ground to each door lock actuator.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard reminder

EC

FE

OPERATED PROCEDURE

Power Door Lock Operation

NCEL0112S02

CL

NCEL0112S0201

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

MT

The two above signals are already input into smart entrance control unit. At this point, smart entrance control unit receives a LOCK signal from remote controller. Smart entrance control unit locks all doors with input of LOCK signal from remote controller.

AT

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

AX

Then, if an UNLOCK signal is sent from remote controller again within 5 seconds, all other door will be unlocked.

Hazard Reminder

NCEL0112S0204

SU

Power is supplied at all times

- to multi-remote control relay terminals 1, 3 and 6
- through 10A fuse [No. 20, located in the fuse block (J/B)].

BR

When smart entrance control unit receives a LOCK signal from remote controller, ground is supplied

- to multi-remote control relay terminal 2
- through smart entrance control unit terminal 7.

ST

Multi-remote control relay is now energized, and hazard warning lamp flash twice as a reminder. For detailed description, refer to "TURN SIGNAL AND HAZARD WARNING LAMPS" (EL-46).

RS

Interior Lamp Operation

NCEL0112S0202

BT

When the following input signals are both supplied:

- key switch OFF (when ignition key is not inserted in key cylinder);
- door switch CLOSED (when all the doors are closed);

HA

multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

SC

For detailed description, refer to "SMART ENTRANCE CONTROL UNIT" (EL-190).

Panic Alarm Operation

NCEL0112S0203

EL

When key switch is OFF (when ignition key is not inserted in key cylinder), multi-remote control system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from remote controller.

For detailed description, refer to "THEFT WARNING SYSTEM" (EL-169).

IDX

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI —

Wiring Diagram — MULTI —

NCEL0114





NCEL0114S01

FIG. 1

EL-MULTI-01

Refer to EL-POWER.

SMART
ENTRANCE
CONTROL
UNIT
(M23, M24)



Refer to last page (Foldout page).

- (M6), (E75)
- (M1)
- (M2)
- (M3)
- (E72)


MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

FIG. 2

NCEL0114502

EL-MULTI-02



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Refer to last page (Foldout page).



TEL935A

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses

Trouble Diagnoses SYMPTOM CHART

NCEL0115

NCEL0115S01

Symptom	Diagnoses/service procedure	Reference page (EL-)
All function of multi-remote control system do not operate.	1. Remote controller battery check	159
	2. Key switch (insert) check	162
	3. Door switch check	161
	4. Power supply and ground circuit for control unit check	159
	5. Replace remote controller. Refer to ID Code Entry Procedure.	166
The new ID of remote controller cannot entered.	1. Remote controller battery check	159
	2. Key switch (insert) check	162
	3. Door switch check	161
	4. Door unlock sensor check	163
	5. Power supply and ground circuit for control unit check	159
	6. Replace remote controller. Refer to ID Code Entry Procedure.	166
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to EL-147.)	1. Key switch (insert) input signal check	162
	2. Door switch check	161
	3. Door unlock sensor check	163
	4. Replace remote controller. Refer to ID Code Entry Procedure.	166
Hazard indicator does not flash twice when pressing lock button of remote controller.	1. Hazard reminder check	164
	2. Replace remote controller. Refer to ID Code Entry Procedure.	166
Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller.	1. Interior room lamp operation check	165
	2. Replace remote controller. Refer to ID Code Entry Procedure.	166
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed more than 1.5 seconds.	1. Theft warning operation check. Refer to "PRELIMINARY CHECK" in "THEFT WARNING SYSTEM".	177
	2. Replace remote controller. Refer to ID Code Entry Procedure.	166

NOTE:

- The unlock and panic alarm operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
- The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder or if one of the doors is opened.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

REMOTE CONTROLLER BATTERY CHECK

=NCEL0115502

1	CHECK REMOTE CONTROLLER BATTERY
<p>Remove battery (refer to EL-167) and measure voltage across battery positive and negative terminals, (+) and (-). NOTE: Remote controller does not function if battery is not set correctly.</p>	
<p>Voltage [V]: 2.5 - 3.0</p> <p style="text-align: right;">SEL277V</p>	
OK or NG	
OK	▶ Check remote controller battery terminals for corrosion or damage.
NG	▶ Replace battery.

POWER SUPPLY AND GROUND CIRCUIT CHECK

NCEL0115504

1	CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT
<p>1. Disconnect connector from control unit. 2. Check voltage between control unit terminals 10 or 11 and ground.</p>	
<p>Refer to wiring diagram in EL-156.</p> <p style="text-align: right;">SEL884V</p>	
Does battery voltage exist?	
Yes	▶ GO TO 2.
No	▶ Check the following. <ul style="list-style-type: none"> ● 30A fusible link (letter d, located in fuse and fusible link box) ● 10A fuse [No. 24, located in fuse block (J/B)] ● M13 circuit breaker ● Harness for open or short between control unit and circuit breaker

2	CHECK IGNITION SWITCH "ACC" CIRCUIT
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 21 and ground while ignition switch is "ACC".</p>	
<p>Refer to wiring diagram in EL-156.</p> <p style="text-align: right;">SEL885V</p>	
Does battery voltage exist?	
Yes	▶ GO TO 3.
No	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 10, located in fuse block (J/B)] ● Harness for open or short between control unit and fuse

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

3	CHECK IGNITION SWITCH "ON" CIRCUIT
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 33 and ground with ignition switch "ON".</p>	
SEL790V	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check the following. <ul style="list-style-type: none"> ● 10A fuse [No. 8, located in fuse block (J/B)] ● Harness for open or short between control unit and fuse

4	CHECK GROUND CIRCUIT FOR CONTROL UNIT
<p>1. Disconnect control unit connector. 2. Check continuity between control unit terminal 16 and ground.</p>	
SEL791V	
Does continuity exist?	
Yes	▶ Power supply and ground circuits are OK.
No	▶ Check ground harness.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DOOR SWITCH CHECK

=NCEL0115905

1	CHECK DOOR SWITCH INPUT SIGNAL			
	Check voltage between control unit terminals 15, 16 or 35 and ground.			
	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door switch	29	ground	Open	0
			Closed	Approx. 12
Front RH door switch	40	ground	Open	0
			Closed	Approx. 12
All door switches	28	ground	Open	0
			Closed	Approx. 12

MTBL0158

Smart entrance control unit connector (M24)

Refer to wiring diagram in EL-157.

SEL886V

OK or NG	
OK	▶ Door switch is OK.
NG	▶ GO TO 2.

2	CHECK DOOR SWITCH		
1. Disconnect door switch connector.			
2. Check continuity between door switch terminals.			
	Terminals	Condition	Continuity
Front door switch	2 - 3, 1 - ground	Closed	No
		Open	Yes
Rear door switch	1 - ground	Closed	No
		Open	Yes

MTBL0159

Door switch connector
Front LH : (B4)
Front RH : (B22)

Door switch connector
Rear LH : (B11)
Rear RH : (B111)

SEL887V

OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> ● Door switch ground circuit (Front, back door) or door switch ground condition ● Harness for open or short between control unit and door switch
NG	▶ Replace door switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

KEY SWITCH (INSERT) CHECK

=NCEL0115S07

1	CHECK KEY SWITCH INPUT SIGNAL
<p>Check voltage between control unit terminal 32 and ground.</p> <p>Smart entrance control unit connector (M24)</p> <p>SEL888V</p> <p>Refer to wiring diagram in EL-156.</p> <p>Voltage [V]: Condition of key switch: Key is inserted. Approx. 12 Condition of key switch: Key is withdrawn. 0</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Key switch is OK.
NG	▶ GO TO 2.

2	CHECK KEY SWITCH (INSERT)
<p>Check continuity between terminals 1 and 2.</p> <p>Key switch connector (E77)</p> <p>SEL784V</p> <p>Continuity: Condition of key switch: Key is inserted. Yes Condition of key switch: Key is withdrawn. No</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check the following. <ul style="list-style-type: none"> ● 10A fuse [No. 24, located in fuse block (J/B)] ● Harness for open or short between key switch and fuse ● Harness for open or short between control unit and key switch
NG	▶ Replace key switch.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DOOR UNLOCK SENSOR CHECK

=NCEL0115506

1	CHECK DOOR UNLOCK SENSOR INPUT SIGNAL			
	Check voltage between control unit terminals 26, 36 or 37 and ground.			
	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door	36	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	37	Ground	Locked	Approx. 12
			Unlocked	0
Rear and back door	26	Ground	Locked	Approx. 12
			Unlocked	0

MTBL0160

Smart entrance control unit connector (M24)

CONNECT

SEL889V

Refer to wiring diagram in EL-156.

OK or NG

OK	▶	Door unlock sensor is OK.
NG	▶	GO TO 2.

2	CHECK DOOR UNLOCK SENSOR	
<ol style="list-style-type: none"> Disconnect door unlock sensor connector. Check continuity between door unlock sensor terminals. 		
<p>Door lock actuator connectors</p> <p>Front LH : (D9) Rear LH : (D44)</p> <p>Front RH : (D28) Rear RH : (D64)</p>		
<p>DISCONNECT</p> <p>SEL247VC</p>		
<p>Continuity:</p> <p>Condition: Locked</p> <p style="padding-left: 20px;">No</p> <p>Condition: Unlocked</p> <p style="padding-left: 20px;">Yes</p>		
OK or NG		
OK	▶	<p>Check the following.</p> <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor
NG	▶	Replace door unlock sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

HAZARD REMINDER CHECK

=NCEL0115S09

1	CHECK HAZARD INDICATOR
Check if hazard indicator flashes with hazard switch.	
Does hazard indicator operate?	
Yes	▶ GO TO 2.
No	▶ Check "hazard indicator" circuit.

2	CHECK HAZARD REMINDER OPERATION
1. Disconnect control unit connector. 2. Apply ground to control unit terminal 7.	
<p>Smart entrance control unit connector (M23)</p> <p>Refer to wiring diagram in EL-157.</p>	
Does hazard indicator illuminate?	
Yes	▶ Replace smart entrance control unit.
No	▶ GO TO 3.

3	CHECK MULTI-REMOTE CONTROL RELAY
Check multi-remote control relay.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace.

4	CHECK POWER SUPPLY FOR MULTI-REMOTE CONTROL RELAY
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminal 1 and ground.	
<p>Multi-remote control relay connector (M20)</p>	
Does battery voltage exist?	
Yes	▶ GO TO 5.
No	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse [No. 20, located in fuse block (J/B)] • Harness for open or short between multi-remote control relay and fuse

5	CHECK MULTI-REMOTE CONTROL RELAY CIRCUIT
1. Disconnect multi-remote control relay connector. 2. Check voltage between terminals 3 and 5. Battery voltage should exist. 3. Check voltage between terminals 6 and 7. Battery voltage should exist.	
<p>Multi-remote control relay connector (M20)</p>	
OK or NG	
OK	▶ Check harness for open or short between control unit and multi-remote control relay.
NG	▶ Check the following. <ul style="list-style-type: none"> • Harness for open or short between multi-remote control relay and fuse • Harness for open or short between multi-remote control relay and turn signal lamps

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

INTERIOR ROOM LAMP OPERATION CHECK

=NCEL0115S09

1	CHECK INTERIOR ROOM LAMP
Check if the interior room lamp switch is in the "DOOR" position and the lamp illuminates when a door is open.	
Does interior room lamp illuminate?	
Yes	▶ GO TO 2.
No	▶ Check "Interior room lamp" circuit.

2	CHECK INTERIOR ROOM LAMP CIRCUIT
When interior room lamp switch is "DOOR" position, check voltage across control unit terminal 8 and ground.	
Refer to wiring diagram in EL-156.	
Does battery voltage exist?	
Yes	▶ GO TO 3.
No	▶ Repair harness between control unit and interior room lamp.

3	CHECK CONTROL UNIT OUTPUT
Push unlock button of remote controller and check voltage across control unit terminal 8 and ground.	
Voltage (V): Unlock button is pushed. 0 (For approx. 30 seconds.) Unlock button is not pushed. Battery voltage	
OK or NG	
OK	▶ Check system again.
NG	▶ Replace smart entrance control unit.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MULTI-REMOTE CONTROL SYSTEM

ID Code Entry Procedure

Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

To enter the ID code, follow the procedures below.



NOTE:


- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.

MULTI-REMOTE CONTROL SYSTEM


Remote Controller Battery Replacement

Remote Controller Battery Replacement


NCEL011B




Open the lid using a coin.



Remove the battery.



Insert the new battery.
Recommended battery: CR2025 or equivalent.



Close the lid securely.

SEL126V



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location

Component Parts and Harness Connector Location

NCELD119



SEL839V

System Description


NCEL0120

NCEL0120S01

NCEL0120S0101

DESCRIPTION

1. Operation Flow



2. Setting The Theft Warning System

Initial condition

- 1) Close all doors.
- 2) Close engine hood and trunk lid.

Disarmed phase

The theft warning system is in the disarmed phase when any door(s), engine hood or trunk lid is opened. The security indicator lamp blinks every second.

Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when engine hood, trunk lid and all doors are closed and the doors are locked by key or multi-remote controller. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

3. Canceling The Set Theft Warning System

When the following 1) or 2) operation is performed, the armed phase is canceled.

- 1) Unlock the doors with the key or multi-remote controller.
- 2) Open the trunk lid with the key. When the trunk lid is closed after opening the trunk lid with the key, the system returns to the armed phase.

4. Activating The Alarm Operation of The Theft Warning System

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When the following operation 1) or 2) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. (At the same time, the system disconnects the starting system circuit.)

- 1) Engine hood, trunk lid or any door is opened before unlocking door with key or multi-remote controller.
- 2) Door is unlocked without using key or multi-remote controller.

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 7.5A fuse [No. 5, located in the fuse block (J/B)]
- to security indicator lamp terminal 1.

Power is supplied at all times

- through 30A fusible link (letter d, located in the fuse and fusible link box)
- to smart entrance control unit terminal 11.

THEFT WARNING SYSTEM

System Description (Cont'd)

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 21.

Ground is supplied

- to smart entrance control unit terminal 16
- through body grounds M15, M71 and M76.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

NCEL0120S02

The operation of the theft warning system is controlled by the doors, engine hood and trunk lid.

To activate the theft warning system, the smart entrance control unit must receive signals indicating the doors, engine hood and trunk lid are closed and the doors are locked.

When a door is open, smart entrance control unit terminal 28, 29 or 40 receives a ground signal from each door switch.

When a door is unlocked, smart entrance control unit terminal 26, 36 or 37 receives a ground signal from terminal 4 of each door unlock sensor.

When the engine hood is open, smart entrance control unit terminal 27 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E9 and E28.

When the trunk lid is open, smart entrance control unit terminal 38 receives a ground signal

- from terminal 1 of the trunk room lamp switch
- through body grounds D109 and B110.

When the doors are locked with key or multi-remote controller and none of the described conditions exist, the theft warning system will automatically shift to armed mode.

THEFT WARNING SYSTEM ACTIVATION (WITH KEY OR REMOTE CONTROLLER USED TO LOCK DOORS)

NCEL0120S03

If the key is used to lock doors, terminal 41 receives a ground signal

- from terminal 3 of the key cylinder switch (driver side)
- from terminal 1 of the front door key cylinder switch (passenger side)
- through body grounds M15, M71 and M76
- from terminal 1 of the trunk lid key cylinder switch
- through body grounds B109 and B110.

If this signal or lock signal from remote controller is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal 31 supplies ground to terminal 2 of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

THEFT WARNING SYSTEM ALARM OPERATION

NCEL0120S04

The theft warning system is triggered by

- opening the door without using the key
- opening the engine hood or the trunk lid
- unlocking the door without using the key.

Once the theft warning system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 26, 36, 37 (door unlock sensor), 28, 29, 40 (door switch), 38 (trunk room lamp switch) or 27 (hood switch), the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

Power is supplied at all times

- through 10A fuse [No. 16, located in the fuse block (J/B)].
- to theft warning relay terminal 1.

If the theft warning system is triggered, ground is supplied

- from terminal 3 of the smart entrance control unit
- to theft warning relay terminal 2.

THEFT WARNING SYSTEM

System Description (Cont'd)

With power and ground supplied, power to starting system is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 10A fuse (No. 41, located in fuse and fusible link box)
- to theft warning lamp relay terminal 1 and
- to horn high relay terminal 2.
- through 10A fuse (No. 36, located in fuse and fusible link box)
- to horn low relay terminal 2.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal 4 of the smart entrance control unit
- to theft warning lamp relay terminal 2,
- to horn low relay terminal 1 and
- to horn high relay terminal 1.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, the door or the trunk lid must be unlocked with the key or remote controller. NCELD120505

When the key is used to unlock the door, smart entrance control unit terminal 30 receives a ground signal

- from terminal 3 of the front door key cylinder switch (driver side)
- from terminal 1 of the front door key cylinder switch (passenger side)

When the key is used to open the trunk lid, smart entrance control unit terminal 42 receives a ground signal from terminal 1 of the back door key cylinder switch. NCELD120506

When the smart entrance control unit receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required. When the multi-remote control system is triggered, ground is supplied intermittently. NCELD120506

- from smart entrance control unit terminal 4
- to theft warning lamp relay terminal 2 and
- to each terminal 1 of horn low relay and horn high replay.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

THEFT WARNING SYSTEM

Schematic

NCEL0121

Schematic



THEFT WARNING SYSTEM

Wiring Diagram — THEFT —

FIG. 1



Wiring Diagram — THEFT —

NCEL0122

NCEL0122S01

EL-THEFT-01

Refer to EL-POWER.



Refer to last page (Foldout page).

- M6, E75
- M1
- M3
- M5

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



THEFT WARNING SYSTEM



Wiring Diagram — THEFT — (Cont'd)

FIG. 2

NCEL0122S02

EL-THEFT-02

SMART
ENTRANCE
CONTROL
UNIT
(M24)



Refer to last page (Foldout page).
 M6, E75


THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)


FIG. 3

NCEL0122503

EL-THEFT-03



⊗ : With A/T
⊙ : With M/T



Refer to last page (Foldout page).

⊗ M6, E75
⊙ E72

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



TEL939A

THEFT WARNING SYSTEM


Wiring Diagram — THEFT — (Cont'd)

FIG. 4

NCEL0122S04



Refer to last page (Foldout page).



THEFT WARNING SYSTEM

Trouble Diagnoses

Trouble Diagnoses


NCEL0123

PRELIMINARY CHECK

NCEL0123S01

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



MEL447HB

After performing preliminary check, go to symptom chart on next page.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

NCEL0123S02

REFERENCE PAGE (EL-)		177	179	180	183	184	185	186	187	188	189	158
SYMPTOM		PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND TRUNK ROOM LAMP SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR UNLOCK SENSOR CHECK	DOOR KEY CYLINDER SWITCH CHECK	TRUNK LID KEY CYLINDER SWITCH CHECK	THEFT WARNING HORN ALARM CHECK	THEFT WARNING HEADLAMP ALARM CHECK	STARTER INTERRUPT SYSTEM CHECK	Check "MULTI-REMOTE CONTROL" system.
1	Theft warning indicator does not turn "ON" or blinking.	X	X		X							
2	Theft warning system cannot be set by ...	X	X	X		X						
		X	X				X					
		X	X									X
3	*1 Theft warning system does not alarm when ...	X	X	X								
		X	X				X					
4	Theft warning alarm does not activate.	X	X	X		X						
		X	X						X			
		X	X								X	
		X	X									X
5	Theft warning system cannot be canceled by ...	X	X				X					
		X	X					X				
		X	X									X

X : Applicable


*1: Make sure the system is in the armed phase.

Before starting trouble diagnoses above, perform preliminary check, EL-177.

Symptom numbers in the symptom chart correspond with those of preliminary check.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)




POWER SUPPLY AND GROUND CIRCUIT CHECK

NCEL0123S03

Power Supply Circuit Check

NCEL0123S0301

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
11	Ground	Battery voltage	Battery voltage	Battery voltage
33	Ground	0V	0V	Battery voltage
21	Ground	0V	Battery voltage	Battery voltage



Ground Circuit Check

NCEL0123S0302

Terminals	Continuity
16 - Ground	Yes

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DOOR, HOOD AND TRUNK ROOM LAMP SWITCH CHECK

-NCEL0123S04

Door Switch Check

NCEL0123S0401

1	PRELIMINARY CHECK
<ol style="list-style-type: none"> Turn ignition switch "OFF" and remove key from key cylinder. Close all doors, engine hood and trunk lid. "SECURITY" indicator lamp should turn off. Open any passenger door or back door. "SECURITY" indicator lamp should blink every second. <p style="text-align: center;">OK or NG</p>	
OK	▶ Door switch is OK.
NG	▶ GO TO 2.

2	CHECK DOOR SWITCH INPUT SIGNAL																												
Check voltage between control unit terminals 28, 29 or 40 and ground.																													
	<table border="1"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">29</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">Front RH door switch</td> <td rowspan="2">40</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> <tr> <td rowspan="2">Front LH and rear door switches</td> <td rowspan="2">28</td> <td rowspan="2">ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 12</td> </tr> </tbody> </table>		Terminals		Condition	Voltage [V]	(+)	(-)	Front LH door switch	29	ground	Open	0	Closed	Approx. 12	Front RH door switch	40	ground	Open	0	Closed	Approx. 12	Front LH and rear door switches	28	ground	Open	0	Closed	Approx. 12
	Terminals		Condition	Voltage [V]																									
	(+)	(-)																											
Front LH door switch	29	ground	Open	0																									
			Closed	Approx. 12																									
Front RH door switch	40	ground	Open	0																									
			Closed	Approx. 12																									
Front LH and rear door switches	28	ground	Open	0																									
			Closed	Approx. 12																									
MTBL0194																													
<p style="text-align: center;">Smart entrance control unit connector (M24)</p> <p style="text-align: center;">R/W R/L SB</p> <p style="text-align: center;">SEL930V</p>																													
Refer to wiring diagram in EL-174.																													
OK or NG																													
OK	▶ Door switch is OK.																												
NG	▶ GO TO 3.																												

3	CHECK DOOR SWITCH																
<ol style="list-style-type: none"> Disconnect door switch connector. Check continuity between door switch terminals. 																	
	<table border="1"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front LH door switch</td> <td rowspan="2">2 - 3, 1 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Front RH and rear door switches</td> <td rowspan="2">1 - ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table>		Terminals	Condition	Continuity	Front LH door switch	2 - 3, 1 - ground	Closed	No	Open	Yes	Front RH and rear door switches	1 - ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity														
Front LH door switch	2 - 3, 1 - ground	Closed	No														
		Open	Yes														
Front RH and rear door switches	1 - ground	Closed	No														
		Open	Yes														
MTBL0195																	
<p style="text-align: center;">DISCONNECT Door switch connector Front LH : (B4)</p>																	
<p style="text-align: center;">DISCONNECT Door switch connector Front RH : (B22) Rear LH : (B11) Rear RH : (B111)</p> <p style="text-align: center;">SEL931V</p>																	
OK or NG																	
OK	▶ Check the following. <ul style="list-style-type: none"> Door switch ground circuit (Front, back door) or door switch ground condition Harness for open or short between control unit and door switch 																
NG	▶ Replace door switch.																

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Hood Switch Check

=NCEL0123S0402

1	PRELIMINARY CHECK
1. Turn ignition switch "OFF" and remove key from key cylinder. 2. Close all doors, engine hood and trunk lid. "SECURITY" indicator lamp should turn off. 3. Open hood. "SECURITY" indicator lamp should blink every second.	
OK or NG	
OK	▶ Hood switch is OK.
NG	▶ GO TO 2.

2	CHECK HOOD SWITCH FITTING CONDITION
OK or NG	
OK	▶ GO TO 3.
NG	▶ Adjust installation of hood switch or hood.

3	CHECK HOOD SWITCH INPUT SIGNAL
Check voltage between control unit terminal 27 and ground.	
SEL932V	
Refer to wiring diagram in EL-174.	
Voltage [V]:	
Engine hood is open.	
0	
Engine hood is closed.	
Approx. 12	
OK or NG	
OK	▶ Hood switch is OK.
NG	▶ GO TO 4.

4	CHECK HOOD SWITCH
1. Disconnect hood switch connector. 2. Check continuity between hood switch terminals 1 and 2.	
SEL397TC	
Continuity:	
Condition: Pushed	
No	
Condition: Released	
Yes	
OK or NG	
OK	▶ Check the following.
<ul style="list-style-type: none"> ● Hood switch ground circuit ● Harness for open or short between control unit and hood switch 	
NG	▶ Replace hood switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Trunk Room Lamp Switch Check

=NCEL012350403

1	PRELIMINARY CHECK
1. Turn ignition switch "OFF" and remove key from key cylinder. 2. Close all doors, engine hood and trunk lid. "SECURITY" indicator lamp should turn off. 3. Open trunk lid. "SECURITY" indicator lamp should blink every second.	
OK or NG	
OK	▶ Trunk room lamp switch is OK.
NG	▶ GO TO 2.

2	CHECK TRUNK ROOM LAMP SWITCH INPUT SIGNAL
Check voltage between control unit terminal 38 and ground.	
Refer to wiring diagram in EL-174. Voltage [V]: Trunk lid is open. Approx. 0 Trunk lid is closed. Approx. 12	
OK or NG	
OK	▶ Trunk room lamp switch is OK.
NG	▶ GO TO 3.

3	CHECK TRUNK ROOM LAMP SWITCH
1. Disconnect trunk room lamp switch connector. 2. Check continuity between trunk room lamp switch terminals 1 and 2.	
Continuity: Condition: Closed No Condition: Open Yes	
OK or NG	
OK	▶ Check the following. <ul style="list-style-type: none"> ● Trunk room lamp switch ground circuit ● Harness for open or short between control unit and trunk room lamp switch
NG	▶ Replace trunk room lamp switch.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

SECURITY INDICATOR LAMP CHECK

#NCEL0123S05

1	CHECK INDICATOR LAMP OUTPUT SIGNAL
<p>1. Disconnect control unit connector. 2. Check voltage between control unit terminal 31 and ground.</p>	
<p>Refer to wiring diagram in EL-173.</p> <p>SEL935V</p>	
Does battery voltage exist?	
Yes	▶ Security indicator lamp is OK.
No	▶ GO TO 2.

2	CHECK INDICATOR LAMP
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace indicator lamp.

3	CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP
<p>1. Disconnect security lamp connector. 2. Check voltage between indicator lamp terminal 1 and ground.</p>	
<p>SEL936V</p>	
Does battery voltage exist?	
Yes	▶ Check harness for open or short between security indicator lamp and control unit.
No	▶ Check the following. <ul style="list-style-type: none"> ● 7.5A fuse [No. 5, located in fuse block (J/B)] ● Harness for open or short between security indicator lamp and fuse

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DOOR UNLOCK SENSOR CHECK

#NGEL0123S06

1 CHECK DOOR UNLOCK SENSOR INPUT SIGNAL

Check voltage between control unit terminals 26, 36 or 37 and ground.

	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door	36	Ground	Locked	Approx. 12
			Unlocked	0
Front RH door	37	Ground	Locked	Approx. 12
			Unlocked	0
Rear door	26	Ground	Locked	Approx. 12
			Unlocked	0

MTBL0163

SEL937V

Refer to wiring diagram in EL-173.

OK or NG

OK	▶	Door unlock sensor is OK.
NG	▶	GO TO 2.

2 CHECK DOOR UNLOCK SENSOR

- Disconnect door unlock sensor connector.
- Check continuity between door unlock sensor terminals.

Door switch actuator connectors
 Front LH : (D9) Rear LH : (D44)
 Front RH : (D28) Rear RH : (D64)

SEL938V

Continuity:
 Condition: Locked
 No
 Condition: Unlocked
 Yes

OK or NG

OK	▶	Check the following. <ul style="list-style-type: none"> • Door unlock sensor ground circuit • Harness for open or short between control unit and door unlock sensor
NG	▶	Replace door unlock sensor.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DOOR KEY CYLINDER SWITCH CHECK

=NCEL0123S07

1	CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)																		
Check voltage between control unit terminals 30 or 41 and ground.																			
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">30</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">0</td> </tr> <tr> <td rowspan="2" style="text-align: center;">41</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Lock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>		Terminals		Key position	Voltage [V]	(+)	(-)	30	Ground	Neutral	Approx. 12	Unlock	0	41	Ground	Neutral	Approx. 12	Lock	0
Terminals		Key position	Voltage [V]																
(+)	(-)																		
30	Ground	Neutral	Approx. 12																
		Unlock	0																
41	Ground	Neutral	Approx. 12																
		Lock	0																
MTBL0164																			
<p style="text-align: center;">Smart entrance control unit connector (M24)</p> <p style="text-align: center;">Driver's side</p> <p style="text-align: center;">Passenger side</p>																			
SEL939V																			
Refer to wiring diagram in EL-175.																			
OK or NG																			
OK	▶ Door key cylinder switch is OK.																		
NG	▶ GO TO 2.																		

2	CHECK DOOR KEY CYLINDER SWITCH													
<ol style="list-style-type: none"> Disconnect door key cylinder switch connector. Check continuity between door key cylinder switch terminals. 														
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">D27: 3 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">Lock</td> <td style="text-align: center;">Yes</td> </tr> <tr> <td rowspan="2" style="text-align: center;">D8: 1 - 2</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table>		Terminals	Key position	Continuity	D27: 3 - 2	Neutral	No	Lock	Yes	D8: 1 - 2	Neutral	No	Unlock	Yes
Terminals	Key position	Continuity												
D27: 3 - 2	Neutral	No												
	Lock	Yes												
D8: 1 - 2	Neutral	No												
	Unlock	Yes												
MTBL0165														
<p style="text-align: center;">Door key cylinder switch connector</p> <p style="text-align: center;">Driver side : (D8) Passenger side : (D27)</p> <p style="text-align: center;">① : Door unlock switch terminal (D27) Door lock switch terminal (D8)</p> <p style="text-align: center;">② : Ground terminal</p> <p style="text-align: center;">③ : Door lock switch terminal (D27) Door unlock switch terminal (D8)</p>														
SEL940V														
OK or NG														
OK	▶ Check the following. <ul style="list-style-type: none"> ● Door key cylinder switch ground circuit ● Harness for open or short between control unit and door key cylinder switch 													
NG	▶ Replace door key cylinder switch.													

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

TRUNK LID KEY CYLINDER SWITCH CHECK

=NCEL0123S08

1	CHECK TRUNK LID KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL)												
Check voltage between control unit terminal 42 and ground.													
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminal</th> <th rowspan="2">Key position</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2" style="text-align: center;">42</td> <td rowspan="2" style="text-align: center;">Ground</td> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">Approx. 12</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">0</td> </tr> </tbody> </table>		Terminal		Key position	Voltage [V]	(+)	(-)	42	Ground	Neutral	Approx. 12	Unlock	0
Terminal		Key position	Voltage [V]										
(+)	(-)												
42	Ground	Neutral	Approx. 12										
		Unlock	0										
MTBL0166													
<p>Smart entrance control unit connector (M24)</p>													
<p>Continuity exist Neutral Unlock</p>													
SEL941V													
Refer to wiring diagram in EL-175.													
OK or NG													
OK	▶ Trunk lid key cylinder switch is OK.												
NG	▶ GO TO 2.												

2	CHECK TRUNK LID KEY CYLINDER SWITCH						
<ol style="list-style-type: none"> 1. Disconnect trunk lid key cylinder switch connector. 2. Check continuity between trunk lid key cylinder switch terminals. 							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Neutral</td> <td style="text-align: center;">No</td> </tr> <tr> <td style="text-align: center;">Unlock</td> <td style="text-align: center;">Yes</td> </tr> </tbody> </table>		Key position	Continuity	Neutral	No	Unlock	Yes
Key position	Continuity						
Neutral	No						
Unlock	Yes						
MTBL0167							
<p>Trunk lid key cylinder switch (T53)</p>							
SEL942V							
OK or NG							
OK	▶ Check the following. <ul style="list-style-type: none"> ● Trunk lid key cylinder switch ground circuit ● Harness for open or short between control unit and trunk lid key cylinder switch 						
NG	▶ Replace trunk lid key cylinder switch.						

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

THEFT WARNING HORN ALARM CHECK

=NCEL0123S09

1	CHECK THEFT WARNING HORN ALARM OPERATION
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 4.</p>	
SEL943V	
Refer to wiring diagram in EL-176.	
Does horn alarm activate?	
Yes	▶ Horn alarm is OK.
No	▶ GO TO 2.

2	CHECK THEFT WARNING HORN RELAYS
Check horn high relay and horn low relay.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Replace.

3	CHECK POWER SUPPLY FOR THEFT WARNING HORN RELAYS
<p>1. Disconnect horn high relay and horn low relay connectors. 2. Check voltage between terminal 2 and ground.</p>	
SEL944V	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check the following. <ul style="list-style-type: none"> • 10A fuse (No. 36 and 41, located in the fuse and fusible link box) • Harness for open or short between theft warning horn relays and fuse

4	CHECK THEFT WARNING HORN RELAYS CIRCUIT
<p>1. Disconnect horn high relay and horn low relay connectors. 2. Check voltage between terminals 2 and 3 of each relay. Battery voltage should exist.</p>	
SEL945V	
OK or NG	
OK	▶ Check harness for open or short between theft warning horn relays and control unit.
NG	▶ Check harness for open or short.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

THEFT WARNING HEADLAMP ALARM CHECK

=NCEL0123S10

1	CHECK THEFT WARNING HEADLAMP ALARM OPERATION
<p>1. Disconnect control unit connector. 2. Apply ground to control unit terminal 4.</p>	
<p>Smart entrance control unit connector (M23)</p>	
<p>Refer to wiring diagram in EL-176. SEL943V</p>	
Does headlamp alarm activate?	
Yes	▶ Headlamp alarm is OK.
No	▶ GO TO 2.

2	CHECK HEADLAMP OPERATION
Does headlamp come on when turning lighting switch "ON"?	
Yes	▶ GO TO 3.
No	▶ Check headlamp system. Refer to "HEADLAMP".

3	CHECK THEFT WARNING LAMP RELAY
Check theft warning lamp relay.	
OK or NG	
OK	▶ GO TO 4.
NG	▶ Replace.

4	CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminal 1 and ground.</p>	
<p>Theft warning lamp relay connector (E48)</p>	
<p>Refer to wiring diagram in EL-176. SEL757UD</p>	
Does battery voltage exist?	
Yes	▶ GO TO 5.
No	▶ Check the following. <ul style="list-style-type: none"> ● 10A fuse (No. 41, located in the fuse and fusible link box) ● Harness for open or short between theft warning lamp relay and fuse

5	CHECK THEFT WARNING LAMP RELAY CIRCUIT
<p>1. Disconnect theft warning lamp relay connector. 2. Check voltage between terminals 3 and 5. Battery voltage should exist. 3. Check voltage between terminals 6 and 7. Battery voltage should exist.</p>	
<p>Theft warning lamp relay connector (E48)</p>	
OK or NG	
OK	▶ Check harness for open or short between theft warning lamp relay and control unit.
NG	▶ Check the following. <ul style="list-style-type: none"> ● Harness for open or short between fuse and theft warning lamp relay ● Harness for open or short between theft warning lamp relay and headlamps

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

STARTER INTERRUPT SYSTEM CHECK

=NCEL0123511

1	CHECK STARTER MOTOR INTERRUPT SIGNAL
<p>1. Turn ignition switch "ON". 2. Check voltage between control unit terminal 3 and ground.</p> <div style="text-align: center;"> <p>Smart entrance control unit connector (M23)</p> <p>SEL946V</p> </div> <p>Refer to wiring diagram in EL-175.</p> <p>Voltage [V]: Except starter interrupted phase Approx. 12 Starter interrupted phase 0</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	<p>▶ Check the following.</p> <ul style="list-style-type: none"> ● 10A fuse [No. 16, located in fuse block (J/B)] ● Harness for open or short between theft warning relay and fuse ● Harness for open or short between control unit and theft warning relay

2	CHECK THEFT WARNING RELAY
<p>Check theft warning relay.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ Check system again.
NG	▶ Replace relay.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SMART ENTRANCE CONTROL UNIT

Description

Description

NCEL0124

The following systems are controlled by the smart entrance control unit.

- Warning chime
- Rear window defogger timer
- Power door lock
- Multi-remote control system
- Theft warning system
- Interior room lamp timer
- Battery saver

For detailed description and wiring diagrams, refer to the relevant pages for the each system.

The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.

INPUT/OUTPUT

NCEL0124S01

System	Input	Output
Power door lock	Door lock and unlock switch Key switch (Insert) Front door switch LH Front door switch RH Front door unlock sensor LH Front door unlock sensor RH Door key cylinder switches	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switches Door unlock sensors Antenna (remote controller signal)	Horn relays Theft warning lamp relay Interior room lamp Multi-remote control relay Door lock actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch Front door switch LH	Warning chime
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Theft warning	Ignition switch (ACC, ON) Door switches Hood switch Door key cylinder switches (lock/unlock) Trunk lid key cylinder switch (unlock) Door unlock sensor	Horn relays Theft warning lamp relay Theft warning relay (Starter interrupt) Security indicator
Interior room lamp timer	Door switches Front door key cylinder switch LH (lock/unlock) Ignition switch (ON) Key switch (Insert)	Interior room lamp
Battery saver	Ignition switch (ON) Door switches Front door key cylinder switch LH (lock/unlock)	Interior room lamp Map lamp

BATTERY SAVER

NCEL0124S02

The lamp turns off automatically when the interior room lamp or/and map lamp is illuminated with the ignition key in the OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in the ON position for more than 10 minutes.

SMART ENTRANCE CONTROL UNIT

Description (Cont'd)

NOTE:

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

SMART ENTRANCE CONTROL UNIT

Schematic

NCEL0125

Schematic




SMART ENTRANCE CONTROL UNIT

TEL941A

SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TEL942A

SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

Smart Entrance Control Unit Inspection Table

NCELO126

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)	
2	G	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)	12V → 0V	
3	P/B	Theft warning relay (Starter cut)	OFF → ON (Ignition key is in "ON" position)	12V → 0V	
4	Y/G	Theft warning horn/lamp relay	When panic alarm is operated using remote controller	12V → 0V	
7	P	Multi-remote control relay	When doors are locked using remote controller	12V → 0V	
8	R/L	Interior room lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V	
10	P	Power source (Fuse)	—	12V	
11	W/L	Power source (C/B)	—	12V	
13	P	Driver door lock actuator	Door lock & unlock switch	Free	0V
14	L	Passenger door lock actuator		Unlocked	12V
15	GY	Door lock actuators	Door lock & unlock switch	Free	0V
				Locked	12V
16	B	Ground	—	—	
17	GY/R	Battery saver	Battery saver is not operate → Operate	12V → 0V	
21	G	Ignition switch (ACC)	"ACC" position	12V	
22	W/R	Seat belt buckle switch	Unfasten → Fasten (Ignition key is in "ON" position)	0V → 12V	
23	GY	Door lock & unlock switches	Neutral → Locks	12V → 0V	
26	Y	Rear door unlock sensors	All doors are locked → One or more doors are unlocked	12V → 0V	
27	Y/B	Hood open signal	ON (Open) → OFF (Closed)	0V → 12V	
28	R/W	All door switches	OFF (Closed) → ON (Open)	12V → 0V	
29	SB	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V	
30	LG/R	Door key cylinder unlock switch	OFF (Neutral) → ON (Unlocked)	12V → 0V	
31	BR/Y	Theft warning indicator	Goes off → Illuminates	12V → 0V	
32	L	Ignition key switch (Insert)	key inserted → key removed from IGN key cylinder	12V → 0V	
33	G/R	Ignition switch (ON)	Ignition key is in "ON" position	12V	
34	R/G	Lighting switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V	
35	G	Door lock & unlock switches	Neutral → Unlocks	12V → 0V	
36	Y/R	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V	
37	OR	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V	
38	R	Trunk room lamp switch	ON (Open) → OFF (Closed)	0V → 12V	
39	L/W	Rear window defogger switch	OFF → ON	12V → 0V	
40	R/L	Passenger door switch	OFF (Closed) → ON (Open)	12V → 0V	
41	Y	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	12V → 0V	
42	G/B	Trunk lid key unlock switch	OFF (Neutral) → ON (Unlock)	12V → 0V	

INTEGRATED HOMELINK TRANSMITTER

Wiring Diagram — TRNSMT —

Wiring Diagram — TRNSMT —

NCEL0127

EL-TRNSMT-01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS



BT

HA

SC

EL

IDX



Refer to last page (Foldout page).

M2

TEL943A

INTEGRATED HOMELINK TRANSMITTER

Trouble Diagnoses


DIAGNOSTIC PROCEDURE

NCEL0128


NCEL0128S01


SYMPTOM: Transmitter does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

1	PRELIMINARY CHECK
<p>1. Turn ignition switch "OFF". 2. Does red light (LED) of transmitter illuminate when any button is pressed?</p>	
 <p style="text-align: right;">SEL442U</p>	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

2	CHECK TRANSMITTER FUNCTION
<p>Check transmitter with Tool. For details, refer to Technical Service Bulletin.</p>	
OK or NG	
OK	▶ Receiver or handheld transmitter fault, not vehicle related.
NG	▶ Replace transmitter with sun visor assembly.

3	CHECK POWER SUPPLY
<p>1. Disconnect transmitter connector. 2. Turn ignition switch "OFF". 3. Check voltage between terminal 1 and body ground.</p>	
 <p style="text-align: right;">SEL635U</p>	
Does battery voltage exist?	
Yes	▶ GO TO 4.
No	▶ Check fuse (10A) and repair harness.




4	CHECK GROUND CIRCUIT
<p>Check continuity between terminal 2 and ground.</p>	
 <p style="text-align: right;">SEL636U</p>	
Does continuity exist?	
Yes	▶ Replace transmitter with sun visor assembly.
No	▶ Repair harness.

ELECTRICAL UNITS LOCATION

Engine Compartment

Engine Compartment

NCEL0129



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



CEL949

ELECTRICAL UNITS LOCATION

Passenger Compartment

Passenger Compartment


NCELO130



CEL950

ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX


CEL951

HARNESS LAYOUT

How to Read Harness Layout

How to Read Harness Layout

NCEL0131



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)

TO USE THE GRID REFERENCE

NCEL0131S01

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

NCEL0131S02

Main symbols of connector (in Harness Layout) are indicated in the below.


Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> • Ground terminal etc. 	—			

HARNES LAYOUT

Outline

Outline

NCELD132



NOTE:

For detailed ground distribution information, refer to "Ground Distribution", "GROUND" EL-16.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT

Main Harness

NCEL0133


Main Harness




CEL953

HARNESS LAYOUT

Main Harness (Cont'd)



★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



EL
 SC
 HA
 BT
 RS
 ST
 BR
 SU
 AX
 AT
 MT
 CL
 FC
 LC
 EM
 MA
 GI


CEL954

HARNES LAYOUT




Engine Room Harness

Engine Room Harness

NCEL0134



For detail ground distribution information, refer to "GROUND DISTRIBUTION".



★: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

CEL955

HARNES LAYOUT

Engine Room Harness (Cont'd)

D2*	E1	-	Fuse and Fusible link box
E2	E2	B/1	Battery (+)
E2	E3	B/1	Battery (+)
E2	E4	GY/2	Brake fluid level switch
F1	E5	BR/2	Front wheel sensor LH
E2*	E6	GY/2	Dropping resistor (With A/T)
F2	E7	GY/2	Hood switch
F2	E8	-	Body ground
F2	E9	-	Body ground
G2	E10	GY/2	Side turn signal lamp LH
E3	E11	BR/2	Front turn signal lamp LH
E3*	E12	GY/2	Intake air temperature sensor
E3	E13	BR/2	Front side marker lamp LH
E4	E14	GY/2	Front fog lamp LH
C3	E15	B/2	Ambient sensor (With auto A/C)
D3	E16	GY/2	Parking lamp LH
D3	E17	B/3	Headlamp LH
D3	E18	B/4	Triple-pressure switch
D2*	E19	GY/4	Cooling fan motor-1
D2*	E20	GY/4	Cooling fan motor-2
C2	E21	B/1	Horn high
B1	E22	GY/8	ABS actuator
B1	E23	GY/2	ABS actuator
A2	E24	B/3	Headlamp RH
A2	E25	GY/2	Parking lamp RH
A3	E26	GY/2	Front fog lamp RH

A2	E27	BR/2	Front turn signal lamp RH
B1	E28	-	Body ground
A2	E29	BR/2	Front side marker lamp RH
B3	E30	GY/2	Front washer motor
B3	E31	BR/2	Washer level switch
C1	E32	GY/2	Side turn signal lamp RH
C2*	E33	GY/9	To (E101)
B1	E34	GY/1	To (E102)
C2	E35	GY/1	To (E103)
C2	E36	GY/8	To (E104)
B1, F1	E37	-	Relay box
F1	E38	L/4	Air conditioner relay
F1*	E39	GY/6	Park/Neutral position relay (With A/T)
F1	E40	L/4	Clutch interlock relay (With M/T)
F1	E41	B/5	ABS solenoid valve relay
F1	E42	B/5	ABS motor relay
G1*	E43	BR/6	Cooling fan relay-2
G1	E44	B/5	Theft warning relay
E1	E45	L/4	Front fog lamp relay
F1*	E46	BR/6	Cooling fan relay-3
F1	E47	W/3	Horn high relay
F1	E48	BR/6	Theft warning lamp relay
G1	E49	W/3	Horn low relay
G1*	E50	BR/6	Cooling fan relay-1
D1	E51	GY/2	Front wheel sensor RH
D1	E52	B/1	Horn low
C3	E53	GY/2	Ambient air temperature switch (With manual A/C)

* : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working
 according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
EL
 IDX

CEL956

HARNES LAYOUT



Engine Room Harness (Cont'd)

For detail ground distribution information, refer to "GROUND DISTRIBUTION".



- ★ E71 : Fuse block (J/B)
- E72 : Fuse block (J/B)
- E73 : Fuse block (J/B)
- E74 : Diode
- ★ E75 : To M6
- ★ E76 : Ignition switch
- E77 : Key switch
- E78 : Combination switch (Lighting switch)
- W/4 : Fuse block (J/B)
- W/16 : Fuse block (J/B)
- B/2 : Fuse block (J/B)
- W/2 : Diode
- SMJ : To M6
- W/6 : Ignition switch
- BR/2 : Key switch
- BR/8 : Combination switch (Lighting switch)

- E79 : BR/4 : Combination switch (Lighting switch)
- E80 : W/3 : Combination switch (Front fog lamp switch)
- E81 : GY/8 : Combination switch (Front wiper switch)
- E82 : GY/6 : Daytime light control unit (For Canada)
- E83 : GY/8 : Daytime light control unit (For Canada)
- E84 : W/8 : To B104
- E85 : SMJ : ABS control unit
- E86 : - : Body ground




★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



Engine Control Harness

NCEL0135

For detail ground distribution information, refer to "GROUND DISTRIBUTION".




- Engine control harness**
- ★ F1 GY/3 : Front heated oxygen sensor
 - ★ F2 BR/4 : Mass air flow sensor
 - ★ F3 GY/6 : Distributor
 - ★ F4 GY/2 : Distributor
 - ★ F5 G/4 : To (E122)
 - ★ F6 G/8 : To (E123)
 - ★ F8 GY/3 : Throttle position switch
 - ★ F9 BR/3 : Throttle position sensor
 - ★ F10 GY/3 : Absolute pressure sensor
 - ★ F11 BR/2 : IACV-AAC valve
 - ★ F12 GY/2 : IACV-FICD solenoid valve
 - ★ F13 G/8 : To (F51)
 - ★ F14 GY/2 : EGR temperature sensor
 - ★ F15 - : Engine ground
 - ★ F16 - : Engine ground
 - ★ F17 GY/6 : EVAP canister purge volume control valve
 - ★ F18 GY/2 : Resistor
 - ★ F19 L/12 : Joint connector-1
 - ★ F20 GY/6 : Joint connector-2
 - ★ F21 W/24 : TCM (Transmission control module)
 - ★ F22 GY/24 : TCM (Transmission control module)
 - ★ F23 W/18 : To (M49)
 - ★ F24 W/20 : To (M62)
 - ★ F25 W/16 : To (M63)
 - ★ F26 SMJ : ECM
 - ★ F27 GY/10 : To (E128)



Engine ground

Engine control sub-harness

- ★ F51 G/8 : To (F13)
- ★ F52 B/2 : Injector No. 1
- ★ F53 B/2 : Injector No. 2
- ★ F54 B/2 : Injector No. 3
- ★ F55 B/2 : Injector No. 4
- ★ F56 B/2 : Knock sensor



★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
PS
BT
HA
SC
EL
IDX

CEL959

HARNES LAYOUT

Body Harness

Body harness

- B1 W/12 : Fuse block (J/B)
- B2 W/12 : To M7
- B3 W/20 : To M8
- B4 B/3 : Front door switch (Driver side)
- B5 OR/2 : Satellite sensor LH
- B6 - : Body ground
- B7 - : Body ground
- B8 W/4 : Seat belt pre-tensioner (Driver side)
- B9 W/8 : To D41
- B10 G/12 : To B120
- B11 BR/1 : Rear door switch LH
- B12 Y/2 : Side air bag module LH
- B13 W/3 : Seat belt buckle switch (Driver side)
- B14 W/2 : Power seat switch (Driver side)
- B15 GY/3 : Heated seat (Driver side)
- B16 GY/4 : Rear heated oxygen sensor
- B17 B/1 : Parking brake switch
- B18 W/8 : To B51
- B19 Y/10 : Air bag diagnosis sensor unit
- B20 GY/3 : Heated seat (Passenger side)
- B21 Y/2 : Side air bag module RH
- B22 BR/1 : Front door switch (Passenger side)
- B23 Y/2 : Satellite sensor RH
- B24 - : Body ground
- B25 - : Body ground
- B26 W/4 : Seat belt pre-tensioner (Passenger side)
- B27 W/8 : To D61


Body sub-harness-1

- B51 W/8 : To B19
- B52 L/4 : Heated seat switch LH
- B53 W/4 : Heated seat switch RH




Body sub-harness-2

- B71 B/1 : Rear window defogger (-)
- B72 - : Body ground

★: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



For detail ground distribution information, refer to "GROUND DISTRIBUTION".





HARNES LAYOUT

Body No. 2 Harness

Body No. 2 Harness

NCEL0197

For detail ground distribution information, refer to "GROUND DISTRIBUTION".



- | | | | | |
|----------|-------|---|--|-------|
| (B101) | W/2 | : | To | (M73) |
| ★ (B102) | G/10 | : | To | (M74) |
| (B103) | W/20 | : | To | (M75) |
| (B104) | W/8 | : | To | (E84) |
| (B105) | GY/2 | : | Rear wheel sensor RH | |
| (B106) | GY/2 | : | Fuel pump | |
| ★ (B107) | GY/4 | : | Fuel tank gauge unit | |
| (B108) | BR/2 | : | Rear wheel sensor LH | |
| (B109) | - | : | Body ground | |
| (B110) | - | : | Body ground | |
| (B111) | BR/1 | : | Rear door switch RH | |
| (B112) | W/6 | : | Power antenna | |
| ★ (B113) | W/12 | : | To (T1) | |
| (B114) | GY/26 | : | BOSE speaker amp. | |
| (B115) | B/1 | : | Rear window defogger (+) | |
| (B116) | BR/2 | : | Rear speaker RH | |
| (B117) | W/2 | : | Trunk room lamp | |
| (B118) | W/2 | : | High-mounted stop lamp
(Without rear spoiler) | |
-
- | | | | |
|----------|------|---|-----------------|
| (B119) | BR/2 | : | Rear speaker LH |
| ★ (B120) | G/12 | : | To (B10) |
| (B121) | W/6 | : | To (T31) |

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CEL961

HARNES LAYOUT

Tail & Tail No. 2 Harness

Tail & Tail No. 2 Harness

NCELO138

Tail harness

- ★ T1 W/12 : To (BT13)
- T3 BR/2 : Rear side marker lamp RH
- T4 BR/2 : Rear combination lamp RH (Fender)
- T5 W/3 : Rear combination lamp RH (Fender)
- T6 - : Body ground
- T7 - : Body ground
- T8 W/3 : Rear combination lamp LH (Fender)
- T9 BR/2 : Rear combination lamp LH (Fender)
- T10 BR/2 : Rear side marker lamp LH
- ★ T20 GY/8 : To (T19)

Tail sub-harness



- ★ T11 B/2 : EVAP canister vent control valve
- ★ T12 G/2 : Vacuum cut valve bypass valve
- ★ T13 GY/3 : EVAP control system pressure sensor
- ★ T19 GY/8 : To (T20)

Tail No. 2 sub-harness

- T31 W/6 : To (BT1)
- T32 W/6 : To (T51)

Tail No. 2 harness

- T51 W/6 : To (T32)
- T52 W/4 : Rear combination lamp RH (Trunk lid)
- T53 W/2 : Trunk lid key cylinder switch (Unlock switch)
- T54 BR/2 : High-mounted stop lamp (With rear spoiler)
- T55 B/2 : Trunk room lamp switch
- T56 BR/2 : License lamp
- T57 W/4 : Rear combination lamp LH (Trunk lid)






For detail ground distribution information, refer to "GROUND DISTRIBUTION".

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Engine Harness

NCEL0139



- ★ E101 : GY/9 : To E33
- E102 : GY/1 : To E34
- E103 : GY/1 : To E35
- E104 : GY/8 : To E36
- E105 : - : Body ground
- E106 : GY/2 : Alternator
- E107 : - : Alternator
- E108 : B/1 : Compressor
- E109 : - : Engine ground
- E110 : GY/2 : IACV-air regulator
- E111 : B/1 : Thermal transmitter
- E112 : GY/2 : Engine coolant temperature sensor
- ★ E113 : B/1 : Oil pressure switch
- E114 : G/2 : EVAP canister purge control solenoid valve
- ★ E115 : B/2 : MAP/BARO switch solenoid valve
- ★ E116 : B/2 : EGRC-solenoid valve
- E117 : - : Starter motor
- E118 : GY/1 : Starter motor
- ★ E119 : GY/2 : Vehicle speed sensor
- ★ E120 : B/2 : Park/Neutral position switch } (With M/T)
- E121 : GY/2 : Back-up lamp switch
- ★ E122 : G/4 : To F5
- ★ E123 : G/8 : To F6
- ★ E124 : B/8 : A/T solenoid valve
- ★ E125 : B/10 : Park/Neutral position switch } (With A/T)
- ★ E126 : GY/2 : Crankshaft position sensor (OBD)
- E127 : - : Battery (+)
- ★ E128 : GY/10 : To F27
- ★ E129 : GY/3 : Revolution sensor (With A/T)

★1: With A/T

★2: With M/T

For detail ground distribution information, refer to "GROUND DISTRIBUTION".

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.

Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


CEL958

HARNESS LAYOUT

Room Lamp Harness

Room Lamp Harness

NCELO140



- R1** W/6 : To **M70**
- R2** W/2 : Vanity mirror lamp (Passenger side)
- R3** W/2 : Map lamp
- R4** L/6 : Sunroof switch (With sunroof)
- R5** W/2 : Sunroof motor (With sunroof)
- R6** W/2 : Vanity mirror lamp (Driver side)
- R7** W/2 : Interior room lamp

*1 : With sunroof

*2 : Without sunroof


CEL963

HARNESS LAYOUT

Air Bag Harness

Air Bag Harness

NCELD141



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

HARNESS LAYOUT


Front Door Harness

Front Door Harness

NCEL0142

LH SIDE


- (D1) W/18 : To (M16)
- (D2) W/6 : To (M17)
- (D3) BR/2 : Front door speaker LH
- (D4) BR/3 : Door mirror actuator (Driver side)
(Without door mirror defogger)
- (D5) GY/5 : Door mirror actuator (Driver side)
(With door mirror defogger)
- (D6) W/16 : Power window main switch
- (D7) B/2 : Front power window regulator
(Driver side)
- (D8) BR/3 : Front door key cylinder switch
(Driver side)
- (D9) GY/4 : Front door lock actuator
(Driver side)



CEL965

RH SIDE

- (D21) W/18 : To (M72)
- (D22) BR/2 : Front door speaker RH
- (D23) BR/3 : Door mirror actuator (Passenger side)
(Without door mirror defogger)
- (D24) GY/5 : Door mirror actuator (Passenger side)
(With door mirror defogger)
- (D25) W/8 : Front power window switch
(Passenger side)
- (D26) B/2 : Front power window regulator
(Passenger side)
- (D27) BR/3 : Front door key cylinder switch
(Passenger side)
- (D28) GY/4 : Front door lock actuator
(Passenger side)




CEL966

HARNESS LAYOUT


Rear Door Harness

Rear Door Harness

NCEL0143



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX



SU
BR
ST
RS
BT
HA
SC
EL
IDX

BULB SPECIFICATIONS*Headlamp*

Headlamp		<small>NCELO144S03</small>
Item	Wattage (W)	
High/Low	60/55 (HB2)	

Exterior Lamp

Exterior Lamp		<small>NCELO144S01</small>
Item	Wattage (W)	
Front fog lamp	35 (H3)	
Front turn signal lamp	21	
Side turn signal lamp	5	
Parking lamp	5	
Front side marker lamp	3.8	
Rear combination lamp	Turn signal	21
	Stop/Tail	21/5
	Back-up	13
Rear side marker lamp	3.8	
License lamp	5	
High-mounted stop lamp (without rear spoiler)	21	

Interior Lamp

Interior Lamp		<small>NCELO144S02</small>
Item	Wattage (W)	
Interior room lamp	8	
Map lamp	With sunroof	5
	Without sunroof	8
Vanity mirror lamp	8	
Trunk room lamp	3.4	

WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for. Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C, A	HA	Auto Air Conditioner
A/C, M	HA	Manual Air Conditioner
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
AIRREG	EC	IACV-AIR Regulator
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device
AT/C	EC	A/T Control
AT/IND	EL	A/T Indicator Lamp
ATDIAG	EC	A/T Diagnosis Communication Line
AUDIO	EL	Audio
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Solenoid Valve
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor (OBD)
CMPS	EC	Camshaft Position Sensor
COOL/F	EC	Cooling Fan Control
D/LOCK	EL	Power Door Lock
DEF	EL	Rear Window Defogger
DTRL	EL	Headlamp — With Daytime Light System —
ECTS	EC	Engine Coolant Temperature Sensor
EGR/TS	EC	EGR Temperature Sensor
EGRC/V	EC	EGRC-solenoid Valve
EGRC1	EC	EGR Function

Code	Section	Wiring Diagram Name
ENGSS	AT	Engine Speed Signal
F/FOG	EL	Front Fog Lamp
F/PUMP	EC	Fuel Pump Control
FICD	EC	IACV-FICD Solenoid Valve
FRO2/H	EC	Front Heated Oxygen Sensor Heater
FRO2	EC	Front Heated Oxygen Sensor (Front HO2S)
FTS	AT	A/T Fluid Temperature Sensor
FUEL	EC	Fuel Injection System Function
H/LAMP	EL	Headlamp
HORN	EL	Horn
HSEAT	EL	Heated Seat
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Vanity Mirror and Trunk Room Lamps
KS	EC	Knock Sensor
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil, and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Door Mirror
MULTI	EL	Multi-remote Control System
NONDTC	AT	Non-detectable Items
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
PST/SW	EC	Power Steering Oil Pressure Switch
ROOM/L	EL	Interior Room Lamp
RRO2/H	EC	Rear Heated Oxygen Sensor Heater
RRO2	EC	Rear Heated Oxygen Sensor
S/SIG	EC	Start Signal
SEAT	EL	Power Seat
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop lamp
SW/V	EC	MAP/BARO Switch Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock up)
TCV	AT	Torque Converter Clutch Solenoid Valve
TFTS	EC	Tank Fuel Temperature Sensor
THEFT	EL	Theft Warning System
TP/SW	EC	Throttle Position Switch
TPS	AT	Throttle Position Sensor
TPS	EC	Throttle Position Sensor
TRNSMT	EL	Integrated HOMELINK [™] Transmitter
TURN	EL	Turn Signal and Hazard Warning Lamps
VENT/V	EC	EVAP Canister Vent Control Valve
VSS	EC	Vehicle Speed Sensor
VSSAT	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer