

A
CO
C
D
E
F
G
H
I
J
K
L
M

SECTION CO

ENGINE COOLING SYSTEM

CONTENTS

QG	QR
<p>PRECAUTIONS 3</p> <p style="padding-left: 20px;">Precautions For Liquid Gasket 3</p> <p style="padding-left: 20px;">REMOVAL OF LIQUID GASKET SEALING 3</p> <p style="padding-left: 20px;">LIQUID GASKET APPLICATION PROCEDURE... 3</p> <p>PREPARATION 4</p> <p style="padding-left: 20px;">Special Service Tools 4</p> <p>OVERHEATING CAUSE ANALYSIS 5</p> <p style="padding-left: 20px;">Troubleshooting Chart 5</p> <p>COOLING SYSTEM 7</p> <p style="padding-left: 20px;">Cooling Circuit 7</p> <p>ENGINE COOLANT 8</p> <p style="padding-left: 20px;">Inspection 8</p> <p style="padding-left: 20px;">LEVEL CHECK 8</p> <p style="padding-left: 20px;">LEAK CHECK 8</p> <p style="padding-left: 20px;">Changing Engine Coolant 8</p> <p style="padding-left: 20px;">DRAINING ENGINE COOLANT 8</p> <p style="padding-left: 20px;">REFILLING ENGINE COOLANT 8</p> <p style="padding-left: 20px;">FLUSHING COOLING SYSTEM 9</p> <p>RADIATOR 11</p> <p style="padding-left: 20px;">Removal and Installation 11</p> <p style="padding-left: 20px;">REMOVAL 11</p> <p style="padding-left: 20px;">INSTALLATION 12</p> <p style="padding-left: 20px;">Disassembly and Assembly of Cooling Fan 12</p> <p style="padding-left: 20px;">DISASSEMBLY 12</p> <p style="padding-left: 20px;">ASSEMBLY 12</p> <p style="padding-left: 20px;">CHECKING RADIATOR CAP 12</p> <p style="padding-left: 20px;">CHECKING RADIATOR 13</p> <p>RADIATOR (ALUMINUM TYPE) 14</p> <p style="padding-left: 20px;">Disassembly and Assembly 14</p> <p style="padding-left: 20px;">PREPARATION 14</p> <p style="padding-left: 20px;">DISASSEMBLY 14</p> <p style="padding-left: 20px;">ASSEMBLY 15</p> <p style="padding-left: 20px;">INSPECTION 17</p> <p>WATER PUMP 18</p> <p style="padding-left: 20px;">Removal and Installation 18</p> <p style="padding-left: 20px;">REMOVAL 18</p> <p style="padding-left: 20px;">INSPECTION AFTER REMOVAL 18</p> <p style="padding-left: 20px;">INSTALLATION 19</p> <p style="padding-left: 20px;">INSPECTION AFTER INSTALLATION 19</p>	<p>THERMOSTAT AND THERMOSTAT HOUSING 20</p> <p style="padding-left: 20px;">Removal and Installation 20</p> <p style="padding-left: 20px;">REMOVAL 20</p> <p style="padding-left: 20px;">INSPECTION AFTER REMOVAL 21</p> <p style="padding-left: 20px;">INSTALLATION 21</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS) 22</p> <p style="padding-left: 20px;">Standard and Limit 22</p> <p style="padding-left: 20px;">CAPACITY 22</p> <p style="padding-left: 20px;">THERMOSTAT 22</p> <p style="padding-left: 20px;">RADIATOR 22</p> <p style="padding-left: 20px;">Tightening Torque 22</p>
	QR
	<p>PRECAUTIONS 23</p> <p style="padding-left: 20px;">Precautions For Liquid Gasket 23</p> <p style="padding-left: 20px;">REMOVAL OF LIQUID GASKET 23</p> <p style="padding-left: 20px;">LIQUID GASKET APPLICATION PROCEDURE.. 23</p> <p>PREPARATION 24</p> <p style="padding-left: 20px;">Special Service Tools 24</p> <p>OVERHEATING CAUSE ANALYSIS 25</p> <p style="padding-left: 20px;">Troubleshooting Chart 25</p> <p>COOLING SYSTEM 27</p> <p style="padding-left: 20px;">Cooling Circuit 27</p> <p>ENGINE COOLANT 29</p> <p style="padding-left: 20px;">Inspection 29</p> <p style="padding-left: 20px;">LEVEL CHECK 29</p> <p style="padding-left: 20px;">LEAK CHECK 29</p> <p style="padding-left: 20px;">Changing Engine Coolant 29</p> <p style="padding-left: 20px;">DRAINING ENGINE COOLANT 29</p> <p style="padding-left: 20px;">REFILLING ENGINE COOLANT 29</p> <p style="padding-left: 20px;">FLUSHING COOLING SYSTEM 30</p> <p>RADIATOR 31</p> <p style="padding-left: 20px;">Removal and Installation 31</p> <p style="padding-left: 20px;">REMOVAL 31</p>

INSTALLATION	31
Disassembly and Assembly of Cooling Fan	32
DISASSEMBLY	32
ASSEMBLY	32
CHECKING RADIATOR CAP	32
CHECKING RADIATOR	33
RADIATOR (ALUMINUM TYPE)	34
Disassembly and Assembly	34
PREPARATION	34
DISASSEMBLY	34
ASSEMBLY	35
INSPECTION	37
WATER PUMP	38
Removal and Installation	38
REMOVAL	38
INSPECTION AFTER REMOVAL	39
INSTALLATION	39
INSPECTION AFTER INSTALLATION	39
THERMOSTAT AND WATER CONTROL VALVE	40
Removal and Installation	40
REMOVAL	40
INSPECTION AFTER REMOVAL	41
INSTALLATION	41
SERVICE DATA AND SPECIFICATIONS (SDS)	42
Standard and Limit	42
CAPACITY	42
THERMOSTAT	42
WATER CONTROL VALVE	42
RADIATOR	42
Tightening Torque	42

YD

PRECAUTIONS	43
Precautions For Liquid Gasket	43
REMOVAL AND LIQUID GASKET	43
LIQUID GASKET APPLICATION PROCEDURE..	43
PREPARATION	44
Special Service Tools	44
OVERHEATING CAUSE ANALYSIS	45
Troubleshooting Chart	45

COOLING SYSTEM	47
Cooling Circuit	47
ENGINE COOLANT	49
Inspection	49
LEVEL CHECK	49
LEAK CHECK	49
Changing Engine Coolant	49
DRAINING ENGINE COOLANT	49
REFILLING ENGINE COOLANT	50
FLUSHING COOLING SYSTEM	51
RADIATOR	52
Removal and Installation	52
REMOVAL	52
INSTALLATION	52
Disassembly and Assembly Radiator Fan	53
DISASSEMBLY	53
ASSEMBLY	53
Checking Radiator Cap	53
Checking Radiator	54
RADIATOR (ALUMINUM TYPE)	55
Disassembly and Assembly	55
PREPARATION	55
DISASSEMBLY	55
ASSEMBLY	56
INSPECTION	58
WATER PUMP	59
Removal and Installation	59
REMOVAL	59
INSPECTION AFTER REMOVAL	59
INSTALLATION	60
INSPECTION AFTER INSTALLATION	60
THERMOSTAT AND WATER PIPING	61
Removal and Installation	61
REMOVAL	61
INSPECTION AFTER REMOVAL	62
INSTALLATION	62
SERVICE DATA AND SPECIFICATIONS (SDS)	63
Standard and Limit	63
CAPACITY	63
THERMOSTAT	63
RADIATOR	63
Tightening Torque	63

PRECAUTIONS

Precautions For Liquid Gasket

REMOVAL OF LIQUID GASKET SEALING

- After removing the mounting bolts and nuts, separate the mating surface using a seal cutter and remove the liquid gasket.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the gasket area.


CAUTION:

If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.



LIQUID GASKET APPLICATION PROCEDURE



- Using a scraper, remove the old liquid gasket adhering to the gasket application surface and the mating surface.
 - Remove the liquid gasket completely from the groove of the gasket application surface, mounting bolts and bolt holes.
- Wipe the gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
- Attach the liquid gasket to the tube presser.
 - Use Genuine Liquid Gasket or equivalent.**
- Apply the gasket without breaks to the specified location with the specified dimensions.
 - If there is a groove for the liquid gasket application, apply the gasket to the groove.



- As for the bolt holes, normally apply the gasket inside the holes. Occasionally, it should be applied outside the holes. Make sure to read the instruction in this manual.
- Within five minutes of gasket application, install the mating component.
- If the liquid gasket protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed from the installation, fill the engine oil and coolant.

CAUTION:

If there are additional instructions in this manual, observe them.



A
CO
C
D
E
F
G
H
I
J
K
L
M

PREPARATION





[QG]

PFP:00002

EBS00GPV

PREPARATION

Special Service Tools

Tool number Tool name	Description
WS39930000 Tube presser  <p style="text-align: center;">S-NT052</p>	Pressing the tube of liquid gasket
EG17650301 Radiator cap tester adapter  <p style="text-align: center;">S-NT564</p>	Adapting radiator cap tester to radiator filler neck a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)
KV99103510 Radiator plate pliers A  <p style="text-align: center;">S-NT224</p>	Installing radiator upper and lower tanks
KV99103520 Radiator plate pliers B  <p style="text-align: center;">S-NT225</p>	Removing radiator upper and lower tanks

OVERHEATING CAUSE ANALYSIS

[QG]

OVERHEATING CAUSE ANALYSIS

PFP:00012

Troubleshooting Chart

EBS00GPW

	Symptom		Check items	
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—
		Thermostat stuck closed	—	
		Damaged fins	Dust contamination or paper clogging	
			Mechanical damage	
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)	
	Reduced air flow	Cooling fan does not operate	—	—
		High resistance to fan rotation		
		Damaged fan blades		
		Damaged radiator shroud	—	—
		Improper coolant mixture ratio	—	—
		Poor coolant quality	—	—
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp
				Cracked hose
			Water pump	Poor sealing
			Radiator cap	Loose
Poor sealing				
Radiator			O-ring for damage, deterioration or improper fitting	
		Cracked radiator tank		
		Cracked radiator core		
	Reservoir tank	Cracked reservoir tank		
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration		
		Cylinder head gasket deterioration		

A
CO
C
D
E
F
G
H
I
J
K
L
M

OVERHEATING CAUSE ANALYSIS

[QG]

	Symptom		Check items			
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load		
				Driving in low gear for extended time		
				Driving at extremely high speed		
						—
			Powertrain system malfunction			
			Installed improper size wheels and tires			
	Dragging brakes					
	Improper ignition timing					
	Blocked or restricted air flow	Blocked bumper		—	—	
		Blocked radiator grille	Installed car brassiere			
Mud contamination or paper clogging						
Blocked radiator		—				
Blocked condenser		—				
Installed large fog lamp		—				

COOLING SYSTEM

[QG]

COOLING SYSTEM



PFP:21020

Cooling Circuit

EBS00GPX

A
C
D
E
F
G
H
I
J
K
L
M

CO



PBIC0644E


ENGINE COOLANT

PFK:KQ100

Inspection LEVEL CHECK

EBS00GPY

- Check if the reservoir tank coolant level is within MIN to MAX when engine is cool.
- Drain or refill coolant when it is too much or too little.



LEAK CHECK

- To check for leakage, apply pressure to the cooling system with a tester.


Testing pressure : 157 kPa (1.57 bar, 1.6 kg/cm² , 23 psi)

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

CAUTION:

Higher pressure than specified may cause radiator damage.



Changing Engine Coolant

EBS00GPZ

WARNING:

- To avoid being scalded, never change the coolant when the engine is hot.
- Wrap a thick cloth around cap and carefully remove the cap. First, turn the cap a quarter of a turn to release built-up pressure. Then turn the cap all the way.

DRAINING ENGINE COOLANT


1. Remove undercover.
2. Disconnect radiator lower hose and remove radiator cap.

CAUTION:

Be careful not to allow coolant to contact drive belts.

3. Open drain plugs on cylinder block.
4. Remove reservoir tank and drain coolant.
5. Check drained coolant for contaminants such as rust, corrosion or discoloration.

If contaminated, flush engine cooling system. Refer to [CO-9](#). **"FLUSHING COOLING SYSTEM"**.



REFILLING ENGINE COOLANT


1. Install reservoir tank, radiator drain plug and cylinder block drain plug.


Apply sealant to the thread of cylinder block drain plug.

- Use Genuine Liquid Gasket or equivalent.

ENGINE COOLANT


[QG]

 : 34.3 - 44.1 N·m (3.5 - 4.4 kg·m , 26 - 32 ft·lb)




2. Remove air relief plug.
3. Fill radiator and reservoir tank to specified level.
- Use Genuine Nissan Anti-freeze Coolant or equivalent mixed with water (distilled or demineralized). Refer to [MA-16, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).

Engine coolant capacity (With reservoir tank):
Approx. 6.7 ℓ (5-7/8 Imp qt)



Reservoir tank:
0.7 ℓ (5/8 Imp qt)

- Pour coolant slowly of less than 2 ℓ (1-3/4 Imp qt) a minute to allow air in system to escape.
- Tighten the air relief plug when the coolant comes out from the relief plug.
4. Warm up engine to normal operating temperature without radiator cap installed.
- If coolant overflows radiator filler hole, install filler cap.
5. Run engine at 3,000 rpm for 10 seconds and return to idle speed with radiator cap installed.
- Repeat two or three times.



Watch coolant temperature gauge so as not to overheat the engine.

6. Stop engine and cool down to less than approximately 50°C (122°F).
- Cool down using a fan to reduce the time.
- If necessary, refill radiator up to filler neck with coolant.
7. Refill reservoir tank to MAX level line with coolant.
8. Repeat steps 4 through 7 two or more times with radiator cap installed until coolant level no longer drops.
9. Check cooling system for leaks with engine running.
10. Warm up engine, and check for sound of coolant flow while running engine from idle up to 3,000 rpm with heater temperature controller set at several positions between COOL and WARM.
- Sound may be noticeable at heater unit.
11. Repeat step 9 three times.
12. If sound is heard, bleed air from cooling system by repeating steps 4 through 7 until coolant level no longer drops.
- Clean excess coolant from engine.

FLUSHING COOLING SYSTEM

1. Fill radiator with water until water spills from the air relief hole, then close air relief plug. Fill radiator and reservoir tank with water and reinstall radiator cap.

ENGINE COOLANT

[QG]


2. Run engine and warm it up to normal operating temperature.
3. Rev engine two or three times under no-load.
4. Stop engine and wait until it cools down.
5. Drain water.
6. Repeat steps 1 through 5 until clear water begins to drain from radiator.

RADIATOR

PFP:21400

Removal and Installation

EBS00GGG



- | | | |
|-------------------------|------------------------|--------------------------|
| 1 Reservoir tank | 2 Cap | 3 Radiator tank hose |
| 4 Radiator hose (upper) | 5 Radiator cap | 6 Nut |
| 7 Clip | 8 Mounting bracket | 9 Mounting rubber |
| 10 Radiator | 11 A/T oil cooler hose | 12 Radiator hose (lower) |
| 13 Cooling fan assembly | 14 Bracket | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

REMOVAL

1. Remove undercover.
2. Drain coolant. Refer to [CO-8, "DRAINING ENGINE COOLANT"](#).

CAUTION:

Perform when the engine is cold.

3. Separate fan motor harness connector.
4. Move relay case on left side of battery.
5. Remove A/T oil cooler hose.
 - Install blind plug to avoid leakage of A/T fluid.
6. Disconnect radiator upper hose, lower hose and mounting bracket.
7. Remove radiator and cooling fan assembly.

CAUTION:


Do not damage or scratch radiator core when removing.

INSTALLATION

- Reinstall any parts removed in reverse order of removal.
- Check for coolant leaks. Refer to [CO-8, "LEAK CHECK"](#).

Disassembly and Assembly of Cooling Fan

EBS00GQH



1 Cooling fan motors

2 Fan shroud

3 Cooling fan

DISASSEMBLY

1. Remove cooling fan.
2. Remove insulator.
3. Remove fan motor from fan shroud.

ASSEMBLY

- Install in the reverse order of removal.
- When installing fan, apply adhesive on nut portion of fan motor shaft and tighten installation nut.


CHECKING RADIATOR CAP

1. Pull the negative-pressure valve to open it and check that it closes completely when released.
- Check that there is no dirt or damage on the valve seat of the radiator cap negative-pressure valve.

RADIATOR

[QG]

- Check that there are no unusual conditions in the opening and closing conditions of the negative-pressure valve.



2. Check radiator cap relief pressure.


Standard :

78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm² , 11 - 14 psi)

Limit :

59 kPa (0.59 bar, 0.6 kg/cm² , 9 psi)

- When connecting the radiator cap to the tester, apply water or LLC to the cap seal part.
- Replace the radiator cap if there is an unusual conditions in the negative-pressure valve, or if the open-valve pressure is outside of the standard values.



CHECKING RADIATOR

Check radiator for mud or clogging. If necessary, clean radiator as follows.


- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, fan shroud and horns. Then tape the harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downwards.
 2. Apply water again to all radiator core surface once per minute.
 3. Stop washing if any stains no longer flow out from the radiator.
 4. Blow air into the back side of radiator core vertically downwards.
- Use compressed air lower than 490 kPa (4.9 bar, 5 kg/cm² , 71 psi) and keep distance more than 30 cm (11.8 in).
5. Blow air again into all the radiator core surface once per minute until no water sprays out.

RADIATOR (ALUMINUM TYPE)

PFP:21460


Disassembly and Assembly

EBS00GQ3




PREPARATION

1. Attach the spacer to the tip of the radiator plate pliers A. Spacer specification: 1.5 mm (0.059 in) thick x 18 mm (0.71 in) wide x 8.5 mm (0.335 in) long.
2. Make sure that when radiator plate pliers A are closed dimension H'' is approx. 7.6 mm (0.299 in).
3. Adjust dimension H'' with the spacer, if necessary.



DISASSEMBLY


1. Remove tank with Tool.



RADIATOR (ALUMINUM TYPE)


[QG]

- Grip the crimped edge and bend it upwards so that Tool slips off.
Do not bend excessively.




- In areas where Tool cannot be used, use a screwdriver to bend the edge up.

Be careful not to damage tank.




2. Make sure the edge stands straight up.
3. Remove oil cooler from tank. (A/T model only)



ASSEMBLY

1. Install oil cooler. (A/T model only)
Pay attention to direction of conical washer.




A
CO
C
D
E
F
G
H
I
J
K
L
M


RADIATOR (ALUMINUM TYPE)

[QG]



2. Clean contact portion of tank.




3. Install sealing rubber.
Push it in with fingers.
Be careful not to twist sealing rubber.



4. Caulk tank in specified sequence with Tool.



- Use pliers in the locations where Tool cannot be used.



RADIATOR (ALUMINUM TYPE)


[QG]

5. Make sure that the rim is completely crimped down.

Standard height "H" : 8.0 - 8.4 mm (0.315 - 0.331 in)

6. Confirm that there is no leakage.

Refer to Inspection.



A

CO

C

D


INSPECTION

1. Apply pressure with Tool.

Specified pressure value : 157 kPa (1.57 bar, 1.6 kg/cm², 23 psi)

WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp. Attach a hose to the oil cooler as well. (A/T model only)




E

F

G

H

2. Check for leakage.



I

J

K

L


M

WATER PUMP

PFP:21020

Removal and Installation

EBS00GQ4



- | | | |
|---------------|--------------|---------------------|
| 1 Gasket | 2 Water pump | 3 Water pump pulley |
| 4 Front cover | | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

Water Pump Removal

1. Remove drive belts. Refer to DRIVE BELTS, [EM-16, "Removal and Installation"](#) .
2. Drain coolant. Refer to [CO-8, "DRAINING ENGINE COOLANT"](#) .

CAUTION:

Perform when the engine is cold.


3. Remove idler pulley.
4. Remove right engine mounting stay.
5. Remove water pump.
 - Coolant will leak from the cylinder block, so have a receptacle ready below.

CAUTION:

- Handle the water pump vane so that it does not contact any other parts.
- Water pump cannot be disassembled and should be replaced as a unit.

INSPECTION AFTER REMOVAL

- Visually check that there is no significant dirt or rusting on the water pump body and vane.
- Check that there is no looseness in the vane shaft, and that it turns smoothly when rotated by hand.




INSTALLATION

- Install in the reverse order of removal.

CAUTION:

As shown in the figure, two types of bolts are used.

- A** : Long
- B** : Short



INSPECTION AFTER INSTALLATION

- Check for coolant leaks using radiator cap tester. Refer to [CO-8, "LEAK CHECK"](#).


A
CO
C
D
E
F
G
H
I
J
K
L
M

THERMOSTAT AND THERMOSTAT HOUSING

PFP:21200

Removal and Installation

EBS00G05



- | | | |
|-------------------------|-----------------|-------------------------|
| 1 Heater hose | 2 Gasket | 3 Thermostat housing |
| 4 Radiator hose (upper) | 5 Copper washer | 6 Air relief plug |
| 7 Thermostat | 8 Rubber ring | 9 Radiator hose (lower) |
| 10 Water inlet | | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

Thermostat Removal

1. Drain engine coolant. Refer to [CO-8, "DRAINING ENGINE COOLANT"](#).


CAUTION:

Perform when the engine is cold.

2. Remove air cleaner case (upper).
3. Disconnect radiator lower hose.
4. Remove water inlet and thermostat.
5. Remove air duct and resonator.
6. Remove thermostat housing.

INSPECTION AFTER REMOVAL

- Place a thread so that it is caught in the valves of the thermostat. Immerse fully in a container filled with water. Heat while stirring. (The example in the figure shows the thermostat.)
- The valve opening temperature is the temperature at which the valve opens and falls from the thread.
- Continue heating. Check the full-open lift amount.
- After checking the full-open lift amount, lower the water temperature and check the valve closing temperature.



Standard values


	Thermostat
Valve opening temperature	80.5 - 83.5°C (177 - 182°F)
Full-open lift amount	More than 9 mm/ 95°C (0.35 in/ 203°F)
Valve closing temperature	77°C (171°F)

INSTALLATION


- Install in the reverse order of removal paying attention to the following.

Installation of Thermostat

- Install the thermostat with the whole circumference of each flange part fit securely inside the rubber ring. (The example in the figure shows the thermostat.)



- Install thermostat with jiggle valve facing the direction shown in the figure.
- Install water inlet without changing thermostat position.



SERVICE DATA AND SPECIFICATIONS (SDS)

[QG]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit CAPACITY

EBS00H9V

Coolant capacity [With reservoir tank (MAX level)]	Approximately 6.7 ℓ (5-7/8 Imp qt)
--	------------------------------------

THERMOSTAT

Valve opening temperature	80.5 - 83.5°C (177 - 182°F)
Valve lift	More than 9 mm/ 95°C (0.35 in/203°F)

RADIATOR

Unit: kPa (bar, kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.78 - 0.98, 0.8 - 1.0, 11 - 14)
	Limit	59 (0.59, 0.6, 9)
Leakage test pressure		157 (1.57, 1.6, 23)

Tightening Torque

EBS00GQA

Unit: N·m (kg-m, ft-lb)
Unit: N·m (kg-m, in-lb)*

Cylinder block drain plug	34.3 - 44.1 (3.5 - 4.5, 26 - 32)
Radiator mounting bracket	3.8 - 4.5 (0.39 - 0.46, 34 - 39)*
Water pump	17 - 24 (1.8 - 2.4, 13 - 17)
Water inlet	6.3 - 8.3 (0.65 - 0.84, 56 - 73)*

PRECAUTIONS

Precautions For Liquid Gasket REMOVAL OF LIQUID GASKET

- After removing the mounting bolts and nuts, separate the mating surface using a seal cutter and remove the liquid gasket.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the gasket applied area.



CAUTION:

If for some unavoidable reason a tool such as a flat-blade screwdriver is used, be careful not to damage the mating surfaces.




LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old liquid gasket adhering to the gasket application surface and the mating surface.
 - Remove the liquid gasket completely from the groove of the gasket application surface, mounting bolts and bolt holes.
2. Wipe the gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
3. Attach the liquid gasket to the tube presser.
 - **Use Genuine Liquid Gasket or equivalent.**
4. Apply the gasket without breaks to the specified location with the specified dimensions.
 - If there is a groove for the liquid gasket application, apply the gasket to the groove.



- As for the bolt holes, normally apply the gasket inside the holes. Occasionally, it should be applied outside the holes. Make sure to read the instruction in this manual.
- Within five minutes of gasket application, install the mating component.
- If the liquid gasket protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed from the installation, fill the engine oil and coolant.



CAUTION:

If there are instructions in this manual, observe them.

PREPARATION





[QR]

PFP:00002

EBS00G02

PREPARATION

Special Service Tools

Tool number Tool name	Description
WS39930000 Tube presser  <p style="text-align: center;">S-NT052</p>	Pressing the tube of liquid gasket
EG17650301 Radiator cap tester adapter  <p style="text-align: center;">S-NT564</p>	Adapting radiator cap tester to radiator filler neck a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)
KV99103510 Radiator plate pliers A  <p style="text-align: center;">S-NT224</p>	Installing radiator upper and lower tanks
KV99103520 Radiator plate pliers B  <p style="text-align: center;">S-NT225</p>	Removing radiator upper and lower tanks

OVERHEATING CAUSE ANALYSIS

[QR]

OVERHEATING CAUSE ANALYSIS

PFP:00012

Troubleshooting Chart

EBS00G03

	Symptom		Check items		
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	
		Thermostat stuck closed	—		
		Damaged fins	Dust contamination or paper clogging		—
			Mechanical damage		
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)		
	Reduced air flow	Cooling fan does not operate	—	—	
		High resistance to fan rotation			
		Damaged fan blades			
		Damaged radiator shroud	—	—	
		Improper coolant mixture ratio	—	—	
		Poor coolant quality	—	—	
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	
				Cracked hose	
			Water pump	Poor sealing	
			Radiator cap	Loose	
Poor sealing					
Radiator			O-ring for damage, deterioration or improper fitting		
		Cracked radiator tank			
		Cracked radiator core			
	Reservoir tank	Cracked reservoir tank			
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration			
		Cylinder head gasket deterioration			

A
CO
C
D
E
F
G
H
I
J
K
L
M

OVERHEATING CAUSE ANALYSIS

[QR]

	Symptom		Check items			
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load		
				Driving in low gear for extended time		
				Driving at extremely high speed		
					Powertrain system malfunction	—
					Installed improper size wheels and tires	
					Dragging brakes	
			Improper ignition timing			
	Blocked or restricted air flow	Blocked bumper		—	—	
		Blocked radiator grille	Installed car brassiere			
			Mud contamination or paper clogging			
Blocked radiator		—				
Blocked condenser		—				
Installed large fog lamp		—				

COOLING SYSTEM


[QR]

COOLING SYSTEM

PFP:21020

Cooling Circuit


EBS00G04



A
CO
C
D
E
F
G
H
I
J
K
L
M

COOLING SYSTEM

[QR]




ENGINE COOLANT

PFP:KQ100

EBS00G05

Inspection LEVEL CHECK

- Check if the reservoir tank coolant level is within MIN to MAX when engine is cool.
- Adjust coolant if too much or too little.



LEAK CHECK

- To check for leakage, apply pressure to the cooling system with a tester.


Testing pressure : 157 kPa (1.57 bar, 1.6 kg/cm² , 23 psi)

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

CAUTION:

Higher pressure than specified may cause radiator damage.



Changing Engine Coolant

WARNING:

- To avoid being scalded, never change the coolant when the engine is hot.
- Wrap a thick cloth around cap and carefully remove the cap. First, turn the cap a quarter of a turn to release built-up pressure. Then turn the cap all the way.

DRAINING ENGINE COOLANT


1. Remove undercover.
2. Disconnect radiator lower hose and remove radiator cap.

CAUTION:

Be careful not to allow coolant to contact drive belts.

3. Open drain plugs on cylinder block.
4. Remove reservoir tank and drain coolant.
5. Check drained coolant for contaminants such as rust, corrosion or discoloration.

If contaminated, flush engine cooling system. Refer to [CO-30](#), "[FLUSHING COOLING SYSTEM](#)".



REFILLING ENGINE COOLANT

1. Install reservoir tank, radiator drain plug and cylinder block drain plug.

Apply sealant to the thread of cylinder block drain plug.

- Use Genuine Liquid Gasket or equivalent.

: 7.8 - 11.8 N·m (0.8 - 1.2 kg·m , 69 - 104 in·lb)

ENGINE COOLANT

[QR]

2. Fill radiator and reservoir tank to specified level.
- **Use Genuine Nissan Anti-freeze Coolant or equivalent mixed with water (distilled or demineralized). Refer to [MA-16, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).**

Engine coolant capacity (With reservoir tank):
Approx. 6.9 ℓ (6-1/8 Imp qt)

Reservoir tank:
0.7 ℓ (5/8 Imp qt)



- **Pour coolant slowly of less than 2 ℓ (1-3/4 Imp qt) a minute to allow air in system to escape.**
3. Warm up engine to normal operating temperature without radiator cap installed.
- **If coolant overflows radiator filler hole, install filler cap.**
4. Run engine at 3,000 rpm for 10 seconds and return to idle speed with radiator cap installed.
- Repeat two or three times.

Watch coolant temperature gauge so as not to overheat the engine.

5. Stop engine and cool down to less than approximately 50°C (122°F).
- Cool down using a fan to reduce the time.
- If necessary, refill radiator up to filler neck with coolant.
6. Refill reservoir tank to MAX level line with coolant.
7. Repeat steps 3 through 6 two or more times with radiator cap installed until coolant level no longer drops.
8. Check cooling system for leaks with engine running.
9. Warm up engine, and check for sound of coolant flow while running engine from idle up to 3,000 rpm with heater temperature controller set at several positions between COOL and WARM.
- Sound may be noticeable at heater unit.
10. If sound is heard, bleed air from cooling system by repeating steps 3 through 6 until coolant level no longer drops.
- **Clean excess coolant from engine.**


FLUSHING COOLING SYSTEM

1. Fill radiator and reservoir tank with water and reinstall radiator cap.
2. Run engine and warm it up to normal operating temperature.
3. Rev engine two or three times under no-load.
4. Stop engine and wait until it cools down.
5. Drain water.
6. Repeat steps 1 through 5 until clear water begins to drain from radiator.



RADIATOR

Removal and Installation



- | | | |
|-------------------------|------------------------|--------------------------|
| 1 Reservoir tank | 2 Cap | 3 Radiator tank hose |
| 4 Radiator hose (upper) | 5 Radiator cap | 6 Nut |
| 7 Clip | 8 Mounting bracket | 9 Mounting rubber |
| 10 Radiator | 11 A/T oil cooler hose | 12 Radiator hose (lower) |
| 13 Cooling fan assembly | 14 Bracket | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

REMOVAL

1. Drain coolant. Refer to [CO-29, "DRAINING ENGINE COOLANT"](#).

CAUTION:

Perform when the engine is cold.

2. Remove air duct with air cleaner assembly.
3. Remove A/T oil cooler hose.
 - Install blind plug to avoid leakage of A/T fluid.
4. Disconnect radiator upper hose, lower hose and mounting bracket.
5. Remove radiator and cooling fan assembly.


CAUTION:

- Do not damage or scratch radiator core when removing.

INSTALLATION

- Reinstall any parts removed in reverse order of removal.
- Check for coolant leaks. Refer to [CO-29, "LEAK CHECK"](#).

Disassembly and Assembly of Cooling Fan



1 Cooling fan motors

2 Fan shroud

3 Cooling fan

DISASSEMBLY


1. Remove cooling fan.
2. Remove insulator.
3. Remove fan motor from fan shroud.

ASSEMBLY

- Install in the reverse order of removal.

CHECKING RADIATOR CAP

- Check that there is no dirt or damage on the valve seat of the radiator cap negative-pressure valve.
- Check that there are no unusual conditions in the opening and closing conditions of the negative-pressure valve.
- Pull the negative-pressure valve to open it.
- Check that it closes completely when released.



RADIATOR

[QR]

- Check radiator cap relief pressure.


Standard :

78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm² , 11 - 14 psi)

Limit :

59 kPa (0.59 bar, 0.6 kg/cm² , 9 psi)

- When connecting the radiator cap to the tester, apply water or LLC to the cap seal part.
- Replace the radiator cap if there is an unusual conditions in the negative-pressure valve, or if the open-valve pressure is outside of the standard values.



A

CO

C

D

CHECKING RADIATOR

Check radiator for mud or clogging. If necessary, clean radiator as follows.

- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns. Then tape the harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downwards.
 2. Apply water again to all radiator core surface once per minute.
 3. Stop washing if any stains no longer flow out from the radiator.
 4. Blow air into the back side of radiator core vertically downwards.
- Use compressed air lower than 490 kPa (4.9 bar, 5 kg/cm² , 71 psi) and keep distance more than 30 cm (11.8 in).
5. Blow air again into all the radiator core surface once per minute until no water sprays out.

E

F

G

H

I

J

K

L


M

RADIATOR (ALUMINUM TYPE)

PFP:21460


Disassembly and Assembly

EBS00GOA




PREPARATION

1. Attach the spacer to the tip of the radiator plate pliers A.
Spacer specification: 1.5 mm (0.059 in) thick x 18 mm (0.71 in) wide x 8.5 mm (0.335 in) long.
2. Make sure that when radiator plate pliers A are closed dimension H'' is approx. 7.6 mm (0.299 in).
3. Adjust dimension H'' with the spacer, if necessary.



DISASSEMBLY


1. Remove tank with Tool.




RADIATOR (ALUMINUM TYPE)

[QR]


- Grip the crimped edge and bend it upwards so that Tool slips off.
Do not bend excessively.



- In areas where Tool cannot be used, use a screwdriver to bend the edge up.
Be careful not to damage tank.




2. Make sure the edge stands straight up.
3. Remove oil cooler from tank. (A/T model only)



ASSEMBLY

1. Install oil cooler. (A/T model only)
Pay attention to direction of conical washer.




A
CO
C
D
E
F
G
H
I
J
K
L
M


RADIATOR (ALUMINUM TYPE)

[QR]



2. Clean contact portion of tank.




3. Install sealing rubber.
Push it in with fingers.
Be careful not to twist sealing rubber.



4. Caulk tank in specified sequence with Tool.



● Use pliers in the locations where Tool cannot be used.



RADIATOR (ALUMINUM TYPE)


[QR]

5. Make sure that the rim is completely crimped down.

Standard height "H" : 8.0 - 8.4 mm (0.315 - 0.331 in)

6. Confirm that there is no leakage.

Refer to Inspection.



A

CO

C

D


INSPECTION

1. Apply pressure with Tool.

Specified pressure value : 157 kPa (1.57 bar, 1.6 kg/cm², 23 psi)

WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp. Attach a hose to the oil cooler as well. (A/T model only)




E

F

G

H

2. Check for leakage.



I

J

K

L


M

WATER PUMP

PFP:21020

Removal and Installation

EBS00GOB



- | | | |
|--------------|----------|----------------------|
| 1 Water pump | 2 Gasket | 3 Water pump housing |
| 4 Water pipe | | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

Water Pump Removal

1. Drain coolant. Refer to [CO-29, "DRAINING ENGINE COOLANT"](#) .

CAUTION:

Perform when the engine is cold.

2. Remove the following parts.
 - Engine undercover
 - Alternator, water pump and air compressor belt
Refer to drive belt [CO-38, "Removal and Installation"](#) .
 3. Remove water pump.
 - Coolant will leak from the cylinder block, so have a receptacle ready below.
- CAUTION:**
- Handle the water pump vane so that it does not contact any other parts.
 - Water pump cannot be disassembled and should be replaced as a unit.

Water Pump Housing Removal

1. Perform step 1 and 2 of "Water Pump Removal".
2. Remove alternator.
3. Remove oil level gauge.

CAUTION:

Plug the oil level gauge guide opening to prevent oil pan from entering foreign materials.
4. Remove bolts mounting water pipe.
5. Remove water pump housing.

Water Pipe Removal

1. Remove water pump housing.


WATER PUMP

[QR]

2. Remove exhaust manifold and three way catalyst assembly. Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .
3. Remove water pipe.

INSPECTION AFTER REMOVAL

- Visually check that there is no significant dirt or rusting on the water pump body and vane.
- Check that there is no looseness in the vane shaft, and that it turns smoothly when rotated by hand.
- If there are unusual conditions, replace the water pump assembly.



INSTALLATION

- Install in the reverse order of removal.
- When inserting water pipe end to cylinder block, apply a neutral detergent to O-ring. Then insert it immediately.

INSPECTION AFTER INSTALLATION

- Check for coolant leaks using radiator cap tester. Refer to [CO-29, "LEAK CHECK"](#) .

A

CO

C

D

E

F

G

H

I

J

K

L


M

THERMOSTAT AND WATER CONTROL VALVE

PFP:21200

Removal and Installation

EBS00G0C



- | | | |
|----------------|---------------|-------------------------------------|
| 1 Thermostat | 2 Water inlet | 3 Water control valve |
| 4 Water outlet | 5 Heater hose | 6 Engine coolant temperature sensor |
| 7 Heater pipe | | |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

Thermostat Removal

1. Drain engine coolant. Refer to [CO-29, "DRAINING ENGINE COOLANT"](#).

CAUTION:

Perform when the engine is cold.

2. Disconnect radiator lower hose at water inlet side.
3. Remove water inlet and thermostat.

Water Control Valve Removal

1. Drain engine coolant. Refer to [CO-29, "DRAINING ENGINE COOLANT"](#).
2. Disconnect radiator upper hose, heater pipe and heater hose at water outlet side.
3. Remove water outlet.
4. Remove water control valve.


INSPECTION AFTER REMOVAL

- Place a thread so that it is caught in the valves of the thermostat and water control valve. Immerse fully in a container filled with water. Heat while stirring. (The example in the figure shows the thermostat.)
- The valve opening temperature is the temperature at which the valve opens and falls from the thread.
- Continue heating. Check the full-open lift amount.

NOTE:

The full-open lift amount standard temperature for the water control valve is the reference value.

- After checking the full-open lift amount, lower the water temperature and check the valve closing temperature.



Standard values


	Thermostat	Water control valve
Valve opening temperature	80.5 - 83.5°C (177 - 182°F)	93.5 - 96.5°C (200 - 206°F)
Full-open lift amount	More than 8 mm/ 95°C (0.315 in/ 203°F)	More than 8 mm/ 108°C (0.315 in/ 226°F)
Valve closing temperature	77°C (171°F)	90°C (194°F)

INSTALLATION


- Install in the reverse order of removal paying attention to the following.

Installation of Thermostat and Water Control Valve

- Install the thermostat and water control valve with the whole circumference of each flange part fit securely inside the rubber ring. (The example in the figure shows the thermostat.)



- Install the thermostat with the jiggle valve facing upwards. (The position deviation may be within the range of $\pm 10^\circ$)
- Install the water control valve with the up-mark facing up and the frame center part facing upwards. (The position deviation may be within the range of $\pm 10^\circ$)



Heater Pipe Installation

- First apply a neutral detergent to the O-ring, then quickly insert the insertion parts of the heater pipe into the installation holes.

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit CAPACITY

EBS00H9U

Coolant capacity [With reservoir tank (MAX level)]	Approximately 6.9 ℓ (6-1/8 Imp qt)
--	-------------------------------------

THERMOSTAT

Valve opening temperature	80.5 - 83.5°C (177 - 182°F)
Valve lift	More than 8 mm/ 95°C (0.315 in/203°F)

WATER CONTROL VALVE

Valve opening temperature	93.5 - 96.5°C (200 - 206°F)
Valve lift	More than 8 mm/108°C (0.315 in/226°F)

RADIATOR

Unit: kPa (bar, kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.78 - 0.98, 0.8 - 1.0, 11 - 14)
	Limit	59 (0.59, 0.6, 9)
Leakage test pressure		157 (1.57, 1.6, 23)

Tightening Torque

EBS00GOH

Unit: N·m (kg·m, ft·lb)
Unit: N·m (kg·m, in·lb)*

Radiator mounting bracket	3.8 - 4.5 (0.39 - 0.46, 34 - 39)*
Cooling fan assembly	3.8 - 4.5 (0.39 - 0.46, 34 - 39)*
Fan	2.9 - 3.9 (0.30 - 0.40, 26 - 34)*
Fan motor	3.9 - 4.9 (0.40 - 0.50, 35 - 43)*
Water pump	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Water pump housing	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Water inlet	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Water outlet	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Water pipe	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Heater pipe	20.8 - 28.2 (2.1 - 2.9, 16 - 20)
Engine coolant temperature sensor	19.6 - 29.4 (2.0 - 3.0, 14 - 22)

PRECAUTIONS

PF0:00001

Precautions For Liquid Gasket REMOVAL AND LIQUID GASKET

EBS00GT5

- After removing the mounting bolts and nuts, separate the mating surface using a seal cutter and remove the liquid gasket.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the gasket applied area.

CAUTION:


If for some unavoidable reason a tool such as a flat-blade screwdriver is used, be careful not to damage the mating surfaces.



PBIC0275E

LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old liquid gasket adhering to the gasket application surface and the mating surface.
 - Remove the liquid gasket completely from the groove of the gasket application surface, mounting bolts, and bolt holes.
2. Wipe the gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.
3. Attach the liquid gasket to the tube presser.
 - **Use Genuine Liquid Gasket or equivalent.**
4. Apply the gasket without breaks to the specified location with the specified dimensions.
 - If there is a groove for the liquid gasket application, apply the gasket to the groove.




PBIC0003E


- As for the bolt holes, normally apply the gasket inside the holes. Occasionally, it should be applied outside the holes. Make sure to read this service manual.
- Within five minutes of gasket application, install the mating component.
- If the liquid gasket protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed from the installation, fill the engine oil and coolant.

CAUTION:

If there are specific instructions in this service manual, observe them.



EMA0622D



SEM164F

PREPARATION





[YD]

PFP:00002

EBS00GT6

PREPARATION

Special Service Tools

Tool number Tool name	Description
WS39930000 Tube pressure  S-NT052	Pressing the tube of liquid gasket
EG17650301 Radiator cap tester adapter  S-NT564	Adapting radiator cap tester to radiator filler neck a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)
KV99103510 Radiator plate pliers A  S-NT224	Installing radiator upper and lower tanks
KV99103520 Radiator plate pliers B  S-NT225	Removing radiator upper and lower tanks

OVERHEATING CAUSE ANALYSIS

[YD]

OVERHEATING CAUSE ANALYSIS

PFP:00012

Troubleshooting Chart

EBS00GT7

	Symptom		Check items		
Cooling system parts malfunction	Poor heat transfer	Water pump malfunction	Worn or loose drive belt	—	
		Thermostat stuck closed	—		
		Damaged fins	Dust contamination or paper clogging		
			Mechanical damage		
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)		
	Reduced air flow	Cooling fan does not operate	—	—	
		High resistance to fan rotation			
		Damaged fan blades			
		Damaged radiator shroud	—	—	—
		Improper coolant mixture ratio	—	—	—
		Poor coolant quality	—	—	—
	Insufficient coolant	Coolant leaks	Cooling hose	Loose clamp	
				Cracked hose	
			Water pump	Poor sealing	
			Radiator cap	Loose	
Poor sealing					
Radiator			O-ring for damage, deterioration or improper fitting		
		Cracked radiator tank			
		Cracked radiator core			
	Reservoir tank	Cracked reservoir tank			
Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head deterioration			
		Cylinder head gasket deterioration			

A
CO
C
D
E
F
G
H
I
J
K
L
M

OVERHEATING CAUSE ANALYSIS

[YD]

	Symptom		Check items			
Except cooling system parts malfunction	—	Overload on engine	Abusive driving	High engine rpm under no load		
				Driving in low gear for extended time		
				Driving at extremely high speed		
			—	—	Powertrain system malfunction	—
					Installed improper size wheels and tires	
					Dragging brakes	
	Improper ignition timing					
	Blocked or restricted air flow	Blocked or restricted air flow	Blocked bumper	—	—	
			Blocked radiator grille	Installed car brassiere		
				Mud contamination or paper clogging		
Blocked radiator			—			
Blocked condenser			—			
Installed large fog lamp			—			

COOLING SYSTEM


[YD]

COOLING SYSTEM

PFP:21020

Cooling Circuit


EBS00GT8



A
CO
C
D
E
F
G
H
I
J
K
L
M

COOLING SYSTEM

[YD]




ENGINE COOLANT

PFP:KQ100

EBS00GT9

Inspection LEVEL CHECK

- Check if the reservoir tank coolant level within MIN to MAX when engine is cool.
- Adjust coolant if too much or too little.



LEAK CHECK

- To check for leakage, apply pressure to the cooling system with a tester.


Testing pressure : 157 kPa (1.57bar, 1.6 kg/cm² , 23 psi)

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

CAUTION:

Higher pressure than specified may cause radiator damage.




Changing Engine Coolant

WARNING:

- To avoid being scalded, never change the coolant when the engine is hot.
- Wrap a thick cloth around cap and carefully remove the cap. First, turn the cap a quarter of a turn to release built-up pressure. Then turn the cap all the way.

DRAINING ENGINE COOLANT

1. Disconnect lower radiator hose, and remove radiator cap.
 - Be careful not to allow coolant to contact drive belts.
 - Cover the exhaust tube heat shield to prevent from splashing coolant.
2. Remove reservoir tank, drain coolant, then clean reservoir tank.





ENGINE COOLANT

[YD]

3. Open drain plugs on cylinder block and air relief plug.
4. Check drained coolant for contaminants such as rust, corrosion or discoloration.

If contaminated, flush engine cooling system. Refer to [CO-51, "FLUSHING COOLING SYSTEM"](#).




REFILLING ENGINE COOLANT

1. Install reservoir tank, radiator lower hose and cylinder block drain plug.

Apply sealant to the thread of cylinder block drain plug.

- Use Genuine Liquid Gasket or equivalent.

 : 7.8 - 11.8 N-m (0.8 - 1.2 kg-m , 69 - 104 in-lb)


2. Fill radiator slowly with coolant until coolant spills from the air relief plugs, then install air relief plugs.

CAUTION:

If the filling rate is too fast, this could lead to air being mixed in the coolant. Be sure to fill the coolant slowly according to the rate indicated above.

- Replace the copper washer of the air relief plug.

Air relief plug :

 : 6.7 - 7.9 N-m (0.68 - 0.81 kg-m, 59 - 70 in-lb)


- Use genuine Nissan anti-freeze coolant or equivalent mixed with water (distilled or demineralized). Refer to [MA-16, "RECOMMENDED FLUIDS AND LUBRICANTS"](#).

Engine coolant capacity (With reservoir tank):

9.5 ℓ (8-3/8 Imp qt)

Reservoir tank : 0.6 ℓ (1/2 Imp qt)

- Pour coolant through coolant filler neck slowly of less than 2 ℓ (1-3/4 Imp qt) a minute to allow air in system to escape.




ENGINE COOLANT

[YD]

3. Fill reservoir tank to specified level.
4. Warm up engine to normal operating temperature without radiator cap installed.
 - **If coolant overflows radiator filler hole, install filler cap.**
5. Run engine at 3,000 rpm for 10 seconds and return to idle speed with radiator cap installed.
 - Repeat two or three times.

Watch coolant temperature gauge so as not to overheat the engine.

6. Stop engine and cool down to less than approximately 50°C (122°F).
 - Cool down using a fan to reduce the time.
 - If necessary, refill radiator up to filler neck with coolant.
7. Refill reservoir tank to MAX level line with coolant.
8. Repeat steps 5 through 7 two or more times with radiator cap installed until coolant level no longer drops.
9. Check cooling system for leaks with engine running.
10. Warm up engine, and check for sound of coolant flow while running engine from idle up to 3,000 rpm with heater temperature controller set at several position between COOL and WARM.
 - Sound may be noticeable at heater unit.
11. If sound is heard, bleed air from cooling system by repeating steps 5 through 7 until coolant level no longer drops.
 - **Clean excess coolant from engine.**




FLUSHING COOLING SYSTEM

1. Fill radiator with water until water spills from the air relief hole, then close air relief plug. Fill radiator and reservoir tank with water and reinstall radiator cap.
2. Run engine and warm it up to normal operating temperature.
3. Rev engine two or three times under no-load.
4. Stop engine and wait until it cools down.
5. Drain water.
6. Repeat steps 1 through 5 until clear water begins to drain from radiator.

RADIATOR

Removal and Installation



- | | | |
|----------------------|-------------------------|-------------------------|
| 1 Radiator | 2 Bracket | 3 Mounting rubber |
| 4 Reservoir tank cap | 5 Radiator hose (lower) | 6 Radiator fan assembly |
| 7 Reservoir tank | 8 Radiator hose (upper) | 9 Radiator Cap |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator. Wrap a thick cloth around the cap. Slowly turn it a quarter turn to allow built-up pressure to escape. Carefully remove the cap by turning it all the way.

REMOVAL

1. Disconnect lower radiator hose. Refer to [CO-49, "DRAINING ENGINE COOLANT"](#).
2. Remove under cover.
3. Disconnect radiator upper hose, reservoir tank hose and mounting bracket.
4. Remove radiator and radiator fan assembly

CAUTION:

- Do not damage or scratch radiator core when removing.

INSTALLATION

- Reinstall any parts removed in reverse order of removal.
- Check for engine coolant leaks. Refer to [CO-49, "LEAK CHECK"](#).

Disassembly and Assembly Radiator Fan

EBS00GTC

A

CO

C

D

E

F

G

H


I

J

K

L

M



1. Radiator fan motors

2. Radiator fan shroud

3. Radiator fan

DISASSEMBLY

1. Remove radiator fan and shroud assembly.
2. Remove radiator fan.
3. Remove fan motor from fan shroud.


ASSEMBLY

- Install in the reverse order of removal.

Checking Radiator Cap

EBS00GTD

- Check that there is no dirt or damage on the valve seat of the radiator cap negative-pressure valve.
- Check that there are no unusualness in the opening and closing conditions of the negative-pressure valve.
- Pull the negative pressure valve to open it.
- Check that it close completely when released.



RADIATOR


[YD]

- Check radiator cap relief pressure.

Standard : 78 - 98 kpa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm² , 11 - 14 psi)

Limit : 59 kpa (0.59 bar, 0.6 kg/cm² , 9 psi)

- When connecting the radiator cap to the tester, apply water or LLC to the cap seal part.
- Replace the radiator cap if there is an unusualness in the negative-pressure valve, or if the relief pressure is outside of the limit.



EBS00GTE

Checking Radiator

Check radiator for mud or clogging. If necessary, clean radiator as follows.


- Be careful not to bend or damage the radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as cooling fan, radiator shroud and horns. Then tape the harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downwards.
 2. Apply water again to all radiator core surface once per minute.
 3. Stop washing if any stains no longer flow out from the radiator.
 4. Blow air into the back side of radiator core vertically downwards.
- Use compressed air lower than 490 kpa (4.9 bar 5 kg/cm² , 71psi) and keep distance more than 30 cm(11.8 in).
5. Blow air again into all the radiator core surface once per minute until no water sprays out.

RADIATOR (ALUMINUM TYPE)

PFP:21460


Disassembly and Assembly

EBS00GTF




PREPARATION

1. Attach the spacer to the tip of the radiator plate pliers A.
Spacer specification: 1.5 mm (0.059 in) thick x 18 mm (0.71 in) wide x 8.5 mm (0.335 in) long.
2. Make sure that when radiator plate pliers A are closed dimension H'' is approx. 7.6 mm (0.299 in).
3. Adjust dimension H'' with the spacer, if necessary.



DISASSEMBLY

1. Remove tank with Tool.




RADIATOR (ALUMINUM TYPE)

[YD]


- Grip the crimped edge and bend it upwards so that Tool slips off.

Do not bend excessively.




- In areas where Tool cannot be used, use a screwdriver to bend the edge up.

Be careful not to damage tank.




2. Make sure the edge stands straight up.
3. Remove oil cooler from tank. (A/T model only)



ASSEMBLY

1. Install oil cooler. (A/T model only)


Pay attention to direction of conical washer.




RADIATOR (ALUMINUM TYPE)

[YD]



2. Clean contact portion of tank.




3. Install sealing rubber.
Push it in with fingers.
Be careful not to twist sealing rubber.



4. Caulk tank in specified sequence with Tool.



● Use pliers in the locations where Tool cannot be used.



A
CO
C
D
E
F
G
H
I
J
K
L
M

RADIATOR (ALUMINUM TYPE)


[YD]

5. Make sure that the rim is completely crimped down.

Standard height "H" : 8.0 - 8.4 mm (0.315 - 0.331 in)

6. Confirm that there is no leakage.

Refer to Inspection.




INSPECTION

1. Apply pressure with Tool.


Specified pressure value : 157 kPa (1.57 bar, 1.6 kg/cm², 23 psi)

WARNING:

To prevent the risk of the hose coming undone while under pressure, securely fasten it down with a hose clamp. Attach a hose to the oil cooler as well. (A/T model only)



2. Check for leakage.




WATER PUMP

PFP:21020

Removal and Installation

EBS00GTG



WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

1. Remove the under cover, splash cover (right).
2. Remove the drive belts.
3. Drain engine coolant. Refer to [CO-49, "DRAINING ENGINE COOLANT"](#).

CAUTION:

Perform when the engine is cold.


4. Support the bottom of the oil pan with a floor jack etc, and remove the right engine mount bracket (front side of the engine).
5. Remove the water pump pulley.
 - Loosen the pulley bolts after fixing the pulley using a screwdriver etc.
6. Remove engine mount bracket.
7. Remove the water pump.
 - Coolant will leak from the cylinder block, so have a receptacle ready below.

CAUTION:

- Handle the water pump vane so that it does not contact any other parts.
- Water pump cannot be disassembled and should be replaced as a unit.

INSPECTION AFTER REMOVAL

- Visually check that there is no significant dirt or rusting on the water pump body and vane.
- Check that there is no looseness in the vane shaft, and that it turns smoothly when rotated by hand.
- If there are any unusualness, replace the water pump assembly.



INSTALLATION

- Install in the reverse order of removal
- Install the water pump pulley with the front mark (painted white, used to prevent errors during assembly) facing the front of the engine. Refer to the figure above.

INSPECTION AFTER INSTALLATION


- Check for engine coolant leaks using radiator cap tester. Refer to [CO-49, "LEAK CHECK"](#) .

THERMOSTAT AND WATER PIPING

PFP:21200

Removal and Installation

EBS00GTH



- | | | |
|--------------------|----------------------|----------------------|
| 1 Thermostat | 2 Water inlet | 3 Thermostat housing |
| 4 Water inlet pipe | 5 Heater return pipe | 6 Gasket |

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

REMOVAL

1. Remove the under cover and splash cover (right and left).
2. Drain engine coolant. Refer to [CO-49, "DRAINING ENGINE COOLANT"](#).

CAUTION:


Perform when the engine cold.

3. Remove radiator lower hose from water inlet side.
4. Remove water inlet and thermostat.
5. Remove thermostat housing.

INSPECTION AFTER REMOVAL

Thermostat

- Place a string so that it is caught in the valves of the thermostat. Immerse fully in a container filled with water. Heat while stirring.
- The valve opening temperature is the temperature at which the valve opens and falls from the thread.
- Continue heating. Check the full-open lift amount.
- After checking the full-open lift amount, lower the water temperature and check the valve closing temperature.



Standard values


Item	Thermostat
Valve opening temperature	80 - 84°C (176 - 183° F)
Full-open lift amount	More than 10 mm/ 95°C (0.39 in/ 203 °F)
Valve closing temperature	Approximately 77°C (171°F)

INSTALLATION

- Install in the reverse order of removal paying attention to the following.

Thermostat

- Install the thermostat with the whole circumference of each flange part fit securely inside the rubber ring.
- Install the thermostat with the jiggle valve facing upwards.



SERVICE DATA AND SPECIFICATIONS (SDS)

[YD]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Standard and Limit CAPACITY

EBS00GTI

Engine coolant capacity [With reservoir tank (MAX level)]	9.5 ℓ (8-3/8 Imp qt)
---	----------------------

THERMOSTAT

Valve opening temperature	80 - 84°C (176 - 183°F)
Full open lift amount	More than 10 mm/ 95°C (0.39 in/203°F)

RADIATOR

Unit: kPa (bar, kg/cm², psi)

Cap relief pressure	Standard	78 - 98 (0.78 - 0.98, 0.8 - 1.0, 11 - 14)
	Limit	59 (0.59, 0.6, 9)
Leakage test pressure		157 (1.57, 1.6, 23)

Tightening Torque

EBS00GTJ

Unit: N·m (kg-m, ft-lb), N·m (kg-m, in-lb)*

Radiator mounting bracket	3.8 - 4.5 (0.39 - 0.46, 34 - 39)*
Radiator fan assembly	3.8 - 4.5 (0.39 - 0.46, 34 - 39)*
Radiator fan	2.9 - 3.9 (0.30 - 0.40, 26 - 34)*
Radiator fan motor	4.0 - 4.5 (0.41 - 0.45, 36 - 39)*
Water pump	23.0 - 30.0 (2.3 - 3.1, 17 - 22)
Water pump pulley	7.3 - 9.6 (0.74 - 0.98, 65 - 85)*
Water inlet	21 - 28 (2.1 - 2.9, 16 - 20)
Thermostat housing	21 - 28 (2.1 - 2.9, 16 - 20)
Water inlet pipe	21 - 28 (2.1 - 2.9, 16 - 20)
Water return pipe	21 - 28 (2.1 - 2.9, 16 - 20)

