

DI

SECTION

DRIVER INFORMATION SYSTEM

CONTENTS

| | |
|--|--|
| <p>PRECAUTIONS 4</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4</p> <p style="padding-left: 20px;">Precaution 4</p> <p style="padding-left: 20px;">Wiring Diagrams and Trouble Diagnosis 4</p> <p>COMBINATION METERS (LHD MODELS) 5</p> <p style="padding-left: 20px;">System Description 5</p> <p style="padding-left: 40px;">UNIFIED CONTROL METER 5</p> <p style="padding-left: 40px;">HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER 5</p> <p style="padding-left: 40px;">POWER SUPPLY AND GROUND CIRCUIT 5</p> <p style="padding-left: 40px;">WATER TEMPERATURE GAUGE 6</p> <p style="padding-left: 40px;">TACHOMETER 6</p> <p style="padding-left: 40px;">FUEL GAUGE 6</p> <p style="padding-left: 40px;">SPEEDOMETER 6</p> <p style="padding-left: 20px;">CAN Communication 7</p> <p style="padding-left: 20px;">SYSTEM DESCRIPTION 7</p> <p style="padding-left: 40px;">WITH TYRE PRESSURE MONITORING SYSTEM 7</p> <p style="padding-left: 40px;">TYPE 1 7</p> <p style="padding-left: 40px;">TYPE 2 9</p> <p style="padding-left: 40px;">TYPE 3 10</p> <p style="padding-left: 40px;">TYPE 4 11</p> <p style="padding-left: 40px;">TYPE 5 12</p> <p style="padding-left: 40px;">TYPE 6 13</p> <p style="padding-left: 40px;">WITHOUT TYRE PRESSURE MONITORING SYSTEM 14</p> <p style="padding-left: 40px;">TYPE 7 14</p> <p style="padding-left: 40px;">TYPE 8 15</p> <p style="padding-left: 40px;">TYPE 9 16</p> <p style="padding-left: 40px;">TYPE 10 17</p> <p style="padding-left: 40px;">TYPE 11 18</p> <p style="padding-left: 40px;">TYPE 12 19</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location 20</p> <p style="padding-left: 20px;">Combination Meter 21</p> <p style="padding-left: 40px;">CHECK 21</p> <p style="padding-left: 20px;">Schematic 22</p> <p style="padding-left: 20px;">Wiring Diagram — METER — 23</p> <p style="padding-left: 20px;">Combination Meter Self-Diagnosis 24</p> | <p style="padding-left: 20px;">PERFORMING SELF-DIAGNOSIS MODE 24</p> <p style="padding-left: 20px;">Trouble Diagnoses 27</p> <p style="padding-left: 40px;">PRELIMINARY CHECK 27</p> <p style="padding-left: 40px;">SYMPTOM CHART 28</p> <p style="padding-left: 20px;">Power Supply and Ground Circuit Check 29</p> <p style="padding-left: 20px;">Inspection/Vehicle Speed Signal 29</p> <p style="padding-left: 20px;">Inspection/Engine Speed Signal 29</p> <p style="padding-left: 20px;">Inspection/Fuel Level Sensor Unit 30</p> <p style="padding-left: 40px;">FUEL LEVEL SENSOR UNIT 30</p> <p style="padding-left: 40px;">LOW-FUEL WARNING LAMP 30</p> <p style="padding-left: 20px;">Inspection/Water Temperature Gauge 31</p> <p style="padding-left: 20px;">The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies. 31</p> <p style="padding-left: 20px;">The Fuel Gauge Does Not Move to F-position. 31</p> <p style="padding-left: 20px;">The Fuel Gauge Does Not Work. 32</p> <p style="padding-left: 20px;">Electrical Components Inspection 32</p> <p style="padding-left: 40px;">FUEL LEVEL SENSOR UNIT CHECK 32</p> <p style="padding-left: 20px;">Removal and Installation for Combination Meter ... 33</p> <p style="padding-left: 20px;">Disassembly and Assembly for Combination Meter.. 33</p> <p>COMBINATION METERS (RHD MODELS) 34</p> <p style="padding-left: 20px;">System Description 34</p> <p style="padding-left: 40px;">UNIFIED CONTROL METER 34</p> <p style="padding-left: 40px;">HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER 34</p> <p style="padding-left: 40px;">POWER SUPPLY AND GROUND CIRCUIT 34</p> <p style="padding-left: 40px;">WATER TEMPERATURE GAUGE 35</p> <p style="padding-left: 40px;">TACHOMETER 35</p> <p style="padding-left: 40px;">FUEL GAUGE 35</p> <p style="padding-left: 40px;">SPEEDOMETER 35</p> <p style="padding-left: 20px;">CAN Communication 35</p> <p style="padding-left: 20px;">SYSTEM DESCRIPTION 35</p> <p style="padding-left: 40px;">WITH TYRE PRESSURE MONITORING SYSTEM 35</p> <p style="padding-left: 40px;">TYPE 13 36</p> <p style="padding-left: 40px;">TYPE 14 37</p> <p style="padding-left: 40px;">TYPE 15 38</p> <p style="padding-left: 40px;">TYPE 16 39</p> <p style="padding-left: 40px;">TYPE 17 40</p> <p style="padding-left: 40px;">TYPE 18 41</p> <p style="padding-left: 40px;">WITHOUT TYRE PRESSURE MONITORING</p> |
|--|--|

| | | | |
|--|-----------|--|------------|
| SYSTEM | 42 | DISPLAY DIAGNOSIS | 80 |
| TYPE 19 | 43 | VEHICLE SIGNALS | 81 |
| TYPE 20 | 44 | SERVICE | 81 |
| TYPE 21 | 45 | Power Supply and Ground Circuit Check for Display Unit | 81 |
| TYPE 22 | 46 | Power Supply and Ground Circuit Check for Multifunction Switch | 82 |
| TYPE 23 | 47 | Vehicle Speed Signal Check/LHD Models | 83 |
| TYPE 24 | 48 | Vehicle Speed Signal Check/RHD Models | 84 |
| Component Parts and Harness Connector Location.. | 49 | Illumination Control Signal Check | 85 |
| Combination Meter | 50 | Ignition Signal Check | 85 |
| CHECK | 50 | Audio Circuit Check | 86 |
| Schematic | 51 | CD Changer Circuit Check | 86 |
| Wiring Diagram — METER — | 52 | AV Communication Line Check | 87 |
| Combination Meter Self-Diagnosis | 53 | Self-Diagnosis Does Not Perform | 88 |
| PERFORMING SELF-DIAGNOSIS MODE | 53 | RGB Screen Is Not Shown | 89 |
| Trouble Diagnoses | 56 | Color of RGB Image Is Not Proper | 89 |
| PRELIMINARY CHECK | 56 | RGB Screen Is Rolling | 90 |
| SYMPTOM CHART | 57 | Air Conditioning Controls (Only) Are Ineffective (Rear Defogger Control Excluded). | 90 |
| Power Supply and Ground Circuit Check | 58 | No Fuel Information Is Displayed/No Warning Message Is Displayed/LHD Models | 91 |
| Inspection/Vehicle Speed Signal | 58 | No Fuel Information Is Displayed/No Warning Message Is Displayed/RHD Models | 93 |
| Inspection/Engine Speed Signal | 59 | Multifunction Switch Does Not Operate. | 94 |
| Inspection/Fuel Level Sensor Unit | 59 | Removal and Installation of Multifunction switch ... | 94 |
| FUEL LEVEL SENSOR UNIT | 59 | Removal and Installation of Display | 94 |
| LOW-FUEL WARNING LAMP | 59 | WARNING LAMPS | 95 |
| Inspection/Water Temperature Gauge | 60 | Schematic | 95 |
| The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies. | 60 | Wiring Diagram — WARN —/LHD Models | 96 |
| The Fuel Gauge Does Not Move to F-position. | 60 | Wiring Diagram — WARN — /RHD Models | 100 |
| The Fuel Gauge Does Not Work. | 61 | Electrical Components Inspection | 104 |
| Low Fuel Warning Lamp Illuminate or Not Illuminate.. | 61 | OIL PRESSURE SWITCH CHECK | 104 |
| Electrical Components Inspection | 61 | A/T INDICATOR | 105 |
| Removal and Installation for Combination Meter ... | 62 | Wiring Diagram — AT/IND — | 105 |
| Disassembly and Assembly for Combination Meter.. | 62 | SYMPTOM CHART | 106 |
| VFD DISPLAY | 63 | WARNING CHIME | 107 |
| Wiring Diagram — COMM — | 63 | System Description | 107 |
| LCD DISPLAY | 65 | POWER SUPPLY AND GROUND CIRCUIT | 107 |
| System Description | 65 | IGNITION KEY WARNING CHIME | 107 |
| MULTIFUNCTION SWITCH SYSTEM | 65 | LIGHT WARNING CHIME | 107 |
| PRECAUTION OF LCD MONITOR | 65 | SEAT BELT WARNING CHIME | 107 |
| POWER SUPPLY AND GROUND | 65 | Component Parts and Harness Connector Location | 108 |
| AV COMMUNICATION LINE | 65 | Wiring Diagram — CHIME — | 109 |
| VEHICLE INFORMATION SYSTEM | 65 | LHD MODELS | 109 |
| WARNING INDICATIONS | 67 | RHD MODELS | 111 |
| Precautions for Display Unit Replacement | 69 | CONSULT-II Inspection Procedure | 113 |
| Component Parts and Harness Connector and Harness Connector Location | 70 | DIAGNOSTIC ITEMS DESCRIPTION | 113 |
| Schematic | 71 | CONSULT-IIBASIC OPERATION PROCEDURE | 113 |
| Wiring Diagram — COMM — | 72 | Symptom Chart | 114 |
| Terminals and Reference Value for Display Unit ... | 75 | Power Supply and Ground Circuit Check | 115 |
| Terminals and Reference Value for Multifunction Switch | 76 | Lighting Switch Input Signal Check | 116 |
| On Board Self-Diagnosis Function | 76 | Key Switch Insert Signal Check | 118 |
| DESCRIPTION | 76 | Front Door Switch (Driver side) Check | 119 |
| DIAGNOSIS ITEM | 77 | Seat Belt Buckle Switch Check (Driver side) | 120 |
| Self-Diagnosis Mode | 77 | Seat Belt Buckle Switch Check (Passenger Side). 123 | |
| OPERATION PROCEDURES | 77 | | |
| SELF-DIAGNOSIS RESULT | 78 | | |
| CONFIRMATION/ADJUSTMENT Mode | 79 | | |
| OPERATION PROCEDURE | 79 | | |

| | | | |
|----------------------------------|------------|--|-----|
| CLOCK | 128 | LHD MODELS | 132 |
| Wiring Diagram — CLOCK — | 128 | RHD MODELS | 136 |
| REAR VIEW MONITOR | 129 | Terminals and Reference Value for Rear View Cam- | |
| System Description | 129 | era Control Unit | 140 |
| POWER SUPPLY AND GROUND | 129 | Power Supply and Ground Circuit Check | 140 |
| REAR VIEW CAMERA OPERATION | 129 | Rear View Is Not Displayed With The Selector Lever | |
| Component Location | 130 | In R-position. | 141 |
| Schematic | 131 | The Rear View Image Is Distorted. | 144 |
| Wiring Diagram — R/VIEW — | 132 | Removal and Installation of Rear View Camera .. | 146 |

A
B
C
D
E
F
G
H
I
J
L
M

DI

PRECAUTIONS

PRECAUTIONS

PFP:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS004MN

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precaution

EKS004MO

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of the headlamp. When replacing the bulb, be sure to replace it with a new one.
- Adjust aiming by tightening aiming screw. (To adjust it toward loosening side, first loosen adjusting screw, and then make adjustment by tightening.)
- To remove soil or sealant of bulbs, do not use organic solvent (thinner, gasoline, etc.)
- When replacing bulb, be sure to hold bulb socket and pull it out straight. If wiring harness of the bulb is pulled at an angle, the bulb may be caught in the lamp, making it difficult to take out.

Wiring Diagrams and Trouble Diagnosis

EKS004MP

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- Refer to [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "How to Follow Trouble Diagnoses"](#) in GI section
- Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

COMBINATION METERS (LHD MODELS)

COMBINATION METERS (LHD MODELS)

PPF:24810

System Description


EKS004QF

UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit built in combination meter.
- Signal of speedometer, odo/trip meter, tachometer and water temperature gauge are sent via CAN communication line.
- Digital meter is adopted for odo/trip meter.*
*The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter, A/T indicator and ICC system display segments can be checked in self-diagnosis mode.
- Meter/gauge can be checked in self-diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The CAN communication signals (vehicle speed signal) from ESP/TCS/ABS control unit, and the memory signals from the meter memory circuit are processed by the combination meter, and the mileage is displayed.
- Operating the odometer/trip switch allows switching the mode in the following order.



- The odometer/trip display switching and trip display resetting can be identified by the time from pressing the odometer/trip switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (same as trip B).

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [NO. 12, located in the fuse block (J/B)]
- to combination meter terminal 52.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [NO. 30, located in the fuse block (J/B)]
- to combination meter terminal 51.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [NO. 1, located in the fuse block (J/B)]
- to combination meter terminal 50.

Ground is supplied

- to combination meter terminals 24, 25 and 45
- through body grounds M16, M50 and M70.

COMBINATION METERS (LHD MODELS)

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature.

ECM provides a water temperature signal to combination meter for water temperature gauge with CAN communication line.

TACHOMETER

The tachometer indicates engine speed in revolution per minutes (rpm). ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable resistor signal supplied

- to combination meter terminal 47 for the fuel level sensor
- from terminal 4 of the fuel level sensor unit
- through terminal 1 of the fuel level sensor unit and
- through combination meter terminal 46

SPEEDOMETER

ESP/TCS/ABS control unit provides a vehicle speed signal to the combination meter for the speedometer with CAN communication line.

COMBINATION METERS (LHD MODELS)

EKS004QG

CAN Communication SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


WITH TYRE PRESSURE MONITORING SYSTEM

Go to CAN system, when selecting your car model from the following table.

| | | | | | | | | | |
|---|-----------------------------------|-----------------------------------|------------------------------------|------------------------------------|------------------------------------|---------------------------------|--------|-----------|---|
| Body type | Sedan/Wagon | | | | | | | | |
| Axle | 2WD | | | | | | | | |
| Engine | QR20DE | | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DD Ti | |
| Transmission | CVT | | A/T | 6M/T | 5M/T | | 6M/T | | |
| Brake control | ESP | | ABS | | ESP | ABS | | | |
| ICC system | Applicable | Not applicable | | | | | | | |
| CAN communication unit | | | | | | | | | |
| ECM | × | × | × | × | × | × | × | × | × |
| TCM | × | × | × | × | | | | | |
| ESP/TCS/ABS control unit | × | × | | | × | | | | |
| ABS actuator and electric unit (control unit) | | | × | × | | × | × | × | × |
| Data link connector | × | × | × | × | × | × | × | × | × |
| Steering angle sensor | × | × | | | × | | | | |
| Smart entrance control unit | × | × | × | × | × | × | × | × | × |
| Tyre pressure monitoring control unit | × | × | × | × | × | × | × | × | × |
| ICC unit | × | | | | | | | | |
| ICC sensor | × | | | | | | | | |
| Combination meter | × | × | × | × | × | × | × | × | × |
| CAN communication type | DI-7. "TYPE 1" | DI-9. "TYPE 2" | DI-10. "TYPE 3" | DI-11. "TYPE 4" | DI-12. "TYPE 5" | DI-13. "TYPE 6" | | | |

TYPE 1

System diagram



COMBINATION METERS (LHD MODELS)

Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | TCM | ESP/ TCS / ABS control unit | Steer- ing angle sensor | Smart entranc e con- trol unit | Tyre pres- sure moni- toring control unit | ICC unit | ICC sensor | Combi- nation meter |
|------------------------------------|-----|-----|---|----------------------------------|---|---|-------------|---------------|---------------------------|
| Engine speed signal | T | R | R | | | | R | | R |
| Accelerator pedal position signal | T | R | R | | | | R | | |
| Closed throttle position signal | T | | | | | | R | | |
| ICC steering switch signal | T | | | | | | R | | |
| Shift pattern signal | | T | | | | | R | | |
| Parking brake switch signal | | | T | | | | R | | |
| ICC system display signal | | | | | | | T | | R |
| ICC sensor signal | | | | | | | R | T | |
| ESP operation signal | R | | T | | | | R | | |
| TCS operation signal | R | | T | | | | R | | |
| ABS operation signal | R | R | T | | | | R | | |
| Stop lamp switch signal | | R | T | | | | | | |
| Steering wheel angle sensor signal | | | R | T | | | | | |
| Wheel speed sensor signal | | | T | | | | R | | |
| Rear window defogger signal | R | | | | T | | | | |
| Heater fan switch signal | R | | | | | | | | T |
| Air conditioner switch signal | R | | | | | | | | T |
| Primary pulley revolution signal | R | T | | | | | R | | |
| Secondary pulley revolution signal | R | T | | | | | R | | |
| ICC operation signal | R | | | | | | T | | |
| Brake switch signal | R | | | | | | T | | |
| MI signal | T | | | | | | | | R |
| Current gear position signal | | T | | | | | | | R |
| Engine coolant temperature signal | T | | | | | | R | | R |
| Fuel consumption signal | T | | | | | | | | R |
| Vehicle speed signal | | | T | | | | | | R |
| | R | | | | | | | | T |
| Seat belt reminder signal | | | | | R | | | | T |
| Headlamp switch signal | | | | | T | | | | R |
| Flashing indicator signal | | | | | T | | | | R |
| Engine cooling fan speed signal | T | | | | R | | | | |
| Child lock indicator signal | | | | | T | | | | R |
| Door switches state signal | | | | | T | | | | R |
| Key ID signal | R | | | | T | | | | |
| | T | | | | R | | | | |
| A/C compressor signal | T | | | | R | | | | |
| Tire pressure signal | | | | | | T | | | R |

COMBINATION METERS (LHD MODELS)

TYPE 2

System diagram



Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | TCM | ESP/TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Tyre pressure monitoring control unit | Combination meter |
|------------------------------------|-----|-----|----------------------------|-----------------------|-----------------------------|---------------------------------------|-------------------|
| Engine speed signal | T | R | R | | | | R |
| Accelerator pedal position signal | T | R | R | | | | |
| ESP operation signal | R | | T | | | | |
| TCS operation signal | R | | T | | | | |
| ABS operation signal | R | R | T | | | | |
| Stop lamp switch signal | | R | T | | | | |
| Steering wheel angle sensor signal | | | R | T | | | |
| Rear window defogger signal | R | | | | T | | |
| Heater fan switch signal | R | | | | | | T |
| Air conditioner switch signal | R | | | | | | T |
| Primary pulley revolution signal | R | T | | | | | |
| Secondary pulley revolution signal | R | T | | | | | |
| MI signal | T | | | | | | R |
| Current gear position signal | | T | | | | | R |
| Engine coolant temperature signal | T | | | | | | R |
| Fuel consumption signal | T | | | | | | R |
| Vehicle speed signal | | | T | | | | R |
| | R | | | | | | T |
| Seat belt reminder signal | | | | | R | | T |
| Headlamp switch signal | | | | | T | | R |
| Flashing indicator signal | | | | | T | | R |
| Engine cooling fan speed signal | T | | | | R | | |
| Child lock indicator signal | | | | | T | | R |
| Door switches state signal | | | | | T | | R |
| Key ID signal | R | | | | T | | |
| | T | | | | R | | |
| A/C compressor signal | T | | | | R | | |
| Tire pressure signal | | | | | | T | R |

COMBINATION METERS (LHD MODELS)

TYPE 3

System diagram



Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Tyre pressure monitoring control unit | Combination meter |
|------------------------------------|-----|-----|---|-----------------------------|---------------------------------------|-------------------|
| Engine speed signal | T | R | | | | R |
| Stop lamp switch signal | | R | T | | | |
| Rear window defogger signal | R | | | T | | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| Primary pulley revolution signal | R | T | | | | |
| Secondary pulley revolution signal | R | T | | | | |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | R | | T |
| Headlamp switch signal | | | | T | | R |
| Flashing indicator signal | | | | T | | R |
| Engine cooling fan speed signal | T | | | R | | |
| Child lock indicator signal | | | | T | | R |
| Door switches state signal | | | | T | | R |
| Key ID signal | R | | | T | | |
| | T | | | R | | |
| A/C compressor signal | T | | | R | | |
| Tire pressure signal | | | | | T | R |

COMBINATION METERS (LHD MODELS)

TYPE 4

System diagram



Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Tyre pressure monitoring control unit | Combination meter |
|-----------------------------------|-----|-----|---|-----------------------------|---------------------------------------|-------------------|
| Engine speed signal | T | R | | | | R |
| Stop lamp switch signal | | R | T | | | |
| Rear window defogger signal | R | | | T | | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | R | | T |
| Headlamp switch signal | | | | T | | R |
| Flashing indicator signal | | | | T | | R |
| Engine cooling fan speed signal | T | | | R | | |
| Child lock indicator signal | | | | T | | R |
| Door switches state signal | | | | T | | R |
| Key ID signal | R | | | T | | |
| | T | | | R | | |
| A/C compressor signal | T | | | R | | |
| Tire pressure signal | | | | | T | R |

COMBINATION METERS (LHD MODELS)

TYPE 5

System diagram



Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | ESP/ TCS / ABS control unit | Steering angle sen- sor | Smart entrance control unit | Tyre pres- sure moni- toring control unit | Combina- tion meter |
|------------------------------------|-----|-----------------------------------|-------------------------------|-----------------------------------|--|------------------------|
| Engine speed signal | T | R | | | | R |
| Accelerator pedal position signal | T | R | | | | |
| ESP operation signal | R | T | | | | |
| TCS operation signal | R | T | | | | |
| ABS operation signal | R | T | | | | |
| Steering wheel angle sensor signal | | R | T | | | |
| Rear window defogger signal | R | | | T | | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| MI signal | T | | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | T | | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | R | | T |
| Headlamp switch signal | | | | T | | R |
| Flashing indicator signal | | | | T | | R |
| Engine cooling fan speed signal | T | | | R | | |
| Child lock indicator signal | | | | T | | R |
| Door switches state signal | | | | T | | R |
| Key ID signal | R | | | T | | |
| | T | | | R | | |
| A/C compressor signal | T | | | R | | |
| Tire pressure signal | | | | | T | R |

COMBINATION METERS (LHD MODELS)

TYPE 6

System diagram



Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Tyre pressure monitoring control unit | Combination meter |
|-----------------------------------|-----------------|---|-----------------------------|---------------------------------------|-------------------|
| Engine speed signal | T | | | | R |
| Rear window defogger signal | R ^{*1} | | T | | |
| Heater fan switch signal | R ^{*1} | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |
| Glow lamp signal ^{*2} | T | | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | T | | | R |
| | R | | | | T |
| Seat belt reminder signal | | | R | | T |
| Headlamp switch signal | | | T | | R |
| Flashing indicator signal | | | T | | R |
| Engine cooling fan speed signal | T | | R | | |
| Child lock indicator signal | | | T | | R |
| Door switches state signal | | | T | | R |
| Key ID signal | R | | T | | |
| | T | | R | | |
| A/C compressor signal | T | | R | | |
| Tire pressure signal | | | | T | R |

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

COMBINATION METERS (LHD MODELS)


WITHOUT TYRE PRESSURE MONITORING SYSTEM

Go to CAN system, when selecting your car model from the following table.

| | | | | | | | | | |
|---|--|--|--|---|---|---|--------|--------|--------------|
| Body type | Sedan/Wagon | | | | | | | | |
| Axle | 2WD | | | | | | | | |
| Engine | QR20DE | | | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DD Ti |
| Transmission | CVT | | | A/T | 6M/T | 5M/T | | 6M/T | |
| Brake control | ESP | | | ABS | | ESP | ABS | | |
| ICC system | Applica- ble | Not applicable | | | | | | | |
| CAN communication unit | | | | | | | | | |
| ECM | × | × | × | × | × | × | × | × | × |
| TCM | × | × | × | × | | | | | |
| ESP/TCS/ABS control unit | × | × | | | × | | | | |
| ABS actuator and electric unit (control unit) | | | × | × | | × | × | × | × |
| Data link connector | × | × | × | × | × | × | × | × | × |
| Steering angle sensor | × | × | | | × | | | | |
| Smart entrance control unit | × | × | × | × | × | × | × | × | × |
| ICC unit | × | | | | | | | | |
| ICC sensor | × | | | | | | | | |
| Combination meter | × | × | × | × | × | × | × | × | × |
| Can communication type | DI-14. "TYPE 7" | DI-15. "TYPE 8" | DI-16. "TYPE 9" | DI-17. "TYPE 10" | DI-18. "TYPE 11" | DI-19. "TYPE 12" | | | |

TYPE 7

System diagram



Input/output signal chart


T: Transmit R: Receive

| Signals | ECM | TCM | ESP/ TCS / ABS con- trol unit | Steering angle sensor | Smart entrance control unit | ICC unit | ICC sen- sor | Combina- tion meter |
|-----------------------------------|-----|-----|--|-----------------------------|--------------------------------------|----------|-----------------|---------------------------|
| Engine speed signal | T | R | R | | | R | | R |
| Accelerator pedal position signal | T | R | R | | | R | | |
| Closed throttle position signal | T | | | | | R | | |
| ICC steering switch signal | T | | | | | R | | |
| Shift pattern signal | | T | | | | R | | |
| Parking brake switch signal | | | T | | | R | | |

COMBINATION METERS (LHD MODELS)

| Signals | ECM | TCM | ESP/ TCS / ABS con- trol unit | Steering angle sensor | Smart entrance control unit | ICC unit | ICC sen- sor | Combina- tion meter |
|------------------------------------|-----|-----|--|-----------------------------|--------------------------------------|----------|-----------------|---------------------------|
| ICC system display signal | | | | | | T | | R |
| ICC sensor signal | | | | | | R | T | |
| ESP operation signal | R | | T | | | R | | |
| TCS operation signal | R | | T | | | R | | |
| ABS operation signal | R | R | T | | | R | | |
| Stop lamp switch signal | | R | T | | | | | |
| Steering wheel angle sensor signal | | | R | T | | | | |
| Wheel speed sensor signal | | | T | | | R | | |
| Rear window defogger signal | R | | | | T | | | |
| Heater fan switch signal | R | | | | | | | T |
| Air conditioner switch signal | R | | | | | | | T |
| Primary pulley revolution signal | R | T | | | | R | | |
| Secondary pulley revolution signal | R | T | | | | R | | |
| ICC operation signal | R | | | | | T | | |
| Brake switch signal | R | | | | | T | | |
| MI signal | T | | | | | | | R |
| Current gear position signal | | T | | | | | | R |
| Engine coolant temperature signal | T | | | | | R | | R |
| Fuel consumption signal | T | | | | | | | R |
| Vehicle speed signal | | | T | | | | | R |
| | R | | | | | | | T |
| Seat belt reminder signal | | | | | R | | | T |
| Headlamp switch signal | | | | | T | | | R |
| Flashing indicator signal | | | | | T | | | R |
| Engine cooling fan speed signal | T | | | | R | | | |
| Child lock indicator signal | | | | | T | | | R |
| Door switches state signal | | | | | T | | | R |
| Key ID signal | R | | | | T | | | |
| | T | | | | R | | | |
| A/C compressor signal | T | | | | R | | | |

TYPE 8 System diagram



COMBINATION METERS (LHD MODELS)


Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | TCM | ESP/ TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combina- tion meter |
|------------------------------------|-----|-----|-----------------------------------|--------------------------|-----------------------------------|------------------------|
| Engine speed signal | T | R | R | | | R |
| Accelerator pedal position signal | T | R | R | | | |
| ESP operation signal | R | | T | | | |
| TCS operation signal | R | | T | | | |
| ABS operation signal | R | R | T | | | |
| Stop lamp switch signal | | R | T | | | |
| Steering wheel angle sensor signal | | | R | T | | |
| Rear window defogger signal | R | | | | T | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| Primary pulley revolution signal | R | T | | | | |
| Secondary pulley revolution signal | R | T | | | | |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | | R | T |
| Headlamp switch signal | | | | | T | R |
| Flashing indicator signal | | | | | T | R |
| Engine cooling fan speed signal | T | | | | R | |
| Child lock indicator signal | | | | | T | R |
| Door switches state signal | | | | | T | R |
| Key ID signal | R | | | | T | |
| | T | | | | R | |
| A/C compressor signal | T | | | | R | |

TYPE 9

System diagram



COMBINATION METERS (LHD MODELS)


Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|---|-----------------------------|-------------------|
| Engine speed signal | T | R | | | R |
| Stop lamp switch signal | | R | T | | |
| Rear window defogger signal | R | | | T | |
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| Primary pulley revolution signal | R | T | | | |
| Secondary pulley revolution signal | R | T | | | |
| MI signal | T | | | | R |
| Current gear position signal | | T | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | | T | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 10

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-----------------------------|-----|-----|---|-----------------------------|-------------------|
| Engine speed signal | T | R | | | R |
| Stop lamp switch signal | | R | T | | |
| Rear window defogger signal | R | | | T | |

COMBINATION METERS (LHD MODELS)

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----|---|-----------------------------|-------------------|
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |
| Current gear position signal | | T | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | | T | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 11

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | ESP/ TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----------------------------|-----------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | | | R |
| Accelerator pedal position signal | T | R | | | |
| ESP operation signal | R | T | | | |
| TCS operation signal | R | T | | | |
| ABS operation signal | R | T | | | |
| Steering wheel angle sensor signal | | R | T | | |
| Rear window defogger signal | R | | | T | |
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |

COMBINATION METERS (LHD MODELS)

| Signals | ECM | ESP/ TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----------------------------------|--------------------------|--------------------------------|----------------------|
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | T | | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 12

System diagram



Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | ABS actuator and electric unit (con- trol unit) | Smart entrance control unit | Combination meter |
|-----------------------------------|-----------------|---|--------------------------------|----------------------|
| Engine speed signal | T | | | R |
| Rear window defogger signal | R ^{*1} | | T | |
| Heater fan switch signal | R ^{*1} | | | T |
| Air conditioner switch signal | R | | | T |
| MI signal | T | | | R |
| Glow lamp signal ^{*2} | T | | | R |
| Engine coolant temperature signal | T | | | R |
| Fuel consumption signal | T | | | R |
| Vehicle speed signal | | T | | R |
| | R | | | T |
| Seat belt reminder signal | | | R | T |
| Headlamp switch signal | | | T | R |
| Flashing indicator signal | | | T | R |
| Engine cooling fan speed signal | T | | R | |

COMBINATION METERS (LHD MODELS)


| Signals | ECM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-----------------------------|-----|---|-----------------------------|-------------------|
| Child lock indicator signal | | | T | R |
| Door switches state signal | | | T | R |
| Key ID signal | R | | T | |
| | T | | R | |
| A/C compressor signal | T | | R | |

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

Component Parts and Harness Connector Location

EKS003VC




MKIB0048E


COMBINATION METERS (LHD MODELS)

Combination Meter CHECK


EKS004QH



CVT : (C)
O/D : (A)
OFF



(A) : With A/T
(C) : With CVT




A
B
C
D
E
F
G
H
I
J
DI
L
M

MKWA0172E

COMBINATION METERS (LHD MODELS)

Schematic

EKS003VE



() : RHD MODELS



MKWA0174E

COMBINATION METERS (LHD MODELS)

Wiring Diagram — METER —

EKS004Q1

DI-METER-01



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK-
 JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
DI
L
M

COMBINATION METERS (LHD MODELS)


EKS004QJ






Combination Meter Self-Diagnosis PERFORMING SELF-DIAGNOSIS MODE

1. Turn the ignition switch to the "LOCK" position.
2. Press both reset buttons on the combination meter and keep them depressed.
3. Turn the ignition switch to the "ON" position, while keeping the reset buttons pressed.
4. Release both reset buttons then self-diagnosis will start. The sequence (A to L) is activated by press the either reset buttons.








NOTE:

If either reset button is not pressed for 20 seconds at each step or if the ignition switch is turned OFF, the self-diagnosis mode is exited.



| | Check items | Display | Remarks |
|----|-----------------------|---|---|
| A) | Odometer segment test |  <p style="text-align: center;">MKIB0001E</p> | All odo/trip meter, A/T indicator and ICC system display segments are ON. |
| B) | Work instruction code |  <p style="text-align: center;">This code is an example. MKIB0002E</p> | This information is not used for service. Skip this step. |
| C) | Software code |  <p style="text-align: center;">This code is an example. MKIB0003E</p> | This information is not used for service. Skip this step. |
| D) | EEPROM code |  <p style="text-align: center;">This code is an example. MKIB0004E</p> | This information is not used for service. Skip this step. |
| E) | Hardware code |  <p style="text-align: center;">This code is an example. MKIB0005E</p> | This information is not used for service. Skip this step. |

COMBINATION METERS (LHD MODELS)

| | Check items | Display | Remarks |
|----|---|--|--|
| F) | PCB code |  <p>This code is an example. MKIB0006E</p> | This information is not used for service. Skip this step. |
| G) | Meter/gauge test (Sweeping movement) |  <p>Flashing MKIB0007E</p> | Tachometer, speedometer, fuel level gauge and water temperature gauge have sweeping movement test. (The meter/gauges operate MIN. → MAX., MAX. → MIN. for 2 times) The odo/trip meter segment flashes during the sweep movement. |
| H) | Error 1 (Bit 0 - Bit 3) | <p style="text-align: center;">3 2 1 0 bit</p>  <p>This value is an example. MKIB0008E</p> | The segment of each bit displays "0", meaning no malfunction. If the bit(s) displays figures other than "0", the item of the bit has malfunctioned. For details, refer to "Malfunction chart for Error 1 and Error E" below. |
| I) | Error E (Bit 4 - Bit 7) | <p style="text-align: center;">7 6 5 4 bit</p>  <p>This value is an example. MKIB0009E</p> | |
| J) | Fuel warning lamp test |  <p>Flashing MKIB0010E</p> | Fuel warning lamp is on and odo/trip meter segment "FUEL" flashes. |
| K) | Fuel gauge calibration (CAL) |  <p>This value is an example. MKIB0011E</p> | This information is not used for service. Skip this step. |
| L) | Fuel gauge calibration (OLD) |  <p>This value is an example. MKIB0012E</p> | This information is not used for service. Skip this step. |

A
B
C
D
E
F
G
H
I
J
L
M

DI

COMBINATION METERS (LHD MODELS)

Malfunction Chart for “Error 1” and “Error E”

| Bit | Detectable items | Description of the malfunction | Displayed figure on the bit | | |
|-----|--------------------------------|--|--|----------------|---|
| | | | Malfunction | No malfunction | |
| 0 | Speedometer input signal | No input signal When no signal is detected for 5 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.) | 1 | 0 | |
| | | Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction. | 2 | | |
| 1 | Tachometer input signal | No input signal When no signal is detected for 5 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.) | 1 | 0 | |
| | | Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction. | 2 | | |
| 2 | Fuel level input signal | Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction. | 1 | 0 | |
| | | Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction. | 2 | | |
| 3 | Water temperature input signal | Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction. | 1 | 0 | |
| | | Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction. | 2 | | |
| 4 | Reset buttons | Short circuit for reset buttons When the short circuit is continuously detected for 5 minutes or more, it should be judged as short-circuit malfunction. | Right side reset button has malfunctioned. | 1 | 0 |
| | | | Left side reset button has malfunctioned. | 2 | |
| | | | Both reset buttons have malfunctioned. | 3 | |
| 5 | CPU | CPU RAM malfunction | 1 | 0 | |
| 6 | — | — | 0 | 0 | |

Combination Meter Calibration

After replacing a combination meter, it might be necessary to calibrate the fuel gauge/low fuel warning lamp. In case the fuel warning lamp is flashing after replacing the combination meter perform the following:

1. Press both reset buttons.
2. Turn the ignition ON **and keep the reset buttons depressed for at least 5 seconds.**
3. Release both reset buttons.

The low fuel warning lamp will stop flashing and the combination meter will shown CALL and possibly CALL FAIL. Showing CALL FAIL does not indicate a concern as this might be related to the current (unexpected) amount of fuel in the tank.

COMBINATION METERS (LHD MODELS)

EKS004QK

Trouble Diagnoses PRELIMINARY CHECK

1. CHECK WARNING LAMPS

1. Turn ignition switch ON.
2. Warning lamps should illuminate (seat belt warning or door warning etc.).

Do warning lamps illuminate?

- YES >> GO TO 2.
NO >> Power supply and ground check. Refer to [DI-29, "Power Supply and Ground Circuit Check"](#).

2. CHECK SELF-DIAGNOSIS MODE OPERATION

Perform self-diagnosis mode. Refer to [DI-24, "Performing Self-Diagnosis Mode"](#).

Can self-diagnosis mode be activated?

- YES >> GO TO 3.
NO >> Replace unified meter control unit. Refer to [DI-33, "Removal and Installation for Combination Meter"](#).

3. CHECK METER/GAUGE OPERATION

Check meter/gauge operation in self-diagnosis mode (Meter/gauge test). Refer to [DI-24, "Performing Self-Diagnosis Mode"](#).

Is any malfunction indicated in self-diagnosis mode?

- YES >> GO TO "Symptom Chart 1". Refer to [DI-28, "SYMPTOM CHART"](#).
NO >> GO TO 4.

4. CHECK SEGMENTS

Check all odo/trip meter segments in self-diagnosis mode (Odo/trip meter segment test). Refer to [DI-24, "Performing Self-Diagnosis Mode"](#).

Is any malfunction indicated in self-diagnosis mode?

- YES >> GO TO "Symptom Chart 1". Refer to [DI-28, "SYMPTOM CHART"](#).
NO >> GO TO 5.

5. CHECK FUEL WARNING LAMP

Check fuel warning lamp in self-diagnosis mode (Fuel warning lamp test). Refer to [DI-24, "Performing Self-Diagnosis Mode"](#).

Do fuel warning lamp illuminate?

- YES >> GO TO "Symptom Chart 1". Refer to [DI-28, "SYMPTOM CHART"](#).
NO >> GO TO 6.

6. CHECK INPUT SIGNALS

Check input signals from each sensors in self-diagnosis mode (Error 1 and Error E). Refer to [DI-24, "Performing Self-Diagnosis Mode"](#).

OK or NG?

- OK >> GO TO 7.
NG >> GO TO "Symptom Chart 2". Refer to [DI-28, "SYMPTOM CHART"](#).

7. CHECK OTHER MALFUNCTION

Check each malfunction according to the instruction of the "SYMPTOM CHART 3". Refer to [DI-28, "SYMPTOM CHART"](#).

- OK >> Combination meter is OK.
NG >> Check the case of malfunction.

COMBINATION METERS (LHD MODELS)

SYMPTOM CHART

Symptom Chart 1

| Symptom | Possible causes | Repair order |
|---|----------------------------|--|
| Odo/trip meter indicates malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit. Refer to DI-33, "Removal and Installation for Combination Meter" . |
| Multiple meter/gauge indicate malfunction in Diagnosis mode. | | |
| One of speedometer/tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode. | | |

Symptom Chart 2

| Symptom | Possible causes | Repair order |
|---|--------------------------------|---|
| Speedometer input signal indicates malfunction in Diagnosis mode. | Speedometer input signal | Check signal for speedometer. Refer to DI-29, "Inspection/Vehicle Speed Signal" . |
| Tachometer input signal indicates malfunction in Diagnosis mode. | Tachometer input signal | Check signal for tachometer. Refer to DI-29, "Inspection/Engine Speed Signal" . |
| Fuel level input signal indicates malfunction in Diagnosis mode. | Fuel level input signal | Check signal for tachometer. Refer to DI-30, "Inspection/Fuel Level Sensor Unit" . |
| Water temperature input signal Indicates malfunction in Diagnosis mode. | Water temp. gauge input signal | Check signal for water temp. gauge. Refer to DI-31, "Inspection/Water Temperature Gauge" . |
| Reset buttons indicates malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit assembly. Refer to DI-33, "Removal and Installation for Combination Meter" . |
| CPU indicates malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit assembly. Refer to DI-33, "Removal and Installation for Combination Meter" . |

Symptom Chart 3

| Symptom | Possible causes | Repair order |
|---|-----------------|---|
| Fuel gauge pointer fluctuates, Indicator wrong value or varies. | - | Check the case of malfunction. Refer to DI-31, "The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies." . |
| Fuel gauge does not move to "F" position. | - | Check the case of malfunction. Refer to DI-31, "The Fuel Gauge Does Not Move to F-position." . |
| Fuel gauge does not work. | - | Check the case of malfunction. Refer to DI-32, "The Fuel Gauge Does Not Work." . |

COMBINATION METERS (LHD MODELS)

EKS004QL

Power Supply and Ground Circuit Check

1. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector and ground in the following conditions.

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (wire color) | | | | |
| M37 | 50 (P)* | Ground | 0V | Battery voltage | Battery voltage |
| M37 | 51 (Y) | Ground | 0V | 0V | Battery voltage |
| M37 | 52 (R/B) | Ground | Battery voltage | Battery voltage | Battery voltage |

*: With Navigation system

OK or NG?

OK >> GO TO 2.

- NG >>
- 10A fuse [No. 1, located in fuse block (J/B)].
 - 10A fuse [No. 30, located in fuse block (J/B)].
 - 10A fuse [No. 12, located in fuse block (J/B)].
 - Harness for open or short between fuse and combination meter.

2. GROUND CIRCUIT CHECK

Check continuity between combination meter and ground in the following conditions.

| Terminals | | (-) | Continuity |
|-----------|----------|--------|------------|
| (+) | | | |
| Connector | Terminal | | |
| M36 | 25 | Ground | Yes |
| M37 | 45 | Ground | Yes |
| M36 | 24 | Ground | Yes |

OK or NG?

OK >> INSPECTION END.

NG >> Harness for open ground circuit.

Inspection/Vehicle Speed Signal

EKS004QM

1. ESP/TCS/ABS CONTROL UNIT SYSTEM INSPECTION

- Perform ESP/TCS/ABS control unit self-diagnosis. Refer to [BRC-76, "Functions of CONSULT-II"](#).

OK or NG?

OK >> Recheck "PRELIMINARY CHECK".



NG >> Check ESP/TCS/ABS control system.

Inspection/Engine Speed Signal

EKS004QN

1. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-121, "CONSULT-II Function"](#) (QG engine with EURO-OBD), [EC-636, "CONSULT-II Function"](#) (QG engine without EURO-OBD), [EC-1054, "CONSULT-II Function"](#) (QR



COMBINATION METERS (LHD MODELS)

engine with EURO-OBD), [EC-1479, "CONSULT-II Function"](#) (QR engine without EURO-OBD) or [EC-1773, "CONSULT-II Function"](#) (YD engine)

OK or NG?

- OK >> Recheck "PRELIMINALLY CHECK".
- NG >> Check engine control system.

Inspection/Fuel Level Sensor Unit FUEL LEVEL SENSOR UNIT

EKS004QO

The following symptoms do not indicate a malfunction.

- Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the warning lamp ON timing may be changed.

1. HARNESS CONNECTOR INSPECTION


1. Turn the ignition switch OFF.
2. Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, and harness-side) for poor connection and bend.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair or replace terminals or connectors.

2. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector and combination meter harness connector.
3. Check the following.
 - Harness continuity between fuel level sensor unit pump harness connector B22 terminal 4 (G/Y) and combination meter harness connector M37 terminal 47 (G/Y).
 - Harness continuity between combination meter harness connector M37 terminal 47 (G/Y) and ground.



| Terminals | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M37 | 47 (G/Y) | B22 | 4 (G/Y) | Yes |
| M37 | 47 (G/Y) | Ground | | No |

OK or NG?

- OK >> GO TO 3.
- NG >> Repair harness or connector.

COMBINATION METERS (LHD MODELS)


3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

Check harness continuity between fuel level sensor unit connector B22 terminal 1 and ground.

Continuity should exist.

OK or NG?

- OK >> GO TO 4.
- NG >> Repair harness or connector.



4. FUEL LEVEL SENSOR UNIT INSPECTION

Refer to [DI-32, "FUEL LEVEL SENSOR UNIT CHECK"](#).

OK or NG?

- OK >> GO TO 5.
- NG >> Replace fuel level sensor unit.

5. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any components inside the arm.

OK or NG?

- OK >> Replace combination meter.
- NG >> Install fuel level sensor unit properly.

Inspection/Water Temperature Gauge

EKS004QP

1. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-121, "CONSULT-II Function"](#) (QG engine with EURO-OBD), [EC-636, "CONSULT-II Function"](#) (QG engine without EURO-OBD), [EC-1054, "CONSULT-II Function"](#) (QR engine with EURO-OBD), [EC-1479, "CONSULT-II Function"](#) (QR engine without EURO-OBD) or [EC-1773, "CONSULT-II Function"](#) (YD engine)

OK or NG?

- OK >> Recheck "PRELIMINALY CHECK".
- NG >> Check engine control system.

The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies.

EKS004QQ

1. CHECK THE FUEL GAUGE POINTER FOR FLUCTUATION

Does the indication value fluctuate during driving or before/after stop?

OK or NG?

- OK >> The pointer fluctuation may be caused by fuel level change in the fuel tank.
- NG >> Ask the customer about the situation when the symptom occurs in detail, and Preform the trouble diagnosis.

The Fuel Gauge Does Not Move to F-position.

EKS004QR

1. QUESTIONNAIRE 1

Does it take a long time for the pointer to move to F-position?

YES or NO?

- YES >> GO TO 2.
- NO >> GO TO 3.

COMBINATION METERS (LHD MODELS)

2. QUESTIONNAIRE 2

Was the vehicle fueled with the ignition switch ON?

YES or NO?

- YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise it will take a long time to move to F-position because of the characteristic of the fuel gauge.
 NO >> GO TO 3.

3. QUESTIONNAIRE 3

Is the floor or the vehicle inclined?

YES or NO?

- YES >> It may not be filled fully.
 NO >> GO TO 4.

4. QUESTIONNAIRE 4

During driving, does the fuel gauge pointer move gradually toward E-position?

YES or NO?

- YES >> Check the components. Refer to [DI-32, "Electrical Components Inspection"](#) .
 NO >> The float arm may interfere or bind with any of the components in the fuel tank.

The Fuel Gauge Does Not Work.

EKS004QS

1. HARNESS CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, and harness-side) for poor connection and bend.

OK or NG?

- OK >> GO TO 2.
 NG >> Repair connector.

2. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation (refer to [FL-6, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY \(EXCEPT YD22DDTi\)"](#) or [FL-10, "FUEL LEVEL SENSOR UNIT \(YD22DDTi\)"](#)), and check whether the float arm interferes or binds with any components inside the arm.

OK or NG?

- OK >> Recheck "PRELIMINARY CHECK".
 NG >> Check fuel level sensor unit. Refer to [DI-32, "Electrical Components Inspection"](#) .


Electrical Components Inspection FUEL LEVEL SENSOR UNIT CHECK

EKS004QT

For removal, refer to [FL-6, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY \(EXCEPT YD22DDTi\)"](#) or [FL-10, "FUEL LEVEL SENSOR UNIT \(YD22DDTi\)"](#) for Gasoline engine models. Check the resistance between terminals 1 and 4.

| Ohmmeter | | Float position | | mm (in) | Resistance value Ω |
|----------|-----|----------------|-------|-------------------|--------------------|
| (+) | (-) | *1 | *2 | | |
| 4 | 1 | Full | Empty | 35 (1.38) | 179 (7.05) |
| | | | | Approx. 4.5 - 5.5 | Approx. 80 - 83 |


*1 and *2: When float rod is in contact with stopper.



COMBINATION METERS (LHD MODELS)


Removal and Installation for Combination Meter

1. Remove the cluster lid A. Refer to [IP-3, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove the screws (4), and pull out combination meter.
3. Disconnect connectors and remove combination meter.



Disassembly and Assembly for Combination Meter

1. Disengage the tabs (8) to separate front cover.
2. Remove upper housing.



A
B
C
D
E
F
G
H
I
J
DI
L
M

DI

COMBINATION METERS (RHD MODELS)

COMBINATION METERS (RHD MODELS)

PFP:24810

System Description


EKS004QV

UNIFIED CONTROL METER

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit built in combination meter.
- Signal of speedometer, odo/trip meter, tachometer and water temperature gauge are sent via CAN communication line.
- Digital meter is adopted for odo/trip meter.*
*The record of the odometer is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter, A/T indicator and ICC system display segments can be checked in self-diagnosis mode.
- Meter/gauge can be checked in self-diagnosis mode.

HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

- The CAN communication signals (vehicle speed signal) from ESP/TCS/ABS control unit, and the memory signals from the meter memory circuit are processed by the combination meter, and the mileage is displayed.
- Operating the odometer/trip switch allows switching the mode in the following order.



- The odometer/trip display switching and trip display resetting can be identified by the time from pressing the odometer/trip switch to releasing it.
- When resetting with trip A displayed, only trip A display is reset (same as trip B).

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse [NO. 12, located in the fuse block (J/B)]
- to combination meter terminal 39.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [NO. 30, located in the fuse block (J/B)]
- to combination meter terminal 38.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [NO. 1, located in the fuse block (J/B)]
- to combination meter terminal 37.

Ground is supplied

- to combination meter terminals 11, 12 and 32
- through body grounds M16, M50 and M70.

COMBINATION METERS (RHD MODELS)

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. ECM provides a water temperature signal to combination meter for water temperature gauge with CAN communication line.

TACHOMETER

The tachometer indicates engine speed in revolution per minutes (rpm). ECM provides an engine speed signal to combination meter for tachometer with CAN communication line.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable resistor signal supplied

- to combination meter terminal 34 for the fuel level sensor
- from terminal 4 of the fuel level sensor unit
- through terminal 1 of the fuel level sensor unit and
- through combination meter terminal 33

SPEEDOMETER

ESP/TCS/ABS control unit provides a vehicle speed signal to the combination meter for the speedometer with CAN communication line.

CAN Communication SYSTEM DESCRIPTION

EKS004U6

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

WITH TYRE PRESSURE MONITORING SYSTEM

| | | | | | | | | | |
|---------------|-------------|----------------|--|--------|--------|--------|--------|--------|-----------|
| Body type | Sedan/Wagon | | | | | | | | |
| Axle | 2WD | | | | | | | | |
| Engine | QR20DE | | | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DD Ti |
| Transmission | CVT | | | A/T | 6M/T | 5M/T | | 6M/T | |
| Brake control | ESP | | | ABS | | ESP | ABS | | |
| ICC system | Applicable | Not applicable | | | | | | | |


| CAN communication unit | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|---|
| ECM | × | × | × | × | × | × | × | × | × |
| TCM | × | × | × | × | | | | | |
| ICC sensor | × | | | | | | | | |
| ESP/TCS/ABS control unit | × | × | | | × | | | | |
| ABS actuator and electric unit (control unit) | | | × | × | | × | × | × | × |
| Data link connector | × | × | × | × | × | × | × | × | × |
| Tyre pressure monitoring control unit | × | × | × | × | × | × | × | × | × |
| Steering angle sensor | × | × | | | × | | | | |
| ICC unit | × | | | | | | | | |
| Smart entrance control unit | × | × | × | × | × | × | × | × | × |

COMBINATION METERS (RHD MODELS)

| | | | | | | | | |
|------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|--------|-----------|
| Body type | Sedan/Wagon | | | | | | | |
| Axle | 2WD | | | | | | | |
| Engine | QR20DE | | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DD Ti |
| Transmission | CVT | | A/T | 6M/T | 5M/T | | 6M/T | |
| Brake control | ESP | | ABS | | ESP | ABS | | |
| ICC system | Applicable | Not applicable | | | | | | |
| CAN communication unit | | | | | | | | |
| Combination meter | × | × | × | × | × | × | × | × |
| CAN communication type | DI-36, "TYPE 13" | DI-37, "TYPE 14" | DI-38, "TYPE 15" | DI-39, "TYPE 16" | DI-40, "TYPE 17" | DI-41, "TYPE 18" | | |

TYPE 13

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ICC sensor | ESP/TCS/ABS control unit | Tyre pressure monitoring control unit | Steering angle sensor | ICC unit | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|------------|--------------------------|---------------------------------------|-----------------------|----------|-----------------------------|-------------------|
| Engine speed signal | T | R | | R | | | R | | R |
| Accelerator pedal position signal | T | R | | R | | | R | | |
| Closed throttle position signal | T | | | | | | R | | |
| ICC steering switch signal | T | | | | | | R | | |
| Shift pattern signal | | T | | | | | R | | |
| Parking brake switch signal | | | | T | | | R | | |
| ICC system display signal | | | | | | | T | | |
| ICC sensor signal | | | T | | | | R | | |
| ESP operation signal | R | | | T | | | R | | |
| TCS operation signal | R | | | T | | | R | | |
| ABS operation signal | R | R | | T | | | R | | |
| Stop lamp switch signal | | R | | T | | | | | |
| Steering wheel angle sensor signal | | | | R | | T | | | |
| Wheel speed sensor signal | | | | T | | | R | | |
| Rear window defogger signal | R | | | | | | | T | |
| Heater fan switch signal | R | | | | | | | | T |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ICC sensor | ESP/TCS / ABS control unit | Tyre pressure monitoring control unit | Steering angle sensor | ICC unit | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|------------|----------------------------|---------------------------------------|-----------------------|----------|-----------------------------|-------------------|
| Air conditioner switch signal | R | | | | | | | | T |
| Primary pulley revolution signal | R | T | | | | | R | | |
| Secondary pulley revolution signal | R | T | | | | | R | | |
| ICC operation signal | R | | | | | | T | | |
| Brake switch signal | R | | | | | | T | | |
| MI signal | T | | | | | | | | R |
| Current gear position signal | | T | | | | | | | R |
| Engine coolant temperature signal | T | | | | | | R | | R |
| Fuel consumption signal | T | | | | | | | | R |
| Vehicle speed signal | | | | T | | | | | R |
| | R | | | | | | | | T |
| Seat belt reminder signal | | | | | | | | R | T |
| Headlamp switch signal | | | | | | | | T | R |
| Flashing indicator signal | | | | | | | | T | R |
| Engine cooling fan speed signal | T | | | | | | | R | |
| Child lock indicator signal | | | | | | | | T | R |
| Door switches state signal | | | | | | | | T | R |
| Key ID signal | R | | | | | | | T | |
| | T | | | | | | | R | |
| A/C compressor signal | T | | | | | | | R | |
| Tire pressure signal | | | | | T | | | | R |

TYPE 14

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ESP/TCS / ABS control unit | Tyre pressure monitoring control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----|----------------------------|---------------------------------------|-----------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | R | | | | R |
| Accelerator pedal position signal | T | R | R | | | | |
| ESP operation signal | R | | T | | | | |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ESP/ TCS / ABS con- trol unit | Tyre pressure monitor- ing con- trol unit | Steering angle sensor | Smart entrance control unit | Combi- nation meter |
|------------------------------------|-----|-----|--|---|-----------------------------|--------------------------------------|---------------------------|
| TCS operation signal | R | | T | | | | |
| ABS operation signal | R | R | T | | | | |
| Stop lamp switch signal | | R | T | | | | |
| Steering wheel angle sensor signal | | | R | | T | | |
| Rear window defogger signal | R | | | | | T | |
| Heater fan switch signal | R | | | | | | T |
| Air conditioner switch signal | R | | | | | | T |
| Primary pulley revolution signal | R | T | | | | | |
| Secondary pulley revolution signal | R | T | | | | | |
| MI signal | T | | | | | | R |
| Current gear position signal | | T | | | | | R |
| Engine coolant temperature | T | | | | | | R |
| Fuel consumption signal | T | | | | | | R |
| Vehicle speed signal | | | T | | | | R |
| | R | | | | | | T |
| Seat belt reminder signal | | | | | | R | T |
| Headlamp switch signal | | | | | | T | R |
| Flashing indicator signal | | | | | | T | R |
| Engine cooling fan speed signal | T | | | | | R | |
| Child lock indicator signal | | | | | | T | R |
| Door switches state signal | | | | | | T | R |
| Key ID signal | R | | | | | T | |
| | T | | | | | R | |
| A/C compressor signal | T | | | | | R | |
| Tire pressure signal | | | | T | | | R |

TYPE 15

System diagram



COMBINATION METERS (RHD MODELS)


Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Tyre pressure monitoring control unit | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|---|---------------------------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | | | | R |
| Stop lamp switch signal | | R | T | | | |
| Rear window defogger signal | R | | | | T | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| Primary pulley revolution signal | R | T | | | | |
| Secondary pulley revolution signal | R | T | | | | |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | | R | T |
| Headlamp switch signal | | | | | T | R |
| Flashing indicator signal | | | | | T | R |
| Engine cooling fan speed signal | T | | | | R | |
| Child lock indicator signal | | | | | T | R |
| Door switches state signal | | | | | T | R |
| Key ID signal | R | | | | T | |
| | T | | | | R | |
| A/C compressor signal | T | | | | R | |
| Tire pressure signal | | | | T | | R |

TYPE 16

System diagram



COMBINATION METERS (RHD MODELS)


Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Tyre pressure monitoring control unit | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----|---|---------------------------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | | | | R |
| Stop lamp switch signal | | R | T | | | |
| Rear window defogger signal | R | | | | T | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | | R | T |
| Headlamp switch signal | | | | | T | R |
| Flashing indicator signal | | | | | T | R |
| Engine cooling fan speed signal | T | | | | R | |
| Child lock indicator signal | | | | | T | R |
| Door switches state signal | | | | | T | R |
| Key ID signal | R | | | | T | |
| | T | | | | R | |
| A/C compressor signal | T | | | | R | |
| Tire pressure signal | | | | T | | R |

TYPE 17

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | ESP/TCS / ABS control unit | Tyre pressure monitoring control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|----------------------------|---------------------------------------|-----------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | | | | R |
| Accelerator pedal position signal | T | R | | | | |
| ESP operation signal | R | T | | | | |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | ESP/ TCS / ABS control unit | Tyre pressure monitoring control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----------------------------|---------------------------------------|-----------------------|-----------------------------|-------------------|
| TCS operation signal | R | T | | | | |
| ABS operation signal | R | T | | | | |
| Steering wheel angle sensor signal | | R | | T | | |
| Rear window defogger signal | R | | | | T | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| MI signal | T | | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | T | | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | | R | T |
| Headlamp switch signal | | | | | T | R |
| Flashing indicator signal | | | | | T | R |
| Engine cooling fan speed signal | T | | | | R | |
| Child lock indicator signal | | | | | T | R |
| Door switches state signal | | | | | T | R |
| Key ID signal | R | | | | T | |
| | T | | | | R | |
| A/C compressor signal | T | | | | R | |
| Tire pressure signal | | | T | | | R |

TYPE 18

System diagram



Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | ABS actuator and electric unit (control unit) | Tyre pressure monitoring control unit | Smart entrance control unit | Combination meter |
|-------------------------------|-----|---|---------------------------------------|-----------------------------|-------------------|
| Engine speed signal | T | | | | R |
| Rear window defogger signal | R*1 | | | T | |
| Heater fan switch signal | R*1 | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | ABS actuator and electric unit (control unit) | Tyre pressure monitoring control unit | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|---|---------------------------------------|-----------------------------|-------------------|
| Glow lamp signal*2 | T | | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | T | | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |
| Tire pressure signal | | | T | | R |

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

WITHOUT TYRE PRESSURE MONITORING SYSTEM


| Body type | Sedan/Wagon | | | | | | | | |
|---|-------------|----------------|--------|--------|--------|--------|--------|----------|---|
| Axle | 2WD | | | | | | | | |
| Engine | QR20DE | | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DDTi | |
| Transmission | CVT | | A/T | 6M/T | 5M/T | | 6M/T | | |
| Brake control | ESP | | ABS | | ESP | ABS | | | |
| ICC system | Applicable | Not applicable | | | | | | | |
| CAN communication unit | | | | | | | | | |
| ECM | × | × | × | × | × | × | × | × | × |
| TCM | × | × | × | × | | | | | |
| ICC sensor | × | | | | | | | | |
| ESP/TCS/ABS control unit | × | × | | | × | | | | |
| ABS actuator and electric unit (control unit) | | | × | × | | × | × | × | × |
| Data link connector | × | × | × | × | × | × | × | × | × |
| Steering angle sensor | × | × | | | × | | | | |
| ICC unit | × | | | | | | | | |
| Smart entrance control unit | × | × | × | × | × | × | × | × | × |
| Combination meter | × | × | × | × | × | × | × | × | × |

COMBINATION METERS (RHD MODELS)

| | | | | | | | |
|------------------------------|--|--|--|--|--|---|-----------|
| Body type | Sedan/Wagon | | | | | | |
| Axle | 2WD | | | | | | |
| Engine | QR20DE | QG18DE | QR20DE | QG16DE | QG18DE | QR20DE | YD22DD Ti |
| Transmission | CVT | A/T | 6M/T | 5M/T | 6M/T | | |
| Brake control | ESP | ABS | ESP | ABS | | | |
| ICC system | Applicable | Not applicable | | | | | |
| CAN communication unit | | | | | | | |
| Can communication type | DI-43, "TYPE 19" | DI-44, "TYPE 20" | DI-45, "TYPE 21" | DI-46, "TYPE 22" | DI-47, "TYPE 23" | DI-48, "TYPE 24" | |
| Can system Trouble Diagnosis | LAN-379, "CAN SYS-TEM (TYPE 19)" | LAN-404, "CAN SYS-TEM (TYPE 20)" | LAN-422, "CAN SYS-TEM (TYPE 21)" | LAN-438, "CAN SYS-TEM (TYPE 22)" | LAN-454, "CAN SYS-TEM (TYPE 23)" | LAN-469, "CAN SYSTEM (TYPE 24)" | |

TYPE 19

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ICC sensor | ESP/TCS / ABS control unit | Steering angle sensor | ICC unit | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|------------|----------------------------|-----------------------|----------|-----------------------------|-------------------|
| Engine speed signal | T | R | | R | | R | | R |
| Accelerator pedal position signal | T | R | | R | | R | | |
| Closed throttle position signal | T | | | | | R | | |
| ICC steering switch signal | T | | | | | R | | |
| Shift pattern signal | | T | | | | R | | |
| Parking brake switch signal | | | | T | | R | | |
| ICC system display signal | | | | | | T | | R |
| ICC sensor signal | | | T | | | R | | |
| ESP operation signal | R | | | T | | R | | |
| TCS operation signal | R | | | T | | R | | |
| ABS operation signal | R | R | | T | | R | | |
| Stop lamp switch signal | | R | | T | | | | |
| Steering wheel angle sensor signal | | | | R | T | | | |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ICC sensor | ESP/TCS/ABS control unit | Steering angle sensor | ICC unit | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|------------|--------------------------|-----------------------|----------|-----------------------------|-------------------|
| Wheel speed sensor signal | | | | T | | R | | |
| Rear window defogger signal | R | | | | | | T | |
| Heater fan switch signal | R | | | | | | | T |
| Air conditioner switch signal | R | | | | | | | T |
| Primary pulley revolution signal | R | T | | | | R | | |
| Secondary pulley revolution signal | R | T | | | | R | | |
| ICC operation signal | R | | | | | T | | |
| Brake switch signal | R | | | | | T | | |
| MI signal | T | | | | | | | R |
| Current gear position signal | | T | | | | | | R |
| Engine coolant temperature signal | T | | | | | R | | R |
| Fuel consumption signal | T | | | | | | | R |
| Vehicle speed signal | | | | T | | | | R |
| | R | | | | | | | T |
| Seat belt reminder signal | | | | | | | R | T |
| Headlamp switch signal | | | | | | | T | R |
| Flashing indicator signal | | | | | | | T | R |
| Engine cooling fan speed signal | T | | | | | | R | |
| Child lock indicator signal | | | | | | | T | R |
| Door switches state signal | | | | | | | T | R |
| Key ID signal | R | | | | | | T | |
| | T | | | | | | R | |
| A/C compressor signal | T | | | | | | R | |

TYPE 20

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ESP/TCS/ABS control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----|--------------------------|-----------------------|-----------------------------|-------------------|
| Engine speed signal | T | R | R | | | R |
| Accelerator pedal position signal | T | R | R | | | |
| ESP operation signal | R | | T | | | |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ESP/TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|----------------------------|-----------------------|-----------------------------|-------------------|
| TCS operation signal | R | | T | | | |
| ABS operation signal | R | R | T | | | |
| Stop lamp switch signal | | R | T | | | |
| Steering wheel angle sensor signal | | | R | T | | |
| Rear window defogger signal | R | | | | T | |
| Heater fan switch signal | R | | | | | T |
| Air conditioner switch signal | R | | | | | T |
| Primary pulley revolution signal | R | T | | | | |
| Secondary pulley revolution signal | R | T | | | | |
| MI signal | T | | | | | R |
| Current gear position signal | | T | | | | R |
| Engine coolant temperature signal | T | | | | | R |
| Fuel consumption signal | T | | | | | R |
| Vehicle speed signal | | | T | | | R |
| | R | | | | | T |
| Seat belt reminder signal | | | | | R | T |
| Headlamp switch signal | | | | | T | R |
| Flashing indicator signal | | | | | T | R |
| Engine cooling fan speed signal | T | | | | R | |
| Child lock indicator signal | | | | | T | R |
| Door switches state signal | | | | | T | R |
| Key ID signal | R | | | | T | |
| | T | | | | R | |
| A/C compressor signal | T | | | | R | |

TYPE 21

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-------------------------|-----|-----|---|-----------------------------|-------------------|
| Engine speed signal | T | R | | | R |
| Stop lamp switch signal | | R | T | | |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|------------------------------------|-----|-----|---|-----------------------------|-------------------|
| Rear window defogger signal | R | | | T | |
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| Primary pulley revolution signal | R | T | | | |
| Secondary pulley revolution signal | R | T | | | |
| MI signal | T | | | | R |
| Current gear position signal | | T | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | | T | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 22

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-------------------------------|-----|-----|---|-----------------------------|-------------------|
| Engine speed signal | T | R | | | R |
| Stop lamp switch signal | | R | T | | |
| Rear window defogger signal | R | | | T | |
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | TCM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-----------------------------------|-----|-----|---|-----------------------------|-------------------|
| Current gear position signal | | T | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |
| Vehicle speed signal | | | T | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 23

System diagram



Input/output signal chart

T: Transmit R: Receive


| Signals | ECM | ESP/ TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combina-tion meter |
|------------------------------------|-----|-----------------------------|-----------------------|-----------------------------|--------------------|
| Engine speed signal | T | R | | | R |
| Accelerator pedal position signal | T | R | | | |
| ESP operation signal | R | T | | | |
| TCS operation signal | R | T | | | |
| ABS operation signal | R | T | | | |
| Steering wheel angle sensor signal | | R | T | | |
| Rear window defogger signal | R | | | T | |
| Heater fan switch signal | R | | | | T |
| Air conditioner switch signal | R | | | | T |
| MI signal | T | | | | R |
| Engine coolant temperature signal | T | | | | R |
| Fuel consumption signal | T | | | | R |

COMBINATION METERS (RHD MODELS)

| Signals | ECM | ESP/ TCS / ABS control unit | Steering angle sensor | Smart entrance control unit | Combina- tion meter |
|---------------------------------|-----|-----------------------------------|--------------------------|-----------------------------------|------------------------|
| Vehicle speed signal | | T | | | R |
| | R | | | | T |
| Seat belt reminder signal | | | | R | T |
| Headlamp switch signal | | | | T | R |
| Flashing indicator signal | | | | T | R |
| Engine cooling fan speed signal | T | | | R | |
| Child lock indicator signal | | | | T | R |
| Door switches state signal | | | | T | R |
| Key ID signal | R | | | T | |
| | T | | | R | |
| A/C compressor signal | T | | | R | |

TYPE 24

System diagram



Input/output signal chart

T: Transmit R: Receive

| Signals | ECM | ABS actuator and electric unit (con- trol unit) | Smart entrance control unit | Combination meter |
|-----------------------------------|-----------------|---|--------------------------------|----------------------|
| Engine speed signal | T | | | R |
| Rear window defogger signal | R ^{*1} | | T | |
| Heater fan switch signal | R ^{*1} | | | T |
| Air conditioner switch signal | R | | | T |
| MI signal | T | | | R |
| Glow lamp signal ^{*2} | T | | | R |
| Engine coolant temperature signal | T | | | R |
| Fuel consumption signal | T | | | R |
| Vehicle speed signal | | T | | R |
| | R | | | T |
| Seat belt reminder signal | | | R | T |
| Headlamp switch signal | | | T | R |
| Flashing indicator signal | | | T | R |
| Engine cooling fan speed signal | T | | R | |
| Child lock indicator signal | | | T | R |
| Door switches state signal | | | T | R |

COMBINATION METERS (RHD MODELS)


| Signals | ECM | ABS actuator and electric unit (control unit) | Smart entrance control unit | Combination meter |
|-----------------------|-----|---|-----------------------------|-------------------|
| Key ID signal | R | | T | |
| | T | | R | |
| A/C compressor signal | T | | R | |

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

Component Parts and Harness Connector Location

EKS003VW




MKIB0048E

A
B
C
D
E
F
G
H
I
J
DI
L
M

COMBINATION METERS (RHD MODELS)

EKS004QW

Combination Meter CHECK



CVT : (C)
O/D OFF : (A)

(A) : With A/T
(C) : With CVT

(M36)


(M37)

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 |

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 |
| 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 |

(Blue)

(Yellow)




MKWA0173E

COMBINATION METERS (RHD MODELS)

Schematic

EKS003VY

A
B
C
D
E
F
G
H
I
J
DI
L
M



() : RHD MODELS





MKWA0174E

COMBINATION METERS (RHD MODELS)

EKS004QX

Wiring Diagram — METER —

DI-METER-02



REFER TO THE FOLLOWING.

(M1), (M2) - FUSE BLOCK- JUNCTION BOX (J/B)

MKWA0176E

COMBINATION METERS (RHD MODELS)


EKS004QY






Combination Meter Self-Diagnosis PERFORMING SELF-DIAGNOSIS MODE

1. Turn the ignition switch to the "LOCK" position.
2. Press both reset buttons on the combination meter and keep them depressed.
3. Turn the ignition switch to the "ON" position, while keeping the reset buttons pressed.
4. Release both reset buttons then self-diagnosis will start. The sequence (A to L) is activated by press the either reset buttons.

NOTE:

If either reset button is not pressed for 20 seconds at each step or if the ignition switch is turned OFF, the self-diagnosis mode is exited.










| | Check items | Display | Remarks |
|----|-----------------------|---|---|
| A) | Odometer segment test |  <p style="text-align: center;">MKIB0001E</p> | All odo/trip meter, A/T indicator and ICC system display segments are ON. |
| B) | Work instruction code |  <p style="text-align: center;">This code is an example. MKIB0002E</p> | This information is not used for service. Skip this step. |
| C) | Software code |  <p style="text-align: center;">This code is an example. MKIB0003E</p> | This information is not used for service. Skip this step. |
| D) | EEPROM code |  <p style="text-align: center;">This code is an example. MKIB0004E</p> | This information is not used for service. Skip this step. |
| E) | Hardware code |  <p style="text-align: center;">This code is an example. MKIB0005E</p> | This information is not used for service. Skip this step. |

A
B
C
D
E
F
G
H
I
J
L
M

DI

COMBINATION METERS (RHD MODELS)

| | Check items | Display | Remarks |
|----|---|--|--|
| F) | PCB code |  <p>This code is an example. MKIB0006E</p> | This information is not used for service. Skip this step. |
| G) | Meter/gauge test (Sweeping movement) |  <p>Flashing MKIB0007E</p> | Tachometer, speedometer, fuel level gauge and water temperature gauge have sweeping movement test. (The meter/gauges operate MIN. → MAX., MAX. → MIN. for 2 times) The odo/trip meter segment flashes during the sweep movement. |
| H) | Error 1 (Bit 0 - Bit 3) | <p style="text-align: center;">3 2 1 0 bit</p>  <p>This value is an example. MKIB0008E</p> | The segment of each bit displays "0", meaning no malfunction. If the bit(s) displays figures other than "0", the item of the bit has malfunctioned. For details, refer to "Malfunction chart for Error 1 and Error E" below. |
| I) | Error E (Bit 4 - Bit 7) | <p style="text-align: center;">7 6 5 4 bit</p>  <p>This value is an example. MKIB0009E</p> | |
| J) | Fuel warning lamp test |  <p>Flashing MKIB0010E</p> | Fuel warning lamp is on and odo/trip meter segment "FUEL" flashes. |
| K) | Fuel gauge calibration (CAL) |  <p>This value is an example. MKIB0011E</p> | This information is not used for service. Skip this step. |
| L) | Fuel gauge calibration (OLD) |  <p>This value is an example. MKIB0012E</p> | This information is not used for service. Skip this step. |

COMBINATION METERS (RHD MODELS)

Malfunction Chart for “Error 1” and “Error E”

| Bit | Detectable items | Description of the malfunction | Displayed figure on the bit | |
|-----|--------------------------------|--|-----------------------------|----------------|
| | | | malfunction | No malfunction |
| 0 | Speedometer input signal | No input signal When no signal is detected for 5 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.) | 1 | 0 |
| | | Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction. | 2 | |
| 1 | Tachometer input signal | No input signal When no signal is detected for 5 minutes continuously with the ignition ON, it should be judged as signal malfunction. (If input signal is detected later, then the judgement will be canceled immediately.) | 1 | 0 |
| | | Unusual input signal When any signal of frequency which would not exist in normal conditions is detected, it should be judged as signal malfunction. | 2 | |
| 2 | Fuel level input signal | Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction. | 1 | 0 |
| | | Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction. | 2 | |
| 3 | Water temperature input signal | Short circuit When short circuit of the signal line is detected for 5 seconds or more, it should be judged as short-circuit malfunction. | 1 | 0 |
| | | Open circuit When open circuit of the signal line is detected for 5 seconds or more, it should be judged as open-circuit malfunction. | 2 | |
| 4 | Reset buttons | Short circuit for reset buttons When the short circuit is continuously detected for 5 minutes or more, it should be judged as short-circuit malfunction. | 1 | 0 |
| | | Right side reset button has malfunctioned. | 2 | |
| | | Left side reset button has malfunctioned. | 3 | |
| 5 | CPU | CPU RAM malfunction | 1 | 0 |
| 6 | — | — | 0 | 0 |

Combination Meter Calibration

After replacing a combination meter, it might be necessary to calibrate the fuel gauge/low fuel warning lamp. In case the fuel warning lamp is flashing after replacing the combination meter perform the following:

1. Press both reset buttons.
2. Turn the ignition ON **and keep the reset buttons depressed for at least 5 seconds.**
3. Release both reset buttons.

The low fuel warning lamp will stop flashing and the combination meter will shown CALL and possibly CALL FAIL. Showing CALL FAIL does not indicate a concern as this might be related to the current (unexpected) amount of fuel in the tank.

COMBINATION METERS (RHD MODELS)

EKS004QZ

Trouble Diagnoses PRELIMINARY CHECK

1. CHECK WARNING LAMPS

1. Turn ignition switch ON.
2. Warning lamps should illuminate (seat belt warning or door warning etc.).

Do warning lamps illuminate?

YES >> GO TO 2.

NO >> Power supply and ground check. Refer to [DI-58, "Power Supply and Ground Circuit Check"](#) .

2. CHECK SELF-DIAGNOSIS MODE OPERATION

Perform self-diagnosis mode. Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

Can self-diagnosis mode be activated?

YES >> GO TO 3.

NO >> Replace unified meter control unit. Refer to [DI-62, "Removal and Installation for Combination Meter"](#) .

3. CHECK METER/GAUGE OPERATION

Check meter/gauge operation in self-diagnosis mode (Meter/gauge test). Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

Is any malfunction indicated in self-diagnosis mode?

YES >> GO TO "Symptom Chart 1". Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

NO >> GO TO 4.

4. CHECK SEGMENTS

Check all odo/trip meter segments in self-diagnosis mode (Odo/trip meter segment test). Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

Is any malfunction indicated in self-diagnosis mode?

YES >> GO TO "Symptom Chart 1" [DI-57, "Symptom Chart 1"](#) .

NO >> GO TO 5.

5. CHECK FUEL WARNING LAMP

Check fuel warning lamp in self-diagnosis mode (Fuel warning lamp test). Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

Do fuel warning lamp illuminate?

YES >> GO TO "Symptom Chart 1" [DI-57, "Symptom Chart 1"](#) .

NO >> GO TO 6.

6. CHECK INPUT SIGNALS

Check input signals from each sensors in self-diagnosis mode (Error 1 and Error E). Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

OK or NG?

OK >> GO TO 7.

NG >> GO TO "Symptom Chart 2" [DI-57, "Symptom Chart 2"](#) .

7. CHECK OTHER MALFUNCTION

Check each malfunction according to the instruction of the "SYMPTOM CHART 3" [DI-57, "Symptom Chart 3"](#) .

OK >> Combination meter is OK.

NG >> Check the case of malfunction.

COMBINATION METERS (RHD MODELS)

SYMPTOM CHART

Symptom Chart 1

| Symptom | Possible causes | Repair order |
|---|----------------------------|--|
| Odo/trip meter indicates malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit. Refer to DI-62, "Removal and Installation for Combination Meter" . |
| Multiple meter/gauge indicate malfunction in Diagnosis mode. | | |
| One of speedometer/tachometer/fuel gauge/water temp. gauge indicates malfunction in Diagnosis mode. | | |

Symptom Chart 2

| Symptom | Possible causes | Repair order |
|---|--------------------------------|---|
| Speedometer input signal indicates malfunction in Diagnosis mode. | Speedometer input signal | Check signal for speedometer. Refer to DI-58, "Inspection/Vehicle Speed Signal" . |
| Tachometer input signal indicates malfunction in Diagnosis mode. | Tachometer input signal | Check signal for tachometer. Refer to DI-59, "Inspection/Engine Speed Signal" . |
| Fuel level input signal indicates malfunction in Diagnosis mode. | Fuel level input signal | Check signal for tachometer. Refer to DI-59, "Inspection/Fuel Level Sensor Unit" . |
| Water temperature input signal Indicates malfunction in Diagnosis mode. | Water temp. gauge input signal | Check signal for water temp. gauge. Refer to DI-60, "Inspection/Water Temperature Gauge" . |
| Reset buttons indicate malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit assembly. Refer to DI-62, "Removal and Installation for Combination Meter" . |
| CPU indicates malfunction in Diagnosis mode. | Unified meter control unit | Replace unified meter control unit assembly. Refer to DI-62, "Removal and Installation for Combination Meter" . |

Symptom Chart 3

| Symptom | Possible causes | Repair order |
|---|-----------------|---|
| Fuel gauge pointer fluctuates, Indicator wrong value or varies. | - | Check the case of malfunction. Refer to DI-60, "The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies." . |
| Fuel gauge does not move to "F" position. | - | Check the case of malfunction. Refer to DI-60, "The Fuel Gauge Does Not Move to F-position." . |
| Fuel gauge does not work. | - | Check the case of malfunction. Refer to DI-61, "The Fuel Gauge Does Not Work." . |

COMBINATION METERS (RHD MODELS)

EKS004R0

Power Supply and Ground Circuit Check

1. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector and ground in the following conditions.

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (wire color) | | | | |
| M37 | 37 (P)* | Ground | 0V | Battery voltage | Battery voltage |
| M37 | 38 (Y) | Ground | 0V | 0V | Battery voltage |
| M46 | 39 (R/B) | Ground | Battery voltage | Battery voltage | Battery voltage |

*: With Navigation system

OK or NG?

- OK >> GO TO 2.
 NG >> ● 10A fuse [No. 1, located in fuse block (J/B)].
 ● 10A fuse [No. 30, located in fuse block (J/B)].
 ● 10A fuse [No. 12, located in fuse block (J/B)].
 ● Harness for open or short between fuse and combination meter.

2. GROUND CIRCUIT CHECK

Check continuity between combination meter and ground in the following conditions.

| Terminals | | (-) | Continuity |
|-----------|----------|--------|------------|
| (+) | | | |
| Connector | Terminal | | |
| M36 | 12 | Ground | Yes |
| M37 | 32 | Ground | Yes |
| M36 | 11 | Ground | Yes |

OK or NG?

- OK >> INSPECTION END.
 NG >> Harness for open ground circuit.

Inspection/Vehicle Speed Signal



EKS004T4

1. ESP/TCS/ABS CONTROL UNIT SYSTEM INSPECTION

Perform ESP/TCS/ABS control unit self-diagnosis. Refer to [BRC-76, "Functions of CONSULT-II"](#).

OK or NG?

- OK >> Recheck "PRELIMINALY CHECK".
 NG >> Check ESP/TCS/ABS control system.



COMBINATION METERS (RHD MODELS)

Inspection/Engine Speed Signal

EKS004R1

1. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-121, "CONSULT-II Function"](#).

OK or NG?

- OK >> Recheck "PRELIMINALY CHECK".
- NG >> Check engine control system.

Inspection/Fuel Level Sensor Unit

EKS004R2

FUEL LEVEL SENSOR UNIT

The following symptoms do not indicate a malfunction.

- Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the pointer may fluctuate.
- If the vehicle is fueled with the ignition switch ON, the pointer will move slowly.

LOW-FUEL WARNING LAMP

Depending on vehicle posture or driving circumstance, the fuel level in the tank varies, and the warning lamp ON timing may be changed.

1. HARNESS CONNECTOR INSPECTION


1. Turn the ignition switch OFF.
2. Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, and harness-side) for poor connection and bend.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair or replace terminals or connectors.

2. CHECK FUEL LEVEL SENSOR INPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector and combination meter harness connector.
3. Check the following.
 - Harness continuity between fuel level sensor unit harness connector B22 terminal 4 (G/Y) and combination meter harness connector M37 terminal 34 (G/Y).
 - Harness continuity between combination meter harness connector M37 terminal 34 (G/Y) and ground.



| Terminals | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M37 | 34 (G/Y) | B22 | 4 (G/Y) | Yes |
| M37 | 34 (G/Y) | Ground | | No |

OK or NG?

- OK >> GO TO 3.
- NG >> Repair harness or connector.

COMBINATION METERS (RHD MODELS)


3. CHECK FUEL LEVEL SENSOR GROUND CIRCUIT

Check harness continuity between fuel level sensor unit connector B22 terminal 1 (B) and ground.

Continuity should exist.

OK or NG?

- OK >> GO TO 4.
- NG >> Repair harness or connector.



4. FUEL LEVEL SENSOR UNIT INSPECTION

Refer to [DI-59, "Inspection/Fuel Level Sensor Unit"](#).

OK or NG?

- OK >> GO TO 5.
- NG >> Replace fuel level sensor unit.

5. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any components inside the arm.

OK or NG?

- OK >> Replace combination meter.
- NG >> Install fuel level sensor unit properly.

Inspection/Water Temperature Gauge

EKS004R3

1. ECM SYSTEM INSPECTION

Perform ECM self-diagnosis. Refer to [EC-121, "CONSULT-II Function"](#) (QG engine with EURO-OBD), [EC-636, "CONSULT-II Function"](#) (QG engine without EURO-OBD), [EC-1054, "CONSULT-II Function"](#) (QR engine with EURO-OBD), [EC-1479, "CONSULT-II Function"](#) (QR engine without EURO-OBD) or [EC-1773, "CONSULT-II Function"](#) (YD engine).

OK or NG?

- OK >> Recheck "PRELIMINALY CHECK".
- NG >> Check engine control system.

The Fuel Gauge Pointer Fluctuates Indicator Wrong Value or Varies.

EKS003W8

1. CHECK THE FUEL GAUGE POINTER FOR FLUCTUATION

Does the indication value fluctuate during driving or before/after stop?

Does the indication value vary?

- YES >> The pointer fluctuation may be caused by fuel level change in the fuel tank.
- NO >> Ask the customer about the situation when the symptom occurs in detail, and Preform the trouble diagnosis.

The Fuel Gauge Does Not Move to F-position.

EKS004R4

1. QUESTIONNAIRE 1

Does it take a long time for the pointer to move to F-position?

YES or NO?

- YES >> GO TO 2.
- NO >> GO TO 3.

COMBINATION METERS (RHD MODELS)

2. QUESTIONNAIRE 2

Was the vehicle fueled with the ignition switch ON?

YES or NO?

- YES >> Be sure to fuel the vehicle with the ignition switch OFF. Otherwise it will take a long time to move to F-position because of the characteristic of the fuel gauge.
- NO >> GO TO 3.

3. QUESTIONNAIRE 3

Is the floor or the vehicle inclined?

YES or NO?

- YES >> It may not be filled fully.
- NO >> GO TO 4.

4. QUESTIONNAIRE 4

During driving, does the fuel gauge pointer move gradually toward E-position?

YES or NO?

- YES >> Check the components. Refer to [DI-61, "Electrical Components Inspection"](#) .
- NO >> The float arm may interfere or bind with any of the components in the fuel tank.

The Fuel Gauge Does Not Work.

EKS004R5

1. HARNESS CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Check combination meter, fuel level sensor unit and terminals (meter-side, module-side, and harness-side) for poor connection and bend.

OK or NG?

- OK >> GO TO 2.
- NG >> Repair connector.

2. CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation (Refer to [FL-6, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY \(EXCEPT YD22DDTI\)"](#) or [FL-10, "FUEL LEVEL SENSOR UNIT \(YD22DDTI\)"](#) , check whether the float arm interferes or binds with any components inside the arm.

OK or NG?

- OK >> Fuel level sensor unit is OK.
- NG >> Check fuel level sensor unit. Refer to [DI-61, "Electrical Components Inspection"](#) .

Low Fuel Warning Lamp Illuminate or Not Illuminate

EKS003WB

1. DIAGNOSIS MODE INSPECTION

Perform combination meter diagnosis mode. Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .

OK or NG?

- OK >> Check fuel level sensor unit. Refer to [DI-61, "Electrical Components Inspection"](#) .
- NG >> Replace combination meter.

Electrical Components Inspection

EKS004R6


For electrical components Inspection, refer to [DI-61, "Electrical Components Inspection"](#) .

COMBINATION METERS (RHD MODELS)

Removal and Installation for Combination Meter

EKS003WD


1. Remove the cluster lid A. Refer to [IP-3, "INSTRUMENT PANEL ASSEMBLY"](#).
2. Remove the screws (4), and pull out combination meter.
3. Disconnect connectors and remove combination meter.



Disassembly and Assembly for Combination Meter

EKS003WE

1. Disengage the tabs (8) to separate front cover.
2. Remove upper housing.



VFD DISPLAY



PPF:28090

VFD DISPLAY

Wiring Diagram — COMM —

EKS0055C

DI-COMM-01




REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK-
 JUNCTION BOX (J/B)

VFD DISPLAY

DI-COMM-02

- L : LHD MODELS *1 41 : L *3 42 : L
R : RHD MODELS 28 : R 29 : R
 *2 40 : L *4 34 : L
 27 : R 47 : R



| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 |
| 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 |

(M37)
Y

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|---|---|---|---|
| 24 | 22 | 20 | 18 | 16 | 14 | 12 | 10 | 8 | 6 | 4 | 2 |
| 23 | 21 | 19 | 17 | 15 | 13 | 11 | 9 | 7 | 5 | 3 | 1 |

(M61)
BR

| | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

(M75)
GY

MKWA0350E

LCD DISPLAY

PPF:28395

System Description MULTIFUNCTION SWITCH SYSTEM

EKS00406

Refer to Owner's Manual for multifunction switch operating instructions.

Using the multifunction switch at the center of the instrument panel, the controls of the following systems are centralized:

- Auto A/C system
- Vehicle information system
- Audio system

PRECAUTION OF LCD MONITOR

- When passenger compartment temperature is low, the LCD monitor sometimes dims because of the brightness of the back light (small fluorescent light) integrated into the LCD monitor decrease. In this case, the refreshing rate of the picture also becomes low because of the low response of the LCD monitor. When passenger compartment becomes warm, however, the LCD recovers the normal display.
- Sometimes, black or bright dots peculiar to LCD monitor can be seen on the display.
- Back light sometimes flickers or darkens according to the total consumption hours and the number of ON and OFF switching. In this case, the back light should be replaced. (display unit assembly)

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 15A fuse (No. 33, located in fuse and fusible link box)
- to display unit terminals 2 and 4
- to audio unit terminals 3 and 4.

When ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 1, located in fuse block (J/B)]
- to display unit terminal 6,
- to multifunction switch terminal 6 and
- to audio unit terminal 2.

When ignition switch is in ON or START position, power is supplied

- through 10A fuse [No. 10, located in fuse block (J/B)]
- to display unit terminal 5.

Ground is supplied

- to multifunction switch terminal 1 and
- to display unit terminals 1 and 3
- through body grounds M16, M50 and M70.

AV COMMUNICATION LINE

Display unit is controlled by the following unit with AV communication line.

- Multifunction switch
- Audio unit


VEHICLE INFORMATION SYSTEM

Refer to Owner's Manual for vehicle information system operating instructions.

Vehicle information system is monitoring to drive information, fuel economy information, maintenance information and Tyre pressure monitoring.

LCD DISPLAY

1. Press "INFO" switch to display vehicle information display.
2. Select "Drive", "Fuel Economy", "Maintenance" or "Tyre pressure".




| Display items | Display/Setting contents | |
|--|---------------------------------------|--|
| Drive | Elapsed Time | Displays driving time with a range of 0000:00:00 to 9999:59:59. |
| | Driving Distance (km) | Displays driving distance with a range of 00000.0 to 99999.9. |
| | Average speed (km/h) | Displays average speed with a range of 000.0 to 999.9. |
| Fuel Economy | Average Fuel Economy (l/100km) | Displays fuel economy with ignition switch ON, average fuel economy each 30 minutes. |
| | Distance to Empty (km) | Displays possible driving distance with remaining fuel. |
| | Fuel Economy (l/100km) | Displays fuel economy each approx. 100 ms. |
| | Fuel Economy Record (l/100 km) | Displays Average Fuel Consumption History. |
| Maintenance (with Maintenance information*) | Engine oil | Maintenance intervals of engine oil and setting of oil change cycle |
| | Oil Filter | Maintenance intervals of oil filter and setting of filter replacement cycle |
| | Custom 1 | Determines when maintenance intervals are needed. |
| | Custom 2 | Determines when maintenance intervals are needed. |
| Tyre Pressure monitoring | Tyre pressure monitoring information. | |

*: Maintenance information displays the change cycle of engine oil, oil filter, custom1 and custom2 on LCD monitor depending on the driving distance specified by a driver or a technician.

Drive Information


1. Select "Drive".
2. Elapsed time, Driving distance and Average speed are displayed as Drive information. When pushing "ENTER", Elapsed time, Driving distance and Average speed are all reset.




LCD DISPLAY

Fuel Economy Information

1. Select "Fuel Economy".
2. Average Fuel Economy, Distance to Empty, Fuel Economy are displayed as Fuel Economy information.




3. Select "Fuel Economy Record". The average fuel consumption history will be displayed in graph along with the average for the previous Reset – to – Reset period.




Maintenance Information

1. Select "Maintenance".
2. Engine Oil, Oil Filter, Custom1 and Custom2 are displayed as Maintenance information.



Tyre Pressure

1. Select "Tyre Pressure".
2. Tyre pressure is displayed as Tyre pressure information.



WARNING INDICATIONS

When combination meter receives warning signal from some control units or sensors, then combination meter warning lamp is illuminated. Then combination meter sends warning signal to display unit warning indications on the screen.

LCD DISPLAY

| Warning indicators | Warning lamps in instrument panel | Warning detection and cancel conditions | | Cases of malfunction |
|---------------------|-----------------------------------|---|---|-----------------------------------|
| ENGINE | ENGINE | Detection condition | Warning lamp ON signal is detected while engine is running. | ECM malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| ENGINE OIL PRESSURE | Engine oil pressure | Detection condition | Warning lamp ON signal is detected for at least approx. 5 seconds while engine is running. | Engine oil pressure decreases. |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| AIR BAG | Air bag | Detection condition | Warning lamp ON signal is detected for at least approx. 10 seconds after ignition switch is turned ON. | SRS air bag system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| LOW BRAKE FLUID | Brake | Detection condition | Warning lamp ON signal (fluid level) is detected. | Low brake fluid level |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| OVERHEATING | - | Detection condition | Engine coolant temperature as being approx. 119°C (246°F) min. | Engine cooling system malfunction |
| | | Cancel condition | Engine coolant temperature as being approx. 105°C (221°F) max. | |
| CHARGE | Charge | Detection condition | Warning lamp ON signal is detected while engine is running. Charging system malfunction | Charging system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| LOW WASHER FLUID | - | Detection condition | Washer liquid level falls below approx. 0.8 ℓ (1-3/8 Imp pt) | Low washer liquid level |
| | | Cancel condition | Except above condition. | |
| LOW FUEL | Fuel level | Detection condition | After warning lamp ON signal is detected, vehicle is driven for over specified distance. [Fuel level: Approx. 9.6 ℓ (8-1/2 Imp pt)] | Low fuel level |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| PARKING BRAKE | Brake | Detection condition | Parking brake ON signal is detected while vehicle is running [approx. 5 km/h (3 MPH) or faster]. | Parking brake remains engaged. |
| | | Cancel condition | Vehicle is stopped, or parking brake OFF signal is detected. | |
| DOOR OPEN | Door | Detection condition | Vehicle is running [approx. 5 km/h (3 MPH) or faster] and door ajar of any of the doors is detected. | Door is open |
| | | Cancel condition | Vehicle is stopped and all the doors lock. | |
| ABS | ABS | Detection condition | Warning lamp ON signal is detected when engine is running. | ABS control system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |

LCD DISPLAY

| Warning indicators | Warning lamps in instrument panel | Warning detection and cancel conditions | | Cases of malfunction |
|-------------------------------|-----------------------------------|---|--|---|
| ESP ELECTRONIC CONTROL SYSTEM | ESP | Detection condition | Warning lamp ON signal is detected when engine is running. | ESP system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| CVT ELECTRONIC CONTROL SYSTEM | CVT | Detection condition | Warning lamp ON signal is detected after ignition switch is turned ON. | TCM system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| TYRE PRESSURE | Tyre Pressure | Detection condition | Warning lamp ON signal is detected after ignition switch is turned ON. | Tyre pressure monitoring control system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |
| CRUISE CONTROL SYSTEM | CRUISE | Detection condition | Warning lamp ON signal is detected after ignition switch is turned ON. | ICC system malfunction |
| | | Cancel condition | Warning lamp OFF signal is detected. | |

Precautions for Display Unit Replacement


EKS00407

- Record the following memorized contents before replacing the control unit.
 - <FM-AM>
 - Preset frequency
 - Area for indicating station, selection of overlapped stations
 - <CD>
 - Program status
 - <Sound quality>
 - Volume balance memory set values
 - Equalizer memory set values
 - <Image quality>
 - Brightness of light when ON/OFF
 - Dimming switching
 - Display color switching
- Replace the Display unit after disconnecting both battery cables.

LCD DISPLAY

Component Parts and Harness Connector and Harness Connector Location


EKS00408



LCD DISPLAY

Schematic

EKS004SQ



A
B
C
D
E
F
G
H
I
J
DI
L
M




MKWA0391E

LCD DISPLAY

Wiring Diagram — COMM —



EKS0040A

DI-COMM-03



REFER TO THE FOLLOWING.







M1, M2 - FUSE BLOCK-
JUNCTION BOX (J/B)



MKWA0351E

LCD DISPLAY

DI-COMM-04




MKWA0392E

LCD DISPLAY

DI-COMM-05

- L : LHD MODELS *1 41 : L *3 42 : L
R : RHD MODELS 28 : R 29 : R
 *2 40 : L *4 34 : L
 27 : R 47 : R



| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 52 | 51 | 50 | 49 | 48 | 47 | 46 | 45 | 44 | 43 | 42 | 41 | 40 |
| 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 |

(M37)
Y

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|---|---|---|---|
| 24 | 22 | 20 | 18 | 16 | 14 | 12 | 11 | 10 | 8 | 6 | 4 | 2 |
| 23 | 21 | 19 | 17 | 15 | 13 | 12 | 11 | 9 | 7 | 5 | 3 | 1 |

(M61)
BR

| | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |





(M75)
GY

MKWA0352E

LCD DISPLAY

Terminals and Reference Value for Display Unit

EKS0040D

| TERMINALS | | | SIGNAL | CONDITION | | VOLTAGE | |
|-----------|------------|--------|------------------------------|-----------------|--------------------------|--|-----------------|
| (+) | | (-) | | IGNITION SWITCH | OPERATION | | |
| TERMINAL | WIRE COLOR | | | | | | |
| 1 | B | Ground | — | — | — | — | |
| 2 | Y | Ground | Battery power | OFF | — | Battery voltage | |
| 3 | B | Ground | — | — | — | — | |
| 4 | Y | Ground | Battery power | OFF | — | Battery voltage | |
| 5 | Y/G | Ground | Ignition signal | ON | — | — | |
| 6 | P | Ground | ACC signal | ACC | — | — | |
| 8 | LG | Ground | Illumination control signal | ON | Lighting switch position | 1st or 2nd | Battery voltage |
| | | | | | | OFF | 0V |
| 16 | R | Ground | Communication signal (AV-ME) | ON | — |  <p>SKIA0169E</p> | |
| 17 | — | — | Shield ground | — | — | — | |
| 18 | G | Ground | Communication signal (ME-AV) | ON | — |  <p>SKIA0170E</p> | |
| 19 | L | Ground | Communication signal (-) | ON | — |  <p>SKIA0176E</p> | |
| 20 | B/W | Ground | Communication signal (+) | ON | — |  <p>SKIA0175E</p> | |
| 21 | — | Ground | Shield ground | — | — | — | |





A
B
C
D
E
F
G
H
I
J
L
M

DI

LCD DISPLAY

Terminals and Reference Value for Multifunction Switch

EKS0040E

| TERMINALS | | | SIGNAL | CONDITION | | DATA |
|-----------|------------|--------|--------------------------|-----------------|-----------|--|
| (+) | | (-) | | IGNITION SWITCH | OPERATION | |
| TERMINAL | WIRE COLOR | | | | | |
| 6 | L/OR | Ground | ACC | ACC | — | Battery voltage |
| 1 | B | Ground | Ground | ON | — | Approx. 0V |
| 11 | R | Ground | Communication signal (+) | ON | — |  SKIA0175E |
| 12 | R | Ground | Communication signal (+) | ON | — |  SKIA0175E |
| 13 | L | Ground | Communication signal (-) | ON | — |  SKIA0176E |
| 14 | L | Ground | Communication signal (-) | ON | — |  SKIA0176E |
| 15 | — | Ground | Shield ground | ON | — | — |
| 16 | — | Ground | Shield ground | ON | — | — |

On Board Self-Diagnosis Function DESCRIPTION

EKS0040F

- Diagnosis function consists of the self-diagnosis mode performed automatically and the CONFIRMATION/ADJUSTMENT mode operated manually.
- Self-diagnosis mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- CONFIRMATION/ADJUSTMENT mode is used to perform trouble diagnosis that require operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value.

LCD DISPLAY



DIAGNOSIS ITEM

| Mode | | Description | Reference page | |
|-------------------------|----------------------|--|--|---|
| Self-diagnosis | | <ul style="list-style-type: none"> Center control unit (display unit) diagnosis. Analyzes connection between the display unit and each unit, and operation of each unit. | DI-77, "Self-Diagnosis Mode" | |
| CONFIRMATION/ADJUSTMENT | Display Diagnosis | Display Color Spectrum Bar | Color of display can be checked in this mode. | |
| | | Display Gradation Bar | Gray gradation of display can be checked in this mode. | |
| | Vehicle Signals | Vehicle Speed | Vehicle speed input signal to center control unit (display unit), can be monitored in this mode. | DI-81, "VEHICLE SIGNALS" |
| | | Light | Light input signal to center control unit (display unit), can be monitored in this mode. | |
| | | IGN | Ignition input signal to center control unit (display unit), can be monitored in this mode. | |
| | Auto Climate Control | | Trouble diagnosis for auto climate control unit (A/C auto amp), can be checked in this mode. | ATC-42, "FUNCTION CONFIRMATION PROCEDURE" |
| Service | | Service schedule can be changed in this mode | DI-81, "SERVICE" | |

Self-Diagnosis Mode OPERATION PROCEDURES


EKS0040G

- Start the engine.
- Turn the audio system off.
- While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
 - Shifting from current screen to previous screen is performed by pressing "PREV" switch.
- The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.




LCD DISPLAY

- Perform self-diagnosis by selecting the "SELF-DIAGNOSIS".
 - Self-diagnosis subdivision screen will be shown and the operation enters the self-diagnosis mode.
 - A bar graph shown below the self-diagnosis subdivision screen indicates progress of the diagnosis.



- When the self-diagnosis completes, optional part confirmation screen will be shown.
 - When connection of an optional part is judged malfunction, a screen to check if the optional part is fitted on the vehicle or not will be shown. When fitted, select the switch of the part on the screen and press "END". Then the "Self-diagnosis" screen will be shown.
 - When the optional part is connected normally, the switch for the part will not appear on the screen.




- On the "Self-diagnosis" screen, each unit name will be colored according to the diagnosis result, as follows.

Green : No malfunctioning.


Yellow : Cannot be judged by self-diagnosis results.

Red : Unit is malfunctioning.

- If several malfunctions are present in a unit, color of its switch on the screen will be either red, yellow, or gray, determined by the malfunction of the highest priority.



- Select a switch on the "Self-diagnosis" screen and comments for the diagnosis results will be shown.
 - When the switch is green, the following comment will be shown. "Self-diagnosis was successful. Further diagnosis and adjustments are recommended. Follow the "confirmation and adjustments" menu or refer to the service manual."
 - When the switch is yellow, the following comment will be shown. "Connection to the following unit is abnormal. See the service manual for further details."
 - When the switch is red, the following comment will be shown. "Center Control Unit is abnormal."



CAUTION:

If self-diagnosis cannot be activated, refer to [DI-88. "Self-Diagnosis Does Not Perform"](#).

SELF-DIAGNOSIS RESULT

Quick reference table

- Select an applicable diagnosis No. in the diagnosis result quick reference table.
- Find estimated malfunctioning system in the diagnosis No. table and perform check by referring to the AV communication line circuit diagram.
- Turn the ignition switch to OFF and perform self-diagnosis again.

LCD DISPLAY

| Screen switch | | | | | Diagnosis No. |
|---------------|-----------------------|----------------------|------------|-----------------|---------------|
| Switch color | Center control unit * | Multifunction switch | Audio unit | CD auto changer | |
| Red | × | | | | 1 |
| Yellow | × | × | | | 2 |
| | × | | × | × | 3 |
| | × | | | × | 4 |
| | × | × | × | × | 5 |

*: Center control unit = Display unit

CAUTION:

When an error is in the AV communication line, it cannot be detected on the screen because self-diagnosis is inoperative. However, the error can be detected with CONSULT-II.


SELF-DIAGNOSIS CODES

| Diagnosis No. | Possible cause | Reference page |
|---------------|---|---|
| 1 | Display unit malfunction. | - |
| 2 | Multifunction switch power supply and ground circuit. | DI-82, "Power Supply and Ground Circuit Check for Multifunction Switch" |
| 3 | Audio unit power supply and ground circuit. AV communication line between multifunction switch and the display unit. Audio unit internal communication circuit. | <ul style="list-style-type: none"> ● AV-41, "Power Supply Circuit Inspection" ● DI-86, "Audio Circuit Check" |
| 4 | CD auto changer power supply and ground circuit. AV communication line between CD auto changer and audio unit. | <ul style="list-style-type: none"> ● AV-41, "Power Supply Circuit Inspection" ● DI-86, "CD Changer Circuit Check" |
| 5 | AV communication line circuit malfunction. | DI-87, "AV Communication Line Check" |

CONFIRMATION/ADJUSTMENT Mode OPERATION PROCEDURE


EKS0040H

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "INFO" switch, turn the volume control dial clockwise or counterclockwise for 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)
 - Shifting from current screen to previous screen is performed by pressing "PREV" switch.




LCD DISPLAY

- The initial trouble diagnosis screen will be shown, and items "SELF-DIAGNOSIS" and "CONFIRMATION/ADJUSTMENT" will become selective.




- When "CONFIRMATION/ADJUSTMENT" is selected on the initial trouble diagnosis screen, the operation will enter the CONFIRMATION/ADJUSTMENT mode. In this mode, check and adjustment of each item will become possible.
- Select each switch on "CONFIRMATION/ADJUSTMENT" screen to display the relevant diagnosis screen.



DISPLAY DIAGNOSIS

Use this mode to check the display color brightness and setting. The display unit must be replaced if the color brightness and shading are unusual.




CAUTION:

When Display Color Spectrum Bar screen is completed after "BACK" switch is pressed, the screen color changes once. This is normal.

LCD DISPLAY

VEHICLE SIGNALS

- In this mode, following input signals to the display unit can be checked on the display.



| Diagnosis item | Display | Condition | Remarks |
|----------------|---------|---|--|
| Vehicle speed | ON | Vehicle speed is greater than 0 km/h (0 MPH) | Changes in indication may be delayed by approx. 1.5 seconds. This is normal. |
| | OFF | Vehicle speed is 0 km / (0 MPH) | |
| | - | Ignition switch is in "ACC" position. | |
| Light | ON | Lighting switch is 1st or 2nd position. | - |
| | OFF | Lighting switch is "OFF" position. | |
| IGN | ON | Ignition switch is in "ON" position. | - |
| | OFF | Ignition switch is in "ACC" or "OFF" position | |


- If vehicle speed is NG, refer to [DI-83, "Vehicle Speed Signal Check/LHD Models"](#) or [DI-84, "Vehicle Speed Signal Check/RHD Models"](#).
- If light is NG, refer to [DI-85, "Illumination Control Signal Check"](#).
- If IGN is NG, refer to [DI-85, "Ignition Signal Check"](#).

SERVICE

- In this mode, Service schedule can be set on this display.

NOTE:

- To set Service schedule, change journey distance.
- When the indicator of "Service Information Display" is set green, the color of the journey distance marker will be red. And automatically Service information screen will be displayed when journey distance is reached on service schedule.



Power Supply and Ground Circuit Check for Display Unit

EKS0040P

1. CHECK FUSE

- Check that the following fuses in display are blown.

| Unit | Power source | Fuse No. |
|---------|---------------------------|----------|
| Display | Battery power | 33 |
| | Ignition switch ACC or ON | 1 |

OK or NG

OK >> GO TO 2.


NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3, "POWER SUPPLY ROUTING"](#).

LCD DISPLAY

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect display connector.
2. Check voltage between display unit connector and ground.

| Terminals | | Ignition switch position | | | |
|-----------|-----------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (Wire color) | | | | |
| M61 | 2 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 4 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 6 (P) | Ground | 0V | Battery voltage | Battery voltage |




OK or NG

- OK >> GO TO 3.
 NG >> Check harness for open or short between display and fuse.

3. GROUND CIRCUIT CHECK

Check continuity between display unit and ground.

| Terminals | | (-) | Continuity |
|-----------|-----------------------|--------|------------|
| (+) | | | |
| Connector | Terminal (wire color) | | |
| M61 | 1 (B) | Ground | Yes |
| | 3 (B) | Ground | Yes |



OK or NG

- OK >> Inspection end.
 NG >> Check ground harness.

Power Supply and Ground Circuit Check for Multifunction Switch

EKS00400

1. CHECK FUSES.

- Check the fuse below.

| Unit | Power source | Fuse No. |
|----------------------|---------------------------|----------|
| Multifunction switch | Ignition switch ACC or ON | 1 |

OK or NG

- OK >> GO TO 2.
 NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3](#), "[POWER SUPPLY ROUTING](#)".

LCD DISPLAY

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect multifunction switch connector.
2. Check voltage between multifunction switch and ground.

| Terminals | | Ignition switch position | | | |
|-----------|--------------------------|--------------------------|-----|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (Wire color) | | | | |
| M49 | 6 (P) | Ground | 0V | Battery voltage | Battery voltage |

OK or NG

OK >> GO TO 3.

NG >> Check harness for open or short between multifunction switch and fuse.



3. GROUND CIRCUIT CHECK


1. Check continuity between multifunction switch harness connector M49 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Inspection end.

NG >> Check ground harness.



Vehicle Speed Signal Check/LHD Models

1. HARNESS CHECK

1. Disconnect display unit connector and combination meter.
2. Check the following.
 - Continuity between display unit connector M61 terminal 19 (L/B) and combination meter connector M37 terminal 34 (L/B).

Continuity should exist.


- Continuity between display unit connector M61 terminal 19 (L/B) and ground.

Continuity should not exist.

OK or NG

OK >> GO TO 2.

NG >> Replace harness or connector.



LCD DISPLAY

2. VEHICLE SPEED SIGNAL CHECK

Connect combination meter connector and display unit connector.

Ⓜ With CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check signal between display unit connector M61 terminal 19(L/B) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)


ⓧ Without CONSULT -II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check voltage between display unit connector M61 terminal 19(L/B) and ground when rotating wheels with engine at idle.

Voltage: Approximately 0 – 5V

OK or NG

- OK >> Replace display unit.
NG >> Check combination meter system. Refer to [DI-24, "Combination Meter Self-Diagnosis"](#).



EKS004TW

Vehicle Speed Signal Check/RHD Models

1. HARNESS CHECK

1. Disconnect display unit connector and combination meter.
2. Check the following.
 - Continuity between display unit connector M61 terminal 19 (L/B) and combination meter connector M37 terminal 47 (L/B)


Continuity should exist.

- Continuity between display unit connector M61 terminal 19 (L/B) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 2.
NG >> Replace harness or connector.



LCD DISPLAY

2. VEHICLE SPEED SIGNAL CHECK

Connect combination meter connector and display unit connector.

Ⓟ With CONSULT-II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check signal between display unit connector M61 terminal 19(L/B) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)


ⓧ Without CONSULT -II

1. Lift up drive wheels.
2. Start engine and drive vehicle at more than 20 km/h (12MPH).
3. Check voltage between display unit connector M61 terminal 19(L/B) and ground when rotating wheels with engine at idle.

Voltage: Approximately 0 – 5V

OK or NG

- OK >> Replace display unit.
 NG >> Check combination meter system. Refer to [DI-53, "Combination Meter Self-Diagnosis"](#) .



EKS0040T

Illumination Control Signal Check


1. ILLUMINATION CONTROL SIGNAL CHECK

1. Turn ignition switch ON.
2. Check voltage between display unit and ground.

| Terminals | | Condition | Voltage (V) |
|-----------|-----------------------|-------------------------------------|-----------------|
| (+) | (-) | | |
| Connector | Terminal (wire color) | | |
| M61 | 8 (R/L) | Lighting switch 1st or 2nd position | Battery voltage |
| | | OFF | Approx.0 |

OK or NG

- OK >> Replace display unit.
 NG >> Check harness for open or short between display unit and lighting switch.



EKS0040U

Ignition Signal Check


1. IGNITION SIGNAL CHECK

1. Disconnect the display unit connector.
2. Check voltage between display unit harness connector M61 terminal 5 (Y/G) and ground.

Battery voltage should exist.

OK or NG

- OK >> Replace display unit.
 NG >> Check harness for open or short between display unit and fuse.



LCD DISPLAY

EKS004TX

Audio Circuit Check

1. AUDIO UNIT CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect audio unit connector.
3. Check continuity between multifunction switch and audio unit.


| Terminals | | | | Continuity |
|----------------------|-----------------------|------------|-----------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |

4. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

Question

- OK >> Replace audio unit.
 NG >> Replace harness or connector.



CD Changer Circuit Check

EKS004TY

1. CD CHANGER CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.


| Terminals | | | | Continuity |
|----------------------|-----------------------|-----------------|-----------------------|------------|
| Multifunction switch | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R) | B31 | 28 (R) | Yes |
| | 21 (W) | | 29 (W) | |
| | 22 (B) | | 30 (B) | |

3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 20 (R) | Ground | No |
| | 21 (W) | | |
| | 22 (B) | | |

Question

- OK >> Replace CD auto changer.
 NG >> Replace harness or connector.



LCD DISPLAY

EKS004SM

AV Communication Line Check

1. MULTIFUNCTION SWITCH CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect display unit connector and multifunction switch connector.
3. Check continuity between display unit and multifunction switch.

| Terminals | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M61 | 19 (L) | M49 | 14 (L) | Yes |
| | 20 (B/W) | | 12 (B/W) | |

4. Check continuity between display unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M61 | 19 (L) | Ground | No |
| | 20 (B/W) | | |

OK or NG

- OK >> GO TO 2.
 NG >> Replace harness or connector

2. AUDIO UNIT CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect audio unit connector.
3. Check continuity between multifunction switch and audio unit.



| Terminals | | | | Continuity |
|----------------------|-----------------------|------------|-----------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |

4. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

Question

- OK >> GO TO 3.
 NG >> Replace harness or connector.




A
B
C
D
E
F
G
H
I
J
DI
L
M

LCD DISPLAY

3. CD CHANGER CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.

| Terminals | | | | Continuity |
|----------------------|-----------------------|-----------------|-----------------------|------------|
| Multifunction switch | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R) | B31 | 28 (R) | Yes |
| | 21 (W) | | 29 (W) | |
| | 22 (B) | | 30 (B) | |



3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 20 (R) | Ground | No |
| | 21 (W) | | |
| | 22 (B) | | |

Question

- OK >> Replace display unit.
 NG >> Replace harness or connector.

Self-Diagnosis Does Not Perform

EKS00450

1. MULTIFUNCTION SWITCH CHECK

Check multifunction switch power and ground circuit. Refer to [DI-82, "Power Supply and Ground Circuit Check for Multifunction Switch"](#).

>> GO TO 2.

2. DISPLAY UNIT CHECK

Check display unit power and ground circuit. Refer to [DI-81, "Power Supply and Ground Circuit Check for Display Unit"](#).

>> GO TO 3.

3. SELF-DIAGNOSIS CHECK

1. Disconnect audio unit connector M53.
2. Perform self-diagnosis mode.

Self-diagnosis activated

- OK >> GO TO 4.
 NG >> AV communication line check. Refer to [DI-87, "AV Communication Line Check"](#).

LCD DISPLAY

4. MULTIFUNCTION SWITCH CIRCUIT CHECK

1. Disconnect multifunction switch connector.
2. Check continuity between multifunction switch and audio unit.


| Terminals | | | | Continuity |
|----------------------|-----------------------|------------|-----------------------|------------|
| Multifunction switch | | Audio unit | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M49 | 11 (L) | M53 | 44 (L) | Yes |
| | 13 (P) | | 43 (P) | |

3. Check continuity between multifunction switch and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M49 | 11 (L) | Ground | No |
| | 13 (P) | | |

OK or NG

- OK >> GO TO 5.
 NG >> Replace harness or connector.



5. AUDIO UNIT CIRCUIT CHECK

1. Disconnect CD auto changer connector.
2. Check continuity between audio unit and CD auto changer.

| Terminals | | | | Continuity |
|----------------------|-----------------------|-----------------|-----------------------|------------|
| Multifunction switch | | CD auto changer | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M52 | 20 (R) | B31 | 28 (R) | Yes |
| | 21 (W) | | 29 (W) | |
| | 22 (B) | | 30 (B) | |

3. Check continuity between audio unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (Wire color) | Terminal | |
| M52 | 20 (R) | Ground | No |
| | 21 (W) | | |
| | 22 (B) | | |

OK or NG


- OK >> Inspection end.
 NG >> Replace harness or connector.

RGB Screen Is Not Shown

Replace display unit.

Color of RGB Image Is Not Proper

Replace display unit.



EKS0040V

EKS0040W

LCD DISPLAY

EKS0040X

RGB Screen Is Rolling

Replace display unit.


Air Conditioning Controls (Only) Are Ineffective (Rear Defogger Control Excluded).

EKS004TF

1. A/C AUTO AMP. AND DISPLAY UNIT CIRCUIT CHECK


1. Turn the ignition switch OFF.
2. Disconnect A/C auto amp. connector and display unit connector.
3. Check continuity between display unit and A/C auto amp.

| Terminals | | | | Continuity |
|------------------|-----------------------|-------------------|-----------------------|------------|
| Display unit (+) | | A/C auto amp. (-) | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 13 (L) | M75 | 20 (L) | YES |
| | 14 (L/R) | | 10 (L/R) | |
| | 15 (L/W) | | 9 (L/W) | |



4. Check continuity between display unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|--------|------------|
| Connector | Terminal (wire color) | (-) | |
| M61 | 13 (L) | Ground | NO |
| | 14 (L/R) | | |
| | 15 (L/W) | | |




Ok or NG

- OK >> GO TO 2.
 NG >> Replace harness or connector.

2. A/C-AV, AV-AC, AC-CLK COMMUNICATION SIGNAL CHECK

1. Connect A/C auto amp. connector.
2. Turn the ignition switch ON.
3. Check voltage between display unit and ground.

| Terminals | | | Voltage (V) |
|---------------------------|-----------------------|--------|---------------------|
| (+) Terminal (wire color) | | (-) | |
| Connector | Terminal (wire color) | | |
| M61 | 13 (L) | Ground | Approx. 3.5 or more |
| | 14 (L/R) | | |
| | 15 (L/W) | | |



OK or NG

- OK >> GO TO 3.
 NG >> Replace A/C auto amp.

LCD DISPLAY

3. A/C- AV, AV- AC, AC- CLK COMMUNICATION SIGNAL CHECK

1. Connect display unit connector.
2. Turn the ignition switch ON.
3. Check voltage between display unit and ground.


| Terminals | | Reference signal |
|-----------|-----------------------|------------------|
| (+) | | |
| Connector | Terminal (wire color) | (-) |
| M61 | 13 (L) | Ground |
| | 14 (L/R) | |
| | 15 (L/W) | |

DI-75, "Terminals and Reference Value for Display Unit"

OK or NG

OK >> Replace A/C auto amp.

NG >> Replace display unit.



No Fuel Information Is Displayed/No Warning Message Is Displayed/LHD Models


EKS0040Y

1. COMMUNICATION LINE (MA-AV, AV-ME) CIRCUIT CHECK

1. Disconnect the Display unit connector and combination meter connector.
2. Check continuity between display unit and ground.

| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (wire color) | Terminal | |
| M61 | 16 (R) | Ground | No |
| | 18 (G) | | |

3. Check continuity between display unit and combination meter.



| Terminals | | | | Continuity |
|--------------|-----------------------|-------------------|-----------------------|------------|
| Display unit | | Combination meter | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 16 (R) | M37 | 41 (R) | Yes |
| | 18 (G) | | 40 (G) | |

OK or NG



OK >> GO TO 2.

NG >> Replace harness or connector.

LCD DISPLAY

2. COMMUNICATION SIGNAL (AV-ME) CHECK

1. Connect display unit connector and combination meter connector.
2. Turn ignition switch ON.
3. Check voltage signal between display unit terminal 16 (R) and ground.





OK or NG

- OK >> GO TO 3.
NG >> Replace display unit.

3. COMMUNICATION SIGNAL (ME-AV) CHECK

1. Turn ignition switch to ON and display.
2. Check voltage signal between display unit connector terminal 18 (L) and ground.



OK or NG

- OK >> Replace display unit.
NG >> Replace combination meter.

LCD DISPLAY

No Fuel Information Is Displayed/No Warning Message Is Displayed/RHD Models

EKS004SP

1. COMMUNICATION LINE (MA-AV, AV-ME) CIRCUIT CHECK

1. Disconnect the Display unit connector and combination meter connector.
2. Check continuity between display unit and ground.


| Terminals | | | Continuity |
|-----------|-----------------------|----------|------------|
| Connector | Terminal (wire color) | Terminal | |
| M61 | 16 (R) | Ground | No |
| | 18 (G) | | |

3. Check continuity between display unit and combination meter.

| Terminals | | | | Continuity |
|--------------|-----------------------|-------------------|-----------------------|------------|
| Display unit | | Combination meter | | |
| Connector | Terminal (wire color) | Connector | Terminal (wire color) | |
| M61 | 16 (R) | M37 | 28 (R) | Yes |
| | 18 (G) | | 27 (G) | |


OK or NG

- OK >> GO TO 2.
 NG >> Replace harness or connector.



2. COMMUNICATION SIGNAL (AV-ME) CHECK


1. Connect display unit connector and combination meter connector.
2. Turn ignition switch ON.
3. Check voltage signal between display unit terminal 16 (R) and ground.



SKIA0169E

OK or NG



- OK >> GO TO 3.
 NG >> Replace display unit.



LCD DISPLAY

3. COMMUNICATION SIGNAL (ME-AV) CHECK

1. Turn ignition switch to ON and display.
2. Check voltage signal between display unit connector terminal 18 (L) and ground.



OK or NG

- OK >> Replace display unit.
- NG >> Replace combination meter.

Multifunction Switch Does Not Operate.

EKS004P0

1. POWER AND GROUND CIRCUIT CHECK

- Check power and ground circuit. Refer to [DI-76, "Terminals and Reference Value for Multifunction Switch"](#)


OK or NG

- OK >> Replace multifunction switch.
- NG >> Repair or replace harness.

Removal and Installation of Multifunction switch

EKS004T3


1. Remove the cluster lid C. Refer to [IP-6, "CLUSTER LID C"](#).
2. Remove the screw (4), and remove the multifunction switch.



Removal and Installation of Display

EKS004P2

1. Remove the cluster lid C. Refer to [IP-6, "CLUSTER LID C"](#).
2. Remove the screws (2), and remove the display.




WARNING LAMPS

WARNING LAMPS

PFP:24814

Schematic

EKS003XH



MKWA0177E


A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING LAMPS



Wiring Diagram — WARN —/LHD Models

EKS003X1

DI-WARN-01



1 2 M28 E7
B



REFER TO THE FOLLOWING.
 M1, M2 - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0178E



WARNING LAMPS

DI-WARN-02

⬡ : WITH GASOLINE ENGINE
 ⬢ : WITH DIESEL ENGINE

*1 1 : ⬡
 7 : ⬢

A
B
C
D
E
F
G
H
I
J
K
L
M








MKWA0179E

WARNING LAMPS

DI-WARN-03

⬡ : WITH A/T
 ⬢ : WITH CVT





MKWA0180E

WARNING LAMPS

DI-WARN-04

DATA LINE




MKWA0181E

WARNING LAMPS



Wiring Diagram — WARN — /RHD Models

EKS003XJ

DI-WARN-05



1 2 M28 E7
B



REFER TO THE FOLLOWING.



M1, M2 - FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0182E

WARNING LAMPS

DI-WARN-07

⬡ A : WITH A/T
 ⬡ C : WITH CVT








MKWA0184E

WARNING LAMPS

DI-WARN-08

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
DI
L
M


WARNING LAMPS

Electrical Components Inspection OIL PRESSURE SWITCH CHECK

EKS003XK

| | Oil pressure kPa (bar, kg/cm ² , psi) | Continuity |
|--------------------|---|------------|
| Engine running | More than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3) | No |
| Engine not running | Less than 10 - 20 (0.10 - 0.20, 0.1 - 0.2, 1 - 3) | Yes |

Check the continuity between the terminals of oil pressure switch and body ground.




A/T INDICATOR

PFP:24814

A/T INDICATOR


Wiring Diagram — AT/IND —

EKS003XL



DI-AT/IND-01

- : DATA LINE
- ⬡ : LHD MODELS
- ⬢ : RHD MODELS
- *1 52 : ⬡
- 39 : ⬢
- *2 51 : ⬡
- 38 : ⬢
- *3 24 : ⬡
- 11 : ⬢
- *4 45 : ⬡
- 32 : ⬢
- *5 25 : ⬡
- 12 : ⬢
- *6 44 : ⬡
- 31 : ⬢
- *7 43 : ⬡
- 30 : ⬢



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0186E

A/T INDICATOR

SYMPTOM CHART

| Symptom | | Possible cause |
|---------------------------------------|--|---|
| A/T indicator lamp is malfunctioning. | All the lamps inactive Partially inactive | A/T indicator does not illuminate. Shown the below. |
| | Segment is missing | <ul style="list-style-type: none">● Combination meter self-diagnosis mode. Refer to DI-24, "Combination Meter Self-Diagnosis" (LHD models) or DI-53, "Combination Meter Self-Diagnosis" (RHD models).● Check the connector conditions in combination meter. If the above system is OK, replace unified meter control unit. |

1. TCM CONTROL UNIT SYSTEM INSPECTION

Perform TCM self-diagnosis. Refer to in AT section.

OK or NG?

OK >> GO TO 2.

NG >> GO to TCM trouble diagnosis.

2. SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis mode. Refer to [DI-24, "Combination Meter Self-Diagnosis"](#) (LHD models) or [DI-53, "Combination Meter Self-Diagnosis"](#) (RHD models).

OK or NG?

OK >> A/T indicator is OK.

NG >> Replace combination meter control unit assembly.

WARNING CHIME

WARNING CHIME

PFP:24814

System Description

EKS004MQ

POWER SUPPLY AND GROUND CIRCUIT

Power is supplied at all times

- through 10A fuse (No. 32, located in fuse and fusible link box)
- to combination switch terminal 11, and
- to daytime light control unit terminal 1 (with daytime light control unit).
- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to key switch terminal 1 and
- to smart entrance control unit terminal 5.

With ignition switch in ON or START position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 29.

Ground is supplied

- to smart entrance control unit terminal 53
- through body grounds M16, M50 and M70.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

IGNITION KEY WARNING CHIME

With the key in the ignition key cylinder, the ignition switch in OFF or ACC position, and the driver's door open, the warning chime will sound. Power is supplied

- through key switch terminal 2
- to smart entrance control unit terminal 5.

Ground is supplied

- from front door switch (driver side) terminal 1
- to smart entrance control unit terminal 43.

Ground is supplied through the case of the front door switch (driver side).

LIGHT WARNING CHIME

With ignition switch OFF position, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied

- from the lighting switch terminal 12 or daytime light control unit terminal 10 (with daytime light system)
- to smart entrance control unit terminal 17.

Ground is supplied

- from front door switch (driver side) terminal 1
- to smart entrance control unit terminal 43.

Ground is supplied through the case of the front door switch (driver side).

SEAT BELT WARNING CHIME

Driver side

When the vehicle speed exceeds 25 km/h (16 MPH) with front driver side seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 90 seconds.

If the seat belt are fastened, then unfastened again, warning chime will sound.

Ground is supplied:

- from seat belt buckle switch (driver side) terminal 1
- to combination meter terminal 8 (LHD models) or 21 (RHD models).

Seat belt buckle switch (driver side) terminal 2 is grounded through body grounds B17, B24 and D94.

Passenger side


When the person is sitting on the passenger side seat, warning chime will sound in case of the same condition as the driver side.

A
B
C
D
E
F
G
H
I
J
DI
L
M

WARNING CHIME

Component Parts and Harness Connector Location

EKS003XN





MKIB0050E

WARNING CHIME

Wiring Diagram — CHIME — LHD MODELS

EKS004R8

DI-CHIME-01






REFER TO THE FOLLOWING.
 (M1), (M2), (E106) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0187E

WARNING CHIME

DI-CHIME-02

▬ : DATA LINE
 ◻ W : WAGON




MKWA0188E




WARNING CHIME

RHD MODELS

DI-CHIME-03



A
B
C
D
E
F
G
H
I
J
DI
L
M



REFER TO THE FOLLOWING.

(M1), (M2), (E106) - FUSE BLOCK-
JUNCTION BOX (J/B)





MKWA0189E

WARNING CHIME

DI-CHIME-04

: DATA LINE
 : WAGON



MKWA0190E

WARNING CHIME

CONSULT-II Inspection Procedure

EKS004R9


CONSULT-II executes the following functions by combining data reception and command transmission via the communication line from smart entrance control unit. CAN communication inspection and data monitor display.

DIAGNOSTIC ITEMS DESCRIPTION


| SMART ENTRANCE diagnosis position | Diagnosis mode | Description |
|-----------------------------------|----------------|---|
| KEY REMINDER | Data monitor | The input data to the SMART ENTRANCE control units is displayed in real time. |
| LIGHT ON REMINDER | Data monitor | The input data to the SMART ENTRANCE control units is displayed in real time. |
| SMART ENTRANCE PART NUMBER | | Displays SMART ENTRANCE part No. |

CONSULT-II BASIC OPERATION PROCEDURE


1. With the ignition switch OFF, connect CONSULT-II to the data link connector, and turn the ignition switch ON.



2. Touch "START".



3. Touch "SMART ENTRANCE".



4. Select the desired part to be diagnosed on the "SELECT TEST ITEM" screen.

WARNING CHIME

Data monitor item (KEY REMINDER)

| Monitored item | Description |
|----------------|---|
| IGNITION SW | Indicates [ON/OFF] condition of ignition switch. |
| KEY IN DETECT | Indicates [ON/OFF] condition of electronic key switch. |
| DR DOOR SW | Indicates [ON/OFF] condition of front door switch (driver side). |
| CDL LOCK SW | Indicates [ON/OFF] condition of door lock/unlock switch. |
| RKE LOCK | Indicates [ON/OFF] condition of lock signal from remote controller. |

Data monitor item (Light warning chime)

| Monitored item | Description |
|----------------|--|
| IGN ON SW | Indicates [ON/OFF] condition of ignition switch. |
| DR DOOR SW | Indicates [ON/OFF] condition of front door switch (driver side). |
| TAIL LAMP ON | Indicates [ON/OFF] condition of lighting switch. |

Symptom Chart

EKS004MS

First perform the "SELF-DIAG RESULTS" in "SMART ENTRANCE" with CONSULT-II, when perform the each trouble diagnosis.

| Symptom | Diagnoses/Service procedure | Reference page |
|---|--|--|
| Light warning chime does not activate. | <ul style="list-style-type: none"> ● Power supply and ground circuit check | DI-115, "Power Supply and Ground Circuit Check" |
| | <ul style="list-style-type: none"> ● Lighting switch check | DI-116, "Lighting Switch Input Signal Check" |
| | <ul style="list-style-type: none"> ● Front door switch (driver side) check | DI-119, "Front Door Switch (Driver side) Check" |
| Key warning chime does not activate. | <ul style="list-style-type: none"> ● Power supply and ground circuit check | DI-115, "Power Supply and Ground Circuit Check" |
| | <ul style="list-style-type: none"> ● Key switch insert signal check | DI-118, "Key Switch Insert Signal Check" |
| | <ul style="list-style-type: none"> ● Front door switch (driver side) check | DI-119, "Front Door Switch (Driver side) Check" |
| Seat belt chime does not activate. | <ul style="list-style-type: none"> ● Power supply and ground circuit check | DI-115, "Power Supply and Ground Circuit Check" |
| | <ul style="list-style-type: none"> ● Seat belt buckle switch (driver side) check | DI-120, "Seat Belt Buckle Switch Check (Driver side)" |
| | <ul style="list-style-type: none"> ● Seat belt buckle switch (passenger side) check | DI-123, "Seat Belt Buckle Switch Check (Passenger Side)" |
| All warning chimes do not activate. | <ul style="list-style-type: none"> ● Power supply and ground circuit check | DI-115, "Power Supply and Ground Circuit Check" |
| With the ignition switch turned OFF and the door closed (driver side) turning the lighting switch ON (1st) activates the chime. | <ul style="list-style-type: none"> ● Front door switch (driver side) check | DI-119, "Front Door Switch (Driver side) Check" |

WARNING CHIME

EKS004MT

Power Supply and Ground Circuit Check

1. POWER SUPPLY CIRCUIT CHECK

1. Disconnect smart entrance control unit connector.
2. Check the following.

| Terminals | | Ignition switch position | | | |
|-----------|--------------------------|--------------------------|-----------------|-----------------|-----------------|
| (+) | | (-) | OFF | ACC | ON |
| Connector | Terminal (Wire color) | | | | |
| M42 | 29 (Y/G) | Ground | 0V | 0V | Battery voltage |
| M43 | 56 (R/B) | Ground | Battery voltage | Battery voltage | Battery voltage |


OK or NG?

OK >> GO TO 2.

NG >> ● 10A fuse [NO. 10, located in fuse block (J/B)].

● 10A fuse [NO. 12, located in fuse block (J/B)].

● Check harness for open or short between smart entrance control unit and fuse.



2. GROUND CIRCUIT CHECK


Check continuity between smart entrance control unit harness connector M43 terminal 53 (B) and ground.

Continuity should exist.

OK or NG?

OK >> INSPECTION END.

NG >> Check ground harness.



WARNING CHIME

EKS004MU

Lighting Switch Input Signal Check

1. CHECK LIGHTING SWITCH INPUT SIGNAL

④ With CONSULT-II

Check lighting switch ("TAIL LAMP ON") in "DATA MONITOR" mode with CONSULT-II.

When lighting switch is in : TAIL LAMP ON ON
1st or 2nd position

When lighting switch is in : TAIL LAMP ON OFF
OFF position

| DATA MONITOR | |
|--------------|--------|
| MONITOR | NO DTC |
| IGNITION SW | ON |
| DR DOOR SW | OFF |
| TAIL LAMP ON | OFF |

MKIB0192E


⊗ Without CONSULT-II

Check voltage between smart entrance control unit harness connector M41 terminal 17 (R/G) and ground.

| Condition of switch | Voltage [V]: |
|-----------------------------|--------------|
| Lighting switch: 1st or 2nd | Approx. 12 |
| Lighting switch: OFF | 0 |

OK or NG?

OK >> Lighting switch is OK.
NG >> GO TO 2.




2. CHECK LIGHTING SWITCH POWER SUPPLY CIRCUIT FOR OPEN OR SHORT

1. Disconnect lighting switch harness connector.
2. Check voltage between lighting switch harness connector E115 terminal 11 (B/R) and ground.

Battery voltage should exist.

OK or NG?

- OK >> GO TO 3.
NG >> Check the following.
- 10A fuse (No. 32 located in the fuse and fusible link box)
 - Harness for open or short between lighting switch and fuse



WARNING CHIME

3. CHECK LIGHTING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

Check harness continuity between lighting switch harness connector E115 terminal 12 (W/R) and smart entrance control unit harness connector M41 terminal 17 (R/G).


Continuity should exist.

OK or NG?

OK >> GO TO 4.

NG >> Check the following.

- Harness for open or short between smart entrance control unit and lighting switch.
- Harness for open or short between smart entrance control unit and lighting switch/daytime light control unit (with daytime light control unit).



4. CHECK LIGHTING SWITCH (DRIVER SIDE)


Check continuity between lighting switch harness connector E115 terminals 11 and 12.

| Terminals | | | Condition | Continuity |
|--------------|----------|--------------|---------------------|------------|
| (+) Terminal | | (-) Terminal | | |
| Connector | Terminal | Terminal | | |
| E115 | 11 | 12 | OFF position | No |
| | | | 1st or 2nd position | Yes |

OK or NG?

OK >> Lighting switch is OK.

NG >> Replace lighting switch.



A
B
C
D
E
F
G
H
I
J
L
M

DI

WARNING CHIME

EKS004MV

Key Switch Insert Signal Check

1. CHECK KEY SWITCH INPUT SIGNAL

With CONSULT-II

Check key switch ("KEY IN DETECT") in "DATA MONITOR" mode with CONSULT-II.

When key is inserted to ignition key cylinder : KEY IN DETECT ON

When key is removed from ignition key cylinder : KEY IN DETECT OFF

| DATA MONITOR | |
|---------------|--------|
| MONITOR | NO DTC |
| IGNITION SW | ON |
| KEY IN DETECT | ON |
| DR DOOR SW | ON |
| CDL LOCK SW | OFF |
| RKE LOCK | OFF |

MKIB0193E


Without CONSULT-II

Check voltage between smart entrance control unit harness connector M41 terminal 5 (B/L) and ground.

Condition of key switch Voltage [V]

When key is inserted to ignition key cylinder: Approx. 12

When key is removed from ignition key cylinder: 0



OK or NG?

- OK >> Key switch is OK.
- NG >> GO TO 2.


2. CHECK KEY SWITCH POWER SUPPLY CIRCUIT FOR OPEN OR SHORT

1. Disconnect key switch harness connector.
2. Check voltage between key switch harness connector M30 terminal 1 (R/B) and ground.

Battery voltage should exist.

OK or NG?

- OK >> GO TO 3.
- NG >> Check the following.
 - 10A fuse [No. 32 located in fuse block (J/B)]
 - Harness for open or short between key switch and fuse




3. CHECK KEY SWITCH INPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

Check harness continuity between key switch harness connector M30 terminal 2 (B/R) and smart entrance control unit harness connector M41 terminal 5 (B/R).

Continuity should exist.

OK or NG?

- OK >> GO TO 4.
- NG >> Repair or replace harness.



WARNING CHIME


4. CHECK KEY SWITCH

Check continuity between key switch harness connector M30 terminals 1 and 2.

| Terminals | | | Condition | Continuity |
|-----------|----------|----------|-----------|------------|
| (+) | | (-) | | |
| Connector | Terminal | Terminal | | |
| M30 | 1 | 2 | Inserted | Yes |
| | | | Removed | No |

OK or NG?

- OK >> Key switch is OK.
- NG >> Replace key switch.



Front Door Switch (Driver side) Check

EKS004MW

1. CHECK FRONT DOOR SWITCH (DRIVER SIDE) INPUT SIGNAL

With CONSULT-II

- Check front door switch ("DR DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When driver's door is open : DR DOOR SW ON

When driver's door is closed : DR DOOR SW OFF

| DATA MONITOR | |
|---------------|--------|
| MONITOR | NO DTC |
| IGNITION SW | ON |
| KEY IN DETECT | ON |
| DR DOOR SW | ON |
| CDL LOCK SW | OFF |
| RKE LOCK | OFF |


Without CONSULT-II

- Check voltage between smart entrance control unit harness connector M42 terminal 43 (R/W) and ground.

| Terminal | | Condition (Driver's door) | Voltage [V] |
|----------|--------|---------------------------|-------------|
| (+) | (-) | | |
| 43 (R/W) | Ground | Open | Approx. 5 |
| | | Closed | 0 |

OK or NG?

- OK >> INSPECTION END
- NG >> GO TO 2.



WARNING CHIME


2. CHECK DOOR SWITCH OPEN OR SHORT CIRCUIT

1. Disconnect smart entrance control unit harness connector and front door switch (driver side) connector.
2. Check the following.
 - Harness continuity between smart entrance control unit harness connector M42 terminal 43 (R/W) and door switch (driver side) connector B16 terminal 1 (R/W).
 - Harness continuity between smart entrance control unit harness connector M42 terminal 43 (R/W) and body ground.

| Terminals | | | | Continuity |
|-----------|--------------------------|-----------|--------------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M42 | 43 (R/W) | B16 (R/W) | 1 (W/R) | Yes |
| M42 | 43 (R/W) | Ground | | No |

OK or NG?

- OK >> GO TO 3.
 NG >> Repair or replace harness.




3. CHECK DOOR SWITCH (DRIVER SIDE)

Check continuity between front door switch (driver side) harness connector B16 terminal 1 (R/W) and body ground.

| Terminals | | | Condition | Continuity |
|-----------|--------------------------|--------|----------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | (-) | | |
| B16 | 1 (R/W) | Ground | Door is open | Yes |
| | | | Door is closed | No |

OK or NG?

- OK >> Front door switch (driver side) is OK.
 NG >> Replace front door switch (driver side)



Seat Belt Buckle Switch Check (Driver side)

EKS004MX

1. SMART ENTRANCE CONTROL UNIT SYSTEM INSPECTION

Perform the smart entrance control unit self-diagnosis. Refer to [BCS-33, "SELF-DIAG RESULTS MODE"](#) in "Body control system (BCS)" section.

OK or NG?

- OK >> GO TO 2.
 NG >> Check Smart entrance control system.

2. COMBINATION METER SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis mode. Refer to [DI-24, "Combination Meter Self-Diagnosis"](#) (LHD models) or [DI-53, "Combination Meter Self-Diagnosis"](#) (RHD models).

OK or NG?

- OK >> GO TO 3.
 NG >> Check Combination meter system.

WARNING CHIME


3. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL

1. Turn ignition switch "ON".
2. Check voltage between seat belt buckle switch (driver side) harness connector B12 terminal 1 (G/W) and ground.

| Terminal | | Condition (Driver side seat belt buckle switch) | Voltage [V] |
|----------|--------|---|-------------|
| (+) | (-) | | |
| 1 (G/W) | Ground | Fasten | Approx. 5 |
| | | Unfasten | 0 |

OK or NG?

- OK >> Seat belt buckle switch is OK.
- NG >> GO TO 4. (LHD models)
- NG >> GO TO 5. (RHD models)




4. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL CIRCUIT (LHD MODELS)

1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector and seat belt buckle switch (driver side) harness connector.
3. Check the following.
 - Harness continuity between combination meter harness connector M36 terminal 8 (G/W) and seat belt buckle switch (driver side) harness connector B12 terminal 1 (G/W).
 - Harness continuity between combination meter harness connector M36 terminal 8 (G/W) and body ground.

| Terminal | | | | Continuity |
|---------------|-----------------------|---------------|-----------------------|------------|
| (+) Connector | | (-) Connector | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M36 | 8 (G/W) | B12 | 1 (G/W) | Yes |
| M36 | 8 (G/W) | Ground | | No |

OK or NG?

- OK >> GO TO 6.
- NG >> Repair or replace harness.



WARNING CHIME

5. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL CIRCUIT (RHD MODELS)


1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector and seat belt buckle switch (driver side) harness connector.
3. Check the following.
 - Harness continuity between combination meter harness connector M36 terminal 21 (G/W) and seat belt buckle switch (driver side) harness connector B12 terminal 1 (G/W).
 - Harness continuity between combination meter harness connector M36 terminal 21 (G/W) and body ground.

| Terminal | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M36 | 21 (G/W) | B12 | 1 (G/W) | Yes |
| M36 | 21 (G/W) | Ground | | No |

OK or NG?

OK >> GO TO 6.

NG >> Repair or replace harness.



6. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT


Check harness continuity between seat belt buckle switch (driver side) harness connector B12 terminal 2 (B) and body ground.

Continuity should exist.

OK or NG?

OK >> GO TO 7.

NG >> Repair or replace harness.



7. CHECK SEAT BELT BUCKLE SWITCH

Check continuity between seat belt buckle switch (driver side) harness connector B12 terminal 1 and 2.


When seat belt fastened : Continuity should not exist.

When seat belt unfastened : Continuity should exist.

OK or NG?

OK >> INSPECTION END.

NG >> Replace seat belt buckle switch (driver side).



WARNING CHIME

Seat Belt Buckle Switch Check (Passenger Side)

EKS004T5

1. SMART ENTRANCE CONTROL UNIT SYSTEM INSPECTION

Perform the smart entrance control unit self-diagnosis. Refer to [BCS-33, "SELF-DIAG RESULTS MODE"](#) in "Body control system (BCS)" section.

OK or NG?

- OK >> GO TO 2.
- NG >> Check Smart entrance control system.

2. COMBINATION METER SELF-DIAGNOSIS INSPECTION

Perform combination meter self-diagnosis mode. Refer to [DI-24, "Combination Meter Self-Diagnosis"](#) (LHD models) or [DI-53, "Combination Meter Self-Diagnosis"](#) (RHD models).

OK or NG?

- OK >> GO TO 3. (LHD models)
- OK >> GO TO 4. (RHD models)
- NG >> Check Combination meter system.

3. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL (LHD MODELS)

1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector.
3. Check continuity between combination meter harness connector M36 terminal 9 (G/B) and ground.


NOTE:

When performing the following procedure, a person is sitting on the passenger side seat. (As a result, the seat pressure sensor is turned ON.)

| Terminal | | Condition (Passenger side seat belt buckle switch) | Continuity |
|----------|--------|---|------------|
| 9 (G/B) | Ground | Fasten | Yes |
| | | Unfasten | No |

OK or NG?

- OK >> Seat belt buckle switch is OK.
- NG >> GO TO 5.




WARNING CHIME

4. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL (RHD MODELS)

1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector.
3. Check continuity between combination meter harness connector M36 terminal 22 (G/B) and ground.

NOTE:

When performing the following procedure, a person is sitting on the passenger side seat. (As a result, the seat pressure sensor is turned ON.)




| Terminal | | Condition (Passenger side seat belt buckle switch) | Continuity |
|----------|--------|---|------------|
| 22 (G/B) | Ground | Fasten | Yes |
| | | Unfasten | No |

OK or NG?

- OK >> Seat belt buckle switch is OK.
 NG >> GO TO 5.

5. CHECK SEAT PRESSURE SWITCH INPUT SIGNAL

1. Reconnect combination meter harness connector.
2. Disconnect seat belt buckle switch (passenger side) harness connector.
3. Turn ignition switch "ON".
4. Check voltage between seat belt buckle switch (passenger side) harness connector B111 terminal 1 (G) and ground.



| Terminal | | Condition (Seat pressure switch) | Voltage [V] |
|----------|--------|--|-------------|
| (+) | (-) | | |
| 1 (G) | Ground | Person is not sitting in passenger side seat. (Seat pressure switch "OFF") | 0 |
| | | Person is sitting in passenger side seat. (Seat pressure switch "ON") | Approx. 5 |

OK or NG?

- OK >> GO TO 10.
 NG >> GO TO 6. (LHD models)
 NG >> GO TO 7. (RHD models)

WARNING CHIME


6. CHECK SEAT PRESSURE SWITCH INPUT SIGNAL CIRCUIT (LHD MODELS)

1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector and seat pressure switch harness connector.
3. Check the following.
 - Harness continuity between combination meter harness connector M36 terminal 9 (G/B) and seat pressure switch harness connector B110 terminal 2 (G/B).
 - Harness continuity between combination meter harness connector M36 terminal 9 (G/B) and body ground.

| Terminal | | | | Continuity |
|-----------|--------------------------|-----------|--------------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M36 | 9 (G/B) | B110 | 2 (G/B) | Yes |
| M36 | 9 (G/B) | Ground | | No |

OK or NG?

- OK >> GO TO 8.
 NG >> Repair or replace harness.




7. CHECK SEAT PRESSURE SWITCH INPUT SIGNAL CIRCUIT (RHD MODELS)

1. Turn ignition switch "OFF".
2. Disconnect combination meter harness connector and seat pressure switch harness connector.
3. Check the following.
 - Harness continuity between combination meter harness connector M36 terminal 22 (G/B) and seat pressure switch harness connector B110 terminal 2 (G/B).
 - Harness continuity between combination meter harness connector M36 terminal 22 (G/B) and body ground.

| Terminal | | | | Continuity |
|-----------|--------------------------|-----------|--------------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M36 | 22 (G/B) | B110 | 2 (G/B) | Yes |
| M36 | 22 (G/B) | Ground | | No |

OK or NG?

- OK >> GO TO 8.
 NG >> Repair or replace harness.



WARNING CHIME


8. CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect seat belt buckle switch (passenger side) and seat pressure switch harness connector.
2. Check the following.
 - Harness continuity between seat belt buckle switch (passenger side) harness connector B111 terminal 1 (G) and seat pressure switch harness connector B110 terminal 1 (G).
 - Harness continuity between seat pressure switch harness connector B110 terminal 1 (G) and body ground.

| Terminal | | | | Continuity |
|-----------|-----------------------|-----------|-----------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| M110 | 1 (G) | B111 | 1 (G) | Yes |
| M110 | 1 (G) | Ground | | No |

OK or NG?

- OK >> GO TO 9.
 NG >> Repair or replace harness.




9. CHECK SEAT PRESSURE SWITCH

Check continuity between seat pressure switch harness connector B110 terminal 1 and 2.

| Terminal | | Condition (Seat pressure switch) | Continuity |
|----------|-----|--|------------|
| (+) | (-) | | |
| 1 | 2 | Person is not sitting in passenger side seat. (Seat pressure switch "OFF") | No |
| | | Person is sitting in passenger side seat. (Seat pressure switch "ON") | Yes |

OK or NG?

- OK >> GO TO 10.
 NG >> Replace seat pressure switch.




10. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch (passenger side) harness connector B111 terminal 2 (B) and body ground.

Continuity should exist.

OK or NG?

- OK >> GO TO 11.
 NG >> Repair or replace harness.



WARNING CHIME

11. CHECK SEAT BELT BUCKLE SWITCH

Check continuity between seat belt buckle switch (passenger side) harness connector B111 terminals 1 and 2.


When seat belt fastened: Continuity should not exist.

When seat belt unfastened: Continuity should exist.

OK or NG?

OK >> INSPECTION END.

NG >> Replace seat belt buckle switch (passenger side)



A
B
C
D
E
F
G
H
I
J
DI
L
M

CLOCK


PFP:25820

EKS003XV

DI-CLOCK-01

CLOCK

Wiring Diagram — CLOCK —



L : LHD MODELS

R : RHD MODELS

*1 46 : L




59 : R

*2 45 : L

58 : R

*3 47 : L

60 : R



REFER TO THE FOLLOWING.

(M1), (M2) - FUSE BLOCK-JUNCTION BOX (J/B)

TKWA0129E

REAR VIEW MONITOR

PFP:28260

System Description

EKS004TG

- The rear view monitor is equipped to check the rearward of the vehicle with display when the selector lever is in R position.
- The lines of vehicle sides and the distance from the rear end of the vehicle are provided on display as a guide. It allows the driver to know the distance between the vehicle and a rearward object, and the width of the vehicle much easier.

POWER SUPPLY AND GROUND

Power is supplied at all time

- through 15 A fuse (No.33, located in fuse and fusible link box)
- to rear view camera control unit terminal 7.

When ignition switch is ACC or ON position, power is supplied

- through 10 A fuse [No.1, located in fuse block (J/B)]
- to rear view camera control unit terminal 6.

When ignition switch is ON or START position, power is supplied

- through 10 A fuse [NO.30, located in fuse block (J/B)]
- to back-up lamp switch terminal 1 (M/T models)
- to park/neutral position switch terminal 3 (CVT or A/T models).

Ground is supplied

LHD models

- to rear view camera control unit terminal 16
- through body ground B120, and
- to rear view camera terminal 3
- through body ground B120 (sedan models) or B17, B24 and D94 (wagon models).

RHD models

- to rear view camera control unit terminal 16
- through body ground B24, D94 and B117, and
- to rear view camera terminal 3
- through body ground B17 and B24 (sedan models) or B17, B24 and D94 (wagon models).

REAR VIEW CAMERA OPERATION

When A/T selector lever is reverse position

- through back-up lamp switch terminal 2 (M/T models)
- through park/neutral position switch terminal 8 (CVT or A/T models)
- to rear view camera control unit terminal 14, and
- to AV and NAVI control unit terminal 32 (with navigation system)
- to display unit terminal 7 (without navigation system).

Then, camera ON signal is sent

- through rear view camera control unit terminal 5
- to rear view camera terminal 4.

An image taken by rear view camera is sent

- through rear view camera terminal 2
- to rear view camera control unit terminal 3.

Then an image is sent

- through rear view camera control unit terminal 2 and 13
- to display terminal 9 and 10 (with navigation system)
- to display unit terminal 23 and 24 (without navigation system).

An image of rear view will be projected on the display.

REAR VIEW MONITOR


Rear View Camera Guide Line (With Navigation System)

- from AV and NAVI control unit terminal 37
- to display terminal 10.

Rear view guideline will be projected on the display.

Component Location

EKS004TH




REAR VIEW MONITOR

Schematic

EKS004T1

- (A) : With A/T
- (C) : With CVT
- (M) : With M/T
- (NV) : With navigation system
- (ON) : Without navigation system




A
B
C
D
E
F
G
H
I
J
DI
L
M

REAR VIEW MONITOR

Wiring Diagram — R/VIEW — LHD MODELS

EKS004TJ

DI-R/VIEW-01



| | | | | | | |
|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| 15 | 16 | | | | | |

(M89)
W

(E109)
W

| | | | | | | |
|----|----|----|----|----|----|----|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 |
| 9 | 8 | | | | | |


(B130)
W

REFER TO THE FOLLOWING.

(M2) - FUSE BLOCK-
JUNCTION BOX (J/B)


REAR VIEW MONITOR

DI-R/VIEW-02



- ⬡ : WITH A/T
 - ⬢ : WITH CVT
 - ⬣ : WITH M/T
 - ⬤ : WITH GASOLINE ENGINE
 - ⬥ : WITH DIESEL ENGINE
 - ⬦ : WITH QR ENGINE
 - ⬧ : WITH QG ENGINE
- *1 4 : ⬦
- 3 : ⬧
- *2 7 : ⬦
- 17 : ⬧

A
B
C
D
E
F
G
H
I
J
DI
L
M





REFER TO THE FOLLOWING.

⬢ - FUSE BLOCK- JUNCTION BOX (J/B)

REAR VIEW MONITOR

DI-R/VIEW-03

(S) : SEDAN
(W) : WAGON




MKWA0194E

REAR VIEW MONITOR

NV : WITH NAVIGATION SYSTEM
ON : WITHOUT NAVIGATION SYSTEM

DI-R/VIEW-04



A
B
C
D
E
F
G
H
I
J
DI
L
M

| | | | | | | | | |
|----|----|----|----|---|---|---|---|---|
| 16 | 14 | 12 | 8 | 6 | 4 | 2 | | |
| 15 | 13 | 11 | 10 | 9 | 7 | 5 | 3 | 1 |

(M49) W

| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 48 | 45 | 42 | 39 | 37 | 35 | 33 | 30 | 27 |
| 47 | 44 | 41 | 38 | 36 | 34 | 32 | 29 | 26 |
| 46 | 43 | 40 | | | | 31 | 28 | 25 |

(M55) GY

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|---|---|---|---|---|
| 24 | 22 | 20 | 18 | 16 | 14 | 10 | 8 | 6 | 4 | 2 | | |
| 23 | 21 | 19 | 17 | 15 | 13 | 12 | 11 | 9 | 7 | 5 | 3 | 1 |

(M61) BR (M63) GY

| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | | |
| 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

(M87) W

| | | | | | | | | |
|----|----|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | | |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |

(B130) W



MKWA0195E

REAR VIEW MONITOR

RHD MODELS

DI-R/VIEW-05

⬡ W : WAGON




REFER TO THE FOLLOWING.
 ⬡ M2 - FUSE BLOCK-
 JUNCTION BOX (J/B)


REAR VIEW MONITOR

DI-R/VIEW-06

A
B
C
D
E
F
G
H
I
J
DI
L
M



- ⬡ : WITH A/T
 - ⬡ : WITH CVT
 - ⬡ : WITH M/T
 - ⬡ : WITH GASOLINE ENGINE
 - ⬡ : WITH DIESEL ENGINE
 - ⬡ : WITH QR ENGINE
 - ⬡ : WITH QG ENGINE
- *1 6 : ⬡
- 4 : ⬡
- *2 7 : ⬡
- 17 : ⬡





REFER TO THE FOLLOWING.

(E106) - FUSE BLOCK- JUNCTION BOX (J/B)

REAR VIEW MONITOR

DI-R/VIEW-07

S : SEDAN
W : WAGON




MKWA0198E


REAR VIEW MONITOR

DI-R/VIEW-08

NV : WITH NAVIGATION SYSTEM
ON : WITHOUT NAVIGATION SYSTEM



A
B
C
D
E
F
G
H
I
J
DI
L
M






MKWA0199E

REAR VIEW MONITOR

Terminals and Reference Value for Rear View Camera Control Unit

EKS004TK

| TERMINALS | | | ITEM | CONDITION | | Voltage (V) |
|---------------|---------------|--------|---|-------------------------|-------------------------------|--|
| (+) | | (-) | | Igni- tion switch | Operation | |
| TER- MINAL | WIRE COLOR | | | | | |
| 2 | R | Ground | Image signal (out- put) | ON | Gear position: "R" position | Approximately 0V  MKIB0189E |
| 3 | W | Ground | Camera image signal (input) | ON | Gear position "R" position | Approximately 0V  MKIB0189E |
| 5 | PU | Ground | Camera power output | ON | Gear position: R-position | Approximately 6.5V |
| 6 | P | Ground | ACC power | ACC | — | Battery voltage |
| 7 | Y | Ground | Battery power | OFF | — | Battery voltage |
| 9 | — | Ground | Shield ground | ON | — | Battery voltage |
| 10 | — | Ground | Shield ground | ON | — | Battery voltage |
| 13 | L | Ground | Image synchro- nous signal (out- put) | ON | Gear position: R-position | Approximately 5V  MKIB0190E |
| 14 | G/W | Ground | Reverse signal input | ON | Gear position: "R" position | Battery voltage |
| | | | | | Gear position: Other position | Approximately 0V |
| 15 | PU/W | Ground | Connected recog- nition signal | ON | — | Approximately 0V |
| 16 | B | Ground | Ground | ON | — | — |

Power Supply and Ground Circuit Check

EKS004TP

1. CHECK THE FUSES

- Check that the fuses for rear view camera control unit is blown.

| Unit | Power source | Fuse No. |
|-------------------------------|---------------------------|----------|
| Rear view camera control unit | Battery Power | 33 |
| | Ignition switch ACC or ON | 1 |

OK or NG

OK >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-3](#), "[POWER SUPPLY ROUTING](#)".

REAR VIEW MONITOR

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect camera controller connector.
2. Check voltage rear view camera control unit B130(LHD models) or B44(RHD models) terminal 6(P) and 7(Y), and ground.

| Terminals | | (-) | OFF | ACC | ON |
|-------------|-----------------------|--------|-----------------|-----------------|-----------------|
| (+) | Terminal (Wire color) | | | | |
| B130 or B44 | 6 (P) | Ground | 0V | Battery voltage | Battery voltage |
| B130 or B44 | 7 (Y) | Ground | Battery voltage | Battery voltage | Battery voltage |

OK or NG

OK >> GO TO 3.

NO >> Check harness for open or short between rear view camera control unit and fuse.



3. GROUND CIRCUIT CHECK

Check the following.


- Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 16(B) and ground.

Continuity should exist.

OK or NG

OK >> Inspection end.

NG >> Check ground harness.



Rear View Is Not Displayed With The Selector Lever In R-position.

EKS004TQ

1. BACKUP LAMP INSPECTION

1. Turn ignition switch ON position.
2. Shift the selector lever to R-position.

Dose backup lamp illuminate?

YES >> GO TO 2.

NO >> Check backup lamp system.

REAR VIEW MONITOR

2. CHECK REVERSE POSITION INPUT SIGNAL -I

1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector.
3. Turn ignition switch ON.
4. Shift the selector lever to R-position.
5. Check voltage between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 14(G/W) and ground.


Battery voltage should exist.

OK or NG

OK >> GO TO 3 (with navigation system).

OK >> GO TO 4 (without navigation system).

NG >> Check harness for open or short between rear view camera control unit and backup lamp switch (M/T models) or park/neutral position switch (CVT or A/T models).



3. CHECK REVERSE POSITION INPUT SIGNAL -II


1. Turn ignition switch OFF.
2. Disconnect rear AV and NAVI control unit connector.
3. Turn ignition switch ON.
4. Shift the selector lever to R-position.
5. Check voltage between AV and NAVI control unit harness connector M55 terminal 32(G/W) and ground.

Battery voltage should exist.

OK or NG

OK >> GO TO 5.

NG >> Check harness for open or short between AV and NAVI control unit and backup lamp switch (M/T models) or park/neutral position switch (CVT or A/T models).



4. CHECK REVERSE POSITION INPUT SIGNAL -III


1. Turn ignition switch OFF.
2. Disconnect display unit connector.
3. Turn ignition switch ON.
4. Shift the selector lever to R-position.
5. Check voltage between display unit harness connector M61 terminal 7(G/W) and ground.

Battery voltage should exist.

OK or NG

OK >> GO TO 5.

NG >> Check harness for open or short between display unit and back up lamp switch (M/T models) or park/neutral position switch (CVT or A/T models).




REAR VIEW MONITOR

5. CHECK REAR VIEW CAMERA CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector and rear view camera connector.
3. Check the following.
 - Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 3(W) and rear view camera harness connector T5(sedan models) or D91(wagon models) each terminal 2(W).
 - Continuity between rear view camera control unit harness connector B130(LHD models) or B44 (RHD models) terminal 5(PU) and rear view camera harness connector T5(sedan models) or D91(wagon models) each terminal 4(PU).
 - Continuity between rear view camera harness connector T5(sedan models) or D91(wagon models) each terminal 3(B) and ground.

| Terminals | | | | Continuity |
|-------------|-----------------------|-----------|-----------------------|------------|
| (+) | | (-) | | |
| Connector | Terminal (Wire color) | Connector | Terminal (Wire color) | |
| B130 or B44 | 3 (W) | T5 or D91 | 2 (W) | Yes |
| B130 or B44 | 5 (PU) | T5 or D91 | 4 (PU) | Yes |
| T5 or D91 | 3 (B) | Ground | | Yes |



OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace harness.


6. CHECK REAR VIEW CAMERA CONTROL UNIT OUTPUT SIGNAL

1. Connect rear view camera control unit connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R-position.
4. Check voltage between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 5(PU) and ground.

Approx. 6.5V

OK or NG

- OK >> GO TO 7.
- NG >> Replace rear view camera control unit.



7. CHECK REAR VIEW CAMERA SIGNAL


1. Connect the rear view camera connector.
2. Check voltage between rear view camera harness connector T5(sedan models) or D91(wagon models) each terminal 2(W) and ground.

:Refer to DI-140, "Terminals and Reference Value for Rear View Camera Control Unit" .

2 - Ground

OK or NG

- OK >> Replace rear view camera control unit.
- NG >> Replace rear view camera.





REAR VIEW MONITOR

EKS004TS

The Rear View Image Is Distorted.

1. CHECK SYNCHRO SIGNAL OPEN OR SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera control unit connector and display unit.
3. Check the following
 - Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 2 (R) and display unit harness connector M61 terminal 24 (R) (without navigation system).
 - Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 2 (R) and display harness connector M63 terminal 9 (R) (with navigation system).
 - Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 2 (R) and ground.



| Terminals | | | | Continuity |
|---------------------------|-----------------------|--------------|----------|------------|
| (+) Terminal (Wire color) | | (-) Terminal | | |
| Connector | Terminal (Wire color) | Connector | Terminal | |
| B130 or B44 | 2 (R) | M61 | 24 (R) | Yes |
| B130 or B44 | 2 (R) | M63 | 9 (R) | Yes |
| B130 or B44 | 2 (R) | Ground | | No |

OK or NG


- OK >> GO TO 2.
 NG >> Repair or replace harness.

REAR VIEW MONITOR


2. CHECK SYNCHRO SIGNAL OPEN OR SHORT CIRCUIT

1. Check the following.

- Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 9 and display unit harness connector M61 terminal 22 (without navigation system).



- Continuity between rear view camera control unit harness connector B130(LHD models) or B44(RHD models) terminal 9 and display harness connector M63 terminal 11 (with navigation system).



Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.

3. CHECK REAR VIEW CONTROL UNIT SYNCHRO SIGNAL

1. Connect rear view camera control unit connector.
2. Turn ignition switch ON.
3. Shift the selector lever to R-position.
4. Check signal between rear view camera control unit harness connector B130(LHD models) or B44 (RHD models) terminal 13 (L) and ground.

13 - Ground:

Refer to [DI-140, "Terminals and Reference Value for Rear View Camera Control Unit"](#) .

OK or NG

- OK >> Replace display unit or display.
- NG >> Replace rear view camera control unit.

REAR VIEW MONITOR

Removal and Installation of Rear View Camera

EKS004TU

1. Remove the trunk trim. Refer to.
2. Remove the license plate finisher. Refer to [EI-21, "LICENSE PLATE FINISHER"](#) .
3. Remove the nuts (2), and remove the rear view monitor camera.

