

A
EC
C
D
E
F
G
H
I
J
K
L
M

SECTION EC

ENGINE CONTROL SYSTEM

CONTENTS

QG (WITH EURO-OBD)	
INDEX FOR DTC	23
Alphabetical Index	23
DTC No. Index	27
PRECAUTIONS	33
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	33
On Board Diagnostic (OBD) System of Engine and A/T	33
Precaution	33
Wiring Diagrams and Trouble Diagnosis	36
PREPARATION	37
Special Service Tools	37
Commercial Service Tools	37
ENGINE CONTROL SYSTEM	39
System Diagram - QG16DE Engine Models	39
System Diagram - QG18DE Engine Models	40
Vacuum Hose Drawing	41
System Chart	42
Multiport Fuel Injection (MFI) System	42
Electronic Ignition (EI) System	45
Air Conditioning Cut Control	45
Fuel Cut Control (at No Load and High Engine Speed)	46
CAN communication	46
BASIC SERVICE PROCEDURE	54
Idle Speed and Ignition Timing Check	54
Accelerator Pedal Released Position Learning	55
Throttle Valve Closed Position Learning	55
Idle Air Volume Learning	55
Fuel Pressure Check	58
ON BOARD DIAGNOSTIC (OBD) SYSTEM	60
Introduction	60
Two Trip Detection Logic	60
Emission-related Diagnostic Information	61
NATS (Nissan Anti-theft System)	75
Malfunction Indicator (MI)	75
OBD System Operation Chart	79
TROUBLE DIAGNOSIS	84
Trouble Diagnosis Introduction	84
DTC Inspection Priority Chart	88
Fail-safe Chart	90
Basic Inspection	92
Symptom Matrix Chart	97
Engine Control Component Parts Location	101
Circuit Diagram	105
ECM Harness Connector Terminal Layout	107
ECM Terminals and Reference Value	107
CONSULT-II Function	121
Generic Scan Tool (GST) Function	132
CONSULT-II Reference Value in Data Monitor Mode	133
Major Sensor Reference Graph in Data Monitor Mode	136
TROUBLE DIAGNOSIS - SPECIFICATION VALUE	139
Description	139
Testing Condition	139
Inspection Procedure	139
Diagnostic Procedure	140
TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	143
Description	143
Diagnostic Procedure	143
POWER SUPPLY CIRCUIT FOR ECM	144
Wiring Diagram	144
Diagnostic Procedure	145
Component Inspection	149
DTC U1000, U1001 CAN COMMUNICATION LINE	150
Description	150
On Board Diagnosis Logic	150
DTC Confirmation Procedure	150
Wiring Diagram	151
Diagnostic Procedure	152
DTC P0011 IVT CONTROL	153
Description	153
CONSULT-II Reference Value in Data Monitor Mode	153
On Board Diagnosis Logic	154

DTC Confirmation Procedure	154	Wiring Diagram	191
Diagnostic Procedure	154	Diagnostic Procedure	192
DTC P0031, P0032 HO2S1 HEATER (QG16DE) ..156		Component Inspection	193
Description	156	Removal and Installation	193
CONSULT-II Reference Value in Data Monitor Mode	156	DTC P0117, P0118 ECT SENSOR	194
On Board Diagnosis Logic	156	Component Description	194
DTC Confirmation Procedure	156	On Board Diagnosis Logic	194
Wiring Diagram	158	DTC Confirmation Procedure	195
Diagnostic Procedure	159	Wiring Diagram	196
Component Inspection	161	Diagnostic Procedure	197
Removal and Installation	161	Component Inspection	198
DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE)	162	Removal and Installation	198
Description	162	DTC P0132 HO2S1 (QG16DE)	199
CONSULT-II Reference Value in Data Monitor Mode	162	Component Description	199
On Board Diagnosis Logic	162	CONSULT-II Reference Value in Data Monitor Mode	199
DTC Confirmation Procedure	162	On Board Diagnosis Logic	199
Wiring Diagram	164	DTC Confirmation Procedure	200
Diagnostic Procedure	167	Wiring Diagram	201
Component Inspection	169	Diagnostic Procedure	202
Removal and Installation	169	Component Inspection	203
DTC P0037, P0038 HO2S2 HEATER (QG16DE) ..170		Removal and Installation	204
Description	170	DTC P0132, P0152 HO2S1 (QG18DE)	205
CONSULT-II Reference Value in Data Monitor Mode	170	Component Description	205
On Board Diagnosis Logic	170	CONSULT-II Reference Value in Data Monitor Mode	205
DTC Confirmation Procedure	170	On Board Diagnosis Logic	205
Wiring Diagram	172	DTC Confirmation Procedure	206
Diagnostic Procedure	173	Wiring Diagram	207
Component Inspection	174	Diagnostic Procedure	210
Removal and Installation	174	Component Inspection	211
DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE)	175	Removal and Installation	213
Description	175	DTC P0133 HO2S1 (QG16DE)	214
CONSULT-II Reference Value in Data Monitor Mode	175	Component Description	214
On Board Diagnosis Logic	175	CONSULT-II Reference Value in Data Monitor Mode	214
DTC Confirmation Procedure	175	On Board Diagnosis Logic	214
Wiring Diagram	177	DTC Confirmation Procedure	215
Diagnostic Procedure	180	Overall Function Check	216
Component Inspection	181	Wiring Diagram	217
Removal and Installation	182	Diagnostic Procedure	218
DTC P0102, P0103 MAF SENSOR	183	Component Inspection	221
Component Description	183	Removal and Installation	222
CONSULT-II Reference Value in Data Monitor Mode	183	DTC P0133, P0153, HO2S1 (QG18DE)	223
On Board Diagnosis Logic	183	Component Description	223
DTC Confirmation Procedure	183	CONSULT-II Reference Value in Data Monitor Mode	223
Wiring Diagram	185	On Board Diagnosis Logic	223
Diagnostic Procedure	186	DTC Confirmation Procedure	224
Component Inspection	188	Overall Function Check	225
Removal and Installation	188	Wiring Diagram	226
DTC P0112, P0113 IAT SENSOR	189	Diagnostic Procedure	229
Component Description	189	Component Inspection	232
On Board Diagnosis Logic	189	Removal and Installation	233
DTC Confirmation Procedure	189	DTC P0134 HO2S1 (QG16DE)	234
		Component Description	234
		CONSULT-II Reference Value in Data Monitor Mode	234

On Board Diagnosis Logic	234	Wiring Diagram	278
DTC Confirmation Procedure	235	Diagnostic Procedure	281
Overall Function Check	235	Component Inspection	283
Wiring Diagram	237	Removal and Installation	284
Diagnostic Procedure	238	DTC P0171, P0174 FUEL INJECTION SYSTEM	
Component Inspection	239	FUNCTION (QG18DE)	285
Removal and Installation	240	On Board Diagnosis Logic	285
DTC P0134, P0154 HO2S1 (QG18DE)	241	DTC Confirmation Procedure	285
Component Description	241	Wiring Diagram	287
CONSULT-II Reference Value in Data Monitor Mode	241	Diagnostic Procedure	288
On Board Diagnosis Logic	241	DTC P0171, P0174 FUEL INJECTION SYSTEM	
DTC Confirmation Procedure	242	FUNCTION (QG18DE)	291
Overall Function Check	243	On Board Diagnosis Logic	291
Wiring Diagram	244	DTC Confirmation Procedure	291
Diagnostic Procedure	247	Wiring Diagram	293
Component Inspection	248	Diagnostic Procedure	295
Removal and Installation	250	DTC P0172, P0175 FUEL INJECTION SYSTEM	
DTC P0138 HO2S2 (QG16DE)	251	FUNCTION (QG18DE)	305
Component Description	251	On Board Diagnosis Logic	305
CONSULT-II Reference Value in Data Monitor Mode	251	DTC Confirmation Procedure	305
On Board Diagnosis Logic	251	Wiring Diagram	301
DTC Confirmation Procedure	251	Diagnostic Procedure	302
Overall Function Check	252	DTC P0172, P0175 FUEL INJECTION SYSTEM	
Wiring Diagram	253	FUNCTION (QG18DE)	305
Diagnostic Procedure	254	On Board Diagnosis Logic	305
Component Inspection	256	DTC Confirmation Procedure	305
Removal and Installation	257	Wiring Diagram	307
DTC P0138, P0158 HO2S2 (QG18DE)	258	Diagnostic Procedure	309
Component Description	258	DTC P0221 TP SENSOR	312
CONSULT-II Reference Value in Data Monitor Mode	258	Component Description	312
On Board Diagnosis Logic	258	CONSULT-II Reference Value in Data Monitor Mode	312
DTC Confirmation Procedure	258	On Board Diagnosis Logic	312
Overall Function Check	259	DTC Confirmation Procedure	312
Wiring Diagram	260	Wiring Diagram	314
Diagnostic Procedure	263	Diagnostic Procedure	315
Component Inspection	265	Component Inspection	317
Removal and Installation	266	Remove and Installation	317
DTC P0139 HO2S2 (QG16DE)	267	DTC P0222, P0223 TP SENSOR	318
Component Description	267	Component Description	318
CONSULT-II Reference Value in Data Monitor Mode	267	CONSULT-II Reference Value in Data Monitor Mode	318
On Board Diagnosis Logic	267	On Board Diagnosis Logic	318
DTC Confirmation Procedure	267	DTC Confirmation Procedure	318
Overall Function Check	269	Wiring Diagram	320
Wiring Diagram	270	Diagnostic Procedure	321
Diagnostic Procedure	271	Component Inspection	323
Component Inspection	273	Remove and Installation	323
Removal and Installation	274	DTC P0226 APP SENSOR	324
DTC P0139, P0159 HO2S2 (QG18DE)	275	Component Description	324
Component Description	275	CONSULT-II Reference Value in Data Monitor Mode	324
CONSULT-II Reference Value in Data Monitor Mode	275	On Board Diagnosis Logic	324
On Board Diagnosis Logic	275	DTC Confirmation Procedure	324
DTC Confirmation Procedure	275	Wiring Diagram	326
Overall Function Check	277	Diagnostic Procedure	327
		Component Inspection	329
		Remove and Installation	330

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0227, P0228 APP SENSOR	331	On Board Diagnosis Logic	370
Component Description	331	DTC Confirmation Procedure	370
CONSULT-II Reference Value in Data Monitor Mode	331	Wiring Diagram	371
On Board Diagnosis Logic	331	Diagnostic Procedure	372
DTC Confirmation Procedure	331	Component Inspection	374
Wiring Diagram	333	Removal and Installation	374
Diagnostic Procedure	334	DTC P0500 VSS	375
Component Inspection	336	Description	375
Remove and Installation	337	On Board Diagnosis Logic	375
DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE	338	DTC Confirmation Procedure	375
On Board Diagnosis Logic	338	Overall Function Check	375
DTC Confirmation Procedure	338	Diagnostic Procedure	376
Diagnostic Procedure	339	DTC P0550 PSP SENSOR	377
DTC P0327, P0328 KS	344	Component Description	377
Component Description	344	CONSULT-II Reference Value in Data Monitor Mode	377
On Board Diagnosis Logic	344	On Board Diagnosis Logic	377
DTC Confirmation Procedure	344	DTC Confirmation Procedure	377
Wiring Diagram	345	Wiring Diagram	378
Diagnostic Procedure	346	Diagnostic Procedure	379
Component Inspection	347	Component Inspection	381
Removal and Installation	347	DTC P0605 ECM	382
DTC P0335 CKP SENSOR (POS)	348	Component Description	382
Component Description	348	On Board Diagnosis Logic	382
CONSULT-II Reference Value in Data Monitor Mode	348	DTC Confirmation Procedure	382
On Board Diagnosis Logic	348	Diagnostic Procedure	384
DTC Confirmation Procedure	348	DTC P1065 ECM POWER SUPPLY	385
Wiring Diagram	350	Component Description	385
Diagnostic Procedure	351	On Board Diagnosis Logic	385
Component Inspection	353	DTC Confirmation Procedure	385
Removal and Installation	354	Wiring Diagram	386
DTC P0340 CMP SENSOR (PHASE)	355	Diagnostic Procedure	387
Component Description	355	DTC P1102 MAF SENSOR	389
On Board Diagnosis Logic	355	Component Description	389
DTC Confirmation Procedure	355	CONSULT-II Reference Value in Data Monitor Mode	389
Wiring Diagram	356	On Board Diagnosis Logic	389
Diagnostic Procedure	357	DTC Confirmation Procedure	389
Component Inspection	359	Wiring Diagram	391
Removal and Installation	360	Diagnostic Procedure	392
DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE)	361	Component Inspection	394
On Board Diagnosis Logic	361	Removal and Installation	394
DTC Confirmation Procedure	361	DTC P1111 IVT CONTROL SOLENOID VALVE	395
Overall Function Check	362	Description	395
Diagnostic Procedure	363	CONSULT-II Reference Value in Data Monitor Mode	395
DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE)	365	On Board Diagnosis Logic	396
On Board Diagnosis Logic	365	DTC Confirmation Procedure	396
DTC Confirmation Procedure	365	Wiring Diagram	397
Overall Function Check	366	Diagnostic Procedure	398
Diagnostic Procedure	367	Component Inspection	399
DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	369	Removal and Installation	399
Description	369	DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR	400
CONSULT-II Reference Value in Data Monitor Mode	369	Component Description	400
		On Board Diagnosis Logic	400
		DTC Confirmation Procedure	400

Diagnostic Procedure	401	Component Inspection	436	
Remove and Installation	401	Removal and Installation	437	A
DTC P1122 ELECTRIC THROTTLE CONTROL		DTC P1144, P1164 HO2S1 (QG18DE)	438	
FUNCTION	402	Component Description	438	
Description	402	CONSULT-II Reference Value in Data Monitor Mode		EC
On Board Diagnosis Logic	402		438	
DTC Confirmation Procedure	402	On Board Diagnosis Logic	438	
Wiring Diagram	403	DTC Confirmation Procedure	439	C
Diagnostic Procedure	404	Overall Function Check	440	
Component Inspection	408	Diagnostic Procedure	440	
Remove and Installation	408	Component Inspection	442	
DTC P1124, P1126 THROTTLE CONTROL MOTOR		Removal and Installation	443	D
RELAY	409	DTC P1146 HO2S2 (QG16DE)	444	
Component Description	409	Component Description	444	
CONSULT-II Reference Value in Data Monitor Mode		CONSULT-II Reference Value in Data Monitor Mode		E
	409		444	
On Board Diagnosis Logic	409	On Board Diagnosis Logic	444	
DTC Confirmation Procedure	409	DTC Confirmation Procedure	444	F
Wiring Diagram	411	Overall Function Check	446	
Diagnostic Procedure	412	Wiring Diagram	447	
Component Inspection	413	Diagnostic Procedure	448	
DTC P1128 THROTTLE CONTROL MOTOR	415	Component Inspection	450	G
Component Description	415	Removal and Installation	451	
On Board Diagnosis Logic	415	DTC P1146, P1166 HO2S2 (QG18DE)	452	
DTC Confirmation Procedure	415	Component Description	452	H
Wiring Diagram	416	CONSULT-II Reference Value in Data Monitor Mode		
Diagnostic Procedure	417		452	
Component Inspection	418	On Board Diagnosis Logic	452	I
Remove and Installation	419	DTC Confirmation Procedure	452	
DTC P1143 HO2S1 (QG16DE)	420	Overall Function Check	454	
Component Description	420	Wiring Diagram	455	J
CONSULT-II Reference Value in Data Monitor Mode		Diagnostic Procedure	458	
	420	Component Inspection	460	
On Board Diagnosis Logic	420	Removal and Installation	461	
DTC Confirmation Procedure	421	DTC P1147 HO2S2 (QG16DE)	462	K
Overall Function Check	422	Component Description	462	
Diagnostic Procedure	422	CONSULT-II Reference Value in Data Monitor Mode		
Component Inspection	424		462	L
Remove and Installation	425	On Board Diagnosis Logic	462	
DTC P1143, P1163 HO2S1 (QG18DE)	426	DTC Confirmation Procedure	462	
Component Description	426	Overall Function Check	464	M
CONSULT-II Reference Value in Data Monitor Mode		Wiring Diagram	465	
	426	Diagnostic Procedure	466	
On Board Diagnosis Logic	426	Component Inspection	468	
DTC Confirmation Procedure	427	Removal and Installation	469	
Overall Function Check	428	DTC P1147, P1167 HO2S2 (QG18DE)	470	
Diagnostic Procedure	428	Component Description	470	
Component Inspection	430	CONSULT-II Reference Value in Data Monitor Mode		
Remove and Installation	431		470	
DTC P1144 HO2S1 (QG16DE)	432	On Board Diagnosis Logic	470	
Component Description	432	DTC Confirmation Procedure	470	
CONSULT-II Reference Value in Data Monitor Mode		Overall Function Check	472	
	432	Wiring Diagram	473	
On Board Diagnosis Logic	432	Diagnostic Procedure	476	
DTC Confirmation Procedure	433	Component Inspection	478	
Overall Function Check	433	Removal and Installation	479	
Diagnostic Procedure	434	DTC P1217 ENGINE OVER TEMPERATURE	480	
		System Description	480	

CONSULT-II Reference Value in Data Monitor Mode	480	On Board Diagnosis Logic	515
On Board Diagnosis Logic	481	DTC Confirmation Procedure	515
Overall Function Check	481	Wiring Diagram	516
Wiring Diagram	483	Diagnostic Procedure	517
Diagnostic Procedure	484	Component Inspection	519
Main 12 Causes of Overheating	488	IGNITION SIGNAL	520
Component Inspection	489	Component Description	520
DTC P1223, P1224 TP SENSOR	490	Wiring Diagram	521
Component Description	490	Diagnostic Procedure	524
CONSULT-II Reference Value in Data Monitor Mode	490	Component Inspection	528
On Board Diagnosis Logic	490	Removal and Installation	529
DTC Confirmation Procedure	490	INJECTOR CIRCUIT	530
Wiring Diagram	492	Component Description	530
Diagnostic Procedure	493	CONSULT-II Reference Value in Data Monitor Mode	530
Component Inspection	495	Wiring Diagram	531
Remove and Installation	495	Diagnostic Procedure	532
DTC P1225 TP SENSOR	496	Component Inspection	535
Component Description	496	Remove and Installation	535
On Board Diagnosis Logic	496	FUEL PUMP CIRCUIT	536
DTC Confirmation Procedure	496	Description	536
Diagnostic Procedure	497	CONSULT-II Reference Value in Data Monitor Mode	536
Remove and Installation	497	Wiring Diagram	537
DTC P1226 TP SENSOR	498	Diagnostic Procedure	538
Component Description	498	Component Inspection	540
On Board Diagnosis Logic	498	Remove and Installation	541
DTC Confirmation Procedure	498	REFRIGERANT PRESSURE SENSOR	542
Diagnostic Procedure	499	Component Description	542
Remove and Installation	499	Wiring Diagram	543
DTC P1227, P1228 APP SENSOR	500	Diagnostic Procedure	544
Component Description	500	Remove and Installation	546
CONSULT-II Reference Value in Data Monitor Mode	500	ELECTRICAL LOAD SIGNAL	547
On Board Diagnosis Logic	500	Description	547
DTC Confirmation Procedure	500	CONSULT-II Reference Value in Data Monitor Mode	547
Wiring Diagram	502	Wiring Diagram	548
Diagnostic Procedure	503	Diagnostic Procedure	549
Component Inspection	505	MI & DATA LINK CONNECTORS	552
Remove and Installation	506	Wiring Diagram—LHD Models	552
DTC P1229 SENSOR POWER SUPPLY	507	Wiring Diagram—RHD Models	553
On Board Diagnosis Logic	507	EVAPORATIVE EMISSION SYSTEM	554
DTC Confirmation Procedure	507	Description	554
Wiring Diagram	508	Component Inspection	556
Diagnostic Procedure	509	POSITIVE CRANKCASE VENTILATION	557
DTC P1706 PNP SWITCH	511	Description	557
Component Description	511	Component Inspection	557
CONSULT-II Reference Value in Data Monitor Mode	511	SERVICE DATA AND SPECIFICATIONS (SDS)	559
On Board Diagnosis Logic	511	Fuel Pressure	559
DTC Confirmation Procedure	511	Idle Speed and Ignition Timing	559
Overall Function Check	512	Calculated Load Value	559
Wiring Diagram	513	Mass Air Flow Sensor	559
Diagnostic Procedure	514	Intake Air Temperature Sensor	559
DTC P1805 BRAKE SWITCH	515	Engine Coolant Temperature Sensor	559
Description	515	Heated Oxygen Sensor 1 Heater	559
CONSULT-II Reference Value in Data Monitor Mode	515	Heated Oxygen sensor 2 Heater	559
		Crankshaft Position Sensor (POS)	559
		Camshaft Position Sensor (PHASE)	559

Throttle Control Motor	560
Injector	560
Fuel Pump	560

QG (WITHOUT EURO-OBD)

INDEX FOR DTC	561
Alphabetical Index	561
DTC No. Index	563
PRECAUTIONS	567
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	567
On Board Diagnostic (OBD) System of Engine ...	567
Precaution	567
Wiring Diagrams and Trouble Diagnosis	570
PREPARATION	571
Special Service Tools	571
Commercial Service Tools	571
ENGINE CONTROL SYSTEM	573
System Diagram - QG16DE Engine Models	573
System Diagram - QG18DE Engine Models	574
Vacuum Hose Drawing	575
System Chart	576
Multiport Fuel Injection (MFI) System	576
Electronic Ignition (EI) System	579
Air Conditioning Cut Control	579
Fuel Cut Control (at No Load and High Engine Speed)	580
CAN communication	580
BASIC SERVICE PROCEDURE	588
Idle Speed and Ignition Timing Check	588
Accelerator Pedal Released Position Learning ...	589
Throttle Valve Closed Position Learning	589
Idle Air Volume Learning	589
Fuel Pressure Check	591
ON BOARD DIAGNOSTIC (OBD) SYSTEM	593
Introduction	593
Two Trip Detection Logic	593
Emission-related Diagnostic Information	593
NATS (Nissan Anti-theft System)	595
Malfunction Indicator (MI)	596
TROUBLE DIAGNOSIS	600
Trouble Diagnosis Introduction	600
DTC Inspection Priority Chart	604
Fail-safe Chart	605
Basic Inspection	607
Symptom Matrix Chart	612
Engine Control Component Parts Location	616
Circuit Diagram	620
ECM Harness Connector Terminal Layout	622
ECM Terminals and Reference Value	622
CONSULT-II Function	636
CONSULT-II Reference Value in Data Monitor Mode	646
Major Sensor Reference Graph in Data Monitor Mode	649

TROUBLE DIAGNOSIS - SPECIFICATION VALUE 652	
Description	652
Testing Condition	652
Inspection Procedure	652
Diagnostic Procedure	653
TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	656
Description	656
Diagnostic Procedure	656
POWER SUPPLY CIRCUIT FOR ECM	657
Wiring Diagram	657
Diagnostic Procedure	658
Component Inspection	662
DTC U1000, U1001 CAN COMMUNICATION LINE 663	
Description	663
On Board Diagnosis Logic	663
DTC Confirmation Procedure	663
Wiring Diagram	664
Diagnostic Procedure	665
DTC P0102, P0103 MAF SENSOR	666
Component Description	666
CONSULT-II Reference Value in Data Monitor Mode	666
On Board Diagnosis Logic	666
DTC Confirmation Procedure	666
Wiring Diagram	668
Diagnostic Procedure	669
Component Inspection	671
Removal and Installation	671
DTC P0117, P0118 ECT SENSOR	672
Component Description	672
On Board Diagnosis Logic	672
DTC Confirmation Procedure	673
Wiring Diagram	674
Diagnostic Procedure	675
Component Inspection	676
Removal and Installation	676
DTC P0132 HO2S1 (QG16DE)	677
Component Description	677
CONSULT-II Reference Value in Data Monitor Mode	677
On Board Diagnosis Logic	677
DTC Confirmation Procedure	678
Wiring Diagram	679
Diagnostic Procedure	680
Component Inspection	681
Removal and Installation	682
DTC P0132, P0152 HO2S1 (QG18DE)	683
Component Description	683
CONSULT-II Reference Value in Data Monitor Mode	683
On Board Diagnosis Logic	683
DTC Confirmation Procedure	684
Wiring Diagram	685
Diagnostic Procedure	688
Component Inspection	689
Removal and Installation	691

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0134 HO2S1 (QG16DE)	692	Wiring Diagram	731
Component Description	692	Diagnostic Procedure	732
CONSULT-II Reference Value in Data Monitor Mode	692	Component Inspection	734
On Board Diagnosis Logic	692	Remove and Installation	734
Overall Function Check	693	DTC P0226 APP SENSOR	735
Wiring Diagram	694	Component Description	735
Diagnostic Procedure	695	CONSULT-II Reference Value in Data Monitor Mode	735
Component Inspection	696	On Board Diagnosis Logic	735
Removal and Installation	697	DTC Confirmation Procedure	735
DTC P0134, P0154 HO2S1 (QG18DE)	698	Wiring Diagram	737
Component Description	698	Diagnostic Procedure	738
CONSULT-II Reference Value in Data Monitor Mode	698	Component Inspection	740
On Board Diagnosis Logic	698	Remove and Installation	741
Overall Function Check	699	DTC P0227, P0228 APP SENSOR	742
Wiring Diagram	700	Component Description	742
Diagnostic Procedure	703	CONSULT-II Reference Value in Data Monitor Mode	742
Component Inspection	704	On Board Diagnosis Logic	742
Removal and Installation	706	DTC Confirmation Procedure	742
DTC P0138 HO2S2 (QG16DE)	707	Wiring Diagram	744
Component Description	707	Diagnostic Procedure	745
CONSULT-II Reference Value in Data Monitor Mode	707	Component Inspection	747
On Board Diagnosis Logic	707	Remove and Installation	748
DTC Confirmation Procedure	707	DTC P0327, P0328 KS	749
Overall Function Check	708	Component Description	749
Wiring Diagram	709	On Board Diagnosis Logic	749
Diagnostic Procedure	710	DTC Confirmation Procedure	749
Component Inspection	712	Wiring Diagram	750
Removal and Installation	713	Diagnostic Procedure	751
DTC P0138, P0158 HO2S2 (QG18DE)	714	Component Inspection	752
Component Description	714	Removal and Installation	752
CONSULT-II Reference Value in Data Monitor Mode	714	DTC P0335 CKP SENSOR (POS)	753
On Board Diagnosis Logic	714	Component Description	753
DTC Confirmation Procedure	714	CONSULT-II Reference Value in Data Monitor Mode	753
Overall Function Check	715	On Board Diagnosis Logic	753
Wiring Diagram	716	DTC Confirmation Procedure	753
Diagnostic Procedure	719	Wiring Diagram	755
Component Inspection	721	Diagnostic Procedure	756
Removal and Installation	722	Component Inspection	758
DTC P0221 TP SENSOR	723	Removal and Installation	759
Component Description	723	DTC P0340 CMP SENSOR (PHASE)	760
CONSULT-II Reference Value in Data Monitor Mode	723	Component Description	760
On Board Diagnosis Logic	723	On Board Diagnosis Logic	760
DTC Confirmation Procedure	723	DTC Confirmation Procedure	760
Wiring Diagram	725	Wiring Diagram	762
Diagnostic Procedure	726	Diagnostic Procedure	763
Component Inspection	728	Component Inspection	765
Remove and Installation	728	Removal and Installation	766
DTC P0222, P0223 TP SENSOR	729	DTC P0605 ECM	767
Component Description	729	Component Description	767
CONSULT-II Reference Value in Data Monitor Mode	729	On Board Diagnosis Logic	767
On Board Diagnosis Logic	729	DTC Confirmation Procedure	767
DTC Confirmation Procedure	729	Diagnostic Procedure	769
		DTC P1065 ECM POWER SUPPLY	770
		Component Description	770
		On Board Diagnosis Logic	770

DTC Confirmation Procedure	770	DTC P1223, P1224 TP SENSOR	811	
Wiring Diagram	771	Component Description	811	A
Diagnostic Procedure	772	CONSULT-II Reference Value in Data Monitor Mode	811	
DTC P1102 MAF SENSOR	774	On Board Diagnosis Logic	811	EC
Component Description	774	DTC Confirmation Procedure	811	
CONSULT-II Reference Value in Data Monitor Mode	774	Wiring Diagram	813	
On Board Diagnosis Logic	774	Diagnostic Procedure	814	C
DTC Confirmation Procedure	774	Component Inspection	816	
Wiring Diagram	776	Remove and Installation	816	
Diagnostic Procedure	777	DTC P1225 TP SENSOR	817	D
Component Inspection	779	Component Description	817	
Removal and Installation	779	On Board Diagnosis Logic	817	
DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR	780	DTC Confirmation Procedure	817	E
Component Description	780	Diagnostic Procedure	818	
On Board Diagnosis Logic	780	Remove and Installation	818	
DTC Confirmation Procedure	780	DTC P1226 TP SENSOR	819	F
Diagnostic Procedure	781	Component Description	819	
Remove and Installation	782	On Board Diagnosis Logic	819	
DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION	783	DTC Confirmation Procedure	819	G
Description	783	Diagnostic Procedure	820	
On Board Diagnosis Logic	783	Remove and Installation	820	
DTC Confirmation Procedure	783	DTC P1227, P1228 APP SENSOR	821	H
Wiring Diagram	784	Component Description	821	
Diagnostic Procedure	785	CONSULT-II Reference Value in Data Monitor Mode	821	
Component Inspection	789	On Board Diagnosis Logic	821	I
Remove and Installation	789	DTC Confirmation Procedure	821	
DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY	790	Wiring Diagram	823	J
Component Description	790	Diagnostic Procedure	824	
CONSULT-II Reference Value in Data Monitor Mode	790	Component Inspection	826	
On Board Diagnosis Logic	790	Remove and Installation	827	
DTC Confirmation Procedure	790	DTC P1229 SENSOR POWER SUPPLY	828	K
Wiring Diagram	792	On Board Diagnosis Logic	828	
Diagnostic Procedure	793	DTC Confirmation Procedure	828	
Component Inspection	794	Wiring Diagram	829	
DTC P1128 THROTTLE CONTROL MOTOR	796	Diagnostic Procedure	830	L
Component Description	796	DTC P1805 BRAKE SWITCH	832	
On Board Diagnosis Logic	796	Description	832	
DTC Confirmation Procedure	796	CONSULT-II Reference Value in Data Monitor Mode	832	M
Wiring Diagram	797	On Board Diagnosis Logic	832	
Diagnostic Procedure	798	DTC Confirmation Procedure	832	
Component Inspection	799	Wiring Diagram	833	
Remove and Installation	800	Diagnostic Procedure	834	
DTC P1217 ENGINE OVER TEMPERATURE	801	Component Inspection	836	
System Description	801	HO2S1 HEATER (QG16DE)	837	
CONSULT-II Reference Value in Data Monitor Mode	801	Description	837	
On Board Diagnosis Logic	802	CONSULT-II Reference Value in Data Monitor Mode	837	
Overall Function Check	802	Wiring Diagram	838	
Wiring Diagram	804	Diagnostic Procedure	839	
Diagnostic Procedure	805	Component Inspection	841	
Main 12 Causes of Overheating	809	Remove and Installation	841	
Component Inspection	810	HO2S1 HEATER (QG18DE)	842	
		Description	842	
		CONSULT-II Reference Value in Data Monitor Mode	842	

Wiring Diagram	843	IGNITION SIGNAL	895
Diagnostic Procedure	846	Component Description	895
Component Inspection	848	Wiring Diagram	896
Removal and Installation	848	Diagnostic Procedure	899
HO2S2 HEATER (QG16DE)	849	Component Inspection	903
Description	849	Removal and Installation	904
CONSULT-II Reference Value in Data Monitor Mode	.849	EVAP CANISTER PURGE VOLUME CONTROL	
Wiring Diagram	850	SOLENOID VALVE	905
Diagnostic Procedure	851	Description	905
Component Inspection	853	CONSULT-II Reference Value in Data Monitor Mode	.905
Removal and Installation	853	Wiring Diagram	906
HO2S2 HEATER (QG18DE)	854	Diagnostic Procedure	908
Description	854	Component Inspection	911
CONSULT-II Reference Value in Data Monitor Mode	.854	Removal and Installation	911
Wiring Diagram	855	VSS	912
Diagnostic Procedure	858	Description	912
Component Inspection	860	Diagnostic Procedure	912
Removal and Installation	860	POWER STEERING PRESSURE SENSOR	913
IAT SENSOR	861	Component Description	913
Component Description	861	CONSULT-II Reference Value in Data Monitor Mode	.913
Wiring Diagram	862	Wiring Diagram	914
Diagnostic Procedure	863	Diagnostic Procedure	915
Component Inspection	864	Component Inspection	917
Removal and Installation	864	IVT CONTROL SOLENOID VALVE	918
HO2S1 (QG16DE)	865	Description	918
Component Description	865	CONSULT-II Reference Value in Data Monitor Mode	.918
CONSULT-II Reference Value in Data Monitor Mode	.865	Wiring Diagram	920
Wiring Diagram	866	Diagnostic Procedure	921
Diagnostic Procedure	867	Component Inspection	923
Component Inspection	870	Removal and Installation	923
Removal and Installation	871	PNP SWITCH	924
HO2S1 (QG18DE)	872	Component Description	924
Component Description	872	CONSULT-II Reference Value in Data Monitor Mode	.924
CONSULT-II Reference Value in Data Monitor Mode	.872	Wiring Diagram	925
Wiring Diagram	873	Diagnostic Procedure	926
Diagnostic Procedure	876	INJECTOR CIRCUIT	928
Component Inspection	879	Component Description	928
Removal and Installation	880	CONSULT-II Reference Value in Data Monitor Mode	.928
HO2S2 (QG16DE)	881	Wiring Diagram	929
Component Description	881	Diagnostic Procedure	930
CONSULT-II Reference Value in Data Monitor Mode	.881	Component Inspection	933
Wiring Diagram	882	Removal and Installation	933
Diagnostic Procedure	883	FUEL PUMP CIRCUIT	934
Component Inspection	885	Description	934
Removal and Installation	886	CONSULT-II Reference Value in Data Monitor Mode	.934
HO2S2 (QG18DE)	887	Wiring Diagram	935
Component Description	887	Diagnostic Procedure	936
CONSULT-II Reference Value in Data Monitor Mode	.887	Component Inspection	938
Wiring Diagram	888	Removal and Installation	939
Diagnostic Procedure	891	REFRIGERANT PRESSURE SENSOR	940
Component Inspection	893	Component Description	940
Removal and Installation	894	Wiring Diagram	941

Diagnostic Procedure	942	BASIC SERVICE PROCEDURE	997	
Removal and Installation	944	Idle Speed and Ignition Timing Check	997	A
ELECTRICAL LOAD SIGNAL	945	Accelerator Pedal Released Position Learning ...	998	
Description	945	Throttle Valve Closed Position Learning	998	
CONSULT-II Reference Value in Data Monitor Mode		Idle Air Volume Learning	999	EC
	945	Fuel Pressure Check	1001	
Wiring Diagram	946	ON BOARD DIAGNOSTIC (OBD) SYSTEM	1004	
Diagnostic Procedure	947	Introduction	1004	C
MI & DATA LINK CONNECTORS	950	Two Trip Detection Logic	1004	
Wiring Diagram—LHD Models	950	Emission-related Diagnostic Information	1005	D
Wiring Diagram—RHD Models	951	NATS (Nissan Anti-theft System)	1016	
EVAPORATIVE EMISSION SYSTEM	952	Malfunction Indicator (MI)	1016	D
Description	952	OBD System Operation Chart	1019	
Component Inspection	954	TROUBLE DIAGNOSIS	1025	E
POSITIVE CRANKCASE VENTILATION	955	Trouble Diagnosis Introduction	1025	
Description	955	DTC Inspection Priority Chart	1029	F
Component Inspection	955	Fail-safe Chart	1030	
SERVICE DATA AND SPECIFICATIONS (SDS) ...	957	Basic Inspection	1032	F
Fuel Pressure	957	Symptom Matrix Chart	1037	
Idle Speed and Ignition Timing	957	Engine Control Component Parts Location	1041	G
Calculated Load Value	957	Circuit Diagram	1045	
Mass Air Flow Sensor	957	ECM Harness Connector Terminal Layout	1047	G
Intake Air Temperature Sensor	957	ECM Terminals and Reference Value	1047	
Engine Coolant Temperature Sensor	957	CONSULT-II Function	1054	H
Heated Oxygen Sensor 1 Heater	957	Generic Scan Tool (GST) Function	1065	
Heated Oxygen sensor 2 Heater	957	CONSULT-II Reference Value in Data Monitor Mode		
Crankshaft Position Sensor (POS)	957		1067	I
Camshaft Position Sensor (PHASE)	957	Major Sensor Reference Graph in Data Monitor		
Throttle Control Motor	958	Mode	1070	I
Injector	958	TROUBLE DIAGNOSIS - SPECIFICATION VALUE	1072	J
Fuel Pump	958	Description	1072	
		Testing Condition	1072	J
		Inspection Procedure	1072	
		Diagnostic Procedure	1073	K
		TROUBLE DIAGNOSIS FOR INTERMITTENT INCI-	1076	
		DENT	1076	K
		Description	1076	
		Diagnostic Procedure	1076	L
		POWER SUPPLY CIRCUIT FOR ECM	1077	
		Wiring Diagram	1077	
		Diagnostic Procedure	1078	M
		Component Inspection	1082	
		DTC U1000, U1001 CAN COMMUNICATION LINE	1083	
		Description	1083	
		On Board Diagnosis Logic	1083	
		DTC Confirmation Procedure	1083	
		Wiring Diagram	1084	
		Diagnostic Procedure	1085	
		DTC P0011 IVT CONTROL	1087	
		Description	1087	
		CONSULT-II Reference Value in Data Monitor Mode		
			1087	
		On Board Diagnosis Logic	1088	
		DTC Confirmation Procedure	1088	
		Diagnostic Procedure	1088	
		DTC P0031, P0032 HO2S1 HEATER	1090	
		Description	1090	
		CONSULT-II Reference Value in Data Monitor Mode		

QR (WITH EURO-OBD)

INDEX FOR DTC	959		
Alphabetical Index	959		
DTC No. Index	961		
PRECAUTIONS	964		
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	964		
On Board Diagnostic (OBD) System of Engine and CVT	964		
Precaution	964		
Wiring Diagrams and Trouble Diagnosis	967		
PREPARATION	968		
Special Service Tools	968		
Commercial Service Tools	968		
ENGINE CONTROL SYSTEM	970		
System Diagram	970		
Vacuum Hose Drawing	971		
System Chart	972		
Multiport Fuel Injection (MFI) System	972		
Electronic Ignition (EI) System	975		
Air Conditioning Cut Control	975		
Fuel Cut Control (at No Load and High Engine Speed)	976		
CAN communication	976		

On Board Diagnosis Logic	1090	Component Inspection	1123
DTC Confirmation Procedure	1090	Removal and Installation	1124
Wiring Diagram	1092	DTC P0133 HO2S1	1125
Diagnostic Procedure	1093	Component Description	1125
Component Inspection	1094	CONSULT-II Reference Value in Data Monitor Mode	
Removal and Installation	1094		1125
DTC P0037, P0038 HO2S2 HEATER	1095	On Board Diagnosis Logic	1125
Description	1095	DTC Confirmation Procedure	1126
CONSULT-II Reference Value in Data Monitor Mode		Overall Function Check	1127
	1095	Wiring Diagram	1128
On Board Diagnosis Logic	1095	Diagnostic Procedure	1129
DTC Confirmation Procedure	1095	Component Inspection	1132
Wiring Diagram	1097	Removal and Installation	1134
Diagnostic Procedure	1098	DTC P0134 HO2S1	1135
Component Inspection	1099	Component Description	1135
Removal and Installation	1099	CONSULT-II Reference Value in Data Monitor Mode	
DTC P0102, P0103 MAF SENSOR	1100		1135
Component Description	1100	On Board Diagnosis Logic	1135
CONSULT-II Reference Value in Data Monitor Mode		DTC Confirmation Procedure	1136
	1100	Overall Function Check	1136
On Board Diagnosis Logic	1100	Wiring Diagram	1138
DTC Confirmation Procedure	1100	Diagnostic Procedure	1139
Wiring Diagram	1102	Component Inspection	1140
Diagnostic Procedure	1103	Removal and Installation	1141
Component Inspection	1105	DTC P0138 HO2S2	1142
Removal and Installation	1105	Component Description	1142
DTC P0112, P0113 IAT SENSOR	1106	CONSULT-II Reference Value in Data Monitor Mode	
Component Description	1106		1142
On Board Diagnosis Logic	1106	On Board Diagnosis Logic	1142
DTC Confirmation Procedure	1106	DTC Confirmation Procedure	1142
Wiring Diagram	1108	Overall Function Check	1143
Diagnostic Procedure	1109	Wiring Diagram	1144
Component Inspection	1110	Diagnostic Procedure	1145
Removal and Installation	1110	Component Inspection	1147
DTC P0117, P0118 ECT SENSOR	1111	Removal and Installation	1148
Component Description	1111	DTC P0139 HO2S2	1149
On Board Diagnosis Logic	1111	Component Description	1149
DTC Confirmation Procedure	1112	CONSULT-II Reference Value in Data Monitor Mode	
Wiring Diagram	1113		1149
Diagnostic Procedure	1114	On Board Diagnosis Logic	1149
Component Inspection	1115	DTC Confirmation Procedure	1149
Removal and Installation	1115	Overall Function Check	1151
DTC P0127 IAT SENSOR	1116	Wiring Diagram	1152
Component Description	1116	Diagnostic Procedure	1153
On Board Diagnosis Logic	1116	Component Inspection	1155
DTC Confirmation Procedure	1116	Removal and Installation	1156
Diagnostic Procedure	1117	DTC P0171 FUEL INJECTION SYSTEM FUNCTION 157	
Component Inspection	1117	On Board Diagnosis Logic	1157
Removal and Installation	1118	DTC Confirmation Procedure	1157
DTC P0132 HO2S1	1119	Wiring Diagram	1159
Component Description	1119	Diagnostic Procedure	1160
CONSULT-II Reference Value in Data Monitor Mode		DTC P0172 FUEL INJECTION SYSTEM FUNCTION 163	
	1119	On Board Diagnosis Logic	1163
On Board Diagnosis Logic	1119	DTC Confirmation Procedure	1163
DTC Confirmation Procedure	1120	Wiring Diagram	1165
Wiring Diagram	1121	Diagnostic Procedure	1166
Diagnostic Procedure	1122	DTC P0221 TP SENSOR	1169
		Component Description	1169

CONSULT-II Reference Value in Data Monitor Mode	1169	Diagnostic Procedure	1208	
On Board Diagnosis Logic	1169	Component Inspection	1210	A
DTC Confirmation Procedure	1169	Removal and Installation	1211	
Wiring Diagram	1171	DTC P0340 CMP SENSOR (PHASE)	1212	EC
Diagnostic Procedure	1172	Component Description	1212	
Component Inspection	1174	On Board Diagnosis Logic	1212	
Remove and Installation	1174	DTC Confirmation Procedure	1212	
DTC P0222, P0223 TP SENSOR	1175	Wiring Diagram	1213	
Component Description	1175	Diagnostic Procedure	1214	C
CONSULT-II Reference Value in Data Monitor Mode	1175	Component Inspection	1216	
On Board Diagnosis Logic	1175	Remove and Installation	1217	
DTC Confirmation Procedure	1175	DTC P0420 THREE WAY CATALYST FUNCTION	1218	D
Wiring Diagram	1177	On Board Diagnosis Logic	1218	
Diagnostic Procedure	1178	DTC Confirmation Procedure	1218	
Component Inspection	1180	Overall Function Check	1219	E
Remove and Installation	1180	Diagnostic Procedure	1220	
DTC P0226 APP SENSOR	1181	DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE	1222	F
Component Description	1181	Description	1222	
CONSULT-II Reference Value in Data Monitor Mode	1181	CONSULT-II Reference Value in Data Monitor Mode	1222	
On Board Diagnosis Logic	1181	On Board Diagnosis Logic	1223	G
DTC Confirmation Procedure	1181	DTC Confirmation Procedure	1223	
Wiring Diagram	1183	Wiring Diagram	1224	
Diagnostic Procedure	1184	Diagnostic Procedure	1225	H
Component Inspection	1187	Component Inspection	1227	
Remove and Installation	1187	Remove and Installation	1227	
DTC P0227, P0228 APP SENSOR	1188	DTC P0500 VSS	1228	I
Component Description	1188	Description	1228	
CONSULT-II Reference Value in Data Monitor Mode	1188	On Board Diagnosis Logic	1228	
On Board Diagnosis Logic	1188	DTC Confirmation Procedure	1228	J
DTC Confirmation Procedure	1188	Overall Function Check	1228	
Wiring Diagram	1190	Diagnostic Procedure	1229	
Diagnostic Procedure	1191	DTC P0550 PSP SENSOR	1230	K
Component Inspection	1193	Component Description	1230	
Remove and Installation	1194	CONSULT-II Reference Value in Data Monitor Mode	1230	
DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE	1195	On Board Diagnosis Logic	1230	L
On Board Diagnosis Logic	1195	DTC Confirmation Procedure	1230	
DTC Confirmation Procedure	1195	Wiring Diagram	1231	
Diagnostic Procedure	1196	Diagnostic Procedure	1232	
DTC P0327, P0328 KS	1201	Component Inspection	1234	M
Component Description	1201	DTC P0605 ECM	1235	
On Board Diagnosis Logic	1201	Component Description	1235	
DTC Confirmation Procedure	1201	On Board Diagnosis Logic	1235	
Wiring Diagram	1202	DTC Confirmation Procedure	1235	
Diagnostic Procedure	1203	Diagnostic Procedure	1237	
Component Inspection	1204	DTC P1065 ECM POWER SUPPLY	1238	
Remove and Installation	1204	Component Description	1238	
DTC P0335 CKP SENSOR (POS)	1205	On Board Diagnosis Logic	1238	
Component Description	1205	DTC Confirmation Procedure	1238	
CONSULT-II Reference Value in Data Monitor Mode	1205	Wiring Diagram	1239	
On Board Diagnosis Logic	1205	Diagnostic Procedure	1240	
DTC Confirmation Procedure	1205	DTC P1111 IVT CONTROL SOLENOID VALVE	1242	
Wiring Diagram	1207	Component Description	1242	
		CONSULT-II Reference Value in Data Monitor Mode	1242	
		On Board Diagnosis Logic	1242	

DTC Confirmation Procedure	1242	Component Inspection	1276
Wiring Diagram	1243	Removal and Installation	1277
Diagnostic Procedure	1244	DTC P1146 HO2S2	1278
Component Inspection	1245	Component Description	1278
Removal and Installation	1245	CONSULT-II Reference Value in Data Monitor Mode	
DTC P1121 ELECTRIC THROTTLE CONTROL			1278
ACTUATOR	1246	On Board Diagnosis Logic	1278
Component Description	1246	DTC Confirmation Procedure	1278
On Board Diagnosis Logic	1246	Overall Function Check	1280
DTC Confirmation Procedure	1246	Wiring Diagram	1281
Diagnostic Procedure	1247	Diagnostic Procedure	1282
Removal and Installation	1247	Component Inspection	1284
DTC P1122 ELECTRIC THROTTLE CONTROL		Removal and Installation	1285
FUNCTION	1248	DTC P1147 HO2S2	1286
Description	1248	Component Description	1286
On Board Diagnosis Logic	1248	CONSULT-II Reference Value in Data Monitor Mode	
DTC Confirmation Procedure	1248		1286
Wiring Diagram	1249	On Board Diagnosis Logic	1286
Diagnostic Procedure	1250	DTC Confirmation Procedure	1286
Component Inspection	1254	Overall Function Check	1288
Remove and Installation	1254	Wiring Diagram	1289
DTC P1124, P1126 THROTTLE CONTROL MOTOR		Diagnostic Procedure	1290
RELAY	1255	Component Inspection	1292
Component Description	1255	Removal and Installation	1293
CONSULT-II Reference Value in Data Monitor Mode		DTC P1212 ESP/TCS/ABS COMMUNICATION	
	1255	LINE	1294
On Board Diagnosis Logic	1255	Description	1294
DTC Confirmation Procedure	1255	On Board Diagnosis Logic	1294
Wiring Diagram	1257	DTC Confirmation Procedure	1294
Diagnostic Procedure	1258	Diagnostic Procedure	1294
Component Inspection	1259	DTC P1217 ENGINE OVER TEMPERATURE	1295
DTC P1128 THROTTLE CONTROL MOTOR	1261	System Description	1295
Component Description	1261	CONSULT-II Reference Value in Data Monitor Mode	
On Board Diagnosis Logic	1261		1295
DTC Confirmation Procedure	1261	On Board Diagnosis Logic	1296
Wiring Diagram	1262	Overall Function Check	1296
Diagnostic Procedure	1263	Wiring Diagram	1298
Component Inspection	1264	Diagnostic Procedure	1300
Remove and Installation	1265	Main 12 Causes of Overheating	1310
DTC P1143 HO2S1	1266	Component Inspection	1311
Component Description	1266	DTC P1223, P1224 TP SENSOR	1312
CONSULT-II Reference Value in Data Monitor Mode		Component Description	1312
	1266	CONSULT-II Reference Value in Data Monitor Mode	
On Board Diagnosis Logic	1266		1312
DTC Confirmation Procedure	1267	On Board Diagnosis Logic	1312
Overall Function Check	1268	DTC Confirmation Procedure	1312
Diagnostic Procedure	1268	Wiring Diagram	1314
Component Inspection	1270	Diagnostic Procedure	1315
Removal and Installation	1271	Component Inspection	1317
DTC P1144 HO2S1	1272	Remove and Installation	1317
Component Description	1272	DTC P1225 TP SENSOR	1318
CONSULT-II Reference Value in Data Monitor Mode		Component Description	1318
	1272	On Board Diagnosis Logic	1318
On Board Diagnosis Logic	1272	DTC Confirmation Procedure	1318
DTC Confirmation Procedure	1273	Diagnostic Procedure	1319
Overall Function Check	1273	Remove and Installation	1319
Diagnostic Procedure	1274	DTC P1226 TP SENSOR	1320
		Component Description	1320

On Board Diagnosis Logic	1320	CONSULT-II Reference Value in Data Monitor Mode	1358	A
DTC Confirmation Procedure	1320	On Board Diagnosis Logic	1358	
Diagnostic Procedure	1321	DTC Confirmation Procedure	1358	
Remove and Installation	1321	Diagnostic Procedure	1358	EC
DTC P1227, P1228 APP SENSOR	1322	DTC P1805 BRAKE SWITCH	1360	
Component Description	1322	Description	1360	
CONSULT-II Reference Value in Data Monitor Mode	1322	CONSULT-II Reference Value in Data Monitor Mode	1360	C
On Board Diagnosis Logic	1322	On Board Diagnosis Logic	1360	
DTC Confirmation Procedure	1322	DTC Confirmation Procedure	1360	
Wiring Diagram	1324	Wiring Diagram	1361	D
Diagnostic Procedure	1325	Diagnostic Procedure	1362	
Component Inspection	1327	Component Inspection	1363	
Remove and Installation	1328	IGNITION SIGNAL	1365	E
DTC P1229 SENSOR POWER SUPPLY	1329	Component Description	1365	
On Board Diagnosis Logic	1329	Wiring Diagram	1366	
DTC Confirmation Procedure	1329	Diagnostic Procedure	1369	F
Wiring Diagram	1330	Component Inspection	1373	
Diagnostic Procedure	1331	Removal and Installation	1374	
DTC P1564 ICC STEERING SWITCH	1333	INJECTOR CIRCUIT	1375	G
Component Description	1333	Component Description	1375	
CONSULT-II Reference Value in Data Monitor Mode	1333	CONSULT-II Reference Value in Data Monitor Mode	1375	
On Board Diagnosis Logic	1333	Wiring Diagram	1376	H
DTC Confirmation Procedure	1333	Diagnostic Procedure	1377	
Wiring Diagram	1335	Component Inspection	1380	
Diagnostic Procedure	1337	Removal and Installation	1380	I
Component Inspection	1339	FUEL PUMP CIRCUIT	1381	
DTC P1568 ICC FUNCTION	1340	Description	1381	J
On Board Diagnosis Logic	1340	CONSULT-II Reference Value in Data Monitor Mode	1381	
DTC Confirmation Procedure	1340	Wiring Diagram	1382	
Diagnostic Procedure	1340	Diagnostic Procedure	1383	
DTC P1572 ICC BRAKE SWITCH	1341	Component Inspection	1385	K
Component Description	1341	Removal and Installation	1386	
CONSULT-II Reference Value in Data Monitor Mode	1341	REFRIGERANT PRESSURE SENSOR	1387	L
On Board Diagnosis Logic	1341	Component Description	1387	
DTC Confirmation Procedure	1341	Wiring Diagram	1388	
Wiring Diagram	1343	Diagnostic Procedure	1389	
Diagnostic Procedure	1344	Removal and Installation	1391	M
Component Inspection	1349	ELECTRICAL LOAD SIGNAL	1392	
DTC P1574 ICC VEHICLE SPEED SENSOR	1351	Description	1392	
Component Description	1351	CONSULT-II Reference Value in Data Monitor Mode	1392	
On Board Diagnosis Logic	1351	Wiring Diagram	1393	
DTC Confirmation Procedure	1351	Diagnostic Procedure	1394	
Diagnostic Procedure	1352	ICC BRAKE SWITCH	1397	
DTC P1706 PNP SWITCH	1353	Component Description	1397	
Component Description	1353	CONSULT-II Reference Value in Data Monitor Mode	1397	
CONSULT-II Reference Value in Data Monitor Mode	1353	Wiring Diagram	1398	
On Board Diagnosis Logic	1353	Diagnostic Procedure	1399	
DTC Confirmation Procedure	1353	Component Inspection	1404	
Overall Function Check	1354	MI & DATA LINK CONNECTORS	1406	
Wiring Diagram	1355	Wiring Diagram (LHD Models)	1406	
Diagnostic Procedure	1356	Wiring Diagram (RHD Models)	1407	
DTC P1720 VSS	1358			
Description	1358			

EVAPORATIVE EMISSION SYSTEM	1408	TROUBLE DIAGNOSIS	1451
Description	1408	Trouble Diagnosis Introduction	1451
Component Inspection	1410	DTC Inspection Priority Chart	1455
POSITIVE CRANKCASE VENTILATION	1411	Fail-safe Chart	1456
Description	1411	Basic Inspection	1457
Component Inspection	1411	Symptom Matrix Chart	1462
SERVICE DATA AND SPECIFICATIONS (SDS) ..	1413	Engine Control Component Parts Location	1466
Fuel Pressure	1413	Circuit Diagram	1470
Idle Speed and Ignition Timing	1413	ECM Harness Connector Terminal Layout	1472
Calculated Load Value	1413	ECM Terminals and Reference Value	1472
Mass Air Flow Sensor	1413	CONSULT-II Function	1479
Intake Air Temperature Sensor	1413	CONSULT-II Reference Value in Data Monitor Mode	1489
Engine Coolant Temperature Sensor	1413	Major Sensor Reference Graph in Data Monitor	
Heated Oxygen Sensor 1 Heater	1413	Mode	1492
Heated Oxygen sensor 2 Heater	1413	TROUBLE DIAGNOSIS - SPECIFICATION VALUE 1494	
Crankshaft Position Sensor (POS)	1413	Description	1494
Camshaft Position Sensor (PHASE)	1413	Testing Condition	1494
Throttle Control Motor	1414	Inspection Procedure	1494
Injector	1414	Diagnostic Procedure	1495
Fuel Pump	1414	TROUBLE DIAGNOSIS FOR INTERMITTENT INCI-	
		DENT	1498
		Description	1498
		Diagnostic Procedure	1498
		POWER SUPPLY CIRCUIT FOR ECM	1499
		Wiring Diagram	1499
		Diagnostic Procedure	1500
		Component Inspection	1504
		DTC U1000, U1001 CAN COMMUNICATION LINE 1505	
		Description	1505
		On Board Diagnosis Logic	1505
		DTC Confirmation Procedure	1505
		Wiring Diagram	1506
		Diagnostic Procedure	1507
		DTC P0102, P0103 MAF SENSOR	1508
		Component Description	1508
		CONSULT-II Reference Value in Data Monitor Mode	1508
		On Board Diagnosis Logic	1508
		DTC Confirmation Procedure	1508
		Wiring Diagram	1510
		Diagnostic Procedure	1511
		Component Inspection	1513
		Removal and Installation	1513
		DTC P0117, P0118 ECT SENSOR	1514
		Component Description	1514
		On Board Diagnosis Logic	1514
		DTC Confirmation Procedure	1515
		Wiring Diagram	1516
		Diagnostic Procedure	1517
		Component Inspection	1518
		Removal and Installation	1518
		DTC P0134 HO2S1	1519
		Component Description	1519
		CONSULT-II Reference Value in Data Monitor Mode	1519
		On Board Diagnosis Logic	1519
		Overall Function Check	1520

QR (WITHOUT EURO-OBD)

INDEX FOR DTC	1415
Alphabetical Index	1415
DTC No. Index	1416
PRECAUTIONS	1418
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	1418
On Board Diagnostic (OBD) System of Engine ..	1418
Precaution	1418
Wiring Diagrams and Trouble Diagnosis	1421
PREPARATION	1422
Special Service Tools	1422
Commercial Service Tools	1422
ENGINE CONTROL SYSTEM	1424
System Diagram	1424
Vacuum Hose Drawing	1425
System Chart	1426
Multiport Fuel Injection (MFI) System	1426
Electronic Ignition (EI) System	1429
Air Conditioning Cut Control	1429
Fuel Cut Control (at No Load and High Engine Speed)	1430
CAN communication	1430
BASIC SERVICE PROCEDURE	1439
Idle Speed and Ignition Timing Check	1439
Accelerator Pedal Released Position Learning ..	1440
Throttle Valve Closed Position Learning	1440
Idle Air Volume Learning	1440
Fuel Pressure Check	1443
ON BOARD DIAGNOSTIC (OBD) SYSTEM	1445
Introduction	1445
Two Trip Detection Logic	1445
Emission-related Diagnostic Information	1445
NATS (Nissan Anti-theft System)	1447
Malfunction Indicator (MI)	1448

Wiring Diagram	1521	Wiring Diagram	1557
Diagnostic Procedure	1522	Diagnostic Procedure	1558
Component Inspection	1523	Component Inspection	1560
Removal and Installation	1524	Removal and Installation	1561
DTC P0221 TP SENSOR	1525	DTC P0340 CMP SENSOR (PHASE)	1562
Component Description	1525	Component Description	1562
CONSULT-II Reference Value in Data Monitor Mode	1525	On Board Diagnosis Logic	1562
On Board Diagnosis Logic	1525	DTC Confirmation Procedure	1562
DTC Confirmation Procedure	1525	Wiring Diagram	1564
Wiring Diagram	1527	Diagnostic Procedure	1565
Diagnostic Procedure	1528	Component Inspection	1567
Component Inspection	1530	Removal and Installation	1568
Remove and Installation	1530	DTC P0500 VSS	1569
DTC P0222, P0223 TP SENSOR	1531	Description	1569
Component Description	1531	On Board Diagnosis Logic	1569
CONSULT-II Reference Value in Data Monitor Mode	1531	DTC Confirmation Procedure	1569
On Board Diagnosis Logic	1531	Overall Function Check	1569
DTC Confirmation Procedure	1531	Diagnostic Procedure	1570
Wiring Diagram	1533	DTC P0550 PSP SENSOR	1571
Diagnostic Procedure	1534	Component Description	1571
Component Inspection	1536	CONSULT-II Reference Value in Data Monitor Mode	1571
Remove and Installation	1536	On Board Diagnosis Logic	1571
DTC P0226 APP SENSOR	1537	DTC Confirmation Procedure	1571
Component Description	1537	Wiring Diagram	1572
CONSULT-II Reference Value in Data Monitor Mode	1537	Diagnostic Procedure	1573
On Board Diagnosis Logic	1537	Component Inspection	1575
DTC Confirmation Procedure	1537	DTC P0605 ECM	1576
Wiring Diagram	1539	Component Description	1576
Diagnostic Procedure	1540	On Board Diagnosis Logic	1576
Component Inspection	1543	DTC Confirmation Procedure	1576
Remove and Installation	1543	Diagnostic Procedure	1578
DTC P0227, P0228 APP SENSOR	1544	DTC P1065 ECM POWER SUPPLY	1579
Component Description	1544	Component Description	1579
CONSULT-II Reference Value in Data Monitor Mode	1544	On Board Diagnosis Logic	1579
On Board Diagnosis Logic	1544	DTC Confirmation Procedure	1579
DTC Confirmation Procedure	1544	Wiring Diagram	1580
Wiring Diagram	1546	Diagnostic Procedure	1581
Diagnostic Procedure	1547	DTC P1121 ELECTRIC THROTTLE CONTROL	
Component Inspection	1549	ACTUATOR	1583
Remove and Installation	1550	Component Description	1583
DTC P0327, P0328 KS	1551	On Board Diagnosis Logic	1583
Component Description	1551	DTC Confirmation Procedure	1583
On Board Diagnosis Logic	1551	Diagnostic Procedure	1584
DTC Confirmation Procedure	1551	Removal and Installation	1584
Wiring Diagram	1552	DTC P1122 ELECTRIC THROTTLE CONTROL	
Diagnostic Procedure	1553	FUNCTION	1585
Component Inspection	1554	Description	1585
Remove and Installation	1554	On Board Diagnosis Logic	1585
DTC P0335 CKP SENSOR (POS)	1555	DTC Confirmation Procedure	1585
Component Description	1555	Wiring Diagram	1586
CONSULT-II Reference Value in Data Monitor Mode	1555	Diagnostic Procedure	1587
On Board Diagnosis Logic	1555	Component Inspection	1591
DTC Confirmation Procedure	1555	Remove and Installation	1591
		DTC P1124, P1126 THROTTLE CONTROL MOTOR	
		RELAY	1592
		Component Description	1592
		CONSULT-II Reference Value in Data Monitor Mode	

A

EC

C

D

E

F

G

H

I

J

K

L

M

On Board Diagnosis Logic	1592	DTC Confirmation Procedure	1637
DTC Confirmation Procedure	1592	Wiring Diagram	1638
Wiring Diagram	1594	Diagnostic Procedure	1639
Diagnostic Procedure	1595	DTC P1805 BRAKE SWITCH	1641
Component Inspection	1596	Description	1641
DTC P1128 THROTTLE CONTROL MOTOR	1598	CONSULT-II Reference Value in Data Monitor Mode	1641
Component Description	1598	On Board Diagnosis Logic	1641
On Board Diagnosis Logic	1598	DTC Confirmation Procedure	1641
DTC Confirmation Procedure	1598	Wiring Diagram	1642
Wiring Diagram	1599	Diagnostic Procedure	1643
Diagnostic Procedure	1600	Component Inspection	1644
Component Inspection	1601	HO2S1 HEATER	1646
Remove and Installation	1602	Description	1646
DTC P1217 ENGINE OVER TEMPERATURE	1603	CONSULT-II Reference Value in Data Monitor Mode	1646
System Description	1603	Wiring Diagram	1647
CONSULT-II Reference Value in Data Monitor Mode	1603	Diagnostic Procedure	1648
On Board Diagnosis Logic	1604	Component Inspection	1650
Overall Function Check	1604	Removal and Installation	1650
Wiring Diagram	1606	HO2S2 HEATER	1651
Diagnostic Procedure	1608	Description	1651
Main 12 Causes of Overheating	1618	CONSULT-II Reference Value in Data Monitor Mode	1651
Component Inspection	1619	Wiring Diagram	1652
DTC P1223, P1224 TP SENSOR	1620	Diagnostic Procedure	1653
Component Description	1620	Component Inspection	1655
CONSULT-II Reference Value in Data Monitor Mode	1620	Removal and Installation	1655
On Board Diagnosis Logic	1620	IAT SENSOR	1656
DTC Confirmation Procedure	1620	Component Description	1656
Wiring Diagram	1622	Wiring Diagram	1657
Diagnostic Procedure	1623	Diagnostic Procedure	1658
Component Inspection	1625	Component Inspection	1659
Remove and Installation	1625	Removal and Installation	1659
DTC P1225 TP SENSOR	1626	HO2S1	1660
Component Description	1626	Component Description	1660
On Board Diagnosis Logic	1626	CONSULT-II Reference Value in Data Monitor Mode	1660
DTC Confirmation Procedure	1626	Wiring Diagram	1661
Diagnostic Procedure	1627	Diagnostic Procedure	1662
Remove and Installation	1627	Component Inspection	1664
DTC P1226 TP SENSOR	1628	Removal and Installation	1665
Component Description	1628	HO2S2	1666
On Board Diagnosis Logic	1628	Component Description	1666
DTC Confirmation Procedure	1628	CONSULT-II Reference Value in Data Monitor Mode	1666
Diagnostic Procedure	1629	Wiring Diagram	1667
Remove and Installation	1629	Diagnostic Procedure	1668
DTC P1227, P1228 APP SENSOR	1630	Component Inspection	1669
Component Description	1630	Removal and Installation	1671
CONSULT-II Reference Value in Data Monitor Mode	1630	IGNITION SIGNAL	1672
On Board Diagnosis Logic	1630	Component Description	1672
DTC Confirmation Procedure	1630	Wiring Diagram	1673
Wiring Diagram	1632	Diagnostic Procedure	1676
Diagnostic Procedure	1633	Component Inspection	1680
Component Inspection	1635	Removal and Installation	1681
Remove and Installation	1636	EVAP CANISTER PURGE VOLUME CONTROL	
DTC P1229 SENSOR POWER SUPPLY	1637		
On Board Diagnosis Logic	1637		

SOLENOID VALVE	1682	SERVICE DATA AND SPECIFICATIONS (SDS) ..	1728
Description	1682	Fuel Pressure	1728
CONSULT-II Reference Value in Data Monitor Mode	1682	Idle Speed and Ignition Timing	1728
Wiring Diagram	1683	Calculated Load Value	1728
Diagnostic Procedure	1685	Mass Air Flow Sensor	1728
Component Inspection	1688	Intake Air Temperature Sensor	1728
Removal and Installation	1688	Engine Coolant Temperature Sensor	1728
IVT CONTROL SOLENOID VALVE	1689	Heated Oxygen Sensor 1 Heater	1728
Description	1689	Heated Oxygen sensor 2 Heater	1728
CONSULT-II Reference Value in Data Monitor Mode	1689	Crankshaft Position Sensor (POS)	1728
Wiring Diagram	1691	Camshaft Position Sensor (PHASE)	1728
Diagnostic Procedure	1692	Throttle Control Motor	1729
Component Inspection	1694	Injector	1729
Removal and Installation	1694	Fuel Pump	1729
PNP SWITCH	1695		
Component Description	1695		
CONSULT-II Reference Value in Data Monitor Mode	1695		
Wiring Diagram	1696		
Diagnostic Procedure	1697		
INJECTOR CIRCUIT	1699		
Component Description	1699		
CONSULT-II Reference Value in Data Monitor Mode	1699		
Wiring Diagram	1700		
Diagnostic Procedure	1701		
Component Inspection	1704		
Removal and Installation	1704		
FUEL PUMP CIRCUIT	1705		
Description	1705		
CONSULT-II Reference Value in Data Monitor Mode	1705		
Wiring Diagram	1706		
Diagnostic Procedure	1707		
Component Inspection	1709		
Removal and Installation	1710		
REFRIGERANT PRESSURE SENSOR	1711		
Component Description	1711		
Wiring Diagram	1712		
Diagnostic Procedure	1713		
Removal and Installation	1715		
ELECTRICAL LOAD SIGNAL	1716		
Description	1716		
CONSULT-II Reference Value in Data Monitor Mode	1716		
Wiring Diagram	1717		
Diagnostic Procedure	1718		
MI & DATA LINK CONNECTORS	1721		
Wiring Diagram (LHD Models)	1721		
Wiring Diagram (RHD Models)	1722		
EVAPORATIVE EMISSION SYSTEM	1723		
Description	1723		
Component Inspection	1725		
POSITIVE CRANKCASE VENTILATION	1726		
Description	1726		
Component Inspection	1726		
		YD	
		INDEX FOR DTC	1730
		Alphabetical Index	1730
		DTC No. Index	1730
		PRECAUTIONS	1732
		Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	1732
		Precautions	1732
		Wiring Diagrams and Trouble Diagnosis	1734
		ENGINE CONTROL SYSTEM	1735
		System Diagram	1735
		Vacuum Hose Drawing	1736
		System Chart	1737
		Fuel Injection Control System	1737
		Fuel Injection Timing Control System	1739
		Air Conditioning Cut Control	1739
		Fuel Cut Control (At No Load & High Engine Speed)	1739
		Crankcase Ventilation System	1740
		CAN communication	1740
		BASIC SERVICE PROCEDURE	1745
		Fuel Filter	1745
		Accelerator Pedal Released Position Learning	1745
		Fuel Pressure Relief Valve	1746
		ON BOARD DIAGNOSTIC (OBD) SYSTEM	1748
		DTC and MI Detection Logic	1748
		Diagnostic Trouble Code (DTC)	1748
		NATS (Nissan Anti-theft System)	1748
		Malfunction Indicator (MI)	1749
		TROUBLE DIAGNOSIS	1751
		Trouble Diagnosis Introduction	1751
		Basic Inspection	1754
		Symptom Matrix Chart	1758
		Engine Control Component Parts Location	1762
		Circuit Diagram	1765
		ECM Harness Connector Terminal Layout	1767
		ECM Terminals And Reference Value	1767
		CONSULT-II Function	1773
		CONSULT-II Reference Value in Data Monitor Mode	1779
		Major Sensor Reference Graph in Data Monitor Mode	1781

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT	1783	Component Inspection	1813
Description	1783	Removal and Installation	1813
Diagnostic Procedure	1783	DTC P0201 - P0204 FUEL INJECTOR	1814
POWER SUPPLY CIRCUIT FOR ECM	1784	Description	1814
ECM Terminals and Reference Value	1784	CONSULT-II Reference Value in Data Monitor Mode	1814
Wiring Diagram	1785	ECM Terminals and Reference Value	1814
Diagnostic Procedure	1786	On Board Diagnosis Logic	1815
Component Inspection	1789	DTC Confirmation Procedure	1816
DTC U1000 CAN COMMUNICATION LINE	1790	Wiring Diagram	1817
Description	1790	Diagnostic Procedure	1819
On Board Diagnosis Logic	1790	Component Inspection	1820
DTC Confirmation Procedure	1790	Removal and Installation	1820
Wiring Diagram	1791	DTC P0235 CHARGE AIR PRESSURE SENSOR	1821
Diagnostic Procedure	1792	Component Description	1821
DTC P0100 MASS AIR FLOW SENSOR (MAFS)	1793	ECM Terminals and Reference Value	1821
Component Description	1793	On Board Diagnosis Logic	1821
CONSULT-II Reference Value in Data Monitor Mode	1793	DTC Confirmation Procedure	1821
ECM Terminals and Reference Value	1793	Wiring Diagram	1823
On Board Diagnosis Logic	1794	Diagnostic Procedure	1824
DTC Confirmation Procedure	1794	Component Inspection	1826
Wiring Diagram	1795	Removal and Installation	1826
Diagnostic Procedure	1796	DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)	1827
Component Inspection	1797	Description	1827
Removal and Installation	1797	CONSULT-II Reference Value in Data Monitor Mode	1827
DTC P0115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR (CIRCUIT)	1798	ECM Terminals and Reference Value	1827
Description	1798	On Board Diagnosis Logic	1828
On Board Diagnosis Logic	1798	DTC Confirmation Procedure	1828
DTC Confirmation Procedure	1798	Wiring Diagram	1829
Wiring Diagram	1799	Diagnostic Procedure	1830
Diagnostic Procedure	1800	Component Inspection	1830
Component Inspection	1801	Removal and Installation	1831
Removal and Installation	1801	DTC P0340 CAMSHAFT POSITION SENSOR	1832
DTC P0120 ACCELERATOR PEDAL POSITION SENSOR	1802	Description	1832
Description	1802	ECM Terminals and Reference Value	1832
CONSULT-II Reference Value in Data Monitor Mode	1802	On Board Diagnosis Logic	1832
ECM Terminals and Reference Value	1802	DTC Confirmation Procedure	1832
On Board Diagnosis Logic	1803	Wiring Diagram	1834
DTC Confirmation Procedure	1803	Diagnostic Procedure	1835
Wiring Diagram	1804	Component Inspection	1835
Diagnostic Procedure	1805	Removal and Installation	1836
Component Inspection	1809	DTC P0500 VEHICLE SPEED SENSOR (VSS)	1837
Removal and Installation	1809	Description	1837
DTC P0190 COMMON RAIL FUEL PRESSURE SENSOR	1810	On Board Diagnosis Logic	1837
Description	1810	Overall Function Check	1837
CONSULT-II Reference Value in Data Monitor Mode	1810	Diagnostic Procedure	1837
ECM Terminals and Reference Value	1810	DTC P1107 ABSOLUTE PRESSURE SENSOR	1838
On Board Diagnosis Logic	1810	Description	1838
DTC Confirmation Procedure	1810	On Board Diagnosis Logic	1838
Wiring Diagram	1811	DTC Confirmation Procedure	1838
Diagnostic Procedure	1812	Diagnostic Procedure	1838
Component Inspection	1813	DTC P1180 FUEL TEMPERATURE SENSOR	1840
Removal and Installation	1813	Description	1840
DTC Confirmation Procedure	1816	CONSULT-II Reference Value in Data Monitor Mode	1840
Wiring Diagram	1817	ECM Terminals and Reference Value	1840
Diagnostic Procedure	1819		
Component Inspection	1820		
Removal and Installation	1820		

On Board Diagnosis Logic	1840	Wiring Diagram	1878
DTC Confirmation Procedure	1840	Diagnostic Procedure	1879
Wiring Diagram	1841	Component Inspection	1880
Diagnostic Procedure	1842	Removal and Installation	1880
Removal and Installation	1842	DTC P1606 ECM	1881
DTC P1216 EDU	1843	Description	1881
Description	1843	On Board Diagnosis Logic	1881
ECM Terminals and Reference Value	1843	DTC Confirmation Procedure	1881
On Board Diagnosis Logic	1844	Diagnostic Procedure	1881
DTC Confirmation Procedure	1844	DTC P1621 ECM RELAY	1883
Wiring Diagram	1845	ECM Terminals and Reference valve	1883
Diagnostic Procedure	1847	On Board Diagnosis Logic	1883
Removal and Installation	1849	DTC Confirmation Procedure	1883
DTC P1217 OVERHEAT (COOLING SYSTEM) ...	1850	Wiring Diagram	1884
Description	1850	Diagnostic Procedure	1885
CONSULT-II Reference Value in Data Monitor Mode	1850	Component Inspection	1886
ECM Terminals and Reference Value	1850	DTC P1660 BATTERY VOLTAGE	1887
On Board Diagnosis Logic	1851	On Board Diagnosis Logic	1887
Overall Function Check	1851	DTC Confirmation Procedure	1887
Wiring Diagram	1853	Diagnostic Procedure	1887
Diagnostic Procedure	1855	GLOW CONTROL SYSTEM	1889
Main 12 Causes of Overheating	1863	Description	1889
Component Inspection	1864	ECM Terminals and Reference Value	1889
DTC P1233 - P1234 SUCTION CONTROL VALVE	1865	Wiring Diagram	1890
Description	1865	Diagnostic Procedure	1891
CONSULT-II Reference Value in Data Monitor Mode	1865	Component Inspection	1894
ECM Terminals and Reference Value	1865	Removal and Installation	1895
On Board Diagnosis Logic	1866	EGR VOLUME CONTROL SYSTEM	1896
DTC Confirmation Procedure	1866	Description	1896
Wiring Diagram	1867	CONSULT-II Reference Value in Data Monitor Mode	1896
Diagnostic Procedure	1868	ECM Terminals and Reference Value	1897
Component Inspection	1868	Wiring Diagram	1898
Removal and Installation	1869	Diagnostic Procedure	1899
DTC P1301 - P1304 FUEL INJECTOR ADJUST-		Component Inspection	1901
MENT RESISTOR	1870	Removal and Installation	1902
Description	1870	VARIABLE NOZZLE TURBOCHARGER CON-	
ECM Terminals and Reference Value	1870	TROL SOLENOID VALVE	1903
On Board Diagnosis Logic	1870	Description	1903
DTC Confirmation Procedure	1870	ECM Terminals and Reference Value	1903
Wiring Diagram	1871	Wiring Diagram	1904
Diagnostic Procedure	1872	Diagnostic Procedure	1905
Component Inspection	1873	Component Inspection	1907
Removal and Installation	1873	Removal and Installation	1908
DTC P1305 FUEL LEAK	1874	BRAKE SWITCH	1909
On Board Diagnosis Logic	1874	Description	1909
DTC Confirmation Procedure	1874	ECM Terminals and Reference Value	1909
Diagnostic Procedure	1874	Wiring Diagram	1910
Removal and Installation	1874	Diagnostic Procedure	1911
DTC P1510 ACCELERATOR PEDAL RELEASED		Component Inspection	1912
POSITION SWITCH	1876	PARK/NEUTRAL POSITION (PNP) SWITCH	1913
Description	1876	Description	1913
CONSULT-II Reference Value in Data Monitor Mode	1876	CONSULT-II Reference Value in Data Monitor Mode	1913
ECM Terminals and Reference Value	1876	ECM Terminals and Reference Value	1913
On Board Diagnosis Logic	1877	Wiring Diagram	1914
DTC Confirmation Procedure	1877	Diagnostic Procedure	1915

START SIGNAL	1916	MI & DATA LINK CONNECTORS	1922
Wiring Diagram	1916	Wiring Diagram	1922
Diagnostic Procedure	1917	SERVICE DATA AND SPECIFICATIONS (SDS) ..	1923
POWER STEERING OIL PRESSURE SWITCH ..	1918	General Specifications	1923
Component Description	1918	Mass Air Flow Sensor	1923
CONSULT-II Reference Value in Data Monitor Mode		Engine Coolant Temperature Sensor	1923
ECM Terminals and Reference Value	1918	Common Rail Fuel Pressure Sensor	1923
Wiring Diagram	1919	Crankshaft Position Sensor (TDC)	1923
Diagnostic Procedure	1920	Camshaft Position Sensor	1923
Component Inspection	1921	Glow Plug	1923
Removal and Installation	1921	EGR Volume Control Valve	1923

INDEX FOR DTC

PFP:00024

Alphabetical Index

EBS00EL6

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#) .

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-150, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

QG16DE ENGINE MODELS

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
APP SEN 1/CIRC*5	P0227	0227	EC-331
APP SEN 1/CIRC*5	P0228	0228	EC-331
APP SEN 2/CIRC*5	P1227	1227	EC-500
APP SEN 2/CIRC*5	P1228	1228	EC-500
APP SENSOR*5	P0226	0226	EC-324
BRAKE SW/CIRCUIT	P1805	1805	EC-515
CAN COMM CIRCUIT	U1001	1001*6	EC-150
CKP SEN/CIRCUIT	P0335	0335	EC-348
CMP SEN/CIRC-B1	P0340	0340	EC-355
CTP LEARNING	P1225	1225	EC-496
CTP LEARNING	P1226	1226	EC-498
CYL 1 MISFIRE	P0301	0301	EC-338
CYL 2 MISFIRE	P0302	0302	EC-338
CYL 3 MISFIRE	P0303	0303	EC-338
CYL 4 MISFIRE	P0304	0304	EC-338
ECM	P0605	0605	EC-382
ECM BACK UP/CIRC	P1065	1065	EC-385
ECT SEN/CIRCUIT*5	P0117	0117	EC-194
ECT SEN/CIRCUIT*5	P0118	0118	EC-194
ENG OVER TEMP	P1217	1217	EC-480
ETC ACTR*5	P1121	1121	EC-400
ETC FUNCTION/CIRC*5	P1122	1122	EC-402
ETC MOT*5	P1128	1128	EC-415
ETC MOT PWR*5	P1124	1124	EC-409
ETC MOT PWR*5	P1126	1126	EC-409
FUEL SYS-LEAN-B1	P0171	0171	EC-285
FUEL SYS-RICH-B1	P0172	0172	EC-299
HO2S1 (B1)	P0132	0132	EC-199
HO2S1 (B1)	P0133	0133	EC-214
HO2S1 (B1)	P0134	0134	EC-234
HO2S1 (B1)	P1143	1143	EC-420
HO2S1 (B1)	P1144	1144	EC-432

INDEX FOR DTC

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
HO2S1 HTR (B1)	P0031	0031	EC-156
HO2S1 HTR (B1)	P0032	0032	EC-156
HO2S2 (B1)	P0138	0138	EC-251
HO2S2 (B1)	P0139	0139	EC-267
HO2S2 (B1)	P1146	1146	EC-444
HO2S2 (B1)	P1147	1147	EC-462
HO2S2 HTR (B1)	P0037	0037	EC-170
HO2S2 HTR (B1)	P0038	0038	EC-170
IAT SEN/CIRCUIT	P0112	0112	EC-189
IAT SEN/CIRCUIT	P0113	0113	EC-189
INT/V TIM CONT-B1	P0011	0011	EC-153
INT/V TIM V/CIR-B1	P1111	1111	EC-395
KNOCK SEN/CIRC-B1	P0327	0327	EC-344
KNOCK SEN/CIRC-B1	P0328	0328	EC-344
MAF SEN/CIRCUIT*5	P0102	0102	EC-183
MAF SEN/CIRCUIT*5	P0103	0103	EC-183
MAF SENSOR*5	P1102	1102	EC-389
MULTI CYL MISFIRE	P0300	0300	EC-338
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-75
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	EC-76
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
P-N POS SW/CIRCUIT	P1706	1706	EC-511
PURG VOLUME CONT/V	P0444	0444	EC-369
PURG VOLUME CONT/V	P0445	0445	EC-369
PW ST P SEN/CIRC	P0550	0550	EC-377
SENSOR POWER/CIRC*5	P1229	1229	EC-507
TP SEN 1/CIRC*5	P0222	0222	EC-318
TP SEN 1/CIRC*5	P0223	0223	EC-318
TP SEN 2/CIRC*5	P1223	1223	EC-490
TP SEN 2/CIRC*5	P1224	1224	EC-490
TP SENSOR*5	P0221	0221	EC-312
TW CATALYST SYS-B1	P0420	0420	EC-361
VEH SPEED SEN/CIRC	P0500	0500	EC-375

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for this DTC needs CONSULT-II.

INDEX FOR DTC

[QG (WITH EURO-OBD)]

QR18DE ENGINE MODELS

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
A/T 1ST GR FNCTN	P0731	0731	AT-131
A/T 2ND GR FNCTN	P0732	0732	AT-138
A/T 3RD GR FNCTN	P0733	0733	AT-144
A/T 4TH GR FNCTN	P0734	0734	AT-150
APP SEN 1/CIRC*5	P0227	0227	EC-331
APP SEN 1/CIRC*5	P0228	0228	EC-331
APP SEN 2/CIRC*5	P1227	1227	EC-500
APP SEN 2/CIRC*5	P1228	1228	EC-500
APP SENSOR*5	P0226	0226	EC-324
ATF TEMP SEN/CIRC	P0710	0710	AT-116
BRAKE SW/CIRCUIT	P1805	1805	EC-515
CAN COMM CIRCUIT	U1000	1000*6	EC-150
CAN COMM CIRCUIT	U1001	1001*6	EC-150
CKP SEN/CIRCUIT	P0335	0335	EC-348
CMP SEN/CIRC-B1	P0340	0340	EC-355
CTP LEARNING	P1225	1225	EC-496
CTP LEARNING	P1226	1226	EC-498
CYL 1 MISFIRE	P0301	0301	EC-338
CYL 2 MISFIRE	P0302	0302	EC-338
CYL 3 MISFIRE	P0303	0303	EC-338
CYL 4 MISFIRE	P0304	0304	EC-338
ECM	P0605	0605	EC-382
ECM BACK UP/CIRC	P1065	1065	EC-385
ECT SEN/CIRCUIT*5	P0117	0117	EC-194
ECT SEN/CIRCUIT*5	P0118	0118	EC-194
ENG OVER TEMP	P1217	1217	EC-480
ENGINE SPEED SIG	P0725	0725	AT-127
ETC ACTR*5	P1121	1121	EC-400
ETC FUNCTION/CIRC*5	P1122	1122	EC-402
ETC MOT*5	P1128	1128	EC-415
ETC MOT PWR*5	P1124	1124	EC-409
ETC MOT PWR*5	P1126	1126	EC-409
FUEL SYS-LEAN-B1	P0171	0171	EC-291
FUEL SYS-LEAN-B2	P0174	0174	EC-291
FUEL SYS-RICH-B1	P0172	0172	EC-305
FUEL SYS-RICH-B2	P0175	0175	EC-305
HO2S1 (B1)	P0132	0132	EC-205
HO2S1 (B1)	P0133	0133	EC-223
HO2S1 (B1)	P0134	0134	EC-241

INDEX FOR DTC

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
HO2S1 (B1)	P1143	1143	EC-426
HO2S1 (B1)	P1144	1144	EC-438
HO2S1 (B2)	P0152	0152	EC-205
HO2S1 (B2)	P0153	0153	EC-223
HO2S1 (B2)	P0154	0154	EC-241
HO2S1 (B2)	P1163	1163	EC-426
HO2S1 (B2)	P1164	1164	EC-438
HO2S1 HTR (B1)	P0031	0031	EC-162
HO2S1 HTR (B1)	P0032	0032	EC-162
HO2S1 HTR (B2)	P0051	0051	EC-162
HO2S1 HTR (B2)	P0052	0052	EC-162
HO2S2 (B1)	P0138	0138	EC-258
HO2S2 (B1)	P0139	0139	EC-275
HO2S2 (B1)	P1146	1146	EC-452
HO2S2 (B1)	P1147	1147	EC-470
HO2S2 (B2)	P0158	0158	EC-258
HO2S2 (B2)	P0159	0159	EC-275
HO2S2 (B2)	P1166	1166	EC-452
HO2S2 (B2)	P1167	1167	EC-470
HO2S2 HTR (B1)	P0037	0037	EC-175
HO2S2 HTR (B1)	P0038	0038	EC-175
HO2S2 HTR (B2)	P0057	0057	EC-175
HO2S2 HTR (B2)	P0058	0058	EC-175
IAT SEN/CIRCUIT	P0112	0112	EC-189
IAT SEN/CIRCUIT	P0113	0113	EC-189
INT/V TIM CONT-B1	P0011	0011	EC-153
INT/V TIM V/CIR-B1	P1111	1111	EC-395
KNOCK SEN/CIRC-B1	P0327	0327	EC-344
KNOCK SEN/CIRC-B1	P0328	0328	EC-344
L/PRESS SOL/CIRC	P0745	0745	AT-163
MAF SEN/CIRCUIT*5	P0102	0102	EC-183
MAF SEN/CIRCUIT*5	P0103	0103	EC-183
MAF SENSOR*5	P1102	1102	EC-389
MULTI CYL MISFIRE	P0300	0300	EC-338
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-75
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	EC-76
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
O/R CLTCH SOL/CIRC	P1760	1760	AT-185
P-N POS SW/CIRCUIT	P1706	1706	EC-511

INDEX FOR DTC

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
PNP SW/CIRC	P0705	0705	AT-110
PURG VOLUME CONT/V	P0444	0444	EC-369
PURG VOLUME CONT/V	P0445	0445	EC-369
PW ST P SEN/CIRC	P0550	0550	EC-377
SENSOR POWER/CIRC*5	P1229	1229	EC-507
SFT SOL A/CIRC*5	P0750	0750	AT-170
SFT SOL B/CIRC*5	P0755	0755	AT-175
TCC SOLENOID/CIRC	P0740	0740	AT-158
TP SEN 1/CIRC*5	P0222	0222	EC-318
TP SEN 1/CIRC*5	P0223	0223	EC-318
TP SEN 2/CIRC*5	P1223	1223	EC-490
TP SEN 2/CIRC*5	P1224	1224	EC-490
TP SENSOR*5	P0221	0221	EC-312
TPV SEN/CIRC A/T	P1705	1705	AT-180
TW CATALYST SYS-B1	P0420	0420	EC-365
TW CATALYST SYS-B2	P0430	0430	EC-365
VEH SPD SEN/CIR AT*7	P0720	0720	AT-122
VEH SPEED SEN/CIRC*7	P0500	0500	EC-375

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The trouble shooting for these DTCs needs CONSULT-II.

*7: When the fail-safe operations for both self-diagnoses occur, the MI illuminates.

NOTE:

Regarding P12 models with QG18DE engine, "B1" indicates bank 1, "B2" indicates bank 2.

DTC No. Index

EBS00EL7

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#).

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-150, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

QG16DE ENGINE MODELS

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-76
U1001	1001*6	CAN COMM CIRCUIT	EC-150
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—

INDEX FOR DTC

[QG (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0011	0011	INT/V TIM CONT-B1	EC-153
P0031	0031	HO2S1 HTR (B1)	EC-156
P0032	0032	HO2S1 HTR (B1)	EC-156
P0037	0037	HO2S2 HTR (B1)	EC-170
P0038	0038	HO2S2 HTR (B1)	EC-170
P0102	0102	MAF SEN/CIRCUIT*5	EC-183
P0103	0103	MAF SEN/CIRCUIT*5	EC-183
P0112	0112	IAT SEN/CIRCUIT	EC-189
P0113	0113	IAT SEN/CIRCUIT	EC-189
P0117	0117	ECT SEN/CIRCUIT*5	EC-194
P0118	0118	ECT SEN/CIRCUIT*5	EC-194
P0132	0132	HO2S1 (B1)	EC-199
P0133	0133	HO2S1 (B1)	EC-214
P0134	0134	HO2S1 (B1)	EC-234
P0138	0138	HO2S2 (B1)	EC-251
P0139	0139	HO2S2 (B1)	EC-267
P0171	0171	FUEL SYS-LEAN-B1	EC-285
P0172	0172	FUEL SYS-RICH-B1	EC-299
P0221	0221	TP SENSOR*5	EC-312
P0222	0222	TP SEN 1/CIRC*5	EC-318
P0223	0223	TP SEN 1/CIRC*5	EC-318
P0226	0226	APP SENSOR*5	EC-324
P0227	0227	APP SEN 1/CIRC*5	EC-331
P0228	0228	APP SEN 1/CIRC*5	EC-331
P0300	0300	MULTI CYL MISFIRE	EC-338
P0301	0301	CYL 1 MISFIRE	EC-338
P0302	0302	CYL 2 MISFIRE	EC-338
P0303	0303	CYL 3 MISFIRE	EC-338
P0304	0304	CYL 4 MISFIRE	EC-338
P0327	0327	KNOCK SEN/CIRC-B1	EC-344
P0328	0328	KNOCK SEN/CIRC-B1	EC-344
P0335	0335	CKP SEN/CIRCUIT	EC-348
P0340	0340	CMP SEN/CIRC-B1	EC-355
P0420	0420	TW CATALYST SYS-B1	EC-361
P0444	0444	PURG VOLUME CONT/V	EC-369
P0445	0445	PURG VOLUME CONT/V	EC-369
P0500	0500	VEH SPEED SEN/CIRC	EC-375
P0550	0550	PW ST P SEN/CIRC	EC-377
P0605	0605	ECM	EC-382
P1065	1065	ECM BACK UP/CIRC	EC-385

INDEX FOR DTC

[QG (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P1102	1102	MAF SENSOR*5	EC-389
P1111	1111	INT/V TIM V/CIR-B1	EC-395
P1121	1121	ETC ACTR*5	EC-400
P1122	1122	ETC FUNCTION/CIRC*5	EC-402
P1124	1124	ETC MOT PWR*5	EC-409
P1126	1126	ETC MOT PWR*5	EC-409
P1128	1128	ETC MOT*5	EC-415
P1143	1143	HO2S1 (B1)	EC-420
P1144	1144	HO2S1 (B1)	EC-432
P1146	1146	HO2S2 (B1)	EC-444
P1147	1147	HO2S2 (B1)	EC-462
P1217	1217	ENG OVER TEMP	EC-480
P1223	1223	TP SEN 2/CIRC*5	EC-490
P1224	1224	TP SEN 2/CIRC*5	EC-490
P1225	1225	CTP LEARNING	EC-496
P1226	1226	CTP LEARNING	EC-498
P1227	1227	APP SEN 2/CIRC*5	EC-500
P1228	1228	APP SEN 2/CIRC*5	EC-500
P1229	1229	SENSOR POWER/CIRC*5	EC-507
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-75
P1706	1706	P-N POS SW/CIRCUIT	EC-511
P1805	1805	BRAKE SW/CIRCUIT	EC-515

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The trouble shooting for this DTC needs CONSULT-II.

QG18DE ENGINE MODELS

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-76
U1000	1000*6	CAN COMM CIRCUIT	EC-150
U1001	1001*6	CAN COMM CIRCUIT	EC-150
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—
P0011	0011	INT/V TIM CONT-B1	EC-153
P0031	0031	HO2S1 HTR (B1)	EC-162

INDEX FOR DTC

[QG (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0032	0032	HO2S1 HTR (B1)	EC-162
P0037	0037	HO2S2 HTR (B1)	EC-175
P0038	0038	HO2S2 HTR (B1)	EC-175
P0051	0051	HO2S1 HTR (B2)	EC-162
P0052	0052	HO2S1 HTR (B2)	EC-162
P0057	0057	HO2S2 HTR (B2)	EC-175
P0058	0058	HO2S2 HTR (B2)	EC-175
P0102	0102	MAF SEN/CIRCUIT*5	EC-183
P0103	0103	MAF SEN/CIRCUIT*5	EC-183
P0112	0112	IAT SEN/CIRCUIT	EC-189
P0113	0113	IAT SEN/CIRCUIT	EC-189
P0117	0117	ECT SEN/CIRCUIT*5	EC-194
P0118	0118	ECT SEN/CIRCUIT*5	EC-194
P0132	0132	HO2S1 (B1)	EC-205
P0133	0133	HO2S1 (B1)	EC-223
P0134	0134	HO2S1 (B1)	EC-241
P0138	0138	HO2S2 (B1)	EC-258
P0139	0139	HO2S2 (B1)	EC-275
P0152	0152	HO2S1 (B2)	EC-205
P0153	0153	HO2S1 (B2)	EC-223
P0154	0154	HO2S1 (B2)	EC-241
P0158	0158	HO2S2 (B2)	EC-258
P0159	0159	HO2S2 (B2)	EC-275
P0171	0171	FUEL SYS-LEAN-B1	EC-291
P0172	0172	FUEL SYS-RICH-B1	EC-305
P0174	0174	FUEL SYS-LEAN-B2	EC-291
P0175	0175	FUEL SYS-RICH-B2	EC-305
P0221	0221	TP SENSOR*5	EC-312
P0222	0222	TP SEN 1/CIRC*5	EC-318
P0223	0223	TP SEN 1/CIRC*5	EC-318
P0226	0226	APP SENSOR*5	EC-324
P0227	0227	APP SEN 1/CIRC*5	EC-331
P0228	0228	APP SEN 1/CIRC*5	EC-331
P0300	0300	MULTI CYL MISFIRE	EC-338
P0301	0301	CYL 1 MISFIRE	EC-338
P0302	0302	CYL 2 MISFIRE	EC-338
P0303	0303	CYL 3 MISFIRE	EC-338
P0304	0304	CYL 4 MISFIRE	EC-338
P0327	0327	KNOCK SEN/CIRC-B1	EC-344
P0328	0328	KNOCK SEN/CIRC-B1	EC-344

INDEX FOR DTC

[QG (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0335	0335	CKP SEN/CIRCUIT	EC-348
P0340	0340	CMP SEN/CIRC-B1	EC-355
P0420	0420	TW CATALYST SYS-B1	EC-365
P0430	0430	TW CATALYST SYS-B2	EC-365
P0444	0444	PURG VOLUME CONT/V	EC-369
P0445	0445	PURG VOLUME CONT/V	EC-369
P0500	0500	VEH SPEED SEN/CIRC*7	EC-375
P0550	0550	PW ST P SEN/CIRC	EC-377
P0605	0605	ECM	EC-382
P0705	0705	PNP SW/CIRC	AT-110
P0710	0710	ATF TEMP SEN/CIRC	AT-116
P0720	0720	VEH SPD SEN/CIRC AT*7	AT-122
P0725	0725	ENGINE SPEED SIG	AT-127
P0731	0731	A/T 1ST GR FNCTN	AT-131
P0732	0732	A/T 2ND GR FNCTN	AT-138
P0733	0733	A/T 3RD GR FNCTN	AT-144
P0734	0734	A/T 4TH GR FNCTN	AT-150
P0740	0740	TCC SOLENOID/CIRC	AT-158
P0745	0745	L/PRESS SOL/CIRC	AT-163
P0750	0750	SFT SOL A/CIRC*5	AT-170
P0755	0755	SFT SOL B/CIRC*5	AT-175
P1065	1065	ECM BACK UP/CIRC	EC-385
P1102	1102	MAF SENSOR*5	EC-389
P1111	1111	INT/V TIM V/CIR-B1	EC-395
P1121	1121	ETC ACTR*5	EC-400
P1122	1122	ETC FUNCTION/CIRC*5	EC-402
P1124	1124	ETC MOT PWR*5	EC-409
P1126	1126	ETC MOT PWR*5	EC-409
P1128	1128	ETC MOT*5	EC-415
P1143	1143	HO2S1 (B1)	EC-426
P1144	1144	HO2S1 (B1)	EC-438
P1146	1146	HO2S2 (B1)	EC-452
P1147	1147	HO2S2 (B1)	EC-470
P1163	1163	HO2S1 (B2)	EC-426
P1164	1164	HO2S1 (B2)	EC-438
P1166	1166	HO2S2 (B2)	EC-452
P1167	1167	HO2S2 (B2)	EC-470
P1217	1217	ENG OVER TEMP	EC-480
P1223	1223	TP SEN 2/CIRC*5	EC-490
P1224	1224	TP SEN 2/CIRC*5	EC-490

A
EC
C
D
E
F
G
H
I
J
K
L
M

INDEX FOR DTC

[QG (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P1225	1225	CTP LEARNING	EC-496
P1226	1226	CTP LEARNING	EC-498
P1227	1227	APP SEN 2/CIRC*5	EC-500
P1228	1228	APP SEN 2/CIRC*5	EC-500
P1229	1229	SENSOR POWER/CIRC*5	EC-507
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-75
P1705	1705	TPV SEN/CIRC A/T	AT-180
P1706	1706	P-N POS SW/CIRCUIT	EC-511
P1760	1760	O/R CLTCH SOL/CIRC	AT-185
P1805	1805	BRAKE SW/CIRCUIT	EC-515

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The trouble shooting for these DTCs need CONSULT-II.

*7: When the fail-safe operations for both self-diagnoses occur at the same time, the MI illuminates.

NOTE:

Regarding P12 models with QG18DE engine, "B1" indicates bank 1, "B2" indicates bank 2.

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EBS00EL8

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

On Board Diagnostic (OBD) System of Engine and A/T

EBS00EL9

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.


CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery ground cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-86. "HARNESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.

Precaution

EBS00ELA


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery ground cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




PRECAUTIONS

[QG (WITH EURO-OBD)]


- Do not disassemble ECM.
- If battery cable is disconnected, the memory will return to the initial ECM values.
The ECM will now start to self-control at its initial values. Engine operation can vary slightly when the cable is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown at right.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.




- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-107, "ECM Terminals and Reference Value"](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




PRECAUTIONS

[QG (WITH EURO-OBD)]


- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.





PRECAUTIONS

[QG (WITH EURO-OBD)]

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.
- Regarding P12 models with QG18DE engine, "B1" indicates bank 1 (cylinders number 1 and 4), "B2" indicates bank 2 (cylinders number 2 and 3).



Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)





EBS00ELB

PREPARATION

PFP:00002



Special Service Tools

EBS00ELC

Tool number Tool name	Description	
KV10117100 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT379</p>	Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT636</p>	Loosening or tightening heated oxygen sensors a: 22 mm (0.87 in)
KV109E0010 Break-out box	 <p style="text-align: center;">S-NT825</p>	Measuring the ECM signals with a circuit tester
KV109E0080 Y-cable adapter	 <p style="text-align: center;">S-NT826</p>	Measuring the ECM signals with a circuit tester




Commercial Service Tools

EBS00ELD

Tool name	Description	
Quick connector release	 <p style="text-align: center;">PBIC0198E</p>	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)
Fuel filler cap adapter	 <p style="text-align: center;">S-NT653</p>	Checking fuel tank vacuum relief valve opening pressure

PREPARATION

[QG (WITH EURO-OBD)]


Tool name	Description	
Socket wrench	 <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.26 in)</p> <p>S-NT705</p>	Removing and installing engine coolant temperature sensor
Oxygen sensor thread cleaner ie: (J-43897-18) (J-43897-12)	 <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> <p>AEM488</p>	Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor
Anti-seize lubricant ie: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p>S-NT779</p>	Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.

ENGINE CONTROL SYSTEM

PF23710

System Diagram - QG16DE Engine Models

EBS00ELE



A

EC

C

D

E

F

G

H

I

J

K

L

M


MBIB0011E

ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

System Diagram - QG18DE Engine Models


EBS00GBC



MBIB0012E

Vacuum Hose Drawing

EBS00ELF



NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

MBIB0013E

Refer to [EC-39. "System Diagram - QG16DE Engine Models"](#) or [EC-40. "System Diagram - QG18DE Engine Models"](#) for Vacuum Control System.

A
EC
C
D
E
F
G
H
I
J
K
L
M

ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

System Chart

EBS00ELG

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor (PHASE) ● Crankshaft position sensor (POS) ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Throttle position sensor ● Accelerator pedal position sensor ● Park/neutral position (PNP) switch ● Intake air temperature sensor ● Power steering pressure sensor ● Ignition switch ● Stop lamp switch ● Battery voltage ● Knock sensor ● Refrigerant pressure sensor ● Heated oxygen sensor 2^{*1} ● TCM (Transmission control module)^{*2} ● Air conditioner switch^{*2} ● Vehicle speed signal^{*2} ● Electrical load signal^{*2} 	Fuel injection & mixture ratio control	Fuel injectors
	Electronic ignition system	Power transistor
	Fuel pump control	Fuel pump relay
	On board diagnostic system	MI (On the instrument panel) ^{*3}
	Intake valve timing control	Intake valve timing control solenoid valve
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay ^{*3}
	Cooling fan control	Cooling fan relay ^{*3}

*1: This sensor is not used to control the engine system under normal conditions.

*2: The signals are sent to the ECM through CAN communication line.

*3: The output signals are sent from the ECM through CAN communication line.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

EBS00ELH

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed ^{*3} and piston position	Fuel injection & mixture ratio control	Fuel injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage ^{*3}		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2 ^{*2}	Density of oxygen in exhaust gas		
Vehicle speed signal ^{*2}	Vehicle speed		
Air conditioner switch ^{*2}	Air conditioner operation		

*1: Under normal conditions, this sensor is not for engine control operation.

*2: This signal is sent to the ECM through CAN communication line.

*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from the crankshaft position sensor (POS), the camshaft position sensor (PHASE) and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from “N” to “D” (A/T models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about heated oxygen sensor 1, refer to [EC-214](#) (QG16DE engine models) or [EC-223](#) (QG18DE engine models). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from “N” to “D” (A/T models)
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multipoint Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multipoint Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Electronic Ignition (EI) System INPUT/OUTPUT SIGNAL CHART

EBS00ELI

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2 and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage*2		
Vehicle speed signal*1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION


The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown. The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration



The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control INPUT/OUTPUT SIGNAL CHART

EBS00ELJ

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch*1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage*2		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Vehicle speed signal*1	Vehicle speed		

*1: These signals are sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

Fuel Cut Control (at No Load and High Engine Speed) INPUT/OUTPUT SIGNAL CHART

EBS00ELK

Sensor	Input Signal to ECM	ECM Function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injectors
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Vehicle speed signal*1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

If the engine speed is above 3,950 rpm with no load (for example, in neutral and engine speed over 3,950 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under “Multiport Fuel Injection (MFI) System”, [EC-42](#) .

CAN communication SYSTEM DESCRIPTION


EBS00ELL

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

LHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

ENGINE CONTROL SYSTEM


[QG (WITH EURO-OBD)]

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tire pressure signal					T	R

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R ^{*1}		T		
Heater fan switch signal	R ^{*1}				T
Air conditioner switch signal	R				T

ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
MI signal	T				R
Glow lamp signal ^{*2}	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tire pressure signal				T	R


*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

LHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R


ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R

ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	


*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

RHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	


ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
A/C compressor signal	T				R	
Tyre pressure signal				T		R

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R ^{*1}			T	
Heater fan switch signal	R ^{*1}				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal ^{*2}	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	
Tyre pressure signal			T		R

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only


ENGINE CONTROL SYSTEM

[QG (WITH EURO-OBD)]

RHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram




Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

BASIC SERVICE PROCEDURE

PFP:00018

Idle Speed and Ignition Timing Check

IDLE SPEED

EBS00ELM

Ⓜ With CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Ⓜ With GST


Check idle speed in "MODE 1" with GST.

IGNITION TIMING

Any of following two methods may be used.


Method A

1. Slide the harness protector of ignition coil No. 1 to clear the wires.
2. Attach timing light to the wires as shown.
3. Check ignition timing.





Method B

1. Remove No. 1 ignition coil.



- Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.



- Check ignition timing.

Accelerator Pedal Released Position Learning DESCRIPTION

EBS00ELO

“Accelerator Pedal Released Position Learning” is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

- Make sure that accelerator pedal is fully released.
- Turn ignition switch “ON” and wait at least 2 seconds.
- Turn ignition switch “OFF” wait at least 10 seconds.
- Turn ignition switch “ON” and wait at least 2 seconds.
- Turn ignition switch “OFF” wait at least 10 seconds.

Throttle Valve Closed Position Learning DESCRIPTION

EBS00ELP

“Throttle Valve Closed Position Learning” is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

OPERATION PROCEDURE

- Make sure that accelerator pedal is fully released.
- Turn ignition switch “ON”.
- Turn ignition switch “OFF” wait at least 10 seconds.
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

Idle Air Volume Learning DESCRIPTION

EBS00ELQ

“Idle Air Volume Learning” is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

PREPARATION


Before performing "Idle Air Volume Learning", make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 95°C (158 - 203°F)
- PNP switch: ON
- Electric load switch: OFF
(Air conditioner, headlamp, rear window defogger)
On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
For A/T models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.
For A/T models without CONSULT-II and M/T models, drive vehicle for 10 minutes.


OPERATION PROCEDURE

④ With CONSULT-II

1. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.




6. Touch "START" and wait 20 seconds.



BASIC SERVICE PROCEDURE

[QG (WITH EURO-OBD)]

7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "INCMP" is displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.




ITEM	SPECIFICATION
Idle speed	M/T: 700±50 rpm A/T: 800±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 8±5° BTDC A/T: 10±5° BTDC (in "P" or "N" position)

⊗ Without CONSULT-II

NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
 2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
 3. Start engine and warm it up to normal operating temperature.
 4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
 7. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
 8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
 9. Fully release the accelerator pedal within 3 seconds after the MI turned ON.
 10. Start engine and let it idle.
 11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 700±50 rpm A/T: 800±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 8±5° BTDC A/T: 10±5° BTDC (in "P" or "N" position)

13. If idle speed and ignition timing are not within the specification, the result will be incomplete. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.

DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:

1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the problem.
It is useful to perform [EC-139, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).
5. If any of the following conditions occur after the engine has started, eliminate the cause of the problem and perform "Idle air volume learning" all over again:
 - Engine stalls.
 - Erroneous idle.

Fuel Pressure Check FUEL PRESSURE RELEASE

EBS00ELR


Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

NOTE:

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because P12 models do not have fuel return system.


Ⓜ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".



ⓧ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK

NOTE:

- When reconnecting fuel line, always use new clamps.
 - Make sure that clamp screw does not contact adjacent parts.
 - Use a torque driver to tighten clamps.
 - Use Pressure Gauge to check fuel pressure.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
1. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#).


BASIC SERVICE PROCEDURE

[QG (WITH EURO-OBD)]

2. Install the fuel pressure gauge into the fuel line as shown in the figure.
3. Turn ignition switch "ON", and check for fuel leakage.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idling: Approximately 350 kPa (3.7 kg/cm² , 51 psi)

6. If result is unsatisfactory, go to next step.
7. Check the following.
 - Fuel hoses and fuel tubes for clogging
 - Fuel filter for clogging
 - Fuel pump
 - Fuel pressure regulator for cloggingIf OK, replace fuel pressure regulator.
If NG, repair or replace.



A

EC

C

D

E

F

G

H

I

J

K

L

M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

EBS00ELS

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	ISO Standard
Diagnostic Trouble Code (DTC)	Mode 3 of ISO 15031-5
Freeze Frame data	Mode 2 of ISO 15031-5
System Readiness Test (SRT) code	Mode 1 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of ISO 15031-5
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of ISO 15031-5
Calibration ID	Mode 9 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	×	×	×	×	×	—
GST	×	×*1	×	—	×	×
ECM	×	×*2	—	—	—	—

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*2: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-90](#).)

Two Trip Detection Logic

EBS00ELT

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MI, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

×: Applicable —: Not applicable

Items	MI				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	×	—	—	—	—	—	×	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	—	—	×	—	—	×	—	—
Fail-safe items (Refer to EC-90 .)	—	×	—	—	×*1	—	×*1	—
Except above	—	—	—	×	—	×	×	—

*1: Except “ECM”

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS QG16DE Engine Models

EBS00ELU

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
CAN COMM CIRCUIT	U1001	1001*4	—	—	×	EC-150
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—	—	—
INT/V TIM CONT-B1	P0011	0011	—	—	×	EC-153
HO2S1 HTR (B1)	P0031	0031	×	×	×*5	EC-156
HO2S1 HTR (B1)	P0032	0032	×	×	×*5	EC-156
HO2S2 HTR (B1)	P0037	0037	×	×	×*5	EC-170
HO2S2 HTR (B1)	P0038	0038	×	×	×*5	EC-170
MAF SEN/CIRCUIT*3	P0102	0102	—	—	—	EC-183
MAF SEN/CIRCUIT*3	P0103	0103	—	—	—	EC-183
IAT SEN/CIRCUIT	P0112	0112	—	—	×	EC-189
IAT SEN/CIRCUIT	P0113	0113	—	—	×	EC-189
ECT SEN/CIRCUIT*3	P0117	0117	—	—	—	EC-194
ECT SEN/CIRCUIT*3	P0118	0118	—	—	—	EC-194
HO2S1 (B1)	P0132	0132	×	×	×*5	EC-199
HO2S1 (B1)	P0133	0133	×	×	×*5	EC-214
HO2S1 (B1)	P0134	0134	×	×	×*5	EC-234
HO2S2 (B1)	P0138	0138	×	×	×*5	EC-251
HO2S2 (B1)	P0139	0139	×	×	×*5	EC-267
FUEL SYS-LEAN-B1	P0171	0171	—	—	×	EC-285
FUEL SYS-RICH-B1	P0172	0172	—	—	×	EC-299
TP SENSOR*3	P0221	0221	—	—	—	EC-312
TP SEN 1/CIRC*3	P0222	0222	—	—	—	EC-318
TP SEN 1/CIRC*3	P0223	0223	—	—	—	EC-318
APP SENSOR*3	P0226	0226	—	—	—	EC-324
APP SEN 1/CIRC*3	P0227	0227	—	—	—	EC-331
APP SEN 1/CIRC*3	P0228	0228	—	—	—	EC-331
MULTI CYL MISFIRE	P0300	0300	—	—	×	EC-338
CYL 1 MISFIRE	P0301	0301	—	—	×	EC-338
CYL 2 MISFIRE	P0302	0302	—	—	×	EC-338
CYL 3 MISFIRE	P0303	0303	—	—	×	EC-338
CYL 4 MISFIRE	P0304	0304	—	—	×	EC-338
KNOCK SEN/CIRC-B1	P0327	0327	—	—	×	EC-344
KNOCK SEN/CIRC-B1	P0328	0328	—	—	×	EC-344
CKP SEN/CIRCUIT	P0335	0335	—	—	×	EC-348
CMP SEN/CIRC-B1	P0340	0340	—	—	×	EC-355

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
TW CATALYST SYS-B1	P0420	0420	×	×	×*5	EC-361
PURG VOLUME CONT/V	P0444	0444	—	—	×	EC-369
PURG VOLUME CONT/V	P0445	0445	—	—	×	EC-369
VEH SPEED SEN/CIRC	P0500	0500	—	—	×	EC-375
PW ST P SEN/CIRC	P0550	0550	—	—	×	EC-377
ECM	P0605	0605	—	—	×	EC-382
ECM BACK UP/CIRC	P1065	1065	—	—	×	EC-385
MAF SENSOR*3	P1102	1102	—	—	—	EC-389
INT/V TIM V/CIR-B1	P1111	1111	—	—	×	EC-395
ETC ACTR*3	P1121	1121	—	—	—	EC-400
ETC FUNCTION/CIRC*3	P1122	1122	—	—	—	EC-402
ETC MOT PWR*3	P1124	1124	—	—	—	EC-409
ETC MOT PWR*3	P1126	1126	—	—	—	EC-409
ETC MOT*3	P1128	1128	—	—	—	EC-415
HO2S1 (B1)	P1143	1143	×	×	×*5	EC-420
HO2S1 (B1)	P1144	1144	×	×	×*5	EC-432
HO2S2 (B1)	P1146	1146	×	×	×*5	EC-444
HO2S2 (B1)	P1147	1147	×	×	×*5	EC-462
ENG OVER TEMP	P1217	1217	—	—	×	EC-480
TP SEN 2/CIRC*3	P1223	1223	—	—	—	EC-490
TP SEN 2/CIRC*3	P1224	1224	—	—	—	EC-490
CTP LEARNING	P1225	1225	—	—	×	EC-496
CTP LEARNING	P1226	1226	—	—	×	EC-498
APP SEN 2/CIRC*3	P1227	1227	—	—	—	EC-500
APP SEN 2/CIRC*3	P1228	1228	—	—	—	EC-500
SENSOR POWER/CIRC*3	P1229	1229	—	—	—	EC-507
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	—	×	EC-75
P-N POS SW/CIRCUIT	P1706	1706	—	—	×	EC-511
BRAKE SW/CIRCUIT	P1805	1805	—	—	×	EC-515

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: When the fail-safe operation occurs, the MI illuminates.

*4: The trouble shooting for this DTC needs CONSULT-II.

*5: These are not displayed with GST.

QG18DE Engine Models

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
CAN COMM CIRCUIT	U1000	1000*4	—	—	×	EC-150
CAN COMM CIRCUIT	U1001	1001*4	—	—	×	EC-150

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—	—	—
INT/V TIM CONT-B1	P0011	0011	—	—	×	EC-153
HO2S1 HTR (B1)	P0031	0031	×	×	×*5	EC-162
HO2S1 HTR (B1)	P0032	0032	×	×	×*5	EC-162
HO2S2 HTR (B1)	P0037	0037	×	×	×*5	EC-175
HO2S2 HTR (B1)	P0038	0038	×	×	×*5	EC-175
HO2S1 HTR (B2)	P0051	0051	×	×	×*5	EC-162
HO2S1 HTR (B2)	P0052	0052	×	×	×*5	EC-162
HO2S2 HTR (B2)	P0057	0057	×	×	×*5	EC-175
HO2S2 HTR (B2)	P0058	0058	×	×	×*5	EC-175
MAF SEN/CIRCUIT*3	P0102	0102	—	—	—	EC-183
MAF SEN/CIRCUIT*3	P0103	0103	—	—	—	EC-183
IAT SEN/CIRCUIT	P0112	0112	—	—	×	EC-189
IAT SEN/CIRCUIT	P0113	0113	—	—	×	EC-189
ECT SEN/CIRCUIT*3	P0117	0117	—	—	—	EC-194
ECT SEN/CIRCUIT*3	P0118	0118	—	—	—	EC-194
HO2S1 (B1)	P0132	0132	×	×	×*5	EC-205
HO2S1 (B1)	P0133	0133	×	×	×*5	EC-223
HO2S1 (B1)	P0134	0134	×	×	×*5	EC-241
HO2S2 (B1)	P0138	0138	×	×	×*5	EC-258
HO2S2 (B1)	P0139	0139	×	×	×*5	EC-275
HO2S1 (B2)	P0152	0152	×	×	×*5	EC-205
HO2S1 (B2)	P0153	0153	×	×	×*5	EC-223
HO2S1 (B2)	P0154	0154	×	×	×*5	EC-241
HO2S2 (B2)	P0158	0158	×	×	×*5	EC-258
HO2S2 (B2)	P0159	0159	×	×	×*5	EC-275
FUEL SYS-LEAN-B1	P0171	0171	—	—	×	EC-291
FUEL SYS-RICH-B1	P0172	0172	—	—	×	EC-305
FUEL SYS-LEAN-B2	P0174	0174	—	—	×	EC-291
FUEL SYS-RICH-B2	P0175	0175	—	—	×	EC-305
TP SENSOR*3	P0221	0221	—	—	—	EC-312
TP SEN 1/CIRC*3	P0222	0222	—	—	—	EC-318
TP SEN 1/CIRC*3	P0223	0223	—	—	—	EC-318
APP SENSOR*3	P0226	0226	—	—	—	EC-324
APP SEN 1/CIRC*3	P0227	0227	—	—	—	EC-331
APP SEN 1/CIRC*3	P0228	0228	—	—	—	EC-331

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
MULTI CYL MISFIRE	P0300	0300	—	—	×	EC-338
CYL 1 MISFIRE	P0301	0301	—	—	×	EC-338
CYL 2 MISFIRE	P0302	0302	—	—	×	EC-338
CYL 3 MISFIRE	P0303	0303	—	—	×	EC-338
CYL 4 MISFIRE	P0304	0304	—	—	×	EC-338
KNOCK SEN/CIRC-B1	P0327	0327	—	—	×	EC-344
KNOCK SEN/CIRC-B1	P0328	0328	—	—	×	EC-344
CKP SEN/CIRCUIT	P0335	0335	—	—	×	EC-348
CMP SEN/CIRC-B1	P0340	0340	—	—	×	EC-355
TW CATALYST SYS-B1	P0420	0420	×	×	×*5	EC-365
TW CATALYST SYS-B2	P0430	0430	×	×	×*5	EC-365
PURG VOLUME CONT/V	P0444	0444	—	—	×	EC-369
PURG VOLUME CONT/V	P0445	0445	—	—	×	EC-369
VEH SPEED SEN/CIRC*6	P0500	0500	—	—	×	EC-375
PW ST P SEN/CIRC	P0550	0550	—	—	×	EC-377
ECM	P0605	0605	—	—	×	EC-382
PNP SW/CIRC	P0705	0705	—	—	×	AT-110
ATF TEMP SEN/CIRC	P0710	0710	—	—	×	AT-116
VEH SPD SEN/CIRC AT*6	P0720	0720	—	—	×	AT-122
ENGINE SPEED SIG	P0725	0725	—	—	×	AT-127
A/T 1ST GR FNCTN	P0731	0731	—	—	×	AT-131
A/T 2ND GR FNCTN	P0732	0732	—	—	×	AT-138
A/T 3RD GR FNCTN	P0733	0733	—	—	×	AT-144
A/T 4TH GR FNCTN	P0734	0734	—	—	×	AT-150
TCC SOLENOID/CIRC	P0740	0740	—	—	×	AT-158
L/PRESS SOL/CIRC	P0745	0745	—	—	×	AT-163
SFT SOL A/CIRC*3	P0750	0750	—	—	—	AT-170
SFT SOL B/CIRC*3	P0755	0755	—	—	—	AT-175
ECM BACK UP/CIRC	P1065	1065	—	—	×	EC-385
MAF SENSOR*3	P1102	1102	—	—	—	EC-389
INT/V TIM V/CIR-B1	P1111	1111	—	—	×	EC-395
ETC ACTR*3	P1121	1121	—	—	—	EC-400
ETC FUNCTION/CIRC*3	P1122	1122	—	—	—	EC-402
ETC MOT PWR*3	P1124	1124	—	—	—	EC-409
ETC MOT PWR*3	P1126	1126	—	—	—	EC-409
ETC MOT*3	P1128	1128	—	—	—	EC-415
HO2S1 (B1)	P1143	1143	×	×	×*5	EC-426
HO2S1 (B1)	P1144	1144	×	×	×*5	EC-438
HO2S2 (B1)	P1146	1146	×	×	×*5	EC-452

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM				
HO2S2 (B1)	P1147	1147	×	×	×*5	EC-470
HO2S1 (B2)	P1163	1163	×	×	×*5	EC-426
HO2S1 (B2)	P1164	1164	×	×	×*5	EC-438
HO2S2 (B2)	P1166	1166	×	×	×*5	EC-452
HO2S2 (B2)	P1167	1167	×	×	×*5	EC-470
ENG OVER TEMP	P1217	1217	—	—	×	EC-480
TP SEN 2/CIRC*3	P1223	1223	—	—	—	EC-490
TP SEN 2/CIRC*3	P1224	1224	—	—	—	EC-490
CTP LEARNING	P1225	1225	—	—	×	EC-496
CTP LEARNING	P1226	1226	—	—	×	EC-498
APP SEN 2/CIRC*3	P1227	1227	—	—	—	EC-500
APP SEN 2/CIRC*3	P1228	1228	—	—	—	EC-500
SENSOR POWER/CIRC*3	P1229	1229	—	—	—	EC-507
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	—	×	EC-75
TPV SEN/CIRC A/T	P1705	1705	—	—	×	AT-180
P-N POS SW/CIRCUIT	P1706	1706	—	—	×	EC-511
O/R CLTCH SOL/CIRC	P1760	1760	—	—	×	AT-185
BRAKE SW/CIRCUIT	P1805	1805	—	—	×	EC-515

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: When the fail-safe operation occurs, the MI illuminates.

*4: The trouble shooting for these DTCs need CONSULT-II.

*5: These are not displayed with GST.

*6: When the fail-safe operations for both self-diagnoses occur at the same time, the MI illuminates.

NOTE:

Regarding P12 models with QG18DE engine, "B1" indicates bank 1, "B2" indicates bank 2.

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MI during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-61, "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS"](#). These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of ISO 15031-5. 1st trip DTC detection occurs without lighting up the MI and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in “Work Flow” procedure Step II, refer to [EC-85, "WORK FLOW"](#). Then perform “DTC Confirmation Procedure” or “Overall Function Check” to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P0705, P0750, etc.

These DTCs are prescribed by ISO 15031-5.

(CONSULT-II also displays the malfunctioning component or system.)

 **No Tools**

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0102, 0340 etc.

These DTCs are controlled by NISSAN.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST or the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be “0”.

If a 1st trip DTC is stored in the ECM, the time data will be “[1t]”.

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS	TIME		DTC RESULTS	TIME
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-124, "Freeze Frame Data and 1st Trip Freeze Frame Data"](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 Fuel Injection System Function — DTC: P0171, P0172, P0174*, P0175*
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

*: For QG18DE engine models

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-73, "HOW TO ERASE EMIS-SION-RELATED DIAGNOSTIC INFORMATION"](#).

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

NOTE:

If MI is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

SRT Item

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority*1	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.	
			QG16DE	QG18DE
CATALYST	2	Three way catalyst function	P0420	P0420, P0430
HO2S	1	Heated oxygen sensor 1	P0132	P0132, P0152
		Heated oxygen sensor 1	P0133	P0133, P0153
		Heated oxygen sensor 1	P0134	P0134, P0154
		Heated oxygen sensor 1	P1143	P1143, P1163
		Heated oxygen sensor 1	P1144	P1144, P1164
		Heated oxygen sensor 2	P0138	P0138, P0158
		Heated oxygen sensor 2	P0139	P0139, P0159
		Heated oxygen sensor 2	P1146	P1146, P1166
		Heated oxygen sensor 2	P1147	P1147, P1167

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

SRT item (CONSULT-II indication)	Performance Priority *1	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.	
			QG16DE	QG18DE
HO2S HTR	1	Heated oxygen sensor 1 heater	P0031, P0032	P0031, P0032, P0051, P0052
		Heated oxygen sensor 2 heater	P0037, P0038	P0037, P0038, P0057, P0058

*1: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-II.

SRT Set Timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result		Example							
		Diagnosis	Ignition cycle						
			← ON →	OFF	← ON →	OFF	← ON →	OFF	← ON →
All OK	Case 1	P0400	OK (1)	— (1)	OK (2)	— (2)			
		P0402	OK (1)	— (1)	— (1)	OK (2)			
		P1402	OK (1)	OK (2)	— (2)	— (2)			
		SRT of EGR	"CMPLT"	"CMPLT"	"CMPLT"	"CMPLT"			
	Case 2	P0400	OK (1)	— (1)	— (1)	— (1)			
		P0402	— (0)	— (0)	OK (1)	— (1)			
		P1402	OK (1)	OK (2)	— (2)	— (2)			
		SRT of EGR	"INCMP"	"INCMP"	"CMPLT"	"CMPLT"			
NG exists	Case 3	P0400	OK	OK	—	—			
		P0402	—	—	—	—			
		P1402	NG	—	NG	NG	NG (Consecutive NG)		
		(1st trip) DTC	1st trip DTC	—	1st trip DTC	DTC (= MI "ON")			
		SRT of EGR	"INCMP"	"INCMP"	"INCMP"	"CMPLT"			

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate "CMPLT". → Case 1 above

When all SRT related self-diagnoses showed OK results through several different cycles, the SRT will indicate "CMPLT" at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate "CMPLT". → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as "INCMP" is one (1) for each self-diagnosis (Case 1 & 2) or two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate "CMPLT" at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires "CMPLT" of the SRT only with OK self-diagnosis results.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to "CMPLT" of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate "INCMP".

ON BOARD DIAGNOSTIC (OBD) SYSTEM


[QG (WITH EURO-OBD)]

NOTE:

SRT can be set as "CMPLT" together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates "CMPLT".

SRT Service Procedure

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating "INCMP", review the flowchart diagnostic sequence on the next page.



SEF573XB

*1 [EC-66](#)

*2 [EC-70](#)

*3 [EC-70](#)

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

How to Display SRT Code

WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown at right.

"INCMP" means the self-diagnosis is incomplete and SRT is not set.

"CMPLT" means the self-diagnosis is complete and SRT is set.

WITH GST

Selecting Mode 1 with GST (Generic Scan Tool)

SRT STATUS	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	CMPLT

PBIB0666E

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

WITH CONSULT-II

Perform corresponding DTC Confirmation Procedure one by one based on "Performance Priority" in the table on [EC-67, "SRT Item"](#).


WITHOUT CONSULT-II

The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

Driving Pattern

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.

Driving pattern



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time, required for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 72 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 72 and ground is lower than 1.4V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Checking the vehicle speed with GST is advised.

Suggested Transmission Gear Position for A/T Models

Set the selector lever in the "D" position with the overdrive switch turned ON.

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of ISO 15031-5.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

QG16DE Engine Models

×: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function	01H	01H	Max.	×
HO2S	Heated oxygen sensor 1	09H	04H	Max.	×
		0AH	84H	Min.	×
		0BH	04H	Max.	×
		0CH	04H	Max.	×
	Heated oxygen sensor 2	0DH	04H	Max.	×
		19H	86H	Min.	×
		1AH	86H	Min.	×
		1BH	06H	Max.	×
		1CH	06H	Max.	×

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
HO2S HTR	Heated oxygen sensor 1 heater	29H	08H	Max.	×
		2AH	88H	Min.	×
	Heated oxygen sensor 2 heater	2DH	0AH	Max.	×
		2EH	8AH	Min.	×

QG18DE Engine Models

×: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function (Bank1)	01H	01H	Max.	×
		02H	81H	Min.	×
	Three way catalyst function (Bank2)	03H	02H	Max.	×
		04H	82H	Min.	×
HO2S	Heated oxygen sensor 1 (Bank 1)	09H	04H	Max.	×
		0AH	84H	Min.	×
		0BH	04H	Max.	×
		0CH	04H	Max.	×
	Heated oxygen sensor 1 (Bank 2)	0DH	04H	Max.	×
		11H	05H	Max.	×
		12H	85H	Min.	×
		13H	05H	Max.	×
		14H	05H	Max.	×
	Heated oxygen sensor 2 (Bank 1)	15H	05H	Max.	×
		19H	86H	Min.	×
		1AH	86H	Min.	×
		1BH	06H	Max.	×
	Heated oxygen sensor 2 (Bank 2)	1CH	06H	Max.	×
		21H	87H	Min.	×
		22H	87H	Min.	×
23H		07H	Max.	×	
HO2S HTR	Heated oxygen sensor 1 heater (Bank 1)	24H	07H	Max.	×
		29H	08H	Max.	×
	Heated oxygen sensor 1 heater (Bank 2)	2AH	88H	Min.	×
		2BH	09H	Max.	×
	Heated oxygen sensor 2 heater (Bank 1)	2CH	89H	Min.	×
		2DH	0AH	Max.	×
	Heated oxygen sensor 2 heater (Bank 2)	2EH	8AH	Min.	×
		2FH	0BH	Max.	×
		30H	8BH	Min.	×

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)

The emission related diagnostic information in the ECM can be erased by selecting “ERASE” in the “SELF-DIAG RESULTS” mode with CONSULT-II.

If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

NOTE:

If the DTC is not for A/T related items (see [EC-23, "INDEX FOR DTC"](#)), skip steps 2 through 4.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "A/T".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". [The DTC in the TCM (Transmission control module) will be erased.] Then touch "BACK" twice.
5. Touch "ENGINE".
6. Touch "SELF-DIAG RESULTS".
7. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
ENGINE
A/T



SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SELF-DIAG RESULTS	
DTC RESULTS	TIME
SHIFT SOLENOID/V A	

2. Turn CONSULT-II "ON", and touch "A/T".

3. Touch "SELF-DIAG RESULTS".

4. Touch "ERASE". (The DTC in the TCM will be erased.)



SELECT SYSTEM
ENGINE
A/T

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SELF DIAG RESULTS	
DTC RESULTS	TIME
SFT SOL A/CIRC [P0750]	0

5. Touch "ENGINE".

6. Touch "SELF-DIAG RESULTS".

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SEF966X

How to Erase DTC (With GST)

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

NOTE:

If the DTC is not for A/T related items (see [EC-23, "INDEX FOR DTC"](#)), skip step 2.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with GST (Generic Scan Tool).

How to Erase DTC (No Tools)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch OFF" once.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

2. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
 3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-76, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).
- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
 - The following data are cleared when the ECM memory is erased.
 1. Diagnostic trouble codes
 2. 1st trip diagnostic trouble codes
 3. Freeze frame data
 4. 1st trip freeze frame data
 5. System readiness test (SRT) codes
 6. Test values
 7. Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

NATS (Nissan Anti-theft System)

EBS00ELV

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-156, "NATS \(NISSAN ANTI-THEFT SYSTEM\)"](#).
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF515Y


Malfunction Indicator (MI)

EBS00ELW

DESCRIPTION

The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MI does not light up, refer to [DI-95, "WARNING LAMPS"](#), or see [EC-552](#).
2. When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.









ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MI in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● Fail-safe mode
Mode II	Ignition switch in "ON" position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1, to be read.

MI Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode, [EC-76, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

How to switch the diagnostic test (function) modes, and details of the above functions are described later, [EC-76, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others

HOW TO SWITCH DIAGNOSTIC TEST MODE

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned "OFF".


How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

2. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
4. Fully release the accelerator pedal.
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).




How to Set Diagnostic Test Mode II (Heated Oxygen Sensor 1 Monitor)

1. Set the ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-76, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Start Engine.
ECM has entered to Diagnostic Test Mode II (Heated oxygen sensor 1 monitor).
ECM will start heated oxygen sensor 1 monitoring from the bank 1 sensor for QG18DE engine models.

How to Switch Monitored Sensor From Bank 1 to Bank 2 or Vice Versa

1. Fully depress the accelerator pedal quickly and then release it immediately.
2. Make sure that monitoring sensor has changed by MI blinking as follows.



How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-76, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-95, "WARNING LAMPS"](#) or see [EC-552](#).


DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle. A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC “0000” refers to no malfunction. (See [EC-23, "INDEX FOR DTC"](#))

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-76, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

- If the battery is disconnected, the DTC will be lost from the backup memory after approx 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

DIAGNOSTIC TEST MODE II — HEATED OXYGEN SENSOR 1 MONITOR

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1.

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

OBD System Operation Chart

EBS00ELX

RELATIONSHIP BETWEEN MI, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MI will come on. For details, refer to [EC-60, "Two Trip Detection Logic"](#).
- The MI will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MI (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see [EC-81](#).

For details about patterns "A" and "B" under "Other", see [EC-83](#).


*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MI will light up.

*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

EXPLANATION FOR DRIVING PATTERNS FOR “MISFIRE <EXHAUST QUALITY DETERIORATION>”, “FUEL INJECTION SYSTEM”

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MI will go off when the B counter reaches 3. (*2 in “OBD SYSTEM OPERATION CHART”)

<Driving Pattern C>

Driving pattern C means the vehicle operation as follows:

1. The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), “T” should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), “T” should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:


Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



SEF393SA

*1: When the same malfunction is detected in two consecutive trips, MI will light up.

*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.


*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITH EURO-OBD)]

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MI will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").

TROUBLE DIAGNOSIS

PFP:00004

Trouble Diagnosis Introduction
INTRODUCTION

EBS00ELY




The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-85](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on [EC-88](#) should be used.


Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.



WORK FLOW

Flow Chart

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBIB0159E

- *1: If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .
- *2: If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .
- *3: If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-144, "POWER SUPPLY CIRCUIT FOR ECM"](#) .
- *4: If malfunctioning part cannot be detected, perform [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .
- *5: [EC-71, "Driving Pattern"](#)
- *6: [EC-139, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#)

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-87 .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-73 , " HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION " .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-143 , " TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT " . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-97 .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-143 , " TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT " . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-143 , " TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT " . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-92 .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS – SPECIFICATION VALUE". (Refer to EC-139 .) (If malfunction is detected, proceed to "PERAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-97 .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-107 , EC-133 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI-24 , " How to Perform Efficient Diagnosis for an Electrical Incident " . Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-143 , " TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT " .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-73 , " HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION " and AT-37 , " HOW TO ERASE DTC " .)

DIAGNOSTIC WORKSHEET

Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MI to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

QG16DE ENGINE

Priority	Detected items (DTC)	A
1	<ul style="list-style-type: none"> ● U1001 CAN communication line ● P0102 P0103 P1102 Mass air flow sensor ● P0112 P0113 Intake air temperature sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 P1229 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0500 Vehicle speed sensor ● P0605 ECM ● P1610-P1615 NATS ● P1706 Park/Neutral position (PNP) switch 	<p style="background-color: black; color: white; padding: 2px;">EC</p> <p>C</p> <p>D</p> <p>E</p>
2	<ul style="list-style-type: none"> ● P0031 P0032 Heated oxygen sensor 1 heater ● P0037 P0038 Heated oxygen sensor 2 heater ● P0132 P0133 P0134 P1143 P1144 Heated oxygen sensor 1 ● P0138 P0139 P1146 P1147 Heated oxygen sensor 2 ● P0550 Power steering pressure sensor ● P1065 ECM power supply ● P1111 Intake valve timing control solenoid valve ● P1122 Electric throttle control function ● P1124 P1126 P1128 Electric throttle control actuator ● P1805 Brake switch 	<p>F</p> <p>G</p> <p>H</p> <p>I</p>
3	<ul style="list-style-type: none"> ● P0011 Intake valve timing control ● P0171 P0172 Fuel injection system function ● P0300 - P0304 Misfire ● P0420 Three way catalyst function ● P0444 P0445 EVAP canister purge volume control solenoid valve ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT) 	<p>J</p> <p>K</p> <p>L</p>

M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

QG18DE ENGINE

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● U1000 U1001 CAN communication line ● P0102 P0103 P1102 Mass air flow sensor ● P0112 P0113 Intake air temperature sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 P1229 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0500 Vehicle speed sensor ● P0605 ECM ● P0705 Park/Neutral position (PNP) switch ● P1610-P1615 NATS ● P1706 Park/Neutral position (PNP) switch
2	<ul style="list-style-type: none"> ● P0031 P0032 P0051 P0052 Heated oxygen sensor 1 heater ● P0037 P0038 P0057 P0058 Heated oxygen sensor 2 heater ● P0132 P0133 P0134 P0152 P0153 P0154 P1143 P1144 P1163 P1164 Heated oxygen sensor 1 ● P0138 P0139 P0158 P0159 P1146 P1147 P1166 P1167 Heated oxygen sensor 2 ● P0550 Power steering pressure sensor ● P0710-P0725, P0740-P0755, P1705 P1760 A/T related sensors and solenoid valves ● P1065 ECM power supply ● P1111 Intake valve timing control solenoid valve ● P1122 Electric throttle control function ● P1124 P1126 P1128 Electric throttle control actuator ● P1805 Brake switch
3	<ul style="list-style-type: none"> ● P0011 Intake valve timing control ● P0171 P0172 P0174 P0175 Fuel injection system function ● P0300 - P0304 Misfire ● P0420 P0430 Three way catalyst function ● P0444 P0445 EVAP canister purge volume control solenoid valve ● P0731-P0734 A/T function ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT)

Fail-safe Chart

EBS00EM0

When the DTC listed below is detected, the ECM enters fail-safe mode and the MI lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode
P0102 P0103 P1102	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]



DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0117 P0118	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.								
		<table border="1"> <thead> <tr> <th>Condition</th> <th>Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td>40°C (104°F)</td> </tr> <tr> <td>More than approx. 4 minutes after ignition ON or Start</td> <td>80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td>40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or Start	40°C (104°F)	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
		Condition	Engine coolant temperature decided (CONSULT-II display)							
		Just as ignition switch is turned ON or Start	40°C (104°F)							
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)							
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)							
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.										
P0221 P0222 P0223 P1223 P1224	Throttle position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.								
P0226 P0227 P0228 P1227 P1228	Accelerator pedal position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.								
P1121	Electric throttle control actuator (ECM detect the throttle valve is stuck open.)	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.								
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								

A
EC
C
D
E
F
G
H
I
J
K
L
M

Basic Inspection

1. INSPECTION START


1. Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge. Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no-load.
6. Make sure that no DTC is displayed with CONSULT-II or GST.

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. REPAIR OR REPLACE


Repair or replace components as necessary according to corresponding "Diagnostic Procedure".

>> GO TO 3.

3. CHECK TARGET IDLE SPEED

With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.
3. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 10.
NG >> GO TO 4.

4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#).

>> GO TO 5.

5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-55, "Throttle Valve Closed Position Learning"](#).

>> GO TO 6.

6. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-55, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 7.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

7. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 10.

NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-355](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-348](#) .

OK or NG

OK >> GO TO 9.

NG >> 1. Repair or replace.

2. GO TO 4.

9. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-75, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

10. CHECK IGNITION TIMING

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $8 \pm 5^\circ$ BTDC

A/T: $10 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 11.

11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 12.

12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 13.

13. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-55, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 14.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

14. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 15.

NG >> GO TO 17.

15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $8 \pm 5^\circ$ BTDC

A/T: $10 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 16.

16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-49, "TIMING CHAIN"](#) .

OK or NG

OK >> GO TO 17.

NG >> 1. Repair the timing chain installation.
2. GO TO 4.

17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-355](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-348](#) .

OK or NG

OK >> GO TO 18.

NG >> 1. Repair or replace.
2. GO TO 4.

18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-75, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

EBS00EM2

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-536
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-58
	Injector circuit	1	1	2	3	2		2	2			2			EC-530
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-369 , EC-554
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-557
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-92
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	EC-400 , EC-402 , EC-409 , EC-415
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-92
	Ignition circuit	1	1	2	2	2		2	2			2			EC-520
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3			EC-144
Mass air flow sensor circuit		1	1	2	2	2		2	2			2			EC-183 , EC-389
Engine coolant temperature sensor circuit		1	1	2	2	2	3	2	2	3	1	2			EC-194
Throttle position sensor circuit			1	2		2	2	2	2	2		2			EC-312 , EC-318 , EC-490 , EC-496 , EC-498 , EC-507
Accelerator pedal position sensor circuit				3	2	1	2			2					EC-324 , EC-331 , EC-500

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

	SYMPTOM													Reference page	
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)		
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Heated oxygen sensor 1 circuit		1	2	3	2			2	2				2		EC-199 , EC-205 , EC-214 , EC-223 , EC-234 , EC-241 , EC-420 , EC-426 , EC-432 , EC-438
Knock sensor circuit			2	2								3			EC-344
Crankshaft position sensor (POS) circuit	2	2													EC-348
Camshaft position sensor (PHASE) circuit	2	2													EC-355
Vehicle speed signal circuit		2	3		3							3			EC-375
Power steering pressure sensor circuit		2				3	3	3	3						EC-377
ECM	2	2	3	3	3	3	3	3	3	3	3				EC-382 , EC-385
Intake valve timing control solenoid valve circuit	3	3	2		1	3	2	2	3			3			EC-395
PNP switch circuit			3		3	3	3	3	3			3			EC-511
Refrigerant pressure sensor circuit		2				3	3	3	3			4			EC-542
Electrical load signal circuit						3	3	3	3						EC-547
Air conditioner circuit	2	2	3	3	3	3	3	3	3			3	2		ATC-30

1 - 6: The numbers refer to the order of inspection.
 (continued on next page)

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank														FL-13
	Fuel piping	5		5	5	5		5	5			5			FL-3, MA-23
	Vapor lock		5												—
	Valve deposit														—
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5			—
Air	Air duct														EM-17
	Air cleaner														EM-17
	Air leakage from air duct (Mass air flow sensor —electric throttle control actuator)		5	5		5		5	5			5			EM-17
	Electric throttle control actuator	5			5		5			5					EM-19
	Air leakage from intake manifold/Collector/Gasket														EM-19
Cranking	Battery	1	1	1		1		1	1			1		1	SC-3
	Alternator circuit														SC-12
	Starter circuit	3													SC-22
	Signal plate/Flywheel/Drive plate	6													EM-70
	PNP switch	4													MT-14, MT-62 or AT-115
Engine	Cylinder head	5	5	5	5	5		5	5			5	3		EM-57
	Cylinder head gasket										4				
	Cylinder block												4		
	Piston													4	
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			EM-70
	Bearing														
	Crankshaft														

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Valve mechanism	Timing chain														EM-49
	Camshaft														EM-36
	Intake valve timing control	5	5	5	5	5		5	5			5			EM-49
	Intake valve												3		EM-57
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5		5	5			5			EM-23 , EX-3
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5	2		EM-27 , LU-8 , LU-9 , LU-5
	Oil level (Low)/Filthy oil														LU-6
Cooling	Radiator/Hose/Radiator filler cap														CO-11
	Thermostat									5					CO-20
	Water pump														CO-18
	Water gallery	5	5	5	5	5		5	5		2	5			CO-7
	Cooling fan									5					CO-11
	Coolant level (low)/Contaminated coolant														CO-8
NATS (Nissan Anti-Theft System)		1	1												EC-75 or BL-156

1 - 6: The numbers refer to the order of inspection.

Engine Control Component Parts Location

EBS00EM3

A

EC

C

D

E

F

G

H


I

J









K

L









M











MBIB0117E



A
EC
C
D
E
F
G
H
I
J
K
L
M



MBIB0119E




TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Circuit Diagram


EBS00EM4



A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS


[QG (WITH EURO-OBD)]



MBWA0043E

ECM Harness Connector Terminal Layout

EBS00EM5




MBIB0045E

ECM Terminals and Reference Value PREPARATION


EBS00EM6

1. ECM is located behind the glove box. For this inspection, remove glove box.
2. Remove ECM harness protector.



MBIB0155E

3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown at right.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



MBIB0145E

ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

QG16DE Engine Models

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground





TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/B	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal is releasing 	0 - 14V★  <small>>>10.0 V/Div 200 us/Div T</small>
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal is depressing 	0 - 14V★  <small>>>10.0 V/Div 200 us/Div T</small>
12	L	Power steering pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	0.5 - 4.0V
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	0.4 - 0.8V
13	R	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 3.0V★  <small>>>5 V/Div 1 ms/Div T</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 3.0V★  <small>>>5.0 V/Div 1 ms/Div T</small>

TROUBLE DIAGNOSIS




[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	R	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0526E</p>
15	W	Knock sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V
16	W	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
19	GY/L	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>

A
EC
C
D
E
F
G
H
I
J
K
L
M





TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0530E</p>
24	G	Heated oxygen sensor 1 heater	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm. 	<p>Approximately 7.0V★</p>  <p style="text-align: right;">PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped. <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	<p>BATTERY VOLTAGE (11 - 14V)</p>
29	B	Camshaft position sensor (PHASE) ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 0V</p>
30	B	Camshaft position sensor (POS) ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 0V</p>
34	BR	Intake air temperature sensor	<p>[Engine is running]</p>	<p>Approximately 0 - 4.8V Output voltage varies with intake air temperature.</p>
35	W	Heated oxygen sensor 1	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - Approximately 1.0V (Periodically change)</p>
45	R	Sensor power supply (Mass air flow sensor)	<p>[Ignition switch "ON"]</p>	<p>Approximately 5V</p>
46	R	Sensor power supply (Refrigerant pressure sensor)	<p>[Ignition switch "ON"]</p>	<p>Approximately 5V</p>
47	G	Sensor power supply (Throttle position sensor)	<p>[Ignition switch "ON"]</p>	<p>Approximately 5V</p>

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully released 	More than 0.36V	EC
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully depressed 	Less than 4.75V	C
50	Y	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V	D
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm. 	1.5 - 2.1V	E
54	-	Sensor ground (Knock sensor shield circuit)	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V	F
57	B	Sensor ground (Power steering pressure sensor/Refrigerant pressure sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	G
60 61 79 80	L/R BR GY/R PU	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.1V★  PBIB0521E	H
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - 0.2V★  PBIB0522E	I
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  MBIB0052E	J
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed 2,500 rpm 	7 - 10V★  PBIB0532E	K

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully depressed	More than 0.36V
69	R/L	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.)	1.0 - 4.0V
72	BR/W	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
73	B	Sensor ground (Engine coolant temperature sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
74	B	Sensor ground (Heated oxygen sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
85	LG	DATA link connector	[Ignition switch "ON"] ● CONSULT-II or GST is disconnected.	BATTERY VOLTAGE (11 - 14V)
86	R	CAN communication line	[Ignition switch "ON"]	Approximately 2.3V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
94	L	CAN communication line	[Ignition switch "ON"]	Approximately 2.8V

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]



TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully released 	0.175 - 0.335V	EC
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully depressed 	More than 1.95V	C
101	R/G	Stop lamp switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully released 	Approximately 0V	D
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully depressed 	BATTERY VOLTAGE (11 - 14V)	E
102	G/OR	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Gear position is neutral 	Approximately 0V	F
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Except the above gear position 	Approximately 5V	G
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)	H
			[Ignition switch "ON"]	0 - 1.0V	I
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully released 	0.35 - 0.67V	J
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully depressed 	More than 3.9V	K
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V	L
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	M
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch "OFF" 	0 - 1.0V	M
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● 5 seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)	
113	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> ● For 1 second after turning ignition switch "ON" 	0 - 1.0V	
			[Engine is running] [Ignition switch "ON"] <ul style="list-style-type: none"> ● More than 1 second after turning ignition switch "ON". 	BATTERY VOLTAGE (11 - 14V)	
115 116	B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground	
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)	

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS





[QG (WITH EURO-OBD)]

QG18DE Engine Models

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
2	L	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more	0 - 1.0V
			[Ignition switch "ON"] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing	0 - 14V★  PBIB0533E
7	W/R	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] ● Engine speed is below 3,600 rpm ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more	0 - 1.0V
			[Ignition switch "ON"] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14)
12	L	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned	Approximately 3.6V
			[Engine is running] ● Steering wheel is not being turned	Approximately 0.6V






TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
13	R	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 3.0V★  <small>>> 5 V/Div 1 ms/Div T</small> PBIB0527E	EC
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 3.0V★  <small>>> 5.0 V/Div 1 ms/Div T</small> PBIB0528E	C
14	R	Camshaft position sensor (PHASE)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 4.0V★  <small>>> 5.0 V/Div 20 ms/Div T</small> PBIB0525E	D
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	1.0 - 4.0V★  <small>>> 5.0 V/Div 20 ms/Div T</small> PBIB0526E	E
15	W	Knock sensor	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V	F
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V	G
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V	H


TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	GY/L	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0530E</p>
24	G	Heated oxygen sensor 1 heater (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm (M/T model) ● Engine speed is below 3,200 rpm (A/T model) 	<p>Approximately 7.0V★</p>  <p style="text-align: right;">PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (M/T model) ● Engine speed is above 3,200 rpm (A/T model) 	<p>BATTERY VOLTAGE (11 - 14V)</p>





TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	R/B	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm (M/T model) ● Engine speed is below 3,200 rpm (A/T model) 	Approximately 7.0V★  PBIB0519E
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm (M/T model) ● Engine speed is above 3,200 rpm (A/T model) 	BATTERY VOLTAGE (11 - 14V)
29	B	Camshaft position sensor (PHASE) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
30	B	Camshaft position sensor (POS) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
34	BR	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
46	R	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	Less than 4.75V
50	Y	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	1.5 - 2.1V

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	-	Sensor ground (Knock sensor shield circuit)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
57	B	Sensor ground (Power steering pressure sensor/Refrigerant pressure sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
60 61 79 80	L/R BR GY/R PU	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.1V★  PBIB0521E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 0.2V★  PBIB0522E
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  MBIB0052E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	7 - 10V★  PBIB0532E
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V



TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
68	R	Throttle position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	Less than 4.75V	EC
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	More than 0.36V	C
69	R/L	Refrigerant pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.) 	1.0 - 4.0V	E
72	BR/W	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.	F
73	B	Sensor ground (Engine coolant temperature sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	G
74	B	Sensor ground (Heated oxygen sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	H
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	I
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	J
85	LG	DATA link connector	[Ignition switch "ON"] <ul style="list-style-type: none"> ● CONSULT-II or GST is disconnected. 	BATTERY VOLTAGE (11 - 14V)	K
86	R	CAN communication line	[Ignition switch "ON"]	Approximately 2.3V	L
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V	M
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V	
92		Accelerator pedal position sensor signal output	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.35 - 0.67V	
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 3.9V	
94	L	CAN communication line	[Ignition switch "ON"]	Approximately 2.8V	

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.175 - 0.335V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 1.95V
101	R/G	Stop lamp switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully released 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully depressed 	BATTERY VOLTAGE (11 - 14V)
102	P (A/T) G/OR (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Gear position is "P" or "N" 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Except the above gear position 	A/T models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V
103		Tachometer signal output	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	10 - 11V★  MBIB0053E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	10 - 11V★  MBIB0054E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	Less than 4.75V
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "OFF" 	0 - 1.0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> 5 seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
113	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> For 1 second after turning ignition switch "ON" 	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] <ul style="list-style-type: none"> More than 1 second after turning ignition switch "ON". 	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> Idle speed 	Engine ground
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

CONSULT-II Function FUNCTION

EBS00EM7

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
DTC & SRT confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
ECM part number	ECM part number can be read.

*1: The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. System readiness test (SRT) codes
6. Test values
7. Others

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC* ¹	FREEZE FRAME DATA* ²				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)	×	×	×	×			
	Camshaft position sensor (PHASE)	×	×	×	×				
	Mass air flow sensor	×		×	×				
	Engine coolant temperature sensor	×	×	×	×	×			
	Heated oxygen sensor 1	×		×	×		×	×	
	Heated oxygen sensor 2	×		×	×		×	×	
	Vehicle speed signal	×	×	×	×				
	Accelerator pedal position sensor	×		×	×				
	Throttle position sensor	×		×	×				
	Intake air temperature sensor	×		×	×				
	Knock sensor	×							
	Refrigerant pressure sensor				×	×			
	Closed throttle position switch (accelerator pedal position sensor signal)				×	×			
	Air conditioner switch				×	×			
	Park/neutral position (PNP) switch	×			×	×			
	Stop lamp switch	×			×	×			
	Power steering pressure sensor	×			×	×			
	Battery voltage				×	×			
	Electrical load signal				×	×			
	OUTPUT	Injectors			×	×	×		
	Power transistor (Ignition timing)				×	×	×		
	Throttle control motor relay	×			×	×			
	Throttle control motor	×							
	EVAP canister purge volume control solenoid valve	×			×	×	×		
	Air conditioner relay				×	×			
	Fuel pump relay	×			×	×	×		
	Cooling fan relay	×			×	×	×		
	Heated oxygen sensor 1 heater	×			×	×		×	
Heated oxygen sensor 2 heater	×			×	×		×		
Intake valve timing control solenoid valve	×			×	×	×			
Calculated load value			×	×	×				


X: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-66, "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA"](#).

CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector, which is located under the drivers side dash panel.
3. Turn ignition switch ON.



4. Touch "START".




5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.



A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM. 	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> IDLE CONDITION 	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> IDLE CONDITION 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light.

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to [EC-23, "INDEX FOR DTC" .\)](#)

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item ^{*1}	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-23, "INDEX FOR DTC" .)
FUEL SYS-B1	<ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> The intake air temperature at the moment a malfunction is detected is displayed.

*1: The items are the same as those of 1st trip freeze frame data.

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

DATA MONITOR MODE

Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ENG SPEED [rpm]	×	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signals of the crankshaft position sensor (POS) and camshaft position sensor (PHASE). 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		×		<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		×		<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%] ^{*1}		×			
COOLAN TEMP/S [°C] or [°F]	×	×		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S1 (B2) [V] ^{*1}	×				
HO2S2 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S2 (B2) [V] ^{*1}	×				
HO2S1 MNTR (B1) [RICH/LEAN]	×	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S1 MNTR (B2) [RICH/LEAN] ^{*1}	×				
HO2S2 MNTR (B1) [RICH/LEAN]	×			<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
HO2S2 MNTR (B2) [RICH/LEAN] ^{*1}	×				
VHCL SPEED SE [km/h] or [mph]	×	×		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	
BATTERY VOLT [V]	×	×		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ACCEL SEN 1 [V]	×	×		● The accelerator pedal position sensor signal voltage is displayed.	
ACCEL SEN 2 [V]	×				
THRTL SEN 1 [V]	×	×		● The throttle position sensor signal voltage is displayed.	
THRTL SEN 2 [V]	×				
INT/A TEMP SE [°C] or [°F]	×	×		● The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.	
START SIGNAL [ON/OFF]	×	×		● Indicates [ON/OFF] condition of the starter signal computed from the signals of the crankshaft position sensor (POS), camshaft position sensor (PHASE) and battery voltage.	● After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	×	×		● Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.	
AIR COND SIG [ON/OFF]	×	×		● Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.	
P/N POSI SW [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.	
PW/ST SIGNAL [ON/OFF]	×	×		● [ON/OFF] condition of the power steering oil pressure switch as determined by the power steering oil pressure signal is indicated.	
LOAD SIGNAL [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the electrical load signal. ON ... Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF ... Both rear window defogger switch and lighting switch are OFF.	
IGNITION SW [ON/OFF]	×			● Indicates [ON/OFF] condition from ignition switch.	
HEATER FAN SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the heater fan switch signal.	
BRAKE SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the stop lamp switch signal.	
INJ PULSE-B1 [msec]		×		● Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.	● When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec] ^{*1}					
IGN TIMING [BTDC]		×		● Indicates the ignition timing computed by ECM according to the input signals.	● When the engine is stopped, a certain value is indicated.
CAL/LD VALUE [%]				● "Calculated load value" indicates the value of the current airflow divided by peak airflow.	
MASS AIRFLOW [g·m/s]				● Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor.	

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
PURG VOL C/V [%]				<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 	
INT/V TIM (B1) [°CA]				<ul style="list-style-type: none"> Indicates [°CA] of intake camshaft advanced angle. 	
INT/V SOL (B1) [%]				<ul style="list-style-type: none"> The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
AIR COND RLY [ON/OFF]		×		<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. 	
FUEL PUMP RLY [ON/OFF]		×		<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
THRTL RELAY [ON/OFF]		× ²		<ul style="list-style-type: none"> Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. 	
COOLING FAN [ON/OFF]				<ul style="list-style-type: none"> Indicates the condition of the cooling fan (determined by ECM according to the input signals). ON ... Operation OFF ... Stop 	
HO2S1 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S1 HTR (B2) [ON/OFF] ^{*1}					
HO2S2 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B2) [ON/OFF] ^{*1}					
VEHICLE SPEED [km/h] or [mph]	×			<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal sent from TCM is displayed. 	
IDL A/V LEARN [YET/CMPLT/ INCMP]				<ul style="list-style-type: none"> Display the condition of idle air volume learning YET ... Idle air volume learning has not been performed yet. CMPLT ... Idle air volume learning has already been performed successfully. INCMP ... Idle air volume learning has not been performed successfully. 	
TRVL AFTER MIL [km] or [mile]				<ul style="list-style-type: none"> Distance traveled while MI is activated. 	

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
O2SEN HTR DTY [%]				<ul style="list-style-type: none"> Indicates the heated oxygen sensor 1 heater control value computed by the ECM according to the input signals. 	
AC PRESS SEN [V]	×*2			<ul style="list-style-type: none"> The signal voltage from the refrigerant pressure sensor is displayed. 	
Voltage [V]				<ul style="list-style-type: none"> Voltage, frequency, duty cycle or pulse width measured by the probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					
CAN COMM [OK/NG]			×		
CAN CIRC 1 [OK/UNKWN]			×		
CAN CIRC 2 [OK/UNKWN]			×		
CAN CIRC 3 [OK/UNKWN]			×		
CAN CIRC 4 [OK/UNKWN]			×		
CAN CIRC 5 [OK/UNKWN]			×		
CAN CIRC 6 [OK/UNKWN]			×		
CAN CIRC 7 [OK/UNKWN]			×		

*1: For QG18 engine models.

*2: For QG16 engine models.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

DATA MONITOR (SPEC) MODE

Monitored Item

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> Indicates the engine speed computed from the signal of the crankshaft position sensor (POS). 	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> “Base fuel schedule” indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]*1		×		

*1: For QG18 engine models

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Perform "Idle Air Volume Learning".
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connectors Compression Fuel injectors Power transistor Spark plugs Ignition coils
COOLING FAN	<ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan "ON" and "OFF" with CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> Harness and connectors Cooling fan relay Cooling fan motor
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Engine coolant temperature sensor Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connectors Fuel pump relay
PURG VOL CONT/V	<ul style="list-style-type: none"> Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connectors Solenoid valve
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change intake valve timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Intake valve timing control solenoid valve

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to [EC-67, "SYSTEM READINESS TEST \(SRT\) CODE"](#) .

SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC Work Support Mode

QG16 engine models

Test mode	Test item	Condition	Reference page
HO2S1	HO2S1 (B1) P0133	Refer to corresponding trouble diagnosis for DTC.	EC-214
	HO2S1 (B1) P0134		EC-234
	HO2S1 (B1) P1143		EC-420
	HO2S1 (B1) P1144		EC-432
HO2S2	HO2S2 (B1) P0139		EC-267
	HO2S2 (B1) P1146		EC-444
	HO2S2 (B1) P1147	EC-462	

QG18 engine models

Test mode	Test item	Condition	Reference page
HO2S1	HO2S1 (B1) P0133, P0153	Refer to corresponding trouble diagnosis for DTC.	EC-223
	HO2S1 (B1) P0134, P0154		EC-241
	HO2S1 (B1) P1143, P1163		EC-426
	HO2S1 (B1) P1144, P1164		EC-438
HO2S2	HO2S2 (B1) P0139, P0159		EC-275
	HO2S2 (B1) P1146, P1166		EC-452
	HO2S2 (B1) P1147, P1167	EC-470	

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the

DATA MONITOR	
Recording Data...11%	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
VHCL SPEED SE	XXX km/h

SEF705Y


TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
- DATA MONITOR can be performed continuously even though a malfunction is detected.




Operation

1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



PBIB0197E


Generic Scan Tool (GST) Function

DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with ISO 15031-4 has 8 different functions explained below.

ISO9141 is used as the protocol.

The name "GST" or "Generic Scan Tool" is used in this service manual.




FUNCTION

Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-66. "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA" .
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	This mode is not applicable on this vehicle.
MODE 9	(CALIBRATION ID)	This mode enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.

GST INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector, which is located under the driver side dash panel near the fuse box cover.
3. Turn ignition switch ON.




TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]


4. Enter the program according to instruction on the screen or in the operation manual.

(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EM9

Remarks:

● Specification data are reference values.

● Specification data are output/input values which are detected or supplied by the ECM at the connector.

* Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value.
MAS A/F SE-B1	<ul style="list-style-type: none"> Engine: After warming up Air conditioner switch: OFF Shift lever: N No-load 	Idle	Approx. 1.0 - 1.7V
		2,500 rpm	Approx. 1.5 - 2.1V
B/FUEL SCHDL	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N Air conditioner switch: OFF No-load 	Idle	1.5 - 3.0 msec
		2,000 rpm	1.2 - 3.0 msec
A/F ALPHA-B1 A/F ALPHA-B2*	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	75% - 125%
COOLAN TEMP/S	<ul style="list-style-type: none"> Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)*	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1) HO2S2 (B2)*	<ul style="list-style-type: none"> Engine: After warming up 	Revvng engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)*	<ul style="list-style-type: none"> Engine: After warming up 	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 MNTR (B1) HO2S2 MNTR (B2)*	<ul style="list-style-type: none"> Engine: After warming up 	Revvng engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION	
VEH SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value	
BATTERY VOLT	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	11 - 14V	
ACCEL SEN1 ACCEL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (engine stopped) 	Accelerator pedal: Fully released Accelerator pedal: Fully depressed	0.35 - 0.67V More than 3.9V
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully released Accelerator pedal: Fully depressed	More than 0.36V Less than 4.75V
START SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON → START → ON 	OFF → ON → OFF	
CLSD THL POS	<ul style="list-style-type: none"> Ignition switch: ON 	Accelerator pedal: Fully released Accelerator pedal: Slightly depressed	ON OFF
AIR COND SIG	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Air conditioner switch: OFF Air conditioner switch: ON (Compressor operates.)	OFF ON
P/N POSI SW	<ul style="list-style-type: none"> Ignition switch: ON 	Shift lever: P or N (A/T model) Neutral (M/T model) Shift lever: Except above	ON OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction) Steering wheel is turned.	OFF ON
LOAD SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON 	Rear window defogger switch is ON and/or lighting switch is in 2nd. Rear window defogger switch is OFF and lighting switch is OFF.	ON OFF
IGNITION SW	<ul style="list-style-type: none"> Ignition switch: ON → OFF → ON 	ON → OFF → ON	
HEATER FAN SW	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Heater fan is operating. Heater fan is not operating	ON OFF
BRAKE SW	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released Brake pedal: Slightly depressed	OFF ON
INJ PULSE-B1 INJ PULSE-B2*	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N Air conditioner switch: OFF No-load 	Idle 2,000 rpm	2.0 - 3.5 msec 1.5 - 3.5 msec
IGN TIMING	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N Air conditioner switch: OFF No-load 	Idle 2,000 rpm	M/T: 8°±5° BTDC A/T: 10°±5° BTDC 25° - 45° BTDC
CAL/LD VALUE	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N Air conditioner switch: OFF No-load 	Idle 2,500 rpm	10% - 35% 10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> Engine: After warming up Shift lever: N Air conditioner switch: OFF No-load 	Idle 2,500 rpm	1.0 - 4.0 g-m/s 5.0 - 10.0 g-m/s

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up 	Idle
	<ul style="list-style-type: none"> ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	2,000 rpm
INT/V TIM (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Idle
	<ul style="list-style-type: none"> ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	2,000 rpm
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Idle
	<ul style="list-style-type: none"> ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	2,000 rpm
AIR COND RLY	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF
		Air conditioner switch: ON (Compressor operates)
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking 	ON
	<ul style="list-style-type: none"> ● Except above conditions 	OFF
THRTL RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON 	ON
COOLING FAN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Engine coolant temperature is 99°C (210°F) or less
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF 	Engine coolant temperature is 100°C (212°F) or more
HO2S1 HTR (B1) HO2S1 HTR (B2)*	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm (M/T models) Below 3,200 rpm (A/T models) 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm (M/T models) Above 3,200 rpm (A/T models) 	OFF
HO2S2 HTR (B1) HO2S2 HTR (B2)*	<ul style="list-style-type: none"> ● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF
TRVL AFTER MIL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Vehicle has traveled after MI has turned ON.
O2SEN HTR DTY	<ul style="list-style-type: none"> ● Engine coolant temperature when engine started: More than 80° (176°F) ● Engine speed: Below 3,600 rpm (M/T models) Below 3,200 rpm (A/T models) 	Approx. 50%
AC PRESS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Approx. 0V
	<ul style="list-style-type: none"> ● Engine: Idle ● Air conditioner switch: OFF 	1.0 - 4.0V
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
CAN COMM	● Ignition switch: ON	OK
CAN CIRC 1		OK
CAN CIRC 2		OK or UNKWN
CAN CIRC 3		UNKWN
CAN CIRC 4		OK
CAN CIRC 5		UNKWN
CAN CIRC 6		OK
CAN CIRC 7		UNKWN

*: These items are displayed with QG18DE engine models

Major Sensor Reference Graph in Data Monitor Mode


EBS00EMA

The following are the major sensor reference graphs in "DATA MONITOR" mode.

CLSD THL POS, ACCEL SEN 1, THRTL SEN 1

Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch "ON" and with selector lever in "D" position (A/T models) or with shift lever in "1st" position (M/T models).

The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.


TROUBLE DIAGNOSIS

[QG (WITH EURO-OBD)]


Each value is for reference, the exact value may vary.




A
EC
C
D
E
F
G
H
I
J
K
L
M




- "THRTL SEN 1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

EBS00EMB

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONITOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

EBS00EMC

- Vehicle driven distance: More than 5,000 km (3,017 miles)
- Barometric pressure: 98.3 - 104.3 kPa (1.003 - 1.064 kg/cm², 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*¹
- Electrical load: Not applied*²
- Engine speed: Idle

*1: For A/T models with CONSULT-II, after the engine is warmed up to normal operating temperature, drive vehicle until "FLUID TEMP SE" (A/T fluid temperature sensor signal) indicates more than 60°C (140°F).

For A/T models without CONSULT-II and M/T models, after the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.

*2: Rear window defogger switch, air conditioner switch, lighting switch are "OFF". Steering wheel is straight ahead.


Inspection Procedure

EBS00EMD

NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

1. Perform [EC-92, "Basic Inspection"](#).
2. Confirm that the testing conditions indicated above are met.
3. Select "B/FUEL SCHDL", "A/F ALPHA-B1/B2" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-140, "Diagnostic Procedure"](#).




TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITH EURO-OBD)]

Diagnostic Procedure

EBS00EME




(Go to next page.)

SEF613ZD

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITH EURO-OBD)]




A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF768Z

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITH EURO-OBD)]



SEF615ZA

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT [QG (WITH EURO-OBD)]

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

Description

EBS00EMF

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the problem area.

Diagnostic Procedure

EBS00EMG

1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITH EURO-OBD)]



POWER SUPPLY CIRCUIT FOR ECM

PFP:24110



Wiring Diagram

EBS00EMH

EC-MAIN-01



REFER TO THE FOLLOWING.
M1 - FUSE BLOCK-JUNCTION BOX (J/B)



MBWA0044E

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 3 seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● 3 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EMI

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

- Yes >> GO TO 8.
- No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF" and then "ON".
2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.


OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminals 1 and 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 111 and ECM relay terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG


OK >> Go to [EC-520, "IGNITION SIGNAL"](#) .

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Stop engine and wait at least 10 seconds.
2. Turn ignition switch "ON" and then "OFF".
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.



OK or NG


OK >> GO TO 13.

NG (Battery voltage does not exist.)>>GO TO 9.

NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 11.
 NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and E70, F13 (LHD models)
- Harness for open or short between ECM relay and E63, F31 (RHD models)

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 119, 120 and ECM relay terminal 5. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 12.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK ECM RELAY

Refer to [EC-149, "Component Inspection"](#).

OK or NG

- OK >> GO TO 13.
 NG >> Replace ECM relay.

13. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 14.

NG >> Repair open circuit or short to power in harness or connectors.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> **INSPECTION END**


Component Inspection

ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC U1000, U1001 CAN COMMUNICATION LINE

[QG (WITH EURO-OBD)]

DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

Description

EBS00G8M

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

EBS00G8N

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	● ECM can not communicate to other control unit.	● Harness or connectors (CAN communication line is open or shorted).
U1001 1001		● ECM can not communicate for more than the specified time.	

DTC Confirmation Procedure

EBS00G8O

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-152, "Diagnostic Procedure"](#).

DTC U1000, U1001 CAN COMMUNICATION LINE [QG (WITH EURO-OBD)]



Wiring Diagram

EBS00G8P

EC-CAN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC
 : DATA LINE



MBWA0038E

DTC U1000, U1001 CAN COMMUNICATION LINE

[QG (WITH EURO-OBD)]

Diagnostic Procedure

EBS00G8Q

1. INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

A/T models

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	OK	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0180E

M/T models

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	UNKWN	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0179E

>> Go to [LAN-8, "CAN COMMUNICATION"](#) .

DTC P0011 IVT CONTROL


PFP:23796

Description
SYSTEM DESCRIPTION

EBS00GW1

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS)	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed signal*	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GW2

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V TIM (B1)	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle -5° - 5°C A
	When revving engine up to 2,000 rpm quickly	Approx. 0° - 30°C A
INT/V SOL (B1)	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle 0% - 2%
	When revving engine up to 2,000 rpm quickly	Approx. 0% - 60%

On Board Diagnosis Logic

EBS00GW4

DTC No.	Trouble diagnosis name	Detecting condition	Possible cause
P0011 0011	Intake valve timing control performance	There is a gap between angle of target and phase-control angle degree.	<ul style="list-style-type: none"> ● Crankshaft position sensor (POS) ● Camshaft position sensor (PHASE) ● Accumulation of debris to the signal pick-up portion of the camshaft

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode.

Detected items	Engine operating condition in fail-safe mode
Intake valve timing control	The signal is not energized to the solenoid valve and the valve control does not function

DTC Confirmation Procedure

EBS00GW5

CAUTION:

Always drive at a safe speed.

NOTE:

- If DTC P0011 is displayed with DTC P1111, first perform trouble diagnosis for “DTC P1111”. See [EC-395, "DTC P1111 IVT CONTROL SOLENOID VALVE"](#) .
- If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10V and 16V at idle.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	1,700 - 3,175 rpm (A constant rotation is maintained.)
COOLANT TEMPS	70 - 105°C (176 - 194°F)
Selector lever	1st or 2nd position
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLANT TEMP/S	XXX °C

SEF174Y

4. If 1st trip DTC is detected, go to [EC-154, "Diagnostic Procedure"](#)

WITH GST

Follow the procedure “WITH CONSULT-II” above.

Diagnostic Procedure

EBS00GW6

1. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-353, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Replace crankshaft position sensor (POS).

2. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-359, "Component Inspection"](#) .

OK or NG

OK >> GO TO 3.

NG >> Replace camshaft position sensor (PHASE).

3. CHECK CAMSHAFT (INTAKE)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

OK >> GO TO 4.

NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



4. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For wiring diagram refer to [EC-350, "Wiring Diagram"](#) for CKP sensor (POS) and [EC-356, "Wiring Diagram"](#) for CMP sensor (PHASE).

>> INSPECTION END

DTC P0031, P0032 HO2S1 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

DTC P0031, P0032 HO2S1 HEATER (QG16DE)

PFP:22690

Description SYSTEM DESCRIPTION

EBS00F04

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00F05

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	<ul style="list-style-type: none">● Engine: After warming up● Engine speed: Below 3,600 rpm	ON
	<ul style="list-style-type: none">● Engine speed: Above 3,600 rpm	OFF

On Board Diagnosis Logic

EBS00F06

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 0031	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none">● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.)● Heater oxygen sensor 1 heater
P0032 0032	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none">● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.)● Heater oxygen sensor 1 heater

DTC Confirmation Procedure

EBS00F07

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0031, P0032 HO2S1 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

3. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 6 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-159, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and run it for at least 6 seconds at idle speed.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine and run it for at least 6 seconds at idle speed.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-159, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**



DTC P0031, P0032 HO2S1 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

EBS00F08

Wiring Diagram

EC-HO2S1H-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0049E


DTC P0031, P0032 HO2S1 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	Heated oxygen sensor 1 heater	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,600 rpm. 	<p>Approximately 7.0V★</p>  <p>10.0 V/Div 50 ms/Div T</p> <p>PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped. <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	<p>BATTERY VOLTAGE (11 - 14V)</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00F09

1. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 24 and HO2S1 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-161, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

DTC P0031, P0032 HO2S1 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

Component Inspection

HEATED OXYGEN SENSOR 1 HEATER

EBS00FOA


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	8 - 10 Ω at 20°C (68°F)
2 and 1, 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation

HEATED OXYGEN SENSOR 1

EBS00FOB

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBDD)]

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE)

PDF:22690

Description SYSTEM DESCRIPTION

EBS00FOC

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,200 (A/T models) Above 3,600 (M/T models)	OFF
Below 3,200 (A/T models) Below 3,600 (M/T models)	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FOD

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1) HO2S1 HTR (B2)	<ul style="list-style-type: none"> Engine: After warming up Engine speed: Below 3,200 rpm (A/T models) Below 3,600 rpm (M/T models) 	ON
	<ul style="list-style-type: none"> Engine speed: Above 3,200 rpm (A/T models) Above 3,600 rpm (M/T models) 	OFF

On Board Diagnosis Logic

EBS00FOE

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 0031 (Bank 1)	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.) Heater oxygen sensor 1 heater
P0051 0051 (Bank 2)			
P0032 0032 (Bank 1)	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.) Heater oxygen sensor 1 heater
P0052 0052 (Bank 2)			

DTC Confirmation Procedure

EBS00FOF

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

3. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 6 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-167, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST



1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and run it for at least 6 seconds at idle speed.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine and run it for at least 6 seconds at idle speed.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-167, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

EBS00FOG

Wiring Diagram BANK 1

EC-O2H1B1-01



REFER TO THE FOLLOWING.

(E105) - FUSE BLOCK-JUNCTION BOX (J/B)


MBWA0053E

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	Heated oxygen sensor 1 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,200 rpm (A/T models). ● Engine speed is below 3,600 rpm (M/T models). 	Approximately 7.0V★ 
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped. [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (A/T models). ● Engine speed is above 3,600 rpm (M/T models). 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

BANK 2

EC-O2H1B2-01



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)


MBWA0055E

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	R/B	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,200 rpm (A/T models). ● Engine speed is below 3,600 rpm (M/T models). 	Approximately 7.0V★  PBIB0519E
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped. [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (A/T models). ● Engine speed is above 3,600 rpm (M/T models). 	BATTERY VOLTAGE (11 - 14V)


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00FOH

1. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE)
[QG (WITH EURO-OBD)]

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0031, P0032	24	1	1
P0051, P0052	25	1	2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-169, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0031, P0032, P0051, P0052 HO2S1 HEATER (QG18DE) [QG (WITH EURO-OBD)]

EBS00FOI

Component Inspection HEATED OXYGEN SENSOR 1 HEATER


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	8 - 10 Ω at 20°C (68°F)
2 and 1, 3, 4	∞ Ω
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FOJ

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

DTC P0037, P0038 HO2S2 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

DTC P0037, P0038 HO2S2 HEATER (QG16DE)

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00F0K

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00F0L

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1)	● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON
	● Engine speed: Above 3,600 rpm	OFF

On Board Diagnosis Logic

EBS00F0M

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 0037	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) ● Heater oxygen sensor 2 heater
P0038 0038	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) ● Heater oxygen sensor 2 heater

DTC Confirmation Procedure

EBS00F0N

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine.
3. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.

DTC P0037, P0038 HO2S2 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

4. Stop vehicle and let engine idle for at least 6 seconds.
5. If 1st trip DTC is detected, go to [EC-173, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

1. Start engine.
 2. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 3. Stop vehicle and let engine idle for at least 6 seconds.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine.
 6. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 7. Stop vehicle and let engine idle for at least 6 seconds.
 8. Select "MODE 3" with GST.
 9. If DTC is detected, go to [EC-173, "Diagnostic Procedure"](#) .
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**




DTC P0037, P0038 HO2S2 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00FOO

EC-HO2S2H-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0051E

DTC P0037, P0038 HO2S2 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/B	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00FOP

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0037, P0038 HO2S2 HEATER (QG16DE)

[QG (WITH EURO-OBD)]

3. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 and HO2S2 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-174, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 2.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2 HEATER

EBS00FOQ


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	$\infty \Omega$ (Continuity should not exist)
3 and 1, 2, 4	

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 2

EBS00FOQ

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE) [QG (WITH EURO-OBD)]

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE)

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00FOS

Sensor	Input Signal to ECM	ECM Function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FOT

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON
	● Engine speed: Above 3,600 rpm	OFF

On Board Diagnosis Logic

EBS00FOU

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 0037 (Bank 1)	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) ● Heater oxygen sensor 2 heater
P0057 0057 (Bank 2)			
P0038 0038 (Bank 1)	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) ● Heater oxygen sensor 2 heater
P0058 0058 (Bank 2)			

DTC Confirmation Procedure

EBS00FOV

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine.
3. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE)
[QG (WITH EURO-OBD)]

4. Stop vehicle and let engine idle for at least 6 seconds.
5. If 1st trip DTC is detected, go to [EC-180, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

 **WITH GST**


1. Start engine.
 2. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 3. Stop vehicle and let engine idle for at least 6 seconds.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine.
 6. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 7. Stop vehicle and let engine idle for at least 6 seconds.
 8. Select "MODE 3" with GST.
 9. If DTC is detected, go to [EC-180, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE) [QG (WITH EURO-OBD)]



EBS00FOW

Wiring Diagram BANK 1

EC-O2H2B1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

**DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE)
[QG (WITH EURO-OBD)]**

Specification data are reference values and are measured between each terminal and ground.

CAUTION:


Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)



DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE) [QG (WITH EURO-OBD)]

BANK 2

EC-O2H2B2-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE) [QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
7	W/R	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> Engine speed is below 3,600 rpm. After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Engine stopped [Engine is running] <ul style="list-style-type: none"> Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00FOX

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect heated oxygen sensor 2 harness connector.
- Turn ignition switch "ON".




- Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE) [QG (WITH EURO-OBD)]

3. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0037, P0038	2	1	1
P0057, P0058	7	1	2

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-181, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace malfunctioning heated oxygen sensor 2.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection HEATED OXYGEN SENSOR 2 HEATER

EBS00FOY


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



**DTC P0037, P0038, P0057, P0058 HO2S2 HEATER (QG18DE)
[QG (WITH EURO-OBD)]**

**Removal and Installation
HEATED OXYGEN SENSOR 2**

EBS00FOZ

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .


DTC P0102, P0103 MAF SENSOR

PFP:22680

Component Description

EBS00EMO

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EMP

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.0 - 1.7V
	2,500 rpm	Approx. 1.5 - 2.1V
CAL/LD VALUE	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	1.0 - 4.0 g-m/s
	2,500 rpm	5.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00EMO

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00EMR

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

DTC P0102, P0103 MAF SENSOR

[QG (WITH EURO-OBD)]

PROCEDURE FOR DTC P0102

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-186, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-186, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-186, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.





DTC P0102, P0103 MAF SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EMS

EC-MAFS-01



MBWA0045E

DTC P0102, P0103 MAF SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
50	Y	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.5 - 2.1V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00EMT

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold

OK or NG


OK >> GO TO 3.

NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 67. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 1 and ECM terminal 50. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-188, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection MASS AIR FLOW SENSOR

EBS00EMU

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.5 - 2.1
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0


*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.

Removal and Installation MASS AIR FLOW SENSOR

EBS00EMV

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .



DTC P0112, P0113 IAT SENSOR


PF2:22630

Component Description

EBS00EMW

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.43	7.9 - 9.3
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 34 (Intake air temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00EMX

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00EMY

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-192, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P0112, P0113 IAT SENSOR

[QG (WITH EURO-OBD)]

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0112, P0113 IAT SENSOR


[QG (WITH EURO-OBD)]

Wiring Diagram



EBS00EMZ

EC-IATS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



MBWA0046E

Diagnostic Procedure**1. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch "OFF".
2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
3. Turn ignition switch "ON".




4. Check voltage between MAF sensor terminal 5 and ground.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**2. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 67. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-193, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0112, P0113 IAT SENSOR

[QG (WITH EURO-OBD)]

Component Inspection



INTAKE AIR TEMPERATURE SENSOR

EBS00EN1

1. Check resistance between mass air flow sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



Removal and Installation

MASS AIR FLOW SENSOR

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

EBS00EN2


DTC P0117, P0118 ECT SENSOR

PFP:22630

Component Description

EBS00EN3


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00EN4

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When this malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-197, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Ⓢ WITH GST

Follow the procedure "WITH CONSULT-II" above.

A
EC
C
D
E
F
G
H
I
J
K
L
M




DTC P0117, P0118 ECT SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EN6

EC-ECTS-01




MBWA0047E

Diagnostic Procedure

1. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature (ECT) sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 2.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between engine coolant temperature sensor and ECM
- Harness for open or short between engine coolant temperature sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-198, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace engine coolant temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR

EBS00EN8


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



2. If NG, replace engine coolant temperature sensor.

Removal and Installation
ENGINE COOLANT TEMPERATURE SENSOR

EBS00EN9

Refer to [CO-20, "THERMOSTAT AND THERMOSTAT HOUSING"](#) .



DTC P0132 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FP0

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FP1


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FP2

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

DTC Confirmation Procedure

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-202, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y


WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-202, "Diagnostic Procedure"](#).
- When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.



Wiring Diagram

EBS00FP4

EC-HO2S1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
(E105) -FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure


EBS00FP5

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch "OFF".
2. Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 CONNECTOR FOR WATER

Check heated oxygen sensor 1 connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-203, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 1**

EBS00FP6

④ With CONSULT-II



1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.

- “HO2S1 MNTR (B1)” in “DATA MONITOR” mode changes from “RICH” to “LEAN” to “RICH” 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- “HO2S1 (B1)” voltage goes above 0.6V at least once.
- “HO2S1 (B1)” voltage goes below 0.3V at least once.
- “HO2S1 (B1)” voltage never exceeds 1.0V.



CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FP7

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).



DTC P0132, P0152 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FP8

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FP9


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FPA

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132 (Bank 1)	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted). ● Heated oxygen sensor 1
P0152 0152 (Bank 2)			

DTC Confirmation Procedure

EBS00FPB

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-210, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y


WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-210, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**



Wiring Diagram
BANK 1

EBS00FPC

EC-O2S1B1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S1B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0054E

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure


EBS00FPD

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch "OFF".
2. Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	35	2	1
P0152	36	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	35	2	1
P0152	36	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 CONNECTOR FOR WATER

Check heated oxygen sensor 1 connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-211, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FPE

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5
	HO2S1 MNTR (B1)	R	L	R	L	R
Bank 2	cycle	1	2	3	4	5
	HO2S1 MNTR (B2)	R	L	R	L	R

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FPF

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P0133 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FPG

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FPH


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FPI

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 0133	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor

DTC Confirmation Procedure

EBS00FPJ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P0133” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANTEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h
SEF338Z	


6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 20 to 50 seconds.)

ENG SPEED	More than 2,100 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	3.2 - 6.7 msec
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANTEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h
SEF339Z	

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-218, "Diagnostic Procedure"](#) .



Overall Function Check

EBS00FPK

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

**2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V
→ 0 - 0.3V**


4. If NG, go to [EC-218, "Diagnostic Procedure"](#) .





Wiring Diagram

EBS00FPL

EC-HO2S1-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



REFER TO THE FOLLOWING.
 (E105) -FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FPM

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 3.




3. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (Manifold).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.



4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG


OK >> GO TO 5.

NG >> Repair or replace.

5. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



Yes or No

Yes >> Perform trouble diagnosis for DTC P0171 or DTC P0172 (Refer to [EC-285](#) or [EC-299](#)).

No >> GO TO 6.

6. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



7. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground. Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-161, "Component Inspection"](#).

OK or NG

OK >> GO TO 9.

NG >> Replace malfunctioning heated oxygen sensor 1.

9. CHECK MASS AIR FLOW SENSOR

Refer to [EC-188, "Component Inspection"](#).

OK or NG

OK >> GO TO 10.

NG >> Replace mass air flow sensor.

10. CHECK PCV VALVE

Refer to [EC-557, "Component Inspection"](#).

OK or NG

OK >> GO TO 11.

NG >> Replace PCV valve.

11. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-221, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Replace heated oxygen sensor 1.

12. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FPN

ⓑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5	
HO2S1 MNTR (B1)	R	L	R	L	R	L

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FPO

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .



DTC P0133, P0153, HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FPP

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FPQ


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FPP

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.



DTC P0133, P0153, HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 0133 (Bank 1)	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor
P0153 0153 (Bank 2)			

DTC Confirmation Procedure

EBS00FPS

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P0133" or "HO2S1 (B2) P0153" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm (M/T models) or 3,200 rpm (A/T models) after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF338Z

6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 20 to 50 seconds.)


ENG SPEED	More than 1,900 rpm (A/T models) More than 2,100 rpm (M/T models)
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	3.7 - 7.8 msec (A/T models) 3.2 - 6.7 msec (M/T models)
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

SEF339Z

If "TESTING" is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-229, "Diagnostic Procedure"](#).



Overall Function Check

EBS00FPT

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1(B1) signal] or 36 [HO2S1(B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

4. If NG, go to [EC-229, "Diagnostic Procedure"](#).






DTC P0133, P0153, HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

EBS00FPU

Wiring Diagram BANK 1

EC-O2S1B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0052E

DTC P0133, P0153, HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V




A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0133, P0153, HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S1B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0054E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FPV

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 3.




3. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (Manifold).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.



4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG


OK >> GO TO 5.

NG >> Repair or replace.

5. CLEAR THE SELF-LEARNING DATA


Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



Yes or No

Yes >> Perform trouble diagnosis for DTC P0171, P0174 or DTC P0172, P0175 (Refer to [EC-291](#) or [EC-305](#)).

No >> GO TO 6.

6. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**7. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	35	2	1
P0153	36	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0133	35	2	1
P0153	36	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-169, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace malfunctioning heated oxygen sensor 1.

9. CHECK MASS AIR FLOW SENSOR

Refer to [EC-188, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace mass air flow sensor.

10. CHECK PCV VALVE

Refer to [EC-557, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 11.
- NG >> Replace PCV valve.

11. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-232, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Replace malfunctioning heated oxygen sensor 1.

12. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FPW

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R-L-R					
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R-L-R-L-R-L-R-L-R-L-R					
R means HO2S1							
MNTR (B1)/(B2) indicates RICH							
L means HO2S1							
MNTR (B1)/(B2) indicates LEAN							

SEF646Y




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).

EBS00FPX



DTC P0134 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FPY

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FPZ


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FQ0

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 (B1) P0134" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
3. Touch "START".
4. Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 4.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0544E

5. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,700 - 3,800 rpm
Vehicle speed	More than 64 km/h (40 MPH)
B/FUEL SCHDL	2.9 - 7.3 msec
Selector lever	Suitable position

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0545E

If "TESTING" is not displayed after 5 minutes, retry from step 2.

6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-238, "Diagnostic Procedure"](#).

HO2S1 (B1) P0134	
COMPLETED	

SEC750C

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.

DTC P0134 HO2S1 (QG16DE)

[QG (WITH EURO-OBD)]


3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-238, "Diagnostic Procedure"](#).





Wiring Diagram

EBS00FQ3

EC-HO2S1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
E105 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00F04

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.

**2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT**

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-239, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> **INSPECTION END**

**Component Inspection
HEATED OXYGEN SENSOR 1**

EBS00FQ5

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

DTC P0134 HO2S1 (QG16DE)


[QG (WITH EURO-OBD)]

6. Check the following.

- “HO2S1 MNTR (B1)” in “DATA MONITOR” mode changes from “RICH” to “LEAN” to “RICH” 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- “HO2S1 (B1)” voltage goes above 0.6V at least once.
- “HO2S1 (B1)” voltage goes below 0.3V at least once.
- “HO2S1 (B1)” voltage never exceeds 1.0V.

cycle | 1 | 2 | 3 | 4 | 5 |
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R
 R means HO2S1 MNTR (B1) indicates RICH
 L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
 HEATED OXYGEN SENSOR 1**

EBS00FQ6

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .





DTC P0134, P0154 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FQ7

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FQ8


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FQ9

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1
P0154 0154 (Bank 2)			

DTC Confirmation Procedure

EBS00FOA

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 (B1) P0134" or "HO2S1 (B2) P0154" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
3. Touch "START".
4. Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm (M/T models) or 3,200 rpm (A/T models) after this step. If the engine speed limit is exceeded, return to step 4.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0544E

5. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,500 - 3,400 rpm (A/T models) 1,700 - 3,800 rpm (M/T models)
Vehicle speed	More than 64 km/h (40 MPH)
B/FUEL SCHDL	3.3 - 8.7 msec (A/T models) 2.9 - 7.3 msec (M/T models)
Selector lever	Suitable position

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0545E

If "TESTING" is not displayed after 5 minutes, retry from step 2.

6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-247, "Diagnostic Procedure"](#).

HO2S1 (B1) P0134	
COMPLETED	

SEC750C


Overall Function Check

EBS00FQB

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-247, "Diagnostic Procedure"](#).






DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

EBS00FQC

Wiring Diagram BANK 1

EC-O2S1B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0052E

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V




A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S1B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0054E

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FQD

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	35	2	1
P0154	36	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	35	2	1
P0154	36	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-248, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00F0E

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	R	L	R	L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	R	L	R	L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FQF

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .


DTC P0138 HO2S2 (QG16DE)

PFP:226A0

Component Description

EBS00FQG

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FQH


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FQJ

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2

DTC Confirmation Procedure

EBS00FQK

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
3. Stop vehicle with engine running.

4. Let engine idle for 1 minute.
5. If 1st trip DTC is detected, go to [EC-254, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y


Overall Function Check

EBS00FQL

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST




1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 1.4V during this procedure.
5. If NG, go to [EC-254, "Diagnostic Procedure"](#).



Wiring Diagram

EBS00FQM

EC-HO2S2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00FQN

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-299](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-256, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00FQ0


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)


The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

EBS00FQP

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0138, P0158 HO2S2 (QG18DE)

PFP:226A0

Component Description


EBS00FQQ

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FQR


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FQT

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2
P0158 0158 (Bank 2)			

DTC Confirmation Procedure

EBS00FQU

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
3. Stop vehicle with engine running.

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

- Let engine idle for 1 minute.
- If 1st trip DTC is detected, go to [EC-263, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y


Overall Function Check

EBS00FQV

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

- Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- Stop vehicle with engine running.
- Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
The voltage should be below 1.4V during this procedure.
- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
- If NG, go to [EC-263, "Diagnostic Procedure"](#).






DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

EBS00FQW

Wiring Diagram BANK 1

EC-O2S2B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0056E

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V




A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S2B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0058E

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FQX

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



☒ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-305](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	16	2	1
P0158	17	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	16	2	1
P0158	17	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-265, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

**Component Inspection
HEATED OXYGEN SENSOR 2**

EBS00FQY

 **With CONSULT-II**

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.
5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.50V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#).

EBS00FQZ


DTC P0139 HO2S2 (QG16DE)

PFP:226A0

Component Description

EBS00FR0

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FR1


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FR3

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 0139	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00FR4

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

Ⓟ WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P0139" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105 °C
Selector level	Suitable position

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P0139																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P0139																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0552E

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completely from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)

NOTE:


If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">HO2S2 (B1) P0139</td></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><td colspan="2" style="text-align: center;">MONITOR</td></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P0139														
COND1:	COMPLETED													
COND2:	COMPLETED													
COND3:	INCOMPLETE													
MONITOR														
ENG SPEED	XXX rpm													
B/FUEL SCHDL	XXX msec													

PBIB0553E

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-271, "Diagnostic Procedure"](#).


**Overall Function Check**

EBS00FR5

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.




WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should change at more than 0.06V for 1 second during this procedure.
6. If NG, go to [EC-271, "Diagnostic Procedure"](#).



Wiring Diagram

EC-HO2S2-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00FR7

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-285](#) or [EC-299](#).
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-273, "Component Inspection"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 2**

EBS00FR8


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.


CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .



EBS00FR9


DTC P0139, P0159 HO2S2 (QG18DE)

PFP:226A0

Component Description

EBS00FRA

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FRB


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FRD

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 0139 (Bank 1)	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks
P0159 0159 (Bank 2)			

DTC Confirmation Procedure

EBS00FRE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P0139" or "HO2S2 (B2) P0159" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105 °C
Selector level	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0552E
HO2S2 (B1) P0139																																													
COND1:	OUT OF CONDITION																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P0139																																													
COND1:	TESTING																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P0139																																													
COND1:	COMPLETED																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completely with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)


NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0553E
HO2S2 (B1) P0139															
COND1:	COMPLETED														
COND2:	COMPLETED														
COND3:	INCOMPLETE														
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-281, "Diagnostic Procedure"](#) .




Overall Function Check

EBS00FRF

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should change at more than 0.06V for 1 second during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should change at more than 0.06V for 1 second during this procedure.
6. If NG, go to [EC-281, "Diagnostic Procedure"](#) .






DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

EBS00FRG

Wiring Diagram BANK 1

EC-O2S2B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0056E

DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V




A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S2B2-01



REFER TO THE FOLLOWING.

(E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0058E

DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FRH

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171, P0172, P0174 or P0175 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174 or P0172, P0175. Refer to [EC-291](#) or [EC-305](#).
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	16	2	1
P0159	17	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0139	16	2	1
P0159	17	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-283, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

**Component Inspection
HEATED OXYGEN SENSOR 2**

EBS00FRI

 **With CONSULT-II**

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

DTC P0139, P0159 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.


6. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#).



EBS00FRJ

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE)

PF16600

On Board Diagnosis Logic

EBS00ENA

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 0171	Fuel injection system too lean	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor ● Incorrect PCV hose connection

DTC Confirmation Procedure


EBS00ENB

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching "CLEAR".
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-288, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-288, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-288, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-288, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.





DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

EBS00ENC

Wiring Diagram

EC-FUEL-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0060E

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

EBS00END


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Listen for an intake air leak after the mass air flow sensor.
2. Check PCV hose connection.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2, ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.

Continuity should exist.

5. Check harness continuity between ECM terminals 35, 74 or HO2S1 terminals 2, 3 and ground. Refer to Wiring Diagram.

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.


4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#).
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-58, "FUEL PRESSURE CHECK"](#).

At idling: Approximately 350 kPa (3.7 kg/cm² , 51 psi)

OK or NG

- OK >> GO TO 5.
NG >> Follow the construction of "FUEL PRESSURE CHECK".



DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

5. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10 g-m/sec: at 2,500 rpm

With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 6.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-183, "DTC P0102, P0103 MAF SENSOR"](#) .

6. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for [EC-530, "INJECTOR CIRCUIT"](#) .

DTC P0171 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

7. CHECK INJECTOR


1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch "OFF".
3. Disconnect injector harness connectors.
4. Remove injector gallery assembly. Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors should remain connected.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injector.
7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each injector.

OK or NG

OK >> GO TO 8.

NG >> Replace injectors from which fuel does not spray out.
Always replace O-ring with new ones.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE)

PFP:16600

On Board Diagnosis Logic

EBS00ENE

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 0171 (Bank 1)	Fuel injection system too lean	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> ● Intake air leaks ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Lack of fuel ● Mass air flow sensor ● Incorrect PCV hose connection
P0174 0174 (Bank 2)			

DTC Confirmation Procedure


EBS00ENF

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching "CLEAR".
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-295, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-295, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 or P0174 should be detected at this stage, if a malfunction exists. If so, go to [EC-295, "Diagnostic Procedure"](#) .
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-295, "Diagnostic Procedure"](#) . If engine does not start, check exhaust and intake air leak visually.




DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]


EBS00ENG

Wiring Diagram BANK 1

EC-FUEL B1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M





REFER TO THE FOLLOWING.
 (M1), (E105) - FUSE BLOCK-
 JUNCTION BOX (J/B)

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

BANK 2

EC-FUELB2-01



REFER TO THE FOLLOWING.
 (M1), (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0062E

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

EBS00ENH


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK

1. Listen for an intake air leak after the mass air flow sensor.
2. Check PCV hose connection.


OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect corresponding heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.



DTC	Terminals		Bank
	ECM	Sensor	
P0171	35	2	1
	74	3	
P0174	36	2	2
	74	3	

Continuity should exist.

5. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0171	35, 74	2, 3	1
P0174	36, 74	2, 3	2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-58, "FUEL PRESSURE CHECK"](#) .

At idling: 350 kPa (3.7 kg/cm² , 51 psi)

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-536, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-58, "FUEL PRESSURE CHECK"](#) .)
- Fuel lines (Refer to [MA-23, "Checking Fuel Lines"](#) .)
- Fuel filter for clogging

>> Repair or replace.

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

6. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling
5.0 - 10.0 g-m/sec: at 2,500 rpm

With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling
5.0 - 10.0 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 7.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-183, "DTC P0102, P0103 MAF SENSOR"](#) .

7. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 8.

NG >> Perform trouble diagnosis for [EC-530, "INJECTOR CIRCUIT"](#) .

DTC P0171, P0174 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

8. CHECK INJECTOR


1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch "OFF".
3. Disconnect injector harness connectors on bank 2 (for DTC P0171), bank 1 (for DTC P0174).
4. Remove injector gallery assembly. Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors on bank 1 (for DTC P0171), bank 2 (for DTC P0174) should remain connected.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injector.
7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each injector.

OK or NG

OK >> GO TO 9.

NG >> Replace injectors from which fuel does not spray out.
Always replace O-ring with new ones.



9. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE)

PPF:16600

On Board Diagnosis Logic

EBS00FRK

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 0172	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor

DTC Confirmation Procedure


EBS00FRL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching "CLEAR".
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes.
The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-302, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-302, "Diagnostic Procedure"](#). If engine does not start, remove ignition plugs and check for fouling, etc.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-302, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-302, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.





DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

Wiring Diagram

EBS00FRM

EC-FUEL-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0060E

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

EBS00FRN


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2, ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.

Continuity should exist.

5. Check harness continuity between ECM terminals 35, 74 or HO2S1 terminals 2, 3 and ground. Refer to Wiring Diagram.

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.


4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#).
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-58, "FUEL PRESSURE CHECK"](#).

At idling: 350 kPa (3.7 kg/cm², 51 psi)

OK or NG

- OK >> GO TO 5.
NG >> Follow the construction of "FUEL PRESSURE CHECK".



DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

5. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10 g-m/sec: at 2,500 rpm

With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 6.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-183, "DTC P0102, P0103 MAF SENSOR"](#) .

6. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for [EC-530, "INJECTOR CIRCUIT"](#) .

DTC P0172 FUEL INJECTION SYSTEM FUNCTION (QG16DE)
[QG (WITH EURO-OBD)]

7. CHECK INJECTOR

1. Remove injector assembly. Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect injector harness connectors.
The injector harness connectors should remain connected.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 8.

NG (Drips.)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE)

PFP:16600

On Board Diagnosis Logic

EBS00FR0

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 0172 (Bank 1)	Fuel injection system too rich	<ul style="list-style-type: none"> ● Fuel injection system does not operate properly. ● The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Injectors ● Exhaust gas leaks ● Incorrect fuel pressure ● Mass air flow sensor
P0175 0175 (Bank 2)			

DTC Confirmation Procedure


EBS00FRP

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
4. Clear the self-learning control coefficient by touching "CLEAR".
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172, P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-309, "Diagnostic Procedure"](#).
7. If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
8. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-309, "Diagnostic Procedure"](#). If engine does not start, remove ignition plugs and check for fouling, etc.




WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 or P0175 should be detected at this stage, if a malfunction exists. If so, go to [EC-309, "Diagnostic Procedure"](#) .
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-309, "Diagnostic Procedure"](#) . If engine does not start, check exhaust and intake air leak visually.




DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]


EBS00FRQ

Wiring Diagram BANK 1

EC-FUEL B1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M





REFER TO THE FOLLOWING.
M1, **E105** - FUSE BLOCK-
 JUNCTION BOX (J/B)

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

BANK 2

EC-FUELB2-01



REFER TO THE FOLLOWING.
 (M1), (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0062E

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

EBS00FRR


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK


Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect corresponding heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.



DTC	Terminals		Bank
	ECM	Sensor	
P0172	35	2	1
	74	3	
P0175	36	2	2
	74	3	

Continuity should exist.

5. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0172	35, 74	2, 3	1
P0175	36, 74	2, 3	2

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#) .
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-58, "FUEL PRESSURE CHECK"](#) .

At idling: 350 kPa (3.7 kg/cm² , 51 psi)

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Fuel pump and circuit (Refer to [EC-536, "FUEL PUMP CIRCUIT"](#) .)
- Fuel pressure regulator (Refer to [EC-58, "FUEL PRESSURE CHECK"](#) .)

>> Repair or replace.

6. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

2.0 - 6.0 g-m/sec: at idling
7.0 - 20.0 g-m/sec: at 2,500 rpm

 **With GST**

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

2.0 - 6.0 g-m/sec: at idling
7.0 - 20.0 g-m/sec: at 2,500 rpm

OK or NG

- OK >> GO TO 7.
NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-183, "DTC P0102, P0103 MAF SENSOR"](#) .

DTC P0172, P0175 FUEL INJECTION SYSTEM FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

7. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 8.

NG >> Perform trouble diagnosis for [EC-530, "INJECTOR CIRCUIT"](#).

8. CHECK INJECTOR

1. Remove injector assembly. Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#).
Keep fuel hose and all injectors connected to injector gallery.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect injector harness connectors bank 2 (for DTC P0172), bank 1 (for P0175).
The injector harness connectors on bank 1 (for P0172), bank 2 (for P0175) should remain connected.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 9.

NG (Drips.)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

DTC P0221 TP SENSOR


PF:16119

Component Description

EBS00ENI

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00ENJ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V

On Board Diagnosis Logic

EBS00ENK

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0221 0221	Throttle position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.
- So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00ENL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0221 TP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-315, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P0221 TP SENSOR

[QG (WITH EURO-OBD)]

EBS00ENM

EC-TPS3-01

Wiring Diagram



MBWA0138E

DTC P0221 TP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00ENN

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4, ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-317, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection
THROTTLE POSITION SENSOR**

EBS00ENO

1. Reconnect all harness connectors disconnected.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-55, "Idle Air Volume Learning"](#) .



**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00ENP

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P0222, P0223 TP SENSOR


PFP:16119

Component Description

EBS00ENQ

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00ENR

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00ENS

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 1 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.
- So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00ENT

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0222, P0223 TP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-321, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P0222, P0223 TP SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ENU

EC-TPS1-01



MBWA0136E

DTC P0222, P0223 TP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00ENV

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-323, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00ENW

1. Reconnect all harness connectors disconnected.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-55, "Idle Air Volume Learning"](#) .



MBIB0022E

Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00ENX

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P0226 APP SENSOR

PFP:18002


Component Description

EBS00ENY

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00ENZ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1 ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00E00

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0226 0226	Accelerator pedal position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> ● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) ● Accelerator pedal position sensor 1 and 2

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00E01

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-327, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0226 APP SENSOR



[QG (WITH EURO-OBD)]

EBS00E02

Wiring Diagram

EC-APPS3-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



MBWA0142E

DTC P0226 APP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00E03

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminals 1, 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 82 and APP sensor terminal 4, ECM terminal 83 and APP sensor terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-329, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection

ACCELERATOR PEDAL POSITION SENSOR

EBS00E04


1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QG (WITH EURO-OBD)]

3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-55, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

EBS00E05

DTC P0227, P0228 APP SENSOR

PFP:18002


Component Description

EBS00E06

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E07

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00E08

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0227 0227	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P0228 0228	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00E09

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0227, P0228 APP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-334, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0227, P0228 APP SENSOR





[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EOA

EC-APPS1-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



MBWA0140E

DTC P0227, P0228 APP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00EOB

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 82 and APP sensor terminal 4. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-336, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00EOC

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P0227, P0228 APP SENSOR

[QG (WITH EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-55, "Idle Air Volume Learning"](#) .

A

Remove and Installation ACCELERATOR PEDAL

EBS00E0D

EC

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

C

D

E

F

G

H

I

J

K

L

M

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

[QG (WITH EURO-OBD)]

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

PFP:00000

On Board Diagnosis Logic

EBS00EOE

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (POS)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.
When a misfire condition occurs, the ECM monitors the CKP sensor (POS) signal every 200 engine revolutions for a change.
When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off.
If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink.
When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.
If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300 0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none">● Improper spark plug● Insufficient compression● Incorrect fuel pressure● The injector circuit is open or shorted● Fuel injectors● Intake air leak● The ignition signal circuit is open or shorted● Lack of fuel● Drive plate or flywheel● Heated oxygen sensor 1● Incorrect PCV hose connection
P0301 0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302 0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303 0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304 0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	

DTC Confirmation Procedure

EBS00EOF

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and warm it up to normal operating temperature.
3. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

[QG (WITH EURO-OBD)]

- Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.
NOTE:
Refer to the freeze frame data for the test driving conditions.
- If 1st trip DTC is detected, go to [EC-339, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

PBIB0164E

WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00EOG

1. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

- Start engine and run it at idle speed.
- Listen for the sound of the intake air leak.
- Check PCV hose connection.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. PERFORM POWER BALANCE TEST

With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V


PBIB0133E

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?

Yes or No

- Yes >> GO TO 4.
 No >> GO TO 7.




4. CHECK INJECTOR

Does each injector make an operating sound at idle?

Yes or No

- Yes >> GO TO 5.
 No >> Check injector(s) and circuit(s). Refer to [EC-530](#).
["INJECTOR CIRCUIT"](#).




5. CHECK IGNITION SPARK

1. Disconnect ignition coil assembly from rocker cover.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

OK or NG

- OK >> GO TO 6.
 NG >> Check ignition coil, power transistor and their circuits.
 Refer to [EC-520](#). ["IGNITION SIGNAL"](#).




6. CHECK SPARK PLUGS

Remove the spark plugs and check for fouling, etc.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-26, "Checking and Changing Spark Plugs"](#).



7. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to [EM-57, "CHECKING COMPRESSION PRESSURE"](#).

QG16DE engine

Standard: 1,353 kPa (13.53 bar, 13.8 kg/cm², 196 psi)/350 rpm

Minimum: 1,157 kPa (11.57 bar, 11.8 kg/cm², 168 psi)/350 rpm

Difference between each cylinder: 98 kPa (0.98 bar, 1.0 kg/cm², 14 psi)/350 rpm

QG18DE engine

Standard: 1,324 kPa (13.24 bar, 13.5 kg/cm², 192 psi)/350 rpm

Minimum: 1,128 kPa (11.28 bar, 11.5 kg/cm², 164 psi)/350 rpm

Difference between each cylinder: 98 kPa (0.98 bar, 1.0 kg/cm², 14 psi)/350 rpm

OK or NG

OK >> GO TO 8.

NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

8. CHECK FUEL PRESSURE

1. Install all removed parts.
2. Release fuel pressure to zero. Refer to [EC-58, "FUEL PRESSURE RELEASE"](#).
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-58, "FUEL PRESSURE CHECK"](#).

At idle: Approx. 350 kPa (3.7 kg/cm², 51 psi)

OK or NG

OK >> GO TO 9.

NG >> Follow the construction of "FUEL PRESSURE CHECK".

9. CHECK IGNITION TIMING

Check the following items. Refer to [EC-92, "Basic Inspection"](#) .

Items	Specifications	
Target idle speed	A/T	800 ± 50 rpm (in "P" or "N" position)
	M/T	700 ± 50 rpm
Ignition timing	A/T	10 ± 5° BTDC (in "P" or "N" position)
	M/T	8 ± 5° BTDC

OK or NG

OK >> GO TO 10.

NG >> Follow the "Basic Inspection".

10. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-203, "Component Inspection"](#) (QG16DE engine models), [EC-211, "Component Inspection"](#) (QG18DE engine models).

OK or NG

OK >> GO TO 12.

NG >> GO TO 11.

11. CHECK MASS AIR FLOW SENSOR

 **With CONSULT-II**

Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10.0 g-m/sec: at 2,500 rpm

 **With GST**

Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling

5.0 - 10.0 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 12.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-183, "DTC P0102, P0103 MAF SENSOR"](#) .

12. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in [EC-97, "Symptom Matrix Chart"](#) .

OK or NG

OK >> GO TO 13.

NG >> Repair or replace.

13. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

>> GO TO 14.

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

[QG (WITH EURO-OBD)]

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P0327, P0328 KS

PFP:22060

Component Description

EBS00EOH

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



On Board Diagnosis Logic

EBS00EOI

The MI will not light for knock sensor malfunction.

DTC No.	Trouble Diagnosis Name	DTC Detected Condition	Possible Cause
P0327 0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328 0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00EOJ

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-346, "Diagnostic Procedure"](#)



WITH GST


Follow the procedure "WITH CONSULT-II" above.

Wiring Diagram


EBS00EOK

EC-KS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V
54	—	Sensor ground (Knock sensor shield circuit)	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00EOL

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 15 and engine ground. Refer to Wiring Diagram.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance: Approximately 530 - 590kΩ [at 20°C (68°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-II


1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 15 and knock sensor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK KNOCK SENSOR**

Refer to [EC-347, "Component Inspection"](#).


OK or NG

- OK >> GO TO 5.
NG >> Replace knock sensor.

4. RETIGHTEN GROUND SCREWS

Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection KNOCK SENSOR

EBS00EOM

Check resistance between knock sensor terminal 1 and ground.


NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance: Approximately 530 - 590kΩ [at 20°C (68°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



EBS00EON

Removal and Installation KNOCK SENSOR

Refer to [EM-70, "CYLINDER BLOCK"](#) .

DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

DTC P0335 CKP SENSOR (POS)

PFP:23731

Component Description

EBS00E00

The crankshaft position sensor (POS) is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.


The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E0P

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

EBS00E0Q

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Crankshaft position sensor (POS) Signal plate

DTC Confirmation Procedure

EBS00E0R

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON".

WITH CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-351, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.

A

EC

C

D

E

F

G

H

I

J

K

L

M





DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

EBS00EOS

EC-POS-01

Wiring Diagram



MBWA0064E



DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	W	Crankshaft position sensor (POS)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 3V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 3V★</p> 
30	B	Crankshaft position sensor (POS) ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00E0T

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

2. CHECK CKP SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CKP sensor (POS) terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 30 and CKP sensor (POS) terminal 1
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for and short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-353, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace crankshaft position sensor (POS).

7. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 8.

NG >> Replace the signal plate.

8. CHECK INTERMITTENT INCIDENT


Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

**Component Inspection
CRANKSHAFT POSITION SENSOR (POS)**

EBS00EOU

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



PBIB0563E


DTC P0335 CKP SENSOR (POS)

[QG (WITH EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	

6. If NG, replace crankshaft position sensor (POS).



EBS00EOV

Removal and Installation CRANKSHAFT POSITION SENSOR (POS)

Refer to [EM-70, "CYLINDER BLOCK"](#) .

DTC P0340 CMP SENSOR (PHASE)

[QG (WITH EURO-OBD)]

DTC P0340 CMP SENSOR (PHASE)

PFP:23731

Component Description

EBS00EOW

The camshaft position sensor (PHASE) senses the retraction with intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.


When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



On Board Diagnosis Logic

EBS00EOX

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. The cylinder No. signal is not set to ECM during engine running. The cylinder No. signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Camshaft position sensor (PHASE) Camshaft (Intake) Starter motor (Refer to SC-22 .) Starting system circuit (Refer to SC-22 .) Dead (Weak) battery

DTC Confirmation Procedure

EBS00EOY

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-357, "Diagnostic Procedure"](#).
If 1st trip DTC is not detected, go to next step.
- Maintain engine speed at more than 800 rpm for at least 5 seconds.
- If 1st trip DTC is detected, go to [EC-357, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
COOLAN TEMP/S	XXX °C

SEF013Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.





DTC P0340 CMP SENSOR (PHASE)

[QG (WITH EURO-OBD)]

EBS00EOZ

EC-PHASE-01

Wiring Diagram



MBWA0065E

DTC P0340 CMP SENSOR (PHASE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	R	Camshaft position sensor (PHASE)	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 4.0V★ PBIB0525E
			[Engine is running] ● Engine speed is 2,000 rpm.	1.0 - 4.0V★ PBIB0526E
29	B	Camshaft position sensor (PHASE) ground	[Engine is running] ● Idle speed	Approximately 0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00EP0

1. CHECK STARTING SYSTEM

Turn ignition switch to "START" position.

Does the engine turn over?

Does the starter motor operate?

Yes or No


Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-22. "STARTING SYSTEM"](#) .)

2. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 3.



3. CHECK CMP SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CMP sensor (PHASE) terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 29 and CMP sensor (PHASE) terminal 1.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 14 and CMP sensor (PHASE) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground or short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0340 CMP SENSOR (PHASE)

[QG (WITH EURO-OBD)]

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-359, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace camshaft position sensor (PHASE).


8. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 9.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



9. CHECK INTERMITTENT INCIDENT


Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection CAMSHAFT POSITION SENSOR (PHASE)


EBS00EP1

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	



DTC P0340 CMP SENSOR (PHASE)

[QG (WITH EURO-OBD)]

Removal and Installation CAMSHAFT POSITION SENSOR (PHASE)

EBS00EP2

Refer to [EM-36, "CAMSHAFT"](#) .

DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE)

PF2:20905


On Board Diagnosis Logic

EBS00FRS

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> Three way catalyst (Manifold) does not operate properly. Three way catalyst (Manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> Three way catalyst (Manifold) Exhaust tube Intake air leaks Fuel injectors Fuel injector leaks Spark plug Improper ignition timing

DTC Confirmation Procedure

EBS00FR2

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Open engine hood before conducting the following procedure.
 - Do not hold engine speed for more than the specified minutes below.
- Turn ignition switch "ON".
 - Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
 - Start engine.
 - Rev engine up to 2,500 to 3,500 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "COMPLT", go to step 7
 - Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0566E

DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

6. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.

SRT WORK SUPPORT	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0567E

7. Select "SELF-DIAG RESULTS" mode with CONSULT-II.
8. Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-363, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

Overall Function Check

EBS00FRU


Use this procedure to check the overall function of the three way catalyst (Manifold). During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeters probes between ECM terminal 35 (HO2S1 signal) and engine ground, and ECM terminal 16 (HO2S2 signal) and engine ground.
4. Keep engine speed at 2,000 rpm constant under no load.



5. Make sure that the voltage switching frequency (high & low) between ECM terminal 16 and engine ground is very less than that of ECM terminal 35 and engine ground.


Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency

B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly. Go to [EC-363, "Diagnostic Procedure"](#).



NOTE:

If the voltage at terminal 35 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133" first. (See [EC-214](#).)

DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE) [QG (WITH EURO-OBD)]

EBS00FRV

Diagnostic Procedure

1. CHECK EXHAUST SYSTEM

Visually check exhaust tubes and muffler for dent.

OK or NG


- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before the three way catalyst (Manifold).

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.



3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-92, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	8° ± 5° BTDC
Target idle speed	700 ± 50 rpm

OK or NG

- OK >> GO TO 5.
- NG >> Follow the "Basic Inspection".


5. CHECK INJECTORS

1. Refer to Wiring Diagram for Injectors, [EC-531](#) .
2. Stop engine and then turn ignition switch "ON".
3. Check voltage between ECM terminals 22, 23, 41, 42 and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

- OK >> GO TO 6.
- NG >> Perform [EC-532, "Diagnostic Procedure"](#) .



DTC P0420 THREE WAY CATALYST FUNCTION (QG16DE)
[QG (WITH EURO-OBD)]


6. CHECK IGNITION SPARK

1. Turn ignition switch "OFF".
2. Disconnect ignition coil assembly from rocker cover.
3. Connect a known good spark plug to the ignition coil assembly.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

OK >> GO TO 7.

NG >> Check ignition coil with power transistor and their circuit.
Refer to [EC-520, "IGNITION SIGNAL"](#) .



7. CHECK INJECTOR

1. Turn ignition switch "OFF".
2. Remove injector assembly.
Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect all ignition coil harness connectors.
4. Turn ignition switch "ON".
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 8.

NG (Drips.)>>Replace the injector(s) from which fuel is dripping.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed.>>**INSPECTION END**

Trouble is not fixed.>>Replace three way catalyst (Manifold).

DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE)

PF20905


On Board Diagnosis Logic

EBS00FRW

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420 (Bank 1)	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) does not operate properly. ● Three way catalyst (Manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> ● Three way catalyst (Manifold) ● Exhaust tube ● Intake air leaks ● Fuel injectors ● Fuel injector leaks ● Spark plug ● Improper ignition timing
P0430 0430 (Bank 2)			

DTC Confirmation Procedure

EBS00FRX

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

TESTING CONDITION:

- Open engine hood before conducting the following procedure.
 - Do not hold engine speed for more than the specified minutes below.
1. Turn ignition switch "ON".
 2. Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
 3. Start engine.
 4. Rev engine up to 2,500 to 3,500 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely.
If "INCMP" of "CATALYST" changed to "COMPLT", go to step 7
 5. Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0566E

DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

6. Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.

SRT WORK SUPPORT	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0567E

7. Select "SELF-DIAG RESULTS" mode with CONSULT-II.
8. Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-367, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

Overall Function Check


EBS00FRY

Use this procedure to check the overall function of the three way catalyst (Manifold). During this check, a 1st trip DTC might not be confirmed.

CAUTION:
Always drive vehicle at a safe speed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeters probes between ECM terminals 35 [HO2S1 (B 1) signal], 36 [HO2S1 (B 2) signal] and engine ground, and ECM terminals 16 [HO2S2 (B 1) signal], 17 [HO2S2 (B 2) signal] and engine ground.
4. Keep engine speed at 2,000 rpm constant under no load.



5. Make sure that the voltage switching frequency (high & low) between ECM terminals 16 and engine ground, or 17 and engine ground is very less than that of ECM terminals 35 and engine ground, or 36 and engine ground.


Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency

B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly. Go to [EC-367, "Diagnostic Procedure"](#).



DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

NOTE:

If the voltage at terminal 35 or 36 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133, P0153" first. (See [EC-223](#).)

Diagnostic Procedure

EBS00FRZ

1. CHECK EXHAUST SYSTEM

Visually check exhaust tubes and muffler for dent.

OK or NG


- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before the three way catalyst (Manifold).

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.



3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace.

4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-92, "Basic Inspection"](#) .

Items	Specifications
Ignition timing	M/T: $8^{\circ} \pm 5^{\circ}$ BTDC
	A/T: $10^{\circ} \pm 5^{\circ}$ BTDC (in "P" or "N" position)
Target idle speed	M/T: 700 ± 50 rpm
	A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 5.
- NG >> Follow the [EC-92, "Basic Inspection"](#) .

DTC P0420, P0430 THREE WAY CATALYST FUNCTION (QG18DE) [QG (WITH EURO-OBD)]

5. CHECK INJECTORS

1. Stop engine and then turn ignition switch "ON".
2. Check voltage between ECM terminals 22, 23, 41, 42 and ground with CONSULT-II or tester.


Battery voltage should exist.

3. Refer to Wiring Diagram for Injectors, [EC-531](#) .

OK or NG

OK >> GO TO 6.

NG >> Perform [EC-532, "Diagnostic Procedure"](#) .




6. CHECK IGNITION SPARK

1. Turn ignition switch "OFF".
2. Disconnect ignition coil assembly from rocker cover.
3. Connect a known good spark plug to the ignition coil assembly.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

OK >> GO TO 7.

NG >> Check ignition coil with power transistor and their circuit.
Refer to [EC-520, "IGNITION SIGNAL"](#) .



7. CHECK INJECTOR

1. Turn ignition switch "OFF".
2. Remove injector assembly.
Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect all ignition coil harness connectors.
4. Turn ignition switch "ON".
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 8.

NG (Drips.)>>Replace the injector(s) from which fuel is dripping.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed.>>**INSPECTION END**

Trouble is not fixed.>>Replace three way catalyst (Manifold).

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PF3:14920

Description SYSTEM DESCRIPTION

EBS00GW7

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage*2		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Vehicle speed signal*1	Vehicle speed		


*: This signal is sent to the ECM through CAN communication line.

*2: The ECM determines the start signal status by the signals of engine speed and battery voltage.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GW8

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
PURG VOL C/V	● Engine: After warming up ● Shift lever: N	Idle 0%
	● Air conditioner switch: OFF ● No-load	2,000 rpm 15 - 30%

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

On Board Diagnosis Logic

EBS00GWA

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444 0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445 0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

EBS00GWB

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 13 seconds.
4. If 1st trip DTC is detected, go to [EC-372, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.


DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]




Wiring Diagram

EBS00GWC

EC-PGC/V-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- L** : LHD MODELS
- R** : RHD MODELS



MBWA0066E



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	GY/L	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p>PBIB0520E</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GWD

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 19 and EVAP canister purge volume control solenoid valve terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 4.

OK (Without CONSULT-II)>>GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-374, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace EVAP canister purge volume control solenoid valve.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

Component Inspection


EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00GWE

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between A and B
100.0%	Yes
0.0%	No



Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



Removal and Installation

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00GWF

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P0500 VSS

PF3:32702

Description

EBS00EP3

NOTE:

If DTC P0500 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-150, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from ABS actuator and electric unit (control unit) through CAN communication line. The combination meter then sends a signal to the ECM through CAN communication line.

On Board Diagnosis Logic

EBS00EP4

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500 0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The CAN communication line is open or shorted.) ● ABS actuator and electric unit (control unit) ● Combination meter ● Vehicle speed signal

DTC Confirmation Procedure

EBS00EP5

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Start engine.
2. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to [EC-376, "Diagnostic Procedure"](#).
If OK, go to following step.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	2,000 - 6,000 rpm (A/T models) 2,300 - 6,000 rpm (M/T models)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	More than 5.0 msec (A/T models) More than 4.3 msec (M/T models)
Selector lever	Suitable position
PW/ST SIGNAL	OFF

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

6. If 1st trip DTC is detected, go to [EC-376, "Diagnostic Procedure"](#).

Overall Function Check

EBS00EP6

Use this procedure to check the overall function of the vehicle speed signal circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.

2. Start engine.
3. Read vehicle speed signal in "MODE 1" with GST.
The vehicle speed signal on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-376, "Diagnostic Procedure"](#) .

Diagnostic Procedure

EBS00EP7

1. CHECK DTC

Check DTC with ABS actuator and electric unit (control unit), Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#) .

>> INSPECTION END


DTC P0550 PSP SENSOR

PF:49763

Component Description

EBS00FS0

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FS1

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

On Board Diagnosis Logic

EBS00FS2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Power steering pressure sensor

DTC Confirmation Procedure

EBS00FS3

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-379, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0550 PSP SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00FS4

EC-PS/SEN-01



MBWA0089E

DTC P0550 PSP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	L	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned.	0.5 - 4.0V
			[Engine is running] ● Steering wheel is not being turned.	0.4 - 0.8V
57	B	Sensor ground (Power steering pressure sensor)	[Engine is running] ● Idle speed	Approximately 0V
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00FS5

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 57 and PSP sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PSP SENSOR

Refer to [EC-381, "Component Inspection"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace PSP sensor.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection
POWER STEERING PRESSURE SENSOR

EBS00FS6

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned fully.	Approximately 3.6V
Steering wheel is not being turned.	Approximately 0.6V



A
EC
C
D
E
F
G
H
I
J
K
L
M


DTC P0605 ECM

PF0:23710

Component Description

EBS00EP8

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



On Board Diagnosis Logic

EBS00EP9

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

FAIL-SAFE MODE

ECM enters fail-safe mode when malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EPA

Perform "PROCEDURE FOR MALFUNCTION A" first. If the DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-384, "Diagnostic Procedure"](#).



With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR MALFUNCTION B

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. If 1st trip DTC is detected, go to [EC-384, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. Repeat step 3 procedure, 32 times.
5. If 1st trip DTC is detected, go to [EC-384, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Diagnostic Procedure

1. INSPECTION START

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-382](#) .
5. Is the 1st trip DTC P0605 displayed again?

With GST

1. Turn ignition switch "ON".
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-382](#) .
5. Is the 1st trip DTC P0605 displayed again?

Yes or No

- Yes >> GO TO 2.
No >> **INSPECTION END**

2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-75, "NATS \(Nissan Anti-theft System\)"](#) .
3. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**


DTC P1065 ECM POWER SUPPLY

PFP:23710

Component Description

EBS00EPC

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



On Board Diagnosis Logic

EBS00EPD

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back up RAM system does not function properly.	<ul style="list-style-type: none"> ● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.] ● ECM

DTC Confirmation Procedure


EBS00EPE

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. Repeat steps 3 and 4 four times.
6. If 1st trip DTC is detected, go to [EC-387, "Diagnostic Procedure"](#)



Ⓢ WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1065 ECM POWER SUPPLY

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EPF

EC-ECM/PW-01



MBWA0094E

DTC P1065 ECM POWER SUPPLY

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EPG


1. CHECK ECM POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- Harness for open or short between ECM and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-385](#) .
5. Is the 1st trip DTC P1065 displayed again?

With GST

1. Turn ignition switch "ON".
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-385](#) .
5. Is the 1st trip DTC P1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

5. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-75, "NATS \(Nissan Anti-theft System\)"](#) .
3. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**


DTC P1102 MAF SENSOR

PFP:22680

Component Description

EBS00FS7

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FS8

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle	Approx. 1.0 - 1.7V
		2,500 rpm	Approx. 1.5 - 2.1V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	10% - 35%
		2,500 rpm	10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	1.0 - 4.0 g-m/s
		2,500 rpm	5.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00FS9

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1102 1102	Mass air flow sensor circuit range/performance problem	A voltage from the sensor is constantly approx.1.0V when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00FSA

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1102 MAF SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-392, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II" above.





DTC P1102 MAF SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00FSB

EC-MAFS-01



MBWA0045E

DTC P1102 MAF SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor power supply (Mass air flow sensor sensor)	[Ignition switch "ON"]	Approximately 5V
50	Y	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.5 - 2.1V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FSC

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 67 and MAF sensor terminal 3. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 50 and MAF sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-394, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace mass air flow sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
MASS AIR FLOW SENSOR**


EBS00FSD

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.5 - 2.1
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.



**Removal and Installation
MASS AIR FLOW SENSOR**

EBS00FSE

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

DTC P1111 IVT CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

DTC P1111 IVT CONTROL SOLENOID VALVE


PFP:23796

Description SYSTEM DESCRIPTION

EBS00GNV

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS)	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed signal*	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

COMPONENT DESCRIPTION


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EPI

Specification data are reference values.

DTC P1111 IVT CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle
		2,000 rpm
		0% - 2%
		Approx. 0% - 60%

On Board Diagnosis Logic

EBS00EPJ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1111 1111	Intake valve timing control solenoid valve circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (Solenoid valve circuit is open or shorted.) ● Intake valve timing control solenoid valve

DTC Confirmation Procedure

EBS00EPK

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON”.
2. Select “DATA MONITOR” mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If 1st trip DTC is detected, go to [EC-398, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
<small>SEF058Y</small>	

WITH GST

Following the procedure “WITH CONSULT-II” above.

DTC P1111 IVT CONTROL SOLENOID VALVE




[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EPL

EC-IVC-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0067E


DTC P1111 IVT CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	Approximately 9V★  PBIB0532E


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00EPM

1. CHECK IVT CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect intake valve timing control solenoid valve harness connector.
- Turn ignition switch "ON".




- Check voltage between intake valve timing control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTION PART

Check the following.

- Harness for open or short between intake valve timing control solenoid valve and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1111 IVT CONTROL SOLENOID VALVE

[QG (WITH EURO-OBD)]

3. CHECK IVT CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 62 and intake valve timing control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-399, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace intake valve timing control solenoid valve.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00EPN

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve terminals 1 and 2 under the following conditions.

Terminals	Resistance
1 and 2	Approximately 8Ω at 20°C (68°F)
1 or 2 and ground	$\infty\Omega$ (Continuity should not exist)



Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00EPO

Refer to [EM-49, "TIMING CHAIN"](#) .

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QG (WITH EURO-OBD)]

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PF16:16119

Component Description

EBS00EPP

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00EPO

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open. This self-diagnosis has the one trip detection logic.	

FAIL-SAFE MODE

When the malfunction A or B is detected in the two consecutive trips, the ECM enters in fail-safe mode and MI lights up.

When the malfunction C is detected even in the 1st trip, the ECM enters in fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.

DTC Confirmation Procedure

EBS00EPR

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A AND B" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A AND B

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. If 1st trip DTC is detected, go to [EC-401, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QG (WITH EURO-OBD)]

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
4. Shift selector lever to "N" or "P" position.
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to [EC-401, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.


Diagnostic Procedure

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if a foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 2.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PFP:16119

Description

EBS00EPT

NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-400](#) or [EC-409](#).

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00GB5

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is open or shorted.) ● Harness or connectors (Throttle control motor relay circuit is open or shorted.) ● Electric throttle control actuator ● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GB6

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-404, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST


Follow the procedure "WITH CONSULT-II" above.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]



Wiring Diagram

EC-ETC1-01

EBS00GB7



A
EC
C
D
E
F
G
H
I
J
K
L
M





MBWA0143E

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00GB8

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]


2. CHECK THROTTLE CONTROL MOTOR RELAY SIGNAL CIRCUIT

Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)


OK or NG

- OK >> GO TO 10.
- NG >> GO TO 3.



3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[QG (WITH EURO-OBD)]

5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.
NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-408, "Component Inspection"](#).

OK or NG

- OK >> GO TO 13.
NG >> Replace throttle control motor relay.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]

10. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.


Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.




11. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 12.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



12. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-408, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> GO TO 14.

13. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 14.

NG >> Repair or replace harness or connectors.

14. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITH EURO-OBD)]


EBS00EPY

Component Inspection THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.




THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-55, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EPZ

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PPF:16119

Component Description

EBS00EQ0

Power supply for the Throttle Control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

CONSULT-II Reference Value in Data Monitor Mode

EBS00EQ1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

On Board Diagnosis Logic

EBS00EQ2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detect the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is shorted.) ● Throttle control motor relay
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low. This self-diagnosis has the one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is open.) ● Throttle control motor relay

FAIL-SAFE MODE

When the DTC P1124 is detected in the two consecutive trips, the ECM enters fail-safe mode and the MI lights up.

When the DTC P1126 is detected even in the 1st trip, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EQ3

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR DTC P1124

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓑ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-412, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR DTC P1126

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-412, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST




Follow the procedure "With CONSULT-II" above.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

Wiring Diagram

EC-ETC2-01

EBS00EQ4



MBWA0144E

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

Diagnostic Procedure

EBS00EQ5

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

3. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-413, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace throttle control motor relay.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection THROTTLE CONTROL MOTOR RELAY


1. Apply 12V direct current between relay terminals 1 and 2.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITH EURO-OBD)]

2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.



DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITH EURO-OBD)]

DTC P1128 THROTTLE CONTROL MOTOR

PFP:16119

Component Description

EBS00EQ6

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00EQ7

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short both circuits between ECM and throttle control motor.	<ul style="list-style-type: none">● Harness or connectors (Throttle control motor circuit is shorted.)● Electric throttle control actuator (Throttle control motor)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EQ8

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-417, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITH EURO-OBD)]

EBS00EQ9

EC-ETC3-01

Wiring Diagram



MBWA0145E



DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	BR	Throttle control motor (Close)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	<p>0 - 14V★</p>  <p>PBIB0534E</p>
5	Y	Throttle control motor (Open)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	<p>0 - 14V★</p>  <p>PBIB0533E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00EQA

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITH EURO-OBD)]

2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-418, "Component Inspection"](#).

OK or NG

OK >> GO TO 4.

NG >> GO TO 5.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#).
3. Perform [EC-55, "Idle Air Volume Learning"](#).

>> INSPECTION END


Component Inspection THROTTLE CONTROL MOTOR

EBS00EQB

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-55, "Throttle Valve Closed Position Learning"](#).
5. Perform [EC-55, "Idle Air Volume Learning"](#).



DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITH EURO-OBD)]

Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EQC

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P1143 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FSF

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FSH


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FSH

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 1143	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00FSI

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P1143” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P1143	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0546E

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)


ENG SPEED	1,300 - 3,000 rpm
Vehicle speed	50 - 100 km/h (30 - 62 MPH)
B/FUEL SCHDL	2.4 - 5.5 msec
Selector lever	Suitable position

If “TESTING” is not displayed after 5 minutes, retry from step 2.

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0547E

- Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-422, "Diagnostic Procedure"](#).




Overall Function Check

EBS00FSJ

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

- Start engine and warm it up to normal operating temperature.
- Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
- Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
- If NG, go to [EC-422, "Diagnostic Procedure"](#).



MBIB0018E


Diagnostic Procedure

EBS00FSK

1. RETIGHTEN GROUND SCREWS

- Turn ignition switch "OFF".
- Loosen and retighten engine ground screws.

>> GO TO 2.




MBIB0095E

2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer to [EC-285](#).
No >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-161, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
NG >> Replace heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-424, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-201, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FSL

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5
HO2S1 MNTR (B1)	R	L	R	L	R

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 1

EBS00FSM

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .



DTC P1143, P1163 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FSN

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FSP


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FSP

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC P1143, P1163 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 1143 (Bank 1)	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks
P1163 1163 (Bank 2)			

DTC Confirmation Procedure

EBS00FSQ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P1143” of “HO2S1” or “HO2S1 (B2) P1163” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm (M/T models) or 3,200 rpm (A/T models) after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P1143	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0546E

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,600 rpm (A/T models) 1,300 - 3,000 rpm (M/T models)
Vehicle speed	50 - 100 km/h (30 - 62 MPH)
B/FUEL SCHDL	3.0 - 6.5 msec (A/T models) 2.4 - 5.5 msec (M/T models)
Selector lever	Suitable position

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h


PBIB0547E

If “TESTING” is not displayed after 5 minutes, retry from step 2.

DTC P1143, P1163 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-428, "Diagnostic Procedure"](#).




Overall Function Check

EBS00FSR

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to [EC-428, "Diagnostic Procedure"](#).




EBS00FSS

Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-291](#) .
No >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-169, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-430, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-207, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FST

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5
	HO2S1 MNTR (B1)	R	-L	-R	-L	-R
Bank 2	cycle	1	2	3	4	5
	HO2S1 MNTR (B2)	R	-L	-R	-L	-R

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 1

EBS00FSU

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).



DTC P1144 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FSV

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FSW


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FSX

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 1144	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:


- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P1144" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 3 minutes.


NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.




6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,300 - 3,000 rpm
Vehicle speed	50 - 100 km/h (30 - 62 MPH)
B/FUEL SCHDL	2.4 - 5.5 msec
Selector lever	Suitable position



If "TESTING" is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-434, "Diagnostic Procedure"](#).




Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.32V at least one time.
4. If NG, go to [EC-434, "Diagnostic Procedure"](#) .




EBS00FT0

Diagnostic Procedure**1. RETIGHTEN GROUND SCREWS**

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.

**2. RETIGHTEN HEATED OXYGEN SENSOR 1**

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-299](#) .
No >> GO TO 4.


4. CHECK HO2S1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check connectors for water.

Water should not exist.

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness or connectors.



5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-161, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
NG >> Replace heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-436, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Replace heated oxygen sensor 1.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-201, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FT1

④ With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
- Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
- Hold engine speed at 2,000 rpm under no load during the following steps.
- Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

- Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5	
HO2S1 MNTR (B1)	R	L	R	L	R	L
R means HO2S1 MNTR (B1) indicates RICH L means HO2S1 MNTR (B1) indicates LEAN						

SEF217YA




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

EBS00FT2

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).



DTC P1144, P1164 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FT3

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FT4


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FT5

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC P1144, P1164 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 1144 (Bank 1)	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors
P1164 1164 (Bank 2)			

DTC Confirmation Procedure

EBS00FT6

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P1144" or "HO2S1 (B2) P1164" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm (M/T models) or 3,200 rpm (A/T models) after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P1144	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANT TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0548E

6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,200 - 2,600 rpm (A/T models) 1,300 - 3,000 rpm (M/T models)
Vehicle speed	50 - 100 km/h (30 - 62 MPH)
B/FUEL SCHDL	3.0 - 6.5 msec (A/T models) 2.4 - 5.5 msec (M/T models)
Selector lever	Suitable position

HO2S1 (B1) P1144	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLANT TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h


PBIB0549E

If "TESTING" is not displayed after 5 minutes, retry from step 2.

DTC P1144, P1164 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-440, "Diagnostic Procedure"](#).




Overall Function Check

EBS00FT7

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.32V at least one time.
4. If NG, go to [EC-440, "Diagnostic Procedure"](#).




Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

EBS00FT8

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-305](#).
- No >> GO TO 4.


4. CHECK HO2S1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check connectors for water.

Water should not exist.

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness or connectors.



5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-169, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-442, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Replace malfunctioning heated oxygen sensor 1.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-207, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FT9

Ⓟ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN



SEF646Y

DTC P1144, P1164 HO2S1 (QG18DE)

[QG (WITH EURO-OBD)]

6. Check the following.

- “HO2S1 MNTR (B1)/(B2)” in “DATA MONITOR” mode changes from “RICH” to “LEAN” to “RICH” 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- “HO2S1 (B1)/(B2)” voltage goes above 0.6V at least once.
- “HO2S1 (B1)/(B2)” voltage goes below 0.3V at least once.
- “HO2S1 (B1)/(B2)” voltage never exceeds 1.0V.



CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



**Removal and Installation
HEATED OXYGEN SENSOR 1**

EBS00FTA

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

DTC P1146 HO2S2 (QG16DE)

PFP:226A0

Component Description


EBS00FTB

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FTC


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FTE

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 1146	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors

DTC Confirmation Procedure

EBS00FTF

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in “Procedure for COND1”

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1146" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1146</th> </tr> <tr> <td>COND1:</td> <td>OUT OF CONDITION</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1146		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1146</th> </tr> <tr> <td>COND1:</td> <td>TESTING</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1146		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1146</th> </tr> <tr> <td>COND1:</td> <td>COMPLETED</td> </tr> <tr> <td>COND2:</td> <td>INCOMPLETE</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1146																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0555E

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)

NOTE:


If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr> <th colspan="2">HO2S2 (B1) P1146</th> </tr> <tr> <td>COND1:</td> <td>COMPLETED</td> </tr> <tr> <td>COND2:</td> <td>COMPLETED</td> </tr> <tr> <td>COND3:</td> <td>INCOMPLETE</td> </tr> <tr> <th colspan="2">MONITOR</th> </tr> <tr> <td>ENG SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>B/FUEL SCHDL</td> <td>XXX msec</td> </tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1146														
COND1:	COMPLETED													
COND2:	COMPLETED													
COND3:	INCOMPLETE													
MONITOR														
ENG SPEED	XXX rpm													
B/FUEL SCHDL	XXX msec													

PBIB0556E

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-448. "Diagnostic Procedure"](#) .

**Overall Function Check**

EBS00FTG

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)


The voltage should be below 0.56V at least once during this procedure.

If the voltage can be confirmed in step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.56V at least once during this procedure.

6. If NG, go to [EC-448. "Diagnostic Procedure"](#) .




MBIB0020E

Wiring Diagram

EBS00FTH

EC-HO2S2-01



A

EC

C

D

E

F

G

H



I

J

K

L

M



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P1146 HO2S2 (QG16DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FTI

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-299](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-450, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00FTJ


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.
 “HO2S2 (B1)” should be below 0.56V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)


The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.56V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

EBS00FTK

DTC P1146, P1166 HO2S2 (QG18DE)

PFP:226A0

Component Description


EBS00FTL

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FTM


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FTO

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 1146 (Bank 1)	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors
P1166 1166 (Bank 2)			

DTC Confirmation Procedure

EBS00FTP

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- “COMPLETED” will appear on CONSULT-II screen when all tests “COND1”, “COND2” and “COND3” are completed.
- If “DTC confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in “Procedure for COND1”

DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1146" or "HO2S2 (B2) P1166" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0555E
HO2S2 (B1) P1146																																														
COND1:	OUT OF CONDITION																																													
COND2:	INCOMPLETE																																													
COND3:	INCOMPLETE																																													
MONITOR																																														
ENG SPEED	XXX rpm																																													
B/FUEL SCHDL	XXX msec																																													
HO2S2 (B1) P1146																																														
COND1:	TESTING																																													
COND2:	INCOMPLETE																																													
COND3:	INCOMPLETE																																													
MONITOR																																														
ENG SPEED	XXX rpm																																													
B/FUEL SCHDL	XXX msec																																													
HO2S2 (B1) P1146																																														
COND1:	COMPLETED																																													
COND2:	INCOMPLETE																																													
COND3:	INCOMPLETE																																													
MONITOR																																														
ENG SPEED	XXX rpm																																													
B/FUEL SCHDL	XXX msec																																													

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0556E
HO2S2 (B1) P1146																
COND1:	COMPLETED															
COND2:	COMPLETED															
COND3:	INCOMPLETE															
MONITOR																
ENG SPEED	XXX rpm															
B/FUEL SCHDL	XXX msec															

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-458, "Diagnostic Procedure"](#) .




Overall Function Check

EBS00FTQ

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 0.56V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.56V at least once during this procedure.
6. If NG, go to [EC-458, "Diagnostic Procedure"](#) .






DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Wiring Diagram BANK 1

EBS00FTR

EC-O2S2B1-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V

DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S2B2-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0058E

DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FTS

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-305](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	16	2	1
P1166	17	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1146	16	2	1
P1166	17	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-460, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00FTT

 With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

DTC P1146, P1166 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.56V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.
5. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.56V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#).

EBS00FTU

DTC P1147 HO2S2 (QG16DE)

PFP:226A0

Component Description


EBS00FTV

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FTW


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FTV

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 1147	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00FTZ

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in "Procedure for COND1"

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1147" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0557E
HO2S2 (B1) P1147																																													
COND1:	OUT OF CONDITION																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	TESTING																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	COMPLETED																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0558E
HO2S2 (B1) P1147															
COND1:	COMPLETED														
COND2:	COMPLETED														
COND3:	INCOMPLETE														
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-466. "Diagnostic Procedure"](#) .

**Overall Function Check**

EBS00FU0

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)


The voltage should be above 0.68V at least once during this procedure.

If the voltage can be confirmed in step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be above 0.68V at least once during this procedure.

6. If NG, go to [EC-466. "Diagnostic Procedure"](#) .




MBIB0020E

Wiring Diagram

EBS00FU1

EC-HO2S2-01



A

EC

C

D

E

F

G

H



I

J

K

L

M



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P1147 HO2S2 (QG16DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FU2

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer to [EC-285](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-468, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00FU3


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.56V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.


5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.56V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation

HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

EBS00FU4

DTC P1147, P1167 HO2S2 (QG18DE)

PFP:226A0

Component Description


EBS00FU5

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FU6


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00FU8

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 1147 (Bank 1)	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks
P1167 1167 (Bank 2)			

DTC Confirmation Procedure

EBS00FU9

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in "Procedure for COND1"

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1147" or "HO2S2 (B2) P1167" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0557E
HO2S2 (B1) P1147																																													
COND1:	OUT OF CONDITION																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	TESTING																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	COMPLETED																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed with "OD" OFF (A/T models only) from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0558E
HO2S2 (B1) P1147															
COND1:	COMPLETED														
COND2:	COMPLETED														
COND3:	INCOMPLETE														
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-476, "Diagnostic Procedure"](#) .




Overall Function Check

EBS00FUA

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage can be confirmed in step 4, step 5 is not necessary.
5. Keep vehicle idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be above 0.68V at least once during this procedure.
6. If NG, go to [EC-476, "Diagnostic Procedure"](#) .






DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Wiring Diagram BANK 1

EBS00FUB

EC-O2S2B1-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0056E

DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V

DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

BANK 2

EC-O2S2B2-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0058E

DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FUC

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 or P0174 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171, P0174. Refer to [EC-291](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1147	16	2	1
P1167	17	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P1147	16	2	1
P1167	17	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-478, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00FUD

 With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

DTC P1147, P1167 HO2S2 (QG18DE)

[QG (WITH EURO-OBD)]

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.56V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.
5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.56V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#).

EBS00FUE

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

DTC P1217 ENGINE OVER TEMPERATURE

PFP:00000

System Description

EBS00EQD

NOTE:

If DTC P1217 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-150, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

COOLING FAN CONTROL

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* ¹	Cooling fan control	Cooling fan relay(s)
Battery	Battery voltage* ¹		
Vehicle speed signal	Vehicle speed* ²		
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal* ²		
Refrigerant pressure sensor	Refrigerant pressure		


*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: These signals are sent to the ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 2-step control [ON/OFF].

The ECM sends a cooling fan control signal to the smart entrance control unit through CAN communication line, and the smart entrance control unit controls cooling fan relays.

OPERATION



CONSULT-II Reference Value in Data Monitor Mode

EBS00EQE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine Air conditioner switch: OFF	OFF
	● Engine: After warming up, idle the engine Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	● Engine: After warming up, idle the engine Engine coolant temperature is 99°C (210°F) or less	OFF
	● Air conditioner switch: OFF Engine coolant temperature is 100°C (212°F) or more	ON

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

On Board Diagnosis Logic

EBS00EQF

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Harness or connectors (The CAN communication line is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to EC-488, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [CO-8](#), "[Changing Engine Coolant](#)". Also, replace the engine oil. Refer to [LU-7](#), "[Changing Engine Oil](#)".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-18](#), "[Engine Coolant Mixture Ratio](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

EBS00EQG

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-484](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-484](#), "[Diagnostic Procedure](#)".
3. Turn ignition switch "ON".



DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]



4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-484, "Diagnostic Procedure"](#) .

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E

WITH GST

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-484, "Diagnostic Procedure"](#) .
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-484, "Diagnostic Procedure"](#) .
3. Start engine.
Be careful not to overheat engine.
4. Turn air conditioner switch "ON".
5. Turn blower fan switch "ON".
6. Make sure that cooling fans operate.
If NG, go to [EC-484, "Diagnostic Procedure"](#) .




DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

Wiring Diagram


EBS00EQH

EC-COOL/F-01




REFER TO PG-POWER.

- : DATA LINE
- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- : LHD MODELS
- : RHD MODELS
- *1 5:
- 11:



REFER TO THE FOLLOWING.
(E106) - FUSE BLOCK JUNCTION BOX (J/B)



MBWA0068E

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

EBS00EQI

Diagnostic Procedure

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK COOLING FAN OPERATION

With CONSULT-II

1. Start engine and let it idle.
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II and touch "ON" on the CONSULT-II screen.
3. Make sure that cooling fans-1 and -2 operate.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-486. "PROCEDURE A"](#) .)

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E


3. CHECK COOLING FAN OPERATION

Without CONSULT-II

1. Start engine and let it idle.
2. Turn air conditioner switch "ON".
3. Turn blower fan switch "ON".
4. Make sure that cooling fans-1 and -2 operate.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-486. "PROCEDURE A"](#) .)



DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

4. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 157 kPa (1.6 kg/cm² , 23 psi)

CAUTION:

Higher than the specified pressure may cause radiator damage. Pressure should not drop.


OK or NG

OK >> GO TO 5.

NG >> Check the following for leak

- Hose
- Radiator
- Water pump

Refer to [CO-18, "WATER PUMP"](#).



5. CHECK RADIATOR CAP


Apply pressure to cap with a tester.

**Radiator cap relief pressure: 59 - 98 kPa
(0.6 - 1.0 kg/cm² , 9 - 14 psi)**

OK or NG

OK >> GO TO 6.

NG >> Replace radiator cap.



6. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures.

It should seat tightly.

2. Check valve opening temperature and valve lift.

Valve opening temperature: 82°C (180°F) [standard]

**Valve lift: More than 8 mm/95°C
(0.31 in/203°F)**


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-20, "THERMOSTAT AND THERMOSTAT HOUSING"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace thermostat



7. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-198, "Component Inspection"](#).

OK or NG

OK >> GO TO 8.

NG >> Replace engine coolant temperature sensor.

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

8. CHECK MAIN 12 CAUSES


If the cause cannot be isolated, go to [EC-488, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END

PROCEDURE A

1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-1 terminals 1, 3, 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 30A fusible links
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

3. CHECK COOLING FAN MOTORS CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Check harness continuity between cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1, cooling fan motor-1 terminal 2 and body ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.
5. Check harness continuity between cooling fan relay-1 terminal 7 and cooling fan motor-2 terminal 1, cooling fan motor-2 terminal 2 and body ground.
Refer to Wiring Diagram.


Continuity should exist.

6. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit.
2. Check harness continuity between smart entrance control unit terminal 33 and cooling fan relay-1 terminal 2.
Refer to Wiring Diagram.


Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between smart entrance control unit and cooling fan relay-1

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK COOLING FAN RELAY-1

Refer to [EC-489, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan relay.

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

7. CHECK COOLING FAN MOTORS

Refer to [EC-489, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace cooling fan motors.

8. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [EC-489, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace smart entrance control unit.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Main 12 Causes of Overheating

EBS00EQJ

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-18, "Engine Coolant Mixture Ratio" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-20, "Changing Engine Coolant" .
	4	● Radiator cap	● Pressure tester	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See MA-22, "CHECKING RADIATOR CAP" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See MA-23, "CHECKING COOLING SYSTEM FOR LEAKS" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-20, "THERMOSTAT AND THERMOSTAT HOUSING" , and CO-11, "RADIATOR" .
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 (EC-480) .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-20, "Changing Engine Coolant" .
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-8, "LEVEL CHECK" .

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITH EURO-OBD)]

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-57, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-57, "CYLINDER HEAD" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to [CO-5, "OVERHEATING CAUSE ANALYSIS"](#) .


Component Inspection COOLING FAN RELAY-1

EBS00EQK

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace cooling fan relay.



PBIB0077E


COOLING FAN MOTORS-1 AND -2

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(+)	(-)
Cooling fan motor	1	2

Cooling fan motor should operate.

3. If NG, replace cooling fan motor.



MBIB0109E

DTC P1223, P1224 TP SENSOR


PFP:16119

Component Description

EBS00EQL

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EQM

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00EQN

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1223 1223	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 2)
P1224 1224	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EQO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1223, P1224 TP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-493, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1223, P1224 TP SENSOR

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00EQP

EC-TPS2-01



MBWA0137E

DTC P1223, P1224 TP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00EQQ

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-495, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00EQR

1. Reconnect all harness connectors disconnected.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-55, "Idle Air Volume Learning"](#) .



MBIB0022E

Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EQS

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1225 TP SENSOR


PFP:16119

Component Description

EBS00EQT

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00EQU

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00EVV

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. If 1st trip DTC is detected, go to [EC-497, "Diagnostic Procedure"](#)

The screenshot shows the CONSULT-II interface. At the top, it says 'DATA MONITOR'. Below that, there are two columns: 'MONITOR' and 'NO DTC'. Under 'MONITOR', it displays 'ENG SPEED' and 'XXX rpm'. The 'NO DTC' column is empty. The bottom right corner of the screen shows 'SEF058Y'.

WITH GST

Follow the procedure "With CONSULT-II" above.


Diagnostic Procedure**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1226 TP SENSOR


PFP:16119

Component Description

EBS00EQY

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00EQZ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance problem	Closed throttle position learning is not performed successfully, repeatedly.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00ERO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. Repeat steps 3 and 4, 32 times.
6. If 1st trip DTC is detected, go to [EC-499, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

EBS00ER1


1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00ER2

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1227, P1228 APP SENSOR

PFP:18002


Component Description

EBS00ER3

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00ER4

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.41 - 0.71V
		Accelerator pedal: Fully depressed	More than 4.2V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00ER5

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1227 1227	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P1228 1228	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00ER6

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1227, P1228 APP SENSOR

[QG (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-503, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P1227, P1228 APP SENSOR





[QG (WITH EURO-OBD)]

EBS00ER7

Wiring Diagram

EC-APPS2-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



DTC P1227, P1228 APP SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00ER8

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 83 and APP sensor terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1227, P1228 APP SENSOR

[QG (WITH EURO-OBD)]

6. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-505, "Component Inspection"](#).

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#).
3. Perform [EC-55, "Throttle Valve Closed Position Learning"](#).
4. Perform [EC-55, "Idle Air Volume Learning"](#).

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00ER9

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P1227, P1228 APP SENSOR

[QG (WITH EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-55, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-55, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00ERA

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P1229 SENSOR POWER SUPPLY

[QG (WITH EURO-OBD)]

DTC P1229 SENSOR POWER SUPPLY

PFP:16119

On Board Diagnosis Logic

EBS00ERB

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none">● Harness or connectors (The TP sensor 1 and 2 circuit is shorted.)● Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00ERC

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-509, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1229 SENSOR POWER SUPPLY

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ERD

EC-SEN/PW-01



DTC P1229 SENSOR POWER SUPPLY

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00ERE

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



DTC P1229 SENSOR POWER SUPPLY

[QG (WITH EURO-OBD)]

3. CHECK SENSOR POWER SUPPLY CIRCUITS FOR SHORT

Check the following.

- Harness for short to power and short to ground between ECM terminal 47 and electric throttle control actuator terminal 1.
- ECM pin terminal.

OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR

Refer to [EC-317, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-55, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-55, "Idle Air Volume Learning"](#) .

>> INSPECTION END

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1706 PNP SWITCH

PFP:32006

Component Description

EBS00ERF

When the shift lever position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

EBS00ERG

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	ON
	Shift lever: Except above	OFF

On Board Diagnosis Logic

EBS00ERH

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706 1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> ● Harness or connectors (PNP switch circuit is open or shorted.) ● Park/neutral position (PNP) switch

DTC Confirmation Procedure

EBS00ERI

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
"N" and "P" position	ON
Except the above position	OFF

If NG, go to [EC-514, "Diagnostic Procedure"](#) .
If OK, go to following step.

3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,200 - 6,000 rpm (A/T models) 1,300 - 6,000 rpm (M/T models)
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	More than 3.0 msec (A/T models) More than 2.7 msec (M/T models)
VHCL SPEED SE	More than 46 km/h (30 MPH)
Selector lever	Suitable position

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

6. If 1st trip DTC is detected, go to [EC-514, "Diagnostic Procedure"](#)

Overall Function Check


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Turn ignition switch "ON".
2. Check voltage between ECM terminal 102 (PNP switch signal) and body ground under the following conditions.

Condition (Gear position)	Voltage V (Known-good data)
"P" (A/T models only) and "N" position	Approximately 0
Except the above position	A/T models: Battery voltage M/T models: Approximately 5

3. If NG, go to [EC-514, "Diagnostic Procedure"](#) .






DTC P1706 PNP SWITCH

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ERK

EC-PNP/SW-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

DTC P1706 PNP SWITCH

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	P (A/T) G/OR (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none">Shift lever position is "P" or "N" (A/T models), "Neutral" (M/T models).	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none">Except the above gear position	A/T models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V

Diagnostic Procedure

EBS00ERL

1. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

- Turn ignition switch "OFF".
- Disconnect PNP switch harness connector.
- Check harness continuity between PNP switch terminal 2 and body ground.
Refer to Wiring Diagram.


Continuity should exist.

- Also check harness for short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to power in harness or connectors.



2. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

- Disconnect ECM harness connector.
- Check harness continuity between ECM terminal 102 and PNP switch terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

- Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK PNP SWITCH

Refer to [AT-110, "DTC P0705 PARK/NEUTRAL POSITION \(PNP\) SWITCH"](#) (A/T models) or [MT-14, "POSITION SWITCH"](#), [MT-62, "POSITION SWITCH"](#) (M/T models).

OK or NG

OK >> GO TO 4.

NG >> Replace PNP switch.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

DTC P1805 BRAKE SWITCH

PFP:25320

Description

EBS00ERM

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

CONSULT-II Reference Value in Data Monitor Mode

EBS00ERN

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released OFF
		Brake pedal: Slightly depressed ON

On Board Diagnosis Logic

EBS00ERO

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for an extremely long time while the vehicle is driving.	<ul style="list-style-type: none"> ● Harness or connectors (Stop lamp switch circuit is open or shorted.) ● Stop lamp switch

DTC Confirmation Procedure

EBS00ERP

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to [EC-517, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P1805 BRAKE SWITCH

[QG (WITH EURO-OBD)]

EBS00ERG

Wiring Diagram

EC-BRK/SW-01



REFER TO THE FOLLOWING.

(M2) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0091E

DTC P1805 BRAKE SWITCH

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00ERR

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch "OFF".
2. Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Depressed	Illuminated

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch harness connector.




2. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Fuse block (J/B) connector M2
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect stop lamp switch harness connector.
4. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to [EC-519, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Replace stop lamp switch.


7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection STOP LAMP SWITCH


1. Disconnect stop lamp switch harness connector.



2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.

If NG, adjust brake pedal installation, refer to [BR-6, "BRAKE PEDAL"](#), and perform step 2 again.



A
EC
C
D
E
F
G
H
I
J
K
L
M

IGNITION SIGNAL


PFP:22448

Component Description

EBS00ERT

IGNITION COIL & POWER TRANSISTOR

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.



IGNITION SIGNAL




[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ERU

EC-IGNSYS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0087E

IGNITION SIGNAL

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● More than a few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

IGNITION SIGNAL


[QG (WITH EURO-OBD)]

EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



1 2 3 (F26), (F28), (F29), (F30)
 GY GY GY GY





IGNITION SIGNAL

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
60 61 79 80	L/R BR GY/R PU	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 0.1V★</p>  <p>PBIB0521E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	<p>0 - 0.2V★</p>  <p>PBIB0522E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00ERV

1. CHECK ENGINE START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 4.

2. CHECK OVERALL FUNCTION

④ **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.

2. Make sure that each circuit produces a momentary engine speed drop.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 10.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


3. CHECK OVERALL FUNCTION

⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 79, 80 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.



PBIB0521E



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 10.


4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> Go to [EC-144, "POWER SUPPLY CIRCUIT FOR ECM"](#)




5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Turn ignition switch "ON".
4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 6.



6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.
3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



7. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV


Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair or replace harness or connectors.

9. CHECK ECM RELAY

Refer to [EC-528, "Component Inspection"](#).

OK or NG

OK >> GO TO 17.

NG >> Replace ECM relay.

10. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check harness continuity between condenser terminal 2 and ground.
Refer to Wiring diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to power in harness or connector.

11. CHECK CONDENSER

Refer to [EC-528, "Component Inspection"](#) .


OK or NG

OK >> GO TO 12.

NG >> Replace condenser.

12. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

1. Turn ignition switch "OFF".
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.
4. Turn ignition switch "ON".




5. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 14.

NG >> GO TO 13.



13. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ignition coil and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

14. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ignition coil terminal 2 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 15.

NG >> Repair open circuit or short to power in harness or connectors.

15. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 79, 80 and ignition coil terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to [EC-528, "Component Inspection"](#) .

OK or NG

OK >> GO TO 17.

NG >> Replace ignition coil with power transistor.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> **INSPECTION END**

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



EBS00ERW

PBIB0077E

CONDENSER


1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.

IGNITION SIGNAL

[QG (WITH EURO-OBD)]

3. Check resistance between condenser terminals 1 and 2.


Resistance: Above 1 MΩ at 25°C (77°F)



IGNITION COIL WITH POWER TRANSISTOR

1. Turn ignition switch "OFF".
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

Terminal No.	Resistance Ω [at 25°C (77°F)]
3 and 1	Except 0 or ∞
3 and 2	Except 0
1 and 2	



EBS00ERX

Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-29, "IGNITION COIL"](#) .


INJECTOR CIRCUIT

PFP:16600

Component Description

EBS00E55

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E56

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	1.5 - 3.0 msec
		2,000 rpm	1.2 - 3.0 msec
INJ PULSE-B1 INJ PULSE-B2*	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.0 - 3.5 msec
		2,000 rpm	1.5 - 3.5 msec

*: This item is displayed with QG18DE engine models.





INJECTOR CIRCUIT

[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ES7

EC-INJECT-01



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0086E



INJECTOR CIRCUIT

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0530E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00ES8

1. INSPECTION START

Turn ignition switch to "START".

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

④ With CONSULT-II


1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

⊗ Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.




OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 3.

3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect injector harness connector.
3. Turn ignition switch "ON".




4. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between injector terminal 2 and ECM terminals 22, 23, 41, 42. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK INJECTOR

Refer to [EC-535, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
 NG >> Replace injector.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INJECTOR

EBS00ES9

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: 13.5 - 17.5Ω [at 20°C (68°F)]



EBS00ESA

Removal and Installation INJECTOR

Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .

FUEL PUMP CIRCUIT

[QG (WITH EURO-OBD)]

FUEL PUMP CIRCUIT

PFP:17042

Description SYSTEM DESCRIPTION

EBS00ESE

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		


*: The ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a engine speed signal from the crankshaft position sensor (POS) and camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.



CONSULT-II Reference Value in Data Monitor Mode

EBS00ESF

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> For 1 seconds after turning ignition switch ON Engine running or cranking 	ON
	<ul style="list-style-type: none"> Except above conditions 	OFF


FUEL PUMP CIRCUIT

[QG (WITH EURO-OBD)]


EBS00ESG

Wiring Diagram

EC-F/PUMP-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ◊ : LHD MODELS
- ◊ : RHD MODELS
- ◊ : WAGON
- *1 20 : ◊
- 23 : ◊



REFER TO THE FOLLOWING.

(B1) - FUSE BLOCK-JUNCTION BOX (J/B)

FUEL PUMP CIRCUIT

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 seconds after turning ignition switch "ON"	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] ● More than 1 seconds after turning ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00ESH

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with two fingers.
Fuel pressure pulsation should be felt on the fuel hose for 1 second after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between fuel pump relay terminals 1, 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector B1
- 10A fuse
- 15A fuse
- Harness for open or short between fuel pump relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Check harness continuity between fuel pump relay terminal 3 and fuel level sensor unit and fuel pump terminal 5, fuel level sensor unit and fuel pump terminal 3 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B37, D83
- Harness for open or short between fuel level sensor unit and fuel pump and fuel pump relay
- Harness for open or short between fuel level sensor unit and fuel pump and body ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 113 and fuel pump relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors B5, M23 (LHD models)
- Harness connectors B42, M95 (RHD models)
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

Refer to [EC-540, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace fuel pump relay.

9. CHECK FUEL PUMP

Refer to [EC-540, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace fuel pump.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection FUEL PUMP RELAY

EBS00ES1

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



FUEL PUMP

1. Disconnect fuel level sensor unit and fuel pump harness connector.
2. Check resistance between fuel level sensor unit and fuel pump terminals 3 and 5.

Resistance: Approximately 1.0Ω [at 25°C (77°F)]



Removal and Installation

FUEL PUMP

EBS00ESJ

Refer to [DI-32, "FUEL LEVEL SENSOR UNIT CHECK"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

REFRIGERANT PRESSURE SENSOR

[QG (WITH EURO-OBD)]



REFRIGERANT PRESSURE SENSOR

PFP:92136

Component Description

EBS00ESQ

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



REFRIGERANT PRESSURE SENSOR




[QG (WITH EURO-OBD)]

Wiring Diagram

EBS00ESR

EC-RP/SEN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0090E

REFRIGERANT PRESSURE SENSOR

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	R	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
57	B	Sensor ground (Refrigerant pressure sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
69	W (LHD) B (RHD)	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON". (Compressor operates.)	1.0 - 4.0V

Diagnostic Procedure

EBS00ESS


1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch "ON".
3. Check voltage between ECM terminal 69 and ground with CONSULT-II or tester.

Voltage: 1.0 - 4.0V

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.




REFRIGERANT PRESSURE SENSOR

[QG (WITH EURO-OBD)]

2. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn A/C switch and blower switch "OFF".
2. Stop engine.
3. Disconnect refrigerant pressure sensor harness connector.
4. Turn ignition switch "ON".




5. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 57 and refrigerant pressure sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

REFRIGERANT PRESSURE SENSOR

[QG (WITH EURO-OBD)]

6. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 69 and refrigerant pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.
- NG >> Repair or replace.

Removal and Installation

REFRIGERANT PRESSURE SENSOR

Refer to [ATC-127, "REFRIGERANT LINES"](#) .

EBS00EST

ELECTRICAL LOAD SIGNAL

[QG (WITH EURO-OBD)]

ELECTRICAL LOAD SIGNAL

PFP:25350

Description

EBS00ESU

The electrical load signals except headlamp switch signal are transferred through the CAN communication line.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H63

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF

A
EC
C
D
E
F
G
H
I
J
K
L
M

ELECTRICAL LOAD SIGNAL




[QG (WITH EURO-OBD)]

EBS00H64

EC-LOAD-01

Wiring Diagram

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- CH** : CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM
- CD** : CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM
- XN** : XENON TYPE HEADLAMP



MBWA0147E

ELECTRICAL LOAD SIGNAL

[QG (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] ● Lighting switch is "2ND" position	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Lighting switch is "OFF"	Approximately 0V

Diagnostic Procedure

EBS00H65

1. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

Ⓟ With CONSULT-II

Ⓢ With GST

- Turn ignition switch "ON".
- Connect CONSULT-II or GST and select "DATA MONITOR" mode.
- Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch "ON"	ON
Rear window defogger switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> GO TO 4.

2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

Ⓟ With CONSULT-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch "ON" at 2nd position	ON
Lighting switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

3. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II


⊗ Without CONSULT-II

Check voltage between ECM terminal 84 and ground under the following conditions.

Condition	Voltage
Lighting switch "ON" at 2nd position	Battery voltage
Lighting switch "OFF"	Approximately 0V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.



4. CHECK REAR WINDOW DEFOGGER SYSTEM

Refer to [GW-40, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

5. CHECK HEADLAMP FUNCTION

1. Turn lighting switch "ON" at 2nd position.
2. Check that headlamps are illuminated.

OK or NG

- OK >> GO TO 6.
- NG >> Refer to [LT-5, "HEADLAMP -CONVENTIONAL TYPE-"](#) , [LT-10, "HEADLAMP - XENON TYPE -"](#) , [LT-18, "HEADLAMP \(WITH DAYTIME\) - CONVENTIONAL TYPE -"](#) or [LT-25, "HEADLAMP \(WITH DAYTIME\) - XENON TYPE -"](#) .

6. CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect lighting switch harness connector.
4. Check harness continuity between ECM terminal 84 and lighting switch terminal 10.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect daytime light relay.
4. Check harness continuity between ECM terminal 84 and daytime light relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

XENON TYPE HEADLAMP

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect headlamp LH relay.
4. Check harness continuity between ECM terminal 84 and headlamp LH relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- harness for open and short between ECM and lighting switch
- harness for open and short between ECM and daytime light relay
- harness for open and short between ECM and headlamp LH relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT




Refer to [EC-143, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**




MI & DATA LINK CONNECTORS

Wiring Diagram—LHD Models

EBS00ESW



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK
 - JUNCTION BOX (J/B)





MI & DATA LINK CONNECTORS




[QG (WITH EURO-OBD)]

Wiring Diagram—RHD Models

EBS00H9S



REFER TO THE FOLLOWING.
 (M1) (M2) - FUSE BLOCK
 - JUNCTION BOX (J/B)




EVAPORATIVE EMISSION SYSTEM

PFP:14950

Description SYSTEM DESCRIPTION

EBS00ESX




The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM

[QG (WITH EURO-OBD)]

EVAPORATIVE EMISSION LINE DRAWING



A

EC

C

D

E

F

G

H

I

J

K


L

M

Component Inspection EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** . Orally blow air through port **A** .
Check that air flows freely through port **C** .
2. Block port **A** . Orally blow air through port **B** .
Check that air flows freely through port **C** .




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure: 15.3 - 20.0 kPa (0.153 - 0.200 bar,
0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.3 kPa (-0.060 to -0.033 bar,
-0.061 to -0.034 kg/cm² , -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.



EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-374, "Component Inspection"](#) .

POSITIVE CRANKCASE VENTILATION


[QG (WITH EURO-OBD)]

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description SYSTEM DESCRIPTION


EBS00ESZ



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.



Component Inspection PCV (POSITIVE CRANKCASE VENTILATION) VALVE

EBS00ET0

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.




POSITIVE CRANKCASE VENTILATION

[QG (WITH EURO-OBD)]

PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



SERVICE DATA AND SPECIFICATIONS (SDS) [QG (WITH EURO-OBD)]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure

EBS00ET1

Fuel pressure at idle	Approximately 350 kPa (3.7kg/cm ² , 51psi)
-----------------------	---

Idle Speed and Ignition Timing

EBS00ET2

Target idle speed	No-load*1 (in "P" or "N" position)	A/T: 800±50 rpm M/T: 700±50 rpm
Air conditioner: ON	In "P" or "N" position	825 rpm or more
Ignition timing	In "P" or "N" position	A/T: 10°±5° BTDC M/T: 8°±5° BTDC

*1: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Calculated Load Value

EBS00ET3

	Calculated load value % (Using CONSULT-II or GST)
At idle	10 - 35
At 2,500 rpm	10 - 35

Mass Air Flow Sensor

EBS00ET4

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	1.0 - 1.7*V
Mass air flow (Using CONSULT-II or GST)	1.0 - 4.0 g·m/sec at idle* 5.0 - 10.0 g·m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Intake Air Temperature Sensor

EBS00ET5

Temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1
80 (176)	0.31 - 0.37

Engine Coolant Temperature Sensor

EBS00ET6

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

EBS00ET7

Resistance [at 20°C (68°F)]	8 - 10Ω
-----------------------------	---------

Heated Oxygen sensor 2 Heater

EBS00ET8

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (POS)

EBS00ET9

Refer to [EC-353, "Component Inspection"](#) .

Camshaft Position Sensor (PHASE)

EBS00ETA

Refer to [EC-359, "Component Inspection"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)
[QG (WITH EURO-OBD)]

Throttle Control Motor

EBS00ETB

Resistance [at 25°C (77°F)]

Approximately 1 - 15Ω

Injector

EBS00ETC

Resistance [at 20°C (68°F)]

13.5 - 17.5Ω

Fuel Pump

EBS00ETD

Resistance [at 25°C (77°F)]

Approximately 1.0Ω

INDEX FOR DTC

PFP:00024

Alphabetical Index

EBS00ETE

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#) .

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-663, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

QG16DE ENGINE MODELS

Items (CONSULT-II screen terms)	DTC ^{*1}		Reference page
	CONSULT-II ^{*2}	ECM ^{*3}	
APP SEN 1/CIRC ^{*5}	P0227	0227	EC-742
APP SEN 1/CIRC ^{*5}	P0228	0228	EC-742
APP SEN 2/CIRC ^{*5}	P1227	1227	EC-821
APP SEN 2/CIRC ^{*5}	P1228	1228	EC-821
APP SENSOR ^{*5}	P0226	0226	EC-735
BRAKE SW/CIRCUIT	P1805	1805	EC-832
CAN COMM CIRCUIT ^{*6}	U1001	1001	EC-663
CKP SEN/CIRCUIT	P0335	0335	EC-753
CMP SEN/CIRC-B1	P0340	0340	EC-760
CTP LEARNING	P1225	1225	EC-817
CTP LEARNING	P1226	1226	EC-819
ECM	P0605	0605	EC-767
ECM BACK UP/CIRC	P1065	1065	EC-770
ECT SEN/CIRCUIT ^{*5}	P0117	0117	EC-672
ECT SEN/CIRCUIT ^{*5}	P0118	0118	EC-672
ENG OVER TEMP	P1217	1217	EC-801
ETC ACTR ^{*5}	P1121	1121	EC-780
ETC FUNCTION/CIRC ^{*5}	P1122	1122	EC-783
ETC MOT ^{*5}	P1128	1128	EC-796
ETC MOT PWR ^{*5}	P1124	1124	EC-790
ETC MOT PWR ^{*5}	P1126	1126	EC-790
HO2S1 (B1)	P0132	0132	EC-677
HO2S1 (B1)	P0134	0134	EC-692
HO2S2 (B1)	P0138	0138	EC-707
KNOCK SEN/CIRC-B1	P0327	0327	EC-749
KNOCK SEN/CIRC-B1	P0328	0328	EC-749
MAF SEN/CIRCUIT ^{*5}	P0102	0102	EC-666
MAF SEN/CIRCUIT ^{*5}	P0103	0103	EC-666
MAF SENSOR ^{*5}	P1102	1102	EC-774
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-595
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing ^{*4}	EC-596

INDEX FOR DTC

[QG (WITHOUT EURO-OBD)]

Items (CONSULT-II screen terms)	DTC ^{*1}		Reference page
	CONSULT-II ^{*2}	ECM ^{*3}	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
SENSOR POWER/CIRC ^{*5}	P1229	1229	EC-828
TP SEN 1/CIRC ^{*5}	P0222	0222	EC-729
TP SEN 1/CIRC ^{*5}	P0223	0223	EC-729
TP SEN 2/CIRC ^{*5}	P1223	1223	EC-811
TP SEN 2/CIRC ^{*5}	P1224	1224	EC-811
TP SENSOR ^{*5}	P0221	0221	EC-723

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The trouble shooting for this DTC needs CONSULT-II.

QG18DE ENGINE MODELS

Items (CONSULT-II screen terms)	DTC ^{*1}		Reference page
	CONSULT-II ^{*2}	ECM ^{*3}	
APP SEN 1/CIRC ^{*5}	P0227	0227	EC-742
APP SEN 1/CIRC ^{*5}	P0228	0228	EC-742
APP SEN 2/CIRC ^{*5}	P1227	1227	EC-821
APP SEN 2/CIRC ^{*5}	P1228	1228	EC-821
APP SENSOR ^{*5}	P0226	0226	EC-735
BRAKE SW/CIRCUIT	P1805	1805	EC-832
CAN COMM CIRCUIT ^{*5}	U1000	1000	EC-663
CAN COMM CIRCUIT ^{*6}	U1001	1001	EC-663
CKP SEN/CIRCUIT	P0335	0335	EC-753
CMP SEN/CIRC-B1	P0340	0340	EC-760
CTP LEARNING	P1225	1225	EC-817
CTP LEARNING	P1226	1226	EC-819
ECM	P0605	0605	EC-767
ECM BACK UP/CIRC	P1065	1065	EC-770
ECT SEN/CIRCUIT ^{*5}	P0117	0117	EC-672
ECT SEN/CIRCUIT ^{*5}	P0118	0118	EC-672
ENG OVER TEMP	P1217	1217	EC-801
ETC ACTR ^{*5}	P1121	1121	EC-780
ETC FUNCTION/CIRC ^{*5}	P1122	1122	EC-783
ETC MOT ^{*5}	P1128	1128	EC-796
ETC MOT PWR ^{*5}	P1124	1124	EC-790
ETC MOT PWR ^{*5}	P1126	1126	EC-790
HO2S1 (B1)	P0132	0132	EC-683

INDEX FOR DTC

[QG (WITHOUT EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II*2	ECM*3	
HO2S1 (B1)	P0134	0134	EC-698
HO2S1 (B2)	P0152	0152	EC-683
HO2S1 (B2)	P0154	0154	EC-698
HO2S2 (B1)	P0138	0138	EC-714
HO2S2 (B2)	P0158	0158	EC-714
KNOCK SEN/CIRC-B1	P0327	0327	EC-749
KNOCK SEN/CIRC-B1	P0328	0328	EC-749
MAF SEN/CIRCUIT*5	P0102	0102	EC-666
MAF SEN/CIRCUIT*5	P0103	0103	EC-666
MAF SENSOR*5	P1102	1102	EC-774
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-595
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	EC-596
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
SENSOR POWER/CIRC*5	P1229	1229	EC-828
TP SEN 1/CIRC*5	P0222	0222	EC-729
TP SEN 1/CIRC*5	P0223	0223	EC-729
TP SEN 2/CIRC*5	P1223	1223	EC-811
TP SEN 2/CIRC*5	P1224	1224	EC-811
TP SENSOR*5	P0221	0221	EC-723

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The trouble shooting for this DTC needs CONSULT-II.

NOTE:

Regarding P12 models with QG18DE engine, "B1" indicates bank 1, "B2" indicates bank 2.

DTC No. Index

EBS00ETF

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#).

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-663, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

QG16DE ENGINE MODELS

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-596
U1001	1001*6	CAN COMM CIRCUIT	EC-663

INDEX FOR DTC

[QG (WITHOUT EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—
P0102	0102	MAF SEN/CIRCUIT*5	EC-666
P0103	0103	MAF SEN/CIRCUIT*5	EC-666
P0117	0117	ECT SEN/CIRCUIT*5	EC-672
P0118	0118	ECT SEN/CIRCUIT*5	EC-672
P0132	0132	HO2S1 (B1)	EC-677
P0134	0134	HO2S1 (B1)	EC-692
P0138	0138	HO2S2 (B1)	EC-707
P0221	0221	TP SENSOR*5	EC-723
P0222	0222	TP SEN 1/CIRC*5	EC-729
P0223	0223	TP SEN 1/CIRC*5	EC-729
P0226	0226	APP SENSOR*5	EC-735
P0227	0227	APP SEN 1/CIRC*5	EC-742
P0228	0228	APP SEN 1/CIRC*5	EC-742
P0327	0327	KNOCK SEN/CIRC-B1	EC-749
P0328	0328	KNOCK SEN/CIRC-B1	EC-749
P0335	0335	CKP SEN/CIRCUIT	EC-753
P0340	0340	CMP SEN/CIRC-B1	EC-760
P0605	0605	ECM	EC-767
P1065	1065	ECM BACK UP/CIRC	EC-770
P1102	1102	MAF SENSOR*5	EC-774
P1121	1121	ETC ACTR*5	EC-780
P1122	1122	ETC FUNCTION/CIRC*5	EC-783
P1124	1124	ETC MOT PWR*5	EC-790
P1126	1126	ETC MOT PWR*5	EC-790
P1128	1128	ETC MOT*5	EC-796
P1217	1217	ENG OVER TEMP	EC-801
P1223	1223	TP SEN 2/CIRC*5	EC-811
P1224	1224	TP SEN 2/CIRC*5	EC-790
P1225	1225	CTP LEARNING	EC-817
P1226	1226	CTP LEARNING	EC-819
P1227	1227	APP SEN 2/CIRC*5	EC-821
P1228	1228	APP SEN 2/CIRC*5	EC-821
P1229	1229	SENSOR POWER/CIRC*5	EC-828
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-595
P1805	1805	BRAKE SW/CIRCUIT	EC-832

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

INDEX FOR DTC

[QG (WITHOUT EURO-OBD)]

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for this DTC needs CONSULT-II.

QG18DE ENGINE MODELS

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-596
U1000	1000*6	CAN COMM CIRCUIT	EC-663
U1001	1001*6	CAN COMM CIRCUIT	EC-663
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—
P0102	0102	MAF SEN/CIRCUIT*5	EC-666
P0103	0103	MAF SEN/CIRCUIT*5	EC-666
P0117	0117	ECT SEN/CIRCUIT*5	EC-672
P0118	0118	ECT SEN/CIRCUIT*5	EC-672
P0132	0132	HO2S1 (B1)	EC-683
P0134	0134	HO2S1 (B1)	EC-698
P0138	0138	HO2S2 (B1)	EC-714
P0152	0152	HO2S1 (B2)	EC-683
P0154	0154	HO2S1 (B2)	EC-698
P0158	0158	HO2S2 (B2)	EC-714
P0221	0221	TP SENSOR*	EC-723
P0222	0222	TP SEN 1/CIRC*5	EC-729
P0223	0223	TP SEN 1/CIRC*5	EC-729
P0226	0226	APP SENSOR*5	EC-735
P0227	0227	APP SEN 1/CIRC*5	EC-742
P0228	0228	APP SEN 1/CIRC*5	EC-742
P0327	0327	KNOCK SEN/CIRC-B1	EC-749
P0328	0328	KNOCK SEN/CIRC-B1	EC-749
P0335	0335	CKP SEN/CIRCUIT	EC-753
P0340	0340	CMP SEN/CIRC-B1	EC-760
P0605	0605	ECM	EC-767
P1065	1065	ECM BACK UP/CIRC	EC-770
P1102	1102	MAF SENSOR*5	EC-774
P1121	1121	ETC ACTR*5	EC-780
P1122	1122	ETC FUNCTION/CIRC*5	EC-783
P1124	1124	ETC MOT PWR	EC-811
P1126	1126	ETC MOT PWR*5	EC-790
P1128	1128	ETC MOT*5	EC-796
P1217	1217	ENG OVER TEMP	EC-801
P1223	1223	TP SEN 2/CIRC*5	EC-811

INDEX FOR DTC

[QG (WITHOUT EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
P1224	1224	TP SEN 2/CIRC*5	EC-811
P1225	1225	CTP LEARNING	EC-817
P1226	1226	CTP LEARNING	EC-819
P1227	1227	APP SEN 2/CIRC*5	EC-821
P1228	1228	APP SEN 2/CIRC*5	EC-821
P1229	1229	SENSOR POWER/CIRC*5	EC-828
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-595
P1805	1805	BRAKE SW/CIRCUIT	EC-832

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for this DTC needs CONSULT-II.

NOTE:

Regarding P12 models with QG18DE engine, "B1" indicates bank 1, "B2" indicates bank 2.

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EBS00ETG

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

On Board Diagnostic (OBD) System of Engine

EBS00ETH

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.


CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery ground cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-86. "HARNESSESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

Precaution

EBS00ETI


- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery ground cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




PRECAUTIONS

[QG (WITHOUT EURO-OBD)]

- Do not disassemble ECM.
- If battery cable is disconnected, the memory will return to the initial ECM values.
The ECM will now start to self-control at its initial values. Engine operation can vary slightly when the cable is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, fasten it securely with a lever as far as it will go as shown at right.




- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.

- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.




- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-622, "ECM Terminals and Reference Value"](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




PRECAUTIONS

[QG (WITHOUT EURO-OBD)]


- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.





PRECAUTIONS

[QG (WITHOUT EURO-OBD)]

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.
- Regarding P12 models with QG18DE engine, "B1" indicates bank 1 (cylinders number 1 and 4), "B2" indicates bank 2 (cylinders number 2 and 3).



Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)





EBS00ETJ

PREPARATION

PFP:00002



Special Service Tools

EBS00ETK

Tool number Tool name	Description	
KV10117100 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT379</p>	Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT636</p>	Loosening or tightening heated oxygen sensors a: 22 mm (0.87 in)
KV109E0010 Break-out box	 <p style="text-align: center;">S-NT825</p>	Measuring ECM signals with a circuit tester
KV109E0080 Y-cable adapter	 <p style="text-align: center;">S-NT826</p>	Measuring ECM signals with a circuit tester




Commercial Service Tools

EBS00ETL

Tool name	Description	
Quick connector release	 <p style="text-align: center;">PBIC0198E</p>	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)
Fuel filler cap adapter	 <p style="text-align: center;">S-NT653</p>	Checking fuel tank vacuum relief valve opening pressure

PREPARATION

[QG (WITHOUT EURO-OBD)]

Tool name	Description	
Socket wrench	 <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.26 in)</p> <p>S-NT705</p>	Removing and installing engine coolant temperature sensor
Oxygen sensor thread cleaner ie: (J-43897-18) (J-43897-12)	 <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> <p>AEM488</p>	Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor
Anti-seize lubricant ie: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p>S-NT779</p>	Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.

ENGINE CONTROL SYSTEM


[QG (WITHOUT EURO-OBD)]

ENGINE CONTROL SYSTEM

PF23710

System Diagram - QG16DE Engine Models

EBS00ETM



EC

C

D

E

F

G

H

I

J

K

L

M


MBIB0011E

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

System Diagram - QG18DE Engine Models


EBS00GBB



MBIB0012E

Vacuum Hose Drawing

EBS00ETN



NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

MBIB0013E

Refer to [EC-573. "System Diagram - QG16DE Engine Models"](#) or [EC-574. "System Diagram - QG18DE Engine Models"](#) for Vacuum Control System.

A
EC
C
D
E
F
G
H
I
J
K
L
M

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBDD)]

System Chart

EBS00ETO

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor (PHASE) ● Crankshaft position sensor (POS) ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Throttle position sensor ● Accelerator pedal position sensor ● Park/neutral position (PNP) switch ● Intake air temperature sensor ● Power steering pressure sensor ● Ignition switch ● Stop lamp switch ● Battery voltage ● Knock sensor ● Refrigerant pressure sensor ● Heated oxygen sensor 2^{*1} ● TCM (Transmission control module)^{*2} ● Air conditioner switch^{*2} ● Vehicle speed signal^{*2} ● Electrical load signal^{*2} 	Fuel injection & mixture ratio control	Fuel injectors
	Electronic ignition system	Power transistor
	Fuel pump control	Fuel pump relay
	On board diagnostic system	MI (On the instrument panel) ^{*3}
	Intake valve timing control	Intake valve timing control solenoid valve
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay ^{*3}
	Cooling fan control	Cooling fan relays ^{*3}

*1: This sensor is not used to control the engine system under normal conditions.

*2: The signals are sent to the ECM through CAN communication line.

*3: The output signals are sent from the ECM through CAN communication line.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

EBS00ETP

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed ^{*3} and piston position	Fuel injection & mixture ratio control	Fuel injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage ^{*3}		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2 ^{*1}	Density of oxygen in exhaust gas		
Vehicle speed signal ^{*2}	Vehicle speed		
Air conditioner switch ^{*2}	Air conditioner operation		

*1: Under normal conditions, this sensor is not for engine control operation.

*2: This signal is sent to the ECM through CAN communication line.

*3: The ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from the crankshaft position sensor (POS), camshaft position sensor (PHASE) and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from "N" to "D" (A/T models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about heated oxygen sensor 1, refer to [EC-692, "DTC P0134 HO2S1 \(QG16DE\)"](#) or [EC-698, "DTC P0134, P0154 HO2S1 \(QG18DE\)"](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture). This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from "N" to "D" (A/T models)
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

EBS00ETQ

Electronic Ignition (EI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2 and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage*2		
Vehicle speed signal*1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

*2: The ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION


The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown. The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.

e.g., N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration



The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.

Air Conditioning Cut Control INPUT/OUTPUT SIGNAL CHART

EBS00ETR

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch*1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage*2		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Vehicle speed signal*1	Vehicle speed		

*1: These signals are sent to the ECM through CAN communication line.

*2: The ECM determines the start signal status by the signals of engine speed and battery voltage.

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

Fuel Cut Control (at No Load and High Engine Speed)

EBS00ETS

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injectors
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Vehicle speed signal*1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

If the engine speed is above 3,950 rpm with no load (for example, in neutral and engine speed over 3,950 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", [EC-576](#)

CAN communication

EBS00ETT


SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

LHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

ENGINE CONTROL SYSTEM


[QG (WITHOUT EURO-OBD)]

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tire pressure signal					T	R

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R ^{*1}		T		
Heater fan switch signal	R ^{*1}				T
Air conditioner switch signal	R				T

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
MI signal	T				R
Glow lamp signal*2	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tire pressure signal				T	R


*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

LHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R


ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	


*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

RHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	


ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
A/C compressor signal	T				R	
Tyre pressure signal				T		R

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R ^{*1}			T	
Heater fan switch signal	R ^{*1}				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal ^{*2}	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	
Tyre pressure signal			T		R

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only


ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

RHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

A/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

ENGINE CONTROL SYSTEM

[QG (WITHOUT EURO-OBD)]

M/T Models

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

BASIC SERVICE PROCEDURE

[QG (WITHOUT EURO-OBID)]

BASIC SERVICE PROCEDURE

PFP:00018

Idle Speed and Ignition Timing Check IDLE SPEED

EBS00ETU

④ With CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm


SEF058Y

IGNITION TIMING

Any of following two methods may be used.


Method A

1. Slide the harness protector of ignition coil No. 1 to clear the wires.
2. Attach timing light to the wires as shown.
3. Check ignition timing.





Method B

1. Remove No. 1 ignition coil.



2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.





3. Check ignition timing.

Accelerator Pedal Released Position Learning
DESCRIPTION

EBS00ETW

“Accelerator Pedal Released Position Learning” is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON” and wait at least 2 seconds.
3. Turn ignition switch “OFF” wait at least 10 seconds.
4. Turn ignition switch “ON” and wait at least 2 seconds.
5. Turn ignition switch “OFF” wait at least 10 seconds.

Throttle Valve Closed Position Learning
DESCRIPTION

EBS00ETX

“Throttle Valve Closed Position Learning” is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON”.
3. Turn ignition switch “OFF” wait at least 10 seconds.
 Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

Idle Air Volume Learning
DESCRIPTION

EBS00ETY

“Idle Air Volume Learning” is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

PREPARATION

Before performing “Idle Air Volume Learning”, make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 95°C (158 - 203°F)
- PNP switch: ON
- Electric load switch: OFF
 (Air conditioner, headlamp, rear window defogger)
On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped

A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

BASIC SERVICE PROCEDURE


[QG (WITHOUT EURO-OBDD)]

- Transmission: Warmed-up
For A/T models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.
For A/T models without CONSULT-II and M/T models, drive vehicle for 10 minutes.


OPERATION PROCEDURE

④ With CONSULT-II

1. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.




6. Touch "START" and wait 20 seconds.



7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "INCMP" is displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 700±50 rpm A/T: 800±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 8±5° BTDC A/T: 10° BTDC (in "P" or "N" position)



⊗ Without CONSULT-II


NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
 2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .

BASIC SERVICE PROCEDURE

[QG (WITHOUT EURO-OBD)]

3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
7. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
9. Fully release the accelerator pedal within 3 seconds after the MI turned ON.
10. Start engine and let it idle.
11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 700±50 rpm A/T: 800±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 8±5° BTDC A/T: 10±5° BTDC (in "P" or "N" position)

13. If idle speed and ignition timing are not within the specification, the result will be incomplete. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.

DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:

1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the problem.
It is useful to perform [EC-652, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).
5. If any of the following conditions occur after the engine has started, eliminate the cause of the problem and perform "Idle air volume learning" all over again:
 - Engine stalls.
 - Erroneous idle.

Fuel Pressure Check FUEL PRESSURE RELEASE

EBS00ETZ

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

NOTE:


Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because P12 models do not have fuel return system.

BASIC SERVICE PROCEDURE

[QG (WITHOUT EURO-OBD)]


④ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".



⊗ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK


NOTE:

- When reconnecting fuel line, always use new clamps.
- Make sure that clamp screw does not contact adjacent parts.
- Use a torque driver to tighten clamps.
- Use Pressure Gauge to check fuel pressure.
- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.

1. Release fuel pressure to zero. Refer to [EC-591, "FUEL PRESSURE RELEASE"](#).
2. Install the fuel pressure gauge with the fuel pressure check adapter as shown in the figure.
3. Turn ignition switch "ON", and check for fuel leakage.
4. Start engine and check for fuel leakage.
5. Read the indication of fuel pressure gauge.

At idling: Approximately 350 kPa (3.7 kg/cm², 51 psi)

6. If result is unsatisfactory, go to next step.
7. Check the following.
 - Fuel hoses and fuel tubes for clogging
 - Fuel filter for clogging
 - Fuel pump
 - Fuel pressure regulator for cloggingIf OK, replace fuel pressure regulator.
If NG, repair or replace.



ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

EBS00EU0

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information

Diagnostic Trouble Code (DTC)

Freeze Frame data

1st Trip Diagnostic Trouble Code (1st Trip DTC)

1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data
CONSULT-II	×	×	×	×
ECM	×	×*1	—	—

*1: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-605](#).)

Two Trip Detection Logic

EBS00EU1

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. When the ECM enters fail-safe mode (Refer to [EC-605](#).), the DTC is stored in the ECM memory even in the 1st trip.

Emission-related Diagnostic Information DTC AND 1ST TRIP DTC

EBS00EU2

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For fail-safe items, the DTC is stored in the ECM memory even in the 1st trip.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in “Work Flow” procedure Step II, refer to [EC-601](#). Then perform “DTC Confirmation Procedure” or “Overall Function Check” to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

☑ With CONSULT-II

CONSULT-II displays the DTC in “SELF-DIAG RESULTS” mode. Examples: P0117, P0340, P1065, etc. (CONSULT-II also displays the malfunctioning component or system.)

☒ Without CONSULT-II

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0117, 0340 1065 etc.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, the Diagnostic Test Mode II does not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS	
	DTC RESULTS	TIME
	CKP SEN/CIRCUIT [P0335]	0
1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS	TIME
	CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II. For details, see [EC-639](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]

4. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)
 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

2. Turn CONSULT-II "ON" and touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
ACTIVE TEST
ECM PART NUMBER

3. Touch "SELF-DIAG RESULTS".

SELF DIAG RESULTS	
DTC RESULTS	TIME
MAF SEN/CIRCUIT [P0102]	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

PBIB0671E

⊗ How to Erase DTC (Without CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once.
 2. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
 3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-597, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).
- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
 - The following data are cleared when the ECM memory is erased.
 1. Diagnostic trouble codes
 2. 1st trip diagnostic trouble codes
 3. Freeze frame data
 4. 1st trip freeze frame data
 5. Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

NATS (Nissan Anti-theft System)

EBS00EU3

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-156, "NATS \(NISSAN ANTI-THEFT SYSTEM\)"](#).
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF515Y

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]


EBS00EU4

Malfunction Indicator (MI)

DESCRIPTION







The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MI does not light up, refer to [DI-95, "WARNING LAMPS"](#) , or see [EC-950, "MI & DATA LINK CONNECTORS"](#) .
2. When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.



ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up the MI in the 1st trip. <ul style="list-style-type: none"> ● Fail-safe mode
Mode II	Ignition switch in "ON" position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1, to be read.

MI Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode. Refer to [EC-597, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

How to switch the diagnostic test (function) modes, and details of the above functions are described later [EC-597, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]

4. 1st trip freeze frame data
5. Others


HOW TO SWITCH DIAGNOSTIC TEST MODE

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned "OFF".

How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
4. Fully release the accelerator pedal.
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).




How to Set Diagnostic Test Mode II (Heated Oxygen Sensor 1 Monitor)

1. Set the ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-597, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Start Engine.
ECM has entered to Diagnostic Test Mode II (Heated oxygen sensor 1 monitor).
ECM will start heated oxygen sensor 1 monitoring from the bank 1 sensor for QG18DE engine models.

How to Switch Monitored Sensor From Bank 1 to Bank 2 or Vice Versa

1. Fully depress the accelerator pedal quickly and then release it immediately.
2. Make sure that monitoring sensor has changed by MI blinking as follows.



How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-597, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.
The emission-related diagnostic information has been erased from the backup memory in the ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QG (WITHOUT EURO-OBD)]

3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-95, "WARNING LAMPS"](#) or see [EC-950, "MI & DATA LINK CONNECTORS"](#).


DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)

DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The "zero" is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC "0000" refers to no malfunction. (See [EC-561, "INDEX FOR DTC"](#))

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-597, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).

- If the battery is disconnected, the DTC will be lost from the backup memory after approx 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

DIAGNOSTIC TEST MODE II — HEATED OXYGEN SENSOR 1 MONITOR

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1.

ON BOARD DIAGNOSTIC (OBD) SYSTEM [QG (WITHOUT EURO-OBD)]

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

PFP:00004

Trouble Diagnosis Introduction INTRODUCTION

EBS00EU5




The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-601](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on [EC-604](#) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.




TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBDD)]

WORK FLOW

Flow Chart



MBIB0178E

*1 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*2 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-657, "POWER SUPPLY CIRCUIT FOR ECM"](#).

*4 If the incident cannot be verified, perform [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

*5 [EC-652, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#)

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBID)]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-604 .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-612 .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-607 .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS – SPECIFICATION VALUE". (Refer to EC-652 .) (If malfunction is detected, proceed to "PERAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-612 .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-622 , EC-646 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident" . Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .)

DIAGNOSTIC WORKSHEET

Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MI to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

QG16DE ENGINE

Priority	Detected items (DTC)	
1	<ul style="list-style-type: none"> ● U1001 CAN communication line ● P0102 P0103 P1102 Mass air flow sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 P1229 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0605 ECM ● P1610-P1615 NATS 	A EC C D
2	<ul style="list-style-type: none"> ● P0132 P0134 Heated oxygen sensor 1 ● P0138 Heated oxygen sensor 2 ● P1065 ECM power supply ● P1122 Electric throttle control function ● P1124 P1126 P1128 Electric throttle control actuator ● P1805 Brake switch 	E F G
3	<ul style="list-style-type: none"> ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT) 	H

QG18DE ENGINE

Priority	Detected items (DTC)	
1	<ul style="list-style-type: none"> ● U1000 U1001 CAN communication line ● P0102 P0103 P1102 Mass air flow sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 P1229 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0605 ECM ● P1610-P1615 NATS 	I J K L
2	<ul style="list-style-type: none"> ● P0132 P0134 P0152 P0154 Heated oxygen sensor 1 ● P0138 P0158 Heated oxygen sensor 2 ● P1065 ECM power supply ● P1122 Electric throttle control function ● P1124 P1126 P1128 Electric throttle control actuator ● P1805 Brake switch 	M
3	<ul style="list-style-type: none"> ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT) 	

Fail-safe Chart

EBS00EU7

When the DTC listed below is detected, the ECM enters the fail-safe mode and the MI lights up.



TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0102 P0103 P1102	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.								
P0117 P0118	Engine coolant temperature sensor circuit	<p>Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th style="text-align: center;">Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td>More than approx. 4 minutes after ignition ON or Start</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table> <p>When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.</p>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or Start	40°C (104°F)	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
Condition	Engine coolant temperature decided (CONSULT-II display)									
Just as ignition switch is turned ON or Start	40°C (104°F)									
More than approx. 4 minutes after ignition ON or Start	80°C (176°F)									
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)									
P0221 P0222 P0223 P1223 P1224	Throttle position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								
P0226 P0227 P0228 P1227 P1228	Accelerator pedal position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								
P1121	Electric throttle control actuator (ECM detect the throttle valve is stuck open.)	<p>While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.</p>								
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								

Basic Inspection**1. INSPECTION START**


1. Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge. Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no-load.
6. Make sure that no DTC is displayed with CONSULT-II or ECM.

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.

**2. REPAIR OR REPLACE**


Repair or replace components as necessary according to corresponding "Diagnostic Procedure".

>> GO TO 3.

3. CHECK TARGET IDLE SPEED

④ With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.
3. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 10.
NG >> GO TO 4.

4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 5.

5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 6.

6. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-589, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 7.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

7. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 10.

NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-760](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-753](#) .

OK or NG

OK >> GO TO 9.

NG >> 1. Repair or replace.

2. GO TO 4.

9. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-595, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

10. CHECK IGNITION TIMING

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $8 \pm 5^\circ$ BTDC

A/T: $10 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 11.

11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 12.

12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 13.

13. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-589, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 14.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

14. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 700 ± 50 rpm

A/T: 800 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 15.

NG >> GO TO 17.

15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $8 \pm 5^\circ$ BTDC

A/T: $10 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 16.

16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-49, "TIMING CHAIN"](#) .

OK or NG

OK >> GO TO 17.

NG >> 1. Repair the timing chain installation.
2. GO TO 4.

17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-760](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-753](#) .

OK or NG

OK >> GO TO 18.

NG >> 1. Repair or replace.
2. GO TO 4.

18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-595, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBDD)]

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

EBS00EU9

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-934
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-591
	Injector circuit	1	1	2	3	2		2	2			2			EC-928
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-952
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-955
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-607
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	EC-780 , EC-783 , EC-790 , EC-796
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-607
	Ignition circuit	1	1	2	2	2		2	2			2			EC-895
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3			EC-657
Mass air flow sensor circuit		1	1	2	2	2		2	2			2			EC-666 , EC-774
Engine coolant temperature sensor circuit		1	1	2	2	2	3	2	2	3	1	2			EC-672
Throttle position sensor circuit			1	2		2	2	2	2	2		2			EC-723 , EC-729 , EC-811 , EC-817 , EC-819 , EC-828
Accelerator pedal position sensor circuit				3	2	1	2			2					EC-735 , EC-742 , EC-821
Heated oxygen sensor 1 circuit			1	2	3	2		2	2			2			EC-677 , EC-683 , EC-692 , EC-698 , EC-865 , EC-872
Knock sensor circuit				2	2							3			EC-749
Crankshaft position sensor (POS) circuit		2	2												EC-753
Camshaft position sensor (PHASE) circuit		2	2												EC-760

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Vehicle speed signal circuit		2	3		3						3			EC-912
Power steering pressure sensor circuit		2				3	3	3	3					EC-913
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-767 , EC-770
Intake valve timing control solenoid valve circuit	3	3	2		1	3	2	2	3		3			EC-918
PNP switch circuit			3		3	3	3	3	3		3			EC-924
Refrigerant pressure sensor circuit		2				3	3	3	3		4			EC-940
Electrical load signal circuit						3	3	3	3					EC-945
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	ATC-30

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM													Reference page
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel tank														FL-13
	Fuel piping	5		5	5	5		5	5			5			FL-3, MA-23
	Vapor lock		5												—
	Valve deposit														—
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5			5			—
Air	Air duct														EM-17
	Air cleaner														EM-17
	Air leakage from air duct (Mass air flow sensor —electric throttle control actuator)		5	5		5		5	5			5			EM-17
	Electric throttle control actuator	5			5		5			5					EM-19
	Air leakage from intake manifold/Collector/Gasket														EM-19
Cranking	Battery					1		1	1			1		1	SC-3
	Alternator circuit	1	1	1											SC-12
	Starter circuit	3													SC-22
	Signal plate/Flywheel/Drive plate	6													EM-70
	PNP switch	4													MT-14, MT-62 or AT-115
Engine	Cylinder head	5	5	5	5	5		5	5			5	3		EM-57
	Cylinder head gasket										4				
	Cylinder block												4		
	Piston													4	
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			EM-70
	Bearing														
	Crankshaft														

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]


		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Valve mechanism	Timing chain														EM-49
	Camshaft														EM-36
	Intake valve timing control	5	5	5	5	5		5	5			5			EM-49
	Intake valve												3		EM-57
	Exhaust valve														
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	5	5	5	5	5		5	5			5			EM-23 , EX-3
	Three way catalyst														
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5	2		EM-27 , LU-8 , LU-9 , LU-5
	Oil level (Low)/Filthy oil														LU-6
Cooling	Radiator/Hose/Radiator filler cap														CO-11
	Thermostat								5						CO-20
	Water pump														CO-18
	Water gallery	5	5	5	5	5		5	5		2	5			CO-7
	Cooling fan								5						CO-11
	Coolant level (low)/Contaminated coolant														CO-8
NATS (Nissan Anti-Theft System)		1	1												EC-595 or BL-156

1 - 6: The numbers refer to the order of inspection.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Engine Control Component Parts Location

EBS00EUA











MBIB0117E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]









A
EC
C
D
E
F
G
H
I
J
K
L
M



MBIB0118E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]











MBIB0119E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

A
EC
C
D
E
F
G
H
I
J
K
L
M




MBIB0120E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

EBS00EUB


Circuit Diagram



MBWA0042E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]



A
EC
C
D
E
F
G
H
I
J
K
L
M


MBWA0043E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

ECM Harness Connector Terminal Layout

EBS00EUC




MBIB0045E


ECM Terminals and Reference Value PREPARATION

EBS00EUD

1. ECM is located behind the glove box. For this inspection, remove glove box.
2. Remove ECM harness protector.



3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown at right.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground.

CAUTION:





Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

QG16DE Engine Models

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground





TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
2	R/B	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more 	0 - 1.0V	A
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm 	BATTERY VOLTAGE (11 - 14V)	EC
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)	C
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E	D
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E	E
12	L	Power steering pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	0.5 - 4.0V	F
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	0.4 - 0.8V	G
13	R	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 3.0V★  PBIB0527E	H
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 3.0V★  PBIB0528E	I




TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	R	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0526E</p>
15	W	Knock sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V
16	W	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
19	GY/L	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div T</small> PBIB0529E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div T</small> PBIB0530E
24	G	Heated oxygen sensor 1 heater	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm. 	Approximately 7.0V★  <small>10.0 V/Div 50 ms/Div T</small> PBIB0519E
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped. [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)
29	B	Camshaft position sensor (PHASE) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
30	B	Camshaft position sensor (POS) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
34	BR	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
35	W	Heated oxygen sensor 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - Approximately 1.0V (Periodically change)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
46	R	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V

A

EC

C

D

E

F

G

H

I

J





K

L

M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "1st" ● Accelerator pedal fully depressed 	Less than 4.75V
50	Y	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm. 	1.5 - 2.1V
54	-	Sensor ground (Knock sensor shield circuit)	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
57	B	Sensor ground (Power steering pressure sensor/Refrigerant pressure sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
60 61 79 80	L/R BR GY/R PU	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.1V★  PBIB0521E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - 0.2V★  PBIB0522E
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  MBIB0052E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed 2,500 rpm 	7 - 10V★  PBIB0532E

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V	A EC
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	C
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	D
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully released	Less than 4.75V	E
			[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully depressed	More than 0.36V	F
69	R/L	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.)	1.0 - 4.0V	G H
72	BR/W	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.	I
73	B	Sensor ground (Engine coolant temperature sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	J
74	B	Sensor ground (Heated oxygen sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	K
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	L
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V	M
85	LG	DATA link connector	[Ignition switch "ON"] ● CONSULT-II or GST is disconnected.	BATTERY VOLTAGE (11 - 14V)	
86	R	CAN communication line	[Ignition switch "ON"]	Approximately 2.3V	
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V	
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V	
94	L	CAN communication line	[Ignition switch "ON"]	Approximately 2.8V	

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]



TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully depressed	More than 1.95V
101	R/G	Stop lamp switch	[Ignition switch "ON"] ● Brake pedal fully released	Approximately 0V
			[Ignition switch "ON"] ● Brake pedal fully depressed	BATTERY VOLTAGE (11 - 14V)
102	G/OR	PNP switch	[Ignition switch "ON"] ● Gear position is neutral	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	Approximately 5V
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "1st" ● Accelerator pedal fully depressed	More than 3.9V
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 5 seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
113	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 second after turning ignition switch "ON"	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] ● More than 1 second after turning ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]





QG18DE Engine Models

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
2	L	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more	0 - 1.0V
			[Ignition switch "ON"] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing	0 - 14V★  PBIB0534E
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing	0 - 14V★  PBIB0533E
7	W/R	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] ● Engine speed is below 3,600 rpm ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more	0 - 1.0V
			[Ignition switch "ON"] ● Engine stopped [Engine is running] ● Engine speed is above 3,600 rpm	BATTERY VOLTAGE (11 - 14)
12	L	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned	Approximately 3.6V
			[Engine is running] ● Steering wheel is not being turned	Approximately 0.6V

A
EC
C
D
E
F
G
H
I
J
K
L
M






TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	R	Crankshaft position sensor (POS)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 3.0V★</p>  <p style="text-align: right;">PBIB0527E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 3.0V★</p>  <p style="text-align: right;">PBIB0528E</p>
14	R	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0526E</p>
15	W	Knock sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 2.5V</p>
16	Y	Heated oxygen sensor 2 (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	<p>0 - Approximately 1.0V</p>
17	L	Heated oxygen sensor 2 (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	<p>0 - Approximately 1.0V</p>

TROUBLE DIAGNOSIS


[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	GY/L	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0530E</p>
24	G	Heated oxygen sensor 1 heater (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm (M/T model) ● Engine speed is below 3,200 rpm (A/T model) 	<p>Approximately 7.0V★</p>  <p style="text-align: right;">PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (M/T model) ● Engine speed is above 3,200 rpm (A/T model) 	<p>BATTERY VOLTAGE (11 - 14V)</p>

A
EC
C
D
E
F
G
H
I
J
K
L
M





TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	R/B	Heated oxygen sensor 1 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm (M/T model) ● Engine speed is below 3,200 rpm (A/T model) 	Approximately 7.0V★  PBIB0519E
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm (M/T model) ● Engine speed is above 3,200 rpm (A/T model) 	BATTERY VOLTAGE (11 - 14V)
29	B	Camshaft position sensor (PHASE) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
30	B	Camshaft position sensor (POS) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
34	BR	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
46	R	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	Less than 4.75V
50	Y	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 1.7V
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,500 rpm 	1.5 - 2.1V

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
54	-	Sensor ground (Knock sensor shield circuit)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
57	B	Sensor ground (Power steering pressure sensor/Refrigerant pressure sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
60 61 79 80	L/R BR GY/R PU	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.1V★  PBIB0521E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	0 - 0.2V★  PBIB0522E
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)★  MBIB0052E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	7 - 10V★  PBIB0532E
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
68	R	Throttle position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	Less than 4.75V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	More than 0.36V
69	R/L	Refrigerant pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.) 	1.0 - 4.0V
72	BR/W	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
73	B	Sensor ground (Engine coolant temperature sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
74	B	Sensor ground (Heated oxygen sensor)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
85	LG	DATA link connector	[Ignition switch "ON"] <ul style="list-style-type: none"> ● CONSULT-II or GST is disconnected. 	BATTERY VOLTAGE (11 - 14V)
86	R	CAN communication line	[Ignition switch "ON"]	Approximately 2.3V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
92		Accelerator pedal position sensor signal output	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.35 - 0.67V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 3.9V
94	L	CAN communication line	[Ignition switch "ON"]	Approximately 2.8V

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.175 - 0.335V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 1.95V
101	R/G	Stop lamp switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully released 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully depressed 	BATTERY VOLTAGE (11 - 14V)
102	P (A/T) G/OR (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Gear position is "P" or "N" 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Except the above gear position 	A/T models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V
103		Tachometer signal output	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	10 - 11V★  MBIB0053E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	10 - 11V★  MBIB0054E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	Less than 4.75V
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> For 5 seconds after turning ignition switch "OFF" 	0 - 1.0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> 5 seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
113	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> For 1 second after turning ignition switch "ON" 	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] <ul style="list-style-type: none"> More than 1 second after turning ignition switch "ON". 	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> Idle speed 	Engine ground
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

CONSULT-II Function FUNCTION

EBS00EUE

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

*1: The following emission-related diagnostic information is cleared when the ECM memory is erased.

1. Diagnostic trouble codes
2. 1st trip diagnostic trouble codes
3. Freeze frame data
4. 1st trip freeze frame data
5. Others

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBID)]

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE					
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST
			DTC ^{*1}	FREEZE FRAME DATA ^{*2}			
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)	×	×	×	×	
	Camshaft position sensor (PHASE)	×		×	×		
	Mass air flow sensor	×		×	×		
	Engine coolant temperature sensor	×	×	×	×	×	
	Heated oxygen sensor 1	×		×	×		
	Heated oxygen sensor 2	×		×	×		
	Vehicle speed signal		×	×	×		
	Accelerator pedal position sensor	×		×	×		
	Throttle position sensor	×		×	×		
	Intake air temperature sensor			×	×		
	Knock sensor	×					
	Refrigerant pressure sensor			×	×		
	Closed throttle position switch (accelerator pedal position sensor signal)			×	×		
	Air conditioner switch			×	×		
	Park/neutral position (PNP) switch			×	×		
	Stop lamp switch	×		×	×		
	Power steering pressure sensor			×	×		
	Battery voltage			×	×		
Electrical load signal			×	×			
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Injectors			×	×	×
	Power transistor (Ignition timing)			×	×	×	
	Throttle control motor relay	×		×	×		
	Throttle control motor	×					
	EVAP canister purge volume control solenoid valve			×	×	×	
	Air conditioner relay			×	×		
	Fuel pump relay	×		×	×	×	
	Cooling fan relay		×	×	×	×	
	Heated oxygen sensor 1 heater			×	×		
	Heated oxygen sensor 2 heater			×	×		
	Intake valve timing control solenoid valve			×	×	×	
	Calculated load value			×	×	×	

X: Applicable

*1: This item includes 1st trip DTCs.

*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-639](#).


CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.


TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]


2. Connect "CONSULT-II" to data link connector, which is located under the driver's side dash panel.
3. Turn ignition switch ON.




4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.
For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> ● THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM. 	When learning the idle air volume

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

WORK ITEM	CONDITION	USAGE
SELF-LEARNING CONT	<ul style="list-style-type: none"> ● THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light.

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to [EC-561, "INDEX FOR DTC"](#) .)

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*1	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ● The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-561, "INDEX FOR DTC" .)
FUEL SYS-B1	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed. ● One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> ● The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed. ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed. ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> ● The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> ● The intake air temperature at the moment a malfunction is detected is displayed.

*1: The items are the same as those of 1st trip freeze frame data.

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

DATA MONITOR MODE

Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ENG SPEED [rpm]	×	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signals of the crankshaft position sensor (POS) and camshaft position sensor (PHASE). 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		×		<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		×		<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%] ^{*1}		×			
COOLAN TEMP/S [°C] or [°F]	×	×		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S1 (B2) [V] ^{*1}	×				
HO2S2 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S2 (B2) [V] ^{*1}	×				
HO2S1 MNTR (B1) [RICH/LEAN]	×	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S1 MNTR (B2) [RICH/LEAN] ^{*1}	×				
HO2S2 MNTR (B1) [RICH/LEAN]	×			<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
HO2S2 MNTR (B2) [RICH/LEAN] ^{*1}	×				
VHCL SPEED SE [km/h] or [mph]	×	×		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	
BATTERY VOLT [V]	×	×		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ACCEL SEN 1 [V]	×	×		● The accelerator pedal position sensor signal voltage is displayed.	
ACCEL SEN 2 [V]	×				
THRTL SEN 1 [V]	×	×		● The throttle position sensor signal voltage is displayed.	
THRTL SEN 2 [V]	×				
INT/A TEMP SE [°C] or [°F]	×	×		● The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.	
START SIGNAL [ON/OFF]	×	×		● Indicates [ON/OFF] condition of the starter signal computed from the signals of the crankshaft position sensor (POS), camshaft position sensor (PHASE) and battery voltage.	● After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	×	×		● Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.	
AIR COND SIG [ON/OFF]	×	×		● Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.	
P/N POSI SW [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.	
PW/ST SIGNAL [ON/OFF]	×	×		● [ON/OFF] condition of the power steering oil pressure switch as determined by the power steering oil pressure signal is indicated.	
LOAD SIGNAL [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the electrical load signal. ON ... Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF ... Both rear window defogger switch and lighting switch are OFF.	
IGNITION SW [ON/OFF]	×			● Indicates [ON/OFF] condition from ignition switch.	
HEATER FAN SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the heater fan switch signal.	
BRAKE SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the stop lamp switch signal.	
INJ PULSE-B1 [msec]		×		● Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.	● When the engine is stopped, a certain computed value is indicated.
INJ PULSE-B2 [msec] ^{*1}					
IGN TIMING [BTDC]		×		● Indicates the ignition timing computed by ECM according to the input signals.	● When the engine is stopped, a certain value is indicated.
CAL/LD VALUE [%]				● "Calculated load value" indicates the value of the current airflow divided by peak airflow.	
MASS AIRFLOW [g·m/s]				● Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor.	

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
PURG VOL C/V [%]				<ul style="list-style-type: none"> Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. The opening becomes larger as the value increases. 	
INT/V TIM (B1) [°CA]				<ul style="list-style-type: none"> Indicates [°CA] of intake camshaft advanced angle. 	
INT/V SOL (B1) [%]				<ul style="list-style-type: none"> The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
AIR COND RLY [ON/OFF]		×		<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. 	
FUEL PUMP RLY [ON/OFF]		×		<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
THRTL RELAY [ON/OFF]		× ^{*2}		<ul style="list-style-type: none"> Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. 	
COOLING FAN [ON/OFF]				<ul style="list-style-type: none"> Indicates the condition of the cooling fan (determined by ECM according to the input signals). ON ... Operation OFF ... Stop 	
HO2S1 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S1 HTR (B2) [ON/OFF] ^{*1}					
HO2S2 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B2) [ON/OFF] ^{*1}					
VEHICLE SPEED [km/h] or [mph]	×			<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal sent from TCM is displayed. 	
IDL A/V LEARN [YET/CMPLT/ INCMP]				<ul style="list-style-type: none"> Display the condition of idle air volume learning YET ... Idle air volume learning has not been performed yet. CMPLT ... Idle air volume learning has already been performed successfully. INCMP ... Idle air volume learning has not been performed successfully. 	
TRVL AFTER MIL [km] or [mile]				<ul style="list-style-type: none"> Distance traveled while MI is activated. 	

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
O2SEN HTR DTY [%]				<ul style="list-style-type: none"> Indicates the heated oxygen sensor 1 heater control value computed by the ECM according to the input signals. 	
AC PRESS SEN [V]	×*2			<ul style="list-style-type: none"> The signal voltage from the refrigerant pressure sensor is displayed. 	
Voltage [V]				<ul style="list-style-type: none"> Voltage, frequency, duty cycle or pulse width measured by the probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					
CAN COMM [OK/NG]			×		
CAN CIRC 1 [OK/UNKWN]			×		
CAN CIRC 2 [OK/UNKWN]			×		
CAN CIRC 3 [OK/UNKWN]			×		
CAN CIRC 4 [OK/UNKWN]			×		
CAN CIRC 5 [OK/UNKWN]			×		
CAN CIRC 6 [OK/UNKWN]			×		
CAN CIRC 7 [OK/UNKWN]			×		

*1: For QG18 engine models.

*2: For QG16 engine models.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

DATA MONITOR (SPEC) MODE

Monitored Item

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	×	×	<ul style="list-style-type: none"> Indicates the engine speed computed from the signal of the crankshaft position sensor (POS). 	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]		×	<ul style="list-style-type: none"> “Base fuel schedule” indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBDD)]

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.
A/F ALPHA-B2 [%]*1		×		

*1: For QG18 engine models

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Fuel injectors Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Perform "Idle Air Volume Learning".
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connectors Compression Fuel injectors Power transistor Spark plugs Ignition coils
COOLING FAN	<ul style="list-style-type: none"> Ignition switch: ON Turn the cooling fan "ON" and "OFF" with CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> Harness and connectors Cooling fan relay Cooling fan motor
ENG COOLANT TEMP	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Engine coolant temperature sensor Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connectors Fuel pump relay
PURG VOL CONT/V	<ul style="list-style-type: none"> Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> Harness and connectors Solenoid valve
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> Engine: Return to the original trouble condition Change intake valve timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> Harness and connectors Intake valve timing control solenoid valve

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.


The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.



2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.



Operation

1. "AUTO TRIG"


- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]



PBIB0197E

CONSULT-II Reference Value in Data Monitor Mode

EBS00EUG

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value.
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle	Approx. 1.0 - 1.7V
		2,500 rpm	Approx. 1.5 - 2.1V
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	1.5 - 3.0 msec
		2,000 rpm	1.2 - 3.0 msec
A/F ALPHA-B1 A/F ALPHA-B2*	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	75% - 125%
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1) HO2S1 (B2)*	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1) HO2S2 (B2)*	<ul style="list-style-type: none"> ● Engine: After warming up 	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 MNTR (B1) HO2S1 MNTR (B2)*	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ←→ RICH Changes more than 5 times during 10 seconds.
HO2S2 MNTR (B1) HO2S2 MNTR (B2)*	● Engine: After warming up	Revvng engine from idle to 3,000 rpm quickly.	LEAN ←→ RICH
VEH SPEED SE	● Turn drive wheels and compare speedometer indication with the CONSULT-II value.		Almost the same speed as the CONSULT-II value
BATTERY VOLT	● Ignition switch: ON (Engine stopped)		11 - 14V
ACCEL SEN1 ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
THRTL SEN1 THRTL SEN2	● Ignition switch: ON (Engine stopped) ● Shift lever: D (A/T model) 1st (M/T model)	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
START SIGNAL	● Ignition switch: ON → START → ON		OFF → ON → OFF
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T model) Neutral (M/T model)	ON
		Shift lever: Except above	OFF
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is in 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF
IGNITION SW	● Ignition switch: ON → OFF → ON		ON → OFF → ON
HEATER FAN SW	● Engine: After warming up, idle the engine	Heater fan is operating.	ON
		Heater fan is not operating	OFF
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1 INJ PULSE-B2*	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle	2.0 - 3.5 msec
		2,000 rpm	1.5 - 3.5 msec
IGN TIMING	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle	M/T: 8°±5° BTDC A/T: 10°±5° BTDC
		2,000 rpm	25° - 45° BTDC
CAL/LD VALUE	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load	Idle	10% - 35%
		2,500 rpm	10% - 35%

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle 1.0 - 4.0 g-m/s
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	2,500 rpm 5.0 - 10.0 g-m/s
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle 0%
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	2,000 rpm 15 - 30%
INT/V TIM (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle -5° - 5°C
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	2,000 rpm Approx. 0° - 30°C
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle 0% - 2%
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	2,000 rpm Approx. 0% - 60%
AIR COND RLY	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF OFF
		Air conditioner switch: ON (Compressor operates) ON
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking 	ON
	<ul style="list-style-type: none"> ● Except above conditions 	OFF
THRTL RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON 	ON
COOLING FAN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Engine coolant temperature is 99°C (210°F) or less OFF
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF 	Engine coolant temperature is 100°C (212°F) or more ON
HO2S1 HTR (B1) HO2S1 HTR (B2)*	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm (M/T models) Below 3,200 rpm (A/T models) 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm (M/T models) Above 3,200 rpm (A/T models) 	OFF
HO2S2 HTR (B1) HO2S2 HTR (B2)*	<ul style="list-style-type: none"> ● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF
TRVL AFTER MIL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Vehicle has traveled after MI has turned ON. 0 - 65,280 km (0 - 40,565 mile)
O2SEN HTR DTY	<ul style="list-style-type: none"> ● Engine coolant temperature when engine started: More than 80° (176°F) ● Engine speed: Below 3,600 rpm (M/T models) Below 3,200 rpm (A/T models) 	Approx. 50%
AC PRESS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Approx. 0V
	<ul style="list-style-type: none"> ● Engine: Idle ● Air conditioner switch: OFF 	1.0 - 4.0V
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OB)]

MONITOR ITEM	CONDITION	SPECIFICATION
CAN COMM	● Ignition switch: ON	OK
CAN CIRC 1		OK
CAN CIRC 2		OK or UNKWN
CAN CIRC 3		UNKWN
CAN CIRC 4		OK
CAN CIRC 5		UNKWN
CAN CIRC 6		OK
CAN CIRC 7		UNKWN

*: These items are displayed with QG18DE engine models

Major Sensor Reference Graph in Data Monitor Mode


EBS00EUH

The following are the major sensor reference graphs in "DATA MONITOR" mode.

CLSD THL POS, ACCEL SEN 1, THRTL SEN 1

Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch "ON" and with selector lever in "D" position (A/T models) or with shift lever in "1st" position (M/T models).

The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBD)]

Each value is for reference, the exact value may vary.



TROUBLE DIAGNOSIS

[QG (WITHOUT EURO-OBID)]

A

EC

C

D

E

F

G

H


I

J

K

L


M




- "THRTL SEN 1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

PBIB0668E

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITHOUT EURO-OBD)]

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

EBS00EUJ

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONITOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MI.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1/B2 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

EBS00EUJ

- Vehicle driven distance: More than 5,000 km (3,017 miles)
- Barometric pressure: 98.3 - 104.3 kPa (1.003 - 1.064 kg/cm² , 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*1
- Electrical load: Not applied*2
- Engine speed: Idle

*1: For A/T models with CONSULT-II, after the engine is warmed up to normal operating temperature, drive vehicle until "FLUID TEMP SE" (A/T fluid temperature sensor signal) indicates more than 60°C (140°F).

For A/T models without CONSULT-II and M/T models, after the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.

*2: Rear window defogger switch, air conditioner switch, lighting switch are "OFF". Steering wheel is straight ahead.


Inspection Procedure

EBS00EUK

NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

1. Perform [EC-607, "Basic Inspection"](#) .
2. Confirm that the testing conditions indicated above are met.
3. Select "B/FUEL SCHDL", "A/F ALPHA-B1/B2" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-653, "Diagnostic Procedure"](#) .




TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITHOUT EURO-OBDD)]

Diagnostic Procedure

EBS00EUL




(Go to next page.)

SEF613ZD

TROUBLE DIAGNOSIS - SPECIFICATION VALUE


[QG (WITHOUT EURO-OBDD)]



SEF768Z

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QG (WITHOUT EURO-OBD)]



A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF615ZA

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT [QG (WITHOUT EURO-OBD)]

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

Description

EBS00EUM

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the problem area.

Diagnostic Procedure

EBS00EUM

1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITHOUT EURO-OBD)]



POWER SUPPLY CIRCUIT FOR ECM

PF24110



Wiring Diagram

EBS00EUO

EC-MAIN-01



REFER TO THE FOLLOWING.
 (M1) - FUSE BLOCK-JUNCTION BOX (J/B)



MBWA0044E

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● More than a few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EUP

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

Yes >> GO TO 8.

No >> GO TO 2.

2. CHECK ECM POWER SUPPLY CIRCUIT-I


- Turn ignition switch "OFF" and then "ON".
- Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.



POWER SUPPLY CIRCUIT FOR ECM [QG (WITHOUT EURO-OBD)]

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.


OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminals 1 and 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



POWER SUPPLY CIRCUIT FOR ECM

[QG (WITHOUT EURO-OBD)]

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 111 and ECM relay terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG


OK >> Go to [EC-895, "IGNITION SIGNAL"](#) .

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Stop engine and wait at least 10 seconds.
2. Turn ignition switch "ON" and then "OFF".
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.



OK or NG

OK >> GO TO 13.

NG (Battery voltage does not exist.)>>GO TO 9.


NG (Battery voltage exists for more than a few seconds.)>>GO TO 12.

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITHOUT EURO-OBD)]

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 11.
NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and F13 (LHD models)
- Harness for open or short between ECM relay and F31 (RHD models)

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 119, 120 and ECM relay terminal 5. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 12.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK ECM RELAY

Refer to [EC-662, "Component Inspection"](#).

OK or NG

- OK >> GO TO 13.
NG >> Replace ECM relay.

POWER SUPPLY CIRCUIT FOR ECM

[QG (WITHOUT EURO-OBDD)]

13. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 14.

NG >> Repair open circuit or short to power in harness or connectors.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection

ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC U1000, U1001 CAN COMMUNICATION LINE [QG (WITHOUT EURO-OBD)]

DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

Description

EBS00EUQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

EBS00EUR

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	● ECM cannot communicate to other control unit.	● Harness or connectors (CAN communication line is open or shorted.)
U1001 1001		● ECM cannot communicate for more than the specified time.	

DTC Confirmation Procedure

EBS00EUS

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-665, "Diagnostic Procedure"](#).



DTC U1000, U1001 CAN COMMUNICATION LINE [QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EUT

EC-CAN-01

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- : DATA LINE



MBWA0038E

DTC U1000, U1001 CAN COMMUNICATION LINE [QG (WITHOUT EURO-OBDD)]

EBS00EUU

Diagnostic Procedure

1. INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

A/T models

OK data	NG data																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>OK</td></tr> <tr><td>CAN CIRC 2</td><td>OK</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>OK</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>OK</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR	NO DTC	CAN COMM	OK	CAN CIRC 1	OK	CAN CIRC 2	OK	CAN CIRC 3	UNKWN	CAN CIRC 4	OK	CAN CIRC 5	UNKWN	CAN CIRC 6	OK	CAN CIRC 7	UNKWN	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 2</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR	NO DTC	CAN COMM	OK	CAN CIRC 1	UNKWN	CAN CIRC 2	UNKWN	CAN CIRC 3	UNKWN	CAN CIRC 4	UNKWN	CAN CIRC 5	UNKWN	CAN CIRC 6	UNKWN	CAN CIRC 7	UNKWN
DATA MONITOR																																									
MONITOR	NO DTC																																								
CAN COMM	OK																																								
CAN CIRC 1	OK																																								
CAN CIRC 2	OK																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	OK																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	OK																																								
CAN CIRC 7	UNKWN																																								
DATA MONITOR																																									
MONITOR	NO DTC																																								
CAN COMM	OK																																								
CAN CIRC 1	UNKWN																																								
CAN CIRC 2	UNKWN																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	UNKWN																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	UNKWN																																								
CAN CIRC 7	UNKWN																																								
MBIB0180E																																									

M/T models

OK data	NG data																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>OK</td></tr> <tr><td>CAN CIRC 2</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>OK</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>OK</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR	NO DTC	CAN COMM	OK	CAN CIRC 1	OK	CAN CIRC 2	UNKWN	CAN CIRC 3	UNKWN	CAN CIRC 4	OK	CAN CIRC 5	UNKWN	CAN CIRC 6	OK	CAN CIRC 7	UNKWN	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;">NO DTC</th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 2</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR	NO DTC	CAN COMM	OK	CAN CIRC 1	UNKWN	CAN CIRC 2	UNKWN	CAN CIRC 3	UNKWN	CAN CIRC 4	UNKWN	CAN CIRC 5	UNKWN	CAN CIRC 6	UNKWN	CAN CIRC 7	UNKWN
DATA MONITOR																																									
MONITOR	NO DTC																																								
CAN COMM	OK																																								
CAN CIRC 1	OK																																								
CAN CIRC 2	UNKWN																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	OK																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	OK																																								
CAN CIRC 7	UNKWN																																								
DATA MONITOR																																									
MONITOR	NO DTC																																								
CAN COMM	OK																																								
CAN CIRC 1	UNKWN																																								
CAN CIRC 2	UNKWN																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	UNKWN																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	UNKWN																																								
CAN CIRC 7	UNKWN																																								
MBIB0179E																																									

>> Go to [LAN-8, "CAN COMMUNICATION"](#) .

DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBDD)]


DTC P0102, P0103 MAF SENSOR

PFPP:22680

Component Description

EBS00EUV

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EUV

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.0 - 1.7V
	2,500 rpm	Approx. 1.5 - 2.1V
CAL/LD VALUE	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	1.0 - 4.0 g-m/s
	2,500 rpm	5.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00EUV

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00EUV

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

PROCEDURE FOR DTC P0102

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Start engine and wait 5 seconds at most.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .

PROCEDURE FOR DTC P0103

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 5 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start engine and wait at least 5 seconds.
7. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
8. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
9. If DTC is detected, go to [EC-669, "Diagnostic Procedure"](#) .





DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

EBS00EUZ

Wiring Diagram

EC-MAFS-01



MBWA0045E

DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
50	Y	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.5 - 2.1V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00EV0

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

P0102 >> GO TO 2.

P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold

OK or NG


OK >> GO TO 3.

NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.




DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 67.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 1 and ECM terminal 50.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0102, P0103 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-671, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection MASS AIR FLOW SENSOR


EBS00EV1

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.5 - 2.1
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.



Removal and Installation MASS AIR FLOW SENSOR

EBS00EV2

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

DTC P0117, P0118 ECT SENSOR

[QG (WITHOUT EURO-OBD)]


DTC P0117, P0118 ECT SENSOR

PFP:22630

Component Description

EBS00EV3


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00EV4

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When this malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

DTC P0117, P0118 ECT SENSOR

[QG (WITHOUT EURO-OBD)]

DTC Confirmation Procedure

EBS00EV5

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-675, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

ⓧ WITHOUT CONSULT-II

1. Turn ignition switch "ON" and wait at least 5 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-675, "Diagnostic Procedure"](#) .





DTC P0117, P0118 ECT SENSOR

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EV6

EC-ECTS-01



MBWA0047E

DTC P0117, P0118 ECT SENSOR


[QG (WITHOUT EURO-OBD)]

Diagnostic Procedure

EBS00EV7

1. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature (ECT) sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between engine coolant temperature sensor and ECM
- Harness for open or short between engine coolant temperature sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-676, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

DTC P0117, P0118 ECT SENSOR

[QG (WITHOUT EURO-OBD)]

5. CHECK INTERMITTENT INCIDENT


Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

EBS00EV8


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



2. If NG, replace engine coolant temperature sensor.

Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

EBS00EV9

Refer to [CO-20, "THERMOSTAT AND THERMOSTAT HOUSING"](#) .



DTC P0132 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00H66

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H67


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00H68

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

DTC Confirmation Procedure**NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-680, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Restart engine and let it idle for 2 minutes.
4. Turn ignition switch "OFF" and wait at least 10 seconds.
5. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
6. If 1st trip DTC is detected, go to [EC-680, "Diagnostic Procedure"](#).




DTC P0132 HO2S1 (QG16DE)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H6A

EC-HO2S1-01



REFER TO THE FOLLOWING.
E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0048E

DTC P0132 HO2S1 (QG16DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure


EBS00H6B

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch "OFF".
2. Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 CONNECTOR FOR WATER

Check heated oxygen sensor 1 connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-681, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 1**

EBS00H6C

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

DTC P0132 HO2S1 (QG16DE)


[QG (WITHOUT EURO-OBD)]

6. Check the following.

- “HO2S1 MNTR (B1)” in “DATA MONITOR” mode changes from “RICH” to “LEAN” to “RICH” 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- “HO2S1 (B1)” voltage goes above 0.6V at least once.
- “HO2S1 (B1)” voltage goes below 0.3V at least once.
- “HO2S1 (B1)” voltage never exceeds 1.0V.

cycle | 1 | 2 | 3 | 4 | 5 |
 HO2S1 MNTR (B1) R-L-R-L-R-L-R-L-R-L-R
 R means HO2S1 MNTR (B1) indicates RICH
 L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



SEF648Y

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**


1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



**Removal and Installation
 HEATED OXYGEN SENSOR 1**

EBS00H6D

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).



DTC P0132, P0152 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00H6E

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H6F


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00H6G

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132 (Bank 1)	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1
P0152 0152 (Bank 2)			

DTC Confirmation Procedure

EBS00H6H

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-688, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Restart engine and let it idle for 2 minutes.
4. Turn ignition switch "OFF" and wait at least 10 seconds.
5. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
6. If 1st trip DTC is detected, go to [EC-688, "Diagnostic Procedure"](#).


DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]



Wiring Diagram BANK 1

EBS00H61

EC-O2S1B1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.





TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2

EC-O2S1B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBDD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure


EBS00H6J

1. RETIGHTEN HEATED OXYGEN SENSOR 1

1. Turn ignition switch "OFF".
2. Loosen and retighten corresponding heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30 - 44 ft·lb)

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	35	2	1
P0152	36	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0132	35	2	1
P0152	36	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 CONNECTOR FOR WATER

Check heated oxygen sensor 1 connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-689, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00H6K

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.

DTC P0132, P0152 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5
	HO2S1 MNTR (B1)	R	L	R	L	R
Bank 2	cycle	1	2	3	4	5
	HO2S1 MNTR (B2)	R	L	R	L	R

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



DTC P0132, P0152 HO2S1 (QG18DE)
[QG (WITHOUT EURO-OBD)]

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 1

EBS00H6L

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0134 HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FUF

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FUG


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FUH

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

Overall Function Check

EBS00FUJ

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

Ⓟ WITH CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)".
3. Hold engine speed at 2,000 rpm under no load.
4. Make sure that the indications do not remain in the range between 0.2 to 0.4V.
5. If NG, go to [EC-695, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

⊗ WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-695, "Diagnostic Procedure"](#).






DTC P0134 HO2S1 (QG16DE)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00FUK

EC-HO2S1-01



MBWA0048E

DTC P0134 HO2S1 (QG16DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FUL

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-695, "Diagnostic Procedure"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FUM

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN



SEF646Y

DTC P0134 HO2S1 (QG16DE)

[QG (WITHOUT EURO-OBD)]

6. Check the following.

- "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)" voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**


1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FUN

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .



DTC P0134, P0154 HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FU0

The heated oxygen sensor 1 is placed into the EXHAUST MANIFOLD. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FU0


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00FU0

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC P0134, P0154 HO2S1 (QG18DE) [QG (WITHOUT EURO-OBD)]

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134 (Bank 1)	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1
P0154 0154 (Bank 2)			

Overall Function Check

EBS00FUS

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)" and "HO2S1 (B2)".
3. Hold engine speed at 2,000 rpm under no load.
4. Make sure that the indications do not remain in the range between 0.2 to 0.4V.
5. If NG, go to [EC-703, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

WITHOUT CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-703, "Diagnostic Procedure"](#).






DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

EBS00FUT

Wiring Diagram BANK 1

EC-O2S1B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0052E

DTC P0134, P0154 HO2S1 (QG18DE)
[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V




A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2

EC-O2S1B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0054E

DTC P0134, P0154 HO2S1 (QG18DE) [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00FUU

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S1 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	35	2	1
P0154	36	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0134	35	2	1
P0154	36	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-704, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace malfunctioning heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FUV

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.

DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	L	R	L	R	L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	L	R	L	R	L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



DTC P0134, P0154 HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FUW

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

DTC P0138 HO2S2 (QG16DE)

PFP:226A0

Component Description


EBS00H6M

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H6N


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Revvng engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Revvng engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00H6O

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2

DTC Confirmation Procedure

EBS00H6P

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
3. Stop vehicle with engine running.

DTC P0138 HO2S2 (QG16DE)

[QG (WITHOUT EURO-OBD)]

- Let engine idle for 1 minute.
- If 1st trip DTC is detected, go to [EC-710, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y


Overall Function Check

EBS00H6Q

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ WITHOUT CONSULT-II

- Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- Stop vehicle with engine running.
- Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 1.4V during this procedure.
- If NG, go to [EC-710, "Diagnostic Procedure"](#).




DTC P0138 HO2S2 (QG16DE)

[QG (WITHOUT EURO-OBD)]



Wiring Diagram

EBS00H6R

EC-HO2S2-01



A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0138 HO2S2 (QG16DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00H6S

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-299](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-712, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00H6T


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



DTC P0138 HO2S2 (QG16DE)

[QG (WITHOUT EURO-OBD)]

“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.


5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 2

EBS00H6U

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0138, P0158 HO2S2 (QG18DE)

PFP:226A0

Component Description


EBS00H6V

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H6W


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00H6X

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138 (Bank 1)	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2
P0158 0158 (Bank 2)			

DTC Confirmation Procedure

EBS00H6Y

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch “ON” and select “DATA MONITOR” mode with CONSULT-II.
2. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
3. Stop vehicle with engine running.

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITHOUT EURO-OBD)]

- 4. Let engine idle for 1 minute.
- 5. If 1st trip DTC is detected, go to [EC-719, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y


Overall Function Check

EBS00H6Z

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

⊗ WITHOUT CONSULT-II

- 1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- 2. Stop vehicle with engine running.
- 3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
- 4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 1.4V during this procedure.
- 5. If NG, go to [EC-719, "Diagnostic Procedure"](#) .






DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITHOUT EURO-OBD)]

EBS00H70

Wiring Diagram BANK 1

EC-O2S2B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0056E

DTC P0138, P0158 HO2S2 (QG18DE)
[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V




A
EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2

EC-O2S2B2-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0058E

**DTC P0138, P0158 HO2S2 (QG18DE)
[QG (WITHOUT EURO-OBD)]**

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00H71

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 or P0175 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172, P0175. Refer to [EC-305](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



DTC P0138, P0158 HO2S2 (QG18DE) [QG (WITHOUT EURO-OBD)]

4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal and HO2S2 terminal as follows.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	16	2	1
P0158	17	2	2

Continuity should exist.

2. Check harness continuity between the following terminals and ground.
Refer to Wiring Diagram.

DTC	Terminals		Bank
	ECM	Sensor	
P0138	16	2	1
P0158	17	2	2

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-721, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00H72

 With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.


ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

DTC P0138, P0158 HO2S2 (QG18DE)

[QG (WITHOUT EURO-OBD)]

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
"HO2S2 (B1)/(B2)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.
5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).
The voltage should be below 0.50V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#)

EBS00H73

DTC P0221 TP SENSOR


PF16119

Component Description

EBS00EVA

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EVB

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00EVC

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0221 0221	Throttle position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.
- So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EVD

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

Ⓟ WITH CONSULT-II

- Turn ignition switch "ON".

DTC P0221 TP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-726, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-726, "Diagnostic Procedure"](#) .




DTC P0221 TP SENSOR

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EVE

EC-TPS3-01



MBWA0138E

DTC P0221 TP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor power supply (Throttle position sensor)	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensor ground (Throttle position sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00EVF

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4, ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-728, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00EVG

1. Reconnect all harness connectors disconnected.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-589, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EVH

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P0222, P0223 TP SENSOR

[QG (WITHOUT EURO-OBD)]

DTC P0222, P0223 TP SENSOR


PF16119

Component Description

EBS00EVI

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EVJ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1	● Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released More than 0.36V
	● Shift lever: D (A/T model) 1st (M/T model)	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00EVK

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	● Harness or connectors (The TP sensor 1 circuit is open or shorted.) ● Electric throttle control actuator (TP sensor 1)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EVL

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0222, P0223 TP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-732, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-732, "Diagnostic Procedure"](#) .

DTC P0222, P0223 TP SENSOR




[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EVM

EC-TPS1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0136E

DTC P0222, P0223 TP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"]	More than 0.36V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	
66	B	Throttle position sensor ground	[Engine is running]	Approximately 0V
			<ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	
68	R	Throttle position sensor 2	[Ignition switch "ON"]	Less than 4.75V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	
			[Ignition switch "ON"]	More than 0.36V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	


Diagnostic Procedure

EBS00EVN

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0222, P0223 TP SENSOR

[QG (WITHOUT EURO-OBD)]

2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-734, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

DTC P0222, P0223 TP SENSOR

[QG (WITHOUT EURO-OBD)]

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00EVO

1. Reconnect all harness connectors disconnected.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-589, "Idle Air Volume Learning"](#) .



MBIB0022E

Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EVP

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P0226 APP SENSOR

PFP:18002


Component Description

EBS00EVO

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EVR

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1 ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00EVS

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0226 0226	Accelerator pedal position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> ● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) ● Accelerator pedal position sensor 1 and 2

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EVT

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-738, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-738, "Diagnostic Procedure"](#).

DTC P0226 APP SENSOR





[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EVU

EC-APPS3-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



DTC P0226 APP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00EVV

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminals 1, 2 and ground with CONSULT-II or tester.

APP sensor terminal	Voltage (V)
1	Approximately 2.5
2	Approximately 5

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 82 and APP sensor terminal 4, ECM terminal 83 and APP sensor terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-740, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00EVW


1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QG (WITHOUT EURO-OBD)]

3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.195V



4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-589, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00EVX

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

DTC P0227, P0228 APP SENSOR

PFP:18002


Component Description

EBS00EVY

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EVZ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00EW0

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0227 0227	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P0228 0228	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EW1

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 8V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-745, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A

EC

C

D

E

F

G

H

I

J

K

L

M

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-745, "Diagnostic Procedure"](#) .

DTC P0227, P0228 APP SENSOR



[QG (WITHOUT EURO-OBD)]

EBS00EW2

Wiring Diagram

EC-APPS1-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



MBWA0140E

DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00EW3

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 82 and APP sensor terminal 4. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

6. CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-747, "Component Inspection"](#).

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#).
3. Perform [EC-589, "Throttle Valve Closed Position Learning"](#).
4. Perform [EC-589, "Idle Air Volume Learning"](#).

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00EW4

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.195V



DTC P0227, P0228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-589, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00EW5

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .


DTC P0327, P0328 KS

PFP:22060

Component Description

EBS00EW6

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



EBS00EW7

On Board Diagnosis Logic

The MI will not light for knock sensor malfunction.

DTC No.	Trouble Diagnosis Name	DTC Detected Condition	Possible Cause
P0327 0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328 0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00EW8

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-751, "Diagnostic Procedure"](#)





WITHOUT CONSULT-II

1. Start engine and run it for at least 5 seconds at idle speed.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-751, "Diagnostic Procedure"](#).

Wiring Diagram

EBS00EW9

EC-KS-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V
54	—	Knock sensor shield circuit ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00EWA

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 15 and engine ground. Refer to Wiring Diagram.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance: Approximately 530 - 590kΩ [at 20°C (68°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-II


1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 15 and knock sensor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK KNOCK SENSOR**

Refer to [EC-752, "Component Inspection"](#).


OK or NG

- OK >> GO TO 5.
NG >> Replace knock sensor.

4. RETIGHTEN GROUND SCREWS

Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection KNOCK SENSOR

EBS00EWB

Check resistance between knock sensor terminal 1 and ground.


NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

Resistance: Approximately 530 - 590k Ω [at 20°C (68°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



EBS00EWC

Removal and Installation KNOCK SENSOR

Refer to [EM-70, "CYLINDER BLOCK"](#) .

DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

DTC P0335 CKP SENSOR (POS)

PF0:23731

Component Description

EBS00EWD

The crankshaft position sensor (POS) is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.


The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EWE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

EBS00EWF

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Crankshaft position sensor (POS) Signal plate

DTC Confirmation Procedure

EBS00EWG

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

WITH CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-756, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

⊗ WITHOUT CONSULT-II

1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-756, "Diagnostic Procedure"](#) .





DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EWH

EC-POS-01



MBWA0064E



DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	W	Crankshaft position sensor (POS)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 3V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 3V★</p> 
30	B	Crankshaft position sensor (POS) ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00EWI

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

2. CHECK CKP SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CKP sensor (POS) terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 30 and CKP sensor (POS) terminal 1
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for and short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

5. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-758, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace crankshaft position sensor (POS).

7. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 8.

NG >> Replace the signal plate.

8. CHECK INTERMITTENT INCIDENT


Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection CRANKSHAFT POSITION SENSOR (POS)

EBS00EWJ

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




DTC P0335 CKP SENSOR (POS)

[QG (WITHOUT EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	

6. If NG, replace crankshaft position sensor (POS).



EBS00EWK

Removal and Installation CRANKSHAFT POSITION SENSOR (POS)

Refer to [EM-70, "CYLINDER BLOCK"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0340 CMP SENSOR (PHASE) [QG (WITHOUT EURO-OBD)]

DTC P0340 CMP SENSOR (PHASE)

PFP:23731

Component Description

EBS00EWL

The camshaft position sensor (PHASE) senses the retraction with intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.


When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



On Board Diagnosis Logic

EBS00EWM

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> ● The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. ● The cylinder No. signal is not set to ECM during engine running. ● The cylinder No. signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Camshaft position sensor (PHASE) ● Camshaft (Intake) ● Starter motor (Refer to SC-22 .) ● Starting system circuit (Refer to SC-22 .) ● Dead (Weak) battery

DTC Confirmation Procedure

EBS00EWN

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

④ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
4. If 1st trip DTC is detected, go to [EC-763, "Diagnostic Procedure"](#).
If 1st trip DTC is not detected, go to next step.
5. Maintain engine speed at more than 800 rpm for at least 5 seconds.
6. If 1st trip DTC is detected, go to [EC-763, "Diagnostic Procedure"](#).



⊗ WITHOUT CONSULT-II

1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-763, "Diagnostic Procedure"](#).
If 1st trip DTC is not detected, go to next step.
5. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0340 CMP SENSOR (PHASE)

[QG (WITHOUT EURO-OBD)]

6. Start engine and maintain engine speed at more than 800 rpm for at least 5 seconds.
7. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
8. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
9. If 1st trip DTC is detected, go to [EC-763, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M





DTC P0340 CMP SENSOR (PHASE)

[QG (WITHOUT EURO-OBD)]

EBS00EWO

EC-PHASE-01

Wiring Diagram





MBWA0065E

DTC P0340 CMP SENSOR (PHASE) [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	R	Camshaft position sensor (PHASE)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1.0 - 4.0V★  PBIB0525E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	1.0 - 4.0V★  PBIB0526E
29	B	Camshaft position sensor (PHASE) ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00EWP

1. CHECK STARTING SYSTEM

Turn ignition switch to "START" position.

Does the engine turn over?

Does the starter motor operate?

Yes or No


Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-22. "STARTING SYSTEM"](#) .)

2. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 3.




DTC P0340 CMP SENSOR (PHASE)

[QG (WITHOUT EURO-OBD)]

3. CHECK CMP SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CMP sensor (PHASE) terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 29 and CMP sensor (PHASE) terminal 1.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 14 and CMP sensor (PHASE) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground or short to power.

OK or NG

- OK >> GO TO 7.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0340 CMP SENSOR (PHASE) [QG (WITHOUT EURO-OBD)]

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-765, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace camshaft position sensor (PHASE).


8. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 9.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



9. CHECK INTERMITTENT INCIDENT


Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection CAMSHAFT POSITION SENSOR (PHASE)


EBS00EWQ

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	



DTC P0340 CMP SENSOR (PHASE)

[QG (WITHOUT EURO-OBD)]

Removal and Installation CAMSHAFT POSITION SENSOR (PHASE)

EBS00EWR

Refer to [EM-36, "CAMSHAFT"](#) .


DTC P0605 ECM

PF:23710

Component Description

EBS00EWX

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



EBS00EWY

On Board Diagnosis Logic

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

FAIL-SAFE MODE

ECM enters fail-safe mode when malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EWZ

Perform "PROCEDURE FOR MALFUNCTION A" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-769, "Diagnostic Procedure"](#)



SEF058Y

Without CONSULT-II

1. Turn ignition switch "ON".
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-769, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION B

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. If 1st trip DTC is detected, go to [EC-769, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-769, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. Repeat step 3 procedure, 32 times.
5. If 1st trip DTC is detected, go to [EC-769, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Repeat step 2 procedure, 32 times.
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If 1st trip DTC is detected, go to [EC-769, "Diagnostic Procedure"](#).

Diagnostic Procedure

1. INSPECTION START

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-767](#) .
5. Is the 1st trip DTC P0605 displayed again?

Without CONSULT-II

1. Turn ignition switch "ON".
2. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .
3. **Perform "DTC Confirmation Procedure".**
See [EC-767](#) .
4. Is the 1st trip DTC P0605 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-595, "NATS \(Nissan Anti-theft System\)"](#) .
3. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1065 ECM POWER SUPPLY

[QG (WITHOUT EURO-OBD)]


DTC P1065 ECM POWER SUPPLY

PFP:23710

Component Description

EBS00EX1

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



On Board Diagnosis Logic

EBS00EX2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back up RAM system does not function properly.	<ul style="list-style-type: none">● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.]● ECM

DTC Confirmation Procedure


EBS00EX3

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. Repeat steps 3 and 4 four times.
6. If 1st trip DTC is detected, go to [EC-772, "Diagnostic Procedure"](#).

A screenshot of a diagnostic tool's data monitor screen. The screen is titled 'DATA MONITOR' and has two columns: 'MONITOR' and 'NO DTC'. Under 'MONITOR', it shows 'ENG SPEED' with a value of 'XXX rpm'. The 'NO DTC' column is empty. The label 'SEF058Y' is at the bottom right.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

⊗ WITHOUT CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Start engine and let it idle for 1 second.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Repeat steps 2 and 3 four times.
5. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
6. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
7. If 1st trip DTC is detected, go to [EC-772, "Diagnostic Procedure"](#).




DTC P1065 ECM POWER SUPPLY [QG (WITHOUT EURO-OBD)]

EBS00EX4

Wiring Diagram

EC-ECM/PW-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0094E

DTC P1065 ECM POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EX5


1. CHECK ECM POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- Harness for open or short between ECM and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1065 ECM POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

4. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-770](#) .
5. Is the 1st trip DTC P1065 displayed again?

Without CONSULT-II

1. Turn ignition switch "ON".
2. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-594, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .
3. **Perform "DTC Confirmation Procedure"**.
See [EC-770](#) .
4. Is the 1st trip DTC P1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

5. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-595, "NATS \(Nissan Anti-theft System\)"](#) .
3. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
4. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> **INSPECTION END**


DTC P1102 MAF SENSOR

PFP:22680

Component Description

EBS00H74

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H75

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.0 - 1.7V
	2,500 rpm	Approx. 1.5 - 2.1V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	1.0 - 4.0 g-m/s
	2,500 rpm	5.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00H76

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1102 1102	Mass air flow sensor circuit range/performance problem	A voltage from the sensor is constantly approx.1.0V when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00H77

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1102 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-777, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

⊗ WITHOUT CONSULT-II

1. Start engine and wait 5 seconds at most.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-777, "Diagnostic Procedure"](#) .





DTC P1102 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

EBS00H78

EC-MAFS-01

Wiring Diagram



MBWA0045E

DTC P1102 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor power supply (Mass air flow sensor)	[Ignition switch "ON"]	Approximately 5V
50	Y	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.0 - 1.7V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.5 - 2.1V
67	B	Sensor ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00H79

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1102 MAF SENSOR

[QG (WITHOUT EURO-OBD)]

2. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 67 and MAF sensor terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 50 and MAF sensor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-779, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace mass air flow sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
MASS AIR FLOW SENSOR**


EBS00H7A

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.0 - 1.7
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.5 - 2.1
Idle to about 4,000 rpm*	1.0 - 1.7 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.



**Removal and Installation
MASS AIR FLOW SENSOR**

EBS00H7B

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QG (WITHOUT EURO-OBDD)]

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PF1:16119

Component Description

EBS00EX6

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00EX7

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open. This self-diagnosis has the one trip detection logic.	

FAIL-SAFE MODE

When the malfunction A or B is detected in the two consecutive trips, the ECM enters in fail-safe mode and MI lights up.

When the malfunction C is detected even in the 1st trip, the ECM enters in fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.

DTC Confirmation Procedure

EBS00EX8

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A AND B" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION C".
If there is no problem on "PROCEDURE FOR MALFUNCTION A AND B", perform "PROCEDURE FOR MALFUNCTION C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A AND B

① With CONSULT-II

1. Turn ignition witch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. If 1st trip DTC is detected, go to [EC-781, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

[QG (WITHOUT EURO-OBD)]


⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If 1st trip DTC is detected, go to [EC-781, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION C

Ⓟ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
4. Shift selector lever to "N" or "P" position.
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#).



⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Shift selector lever to "D" position (A/T), "1st" position (M/T) and wait at least 2 seconds.
3. Shift selector lever to "N" or "P" position.
4. Start engine and let it idle for the 3 seconds.
5. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
6. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
7. If DTC is detected, go to [EC-781, "Diagnostic Procedure"](#).

Diagnostic Procedure


EBS00EX9

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if a foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 2.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#).
3. Perform [EC-589, "Idle Air Volume Learning"](#).

>> INSPECTION END

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR
[QG (WITHOUT EURO-OBD)]

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00HBZ

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PF16119

Description

EBS00EXA

NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-780](#) or [EC-790](#).

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00EXB

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is open or shorted.) ● Harness or connectors (Throttle control motor relay circuit is open or shorted.) ● Electric throttle control actuator ● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EXC

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-785, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

ⓧ WITHOUT CONSULT-II




1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-785, "Diagnostic Procedure"](#).

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]

EBS00EXD

EC-ETC1-01

Wiring Diagram





MBWA0143E

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00EXE

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBID)]


2. CHECK THROTTLE CONTROL MOTOR RELAY SIGNAL CIRCUIT

Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)


OK or NG

- OK >> GO TO 10.
- NG >> GO TO 3.



3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]

5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-789, "Component Inspection"](#).

OK or NG


- OK >> GO TO 13.
- NG >> Replace throttle control motor relay.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]

10. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.


11. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 12.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



12. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-789, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> GO TO 14.

13. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> GO TO 14.

NG >> Repair or replace harness or connectors.

14. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QG (WITHOUT EURO-OBD)]


EBS00EXF

Component Inspection THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.




THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-589, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EXG

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBD)]

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PFP:16119

Component Description

EBS00EXH

Power supply for the Throttle Control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

CONSULT-II Reference Value in Data Monitor Mode

EBS00EXI

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

On Board Diagnosis Logic

EBS00EXJ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detect the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is shorted.) ● Throttle control motor relay
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low. This self-diagnosis has the one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is open.) ● Throttle control motor relay

FAIL-SAFE MODE

When the DTC P1124 is detected in the two consecutive trips, the ECM enters fail-safe mode and the MI lights up.

When the DTC P1126 is detected even in the 1st trip, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EXK

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR DTC P1124

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-793, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBD)]

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. If 1st trip DTC is detected, go to [EC-793, "Diagnostic Procedure"](#) .

PROCEDURE FOR DTC P1126

Ⓜ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-793, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II




1. Turn ignition switch "ON" and wait at least 2 second.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-793, "Diagnostic Procedure"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBD)]

EBS00EXL

EC-ETC2-01

Wiring Diagram



MBWA0144E

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBID)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V
3	R	Throttle control motor power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EXM

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBD)]

3. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-794, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace throttle control motor relay.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection THROTTLE CONTROL MOTOR RELAY


1. Apply 12V direct current between relay terminals 1 and 2.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QG (WITHOUT EURO-OBD)]

2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P1128 THROTTLE CONTROL MOTOR

[QG (WITHOUT EURO-OBD)]

DTC P1128 THROTTLE CONTROL MOTOR

PF16119

Component Description

EBS00EXN

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00EXO

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short both circuits between ECM and throttle control motor.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is shorted.) ● Electric throttle control actuator (Throttle control motor)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EXP

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-798, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II


1. Turn ignition switch "ON" and wait at least 2 second.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-798, "Diagnostic Procedure"](#).

DTC P1128 THROTTLE CONTROL MOTOR [QG (WITHOUT EURO-OBD)]



Wiring Diagram

EC-ETC3-01

EBS00EXO



A
EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M





MBWA0145E

DTC P1128 THROTTLE CONTROL MOTOR [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	BR	Throttle control motor (Close)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	<p>0 - 14V★</p>  <p>PBIB0534E</p>
5	Y	Throttle control motor (Open)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (A/T model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	<p>0 - 14V★</p>  <p>PBIB0533E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00EXR

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1128 THROTTLE CONTROL MOTOR [QG (WITHOUT EURO-OBD)]

2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to ground or short to power in harness connectors.

3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-799, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 5.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 5.
 NG >> Repair or replace harness or connectors.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END


Component Inspection THROTTLE CONTROL MOTOR

EBS00EXS

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-589, "Idle Air Volume Learning"](#) .



DTC P1128 THROTTLE CONTROL MOTOR
[QG (WITHOUT EURO-OBD)]

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EXT

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]

DTC P1217 ENGINE OVER TEMPERATURE

PFP:00000

System Description

EBS00EXU

NOTE:

If DTC P1217 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-663, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

COOLING FAN CONTROL

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* ¹	Cooling fan control	Cooling fan relay
Battery	Battery voltage* ¹		
Vehicle speed signal	Vehicle speed* ²		
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal* ²		
Refrigerant pressure sensor	Refrigerant pressure		


*1: The ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: These signals are sent to the ECM through CAN communication line.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 2-step control [ON/OFF].

The ECM sends a cooling fan control signal to the smart entrance control unit through CAN communication line, and the smart entrance control unit controls cooling fan relay.

OPERATION



CONSULT-II Reference Value in Data Monitor Mode

EBS00EXV

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine Air conditioner switch: OFF	OFF
	Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	● Engine: After warming up, idle the engine Engine coolant temperature is 99°C (210°F) or less	OFF
	● Air conditioner switch: OFF Engine coolant temperature is 100°C (212°F) or more	ON

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]

On Board Diagnosis Logic

EBS00EXW

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none">● Cooling fan does not operate properly (Overheat).● Cooling fan system does not operate properly (Overheat).● Engine coolant was not added to the system using the proper filling method.	<ul style="list-style-type: none">● Harness or connectors (The cooling fan circuit is open or shorted.)● Harness or connectors (The CAN communication line is open or shorted.)● Cooling fan● Radiator hose● Radiator● Radiator cap● Water pump● Thermostat <p>For more information, refer to EC-809, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [CO-8](#), "[Changing Engine Coolant](#)". Also, replace the engine oil. Refer to [LU-7](#), "[Changing Engine Oil](#)".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-18](#), "[Engine Coolant Mixture Ratio](#)".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

EBS00EXX

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

Ⓜ WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-805](#), "[Diagnostic Procedure](#)".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-805](#), "[Diagnostic Procedure](#)".
3. Turn ignition switch "ON".



DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]



4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-805, "Diagnostic Procedure"](#).

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E

⊗ WITHOUT CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
 If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-805, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-805, "Diagnostic Procedure"](#).
3. Start engine and let it idle.
Be careful not to overheat engine.
4. Turn air conditioner switch "ON".
5. Turn blower fan switch "ON".
6. Make sure that cooling fans operate.
 If NG, go to [EC-805, "Diagnostic Procedure"](#).





DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]


EBS00EXY

Wiring Diagram

EC-COOL/F-01



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK JUNCTION BOX (J/B)



DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]

Diagnostic Procedure

EBS00EXZ

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK COOLING FAN OPERATION

① With CONSULT-II

1. Start engine and let it idle.
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II and touch "ON" on the CONSULT-II screen.
3. Make sure that cooling fans-1 and -2 operate.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-807, "PROCEDURE A"](#).)

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E


3. CHECK COOLING FAN OPERATION

⊗ Without CONSULT-II

1. Start engine and let it idle.
2. Turn air conditioner switch "ON".
3. Turn blower fan switch "ON".
4. Make sure that cooling fans-1 and -2 operate.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan control circuit. (Go to [EC-807, "PROCEDURE A"](#).)



DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]

4. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 157 kPa (1.6 kg/cm² , 23 psi)

CAUTION:


Higher than the specified pressure may cause radiator damage. Pressure should not drop.

OK or NG

OK >> GO TO 5.

NG >> Check the following for leak

- Hose
 - Radiator
 - Water pump
- Refer to [CO-18, "WATER PUMP"](#) .



5. CHECK RADIATOR CAP


Apply pressure to cap with a tester.

**Radiator cap relief pressure: 59 - 98 kPa
(0.6 - 1.0 kg/cm² , 9 - 14 psi)**

OK or NG

OK >> GO TO 6.

NG >> Replace radiator cap.



6. CHECK THERMOSTAT

1. Check valve seating condition at normal room temperatures.
It should seat tightly.
2. Check valve opening temperature and valve lift.

Valve opening temperature: 82°C (180°F) [standard]

**Valve lift: More than 8 mm/95°C
(0.31 in/203°F)**


3. Check if valve is closed at 5°C (9°F) below valve opening temperature.

For details, refer to [CO-20, "THERMOSTAT AND THERMOSTAT HOUSING"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace thermostat



7. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-676, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace engine coolant temperature sensor.

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBD)]

8. CHECK MAIN 12 CAUSES


If the cause cannot be isolated, go to [EC-809, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END

PROCEDURE A

1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-1 terminals 1, 3, 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 30A fusible links
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1217 ENGINE OVER TEMPERATURE

[QG (WITHOUT EURO-OBID)]

3. CHECK COOLING FAN MOTORS CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Check harness continuity between cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1, cooling fan motor-1 terminal 2 and body ground.
Refer to wiring diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.
5. Check harness continuity between cooling fan relay-1 terminal 7 and cooling fan motor-2 terminal 1, cooling fan motor-2 terminal 2 and body ground.
Refer to wiring diagram.

Continuity should exist.

6. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit.
2. Check harness continuity between smart entrance control unit terminal 33 and cooling fan relay-1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between smart entrance control unit and cooling fan relay-1

>> Repair open circuit or short to ground or short to power in harness or connectors.



6. CHECK COOLING FAN RELAY-1

Refer to [EC-810, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan relay.



DTC P1217 ENGINE OVER TEMPERATURE [QG (WITHOUT EURO-OBDD)]

7. CHECK COOLING FAN MOTORS

Refer to [EC-810, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace cooling fan motors.

8. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-3, "SMART ENTRANCE CONTROL SYSTEM"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace cooling fan motors.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Main 12 Causes of Overheating

EBS00EY0

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-18, "Engine Coolant Mixture Ratio" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See MA-20, "Changing Engine Coolant" .
	4	● Radiator cap	● Pressure tester	59 - 98 kPa (0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See MA-22, "CHECKING RADIATOR CAP" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See MA-23, "CHECKING COOLING SYSTEM FOR LEAKS" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-20, "THERMOSTAT AND THERMOSTAT HOUSING" , and CO-11, "RADIATOR" .
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 (EC-801) .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-20, "Changing Engine Coolant" .
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-8, "LEVEL CHECK" .

DTC P1217 ENGINE OVER TEMPERATURE [QG (WITHOUT EURO-OBD)]

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-57, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-57, "CYLINDER HEAD" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to [CO-5, "OVERHEATING CAUSE ANALYSIS"](#) .


Component Inspection COOLING FAN RELAY-1

EBS00EY1

- Apply 12V direct current between relay terminals 1 and 2.
- Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

- If NG, replace cooling fan relay.




COOLING FAN MOTORS-1 AND -2

- Disconnect cooling fan motor harness connectors.
- Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(+)	(-)
Cooling fan motor	1	2

Cooling fan motor should operate.
If NG, replace cooling fan motor.



DTC P1223, P1224 TP SENSOR

[QG (WITHOUT EURO-OBD)]

DTC P1223, P1224 TP SENSOR


PF16119

Component Description

EBS00EY2

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EY3

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (A/T model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00EY4

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1223 1223	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 2)
P1224 1224	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EY5

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1223, P1224 TP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-814, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-816, "Component Inspection"](#) .

DTC P1223, P1224 TP SENSOR




[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EY6

EC-TPS2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0137E

DTC P1223, P1224 TP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"]	More than 0.36V
			[Ignition switch "ON"]	Less than 4.75V
66	B	Throttle position sensor ground	[Engine is running]	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"]	Less than 4.75V
			[Ignition switch "ON"]	More than 0.36V


Diagnostic Procedure

EBS00EY7

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1223, P1224 TP SENSOR

[QG (WITHOUT EURO-OBD)]

2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-816, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

DTC P1223, P1224 TP SENSOR

[QG (WITHOUT EURO-OBD)]

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00EY8

1. Reconnect all harness connectors disconnected.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (A/T models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-589, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00EY9

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1225 TP SENSOR


PFP:16119

Component Description

EBS00EYA

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00EYB

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00EYC

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 10 seconds.
- Turn ignition switch "ON".
- If 1st trip DTC is detected, go to [EC-818, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITHOUT CONSULT-II

- Turn ignition switch "ON".
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to [EC-818, "Diagnostic Procedure"](#) .

Diagnostic Procedure

EBS00EYD


1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00EYE

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1226 TP SENSOR


PF16119

Component Description

EBS00EYF

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00EYG

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance problem	Closed throttle position learning is not performed successfully, repeatedly.	● Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00EYH

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. Repeat steps 3 and 4, 32 times.
6. If 1st trip DTC is detected, go to [EC-820, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITHOUT CONSULT-II

1. Turn ignition switch "ON".
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Repeat step 2, 32 times.
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If 1st trip DTC is detected, go to [EC-820, "Diagnostic Procedure"](#).

Diagnostic Procedure


EBS00EYI

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 2.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00EYJ

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

DTC P1227, P1228 APP SENSOR

PFP:18002


Component Description

EBS00EYK

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EYL

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00EYM

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1227 1227	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P1228 1228	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00EYN

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-824, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-824, "Diagnostic Procedure"](#).

DTC P1227, P1228 APP SENSOR


[QG (WITHOUT EURO-OBD)]

Wiring Diagram


EBS00EYO

EC-APPS2-01

ACCELERATOR
PEDAL
POSITION SENSOR
(M47)



6 5 4 3 2 1 (M47)



(F102) H.S.

1 2 3 4 5 6 7 8 9 10 11 (F109) W

DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor ground (Accelerator pedal position sensor 1)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
83	B	Sensor ground (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 0V
90	R	Sensor power supply (Accelerator pedal position sensor 1)	[Ignition switch "ON"]	Approximately 5V
91	G	Sensor power supply (Accelerator pedal position sensor 2)	[Ignition switch "ON"]	Approximately 5V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00EYP

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 83 and APP sensor terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

6. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-826, "Component Inspection"](#).

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#).
3. Perform [EC-589, "Throttle Valve Closed Position Learning"](#).
4. Perform [EC-589, "Idle Air Volume Learning"](#).

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00EYQ

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.195V



DTC P1227, P1228 APP SENSOR

[QG (WITHOUT EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-589, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-589, "Idle Air Volume Learning"](#) .

A

EC

EBS00EYR

Remove and Installation ACCELERATOR PEDAL

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

C

D

E

F

G

H

I

J

K

L

M

DTC P1229 SENSOR POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

DTC P1229 SENSOR POWER SUPPLY

PF16119

On Board Diagnosis Logic

EBS00EYS

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none">● Harness or connectors (The TP sensor 1 and 2 circuit is shorted.)● Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00EYT

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

④ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-830, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-830, "Diagnostic Procedure"](#).




DTC P1229 SENSOR POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EYU

EC-SEN/PW-01



MBWA0139E

DTC P1229 SENSOR POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00EYV

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



DTC P1229 SENSOR POWER SUPPLY

[QG (WITHOUT EURO-OBD)]

3. CHECK SENSOR POWER SUPPLY CIRCUITS FOR SHORT

Check the following.

- Harness for short to power and short to ground between ECM terminal 47 and electric throttle control actuator terminal 1.
- ECM pin terminal.

OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR

Refer to [EC-728, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-589, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-589, "Idle Air Volume Learning"](#) .

>> INSPECTION END

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1805 BRAKE SWITCH

[QG (WITHOUT EURO-OBD)]

DTC P1805 BRAKE SWITCH

PFP:25320

Description

EBS00EYW

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

CONSULT-II Reference Value in Data Monitor Mode

EBS00EYX

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON

On Board Diagnosis Logic

EBS00EYY

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for an extremely long time while the vehicle is driving.	<ul style="list-style-type: none">● Harness or connectors (Stop lamp switch circuit is open or shorted.)● Stop lamp switch

DTC Confirmation Procedure

EBS00EYZ

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to [EC-834, "Diagnostic Procedure"](#)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITHOUT CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal at least 5 seconds.
3. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-594](#).
4. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
5. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
6. If 1st trip DTC is detected, go to [EC-834, "Diagnostic Procedure"](#).


DTC P1805 BRAKE SWITCH

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EZ0


EC-BRK/SW-01



REFER TO PG-POWER.

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.

M2 - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P1805 BRAKE SWITCH

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00EZ1

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch "OFF".
2. Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Depressed	Illuminated

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch harness connector.




2. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



DTC P1805 BRAKE SWITCH

[QG (WITHOUT EURO-OBD)]

3. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Fuse block (J/B) connector M2
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect stop lamp switch harness connector.
4. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to [EC-836, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace stop lamp switch.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


DTC P1805 BRAKE SWITCH

[QG (WITHOUT EURO-OBD)]

EBS00E22

Component Inspection STOP LAMP SWITCH


1. Disconnect stop lamp switch harness connector.



2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.

If NG, adjust brake pedal installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 2 again.



HO2S1 HEATER (QG16DE)

[QG (WITHOUT EURO-OBD)]

HO2S1 HEATER (QG16DE)

PFP:22690

Description SYSTEM DESCRIPTION

EBS00FV4

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FV5

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine: After warming up ● Engine speed: Below 3,600 rpm	ON
	● Engine speed: Above 3,600 rpm	OFF




HO2S1 HEATER (QG16DE)

[QG (WITHOUT EURO-OBID)]

Wiring Diagram

EBS00FV7

EC-FRO2-01



REFER TO THE FOLLOWING.
E105 - FUSE BLOCK-JUNCTION
BOX (J/B)

MBWA0071E

HO2S1 HEATER (QG16DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	Heated oxygen sensor 1 heater	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,600 rpm. 	<p>Approximately 7.0V★</p> <p>PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped. <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	<p>BATTERY VOLTAGE (11 - 14V)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure


EBS00FV8

1. CHECK OVERALL FUNCTION CHECK

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Set the tester probe between ECM terminal 24 (HO2S1 heater signal) and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.
Verify that the oscilloscope screen shows the signal wave as shown below.

Conditions	Voltage
At idle	<p>Approximately 7.0V★</p> <p>PBIB0519E</p>
Engine speed is above 3,600 rpm	<p>BATTERY VOLTAGE (11 - 14V)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)



OK or NG


- OK >> INSPECTION END.
- NG >> GO TO 2.

HO2S1 HEATER (QG16DE)

[QG (WITHOUT EURO-OBID)]

2. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 24 and HO2S1 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-841, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 1 HEATER

EBS00FV9


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	8 - 10 Ω at 20°C (68°F)
2 and 3, 4	∞ Ω
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



EBS00FVA

Removal and Installation
HEATED OXYGEN SENSOR 1

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

HO2S1 HEATER (QG18DE)

[QG (WITHOUT EURO-OBID)]

HO2S1 HEATER (QG18DE)

PFP:22690

Description SYSTEM DESCRIPTION

EBS00FVB

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,200 (A/T models) Above 3,600 (M/T models)	OFF
Below 3,200 (A/T models) Below 3,600 (M/T models)	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FVC

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1) HO2S1 HTR (B2)	<ul style="list-style-type: none">● Engine: After warming up● Engine speed: Below 3,200 rpm (A/T models) Below 3,600 rpm (M/T models)	ON
	<ul style="list-style-type: none">● Engine speed: Above 3,200 rpm (A/T models) Above 3,600 rpm (M/T models)	OFF



HO2S1 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram BANK 1

EBS00FVE

EC-FRO2B1-01



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)


HO2S1 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	G	Heated oxygen sensor 1 heater (bank 1)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,200 rpm (A/T models). ● Engine speed is below 3,600 rpm (M/T models). 	<p>Approximately 7.0V★</p> 
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped. <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (A/T models). ● Engine speed is above 3,600 rpm (M/T models). 	<p>BATTERY VOLTAGE (11 - 14V)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


HO2S1 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2



EC-FRO2B2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO PG-POWER.

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0078E


HO2S1 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
25	R/B	Heated oxygen sensor 1 heater (bank 2)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,200 rpm (A/T models). ● Engine speed is below 3,600 rpm (M/T models). 	<p>Approximately 7.0V★</p>  <p>PBIB0519E</p>
			<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Engine stopped. <p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,200 rpm (A/T models). ● Engine speed is above 3,600 rpm (M/T models). 	<p>BATTERY VOLTAGE (11 - 14V)</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00FVF

1. CHECK OVERALL FUNCTION CHECK


1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Set the tester probe between ECM terminal 24 [HO2S1 (B1) heater signal] or 25 [HO2S1 (B2) heater signal] and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.
Verify that the oscilloscope screen shows the signal wave as shown below.

Conditions	Voltage
At idle	<p>Approximately 7.0V★</p>  <p>PBIB0519E</p>
Engine speed is above 3,600 rpm	<p>BATTERY VOLTAGE (11 - 14V)</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.



2. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 24, 25 and HO2S1 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-848, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
 NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1 HEATER

EBS00FVG


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	8 - 10 Ω at 20°C (68°F)
2 and 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FVH

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#) .

HO2S2 HEATER (QG16DE)

[QG (WITHOUT EURO-OBD)]

HO2S2 HEATER (QG16DE)

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00FVJ

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FVJ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1)	● Engine speed: Below 3,600 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON
	● Engine speed: Above 3,600 rpm	OFF




HO2S2 HEATER (QG16DE)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00FVL

EC-RRO2-01



REFER TO THE FOLLOWING.

(E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0073E

HO2S2 HEATER (QG16DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/B	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> Engine speed is below 3,600 rpm. After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Engine stopped [Engine is running] <ul style="list-style-type: none"> Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00FVM


1. CHECK OVERALL FUNCTION CHECK

1. Start engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set the voltmeter probe between ECM terminal 2 (HO2S2 heater signal) and ground.
4. Check the voltage under the following conditions.

Conditions	Voltage
At idle	0 - 1V
Engine speed is above 3,600 rpm	Battery voltage

OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.




HO2S2 HEATER (QG16DE)

[QG (WITHOUT EURO-OBID)]

2. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 and HO2S2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-853, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.
NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 2 HEATER

EBS00FVN


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



PBIB0542E

EBS00FVO

Removal and Installation
HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

HO2S2 HEATER (QG18DE)

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00FVP

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heaters
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heaters corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heaters
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00FVQ

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1) HO2S2 HTR (B2)	<ul style="list-style-type: none">● Ignition switch: ON (Engine stopped)● Engine is running above 3,600 rpm.	OFF
	<ul style="list-style-type: none">● Engine is running below 3,600 rpm after driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.	ON




HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Wiring Diagram BANK 1

EBS00FVR

EC-RRO2B1-01



REFER TO THE FOLLOWING.
 E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0080E

HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	L	Heated oxygen sensor 2 heater (bank 1)	[Engine is running] <ul style="list-style-type: none">● Engine speed is below 3,600 rpm.● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more.	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none">● Engine stopped [Engine is running] <ul style="list-style-type: none">● Engine speed is above 3,600 rpm.	BATTERY VOLTAGE (11 - 14V)

HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2

EC-RRO2B1-01



REFER TO THE FOLLOWING.
E105 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0082E

HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and body ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
7	W/R	Heated oxygen sensor 2 heater (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,600 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00FVS


1. CHECK OVERALL FUNCTION

1. Start engine and drive the vehicle at 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set voltmeter probes between ECM terminal 2 [HO2S2(B1) heater signal] or 7 [HO2S2(B2) heater signal] and ground.
4. Check the voltage under the following conditions.

Conditions	voltage
At idle	0 - 1V
Engine speed is above 3,600 rpm.	Battery voltage

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.




HO2S2 HEATER (QG18DE)

[QG (WITHOUT EURO-OBD)]

2. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E105
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 and HO2S2 (B1) terminal 1, ECM terminal 7 and HO2S2 (B2) terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-860, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace malfunctioning heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2 HEATER

EBS00FVT


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
2 and 3	2.3 - 4.3 Ω at 25°C (77°F)
1 and 2, 3, 4	$\infty \Omega$
4 and 1, 2, 3	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



EBS00FVU

Removal and Installation HEATED OXYGEN SENSOR 2


Refer to [EX-3, "EXHAUST SYSTEM"](#) .

IAT SENSOR

Component Description

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.




<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 34 (Intake air temperature sensor) and body ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.






IAT SENSOR

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EZ4

EC-IATSEN-01



MBWA0070E

Diagnostic Procedure


1. CHECK OVERALL FUNCTION

1. Turn ignition switch "ON".
2. Check voltage between ECM terminal 34 and ground with CONSULT-II or tester.

Voltage: 0.04 - 4.84V


OK or NG

- OK >> **INSPECTION END.**
 NG >> GO TO 2.



2. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
3. Turn ignition switch "ON".




4. Check voltage between MAF sensor terminal 5 and ground.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 67 and mass air flow sensor terminal 3. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-864, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END



Component Inspection INTAKE AIR TEMPERATURE SENSOR

EBS00EZ6

1. Check resistance between intake air temperature sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



Removal and Installation MASS AIR FLOW SENSOR

EBS00EZ7

Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .



HO2S1 (QG16DE)

PFP:22690

Component Description

EBS00FVV

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.






CONSULT-II Reference Value in Data Monitor Mode

EBS00FVV

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

Wiring Diagram



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

Diagnostic Procedure

EBS00FVZ

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Select "HO2S1 MNTR (B1)" in "DATA MONITOR" mode with CONSULT-II.
- Keep the engine speed at 2,000 rpm under no load, and make sure that the monitors fluctuate between LEAN and RICH more than five times in 10 seconds.

- 1 time: RICH → LEAN → RICH
- 2 times: RICH → LEAN → RICH → LEAN → RICH

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

3. CHECK OVERALL FUNCTION


Without CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
- Keep the engine speed at 2,000 rpm under no load, and make sure that the voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times in 10 seconds.

- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
- 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG


- OK >> **INSPECTION END**
- NG >> GO TO 4.



4. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 5.




5. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30

>> GO TO 6.




6. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (Manifold).

OK or NG

- OK >> GO TO 7.
 NG >> Repair or replace.



7. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.

8. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect HO2S1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**9. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground. Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-841, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace malfunctioning heated oxygen sensor 1.

11. CHECK MASS AIR FLOW SENSOR

Refer to [EC-671, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace mass air flow sensor.

12. CHECK PCV VALVE

Refer to [EC-955, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace PCV valve.

13. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-870, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FW0

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5	
HO2S1 MNTR (B1)	R	L	R	L	R	L

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.


- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00FW1

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).



HO2S1 (QG18DE)

PFP:22690

Component Description

EBS00FW2

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00FW3



Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1) HO2S1 (B2)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1) HO2S1 MNTR (B2)			LEAN ↔ RICH Changes more than 5 times during 10 seconds.

Wiring Diagram
BANK 1

EBS00FW4

EC-FRO2B1-01



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	W	Heated oxygen sensor 1 (bank 1)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none">● Idle speed	Approximately 0V


HO2S1 (QG18DE)

[QG (WITHOUT EURO-OBD)]

BANK 2



EC-FRO2B2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO PG-POWER.

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0078E

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
36	W	Heated oxygen sensor 1 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

Diagnostic Procedure

EBS00FW5

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

With CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Select "HO2S1 MNTR (B1)" and "HO2S1 MNTR (B2)" in "DATA MONITOR" mode with CONSULT-II.
- Keep the engine speed at 2,000 rpm under no load, and make sure that the monitors fluctuate between LEAN and RICH more than five times in 10 seconds.

- 1 time: RICH → LEAN → RICH
- 2 times: RICH → LEAN → RICH → LEAN → RICH

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

3. CHECK OVERALL FUNCTION


Without CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Set voltmeter probes between ECM terminal 35 [HO2S1(B1) signal] or 36 [HO2S1(B2) signal] and engine ground.
- Keep the engine speed at 2,000 rpm under no load, and make sure that the voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than five times in 10 seconds.

- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
- 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

OK or NG


- OK >> **INSPECTION END**
- NG >> GO TO 4.



4. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 5.




5. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 60 N·m (4.1 - 6.2 kg·m, 30

>> GO TO 6.




6. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (Manifold).

OK or NG

- OK >> GO TO 7.
 NG >> Repair or replace.



7. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 8.
 NG >> Repair or replace.

8. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect HO2S1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



9. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 (B1) terminal 2, ECM terminal 36 and HO2S1 (B2) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminals 35, 36 or HO2S1 terminal 2 and ground. Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-848, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace malfunctioning heated oxygen sensor 1.

11. CHECK MASS AIR FLOW SENSOR

Refer to [EC-671, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace mass air flow sensor.

12. CHECK PCV VALVE

Refer to [EC-955, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace PCV valve.

13. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-879, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 14.
- NG >> Replace malfunctioning heated oxygen sensor 1.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00FW6

ⓑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)/(B2)" and "HO2S1 MNTR (B1)/(B2)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)/(B2)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)/(B2)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)/(B2)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)/(B2)" voltage never exceeds 1.0V.

Bank 1	cycle	1	2	3	4	5	
	HO2S1 MNTR (B1)	R	-L	-R	-L	-R	-L
Bank 2	cycle	1	2	3	4	5	
	HO2S1 MNTR (B2)	R	-L	-R	-L	-R	-L

R means HO2S1
MNTR (B1)/(B2) indicates RICH
L means HO2S1
MNTR (B1)/(B2) indicates LEAN

SEF647Y




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] or 36 [HO2S1 (B2) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 1

EBS00FW7

Refer to [EM-23, "EXHAUST MANIFOLD AND CATALYTIC CONVERTER"](#).

HO2S2 (QG16DE)

PFP:226A0

Component Description


EBS00FW8

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.






CONSULT-II Reference Value in Data Monitor Mode

EBS00FW9

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

Wiring Diagram



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W	Heated oxygen sensor 2	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00FWC


1. CHECK OVERALL FUNCTION-I

1. Start engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and ground.
4. Check the voltage while revving up to 4,000 rpm under no load at least 10 times. (Depress and release the accelerator pedal as quickly as possible.)

The voltage does not remain in the range of 0.2 -0.4V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.




2. CHECK OVERALL FUNCTION-II

Keep engine at idle for 10 minutes, then check the voltage between ECM terminal 16 and ground, or check voltage when coasting 80 km/h (50 MPH) in 3rd gear.

The voltage does not remain in the range of 0.2 -0.4V

OK or NG


- OK >> **INSPECTION END**
- NG >> GO TO 3.



3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-885, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace heated oxygen sensor 2.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 2

EBS00FWD


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.

HO2S2 (QG16DE)

[QG (WITHOUT EURO-OBD)]

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.
5. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.
The voltage should be below 0.50V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

EBS00FWE

HO2S2 (QG18DE)

PFP:226A0

Component Description


EBS00FWF

The heated oxygen sensor 2, after three way catalyst, monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode




EBS00FWG

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1) HO2S2 (B2)	● Engine: After warming up	Revving engine from idle up to 2,000 rpm	0 - 0.3V ←→ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1) HO2S2 MNTR (B2)			LEAN ←→ RICH

Wiring Diagram
BANK 1

EC-RRO2B1-01



REFER TO THE FOLLOWING.
E105 - FUSE BLOCK-JUNCTION BOX (J/B)

HO2S2 (QG18DE)

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and body ground.

CAUTION:




Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	Y	Heated oxygen sensor 2 (bank 1)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

BANK 2

EC-RRO2B1-01



REFER TO THE FOLLOWING.

E105 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and body ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
17	L	Heated oxygen sensor 2 (bank 2)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Heated oxygen sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V

Diagnostic Procedure

EBS00FWI


1. CHECK OVERALL FUNCTION - I

1. Start engine and drive the vehicle at 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and ground.
4. Check the voltage while revving engine up to 4,000 rpm under no load at least 10 times.
(Depress and release the accelerator pedal as quickly as possible.)

The voltage does not remain in the range of 0.2 - 0.4V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.




2. CHECK OVERALL FUNCTION - II

Keep engine at idle for 10 minutes, then check the voltage between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and ground, or check the voltage when coasting at 80 km/h (50 MPH) in "D" position with OD "OFF" (A/T), 3rd gear position (M/T).

The voltage does not remain in the range of 0.2 - 0.4V

OK or NG


- OK >> **INSPECTION END**
- NG >> GO TO 3.



3. RETIGHTEN GROUND SCREWS

1. Stop vehicle and turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 2 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 (B1) terminal 2, ECM terminal 17 and HO2S2 (B2) terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminals 16, 17 or HO2S2 terminal 1 and ground. Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-893, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace malfunctioning heated oxygen sensor 2.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 2


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)/(B2)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)/(B2)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)/(B2)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)/(B2)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] or 17 [HO2S2 (B2) signal] and engine ground.

4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.


(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position with "OD" OFF (A/T), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 2

EBS00FWK

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

IGNITION SIGNAL


PFP:22448

Component Description

IGNITION COIL & POWER TRANSISTOR

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

EBS00EZ8



A

EC

C

D

E

F

G

H

I

J

K

L

M




IGNITION SIGNAL

[QG (WITHOUT EURO-OBD)]

EBS00EZ9

EC-IGNSYS-01

Wiring Diagram



MBWA0087E

IGNITION SIGNAL

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> For a few seconds after turning ignition switch "OFF" 	0 - 1.0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> More than a few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
119 120	W W	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)




A
EC
C
D
E
F
G
H
I
J
K
L
M

IGNITION SIGNAL

[QG (WITHOUT EURO-OBD)]

EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



MBWA0088E



IGNITION SIGNAL

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
60	L/R	Ignition signal No. 3	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.1V★  PBIB0521E
61	BR	Ignition signal No. 1		
79	GY/R	Ignition signal No. 4		
80	PU	Ignition signal No. 2		0 - 0.2V★  PBIB0522E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00EZA

1. CHECK ENGINE START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 4.

2. CHECK OVERALL FUNCTION

☞ With CONSULT-II

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.

2. Make sure that each circuit produces a momentary engine speed drop.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 10.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


3. CHECK OVERALL FUNCTION

⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 79, 80 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.



PBIB0521E



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 10.


4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> Go to [EC-657, "POWER SUPPLY CIRCUIT FOR ECM"](#)




5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Turn ignition switch "ON".
4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 6.



6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.
3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



7. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV


Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK ECM RELAY

Refer to [EC-903, "Component Inspection"](#).

OK or NG

OK >> GO TO 17.

NG >> Replace ECM relay.

10. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check harness continuity between condenser terminal 2 and ground.
Refer to Wiring diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to power in harness or connector.

11. CHECK CONDENSER

Refer to [EC-903, "Component Inspection"](#) .


OK or NG

OK >> GO TO 12.

NG >> Replace condenser.

12. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

1. Turn ignition switch "OFF".
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.
4. Turn ignition switch "ON".




5. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 14.

NG >> GO TO 13.



13. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ignition coil and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

14. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ignition coil terminal 2 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 15.

NG >> Repair open circuit or short to power in harness or connectors.

15. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 79, 80 and ignition coil terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to [EC-903, "Component Inspection"](#) .

OK or NG

OK >> GO TO 17.

NG >> Replace ignition coil with power transistor.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> **INSPECTION END**

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



CONDENSER


1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.

IGNITION SIGNAL

[QG (WITHOUT EURO-OBD)]

3. Check resistance between condenser terminals 1 and 2.


Resistance: Above 1 MΩ at 25°C (77°F)



IGNITION COIL WITH POWER TRANSISTOR

1. Turn ignition switch "OFF".
2. Disconnect ignition coil harness connector.
3. Check resistance between ignition coil terminals as follows.

Terminal No.	Resistance Ω [at 25°C (77°F)]
3 and 1	Except 0 or ∞
3 and 2	Except 0
1 and 2	



Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-29, "IGNITION COIL"](#) .

EBS00E2C

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

Description SYSTEM DESCRIPTION

EBS00EZD

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* ²	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage* ²		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Vehicle speed signal* ¹	Vehicle speed		


*: This signal is sent to the ECM through CAN communication line.

*2: The ECM determines the start signal status by the signals of engine speed and battery voltage.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EZE

Specification data are reference values.





MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0%
		2,000 rpm	15 - 30%

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

EBS00EZG

Wiring Diagram

EC-PRGVLV-01




MBWA0083E

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and body ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	GY/L	EVAP canister purge volume control solenoid valve	[Engine is running] ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Engine speed is about 2,000 rpm	Approximately 10V★  PBIB0520E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBDD)]

EBS00EZH

Diagnostic Procedure

1. CHECK OVERALL FUNCTION

With CONSULT-II


1. Turn ignition switch "OFF".
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Turn ignition switch "ON".
4. Select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
5. Start engine and let it idle.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

6. Change the valve opening percentage with touching "Qu" or "Qd" on CONSULT-II screen, and check for vacuum existence at the EVAP purge hose under the following conditions.


Conditions	Vacuum
At idle	Should not exist.
Engine speed is about 2,000 rpm.	Should exist.



Without CONSULT-II

1. Turn ignition switch "OFF".
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Start engine and let it idle for at least 80 seconds.
4. Check for vacuum existence at the EVAP purge hose under the following conditions.

Conditions	Vacuum
At idle	Should not exist.
Engine speed is about 2,000 rpm.	Should exist.



OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.

2. CHECK EVAP CANISTER

Refer to [EC-954, "Component Inspection"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> Replace EVAP canister.

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

3. CHECK EVAP PURGE LINE


Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-953, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or reconnect the hose.

4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 19 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 7.

OK (Without CONSULT-II)>>GO TO 8.

NG >> Repair open circuit or short to ground and short to power in harness or connectors.

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

8. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-911, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace EVAP canister purge volume control solenoid valve.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBDD)]

Component Inspection


EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00EZJ

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between A and B
100.0%	Yes
0.0%	No



Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



Removal and Installation

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00EZJ

Refer to [EM-19, "INTAKE MANIFOLD"](#) .

VSS

PFP:32702

Description

EBS00H90

NOTE:

If DTC U1000 or U1001 is displayed, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-663, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from ABS actuator and electric unit (control unit) through CAN communication line. The combination meter then sends a signal to the ECM through CAN communication line.

Diagnostic Procedure

EBS00H90

1. CHECK VEHICLE SPEED SIGNAL OVERALL FUNCTION**④ With CONSULT-II**

1. Lift up the vehicle.
2. Start engine.
3. Select "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II.
4. Make sure that "VHCL SPEED SE" indication exceeds 10 km/h (6 MPH) when rotating wheels with suitable gear position.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

⊗ Without CONSULT-II

1. Lift up the vehicle.
2. Start engine.
3. Read vehicle speed with combination meter.
Make sure that vehicle speed indication exceeds 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.

2. CHECK DTC

Check DTC with ABS actuator and electric unit (control unit), Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#).

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace.

3. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#).

>> **INSPECTION END**

POWER STEERING PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]


POWER STEERING PRESSURE SENSOR

PFP:49763

Component Description

EBS00H7C

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H7D

Specification data are reference values.



MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	● Engine: After warming up, idle the engine	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

POWER STEERING PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H7G

EC-PS/SEN-01



MBWA0089E

POWER STEERING PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	L	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned.	0.5 - 4.0V
			[Engine is running] ● Steering wheel is not being turned.	0.4 - 0.8V
57	B	Sensor ground (Power steering pressure sensor)	[Engine is running] ● Idle speed	Approximately 0V
65	G	Sensor power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V

Diagnostic Procedure

EBS00H7H

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK POWER STEERING PRESSURE SENSOR OVERALL FUNCTION

 **With CONSULT-II**

- Start engine.
- Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

Steering in neutral position	OFF
Steering is turned	ON

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 4.

DATA MONITOR	
MONITOR	NO DTC
PW/ST SIGNAL	OFF

PBIB0646E

POWER STEERING PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]

3. CHECK POWER STEERING PRESSURE SENSOR OVERALL FUNCTION


⊗ Without CONSULT-II

1. Start engine.
2. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned.	0.5 - 4.0V
Steering wheel is not being turned.	0.4 - 0.8V

OK or NG


- OK >> **INSPECTION END**
 NG >> GO TO 4.



4. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 5.



5. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



POWER STEERING PRESSURE SENSOR

[QG (WITHOUT EURO-OBD)]

6. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 57 and PSP sensor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK PSP SENSOR

Refer to [EC-917, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace PSP sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


Component Inspection

POWER STEERING PRESSURE SENSOR

EBS00H71

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned fully.	0.5 - 4.0V
Steering wheel is not being turned.	0.4 - 0.8V



IVT CONTROL SOLENOID VALVE

[QG (WITHOUT EURO-OBD)]

IVT CONTROL SOLENOID VALVE


PFP:23796

Description SYSTEM DESCRIPTION

EBS00EZK

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed signal*	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.



MBIB0121E

This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

COMPONENT DESCRIPTION


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



EBS00EZL

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

IVT CONTROL SOLENOID VALVE [QG (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V TIM (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	-5° - 5°C
		When revving engine up to 2,000 rpm quickly	Approx. 0° - 30°C
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0% - 2%
		When revving engine up to 2,000 rpm quickly	Approx. 0% - 60%

A
EC
C
D
E
F
G
H
I
J
K
L
M





IVT CONTROL SOLENOID VALVE

[QG (WITHOUT EURO-OBD)]

EBS00EZN

EC-IVC/V-01

Wiring Diagram



MBWA0084E


IVT CONTROL SOLENOID VALVE

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
62	Y/R	Intake valve timing control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Warm-up condition ● When revving engine up to 2,000 rpm quickly	Approximately 9V★ 

PBIB0532E


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure


EBS00EZO

1. CHECK IVT CONTROL SOLENOID VALVE OVERALL FUNCTION CHECK

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Set the tester probe between ECM terminals 62 (IVT control solenoid valve signal) and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.
Verify that the oscilloscope screen shows the signal wave as shown below.

Conditions	Voltage
At idle	BATTERY VOLTAGE (11 - 14V)
When revving engine up to 2,000 rpm quickly	Approximately 9V★ 

PBIB0532E



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

OK or NG


- OK >> INSPECTION END
- NG >> GO TO 2.

IVT CONTROL SOLENOID VALVE

[QG (WITHOUT EURO-OBD)]

2. CHECK IVT CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect intake valve timing control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between intake valve timing control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTION PART

Check harness for open or short between intake valve timing control solenoid valve and ECM relay.

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK IVT CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 62 and intake valve timing control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-923, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake valve timing control solenoid valve.

IVT CONTROL SOLENOID VALVE

[QG (WITHOUT EURO-OBD)]

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-758, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace crankshaft position sensor (POS).

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-765, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace camshaft position sensor (PHASE).


8. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 9.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



9. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00EZP

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve terminals 1 and 2.

Terminals	Resistance
1 and 2	Approximately 8Ω at 20°C (68°F)
1 or 2 and ground	∞Ω (Continuity should not exist)



Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00EZQ

Refer to [EM-49, "TIMING CHAIN"](#) .

PNP SWITCH

[QG (WITHOUT EURO-OBD)]

PNP SWITCH

PFP:32006

Component Description

EBS00EZR

When the gear position is "P" (A/T models only) or "N", park/neutral position (PNP) switch is "ON".
ECM detects the position because the continuity of the line (the "ON" signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

EBS00EZS

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (A/T model) Neutral (M/T model)	ON
		Shift lever: Except above	OFF




PNP SWITCH

[QG (WITHOUT EURO-OBD)]

EBS00EZU

EC-PNPSW1-01

Wiring Diagram



MBWA0085E

PNP SWITCH

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	P (A/T) G/OR (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none"> Shift lever position is "P" or "N" (A/T models), "Neutral" (M/T models). 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Except the above gear position 	A/T models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V

Diagnostic Procedure


EBS00EZV

1. CHECK OVERALL FUNCTION

 **With CONSULT-II**

- Turn ignition switch "ON".
- Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
- Check the "P/N POSI SW" signal under the following conditions.


Selector lever position	P/N POSI SW signal
"P" and "N" position	ON
Except the above position	OFF



 **Without CONSULT-II**

- Turn ignition switch "ON".
- Check voltage between ECM terminal 102 and ground under the following conditions.

Selector lever position	Voltage
"P" and "N" position	Approximately 0V
Except the above position	A/T models: Battery voltage M/T models: Approximately 5V



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.

PNP SWITCH

[QG (WITHOUT EURO-OBD)]

2. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect PNP switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and body ground. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to power in harness or connectors.



3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and PNP switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK PNP SWITCH

Refer to [AT-404, "ON-VEHICLE SERVICE"](#) (A/T models) or [MT-14, "POSITION SWITCH"](#) , [MT-62, "POSITION SWITCH"](#) (M/T models).

OK or NG

OK >> GO TO 5.

NG >> Replace PNP switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


INJECTOR CIRCUIT

PFP:16600

Component Description

EBS00EZV

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

EBS00EZV

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	1.5 - 3.0 msec
		2,000 rpm	1.2 - 3.0 msec
INJ PULSE-B1 INJ PULSE-B2*	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.0 - 3.5 msec
		2,000 rpm	1.5 - 3.5 msec

*: This item is displayed with QG18DE engine models.





INJECTOR CIRCUIT

[QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00EZY

EC-INJECT-01



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0086E



INJECTOR CIRCUIT

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B R/B L/B Y/B	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0530E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00EZZ

1. INSPECTION START

Turn ignition switch to "START".

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

④ With CONSULT-II


1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

⊗ Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.




OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 3.

3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect injector harness connector.
3. Turn ignition switch "ON".




4. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between injector terminal 2 and ECM terminals 22, 23, 41, 42. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK INJECTOR

Refer to [EC-933, "Component Inspection"](#).

OK or NG

- OK >> GO TO 7.
 NG >> Replace injector.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INJECTOR

EBS00F00

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: 13.5 - 17.5Ω [at 20°C (68°F)]



EBS00F01

Removal and Installation INJECTOR

Refer to [EM-31, "FUEL INJECTOR AND FUEL TUBE"](#) .

FUEL PUMP CIRCUIT

[QG (WITHOUT EURO-OBD)]

FUEL PUMP CIRCUIT

PF01:17042

Description SYSTEM DESCRIPTION

EBS00F05

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		


*: The ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a engine speed signal from the crankshaft position sensor (POS) and camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.



CONSULT-II Reference Value in Data Monitor Mode

EBS00F06

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> For 1 seconds after turning ignition switch ON Engine running or cranking 	ON
	<ul style="list-style-type: none"> Except above conditions 	OFF


FUEL PUMP CIRCUIT

[QG (WITHOUT EURO-OBD)]


EBS00F07

Wiring Diagram

EC-F/PUMP-01



- REFER TO PG-POWER.
- : DETECTABLE LINE FOR DTC
 - : NON-DETECTABLE LINE FOR DTC
 - ◻ : LHD MODELS
 - ◻ : RHD MODELS
 - ◻ : WAGON
 - *1 20 : ◻
 - 23 : ◻



REFER TO THE FOLLOWING.

(B1) - FUSE BLOCK-JUNCTION BOX (J/B)

A
EC
C
D
E
F
G
H
I
J
K
L
M

FUEL PUMP CIRCUIT

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 seconds after turning ignition switch "ON"	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] ● More than 1 seconds after turning ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00F08

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with two fingers.
Fuel pressure pulsation should be felt on the fuel hose for 1 second after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between fuel pump relay terminals 1, 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector B1
- 10A fuse
- 15A fuse
- Harness for open or short between fuel pump relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Check harness continuity between fuel pump relay terminal 3 and fuel level sensor unit and fuel pump terminal 5, fuel level sensor unit and fuel pump terminal 3 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B37, D83
- Harness for open or short between fuel level sensor unit and fuel pump and fuel pump relay
- Harness for open or short between fuel level sensor unit and fuel pump and body ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 113 and fuel pump relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors B5, M23 (LHD models)
- Harness connectors B42, M95 (RHD models)
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

Refer to [EC-938, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace fuel pump relay.

9. CHECK FUEL PUMP

Refer to [EC-938, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace fuel pump.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection FUEL PUMP RELAY

EBS00F09


Check continuity between terminals 3 and 5 under the following conditions.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



FUEL PUMP

1. Disconnect fuel level sensor unit and fuel pump harness connector.




FUEL PUMP CIRCUIT

[QG (WITHOUT EURO-OBD)]

2. Check resistance between fuel level sensor unit and fuel pump terminals 3 and 5.

Resistance: Approximately 1.0Ω [at 25°C (77°F)]



Removal and Installation FUEL PUMP

Refer to [FL-6](#), "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY (EXCEPT YD22DDTi)".

REFRIGERANT PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]



PFP:92136

REFRIGERANT PRESSURE SENSOR

Component Description

EBS00F0H

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.






REFRIGERANT PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00F01

EC-RP/SEN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0090E

REFRIGERANT PRESSURE SENSOR

[QG (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	R	Sensor power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
57	B	Sensor ground (Refrigerant pressure sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
69	W (LHD) B (RHD)	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON". (Compressor operates.)	1.0 - 4.0V

Diagnostic Procedure

EBS00F0J


1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch "ON".
3. Check voltage between ECM terminal 69 and ground with CONSULT-II or tester.

Voltage: 1.0 - 4.0V

OK or NG


- OK >> **INSPECTION END**
 NG >> **GO TO 2.**



REFRIGERANT PRESSURE SENSOR [QG (WITHOUT EURO-OBD)]

2. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn A/C switch and blower switch "OFF".
2. Stop engine.
3. Disconnect refrigerant pressure sensor harness connector.
4. Turn ignition switch "ON".




5. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 57 and refrigerant pressure sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

REFRIGERANT PRESSURE SENSOR

[QG (WITHOUT EURO-OBD)]

6. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 69 and refrigerant pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.
- NG >> Repair or replace.

Removal and Installation

REFRIGERANT PRESSURE SENSOR

Refer to [ATC-127, "REFRIGERANT LINES"](#) .

EBS00F0K

ELECTRICAL LOAD SIGNAL

[QG (WITHOUT EURO-OBD)]

ELECTRICAL LOAD SIGNAL

PFP:25350

Description

EBS00H8J

The electrical load signals except headlamp switch signal are transferred through the CAN communication line.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H8K

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF

A

EC

C

D

E

F

G

H

I

J

K

L

M

ELECTRICAL LOAD SIGNAL




[QG (WITHOUT EURO-OBD)]

EBS00H6L

EC-LOAD-01

Wiring Diagram

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⊖CH** : CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM
- ⊖CD** : CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM
- ⊖XN** : XENON TYPE HEADLAMP



MBWA0147E

ELECTRICAL LOAD SIGNAL

[QG (WITHOUT EURO-OBDD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] ● Lighting switch is "2ND" position	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Lighting switch is "OFF"	Approximately 0V

Diagnostic Procedure

EBS00H8M

1. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

④ With CONSULT-II

- Turn ignition switch "ON".
- Connect CONSULT-II and select "DATA MONITOR" mode.
- Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch "ON"	ON
Rear window defogger switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> GO TO 4.

2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

④ With CONSULT-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch "ON" at 2nd position	ON
Lighting switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

ELECTRICAL LOAD SIGNAL

[QG (WITHOUT EURO-OBD)]

3. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II


⊗ Without CONSULT-II

Check voltage between ECM terminal 84 and ground under the following conditions.

Condition	Voltage
Lighting switch "ON" at 2nd position	Battery voltage
Lighting switch "OFF"	Approximately 0V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.



4. CHECK REAR WINDOW DEFOGGER SYSTEM

Refer to [GW-40, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

5. CHECK HEADLAMP FUNCTION

1. Turn lighting switch "ON" at 2nd position.
2. Check that headlamps are illuminated.

OK or NG

- OK >> GO TO 6.
- NG >> Refer to [LT-5, "HEADLAMP -CONVENTIONAL TYPE-"](#) , [LT-10, "HEADLAMP - XENON TYPE -"](#) , [LT-18, "HEADLAMP \(WITH DAYTIME\) - CONVENTIONAL TYPE -"](#) or [LT-25, "HEADLAMP \(WITH DAYTIME\) - XENON TYPE -"](#) .

6. CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect lighting switch harness connector.
4. Check harness continuity between ECM terminal 84 and lighting switch terminal 10.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect daytime light relay.
4. Check harness continuity between ECM terminal 84 and daytime light relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

XENON TYPE HEADLAMP

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect headlamp LH relay.
4. Check harness continuity between ECM terminal 84 and headlamp LH relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- harness for open and short between ECM and lighting switch
- harness for open and short between ECM and daytime light relay
- harness for open and short between ECM and headlamp LH relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-656, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

MI & DATA LINK CONNECTORS



[QG (WITHOUT EURO-OBD)]

PFP:24814





MI & DATA LINK CONNECTORS

Wiring Diagram—LHD Models

EBS00F0N



REFER TO THE FOLLOWING.
(M1), (M2) - FUSE BLOCK
- JUNCTION BOX (J/B)





MBWA0151E

MI & DATA LINK CONNECTORS

[QG (WITHOUT EURO-OBD)]

Wiring Diagram—RHD Models

EBS00H9T



A
EC
C
D
E
F
G
H
I
J
K
L
M

EVAPORATIVE EMISSION SYSTEM


[QG (WITHOUT EURO-OBD)]

EVAPORATIVE EMISSION SYSTEM

PFP:14950

Description SYSTEM DESCRIPTION

EBS00F00



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.


The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM [QG (WITHOUT EURO-OBD)]

EVAPORATIVE EMISSION LINE DRAWING



A
EC
C
D
E
F
G
H
I
J
K
L
M

EVAPORATIVE EMISSION SYSTEM


[QG (WITHOUT EURO-OBD)]

EBS00F0P

Component Inspection EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** . Orally blow air through port **A** .
Check that air flows freely through port **C** .
2. Block port **A** . Orally blow air through port **B** .
Check that air flows freely through port **C** .




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure: 15.3 - 20.0 kPa (0.153 - 0.200 bar,
0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.3 kPa (-0.060 to -0.033 bar,
-0.061 to -0.034 kg/cm² , -0.87 to -0.48 psi)

3. If out of specification, replace fuel filler cap as an assembly.



EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-911, "Component Inspection"](#) .

POSITIVE CRANKCASE VENTILATION


[QG (WITHOUT EURO-OBD)]

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description SYSTEM DESCRIPTION


EBS00F00



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.




Component Inspection

PCV (POSITIVE CRANKCASE VENTILATION) VALVE

EBS00F0R

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.




POSITIVE CRANKCASE VENTILATION

[QG (WITHOUT EURO-OBD)]

PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



SERVICE DATA AND SPECIFICATIONS (SDS) [QG (WITHOUT EURO-OBD)]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure

EBS00F0S

Fuel pressure at idle	Approximately 350 kPa (3.7kg/cm ² , 51psi)
-----------------------	---

Idle Speed and Ignition Timing

EBS00F0T

Target idle speed	No-load*1 (in "P" or "N" position)	A/T: 800±50 rpm M/T: 700±50 rpm
Air conditioner: ON	In "P" or "N" position	825 rpm or more
Ignition timing	In "P" or "N" position	A/T: 10°±5° BTDC M/T: 8°±5° BTDC

*1: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Calculated Load Value

EBS00F0U

	Calculated load value % (Using CONSULT-II)
At idle	10 - 35
At 2,500 rpm	10 - 35

Mass Air Flow Sensor

EBS00F0V

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	1.0 - 1.7*V
Mass air flow (Using CONSULT-II)	1.0 - 4.0 g·m/sec at idle* 5.0 - 10.0 g·m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Intake Air Temperature Sensor

EBS00F0W

Temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1
80 (176)	0.31 - 0.37

Engine Coolant Temperature Sensor

EBS00F0X

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

EBS00F0Y

Resistance [at 20°C (68°F)]	8 - 10Ω
-----------------------------	---------

Heated Oxygen sensor 2 Heater

EBS00F0Z

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (POS)

EBS00F10

Refer to [EC-758, "Component Inspection"](#) .

Camshaft Position Sensor (PHASE)

EBS00F11

Refer to [EC-765, "Component Inspection"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)
[QG (WITHOUT EURO-OBD)]

Throttle Control Motor

EBS00F12

Resistance [at 25°C (77°F)]

Approximately 1 - 15Ω

Injector

EBS00F13

Resistance [at 20°C (68°F)]

13.5 - 17.5Ω

Fuel Pump

EBS00F14

Resistance [at 25°C (77°F)]

Approximately 1.0Ω

INDEX FOR DTC

PFP:00024

Alphabetical Index

EBS00F15

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#) .

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
ACC COMMAND VALUE*7	P1568	1568	EC-1340
APP SEN 1/CIRC*5	P0227	0227	EC-1188
APP SEN 1/CIRC*5	P0228	0228	EC-1188
APP SEN 2/CIRC*5	P1227	1227	EC-1322
APP SEN 2/CIRC*5	P1228	1228	EC-1322
APP SENSOR*5	P0226	0226	EC-1181
ASCD BRAKE SW*7	P1572	1572	EC-1341
ASCD SW*7	P1564	1564	EC-1333
ASCD VHL SPD SEN*7	P1574	1574	EC-1351
BRAKE SW/CIRCUIT	P1805	1805	EC-1360
CAN COMM CIRCUIT	U1000	1000*6	EC-1083
CAN COMM CIRCUIT	U1001	1001*6	EC-1083
CKP SEN/CIRCUIT	P0335	0335	EC-1205
CMP SEN/CIRC-B1	P0340	0340	EC-1212
CTP LEARNING	P1225	1225	EC-1318
CTP LEARNING	P1226	1226	EC-1320
CYL 1 MISFIRE	P0301	0301	EC-1195
CYL 2 MISFIRE	P0302	0302	EC-1195
CYL 3 MISFIRE	P0303	0303	EC-1195
CYL 4 MISFIRE	P0304	0304	EC-1195
ECM	P0605	0605	EC-1235
ECM BACK UP/CIRC	P1065	1065	EC-1238
ECT SEN/CIRCUIT*5	P0117	0117	EC-1111
ECT SEN/CIRCUIT*5	P0118	0118	EC-1111
ENG OVER TEMP	P1217	1217	EC-1295
ETC ACTR*5	P1121	1121	EC-1246
ETC FUNCTION/CIRC*5	P1122	1122	EC-1248
ETC MOT*5	P1128	1128	EC-1261
ETC MOT PWR*5	P1124	1124	EC-1255
ETC MOT PWR*5	P1126	1126	EC-1255
FUEL SYS-LEAN-B1	P0171	0171	EC-1157
FUEL SYS-RICH-B1	P0172	0172	EC-1163
HO2S1 (B1)	P0132	0132	EC-1119

INDEX FOR DTC

[QR (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
HO2S1 (B1)	P0133	0133	EC-1125
HO2S1 (B1)	P0134	0134	EC-1135
HO2S1 (B1)	P1143	1143	EC-1266
HO2S1 (B1)	P1144	1144	EC-1272
HO2S1 HTR (B1)	P0031	0031	EC-1090
HO2S1 HTR (B1)	P0032	0032	EC-1090
HO2S2 (B1)	P0138	0138	EC-1142
HO2S2 (B1)	P0139	0139	EC-1149
HO2S2 (B1)	P1146	1146	EC-1278
HO2S2 (B1)	P1147	1147	EC-1286
HO2S2 HTR (B1)	P0037	0037	EC-1095
HO2S2 HTR (B1)	P0038	0038	EC-1095
IAT SEN/CIRCUIT	P0112	0112	EC-1106
IAT SEN/CIRCUIT	P0113	0113	EC-1106
IAT SENSOR	P0127	0127	EC-1116
IN PULY SPEED	P1715	1715	
IN PY SPD SEN/CIRC	P0715	0715	CVT-78
INT/V TIM CONT-B1	P0011	0011	EC-1087
INT/V TIM V/CIR-B1	P1111	1111	EC-1242
KNOCK SEN/CIRC-B1	P0327	0327	EC-1201
KNOCK SEN/CIRC-B1	P0328	0328	EC-1201
L/PRESS SOL/CIRC	P0745	0745	CVT-94
LINE PRESS SEN	P1791	1791	CVT-113
MAF SEN/CIRCUIT*5	P0102	0102	EC-1100
MAF SEN/CIRCUIT*5	P0103	0103	EC-1100
MULTI CYL MISFIRE	P0300	0300	EC-1195
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-1016
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	EC-1448
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
OUT PULY SPEED	P1720	1720	EC-1358
P-N POS SW/CIRCUIT	P1706	1706	EC-1353
PURG VOLUME CONT/V	P0444	0444	EC-1222
PURG VOLUME CONT/V	P0445	0445	EC-1222
PW ST P SEN/CIRC	P0550	0550	EC-1230
SENSOR POWER/CIRC*5	P1229	1229	EC-1329
STEP MOTR CIRC	P1777	1777	CVT-108
STEP MOTR FNC	P1778	1778	CVT-111
TCC SOLENOID/CIRC	P0740	0740	CVT-89
TCS/CIRC*8	P1212	1212	EC-1294

INDEX FOR DTC

[QR (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II GST*2	ECM*3	
TP SEN 1/CIRC*5	P0222	0222	EC-1175
TP SEN 1/CIRC*5	P0223	0223	EC-1175
TP SEN 2/CIRC*5	P1223	1223	EC-1312
TP SEN 2/CIRC*5	P1224	1224	EC-1312
TP SENSOR*5	P0221	0221	EC-1169
TW CATALYST SYS-B1	P0420	0420	EC-1218
VEH SPEED SEN/CIRC	P0500	0500	EC-1228

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for these DTCs needs CONSULT-II.

*7: For models with ICC system.

*8: For models with ESP/TCS/ABS system.

DTC No. Index

EBS00F16

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-1448
U1000	1000*6	CAN COMM CIRCUIT	EC-1083
U1001	1001*6	CAN COMM CIRCUIT	EC-1083
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—
P0011	0011	INT/V TIM CONT-B1	EC-1087
P0031	0031	HO2S1 HTR (B1)	EC-1090
P0032	0032	HO2S1 HTR (B1)	EC-1090
P0037	0037	HO2S2 HTR (B1)	EC-1095
P0038	0038	HO2S2 HTR (B1)	EC-1095
P0102	0102	MAF SEN/CIRCUIT*5	EC-1100
P0103	0103	MAF SEN/CIRCUIT*5	EC-1100
P0112	0112	IAT SEN/CIRCUIT	EC-1106
P0113	0113	IAT SEN/CIRCUIT	EC-1106
P0117	0117	ECT SEN/CIRCUIT*5	EC-1111
P0118	0118	ECT SEN/CIRCUIT*5	EC-1111
P0127	0127	IAT SENSOR	EC-1116
P0132	0132	HO2S1 (B1)	EC-1119
P0133	0133	HO2S1 (B1)	EC-1125

INDEX FOR DTC

[QR (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P0134	0134	HO2S1 (B1)	EC-1135
P0138	0138	HO2S2 (B1)	EC-1142
P0139	0139	HO2S2 (B1)	EC-1149
P0171	0171	FUEL SYS-LEAN-B1	EC-1157
P0172	0172	FUEL SYS-RICH-B1	EC-1163
P0221	0221	TP SENSOR*5	EC-1169
P0222	0222	TP SEN 1/CIRC*5	EC-1175
P0223	0223	TP SEN 1/CIRC*5	EC-1175
P0226	0226	APP SENSOR*5	EC-1181
P0227	0227	APP SEN 1/CIRC*5	EC-1188
P0228	0228	APP SEN 1/CIRC*5	EC-1188
P0300	0300	MULTI CYL MISFIRE	EC-1195
P0301	0301	CYL 1 MISFIRE	EC-1195
P0302	0302	CYL 2 MISFIRE	EC-1195
P0303	0303	CYL 3 MISFIRE	EC-1195
P0304	0304	CYL 4 MISFIRE	EC-1195
P0327	0327	KNOCK SEN/CIRC-B1	EC-1201
P0328	0328	KNOCK SEN/CIRC-B1	EC-1201
P0335	0335	CKP SEN/CIRCUIT	EC-1205
P0340	0340	CMP SEN/CIRC-B1	EC-1212
P0420	0420	TW CATALYST SYS-B1	EC-1218
P0444	0444	PURG VOLUME CONT/V	EC-1222
P0445	0445	PURG VOLUME CONT/V	EC-1222
P0500	0500	VEH SPEED SEN/CIRC	EC-1228
P0550	0550	PW ST P SEN/CIRC	EC-1230
P0605	0605	ECM	EC-1235
P0715	0715	IN PY SPD SEN/CIRC	CVT-78
P0740	0740	TCC SOLENOID/CIRC	CVT-89
P0745	0745	L/PRESS SOL/CIRC	CVT-94
P1065	1065	ECM BACK UP/CIRC	EC-1238
P1111	1111	INT/V TIM V/CIR-B1	EC-1242
P1121	1121	ETC ACTR*5	EC-1246
P1122	1122	ETC FUNCTION/CIRC*5	EC-1248
P1124	1124	ETC MOT PWR*5	EC-1255
P1126	1126	ETC MOT PWR*5	EC-1255
P1128	1128	ETC MOT*5	EC-1261
P1143	1143	HO2S1 (B1)	EC-1266
P1144	1144	HO2S1 (B1)	EC-1272
P1146	1146	HO2S2 (B1)	EC-1278
P1147	1147	HO2S2 (B1)	EC-1286

INDEX FOR DTC

[QR (WITH EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II GST*2	ECM*3		
P1212	1212	TCS/CIRC*8	EC-1294
P1217	1217	ENG OVER TEMP	EC-1295
P1223	1223	TP SEN 2/CIRC*5	EC-1312
P1224	1224	TP SEN 2/CIRC*5	EC-1312
P1225	1225	CTP LEARNING	EC-1318
P1226	1226	CTP LEARNING	EC-1320
P1227	1227	APP SEN 2/CIRC*5	EC-1322
P1228	1228	APP SEN 2/CIRC*5	EC-1322
P1229	1229	SENSOR POWER/CIRC*5	EC-1329
P1564	1564	ASCD SW*7	EC-1333
P1568	1568	ACC COMMAND VALUE*7	EC-1340
P1572	1572	ASCD BRAKE SW*7	EC-1341
P1574	1574	ASCD VHL SPD SEN*7	EC-1351
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-1016
P1706	1706	P-N POS SW/CIRCUIT	EC-1353
P1715	1715	IN PULY SPEED	
P1720	1720	OUT PULY SPEED	EC-1358
P1777	1777	STEP MOTR CIRC	CVT-108
P1778	1778	STEP MOTR FNC	CVT-111
P1791	1791	LINE PRESS SEN	CVT-113
P1805	1805	BRAKE SW/CIRCUIT	EC-1360

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for these DTCs needs CONSULT-II.

*7: For models with ICC system.

*8: For models with ESP/TCS/ABS system.

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

EBS00F17

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

On Board Diagnostic (OBD) System of Engine and CVT

EBS00F18

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.


CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery ground cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-86. "HARNESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM and TCM (Transmission control module) before returning the vehicle to the customer.

Precaution

EBS00F19

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery ground cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




SEF289H


PRECAUTIONS

[QR (WITH EURO-OBD)]


- Do not disassemble ECM.
- If battery cable is disconnected, the memory will return to the initial ECM values.
The ECM will now start to self-control at its initial values. Engine operation can vary slightly when the cable is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown at right.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.



- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-1047](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




PRECAUTIONS


[QR (WITH EURO-OBD)]

- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.


The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.




PRECAUTIONS

[QR (WITH EURO-OBD)]

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.



Wiring Diagrams and Trouble Diagnosis

EBS00F1A

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

A
EC
C
D
E
F
G
H
I
J
K
L
M

PREPARATION





[QR (WITH EURO-OBD)]

PREPARATION

PFP:00002



Special Service Tools

EBS00F1B

Tool number Tool name	Description	
KV10117100 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT379</p>	Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench	 <p style="text-align: center;">S-NT636</p>	Loosening or tightening heated oxygen sensors a: 22 mm (0.87 in)
KV109E0010 Break-out box	 <p style="text-align: center;">NT825</p>	Measuring ECM signals with a circuit tester
KV109E0080 Y-cable adapter	 <p style="text-align: center;">NT826</p>	Measuring ECM signals with a circuit tester




Commercial Service Tools

EBS00F1C

Tool name	Description	
Quick connector release	 <p style="text-align: center;">PBIC0198E</p>	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)
Fuel filler cap adapter	 <p style="text-align: center;">S-NT653</p>	Checking fuel tank vacuum relief valve opening pressure

PREPARATION

[QR (WITH EURO-OBD)]

Tool name	Description	
Socket wrench	 <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.25 in)</p> <p>S-NT705</p>	Removing and installing engine coolant temperature sensor
Oxygen sensor thread cleaner ie: (J-43897-18) (J-43897-12)	 <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> <p>AEM488</p>	Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below. a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor
Anti-seize lubricant i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p>S-NT779</p>	Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.


A
EC
C
D
E
F
G
H
I
J
K
L
M

ENGINE CONTROL SYSTEM

PFP:23710

System Diagram

EBS00F1D



MBIB0051E

Vacuum Hose Drawing

EBS00F1E

A

EC

C

D

E

F

G

H


I

J

K

L

M



NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to for Vacuum Control System.

PBIB0489E

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

System Chart

EBS00F1F

Input (Sensor)	ECM Function	Output (Actuator)	
<ul style="list-style-type: none"> ● Camshaft position sensor (PHASE) ● Crankshaft position sensor (POS) ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Throttle position sensor ● Accelerator pedal position sensor ● Park/neutral position (PNP) switch ● Intake air temperature sensor ● Power steering pressure sensor ● Ignition switch ● Battery voltage ● Knock sensor ● Refrigerant pressure sensor ● Stop lamp switch ● ICC steering switch ● Heated oxygen sensor 2 *1 ● TCM (Transmission control module) *2 ● ESP/TCS/ABS control unit *2 ● ICC unit *2 ● Air conditioner switch *2 ● Vehicle speed signal *2 ● Electrical load signal *2 	Fuel injection & mixture ratio control	Fuel injectors	
	Electronic ignition system	Power transistor	
	Fuel pump control	Fuel pump relay	
	ICC vehicle speed control	Electric throttle control actuator	
	On board diagnostic system	MI (On the instrument panel) *3	
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater	
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater	
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve	
	Air conditioning cut control	Air conditioner relay *3	
		Cooling fan control	Cooling fan relays *3

*1: This sensor is not used to control the engine system under normal conditions.

*2: These input signals are sent to the ECM through CAN communication line.

*3: These output signals are sent from the ECM through CAN communication line.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

EBS00F1G

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *3 and piston position	Fuel injection & mixture ratio control	Fuel injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage *3		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2 *1	Density of oxygen in exhaust gas		
Vehicle speed signal *2	Vehicle speed		
Air conditioner switch *2	Air conditioner operation		

*1: Under normal conditions, this sensor is not for engine control operation.

*2: These signals are sent to the ECM through CAN communication line.

*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the crankshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from “N” to “D” (CVT models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about heated oxygen sensor 1, refer to [EC-1119](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from “N” to “D” (CVT models)

- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of “injection pulse duration” to automatically compensate for the difference between the two ratios.

“Fuel trim” refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

“Short term fuel trim” is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

“Long term fuel trim” is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multipoint Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multipoint Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

Electronic Ignition (EI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *2 and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage *2		
Vehicle speed signal *1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.


e.g., N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.



Air Conditioning Cut Control INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch *1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *2		
Engine coolant temperature sensor	Engine coolant temperature		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Vehicle speed signal *1	Vehicle speed		

*1: These signals are sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

Fuel Cut Control (at No Load and High Engine Speed)

EBS00F1J

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injectors
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Vehicle speed signal* ¹	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

If the engine speed is above 1,800 rpm with no load (for example, in neutral and engine speed over 1,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under “Multiport Fuel Injection (MFI) System”, [EC-972](#)

CAN communication

EBS00F1K

SYSTEM DESCRIPTION


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

CAN COMMUNICATION UNIT FOR LHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

CVT Models with ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ESP/ TCS/ ABS control unit	Steer- ing angle sensor	Smart entranc e control unit	Tyre pres- sure monit- oring control unit	ICC unit	ICC sensor	Combi- nation meter
Engine speed signal	T	R	R				R		R
Accelerator pedal position signal	T	R	R				R		
Closed throttle position signal	T						R		
ICC steering switch signal	T						R		
Shift pattern signal		T					R		
Parking brake switch signal			T				R		
ICC system display signal							T		R
ICC sensor signal							R	T	
ESP operation signal	R		T				R		
TCS operation signal	R		T				R		
ABS operation signal	R	R	T				R		
Stop lamp switch signal		R	T						
Steering wheel angle sensor signal			R	T					
Wheel speed sensor signal			T				R		
Rear window defogger signal	R				T				
Heater fan switch signal	R								T
Air conditioner switch signal	R								T
Primary pulley revolution signal	R	T					R		
Secondary pulley revolution signal	R	T					R		
ICC operation signal	R						T		
Brake switch signal	R						T		
MI signal	T								R
Current gear position signal		T							R
Engine coolant temperature signal	T						R		R
Fuel consumption signal	T								R

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	ICC unit	ICC sensor	Combination meter
Vehicle speed signal	R		T						R
Seat belt reminder signal					R				T
Headlamp switch signal					T				R
Flashing indicator signal					T				R
Engine cooling fan speed signal	T				R				
Child lock indicator signal					T				R
Door switches state signal					T				R
Key ID signal	R				T				
	T				R				
A/C compressor signal	T				R				
Tire pressure signal						T			R

CVT Models with ESP without ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R	R				R
Accelerator pedal position signal	T	R	R				
ESP operation signal	R		T				
TCS operation signal	R		T				
ABS operation signal	R	R	T				
Stop lamp switch signal		R	T				
Steering wheel angle sensor signal			R	T			
Rear window defogger signal	R				T		
Heater fan switch signal	R						T
Air conditioner switch signal	R						T
Primary pulley revolution signal	R	T					
Secondary pulley revolution signal	R	T					

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
MI signal	T						R
Current gear position signal		T					R
Engine coolant temperature signal	T						R
Fuel consumption signal	T						R
Vehicle speed signal			T				R
	R						T
Seat belt reminder signal					R		T
Headlamp switch signal					T		R
Flashing indicator signal					T		R
Engine cooling fan speed signal	T				R		
Child lock indicator signal					T		R
Door switches state signal					T		R
Key ID signal	R				T		
	T				R		
A/C compressor signal	T				R		
Tire pressure signal						T	R

CVT Models without ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tyre pressure signal					T	R

M/T Models with ESP

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Accelerator pedal position signal	T	R				
ESP operation signal	R	T				
TCS operation signal	R	T				
ABS operation signal	R	T				
Steering wheel angle sensor signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sen- sor	Smart entrance control unit	Tyre pres- sure moni- toring control unit	Combina- tion meter
Vehicle speed signal		T				R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tire pressure signal					T	R

M/T Models without ESP

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance con- trol unit	Tyre pres- sure moni- toring control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R		T		
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tire pressure signal				T	R

CAN COMMUNICATION UNIT FOR LHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

CVT Models with ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS/ABS control unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sensor	Combination meter
Engine speed signal	T	R	R			R		R
Accelerator pedal position signal	T	R	R			R		
Closed throttle position signal	T					R		
ICC steering switch signal	T					R		
Shift pattern signal		T				R		
Parking brake switch signal			T			R		
ICC system display signal						T		R
ICC sensor signal						R	T	
ESP operation signal	R		T			R		
TCS operation signal	R		T			R		
ABS operation signal	R	R	T			R		
Stop lamp switch signal		R	T					
Steering wheel angle sensor signal			R	T				
Wheel speed sensor signal			T			R		
Rear window defogger signal	R				T			
Heater fan switch signal	R							T
Air conditioner switch signal	R							T
Primary pulley revolution signal	R	T				R		
Secondary pulley revolution signal	R	T				R		
ICC operation signal	R					T		

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
Brake switch signal	R					T		
MI signal	T							R
Current gear position signal		T						R
Engine coolant temperature signal	T					R		R
Fuel consumption signal	T							R
Vehicle speed signal			T					R
	R							T
Seat belt reminder signal					R			T
Headlamp switch signal					T			R
Flashing indicator signal					T			R
Engine cooling fan speed signal	T				R			
Child lock indicator signal					T			R
Door switches state signal					T			R
Key ID signal	R				T			
	T				R			
A/C compressor signal	T				R			

CVT Models with ESP without ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Engine speed signal	T	R	R			R
Accelerator pedal position signal	T	R	R			
ESP operation signal	R		T			
TCS operation signal	R		T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	

CVT Models without ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance con- trol unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models with ESP SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Accelerator pedal position signal	T	R			
ESP operation signal	R	T			
TCS operation signal	R	T			
ABS operation signal	R	T			
Steering wheel angle sensor signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models without ESP

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	ABS actuator and electric unit (con- trol unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R		T	
Heater fan switch signal	R			T
Air conditioner switch signal	R			T
MI signal	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

CAN COMMUNICATION UNIT FOR RHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

CVT Models with ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R		R			R		R
Accelerator pedal position signal	T	R		R			R		
Closed throttle position signal	T						R		
ICC steering switch signal	T						R		
Shift pattern signal		T					R		
Parking brake switch signal				T			R		
ICC system display signal							T		
ICC sensor signal			T				R		
ESP operation signal	R			T			R		
TCS operation signal	R			T			R		
ABS operation signal	R	R		T			R		
Stop lamp switch signal		R		T					
Steering wheel angle sensor signal				R		T			
Wheel speed sensor signal				T			R		
Rear window defogger signal	R							T	
Heater fan switch signal	R								T
Air conditioner switch signal	R								T
Primary pulley revolution signal	R	T					R		
Secondary pulley revolution signal	R	T					R		
ICC operation signal	R						T		
Brake switch signal	R						T		
MI signal	T								R
Current gear position signal		T							R
Engine coolant temperature signal	T						R		R
Fuel consumption signal	T								R
Vehicle speed signal				T					R
	R								T

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Seat belt reminder signal								R	T
Headlamp switch signal								T	R
Flashing indicator signal								T	R
Engine cooling fan speed signal	T							R	
Child lock indicator signal								T	R
Door switches state signal								T	R
Key ID signal	R							T	
	T							R	
A/C compressor signal	T							R	
Tire pressure signal					T				R

CVT Models with ESP without ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS/ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R	R				R
Accelerator pedal position signal	T	R	R				
ESP operation signal	R		T				
TCS operation signal	R		T				
ABS operation signal	R	R	T				
Stop lamp switch signal		R	T				
Steering wheel angle sensor signal			R		T		
Rear window defogger signal	R					T	
Heater fan switch signal	R						T
Air conditioner switch signal	R						T
Primary pulley revolution signal	R	T					
Secondary pulley revolution signal	R	T					
MI signal	T						R
Current gear position signal		T					R

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Tyre pressure monitor- ing con- trol unit	Steering angle sensor	Smart entrance control unit	Combi- nation meter
Engine coolant temperature	T						R
Fuel consumption signal	T						R
Vehicle speed signal			T				R
	R						T
Seat belt reminder signal						R	T
Headlamp switch signal						T	R
Flashing indicator signal						T	R
Engine cooling fan speed signal	T					R	
Child lock indicator signal						T	R
Door switches state signal						T	R
Key ID signal	R					T	
	T					R	
A/C compressor signal	T					R	
Tire pressure signal				T			R

CVT Models without ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ABS actua- tor and electric unit (control unit)	Tyre pres- sure moni- toring control unit	Smart entrance control unit	Combi- nation meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
M1 signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tire pressure signal				T		R

M/T Models with ESP SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	ESP/TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Accelerator pedal position signal	T	R				
ESP operation signal	R	T				
TCS operation signal	R	T				
ABS operation signal	R	T				
Steering wheel angle sensor signal		R		T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal		T				R
	R					T

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ESP/ TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tire pressure signal			T			R

M/T Models without ESP SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	
Tyre pressure signal			T		R

CAN COMMUNICATION UNIT FOR RHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

CVT Models with ESP and ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R		R		R		R
Accelerator pedal position signal	T	R		R		R		
Closed throttle position signal	T					R		
ICC steering switch signal	T					R		
Shift pattern signal		T				R		
Parking brake switch signal				T		R		
ICC system display signal						T		R
ICC sensor signal			T			R		
ESP operation signal	R			T		R		
TCS operation signal	R			T		R		
ABS operation signal	R	R		T		R		
Stop lamp switch signal		R		T				
Steering wheel angle sensor signal				R	T			
Wheel speed sensor signal				T		R		
Rear window defogger signal	R						T	
Heater fan switch signal	R							T
Air conditioner switch signal	R							T
Primary pulley revolution signal	R	T				R		
Secondary pulley revolution signal	R	T				R		
ICC operation signal	R					T		

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Brake switch signal	R					T		
MI signal	T							R
Current gear position signal		T						R
Engine coolant temperature signal	T					R		R
Fuel consumption signal	T							R
Vehicle speed signal				T				R
	R							T
Seat belt reminder signal							R	T
Headlamp switch signal							T	R
Flashing indicator signal							T	R
Engine cooling fan speed signal	T						R	
Child lock indicator signal							T	R
Door switches state signal							T	R
Key ID signal	R						T	
	T						R	
A/C compressor signal	T						R	

CVT Models with ESP without ICC SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	TCM	ESP/TCS/ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R	R			R
Accelerator pedal position signal	T	R	R			
ESP operation signal	R		T			
TCS operation signal	R		T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	

CVT Models without ESP and ICC

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R

ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models with ESP SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Accelerator pedal position signal	T	R			
ESP operation signal	R	T			
TCS operation signal	R	T			
ABS operation signal	R	T			
Steering wheel angle sensor signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R


ENGINE CONTROL SYSTEM

[QR (WITH EURO-OBD)]

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models without ESP

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (con- trol unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R		T	
Heater fan switch signal	R			T
Air conditioner switch signal	R			T
MI signal	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

BASIC SERVICE PROCEDURE

PFP:00018

Idle Speed and Ignition Timing Check

IDLE SPEED

EBS00F1L

With CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
SEF058Y	

With GST


Check idle speed in "MODE 1" with GST.

IGNITION TIMING

Any of following two methods may be used.


Method A

1. Slide the harness protector of ignition coil No.1 to clear the wires.
2. Attach timing light to the wires as shown in the figure.
3. Check ignition timing.



Method B

1. Remove No. 1 ignition coil.





A
EC
C
D
E
F
G
H
I
J
K
L
M


BASIC SERVICE PROCEDURE

[QR (WITH EURO-OBD)]

2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.



3. Check ignition timing.



Accelerator Pedal Released Position Learning DESCRIPTION

EBS00F1N

“Accelerator Pedal Released Position Learning” is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON” and wait at least 2 seconds.
3. Turn ignition switch “OFF” wait at least 10 seconds.
4. Turn ignition switch “ON” and wait at least 2 seconds.
5. Turn ignition switch “OFF” wait at least 10 seconds.

Throttle Valve Closed Position Learning DESCRIPTION

EBS00F1O

“Throttle Valve Closed Position Learning” is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON”.

3. Turn ignition switch "OFF" and wait at least 10 seconds.
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

A

Idle Air Volume Learning DESCRIPTION

EBS00F1P

EC

"Idle Air Volume Learning" is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

C

PREPARATION

Before performing "Idle Air Volume Learning", make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

D

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 95°C (158 - 203°F)
- PNP switch: ON
- Electric load switch: OFF
(Air conditioner, headlamp, rear window defogger)

E

On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.

F

- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up

G

For CVT models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "CVT" system indicates less than 0.9V.

H

For CVT models without CONSULT-II and M/T models, drive vehicle for 10 minutes.

OPERATION PROCEDURE


I

④ With CONSULT-II

1. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.

J

K




L

M


BASIC SERVICE PROCEDURE

[QR (WITH EURO-OBD)]

- Touch "START" and wait 20 seconds.



- Make sure that "CMPLT" is displayed on CONSULT-II screen. If "INCMP" is displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.
- Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.




ITEM	SPECIFICATION
Idle speed	M/T: 600±50 rpm CVT: 650±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 14±5° BTDC CVT: 15±5° BTDC (in "P" or "N" position)

⊗ Without CONSULT-II

NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
 - Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
 - Start engine and warm it up to normal operating temperature.
 - Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
 - Turn ignition switch "OFF" and wait at least 10 seconds.
 - Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
 - Repeat the following procedure quickly five times within 5 seconds.
 - Fully depress the accelerator pedal.
 - Fully release the accelerator pedal.
 - Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
 - Fully release the accelerator pedal within 3 seconds after the MI goes off.
 - Start engine and let it idle.

11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 600±50 rpm CVT: 650±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 14±5° BTDC CVT: 15±5° BTDC (in "P" or "N" position)

13. If idle speed and ignition timing are not within the specification, the result will be incomplete. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.

DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:

1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the problem. It is useful to perform [EC-1072, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).
5. If any of the following conditions occur after the engine has started, eliminate the cause of the problem and perform "Idle air volume learning" all over again:
 - Engine stalls.
 - Erroneous idle.

**Fuel Pressure Check
FUEL PRESSURE RELEASE**

EBS00F1Q

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

NOTE:

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because QR engine models do not have fuel return system.

With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".


FUEL PRESSURE RELEASE

FUEL PUMP WILL STOP BY TOUCHING START IN IDLING. CRANK A FEW TIMES AFTER ENGINE STALL.

SEF214Y

⊗ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.




FUEL PRESSURE CHECK

CAUTION:

- The fuel hose connection method used when taking fuel pressure check must not be used for other purposes.
- Be careful not to scratch or put debris around connection area when servicing, so that the quick connector maintains sealability with O-rings inside.
- When installing fuel hose quick connector, refer to [EM-116, "INTAKE MANIFOLD"](#).


1. Release fuel pressure to zero. Refer to [EC-1001, "FUEL PRESSURE RELEASE"](#).
2. Prepare fuel hose and fuel hose clamp for fuel pressure check, and connect fuel pressure gauge.
 - Use suitable fuel hose for fuel pressure check (genuine NISSAN fuel hose without quick connector).
 - To avoid unnecessary force or tension to hose, use moderately long fuel hose for fuel pressure check.
 - Do not use the fuel hose for checking fuel pressure with damage or cracks on it.
 - Use Pressure Gauge to check fuel pressure.
3. Remove fuel hose. Refer to [EM-116, "INTAKE MANIFOLD"](#).
 - Do not twist or kink fuel hose because it is plastic hose.
 - Do not remove fuel hose from quick connector.
 - Keep the original fuel hose to be free from intrusion of dust or foreign substances with a suitable cover.
4. Install the fuel pressure gauge as shown in the figure.
 - Wipe off oil or dirt from hose insertion part using cloth moistened with gasoline.
 - Apply proper amount of gasoline between top of the fuel tube and No.1 spool.
 - Insert fuel hose for fuel pressure check until it touches the No.1 spool on fuel tube.
 - Use NISSAN genuine hose clamp (part number: 16439 N4710 or 16439 40U00).
 - When reconnecting fuel line, always use new clamps.
 - When reconnecting fuel hose, check the original fuel hose for damage and abnormality.
 - Use a torque driver to tighten clamps.
 - Install hose clamp to the position within 1 - 2 mm (0.04 - 0.08 in).



Tightening torque:

1 - 1.5 N·m (0.1 - 0.15 kg·m, 9 - 13 in·lb)

- Make sure that clamp screw does not contact adjacent parts.
5. After connecting fuel hose for fuel pressure check, pull the hose with a force of approximately 98 N (10 kg, 22 lb) to confirm fuel tube does not come off.
 6. Turn ignition switch "ON", and check for fuel leakage.



BASIC SERVICE PROCEDURE

[QR (WITH EURO-OBD)]

7. Start engine and check for fuel leakage.
8. Read the indication of fuel pressure gauge.
 - Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
 - During fuel pressure check, confirm for fuel leakage from fuel connection every 3 minutes.

At idling: Approximately 350 kPa (3.5 bar, 3.7 kg/cm² , 51 psi)

9. If result is unsatisfactory, go to next step.
10. Check the following.
 - Fuel hoses and fuel tubes for clogging
 - Fuel filter for clogging
 - Fuel pump
 - Fuel pressure regulator for cloggingIf OK, replace fuel pressure regulator.
If NG, repair or replace.

A

EC

C

D

E

F

G

H

I

J

K

L

M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

EBS00F1R

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information	ISO Standard
Diagnostic Trouble Code (DTC)	Mode 3 of ISO 15031-5
Freeze Frame data	Mode 2 of ISO 15031-5
System Readiness Test (SRT) code	Mode 1 of ISO 15031-5
1st Trip Diagnostic Trouble Code (1st Trip DTC)	Mode 7 of ISO 15031-5
1st Trip Freeze Frame data	
Test values and Test limits	Mode 6 of ISO 15031-5
Calibration ID	Mode 9 of ISO 15031-5

The above information can be checked using procedures listed in the table below.

×: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
CONSULT-II	×	×	×	×	×	—
GST	×	×*1	×	—	×	×
ECM	×	×*2	—	—	—	—

*1: 1st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

*2: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-1030](#).)

Two Trip Detection Logic

EBS00F1S

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored. <2nd trip> The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MI, and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

×: Applicable —: Not applicable

Items	MI				DTC		1st trip DTC	
	1st trip		2nd trip		1st trip displaying	2nd trip displaying	1st trip displaying	2nd trip displaying
	Blinking	Lighting up	Blinking	Lighting up				
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	×	—	—	—	—	—	×	—
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 is being detected	—	—	×	—	—	×	—	—
Fail-safe items (Refer to EC-1030 .)	—	×	—	—	×*1	—	×*1	—
Except above	—	—	—	×	—	×	×	—

*1: Except “ECM”

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Emission-related Diagnostic Information EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

EBS00F1T

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM*3				
CAN COMM CIRCUIT	U1000	1000*6	—	—	×	EC-1083
CAN COMM CIRCUIT	U1001	1001*6	—	—	×	EC-1083
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—	—	—	—
INT/V TIM CONT-B1	P0011	0011	—	—	×	EC-1087
HO2S1 HTR (B1)	P0031	0031	×	×	×*5	EC-1090
HO2S1 HTR (B1)	P0032	0032	×	×	×*5	EC-1090
HO2S2 HTR (B1)	P0037	0037	×	×	×*5	EC-1095
HO2S2 HTR (B1)	P0038	0038	×	×	×*5	EC-1095
MAF SEN/CIRCUIT*4	P0102	0102	—	—	—	EC-1100
MAF SEN/CIRCUIT*4	P0103	0103	—	—	—	EC-1100
IAT SEN/CIRCUIT	P0112	0112	—	—	×	EC-1106
IAT SEN/CIRCUIT	P0113	0113	—	—	×	EC-1106
ECT SEN/CIRCUIT*4	P0117	0117	—	—	—	EC-1111
ECT SEN/CIRCUIT*4	P0118	0118	—	—	—	EC-1111
IAT SENSOR	P0127	0127	—	—	×	EC-1116
HO2S1 (B1)	P0132	0132	×	×	×*5	EC-1119
HO2S1 (B1)	P0133	0133	×	×	×*5	EC-1125
HO2S1 (B1)	P0134	0134	×	×	×*5	EC-1135
HO2S2 (B1)	P0138	0138	×	×	×*5	EC-1142
HO2S2 (B1)	P0139	0139	×	×	×*5	EC-1149
FUEL SYS-LEAN-B1	P0171	0171	—	—	×	EC-1157
FUEL SYS-RICH-B1	P0172	0172	—	—	×	EC-1163
TP SENSOR*4	P0221	0221	—	—	—	EC-1169
TP SEN 1/CIRC*4	P0222	0222	—	—	—	EC-1175
TP SEN 1/CIRC*4	P0223	0223	—	—	—	EC-1175
APP SENSOR*4	P0226	0226	—	—	—	EC-1181
APP SEN 1/CIRC*4	P0227	0227	—	—	—	EC-1188
APP SEN 1/CIRC*4	P0228	0228	—	—	—	EC-1188
MULTI CYL MISFIRE	P0300	0300	—	—	×	EC-1195
CYL 1 MISFIRE	P0301	0301	—	—	×	EC-1195
CYL 2 MISFIRE	P0302	0302	—	—	×	EC-1195
CYL 3 MISFIRE	P0303	0303	—	—	×	EC-1195
CYL 4 MISFIRE	P0304	0304	—	—	×	EC-1195
KNOCK SEN/CIRC-B1	P0327	0327	—	—	×	EC-1201
KNOCK SEN/CIRC-B1	P0328	0328	—	—	×	EC-1201
CKP SEN/CIRCUIT	P0335	0335	—	—	×	EC-1205

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM*3				
CMP SEN/CIRC-B1	P0340	0340	—	—	×	EC-1212
TW CATALYST SYS-B1	P0420	0420	×	×	×*5	EC-1218
PURG VOLUME CONT/V	P0444	0444	—	—	×	EC-1222
PURG VOLUME CONT/V	P0445	0445	—	—	×	EC-1222
VEH SPEED SEN/CIRC	P0500	0500	—	—	×	EC-1228
PW ST P SEN/CIRC	P0550	0550	—	—	×	EC-1230
ECM	P0605	0605	—	—	×	EC-1235
IN PY SPD SEN/CIRC	P0715	0715	—	—	×	CVT-78
TCC SOLENOID/CIRC	P0740	0740	—	—	×	CVT-89
L/PRESS SOL/CIRC	P0745	0745	—	—	×	CVT-94
ECM BACK UP/CIRC	P1065	1065	—	—	×	EC-1238
INT/V TIM V/CIR-B1	P1111	1111	—	—	×	EC-1242
ETC ACTR*4	P1121	1121	—	—	—	EC-1246
ETC FUNCTION/CIRC*4	P1122	1122	—	—	—	EC-1248
ETC MOT PWR*4	P1124	1124	—	—	×	EC-1255
ETC MOT PWR*4	P1126	1126	—	—	—	EC-1255
ETC MOT*4	P1128	1128	—	—	—	EC-1261
HO2S1 (B1)	P1143	1143	×	×	×*5	EC-1266
HO2S1 (B1)	P1144	1144	×	×	×*5	EC-1272
HO2S2 (B1)	P1146	1146	×	×	×*5	EC-1278
HO2S2 (B1)	P1147	1147	×	×	×*5	EC-1286
TCS/CIRC*8	P1212	1212	—	—	×	EC-1294
ENG OVER TEMP	P1217	1217	—	—	×	EC-1295
TP SEN 2/CIRC*4	P1223	1223	—	—	—	EC-1312
TP SEN 2/CIRC*4	P1224	1224	—	—	—	EC-1312
CTP LEARNING	P1225	1225	—	—	×	EC-1318
CTP LEARNING	P1226	1226	—	—	×	EC-1320
APP SEN 2/CIRC*4	P1227	1227	—	—	—	EC-1322
APP SEN 2/CIRC*4	P1228	1228	—	—	—	EC-1322
SENSOR POWER/CIRC*4	P1229	1229	—	—	—	EC-1329
ASCD SW*7	P1564	1564	—	—	×	EC-1333
ACC COMMAND VALUE*7	P1568	1568	—	—	—	EC-1340
ASCD BRAKE SW*7	P1572	1572	—	—	×	EC-1341
ASCD VHL SPD SEN*7	P1574	1574	—	—	×	EC-1351
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	—	—	×	EC-1016
P-N POS SW/CIRCUIT	P1706	1706	—	—	×	EC-1353
IN PULY SPEED	P1715	1715	—	—	×	
OUT PULY SPEED	P1720	1720	—	—	×	EC-1358

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		SRT code	Test Valve/ Test Limit (GST only)	1st trip DTC	Reference page
	CONSULT-II GST*2	ECM*3				
STEP MOTR CIRC	P1777	1777	—	—	×	CVT-108
STEP MOTR FNC	P1778	1778	—	—	×	CVT-111
LINE PRESS SEN	P1791	1791	—	—	×	CVT-113
BRAKE SW/CIRCUIT	P1805	1805	—	—	×	EC-1360

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When the fail-safe operation occurs, the MI illuminates.

*5: These are not displayed with GST.

*6: The troubleshooting for these DTCs needs CONSULT-II.

*7: For models with ICC system.

*8: For models with ESP system.

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MI during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

For malfunctions in which 1st trip DTCs are displayed, refer to [EC-1005](#). These items are required by legal regulations to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT-II.

1st trip DTC is specified in Mode 7 of ISO 15031-5. 1st trip DTC detection occurs without lighting up the MI and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to [EC-1026](#). Then perform "DTC Confirmation Procedure" or "Overall Function Check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

 **With CONSULT-II**

 **With GST**

CONSULT-II or GST (Generic Scan Tool) Examples: P0340, P0740, P0745, etc.

These DTCs are prescribed by ISO 15031-5.

(CONSULT-II also displays the malfunctioning component or system.)

 **No Tools**

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0102, 0340 etc.

These DTCs are controlled by NISSAN.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, GST or the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display	SELF DIAG RESULTS	
	DTC RESULTS	TIME		DTC RESULTS	TIME
	CKP SEN/CIRCUIT [P0335]	0		CKP SEN/CIRCUIT [P0335]	1t

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For details, see [EC-1058](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 Fuel Injection System Function — DTC: P0171, P0172
2		Except the above items (Includes CVT related items)
3	1st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-1015, "HOW TO ERASE EMIS-SION-RELATED DIAGNOSTIC INFORMATION"](#).

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of ISO 15031-5.

As part of an enhanced emissions test for Inspection & Maintenance (I/M), certain states require the status of SRT be used to indicate whether the ECM has completed self-diagnosis of major emission systems and components. Completion must be verified in order for the emissions inspection to proceed.

If a vehicle is rejected for a State emissions inspection due to one or more SRT items indicating "INCMP", use the information in this Service Manual to set the SRT to "CMPLT".

In most cases the ECM will automatically complete its self-diagnosis cycle during normal usage, and the SRT status will indicate "CMPLT" for each application system. Once set as "CMPLT", the SRT status remains "CMPLT" until the self-diagnosis memory is erased.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Occasionally, certain portions of the self-diagnostic test may not be completed as a result of the customer's normal driving pattern; the SRT will indicate "INCMP" for these items.

NOTE:

The SRT will also indicate "INCMP" if the self-diagnosis memory is erased for any reason or if the ECM memory power supply is interrupted for several hours.

If, during the state emissions inspection, the SRT indicates "CMPLT" for all test items, the inspector will continue with the emissions test. However, if the SRT indicates "INCMP" for one or more of the SRT items the vehicle is returned to the customer untested.

NOTE:

If MI is "ON" during the state emissions inspection, the vehicle is also returned to the customer untested even though the SRT indicates "CMPLT" for all test items. Therefore, it is important to check SRT ("CMPLT") and DTC (No DTCs) before the inspection.

SRT Item

The table below shows required self-diagnostic items to set the SRT to "CMPLT".

SRT item (CONSULT-II indication)	Performance Priority*	Required self-diagnostic items to set the SRT to "CMPLT"	Corresponding DTC No.
CATALYST	2	Three way catalyst function	P0420
HO2S	1	Heated oxygen sensor 1	P0132
		Heated oxygen sensor 1	P0133
		Heated oxygen sensor 1	P0134
		Heated oxygen sensor 1	P1143
		Heated oxygen sensor 1	P1144
		Heated oxygen sensor 2	P0138
		Heated oxygen sensor 2	P0139
		Heated oxygen sensor 2	P1146
HO2S HTR	1	Heated oxygen sensor 1 heater	P0031, P0032
		Heated oxygen sensor 2 heater	P0037, P0038

*: If completion of several SRTs is required, perform driving patterns (DTC confirmation procedure), one by one based on the priority for models with CONSULT-II.

SRT Set Timing

SRT is set as "CMPLT" after self-diagnosis has been performed one or more times. Completion of SRT is done regardless of whether the result is OK or NG. The set timing is different between OK and NG results and is shown in the table below.

Self-diagnosis result		Example					
		Diagnosis	Ignition cycle				← ON →
← ON →	OFF		← ON →	OFF	← ON →	OFF	
All OK	Case 1	P0400	OK (1)	— (1)	OK (2)	— (2)	
		P0402	OK (1)	— (1)	— (1)	OK (2)	
		P1402	OK (1)	OK (2)	— (2)	— (2)	
		SRT of EGR	"CMPLT"	"CMPLT"	"CMPLT"	"CMPLT"	
	Case 2	P0400	OK (1)	— (1)	— (1)	— (1)	
		P0402	— (0)	— (0)	OK (1)	— (1)	
		P1402	OK (1)	OK (2)	— (2)	— (2)	
		SRT of EGR	"INCMP"	"INCMP"	"CMPLT"	"CMPLT"	

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Self-diagnosis result		Example						
		Diagnosis	Ignition cycle					
			← ON →	OFF	← ON →	OFF	← ON →	OFF
NG exists	Case 3	P0400	OK	OK	—	—	—	—
		P0402	—	—	—	—	—	—
		P1402	NG	—	NG	NG	NG	NG (Consecutive NG)
		(1st trip) DTC	1st trip DTC	—	1st trip DTC	DTC (= MI "ON")		
		SRT of EGR	"INCMP"	"INCMP"	"INCMP"	"CMPLT"		

OK: Self-diagnosis is carried out and the result is OK.

NG: Self-diagnosis is carried out and the result is NG.

—: Self-diagnosis is not carried out.

When all SRT related self-diagnoses showed OK results in a single cycle (Ignition OFF-ON-OFF), the SRT will indicate "CMPLT". → Case 1 above

When all SRT related self-diagnoses showed OK results through several different cycles, the SRT will indicate "CMPLT" at the time the respective self-diagnoses have at least one OK result. → Case 2 above

If one or more SRT related self-diagnoses showed NG results in 2 consecutive cycles, the SRT will also indicate "CMPLT". → Case 3 above

The table above shows that the minimum number of cycles for setting SRT as "INCMP" is one (1) for each self-diagnosis (Case 1 & 2) or two (2) for one of self-diagnoses (Case 3). However, in preparation for the state emissions inspection, it is unnecessary for each self-diagnosis to be executed twice (Case 3) for the following reasons:

- The SRT will indicate "CMPLT" at the time the respective self-diagnoses have one (1) OK result.
- The emissions inspection requires "CMPLT" of the SRT only with OK self-diagnosis results.
- When, during SRT driving pattern, 1st trip DTC (NG) is detected prior to "CMPLT" of SRT, the self-diagnosis memory must be erased from ECM after repair.
- If the 1st trip DTC is erased, all the SRT will indicate "INCMP".

NOTE:

SRT can be set as "CMPLT" together with the DTC(s). Therefore, DTC check must always be carried out prior to the state emission inspection even though the SRT indicates "CMPLT".


SRT Service Procedure

If a vehicle has failed the state emissions inspection due to one or more SRT items indicating "INCMP", review the flowchart diagnostic sequence on the next page.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

A
EC
C
D
E
F
G
H
I
J
K
L
M



SEF573XB

*1 [EC-1007](#)

*2 [EC-1011](#)

*3 [EC-1009](#)

How to Display SRT Code

WITH CONSULT-II

Selecting "SRT STATUS" in "DTC CONFIRMATION" mode with CONSULT-II.

For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT-II screen; for items whose SRT codes are not set, "INCMP" is displayed.

A sample of CONSULT-II display for SRT code is shown at right.

"INCMP" means the self-diagnosis is incomplete and SRT is not set.

"CMPLT" means the self-diagnosis is complete and SRT is set.

WITH GST

Selecting Mode 1 with GST (Generic Scan Tool)

SRT STATUS	
CATALYST	CMPLT
H02S HTR	CMPLT
H02S	CMPLT

PBIB0666E

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

How to Set SRT Code

To set all SRT codes, self-diagnosis for the items indicated above must be performed one or more times. Each diagnosis may require a long period of actual driving under various conditions.

WITH CONSULT-II


Perform corresponding DTC Confirmation Procedure one by one based on "Performance Priority" in the table on [EC-1009](#).

WITHOUT CONSULT-II

The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed one or more times to set all SRT codes.

Driving Pattern

Note: Always drive vehicle in safe manner according to traffic conditions and obey all traffic laws. Refer to next page for more information and explanation of chart.



A
EC
C
D
E
F
G
H
I
J
K
L
M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

- The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.
Zone A refers to the range where the time, required for the diagnosis under normal conditions*, is the shortest.
Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

*: Normal conditions refer to the following:

- Sea level
- Flat road
- Ambient air temperature: 20 - 30°C (68 - 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.
Under different conditions [For example: ambient air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1:

- **The engine is started at the engine coolant temperature of –10 to 35°C (14 to 95°F) (where the voltage between the ECM terminal 72 and ground is 3.0 - 4.3V).**
- **The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminal 72 and ground is lower than 1.4V).**

Pattern 2:

- When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Checking the vehicle speed with GST is advised.

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of ISO 15031-5.

The test value is a parameter used to determine whether a system/circuit diagnostic test is “OK” or “NG” while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

×: Applicable —: Not applicable

SRT item	Self-diagnostic test item	Test value (GST display)		Test limit	Application
		TID	CID		
CATALYST	Three way catalyst function	01H	01H	Max.	×
HO2S	Heated oxygen sensor 1	09H	04H	Max.	×
		0AH	84H	Min.	×
		0BH	04H	Max.	×
		0CH	04H	Max.	×
		0DH	04H	Max.	×
	Heated oxygen sensor 2	19H	86H	Min.	×
		1AH	86H	Min.	×
		1BH	06H	Max.	×
HO2S HTR	Heated oxygen sensor 1 heater	1CH	06H	Max.	×
		29H	08H	Max.	×
	Heated oxygen sensor 2 heater	2AH	88H	Min.	×
		2DH	0AH	Max.	×
		2EH	8AH	Min.	×

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)


The emission related diagnostic information in the ECM can be erased by selecting “ERASE” in the “SELF-DIAG RESULTS” mode with CONSULT-II.

If DTCs are displayed for both ECM and TCM (Transmission control module), they need to be erased individually from the ECM and TCM (Transmission control module).

NOTE:

If the DTC is not for CVT related items (see [EC-959](#)), skip steps 2 through 4.

1. If the ignition switch stays “ON” after repair work, be sure to turn ignition switch “OFF” once. Wait at least 10 seconds and then turn it “ON” (engine stopped) again.
2. Turn CONSULT-II “ON” and touch “CVT”.
3. Touch “SELF-DIAG RESULTS”.
4. Touch “ERASE”. [The DTC in the TCM (Transmission control module) will be erased.] Then touch “BACK” twice.
5. Touch “ENGINE”.
6. Touch “SELF-DIAG RESULTS”.
7. Touch “ERASE”. (The DTC in the ECM will be erased.)



How to Erase DTC (With GST)

The emission related diagnostic information in the ECM can be erased by selecting Mode 4 with GST.

NOTE:

If the DTC is not for CVT related items (see [EC-959](#)), skip step 2.

1. If the ignition switch stays “ON” after repair work, be sure to turn ignition switch “OFF” once. Wait at least 10 seconds and then turn it “ON” (engine stopped) again.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT-II)" in CVT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with GST (Generic Scan Tool).

How to Erase DTC (No Tools)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once.
2. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
3. Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-1017, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

● If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.

● The following data are cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

NATS (Nissan Anti-theft System)

EBS00F1U

● If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-156, "NATS \(NISSAN ANTI-THEFT SYSTEM\)"](#) .

● Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.

● When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.

Therefore, be sure to receive all keys from vehicle owner.

Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF515Y


Malfunction Indicator (MI)

DESCRIPTION

EBS00F1V

The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
- If the MI does not light up, refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1406](#) .
2. When the engine is started, the MI should go off.
If the MI remains on, the on board diagnostic system has detected an engine system malfunction.









ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MI in the 1st trip. <ul style="list-style-type: none"> ● "Misfire (Possible three way catalyst damage)" ● Fail-safe mode
Mode II	Ignition switch in "ON" position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1, to be read.

MI Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode. [EC-1017, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

How to switch the diagnostic test (function) modes, and details of the above functions are described later, [EC-1017](#) .

The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- Others

HOW TO SWITCH DIAGNOSTIC TEST MODE

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned "OFF".


How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

2. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
4. Fully release the accelerator pedal.
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).



How to Set Diagnostic Test Mode II (Heated Oxygen Sensor 1 Monitor)

1. Set the ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-1017, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Start Engine.
ECM has entered to Diagnostic Test Mode II (Heated oxygen sensor 1 monitor).

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-1017, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1406](#).

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)


DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below. The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

codes can be identified by using the CONSULT-II or GST. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC “0000” refers to no malfunction. (See [EC-959, "INDEX FOR DTC"](#))

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-1017, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).

- If the battery is disconnected, the DTC will be lost from the backup memory after approx 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

DIAGNOSTIC TEST MODE II — HEATED OXYGEN SENSOR 1 MONITOR

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1.

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

RELATIONSHIP BETWEEN MI, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

EBS00F1W

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MI will come on. For details, refer to [EC-1004, "Two Trip Detection Logic"](#).
- The MI will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting, the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT-II will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

Items	Fuel Injection System	Misfire	Other
MI (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)

For details about patterns "B" and "C" under "Fuel Injection System" and "Misfire", see [EC-1022](#).

For details about patterns "A" and "B" under "Other", see [EC-1024](#).


*1: Clear timing is at the moment OK is detected.

*2: Clear timing is when the same malfunction is detected in the 2nd trip.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MI will light up.

*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

- | | | |
|--|---|---|
| *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.) | *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM. | *6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected. |
| *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared. | *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM. | |

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunction.
- The MI will go off when the B counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

<Driving Pattern C>

Driving pattern C means the vehicle operation as follows:

1. The following conditions should be satisfied at the same time:

Engine speed: (Engine speed in the freeze frame data) ± 375 rpm

Calculated load value: (Calculated load value in the freeze frame data) $\times (1 \pm 0.1)$ [%]

Engine coolant temperature (T) condition:

- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)

To be satisfied with driving pattern C, the vehicle should run under the following conditions:


Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

RELATIONSHIP BETWEEN MI, DTC, 1ST TRIP DTC AND DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



*1: When the same malfunction is detected in two consecutive trips, MI will light up.

*2: MI will go off after vehicle is driven 3 times (pattern B) without any malfunctions.

*3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.

*4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)

*5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.

*6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.


*7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITH EURO-OBD)]

EXPLANATION FOR DRIVING PATTERNS EXCEPT FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

<Driving Pattern A>



- The A counter will be cleared when the malfunction is detected regardless of (1) - (4).
- The A counter will be counted up when (1) - (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

<Driving Pattern B>

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MI will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").

TROUBLE DIAGNOSIS

PFP:00004

Trouble Diagnosis Introduction
INTRODUCTION

EBS00F1X




The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-1026](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on [EC-1029](#) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.




A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

WORK FLOW

Flow Chart



MBIB0159E

*1 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*2 If the incident cannot be verified, perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-1077, "POWER SUPPLY CIRCUIT FOR ECM"](#) .

*4 If malfunctioning part cannot be detected, perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*5 [EC-1013](#)

*6 [EC-1072](#)

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-1028 .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II or GST) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-1015 .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-1037 .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II or GST. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-1032 .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS – SPECIFICATION VALUE". (Refer to EC-1072 .) (If malfunction is detected, proceed to "PERAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-1037 .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-1047 , EC-1067 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident" . Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM and TCM (Transmission control module). (Refer to EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" and CVT-21, "HOW TO ERASE DTC" .)

DIAGNOSTIC WORKSHEET

Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model

WHEN Date, Frequencies

WHERE..... Road conditions

HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● U1000 U1001 CAN communication line ● P0102 P0103 Mass air flow sensor ● P0112 P0113 P0127 Intake air temperature sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0500 Vehicle speed sensor ● P0605 ECM ● P1229 Sensor power supply ● P1610-P1615 NATS ● P1706 Park/Neutral position (PNP) switch
2	<ul style="list-style-type: none"> ● P0031 P0032 Heated oxygen sensor 1 heater ● P0037 P0038 Heated oxygen sensor 2 heater ● P0132 P0133 P0134 P1143 P1144 Heated oxygen sensor 1 ● P0138 P0139 P1146 P1147 Heated oxygen sensor 2 ● P0444 P0445 EVAP canister purge volume control solenoid valve ● P0550 Power steering pressure sensor ● P0715 P0740 P0745 P1715 P1777 P1791 CVT related sensors and solenoid valves ● P1065 ECM power supply ● P1111 Intake valve timing control solenoid valve ● P1122 Electric throttle control function ● P1124 P1126 Throttle control motor relay ● P1128 Throttle control mother ● P1212 ESP/TCS/ABS communication line ● P1720 Vehicle speed sensor ● P1805 Brake switch
3	<ul style="list-style-type: none"> ● P0011 Intake valve timing control ● P0171 P0172 Fuel injection system function ● P0300 - P0304 Misfire ● P0420 Three way catalyst function ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT) ● P1564 ICC steering switch ● P1568 ICC command value ● P1572 ICC brake switch ● P1574 ICC vehicle speed sensor ● P1778 CVT step motor

Fail-safe Chart

EBS00F1Z

When the DTC listed bellow is detected, the ECM enters fail-safe mode and the MI lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

TROUBLE DIAGNOSIS



[QR (WITH EURO-OBD)]

DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0117 P0118	Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.								
		<table border="1"> <thead> <tr> <th>Condition</th> <th>Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td>40°C (104°F)</td> </tr> <tr> <td>More than approx. 4 minutes after ignition ON or Start</td> <td>80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td>40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or Start	40°C (104°F)	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
		Condition	Engine coolant temperature decided (CONSULT-II display)							
		Just as ignition switch is turned ON or Start	40°C (104°F)							
		More than approx. 4 minutes after ignition ON or Start	80°C (176°F)							
		Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)							
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.										
P0221 P0222 P0223 P1223 P1224	Throttle position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.								
P0226 P0227 P0228 P1227 P1228	Accelerator pedal position sensor	The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.								
P1121	Electric throttle control actuator (ECM detect the throttle valve is stuck open.)	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.								
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.								

A
EC
C
D
E
F
G
H
I
J
K
L
M

Basic Inspection**1. INSPECTION START**


1. Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.
2. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
3. Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
4. Start engine and warm it up until engine coolant temperature indicator points the middle of gauge. Ensure engine stays below 1,000 rpm.



5. Run engine at about 2,000 rpm for about 2 minutes under no-load.
6. Make sure that no DTC is displayed with CONSULT-II or GST.

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.


**2. REPAIR OR REPLACE**

Repair or replace components as necessary according to corresponding "Diagnostic Procedure".

>> GO TO 3

3. CHECK TARGET IDLE SPEED**With CONSULT-II**

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.
3. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 4.

4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 5.

5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 6.

6. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-999, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 7.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

7. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 10.

NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the Following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-1212](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-1205](#) .

OK or NG

OK >> GO TO 9.

NG >> 1. Repair or replace.

2. GO TO 4.

9. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-1016, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

10. CHECK IGNITION TIMING

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $14 \pm 5^\circ$ BTDC

CVT: $15 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 11.

11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 12.

12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 13.

13. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-999, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP?

CMPLT or INCMP

CMPLT >> GO TO 14.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

14. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 15.

NG >> GO TO 17.

15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $14 \pm 5^\circ$ BTDC

CVT: $15 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 16.

16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-143, "TIMING CHAIN"](#) .

OK or NG

OK >> GO TO 17.

NG >> 1. Repair the timing chain installation.
2. GO TO 4.

17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-1212](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-1205](#) .

OK or NG

OK >> GO TO 18.

NG >> 1. Repair or replace.
2. GO TO 4.

18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-1016, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

EBS00F21

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-1381
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-1001
	Injector circuit	1	1	2	3	2		2	2			2			EC-1375
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-1408
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-1411
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-1032
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	EC-1246 , EC-1248 , EC-1255 , EC-1261
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-1032
	Ignition circuit	1	1	2	2	2		2	2			2			EC-1365
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3			EC-1077
Mass air flow sensor circuit		1	1	2	2	2		2	2			2			EC-1100
Engine coolant temperature sensor circuit		1	1	2	2	2	3	2	2	3	1	2			EC-1111
Throttle position sensor circuit			1	2		2	2	2	2	2		2			EC-1169 , EC-1175 , EC-1312 , EC-1318 , EC-1320 , EC-1329
Accelerator pedal position sensor circuit				3	2	1	2			2					EC-1181 , EC-1188 , EC-1322
Heated oxygen sensor 1 circuit			1	2	3	2		2	2			2			EC-1119 , EC-1125 , EC-1135 , EC-1266 , EC-1272
Knock sensor circuit				2	2							3			EC-1201
Crankshaft position sensor (POS) circuit		2	2												EC-1205
Camshaft position sensor (PHASE) circuit		2	2												EC-1212
Vehicle speed signal circuit			2	3		3						3			EC-1228

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Power steering pressure sensor circuit		2				3	3	3	3					EC-1230
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-1235 , EC-1238
Intake valve timing control solenoid valve circuit	3	3	2		1	3	2	2	3		3			EC-1242
PNP switch circuit			3		3	3	3	3	3		3			EC-1353
Refrigerant pressure sensor circuit		2				3	3	3	3		4			EC-1387
Electrical load signal circuit						3	3	3	3					EC-1392
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	ATC-30

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

SYSTEM — ENGINE MECHANICAL & OTHER

		SYMPTOM													Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)		
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Fuel	Fuel tank		5												FL-13	
	Fuel piping	5		5	5		5	5				5			MA-23 , EM-128	
	Vapor lock															—
	Valve deposit															—
	Poor fuel (Heavy weight gasoline, Low octane)	5		5	5	5		5	5				5			—

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Air	Air duct														EM-114
	Air cleaner														EM-114
	Air leakage from air duct (Mass air flow sensor —electric throttle control actuator)	5	5	5		5		5	5			5			EM-114
	Electric throttle control actuator	5			5		5			5					EM-116
	Air leakage from intake manifold/ Collector/Gasket														EM-116
Cranking	Battery	1	1	1		1		1	1			1		1	SC-3
	Alternator circuit														SC-12
	Starter circuit	3													SC-22
	Signal plate/Flywheel/Drive plate	6													EM-165
	PNP switch	4													MT-126 or CVT-67
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM-152
	Cylinder head gasket										4	3			
	Cylinder block														
	Piston												4		
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			EM-165
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM-143
	Camshaft														EM-133
	Intake valve timing control	5	5	5	5	5		5	5			5			EM-143
	Intake valve														
	Exhaust valve												3		EM-152
Exhaust	Exhaust manifold/Tube/Muffler/ Gasket	5	5	5	5	5		5	5			5			EM-121 , EX-3
	Three way catalyst														

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]


		SYMPTOM												Reference page			
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)		
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA			
Lubrica- tion	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5	2		EM-123 , LU-18 , LU-19 , LU-14		
	Oil level (Low)/Filthy oil															LU-16	
Cooling	Radiator/Hose/Radiator filler cap															CO-31	
	Thermostat									5						CO-40	
	Water pump															CO-38	
	Water gallery	5	5	5	5	5		5	5		2	5				CO-27	
	Cooling fan									5							CO-31
	Coolant level (low)/Contaminated coolant																CO-29
NATS (Nissan Anti-theft System)		1	1													EC-1016 or BL-156	

1 - 6: The numbers refer to the order of inspection.

Engine Control Component Parts Location

EBS00F22









A
EC
C
D
E
F
G
H
I
J
K
L
M



MBIB0070E









TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]



MBIB0147E







A
EC
C
D
E
F
G
H
I
J
K
L
M



MBIB0148E

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]




MBIB0149E

Circuit Diagram

EBS00F23


A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0001E

TROUBLE DIAGNOSIS


[QR (WITH EURO-OBD)]



MBWA0002E

ECM Harness Connector Terminal Layout

EBS00F24




MBIB0045E

ECM Terminals and Reference Value PREPARATION


EBS00F25

1. ECM is located behind the glove box. For this inspection, remove glove box.
2. Remove ECM harness protector.



MBIB0155E

3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown at right.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



MBIB0145E

ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground.





CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground





TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/W	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,800 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,800 rpm 	BATTERY VOLTAGE (11 - 14V)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  <small>10.0 V/Div 200 us/Div</small>
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  <small>10.0 V/Div 200 us/Div</small>
12	Y	Power steering pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	0.5 - 4.0V
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	0.4 - 0.8V
13	L	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 3.0V★  <small>5 V/Div 1 ms/Div</small>
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 3.0V★  <small>5.0 V/Div 1 ms/Div</small>

TROUBLE DIAGNOSIS




[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	L	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0526E</p>
15	W	Knock sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	Approximately 2.5V
16	W/Y	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
19	P	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>

A
EC
C
D
E
F
G
H
I
J
K
L
M





TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B SB L R/W	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  PBIB0529E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★  PBIB0530E
24	P/L	Heated oxygen sensor 1 heater	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm. 	Approximately 7.0V  PBIB0519E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)
34	G	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
35	PU	Heated oxygen sensor 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
45	R	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
46	R	Sensor's power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
47	G	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	Less than 4.75V

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.1 - 1.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.6 - 2.0V
54	W	Sensors' ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
55	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
60 61 79 80	L/Y Y/R GY/L PU/G	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.1V★  PBIB0521E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - 0.2V★  PBIB0522E
62	Y	Intake valve timing control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)  MBIB0052E
			[Engine is running] ● Warm-up condition ● When revving engine up to 2,000 rpm quickly	Approximately 4V - BATTERY VOLTAGE (11 - 14V)★  PBIB0532E
65	R	Sensor's power supply (Power steering pres- sure sensor)	[Ignition switch "ON"]	Approximately 5V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
68	R	Throttle position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	Less than 4.75V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	More than 0.36V
69	L	Refrigerant pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.) 	1.0 - 4.0V
72	L/OR	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.
74	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
82*2	B	Sensor's ground (ICC steering switch)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Lighting switch is "2ND" position 	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Lighting switch is "OFF" 	Approximately 0V
85	LG	DATA link connector	[Ignition switch "ON"] <ul style="list-style-type: none"> ● CONSULT-II or GST is disconnected. 	BATTERY VOLTAGE (11 - 14V)
86	R	CAN communication line	[Ignition switch "ON"]	1.0 - 2.5V
92*1	GY	Accelerator pedal position sensor signal output	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	Approximately 0.5V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	Approximately 4.2V
94	L	CAN communication line	[Ignition switch "ON"]	2.5 - 4.0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.175 - 0.335V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 1.95V

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
99*2	PU	ICC steering switch	[Ignition switch "ON"] ● ICC steering switch is "OFF".	Approximately 4.3V
			[Ignition switch "ON"] ● ON/OFF switch is "ON".	Approximately 0V
			[Ignition switch "ON"] ● CANCEL switch is "ON".	Approximately 1.3V
			[Ignition switch "ON"] ● DISTANCE switch is "ON".	Approximately 2.2V
			[Ignition switch "ON"] ● SET/COAST switch is "ON".	Approximately 3V
			[Ignition switch "ON"] ● RESUME/ACCEL switch is "ON".	Approximately 3.7V
101	R/G	Stop lamp switch	[Ignition switch "ON"] ● Brake pedal fully released	Approximately 0V
			[Ignition switch "ON"] ● Brake pedal fully depressed	BATTERY VOLTAGE (11 - 14V)
102	P (CVT) L (M/T)	PNP switch	[Ignition switch "ON"] ● Gear position is "P" or "N"	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	CVT models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V
103*1	L/OR	Tachometer signal output	[Engine is running] ● Warm-up condition ● Idle speed	10 - 11V★  MBIB0053E
			[Engine is running] ● Engine speed is 2,000 rpm	10 - 11V★  MBIB0054E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.35 - 0.67V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 3.9V
108*2	R	ICC brake switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal is depressed 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal is fully released 	BATTERY VOLTAGE (11 - 14V)
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch "OFF" 	0 - 1.0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● 5 seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
113	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch "ON" 	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] <ul style="list-style-type: none"> ● More than 1 seconds after turning ignition switch "ON". 	BATTERY VOLTAGE (11 - 14V)
115 116	B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Engine ground
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*1: CVT models

*2: Models with ICC system

CONSULT-II Function FUNCTION

EBS00F26

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Diagnostic test mode	Function
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
DTC & SRT confirmation	The status of system monitoring tests and the self-diagnosis status/result can be confirmed.
ECM part number	ECM part number can be read.

*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values
- Others

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

Item	DIAGNOSTIC TEST MODE							
	WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONITOR	DATA MONITOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
		DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS INPUT	Crankshaft position sensor (POS)	×	×	×	×			
	Camshaft position sensor (PHASE)	×		×	×			
	Mass air flow sensor	×		×	×			
	Engine coolant temperature sensor	×	×	×	×	×		
	Heated oxygen sensor 1	×		×	×		×	×
	Heated oxygen sensor 2	×		×	×		×	×
	Vehicle speed signal	×	×	×	×			
	Accelerator pedal position sensor	×		×	×			
	Throttle position sensor	×		×	×			
	Intake air temperature sensor	×		×	×			
	Knock sensor	×						
	Refrigerant pressure sensor			×	×			
	Closed throttle position switch (accelerator pedal position sensor signal)			×	×			
	Air conditioner switch			×	×			
	Park/neutral position (PNP) switch	×		×	×			
	Stop lamp switch	×		×	×			
	Power steering pressure sensor	×		×	×			
	Battery voltage			×	×			
	Electrical load signal			×	×			
ICC steering switch	×		×	×				
ICC brake switch	×		×	×				

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBDD)]

Item		DIAGNOSTIC TEST MODE							
		WORK SUP-PORT	SELF-DIAGNOSTIC RESULTS		DATA MONI-TOR	DATA MONI-TOR (SPEC)	ACTIVE TEST	DTC & SRT CONFIRMATION	
			DTC*1	FREEZE FRAME DATA*2				SRT STATUS	DTC WORK SUP-PORT
ENGINE CONTROL COMPONENT PARTS OUTPUT	Injectors				×	×	×		
	Power transistor (Ignition timing)				×	×	×		
	Throttle control motor relay		×		×	×			
	Throttle control motor		×						
	EVAP canister purge volume control solenoid valve		×		×	×	×		×
	Air conditioner relay				×	×			
	Fuel pump relay	×			×	×	×		
	Cooling fan relay		×		×	×	×		
	Heated oxygen sensor 1 heater		×		×	×		×	
	Heated oxygen sensor 2 heater		×		×	×		×	
	Intake valve timing control solenoid valve		×		×	×	×		
	Calculated load value			×	×	×			


X: Applicable

*1: This item includes 1st trip DTCs.


*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-1008](#).

CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "CONSULT-II" to data link connector, which is located under drivers side dash panel.
3. Turn ignition switch ON.




4. Touch "START".



TROUBLE DIAGNOSIS


[QR (WITH EURO-OBD)]

5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM. 	When learning the idle air volume
SELF-LEARNING CONT	<ul style="list-style-type: none"> THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> IDLE CONDITION 	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> IDLE CONDITION 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light.

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to [EC-959, "INDEX FOR DTC"](#) .)

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-959, "INDEX FOR DTC" .)
FUEL SYS-B1	<ul style="list-style-type: none"> "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. <ul style="list-style-type: none"> "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	<ul style="list-style-type: none"> The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> The vehicle speed at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> The intake air temperature at the moment a malfunction is detected is displayed.

*: The items are the same as those of 1st trip freeze frame data.

DATA MONITOR MODE

Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIGNALS	MAIN SIGNALS	CAN DIAG SUPPORT MNTR	Description	Remarks
ENG SPEED [rpm]	×	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signals of the crankshaft position sensor (POS) and camshaft position sensor (PHASE). 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		×		<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		×		<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
COOLAN TEMP/S [°C] or [°F]	×	×		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S2 (B1) [V]	×			<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S1 MNTR (B1) [RICH/LEAN]	×	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S2 MNTR (B1) [RICH/LEAN]	×			<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
VHCL SPEED SE [km/h] or [mph]	×	×		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	
BATTERY VOLT [V]	×	×		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
ACCEL SEN 1 [V]	×	×		<ul style="list-style-type: none"> The accelerator pedal position sensor signal voltage is displayed. 	
ACCEL SEN 2 [V]	×				
THRTL SEN 1 [V]	×	×		<ul style="list-style-type: none"> The throttle position sensor signal voltage is displayed. 	
THRTL SEN 2 [V]	×				
INT/A TEMP SE [°C] or [°F]	×	×		<ul style="list-style-type: none"> The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated. 	
START SIGNAL [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage. 	<ul style="list-style-type: none"> After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates idle position [ON/OFF] computed by the ECM according to the accelerator pedal position sensor signal. 	
AIR COND SIG [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal. 	
P/N POSI SW [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal. 	

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
PW/ST SIGNAL [ON/OFF]	×	×		<ul style="list-style-type: none"> ● [ON/OFF] condition of the power steering oil pressure switch as determined by the power steering oil pressure signal is indicated. 	
LOAD SIGNAL [ON/OFF]	×	×		<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition from the electrical load signal. ON ... Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF ... Both rear window defogger switch and lighting switch are OFF. 	
IGNITION SW [ON/OFF]	×			<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition from ignition switch. 	
HEATER FAN SW [ON/OFF]	×			<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition from the heater fan switch signal. 	
BRAKE SW [ON/OFF]	×			<ul style="list-style-type: none"> ● Indicates [ON/OFF] condition from the stop lamp switch signal. 	
INJ PULSE-B1 [msec]		×		<ul style="list-style-type: none"> ● Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	<ul style="list-style-type: none"> ● When the engine is stopped, a certain computed value is indicated.
IGN TIMING [BTDC]		×		<ul style="list-style-type: none"> ● Indicates the ignition timing computed by ECM according to the input signals. 	<ul style="list-style-type: none"> ● When the engine is stopped, a certain value is indicated.
CAL/LD VALUE [%]				<ul style="list-style-type: none"> ● "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	
MASS AIRFLOW [g·m/s]				<ul style="list-style-type: none"> ● Indicates the mass airflow computed by ECM according to the signal voltage of the mass air flow sensor. 	
PURG VOL C/V [%]				<ul style="list-style-type: none"> ● Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. ● The opening becomes larger as the value increases. 	
INT/V TIM (B1) [°CA]				<ul style="list-style-type: none"> ● Indicates [°CA] of intake camshaft advanced angle. 	
INT/V SOL (B1) [%]				<ul style="list-style-type: none"> ● The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
AIR COND RLY [ON/OFF]		×		<ul style="list-style-type: none"> ● The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. 	
FUEL PUMP RLY [ON/OFF]		×		<ul style="list-style-type: none"> ● Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
THRTL RELAY [ON/OFF]		×		<ul style="list-style-type: none"> Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]				<ul style="list-style-type: none"> Indicates the condition of the cooling fan (determined by ECM according to the input signals). HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	
HO2S1 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
I/P PULLY SPD [rpm]	×			<ul style="list-style-type: none"> Indicates the engine speed computed from the primary speed sensor signal. 	
VEHICLE SPEED [km/h] or [mph]	×			<ul style="list-style-type: none"> Indicates the vehicle speed computed from the secondary speed sensor signal. 	
IDL A/V LEARN [YET/CMPLT/ INCMP]				<ul style="list-style-type: none"> Display the condition of idle air volume learning YET ... Idle air volume learning has not been performed yet. CMPLT ... Idle air volume learning has already been performed successfully. INCMP ... Idle air volume learning has not been performed successfully. 	
TRVL AFTER MIL [km] or [mile]				<ul style="list-style-type: none"> Distance traveled while MI is activated. 	
AC PRESS SEN [V]				<ul style="list-style-type: none"> The signal voltage from the refrigerant pressure sensor is displayed. 	
VHCL SPEED SE [km/h] or [mph]				<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal sent from TCM is displayed. 	
SET VHCL SPD [km/h] or [mph]				<ul style="list-style-type: none"> The preset vehicle speed is displayed. 	
MAIN SW [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ON/OFF switch signal. 	
CANCEL SW [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from CANCEL switch signal. 	
RESUME/ACC SW [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ACCEL/RES switch signal. 	
SET SW [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from COAST/SET switch signal. 	
BRAKE SW1 [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ICC brake switch signal. 	
BRAKE SW2 [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of stop lamp switch signal. 	
DIST SW [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition from DISTANCE switch signal. 	

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
CRUISE LAMP [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of CRUISE lamp determined by the ECM according to the input signals. 	
Voltage [V]				<ul style="list-style-type: none"> Voltage, frequency, duty cycle or pulse width measured by the probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					
CAN COMM [OK/NG]			×	<ul style="list-style-type: none"> Indicates the communication condition of CAN communication line. 	<ul style="list-style-type: none"> These items are not displayed in “SELECTION FROM MENU” mode.
CAN CIRC 1 [OK/UNKWN]			×		
CAN CIRC 2 [OK/UNKWN]			×		
CAN CIRC 3 [OK/UNKWN]			×		
CAN CIRC 4 [OK/UNKWN]			×		
CAN CIRC 5 [OK/UNKWN]			×		
CAN CIRC 6 [OK/UNKWN]			×		
CAN CIRC 7 [OK/UNKWN]			×		

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

DATA MONITOR (SPEC) MODE

Monitored Item

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signal of the crankshaft position sensor (POS). 	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]			<ul style="list-style-type: none"> “Base fuel schedule” indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Fuel injectors ● Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Perform "Idle Air Volume Learning".
POWER BALANCE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connectors ● Compression ● Fuel injectors ● Power transistor ● Spark plugs ● Ignition coils
COOLING FAN	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn the cooling fan "ON" and "OFF" with CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connectors ● Cooling fan relay ● Cooling fan motor
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Engine coolant temperature sensor ● Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connectors ● Fuel pump relay
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connectors ● Solenoid valve
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change intake valve timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Intake valve timing control solenoid valve

DTC & SRT CONFIRMATION MODE

SRT STATUS Mode

For details, refer to [EC-1008, "SYSTEM READINESS TEST \(SRT\) CODE"](#) .

SRT Work Support Mode

This mode enables a technician to drive a vehicle to set the SRT while monitoring the SRT status.

DTC Work Support Mode

Test mode	Test item	Condition	Reference page
HO2S1	HO2S1 (B1) P0133	Refer to corresponding trouble diagnosis for DTC.	EC-1125
	HO2S1 (B1) P0134		EC-1135
	HO2S1 (B1) P1143		EC-1266
	HO2S1 (B1) P1144		EC-1272
HO2S2	HO2S2 (B1) P0139		EC-1149
	HO2S2 (B1) P1146		EC-1278
	HO2S2 (B1) P1147		EC-1286


REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.


1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.
In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.
At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.
The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.



2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
DATA MONITOR can be performed continuously even though a malfunction is detected.



Operation


1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in [G1-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.

A
EC
C
D
E
F
G
H
I
J
K
L
M




PBIB0197E

Generic Scan Tool (GST) Function DESCRIPTION

EBS00F27

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 8 different functions explained below. ISO9141 is used as the protocol. The name "GST" or "Generic Scan Tool" is used in this service manual.



FUNCTION

Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. For details, refer to EC-1008, "FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA" .
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.


TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]


Diagnostic test mode		Function
MODE 4	CLEAR DIAG INFO	This mode can clear all emission-related diagnostic information. This includes: <ul style="list-style-type: none"> ● Clear number of diagnostic trouble codes (MODE 1) ● Clear diagnostic trouble codes (MODE 3) ● Clear trouble code for freeze frame data (MODE 1) ● Clear freeze frame data (MODE 2) ● Reset status of system monitoring test (MODE 1) ● Clear on board monitoring test results (MODE 6 and 7)
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.
MODE 8	—	This mode is not applicable on this vehicle.
MODE 9	(CALIBRATION ID)	This mode enables the off-board test device to request specific vehicle information such as Vehicle Identification Number (VIN) and Calibration IDs.

GST INSPECTION PROCEDURE

1. Turn ignition switch OFF.
2. Connect "GST" to data link connector, which is located under drivers side dash panel near the fuse box cover.
3. Turn ignition switch ON.




4. Enter the program according to instruction on the screen or in the operation manual.
(*: Regarding GST screens in this section, sample screens are shown.)



5. Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.



TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

CONSULT-II Reference Value in Data Monitor Mode

EBS00F28

Remarks:

● Specification data are reference values.

● Specification data are output/input values which are detected or supplied by the ECM at the connector.

* Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value.
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle	Approx. 1.1 - 1.5V
		2,500 rpm	Approx. 1.6 - 2.0V
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.5 - 3.5 msec
		2,000 rpm	2.5 - 3.5 msec
A/F ALPHA-B1	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	54% - 155%
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Revving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Revving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
ACCEL SEN1 ACCEL SEN2	<ul style="list-style-type: none"> ● Ignition switch: ON (engine stopped) 	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Shift lever: D (CVT/CVT model) 1st (M/T model) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
CLSD THL POS	<ul style="list-style-type: none"> ● Ignition switch: ON 	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: P or N (CVT model) Neutral (M/T model)	ON
		Shift lever: Except above	OFF

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION	
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON
LOAD SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Rear window defogger switch is ON and/or lighting switch is in 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF
IGNITION SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF → ON 		ON → OFF → ON
HEATER FAN SW	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Heater fan is operating.	ON
		Heater fan is not operating	OFF
BRAKE SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	M/T 12° - 16° BTDC CVT 13° - 17° BTDC
		2,000 rpm	25° - 45° BTDC
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	10% - 35%
		2,500 rpm	10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	1.0 - 4.0 g·m/s
		2,500 rpm	4.0 - 10.0 g·m/s
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0%
		2,000 rpm	20 - 30%
INT/V TIM (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	-5° - 5°CA
		When revving up to 2,000 rpm quickly	Approx. 0° - 20°CA
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0% - 2%
		When revving up to 2,000 rpm quickly	Approx. 0% - 50%
AIR COND RLY	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking ● Except above conditions 		ON
			OFF
THRTL RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON 		ON

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
COOLING FAN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine ● Air conditioner switch: OFF 	Engine coolant temperature is 94°C (201°F) or less	OFF
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)	LOW
		Engine coolant temperature is 100°C (212°F) or more	HIGH
HO2S1 HTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm 		ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 		OFF
HO2S2 HTR (B1)	<ul style="list-style-type: none"> ● Engine speed: Below 3,800 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 		ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,800 rpm 		OFF
I/P PULLY SPD	<ul style="list-style-type: none"> ● Vehicle speed: More than 20 km/h 		Almost the same speed as the CONSULT-II value
VEHICLE SPEED	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value
TRVL AFTER MIL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Vehicle has traveled after MIL has turned ON.	0 - 65,535 km (0 - 40,723 mile)
O2SEN HTR DTY	<ul style="list-style-type: none"> ● Engine coolant temperature when engine started: More than 80°C (176°F) ● Engine speed: below 3,600 rpm 		Approx. 50 %
AC PRESS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		Approx. 0V
	<ul style="list-style-type: none"> ● Engine: Idle ● Air conditioner switch: OFF 		1.0 - 4.0V
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value
SET VHCL SPD	<ul style="list-style-type: none"> ● Engine: Running 	ICC: Operating	The preset vehicle speed is displayed.
MAIN SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	ON/OFF switch: Depressed	ON
		ON/OFF switch: Released	OFF
CANCEL SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	CANCEL switch: Depressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	ACCEL/RES switch: Depressed	ON
		ACCEL/RES switch: Released	OFF
SET SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	COAST/SET switch: Depressed	ON
		COAST/SET switch: Released	OFF
BRAKE SW1	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: Fully released	ON
		Brake pedal: Slightly depressed	OFF
BRAKE SW2	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
DIST SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	DISTANCE switch: Depressed	ON
		DISTANCE switch: Released	OFF
CRUISE LAMP	<ul style="list-style-type: none"> ● Ignition switch: ON 	CRUISE lamp: Illuminated	ON
		CRUISE lamp: Not illuminated	OFF

TROUBLE DIAGNOSIS

[QR (WITH EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
CAN COMM	● Ignition switch: ON	OK
CAN CIRC 1		OK
CAN CIRC 2		OK or ONKWN
CAN CIRC 3		OK
CAN CIRC 4		OK
CAN CIRC 5		OK or UNKWN
CAN CIRC 6		OK
CAN CIRC 7		UNKWN

Major Sensor Reference Graph in Data Monitor Mode


EBS00F29

The following are the major sensor reference graphs in "DATA MONITOR" mode.

CLSD THL POS, ACCEL SEN 1, THRTL SEN 1

Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch "ON" and with selector lever in "D" position (CVT models) or with shift lever in "1st" position (M/T models).


The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".




ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.


Each value is for reference, the exact value may vary.




A
EC
C
D
E
F
G
H
I
J
K
L
M




- "THRTL SEN 1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITH EURO-OBD)]

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

EBS00F2A

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONITOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

EBS00F2B

- Vehicle driven distance: More than 5,000 km (3,017 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.983 - 1.043 bar, 1.003 - 1.064 kg/cm², 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*¹
- Electrical load: Not applied*²
- Engine speed: Idle

*1: For CVT models with CONSULT-II, after the engine is warmed up to normal operating temperature, drive vehicle until "FLUID TEMP SE" (CVT fluid temperature sensor signal) indicates more than 60°C (140°F). For CVT models without CONSULT-II and M/T models, after the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.

*2: Rear window defogger switch, air conditioner switch, lighting switch are "OFF". Steering wheel is straight ahead.


Inspection Procedure

EBS00F2C

NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

1. Perform [EC-1032, "Basic Inspection"](#).
2. Confirm that the testing conditions indicated above are met.
3. Select "B/FUEL SCHDL", "A/F ALPHA-B1" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-1073, "Diagnostic Procedure"](#).




TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITH EURO-OBD)]

Diagnostic Procedure

EBS00F2D




(Go to next page.)

SEF613ZD

TROUBLE DIAGNOSIS - SPECIFICATION VALUE


[QR (WITH EURO-OBD)]



SEF768Z

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITH EURO-OBD)]



A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF615ZA

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

[QR (WITH EURO-OBD)]

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PF0:00006

Description

EBS00F2E

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the problem area.

Diagnostic Procedure

EBS00F2F

1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests", "Ground Inspection".

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITH EURO-OBD)]



POWER SUPPLY CIRCUIT FOR ECM

PPF:24110



Wiring Diagram

EBS00F2G

EC-MAIN-01



REFER TO THE FOLLOWING.
M1 - FUSE BLOCK-JUNCTION BOX (J/B)



MBWA0003E

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1 115 116	B B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 5 seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00GKE

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

- Yes >> GO TO 8.
- No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF" and then "ON".
2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

4. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.


OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminals 1 and 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITH EURO-OBD)]

7. CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 111 and ECM relay terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG


OK >> Go to [EC-1365. "IGNITION SIGNAL"](#) .

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Stop engine and wait at least 10 seconds.
2. Turn ignition switch "ON" and then "OFF".
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.



OK or NG


OK >> GO TO 13.

NG (Battery voltage does not exist.)>>GO TO 9.

NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.



10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM relay and 10A fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 119, 120 and ECM relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK ECM RELAY

Refer to [EC-1082, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace ECM relay.

13. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 14.

NG >> Repair open circuit or short to power in harness or connectors.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> **INSPECTION END**

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITH EURO-OBD)]


EBS00GKF

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITH EURO-OBD)]

DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

Description

EBS00F2I

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

EBS00F2J

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	● ECM cannot communicate to other control unit.	● Harness or connectors (CAN communication line is open or shorted.)
U1001 1001		● ECM cannot communicate for more than the specified time.	

DTC Confirmation Procedure

EBS00F2K

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-1085, "Diagnostic Procedure"](#) .



DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITH EURO-OBD)]

Wiring Diagram

EBS00F2L

EC-CAN-01

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- : DATA LINE



MBWA0038E

DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITH EURO-OBD)]

EBS00F2M

Diagnostic Procedure

1. INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

CVT Models with ESP and ICC

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	OK	CAN CIRC 2	UNKWN
CAN CIRC 3	OK	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	OK	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0174E

CVT Models with ESP without ICC

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	OK	CAN CIRC 2	UNKWN
CAN CIRC 3	OK	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0122E

CVT models without ESP and ICC

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	OK	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0180E

M/T Models with ESP

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	UNKWN	CAN CIRC 2	UNKWN
CAN CIRC 3	OK	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0123E

DTC U1000, U1001 CAN COMMUNICATION LINE

[QR (WITH EURO-OBD)]

M/T models without ESP

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	UNKWN	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0179E

>> Go to [LAN-8, "CAN COMMUNICATION"](#) .

DTC P0011 IVT CONTROL


PFP:23796

Description
SYSTEM DESCRIPTION

EBS00F2N

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed signal*	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.



This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

CONSULT-II Reference Value in Data Monitor Mode

EBS00F2O

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V TIM (B1)	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	-5° - 5°CA
	When revving up to 2,000 rpm quickly	Approx. 0° - 20°CA
INT/V SOL (B1)	● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	0% - 2%
	When revving up to 2,000 rpm quickly	Approx. 0% - 50%

On Board Diagnosis Logic

EBS00F2P

DTC No.	Trouble diagnosis name	Detecting condition	Possible cause
P0011 0011	Intake valve timing control performance	There is a gap between angle of target and phase-control angle degree.	<ul style="list-style-type: none"> ● Crankshaft position sensor (POS) ● Camshaft position sensor (PHASE) ● Accumulation of debris to the signal pick-up portion of the camshaft

FAIL-SAFE MODE

ECM enters in fail-safe mode when the malfunction is detected.

Detected items	Engine operating condition in fail-safe mode
Intake valve timing control	The signal is not energized to the solenoid valve and the valve control does not function

DTC Confirmation Procedure

EBS00F2Q

CAUTION:

Always drive at a safe speed.

NOTE:

- If DTC P0011 is displayed with DTC P1111, first perform trouble diagnosis for "DTC P1111". See [EC-1242](#).
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10V and 16V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Maintain the following conditions for at least 20 consecutive seconds.

ENG SPEED	2,000 - 3,175 rpm (A constant rotation is maintained.)
COOLANT TEMPS	80 - 90°C (176 - 194°F)
Selector lever	1st or 2nd position
Driving location uphill	Driving vehicle uphill (Increased engine load will help maintain the driving conditions required for this test.)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y

4. If 1st trip DTC is detected, go to [EC-1088, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00F2R

1. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-1210, "Component Inspection"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Replace crankshaft position sensor (POS).

2. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-1216, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Replace camshaft position sensor (PHASE).


3. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 4.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For wiring diagram refer to CKP sensor (POS) [EC-1207](#) and CMP sensor (PHASE) [EC-1213](#) .

>> INSPECTION END

DTC P0031, P0032 HO2S1 HEATER

[QR (WITH EURO-OBD)]

DTC P0031, P0032 HO2S1 HEATER

PFP:22690

Description SYSTEM DESCRIPTION

EBS00GBD

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00GBE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF

On Board Diagnosis Logic

EBS00GBF

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0031 0031	Heated oxygen sensor 1 heater control circuit low	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is open or shorted.) ● Heater oxygen sensor 1 heater
P0032 0032	Heated oxygen sensor 1 heater control circuit high	The current amperage in the heated oxygen sensor 1 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 1 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 1 heater circuit is shorted.) ● Heater oxygen sensor 1 heater

DTC Confirmation Procedure

EBS00GBG

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

Ⓜ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0031, P0032 HO2S1 HEATER

[QR (WITH EURO-OBD)]

3. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and run it for at least 6 seconds at idle speed.
5. If 1st trip DTC is detected, go to [EC-1093, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Start engine and run it for at least 6 seconds at idle speed.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine and run it for at least 6 seconds at idle speed.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-1093, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**




DTC P0031, P0032 HO2S1 HEATER

[QR (WITH EURO-OBD)]

EBS00GBH

Wiring Diagram

EC-HO2S1H-01



REFER TO THE FOLLOWING.

E106 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0009E


DTC P0031, P0032 HO2S1 HEATER

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	P/L	Heated oxygen sensor 1 heater	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition. ● Engine speed is below 3,600 rpm. 	<p>Approximately 7.0V</p>  <p>PBIB0519E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	<p>BATTERY VOLTAGE (11 - 14V)</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GBI

1. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E106
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair harness or connectors.

3. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 24 and HO2S1 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1094, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1 HEATER

EBS00GBJ


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00GBK

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

DTC P0037, P0038 HO2S2 HEATER

[QR (WITH EURO-OBD)]

DTC P0037, P0038 HO2S2 HEATER

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00GBL

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,800	OFF
Below 3,800	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00GBM

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1)	● Engine speed: Below 3,800 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON
	● Engine speed: Above 3,800 rpm	OFF

On Board Diagnosis Logic

EBS00GBN

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0037 0037	Heated oxygen sensor 2 heater control circuit low	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively low voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is open or shorted.) ● Heater oxygen sensor 2 heater
P0038 0038	Heated oxygen sensor 2 heater control circuit high	The current amperage in the heated oxygen sensor 2 heater circuit is out of the normal range. (An excessively high voltage signal is sent to ECM through the heated oxygen sensor 2 heater.)	<ul style="list-style-type: none"> ● Harness or connectors (The heated oxygen sensor 2 heater circuit is shorted.) ● Heater oxygen sensor 2 heater

DTC Confirmation Procedure

EBS00GBO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is between 10.5V and 16V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine.
3. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.

DTC P0037, P0038 HO2S2 HEATER

[QR (WITH EURO-OBD)]

4. Stop vehicle and let engine idle for at least 6 seconds.
5. If 1st trip DTC is detected, go to [EC-1098, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

1. Start engine.
 2. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 3. Stop vehicle and let engine idle for at least 6 seconds.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Start engine.
 6. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
 7. Stop vehicle and let engine idle for at least 6 seconds.
 8. Select "MODE 3" with GST.
 9. If DTC is detected, go to [EC-1098, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**




DTC P0037, P0038 HO2S2 HEATER

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GBP

EC-HO2S2H-01



REFER TO THE FOLLOWING.

E106 - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0011E

DTC P0037, P0038 HO2S2 HEATER

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/W	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,800 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,800 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00GBQ

1. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E106
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair harness or connectors.

3. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 and HO2S2 terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-1099, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 2.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 2 HEATER**

EBS00GBR


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	∞ Ω (Continuity should not exist)
3 and 1, 2, 4	

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



PBIB0542E

**Removal and Installation
HEATED OXYGEN SENSOR 2**

EBS00GBS

Refer to [EX-3, "EXHAUST SYSTEM"](#) .


DTC P0102, P0103 MAF SENSOR

PFP:22680

Component Description

EBS00GBT

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GBU

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.1 - 1.5V
	2,500 rpm	Approx. 1.6 - 2.0V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	1.0 - 4.0 g-m/s
	2,500 rpm	4.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00GBV

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00GBW

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

DTC P0102, P0103 MAF SENSOR

[QR (WITH EURO-OBD)]

PROCEDURE FOR DTC P0102

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-1103, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR DTC P0103

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1103, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-1103, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.




DTC P0102, P0103 MAF SENSOR

[QR (WITH EURO-OBD)]

EBS00GBX

EC-MAFS-01

Wiring Diagram



MBWA0004E

DTC P0102, P0103 MAF SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
50	B	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.1 - 1.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.6 - 2.0V
54	W	Sensor's ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00GBY

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold


OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 1 and ECM terminal 50. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1105, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
MASS AIR FLOW SENSOR**


EBS00GBZ

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.1 - 1.5
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.0
Idle to about 4,000 rpm*	1.5 - 2.0 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.



MBIB0017E

**Removal and Installation
MASS AIR FLOW SENSOR**

EBS00GC0

Refer to [EM-114, "AIR CLEANER AND AIR DUCT"](#) .

DTC P0112, P0113 IAT SENSOR


PFP:22630

Component Description

EBS00GC1

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.43	7.9 - 9.3
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 34 (Intake air temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00GC2

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0112 0112	Intake air temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air temperature sensor
P0113 0113	Intake air temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00GC3

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0112, P0113 IAT SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1103, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "With CONSULT-II" above.




DTC P0112, P0113 IAT SENSOR

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GC4


EC-IATS-01



MBWA0005E

Diagnostic Procedure**1. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch "OFF".
2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
3. Turn ignition switch "ON".




4. Check voltage between MAF sensor terminal 5 and ground.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 2.
 NG >> Repair harness or connectors.

**2. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch "OFF".
2. Check harness continuity between MAF sensor terminal 3 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness or connectors.

3. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-1105, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
 NG >> Replace mass air flow sensor (with intake air temperature sensor).

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

DTC P0112, P0113 IAT SENSOR

[QR (WITH EURO-OBD)]

EBS00GC6



Component Inspection

INTAKE AIR TEMPERATURE SENSOR

1. Check resistance between mass air flow sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



Removal and Installation

MASS AIR FLOW SENSOR

Refer to [EM-114, "AIR CLEANER AND AIR DUCT"](#) .

EBS00GC7


DTC P0117, P0118 ECT SENSOR

PFP:22630

Component Description

EBS00GC8


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00GC9

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When this malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

DTC P0117, P0118 ECT SENSOR

[QR (WITH EURO-OBD)]

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

DTC Confirmation Procedure

EBS00GCA

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1114, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0117, P0118 ECT SENSOR




[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GCB

EC-ECTS-01


A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0006E

Diagnostic Procedure**1. CHECK ECT SENSOR POWER SUPPLY CIRCUIT**

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature (ECT) sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**2. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch "OFF".
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between engine coolant temperature sensor and ECM
- Harness for open or short between engine coolant temperature sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1115, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

5. CHECK INTERMITTENT INCIDENT


Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
ENGINE COOLANT TEMPERATURE SENSOR

EBS00GCD

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260


*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.

2. If NG, replace engine coolant temperature sensor.

Removal and Installation
ENGINE COOLANT TEMPERATURE SENSOR

EBS00GCE

Refer to [CO-40, "THERMOSTAT AND WATER CONTROL VALVE"](#) .



DTC P0127 IAT SENSOR


PFP:22630

Component Description

EBS00F3U

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.43	7.9 - 9.3
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 84 (Intake air temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00F3V

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0127 0127	Intake air temperature too high	Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted) ● Intake air temperature sensor

DTC Confirmation Procedure

EBS00F3W

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

This test may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.


WITH CONSULT-II

1. Wait until engine coolant temperature is less than 90°C (194°F)
 - a. Turn ignition switch "ON".

DTC P0127 IAT SENSOR

[QR (WITH EURO-OBD)]

- b. Select "DATA MONITOR" mode with CONSULT-II.
- c. Check the engine coolant temperature.
- d. If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
 - Perform the following steps before engine coolant temperature is above 90°C (194°F).
2. Turn ignition switch "ON".
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine.
5. Hold vehicle speed at more than 70 km/h (43 MPH) for 100 consecutive seconds.
6. If 1st trip DTC is detected, go to [EC-1117, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure

EBS00F3X

1. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-1117, "Component Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

2. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

Refer to [EC-1108, "Wiring Diagram"](#).

>> INSPECTION END



Component Inspection INTAKE AIR TEMPERATURE SENSOR

EBS00F3Y

1. Check resistance between mass air flow sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



Removal and Installation
MASS AIR FLOW SENSOR

EBS00F3Z

Refer to [EM-114, "AIR CLEANER AND AIR DUCT"](#) .



DTC P0132 HO2S1

PFP:22690

Component Description

EBS00GCF

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GCG


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GCH

To judge the malfunction, the diagnosis checks that the heated oxygen sensor 1 output is not inordinately high.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0132 0132	Heated oxygen sensor 1 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

DTC Confirmation Procedure**NOTE:**

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

CONSULT-II WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Select "DATA MONITOR" mode with CONSULT-II.
5. Restart engine and let it idle for 2 minutes.
6. If 1st trip DTC is detected, go to [EC-1122, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C

SEF174Y




GST WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Turn ignition switch "OFF" and wait at least 10 seconds.
 3. Restart engine and let it idle for 2 minutes.
 4. Turn ignition switch "OFF" and wait at least 10 seconds.
 5. Restart engine and let it idle for 2 minutes.
 6. Select "MODE 3" with GST.
 7. If DTC is detected, go to [EC-1122, "Diagnostic Procedure"](#).
- **When using GST, "DTC Confirmation Procedure" should be performed twice as much as when using CONSULT-II because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CONSULT-II is recommended.**

Wiring Diagram

EBS00GCJ

EC-HO2S1-01



REFER TO THE FOLLOWING.

E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	PU	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V

Diagnostic Procedure


EBS00GCK

1. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HO2S1 CONNECTOR FOR WATER

Check heated oxygen sensor 1 connectors for water.

Water should not exist.

OK or NG

OK >> GO TO 5.

NG >> Repair or replace harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1123, "Component Inspection"](#).

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GCL

With CONSULT-II



1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.

- "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)" voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
 2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).

EBS00GCM



DTC P0133 HO2S1

PFP:22690

Component Description

EBS00GCM

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GCO


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GCP

To judge the malfunction of heated oxygen sensor 1, this diagnosis measures response time of heated oxygen sensor 1 signal. The time is compensated by engine operating (speed and load), fuel feedback control constant, and heated oxygen sensor 1 temperature index. Judgment is based on whether the compensated time (heated oxygen sensor 1 cycling time index) is inordinately long or not.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0133 0133	Heated oxygen sensor 1 circuit slow response	The response of the voltage signal from the sensor takes more than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks ● Exhaust gas leaks ● PCV valve ● Mass air flow sensor

DTC Confirmation Procedure

EBS00GCO

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P0133” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P0133	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h
SEF338Z	


6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 20 to 50 seconds.)

ENG SPEED	1,650 - 3,600 rpm
Vehicle speed	More than 80 km/h (50 MPH)
B/FUEL SCHDL	4.0 - 14.5 msec
Selector lever	Suitable position

HO2S1 (B1) P0133	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h
SEF339Z	

If “TESTING” is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1129, "Diagnostic Procedure"](#).



Overall Function Check

EBS00GCR

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V




**2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V
→ 0 - 0.3V**

4. If NG, go to [EC-1129, "Diagnostic Procedure"](#).



EC-HO2S1-01

Wiring Diagram



REFER TO THE FOLLOWING.
 E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	PU	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00GCT

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)

>> GO TO 3.




3. CHECK FOR EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst (Manifold).

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace.



4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.


OK or NG

- OK >> GO TO 5.
NG >> Repair or replace.

5. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or DTC P0172 (Refer to [EC-1157](#) or [EC-1163](#)).
- No >> GO TO 6.

6. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



7. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1094, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace malfunctioning heated oxygen sensor 1.

9. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1105, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace mass air flow sensor.

10. CHECK PCV VALVE

Refer to [EC-1411, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace PCV valve.

11. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1132, "Component Inspection"](#) .

OK or NG

OK >> GO TO 12.

NG >> Replace heated oxygen sensor 1.

12. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GCU

With CONSULT-II



1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.

3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.



CAUTION:


- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
 2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
 3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



-
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation
HEATED OXYGEN SENSOR 1

EBS00GCV

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .



DTC P0134 HO2S1

PFP:22690

Component Description

EBS00GCW

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GCX


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GCY

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 (B1) P0134" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
3. Touch "START".
4. Let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 4.

HO2S1 (B1) P0134	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0544E

5. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 10 to 60 seconds.)

ENG SPEED	1,550 - 3,600 rpm
Vehicle speed	More than 64 km/h (40 MPH)
B/FUEL SCHDL	2.9 - 14.5 msec
Selector lever	Suitable position

If "TESTING" is not displayed after 5 minutes, retry from step 2.

6. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1139, "Diagnostic Procedure"](#).

HO2S1 (B1) P0134	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0545E

HO2S1 (B1) P0134	
COMPLETED	

SEC750C

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.


WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.

DTC P0134 HO2S1

[QR (WITH EURO-OBD)]

3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-1139, "Diagnostic Procedure"](#).



A

EC

C

D

E

F

G

H

I

J




K

L

M

EC-HO2S1-01

Wiring Diagram



REFER TO THE FOLLOWING.
 E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	PU	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00GD2

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT


1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1140, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GD3

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y


6. Check the following.

- "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5
HO2S1 MNTR (B1)	R	L	R	L	R

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA




CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is below 0.3V at least one time.
 - The voltage never exceeds 1.0V.
- 1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V
2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

EBS00GD4

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .


DTC P0138 HO2S2

PFP:226A0

Component Description

EBS00GD5

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GD6


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00GD7

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the voltage is unusually high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0138 0138	Heated oxygen sensor 2 circuit high voltage	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2

DTC Confirmation Procedure

EBS00GD8

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
3. Stop vehicle with engine running.

4. Let engine idle for 1 minute.
5. If 1st trip DTC is detected, go to [EC-1145, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

SEF189Y


EBS00GD9

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.




WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)
The voltage should be below 1.4V during this procedure.
5. If NG, go to [EC-1145, "Diagnostic Procedure"](#).



Wiring Diagram

EC-HO2S2-01



REFER TO THE FOLLOWING.
 E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W/Y	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00GDB

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-1163](#).
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-1147, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 2**

EBS00GDC


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II


1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in “D” position (CVT), 3rd gear position (M/T).
The voltage should be below 0.50V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

Removal and Installation

HEATED OXYGEN SENSOR 2

EBS00GDD

Refer to [EX-3, "EXHAUST SYSTEM"](#) .


DTC P0139 HO2S2

PFP:226A0

Component Description

EBS00GDE

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GDF


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Revsing engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00GDG

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the switching response of the sensor's voltage is faster than specified during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0139 0139	Heated oxygen sensor 2 circuit slow response	It takes more time for the sensor to respond between rich and lean than the specified time.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00GDH

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry this procedure from step 2 in "Procedure for COND1".

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P0139" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105 °C
Selector level	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0552E
HO2S2 (B1) P0139																																													
COND1:	OUT OF CONDITION																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P0139																																													
COND1:	TESTING																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P0139																																													
COND1:	COMPLETED																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completely from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED". (It will take approximately 4 seconds.)


NOTE:

If "COMPLETED" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P0139</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P0139		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0553E
HO2S2 (B1) P0139															
COND1:	COMPLETED														
COND2:	COMPLETED														
COND3:	INCOMPLETE														
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-1153, "Diagnostic Procedure"](#).



Overall Function Check

EBS00GD1

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)


The voltage should change at more than 0.06V for 1 second during this procedure.

If the voltage can be confirmed in step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position (CVT), 3rd gear position (M/T).




The voltage should change at more than 0.06V for 1 second during this procedure.

6. If NG, go to [EC-1153, "Diagnostic Procedure"](#).



Wiring Diagram

EC-HO2S2-01



REFER TO THE FOLLOWING.

E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W/Y	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00GDK

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 or P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171 or P0172. Refer to [EC-1157](#) or [EC-1163](#).
- No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-1155, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

**Component Inspection
HEATED OXYGEN SENSOR 2**

EBS00GDL


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)


The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in “D” position (CVT), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 2**

EBS00GDM

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

PF16600

On Board Diagnosis Logic

EBS00GDN

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensor 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too lean.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0171 0171	Fuel injection system too lean	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too lean.) 	<ul style="list-style-type: none"> Intake air leaks Heated oxygen sensor 1 Injectors Exhaust gas leaks Incorrect fuel pressure Lack of fuel Mass air flow sensor Incorrect PCV hose connection

DTC Confirmation Procedure


EBS00GDO

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-1160, "Diagnostic Procedure"](#).
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- Crank engine while depressing accelerator pedal. If engine starts, go to [EC-1160, "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.




WITH GST

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists. If so, go to [EC-1160, "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal. If engine starts, go to [EC-1160, "Diagnostic Procedure"](#).
If engine does not start, check exhaust and intake air leak visually.



DTC P0171 FUEL INJECTION SYSTEM FUNCTION


[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GDP


EC-FUEL-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO PG-POWER.

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
(M1), (E106) - FUSE BLOCK-
JUNCTION BOX (J/B)

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

EBS00GDO


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

1. Listen for an intake air leak after the mass air flow sensor.
2. Check PCV hose connection.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

5. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.


4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-1001, "FUEL PRESSURE RELEASE"](#).
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1002, "FUEL PRESSURE CHECK"](#).

At idling: Approximately 350 kPa (3.5 bar, 3.7 kg/cm², 51 psi)

OK or NG

- OK >> GO TO 5.
NG >> Follow the construction of "FUEL PRESSURE CHECK".



DTC P0171 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

5. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling

4.0 - 10 g-m/sec: at 2,500 rpm

With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling

4.0 - 10 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 6.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1100, "DTC P0102, P0103 MAF SENSOR"](#) .

6. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for [EC-1375, "INJECTOR CIRCUIT"](#) .

DTC P0171 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

7. CHECK INJECTOR


1. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
2. Turn ignition switch "OFF".
3. Disconnect injector harness connectors.
4. Remove injector gallery assembly. Refer to [EM-128, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
The injector harness connectors should remain connected.
5. Disconnect all ignition coil harness connectors.
6. Prepare pans or saucers under each injector.
7. Crank engine for about 3 seconds. Make sure that fuel sprays out from injectors.

Fuel should be sprayed evenly for each injector.

OK or NG

OK >> GO TO 8.

NG >> Replace injectors from which fuel does not spray out.
Always replace O-ring with new ones.



8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

PFP:16600

On Board Diagnosis Logic

EBS00GDR

With the Air/Fuel Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the heated oxygen sensors 1. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios.

In case the amount of the compensation value is extremely large (The actual mixture ratio is too rich.), the ECM judges the condition as the fuel injection system malfunction and light up the MI (2 trip detection logic).

Sensor	Input Signal to ECM	ECM function	Actuator
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	Fuel injection control	Fuel injectors

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0172 0172	Fuel injection system too rich	<ul style="list-style-type: none"> Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	<ul style="list-style-type: none"> Heated oxygen sensor 1 Injectors Exhaust gas leaks Incorrect fuel pressure Mass air flow sensor

DTC Confirmation Procedure


EBS00GDS

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.
- Turn ignition switch "ON" and select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
- Clear the self-learning control coefficient by touching "CLEAR".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine again and let it idle for at least 10 minutes. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-1166, "Diagnostic Procedure"](#).
- If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.
- Crank engine while depressing accelerator pedal. If engine starts, go to [EC-1166, "Diagnostic Procedure"](#). If engine does not start, remove ignition plugs and check for fouling, etc.




WITH GST

- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

3. Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Select "MODE 3" with GST. Make sure DTC P0102 is detected.
6. Select "MODE 4" with GST and erase the DTC P0102.
7. Start engine again and let it idle for at least 10 minutes.
8. Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. If so, go to [EC-1166. "Diagnostic Procedure"](#).
9. If it is difficult to start engine at step 7, the fuel injection system has a malfunction.
10. Crank engine while depressing accelerator pedal.
If engine starts, go to [EC-1166. "Diagnostic Procedure"](#). If engine does not start, check exhaust and intake air leak visually.



DTC P0172 FUEL INJECTION SYSTEM FUNCTION



[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GDT

EC-FUEL-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (M1), (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

EBS00GDU


Diagnostic Procedure

1. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before three way catalyst.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.



2. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK HEATED OXYGEN SENSOR 1 CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 (HO2S1) harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

5. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

6. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.


4. CHECK FUEL PRESSURE

1. Release fuel pressure to zero. Refer to [EC-1001, "FUEL PRESSURE RELEASE"](#).
2. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1002, "FUEL PRESSURE CHECK"](#).

At idling: 350 kPa (3.5 bar, 3.7 kg/cm², 51 psi)

OK or NG

- OK >> GO TO 5.
NG >> Follow the construction of "FUEL PRESSURE CHECK".



DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

5. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

1. Install all removed parts.
2. Check "MASS AIR FLOW" in "DATA MONITOR" mode with CONSULT-II.

1.0 - 4.0 g-m/sec: at idling

4.0 - 10 g-m/sec: at 2,500 rpm

With GST

1. Install all removed parts.
2. Check mass air flow sensor signal in MODE 1 with GST.

1.0 - 4.0 g-m/sec: at idling

4.0 - 10 g-m/sec: at 2,500 rpm

OK or NG

OK >> GO TO 6.

NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1100, "DTC P0102, P0103 MAF SENSOR"](#) .

6. CHECK FUNCTION OF INJECTORS

With CONSULT-II

1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.

Clicking noise should be heard.



OK or NG

OK >> GO TO 7.

NG >> Perform trouble diagnosis for [EC-1375, "INJECTOR CIRCUIT"](#) .

DTC P0172 FUEL INJECTION SYSTEM FUNCTION

[QR (WITH EURO-OBD)]

7. CHECK INJECTOR

1. Remove injector assembly. Refer to [EM-128, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
2. Confirm that the engine is cooled down and there are no fire hazards near the vehicle.
3. Disconnect injector harness connectors.
The injector harness connectors should remain connected.
4. Disconnect all ignition coil harness connectors.
5. Prepare pans or saucers under each injectors.
6. Crank engine for about 3 seconds.
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 8.

NG (Drips.)>>Replace the injectors from which fuel is dripping. Always replace O-ring with new one.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

DTC P0221 TP SENSOR


PF0:16119

Component Description

EBS00GDV

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GDW

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00GDY

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0221 0221	Throttle position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.
- So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GDY

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0221 TP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1172, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0221 TP SENSOR




[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GDZ

EC-TPS3-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0127E

DTC P0221 TP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00GE0

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4, ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1174, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00GE1

1. Reconnect all harness connectors disconnected.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-999, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GE2

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P0222, P0223 TP SENSOR


PF16119

Component Description

EBS00GE3

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GE4

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00GE5

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 1 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GE6

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

- Turn ignition switch "ON".

DTC P0222, P0223 TP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1178, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0222, P0223 TP SENSOR




[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GE7

EC-TPS1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0125E

DTC P0222, P0223 TP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"]	More than 0.36V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	
66	B	Sensors' ground	[Engine is running]	Approximately 0V
			<ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	
68	R	Throttle position sensor 2	[Ignition switch "ON"]	Less than 4.75V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	
			[Ignition switch "ON"]	More than 0.36V
			<ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	


Diagnostic Procedure

EBS00GE8

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1180, "Component Inspection"](#).

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00GE9

1. Reconnect all harness connectors disconnected.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-999, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GEA

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P0226 APP SENSOR

PFP:18002


Component Description

EBS00GEB

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



A

EC

C

D

E

CONSULT-II Reference Value in Data Monitor Mode

EBS00GEC

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1 ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

F

G

H

On Board Diagnosis Logic

EBS00GEC

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0226 0226	Accelerator pedal position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> ● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) ● Accelerator pedal position sensor 1 and 2

I

J

K

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

L

M

DTC Confirmation Procedure

EBS00GEE

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1184, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0226 APP SENSOR







[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GEF

EC-APPS3-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0131E

DTC P0226 APP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00GEG

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminals 1, 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and APP sensor terminal 4, ECM terminal 66 and APP sensor terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor
- Harness for open or short between TCM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1187, "Component Inspection"](#) .

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT


Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-999, "Idle Air Volume Learning"](#) .

Remove and Installation
ACCELERATOR PEDAL

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

DTC P0227, P0228 APP SENSOR

PFP:18002


Component Description

EBS00GEJ

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GEK

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00GEL

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0227 0227	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P0228 0228	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GEM

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0227, P0228 APP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1191, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.







DTC P0227, P0228 APP SENSOR

[QR (WITH EURO-OBD)]

EBS00GEN

EC-APPS1-01

Wiring Diagram



DTC P0227, P0228 APP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

EBS00GEO


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and APP sensor terminal 4. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor
- Harness for open or short between TCM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1193, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00GEP

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P0227, P0228 APP SENSOR

[QR (WITH EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-999, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00GEO

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

[QR (WITH EURO-OBD)]

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

PPF:00000

On Board Diagnosis Logic

EBS00GER

When a misfire occurs, engine speed will fluctuate. If the engine speed fluctuates enough to cause the crankshaft position (CKP) sensor (POS) signal to vary, ECM can determine that a misfire is occurring.

Sensor	Input Signal to ECM	ECM function
Crankshaft position sensor (POS)	Engine speed	On board diagnosis of misfire

The misfire detection logic consists of the following two conditions.

- One Trip Detection Logic (Three Way Catalyst Damage)**
 On the first trip that a misfire condition occurs that can damage the three way catalyst (TWC) due to overheating, the MI will blink.
 When a misfire condition occurs, the ECM monitors the CKP sensor (POS) signal every 200 engine revolutions for a change.
 When the misfire condition decreases to a level that will not damage the TWC, the MI will turn off.
 If another misfire condition occurs that can damage the TWC on a second trip, the MI will blink.
 When the misfire condition decreases to a level that will not damage the TWC, the MI will remain on.
 If another misfire condition occurs that can damage the TWC, the MI will begin to blink again.
- Two Trip Detection Logic (Exhaust quality deterioration)**
 For misfire conditions that will not damage the TWC (but will affect vehicle emissions), the MI will only light when the misfire is detected on a second trip. During this condition, the ECM monitors the CKP sensor signal every 1,000 engine revolutions.
 A misfire malfunction can be detected on any one cylinder or on multiple cylinders.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0300 0300	Multiple cylinder misfire detected	Multiple cylinder misfire.	<ul style="list-style-type: none"> ● Improper spark plug ● Insufficient compression ● Incorrect fuel pressure ● The injector circuit is open or shorted ● Fuel injectors ● Intake air leak ● The ignition signal circuit is open or shorted ● Lack of fuel ● Drive plate or flywheel ● Heated oxygen sensor 1 ● Incorrect PCV hose connection
P0301 0301	No.1 cylinder misfire detected	No. 1 cylinder misfires.	
P0302 0302	No. 2 cylinder misfire detected	No. 2 cylinder misfires.	
P0303 0303	No. 3 cylinder misfire detected	No. 3 cylinder misfires.	
P0304 0304	No. 4 cylinder misfire detected	No. 4 cylinder misfires.	

DTC Confirmation Procedure

EBS00GES

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

- Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT-II.
- Start engine and warm it up to normal operating temperature.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MISFIRE

[QR (WITH EURO-OBD)]

- Start engine again and drive at 1,500 to 3,000 rpm for at least 3 minutes.
Hold the accelerator pedal as steady as possible.
NOTE:
Refer to the freeze frame data for the test driving conditions.
- If 1st trip DTC is detected, go to [EC-1196, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
B/FUEL SCHDL	XXX msec

PBIB0164E

WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00GET

1. CHECK FOR INTAKE AIR LEAK AND PCV HOSE

- Start engine and run it at idle speed.
- Listen for the sound of the intake air leak.
- Check PCV hose connection.

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.

2. CHECK FOR EXHAUST SYSTEM CLOGGING

Stop engine and visually check exhaust tube, three way catalyst and muffler for dents.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. PERFORM POWER BALANCE TEST

With CONSULT-II


1. Perform "POWER BALANCE" in "ACTIVE TEST" mode.
2. Is there any cylinder which does not produce a momentary engine speed drop?

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

Without CONSULT-II

When disconnecting each injector harness connector one at a time, is there any cylinder which does not produce a momentary engine speed drop?



Yes or No


- Yes >> GO TO 4.
- No >> GO TO 7.

4. CHECK INJECTOR

Does each injector make an operating sound at idle?

Yes or No

- Yes >> GO TO 5.
- No >> Check injector(s) and circuit(s). Refer to [EC-1375](#), "[INJECTOR CIRCUIT](#)".




5. CHECK IGNITION SPARK

1. Disconnect ignition coil assembly from rocker cover.
2. Connect a known good spark plug to the ignition coil assembly.
3. Place end of spark plug against a suitable ground and crank engine.
4. Check for spark.

OK or NG

OK >> GO TO 6.

NG >> Check ignition coil, power transistor and their circuits.
Refer to [EC-1365, "IGNITION SIGNAL"](#) .




6. CHECK SPARK PLUGS

Remove the spark plugs and check for fouling, etc.

OK or NG

OK >> GO TO 7.

NG >> Repair or replace spark plug(s) with standard type one(s). For spark plug type, refer to [MA-26, "Checking and Changing Spark Plugs"](#) .



7. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to [EM-152, "CHECKING COMPRESSION PRESSURE"](#) .

Standard: 1,190 kPa (11.9 bar, 12.1 kg/cm² , 172 psi)/250 rpm

Minimum: 990 kPa (9.9 bar, 10.1 kg/cm² , 144 psi)/250 rpm

Difference between each cylinder: 98 kPa (0.98 bar, 1.0 kg/cm² , 14 psi)/250 rpm

OK or NG

OK >> GO TO 8.

NG >> Check pistons, piston rings, valves, valve seats and cylinder head gaskets.

8. CHECK FUEL PRESSURE

1. Install all removed parts.
2. Release fuel pressure to zero. Refer to [EC-1001, "FUEL PRESSURE RELEASE"](#) .
3. Install fuel pressure gauge and check fuel pressure. Refer to [EC-1002, "FUEL PRESSURE CHECK"](#) .

At idle: Approx. 350 kPa (3.5 bar, 3.7 kg/cm² , 51 psi)

OK or NG

OK >> GO TO 9.

NG >> Follow the construction of "FUEL PRESSURE CHECK".

9. CHECK IGNITION TIMING

Check the following items. Refer to [EC-1032, "Basic Inspection"](#) .

Items	Specifications	
Target idle speed	CVT	650 ± 50 rpm (in "P" or "N" position)
	M/T	600 ± 50 rpm
Ignition timing	CVT	15 ± 5° BTDC (in "P" or "N" position)
	M/T	14 ± 5° BTDC

OK or NG

- OK >> GO TO 10.
- NG >> Follow the "Basic Inspection".

10. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1123, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 11.

11. CHECK MASS AIR FLOW SENSOR

With CONSULT-II

Check mass air flow sensor signal in "DATA MONITOR" mode with CONSULT-II.

- 1.0 - 4.0 g-m/sec: at idling**
- 4.0 - 10.0 g-m/sec: at 2,500 rpm**

With GST

Check mass air flow sensor signal in MODE 1 with GST.

- 1.0 - 4.0 g-m/sec: at idling**
- 4.0 - 10.0 g-m/sec: at 2,500 rpm**

OK or NG

- OK >> GO TO 12.
- NG >> Check connectors for rusted terminals or loose connections in the mass air flow sensor circuit or engine grounds. Refer to [EC-1100, "DTC P0102, P0103 MAF SENSOR"](#) .

12. CHECK SYMPTOM MATRIX CHART

Check items on the rough idle symptom in [EC-1037, "Symptom Matrix Chart"](#) .

OK or NG

- OK >> GO TO 13.
- NG >> Repair or replace.

13. ERASE THE 1ST TRIP DTC

Some tests may cause a 1st trip DTC to be set.

Erase the 1st trip DTC from the ECM memory after performing the tests. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#) .

- >> GO TO 14.

**DTC P0300 - P0304 MULTIPLE CYLINDER MISFIRE, NO. 1 - 4 CYLINDER MIS-
FIRE**

[QR (WITH EURO-OBD)]

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


DTC P0327, P0328 KS

PFP:22060

Component Description

EBS00GEU

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



On Board Diagnosis Logic

EBS00GEV

The MI will not light for knock sensor malfunction.

DTC No.	Trouble Diagnosis Name	DTC Detected Condition	Possible Cause
P0327 0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328 0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00GEW

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-1203, "Diagnostic Procedure"](#).





WITH GST

Follow the procedure "WITH CONSULT-II" above.

Wiring Diagram

EBS00GEX

EC-KS-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V

Diagnostic Procedure

EBS00GEY

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 15 and engine ground. Refer to Wiring Diagram.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance: Approximately 530 - 590kΩ [at 20°C (68°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-II


1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 15 and knock sensor terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

**3. CHECK KNOCK SENSOR**

Refer to [EC-1204, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Replace knock sensor.

4. CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between knock sensor terminal 2 and engine ground.

Continuity should exist

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection KNOCK SENSOR

Check resistance between knock sensor terminal 1 and ground.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

Resistance: Approximately 530 - 590k Ω [at 20°C (68°F)]


CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.

Removal and Installation KNOCK SENSOR

Refer to [EM-165, "CYLINDER BLOCK"](#) .

EBS00GEZ



EBS00GF0

DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

DTC P0335 CKP SENSOR (POS)

PFP:23731

Component Description

EBS00GF1

The crankshaft position sensor (POS) is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.


The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GF2

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED.	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

EBS00GF3

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Crankshaft position sensor (POS) Signal plate

DTC Confirmation Procedure

EBS00GF4

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON".

WITH CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-1208, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

 **WITH GST**

Follow the procedure "WITH CONSULT-II" above.




DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GF5

EC-POS-01



MBWA0014E



DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	L	Crankshaft position sensor (POS)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>Approximately 3V★</p> 
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	<p>Approximately 3V★</p> 

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00GF6

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

2. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.




2. Turn ignition switch "ON".
3. Check voltage between CKP sensor (POS) terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between CKP sensor (POS) terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

5. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-1210, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace crankshaft position sensor (POS).

7. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 8.

NG >> Replace the signal plate.

8. CHECK INTERMITTENT INCIDENT


Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection CRANKSHAFT POSITION SENSOR (POS)

EBS00GF7

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




DTC P0335 CKP SENSOR (POS)

[QR (WITH EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	

6. If NG, replace crankshaft position sensor (POS).



EBS00GF8

Removal and Installation CRANKSHAFT POSITION SENSOR (POS)

Refer to [EM-165, "CYLINDER BLOCK"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0340 CMP SENSOR (PHASE)

[QR (WITH EURO-OBD)]

DTC P0340 CMP SENSOR (PHASE)

PFP:23731

Component Description

EBS00GF9

The camshaft position sensor (PHASE) senses the retraction with intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.


When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



On Board Diagnosis Logic

EBS00GFA

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. The cylinder No. signal is not set to ECM during engine running. The cylinder No. signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Camshaft position sensor (PHASE) Camshaft (Intake) Starter motor (Refer to SC-22 .) Starting system circuit (Refer to SC-22 .) Dead (Weak) battery

DTC Confirmation Procedure

EBS00GFB

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-1214, "Diagnostic Procedure"](#) .
If 1st trip DTC is not detected, go to next step.
- Maintain engine speed at more than 800 rpm for at least 5 seconds.
- If 1st trip DTC is detected, go to [EC-1214, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0340 CMP SENSOR (PHASE)





[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GFC

EC-PHASE-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0015E



DTC P0340 CMP SENSOR (PHASE)

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	L	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p>PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p>PBIB0526E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GFD

1. CHECK STARTING SYSTEM

Turn ignition switch to "START" position.

Does the engine turn over?

Does the starter motor operate?

Yes or No


Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-22, "STARTING SYSTEM"](#) .)

2. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 3.




DTC P0340 CMP SENSOR (PHASE)

[QR (WITH EURO-OBD)]

3. CHECK CAMSHAFT POSITION (CMP) SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CMP sensor (PHASE) terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between CMP sensor (PHASE) terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 14 and CMP sensor (PHASE) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-1216, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace camshaft position sensor (PHASE).

8. CHECK CAMSHAFT (INTAKE)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

OK >> GO TO 9.

NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



9. CHECK INTERMITTENT INCIDENT


Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection CAMSHAFT POSITION SENSOR (PHASE)

EBS00GFE

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




DTC P0340 CMP SENSOR (PHASE)

[QR (WITH EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	



Removal and Installation CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EM-133, "CAMSHAFT"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0420 THREE WAY CATALYST FUNCTION

[QR (WITH EURO-OBD)]

DTC P0420 THREE WAY CATALYST FUNCTION

PFP:20905


On Board Diagnosis Logic

EBS00GFG

The ECM monitors the switching frequency ratio of heated oxygen sensors 1 and 2.

A three way catalyst (Manifold) with high oxygen storage capacity will indicate a low switching frequency of heated oxygen sensor 2. As oxygen storage capacity decreases, the heated oxygen sensor 2 switching frequency will increase.

When the frequency ratio of heated oxygen sensors 1 and 2 approaches a specified limit value, the three way catalyst (Manifold) malfunction is diagnosed.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0420 0420	Catalyst system efficiency below threshold	<ul style="list-style-type: none"> Three way catalyst (Manifold) does not operate properly. Three way catalyst (Manifold) does not have enough oxygen storage capacity. 	<ul style="list-style-type: none"> Three way catalyst (Manifold) Exhaust tube Intake air leaks Fuel injectors Fuel injector leaks Spark plug Improper ignition timing

DTC Confirmation Procedure

EBS00GFH

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

TESTING CONDITION:

- Open engine hood before conducting the following procedure.
 - Do not hold engine speed for more than the specified minutes below.
- Turn ignition switch "ON".
 - Select "DTC & SRT CONFIRMATION" then "SRT WORK SUPPORT" mode with CONSULT-II.
 - Start engine.
 - Rev engine up to 2,000 to 3,000 rpm and hold it for 3 consecutive minutes then release the accelerator pedal completely. If "INCMP" of "CATALYST" changed to "COMPLT", go to step 7
 - Wait 5 seconds at idle.

SRT WORK SUPPORT	
CATALYST	INCMP
HO2S HTR	CMPLT
HO2S	INCMP
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0566E

DTC P0420 THREE WAY CATALYST FUNCTION

[QR (WITH EURO-OBD)]

- Rev engine up to 2,000 to 3,000 rpm and maintain it until "INCMP" of "CATALYST" changes to "CMPLT" (It will take approximately 5 minutes).
If not "CMPLT", stop engine and cool it down to less than 70°C (158°F) and then retest from step 1.

SRT WORK SUPPORT	
CATALYST	CMPLT
HO2S HTR	CMPLT
HO2S	INCMP

MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec

PBIB0567E

- Select "SELF-DIAG RESULTS" mode with CONSULT-II.
- Confirm that the 1st trip DTC is not detected.
If the 1st trip DTC is detected, go to [EC-1220, "Diagnostic Procedure"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SEF535Z

Overall Function Check

EBS00GF1


Use this procedure to check the overall function of the three way catalyst (Manifold). During this check, a 1st trip DTC might not be confirmed.

CAUTION:

Always drive vehicle at a safe speed.

WITH GST

- Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- Stop vehicle with engine running.
- Set voltmeters probes between ECM terminal 35 (HO2S1 signal) and engine ground, and ECM terminal 16 (HO2S2 signal) and engine ground.
- Keep engine speed at 2,000 rpm constant under no load.



- Make sure that the voltage switching frequency (high & low) between ECM terminal 16 and engine ground is very less than that of ECM terminal 35 and engine ground.


Switching frequency ratio = A/B

A: Heated oxygen sensor 2 voltage switching frequency

B: Heated oxygen sensor 1 voltage switching frequency

This ratio should be less than 0.75.

If the ratio is greater than above, it means three way catalyst does not operate properly. Go to [EC-1220, "Diagnostic Procedure"](#).



NOTE:

If the voltage at terminal 92 does not switch periodically more than 5 times within 10 seconds at step 5, perform trouble diagnosis for "DTC P0133" first. (See [EC-1129](#).)

DTC P0420 THREE WAY CATALYST FUNCTION

[QR (WITH EURO-OBD)]

EBS00GFJ

Diagnostic Procedure

1. CHECK EXHAUST SYSTEM

Visually check exhaust tubes and muffler for dent.

OK or NG

OK >> GO TO 2.

NG >> Repair or replace.


2. CHECK EXHAUST AIR LEAK

1. Start engine and run it at idle.
2. Listen for an exhaust air leak before the three way catalyst (Manifold).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.



3. CHECK INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

OK >> GO TO 4.

NG >> Repair or replace.

4. CHECK IGNITION TIMING

Check the following items. Refer to [EC-1032, "Basic Inspection"](#).

Items	Specifications	
Ignition timing	CVT	15° ± 5° BTDC (in "P" or "N" position)
	M/T	14° ± 5° BTDC
Target idle speed	CVT	650 ± 50 rpm (in "P" or "N" position)
	M/T	600 ± 50 rpm

OK or NG

OK >> GO TO 5.

NG >> Follow the "Basic Inspection".

DTC P0420 THREE WAY CATALYST FUNCTION

[QR (WITH EURO-OBD)]

5. CHECK INJECTORS


1. Refer to Wiring Diagram for Injectors, [EC-1376](#) .
2. Stop engine and then turn ignition switch "ON".
3. Check voltage between ECM terminals 22, 23, 41, 42 and ground with CONSULT-II or tester.

Battery voltage should exist.

OK or NG

OK >> GO TO 6.

NG >> Perform [EC-1377, "Diagnostic Procedure"](#) .




6. CHECK IGNITION SPARK

1. Turn ignition switch "OFF".
2. Disconnect ignition coil assembly from rocker cover.
3. Connect a known good spark plug to the ignition coil assembly.
4. Place end of spark plug against a suitable ground and crank engine.
5. Check for spark.

OK or NG

OK >> GO TO 7.

NG >> Check ignition coil with power transistor and their circuit.
Refer to [EC-1365, "IGNITION SIGNAL"](#) .



7. CHECK INJECTOR

1. Turn ignition switch "OFF".
2. Remove injector assembly.
Refer to [EM-128, "FUEL INJECTOR AND FUEL TUBE"](#) .
Keep fuel hose and all injectors connected to injector gallery.
3. Disconnect all ignition coil harness connectors.
4. Turn ignition switch "ON".
Make sure fuel does not drip from injector.

OK or NG

OK (Does not drip.)>>GO TO 8.

NG (Drips.)>>Replace the injector(s) from which fuel is dripping.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

Trouble is fixed.>>**INSPECTION END**

Trouble is not fixed.>>Replace three way catalyst (Manifold).

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PFP:14920

Description SYSTEM DESCRIPTION

EBS00GV7

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed* ¹	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage* ¹		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Vehicle speed signal* ²	Vehicle speed		


*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GVU

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0%
		2,000 rpm	20 - 30%

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

On Board Diagnosis Logic

EBS00GVZ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0444 0444	EVAP canister purge volume control solenoid valve circuit open	An excessively low voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is open or shorted.) ● EVAP canister purge volume control solenoid valve
P0445 0445	EVAP canister purge volume control solenoid valve circuit shorted	An excessively high voltage signal is sent to ECM through the valve	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid valve circuit is shorted.) ● EVAP canister purge volume control solenoid valve

DTC Confirmation Procedure

EBS00GW0

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 13 seconds.
4. If 1st trip DTC is detected, go to [EC-1225, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GVV

EC-PGC/V-01



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0016E



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	P	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p>PBIB0520E</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GVW

1. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

3. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 19 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 4.

OK (Without CONSULT-II)>>GO TO 5.

NG >> Repair open circuit or short to ground and short to power in harness or connectors.

4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

5. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-1227, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace EVAP canister purge volume control solenoid valve.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P0444, P0445 EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

Component Inspection


EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00GVX

With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between A and B
100.0%	Yes
0.0%	No



Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



Removal and Installation

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00GVY

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P0500 VSS

PFP:32702

Description

EBS00GFK

NOTE:

If DTC P0500 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from the ESP/TCS/ABS control unit or ABS actuator and electric unit (control unit) through CAN communication line. The combination meter then sends a signal to the ECM through CAN communication line.

On Board Diagnosis Logic

EBS00GFL

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500 0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The CAN communication line is open or shorted.) ● ESP/TCS/ABS control unit ● ABS actuator and electric unit (control unit) ● Wheel sensor ● Combination meter

DTC Confirmation Procedure

EBS00GFM

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Start engine.
2. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to [EC-1229, "Diagnostic Procedure"](#).
If OK, go to following step.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	2,000 - 6,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	4.9 - 31.8 msec
Selector lever	Suitable position
PW/ST SIGNAL	OFF

6. If 1st trip DTC is detected, go to [EC-1229, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

Overall Function Check

EBS00GFN

Use this procedure to check the overall function of the vehicle speed signal circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Lift up drive wheels.

2. Start engine.
3. Read vehicle speed signal in "MODE 1" with GST.
The vehicle speed signal on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-1229, "Diagnostic Procedure"](#).

Diagnostic Procedure

EBS00GFO

1. CHECK DTC

Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#) (Models without ESP) or [BRC-60, "TROUBLE DIAGNOSIS"](#) (Models with ESP).

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace.

2. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#).

>> INSPECTION END


DTC P0550 PSP SENSOR

PFP:49763

Component Description

EBS00GFP

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GFO

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

On Board Diagnosis Logic

EBS00GFR

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Power steering pressure sensor

DTC Confirmation Procedure

EBS00GFS

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1232, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P0550 PSP SENSOR



[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GFT

EC-PS/SEN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



DTC P0550 PSP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	Y	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned.	Approximately 3.6V
			[Engine is running] ● Steering wheel is not being turned.	Approximately 0.6V
55	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
65	R	Sensor's power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00GFU

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
NG >> Repair harness or connectors.



3. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and PSP sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between power steering pressure sensor and ECM
- Harness for open or short between power steering pressure sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK PSP SENSOR

Refer to [EC-1234, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace PSP sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection
POWER STEERING PRESSURE SENSOR**

EBS00GFV

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned fully.	Approximately 3.6V
Steering wheel is not being turned.	Approximately 0.6V



MBIB0025E


DTC P0605 ECM

PF:23710

Component Description

EBS00GFV

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



On Board Diagnosis Logic

EBS00GFX

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

FAIL-SAFE MODE

ECM enters fail-safe mode when malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GFY

Perform "PROCEDURE FOR MALFUNCTION A" first. If the DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-1237, "Diagnostic Procedure"](#) .



With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR MALFUNCTION B

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. If 1st trip DTC is detected, go to [EC-1237, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. Repeat step 3 procedure, 32 times.
5. If 1st trip DTC is detected, go to [EC-1237, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure**1. INSPECTION START****④ With CONSULT-II**

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-1235](#) .
5. Is the 1st trip DTC P0605 displayed again?

⑥ With GST

1. Turn ignition switch "ON".
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure".**
See [EC-1235](#) .
5. Is the 1st trip DTC P0605 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END****2. REPLACE ECM**

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1016](#), "[NATS \(Nissan Anti-theft System\)](#)".
3. Perform [EC-998](#), "[Accelerator Pedal Released Position Learning](#)".
4. Perform [EC-998](#), "[Throttle Valve Closed Position Learning](#)".
5. Perform [EC-999](#), "[Idle Air Volume Learning](#)".

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1065 ECM POWER SUPPLY

PFP:23710

Component Description

EBS00GG0

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



On Board Diagnosis Logic

EBS00GG1

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back up RAM system does not function properly.	<ul style="list-style-type: none"> ● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.] ● ECM

DTC Confirmation Procedure


EBS00GG2

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. Repeat steps 3 and 4 four times.
6. If 1st trip DTC is detected, go to [EC-1240, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P1065 ECM POWER SUPPLY




[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GG3

EC-ECM/PW-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0040E

DTC P1065 ECM POWER SUPPLY

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00GG4


1. CHECK ECM POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 10A fuse
- Harness for open or short between ECM and battery

>> Repair or replace harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connectors.

4. PERFORM DTC CONFIRMATION PROCEDURE**CONSULT-II**

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-1238](#) .
5. Is the 1st trip DTC P1065 displayed again?

GST

1. Turn ignition switch "ON".
2. Select MODE 4 with GST.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-1238](#) .
5. Is the 1st trip DTC P1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

5. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1016](#), "[NATS \(Nissan Anti-theft System\)](#)".
3. Perform [EC-998](#), "[Accelerator Pedal Released Position Learning](#)".
4. Perform [EC-998](#), "[Throttle Valve Closed Position Learning](#)".
5. Perform [EC-999](#), "[Idle Air Volume Learning](#)".

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1111 IVT CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

DTC P1111 IVT CONTROL SOLENOID VALVE

PFP:23796

Component Description

EBS00GG5


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GG6

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0% - 2%
		When revving engine up to 2,000 rpm quickly	Approx. 0% - 50%

On Board Diagnosis Logic

EBS00GG7

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1111 1111	Intake valve timing control solenoid valve circuit	An improper voltage is sent to the ECM through intake valve timing control solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (Solenoid valve circuit is open or shorted.) ● Intake valve timing control solenoid valve

DTC Confirmation Procedure

EBS00GG8

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1244, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Following the procedure "WITH CONSULT-II" above.

DTC P1111 IVT CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GG9

EC-IVC-01

A

EC

C

D

E

F

G

H


I

J




K

L

M



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- L** : LHD MODELS
- R** : RHD MODELS



MBWA0017E



DTC P1111 IVT CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
62	Y	Intake valve timing control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)</p>  <p>MBIB0052E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● When revving engine up to 2,000 rpm quickly 	<p>Approximately 4V - BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0532E</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GGA

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect intake valve timing control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between intake valve timing control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



DTC P1111 IVT CONTROL SOLENOID VALVE

[QR (WITH EURO-OBD)]

2. DETECT MALFUNCTION PART

Check harness for open or short between intake valve timing control solenoid valve and ECM relay.

>> Repair or replace harness or connectors.

3. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 62 and intake valve timing control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-1245, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace intake valve timing control solenoid valve.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00GGB

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve terminals 1 and 2 under the following conditions.

Terminals	Resistance
1 and 2	Approximately 8Ω at 20°C (68°F)
1 or 2 and ground	$\infty\Omega$ (Continuity should not exist)



EBS00GGC

Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EM-143, "TIMING CHAIN"](#) .

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QR (WITH EURO-OBDD)]

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PF16:16119

Component Description

EBS00GGD

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00GGE

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open. This self-diagnosis has the one trip detection logic.	

FAIL-SAFE MODE

When the malfunction A or B is detected in the two consecutive trips, the ECM enters in fail-safe mode and MI lights up.

When the malfunction C is detected even in the 1st trip, the ECM enters in fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.

DTC Confirmation Procedure

EBS00GNX

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A AND B" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A AND B

④ With CONSULT-II

1. Turn ignition witch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. If 1st trip DTC is detected, go to [EC-1247, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

④ With GST


Follow the procedure "With CONSULT-II" above.

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QR (WITH EURO-OBD)]

PROCEDURE FOR MALFUNCTION C

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
4. Shift selector lever to "N" or "P" position.
5. Start engine and let it idle for 3 seconds.
6. If DTC is detected, go to [EC-1247, "Diagnostic Procedure"](#) .



DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

Diagnostic Procedure


EBS00GNY

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if a foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 2.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Removal and Installation

EBS00HBW

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PFP:16119

Description

EBS00GGH

NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-1246](#) or [EC-1255](#).

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00GGI

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is open or shorted.) ● Harness or connectors (Throttle control motor relay circuit is open or shorted.) ● Electric throttle control actuator ● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GGJ

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1250, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST


Follow the procedure "WITH CONSULT-II" above.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]



Wiring Diagram

EBS00GGK

EC-ETC1-01



A
EC
C
D
E
F
G
H
I
J
K
L
M





MBWA0132E

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00GGL

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]


2. CHECK THROTTLE CONTROL MOTOR RELAY SIGNAL CIRCUIT

Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)


OK or NG

- OK >> GO TO 10.
- NG >> GO TO 3.



3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair or replace harness or connectors.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

[QR (WITH EURO-OBD)]

5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.
NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair or replace harness or connectors.

9. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-1254, "Component Inspection"](#) .

OK or NG


- OK >> GO TO 13.
NG >> Replace throttle control motor relay.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]

10. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG


- OK >> GO TO 11.
NG >> Repair or replace.

11. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 12.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



12. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-1254, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 13.
NG >> GO TO 14.

13. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 14.
NG >> Repair or replace harness or connectors.

14. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITH EURO-OBD)]


EBS00GGM

Component Inspection THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.




THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-999, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GGN

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PFP:16119

Component Description

EBS00GGO

Power supply for the Throttle Control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GGP

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

On Board Diagnosis Logic

EBS00GGQ

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detect the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is shorted.) ● Throttle control motor relay
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low. This self-diagnosis has the one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is open.) ● Throttle control motor relay

FAIL-SAFE MODE

When the DTC P1124 is detected in the two consecutive trips, the ECM enters fail-safe mode and MI lights up. When the DTC P1126 is detected even in the 1st trip, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GGR

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR DTC P1124

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-1258, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST

Follow the procedure "With CONSULT-II" above.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

PROCEDURE FOR DTC P1126

With CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1258, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

With GST




Follow the procedure "With CONSULT-II" above.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GGS

EC-ETC2-01



MBWA0133E

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

Diagnostic Procedure

EBS00GGT

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair or replace harness or connectors.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

3. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair or replace harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-1259, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace throttle control motor relay.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection THROTTLE CONTROL MOTOR RELAY


1. Apply 12V direct current between relay terminals 1 and 2.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITH EURO-OBD)]

2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.



DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITH EURO-OBD)]

DTC P1128 THROTTLE CONTROL MOTOR

PFP:16119

Component Description

EBS00GGV

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00GGW

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short both circuits between ECM and throttle control motor.	<ul style="list-style-type: none">● Harness or connectors (Throttle control motor circuit is shorted.)● Electric throttle control actuator (Throttle control motor)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GGX

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1263, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.



DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	BR	Throttle control motor (Close)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	<p>0 - 14V★</p>  <p>PBIB0534E</p>
5	Y	Throttle control motor (Open)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	<p>0 - 14V★</p>  <p>PBIB0533E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00GGZ

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITH EURO-OBD)]

2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace.

3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-1264, "Component Inspection"](#).

OK or NG

- OK >> GO TO 4.
NG >> GO TO 5.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness or connectors.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#).
3. Perform [EC-999, "Idle Air Volume Learning"](#).

>> INSPECTION END


Component Inspection THROTTLE CONTROL MOTOR

EBS00GH0

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-998, "Throttle Valve Closed Position Learning"](#).
5. Perform [EC-999, "Idle Air Volume Learning"](#).



PBIB0095E

DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITH EURO-OBD)]

Remove and Installation

ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GH1

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P1143 HO2S1

PFP:22690

Component Description

EBS00GH2

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GH3


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GH4

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high and whether the “lean” output is sufficiently low. When both the outputs are shifting to the lean side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1143 1143	Heated oxygen sensor 1 lean shift monitoring	The maximum and minimum voltage from the sensor are not reached to the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00GH5

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously conducted, always turn ignition switch “OFF” and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

- Always perform at a temperature above -10°C (14°F).
- Before performing following procedure, confirm that battery voltage is more than 11V at idle.

Ⓟ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Turn ignition switch “ON” and select “HO2S1 (B1) P1143” of “HO2S1” in “DTC WORK SUPPORT” mode with CONSULT-II.
4. Touch “START”.
5. Start engine and let it idle for at least 3 minutes.

NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.

HO2S1 (B1) P1143	
OUT OF CONDITION	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0546E

6. When the following conditions are met, “TESTING” will be displayed on the CONSULT-II screen. Maintain the conditions continuously until “TESTING” changes to “COMPLETED”. (It will take approximately 50 seconds or more.)


ENG SPEED	1,400 - 3,200 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.9 - 14.5 msec
Selector lever	Suitable position

If “TESTING” is not displayed after 5 minutes, retry from step 2.

HO2S1 (B1) P1143	
TESTING	
MONITOR	
ENG SPEED	XXX rpm
B/FUEL SCHDL	XXX msec
COOLAN TEMP/S	XXX °C
VHCL SPEED SEN	XXX km/h

PBIB0547E

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1268, "Diagnostic Procedure"](#) .




Overall Function Check

EBS00GH6

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is over 0.6V at least one time.
 - The minimum voltage is over 0.1V at least one time.
4. If NG, go to [EC-1268, "Diagnostic Procedure"](#) .



MBIB0018E


Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

EBS00GH7

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




2. RETIGHTEN HEATED OXYGEN SENSOR 1

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


Ⓜ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer to [EC-1157](#).
No >> GO TO 4.

4. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1094, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
NG >> Replace heated oxygen sensor 1.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1270, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-1121, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GH8

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN


SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5
HO2S1 MNTR (B1)	R	L	R	L	R

R means HO2S1 MNTR (B1) indicates RICH
L means HO2S1 MNTR (B1) indicates LEAN

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

EBS00GH9

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .



DTC P1144 HO2S1

PFP:22690

Component Description

EBS00GHA

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GHB


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GHC

To judge the malfunction, the output from the heated oxygen sensor 1 is monitored to determine whether the “rich” output is sufficiently high. The “lean” output is sufficiently low. When both the outputs are shifting to the rich side, the malfunction will be detected.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1144 1144	Heated oxygen sensor 1 rich shift monitoring	The maximum and minimum voltages from the sensor are beyond the specified voltages.	<ul style="list-style-type: none"> ● Heated oxygen sensor 1 ● Heated oxygen sensor 1 heater ● Fuel pressure ● Injectors

DTC Confirmation Procedure

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:


- Always perform at a temperature above -10°C (14°F).
- Before performing the following procedure, confirm that battery voltage is more than 11V at idle.

WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 5 seconds.
3. Turn ignition switch "ON" and select "HO2S1 (B1) P1144" of "HO2S1" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 3 minutes.


NOTE:

Never raise engine speed above 3,600 rpm after this step. If the engine speed limit is exceeded, return to step 5.




6. When the following conditions are met, "TESTING" will be displayed on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 50 seconds or more.)

ENG SPEED	1,400 - 3,200 rpm
Vehicle speed	Less than 100 km/h (62 MPH)
B/FUEL SCHDL	2.9 - 14.5 msec
Selector lever	Suitable position



If "TESTING" is not displayed after 5 minutes, retry from step 2.

7. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS". If "NG" is displayed, refer to [EC-1274, "Diagnostic Procedure"](#).




Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check one of the following with engine speed held at 2,000 rpm constant under no load.
 - The maximum voltage is below 0.8V at least one time.
 - The minimum voltage is below 0.35V at least one time.
4. If NG, go to [EC-1274, "Diagnostic Procedure"](#) .




EBS00GHF

Diagnostic Procedure**1. RETIGHTEN GROUND SCREWS**

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.

**2. RETIGHTEN HEATED OXYGEN SENSOR 1**

Loosen and retighten heated oxygen sensor 1.

Tightening torque: 40 - 50 N·m (4.1 - 5.1 kg·m, 30 - 37 ft·lb)


>> GO TO 3.



3. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-1163](#).
No >> GO TO 4.


4. CHECK HO2S1 CONNECTOR FOR WATER

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Check connectors for water.

Water should not exist.

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness or connectors.



5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1094, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 1.

6. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1276, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace heated oxygen sensor 1.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

For circuit, refer to [EC-1121, "Wiring Diagram"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GHG

④ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1 2 3 4 5
HO2S1 MNTR (B1)	R-L-R-L-R-L-R-L-R
R means HO2S1 MNTR (B1) indicates RICH	
L means HO2S1 MNTR (B1) indicates LEAN	

SEF217YA



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.


⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.

- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
HEATED OXYGEN SENSOR 1**

EBS00GHH

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).

DTC P1146 HO2S2

PFP:226A0

Component Description


EBS00GHI

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GHJ


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00GHK

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the minimum voltage of sensor is sufficiently low during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1146 1146	Heated oxygen sensor 2 minimum voltage monitoring	The minimum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors

DTC Confirmation Procedure

EBS00GHL

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in "Procedure for COND1"

Ⓟ WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1146" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1146																																												
COND1:	OUT OF CONDITION																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	TESTING																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											
HO2S2 (B1) P1146																																												
COND1:	COMPLETED																																											
COND2:	INCOMPLETE																																											
COND3:	INCOMPLETE																																											
MONITOR																																												
ENG SPEED	XXX rpm																																											
B/FUEL SCHDL	XXX msec																																											

PBIB0555E

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)

NOTE:


If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1146</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1146		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec
HO2S2 (B1) P1146														
COND1:	COMPLETED													
COND2:	COMPLETED													
COND3:	INCOMPLETE													
MONITOR														
ENG SPEED	XXX rpm													
B/FUEL SCHDL	XXX msec													

PBIB0556E

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-1282. "Diagnostic Procedure"](#) .



Overall Function Check

EBS00GHM

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)


The voltage should be below 0.50V at least once during this procedure.

If the voltage can be confirmed in step 4, step 5 is not necessary.

5. Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position (CVT), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.


6. If NG, go to [EC-1282. "Diagnostic Procedure"](#) .



Wiring Diagram

EBS00GHN


EC-HO2S2-01




REFER TO PG-POWER.

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC

A
 EC
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W/Y	Heated oxygen sensor 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V
74	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V


Diagnostic Procedure

EBS00GHO

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
Is the 1st trip DTC P0172 detected?
Is it difficult to start engine?



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0172. Refer to [EC-1163](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-1284, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00GHP


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.

“HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)

The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.


5. Keep vehicle at idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in “D” position (CVT), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.

6. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation

HEATED OXYGEN SENSOR 2

Refer to [EX-3, "EXHAUST SYSTEM"](#) .


DTC P1147 HO2S2

PFP:226A0

Component Description

EBS00GHR

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank. Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2. This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GHS


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

On Board Diagnosis Logic

EBS00GHT

The heated oxygen sensor 2 has a much longer switching time between rich and lean than the heated oxygen sensor 1. The oxygen storage capacity before the three way catalyst causes the longer switching time. To judge the malfunctions of heated oxygen sensor 2, ECM monitors whether the maximum voltage of the sensor is sufficiently high during the various driving condition such as fuel-cut.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1147 1147	Heated oxygen sensor 2 maximum voltage monitoring	The maximum voltage from the sensor is not reached to the specified voltage.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit open or shorted.) ● Heated oxygen sensor 2 ● Fuel pressure ● Injectors ● Intake air leaks

DTC Confirmation Procedure

EBS00GHU

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

- "COMPLETED" will appear on CONSULT-II screen when all tests "COND1", "COND2" and "COND3" are completed.
- If "DTC confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Never stop engine during this procedure. If the engine is stopped, retry procedure from step 2 in "Procedure for COND1"

WITH CONSULT-II

Procedure for COND1

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON" and select "HO2S2 (B1) P1147" of "HO2S2" in "DTC WORK SUPPORT" mode with CONSULT-II.
4. Touch "START".
5. Start engine and let it idle for at least 30 seconds.
6. Rev engine up to 2,000 rpm 2 or 3 times quickly under no load.
If "COMPLETED" appears on CONSULT-II screen, go to step 2 in "Procedure for COND3".
If "COMPLETED" does not appear on CONSULT-II screen, go to the following step.
7. Drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
8. When the following conditions are met, "TESTING" will be displayed at "COND1" on the CONSULT-II screen. Maintain the conditions continuously until "TESTING" changes to "COMPLETED". (It will take approximately 60 seconds.)

ENG SPEED	More than 1,000 rpm
B/FUEL SCHDL	More than 1.0 msec
COOLANT TEMP/S	70 - 105°C
Selector lever	Suitable position

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>OUT OF CONDITION</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	OUT OF CONDITION	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>TESTING</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	TESTING	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>INCOMPLETE</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	INCOMPLETE	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0557E
HO2S2 (B1) P1147																																													
COND1:	OUT OF CONDITION																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	TESTING																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												
HO2S2 (B1) P1147																																													
COND1:	COMPLETED																																												
COND2:	INCOMPLETE																																												
COND3:	INCOMPLETE																																												
MONITOR																																													
ENG SPEED	XXX rpm																																												
B/FUEL SCHDL	XXX msec																																												

NOTE:

- If "TESTING" is not displayed after 5 minutes, retry from step 2 in "Procedure for COND1".
- If "COMPLETED" already appears at "COND2" on CONSULT-II screen before "Procedure for COND2" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND2".

Procedure for COND2

1. While driving, release accelerator pedal completed from the above condition [step 8] until "INCOMPLETE" at "COND2" on CONSULT-II screen has turned to "COMPLETED" (It will take approximately 4 seconds.)


NOTE:

If "COMPLETE" already appears at "COND3" on CONSULT-II screen before "Procedure for COND3" is conducted, it is unnecessary to conduct step 1 in "Procedure for COND3".

<table border="1"> <tr><th colspan="2">HO2S2 (B1) P1147</th></tr> <tr><td>COND1:</td><td>COMPLETED</td></tr> <tr><td>COND2:</td><td>COMPLETED</td></tr> <tr><td>COND3:</td><td>INCOMPLETE</td></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>ENG SPEED</td><td>XXX rpm</td></tr> <tr><td>B/FUEL SCHDL</td><td>XXX msec</td></tr> </table>	HO2S2 (B1) P1147		COND1:	COMPLETED	COND2:	COMPLETED	COND3:	INCOMPLETE	MONITOR		ENG SPEED	XXX rpm	B/FUEL SCHDL	XXX msec	PBIB0558E
HO2S2 (B1) P1147															
COND1:	COMPLETED														
COND2:	COMPLETED														
COND3:	INCOMPLETE														
MONITOR															
ENG SPEED	XXX rpm														
B/FUEL SCHDL	XXX msec														

Procedure for COND3

1. Stop vehicle and let it idle until "INCOMPLETE" of "COND3" on CONSULT-II screen has turned to "COMPLETED". (It will take a maximum of approximately 6 minutes.)
2. Make sure that "OK" is displayed after touching "SELF-DIAG RESULTS".
If "NG" is displayed, refer to [EC-1290, "Diagnostic Procedure"](#) .

**Overall Function Check**

EBS00GHV

Use this procedure to check the overall function of the heated oxygen sensor 2 circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
(Depress and release accelerator pedal as soon as possible.)


The voltage should be above 0.68V at least once during this procedure.

If the voltage can be confirmed in step 4, step 5 is not necessary.

5. Keep vehicle idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position (CVT), 3rd gear position (M/T).

The voltage should be above 0.68V at least once during this procedure.

6. If NG, go to [EC-1290, "Diagnostic Procedure"](#) .




MBIB0020E

Wiring Diagram

EBS00GHW


EC-HO2S2-01




REFER TO PG-POWER.

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 E106 - FUSE BLOCK-JUNCTION BOX (J/B)



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W/Y	Heated oxygen sensor 2	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00GHX

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.


>> GO TO 2.



2. CLEAR THE SELF-LEARNING DATA


☑ With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "SELF-LEARNING CONT" in "WORK SUPPORT" mode with CONSULT-II.
3. Clear the self-learning control coefficient by touching "CLEAR".
4. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?**



⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Disconnect mass air flow sensor harness connector, and restart and run engine for at least 5 seconds at idle speed.
4. Stop engine and reconnect mass air flow sensor harness connector.
5. Make sure that DTC P0102 is displayed.
6. Erase the DTC memory. Refer to [EC-1015, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).
7. Make sure that DTC P0000 is displayed.
8. Run engine for at least 10 minutes at idle speed.
**Is the 1st trip DTC P0171 detected?
Is it difficult to start engine?**



Yes or No

- Yes >> Perform trouble diagnosis for DTC P0171. Refer to [EC-1157](#) .
No >> GO TO 3.

3. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-1292, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00GHY


With CONSULT-II

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

4. Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.




“HO2S2 (B1)” should be above 0.68V at least once when the “FUEL INJECTION” is +25%.
 “HO2S2 (B1)” should be below 0.50V at least once when the “FUEL INJECTION” is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ **Without CONSULT-II**

1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and engine ground.
4. Check the voltage when revving up to 4,000 rpm under no load at least 10 times.
 (Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.
If the voltage is above 0.68V at step 4, step 5 is not necessary.



5. Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in “D” position (CVT), 3rd gear position (M/T).
The voltage should be below 0.50V at least once during this procedure.
6. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

**Removal and Installation
 HEATED OXYGEN SENSOR 2**

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

EBS00GHZ

DTC P1212 ESP/TCS/ABS COMMUNICATION LINE

[QR (WITH EURO-OBD)]

DTC P1212 ESP/TCS/ABS COMMUNICATION LINE

PFP:47850

Description

EBS00GWG

NOTE:

If DTC P1212 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

This CAN communication line is used to control the smooth engine operation during ESP/TCS/ABS operation. Pulse signals are exchanged between ECM and ESP/ABS/TCS control unit.

Be sure to erase the malfunction information such as DTC not only in ESP/TCS/ABS control unit but also ECM after the ESP/TCS/ABS related repair.

On Board Diagnosis Logic

EBS00GWH

Freeze frame data is not stored in the ECM for this self-diagnosis. The MI will not light up for this self-diagnosis.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1212 1212	ESP/TCS/ABS communication line	ECM can not receive the information from ESP/TCS/ABS control unit continuously.	<ul style="list-style-type: none">● Harness or connectors (The CAN communication line between ECM and ESP/TCS/ABS control unit is open or shorted.)● ESP/TCS/ABS control unit● Dead (Weak) battery

DTC Confirmation Procedure

EBS00GWI

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 10 seconds.
4. If a 1st trip DTC is detected, go to [EC-1294, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00GWJ

1. CHECK ESP/TCS/ABS CONTROL UNIT FUNCTION

Refer to [BRC-60, "TROUBLE DIAGNOSIS"](#).

>> INSPECTION END

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

DTC P1217 ENGINE OVER TEMPERATURE

PF0:00000

System Description

EBS00G10

NOTE:

If DTC P1217 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

COOLING FAN CONTROL


Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed signal	Vehicle speed*1	Cooling fan control	Cooling fan relay(s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal*1		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2		
Battery	Battery voltage*2		
Refrigerant pressure sensor	Refrigerant pressure		

*1: These signals are sent to ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF]. The ECM sends a cooling fan control signal to the smart entrance control unit through CAN communication line, and the smart entrance control unit controls cooling fan relays.

OPERATION



CONSULT-II Reference Value in Data Monitor Mode

EBS00G11

Specification data are reference values.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature is 99°C (210°F) or less	OFF
		Engine coolant temperature is 100°C (212°F) or more	ON

On Board Diagnosis Logic

EBS00G12

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to EC-1310, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-20](#), "Changing Engine Coolant". Also, replace the engine oil. Refer to [MA-24](#), "Changing Engine Oil".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-18](#), "Engine Coolant Mixture Ratio".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

EBS00G13

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1300](#), "Diagnostic Procedure".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1300](#), "Diagnostic Procedure".
3. Turn ignition switch "ON".



SEF621W

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]




4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-1300, "Diagnostic Procedure"](#).

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E

WITH GST

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1300, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1300, "Diagnostic Procedure"](#).
3. Start engine.
Be careful not to overheat engine.
4. Set temperature control lever to full cold position.
5. Turn air conditioner switch "ON".
6. Turn blower fan switch "ON".
7. Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
8. Make sure that cooling fans operate at low speed.
If NG, go to [EC-1300, "Diagnostic Procedure"](#).
If OK, go to the following step.
9. Turn ignition switch "OFF".
10. Turn air conditioner switch and blower fan switch "OFF".
11. Disconnect engine coolant temperature sensor harness connector.
12. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
13. Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.
14. If NG, go to [EC-1300, "Diagnostic Procedure"](#).






DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

EBS00G14




Wiring Diagram LHD MODELS

EC-COOL/F-01



REFER TO THE FOLLOWING.

(E106) - FUSE BLOCK-JUNCTION BOX (J/B)





MBWA0018E

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

RHD MODELS



MBWA0146E

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

EBS00GRN

Diagnostic Procedure

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 5.

2. CHECK COOLING FAN LOW SPEED OPERATION

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II and touch "LOW" on the CONSULT-II screen.
3. Make sure that cooling fans-1 and -2 operate at low speed.

OK or NG

- OK >> GO TO 3.
- NG >> Check cooling fan low speed control circuit. (Go to [EC-1304](#), "PROCEDURE A" .)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLANT TEMP/S	XXX °C

SEF784Z

3. CHECK COOLING FAN HIGH SPEED OPERATION-I

④ With CONSULT-II

1. Touch "HIGH" on the CONSULT-II screen.
2. Make sure that cooling fan-1 operates at higher speed than low speed.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan high speed control circuit-1. (Go to [EC-1306](#), "PROCEDURE B" .)

ACTIVE TEST	
COOLING FAN	HIGH
MONITOR	
COOLANT TEMP/S	XXX °C

SEF785Z

4. CHECK COOLING FAN HIGH SPEED OPERATION-II

④ With CONSULT-II

Make sure that cooling fan-2 operates at higher speed than low speed.

OK or NG

- OK >> GO TO 8.
- NG >> Check cooling fan high speed control circuit-2. (Go to [EC-1308](#), "PROCEDURE C" .)

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

5. CHECK COOLING FAN LOW SPEED OPERATION


⊗ Without CONSULT-II

1. Start engine and let it idle.
2. Turn air conditioner switch "ON".
3. Turn blower fan switch "ON".
4. Make sure that cooling fans-1 and -2 operate at low speed.

OK or NG

OK >> GO TO 6.

NG >> Check cooling fan low speed control circuit. (Go to [EC-1304, "PROCEDURE A"](#).)



6. CHECK COOLING FAN HIGH SPEED OPERATION-I


⊗ Without CONSULT-II

1. Turn ignition switch "OFF".
2. Turn air conditioner switch and blower fan switch "OFF".
3. Disconnect engine coolant temperature sensor harness connector.
4. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
5. Restart engine and make sure that cooling fan-1 operates at higher speed than low speed.

OK or NG

OK >> GO TO 7.

NG >> Check cooling fan high speed control circuit-1. (Go to [EC-1306, "PROCEDURE B"](#).)



7. CHECK COOLING FAN HIGH SPEED OPERATION-II

⊗ Without CONSULT-II

Make sure that cooling fan-2 operates higher speed than lower speed.

OK or NG

OK >> GO TO 8.

NG >> Check cooling fan high speed control circuit-2. (Go to [EC-1308, "PROCEDURE C"](#).)

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

8. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 157 kPa (1.57 bar, 1.6 kg/cm² , 23psi)


CAUTION:

Higher than the specified pressure may cause radiator damage.

Pressure should not drop.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.



9. DETECT MALFUNCTIONING PART

Check the following for leak.

- Hose
- Radiator
- Water pump (Refer to [CO-38, "WATER PUMP"](#) .)

>> Repair or replace.

10. CHECK RADIATOR CAP


Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure:

78 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm² , 9 - 14 psi)

OK or NG

- OK >> GO TO 11.
- NG >> Replace radiator cap.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

11. CHECK THERMOSTAT

1. Remove thermostat.
2. Check valve seating condition at normal room temperatures.
It should seat tightly.
3. Check valve opening temperature and valve lift.

Valve opening temperature:

80.5 - 83.5 °C (177 - 182 °F)

Valve lift:

More than 8 mm/95 °C (0.31 in/203 °F)

4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to [CO-40, "THERMOSTAT AND WATER CONTROL VALVE"](#).

OK or NG

OK >> GO TO 12.

NG >> Replace thermostat.

12. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1115, "Component Inspection"](#).

OK or NG


OK >> GO TO 13.

NG >> Replace engine coolant temperature sensor.

13. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1310, "Main 12 Causes of Overheating"](#).

>> INSPECTION END



A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

PROCEDURE A

1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-1 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

3. CHECK COOLING FAN MOTORS CONTROL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Disconnect cooling fan relay-2 and cooling fan relay-4.
4. Check harness continuity between the following.
 - Cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1
 - Cooling fan motor-1 terminal 2 and cooling fan relay-2 terminal 3
 - Cooling fan motor-1 terminal 2 and cooling fan relay-4 terminal 3
 - Cooling fan relay-2 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan relay-4 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan motor-2 terminal 2 and groundRefer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-1 terminal 1 and smart entrance control unit terminal 33. Refer to Wiring Diagram.


Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-1 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK COOLING FAN RELAY-1, -2 AND 4

Refer to [EC-1311, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan relay.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

7. CHECK COOLING FAN MOTORS-1 AND -2

Refer to [EC-1311, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace cooling fan motors.

8. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace smart entrance control unit.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

PROCEDURE B

1. CHECK COOLING FAN RELAY GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-2 and cooling fan relay-4.
3. Check harness continuity between cooling fan relay-2 terminal 5 and ground, cooling fan relay-4 terminal 5 and ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 2.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-2 terminal 2 and smart entrance control unit terminal 32, cooling fan relay-4 terminal 2 and smart entrance control unit terminal 32. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-2 and smart entrance control unit
- Harness for open or short between cooling fan relay-4 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COOLING FAN RELAYS-2 AND -4

Refer to [EC-1311, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace cooling fan relays.

5. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace smart entrance control unit.

6. CHECK INTERMITTENT INCIDENT

Perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

PROCEDURE C

1. CHECK COOLING FAN MOTOR-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-3.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-3 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-3 and fuse
- Harness for open or short between cooling fan relay-3 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-2 harness connector.
3. Check harness continuity between cooling fan relay-3 terminal 5 and cooling fan motor-2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to power in harness or connectors.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

4. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR SHORT TO GROUND

Check harness continuity between cooling fan relay-3 terminal 5 or cooling fan motor-2 terminal 1 and ground. Refer to Wiring Diagram.

Continuity should not exist.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Cooling fan relays-2 and -4 (Refer to [EC-1311, "Component Inspection"](#))
- Harness for short to ground between cooling fan relay-2 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-3 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-4 and cooling fan motor-2

>> Repair or replace.

6. CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-3 terminal 1 and smart entrance control unit terminal 32. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-3 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK COOLING FAN RELAY-3

Refer to [EC-1311, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace cooling fan relay.

9. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace smart entrance control unit.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITH EURO-OBD)]

10. CHECK INTERMITTENT INCIDENT

Perform [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Main 12 Causes of Overheating

EBS00G16

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-18, "Engine Coolant Mixture Ratio" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See CO-29, "LEVEL CHECK" .
	4	● Radiator cap	● Pressure tester	59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See CO-32, "CHECKING RADIATOR CAP" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See CO-29, "LEAK CHECK" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-40, "THERMOSTAT AND WATER CONTROL VALVE" , and CO-31, "RADIATOR" .
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 (EC-1295) .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-20, "Changing Engine Coolant" .
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-29, "LEVEL CHECK" .
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-152, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-165, "CYLINDER BLOCK" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to [CO-25, "OVERHEATING CAUSE ANALYSIS"](#) .

DTC P1217 ENGINE OVER TEMPERATURE


[QR (WITH EURO-OBD)]

EBS00G17

Component Inspection COOLING FAN RELAY-1 AND -3

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



COOLING FAN RELAY-2 AND -4

Check continuity between terminals 3 and 4, 3 and 5 under the following conditions.


Conditions	Terminals	Continuity
12V direct current supply between terminals 1 and 2	3 and 4	No
	3 and 5	Yes
No current supply	3 and 4	Yes
	3 and 5	No



COOLING FAN MOTOR-1 AND -2

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(+)	(-)
Cooling fan motor	1	2



DTC P1223, P1224 TP SENSOR


PFP:16119

Component Description

EBS00G18

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00G19

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00G1A

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1223 1223	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 2)
P1224 1224	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00G1B

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1223, P1224 TP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1315, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1223, P1224 TP SENSOR

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00G1C

EC-TPS2-01



MBWA0126E

DTC P1223, P1224 TP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00GID

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1317, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection
THROTTLE POSITION SENSOR**

EBS00GIE

1. Reconnect all harness connectors disconnected.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-999, "Idle Air Volume Learning"](#) .



MBIB0022E

**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00GIF

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1225 TP SENSOR


PFP:16119

Component Description

EBS00GIG

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00GIH

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00GIJ

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds.
4. Turn ignition switch "ON".
5. If 1st trip DTC is detected, go to [EC-1319, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "With CONSULT-II" above.


Diagnostic Procedure**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1226 TP SENSOR


PFP:16119

Component Description

EBS00GIL

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00GIM

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance problem	Closed throttle position learning is not performed successfully, repeatedly.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00GIN

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 10 seconds.
- Turn ignition switch "ON".
- Repeat steps 3 and 4, 32 times.
- If 1st trip DTC is detected, go to [EC-1321, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "With CONSULT-II" above.


Diagnostic Procedure**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1227, P1228 APP SENSOR

PFP:18002


Component Description

EBS00GIQ

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GIQ

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00GIS

These half-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1227 1227	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P1228 1228	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GIT

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1227, P1228 APP SENSOR

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1325, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

WITH GST

Follow the procedure "WITH CONSULT-II" above.







DTC P1227, P1228 APP SENSOR

[QR (WITH EURO-OBD)]

EBS00GIU

EC-APPS2-01

Wiring Diagram



MBWA0130E

DTC P1227, P1228 APP SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

EBS00GIV


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and APP sensor terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1327, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00GIW

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P1227, P1228 APP SENSOR

[QR (WITH EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-999, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00GIX

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P1229 SENSOR POWER SUPPLY

[QR (WITH EURO-OBD)]

DTC P1229 SENSOR POWER SUPPLY

PFPP:16119

On Board Diagnosis Logic

EBS00GIY

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none">● Harness or connectors (The TP sensor 1 and 2 circuit is shorted.) (APP sensor 2 circuit is shorted.)● Electric throttle control actuator (TP sensor 1 and 2)● Accelerator pedal position sensor (APP sensor 2)● ECM pin terminal

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00GIZ

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1331, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

Ⓢ WITH GST

Follow the procedure "WITH CONSULT-II" above.




DTC P1229 SENSOR POWER SUPPLY

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GJ0

EC-SEN/PW-01



DTC P1229 SENSOR POWER SUPPLY

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00GJ1

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 6.
NG >> GO TO 3.



DTC P1229 SENSOR POWER SUPPLY

[QR (WITH EURO-OBD)]

3. CHECK SENSOR POWER SUPPLY CIRCUITS FOR SHORT

Check the following.

- Harness for short to power and short to ground between following terminals.

ECM terminal	Sensor terminals	Reference Wiring Diagram
47	Electric throttle control actuator terminal 1	EC-1330
	Accelerator pedal position sensor terminal 1	EC-1324

- ECM pin terminal.

OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

4. CHECK ACCELERATOR PEDAL POSITON SENSOR

Refer to [EC-1327, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> GO TO 5.

5. REPLACE ACCELERATOR PEDAL POSITION SENSOR

1. Replace accelerator pedal position sensor.
2. Perform [EC-998, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1174, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

7. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-998, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-999, "Idle Air Volume Learning"](#) .

>> INSPECTION END

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1564 ICC STEERING SWITCH

[QR (WITH EURO-OBD)]

DTC P1564 ICC STEERING SWITCH


PFP:25551

Component Description

EBS00GTV

ICC steering switch has variant values of electrical resistance for each button. ECM reads voltage variation of switch, and determines which button is operated.

Refer to [ACS-5, "DESCRIPTION"](#) for the ICC function.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GTW

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN SW	● Ignition switch: ON	● ON/OFF switch pressed	ON
		● ON/OFF switch released	OFF
CANCEL	● Ignition switch: ON	● CANCEL switch pressed	ON
		● CANCEL switch released	OFF
RESUME/ACC SW	● Ignition switch: ON	● ACCEL RES switch pressed	ON
		● ACCEL RES switch released	OFF
SET SW	● Ignition switch: ON	● COAST/SET switch pressed	ON
		● COAST/SET switch released	OFF
DIST SW	● Ignition switch: ON	● DISTANCE switch pressed	ON
		● DISTANCE switch released	OFF

On Board Diagnosis Logic

EBS00GTX

NOTE:

If DTC P1564 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-1235](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1564 1564	ICC steering switch	<ul style="list-style-type: none"> ● An excessively high voltage signal from the ICC steering switch is sent to ECM. ● ECM detects that input signal from the ICC steering switch is out of the specified range. ● ECM detects that the ICC steering switch is stuck ON. 	<ul style="list-style-type: none"> ● Harness or connectors (The switch circuit is open or shorted.) ● ICC steering switch ● ECM

DTC Confirmation Procedure

EBS00GTY

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1564 ICC STEERING SWITCH

[QR (WITH EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 10 seconds.
4. Press "CRUISE" switch for at least 10 seconds, then release it and wait at least 10 seconds.
5. Press "ACCEL/RES" switch for at least 10 seconds, then release it and wait at least 10 seconds.
6. Press "COAST/SET" switch for at least 10 seconds, then release it and wait at least 10 seconds.
7. Press "DISTANCE" switch for at least 10 seconds, then release it and wait at least 10 seconds.
8. Press "CANCEL" switch for at least 10 seconds, then release it and wait at least 10 seconds.
9. If 1st trip DTC is detected, go to [EC-1337, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y



WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P1564 ICC STEERING SWITCH






[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GTZ

EC-ICC/SW-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

MBWA0153E

DTC P1564 ICC STEERING SWITCH

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
82	B	Sensor's ground (ICC steering switch)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
99	PU	ICC steering switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● ICC steering switch is "OFF". 	Approximately 4.3V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● ON/OFF switch is "ON". 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● CANCEL switch is "ON". 	Approximately 1.3V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● DISTANCE switch is "ON". 	Approximately 2.2V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● SET/COAST switch is "ON". 	Approximately 3V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● RESUME/ACCEL switch is "ON". 	Approximately 3.7V

DTC P1564 ICC STEERING SWITCH

[QR (WITH EURO-OBD)]

EBS00GU0

Diagnostic Procedure

1. CHECK ICC STEERING SWITCH CIRCUIT

With CONSULT-II

- Turn ignition switch "ON".
- Select "MAIN SW", "RESUME/ACC SW", "SET SW", "DIST SW" and "CANCEL SW" in "DATA MONITOR" mode with CONSULT-II.
- Check each item indication under the following conditions.

Switch	Monitor item	Condition	Indication
ON/OFF	MAIN SW	Pressed	ON
		Released	OFF
COAST/SET	SET SW	Pressed	ON
		Released	OFF
ACCEL/RES	RESUME/ACC SW	Pressed	ON
		Released	OFF
DISTANCE	DIST SW	Pressed	ON
		Released	OFF
CANCEL	CANCEL SW	Pressed	ON
		Released	OFF


DATA MONITOR	
MONITOR	NO DTC
MAIN SW	OFF
CANCEL SW	OFF
RESUME/ACC SW	OFF
SET SW	OFF
DIST SW	OFF

MBIB0064E

Without CONSULT-II

- Turn ignition switch "ON".
- Check voltage between ECM terminal 99 and ground with pressing each button.

Switch	Condition	Voltage [V]
ON/OFF	Pressed	Approx. 0
	Released	Approx. 4.3
COAST/SET	Pressed	Approx. 3.0
	Released	Approx. 4.3
ACCEL RES	Pressed	Approx. 3.7
	Released	Approx. 4.3
DISTANCE	Pressed	Approx. 2.2
	Released	Approx. 4.3
CANCEL	Pressed	Approx. 1.3
	Released	Approx. 4.3



OK or NG

- OK >> GO TO 7.
 NG >> GO TO 2.

DTC P1564 ICC STEERING SWITCH

[QR (WITH EURO-OBD)]

2. CHECK ICC STEERING SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect ICC steering switch harness connector and ECM harness connector.
3. Check harness continuity between ICC steering switch terminal 2 and ECM terminal 82.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Spiral cable
- Harness for open and short between ECM and ICC steering switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ICC STEERING SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 99 and ICC steering switch terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Spiral cable
- Harness for open and short between ECM and ICC steering switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK ICC STEERING SWITCH

Refer to [EC-1339, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace ICC steering switch.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection ICC STEERING SWITCH

EBS00GU1

1. Disconnect ICC steering switch.
2. Check continuity between ICC steering switch terminals 1 and 2 with pushing each switch.

Switch	Condition	Resistance [Ω]
ON/OFF SW	Pressed	Approx. 0
	Released	Approx. 5,500
COAST/SET SW	Pressed	Approx. 1,400
	Released	Approx. 5,500
ACCEL RES SW	Pressed	Approx. 2,600
	Released	Approx. 5,500
DISTANCE SW	Pressed	Approx. 740
	Released	Approx. 5,500
CANCEL SW	Pressed	Approx. 310
	Released	Approx. 5,500

If NG, replace ICC steering switch.



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P1568 ICC FUNCTION

PFP:18995

On Board Diagnosis Logic

EBS00GTS

This self-diagnosis has the one trip detection logic

NOTE:

- If DTC P1568 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .
- If DTC P1568 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-1235, "DTC P0605 ECM"](#)

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1568 1568	ICC function	ECM detects a difference between signals from ICC unit is out of specified range.	<ul style="list-style-type: none"> ● Harness or connectors (The CAN communication line is open or shorted.) ● ICC unit ● ECM

DTC Confirmation Procedure

EBS00GTT

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Step 4 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Press "ON/OFF" switch on ICC steering switch.
4. Drive the vehicle at more than 40 km/h (25 MPH).
5. Press "COAST/SET" switch.
6. If DTC is detected, go to [EC-1340, "Diagnostic Procedure"](#) .



Ⓜ WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00GTU

1. REPLACE ICC UNIT

1. Replace ICC unit.
2. Perform [ACS-13, "ACTION TEST"](#) .
3. Check DTC of ICC unit. Refer to [ACS-44, "TROUBLE DIAGNOSIS FOR SELF-DIAGNOSTIC ITEMS"](#) .

>> INSPECTION END

DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]


DTC P1572 ICC BRAKE SWITCH

PFP:25320

Component Description

EBS00GU2

When the brake pedal is depressed, ICC brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal). Refer to [ACS-5, "DESCRIPTION"](#) for the ICC function.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GU3

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW1 (ICC brake switch)	● Ignition switch: ON	● Brake pedal fully released	ON
		● Brake pedal depressed	OFF
BRAKE SW2 (stop lamp switch)	● Ignition switch: ON	● Brake pedal fully released	OFF
		● Brake pedal depressed	ON

On Board Diagnosis Logic

EBS00GU4

NOTE:

If DTC P1572 is displayed with DTC P0605, first perform the trouble diagnosis for DTC P0605. Refer to [EC-1235](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1572 1572	ICC brake switch	ON signals from the stop lamp switch and the ICC brake switch are sent to ECM at the same time.	<ul style="list-style-type: none"> ● Harness or connectors (The stop lamp switch circuit is open or shorted.) ● Harness or connectors (The ICC brake switch circuit is open or shorted.) ● Stop lamp switch ● ICC brake switch ● ICC brake hold relay ● Incorrect stop lamp switch installation ● Incorrect ICC brake switch installation ● ECM

DTC Confirmation Procedure

EBS00GU5

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 3 and 4 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.

DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

3. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position

If 1st trip DTC is detected, go to [EC-1344, "Diagnostic Procedure"](#).

If 1st trip DTC is not detected, go to the following step.

4. Drive the vehicle for at least 5 consecutive seconds under the following condition.

VHCL SPEED SE	More than 30 km/h (19 MPH)
Selector lever	Suitable position
Driving location	Depress the brake pedal for more than five seconds so as not to come off from the above-mentioned condition.

5. If 1st trip DTC is detected, go to [EC-1344, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

Wiring Diagram




EBS00GU6

EC-ICC/BS-01



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

REFER TO PG-POWER.

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK
 - JUNCTION BOX (J/B)



DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)
108	R	ICC brake switch	[Ignition switch "ON"] ● Brake pedal is depressed	Approximately 0V
			[Ignition switch "ON"] ● Brake pedal is fully released	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00GU7

1. CHECK OVERALL FUNCTION-I

 **With CONSULT-II**

- Turn ignition switch "ON".
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
When brake pedal is depress	OFF
When brake pedal is fully released	ON




 **Without CONSULT-II**

- Turn ignition switch "ON".
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
When brake pedal is depress	Approximately 0V
When brake pedal is fully released	Battery voltage

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.



DTC P1572 ICC BRAKE SWITCH


[QR (WITH EURO-OBD)]

2. CHECK OVERALL FUNCTION-II

With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.


CONDITION	INDICATION
When brake pedal is released	OFF
When brake pedal is depressed	ON



Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
When brake pedal is released	Approximately 0V
When brake pedal is depressed	Battery voltage



OK or NG


- OK >> GO TO 18.
- NG >> GO TO 11.

DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

3. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ICC brake switch harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ICC brake switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage


OK or NG

- OK >> GO TO 8.
- NG >> GO TO 4.



4. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect ICC brake hold relay.
3. Turn ignition switch "ON".




4. Check voltage between ICC brake hold relay terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ICC brake hold relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Check harness continuity between ICC brake hold relay terminal 3 and ICC brake switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK ICC BRAKE HOLD RELAY

Refer to [EC-1349, "Component Inspection"](#) .

OK or NG

OK >> GO TO 18.

NG >> Replace ICC brake hold relay.

8. CHECK ICC BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ICC brake switch terminal 2 and ECM terminal 108. Refer Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ICC brake switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK ICC BRAKE SWITCH


Refer to [EC-1349, "Component Inspection"](#) .

OK >> GO TO 18.

NG >> Replace ICC brake switch.

11. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT -II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 13.
- NG >> GO TO 12.



12. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M2
- 15A fuse
- Harness for open or short between stop lamp switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

13. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 15.
- NG >> GO TO 14.

14. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

15. CHECK ICC BRAKE HOLD RELAY CIRCUIT FOR OPEN AND SHORT

1. Disconnect ICC brake hold relay.
2. Check harness continuity between stop lamp switch terminal 1 and ICC brake hold relay terminal 7, stop lamp switch terminal 2 and ICC brake hold relay terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK STOP LAMP SWITCH

Refer to [EC-1349, "Component Inspection"](#)

OK or NG

OK >> GO TO 17.

NG >> Replace stop lamp switch.

17. CHECK ICC BRAKE HOLD RELAY

Refer to [EC-1349, "Component Inspection"](#) .

OK or NG

OK >> GO TO 18.

NG >> Replace ICC brake hold relay.

18. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection ICC BRAKE SWITCH

EBS00GU8

1. Turn ignition switch "OFF".
2. Disconnect ICC brake switch harness connector.
3. Check continuity between ICC brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
When brake pedal is fully released.	Should exist.
When brake pedal is depressed.	Should not exist.

If NG, adjust ICC brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.



STOP LAMP SWITCH

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.


DTC P1572 ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

- Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Condition	Continuity
When brake pedal is fully released.	Should not exist.
When brake pedal is depressed.	Should exist.

If NG, adjust stop lamp switch installation, refer to [BR-6](#), "[BRAKE PEDAL](#)", and perform step 3 again.




ICC BRAKE HOLD RELAY

- Apply 12V direct current between ICC brake hold relay terminals 1 and 2.
- Check continuity between relay terminals 3 and 4, 6 and 7 under the following conditions.

Condition	Between terminals	Continuity
12V direct current supply between terminals 1 and 2	3 and 4	Should not exist
	6 and 7	Should exist
No current supply	3 and 4	Should exist
	6 and 7	Should not exist

- If NG, replace ICC brake hold relay.



DTC P1574 ICC VEHICLE SPEED SENSOR

[QR (WITH EURO-OBD)]

DTC P1574 ICC VEHICLE SPEED SENSOR

PFP:31036

Component Description

EBS00GTN

The ECM receives two vehicle speed signals via CAN communication line. One is sent from combination meter, and the other is from TCM (Transmission control module). The ECM uses these signals for ICC control. Refer to [ACS-5, "DESCRIPTION"](#) for ICC functions.

On Board Diagnosis Logic

EBS00GTO

NOTE:

- If DTC P1574 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).
- If DTC P1574 is displayed with DTC P0500, first perform the trouble diagnosis for DTC P0500. Refer to [EC-1228, "DTC P0500 VSS"](#).

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P1574 1574	ICC vehicle speed sensor	ECM detects a difference between two vehicle speed signals is out of the specified range.	<ul style="list-style-type: none">● Harness or connectors (The CAN communication line is open or shorted.)● TCM● Secondary speed sensor● ESP/TCS/ABS control unit● Wheel sensor● Combination meter● ECM

DTC Confirmation Procedure

EBS00GTP

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Step 3 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

WITH CONSULT-II

1. Start engine.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Drive the vehicle at more than 40 km/h (25MPH).
4. If 1st trip DTC is detected, go to [EC-1352, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.

DTC P1574 ICC VEHICLE SPEED SENSOR

[QR (WITH EURO-OBD)]

Diagnostic Procedure

EBS00GTO

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [CVT-20, "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"](#) .

OK or NG

OK >> GO TO 2.

NG >> Perform trouble shooting relevant to DTC indicated.

2. CHECK VEHICLE SPEED SENSOR CIRCUIT

Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#) (Models without ESP) or [BRC-60, "TROUBLE DIAGNOSIS"](#) (Models with ESP).

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#) .

>> INSPECTION END

DTC P1706 PNP SWITCH

PFP:32006

Component Description

EBS00GJ2

When the shift lever position is "P" (CVT models only) or "N", park/neutral position (PNP) switch is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GJ3

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
P/N POSI SW	● Ignition switch: ON	ON
	Shift lever: Except above	OFF

On Board Diagnosis Logic

EBS00GJ4

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1706 1706	Park/neutral position switch	The signal of the park/neutral position (PNP) switch is not changed in the process of engine starting and driving.	<ul style="list-style-type: none"> ● Harness or connectors (PNP switch circuit is open or shorted.) ● Park/neutral position (PNP) switch

DTC Confirmation Procedure

EBS00GJ5

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II. Then check the "P/N POSI SW" signal under the following conditions.

Position (Selector lever)	Known-good signal
"N" and "P" position	ON
Except the above position	OFF

If NG, go to [EC-1356, "Diagnostic Procedure"](#) .
If OK, go to following step.

3. Select "DATA MONITOR" mode with CONSULT-II.
4. Start engine and warm it up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	1,500 - 3,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	3.0 - 31.8 msec
VHCL SPEED SE	More than 64 km/h (40 MPH)
Selector lever	Suitable position

6. If 1st trip DTC is detected, go to [EC-1356, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
P/N POSI SW	ON

SEF212Y

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF
B/FUEL SCHDL	XXX msec

SEF213Y

Overall Function Check


Use this procedure to check the overall function of the park/neutral position (PNP) switch circuit. During this check, a 1st trip DTC might not be confirmed.

WITH GST

1. Turn ignition switch "ON".
2. Check voltage between ECM terminal 102 (PNP switch signal) and body ground under the following conditions.

Condition (Gear position)	Voltage V (Known good data)
"P" (CVT models only) and "N" position	Approx. 0
Except the above position	CVT models: Battery voltage M/T models: Approximately 5V

3. If NG, go to [EC-1356, "Diagnostic Procedure"](#) .






DTC P1706 PNP SWITCH

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GJ7

EC-PNP/SW-01



MBWA0019E

DTC P1706 PNP SWITCH

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
74 (CVT models)	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Idle speed	Approximately 0V
102	P (CVT) L (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none">● Shift lever position is "P" (CVT models) or "N", "Neutral" (M/T models).	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none">● Except the above gear position	CVT models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V

Diagnostic Procedure

EBS00GJ8

1. CHECK GROUND CIRCUIT


1. Turn ignition switch "OFF".
2. Disconnect PNP switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open and short between PNP switch and ECM (CVT models)
- Harness for open and short between PNP switch and ground (M/T models)

>> Repair open circuit or short to power in harness or connectors.

3. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and PNP switch terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK PNP SWITCH

Refer to [CVT-71, "Component Inspection"](#) (CVT models) or [MT-126, "PARK/NEUTRAL POSITION SWITCH"](#) (M/T models).

OK or NG

OK >> GO TO 5.

NG >> Replace PNP switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1720 VSS

PFP:31036

Description

EBS00GVN

NOTE:

If DTC P1720 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1083, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

ECM receives two vehicle speed signals via CAN communication line. One is sent from ESP/TCS/ABS control unit (models with ESP), ABS actuator and electric unit (models without ESP) via combination meter, and the other is from TCM (Transmission control module). ECM uses these signals for engine control.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GVO

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value

On Board Diagnosis Logic

EBS00GVP

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1720 1720	Vehicle speed sensor (TCM output)	A difference between two vehicle speed signals is out of the specified range.	<ul style="list-style-type: none"> ● Harness or connectors (Revolution sensor circuit is open or shorted) ● Harness or connectors (Wheel sensor circuit is open or shorted.) ● TCM ● Secondary speed sensor ● ESP/TCS/ABS control unit ● ABS actuator and electric unit ● Wheel sensor ● Combination meter

DTC Confirmation Procedure

EBS00GVR

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine.
4. Drive vehicle at a speed of 20 km/h (12 MPH) or more for at least 5 seconds without brake pedal depressing.
5. If 1st trip DTC is detected, go to [EC-1358, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II" above.

Diagnostic Procedure

EBS00GVS

1. CHECK DTC WITH TCM

Check DTC with TCM. Refer to [CVT-20, "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION"](#).

OK or NG

- OK >> GO TO 2.
- NG >> Perform trouble shooting relevant to DTC indicated.

2. CHECK DTC WITH ABS

Check DTC with ABS actuator and electric unit (Models without ESP) or ESP/TCS/ABS control unit (Models with ESP). Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#) or [BRC-60, "TROUBLE DIAGNOSIS"](#) .

OK or NG

OK >> GO TO 3.

NG >> Perform trouble shooting relevant to DTC indicated.

3. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#) .

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1805 BRAKE SWITCH

[QR (WITH EURO-OBD)]

DTC P1805 BRAKE SWITCH

PFP:25320

Description

EBS00GJ9

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GJA

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON

On Board Diagnosis Logic

EBS00GJB

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for an extremely long time while the vehicle is driving.	<ul style="list-style-type: none">● Harness or connectors (Stop lamp switch circuit is open or shorted.)● Stop lamp switch

DTC Confirmation Procedure

EBS00GJC

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to [EC-1362, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITH GST

Follow the procedure "WITH CONSULT-II" above.


DTC P1805 BRAKE SWITCH

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GJD



EC-BRK/SW-01



REFER TO PG-POWER.

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.

(M2) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0034E

DTC P1805 BRAKE SWITCH

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00GJE

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch "OFF".
2. Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Depressed	Illuminated

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch harness connector.




2. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Fuse block (J/B) connector M2
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to [EC-1363, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace stop lamp switch.


7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection STOP LAMP SWITCH

1. Disconnect stop lamp switch harness connector.



EBS00GJF


DTC P1805 BRAKE SWITCH

[QR (WITH EURO-OBD)]

2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.

If NG, adjust brake pedal installation, refer to [BR-6, "BRAKE PEDAL"](#), and perform step 2 again.



IGNITION SIGNAL


PFP:22448

Component Description

EBS00GJG

IGNITION COIL & POWER TRANSISTOR

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.



A

EC

C

D

E

F

G

H

I

J

K

L

M



IGNITION SIGNAL

[QR (WITH EURO-OBD)]

EBS00G.JH

EC-IGNSYS-01

Wiring Diagram



MBWA0029E

IGNITION SIGNAL

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● More than a few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)


A
EC
C
D
E
F
G
H
I
J
K
L
M

IGNITION SIGNAL


[QR (WITH EURO-OBD)]

EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



1 2 3 F26, F28, F29, F30
 GY, GY, GY, GY



F101 H.S.

MBWA0030E



IGNITION SIGNAL

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	
60	L/Y	Ignition signal No. 3	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 0.1V★ 	
61	Y/R	Ignition signal No. 1		PBIB0521E	
79	GY/L	Ignition signal No. 4		<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - 0.2V★ 
80	PU/G	Ignition signal No. 2			PBIB0522E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GJI

1. CHECK ENGINE START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 4.

2. CHECK OVERALL FUNCTION

④ **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.

2. Make sure that each circuit produces a momentary engine speed drop.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 12.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


3. CHECK OVERALL FUNCTION

⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 79, 80 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.



PBIB0521E



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 12.


4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> Go to [EC-1077, "POWER SUPPLY CIRCUIT FOR ECM"](#).




5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Turn ignition switch "ON".
4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 6.



6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.
3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV


Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair or replace harness or connectors.

9. CHECK ECM RELAY

Refer to [EC-1373, "Component Inspection"](#) .

OK or NG

OK >> GO TO 17.

NG >> Replace ECM relay.

10. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check harness continuity between condenser terminal 2 and ground.
Refer to Wiring diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to power in harness or connector.

11. CHECK CONDENSER


Refer to [EC-1373, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Replace condenser.

12. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

1. Turn ignition switch "OFF".
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.
4. Turn ignition switch "ON".




5. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.



13. DETECT MALFUNCTIONING PART

Check harness for open or short between ignition coil and ECM relay.

>> Repair or replace harness or connectors.

14. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ignition coil terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
- NG >> Repair open circuit or short to power in harness or connectors.

15. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 79, 80 and ignition coil terminal 3. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to [EC-1373, "Component Inspection"](#) .

OK or NG

OK >> GO TO 17.

NG >> Replace ignition coil with power transistor.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No


3. If NG, replace ECM relay.



CONDENSER

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check resistance between condenser terminals 1 and 2.

Resistance: Above 1 MΩ at 25°C (77°F)



IGNITION COIL WITH POWER TRANSISTOR


1. Turn ignition switch "OFF".
2. Disconnect ignition coil harness connector.

IGNITION SIGNAL

[QR (WITH EURO-OBD)]

3. Check resistance between ignition coil terminals as follows.

Terminal No.	Resistance Ω [at 25°C (77°F)]
2 and 3	Except 0 or ∞
1 and 2	Except 0
1 and 3	



Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-126, "IGNITION COIL"](#) .

EBS00GJK


INJECTOR CIRCUIT

PFP:16600

Component Description

EBS00GJR

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GJS

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.5 - 3.5 msec
		2,000 rpm	2.5 - 3.5 msec
INJ PULSE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec





INJECTOR CIRCUIT

[QR (WITH EURO-OBD)]

EBS00GJT

EC-INJECT-01

Wiring Diagram



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0028E



INJECTOR CIRCUIT

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B SB L R/W	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0530E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00GJU

1. INSPECTION START

Turn ignition switch to "START".

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

④ With CONSULT-II


1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

⊗ Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.




OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 3.

3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect injector harness connector.
3. Turn ignition switch "ON".




4. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors F24, F81
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between injector terminal 2 and ECM terminals 22, 23, 41, 42. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F81, F24
- Harness for open or short between injector and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INJECTOR

Refer to [EC-1380, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace injector.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INJECTOR

EBS00GJV

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: 12.1 - 12.9Ω [at 20°C (68°F)]



EBS00GJV

Removal and Installation INJECTOR

Refer to [EM-128, "FUEL INJECTOR AND FUEL TUBE"](#) .

FUEL PUMP CIRCUIT

[QR (WITH EURO-OBD)]

FUEL PUMP CIRCUIT

PF17042

Description SYSTEM DESCRIPTION

EBS00GK0

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		


*: ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a engine speed signal from the crankshaft position sensor (POS) and camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GK1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking 	ON
	<ul style="list-style-type: none"> ● Except above conditions 	OFF



FUEL PUMP CIRCUIT

[QR (WITH EURO-OBD)]

EBS00GK2

Wiring Diagram

EC-F/PUMP-01



REFER TO THE FOLLOWING.

(B1) - FUSE BLOCK - JUNCTION BOX (J/B)

MBWA0031E

FUEL PUMP CIRCUIT

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 seconds after turning ignition switch "ON"	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] ● More than 1 seconds after turning ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00GK3

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with two fingers.
Fuel pressure pulsation should be felt on the fuel hose for 1 second after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between fuel pump relay terminals 1, 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector B1
- 10A fuse
- 15A fuse
- Harness for open or short between fuel pump relay and fuse

>> Repair harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Check harness continuity between fuel pump relay terminal 3 and fuel level sensor unit and fuel pump terminal 5, fuel level sensor unit and fuel pump terminal 3 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B37, D83 (Wagon)
- Harness for open or short between fuel level sensor unit and fuel pump and fuel pump relay
- Harness for open or short between fuel level sensor unit and fuel pump and body ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 113 and fuel pump relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors B5, M23 (LHD models)
- Harness connectors B42, M95 (RHD models)
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

Refer to [EC-1385, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace fuel pump relay.

9. CHECK FUEL PUMP

Refer to [EC-1385, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace fuel pump.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection FUEL PUMP RELAY

EBS00GK4

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



FUEL PUMP

1. Disconnect fuel level sensor unit and fuel pump harness connector.
2. Check resistance between fuel level sensor unit and fuel pump terminals 3 and 5.

Resistance: Approximately 1.0Ω [at 25°C (77°F)]



Removal and Installation

EBS00GK5

FUEL PUMP

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY \(EXCEPT YD2DDTi\)"](#).

REFRIGERANT PRESSURE SENSOR

[QR (WITH EURO-OBD)]


REFRIGERANT PRESSURE SENSOR

PFP:92136


Component Description

EBS00GK6

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.



A
EC
C
D
E
F
G
H
I
J
K
L
M







REFRIGERANT PRESSURE SENSOR

[QR (WITH EURO-OBD)]

Wiring Diagram

EBS00GK7

EC-RP/SEN-01



MBWA0033E

REFRIGERANT PRESSURE SENSOR

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
46	R	Sensor's power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
69	L	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON". (Compressor operates.)	1.0 - 4.0V

Diagnostic Procedure

EBS00GK8


1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch "ON".
3. Check voltage between ECM terminal 69 and ground with CONSULT-II or tester.

Voltage: 1.0 - 4.0V

OK or NG

- OK >> **INSPECTION END**
- NG >> **GO TO 2.**




REFRIGERANT PRESSURE SENSOR

[QR (WITH EURO-OBD)]

2. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn A/C switch and blower switch "OFF".
2. Stop engine.
3. Disconnect refrigerant pressure sensor harness connector.
4. Turn ignition switch "ON".




5. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair harness or connectors.

4. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and refrigerant pressure sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

REFRIGERANT PRESSURE SENSOR

[QR (WITH EURO-OBD)]

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor
- Harness for open or short between TCM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 69 and refrigerant pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.
- NG >> Repair or replace.

Removal and Installation REFRIGERANT PRESSURE SENSOR

Refer to [ATC-127, "REFRIGERANT LINES"](#) .

A

EC

C

D

E

F

G

H

I

J

K

EBS00GK9

L

M

ELECTRICAL LOAD SIGNAL

[QR (WITH EURO-OBD)]

ELECTRICAL LOAD SIGNAL

PFP:25350

Description

EBS00GKA

The electrical load signals except headlamp switch signal are transferred through the CAN communication line.

CONSULT-II Reference Value in Data Monitor Mode

EBS00GVI

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF

ELECTRICAL LOAD SIGNAL

[QR (WITH EURO-OBD)]




Wiring Diagram

EBS00GVJ

EC-LOAD-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⊖CH** : CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM
- ⊖CD** : CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM
- ⊖XN** : XENON TYPE HEADLAMP



MBWA0147E

ELECTRICAL LOAD SIGNAL

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] ● Lighting switch is "2ND" position	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Lighting switch is "OFF"	Approximately 0V

Diagnostic Procedure

EBS00GKB

1. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

Ⓟ With CONSULT-II

Ⓢ With GST

- Turn ignition switch "ON".
- Connect CONSULT-II or GST and select "DATA MONITOR" mode.
- Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch "ON"	ON
Rear window defogger switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK (With CONSULT-II)>>GO TO 2.
- OK (Without CONSULT-II)>>GO TO 3.
- NG >> GO TO 4.

2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

Ⓟ With CONSULT-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch "ON" at 2nd position	ON
Lighting switch "OFF"	OFF

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

3. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II


 **Without CONSULT-II**

Check voltage between ECM terminal 84 and ground under the following conditions.

Condition	Voltage
Lighting switch "ON" at 2nd position	Battery voltage
Lighting switch "OFF"	Approximately 0V

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 5.



4. CHECK REAR WINDOW DEFOGGER SYSTEM

Refer to [GW-40, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

5. CHECK HEADLAMP FUNCTION

1. Turn lighting switch "ON" at 2nd position.
2. Check that headlamps are illuminated.

OK or NG

- OK >> GO TO 6.
 NG >> Refer to [LT-5, "HEADLAMP - CONVENTIONAL TYPE -"](#) , [LT-10, "HEADLAMP - XENON TYPE -"](#) , [LT-18, "HEADLAMP \(WITH DAYTIME\) - CONVENTIONAL TYPE -"](#) or [LT-25, "HEADLAMP \(WITH DAYTIME\) - XENON TYPE -"](#) .

6. CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect lighting switch harness connector .
4. Check harness continuity between ECM terminal 84 and lighting switch terminal 10.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect daytime light relay.
4. Check harness continuity between ECM terminal 84 and daytime light relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

XENON TYPE HEADLAMP

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect headlamp LH relay.
4. Check harness continuity between ECM terminal 84 and headlamp LH relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- harness for open and short between ECM and lighting switch
- harness for open and short between ECM and daytime light relay
- harness for open and short between ECM and headlamp LH relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]


ICC BRAKE SWITCH

PFP:25320

Component Description

EBS00GU9

When depress on the brake pedal, ICC brake switch is turned OFF and stop lamp switch is turned ON. ECM detects the state of the brake pedal by this input of two kinds (ON/OFF signal)
Refer to [ACS-5, "DESCRIPTION"](#) for the ICC function.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GUA

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW1 (ICC brake switch)	● Ignition switch: ON	● Brake pedal fully released	ON
		● Brake pedal depressed	OFF
BRAKE SW2 (stop lamp switch)	● Ignition switch: ON	● Brake pedal fully released	OFF
		● Brake pedal depressed	ON

ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]



EBS00GUB

EC-ICCB0F-01

Wiring Diagram

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC

REFER TO PG-POWER.



REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK
 - JUNCTION BOX (J/B)

ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)
108	R	ICC brake switch	[Ignition switch "ON"] ● Brake pedal is depressed	Approximately 0V
			[Ignition switch "ON"] ● Brake pedal is fully released	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00GUC

1. CHECK OVERALL FUNCTION-I

 **With CONSULT-II**

- Turn ignition switch "ON".
- Select "BRAKE SW1" in "DATA MONITOR" mode with CONSULT-II.
- Check "BRAKE SW1" indication under the following conditions.

CONDITION	INDICATION
When brake pedal is depress	OFF
When brake pedal is fully released	ON




 **Without CONSULT-II**

- Turn ignition switch "ON".
- Check voltage between ECM terminal 108 and ground under the following conditions.

CONDITION	VOLTAGE
When brake pedal is depress	Approximately 0V
When brake pedal is fully released	Battery voltage

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.



ICC BRAKE SWITCH


[QR (WITH EURO-OBD)]

2. CHECK OVERALL FUNCTION-II

④ With CONSULT-II

Check "BRAKE SW2" indication in "DATA MONITOR" mode.


CONDITION	INDICATION
When brake pedal is released	OFF
When brake pedal is depressed	ON



⊗ Without CONSULT-II

Check voltage between ECM terminal 101 and ground under the following conditions.

CONDITION	VOLTAGE
When brake pedal is released	Approximately 0V
When brake pedal is depressed	Battery voltage




OK or NG

- OK >> **INSPECTION END.**
- NG >> GO TO 11.

3. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ICC brake switch harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ICC brake switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage


OK or NG

- OK >> GO TO 8.
 NG >> GO TO 4.



4. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect ICC brake hold relay.
3. Turn ignition switch "ON".




4. Check voltage between ICC brake hold relay terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 6.
 NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ICC brake hold relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK ICC BRAKE SWITCH POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Check harness continuity between ICC brake hold relay terminal 3 and ICC brake switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK ICC BRAKE HOLD RELAY

Refer to [EC-1404, "Component Inspection"](#) .

OK or NG

OK >> GO TO 18.

NG >> Replace ICC brake hold relay.

8. CHECK ICC BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ICC brake switch terminal 2 and ECM terminal 108. Refer Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ICC brake switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK ICC BRAKE SWITCH


Refer to [EC-1404, "Component Inspection"](#) .

OK >> GO TO 18.

NG >> Replace ICC brake switch.

11. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT -II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 13.
- NG >> GO TO 12.



12. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector M2
- 15A fuse
- Harness for open or short between stop lamp switch and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

13. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 15.
- NG >> GO TO 14.

14. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

15. CHECK ICC BRAKE HOLD RELAY CIRCUIT FOR OPEN AND SHORT

1. Disconnect ICC brake hold relay.
2. Check harness continuity between stop lamp switch terminal 1 and ICC brake hold relay terminal 7, stop lamp switch terminal 2 and ICC brake hold relay terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK STOP LAMP SWITCH

Refer to [EC-1404, "Component Inspection"](#)

OK or NG

OK >> GO TO 17.

NG >> Replace stop lamp switch.

17. CHECK ICC BRAKE HOLD RELAY

Refer to [EC-1404, "Component Inspection"](#) .

OK or NG

OK >> GO TO 18.

NG >> Replace ICC brake hold relay.

18. CHECK INTERMITTENT INCIDENT

Refer to [EC-1076, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


Component Inspection ICC BRAKE SWITCH

EBS00GXB

1. Turn ignition switch "OFF".
2. Disconnect ICC brake switch harness connector.
3. Check continuity between ICC brake switch terminals 1 and 2 under the following conditions.

Condition	Continuity
When brake pedal is fully released.	Should exist.
When brake pedal is depressed.	Should not exist.

If NG, adjust ICC brake switch installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 3 again.



STOP LAMP SWITCH

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.


ICC BRAKE SWITCH

[QR (WITH EURO-OBD)]

- Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Condition	Continuity
When brake pedal is fully released.	Should not exist.
When brake pedal is depressed.	Should exist.

If NG, adjust stop lamp switch installation, refer to [BR-6](#), "BRAKE PEDAL", and perform step 3 again.




A
EC
C
D
E
F
G
H
I
J
K
L
M

ICC BRAKE HOLD RELAY

- Apply 12V direct current between ICC brake hold relay terminals 1 and 2.
- Check continuity between relay terminals 3 and 4, 6 and 7 under the following conditions.

Condition	Between terminals	Continuity
12V direct current supply between terminals 1 and 2	3 and 4	Should not exist
	6 and 7	Should exist
No current supply	3 and 4	Should exist
	6 and 7	Should not exist

- If NG, replace ICC brake hold relay.



MI & DATA LINK CONNECTORS







[QR (WITH EURO-OBD)]

PFP:24814

EBS00FDA

MI & DATA LINK CONNECTORS

Wiring Diagram (LHD Models)





REFER TO THE FOLLOWING.
 M1, M2 - FUSE BLOCK
 J/B - JUNCTION BOX

MI & DATA LINK CONNECTORS

[QR (WITH EURO-OBD)]

EBS00GTM

Wiring Diagram (RHD Models)



MBWA0148E

EVAPORATIVE EMISSION SYSTEM


[QR (WITH EURO-OBD)]

EVAPORATIVE EMISSION SYSTEM

PFP:14950

Description SYSTEM DESCRIPTION

EBS00FDB





The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister. The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank. The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases. EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.

EVAPORATIVE EMISSION SYSTEM


[QR (WITH EURO-OBD)]

EVAPORATIVE EMISSION LINE DRAWING

A
EC
C
D
E
F
G
H
I
J
K
L
M



View from under the vehicle



NOTE:


Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

MBIB0144E

Component Inspection EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** . Orally blow air through port **A** .
Check that air flows freely through port **C** .
2. Block port **A** . Orally blow air through port **B** .
Check that air flows freely through port **C** .




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure: 15.3 - 20.0 kPa (0.153 - 0.200 bar,
0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.4 kPa (-0.060 to -0.034 bar,
-0.061 to -0.035 kg/cm² , -0.87 to -0.49 psi)

3. If out of specification, replace fuel filler cap as an assembly.



EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-1227, "Component Inspection"](#) .

POSITIVE CRANKCASE VENTILATION


[QR (WITH EURO-OBD)]

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description SYSTEM DESCRIPTION


EBS00FDD



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.

On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.




Component Inspection

PCV (POSITIVE CRANKCASE VENTILATION) VALVE

EBS00FDE

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.




POSITIVE CRANKCASE VENTILATION

[QR (WITH EURO-OBD)]

PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



SERVICE DATA AND SPECIFICATIONS (SDS) [QR (WITH EURO-OBD)]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure

EBS00FDH

Fuel pressure at idle	Approximately 350 kPa (3.7kg/cm ² , 51psi)
-----------------------	---

Idle Speed and Ignition Timing

EBS00FDI

Target idle speed	No-load*1 (in "P" or N" position)	M/T: 600±50 rpm CVT: 650±50 rpm
Air conditioner: ON	In "P" or N" position	725 rpm or more
Ignition timing	In "P" or N" position	M/T: 14°±5° BTDC CVT: 15°±5° BTDC

*1: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Calculated Load Value

EBS00FDJ

	Calculated load value % (Using CONSULT-II or GST)
At idle	10 - 35
At 2,500 rpm	10 - 35

Mass Air Flow Sensor

EBS00FDK

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	1.1 - 1.5*V
Mass air flow (Using CONSULT-II or GST)	1.4 - 4.0 g·m/sec at idle* 4.0 - 10.0 g·m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Intake Air Temperature Sensor

EBS00FDL

Temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1
80 (176)	0.31 - 0.37

Engine Coolant Temperature Sensor

EBS00FDM

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

EBS00FDN

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Heated Oxygen sensor 2 Heater

EBS00FDO

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (POS)

EBS00FDP

Refer to [EC-1210, "Component Inspection"](#) .

Camshaft Position Sensor (PHASE)

EBS00FDQ

Refer to [EC-1216, "Component Inspection"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)
[QR (WITH EURO-OBD)]

Throttle Control Motor

EBS00FDR

Resistance [at 25°C (77°F)]

Approximately 1 - 15Ω

Injector

EBS00FDS

Resistance [at 20°C (68°F)]

13.5 - 17.5Ω

Fuel Pump

EBS00FDT

Resistance [at 25°C (77°F)]

Approximately 1.0Ω

INDEX FOR DTC

PFP:00024

Alphabetical Index

EBS00GXE

Check if the vehicle is a model with Euro-OBD (E-OBD) system or not by the "Type approval number" on the identification plate. Refer to [GI-46, "IDENTIFICATION PLATE"](#) .

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1505, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#) .

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II*2	ECM*3	
APP SEN 1/CIRC*5	P0227	0227	EC-1544
APP SEN 1/CIRC*5	P0228	0228	EC-1544
APP SEN 2/CIRC*5	P1227	1227	EC-1630
APP SEN 2/CIRC*5	P1228	1228	EC-1630
APP SENSOR*5	P0226	0226	EC-1537
BRAKE SW/CIRCUIT	P1805	1805	EC-1641
CAN COMM CIRCUIT	U1000	1000*6	EC-1505
CAN COMM CIRCUIT	U1001	1001*6	EC-1505
CKP SEN/CIRCUIT	P0335	0335	EC-1555
CMP SEN/CIRC-B1	P0340	0340	EC-1562
CTP LEARNING	P1225	1225	EC-1626
CTP LEARNING	P1226	1226	EC-1628
ECM	P0605	0605	EC-1576
ECM BACK UP/CIRC	P1065	1065	EC-1579
ECT SEN/CIRCUIT*5	P0117	0117	EC-1514
ECT SEN/CIRCUIT*5	P0118	0118	EC-1514
ENG OVER TEMP	P1217	1217	EC-1603
ETC ACTR*5	P1121	1121	EC-1583
ETC FUNCTION/CIRC*5	P1122	1122	EC-1585
ETC MOT*5	P1128	1128	EC-1598
ETC MOT PWR*5	P1124	1124	EC-1592
ETC MOT PWR*5	P1126	1126	EC-1592
HO2S1 (B1)	P0134	0134	EC-1519
KNOCK SEN/CIRC-B1	P0327	0327	EC-1551
KNOCK SEN/CIRC-B1	P0328	0328	EC-1551
MAF SEN/CIRCUIT*5	P0102	0102	EC-1508
MAF SEN/CIRCUIT*5	P0103	0103	EC-1508
NATS MALFUNCTION	P1610 - P1615	1610 - 1615	EC-1447
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	No DTC	Flashing*4	EC-1448
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	0000	—
PW ST P SEN/CIRC	P0550	0550	EC-1571

INDEX FOR DTC

[QR (WITHOUT EURO-OBD)]

Items (CONSULT-II screen terms)	DTC*1		Reference page
	CONSULT-II*2	ECM*3	
SENSOR POWER/CIRC*5	P1229	1229	EC-1637
TP SEN 1/CIRC*5	P0222	0222	EC-1531
TP SEN 1/CIRC*5	P0223	0223	EC-1531
TP SEN 2/CIRC*5	P1223	1223	EC-1620
TP SEN 2/CIRC*5	P1224	1224	EC-1620
TP SENSOR*5	P0221	0221	EC-1525
VEH SPEED SEN/CIRC	P0500	0500	EC-1569

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for these DTCs needs CONSULT-II.

DTC No. Index

EBS00GXF

NOTE:

If DTC U1000 or U1001 is displayed with other DTC, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1505, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
No DTC	Flashing*4	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	EC-1448
U1000	1000*6	CAN COMM CIRCUIT	EC-1505
U1001	1001*6	CAN COMM CIRCUIT	EC-1505
P0000	0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—
P0102	0102	MAF SEN/CIRCUIT*5	EC-1508
P0103	0103	MAF SEN/CIRCUIT*5	EC-1508
P0117	0117	ECT SEN/CIRCUIT*5	EC-1514
P0118	0118	ECT SEN/CIRCUIT*5	EC-1514
P0134	0134	HO2S1 (B1)	EC-1519
P0221	0221	TP SENSOR*5	EC-1525
P0222	0222	TP SEN 1/CIRC*5	EC-1531
P0223	0223	TP SEN 1/CIRC*5	EC-1531
P0226	0226	APP SENSOR*5	EC-1537
P0227	0227	APP SEN 1/CIRC*5	EC-1544
P0228	0228	APP SEN 1/CIRC*5	EC-1544
P0327	0327	KNOCK SEN/CIRC-B1	EC-1551
P0328	0328	KNOCK SEN/CIRC-B1	EC-1551
P0335	0335	CKP SEN/CIRCUIT	EC-1555
P0340	0340	CMP SEN/CIRC-B1	EC-1562

INDEX FOR DTC

[QR (WITHOUT EURO-OBD)]

DTC*1		Items (CONSULT-II screen terms)	Reference page
CONSULT-II*2	ECM*3		
P0500	0500	VEH SPEED SEN/CIRC	EC-1569
P0550	0550	PW ST P SEN/CIRC	EC-1571
P0605	0605	ECM	EC-1576
P1065	1065	ECM BACK UP/CIRC	EC-1579
P1121	1121	ETC ACTR*5	EC-1583
P1122	1122	ETC FUNCTION/CIRC*5	EC-1585
P1124	1124	ETC MOT PWR*5	EC-1592
P1126	1126	ETC MOT PWR*5	EC-1592
P1128	1128	ETC MOT*5	EC-1598
P1217	1217	ENG OVER TEMP	EC-1603
P1223	1223	TP SEN 2/CIRC*5	EC-1620
P1224	1224	TP SEN 2/CIRC*5	EC-1620
P1225	1225	CTP LEARNING	EC-1626
P1226	1226	CTP LEARNING	EC-1628
P1227	1227	APP SEN 2/CIRC*5	EC-1630
P1228	1228	APP SEN 2/CIRC*5	EC-1630
P1229	1229	SENSOR POWER/CIRC*5	EC-1637
P1610 - P1615	1610 - 1615	NATS MALFUNCTION	EC-1447
P1805	1805	BRAKE SW/CIRCUIT	EC-1641

*1: 1st trip DTC No. is the same as DTC No.

*2: These numbers are prescribed by ISO 15031-5.

*3: In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

*4: When engine is running.

*5: When the fail-safe operation occurs, the MI illuminates.

*6: The troubleshooting for these DTCs needs CONSULT-II.

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EBS00GXG

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

On Board Diagnostic (OBD) System of Engine

EBS00GXH

The ECM has an on board diagnostic system. It will light up the malfunction indicator (MI) to warn the driver of a malfunction causing emission deterioration.


CAUTION:

- Be sure to turn the ignition switch OFF and disconnect the battery ground cable before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MI to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MI to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-86. "HARNESS CONNECTOR"](#).
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc. may cause the MI to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MI to light up due to the malfunction of the fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM.

Precaution

EBS00GXI

- Always use a 12 volt battery as power source.
- Do not attempt to disconnect battery cables while engine is running.
- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect battery ground cable. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.
- Before removing parts, turn ignition switch OFF and then disconnect battery ground cable.




SEF289H


PRECAUTIONS

[QR (WITHOUT EURO-OBD)]


- Do not disassemble ECM.
- If battery cable is disconnected, the memory will return to the initial ECM values.
The ECM will now start to self-control at its initial values. Engine operation can vary slightly when the cable is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.




- When connecting ECM harness connector, fasten it securely with levers as far as they will go as shown at right.



- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.



- Securely connect ECM harness connectors.
A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep engine control system harness at least 10 cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of ICs, etc.
- Keep engine control system parts and harness dry.
- Before replacing ECM, perform "ECM Terminals and Reference Value" inspection and make sure ECM functions properly. Refer to [EC-1472](#).
- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble electric throttle control actuator.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor (PHASE), crankshaft position sensor (POS).




PRECAUTIONS


[QR (WITHOUT EURO-OBD)]

- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.


The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signal with a circuit tester, connect break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.




- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque.




PRECAUTIONS

[QR (WITHOUT EURO-OBD)]

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
 - Keep the antenna as far as possible from the electronic control units.
 - Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
 - Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
 - Be sure to ground the radio to vehicle body.



EBS00GXJ

Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#)
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)

A
EC
C
D
E
F
G
H
I
J
K
L
M

PREPARATION





[QR (WITHOUT EURO-OBD)]

PFP:00002

EBS00GXX



PREPARATION

Special Service Tools

Tool number Tool name	Description	
KV10117100 Heated oxygen sensor wrench	 S-NT379	Loosening or tightening heated oxygen sensors with 22 mm (0.87 in) hexagon nut
KV10114400 Heated oxygen sensor wrench	 S-NT636	Loosening or tightening heated oxygen sensors a: 22 mm (0.87 in)
KV109E0010 Break-out box	 NT825	Measuring ECM signals with a circuit tester
KV109E0080 Y-cable adapter	 NT826	Measuring ECM signals with a circuit tester




Commercial Service Tools

EBS00GXL

Tool name	Description	
Quick connector release	 PBIC0198E	Removing fuel tube quick connectors in engine room (Available in SEC. 164 of PARTS CATALOG: Part No. 16441 6N210)
Fuel filler cap adapter	 S-NT653	Checking fuel tank vacuum relief valve opening pressure

PREPARATION

[QR (WITHOUT EURO-OBD)]

Tool name	Description	
Socket wrench	 <p>19 mm (0.75 in)</p> <p>More than 32 mm (1.25 in)</p> <p>S-NT705</p>	<p>Removing and installing engine coolant temperature sensor</p>
Oxygen sensor thread cleaner ie: (J-43897-18) (J-43897-12)	 <p>a</p> <p>b</p> <p>Mating surface shave cylinder</p> <p>Flutes</p> <p>AEM488</p> <p>S-NT705</p>	<p>Reconditioning the exhaust system threads before installing a new oxygen sensor. Use with anti-seize lubricant shown below.</p> <p>a: 18 mm diameter with pitch 1.5 mm for Zirconia Oxygen Sensor</p> <p>b: 12 mm diameter with pitch 1.25 mm for Titania Oxygen Sensor</p>
Anti-seize lubricant i.e.: (Permatex™ 133AR or equivalent meeting MIL specification MIL-A-907)	 <p>S-NT779</p>	<p>Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads.</p>

A
EC
C
D
E
F
G
H
I
J
K
L
M

ENGINE CONTROL SYSTEM


[QR (WITHOUT EURO-OBD)]

ENGINE CONTROL SYSTEM

PF0:23710

System Diagram

EBS00GXM



MBIB0051E

Vacuum Hose Drawing

EBS00GXN

A

EC

C

D

E

F

G

H


I

J

K

L

M



NOTE: Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

Refer to [EC-1424. "System Diagram"](#) for Vacuum Control System.

PBIB0489E

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

System Chart

EBS00GXO

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Camshaft position sensor (PHASE) ● Crankshaft position sensor (POS) ● Mass air flow sensor ● Engine coolant temperature sensor ● Heated oxygen sensor 1 ● Throttle position sensor ● Accelerator pedal position sensor ● Park/neutral position (PNP) switch ● Intake air temperature sensor ● Power steering pressure sensor ● Ignition switch ● Battery voltage ● Knock sensor ● Refrigerant pressure sensor ● Stop lamp switch ● Heated oxygen sensor 2 *1 ● TCM (Transmission control module) *2 ● Air conditioner switch *2 ● Vehicle speed signal *2 ● Electrical load signal *2 	Fuel injection & mixture ratio control	Fuel injectors
	Electronic ignition system	Power transistor
	Fuel pump control	Fuel pump relay
	On board diagnostic system	MI (On the instrument panel) *3
	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
	Air conditioning cut control	Air conditioner relay *3
	Cooling fan control	Cooling fan relays *3

*1: This sensor is not used to control the engine system under normal conditions.

*2: These input signals are sent to the ECM through CAN communication line.

*3: These output signals are sent from the ECM through CAN communication line.

Multiport Fuel Injection (MFI) System INPUT/OUTPUT SIGNAL CHART

EBS00GXP

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *3 and piston position	Fuel injection & mixture ratio control	Fuel injectors
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Heated oxygen sensor 1	Density of oxygen in exhaust gas		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Park/neutral position (PNP) switch	Gear position		
Knock sensor	Engine knocking condition		
Battery	Battery voltage *3		
Power steering pressure sensor	Power steering operation		
Heated oxygen sensor 2 *1	Density of oxygen in exhaust gas		
Vehicle speed signal *2	Vehicle speed		
Air conditioner switch *2	Air conditioner operation		

*1: Under normal conditions, this sensor is not for engine control operation.

*2: These signals are sent to the ECM through CAN communication line.

*3: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and intake air) from both the crankshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injected is compensated to improve engine performance under various operating conditions as listed below.


<Fuel increase>

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- When selector lever is changed from “N” to “D” (CVT models)
- High-load, high-speed operation

<Fuel decrease>

- During deceleration
- During high engine speed operation

MIXTURE RATIO FEEDBACK CONTROL (CLOSED LOOP CONTROL)



The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst (manifold) can then better reduce CO, HC and NOx emissions. This system uses heated oxygen sensor 1 in the exhaust manifold to monitor if the engine operation is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about heated oxygen sensor 1, refer to [EC-1119](#). This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

Heated oxygen sensor 2 is located downstream of the three way catalyst (manifold). Even if the switching characteristics of heated oxygen sensor 1 shift, the air-fuel ratio is controlled to stoichiometric by the signal from heated oxygen sensor 2.

Open Loop Control

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Malfunction of heated oxygen sensor 1 or its circuit
- Insufficient activation of heated oxygen sensor 1 at low engine coolant temperature
- High engine coolant temperature
- During warm-up
- After shifting from “N” to “D” (CVT models)
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from heated oxygen sensor 1. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e., mass air flow sensor hot film) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short term fuel trim and long term fuel trim.

"Short term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from heated oxygen sensor 1 indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

FUEL INJECTION TIMING



Two types of systems are used.

Sequential Multiport Fuel Injection System

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is running.

Simultaneous Multiport Fuel Injection System

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

EBS00GXQ

Electronic Ignition (EI) System INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *2 and piston position	Ignition timing control	Power transistor
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Knock sensor	Engine knocking		
Park/neutral position (PNP) switch	Gear position		
Battery	Battery voltage *2		
Vehicle speed signal *1	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine. The ignition timing data is stored in the ECM. This data forms the map shown.

The ECM receives information such as the injection pulse width and camshaft position sensor signal. Computing this information, ignition signals are transmitted to the power transistor.


e.g., N: 1,800 rpm, Tp: 1.50 msec

A °BTDC

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- At low battery voltage
- During acceleration

The knock sensor retard system is designed only for emergencies. The basic ignition timing is programmed within the anti-knocking zone, if recommended fuel is used under dry conditions. The retard system does not operate under normal driving conditions. If engine knocking occurs, the knock sensor monitors the condition. The signal is transmitted to the ECM. The ECM retards the ignition timing to eliminate the knocking condition.



Air Conditioning Cut Control INPUT/OUTPUT SIGNAL CHART

EBS00GXR

Sensor	Input Signal to ECM	ECM function	Actuator
Air conditioner switch *1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Throttle position sensor	Throttle valve opening angle		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed *2		
Engine coolant temperature sensor	Engine coolant temperature		
Refrigerant pressure sensor	Refrigerant pressure		
Power steering pressure sensor	Power steering operation		
Vehicle speed signal *1	Vehicle speed		

*1: These signals are sent to the ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used. Under the following conditions, the air conditioner is turned off.

- When the accelerator pedal is fully depressed.
- When cranking the engine.
- At high engine speeds.
- When the engine coolant temperature becomes excessively high.
- When operating power steering during low engine speed or low vehicle speed.
- When engine speed is excessively low.
- When refrigerant pressure is excessively low or high.

Fuel Cut Control (at No Load and High Engine Speed)

EBS00GXS

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM function	Actuator
Park/neutral position (PNP) switch	Neutral position	Fuel cut control	Fuel injectors
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Accelerator pedal position		
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed		
Vehicle speed signal* ¹	Vehicle speed		

*1: This signal is sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

If the engine speed is above 1,800 rpm with no load (for example, in neutral and engine speed over 1,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under "Multiport Fuel Injection (MFI) System", [EC-1426](#).

CAN communication

EBS00GXT

SYSTEM DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

CAN COMMUNICATION UNIT FOR LHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

CVT Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tyre pressure signal					T	R

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

M/T Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R		T		
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tire pressure signal				T	R


ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

CAN COMMUNICATION UNIT FOR LHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

CVT Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

M/T Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART


T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R		T	
Heater fan switch signal	R			T
Air conditioner switch signal	R			T
MI signal	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

CAN COMMUNICATION UNIT FOR RHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

CVT Models

SYSTEM DIAGRAM



ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]


INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tire pressure signal				T		R

M/T Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R			T	

ENGINE CONTROL SYSTEM


[QR (WITHOUT EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	
Tire pressure signal			T		R

CAN COMMUNICATION UNIT FOR RHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

CVT Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R


ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

M/T Models

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL CHART

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R		T	
Heater fan switch signal	R			T
Air conditioner switch signal	R			T
MI signal	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R

ENGINE CONTROL SYSTEM

[QR (WITHOUT EURO-OBD)]

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

BASIC SERVICE PROCEDURE

PFP:00018

Idle Speed and Ignition Timing Check

IDLE SPEED

EBS00GXU

④ With CONSULT-II

Check idle speed in "DATA MONITOR" mode with CONSULT-II.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
SEF058Y	

IGNITION TIMING

Any of following two methods may be used.


Method A

1. Slide the harness protector of ignition coil No.1 to clear the wires.
2. Attach timing light to the wires as shown in the figure.
3. Check ignition timing.




Method B

1. Remove No. 1 ignition coil.




2. Connect No. 1 ignition coil and No. 1 spark plug with suitable high-tension wire as shown, and attach timing light clamp to this wire.




A
EC
C
D
E
F
G
H
I
J
K
L
M

BASIC SERVICE PROCEDURE

[QR (WITHOUT EURO-OBD)]



3. Check ignition timing.



Accelerator Pedal Released Position Learning DESCRIPTION

EBS00GXV

“Accelerator Pedal Released Position Learning” is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON” and wait at least 2 seconds.
3. Turn ignition switch “OFF” wait at least 10 seconds.
4. Turn ignition switch “ON” and wait at least 2 seconds.
5. Turn ignition switch “OFF” wait at least 10 seconds.

Throttle Valve Closed Position Learning DESCRIPTION

EBS00GXW

“Throttle Valve Closed Position Learning” is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

OPERATION PROCEDURE

1. Make sure that accelerator pedal is fully released.
2. Turn ignition switch “ON”.
3. Turn ignition switch “OFF” and wait at least 10 seconds.
Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

Idle Air Volume Learning DESCRIPTION

EBS00GXX

“Idle Air Volume Learning” is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

PREPARATION

Before performing “Idle Air Volume Learning”, make sure that all of the following conditions are satisfied.

BASIC SERVICE PROCEDURE

[QR (WITHOUT EURO-OBD)]


Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 - 95°C (158 - 203°F)
- PNP switch: ON
- Electric load switch: OFF
(Air conditioner, headlamp, rear window defogger)
On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.
- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up
For CVT models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "CVT" system indicates less than 0.9V.
For CVT models without CONSULT-II and M/T models, drive vehicle for 10 minutes.


OPERATION PROCEDURE

④ With CONSULT-II

1. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Start engine and warm it up to normal operating temperature.
4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
5. Select "IDLE AIR VOL LEARN" in "WORK SUPPORT" mode.




6. Touch "START" and wait 20 seconds.



BASIC SERVICE PROCEDURE

[QR (WITHOUT EURO-OBD)]

7. Make sure that "CMPLT" is displayed on CONSULT-II screen. If "INCMP" is displayed, "Idle Air Volume Learning" will not be carried out successfully. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.
8. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.




ITEM	SPECIFICATION
Idle speed	M/T: 600±50 rpm CVT: 650±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 14±5° BTDC CVT: 15±5° BTDC (in "P" or "N" position)

⊗ Without CONSULT-II

NOTE:

- It is better to count the time accurately with a clock.
 - It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
1. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
 2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
 3. Start engine and warm it up to normal operating temperature.
 4. Check that all items listed under the topic "PRE-CONDITIONING" (previously mentioned) are in good order.
 5. Turn ignition switch "OFF" and wait at least 10 seconds.
 6. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
 7. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
 8. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 20 seconds until the MI stops blinking and turned ON.
 9. Fully release the accelerator pedal within 3 seconds after the MI goes off.
 10. Start engine and let it idle.
 11. Wait 20 seconds.



12. Rev up the engine two or three times and make sure that idle speed and ignition timing are within the specifications.

ITEM	SPECIFICATION
Idle speed	M/T: 600±50 rpm CVT: 650±50 rpm (in "P" or "N" position)
Ignition timing	M/T: 14±5° BTDC CVT: 15±5° BTDC (in "P" or "N" position)

13. If idle speed and ignition timing are not within the specification, the result will be incomplete. In this case, find the cause of the problem by referring to the "Diagnostic Procedure" below.

BASIC SERVICE PROCEDURE

[QR (WITHOUT EURO-OBD)]

DIAGNOSTIC PROCEDURE

If idle air volume learning cannot be performed successfully, proceed as follows:

1. Check that throttle valve is fully closed.
2. Check PCV valve operation.
3. Check that downstream of throttle valve is free from air leakage.
4. When the above three items check out OK, engine component parts and their installation condition are questionable. Check and eliminate the cause of the problem.
It is useful to perform [EC-1494, "TROUBLE DIAGNOSIS - SPECIFICATION VALUE"](#).
5. If any of the following conditions occur after the engine has started, eliminate the cause of the problem and perform "Idle air volume learning" all over again:
 - Engine stalls.
 - Erroneous idle.

Fuel Pressure Check

FUEL PRESSURE RELEASE

EBS00GXY


Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.

NOTE:

Prepare pans or saucers under the disconnected fuel line because the fuel may spill out. The fuel pressure cannot be completely released because QR engine models do not have fuel return system.


ⓑ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT-II.
3. Start engine.
4. After engine stalls, crank it two or three times to release all fuel pressure.
5. Turn ignition switch "OFF".



ⓧ Without CONSULT-II

1. Remove fuel pump fuse located in fuse box.
2. Start engine.
3. After engine stalls, crank it two or three times to release all fuel pressure.
4. Turn ignition switch "OFF".
5. Reinstall fuel pump fuse after servicing fuel system.



FUEL PRESSURE CHECK


CAUTION:

- The fuel hose connection method used when taking fuel pressure check must not be used for other purposes.
 - Be careful not to scratch or put debris around connection area when servicing, so that the quick connector maintains sealability with O-rings inside.
 - When installing fuel hose quick connector, refer to [EM-116, "INTAKE MANIFOLD"](#).
1. Release fuel pressure to zero. Refer to [EC-1443, "FUEL PRESSURE RELEASE"](#).
 2. Prepare fuel hose and fuel hose clamp for fuel pressure check, and connect fuel pressure gauge.

BASIC SERVICE PROCEDURE

[QR (WITHOUT EURO-OBD)]


- Use suitable fuel hose for fuel pressure check (genuine NISSAN fuel hose without quick connector).
 - To avoid unnecessary force or tension to hose, use moderately long fuel hose for fuel pressure check.
 - Do not use the fuel hose for checking fuel pressure with damage or cracks on it.
 - Use Pressure Gauge to check fuel pressure.
3. Remove fuel hose. Refer to [EM-116, "INTAKE MANIFOLD"](#) .
- Do not twist or kink fuel hose because it is plastic hose.
 - Do not remove fuel hose from quick connector.
 - Keep the original fuel hose to be free from intrusion of dust or foreign substances with a suitable cover.
4. Install the fuel pressure gauge as shown in the figure.
- Wipe off oil or dirt from hose insertion part using cloth moistened with gasoline.
 - Apply proper amount of gasoline between top of the fuel tube and No.1 spool.
 - Insert fuel hose for fuel pressure check until it touches the No.1 spool on fuel tube.
 - Use NISSAN genuine hose clamp (part number: 16439 N4710 or 16439 40U00).
 - When reconnecting fuel line, always use new clamps.
 - When reconnecting fuel hose, check the original fuel hose for damage and abnormality.
 - Use a torque driver to tighten clamps.
 - Install hose clamp to the position within 1 - 2 mm (0.04 - 0.08 in).



Tightening torque:

1 - 1.5 N·m (0.1 - 0.15 kg·m, 9 - 13 in·lb)

- Make sure that clamp screw does not contact adjacent parts.
5. After connecting fuel hose for fuel pressure check, pull the hose with a force of approximately 98 N (10 kg, 22 lb) to confirm fuel tube does not come off.
6. Turn ignition switch "ON", and check for fuel leakage.
7. Start engine and check for fuel leakage.
8. Read the indication of fuel pressure gauge.
- Do not perform fuel pressure check with system operating. Fuel pressure gauge may indicate false readings.
 - During fuel pressure check, confirm for fuel leakage from fuel connection every 3 minutes.



At idling: Approximately 350 kPa (3.5 bar, 3.7 kg/cm², 51 psi)

9. If result is unsatisfactory, go to next step.
10. Check the following.
- Fuel hoses and fuel tubes for clogging
 - Fuel filter for clogging
 - Fuel pump
 - Fuel pressure regulator for clogging
- If OK, replace fuel pressure regulator.
If NG, repair or replace.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

Introduction

EBS00GXZ

The ECM has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information including:

Emission-related diagnostic information

Diagnostic Trouble Code (DTC)
Freeze Frame data
1st Trip Diagnostic Trouble Code (1st Trip DTC)
1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

x: Applicable —: Not applicable

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data
CONSULT-II	x	x	x	x
ECM	x	x*1	—	—

*: When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator (MI) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode. (Refer to [EC-1456](#).)

Two Trip Detection Logic

EBS00GY0

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MI will not light up at this stage. <1st trip>

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MI lights up. The MI lights up at the same time when the DTC is stored. <2nd trip>

The “trip” in the “Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation. When the ECM enters fail-safe mode (Refer to [EC-1456](#).), the DTC is stored in the ECM memory even in the 1st trip.

Emission-related Diagnostic Information DTC AND 1ST TRIP DTC

EBS00GY1

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed.

If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MI will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MI lights up. In other words, the DTC is stored in the ECM memory and the MI lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For fail-safe items, DTC is stored in the ECM memory even in the 1st trip.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in [EC-1446, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in “Work Flow” procedure Step II, refer to [EC-1452](#). Then perform “DTC Confirmation Procedure” or “Overall Function Check” to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.

How to Read DTC and 1st Trip DTC

DTC and 1st trip DTC can be read by the following methods.

☑ With CONSULT-II

CONSULT-II displays the DTC in “SELF-DIAG RESULTS” mode. Examples: P0117, P0340, P1065, etc. (CONSULT-II also displays the malfunctioning component or system.)

☒ Without CONSULT-II

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]

The number of blinks of the MI in the Diagnostic Test Mode II (Self-Diagnostic Results) indicates the DTC. Example: 0117, 0340, 1065 etc.

- **1st trip DTC No. is the same as DTC No.**
- **Output of a DTC indicates a malfunction. However, the Diagnostic Test Mode II do not indicate whether the malfunction is still occurring or has occurred in the past and has returned to normal. CONSULT-II can identify malfunction status as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC and 1st trip DTC is shown below. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

If the DTC is being detected currently, the time data will be "0".

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

DTC display	SELF DIAG RESULTS		1st trip DTC display
	DTC RESULTS TIME		
	CKP SEN/CIRCUIT [P0335]	0	

1st trip DTC display	SELF DIAG RESULTS		1st trip DTC display
	DTC RESULTS TIME		
	CKP SEN/CIRCUIT [P0335]	1t	

PBIB0911E

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed, vehicle speed, base fuel schedule and intake air temperature at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II. For details, see [EC-1482](#).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MI on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in [EC-1446, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION

How to Erase DTC (With CONSULT-II)

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
2. Touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]

4. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)
 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

2. Turn CONSULT-II "ON" and touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR (SPEC)
ACTIVE TEST
ECM PART NUMBER

3. Touch "SELF-DIAG RESULTS".

SELF DIAG RESULTS	
DTC RESULTS	TIME
MAF SEN/CIRCUIT [P0102]	0

4. Touch "ERASE". (The DTC in the ECM will be erased.)

PBIB0671E

⊗ How to Erase DTC (Without CONSULT-II)

- If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once.
 - Wait at least 10 seconds and then turn it "ON" (engine stopped) again.
 - Change the diagnostic test mode from Mode II to Mode I by depressing the accelerator pedal. Refer to [EC-1449, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).
- If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours.
 - The following data are cleared when the ECM memory is erased.
 - Diagnostic trouble codes
 - 1st trip diagnostic trouble codes
 - Freeze frame data
 - 1st trip freeze frame data
 - Others

Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures.

NATS (Nissan Anti-theft System)

EBS00GY2

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to [BL-156, "NATS \(NISSAN ANTI-THEFT SYSTEM\)"](#).
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DIAG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card. Therefore, be sure to receive all keys from vehicle owner. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF515Y

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]


EBS00GY3

Malfunction Indicator (MI)

DESCRIPTION







The MI is located on the instrument panel.

1. The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MI does not light up, refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1721](#).
2. When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.



ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in "ON" position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit.
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MI will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MI in the 1st trip. <ul style="list-style-type: none"> ● Fail-safe mode
Mode II	Ignition switch in "ON" position  Engine stopped 	SELF-DIAGNOSTIC RESULTS	This function allows DTCs and 1st trip DTCs to be read.
	Engine running 	HEATED OXYGEN SENSOR 1 MONITOR	This function allows the fuel mixture condition (lean or rich), monitored by heated oxygen sensor 1, to be read.

MI Flashing without DTC

If the ECM is in Diagnostic Test Mode II, MI may flash when engine is running. In this case, check ECM diagnostic test mode. [EC-1449, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).

How to switch the diagnostic test (function) modes, and details of the above functions are described later, [EC-1449](#).

The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]

- 1st trip freeze frame data
- Others


HOW TO SWITCH DIAGNOSTIC TEST MODE

NOTE:

- It is better to count the time accurately with a clock.
- It is impossible to switch the diagnostic mode when an accelerator pedal position sensor circuit has a malfunction.
- Always ECM returns to Diagnostic Test Mode I after ignition switch is turned "OFF".

How to Set Diagnostic Test Mode II (Self-diagnostic Results)

1. Confirm that accelerator pedal is fully released, turn ignition switch "ON" and wait 3 seconds.
2. Repeat the following procedure quickly five times within 5 seconds.
 - a. Fully depress the accelerator pedal.
 - b. Fully release the accelerator pedal.
3. Wait 7 seconds, fully depress the accelerator pedal and keep it for approx. 10 seconds until the MI starts blinking.
4. Fully release the accelerator pedal.
ECM has entered to Diagnostic Test Mode II (Self-diagnostic results).



How to Set Diagnostic Test Mode II (Heated Oxygen Sensor 1 Monitor)

1. Set the ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-1449, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Start Engine.
ECM has entered to Diagnostic Test Mode II (Heated oxygen sensor 1 monitor).

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

1. Set ECM in Diagnostic Test Mode II (Self-diagnostic results). Refer to [EC-1449, "How to Set Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
2. Fully depress the accelerator pedal and keep it for more than 10 seconds.
The emission-related diagnostic information has been erased from the backup memory in the ECM.
3. Fully release the accelerator pedal, and confirm the DTC 0000 is displayed.

DIAGNOSTIC TEST MODE I — BULB CHECK

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1721](#).

DIAGNOSTIC TEST MODE I — MALFUNCTION WARNING

MI	Condition
ON	When the malfunction is detected.
OFF	No malfunction.

- These DTC numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS)


DIAGNOSTIC TEST MODE II — SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MI as shown below.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[QR (WITHOUT EURO-OBD)]

The DTC and 1st trip DTC are displayed at the same time. If the MI does not illuminate in diagnostic test mode I (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MI illuminates in diagnostic test mode II (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT-II. A DTC will be used as an example for how to read a code.



A particular trouble code can be identified by the number of four-digit numeral flashes. The “zero” is indicated by the number of ten flashes. The length of time the 1,000th-digit numeral flashes on and off is 1.2 seconds consisting of an ON (0.6-second) - OFF (0.6-second) cycle.

The 100th-digit numeral and lower digit numerals consist of a 0.3-second ON and 0.3-second OFF cycle.

A change from one digit numeral to another occurs at an interval of 1.0-second OFF. In other words, the later numeral appears on the display 1.3 seconds after the former numeral has disappeared.

A change from one trouble code to another occurs at an interval of 1.8-second OFF.

In this way, all the detected malfunctions are classified by their DTC numbers. The DTC “0000” refers to no malfunction. (See [EC-1415, "INDEX FOR DTC"](#))

How to Erase Diagnostic Test Mode II (Self-diagnostic Results)

The DTC can be erased from the back up memory in the ECM by depressing accelerator pedal. Refer to [EC-1449, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#) .

- If the battery is disconnected, the DTC will be lost from the backup memory after approx 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

DIAGNOSTIC TEST MODE II — HEATED OXYGEN SENSOR 1 MONITOR

In this mode, the MI displays the condition of the fuel mixture (lean or rich) which is monitored by the heated oxygen sensor 1.

MI	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	
*Remains ON or OFF	Any condition	Open loop system

*: Maintains conditions just before switching to open loop.

To check the heated oxygen sensor 1 function, start engine in the Diagnostic Test Mode II and warm it up until engine coolant temperature indicator points to the middle of the gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Then make sure that the MI comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

TROUBLE DIAGNOSIS

PFP:00004

Trouble Diagnosis Introduction
INTRODUCTION

EBS00GY5




The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the "Work Flow" on [EC-1452](#).

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on [EC-1455](#) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.




A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

WORK FLOW

Flow Chart



MBIB0178E

*1 If time data of "SELF-DIAG RESULTS" is other than "0" or "[1t]", perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*2 If the incident cannot be verified, perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-1499, "POWER SUPPLY CIRCUIT FOR ECM"](#) .

*4 If malfunctioning part cannot be detected, perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*5 [EC-1494](#)

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-1454 .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) the (1st trip) DTC and the (1st trip) freeze frame data, then erase the DTC and the data. (Refer to EC-1446 .) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. If the incident cannot be verified, perform EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-1462 .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the (1st trip) DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT-II. During the (1st trip) DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the (1st trip) DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION. (Refer to EC-1457 .) If CONSULT-II is available, perform "DATA MONITOR (SPEC)" mode with CONSULT-II and proceed to the "TROUBLE DIAGNOSIS – SPECIFICATION VALUE". (Refer to EC-1494 .) (If malfunction is detected, proceed to "PERAIR/REPLACE".) Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-1462 .)
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-1472 , EC-1489 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to "Circuit Inspection" in GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident" . Repair or replace the malfunction parts. If malfunctioning part cannot be detected, perform EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code [DTC No. P0000] is detected. If the incident is still detected in the final check, perform STEP VI by using a method different from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in ECM. (Refer to EC-1446, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION" .)

A
EC
C
D
E
F
G
H
I
J
K
L
M

DIAGNOSTIC WORKSHEET

Description

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on the next page in order to organize all the information for troubleshooting.

Some conditions may cause the MIL to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> ● U1000 U1001 CAN communication line ● P0102 P0103 Mass air flow sensor ● P0117 P0118 Engine coolant temperature sensor ● P0221 P0222 P0223 P1223 P1224 P1225 P1226 Throttle position sensor ● P0226 P0227 P0228 P1227 P1228 Accelerator pedal position sensor ● P0327 P0328 Knock sensor ● P0335 Crankshaft position sensor (POS) ● P0340 Camshaft position sensor (PHASE) ● P0500 Vehicle speed sensor ● P0605 ECM ● P1229 Sensor power supply ● P1610-P1615 NATS
2	<ul style="list-style-type: none"> ● P0134 Heated oxygen sensor 1 ● P0550 Power steering pressure sensor ● P1065 ECM power supply ● P1122 Electric throttle control function ● P1124 P1126 Throttle control moter relay ● P1128 Throttle control moter ● P1805 Brake switch
3	<ul style="list-style-type: none"> ● P1121 Electric throttle control actuator ● P1217 Engine over temperature (OVERHEAT)

Fail-safe Chart

EBS00GY7

When the DTC listed bellow is detected, the ECM enters fail-safe mode and the MI lights up.

DTC No.	Detected items	Engine operating condition in fail-safe mode								
P0102 P0103	Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.								
P0117 P0118	Engine coolant temperature sensor circuit	<p>Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 50%;">Condition</th> <th>Engine coolant temperature decided (CONSULT-II display)</th> </tr> </thead> <tbody> <tr> <td>Just as ignition switch is turned ON or Start</td> <td style="text-align: center;">40°C (104°F)</td> </tr> <tr> <td>More than approx. 4 minutes after ignition ON or Start</td> <td style="text-align: center;">80°C (176°F)</td> </tr> <tr> <td>Except as shown above</td> <td style="text-align: center;">40 - 80°C (104 - 176°F) (Depends on the time)</td> </tr> </tbody> </table> <p>When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.</p>	Condition	Engine coolant temperature decided (CONSULT-II display)	Just as ignition switch is turned ON or Start	40°C (104°F)	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
Condition	Engine coolant temperature decided (CONSULT-II display)									
Just as ignition switch is turned ON or Start	40°C (104°F)									
More than approx. 4 minutes after ignition ON or Start	80°C (176°F)									
Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)									
P0221 P0222 P0223 P1223 P1224	Throttle position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								
P0226 P0227 P0228 P1227 P1228	Accelerator pedal position sensor	<p>The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees. The ECM regulates the opening speed of the throttle valve to be slower than the normal condition. So, the acceleration will be poor.</p>								

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]



DTC No.	Detected items	Engine operating condition in fail-safe mode
P1121	Electric throttle control actuator (ECM detect the throttle valve is stuck open.)	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.
P1122	Electric throttle control function	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.
P1124 P1126	Throttle control motor relay	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.
P1128	Throttle control motor	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.
P1229	Sensor power supply	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

Basic Inspection

EBS00GY8

1. INSPECTION START


- Check service records for any recent repairs that may indicate a related problem, or a current need for scheduled maintenance.
- Open engine hood and check the following:
 - Harness connectors for improper connections
 - Wiring harness for improper connections, pinches and cut
 - Vacuum hoses for splits, kinks and improper connections
 - Hoses and ducts for leaks
 - Air cleaner clogging
 - Gasket
- Confirm that electrical or mechanical loads are not applied.
 - Headlamp switch is OFF.
 - Air conditioner switch is OFF.
 - Rear window defogger switch is OFF.
 - Steering wheel is in the straight-ahead position, etc.
- Start engine and warm it up until engine coolant temperature indicator points the middle of gauge.
Ensure engine stays below 1,000 rpm.



- Run engine at about 2,000 rpm for about 2 minutes under no-load.
- Make sure that no DTC is displayed with CONSULT-II.

OK or NG

- OK >> GO TO 3.
NG >> GO TO 2.



2. REPAIR OR REPLACE


Repair or replace components as necessary according to corresponding "Diagnostic Procedure".

>> GO TO 3

3. CHECK TARGET IDLE SPEED

④ With CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.



3. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Run engine at about 2,000 rpm for about 2 minutes under no-load.
2. Rev engine (2,000 to 3,000 rpm) two or three times under no-load, then run engine at idle speed for about 1 minute.
3. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 10.

NG >> GO TO 4.

4. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 5.

5. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 6.

6. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-1440, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP ?

CMPLT or INCMP

CMPLT >> GO TO 7.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

7. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 10.

NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the Following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-1562](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-1555](#) .

OK or NG

OK >> GO TO 9.

NG >> 1. Repair or replace.

2. GO TO 4.

9. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-1447, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

10. CHECK IGNITION TIMING

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $14 \pm 5^\circ$ BTDC

CVT: $15 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 11.

11. PERFORM ACCELERATOR PEDAL RELEASED POSITION LEARNING

1. Stop engine.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .

>> GO TO 12.

12. PERFORM THROTTLE VALVE CLOSED POSITION LEARNING

Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .

>> GO TO 13.

13. PERFORM IDLE AIR VOLUME LEARNING

Refer to [EC-1440, "Idle Air Volume Learning"](#) .

Which is the result CMPLT or INCMP ?

CMPLT or INCMP

CMPLT >> GO TO 14.

INCMP >> 1. Follow the construction of "Idle Air Volume Learning".

2. GO TO 4.

14. CHECK TARGET IDLE SPEED AGAIN

 **With CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Read idle speed in "DATA MONITOR" mode with CONSULT-II.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

 **Without CONSULT-II**

1. Start engine and warm it up to normal operating temperature.
2. Check idle speed.

M/T: 600 ± 50 rpm

CVT: 650 ± 50 rpm (in "P" or "N" position)

OK or NG

OK >> GO TO 15.

NG >> GO TO 17.

15. CHECK IGNITION TIMING AGAIN

1. Run engine at idle.
2. Check ignition timing with a timing light.

M/T: $14 \pm 5^\circ$ BTDC

CVT: $15 \pm 5^\circ$ BTDC (in "P" or "N" position)

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 16.

16. CHECK TIMING CHAIN INSTALLATION

Check timing chain installation. Refer to [EM-143, "TIMING CHAIN"](#) .

OK or NG

OK >> GO TO 17.

NG >> 1. Repair the timing chain installation.
2. GO TO 4.

17. DETECT MALFUNCTIONING PART

Check the following.

- Check camshaft position sensor (PHASE) and circuit. Refer to [EC-1562](#) .
- Check crankshaft position sensor (POS) and circuit. Refer to [EC-1555](#) .

OK or NG

OK >> GO TO 18.

NG >> 1. Repair or replace.
2. GO TO 4.

18. CHECK ECM FUNCTION

1. Substitute another known-good ECM to check ECM function. (ECM may be the cause of a problem, but this is the rarely the case.)
2. Perform initialization of NATS system and registration of NATS ignition key IDs. Refer to [EC-1447, "NATS \(Nissan Anti-theft System\)"](#) .

>> GO TO 4.

A

EC

C

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Symptom Matrix Chart SYSTEM — BASIC ENGINE CONTROL SYSTEM

EBS00GY9

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Fuel	Fuel pump circuit	1	1	2	3	2		2	2			3		2	EC-1705
	Fuel pressure regulator system	3	3	4	4	4	4	4	4	4		4			EC-1443
	Injector circuit	1	1	2	3	2		2	2			2			EC-1699
	Evaporative emission system	3	3	4	4	4	4	4	4	4		4			EC-1723
Air	Positive crankcase ventilation system	3	3	4	4	4	4	4	4	4		4	1		EC-1726
	Incorrect idle speed adjustment	3	3				1	1	1	1		1			EC-1457
	Electric throttle control actuator	1	1	2	3	3	2	2	2	2		2		2	EC-1583 , EC-1585 , EC-1592 , EC-1598
Ignition	Incorrect ignition timing adjustment	3	3	1	1	1		1	1			1			EC-1457
	Ignition circuit	1	1	2	2	2		2	2			2			EC-1672
Main power supply and ground circuit		2	2	3	3	3		3	3		2	3			EC-1499
Mass air flow sensor circuit		1	1	2	2	2		2	2			2			EC-1508
Engine coolant temperature sensor circuit		1	1	2	2	2	3	2	2	3	1	2			EC-1514
Throttle position sensor circuit			1	2		2	2	2	2	2		2			EC-1525 , EC-1531 , EC-1620 , EC-1626 , EC-1628 , EC-1637
Accelerator pedal position sensor circuit				3	2	1	2			2					EC-1537 , EC-1544 , EC-1630
Heated oxygen sensor 1 circuit			1	2	3	2		2	2			2			EC-1519 , EC-1660
Knock sensor circuit				2	2							3			EC-1551
Crankshaft position sensor (POS) circuit		2	2												EC-1555
Camshaft position sensor (PHASE) circuit		2	2												EC-1562
Vehicle speed signal circuit			2	3		3						3			EC-1569
Power steering pressure sensor circuit			2				3	3	3	3					EC-1571

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

	SYMPTOM													Reference page
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
ECM	2	2	3	3	3	3	3	3	3	3	3			EC-1576 , EC-1579
Intake valve timing control solenoid valve circuit	3	3	2		1	3	2	2	3		3			EC-1689
PNP switch circuit			3		3	3	3	3	3		3			EC-1695
Refrigerant pressure sensor circuit		2				3	3	3	3		4			EC-1711
Electrical load signal circuit						3	3	3	3					EC-1716
Air conditioner circuit	2	2	3	3	3	3	3	3	3		3		2	ATC-30

1 - 6: The numbers refer to the order of inspection.
(continued on next page)

SYSTEM — ENGINE MECHANICAL & OTHER

	SYMPTOM													Reference page	
	HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)		
Warranty symptom code	AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA		
Fuel	Fuel tank	5												FL-13	
	Fuel piping		5	5	5		5	5			5			MA-23 , EM-128	
	Vapor lock		5												—
	Valve deposit														—
	Poor fuel (Heavy weight gasoline, Low octane)		5		5	5	5		5	5			5		

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Air	Air duct														EM-114
	Air cleaner														EM-114
	Air leakage from air duct (Mass air flow sensor —electric throttle control actuator)		5	5		5		5	5			5			EM-114
	Electric throttle control actuator	5			5		5			5					EM-116
	Air leakage from intake manifold/ Collector/Gasket														EM-116
Cranking	Battery	1	1	1		1		1	1			1		1	SC-3
	Alternator circuit														SC-12
	Starter circuit	3													SC-22
	Signal plate/Flywheel/Drive plate	6													EM-165
	PNP switch	4													MT-126 or CVT-67
Engine	Cylinder head	5	5	5	5	5		5	5			5			EM-152
	Cylinder head gasket										4		3		
	Cylinder block														
	Piston												4		
	Piston ring														
	Connecting rod	6	6	6	6	6		6	6			6			EM-165
	Bearing														
	Crankshaft														
Valve mechanism	Timing chain														EM-143
	Camshaft														EM-133
	Intake valve timing control	5	5	5	5	5		5	5			5		EM-143	
	Intake valve														
	Exhaust valve												3		EM-152
Exhaust	Exhaust manifold/Tube/Muffler/ Gasket	5	5	5	5	5		5	5			5			EM-121 , EX-3
	Three way catalyst														

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]


		SYMPTOM												Reference page	
		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION		BATTERY DEAD (UNDER CHARGE)
Warranty symptom code		AA	AB	AC	AD	AE	AF	AG	AH	AJ	AK	AL	AM	HA	
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	5	5	5	5	5		5	5			5	2		EM-123 , LU-18 , LU-19 , LU-14
	Oil level (Low)/Filthy oil														LU-16
Cooling	Radiator/Hose/Radiator filler cap														CO-31
	Thermostat									5					CO-40
	Water pump														CO-38
	Water gallery	5	5	5	5	5		5	5		2	5			CO-27
	Cooling fan									5					CO-31
	Coolant level (low)/Contaminated coolant														CO-29
NATS (Nissan Anti-theft System)		1	1												EC-1448 or BL-156

1 - 6: The numbers refer to the order of inspection.

A
EC
C
D
E
F
G
H
I
J
K
L
M

Engine Control Component Parts Location









EBS00GYA



MBIB0070E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]



A

EC

C

D

E

F

G

H

I

J

K









L

M

MBIB0147E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]









MBIB0148E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

A
EC
C
D
E
F
G
H
I
J
K
L
M




MBIB0149E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Circuit Diagram


EBS00GYB



MBWA0156E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]



Pre-
ceding
page

A
EC
C
D
E
F
G
H
I
J
K
L
M


MBWA0157E

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

ECM Harness Connector Terminal Layout

EBS00GYC




MBIB0045E


ECM Terminals and Reference Value PREPARATION

EBS00GYD

1. ECM is located behind the glove box. For this inspection, remove glove box.
2. Remove ECM harness protector.



3. When disconnecting ECM harness connector, loosen it with levers as far as they will go as shown at right.
4. Connect a break-out box (SST) and Y-cable adapter (SST) between the ECM and ECM harness connector.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and ground.





CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1	B	ECM ground	[Engine is running] ● Idle speed	Engine ground

TROUBLE DIAGNOSIS





[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/W	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> ● Engine speed is below 3,800 rpm. ● After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Engine stopped [Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,800 rpm 	BATTERY VOLTAGE (11 - 14V)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E
12	Y	Power steering pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	0.5 - 4.0V
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	0.4 - 0.8V
13	L	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 3.0V★  PBIB0527E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	Approximately 3.0V★  PBIB0528E

A
EC
C
D
E
F
G
H
I
J
K
L
M




TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	L	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p style="text-align: right;">PBIB0526E</p>
15	W	Knock sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>Approximately 2.5V</p>
16	W/Y	Heated oxygen sensor 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	<p>0 - Approximately 1.0V</p>
19	P	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>

TROUBLE DIAGNOSIS





[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B SB L R/W	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div T</small> PBIB0529E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	BATTERY VOLTAGE (11 - 14V)★  <small>10.0 V/Div 50 ms/Div T</small> PBIB0530E
24	P/L	Heated oxygen sensor 1 heater	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is below 3,600 rpm. 	Approximately 7.0V  <small>10.0 V/Div 50 ms/Div T</small> PBIB0519E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is above 3,600 rpm. 	BATTERY VOLTAGE (11 - 14V)
34	G	Intake air temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with intake air temperature.
35	PU	Heated oxygen sensor 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	0 - Approximately 1.0V (Periodically change)
45	R	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
46	R	Sensor's power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
47	G	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	More than 0.36V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	Less than 4.75V

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
50	B	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.1 - 1.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.6 - 2.0V
54	W	Sensors' ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
55	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
60 61 79 80	L/Y Y/R GY/L PU/G	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	[Engine is running] ● Warm-up condition ● Idle speed	0 - 0.1V★  PBIB0521E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - 0.2V★  PBIB0522E
62	Y	Intake valve timing control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	BATTERY VOLTAGE (11 - 14V)  MBIB0052E
			[Engine is running] ● Warm-up condition ● When revving engine up to 2,000 rpm quickly	Approximately 4V - BATTERY VOLTAGE (11 - 14V)★  PBIB0532E
65	R	Sensor's power supply (Power steering pres- sure sensor)	[Ignition switch "ON"]	Approximately 5V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V



TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)	A
68	R	Throttle position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released 	Less than 4.75V	EC
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed 	More than 0.36V	C D
69	L	Refrigerant pressure sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Both A/C switch and blower switch are "ON" (Compressor operates.) 	1.0 - 4.0V	E
72	L/OR	Engine coolant temperature sensor	[Engine is running]	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature.	F
74	B	Sensors' ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V	G
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Lighting switch is "2ND" position 	BATTERY VOLTAGE (11 - 14V)	H
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Lighting switch is "OFF" 	Approximately 0V	I
85	LG	DATA link connector	[Ignition switch "ON"] <ul style="list-style-type: none"> ● CONSULT-II or GST is disconnected. 	BATTERY VOLTAGE (11 - 14V)	J
86	R	CAN communication line	[Ignition switch "ON"]	1.0 - 2.5V	K
92*	GY	Accelerator pedal position sensor signal output	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	Approximately 0.5V	L
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	Approximately 4.2V	M
94	L	CAN communication line	[Ignition switch "ON"]	2.5 - 4.0V	
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.175 - 0.335V	
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 1.95V	
101	R/G	Stop lamp switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully released 	Approximately 0V	
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully depressed 	BATTERY VOLTAGE (11 - 14V)	

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
102	P (CVT) L (M/T)	PNP switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Gear position is "P" or "N" 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Except the above gear position 	CVT models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V
103*	L/OR	Tachometer signal output	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	10 - 11V★  MBIB0053E
			[Engine is running] <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm 	10 - 11V★  MBIB0054E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V
106	L	Accelerator pedal posi- tion sensor 1	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released 	0.35 - 0.67V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed 	More than 3.9V
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For 5 seconds after turning ignition switch "OFF" 	0 - 1.0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● 5 seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
113	B/P	Fuel pump relay	[Ignition switch "ON"] <ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch "ON" 	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] <ul style="list-style-type: none"> ● More than 1 seconds after turning ignition switch "ON". 	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
115 116	B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*: CVT models

CONSULT-II Function FUNCTION

EBS00GYE

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT-II unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*
Data monitor	Input/Output data in the ECM can be read.
Data monitor (SPEC)	Input/Output of the specification for Basic fuel schedule, AFM, A/F feedback control value and the other data monitor items can be read.
Active test	Diagnostic Test Mode in which CONSULT-II drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
Function test	This mode is used to inform customers when their vehicle condition requires periodic maintenance.
ECM part number	ECM part number can be read.

*: The following emission-related diagnostic information is cleared when the ECM memory is erased.

- Diagnostic trouble codes
- 1st trip diagnostic trouble codes
- Freeze frame data
- 1st trip freeze frame data
- Others

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		DIAGNOSTIC TEST MODE					
		WORK SUPPORT	SELF-DIAGNOSTIC RESULTS		DATA MONI- TOR	DATA MONI- TOR (SPEC)	ACTIVE TEST
			DTC*1	FREEZE FRAME DATA*2			
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (POS)	×	×	×	×	
	Camshaft position sensor (PHASE)	×		×	×		
	Mass air flow sensor	×		×	×		
	Engine coolant temperature sensor	×	×	×	×	×	
	Heated oxygen sensor 1	×		×	×		
	Heated oxygen sensor 2			×	×		
	Vehicle speed signal	×	×	×	×		
	Accelerator pedal position sensor	×		×	×		
	Throttle position sensor	×		×	×		
	Intake air temperature sensor			×	×		
	Knock sensor	×					
	Refrigerant pressure sensor			×	×		
	Closed throttle position switch (accelerator pedal position sensor signal)			×	×		
	Air conditioner switch			×	×		
	Park/neutral position (PNP) switch			×	×		
	Stop lamp switch	×		×	×		
	Power steering pressure sensor	×		×	×		
	Battery voltage			×	×		
Electrical load signal			×	×			
ENGINE CONTROL COMPONENT PARTS	OUTPUT	Injectors			×	×	×
	Power transistor (Ignition timing)			×	×	×	×
	Throttle control motor relay	×		×	×		
	Throttle control motor	×					
	EVAP canister purge volume control solenoid valve			×	×	×	
	Air conditioner relay			×	×		
	Fuel pump relay	×		×	×	×	
	Cooling fan relay	×		×	×	×	
	Heated oxygen sensor 1 heater			×	×		
	Heated oxygen sensor 2 heater			×	×		
Intake valve timing control solenoid valve			×	×	×		

X: Applicable

*1: This item includes 1st trip DTCs.

*2: This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT-II screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to [EC-1446](#).


CONSULT-II INSPECTION PROCEDURE

1. Turn ignition switch OFF.


TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]


2. Connect "CONSULT-II" to data link connector, which is located under drivers side dash panel.
3. Turn ignition switch ON.




4. Touch "START".



5. Touch "ENGINE".



6. Perform each diagnostic test mode according to each service procedure.
For further information, see the CONSULT-II Operation Manual.



WORK SUPPORT MODE

Work Item

WORK ITEM	CONDITION	USAGE
FUEL PRESSURE RELEASE	<ul style="list-style-type: none"> ● FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS. 	When releasing fuel pressure from fuel line
IDLE AIR VOL LEARN	<ul style="list-style-type: none"> ● THE IDLE AIR VOLUME THAT KEEPS THE ENGINE WITHIN THE SPECIFIED RANGE IS MEMORIZED IN ECM. 	When learning the idle air volume

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

WORK ITEM	CONDITION	USAGE
SELF-LEARNING CONT	<ul style="list-style-type: none"> ● THE COEFFICIENT OF SELF-LEARNING CONTROL MIXTURE RATIO RETURNS TO THE ORIGINAL COEFFICIENT. 	When clearing the coefficient of self-learning control value
TARGET IDLE RPM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When setting target idle speed
TARGET IGN TIM ADJ*	<ul style="list-style-type: none"> ● IDLE CONDITION 	When adjusting target ignition timing After adjustment, confirm target ignition timing with a timing light.

*: This function is not necessary in the usual service procedure.

SELF-DIAG RESULTS MODE

Self Diagnostic Item

Regarding items of "DTC and 1st trip DTC", refer to [EC-1415, "INDEX FOR DTC" .\)](#)

Freeze Frame Data and 1st Trip Freeze Frame Data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	<ul style="list-style-type: none"> ● The engine control component part/control system has a trouble code, it is displayed as "PXXXX". (Refer to EC-1415, "INDEX FOR DTC" .)
FUEL SYS-B1	<ul style="list-style-type: none"> ● "Fuel injection system status" at the moment a malfunction is detected is displayed. ● One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
COOLANT TEMP [°C] or [°F]	<ul style="list-style-type: none"> ● The engine coolant temperature at the moment a malfunction is detected is displayed.
L-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Long-term fuel trim" at the moment a malfunction is detected is displayed. ● The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
S-FUEL TRIM-B1 [%]	<ul style="list-style-type: none"> ● "Short-term fuel trim" at the moment a malfunction is detected is displayed. ● The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
ENGINE SPEED [rpm]	<ul style="list-style-type: none"> ● The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	<ul style="list-style-type: none"> ● The vehicle speed at the moment a malfunction is detected is displayed.
B/FUEL SCHDL [msec]	<ul style="list-style-type: none"> ● The base fuel schedule at the moment a malfunction is detected is displayed.
INT/A TEMP SE [°C] or [°F]	<ul style="list-style-type: none"> ● The intake air temperature at the moment a malfunction is detected is displayed.

*: The items are the same as those of 1st trip freeze frame data.

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

DATA MONITOR MODE

Monitored Item

×: Applicable

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
ENG SPEED [rpm]	×	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signals of the crankshaft position sensor (POS) and camshaft position sensor (PHASE). 	<ul style="list-style-type: none"> Accuracy becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS A/F SE-B1 [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
B/FUEL SCHDL [msec]		×		<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	
A/F ALPHA-B1 [%]		×		<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
COOLAN TEMP/S [°C] or [°F]	×	×		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	<ul style="list-style-type: none"> When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
HO2S1 (B1) [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 1 is displayed. 	
HO2S2 (B1) [V]	×			<ul style="list-style-type: none"> The signal voltage of the heated oxygen sensor 2 is displayed. 	
HO2S1 MNTR (B1) [RICH/LEAN]	×	×		<ul style="list-style-type: none"> Display of heated oxygen sensor 1 signal during air-fuel ratio feedback control: RICH ... means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN ... means the mixture became "lean", and control is being affected toward a rich mixture. 	<ul style="list-style-type: none"> After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamping is displayed continuously.
HO2S2 MNTR (B1) [RICH/LEAN]	×			<ul style="list-style-type: none"> Display of heated oxygen sensor 2 signal: RICH ... means the amount of oxygen after three way catalyst is relatively small. LEAN ... means the amount of oxygen after three way catalyst is relatively large. 	<ul style="list-style-type: none"> When the engine is stopped, a certain value is indicated.
VHCL SPEED SE [km/h] or [mph]	×	×		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	
BATTERY VOLT [V]	×	×		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
ACCEL SEN 1 [V]	×	×		<ul style="list-style-type: none"> The accelerator pedal position sensor signal voltage is displayed. 	
ACCEL SEN 2 [V]	×				

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
THRTL SEN 1 [V]	×	×		● The throttle position sensor signal voltage is displayed.	
THRTL SEN 2 [V]	×				
INT/A TEMP SE [°C] or [°F]	×	×		● The intake air temperature (determined by the signal voltage of the intake air temperature sensor) is indicated.	
START SIGNAL [ON/OFF]	×	×		● Indicates start signal status [ON/OFF] computed by the ECM according to the signals of engine speed and battery voltage.	● After starting the engine, [OFF] is displayed regardless of the starter signal.
CLSD THL POS [ON/OFF]	×	×		● Indicates idle position [ON/OFF] computed by ECM according to the accelerator pedal position sensor signal.	
AIR COND SIG [ON/OFF]	×	×		● Indicates [ON/OFF] condition of the air conditioner switch as determined by the air conditioner signal.	
P/N POSI SW [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the park/neutral position (PNP) switch signal.	
PW/ST SIGNAL [ON/OFF]	×	×		● [ON/OFF] condition of the power steering oil pressure switch as determined by the power steering oil pressure signal is indicated.	
LOAD SIGNAL [ON/OFF]	×	×		● Indicates [ON/OFF] condition from the electrical load signal. ON ... Rear window defogger switch is ON and/or lighting switch is in 2nd position. OFF ... Both rear window defogger switch and lighting switch are OFF.	
IGNITION SW [ON/OFF]	×			● Indicates [ON/OFF] condition from ignition switch.	
HEATER FAN SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the heater fan switch signal.	
BRAKE SW [ON/OFF]	×			● Indicates [ON/OFF] condition from the stop lamp switch signal.	
INJ PULSE-B1 [msec]		×		● Indicates the actual fuel injection pulse width compensated by ECM according to the input signals.	● When the engine is stopped, a certain computed value is indicated.
IGN TIMING [BTDC]		×		● Indicates the ignition timing computed by ECM according to the input signals.	● When the engine is stopped, a certain value is indicated.
PURG VOL C/V [%]				● Indicates the EVAP canister purge volume control solenoid valve control value computed by the ECM according to the input signals. ● The opening becomes larger as the value increases.	
INT/V TIM (B1) [°CA]				● Indicates [°CA] of intake camshaft advanced angle.	

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
INT/V SOL (B1) [%]				<ul style="list-style-type: none"> The control condition of the intake valve timing control solenoid valve (determined by ECM according to the input signals) is indicated. ON ... intake valve timing control is operating. OFF ... Intake valve timing control is not operating. 	
AIR COND RLY [ON/OFF]		×		<ul style="list-style-type: none"> The air conditioner relay control condition (determined by ECM according to the input signals) is indicated. 	
FUEL PUMP RLY [ON/OFF]		×		<ul style="list-style-type: none"> Indicates the fuel pump relay control condition determined by ECM according to the input signals. 	
THRTL RELAY [ON/OFF]		×		<ul style="list-style-type: none"> Indicates the throttle control motor relay control condition determined by the ECM according to the input signals. 	
COOLING FAN [HI/LOW/OFF]				<ul style="list-style-type: none"> Indicates the condition of the cooling fan (determined by ECM according to the input signals). HI ... High speed operation LOW ... Low speed operation OFF ... Stop 	
HO2S1 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 1 heater determined by ECM according to the input signals. 	
HO2S2 HTR (B1) [ON/OFF]				<ul style="list-style-type: none"> Indicates [ON/OFF] condition of heated oxygen sensor 2 heater determined by ECM according to the input signals. 	
I/P PULLY SPD [rpm]	×			<ul style="list-style-type: none"> Indicates the engine speed computed from the primary speed sensor signal. 	
VEHICLE SPEED [km/h] or [mph]	×			<ul style="list-style-type: none"> Indicates the vehicle speed computed from the secondary speed sensor signal. 	
IDL A/V LEARN [YET/CMPLT/ INCMP]				<ul style="list-style-type: none"> Display the condition of idle air volume learning YET ... Idle air volume learning has not been performed yet. CMPLT ... Idle air volume learning has already been performed successfully. INCMP ... Idle air volume learning has not been performed successfully. 	
AC PRESS SEN [V]				<ul style="list-style-type: none"> The signal voltage from the refrigerant pressure sensor is displayed. 	
Voltage [V]				<ul style="list-style-type: none"> Voltage, frequency, duty cycle or pulse width measured by the probe. 	<ul style="list-style-type: none"> Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBID)]

Monitored item [Unit]	ECM INPUT SIG- NALS	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	Description	Remarks
CAN COMM [OK/NG]			×	<ul style="list-style-type: none"> Indicates the communication condition of CAN communication line. 	<ul style="list-style-type: none"> These items are not displayed in "SELECTION FROM MENU" mode.
CAN CIRC 1 [OK/UNKWN]			×		
CAN CIRC 2 [OK/UNKWN]			×		
CAN CIRC 3 [OK/UNKWN]			×		
CAN CIRC 4 [OK/UNKWN]			×		
CAN CIRC 5 [OK/UNKWN]			×		
CAN CIRC 6 [OK/UNKWN]			×		
CAN CIRC 7 [OK/UNKWN]			×		

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

DATA MONITOR (SPEC) MODE

Monitored Item

Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
ENG SPEED [rpm]	×		<ul style="list-style-type: none"> Indicates the engine speed computed from the signal of the crankshaft position sensor (POS). 	
MAS A/F SE-B1 [V]	×	×	<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor specification is displayed. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
B/FUEL SCHDL [msec]			<ul style="list-style-type: none"> "Base fuel schedule" indicates the fuel injection pulse width programmed into ECM, prior to any learned on board correction. 	<ul style="list-style-type: none"> When engine is running specification range is indicated.
A/F ALPHA-B1 [%]		×	<ul style="list-style-type: none"> The mean value of the air-fuel ratio feedback correction factor per cycle is indicated. 	<ul style="list-style-type: none"> When engine is running specification range is indicated. This data also includes the data for the air-fuel ratio learning control.

NOTE:

- Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

ACTIVE TEST MODE

Test Item

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the amount of fuel injection using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Fuel injectors ● Heated oxygen sensor 1
IGNITION TIMING	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Timing light: Set ● Retard the ignition timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Perform "Idle Air Volume Learning".
POWER BALANCE	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine. ● A/C switch "OFF" ● Shift lever "N" ● Cut off each injector signal one at a time using CONSULT-II. 	Engine runs rough or dies.	<ul style="list-style-type: none"> ● Harness and connectors ● Compression ● Fuel injectors ● Power transistor ● Spark plugs ● Ignition coils
COOLING FAN	<ul style="list-style-type: none"> ● Ignition switch: ON ● Turn the cooling fan "ON" and "OFF" with CONSULT-II. 	Cooling fan moves and stops.	<ul style="list-style-type: none"> ● Harness and connectors ● Cooling fan relay ● Cooling fan motor
ENG COOLANT TEMP	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change the engine coolant temperature using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Engine coolant temperature sensor ● Fuel injectors
FUEL PUMP RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Turn the fuel pump relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Fuel pump relay makes the operating sound.	<ul style="list-style-type: none"> ● Harness and connectors ● Fuel pump relay
PURG VOL CONT/V	<ul style="list-style-type: none"> ● Engine: After warming up, run engine at 1,500 rpm. ● Change the EVAP canister purge volume control solenoid valve opening percent using CONSULT-II. 	Engine speed changes according to the opening percent.	<ul style="list-style-type: none"> ● Harness and connectors ● Solenoid valve
V/T ASSIGN ANGLE	<ul style="list-style-type: none"> ● Engine: Return to the original trouble condition ● Change intake valve timing using CONSULT-II. 	If trouble symptom disappears, see CHECK ITEM.	<ul style="list-style-type: none"> ● Harness and connectors ● Intake valve timing control solenoid valve

REAL TIME DIAGNOSIS IN DATA MONITOR MODE (RECORDING VEHICLE DATA)

Description

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

1. "AUTO TRIG" (Automatic trigger):

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBID)]

- The malfunction will be identified on the CONSULT-II screen in real time.
In other words, DTC/1st trip DTC and malfunction item will be displayed if the malfunction is detected by ECM.
At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown at right, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.
The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.

DATA MONITOR	
Recording Data...11%	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
VHCL SPEED SE	XXX km/h

SEF705Y

2. "MANU TRIG" (Manual trigger):

- DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.
DATA MONITOR can be performed continuously even though a malfunction is detected.

SET RECORDING CONDITION
AUTO TRIG
MANU TRIG
TRIGGER POINT
0% 20% 40% 60% 80% 100%
RECORDING SPEED
MIN MAX
/64 /32 /16 /8 /4 /2 FULL

SEF707X

Operation

1. "AUTO TRIG"

- While trying to detect the DTC/1st trip DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.
When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC/1st trip DTC will be displayed. (Refer to "Incident Simulation Tests" in [G1-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .)

2. "MANU TRIG"

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

A

EC

C

D

E

F

G

H


I

J

K

L

M



PBIB0197E

CONSULT-II Reference Value in Data Monitor Mode

EBS00GYG

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

MONITOR ITEM	CONDITION		SPECIFICATION
ENG SPEED	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. 		Almost the same speed as the CONSULT-II value.
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load 	Idle	Approx. 1.1 - 1.5V
		2,500 rpm	Approx. 1.6 - 2.0V
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.5 - 3.5 msec
		2,000 rpm	2.5 - 3.5 msec
A/F ALPHA-B1	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	54% - 155%
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
HO2S1 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Revsing engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Maintaining engine speed at 2,000 rpm
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up 	Revving engine from idle to 3,000 rpm quickly.
VEH SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	11 - 14V
ACCEL SEN1 ACCEL SEN2	<ul style="list-style-type: none"> ● Ignition switch: ON (engine stopped) 	Accelerator pedal: Fully released
		Accelerator pedal: Fully depressed
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) ● Shift lever: D (CVT/CVT model) 1st (M/T model) 	Accelerator pedal: Fully released
		Accelerator pedal: Fully depressed
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 	OFF → ON → OFF
CLSD THL POS	<ul style="list-style-type: none"> ● Ignition switch: ON 	Accelerator pedal: Fully released
		Accelerator pedal: Slightly depressed
AIR COND SIG	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF
		Air conditioner switch: ON (Compressor operates.)
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: P or N (CVT model) Neutral (M/T model)
		Shift lever: Except above
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)
		Steering wheel is turned.
LOAD SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON 	Rear window defogger switch is ON and/or lighting switch is in 2nd.
		Rear window defogger switch is OFF and lighting switch is OFF.
IGNITION SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF → ON 	ON → OFF → ON
HEATER FAN SW	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Heater fan is operating.
		Heater fan is not operating
BRAKE SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: Fully released
		Brake pedal: Slightly depressed
INJ PULSE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle
		2,000 rpm
IGN TIMING	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle
		2,000 rpm
PURG VOL C/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle
		2,000 rpm

TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION	SPECIFICATION
INT/V TIM (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	When revving up to 2,000 rpm quickly
INT/V SOL (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N 	Idle
	<ul style="list-style-type: none"> ● Air conditioner switch: OFF ● No-load 	When revving up to 2,000 rpm quickly
AIR COND RLY	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Air conditioner switch: OFF
		Air conditioner switch: ON (Compressor operates)
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking 	ON
	<ul style="list-style-type: none"> ● Except above conditions 	OFF
THRTL RELAY	<ul style="list-style-type: none"> ● Ignition switch: ON 	ON
COOLING FAN	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine ● Air conditioner switch: OFF 	Engine coolant temperature is 94°C (201°F) or less
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)
		Engine coolant temperature is 100°C (212°F) or more
HO2S1 HTR (B1)	<ul style="list-style-type: none"> ● Engine: After warming up ● Engine speed: Below 3,600 rpm 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,600 rpm 	OFF
HO2S2 HTR (B1)	<ul style="list-style-type: none"> ● Engine speed: Below 3,800 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more] 	ON
	<ul style="list-style-type: none"> ● Engine speed: Above 3,800 rpm 	OFF
I/P PULLY SPD	<ul style="list-style-type: none"> ● Vehicle speed: More than 20 km/h 	Almost the same speed as the CONSULT-II value
VEHICLE SPEED	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value
O2SEN HTR DTY	<ul style="list-style-type: none"> ● Engine coolant temperature when engine started: More than 80°C (176°F) ● Engine speed: below 3,600 rpm 	Approx. 50 %
AC PRESS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Approx. 0V
	<ul style="list-style-type: none"> ● Engine: Idle ● Air conditioner switch: OFF 	1.0 - 4.0V
CAN COMM	<ul style="list-style-type: none"> ● Ignition switch: ON 	OK
CAN CIRC 1		OK
CAN CIRC 2		OK or ONKWN
CAN CIRC 3		OK
CAN CIRC 4		OK
CAN CIRC 5		OK or UNKWN
CAN CIRC 6		OK
CAN CIRC 7		UNKWN

A
EC
C
D
E
F
G
H
I
J
K
L
M


Major Sensor Reference Graph in Data Monitor Mode

The following are the major sensor reference graphs in "DATA MONITOR" mode.

CLSD THL POS, ACCEL SEN 1, THRTL SEN 1

Below is the data for "CLSD THL POS", "ACCEL SEN 1" and "THRTL SEN 1" when depressing the accelerator pedal with the ignition switch "ON" and with selector lever in "D" position (CVT models) or with shift lever in "1st" position (M/T models).


The signal of "ACCEL SEN 1" and "THRTL SEN 1" should rise gradually without any intermittent drop or rise after "CLSD THL POS" is changed from "ON" to "OFF".



ENG SPEED, MAS A/F SE-B1, THRTL SEN 1, HO2S2 (B1), HO2S1 (B1), INJ PULSE-B1

Below is the data for "ENG SPEED", "MAS A/F SE-B1", "THRTL SEN 1", "HO2S2 (B1)", "HO2S1 (B1)" and "INJ PULSE-B1" when revving engine quickly up to 4,800 rpm under no load after warming up engine sufficiently.

Each value is for reference, the exact value may vary.



TROUBLE DIAGNOSIS

[QR (WITHOUT EURO-OB)]

A

EC

C

D

E

F

G

H


I

J

K

L


M




- "THRTL SEN 1" should increase while depressing the accelerator pedal and should decrease while releasing it.



- "HO2S2 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "HO2S1 (B1)" may increase immediately after depressing the accelerator pedal and may decrease after releasing the pedal.



- "INJ PULSE-B1" should increase when depressing the accelerator pedal and should decrease when the pedal is released.

PBIB0668E

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITHOUT EURO-OBD)]

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

PFP:00031

Description

EBS00GYI

The specification (SP) value indicates the tolerance of the value that is displayed in "DATA MONITOR (SPEC)" mode of CONSULT-II during normal operation of the Engine Control System. When the value in "DATA MONITOR (SPEC)" mode is within the SP value, the Engine Control System is confirmed OK. When the value in "DATA MONITOR (SPEC)" mode is NOT within the SP value, the Engine Control System may have one or more malfunctions.

The SP value is used to detect malfunctions that may affect the Engine Control System, but will not light the MIL.

The SP value will be displayed for the following three items:

- B/FUEL SCHDL (The fuel injection pulse width programmed into ECM prior to any learned on board correction)
- A/F ALPHA-B1 (The mean value of air-fuel ratio feedback correction factor per cycle)
- MAS A/F SE-B1 (The signal voltage of the mass air flow sensor)

Testing Condition

EBS00GYJ

- Vehicle driven distance: More than 5,000 km (3,017 miles)
- Barometric pressure: 98.3 - 104.3 kPa (0.983 - 1.043 bar, 1.003 - 1.064 kg/cm², 14.25 - 15.12 psi)
- Atmospheric temperature: 20 - 30°C (68 - 86°F)
- Engine coolant temperature: 75 - 95°C (167 - 203°F)
- Transmission: Warmed-up*¹
- Electrical load: Not applied*²
- Engine speed: Idle

*1: For CVT models with CONSULT-II, after the engine is warmed up to normal operating temperature, drive vehicle until "FLUID TEMP SE" (CVT fluid temperature sensor signal) indicates more than 60°C (140°F). For CVT models without CONSULT-II and M/T models, after the engine is warmed up to normal operating temperature, drive vehicle for 5 minutes.

*2: Rear window defogger switch, air conditioner switch, lighting switch are "OFF". Steering wheel is straight ahead.


Inspection Procedure

EBS00GYK

NOTE:

Perform "DATA MONITOR (SPEC)" mode in maximum scale display.

1. Perform [EC-1457, "Basic Inspection"](#).
2. Confirm that the testing conditions indicated above are met.
3. Select "B/FUEL SCHDL", "A/F ALPHA-B1" and "MAS A/F SE-B1" in "DATA MONITOR (SPEC)" mode with CONSULT-II.
4. Make sure that monitor items are within the SP value.
5. If NG, go to [EC-1495, "Diagnostic Procedure"](#).




TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITHOUT EURO-OBD)]

Diagnostic Procedure


EBS00GYL



SEF613ZD

TROUBLE DIAGNOSIS - SPECIFICATION VALUE


[QR (WITHOUT EURO-OBD)]



SEF768Z

TROUBLE DIAGNOSIS - SPECIFICATION VALUE

[QR (WITHOUT EURO-OBD)]



A
EC
C
D
E
F
G
H
I
J
K
L
M

SEF615ZA

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

[QR (WITHOUT EURO-OBD)]

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

Description

EBS00GYM

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on (1st trip) DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

Common I/I Report Situations

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0" or "[1t]".
III	The symptom described by the customer does not recur.
IV	(1st trip) DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for PXXXX does not indicate the problem area.

Diagnostic Procedure

EBS00GYM

1. INSPECTION START

Erase (1st trip) DTCs. Refer to [EC-1446, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests", "Ground Inspection".

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "Incident Simulation Tests".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITHOUT EURO-OBD)]


POWER SUPPLY CIRCUIT FOR ECM

PPF:24110



Wiring Diagram

EBS00GYO

EC-MAIN-01



REFER TO THE FOLLOWING.
M1 - FUSE BLOCK-JUNCTION BOX (J/B)



POWER SUPPLY CIRCUIT FOR ECM

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
1 115 116	B B B	ECM ground	[Engine is running] ● Idle speed	Engine ground
109	B/R	Ignition switch	[Ignition switch "OFF"]	0V
			[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For 5 seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● 5 seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00GYP

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

- Yes >> GO TO 8.
- No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF" and then "ON".
2. Check voltage between ECM terminal 109 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair harness or connectors.

POWER SUPPLY CIRCUIT FOR ECM [QR (WITHOUT EURO-OBD)]

4. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.


OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM POWER SUPPLY CIRCUIT-II

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminals 1 and 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 10A fuse
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

POWER SUPPLY CIRCUIT FOR ECM

[QR (WITHOUT EURO-OBDD)]

7. CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 111 and ECM relay terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG


OK >> Go to [EC-1672. "IGNITION SIGNAL"](#) .

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Stop engine and wait at least 10 seconds.
2. Turn ignition switch "ON" and then "OFF".
3. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop approximately 0V.



OK or NG


OK >> GO TO 13.

NG (Battery voltage does not exist.)>>GO TO 9.

NG (Battery voltage exists for more than a few seconds.)>>GO TO 11.

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Disconnect ECM relay.




2. Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 11.

NG >> GO TO 10.



POWER SUPPLY CIRCUIT FOR ECM

[QR (WITHOUT EURO-OBD)]

10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM relay and 10A fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK ECM POWER SUPPLY CIRCUIT-V

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 119, 120 and ECM relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK ECM RELAY

Refer to [EC-1504, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace ECM relay.

13. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT-II

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals 1, 115, 116 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 14.

NG >> Repair open circuit or short to power in harness or connectors.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> **INSPECTION END**

POWER SUPPLY CIRCUIT FOR ECM [QR (WITHOUT EURO-OBD)]


EBS00GYQ

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITHOUT EURO-OBD)]

DTC U1000, U1001 CAN COMMUNICATION LINE

PFP:23710

Description

EBS00GYR

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

EBS00GYS

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	● ECM cannot communicate to other control unit.	● Harness or connectors (CAN communication line is open or shorted)
U1001 1001		● ECM cannot communicate for more than the specified time.	

DTC Confirmation Procedure

EBS00GYT

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-1507, "Diagnostic Procedure"](#) .



DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00GYU

EC-CAN-01

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- : DATA LINE



MBWA0038E

DTC U1000, U1001 CAN COMMUNICATION LINE [QR (WITHOUT EURO-OBDD)]

EBS00GYV

Diagnostic Procedure

1. INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

CVT Models

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	OK	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0180E

M/T Models

OK data		NG data	
DATA MONITOR		DATA MONITOR	
MONITOR	NO DTC	MONITOR	NO DTC
CAN COMM	OK	CAN COMM	OK
CAN CIRC 1	OK	CAN CIRC 1	UNKWN
CAN CIRC 2	UNKWN	CAN CIRC 2	UNKWN
CAN CIRC 3	UNKWN	CAN CIRC 3	UNKWN
CAN CIRC 4	OK	CAN CIRC 4	UNKWN
CAN CIRC 5	UNKWN	CAN CIRC 5	UNKWN
CAN CIRC 6	OK	CAN CIRC 6	UNKWN
CAN CIRC 7	UNKWN	CAN CIRC 7	UNKWN

MBIB0179E

>> Go to [LAN-8, "CAN COMMUNICATION"](#) .

DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]


DTC P0102, P0103 MAF SENSOR

PF2:22680

Component Description

EBS00GYW

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GYX

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS A/F SE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: N ● No-load Idle	Approx. 1.1 - 1.5V
	2,500 rpm	Approx. 1.6 - 2.0V
CAL/LD VALUE	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	10% - 35%
	2,500 rpm	10% - 35%
MASS AIRFLOW	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load Idle	1.0 - 4.0 g-m/s
	2,500 rpm	4.0 - 10.0 g-m/s

On Board Diagnosis Logic

EBS00GYX

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0102 0102	Mass air flow sensor circuit low input	An excessively low voltage from the sensor is sent to ECM when engine is running.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Intake air leaks ● Mass air flow sensor
P0103 0103	Mass air flow sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Mass air flow sensor

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Mass air flow sensor circuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.

DTC Confirmation Procedure

EBS00GYZ

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]

PROCEDURE FOR DTC P0102

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and wait 5 seconds at most.
4. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Start engine and wait 5 seconds at most.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .

PROCEDURE FOR DTC P0103

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Start engine and wait at least 5 seconds.
6. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 5 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .
If DTC is not detected, go to next step.
5. Turn ignition switch "OFF" and wait at least 10 seconds.
6. Start engine and wait at least 5 seconds.
7. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
8. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
9. If DTC is detected, go to [EC-1511, "Diagnostic Procedure"](#) .




DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]

EBS00GZ0

EC-MAFS-01

Wiring Diagram



MBWA0004E

DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
50	B	Mass air flow sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.1 - 1.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm.	1.6 - 2.0V
54	W	Sensor's ground (Mass air flow sensor)	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00GZ1

1. INSPECTION START

Which malfunction (P0102 or P0103) is duplicated?

P0102 or P0103

- P0102 >> GO TO 2.
- P0103 >> GO TO 3.

2. CHECK INTAKE SYSTEM

Check the following for connection.

- Air duct
- Vacuum hoses
- Intake air passage between air duct to intake manifold


OK or NG

- OK >> GO TO 3.
- NG >> Reconnect the parts.

3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.




DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]

4. CHECK MAF SENSOR POWER SUPPLY CIRCUIT

1. Disconnect MAF sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between MAF sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair harness or connectors.

6. CHECK MAF SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between MAF sensor terminal 3 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK MAF SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between MAF sensor terminal 1 and ECM terminal 50. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0102, P0103 MAF SENSOR

[QR (WITHOUT EURO-OBD)]

8. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1513, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace mass air flow sensor.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection MASS AIR FLOW SENSOR


EBS00GZ2

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal 50 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed-up to normal operating temperature.)	1.1 - 1.5
2,500 rpm (Engine is warmed-up to normal operating temperature.)	1.6 - 2.0
Idle to about 4,000 rpm*	1.5 - 2.0 to Approx. 4.0

*: Check for liner voltage rise in response to engine being increased to about 4,000 rpm.

4. If the voltage is out of specification, proceed the following.
 - a. Turn ignition switch "OFF".
 - b. Disconnect mass air flow sensor harness connector and reconnect it again.
 - c. Perform steps 2 and 3 again.
5. If NG, remove mass air flow sensor from air duct. Check hot film for damage or dust.
6. If NG, clean or replace mass air flow sensor.



MBIB0017E

Removal and Installation MASS AIR FLOW SENSOR

EBS00GZ3

Refer to [EM-114, "AIR CLEANER AND AIR DUCT"](#) .

DTC P0117, P0118 ECT SENSOR

[QR (WITHOUT EURO-OBD)]


DTC P0117, P0118 ECT SENSOR

PFP:22630

Component Description

EBS00GZ4


The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic

EBS00GZ5

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble Diagnosis Name	DTC Detecting Condition	Possible Cause
P0117 0117	Engine coolant temperature sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Engine coolant temperature sensor
P0118 0118	Engine coolant temperature sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

FAIL-SAFE MODE

When this malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

DTC P0117, P0118 ECT SENSOR

[QR (WITHOUT EURO-OBD)]

Detected items	Engine operating condition in fail-safe mode	
Engine coolant temperature sensor circuit	Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START". CONSULT-II displays the engine coolant temperature decided by ECM.	
	Condition	Engine coolant temperature decided (CONSULT-II display)
	Just as ignition switch is turned ON or Start	40°C (104°F)
	More than approx. 4 minutes after ignition ON or Start	80°C (176°F)
	Except as shown above	40 - 80°C (104 - 176°F) (Depends on the time)
When the fail-safe system for engine coolant temperature sensor is activated, the cooling fan operates while engine is running.		

DTC Confirmation Procedure

EBS00GZ6

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1517, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Turn ignition switch "ON" and wait at least 5 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1517, "Diagnostic Procedure"](#).




DTC P0117, P0118 ECT SENSOR

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00GZ7

EC-ECTS-01



MBWA0006E

DTC P0117, P0118 ECT SENSOR


[QR (WITHOUT EURO-OBD)]

Diagnostic Procedure

EBS00GZ8

1. CHECK ECT SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature (ECT) sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECT sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK ECT SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ECT sensor terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between engine coolant temperature sensor and ECM
- Harness for open or short between engine coolant temperature sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1518, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace engine coolant temperature sensor.

DTC P0117, P0118 ECT SENSOR

[QR (WITHOUT EURO-OBD)]

5. CHECK INTERMITTENT INCIDENT


Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

EBS00GZ9


1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.



<Reference data>

Engine coolant temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

*: These data are reference values and are measured between ECM terminal 72 (Engine coolant temperature sensor) and ground.



2. If NG, replace engine coolant temperature sensor.

Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

EBS00GZA

Refer to [CO-40, "THERMOSTAT AND WATER CONTROL VALVE"](#) .



DTC P0134 HO2S1

PFP:22690

Component Description

EBS00GZB

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GZC


Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.

On Board Diagnosis Logic

EBS00GZD

Under the condition in which the heated oxygen sensor 1 signal is not input, the ECM circuits will read a continuous approximately 0.3V. Therefore, for this diagnosis, the time that output voltage is within 200 to 400 mV range is monitored, and the diagnosis checks that this time is not inordinately long.



DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0134 0134	Heated oxygen sensor 1 circuit no activity detected	The voltage from the sensor is constantly approx. 0.3V.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Heated oxygen sensor 1

Overall Function Check

Use this procedure to check the overall function of the heated oxygen sensor 1 circuit. During this check, a 1st trip DTC might not be confirmed.

④ WITH CONSULT-II


1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" in "DATA MONITOR" mode with CONSULT-II, and select "HO2S1 (B1)".
3. Hold engine speed at 2,000 rpm under no load.
4. Make sure that the indications do not remain in the range between 0.2V to 0.4V.
5. If NG, go to [EC-1522, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

⊗ WITHOUT CONSULT-II




1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.
 - The voltage does not remain in the range of 0.2 - 0.4V.
4. If NG, go to [EC-1522, "Diagnostic Procedure"](#).



Wiring Diagram

EBS00GZG

EC-HO2S1-01



REFER TO THE FOLLOWING.

E106 - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	PU	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00GZH

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Disconnect heated oxygen sensor 1 harness connector.
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1523, "Component Inspection"](#).

OK or NG

OK >> GO TO 5.

NG >> Replace heated oxygen sensor 1.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#).

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00GZ1

With CONSULT-II



1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.

- "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds. 5 times (cycles) are counted as shown at right.
- "HO2S1 (B1)" voltage goes above 0.6V at least once.
- "HO2S1 (B1)" voltage goes below 0.3V at least once.
- "HO2S1 (B1)" voltage never exceeds 1.0V.



CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 (HO2S1 signal) and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.


- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation HEATED OXYGEN SENSOR 1

EBS00GZJ

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

DTC P0221 TP SENSOR


PF:16119

Component Description

EBS00GZK

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GZL

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1 THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00GZM

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0221 0221	Throttle position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from TP sensor 1 and TP sensor 2.	<ul style="list-style-type: none"> Harness or connector (The TP sensor 1 and 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1 and 2)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

- The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.
- The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.
- So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GZN

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ WITH CONSULT-II

- Turn ignition switch "ON".

DTC P0221 TP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1528, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1528, "Diagnostic Procedure"](#) .

DTC P0221 TP SENSOR




[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00GZO

EC-TPS3-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0127E

DTC P0221 TP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00GZP

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4, ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1530, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00GZQ

1. Reconnect all harness connectors disconnected.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-1440, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GZR

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P0222, P0223 TP SENSOR

[QR (WITHOUT EURO-OBD)]

DTC P0222, P0223 TP SENSOR


PF16119

Component Description

EBS00GZS

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00GZT

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN1	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00GZU

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0222 0222	Throttle position sensor 1 circuit low input	An excessively low voltage from the TP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 1 circuit is open or shorted.) Electric throttle control actuator (TP sensor 1)
P0223 0223	Throttle position sensor 1 circuit high input	An excessively high voltage from the TP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00GZV

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0222, P0223 TP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1534, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1534, "Diagnostic Procedure"](#) .

DTC P0222, P0223 TP SENSOR




[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00GZW

EC-TPS1-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0125E

DTC P0222, P0223 TP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"]	More than 0.36V
			[Ignition switch "ON"]	Less than 4.75V
66	B	Sensors' ground	[Engine is running]	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"]	Less than 4.75V
			[Ignition switch "ON"]	More than 0.36V


Diagnostic Procedure

EBS00GZX

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0222, P0223 TP SENSOR

[QR (WITHOUT EURO-OBD)]

2. CHECK THROTTLE POSITION SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 49 and electric throttle control actuator terminal 4. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1536, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

DTC P0222, P0223 TP SENSOR

[QR (WITHOUT EURO-OBD)]

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00GZY

1. Reconnect all harness connectors disconnected.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-1440, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00GZZ

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P0226 APP SENSOR

PFP:18002


Component Description

EBS00H00

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H01

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1 ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00H02

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0226 0226	Accelerator pedal position sensor circuit range/performance problem	Rationally incorrect voltage is sent to ECM compared with the signals from APP sensor 1 and APP sensor 2.	<ul style="list-style-type: none"> ● Harness or connector (The APP sensor 1 and 2 circuit is open or shorted.) ● Accelerator pedal position sensor 1 and 2

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00H03

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0226 APP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1540, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1540, "Diagnostic Procedure"](#) .







DTC P0226 APP SENSOR

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H04

EC-APPS3-01



MBWA0131E

DTC P0226 APP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00H05

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK APP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminals 1, 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and APP sensor terminal 4, ECM terminal 66 and APP sensor terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor
- Harness for open or short between TCM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK APP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3, ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1543, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT


Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
ACCELERATOR PEDAL POSITION SENSOR

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-1440, "Idle Air Volume Learning"](#) .

Remove and Installation
ACCELERATOR PEDAL

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

DTC P0227, P0228 APP SENSOR

PFP:18002


Component Description

EBS00H08

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H09

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN1	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00H0A

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0227 0227	Accelerator pedal position sensor 1 circuit low input	An excessively low voltage from the APP sensor 1 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 1 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 1)
P0228 0228	Accelerator pedal position sensor 1 circuit high input	An excessively high voltage from the APP sensor 1 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00H0B

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1547, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A

EC

C

D

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1547, "Diagnostic Procedure"](#) .

E

F

G

H

I

J

K

L

M







DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

EBS00H0C

EC-APPS1-01

Wiring Diagram



DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

1. RETIGHTEN GROUND SCREWS

EBS00H0D

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

2. CHECK APP SENSOR 1 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 1 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and APP sensor terminal 4. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor
- Harness for open or short between TCM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

6. CHECK APP SENSOR 1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 106 and APP sensor terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M79, F108
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1549, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00H0E

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P0227, P0228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-1440, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00H0F

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .


DTC P0327, P0328 KS

PFP:22060

Component Description

EBS00H0G

The knock sensor is attached to the cylinder block. It senses engine knocking using a piezoelectric element. A knocking vibration from the cylinder block is sensed as vibrational pressure. This pressure is converted into a voltage signal and sent to the ECM.



EBS00H0H

On Board Diagnosis Logic

The MI will not light for knock sensor malfunction.

DTC No.	Trouble Diagnosis Name	DTC Detected Condition	Possible Cause
P0327 0327	Knock sensor circuit low input	An excessively low voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Knock sensor
P0328 0328	Knock sensor circuit high input	An excessively high voltage from the sensor is sent to ECM.	

DTC Confirmation Procedure

EBS00H0I

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Start engine and run it for at least 5 seconds at idle speed.
3. If 1st trip DTC is detected, go to [EC-1553, "Diagnostic Procedure"](#).





WITHOUT CONSULT-II

1. Start engine and run it for at least 5 seconds at idle speed.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-1553, "Diagnostic Procedure"](#).

Wiring Diagram

EBS00H0J

EC-KS-01



Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
15	W	Knock sensor	[Engine is running] ● Idle speed	Approximately 2.5V

Diagnostic Procedure

EBS00H0K

1. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check resistance between ECM terminal 15 and engine ground. Refer to Wiring Diagram.

NOTE:

It is necessary to use an ohmmeter which can measure more than 10 MΩ.

Resistance: Approximately 530 - 590kΩ [at 20°C (68°F)]

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK KNOCK SENSOR INPUT SIGNAL CIRCUIT-II


1. Disconnect knock sensor harness connector.
2. Check harness continuity between ECM terminal 15 and knock sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK KNOCK SENSOR

Refer to [EC-1554, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Replace knock sensor.

4. CHECK KNOCK SENSOR SHIELD CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between knock sensor terminal 2 and engine ground.

Continuity should exist

2. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection KNOCK SENSOR

EBS00H0L

Check resistance between knock sensor terminal 1 and ground.


NOTE:

It is necessary to use an ohmmeter which can measure more than 10 M Ω .

Resistance: Approximately 530 - 590k Ω [at 20°C (68°F)]

CAUTION:

Do not use any knock sensors that have been dropped or physically damaged. Use only new ones.



EBS00H0M

Removal and Installation KNOCK SENSOR

Refer to [EM-165, "CYLINDER BLOCK"](#) .

DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

DTC P0335 CKP SENSOR (POS)

PFP:23731

Component Description

EBS00H0N

The crankshaft position sensor (POS) is located on the cylinder block rear housing facing the gear teeth (cogs) of the signal plate at the end of the crankshaft. It detects the fluctuation of the engine revolution.


The sensor consists of a permanent magnet and Hall IC.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H0O

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
ENG SPEED.	<ul style="list-style-type: none"> Tachometer: Connect Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

On Board Diagnosis Logic

EBS00H0P

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0335 0335	Crankshaft position sensor (POS) circuit	<ul style="list-style-type: none"> The crankshaft position sensor (POS) signal is not detected by the ECM during the first few seconds of engine cranking. The proper pulse signal from the crankshaft position sensor (POS) is not sent to ECM while the engine is running. The crankshaft position sensor (POS) signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Crankshaft position sensor (POS) Signal plate

DTC Confirmation Procedure

EBS00H0Q

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch ON".

WITH CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-1558, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

⊗ WITHOUT CONSULT-II

1. Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-1558, "Diagnostic Procedure"](#) .




DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H0R

EC-POS-01





DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
13	L	Crankshaft position sensor (POS)	[Engine is running] <ul style="list-style-type: none">● Warm-up condition● Idle speed	Approximately 3V★  PBIB0527E
			[Engine is running] <ul style="list-style-type: none">● Engine speed is 2,000 rpm	Approximately 3V★  PBIB0528E

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00H0S

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

2. CHECK CRANKSHAFT POSITION (CKP) SENSOR (POS) POWER SUPPLY CIRCUIT

1. Disconnect crankshaft position (CKP) sensor (POS) harness connector.




2. Turn ignition switch "ON".
3. Check voltage between CKP sensor (POS) terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between crankshaft position sensor (POS) and ECM
- Harness for open or short between crankshaft position sensor (POS) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CKP SENSOR (POS) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between CKP sensor (POS) terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

5. CHECK CKP SENSOR (POS) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 13 and CKP sensor (POS) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-1560, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace crankshaft position sensor (POS).

7. CHECK GEAR TOOTH

Visually check for chipping signal plate gear tooth.

OK or NG

OK >> GO TO 8.

NG >> Replace the signal plate.

8. CHECK INTERMITTENT INCIDENT


Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection CRANKSHAFT POSITION SENSOR (POS)

EBS00HOT

1. Loosen the fixing bolt of the sensor.
2. Disconnect crankshaft position sensor (POS) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




DTC P0335 CKP SENSOR (POS)

[QR (WITHOUT EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	

6. If NG, replace crankshaft position sensor (POS).



Removal and Installation CRANKSHAFT POSITION SENSOR (POS)

Refer to [EM-165, "CYLINDER BLOCK"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P0340 CMP SENSOR (PHASE)

[QR (WITHOUT EURO-OBD)]

DTC P0340 CMP SENSOR (PHASE)

PFP:23731

Component Description

EBS00H0V

The camshaft position sensor (PHASE) senses the retraction with intake valve camshaft to identify a particular cylinder. The camshaft position sensor (PHASE) senses the piston position.


When the crankshaft position sensor (POS) system becomes inoperative, the camshaft position sensor (PHASE) provides various controls of engine parts instead, utilizing timing of cylinder identification signals.

The sensor consists of a permanent magnet and Hall IC.

When engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.



On Board Diagnosis Logic

EBS00H0W

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0340 0340	Camshaft position sensor (PHASE) circuit	<ul style="list-style-type: none"> The cylinder No. signal is not sent to ECM for the first few seconds during engine cranking. The cylinder No. signal is not set to ECM during engine running. The cylinder No. signal is not in the normal pattern during engine running. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Camshaft position sensor (PHASE) Camshaft (Intake) Starter motor (Refer to SC-22 .) Starting system circuit (Refer to SC-22 .) Dead (Weak) battery

DTC Confirmation Procedure

EBS00H0X

NOTE:


If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10.5V with ignition switch "ON".

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- If 1st trip DTC is detected, go to [EC-1565, "Diagnostic Procedure"](#) .
If 1st trip DTC is not detected, go to next step.
- Maintain engine speed at more than 800 rpm for at least 5 seconds.
- If 1st trip DTC is detected, go to [EC-1565, "Diagnostic Procedure"](#) .



WITHOUT CONSULT-II

- Crank engine for at least 2 seconds and run it for at least 5 seconds at idle speed.
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to [EC-1565, "Diagnostic Procedure"](#) .
If 1st trip DTC is not detected, go to next step.
- Turn ignition switch "OFF" and wait at least 10 seconds.

DTC P0340 CMP SENSOR (PHASE)

[QR (WITHOUT EURO-OBD)]

6. Start engine and maintain engine speed at more than 800 rpm for at least 5 seconds.
7. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
8. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
9. If 1st trip DTC is detected, go to [EC-1565, "Diagnostic Procedure"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M




DTC P0340 CMP SENSOR (PHASE)

[QR (WITHOUT EURO-OBD)]

EBS00H0Y

EC-PHASE-01

Wiring Diagram





MBWA0015E

DTC P0340 CMP SENSOR (PHASE) [QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
14	L	Camshaft position sensor (PHASE)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>1.0 - 4.0V★</p>  <p>PBIB0525E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is 2,000 rpm. 	<p>1.0 - 4.0V★</p>  <p>PBIB0526E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00H0Z

1. CHECK STARTING SYSTEM

Turn ignition switch to "START" position.

Does the engine turn over?

Does the starter motor operate?

Yes or No


Yes >> GO TO 2.

No >> Check starting system. (Refer to [SC-22, "STARTING SYSTEM"](#) .)

2. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 3.




DTC P0340 CMP SENSOR (PHASE)

[QR (WITHOUT EURO-OBD)]

3. CHECK CAMSHAFT POSITION (CMP) SENSOR (PHASE) POWER SUPPLY CIRCUIT

1. Disconnect camshaft position (CMP) sensor (PHASE) harness connector.
2. Turn ignition switch "ON".




3. Check voltage between CMP sensor (PHASE) terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between camshaft position sensor (PHASE) and ECM
- Harness for open or short between camshaft position sensor (PHASE) and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK CMP SENSOR (PHASE) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between CMP sensor (PHASE) terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0340 CMP SENSOR (PHASE) [QR (WITHOUT EURO-OBD)]

6. CHECK CMP SENSOR (PHASE) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 14 and CMP sensor (PHASE) terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground or short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-1567, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace camshaft position sensor (PHASE).

8. CHECK CAMSHAFT (INTAKE)


Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

OK >> GO TO 9.

NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.




9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection CAMSHAFT POSITION SENSOR (PHASE)

1. Loosen the fixing bolt of the sensor.
2. Disconnect camshaft position sensor (PHASE) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.




DTC P0340 CMP SENSOR (PHASE)

[QR (WITHOUT EURO-OBD)]

5. Check resistance as shown in the figure.

Terminal No. (Polarity)	Resistance Ω [at 25°C (77°F)]
3 (+) - 1 (-)	Except 0 or ∞
3 (+) - 2 (-)	
2 (+) - 1 (-)	



Removal and Installation CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EM-133, "CAMSHAFT"](#) .

EBS00H11

DTC P0500 VSS

PFP:32702

Description

EBS00H12

NOTE:

If DTC P0500 is displayed with DTC U1000 or U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1505, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from the ABS actuator and electric unit (control unit) through CAN communication line. The combination meter then sends a signal to the ECM through CAN communication line.

On Board Diagnosis Logic

EBS00H13

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500 0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none"> ● Harness or connectors (The CAN communication line is open or shorted.) ● ABS actuator and electric unit (control unit) ● Wheel sensor ● Combination meter

DTC Confirmation Procedure

EBS00H14

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Steps 1 and 2 may be conducted with the drive wheels lifted in the shop or by driving the vehicle. If a road test is expected to be easier, it is unnecessary to lift the vehicle.

 WITH CONSULT-II

1. Start engine.
2. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
If NG, go to [EC-1570, "Diagnostic Procedure"](#).
If OK, go to following step.
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Warm engine up to normal operating temperature.
5. Maintain the following conditions for at least 60 consecutive seconds.

ENG SPEED	2,000 - 6,000 rpm
COOLAN TEMP/S	More than 70°C (158°F)
B/FUEL SCHDL	4.9 - 31.8 msec
Selector lever	Suitable position
PW/ST SIGNAL	OFF

6. If 1st trip DTC is detected, go to [EC-1570, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
COOLAN TEMP/S	XXX °C
B/FUEL SCHDL	XXX msec
PW/ST SIGNAL	OFF
VHCL SPEED SE	XXX km/h

SEF196Y

Overall Function Check

EBS00H15

Use this procedure to check the overall function of the vehicle speed signal circuit. During this check, a 1st trip DTC might not be confirmed.

 WITHOUT CONSULT-II

1. Lift up drive wheels.
2. Start engine.

3. Read vehicle speed with combination meter.
The vehicle speed indication should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-1570, "Diagnostic Procedure"](#) .

Diagnostic Procedure

EBS00H16

1. CHECK DTC

Refer to [BRC-17, "TROUBLE DIAGNOSIS"](#) (Models without ESP) or [BRC-60, "TROUBLE DIAGNOSIS"](#) (Models with ESP).

OK or NG

OK >> GO TO 2.

NG >> Repair or replace.

2. CHECK COMBINATION METER

Check combination meter function.

Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#) .

>> INSPECTION END


DTC P0550 PSP SENSOR

PF:49763

Component Description

EBS00H17

Power steering pressure (PSP) sensor is installed to the power steering high-pressure tube and detects a power steering load. This sensor is a potentiometer which transforms the power steering load into output voltage, and emits the voltage signal to the ECM. The ECM controls the electric throttle control actuator and adjusts the throttle valve opening angle to increase the engine speed and adjusts the idle speed for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H18

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

On Board Diagnosis Logic

EBS00H19

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0550 0550	Power steering pressure sensor circuit	An excessively low or high voltage from the sensor is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Power steering pressure sensor

DTC Confirmation Procedure

EBS00H1A

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for at least 5 seconds.
4. If 1st trip DTC is detected, go to [EC-1573, "Diagnostic Procedure"](#) .

WITHOUT CONSULT-II

1. Start engine and let it idle for at least 5 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-1573, "Diagnostic Procedure"](#) .



DTC P0550 PSP SENSOR

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H1B

EC-PS/SEN-01



MBWA0032E

DTC P0550 PSP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
12	Y	Power steering pressure sensor	[Engine is running] ● Steering wheel is being turned.	Approximately 3.6V
			[Engine is running] ● Steering wheel is not being turned.	Approximately 0.6V
55	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
65	R	Sensor's power supply (Power steering pressure sensor)	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00H1C

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK PSP SENSOR POWER SUPPLY CIRCUIT

1. Disconnect PSP sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between PSP sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness or connectors.



3. CHECK PSP SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and PSP sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between power steering pressure sensor and ECM
- Harness for open or short between power steering pressure sensor and TCM

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK PSP SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 12 and PSP sensor terminal 2.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK PSP SENSOR

Refer to [EC-1575, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace PSP sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

**Component Inspection
POWER STEERING PRESSURE SENSOR**

EBS00H1D

1. Reconnect all harness connectors disconnected.
2. Start engine and let it idle.
3. Check voltage between ECM terminal 12 and ground under the following conditions.

Condition	Voltage
Steering wheel is being turned fully.	Approximately 3.6V
Steering wheel is not being turned.	Approximately 0.6V




DTC P0605 ECM

PF0:23710

Component Description

EBS00H1E

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



On Board Diagnosis Logic

EBS00H1F

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P0605 0605	Engine control module	A)	ECM calculation function is malfunctioning.	● ECM
		B)	ECM EEPROM system is malfunctioning.	
		C)	ECM self shut-off function is malfunctioning.	

FAIL-SAFE MODE

ECM enters fail-safe mode when malfunction A is detected.

Detected items	Engine operation condition in fail-safe mode
Malfunction A	ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00H1G

Perform "PROCEDURE FOR MALFUNCTION A" first. If the DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION B". If there is no problem on "PROCEDURE FOR MALFUNCTION B", perform "PROCEDURE FOR MALFUNCTION C".


NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).



Without CONSULT-II

1. Turn ignition switch "ON".
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION B

Ⓟ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. If 1st trip DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If 1st trip DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION C

Ⓟ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
4. Repeat step 3 procedure, 32 times.
5. If 1st trip DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Repeat step 2 procedure, 32 times.
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If 1st trip DTC is detected, go to [EC-1578, "Diagnostic Procedure"](#).

A
EC
C
D
E
F
G
H
I
J
K
L
M

Diagnostic Procedure

1. INSPECTION START

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-1576](#) .
5. Is the 1st trip DTC P0605 displayed again?

Without CONSULT-II

1. Turn ignition switch "ON".
2. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-1449](#) .
3. **Perform "DTC Confirmation Procedure"**.
See [EC-1576](#) .
4. Is the 1st trip DTC P0605 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1447](#), "[NATS \(Nissan Anti-theft System\)](#)".
3. Perform [EC-1440](#), "[Accelerator Pedal Released Position Learning](#)".
4. Perform [EC-1440](#), "[Throttle Valve Closed Position Learning](#)".
5. Perform [EC-1440](#), "[Idle Air Volume Learning](#)".

>> **INSPECTION END**

DTC P1065 ECM POWER SUPPLY

[QR (WITHOUT EURO-OBD)]


DTC P1065 ECM POWER SUPPLY

PFP:23710

Component Description

EBS00H11

Battery voltage is supplied to the ECM even when the ignition switch is turned OFF for the ECM memory function of the DTC memory, the air fuel ratio feedback compensation value memory, the idle air volume learning value memory, etc.



On Board Diagnosis Logic

EBS00H1J

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1065 1065	ECM power supply circuit	ECM back up RAM system does not function properly.	<ul style="list-style-type: none">● Harness or connectors [ECM power supply (back-up) circuit is open or shorted.]● ECM

DTC Confirmation Procedure


EBS00H1K

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

④ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. Repeat steps 3 and 4 four times.
6. If 1st trip DTC is detected, go to [EC-1581, "Diagnostic Procedure"](#).



⊗ WITHOUT CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Start engine and let it idle for 1 second.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Repeat steps 2 and 3 four times.
5. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
6. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
7. If 1st trip DTC is detected, go to [EC-1581, "Diagnostic Procedure"](#).




DTC P1065 ECM POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H1L

EC-ECM/PW-01



MBWA0040E

DTC P1065 ECM POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00H1M


1. CHECK ECM POWER SUPPLY

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check voltage between ECM terminal 121 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 10A fuse
- Harness for open or short between ECM and battery

>> Repair or replace harness or connectors.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness or connectors.

4. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. **Perform "DTC Confirmation Procedure"**.
See [EC-1579](#) .
5. Is the 1st trip DTC P1065 displayed again?

Without CONSULT-II

1. Turn ignition switch "ON".
2. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-1449](#) .
3. **Perform "DTC Confirmation Procedure"**.
See [EC-1579](#) .
4. Is the 1st trip DTC P1065 displayed again?

Yes or No

Yes >> GO TO 5.

No >> **INSPECTION END**

5. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1447](#), "[NATS \(Nissan Anti-theft System\)](#)".
3. Perform [EC-1440](#), "[Accelerator Pedal Released Position Learning](#)".
4. Perform [EC-1440](#), "[Throttle Valve Closed Position Learning](#)".
5. Perform [EC-1440](#), "[Idle Air Volume Learning](#)".

>> **INSPECTION END**

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QR (WITHOUT EURO-OBDD)]

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR

PFP:16119

Component Description

EBS00H10

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The throttle position sensor detects the throttle valve position, and the opening and closing speed of the throttle valve and feeds the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00H1P

DTC No.	Trouble diagnosis name	DTC detecting condition		Possible cause
P1121 1121	Electric throttle control actuator	A)	Electric throttle control actuator does not function properly due to the return spring malfunction.	● Electric throttle control actuator
		B)	Throttle valve opening angle in fail-safe mode is not in specified range.	
		C)	ECM detect the throttle valve is stuck open. This self-diagnosis has the one trip detection logic.	

FAIL-SAFE MODE

When the malfunction A or B is detected in the two consecutive trips, the ECM enters in fail-safe mode and MI lights up.

When the malfunction C is detected even in the 1st trip, the ECM enters in fail-safe mode and the MI lights up.

Detected items	Engine operating condition in fail-safe mode
Malfunction A	The ECM controls the electric throttle actuator by regulating the throttle opening around the idle position. The engine speed will not rise more than 2,000 rpm.
Malfunction B	ECM controls the electric throttle control actuator by regulating the throttle opening to 20 degrees or less.
Malfunction C	While the vehicle is driving, it slows down gradually by fuel cut. After the vehicle stops, the engine stalls. The engine can restart in "N" or "P" position, and engine speed will not exceed 1,000 rpm or more.

DTC Confirmation Procedure

EBS00H1Q

NOTE:

- Perform "PROCEDURE FOR MALFUNCTION A AND B" first. If the 1st trip DTC cannot be confirmed, perform "PROCEDURE FOR MALFUNCTION C".
- If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR MALFUNCTION A AND B

① With CONSULT-II

1. Turn ignition witch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
4. Turn ignition switch "OFF", wait at least 10 seconds, and then turn "ON".
5. If 1st trip DTC is detected, go to [EC-1584, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.

DTC P1121 ELECTRIC THROTTLE CONTROL ACTUATOR [QR (WITHOUT EURO-OBDD)]

- Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to [EC-1584, "Diagnostic Procedure"](#).

PROCEDURE FOR MALFUNCTION C

① With CONSULT-II

- Turn ignition switch "ON" and wait at least 1 second.
- Select "DATA MONITOR" mode with CONSULT-II.
- Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
- Shift selector lever to "N" or "P" position.
- Start engine and let it idle for 3 seconds.
- If DTC is detected, go to [EC-1584, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

- Turn ignition switch "ON" and wait at least 1 second.
- Shift selector lever to "D" position (CVT), "1st" position (M/T) and wait at least 2 seconds.
- Shift selector lever to "N" or "P" position.
- Start engine and let it idle for the 3 seconds.
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If DTC is detected, go to [EC-1584, "Diagnostic Procedure"](#).

Diagnostic Procedure


EBS00H1R

1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

- Remove the intake air duct.
- Check if a foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 2.
NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

- Replace the electric throttle control actuator.
- Perform [EC-1440, "Throttle Valve Closed Position Learning"](#).
- Perform [EC-1440, "Idle Air Volume Learning"](#).

>> INSPECTION END

Removal and Installation

EBS00HC6

Refer to [EM-116, "INTAKE MANIFOLD"](#).

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBDD)]

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION

PFP:16119

Description

EBS00H1S

NOTE:

If DTC P1122 is displayed with DTC P1121 or 1126, first perform the trouble diagnosis for DTC P1121 or P1126. Refer to [EC-1585](#) or [EC-1592](#).

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc.

The throttle control motor is operated by the ECM and it opens and closes the throttle valve.

The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00H1T

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1122 1122	Electric throttle control performance problem	Electric throttle control function does not operate properly.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is open or shorted.) ● Harness or connectors (Throttle control motor relay circuit is open or shorted.) ● Electric throttle control actuator ● Throttle control motor relay

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00H1U

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

Ⓟ WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1587, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

ⓧ WITHOUT CONSULT-II




1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-1587, "Diagnostic Procedure"](#).

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H1V

EC-ETC1-01





MBWA0132E

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
4	BR	Throttle control motor (Close)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	0 - 14V★  PBIB0534E
5	Y	Throttle control motor (Open)	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	0 - 14V★  PBIB0533E
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00H1W

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBID)]


2. CHECK THROTTLE CONTROL MOTOR RELAY SIGNAL CIRCUIT

Check voltage between ECM terminal 3 and ground under the following conditions with CONSULT-II or tester.

Ignition switch	Voltage
OFF	Approximately 0V
ON	Battery voltage (11 - 14V)


OK or NG

- OK >> GO TO 10.
- NG >> GO TO 3.



3. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect throttle control motor relay.




3. Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair or replace harness or connectors.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBD)]

5. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair or replace harness or connectors.

9. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-1591, "Component Inspection"](#) .

OK or NG


- OK >> GO TO 13.
- NG >> Replace throttle control motor relay.

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBDD)]

10. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals. Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG


- OK >> GO TO 11.
- NG >> Repair or replace.

11. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Remove the intake air duct.
2. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

- OK >> GO TO 12.
- NG >> Remove the foreign matter and clean the electric throttle control actuator inside.



12. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-1591, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 13.
- NG >> GO TO 14.

13. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 14.
- NG >> Repair or replace harness or connectors.

14. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

DTC P1122 ELECTRIC THROTTLE CONTROL FUNCTION [QR (WITHOUT EURO-OBID)]


EBS00H1X

Component Inspection THROTTLE CONTROL MOTOR RELAY

1. Apply 12V direct current between relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.




THROTTLE CONTROL MOTOR

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-1440, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00H1Y

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBD)]

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY

PFP:16119

Component Description

EBS00H1Z

Power supply for the Throttle Control motor is provided to the ECM via throttle control motor relay. The throttle control motor relay is ON/OFF controlled by the ECM. When the ignition switch is turned ON, the ECM sends an ON signal to throttle control motor relay and battery voltage is provided to the ECM. When the ignition switch is turned OFF, the ECM sends an OFF signal to throttle control motor relay and battery voltage is not provided to the ECM.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H20

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL RELAY	● Ignition switch: ON	ON

On Board Diagnosis Logic

EBS00H21

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1124 1124	Throttle control motor relay circuit short	ECM detect the throttle control motor relay is stuck ON.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is shorted.) ● Throttle control motor relay
P1126 1126	Throttle control motor relay circuit open	ECM detects a voltage of power source for throttle control motor is excessively low. This self-diagnosis has the one trip detection logic.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor relay circuit is open.) ● Throttle control motor relay

FAIL-SAFE MODE

When the DTC P1124 is detected in the two consecutive trips, the ECM enters fail-safe mode and MI lights up. When the DTC P1126 is detected even in the 1st trip, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00H22

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

PROCEDURE FOR DTC P1124

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

④ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-1595, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II

1. Turn ignition switch "ON" and wait at least 1 second.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBD)]

2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. If 1st trip DTC is detected, go to [EC-1595, "Diagnostic Procedure"](#) .

PROCEDURE FOR DTC P1126

④ With CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1595, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ Without CONSULT-II




1. Turn ignition switch "ON" and wait at least 2 second.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-1595, "Diagnostic Procedure"](#) .

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H23

EC-ETC2-01



MBWA0133E

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBDD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
3	R	Throttle control motor relay power supply	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
104	OR	Throttle control motor relay	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"]	0 - 1.0V

Diagnostic Procedure

EBS00H24

1. CHECK THROTTLE CONTROL MOTOR RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect throttle control motor relay.




- Check voltage between throttle control motor relay terminals 2, 5 and ground.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Harness for open or short between throttle control motor relay and fuse

>> Repair or replace harness or connectors.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBDD)]

3. CHECK THROTTLE CONTROL MOTOR RELAY INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 3 and throttle control motor relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and throttle control motor relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE CONTROL MOTOR RELAY OUTPUT SIGNAL CIRCUIT

1. Check continuity between ECM terminal 104 and throttle control motor relay terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and throttle control motor relay

>> Repair or replace harness or connectors.

7. CHECK THROTTLE CONTROL MOTOR RELAY

Refer to [EC-1596, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Replace throttle control motor relay.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection THROTTLE CONTROL MOTOR RELAY


1. Apply 12V direct current between relay terminals 1 and 2.

DTC P1124, P1126 THROTTLE CONTROL MOTOR RELAY [QR (WITHOUT EURO-OBD)]

2. Check continuity between relay terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

3. If NG, replace throttle control motor relay.



A
EC
C
D
E
F
G
H
I
J
K
L
M

DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITHOUT EURO-OBD)]

DTC P1128 THROTTLE CONTROL MOTOR

PFP:16119

Component Description

EBS00H26

The throttle control motor is operated by the ECM and it opens and closes the throttle valve. The current opening angle of the throttle valve is detected by the throttle position sensor and it provides feedback to the ECM to control the throttle control motor to make the throttle valve opening angle properly in response to driving condition.

On Board Diagnosis Logic

EBS00H27

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1128 1128	Throttle control motor circuit short	ECM detects short both circuits between ECM and throttle control motor.	<ul style="list-style-type: none"> ● Harness or connectors (Throttle control motor circuit is shorted.) ● Electric throttle control actuator (Throttle control motor)

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00H28

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 5 seconds.
4. If DTC is detected, go to [EC-1600, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITHOUT CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 second.
2. Start engine and let it idle for 5 seconds.
3. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
4. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
5. If DTC is detected, go to [EC-1600, "Diagnostic Procedure"](#) .



DTC P1128 THROTTLE CONTROL MOTOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
4	BR	Throttle control motor (Close)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is releasing 	<p>0 - 14V★</p>  <p>PBIB0534E</p>
5	Y	Throttle control motor (Open)	<p>[Ignition switch "ON"]</p> <ul style="list-style-type: none"> ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal is depressing 	<p>0 - 14V★</p>  <p>PBIB0533E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00H2A

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1128 THROTTLE CONTROL MOTOR [QR (WITHOUT EURO-OBD)]

2. CHECK THROTTLE CONTROL MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch "OFF".
2. Disconnect electric throttle control actuator harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between the following terminals.
Refer to Wiring Diagram.

Electric throttle control actuator terminal	ECM terminal	Continuity
3	4	Should exist
	5	Should not exist
6	4	Should not exist
	5	Should exist



5. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace.

3. CHECK THROTTLE CONTROL MOTOR

Refer to [EC-1601, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace harness or connectors.

5. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END


Component Inspection THROTTLE CONTROL MOTOR

EBS00H2B

1. Disconnect electric throttle control actuator harness connector.
2. Check resistance between terminals 3 and 6.

Resistance: Approximately 1 - 15 Ω [at 25 °C (77°F)]

3. If NG, replace electric throttle control actuator and go to next step.
4. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
5. Perform [EC-1440, "Idle Air Volume Learning"](#) .



PBIB0095E

DTC P1128 THROTTLE CONTROL MOTOR
[QR (WITHOUT EURO-OBD)]

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00H2C

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

DTC P1217 ENGINE OVER TEMPERATURE

PF0:00000

System Description

EBS00H2D

NOTE:

If DTC P1217 is displayed with DTC U1000, U1001, first perform the trouble diagnosis for DTC U1000, U1001. Refer to [EC-1505, "DTC U1000, U1001 CAN COMMUNICATION LINE"](#).

COOLING FAN CONTROL


Sensor	Input Signal to ECM	ECM function	Actuator
Vehicle speed signal	Vehicle speed*1	Cooling fan control	Cooling fan relay(s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal*1		
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*2		
Battery	Battery voltage*2		
Refrigerant pressure sensor	Refrigerant pressure		

*1: These signals are sent to ECM through CAN communication line.

*2: ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, refrigerant pressure, and air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF]. The ECM sends a cooling fan control signal to the smart entrance control unit through CAN communication line, and the smart entrance control unit controls cooling fan relays.

OPERATION



CONSULT-II Reference Value in Data Monitor Mode

EBS00H2E

Specification data are reference values.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
AIR COND SIG	● Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
COOLING FAN	● Engine: After warming up, idle the engine ● Air conditioner switch: OFF	Engine coolant temperature is 99°C (210°F) or less	OFF
		Engine coolant temperature is 100°C (212°F) or more	ON

On Board Diagnosis Logic

EBS00H2F

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise. When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1217 1217	Engine over temperature (Overheat)	<ul style="list-style-type: none"> ● Cooling fan does not operate properly (Overheat). ● Cooling fan system does not operate properly (Overheat). ● Engine coolant was not added to the system using the proper filling method. 	<ul style="list-style-type: none"> ● Harness or connectors (The cooling fan circuit is open or shorted.) ● Cooling fan ● Radiator hose ● Radiator ● Radiator cap ● Water pump ● Thermostat <p>For more information, refer to EC-1618, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant. Refer to [MA-20](#), "Changing Engine Coolant". Also, replace the engine oil. Refer to [MA-24](#), "Changing Engine Oil".

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-18](#), "Engine Coolant Mixture Ratio".
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

EBS00H2G

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1608](#), "Diagnostic Procedure".
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1608](#), "Diagnostic Procedure".
3. Turn ignition switch "ON".



SEF621W

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]




4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
5. If the results are NG, go to [EC-1608, "Diagnostic Procedure"](#).

ACTIVE TEST	
COOLING FAN	ON
MONITOR	
COOLANT TEMP/S	XXX °C

MBIB0037E

⊗ WITHOUT CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
 If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1608, "Diagnostic Procedure"](#).
2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1608, "Diagnostic Procedure"](#).
3. Start engine.
Be careful not to overheat engine.
4. Set temperature control lever to full cold position.
5. Turn air conditioner switch "ON".
6. Turn blower fan switch "ON".
7. Run engine at idle for a few minutes with air conditioner operating.
Be careful not to overheat engine.
8. Make sure that cooling fans operates at low speed.
 If NG, go to [EC-1608, "Diagnostic Procedure"](#).
 If OK, go to the following step.
9. Turn ignition switch "OFF".
10. Turn air conditioner switch and blower fan switch "OFF".
11. Disconnect engine coolant temperature sensor harness connector.
12. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
13. Restart engine and make sure that cooling fan operates at higher speed than low speed.
Be careful not to overheat engine.
14. If NG, go to [EC-1608, "Diagnostic Procedure"](#).






DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]




EBS00H2H

Wiring Diagram LHD MODELS

EC-COOL/F-01





REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

RHD MODELS



MBWA0146E

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

EBS00H21

Diagnostic Procedure

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 5.

2. CHECK COOLING FAN LOW SPEED OPERATION

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II and touch "LOW" on the CONSULT-II screen.
3. Make sure that cooling fans-1 and -2 operate at low speed.

OK or NG

- OK >> GO TO 3.
- NG >> Check cooling fan low speed control circuit. (Go to [EC-1612, "PROCEDURE A"](#) .)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLANT TEMP/S	XXX °C

SEF784Z

3. CHECK COOLING FAN HIGH SPEED OPERATION-I

④ With CONSULT-II

1. Touch "HIGH" on the CONSULT-II screen.
2. Make sure that cooling fan-1 operates at higher speed than low speed.

OK or NG

- OK >> GO TO 4.
- NG >> Check cooling fan high speed control circuit-1. (Go to [EC-1614, "PROCEDURE B"](#) .)

ACTIVE TEST	
COOLING FAN	HIGH
MONITOR	
COOLANT TEMP/S	XXX °C

SEF785Z

4. CHECK COOLING FAN HIGH SPEED OPERATION-II

④ With CONSULT-II

Make sure that cooling fan-2 operates at higher speed than low speed.

OK or NG

- OK >> GO TO 8.
- NG >> Check cooling fan high speed control circuit-2. (Go to [EC-1616, "PROCEDURE C"](#) .)

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

5. CHECK COOLING FAN LOW SPEED OPERATION


⊗ Without CONSULT-II

1. Start engine and let it idle.
2. Turn air conditioner switch "ON".
3. Turn blower fan switch "ON".
4. Make sure that cooling fans-1 and -2 operate at low speed.

OK or NG

OK >> GO TO 6.

NG >> Check cooling fan low speed control circuit. (Go to [EC-1612, "PROCEDURE A"](#).)



6. CHECK COOLING FAN HIGH SPEED OPERATION-I


⊗ Without CONSULT-II

1. Turn ignition switch "OFF".
2. Turn air conditioner switch and blower fan switch "OFF".
3. Disconnect engine coolant temperature sensor harness connector.
4. Connect 150Ω resistor to engine coolant temperature sensor harness connector.
5. Restart engine and make sure that cooling fan-1 operates at higher speed than low speed.

OK or NG

OK >> GO TO 7.

NG >> Check cooling fan high speed control circuit-1. (Go to [EC-1614, "PROCEDURE B"](#).)



7. CHECK COOLING FAN HIGH SPEED OPERATION-II

⊗ Without CONSULT-II

Make sure that cooling fan-2 operates higher speed than lower speed.

OK or NG

OK >> GO TO 8.

NG >> Check cooling fan high speed control circuit-2. (Go to [EC-1616, "PROCEDURE C"](#).)

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

8. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 157 kPa (1.57 bar, 1.6 kg/cm² , 23psi)


CAUTION:

Higher than the specified pressure may cause radiator damage.

Pressure should not drop.

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.



9. DETECT MALFUNCTIONING PART

Check the following for leak.

- Hose
- Radiator
- Water pump (Refer to [CO-38, "WATER PUMP"](#) .)

>> Repair or replace.

10. CHECK RADIATOR CAP


Apply pressure to cap with a tester and check radiator cap relief pressure.

Radiator cap relief pressure:

78 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm² , 9 - 14 psi)

OK or NG

- OK >> GO TO 11.
- NG >> Replace radiator cap.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

11. CHECK THERMOSTAT

1. Remove thermostat.
2. Check valve seating condition at normal room temperatures.
It should seat tightly.
3. Check valve opening temperature and valve lift.

Valve opening temperature:

80.5 - 83.5 °C (177 - 182 °F)

Valve lift:

More than 8 mm/95 °C (0.31 in/203 °F)

4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to [CO-40, "THERMOSTAT AND WATER CONTROL VALVE"](#).

OK or NG

OK >> GO TO 12.

NG >> Replace thermostat.

12. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1518, "Component Inspection"](#).

OK or NG


OK >> GO TO 13.

NG >> Replace engine coolant temperature sensor.

13. CHECK MAIN 12 CAUSES

If the cause cannot be isolated, go to [EC-1618, "Main 12 Causes of Overheating"](#).

>> INSPECTION END



A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

PROCEDURE A

1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-1 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

3. CHECK COOLING FAN MOTORS CONTROL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Disconnect cooling fan relay-2 and cooling fan relay-4.
4. Check harness continuity between the following.
 - Cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1
 - Cooling fan motor-1 terminal 2 and cooling fan relay-2 terminal 3
 - Cooling fan motor-1 terminal 2 and cooling fan relay-4 terminal 3
 - Cooling fan relay-2 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan relay-4 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan motor-2 terminal 2 and groundRefer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-1 terminal 1 and smart entrance control unit terminal 33. Refer to Wiring Diagram.


Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-1 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK COOLING FAN RELAY-1, -2 AND 4

Refer to [EC-1619, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan relay.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

7. CHECK COOLING FAN MOTORS-1 AND -2

Refer to [EC-1619, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace cooling fan motors.

8. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace smart entrance control unit.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

PROCEDURE B

1. CHECK COOLING FAN RELAY GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-2 and cooling fan relay-4.
3. Check harness continuity between cooling fan relay-2 terminal 5 and ground, cooling fan relay-4 terminal 5 and ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 2.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-2 terminal 2 and smart entrance control unit terminal 32, cooling fan relay-4 terminal 2 and smart entrance control unit terminal 32. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-2 and smart entrance control unit
- Harness for open or short between cooling fan relay-4 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COOLING FAN RELAYS-2 AND -4

Refer to [EC-1619, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace cooling fan relays.

5. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace smart entrance control unit.

6. CHECK INTERMITTENT INCIDENT

Perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

A

EC

C

D

E

F

G

H

I

J

K

L

M


DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

PROCEDURE C

1. CHECK COOLING FAN MOTOR-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-3.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-3 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-3 and fuse
- Harness for open or short between cooling fan relay-3 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-2 harness connector.
3. Check harness continuity between cooling fan relay-3 terminal 5 and cooling fan motor-2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 4.
- NG >> Repair open circuit or short to power in harness or connectors.



DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

4. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR SHORT TO GROUND

Check harness continuity between cooling fan relay-3 terminal 5 or cooling fan motor-2 terminal 1 and ground. Refer to Wiring Diagram.

Continuity should not exist.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Cooling fan relays-2 and -4 (Refer to [EC-1619, "Component Inspection"](#))
- Harness for short to ground between cooling fan relay-2 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-3 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-4 and cooling fan motor-2

>> Repair or replace.

6. CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-3 terminal 1 and smart entrance control unit terminal 32. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-3 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK COOLING FAN RELAY-3

Refer to [EC-1619, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace cooling fan relay.

9. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace smart entrance control unit.

DTC P1217 ENGINE OVER TEMPERATURE

[QR (WITHOUT EURO-OBD)]

10. CHECK INTERMITTENT INCIDENT

Perform [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Main 12 Causes of Overheating

EBS00H2J

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked condenser ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-18, "Engine Coolant Mixture Ratio" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See CO-29, "LEVEL CHECK" .
	4	● Radiator cap	● Pressure tester	59 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm ² , 9 - 14 psi) (Limit)	See MA-22, "CHECKING RADIATOR CAP" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See CO-29, "LEAK CHECK" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-40, "THERMOSTAT AND WATER CONTROL VALVE" , and CO-31, "RADIATOR" .
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See trouble diagnosis for DTC P1217 (EC-1603) .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See MA-20, "Changing Engine Coolant" .
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-29, "LEVEL CHECK" .
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See EM-152, "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-165, "CYLINDER BLOCK" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.

For more information, refer to [CO-25, "OVERHEATING CAUSE ANALYSIS"](#) .

DTC P1217 ENGINE OVER TEMPERATURE


[QR (WITHOUT EURO-OBD)]

EBS00H2K

Component Inspection COOLING FAN RELAY-1 AND -3

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



COOLING FAN RELAY-2 AND -4

Check continuity between terminals 3 and 4, 3 and 5 under the following conditions.


Conditions	Terminals	Continuity
12V direct current supply between terminals 1 and 2	3 and 4	No
	3 and 5	Yes
No current supply	3 and 4	Yes
	3 and 5	No



COOLING FAN MOTOR-1 AND -2

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(+)	(-)
Cooling fan motor	1	2



DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

DTC P1223, P1224 TP SENSOR


PFP:16119

Component Description

EBS00H2L

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H2M

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
THRTL SEN2	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) 	Accelerator pedal: Fully released More than 0.36V
	<ul style="list-style-type: none"> Shift lever: D (CVT model) 1st (M/T model) 	Accelerator pedal: Fully depressed Less than 4.75V

On Board Diagnosis Logic

EBS00H2N

These self-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1223 1223	Throttle position sensor 2 circuit low input	An excessively low voltage from the TP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> Harness or connectors (The TP sensor 2 circuit is open or shorted.) Electric throttle control actuator (TP sensor 2)
P1224 1224	Throttle position sensor 2 circuit high input	An excessively high voltage from the TP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of the throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00H2O

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

Ⓜ WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1623, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A
EC
C
D
E
F
G
H
I
J
K
L
M

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1623, "Diagnostic Procedure"](#) .




DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H2P

EC-TPS2-01



MBWA0126E

DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Throttle position sensor power supply	[Ignition switch "ON"]	Approximately 5V
49	W	Throttle position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	More than 0.36V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	Less than 4.75V
66	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
68	R	Throttle position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully released	Less than 4.75V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT model) ● Shift lever position is "1st" (M/T model) ● Accelerator pedal fully depressed	More than 0.36V


Diagnostic Procedure

EBS00H2Q

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

2. CHECK THROTTLE POSITION SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



3. CHECK THROTTLE POSITION SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and electric throttle control actuator terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK THROTTLE POSITION SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 68 and electric throttle control actuator terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1625, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

DTC P1223, P1224 TP SENSOR

[QR (WITHOUT EURO-OBD)]

6. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection THROTTLE POSITION SENSOR

EBS00H2R

1. Reconnect all harness connectors disconnected.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Turn ignition switch "ON".
4. Set selector lever to "D" position (CVT models) or "1st" position (M/T models).
5. Check voltage between ECM terminals 49 (TP sensor 1 signal), 68 (TP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
49 (Throttle position sensor 1)	Fully released	More than 0.36V
	Fully depressed	Less than 4.75V
68 (Throttle position sensor 2)	Fully released	Less than 4.75V
	Fully depressed	More than 0.36V

6. If NG, replace electric throttle control actuator and go to the next step.
7. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
8. Perform [EC-1440, "Idle Air Volume Learning"](#) .



Remove and Installation ELECTRIC THROTTLE CONTROL ACTUATOR

EBS00H2S

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1225 TP SENSOR


PFP:16119

Component Description

EBS00H2T

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00H2U

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1225 1225	Closed throttle position learning performance problem	Closed throttle position learning value is excessively low.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00H2V

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

④ WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 10 seconds.
- Turn ignition switch "ON".
- If 1st trip DTC is detected, go to [EC-1627, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

- Turn ignition switch "ON".
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to [EC-1627, "Diagnostic Procedure"](#).


Diagnostic Procedure**1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY**

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1226 TP SENSOR


PF16119

Component Description

EBS00H2Y

Electric Throttle Control Actuator consists of throttle control motor, throttle position sensor, etc. The throttle position sensor responds to the throttle valve movement.

The throttle position sensor has the two sensors. These sensors are a kind of potentiometers which transform the throttle valve position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the throttle valve and feed the voltage signals to the ECM. The ECM judges the current opening angle of the throttle valve from these signals and the ECM controls the throttle control motor to make the throttle valve opening angle properly in response to driving condition.



On Board Diagnosis Logic

EBS00H2Z

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1226 1226	Closed throttle position learning performance problem	Closed throttle position learning is not performed successfully, repeatedly.	<ul style="list-style-type: none"> Electric throttle control actuator (TP sensor 1 and 2)

DTC Confirmation Procedure

EBS00H30

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 10 seconds.
- Turn ignition switch "ON".
- Repeat steps 3 and 4, 32 times.
- If 1st trip DTC is detected, go to [EC-1629, "Diagnostic Procedure"](#).

The screenshot shows a window titled 'DATA MONITOR'. Inside, there are two columns: 'MONITOR' and 'NO DTC'. Under 'MONITOR', it displays 'ENG SPEED' and 'XXX rpm'. The 'NO DTC' column is empty. The bottom right corner of the window is labeled 'SEF058Y'.

WITHOUT CONSULT-II

- Turn ignition switch "ON".
- Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
- Repeat step 2, 32 times.
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- If 1st trip DTC is detected, go to [EC-1629, "Diagnostic Procedure"](#).

Diagnostic Procedure

EBS00H31


1. CHECK ELECTRIC THROTTLE CONTROL ACTUATOR VISUALLY

1. Turn ignition switch "OFF".
2. Remove the intake air duct.
3. Check if foreign matter is caught between the throttle valve and the housing.

OK or NG

OK >> GO TO 2.

NG >> Remove the foreign matter and clean the electric throttle control actuator inside.

**2. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR**

1. Replace the electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

**Remove and Installation
ELECTRIC THROTTLE CONTROL ACTUATOR**

EBS00H32

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

DTC P1227, P1228 APP SENSOR

PFP:18002


Component Description

EBS00H33

The accelerator pedal position sensor is installed on the upper end of the accelerator pedal assembly. The sensor detects the accelerator position and sends a signal to the ECM.

Accelerator pedal position sensor has two sensors. These sensors are a kind of potentiometers which transform the accelerator pedal position into output voltage, and emit the voltage signal to the ECM. In addition, these sensors detect the opening and closing speed of the accelerator pedal and feed the voltage signals to the ECM. The ECM judges the current opening angle of the accelerator pedal from these signals and controls the throttle control motor based on these signals.

Idle position of the accelerator pedal is determined by the ECM receiving the signal from the accelerator pedal position sensor. The ECM uses this signal for the engine operation such as fuel cut.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H34

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
ACCEL SEN2	● Ignition switch: ON (engine stopped)	Accelerator pedal: Fully released	0.35 - 0.67V
		Accelerator pedal: Fully depressed	More than 3.9V
CLSD THL POS	● Ignition switch: ON	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

On Board Diagnosis Logic

EBS00H35

These half-diagnoses have the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1227 1227	Accelerator pedal position sensor 2 circuit low input	An excessively low voltage from the APP sensor 2 is sent to ECM.	<ul style="list-style-type: none"> ● Harness or connectors (The APP sensor 2 circuit is open or shorted.) ● Accelerator pedal position sensor (Accelerator pedal position sensor 2)
P1228 1228	Accelerator pedal position sensor 2 circuit high input	An excessively high voltage from the APP sensor 2 is sent to ECM.	

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operating condition in fail-safe mode

The ECM controls the electric throttle control actuator in regulating the throttle opening in order for the idle position to be within +10 degrees.

The ECM regulates the opening speed of throttle valve to be slower than the normal condition.

So, the acceleration will be poor.

DTC Confirmation Procedure

EBS00H36

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

WITH CONSULT-II

1. Turn ignition switch "ON".

DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1633, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

A

EC

C

D

E

F

G

H

I

J

K

L

M

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1633, "Diagnostic Procedure"](#) .







DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

EBS00H37

EC-APPS2-01

Wiring Diagram



MBWA0130E

DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
45	R	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
47	G	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
66	B	Sensor's ground	[Ignition switch "ON"] ● Warm-up condition ● Idle speed	Approximately 0V
98	LG	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.175 - 0.335V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 1.95V
106	L	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully released	0.35 - 0.67V
			[Ignition switch "ON"] ● Shift lever position is "D" (CVT models) ● Shift lever position is "1st" (M/T models) ● Accelerator pedal fully depressed	More than 3.9V


Diagnostic Procedure

EBS00H38

1. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.




DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

2. CHECK APP SENSOR 2 POWER SUPPLY CIRCUIT

1. Disconnect accelerator pedal position (APP) sensor harness connector.
2. Turn ignition switch "ON".




3. Check voltage between APP sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK APP SENSOR 2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 66 and APP sensor terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

6. CHECK APP SENSOR 2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 98 and APP sensor terminal 6.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and accelerator pedal position sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK APP SENSOR

Refer to [EC-1635, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> GO TO 9.

9. REPLACE APP SENSOR

1. Replace the accelerator pedal position sensor.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00H39

1. Reconnect all harness connectors disconnected.
2. Turn ignition switch "ON".
3. Check voltage between ECM terminals 106 (APP sensor 1 signal), 98 (APP sensor 2 signal) and engine ground under the following conditions.

Terminal	Accelerator pedal	Voltage
106 (Accelerator pedal position sensor 1)	Fully released	0.35 - 0.67V
	Fully depressed	More than 3.9V
98 (Accelerator pedal position sensor 2)	Fully released	0.175 - 0.335V
	Fully depressed	More than 1.95V



DTC P1227, P1228 APP SENSOR

[QR (WITHOUT EURO-OBD)]

4. If NG, replace accelerator pedal assembly and go to the next step.
5. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
6. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
7. Perform [EC-1440, "Idle Air Volume Learning"](#) .

Remove and Installation ACCELERATOR PEDAL

EBS00H3A

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P1229 SENSOR POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

DTC P1229 SENSOR POWER SUPPLY

PPF:16119

On Board Diagnosis Logic

EBS00H3B

This self-diagnosis has the one trip detection logic.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1229 1229	Sensor power supply circuit short	ECM detects a voltage of power source for sensor is excessively low or high.	<ul style="list-style-type: none">● Harness or connectors (The TP sensor 1 and 2 circuit is shorted.) (APP sensor 2 circuit is shorted.)● Electric throttle control actuator (TP sensor 1 and 2)● Accelerator pedal position sensor (APP sensor 2)● ECM pin terminal

FAIL-SAFE MODE

When the malfunction is detected, the ECM enters in fail-safe mode and the MI lights up.

Engine operation condition in fail-safe mode

ECM stops the electric throttle control actuator control, throttle valve is maintained at a fixed opening (approx. 5 degrees) by the return spring.

DTC Confirmation Procedure

EBS00H3C

NOTE:

If "DTC Confirmation Procedure" has been previously conducted, always turn ignition switch "OFF" and wait at least 10 seconds before conducting the next test.

TESTING CONDITION:

Before performing the following procedure, confirm that battery voltage is more than 10V at idle.

④ WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and let it idle for 1 second.
4. If DTC is detected, go to [EC-1639, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

⊗ WITHOUT CONSULT-II

1. Start engine and let it idle for 1 seconds.
2. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
3. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
4. If DTC is detected, go to [EC-1639, "Diagnostic Procedure"](#) .




DTC P1229 SENSOR POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H3D

EC-SEN/PW-01



MBWA0128E

DTC P1229 SENSOR POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
47	G	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V


Diagnostic Procedure

EBS00H3E

1. RETIGHTEN GROUND SCREWS


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK THROTTLE POSITION SENSOR POWER SUPPLY CIRCUIT

1. Disconnect electric throttle control actuator harness connector.
2. Turn ignition switch "ON".




3. Check voltage between electric throttle control actuator terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 6.
NG >> GO TO 3.



DTC P1229 SENSOR POWER SUPPLY

[QR (WITHOUT EURO-OBD)]

3. CHECK SENSOR POWER SUPPLY CIRCUITS FOR SHORT

Check the following.

- Harness for short to power and short to ground between following terminals.

ECM terminal	Sensor terminals	Reference Wiring Diagram
47	Electric throttle control actuator terminal 1	EC-1638
	Accelerator pedal position sensor terminal 1	EC-1632

- ECM pin terminal.

OK or NG

OK >> GO TO 4.

NG >> Repair short to ground or short to power in harness or connectors.

4. CHECK ACCELERATOR PEDAL POSITON SENSOR

Refer to [EC-1635, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> GO TO 5.

5. REPLACE ACCELERATOR PEDAL POSITION SENSOR

1. Replace accelerator pedal position sensor.
2. Perform [EC-1440, "Accelerator Pedal Released Position Learning"](#) .
3. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
4. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

6. CHECK THROTTLE POSITION SENSOR

Refer to [EC-1530, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> GO TO 6.

7. REPLACE ELECTRIC THROTTLE CONTROL ACTUATOR

1. Replace electric throttle control actuator.
2. Perform [EC-1440, "Throttle Valve Closed Position Learning"](#) .
3. Perform [EC-1440, "Idle Air Volume Learning"](#) .

>> INSPECTION END

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

DTC P1805 BRAKE SWITCH

[QR (WITHOUT EURO-OBD)]

DTC P1805 BRAKE SWITCH

PFP:25320

Description

EBS00H3F

Brake switch signal is applied to the ECM through the stop lamp switch when the brake pedal is depressed. This signal is used mainly to decrease the engine speed when the vehicle is driving.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H3G

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
BRAKE SW	● Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON

On Board Diagnosis Logic

EBS00H3H

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1805 1805	Brake switch	A brake switch signal is not sent to ECM for an extremely long time while the vehicle is driving.	<ul style="list-style-type: none">● Harness or connectors (Stop lamp switch circuit is open or shorted.)● Stop lamp switch

DTC Confirmation Procedure

EBS00H3I

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal for at least 5 seconds.
3. Erase the DTC with CONSULT-II.
4. Select "DATA MONITOR" mode with CONSULT-II.
5. If 1st trip DTC is detected, go to [EC-1643, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm

SEF058Y

WITHOUT CONSULT-II

1. Turn ignition switch "ON".
2. Fully depress the brake pedal at least 5 seconds.
3. Erase the "Diagnostic Test Mode II (Self-diagnostic results)" memory. Refer to [EC-1450, "How to Erase Diagnostic Test Mode II \(Self-diagnostic Results\)"](#).
4. Turn ignition switch "OFF", wait at least 10 seconds and then turn "ON".
5. Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
6. If 1st trip DTC is detected, go to [EC-1643, "Diagnostic Procedure"](#).


DTC P1805 BRAKE SWITCH

[QR (WITHOUT EURO-OBD)]

Wiring Diagram



EBS00H3J

EC-BRK/SW-01



REFER TO PG-POWER.

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

(M2) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0034E

DTC P1805 BRAKE SWITCH

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
101	R/G	Stop lamp switch	[Engine is running] ● Brake pedal fully released	Approximately 0V
			[Engine is running] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00H3K

1. CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch "OFF".
2. Check the stop lamp when depressing and releasing the brake pedal.


Brake pedal	Stop lamp
Fully released	Not illuminated
Depressed	Illuminated

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 2.

2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Disconnect stop lamp switch harness connector.




2. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- 15A fuse
- Fuse block (J/B) connector M2
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 101 and stop lamp switch terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness for open or short between ECM and stop lamp switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to [EC-1644, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace stop lamp switch.


7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection STOP LAMP SWITCH

1. Disconnect stop lamp switch harness connector.



EBS00H3L


DTC P1805 BRAKE SWITCH

[QR (WITHOUT EURO-OBD)]

2. Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.

If NG, adjust brake pedal installation, refer to [BR-6, "BRAKE PEDAL"](#) , and perform step 2 again.



A
EC
C
D
E
F
G
H
I
J
K
L
M

HO2S1 HEATER

[QR (WITHOUT EURO-OBD)]

HO2S1 HEATER

PDF:22690

Description SYSTEM DESCRIPTION

EBS00H3M

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE) Crankshaft position sensor (POS)	Engine speed	Heated oxygen sensor 1 heater control	Heated oxygen sensor 1 heater
Engine coolant temperature sensor	Engine coolant temperature		

The ECM performs ON/OFF duty control of the heated oxygen sensor 1 heater corresponding to the engine speed and engine coolant temperature. The duty percent varies with engine coolant temperature when engine is started.

OPERATION

Engine speed rpm	Heated oxygen sensor 1 heater
Above 3,600	OFF
Below 3,600	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00H3M

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S1 HTR (B1)	● Engine: After warming up ● Engine speed: Below 3,600 rpm	ON
	● Engine speed: Above 3,600 rpm	OFF




HO2S1 HEATER

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H30

EC-FRO2-01



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0021E


HO2S1 HEATER

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
24	P/L	Heated oxygen sensor 1 heater	[Engine is running] ● Warm-up condition. ● Engine speed is below 3,600 rpm.	Approximately 7.0V★  PBIB0519E
			[Engine is running] ● Engine speed is above 3,600 rpm.	BATTERY VOLTAGE (11 - 14V)


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00H3P

1. CHECK OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Set tester probe between ECM terminal 24 (HO2S1 heater signal) and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.
Verify that the oscilloscope screen shows the signal waves as shown below.

Conditions	Voltage
At idle	Approximately 7.0V★  PBIB0519E
Engine speed is above 3,600 rpm.	BATTERY VOLTAGE (11 - 14V)




★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

OK or NG

- OK >> INSPECTION END
- NG >> GO TO 2.

2. CHECK HO2S1 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S1 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E106
- 10A fuse
- Harness for open or short between heated oxygen sensor 1 and fuse

>> Repair harness or connectors.

4. CHECK HO2S1 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 24 and HO2S1 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1 HEATER

Refer to [EC-1650, "Component Inspection"](#).

OK or NG

- OK >> GO TO 6.
- NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 1 HEATER

EBS00H3Q


1. Check resistance between HO2S1 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	$\infty \Omega$
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 1.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation
HEATED OXYGEN SENSOR 1

EBS00H3R

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#) .

HO2S2 HEATER

[QR (WITHOUT EURO-OBD)]

HO2S2 HEATER

PFP:226A0

Description SYSTEM DESCRIPTION

EBS00H3S

Sensor	Input Signal to ECM	ECM function	Actuator
Camshaft position sensor (PHASE)	Engine speed	Heated oxygen sensor 2 heater control	Heated oxygen sensor 2 heater
Crankshaft position sensor (POS)			

The ECM performs ON/OFF control of the heated oxygen sensor 2 heater corresponding to the engine speed.

OPERATION

Engine speed rpm	Heated oxygen sensor 2 heater
Above 3,800	OFF
Below 3,800	ON

CONSULT-II Reference Value in Data Monitor Mode

EBS00H3T

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
HO2S2 HTR (B1)	● Engine speed: Below 3,800 rpm [After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more]	ON
	● Engine speed: Above 3,800 rpm	OFF




HO2S2 HEATER

[QR (WITHOUT EURO-OBD)]

EBS00H3U

EC-RRO2-01

Wiring Diagram



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0023E

HO2S2 HEATER

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
2	R/W	Heated oxygen sensor 2 heater	[Engine is running] <ul style="list-style-type: none"> Engine speed is below 3,800 rpm. After driving for 2 minutes at a speed of 70 km/h (43 MPH) or more. 	0 - 1.0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> Engine stopped [Engine is running] <ul style="list-style-type: none"> Engine speed is above 3,800 rpm. 	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure

EBS00H3V


1. CHECK OVERALL FUNCTION

1. Stop engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set voltmeter probes between ECM terminal 2 (HO2S2 heater signal) and ground.
4. Check the voltage under the following conditions.

Conditions	Voltage
At idle	0 - 1V
Engine speed is above 3,600 rpm.	Battery voltage


OK or NG

- OK >> **INSPECTION END**
- NG >> **GO TO 2.**



2. CHECK HO2S2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Turn ignition switch "ON".




4. Check voltage between HO2S2 terminal 4 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Fuse block (J/B) connector E106
- 10A fuse
- Harness for open or short between heated oxygen sensor 2 and fuse

>> Repair harness or connectors.

4. CHECK HO2S2 OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 2 and HO2S2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 2 HEATER

Refer to [EC-1655, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
 NG >> Replace heated oxygen sensor 2.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection
HEATED OXYGEN SENSOR 2 HEATER

EBS00H3W


1. Check resistance between HO2S2 terminals as follows.

Terminal No.	Resistance
1 and 4	2.3 - 4.3 Ω at 25°C (77°F)
2 and 1, 3, 4	∞ Ω
3 and 1, 2, 4	(Continuity should not exist)

2. If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



EBS00H3X

Removal and Installation
HEATED OXYGEN SENSOR 2


Refer to [EX-3, "EXHAUST SYSTEM"](#) .

IAT SENSOR

Component Description

The intake air temperature sensor is built into mass air flow sensor. The sensor detects intake air temperature and transmits a signal to the ECM.


The temperature sensing unit uses a thermistor which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.



<Reference data>

Intake air temperature °C (°F)	Voltage* V	Resistance kΩ
-10 (14)	4.43	7.9 - 9.3
25 (77)	3.32	1.9 - 2.1
80 (176)	1.23	0.31 - 0.37

*: These data are reference values and are measured between ECM terminal 34 (Intake air temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

IAT SENSOR


[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H3Z




EC-IATSEN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



(F14)

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



Diagnostic Procedure


1. CHECK OVERALL FUNCTION

1. Turn ignition switch "ON".
2. Check voltage between ECM terminal 34 and ground with CONSULT-II or tester.

Voltage: 0.04 - 4.84V


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK INTAKE AIR TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect mass air flow sensor (intake air temperature sensor is built-into) harness connector.
3. Turn ignition switch "ON".




4. Check voltage between MAF sensor terminal 5 and ground.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness or connectors.



3. CHECK INTAKE AIR TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between MAF sensor terminal 3 and ECM terminal 54. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness or connectors.

4. CHECK INTAKE AIR TEMPERATURE SENSOR

Refer to [EC-1513, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace mass air flow sensor (with intake air temperature sensor).

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END



Component Inspection INTAKE AIR TEMPERATURE SENSOR

EBS00H41

1. Check resistance between mass air flow sensor terminals 3 and 5 under the following conditions.

Intake air temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1

2. If NG, replace mass air flow sensor (with intake air temperature sensor).



Removal and Installation MASS AIR FLOW SENSOR

EBS00H42

Refer to [EM-114, "AIR CLEANER AND AIR DUCT"](#) .



HO2S1

PFP:22690

Component Description

EBS00H43

The heated oxygen sensor 1 is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The heated oxygen sensor 1 has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The heated oxygen sensor 1 signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H44

Specification data are reference values.




MONITOR ITEM	CONDITION		SPECIFICATION
HO2S1 (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ←→ Approx. 0.6 - 1.0V
HO2S1 MNTR (B1)	● Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ←→ RICH Changes more than 5 times during 10 seconds.

Wiring Diagram

EBS00H45

EC-FRO2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
 (E108) - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
35	PU	Heated oxygen sensor 1	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V (Periodically change)
74	B	Sensors' ground	[Engine is running] ● Idle speed	Approximately 0V


Diagnostic Procedure

EBS00H46

1. INSPECTION START

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 2.



2. CHECK OVERALL FUNCTION

With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "HO2S1 MNTR (B1)" in "DATA MONITOR" mode with CONSULT-II.
3. Keep the engine speed at 2,000 rpm under no load, and make sure that the monitors fluctuates between LEAN and RICH more than five times in 10 seconds.

1 time: RICH → LEAN → RICH
2 times: RICH → LEAN → RICH → LEAN → RICH

DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
HO2S1 MNTR (B1)	RICH


SEF820Y

Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Stop engine and wait at least 10 seconds.
3. Set ECM in "Diagnostic test mode - II (Heated oxygen sensor 1 monitor)". Refer to [EC-1449, "HOW TO SWITCH DIAGNOSTIC TEST MODE"](#).
4. Keep the engine speed at 2,000 rpm under no load, and make sure that the MI comes ON more than five times in 10 seconds.

OK or NG

OK >> **INSPECTION END**
 NG >> GO TO 3.



3. CHECK HO2S1 GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 1 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S1 terminal 3. Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK HO2S1 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 35 and HO2S1 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 35 or HO2S1 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK HEATED OXYGEN SENSOR 1

Refer to [EC-1664, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace heated oxygen sensor 1.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 1

EBS00H47

 With CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Select "MANU TRIG" and adjust "TRIGGER POINT" to 100% in "DATA MONITOR" mode with CONSULT-II.
3. Select "HO2S1 (B1)" and "HO2S1 MNTR (B1)".
4. Hold engine speed at 2,000 rpm under no load during the following steps.
5. Touch "RECORD" on CONSULT-II screen.


DATA MONITOR	
MONITOR	NO DTC
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V
COOLAN TEMP/S	XXX °C
HO2S1 (B1)	XXX V
HO2S1 MNTR (B1)	LEAN

SEF646Y

6. Check the following.
 - "HO2S1 MNTR (B1)" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.
5 times (cycles) are counted as shown at right.
 - "HO2S1 (B1)" voltage goes above 0.6V at least once.
 - "HO2S1 (B1)" voltage goes below 0.3V at least once.
 - "HO2S1 (B1)" voltage never exceeds 1.0V.

cycle	1	2	3	4	5	
HO2S1 MNTR (B1)	R	L	R	L	R	L
R means HO2S1 MNTR (B1) indicates RICH						
L means HO2S1 MNTR (B1) indicates LEAN						

SEF217YA

**CAUTION:**

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Set voltmeter probes between ECM terminal 35 [HO2S1 (B1) signal] and engine ground.
3. Check the following with engine speed held at 2,000 rpm constant under no load.


- The voltage fluctuates between 0 to 0.3V and 0.6 to 1.0V more than 5 times within 10 seconds.
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.
- The voltage never exceeds 1.0V.

1 time: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V

2 times: 0 - 0.3V → 0.6 - 1.0V → 0 - 0.3V → 0.6 - 1.0V

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation

HEATED OXYGEN SENSOR 1

EBS00H48

Refer to [EM-121, "EXHAUST MANIFOLD AND THREE WAY CATALYST"](#).

HO2S2

PFP:226A0

Component Description


EBS00H49

The heated oxygen sensor 2, after three way catalyst (manifold), monitors the oxygen level in the exhaust gas on each bank.

Even if switching characteristics of the heated oxygen sensor 1 are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the heated oxygen sensor 2.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the heated oxygen sensor 2 is not used for engine control operation.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H4A

Specification data are reference values.




MONITOR ITEM	CONDITION		SPECIFICATION
HO2S2 (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	● Engine: After warming up	Reving engine from idle to 3,000 rpm quickly.	LEAN ↔ RICH

Wiring Diagram

EBS00H4B

EC-RRO2-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
(E108) - FUSE BLOCK-JUNCTION BOX (J/B)

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
16	W/Y	Heated oxygen sensor 2	[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm.	0 - Approximately 1.0V
74	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

Diagnostic Procedure

EBS00H4C


1. CHECK OVERALL FUNCTION-I

1. Start engine and drive the vehicle at over 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle and keep the engine running.
3. Set voltmeter probes between ECM terminal 16 (HO2S2 signal) and ground.
4. Check the voltage while revving up to 4,000 rpm under no load at least 10 times. (Depress and release the accelerator pedal as quickly as possible.)

The voltage does not remain in the range of 0.2 -0.4V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.



2. CHECK OVERALL FUNCTION-II

Keep engine at idle for 10 minutes, then check the voltage between ECM terminal 16 and ground, or check voltage when coasting 80 km/h (50 MPH) in 3rd gear (M/T) or "D" position (CVT).

The voltage does not remain in the range of 0.2 -0.4V


OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 3.

3. RETIGHTEN GROUND SCREWS

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.

>> GO TO 4.



4. CHECK HO2S2 GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect heated oxygen sensor 2 harness connector.
3. Disconnect ECM harness connector.
4. Check harness continuity between ECM terminal 74 and HO2S2 terminal 3.
Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



5. CHECK HO2S2 INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 16 and HO2S2 terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Check harness continuity between ECM terminal 16 or HO2S2 terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should not exist.

3. Also check harness for short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK HEATED OXYGEN SENSOR 2

Refer to [EC-1669, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace heated oxygen sensor 2.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection HEATED OXYGEN SENSOR 2

EBS00H4D

With CONSULT-II


1. Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
2. Stop vehicle with engine running.

- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "HO2S2 (B1)" as the monitor item with CONSULT-II.

ACTIVE TEST	
FUEL INJECTION	25 %
MONITOR	
ENG SPEED	XXX rpm
HO2S1 (B1)	XXX V
HO2S2 (B1)	XXX V
HO2S1 MNTR (B1)	RICH
HO2S2 MNTR (B1)	RICH

SEF662Y

- Check "HO2S2 (B1)" at idle speed when adjusting "FUEL INJECTION" to $\pm 25\%$.



"HO2S2 (B1)" should be above 0.68V at least once when the "FUEL INJECTION" is +25%.
 "HO2S2 (B1)" should be below 0.50V at least once when the "FUEL INJECTION" is -25%.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.

⊗ Without CONSULT-II

- Start engine and drive vehicle at a speed of more than 70 km/h (43 MPH) for 2 consecutive minutes.
- Stop vehicle with engine running.
- Set voltmeter probes between ECM terminal 16 [HO2S2 (B1) signal] and engine ground.
- Check the voltage when revving up to 4,000 rpm under no load at least 10 times.

(Depress and release accelerator pedal as soon as possible.)
The voltage should be above 0.68V at least once during this procedure.

If the voltage is above 0.68V at step 4, step 5 is not necessary.


- Keep vehicle idling for 10 minutes, then check voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in "D" position (CVT), 3rd gear position (M/T).

The voltage should be below 0.50V at least once during this procedure.

- If NG, replace heated oxygen sensor 2.

CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner tool J-43897-18 or J-43897-12 and approved anti-seize lubricant.



Removal and Installation
HEATED OXYGEN SENSOR 2

EBS00H4E

Refer to [EX-3, "EXHAUST SYSTEM"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

IGNITION SIGNAL


PFP:22448

Component Description

IGNITION COIL & POWER TRANSISTOR

EBS00H4F

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.





IGNITION SIGNAL

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H4G

EC-IGNSYS-01



MBWA0029E

IGNITION SIGNAL

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.


TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
111	W/G	ECM relay (Self shut-off)	[Engine is running] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	0 - 1.0V
			[Ignition switch "OFF"] ● More than a few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
119 120	W/R W/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
121	W/L	Power supply for ECM (Buck-up)	[Ignition switch "OFF"]	BATTERY VOLTAGE (11 - 14V)

IGNITION SIGNAL


[QR (WITHOUT EURO-OBD)]

EC-IGNSYS-02

— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



1 2 3 F26, F28, F29, F30
 GY GY GY GY



MBWA0030E



IGNITION SIGNAL

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
60 61 79 80	L/Y Y/R GY/L PU/G	Ignition signal No. 3 Ignition signal No. 1 Ignition signal No. 4 Ignition signal No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 0.1V★</p>  <p>PBIB0521E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm. 	<p>0 - 0.2V★</p>  <p>PBIB0522E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00H4H

1. CHECK ENGINE START

Turn ignition switch "OFF", and restart engine.

Is engine running?

Yes or No

Yes (With CONSULT-II)>>GO TO 2.

Yes (Without CONSULT-II)>>GO TO 3.

No >> GO TO 4.

2. CHECK OVERALL FUNCTION

④ **With CONSULT-II**

1. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.

2. Make sure that each circuit produces a momentary engine speed drop.

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 12.


ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E


3. CHECK OVERALL FUNCTION

⊗ Without CONSULT-II

1. Let engine idle.
2. Read the voltage signal between ECM terminals 60, 61, 79, 80 and ground with an oscilloscope.
3. Verify that the oscilloscope screen shows the signal wave as shown below.



PBIB0521E



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 12.


4. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals 119, 120 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
 NG >> Go to [EC-1499, "POWER SUPPLY CIRCUIT FOR ECM"](#).




5. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Turn ignition switch "ON".
4. Check voltage between condenser terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 10.
 NG >> GO TO 6.



6. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-III

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.
3. Check harness continuity between ECM relay terminal 7 and condenser terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-IV


Check voltage between ECM relay terminal 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.



8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair or replace harness or connectors.

9. CHECK ECM RELAY

Refer to [EC-1680, "Component Inspection"](#).

OK or NG

OK >> GO TO 17.

NG >> Replace ECM relay.

10. CHECK CONDENSER GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check harness continuity between condenser terminal 2 and ground.
Refer to Wiring diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 11.

NG >> Repair open circuit or short to power in harness or connector.

11. CHECK CONDENSER


Refer to [EC-1680, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 12.
- NG >> Replace condenser.

12. CHECK IGNITION COIL POWER SUPPLY CIRCUIT-V

1. Turn ignition switch "OFF".
2. Reconnect all harness connectors disconnected.
3. Disconnect ignition coil harness connector.
4. Turn ignition switch "ON".




5. Check voltage between ignition coil terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.



13. DETECT MALFUNCTIONING PART

Check harness for open or short between ignition coil and ECM relay.

>> Repair or replace harness or connectors.

14. CHECK IGNITION COIL GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ignition coil terminal 2 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 15.
- NG >> Repair open circuit or short to power in harness or connectors.

15. CHECK IGNITION COIL OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals 60, 61, 79, 80 and ignition coil terminal 3. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 16.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

16. CHECK IGNITION COIL WITH POWER TRANSISTOR

Refer to [EC-1680, "Component Inspection"](#) .

OK or NG

OK >> GO TO 17.

NG >> Replace ignition coil with power transistor.

17. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection ECM RELAY

EBS00H41

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No


3. If NG, replace ECM relay.



CONDENSER

1. Turn ignition switch "OFF".
2. Disconnect condenser harness connector.
3. Check resistance between condenser terminals 1 and 2.

Resistance: Above 1 MΩ at 25°C (77°F)



IGNITION COIL WITH POWER TRANSISTOR


1. Turn ignition switch "OFF".
2. Disconnect ignition coil harness connector.

IGNITION SIGNAL

[QR (WITHOUT EURO-OBD)]

3. Check resistance between ignition coil terminals as follows.

Terminal No.	Resistance Ω [at 25°C (77°F)]
2 and 3	Except 0 or ∞
1 and 2	Except 0
1 and 3	



EBS00H4J

Removal and Installation IGNITION COIL WITH POWER TRANSISTOR

Refer to [EM-126, "IGNITION COIL"](#) .

A
EC
C
D
E
F
G
H
I
J
K
L
M

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

PF14920

Description SYSTEM DESCRIPTION

EBS00H4K

Sensor	Input Signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*1	EVAP canister purge flow control	EVAP canister purge volume control solenoid valve
Mass air flow sensor	Amount of intake air		
Engine coolant temperature sensor	Engine coolant temperature		
Battery	Battery voltage*1		
Throttle position sensor	Throttle position		
Accelerator pedal position sensor	Closed throttle position		
Heated oxygen sensors 1	Density of oxygen in exhaust gas (Mixture ratio feedback signal)		
Vehicle speed signal*2	Vehicle speed		


*1: ECM determines the start signal status by the signals of engine speed and battery voltage.

*2: This signal is sent to the ECM through CAN communication line.

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control solenoid valve changes to control the flow rate. The EVAP canister purge volume control solenoid valve repeats ON/OFF operation according to the signal sent from the ECM. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

COMPONENT DESCRIPTION

The EVAP canister purge volume control solenoid valve uses a ON/OFF duty to control the flow rate of fuel vapor from the EVAP canister. The EVAP canister purge volume control solenoid valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of fuel vapor that will flow through the valve.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H4L

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL CV	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	0%
		2,000 rpm	20 - 30%




EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H4M

EC-PRGVLV-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



REFER TO THE FOLLOWING.
E106 -FUSE BLOCK-JUNCTION
 BOX (J/B)



MBWA0025E

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
19	P	EVAP canister purge volume control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right;">PBIB0050E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Engine speed is about 2,000 rpm (More than 100 seconds after starting engine) 	<p>Approximately 10V★</p>  <p style="text-align: right;">PBIB0520E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

EBS00H4N

Diagnostic Procedure

1. CHECK OVERALL FUNCTION

With CONSULT-II


1. Turn ignition switch "OFF".
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Turn ignition switch "ON", and select "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II.
4. Start engine and let it idle.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

5. Change the valve opening percentage with touching "Qu" or "Qd" on CONSULT-II screen, and check for vacuum existence at the EVAP purge hose under the following conditions.


Conditions	Vacuum
At idle	Should not exist.
Engine speed is about 2,000 rpm.	Should exist.



Without CONSULT-II

1. Turn ignition switch "OFF".
2. Disconnect the EVAP purge hose connected to the EVAP canister.
3. Start engine and let it idle for at least 80 seconds.
4. Check for vacuum existence at the EVAP purge hose under the following conditions.

Conditions	Vacuum
At idle	Should not exist.
Engine speed is about 2,000 rpm.	Should exist.



OK or NG

- OK >> GO TO 2.
- NG >> GO TO 3.

2. CHECK EVAP CANISTER

Refer to [EC-1688, "Component Inspection"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> Replace EVAP canister.

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

3. CHECK EVAP PURGE LINE


Check EVAP purge line (pipe, rubber tube, fuel tank and EVAP canister) for cracks or improper connection. Refer to [EC-1724, "EVAPORATIVE EMISSION LINE DRAWING"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or reconnect the hose.

4. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EVAP canister purge volume control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EVAP canister purge volume control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between EVAP canister purge volume control solenoid valve and ECM

>> Repair harness or connectors.

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

6. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 19 and EVAP canister purge volume control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK (With CONSULT-II)>>GO TO 7.

OK (Without CONSULT-II)>>GO TO 8.

NG >> Repair open circuit or short to ground and short to power in harness or connectors.

7. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE OPERATION

 **With CONSULT-II**

1. Reconnect all harness connectors disconnected.
2. Start engine.
3. Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that engine speed varies according to the valve opening.

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

ACTIVE TEST	
PURG VOL CONT/V	XXX %
MONITOR	
ENG SPEED	XXX rpm
A/F ALPHA-B1	XXX %
HO2S1 MNTR (B1)	LEAN

PBIB0569E

8. CHECK EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-1688, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace EVAP canister purge volume control solenoid valve.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE [QR (WITHOUT EURO-OBD)]

EBS00H40


Component Inspection

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

④ With CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.


Condition (PURG VOL CONT/V value)	Air passage continuity between A and B
100.0%	Yes
0.0%	No



⊗ Without CONSULT-II

Check air passage continuity of EVAP canister purge volume control solenoid valve under the following conditions.

Condition	Air passage continuity between A and B
12V direct current supply between terminals 1 and 2	Yes
No supply	No



Removal and Installation

EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

EBS00H4P

Refer to [EM-116, "INTAKE MANIFOLD"](#) .

IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

IVT CONTROL SOLENOID VALVE


PFP:23796

Description SYSTEM DESCRIPTION

EBS00H9N

Sensor	Input signal to ECM	ECM function	Actuator
Crankshaft position sensor (POS)	Engine speed	Intake valve timing control	Intake valve timing control solenoid valve
Camshaft position sensor (PHASE)			
Engine coolant temperature sensor	Engine coolant temperature		
Vehicle speed signal*	Vehicle speed		

*: This signal is sent to the ECM through CAN communication line.



PBIB0540E

This mechanism hydraulically controls cam phases continuously with the fixed operating angle of the intake valve.

The ECM receives signals such as crankshaft position, camshaft position, engine speed, and engine coolant temperature. Then, the ECM sends ON/OFF pulse duty signals to the intake valve timing control solenoid valve depending on driving status. This makes it possible to control the shut/open timing of the intake valve to increase engine torque in low/mid speed range and output in high-speed range.

COMPONENT DESCRIPTION


Intake valve timing control solenoid valve is activated by ON/OFF pulse duty (ratio) signals from the ECM.

The intake valve timing control solenoid valve changes the oil amount and direction of flow through intake valve timing control unit or stops oil flow.

The longer pulse width advances valve angle.

The shorter pulse width retards valve angle.

When ON and OFF pulse widths become equal, the solenoid valve stops oil pressure flow to fix the intake valve angle at the control position.



EBS00H4R

CONSULT-II Reference Value in Data Monitor Mode

Specification data are reference values.

IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

MONITOR ITEM	CONDITION		SPECIFICATION
INT/V SOL (B1)	<ul style="list-style-type: none">● Engine: After warming up● Shift lever: N● Air conditioner switch: OFF● No-load	Idle	0% - 2%
		When revving engine up to 2,000 rpm quickly	Approx. 0% - 50%




IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H4S

EC-IVC/V-01



MBWA0026E



IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
62	Y	Intake valve timing control solenoid valve	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)</p>  <p style="text-align: right; font-size: small;">MBIB0052E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● When revving engine up to 2,000 rpm quickly 	<p>Approximately 4V - BATTERY VOLTAGE (11 - 14V)★</p>  <p style="text-align: right; font-size: small;">PBIB0532E</p>


★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


Diagnostic Procedure

EBS00H4T

1. CHECK OVERALL FUNCTION CHECK

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF" and wait at least 10 seconds.
3. Turn ignition switch "ON".
4. Set the tester probe between ECM terminals 62 (IVT control solenoid valve signal) and ground.
5. Start engine and let it idle.
6. Check the voltage under the following conditions.
Verify that the oscilloscope screen shows the signal wave as shown below.

Conditions	Voltage
At idle	BATTERY VOLTAGE (11 - 14V)
When revving engine up to 2,000 rpm quickly	Approximately 4V - BATTERY VOLTAGE (11 - 14V)★  <p style="text-align: right; font-size: small;">PBIB0532E</p>



★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

OK or NG


- OK >> **INSPECTION END**
- NG >> **GO TO 2.**

IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect intake valve timing control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between intake valve timing control solenoid valve terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTION PART

Check harness for open or short between intake valve timing control solenoid valve and ECM relay.

>> Repair or replace harness or connectors.

4. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 62 and intake valve timing control solenoid valve terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK INTAKE VALVE TIMING CONTROL SOLENOID VALVE

Refer to [EC-1694, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace intake valve timing control solenoid valve.

IVT CONTROL SOLENOID VALVE

[QR (WITHOUT EURO-OBD)]

6. CHECK CRANKSHAFT POSITION SENSOR (POS)

Refer to [EC-1560, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Replace crankshaft position sensor (POS).

7. CHECK CAMSHAFT POSITION SENSOR (PHASE)

Refer to [EC-1567, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace camshaft position sensor (PHASE).


8. CHECK CAMSHAFT (INTAKE)

Check the following.

- Accumulation of debris to the signal plate of camshaft rear end
- Chipping signal plate of camshaft rear end

OK or NG

- OK >> GO TO 9.
- NG >> Remove debris and clean the signal plate of camshaft rear end or replace camshaft.



9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00H4U

1. Disconnect intake valve timing control solenoid valve harness connector.
2. Check resistance between intake valve timing control solenoid valve terminals 1 and 2 under the following conditions.

Terminals	Resistance
1 and 2	Approximately 8Ω at 20°C (68°F)
1 or 2 and ground	∞Ω (Continuity should not exist)



Removal and Installation INTAKE VALVE TIMING CONTROL SOLENOID VALVE

EBS00H4V

Refer to [EM-143, "TIMING CHAIN"](#) .

PNP SWITCH

[QR (WITHOUT EURO-OBD)]

PNP SWITCH

PFP:32006

Component Description

EBS00H4W

When the shift lever position is "P" (CVT models only) or "N", park/neutral position (PNP) switch is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H4X

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: P or N (CVT model) Neutral (M/T model)	ON
		Shift lever: Except above	OFF

A

EC

C

D

E

F

G

H

I

J

K

L

M




PNP SWITCH

[QR (WITHOUT EURO-OBD)]

EBS00H4Y

EC-PNPSW1-01

Wiring Diagram



MBWA0027E

PNP SWITCH

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
74 (CVT models)	B	Sensors' ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
102	P (CVT) L (M/T)	PNP switch	[Ignition switch "ON"] ● Shift lever position is "P" (CVT models) or "N", "Neutral" (M/T models).	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	CVT models BATTERY VOLTAGE (11 - 14V) M/T models Approximately 5V

Diagnostic Procedure


EBS00H4Z

1. CHECK OVERALL FUNCTION

 **With CONSULT-II**

- Turn ignition switch "ON".
- Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
- Check the "P/N POSI SW" signal under the following conditions.


Selector lever position	P/N POSI SW signal
"P" and "N" position	ON
Except the above position	OFF



 **Without CONSULT-II**

- Turn ignition switch "ON".
- Check voltage between ECM terminal 102 and ground under the following conditions.

Selector lever position	Voltage
"P" and "N" position	Approximately 0V
Except the above position	CVT models: Battery voltage M/T models: Approximately 5V



OK or NG

- OK >> **INSPECTION END**
 NG >> **GO TO 2.**

2. CHECK GROUND CIRCUIT


1. Turn ignition switch "OFF".
2. Disconnect PNP switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and ground.
Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
NG >> GO TO 4.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open and short between PNP switch and ECM (CVT models)
- Harness for open and short between PNP switch and ground (M/T models)

>> Repair open circuit or short to power in harness or connectors.

4. CHECK INPUT SIGNAL CIRCUIT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 102 and PNP switch terminal 1.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK PNP SWITCH

Refer to [CVT-204, "PNP Switch, Stop Lamp Switch and Throttle Position Switch"](#) (CVT models) or [MT-126, "PARK/NEUTRAL POSITION SWITCH"](#) (M/T models).

OK or NG

- OK >> GO TO 6.
NG >> Replace PNP switch.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


INJECTOR CIRCUIT

PFP:16600

Component Description

EBS00H50

The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H51

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
B/FUEL SCHDL	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.5 - 3.5 msec
		2,000 rpm	2.5 - 3.5 msec
INJ PULSE-B1	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: N ● Air conditioner switch: OFF ● No-load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec





INJECTOR CIRCUIT

[QR (WITHOUT EURO-OBD)]

EBS00H52

EC-INJECT-01

Wiring Diagram



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0028E



INJECTOR CIRCUIT

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
22 23 41 42	G/B SB L R/W	Injector No. 3 Injector No. 1 Injector No. 4 Injector No. 2	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0529E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>BATTERY VOLTAGE (11 - 14V)★</p>  <p>PBIB0530E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Diagnostic Procedure

EBS00H53

1. INSPECTION START

Turn ignition switch to "START".

Is any cylinder ignited?

Yes or No

- Yes >> GO TO 2.
- No >> GO TO 3.

2. CHECK OVERALL FUNCTION

④ With CONSULT-II


1. Start engine.
2. Perform "POWER BALANCE" in "ACTIVE TEST" mode with CONSULT-II.
3. Make sure that each circuit produces a momentary engine speed drop.

ACTIVE TEST	
POWER BALANCE	
MONITOR	
ENG SPEED	XXX rpm
MAS A/F SE-B1	XXX V

PBIB0133E

⊗ Without CONSULT-II

1. Start engine.
2. Listen to each injector operating sound.
Clicking noise should be heard.




OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 3.

3. CHECK INJECTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect injector harness connector.
3. Turn ignition switch "ON".




4. Check voltage between injector terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors F24, F81
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between injector and fuse

>> Repair harness or connectors.

5. CHECK INJECTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between injector terminal 2 and ECM terminals 22, 23, 41, 42. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F81, F24
- Harness for open or short between injector and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK INJECTOR

Refer to [EC-1704, "Component Inspection"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace injector.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection INJECTOR

EBS00H54

1. Disconnect injector harness connector.
2. Check resistance between terminals as shown in the figure.

Resistance: 12.1 - 12.9Ω [at 20°C (68°F)]



EBS00H55

Removal and Installation INJECTOR

Refer to [EM-128, "FUEL INJECTOR AND FUEL TUBE"](#) .

FUEL PUMP CIRCUIT

[QR (WITHOUT EURO-OBD)]

FUEL PUMP CIRCUIT

PFPP:17042

Description SYSTEM DESCRIPTION

EBS00H56

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (POS) Camshaft position sensor (PHASE)	Engine speed*	Fuel pump control	Fuel pump relay
Battery	Battery voltage*		


*: ECM determines the start signal status by the signals of engine speed and battery voltage.

The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a engine speed signal from the crankshaft position sensor (POS) and camshaft position sensor (PHASE), it knows that the engine is rotating, and causes the pump to operate. If the engine speed signal is not received when the ignition switch is ON, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 1 second.
Engine running and cranking	Operates.
When engine is stopped	Stops in 1.5 seconds.
Except as shown above	Stops.

COMPONENT DESCRIPTION

A turbine type design fuel pump is used in the fuel tank.



CONSULT-II Reference Value in Data Monitor Mode

EBS00H57

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL PUMP RLY	<ul style="list-style-type: none"> ● For 1 seconds after turning ignition switch ON ● Engine running or cranking 	ON
	<ul style="list-style-type: none"> ● Except above conditions 	OFF


FUEL PUMP CIRCUIT

[QR (WITHOUT EURO-OBD)]


EBS00H58

Wiring Diagram

EC-F/PUMP-01



- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⬡ : LHD MODELS
- ⬢ : RHD MODELS
- ⬤ : WAGON
- *1 20 : ⬡
- 23 : ⬢



REFER TO THE FOLLOWING.

(B1) - FUSE BLOCK-JUNCTION BOX (J/B)

MBWA0031E

FUEL PUMP CIRCUIT

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
113	B/P	Fuel pump relay	[Ignition switch "ON"] ● For 1 seconds after turning ignition switch "ON"	0 - 1.0V
			[Engine is running] [Ignition switch "ON"] ● More than 1 seconds after turning ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)

Diagnostic Procedure


EBS00H59

1. CHECK OVERALL FUNCTION

- Turn ignition switch "ON".
- Pinch fuel feed hose with two fingers.
Fuel pressure pulsation should be felt on the fuel hose for 1 second after ignition switch is turned "ON".


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK FUEL PUMP RELAY POWER SUPPLY CIRCUIT

- Turn ignition switch "OFF".
- Disconnect fuel pump relay.
- Turn ignition switch "ON".




- Check voltage between fuel pump relay terminals 1, 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Fuse block (J/B) connector B1
- 10A fuse
- 15A fuse
- Harness for open or short between fuel pump relay and fuse

>> Repair harness or connectors.

4. CHECK FUEL PUMP POWER SUPPLY AND GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit and fuel pump harness connector.
3. Check harness continuity between fuel pump relay terminal 3 and fuel level sensor unit and fuel pump terminal 5, fuel level sensor unit and fuel pump terminal 3 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors B37, D83 (Wagon)
- Harness for open or short between fuel level sensor unit and fuel pump and fuel pump relay
- Harness for open or short between fuel level sensor unit and fuel pump and body ground

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK FUEL PUMP RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal 113 and fuel pump relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Harness connectors B5, M23 (LHD models)
- Harness connectors B42, M95 (RHD models)
- Harness for open or short between ECM and fuel pump relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL PUMP RELAY

Refer to [EC-1709, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace fuel pump relay.

9. CHECK FUEL PUMP

Refer to [EC-1709, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 10.
- NG >> Replace fuel pump.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection FUEL PUMP RELAY

EBS00H5A

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



FUEL PUMP

1. Disconnect fuel level sensor unit and fuel pump harness connector.
2. Check resistance between fuel level sensor unit and fuel pump terminals 3 and 5.

Resistance: Approximately 1.0Ω [at 25°C (77°F)]



Removal and Installation

FUEL PUMP

EBS00H5B

Refer to [FL-6, "FUEL LEVEL SENSOR UNIT, FUEL FILTER AND FUEL PUMP ASSEMBLY \(EXCEPT YD2DDTi\)"](#).

REFRIGERANT PRESSURE SENSOR

[QR (WITHOUT EURO-OBD)]



REFRIGERANT PRESSURE SENSOR

PFP:92136

Component Description

EBS00H5C

The refrigerant pressure sensor is installed at the liquid tank of the air conditioner system. The sensor uses an electrostatic volume pressure transducer to convert refrigerant pressure to voltage. The voltage signal is sent to ECM, and ECM controls cooling fan system.







REFRIGERANT PRESSURE SENSOR [QR (WITHOUT EURO-OBD)]

Wiring Diagram

EBS00H5D

EC-RP/SEN-01



MBWA0033E

REFRIGERANT PRESSURE SENSOR

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
55	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
46	R	Sensor's power supply (Refrigerant pressure sensor)	[Ignition switch "ON"]	Approximately 5V
69	L	Refrigerant pressure sensor	[Engine is running] ● Warm-up condition ● Both A/C switch and blower switch are "ON". (Compressor operates.)	1.0 - 4.0V

Diagnostic Procedure

EBS00H5E


1. CHECK REFRIGERANT PRESSURE SENSOR OVERALL FUNCTION

1. Start engine and warm it up to normal operating temperature.
2. Turn A/C switch and blower switch "ON".
3. Check voltage between ECM terminal 69 and ground with CONSULT-II or tester.

Voltage: 1.0 - 4.0V

OK or NG

- OK >> **INSPECTION END**
- NG >> **GO TO 2.**




REFRIGERANT PRESSURE SENSOR

[QR (WITHOUT EURO-OBD)]

2. CHECK REFRIGERANT PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn A/C switch and blower switch "OFF".
2. Stop engine.
3. Disconnect refrigerant pressure sensor harness connector.
4. Turn ignition switch "ON".




5. Check voltage between refrigerant pressure sensor terminal 3 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E70, F13 (LHD models)
- Harness connectors E63, F31 (RHD models)
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair harness or connectors.

4. CHECK REFRIGERANT PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal 55 and refrigerant pressure sensor terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 5.

REFRIGERANT PRESSURE SENSOR

[QR (WITHOUT EURO-OBD)]

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor
- Harness for open or short between TCM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK REFRIGERANT PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminal 69 and refrigerant pressure sensor terminal 2.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.

7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between ECM and refrigerant pressure sensor

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace refrigerant pressure sensor.
- NG >> Repair or replace.

Removal and Installation

REFRIGERANT PRESSURE SENSOR

Refer to [ATC-127, "REFRIGERANT LINES"](#) .

A

EC

C

D

E

F

G

H

I

J

K

EBS00H5F

L

M

ELECTRICAL LOAD SIGNAL

[QR (WITHOUT EURO-OBD)]

ELECTRICAL LOAD SIGNAL

PFP:25350

Description

EBS00H5G

The electrical load signals except headlamp switch signal are transferred through the CAN communication line.

CONSULT-II Reference Value in Data Monitor Mode

EBS00H5H

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
LOAD SIGNAL	● Ignition switch: ON	Rear window defogger switch is ON and/or lighting switch is 2nd.	ON
		Rear window defogger switch is OFF and lighting switch is OFF.	OFF

ELECTRICAL LOAD SIGNAL

[QR (WITHOUT EURO-OBD)]




Wiring Diagram

EBS00H51

EC-LOAD-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

- : DETECTABLE LINE FOR DTC
- : NON-DETECTABLE LINE FOR DTC
- ⊖** : CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM
- ⊖** : CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM
- ⊖** : XENON TYPE HEADLAMP



MBWA0147E

ELECTRICAL LOAD SIGNAL

[QR (WITHOUT EURO-OBD)]

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
84	R/Y	Electrical load signal (Headlamp signal)	[Ignition switch "ON"] ● Lighting switch is "2ND" position	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Lighting switch is "OFF"	Approximately 0V

Diagnostic Procedure

EBS00H5J

1. INSPECTION START

Do you have CONSULT-II?

Yes or No

- Yes >> GO TO 2.
No >> GO TO 3.

2. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-I

Ⓟ With CONSULT-II

- Turn ignition switch "ON".
- Connect CONSULT-II and select "DATA MONITOR" mode.
- Select "LOAD SIGNAL" and check indication under the following conditions.

Condition	Indication
Rear window defogger switch "ON"	ON
Rear window defogger switch "OFF"	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 6.

DATA MONITOR	
MONITORING	NO DTC
LOAD SIGNAL	ON

PBIB0103E

3. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II

ⓧ Without CONSULT-II

- Turn ignition switch "ON".
- Turn rear window defogger switch "ON".
- Make sure that rear window defogger system operates normally.

OK or NG

- OK >> GO TO 5.
NG >> GO TO 6.

ELECTRICAL LOAD SIGNAL

[QR (WITHOUT EURO-OBD)]

4. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II


With CONSULT-II

Check "LOAD SIGNAL" indication under the following conditions.

Condition	Indication
Lighting switch "ON" at 2nd position	ON
Lighting switch "OFF"	OFF

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



5. CHECK LOAD SIGNAL CIRCUIT OVERALL FUNCTION-II


Without CONSULT-II

Check voltage between ECM terminal 84 and ground under the following conditions.

Condition	Voltage
Lighting switch "ON" at 2nd position	Battery voltage
Lighting switch "OFF"	Approximately 0V

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 7.



6. CHECK REAR WINDOW DEFOGGER SYSTEM

Refer to [GW-40, "REAR WINDOW DEFOGGER"](#) .

>> **INSPECTION END**

7. CHECK HEADLAMP FUNCTION

1. Turn lighting switch "ON" at 2nd position.
2. Check that headlamps are illuminated.

OK or NG

- OK >> GO TO 8.
- NG >> Refer to [LT-5, "HEADLAMP - CONVENTIONAL TYPE -"](#) , [LT-10, "HEADLAMP - XENON TYPE -"](#) , [LT-18, "HEADLAMP \(WITH DAYTIME\) - CONVENTIONAL TYPE -"](#) or [LT-25, "HEADLAMP \(WITH DAYTIME\) - XENON TYPE -"](#) .

8. CHECK HEADLAMP INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

CONVENTIONAL TYPE HEADLAMP WITHOUT DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect lighting switch harness connector .
4. Check harness continuity between ECM terminal 84 and lighting switch terminal 10.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

CONVENTIONAL TYPE HEADLAMP WITH DAYTIME LIGHT SYSTEM

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect daytime light relay.
4. Check harness continuity between ECM terminal 84 and daytime light relay terminal 3.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

XENON TYPE HEADLAMP

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Disconnect headlamp LH relay.
4. Check harness continuity between ECM terminal 84 and headlamp LH relay terminal 5.
Refer to Wiring Diagram.

Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> GO TO 9.

9. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- harness for open and short between ECM and lighting switch
- harness for open and short between ECM and daytime light relay
- harness for open and short between ECM and headlamp LH relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1498, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

MI & DATA LINK CONNECTORS







[QR (WITHOUT EURO-OBD)]

MI & DATA LINK CONNECTORS

PFP:24814

Wiring Diagram (LHD Models)

EBS00H5K





REFER TO THE FOLLOWING.
 (M1), (M2) - FUSE BLOCK
 - JUNCTION BOX (J/B)

MI & DATA LINK CONNECTORS

[QR (WITHOUT EURO-OBD)]

EBS00H5L

Wiring Diagram (RHD Models)



MBWA0148E

EVAPORATIVE EMISSION SYSTEM


[QR (WITHOUT EURO-OBD)]

EVAPORATIVE EMISSION SYSTEM

PFP:14950

Description SYSTEM DESCRIPTION

EBS00H5M



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.

The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating or when refueling to the fuel tank.



The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating. EVAP canister purge volume control solenoid valve is controlled by ECM. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control solenoid valve is proportionally regulated as the air flow increases.

EVAP canister purge volume control solenoid valve also shuts off the vapor purge line during decelerating and idling.


EVAPORATIVE EMISSION SYSTEM

[QR (WITHOUT EURO-OBD)]

EVAPORATIVE EMISSION LINE DRAWING



View from under the vehicle



NOTE:

Do not use soapy water or any type of solvent while installing vacuum hose or purge hoses.

MBIB0144E

EVAPORATIVE EMISSION SYSTEM

[QR (WITHOUT EURO-OBD)]


EBS00H5N

Component Inspection

EVAP CANISTER


Check EVAP canister as follows:

1. Block port **B** . Orally blow air through port **A** .
Check that air flows freely through port **C** .
2. Block port **A** . Orally blow air through port **B** .
Check that air flows freely through port **C** .




FUEL CHECK VALVE

1. Blow air through connector on fuel tank side.
A considerable resistance should be felt and a portion of air flow should be directed toward the EVAP canister side.
2. Blow air through connector on EVAP canister side.
Air flow should be smoothly directed toward fuel tank side.
3. If fuel check valve is suspected of not properly functioning in steps 1 and 2 above, replace it.



FUEL TANK VACUUM RELIEF VALVE (BUILT INTO FUEL FILLER CAP)

1. Wipe clean valve housing.




2. Check valve opening pressure and vacuum.

Pressure: 15.3 - 20.0 kPa (0.153 - 0.200 bar,
0.156 - 0.204 kg/cm² , 2.22 - 2.90 psi)

Vacuum: -6.0 to -3.4 kPa (-0.060 to -0.034 bar,
-0.061 to -0.035 kg/cm² , -0.87 to -0.49 psi)

3. If out of specification, replace fuel filler cap as an assembly.



EVAP CANISTER PURGE VOLUME CONTROL SOLENOID VALVE

Refer to [EC-1688, "Component Inspection"](#) .

POSITIVE CRANKCASE VENTILATION


[QR (WITHOUT EURO-OBD)]

POSITIVE CRANKCASE VENTILATION

PFP:11810

Description SYSTEM DESCRIPTION


EBS00H50



This system returns blow-by gas to the intake manifold.

The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold. During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. The ventilating air is then drawn from the air inlet tubes into the crankcase. In this process the air passes through the hose connecting air inlet tubes to rocker cover. Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the air inlet tubes under all conditions.



Component Inspection PCV (POSITIVE CRANKCASE VENTILATION) VALVE

EBS00H5P

With engine running at idle, remove PCV valve from rocker cover. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over valve inlet.




POSITIVE CRANKCASE VENTILATION

[QR (WITHOUT EURO-OBD)]

PCV VALVE VENTILATION HOSE

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



A

EC

C

D

E

F

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS) [QR (WITHOUT EURO-OBDD)]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

Fuel Pressure

EBS00H5Q

Fuel pressure at idle	Approximately 350 kPa (3.7kg/cm ² , 51psi)
-----------------------	---

Idle Speed and Ignition Timing

EBS00H5R

Target idle speed	No-load*1 (in "P" or N" position)	M/T: 600±50 rpm CVT: 650±50 rpm
Air conditioner: ON	In "P" or N" position	725 rpm or more
Ignition timing	In "P" or N" position	M/T: 14°±5° BTDC CVT: 15°±5° BTDC

*1: Under the following conditions:

- Air conditioner switch: OFF
- Electric load: OFF (Lights, heater fan & rear window defogger)
- Steering wheel: Kept in straight-ahead position

Calculated Load Value

EBS00H5S

	Calculated load value % (Using CONSULT-II or GST)
At idle	10 - 35
At 2,500 rpm	10 - 35

Mass Air Flow Sensor

EBS00H5T

Supply voltage	Battery voltage (11 - 14V)
Output voltage at idle	1.1 - 1.5*V
Mass air flow (Using CONSULT-II)	1.4 - 4.0 g·m/sec at idle* 4.0 - 10.0 g·m/sec at 2,500 rpm*

*: Engine is warmed up to normal operating temperature and running under no-load.

Intake Air Temperature Sensor

EBS00H5U

Temperature °C (°F)	Resistance kΩ
25 (77)	1.9 - 2.1
80 (176)	0.31 - 0.37

Engine Coolant Temperature Sensor

EBS00H5V

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Heated Oxygen Sensor 1 Heater

EBS00H5W

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Heated Oxygen sensor 2 Heater

EBS00H5X

Resistance [at 25°C (77°F)]	2.3 - 4.3Ω
-----------------------------	------------

Crankshaft Position Sensor (POS)

EBS00H5Y

Refer to [EC-1560, "Component Inspection"](#) .

Camshaft Position Sensor (PHASE)

EBS00H5Z

Refer to [EC-1567, "Component Inspection"](#) .

SERVICE DATA AND SPECIFICATIONS (SDS)
[QR (WITHOUT EURO-OBD)]

Throttle Control Motor

EBS00H60

Resistance [at 25°C (77°F)]	Approximately 1 - 15Ω
-----------------------------	-----------------------

A

Injector

EBS00H61

Resistance [at 20°C (68°F)]	13.5 - 17.5Ω
-----------------------------	--------------

EC

Fuel Pump

EBS00H62

Resistance [at 25°C (77°F)]	Approximately 1.0Ω
-----------------------------	--------------------

C

D

E

F

G

H

I

J

K

L

M

INDEX FOR DTC

[YD]

INDEX FOR DTC

PF0:00024

Alphabetical Index

EBS00DY1

X: Applicable —: Not applicable

Items (CONSULT-II screen terms)	DTC	MI illumination	Reference page
ACCEL POS SENSOR	P0120	×	EC-1802
ACCEL POS SW (F/C)	P1510	×	EC-1876
BATTERY VOLTAGE	P1660	×	EC-1887
CAM POS SEN/CIR	P0340	×	EC-1832
CAN COMM CIRCUIT	U1000	×	EC-1790
COOLANT TEMP SEN	P0115	×	EC-1798
CR PRES SEN	P0190	×	EC-1810
CRANK POS SEN (TDC)	P0335	×	EC-1827
CYL1 INJECTOR	P0201	×	EC-1814
CYL2 INJECTOR	P0202	×	EC-1814
CYL3 INJECTOR	P0203	×	EC-1814
CYL4 INJECTOR	P0204	×	EC-1814
ECM 1	P1606	×	EC-1881
ECM 10	P1107	×	EC-1838
ECM 15	P1621	—	EC-1883
FUEL LEAK FNCTN	P1305	×	EC-1874
INJ DRIVE UNIT	P1216	×	EC-1843
INJ1 CORREC R	P1301	—	EC-1870
INJ2 CORREC R	P1302	—	EC-1870
INJ3 CORREC R	P1303	—	EC-1870
INJ4 CORREC R	P1304	—	EC-1870
MAS AIR FLOW SEN	P0100	×	EC-1793
NATS MALFUNCTION	P1610 - P1617	—	EC-1748
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	P0000	—	—
OVER HEAT	P1217	×	EC-1850
P9-FUEL TEMP SEN	P1180	×	EC-1840
SUCTION CONT/V1	P1233	×	EC-1865
SUCTION CONT/V2	P1234	×	EC-1865
TURBO PRESSURE	P0235	×	EC-1821
VEHICLE SPEED SEN	P0500	×	EC-1837

DTC No. Index

EBS00DY2

X: Applicable —: Not applicable

DTC	Items (CONSULT-II screen item)	MI illumination	Reference page
U1000	CAN COMM CIRCUIT	×	EC-1790
P0000	NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—
P0100	MASS AIR FLOW SEN	×	EC-1793
P0115	COOLANT TEMP SEN	×	EC-1798
P0120	ACCEL POS SENSOR	×	EC-1802

INDEX FOR DTC

[YD]

DTC	Items (CONSULT-II screen item)	MI illumination	Reference page	
P0190	CR PRES SEN	×	EC-1810	A
P0201	CYL1 INJECTOR	×	EC-1814	EC
P0202	CYL2 INJECTOR	×	EC-1814	
P0203	CYL3 INJECTOR	×	EC-1814	
P0204	CYL4 INJECTOR	×	EC-1814	
P0235	TURBO PRESSURE	×	EC-1821	C
P0335	CRANK POS SEN (TDC)	×	EC-1827	D
P0340	CAM POS SEN/CIR	×	EC-1832	
P0500	VEHICLE SPEED SEN	×	EC-1837	E
P1107	ECM 10	×	EC-1838	
P1180	P9-FUEL TEMP SEN	×	EC-1840	F
P1216	INJ DRIVE UNIT	×	EC-1843	
P1217	OVER HEAT	×	EC-1850	
P1233	SUCTION CONT/V1	×	EC-1865	G
P1234	SUCTION CONT/V2	×	EC-1865	
P1301	INJ1 CORREC R	—	EC-1870	H
P1302	INJ2 CORREC R	—	EC-1870	
P1303	INJ3 CORREC R	—	EC-1870	
P1304	INJ4 CORREC R	—	EC-1870	
P1305	FUEL LEAK FNCTN	×	EC-1874	I
P1510	ACCEL POS SW (F/C)	×	EC-1876	
P1606	ECM 1	×	EC-1881	J
P1610 - P1617	NATS MALFUNCTION	—	EC-1748	
P1621	ECM 15	—	EC-1883	
P1660	BATTERY VOLTAGE	×	EC-1887	K

L

M

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EBS00DY3

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precautions


EBS00DY4

- Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.




SEF289H

- Do not disassemble ECM.



PBIB0378E

- When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break). Make sure that there are not any bends or breaks on ECM pin terminal, when connecting pin connectors.
- Securely connect ECM harness connectors. A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to IC's.
- Keep engine control system harness at least 10cm (4 in) away from adjacent harness, to prevent engine control system malfunctions due to receiving external noise, degraded operation of IC's, etc.




SEF291H


PRECAUTIONS

[YD]


- Keep engine control system parts and harness dry.
- Before replacing ECM, perform Terminals and Reference Value inspection and make sure ECM functions properly. Refer to [EC-1767](#).
- After performing each TROUBLE DIAGNOSIS, perform “DTC Confirmation Procedure” or “Overall Function Check”.
The DTC should not be displayed in the “DTC Confirmation Procedure” if the repair is completed. The “Overall Function Check” should be a good result if the repair is completed.



- When measuring ECM signals with a circuit tester, never allow the two tester probes to contact. Accidental contact of probes will cause a short circuit and damage the ECM power transistor.
- Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.
- Do not disconnect fuel supply pump harness connector with engine running.
- Do not disassemble fuel supply pump. If NG, take proper action.
- Do not disassemble fuel injector. If NG, replace fuel injector.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the crankshaft position sensor (TDC) and the camshaft position sensor.




- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.



PRECAUTIONS

[YD]

- When installing C.B. ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on installation location.
- Keep the antenna as far as possible from the electronic control units.
- Keep the antenna feeder line more than 20 cm (8 in) away from the harness of electronic controls. Do not let them run parallel for a long distance.
- Adjust the antenna and feeder line so that the standing wave ratio can be kept smaller.
- Be sure to ground the radio to vehicle body.



Wiring Diagrams and Trouble Diagnosis

EBS00DY5

When you read Wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#).
- [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#).
- [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).

ENGINE CONTROL SYSTEM

PFP:23710

System Diagram

EBS00DY6

A

EC

C

D

E

F

G

H


I

J

K

L


M



*1: Suction control valve; *3: Engine coolant temperature sensor

*2: Fuel temperature sensor; Accelerator pedal released position switch

Vacuum Hose Drawing



MBIB0002E

1. Variable nozzle turbocharger control actuator to vacuum gallery
2. Vacuum pump to vacuum gallery
3. Intake air duct to vacuum gallery
4. Variable nozzle turbocharger control solenoid valve to vacuum gallery

Refer to [EC-1735. "System Diagram"](#) for vacuum control system.

System Chart

EBS00DY7

Input (Sensor)	ECM Function	Output (Actuator)
<ul style="list-style-type: none"> ● Accelerator pedal position sensor ● Accelerator pedal released position switch ● Common rail fuel pressure sensor ● Fuel temperature sensor ● Engine coolant temperature sensor ● Crankshaft position sensor (TDC) ● Camshaft position sensor ● Vehicle speed sensor*¹ ● Ignition switch ● Stop Lamp switch ● Air conditioner switch*¹ ● Mass air flow sensor ● Charge air pressure sensor ● Park/neutral position switch ● Battery voltage ● Power steering oil pressure switch 	Fuel injection control	EDU, Fuel injectors and Suction control valve
	Fuel injection timing control	EDU, Fuel injectors and Suction control valve
	Fuel cut control	EDU, Fuel injectors and Suction control valve
	Glow control system	<ul style="list-style-type: none"> ● Glow relay ● Glow indicator lamp*²
	On board diagnostic system	Malfunction indicator (MI)* ²
	EGR volume control	EGR volume control valve
	Cooling fan control	Cooling fan relay* ²
	Air conditioning cut control	Air conditioner relay* ²
	Variable nozzle turbocharger control	Variable nozzle turbocharger control solenoid valve

*1: The input signals are sent to the ECM through CAN communication line.

*2: The output signals are sent from the ECM through CAN communication line.

Fuel Injection Control System SYSTEM DESCRIPTION

EBS00DY8

Three types of fuel injection control are provided to accommodate engine operating conditions; normal control, idle control and start control. The ECM determines the appropriate fuel injection control. Under each control, the amount of fuel injected is adjusted to improve engine performance.

Pulse signals are exchanged between ECM and Electronic Drive Unit (EDU). EDU controls fuel injectors according to the input signals to adjust the amount of fuel injected to the preset value.


START CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature	Fuel injection control (start control)	EDU Fuel injectors Suction control valve
Crankshaft position sensor (TDC)	Engine speed		
Camshaft position sensor	Piston position		
Ignition switch	Start signal		
Common rail fuel pressure sensor	Common rail fuel pressure		

When the ECM receives a start signal from the ignition switch, the ECM adapts the fuel injection system for the start control. The amount of fuel injected at engine starting is a preset program value in the ECM. The program is determined by the engine speed, engine coolant temperature and common rail fuel pressure.

For better startability under cool engine conditions, the lower the coolant temperature becomes, the greater the amount of fuel injected. The ECM ends the start control when the engine speed reaches the specific value, and shifts the control to the normal or idle control.



IDLE CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Engine coolant temperature sensor	Engine coolant temperature	Fuel injection control (Idle control)	EDU Fuel injectors Suction control valve
Crankshaft position sensor (TDC)	Engine speed		
Battery	Battery voltage		
Accelerator pedal position sensor	Accelerator pedal position		
Accelerator pedal released position switch	Accelerator pedal released position		
Vehicle speed sensor*1	Vehicle speed		
Air conditioner switch*1	Air conditioner signal		
Common rail fuel pressure sensor	Common rail fuel pressure		

*1: These signals are sent to the ECM through CAN communication line.

When the ECM determines that the engine speed is at idle, the fuel injection system is adapted for the idle control. The ECM regulates the amount of fuel injected corresponding to changes in load applied to the engine to keep engine speed constant. The ECM also provides the system with a fast idle control in response to the engine coolant temperature signal.


NORMAL CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (TDC)	Engine speed	Fuel injection control (Normal control)	EDU Fuel injectors Suction control valve
Accelerator pedal position sensor	Accelerator position		
Common rail fuel pressure sensor	Common rail fuel pressure		

The amount of fuel injected under normal driving conditions is determined according to sensor signals. The crankshaft position sensor (TDC) detects engine speed, the accelerator pedal position sensor detects accelerator pedal position and common rail fuel pressure sensor detects common rail fuel pressure. These sensors send signals to the ECM.

The fuel injection data, predetermined by correlation between various engine speeds, accelerator pedal positions and common rail fuel pressure are stored in the ECM memory, forming a map. The ECM determines the optimal amount of fuel to be injected using the sensor signals in comparison with the map.



MAXIMUM AMOUNT CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Mass air flow sensor	Amount of intake air	Fuel injection control (Maximum amount control)	EDU Fuel Injectors Suction control valve
Engine coolant temperature sensor	Engine coolant temperature		
Crankshaft position sensor (TDC)	Engine speed		
Accelerator pedal position sensor	Accelerator position		

The maximum injection amount is controlled to an optimum by the engine speed, intake air amount, engine coolant temperature, and accelerator opening in accordance with the driving conditions.

This prevents the oversupply of the injection amount caused by decreased air density at a high altitude or during a system failure.

DECELERATION CONTROL

Input/Output Signal Chart

Sensor	Input Signal to ECM	ECM Function	Actuator
Accelerator pedal released position switch	Accelerator pedal position	Fuel injection control (Deceleration control)	EDU Fuel injectors Suction control valve
Crankshaft position sensor (TDC)	Engine speed		

The ECM sends a fuel cut signal to the fuel injector and suction control valve during deceleration for better fuel efficiency. The ECM determines the time of deceleration according to signals from the accelerator pedal released position switch and crankshaft position sensor (TDC).

Fuel Injection Timing Control System

EBS00DY9

DESCRIPTION

The target fuel injection timing in accordance with the engine speed and the fuel injection amount are recorded as a map in the ECM beforehand. The ECM determines the optimum injection timing using sensor signals accordance with the map.

Air Conditioning Cut Control

EBS00DYA

INPUT / OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Air conditioner switch*1	Air conditioner "ON" signal	Air conditioner cut control	Air conditioner relay
Accelerator pedal position sensor	Accelerator pedal opening angle		
Vehicle speed sensor*1	Vehicle speed		
Engine coolant temperature sensor	Engine coolant temperature		

*1: These signals are sent to the ECM through CAN communication line.

SYSTEM DESCRIPTION

This system improves acceleration when the air conditioner is used.

When the accelerator pedal is fully depressed, the air conditioner is turned off for a few seconds.

When engine coolant temperature becomes excessively high, the air conditioner is turned off. This continues until the engine coolant temperature returns to normal.

Fuel Cut Control (At No Load & High Engine Speed)

EBS00DYB

INPUT/OUTPUT SIGNAL CHART

Sensor	Input Signal to ECM	ECM Function	Actuator
Vehicle speed sensor*1	Vehicle speed	Fuel cut control	EDU Fuel injectors Suction control valve
Accelerator pedal released position switch	Accelerator position		
Crankshaft position sensor (TDC)	Engine speed		

*1: These signals are sent to the ECM through CAN communication line.


If the engine speed is above 2,800 rpm with no load (for example, in neutral and engine speed over 2,800 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed. Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different from deceleration control listed under [EC-1737, "Fuel Injection Control System"](#).

Crankcase Ventilation System DESCRIPTION


In this system, blow-by gas is sucked into the air duct after oil separation by oil separator in the rocker cover.



INSPECTION

Ventilation Hose

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.



CAN communication SYSTEM DESCRIPTION


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

ENGINE CONTROL SYSTEM

[YD]

LHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R*1		T		
Heater fan switch signal	R*1				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal*2	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tyre pressure signal				T	R

*1: Except YD22DDTi engine model


*2: YD22DDTi engine model only

ENGINE CONTROL SYSTEM

[YD]

LHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model


*2: YD22DDTi engine model only

ENGINE CONTROL SYSTEM

[YD]

RHD MODELS WITH TYRE PRESSURE MONITORING SYSTEM

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R*1			T	
Heater fan switch signal	R*1				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal*2	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	
Tire pressure signal			T		R

*1: Except YD22DDTi engine model


*2: YD22DDTi engine model only

ENGINE CONTROL SYSTEM

[YD]

RHD MODELS WITHOUT TYRE PRESSURE MONITORING SYSTEM

System Diagram



Input/Output Signal Chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

BASIC SERVICE PROCEDURE

PFP:00018

Fuel Filter DESCRIPTION


EBS00DYD

A water draining cock is on the lower side and a priming pump for bleeding air is on the upper side.

AIR BLEEDING

Pump the priming pump to bleed air.

- When air is bled completely, the pumping of the priming pump suddenly becomes heavy. Stop the operation at that time.
- If it is difficult to bleed air by the pumping of the priming pump (the pumping of the priming pump does not become heavy), disconnect the fuel supply hose between the fuel filter and the fuel gallery. Then, perform the operation described above, and make sure that fuel comes out. (Use a pan, etc. so as not to spill fuel. Do not let fuel get on engine and other parts.) After that, connect the hose, then bleed air again.
- Start engine and let it idle for at least one minute after performing air bleeding.



WATER DRAINING

1. Remove the fuel filter, filter bracket, protector assembly from the dash panel as follows.
 - a. Remove the air cleaner case (upper), air duct assembly, and vacuum hose for brake booster (between the vacuum pump and vacuum pipe).

CAUTION:

After the duct is removed, cover the opening with gum tape, etc. to prevent foreign object from getting into the engine during the operation.

- b. Remove the mounting nuts on the dash panel, then remove the fuel filter, filter bracket, and protector assembly from the dash panel.
 - It is not necessary to disconnect the fuel hose.

2. Using a tool such as a pliers, loosen the water draining cock at the bottom of the fuel filter.

Loosening drain cock four to five turns causes water to start draining.

Do not remove drain cock by loosening it excessively.


If water does not drain properly, move the priming up and down.

CAUTION:

When the water is drained, the fuel is also drained. Use a pan, etc. to avoid fuel adherence to the rubber parts such as the engine mount insulator.

Do not over-tighten the water draining cock. This will damage the cock thread, resulting in water or fuel leak.

3. Bleed air of the fuel filter. Refer to [EC-1745, "AIR BLEEDING"](#).
4. Start the engine, then check that the MI goes off.



Accelerator Pedal Released Position Learning DESCRIPTION

EBS00DYE

“Accelerator Pedal Released Position Learning” is an operating to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed when accelerator work unit or ECM is replaced.


OPERATION PROCEDURE

1. Turn ignition switch “ON”.


BASIC SERVICE PROCEDURE

[YD]


2. Select "OFF ACCEL PO SIG" in "ACTIVE TEST" mode with CONSULT-II
3. Make sure that accelerator pedal is released.



4. Touch "CLEAR" and wait a few seconds.



5. Make sure that "CMPLT" is displayed on CONSULT-II screen.



Fuel Pressure Relief Valve DESCRIPTION

EBS00DYF


When the fuel pressure in common rail increases to excessively high, fuel pressure relief valve opens to carry excess fuel to the return hose.

FUEL PRESSURE RELIEF VALVE CHECK

WARNING:

Confirm that the engine is cooled down and there are no fire hazards near the vehicle.

1. Turn ignition switch "OFF".
2. Remove fuel hose from fuel pressure relief valve.
3. Attach a blind cap or plug to removed hose.
4. Turn ignition switch "ON".



BASIC SERVICE PROCEDURE

[YD]

5. Select "PRES REGULATOR" in "ACTIVE TEST MODE" with CONSULT-II.
6. Start engine and keep engine speed 2,000 rpm.
7. Raise fuel pressure to 135 MPa with touching "UP" or "Qu" on the CONSULT-II screen.
8. Confirm that the fuel does not come out from the fuel pressure relief valve.
WARNING:
If the fuel comes out, stop the engine immediately.
9. If NG, replace common rail assembly.

ACTIVE TEST	
PRES REGULATOR	XXX MPa
MONITOR	
CKPS-RPM (TDC)	XXX rpm
ACT CR PRESS	XXX MPa

PBIB0587E

A
EC
C
D
E
F
G
H
I
J
K
L
M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PFP:00028

DTC and MI Detection Logic

EBS00DYH

When a malfunction is detected, the malfunction (DTC) is stored in the ECM memory. The MI will light up each time the ECM detects malfunction. For diagnostic items causing the MI to light up, refer to [EC-1730, "INDEX FOR DTC"](#) .

Diagnostic Trouble Code (DTC)

EBS00DYH

HOW TO READ DTC

The DTC can be read by CONSULT-II only.

④ With CONSULT-II

CONSULT-II displays the DTC in "SELF-DIAG RESULTS" mode. Example: P0115, P0335, P1233, etc. These DTCs are prescribed by ISO15031-5.

(CONSULT-II also displays the malfunctioning component or system.)

HOW TO ERASE DTC

④ How to Erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Touch "ENGINE".
3. Touch "SELF-DIAG RESULTS".
4. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)
 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" again.

SELECT SYSTEM
ENGINE

➔

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
FUNCTION TEST
ECM PART NUMBER

➔

SELF DIAG RESULTS	
DTC RESULTS	TIME
COOLANT TEMP SEN [P0115]	0

2. Turn CONSULT-II "ON" and touch "ENGINE".

3. Touch "SELF-DIAG RESULTS".

4. Touch "ERASE". (The DTC in the ECM will be erased.)

PBIB0476E

The emission related diagnostic information in the ECM can be erased by selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT-II.

NATS (Nissan Anti-theft System)

EBS00DYI

- If the security indicator lights up with the ignition switch in the "ON" position or "NATS MALFUNCTION" is displayed on "SELF-DIAG RESULTS" screen, perform self-diagnostic results mode with CONSULT-II using NATS program card. Refer to NATS (Nissan Anti-Theft System) in BL section.
- Confirm no self-diagnostic results of NATS is displayed before touching "ERASE" in "SELF-DAIG RESULTS" mode with CONSULT-II.
- When replacing ECM, initialization of NATS system and registration of all NATS ignition key IDs must be carried out with CONSULT-II using NATS program card.

SELF DIAG RESULTS	
DTC RESULTS	TIME
NATS MALFUNCTION [P1610]	0

SEF543X

ON BOARD DIAGNOSTIC (OBD) SYSTEM

[YD]


Therefore, be sure to receive all keys from vehicle owner. Regarding the procedure of NATS initialization and NATS ignition key ID registration, refer to CONSULT-II operation manual, NATS.

Malfunction Indicator (MI) DESCRIPTION

EBS00DYJ




The MI is located on the instrument panel.

- The MI will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MI does not light up, refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1922](#).
- When the engine is started, the MI should go off. If the MI remains on, the on board diagnostic system has detected an engine system malfunction.



On Board Diagnostic System Function

The on board diagnostic system has the following two functions.

Diagnostic Test Mode	KEY and ENG. Status	Function	Explanation of Function
Mode I	Ignition switch in ON position  Engine stopped 	BULB CHECK	This function checks the MI bulb for damage (blown, open circuit, etc.). If the MI does not come on, check MI circuit. (See EC-1922, "MI & DATA LINK CONNECTORS" .)
	Engine running 	MALFUNCTION WARNING	This is a usual driving condition. When ECM detects a malfunction, the MI will light up to inform the driver that a malfunction has been detected.


Diagnostic Test Mode I - Bulb Check

In this mode, the MI on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to [DI-95, "WARNING LAMPS"](#) or see [EC-1922](#).

Diagnostic Test Mode I - Malfunction Warning

MI	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.

Relationship Between MI, DTC, CONSULT-II and Driving Patterns



PBIB0589E

*1: When a malfunction is detected, MI will light up.

*2: MI will not light up after ignition switch is turned OFF.

*3: When a malfunction is detected for the first time, the DTC will be stored in ECM.

*4: The DTC will not be displayed any longer after vehicle is driven 40 times without the same malfunction. (The DTC still remain in ECM.)

*5: Other screens except SELF-DIAGNOSTIC RESULTS & DATA MONITOR (AUTO TRIG) cannot display the malfunction. DATA MONITOR (AUTO TRIG) can display the malfunction at the moment it is detected.


TROUBLE DIAGNOSIS

PFP:00004


Trouble Diagnosis Introduction INTRODUCTION

EBS00DYK


The engine has an ECM to control major systems such as fuel injection control, fuel injection timing control, glow control system, etc. The ECM accepts input signals from sensors and instantly actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, or other problems with the engine.



It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.




A visual check only may not find the cause of the problems. A road test with CONSULT-II or a circuit tester connected should be performed. Follow the [EC-1752, "WORK FLOW"](#). Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on [EC-1753, "DIAGNOSTIC WORK SHEET"](#) should be used. Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.



TROUBLE DIAGNOSIS

[YD]

WORK FLOW



PBIB0477E

*1 If time data of "SELF-DIAG RESULTS" is other than "0", perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*2 If the incident cannot be verified, perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

*3 If the on board diagnostic system cannot be performed, check main power supply and ground circuit. Refer to [EC-1784, "POWER SUPPLY CIRCUIT FOR ECM"](#) .

*4 If malfunctioning part cannot be detected, perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

TROUBLE DIAGNOSIS

[YD]

Description for Work Flow

STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the EC-1753, "DIAGNOSTIC WORK SHEET" .
STEP II	Before confirming the concern, check and write down (print out using CONSULT-II) the DTC, then erase the DTC. Refer to EC-1748 . If the incident cannot be verified, perform EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . Study the relationship between the cause, specified by DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. Refer to EC-1758 .) Also check related service bulletins for information.
STEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" is useful to verify the incident. Connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . If the malfunction code is detected, skip STEP IV and perform STEP V.
STEP IV	Try to detect the DTC by driving in (or performing) the "DTC Confirmation Procedure". Check and read the DTC by using CONSULT-II. During the DTC verification, be sure to connect CONSULT-II to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" . In case the "DTC Confirmation Procedure" is not available, perform the "Overall Function Check" instead. The DTC cannot be displayed by this check, however, this simplified "check" is an effective alternative. The "NG" result of the "Overall Function Check" is the same as the DTC detection.
STEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to Trouble Diagnosis for DTC PXXXX. If the normal code is indicated, proceed to the Basic Inspection, EC-1754 . Then perform inspections according to the Symptom Matrix Chart. Refer to EC-1758 .
STEP VI	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT-II set in "DATA MONITOR (AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CONSULT-II. Refer to EC-1767 or EC-1779 . The "Diagnostic Procedure" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure. For details, refer to GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident" , "Circuit Inspection". Repair or replace the malfunction parts. If the malfunctioning part cannot be detected, perform EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT" .
STEP VII	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC Confirmation Procedure" and confirm the normal code (DTC P0000) is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one. Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) DTC in ECM. (Refer to EC-1748 .)

DIAGNOSTIC WORK SHEET

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one shown below in order to organize all the information for troubleshooting.

KEY POINTS


WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,
Symptoms

SEF907L

1. INSPECTION START

1. Check service records for any recent repairs that may indicate a related problem.
2. Check the current need for scheduled maintenance, especially for fuel filter and air cleaner filter. Refer to [MA-7, "PERIODIC MAINTENANCE"](#).
3. Open engine hood and check the following:
 - Harness connectors for improper connections
 - Vacuum hoses for splits, kinks, or improper connections
 - Wiring for improper connections, pinches, or cuts
4. Start engine and warm it up to the normal operating temperature.

>> GO TO 2.



2. PREPARATION FOR CHECKING IDLE SPEED

- Ⓜ With CONSULT-II**
Connect CONSULT-II to the data link connector.

>> GO TO 3.


3. CHECK IDLE SPEED

- Ⓜ With CONSULT-II**
1. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
 2. Read idle speed.

725±25 rpm

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 4.



4. CHECK FOR INTAKE AIR LEAK

Listen for an intake air leak after the mass air flow sensor.

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace.

5. BLEED AIR FROM FUEL SYSTEM

1. Stop engine.
2. Use priming pump to bleed air from fuel system. Refer to [EC-1745, "AIR BLEEDING"](#) .

>> GO TO 6.

6. CHECK IDLE SPEED AGAIN

Ⓜ With CONSULT-II

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

725±25 rpm

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 7.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

7. DRAIN WATER FROM FUEL FILTER

Drain water from fuel filter. Refer to [EC-1745, "WATER DRAINING"](#) .

>> GO TO 8.

8. CHECK IDLE SPEED AGAIN

Ⓜ With CONSULT-II

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

725±25 rpm

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 9.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

9. CHECK AIR CLEANER FILTER

Check air cleaner filter for clogging or breaks.

OK or NG

- OK >> GO TO 10.
 NG >> Replace air cleaner filter.

10. CHECK BATTERY VOLTAGE

Check battery voltage.

Voltage: More than 12.13V

OK or NG

- OK >> GO TO 12.
NG >> GO TO 11.

11. CHECK BATTERY

Refer to [SC-3, "BATTERY"](#) .

OK or NG

- OK >> Check charging system. Refer to [SC-12, "CHARGING SYSTEM"](#) .
NG >> Repair or replace.

12. CHECK COMPRESSION PRESSURE

Check compression pressure. Refer to [EM-274, "CHECKING COMPRESSION PRESSURE"](#) .

OK or NG

- OK >> GO TO 11.
NG >> Follow the instruction of "CHECKING COMPRESSION PRESSURE".

13. CHECK IDLE SPEED AGAIN

Ⓟ **With CONSULT-II**

1. Start engine and let it idle.
2. Select "CKPS-RPM (TDC)" in "DATA MONITOR" mode with CONSULT-II.
3. Read idle speed.

725±25 rpm

OK or NG

- OK >> **INSPECTION END**
NG >> 1. Replace fuel injector.
2. GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

TROUBLE DIAGNOSIS

[YD]

Symptom Matrix Chart

EBS00DYM

	SYMPTOM												Reference page		
	HARD/NO START/RESTART (EXCP. HA)				ENGINE STALL			HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE		LOW IDLE	
	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING								
Warranty symptom code	AA				AB			AC	AD	AE	AF				
SYSTEM — Basic engine control system															
Fuel supply pump	5	5	5	5	5	5	5	5		5	5		5	—	
Fuel injector	3	3	3	3	3	3	3	3	3	4	4	3	3	EC-1814	
EDU (Electronic drive unit)	4	4	4	4	4	4	4	4	4	5	5	4	4	EC-1843	
Glow control system	1	1	1	1					1					EC-1889	
Engine body	3	3	3	3	3	3	3		3	4	4		3	EM-285	
EGR system										3	3			EC-1896	
Air cleaner and duct										3	3			MA-7	
Fuel pressure relief valve														EC-1746	
ENGINE CONTROL	Suction control valve circuit	4	4	4	4	4	4	4	4		4	4		4	EC-1865
	Fuel injector circuit	1	1	1	1	1	1	1	1	1	1	1	1	1	EC-1814
	EDU circuit	2	2	2	2	2	2	2	2	2	2	2	2	2	EC-1843
	Mass air flow sensor circuit								1		1	1			EC-1793
	Engine coolant temperature circuit			1		1		1						1	EC-1798
	Vehicle speed signal circuit											1			EC-1837
	Accelerator pedal position sensor circuit								1		1	1			EC-1802
	Accelerator pedal released position switch circuit					1		1	1		1	1		1	EC-1876
	Common rail fuel pressure sensor circuit														EC-1810

TROUBLE DIAGNOSIS

[YD]

	SYMPTOM												Reference page		
	HARD/NO START/RESTART (EXCP. HA)			ENGINE STALL			HESITATION/SURGING/FLAT SPOT	KNOCK/DETONATION	LACK OF POWER	POOR ACCELERATION	HI IDLE	LOW IDLE			
	NO START (with first firing)	NO START (without first firing)	HARD TO START WHEN ENGINE IS COLD	HARD TO START WHEN ENGINE IS HOT	AT IDLE	DURING DRIVING	WHEN DECELERATING								
Warranty symptom code	AA			AB			AC	AD	AE	AF					
ENGINE CONTROL	Crankshaft position sensor (TDC) circuit	1	1	1	1	1	1	1	1	1		1	1	EC-1827	
	Camshaft position sensor circuit		3	3										EC-1832	
	Charge air pressure sensor circuit							1		1	1			EC-1821	
	Variable nozzle turbocharger control solenoid valve circuit							1		1	1			EC-1903	
	Start signal circuit	1	1	1	1	1		1		1	1			EC-1916	
	Ignition switch circuit		1			1	1	1							EC-1784
	Power supply for ECM circuit		1			1	1	1							EC-1784
	Cooling fan relay circuit														EC-1850
	EGR volume control valve circuit							1		1	1				EC-1896
	Glow relay circuit	1	1	1	1										EC-1889
	ECM relay (Self-shutoff) circuit		1				1	1	1						EC-1883
ECM, connector circuit	2	2	2	2	2	2	2	2	2	2	2	2	2	EC-1838 , EC-1881	
NATS (Nissan Anti-theft System)		1												EC-1748	

1 - 5: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[YD]

	SYMPTOM										Reference page	
	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	ABNORMAL SMOKE COLOR		DEAD BATTERY (UNDER CHARGE)	Malfunction indicator illuminates.		Can be detected by CONSULT-II?
Warranty symptom code	AG	AH	AJ	AK	AL	AM	BLACK SMOKE	WHITE SMOKE	HA			
Fuel supply pump	5	5	5		5					1	1	—
Fuel injector	3	3	3		4		4	4		1	1	EC-1814
EDU (Electronic drive unit)	4	4	4		5		5	5		1	1	EC-1843
Glow system								1				EC-1889
Engine body		3	3	3	3	1		3				EM-285
EGR system							3					EC-1896
Air cleaner and duct							3					MA-7
Fuel pressure relief valve												EC-1746
ENGINE CONTROL	Suction control valve circuit	4	4	4		4				1	1	EC-1865
	Fuel injector circuit	1	1	1		1	1	1		1	1	EC-1814
	EDU circuit	2	2	2		2	2	2		1	1	EC-1843
	Mass air flow sensor circuit						1			1	1	EC-1793
	Engine coolant temperature circuit	1	1		1					1	1	EC-1798
	Vehicle speed signal circuit									1	1	EC-1837
	Accelerator pedal position sensor circuit			1						1	1	EC-1802
	Accelerator pedal released position switch circuit									1	1	EC-1876
	Common rail fuel pressure sensor circuit									1	1	EC-1810
	Crankshaft position sensor (TDC) circuit	1	1							1	1	EC-1827

TROUBLE DIAGNOSIS

[YD]


	SYMPTOM										Reference page	
	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEAT/HIGH ENGINE COOLANT TEMPERATURE	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	ABNORMAL SMOKE COLOR		DEAD BATTERY (UNDER CHARGE)	Malfunction indicator illuminates.		Can be detected by CONSULT-II?
SYSTEM — Basic engine control system	AG	AH	AJ	AK	AL	AM	AP	AP	HA			
Warranty symptom code	AG	AH	AJ	AK	AL	AM	AP	AP	HA			
ENGINE CONTROL	Camshaft position sensor circuit									1	1	EC-1832
	Charge air pressure sensor circuit									1	1	EC-1821
	Variable nozzle turbocharger control solenoid valve circuit						1	1				EC-1903
	Start signal circuit											EC-1916
	Ignition switch circuit											EC-1784
	Power supply for ECM circuit									1	1	EC-1784
	Cooling fan relay circuit				2							EC-1850
	EGR volume control valve circuit						1					EC-1896
	Glow relay circuit							1				EC-1889
	ECM relay (Self-shutoff) circuit										1	EC-1883
ECM, connector circuit	2	2	2	2	2	2	2	2	2	2	2	EC-1838, EC-1881
NATS (Nissan Anti-theft System)											1	EC-1748

1 - 5: The numbers refer to the order of inspection.
(continued on next page)

A
EC
C
D
E
F
G
H
I
J
K
L
M

Engine Control Component Parts Location

EBS00DYN



A

EC

C

D

E

F

G

H






I

J








K

L

M




MBIB0168E




Circuit Diagram

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS


[YD]



MBWA0096E

ECM Harness Connector Terminal Layout


EBS00DYP




ECM Terminals And Reference Value PREPARATION

EBS00DYQ

- ECM is located behind the glove box. For this inspection, remove glove box.



- Perform all voltage measurements with the connector connected. Extend tester probe as shown to perform tests easily.
 - Open harness securing clip to make testing easier.
 - Use extreme care not to touch 2 pins at one time.
 - Data is for comparison and may not be exact.



ECM INSPECTION TABLE





Remarks: Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.



TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A1 A2 A3 A4	L/W Y/PU PU Y	EDU drive No. 2 EDU drive No. 4 EDU drive No. 3 EDU drive No. 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 4V ★  PBIB0387E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 4V ★  PBIB0388E
A5 A6 A7	B B B	ECM ground	[Engine is running] <ul style="list-style-type: none"> ● Idle speed 	Approximately 0V
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
A10	R	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0.5 - 2.5V ★  PBIB0389E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	1.5 - 3.5V ★  PBIB0390E
A11	L/OR	Engine coolant temperature sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition 	Approximately 0 - 4.8V Output voltage varies with engine coolant temperature
A12	PU	Fuel temperature sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition 	Approximately 0 - 4.8V Output voltage varies with fuel temperature
A21	B	Accelerator pedal released position switch ground	[Ignition switch "ON"]	Approximately 0V
A22	LG	Accelerator pedal position sensor 1 ground	[Ignition switch "ON"]	Approximately 0V
A23	B	Sensor's ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V

TROUBLE DIAGNOSIS



[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A24	B	Mass air flow sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
A25	PU/W	Injector's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
A26	LG/R	Accelerator pedal position sensor 2 ground	[Ignition switch "ON"]	Approximately 0V
A27	W	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
A28	PU/R	Accelerator pedal position sensor 1 power supply	[Ignition switch "ON"]	Approximately 5V
A29	W/PU	EDU injector check signal	[Engine is running] ● Warm-up condition ● Idle speed	1 - 5V ★  PBIB0391E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	1 - 5V ★  PBIB0392E
A31	W/L	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
B2	Y	Charge air pressure sensor	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.0V
B3 B4 B5 B6	GY/B OR/B W/L GY	EGR volume control valve	[Engine is running] ● Warm-up condition ● Idle speed	0.1 - 14V (Voltage signals of each ECM terminals differ according to the control position of EGR volume control valve.)
B9	Y/B	Fuel injector adjustment resistor No.2	[Ignition switch "ON"]	0.2 - 4.8V (There are individual differences between fuel injector adjustment resistors.)
B10	R/B	Fuel injector adjustment resistor No.4		
B11	G/B	Fuel injector adjustment resistor No.3		
B12	W/B	Fuel injector adjustment resistor No.1		
B13 B14	Y/R Y/R	Common rail fuel pressure sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.6 - 1.8V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	1.8 - 2.0V

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
B15	W	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.8 - 1.3V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.5V
B16	L	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.3 - 1.8V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.0V
B17	L	Variable nozzle turbo-charger control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	4.5 - 6.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	7 - 9V
B18	G	Camshaft position sensor ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
B19	R	Camshaft position sensor	[Engine is running] ● Warm-up condition ● Idle speed	0 - 3V ★  5.0 V/Div 20 ms/Div T PBIB0393E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	0 - 8V ★  5.0 V/Div 20 ms/Div T PBIB0394E
B20	L/R	Crankshaft position sensor (TDC) ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

TROUBLE DIAGNOSIS





[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
B21	L/G	Crankshaft position sensor (TDC)	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0395E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 30.0V ★  PBIB0396E
B23	GY/L	Accelerator pedal position sensor 2 power supply	[Ignition switch "ON"]	Approximately 5V
D14	G/Y	Accelerator pedal released position switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Accelerator pedal slightly depressed 	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Accelerator pedal fully released 	Approximately 0V
D18 D19	W/R W/R	Ignition switch	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" 	Approximately 0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)
D25	R/G	Stop lamp switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal fully released 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Brake pedal depressed 	BATTERY VOLTAGE (11 - 14V)
D27	B/Y	Start signal	[Ignition switch "ON"]	Approximately 0V
			[Ignition switch "START"]	BATTERY VOLTAGE (11 - 14V)

A
EC
C
D
E
F
G
H
I
J
K
L
M



TROUBLE DIAGNOSIS

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
E1	L	Suction control valve power supply	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0399E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 12.5V ★  PBIB0400E
E8	Y/L	Suction control valve 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0401E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 12.5V ★  PBIB0402E
E9	W/R	Glow relay	Refer to EC-1889, "GLOW CONTROL SYSTEM" .	
E10	R	CAN communication line	[Ignition switch "ON"]	Approximately 1.7 - 2.3V Output voltage varies with the communication status.
E11	L	CAN communication line	[Ignition switch "ON"]	Approximately 2.6 - 3.2V Output voltage varies with the communication status.
E12	P/B	Power steering oil pres- sure switch	[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is being turned 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> ● Steering wheel is not being turned 	BATTERY VOLTAGE (11 - 14V)
E13	G/OR	Park/Neutral position switch	[Ignition switch "ON"] <ul style="list-style-type: none"> ● Gear position is "Neutral" 	Approximately 0V
			[Ignition switch "ON"] <ul style="list-style-type: none"> ● Except the above gear position 	BATTERY VOLTAGE (11 - 14V)

TROUBLE DIAGNOSIS

[YD]


TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
E16	G/W	Suction control valve 2	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0401E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 12.5V ★  PBIB0402E
E18	LG/W	Data Link connector	[Ignition switch "ON"] CONSULT-II or GST is disconnected	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)


CONSULT-II Function CONSULT-II INSPECTION PROCEDURE

EBS00DYR

1. Turn ignition switch OFF.
2. Connect CONSULT-II to data link connector, which is located under the driver side dash panel.



3. Turn ignition switch ON.
4. Touch "START".
5. Touch "ENGINE".



TROUBLE DIAGNOSIS

[YD]

6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT-II Operation Manual.

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
FUNCTION TEST
ECM PART NUMBER

PBIB0410E

ENGINE CONTROL COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

		Item	DIAGNOSTIC TEST MODE		
			SELF-DIAG RESULTS	DATA MONITOR	ACTIVE TEST
ENGINE CONTROL COMPONENT PARTS	INPUT	Crankshaft position sensor (TDC)	×	×	
		Camshaft position sensor	×		
		Engine coolant temperature sensor	×	×	
		Vehicle speed signal	×	×	
		Fuel temperature sensor	×	×	
		Accelerator pedal position sensor 1	×	×	
		Accelerator pedal position sensor 2	×	×	
		Accelerator pedal released position switch	×	×	
		Common rail fuel pressure sensor	×	×	
		Park/neutral position (PNP) switch		×	
		Mass air flow sensor	×	×	
		Battery voltage	×	×	
		Power steering oil pressure switch		×	
		Stop lamp switch		×	
		Absolute pressure sensor	×	×	
		Fuel injector adjustment resistor	×		
	Charge air pressure sensor	×	×		
	OUTPUT	Suction control valve	×	×	×
		Fuel injector	×	×	×
		Glow relay		×	×
		Cooling fan relay	×	×	×
EGR volume control valve			×	×	
	Variable nozzle turbocharger control solenoid valve				

X: Applicable

SELF-DIAGNOSTIC MODE

Regarding items detected in "SELF-DIAG RESULTS" mode, refer to — [EC-1730, "INDEX FOR DTC"](#) .

TROUBLE DIAGNOSIS

[YD]

DATA MONITOR MODE

MONITOR ITEM	ECM INPUT SIGNAL	MAIN SIGNALS	CAN DIAG SUPPORT MNTN	CONDITION	SPECIFICATION
CKPS-RPM (TDC) [rpm]	×	×		<ul style="list-style-type: none"> The engine speed computed from the crankshaft position sensor (TDC) signal is displayed. 	
COOLAN TEMP/S [°C] or [°F]	×	×		<ul style="list-style-type: none"> The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	When the engine coolant temperature circuit is open or short, ECM enters fail-safe mode. The engine coolant temperature determined by the ECM is displayed.
VHCL SPEED SE [km/h] or [mph]	×	×		<ul style="list-style-type: none"> The vehicle speed computed from the vehicle speed signal is displayed. 	
FUEL TEMP SEN [°C] or [°F]	×	×		<ul style="list-style-type: none"> The fuel temperature (determined by the signal voltage of the fuel temperature sensor) is displayed. 	
ACCEL POS SEN [V]	×	×		<ul style="list-style-type: none"> The accelerator pedal position sensor 1 signal voltage is displayed. 	
ACCEL SEN 2 [V]	×	×		<ul style="list-style-type: none"> The accelerator pedal position sensor 2 signal voltage is displayed. 	
OFF ACCEL SW [ON/OFF]	×	×		<ul style="list-style-type: none"> indicates [ON/OFF] condition from the accelerator pedal released position switch signal. 	
ACT CR PRESS [MPa]	×	×		<ul style="list-style-type: none"> The common rail fuel pressure (determined by the signal voltage of the common rail fuel pressure sensor) is displayed. 	
BATTERY VOLT [V]	×	×		<ul style="list-style-type: none"> The power supply voltage of ECM is displayed. 	
P/N POSI SW [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from the park/neutral position switch signal. 	
START SIGNAL [ON/OFF]	×	×		<ul style="list-style-type: none"> indicates [ON/OFF] condition from the starter signal. 	
PW/ST SIGNAL [ON/OFF]	×			<ul style="list-style-type: none"> indicates [ON/OFF] condition from the power steering oil pressure switch signal. 	
BRAKE SW [ON/OFF]	×	×		<ul style="list-style-type: none"> indicates [ON/OFF] condition from the stop lamp switch signal. 	
IGN SW [ON/OFF]	×	×		<ul style="list-style-type: none"> Indicates [ON/OFF] condition from ignition switch signal. 	
MAS AIR/FL SE [V]	×	×		<ul style="list-style-type: none"> The signal voltage of the mass air flow sensor is displayed. 	
SUCTION CV [°CA]		×		<ul style="list-style-type: none"> Indicates [°CA] of suction control valve operating angle. 	
MAIN INJ WID [msec]		×		<ul style="list-style-type: none"> Indicates the actual fuel injection pulse width compensated by ECM according to the input signals. 	

A
EC
C
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	ECM IPUT SIG- NAL	MAIN SIG- NALS	CAN DIAG SUP- PORT MNTR	CONDITION	SPECIFICATION
GLOW RLY [ON/OFF]		×		<ul style="list-style-type: none"> ● The glow relay control condition (determined by ECM according to the input signal) is displayed. 	
COOLING FAN [LOW/HI/OFF]		×		<ul style="list-style-type: none"> ● Indicates the control condition of the cooling fans (determined by ECM according to the input signal). LOW ... Operates at low speed. HI ... Operates at high speed. OFF ... Stopped 	
EGR VOL CON/V [step]		×		<ul style="list-style-type: none"> ● Indicates the EGR volume control value computed by the ECM according to the input signals. ● The opening becomes larger as the value increases. 	
INT/A VOLUME [mg/]				<ul style="list-style-type: none"> ● The intake air volume computed from the mass air flow sensor signal is displayed. 	
BARO SEN [kPa]	×	×		<ul style="list-style-type: none"> ● The barometric pressure (determined by the signal voltage from the absolute pressure sensor built into the ECM) is displayed. 	
CYL COUNT [0/1/2/3]				<ul style="list-style-type: none"> ● The cylinder being injected is displayed. 0 ... Cylinder No.1 is injected. 1 ... Cylinder No.3 is injected. 2 ... Cylinder No.4 is injected. 3 ... Cylinder No.2 is injected. 	
TURBO BST SEN				<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load 	
Voltage [V]				Voltage, frequency, duty cycle or pulse width measured by the probe.	Only “#” is displayed if item is unable to be measured. Figures with “#”s are temporary ones. They are the same figures as an actual piece of data which was just previously measured. [Hz] or [%]
Frequency [msec], [Hz] or [%]					
DUTY-HI					
DUTY-LOW					
PLS WIDTH-HI					
PLS WIDTH-LOW					

TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	ECM INPUT SIGNAL	MAIN SIGNALS	CAN DIAG SUPPORT MNTR	CONDITION	SPECIFICATION
CAN COMM [OK/NG]			×	<ul style="list-style-type: none"> Indicates the communication condition of CAN communication line. 	<ul style="list-style-type: none"> These items are not displayed in "SELECTION FROM MENU" mode.
CAN CIRC 1 [OK/UNKWN]			×		
CAN CIRC 2 [OK/UNKWN]			×		
CAN CIRC 3 [OK/UNKWN]			×		
CAN CIRC 4 [OK/UNKWN]			×		
CAN CIRC 5 [OK/UNKWN]			×		
CAN CIRC 6 [OK/UNKWN]			×		
CAN CIRC 7 [OK/UNKWN]			×		

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

ACTIVE TEST MODE

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
POWER BALANCE	<ul style="list-style-type: none"> Engine: After warming up, idle the engine. A/C switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT-II 	Engine runs rough or dies.	<ul style="list-style-type: none"> Harness and connectors Compression Fuel injectors
COOLING FAN	<ul style="list-style-type: none"> Ignition switch: ON Operate the cooling fan at "LOW", "HI" speed and turn "OFF" using CONSULT-II. 	Cooling fan moves at "LOW", "HI" speed and stops.	<ul style="list-style-type: none"> Harness and connector Cooling fan motor Cooling fan relay
OFF ACCEL POS SIG	<ul style="list-style-type: none"> This mode is used for ECM to learn accelerator pedal released positions. 		
GLOW RELAY	<ul style="list-style-type: none"> Ignition switch: ON (Engine stopped) Turn the glow relay "ON" and "OFF" using CONSULT-II and listen to operating sound. 	Glow relay makes the operating sound.	<ul style="list-style-type: none"> Harness and connector Glow relay
EGR VOL CONT/V	<ul style="list-style-type: none"> Ignition switch: ON Change EGR volume control valve opening step using CONSULT-II. 	EGR volume control valve makes an operating sound.	<ul style="list-style-type: none"> Harness and connector EGR volume control valve
PRES REGULATOR	<ul style="list-style-type: none"> Ignition switch: ON Change fuel pressure in common rail using CONSULT-II 	Fuel leaks.	<ul style="list-style-type: none"> Fuel line Fuel pressure relief valve

REAL TIME DIAGNOSIS IN DATA MONITOR MODE

CONSULT-II has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

TROUBLE DIAGNOSIS

[YD]


1. "AUTO TRIG" (Automatic trigger):

- The malfunction will be identified on the CONSULT-II screen in real time.

In other words, DTC will be displayed if the malfunction is detected by ECM.

At the moment a malfunction is detected by ECM, "MONITOR" in "DATA MONITOR" screen is changed to "Recording Data ... xx%" as shown in the figure, and the data after the malfunction detection is recorded. Then when the percentage reached 100%, "REAL-TIME DIAG" screen is displayed. If "STOP" is touched on the screen during "Recording Data ... xx%", "REAL-TIME DIAG" screen is also displayed.

The recording time after the malfunction detection and the recording speed can be changed by "TRIGGER POINT" and "Recording Speed". Refer to CONSULT-II OPERATION MANUAL.



2. "MANU TRIG" (Manual trigger):

- DTC will not be displayed automatically on CONSULT-II screen even though a malfunction is detected by ECM.

DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:


1. "AUTO TRIG"

- While trying to detect the DTC by performing the "DTC Confirmation Procedure", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.

- While narrowing down the possible causes, CONSULT-II should be set in "DATA MONITOR (AUTO TRIG)" mode, especially in case the incident is intermittent.

When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, components and harness in the "DTC Confirmation Procedure", the moment a malfunction is found the DTC will be displayed. Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "INCIDENT SIMULATION TESTS".


2. "MANU TRIG"



TROUBLE DIAGNOSIS

[YD]

- If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT-II to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



FUNCTION TEST

This mode is used to inform customers of their vehicle condition of periodic maintenance.

CONSULT-II Reference Value in Data Monitor Mode

EBS00DYS

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

MONITOR ITEM	CONDITION		SPECIFICATION
CKPS-RPM (TDC)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value 		Almost the same speed as the CONSULT-II value
COOLAN TEMP/S	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 70°C (158°F)
VHCL SPEED SE	<ul style="list-style-type: none"> ● Turn drive wheels and compare speedometer indication with the CONSULT-II value 		Almost the same speed as the CONSULT-II value
FUEL TEMP SEN	<ul style="list-style-type: none"> ● Engine: After warming up 		More than 40°C (104°F)
ACCEL POS SEN	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Accelerator pedal: fully released	0.8 - 1.3V
		Accelerator pedal: fully depressed	More than 3.5V
ACCEL SEN 2	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Accelerator pedal: fully released	0.3 - 1.8V
		Accelerator pedal: fully depressed	More than 3.0V
OFF ACCEL SW	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 	Accelerator pedal: fully released	ON
		Accelerator pedal: slightly depressed	OFF

TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	CONDITION	SPECIFICATION	
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF 	Idle	1.0 - 2.5V
	<ul style="list-style-type: none"> ● Shift lever: Neutral position ● No-load 	2,000 rpm	2.1 - 2.7V
BATTERY VOLT	<ul style="list-style-type: none"> ● Ignition switch: ON (Engine stopped) 		11 - 14V
P/N POSI SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Shift lever: Neutral position	ON
		Except above	OFF
START SIGNAL	<ul style="list-style-type: none"> ● Ignition switch: ON → START → ON 		OFF → ON → OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON
BRAKE SW	<ul style="list-style-type: none"> ● Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
IGN SW	<ul style="list-style-type: none"> ● Ignition switch: ON → OFF 		ON → OFF
ACT CR PRESS	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load 	Idle	30 - 40 MPa
		2,000 rpm	40 - 50 MPa
SUCTION CV	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load 	Idle	70.0 - 71.5°C
		2,000 rpm	73.5 - 75.0°C
MAIN INJ WID	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: Neutral position ● Idle speed 	No-load	0.68 - 0.78 msec
		Air conditioner switch: ON Rear window defogger switch: ON	0.78 - 0.88 msec
GLOW RLY	Refer to EC-1889, "GLOW CONTROL SYSTEM" .		
COOLING FAN	<ul style="list-style-type: none"> ● When cooling fan is stopped. 		OFF
	<ul style="list-style-type: none"> ● When cooling fans operate at low speed. 		LOW
	<ul style="list-style-type: none"> ● When cooling fans operate at high speed. 		HIGH
EGR VOL CON/V	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load 	After one minute at idle	More than 10 steps
		Revvng engine from idle to 3,600 rpm	0 step
INT/A VOLUME	<ul style="list-style-type: none"> ● Engine: After warming up, idle the engine 		150 - 450 mg/st
BARO SEN	<ul style="list-style-type: none"> ● Ignition switch: ON 		Altitude Approx. 0m: Approx. 100.62 kPa (1.0062 bar, 1.026 kg/cm ² , 14.59 psi) Approx. 1,000 m: Approx. 88.95 kPa (0.8895 bar, 0.907 kg/cm ² , 12.90 psi) Approx. 1,500 m: Approx. 83.16 kPa (0.8316 bar, 0.848 kg/cm ² , 12.06 psi) Approx. 2,000 m: Approx. 78.36 kPa (0.7836 bar, 0.799 kg/cm ² , 11.36 psi)
CYL COUNT	<ul style="list-style-type: none"> ● Engine is running 		0 → 1 → 2 → 3

TROUBLE DIAGNOSIS

[YD]

MONITOR ITEM	CONDITION		SPECIFICATION
TURBO BST SEN	● Engine: After warming up	Idle	Approx. 100kPa
	● Air conditioner switch: OFF	2,500 rpm	Approx. 114 kPa
	● Shift lever: Neutral position ● No-load	3,000 rpm	Approx. 100 - 104 kPa

NOTE:

Any monitored item that does not match the vehicle being diagnosed is deleted from the display automatically.

Major Sensor Reference Graph in Data Monitor Mode

EBS00DYT

The following are the major sensor reference graphs in "DATA MONITOR" mode.


ACCEL POS SEN, "CKPS-RPM (TDC)", "MAS AIR/FL SE"

Below is the data for "ACCEL POS SEN", "CKPS-RPM (TDC)" and "MAS AIR/FL SE" when revving engine quickly up to 3,000 rpm under no load after warming up engine to the normal operating temperature.


TROUBLE DIAGNOSIS

[YD]


Each value is for reference, the exact value may vary.



- “ACCEL POS SEN” should increase while depressing the accelerator pedal and should decrease while releasing it.



- “CKPS•RPM (TDC)” should increase gradually while depressing the accelerator pedal and should decrease gradually after releasing the pedal without any intermittent drop or rise.



- “MAS AIR/FL SE” should increase while depressing the accelerator pedal and should decrease gradually after releasing the pedal.

SEF321Y

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

[YD]

TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT

PFP:00006

Description

EBS00DYU

Intermittent incidents (I/I) may occur. In many cases, the problem resolves itself (the part or circuit function returns to normal without intervention). It is important to realize that the symptoms described in the customer's complaint often do not recur on DTC visits. Realize also that the most frequent cause of I/I occurrences is poor electrical connections. Because of this, the conditions under which the incident occurred may not be clear. Therefore, circuit checks made as part of the standard diagnostic procedure may not indicate the specific problem area.

COMMON I/I REPORT SITUATIONS

STEP in Work Flow	Situation
II	The CONSULT-II is used. The SELF-DIAG RESULTS screen shows time data other than "0".
III	The symptom described by the customer does not recur.
IV	DTC does not appear during the DTC Confirmation Procedure.
VI	The Diagnostic Procedure for XXXX does not indicate the problem area.

Diagnostic Procedure

EBS00DYV

1. INSPECTION START

Erase DTCs. Refer to [EC-1748, "HOW TO ERASE DTC"](#).

>> GO TO 2.

2. CHECK GROUND TERMINALS

Check ground terminals for corroding or loose connection.

Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "CIRCUIT INSPECTION", "Ground Inspection".

OK or NG

OK >> GO TO 3.

NG >> Repair or replace.

3. SEARCH FOR ELECTRICAL INCIDENT

Perform [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#), "INCIDENT SIMULATION TESTS".

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace.

POWER SUPPLY CIRCUIT FOR ECM

[YD]

POWER SUPPLY CIRCUIT FOR ECM

PFP:24110

ECM Terminals and Reference Value

EBS00DYW

Remarks: Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A5 A6 A7	B B B	ECM ground	[Engine is running] ● Idle speed	Approximately 0V
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
A31	W/L	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
D18 D19	W/R W/R	Ignition switch	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	Approximately 0V
			[Ignition switch "OFF"] ● A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)

POWER SUPPLY CIRCUIT FOR ECM





[YD]

Wiring Diagram

EBS00DYX


EC-MAIN-01

REFER TO PG-POWER.



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)



Diagnostic Procedure

1. INSPECTION START

Start engine.

Is engine running?

Yes or No

- Yes >> GO TO 6.
- No >> GO TO 2.


2. CHECK ECM POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "ON".
2. Check voltage between ECM terminals D18, D19 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- Fuse block (J/B) connector M1
- 10A fuse
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals A5, A6, A7 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
- NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM POWER SUPPLY CIRCUIT-II


1. Reconnect ECM harness connector.
2. Turn ignition switch "ON" and then "OFF".
3. Check voltage between ECM terminals A8, A9 and ground with CONSULT-II or tester.

Voltage:

After turning ignition switch "OFF", battery voltage will exist for a few seconds, then drop to approximately 0V.


OK or NG

- OK >> Check EDU power supply circuit. Refer to [EC-1847](#), "[Diagnostic Procedure](#)".
- NG >> GO TO 6.



6. CHECK ECM POWER SUPPLY CIRCUIT-III

1. Disconnect ECM relay.




2. Check voltage between relay terminals 1, 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 20A fuse
- Harness for open or short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals D24, D26 and ECM relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK ECM POWER SUPPLY CIRCUIT-IV

1. Check harness continuity between ECM terminals A8, A9 and ECM relay terminal 7. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK ECM RELAY

Refer to [EC-1789, "Component Inspection"](#) .

OK or NG

OK >> GO TO 11.

NG >> Replace ECM relay.

11. CHECK ECM POWER SUPPLY CIRCUIT-V


1. Turn ignition switch "OFF".
2. Check voltage between ECM terminal A31 and ground.

Voltage: Battery voltage

OK or NG

OK >> GO TO 13.

NG >> GO TO 12.



12. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 20A fuse
- Harness for open or short between ECM and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

13. CHECK ECM GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals A5, A6, A7 and engine ground.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to power.

OK or NG

OK >> GO TO 14.

NG >> Repair open circuit or short to power in harness or connectors.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


**Component Inspection
ECM RELAY**

EBS00DYZ

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC U1000 CAN COMMUNICATION LINE

[YD]

DTC U1000 CAN COMMUNICATION LINE

PF:23710

Description

EBS00G9W

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

EBS00G9X

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
U1000 1000	CAN communication line	<ul style="list-style-type: none">● ECM can not communicate to other control unit.● ECM can not communicate for more than the specified time.	<ul style="list-style-type: none">● Harness or connectors (CAN communication line is open or shorted)

DTC Confirmation Procedure

EBS00G9Y

1. Turn ignition switch "ON" and wait at least 3 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If 1st trip DTC is detected, go to [EC-1792, "Diagnostic Procedure"](#) .

DTC U1000 CAN COMMUNICATION LINE




[YD]



Wiring Diagram

EBS00G9Z

EC-CAN-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : DATA LINE



Diagnostic Procedure

EBS00GA0

1. INSPECTION START

1. Turn ignition switch "ON".
2. Select "CAN DIAG SUPPORT MNTR" in "DATA MONITOR" mode with CONSULT-II.
3. Print out the CONSULT-II screen.

OK data	NG data																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 70%;">MONITOR</th> <th></th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>OK</td></tr> <tr><td>CAN CIRC 2</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>OK</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR		CAN COMM	OK	CAN CIRC 1	OK	CAN CIRC 2	UNKWN	CAN CIRC 3	UNKWN	CAN CIRC 4	OK	CAN CIRC 5	UNKWN	CAN CIRC 6	UNKWN	CAN CIRC 7	UNKWN	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 70%;">MONITOR</th> <th></th> </tr> </thead> <tbody> <tr><td>CAN COMM</td><td>OK</td></tr> <tr><td>CAN CIRC 1</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 2</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 3</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 4</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 5</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 6</td><td>UNKWN</td></tr> <tr><td>CAN CIRC 7</td><td>UNKWN</td></tr> </tbody> </table>	DATA MONITOR		MONITOR		CAN COMM	OK	CAN CIRC 1	UNKWN	CAN CIRC 2	UNKWN	CAN CIRC 3	UNKWN	CAN CIRC 4	UNKWN	CAN CIRC 5	UNKWN	CAN CIRC 6	UNKWN	CAN CIRC 7	UNKWN
DATA MONITOR																																									
MONITOR																																									
CAN COMM	OK																																								
CAN CIRC 1	OK																																								
CAN CIRC 2	UNKWN																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	OK																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	UNKWN																																								
CAN CIRC 7	UNKWN																																								
DATA MONITOR																																									
MONITOR																																									
CAN COMM	OK																																								
CAN CIRC 1	UNKWN																																								
CAN CIRC 2	UNKWN																																								
CAN CIRC 3	UNKWN																																								
CAN CIRC 4	UNKWN																																								
CAN CIRC 5	UNKWN																																								
CAN CIRC 6	UNKWN																																								
CAN CIRC 7	UNKWN																																								
<small>MBIB0009E</small>																																									

>> Go to [LAN-8, "CAN COMMUNICATION"](#) .

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

[YD]


DTC P0100 MASS AIR FLOW SENSOR (MAFS)

PFP:22680

Component Description

EBS00DZ0

The mass air flow sensor (MAFS) is placed in the stream of intake air. It measures the intake air flow rate by measuring a part of the entire intake air flow. It consists of a hot film that is supplied with electric current from the ECM. The temperature of the hot film is controlled by the ECM a certain amount. The heat generated by the hot film is reduced as the intake air flows around it. The more air, the greater the heat loss. Therefore, the ECM must supply more electric current to maintain the temperature of the hot film as air flow increases. The ECM detects the air flow by means of this current change.



CONSULT-II Reference Value in Data Monitor Mode

EBS00DZ1

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
MAS AIR/FL SE	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: "OFF" ● Shift lever: Neutral position ● No-load Idle	1.0 - 2.5V
	2,000 rpm	2.1 - 2.7V

ECM Terminals and Reference Value

EBS00DZ2

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
A10	R	Mass air flow sensor	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0.5 - 2.5V ★ PBIB0389E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	1.5 - 3.5V ★ PBIB0390E
A24	B	Mass air flow sensor ground	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
A27	W	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V

DTC P0100 MASS AIR FLOW SENSOR (MAFS)

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] <ul style="list-style-type: none"> For a few seconds after turning ignition switch "OFF" 	Approximately 0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

EBS00DZ3

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0100	<ul style="list-style-type: none"> An excessively high or low voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Mass air flow sensor

DTC Confirmation Procedure

EBS00DZ4

WITH CONSULT-II

- Turn ignition switch "ON", and wait at least 6 seconds.
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine and wait at least 3 seconds.
- If DTC is detected, go to [EC-1796, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y






DTC P0100 MASS AIR FLOW SENSOR (MAFS)

[YD]

Wiring Diagram

EBS00DZ5

EC-MAFS-01




MBWA0098E

Diagnostic Procedure

1. CHECK MAFS POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect mass air flow sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between mass air flow sensor terminals 2, 4 and ground with CONSULT-II or tester.

Terminal	Voltage
2	Approximately 5V
4	Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between mass air flow sensor and ECM
- Harness for open or short between mass air flow sensor and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK MAFS GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.
3. Check harness continuity between mass air flow sensor terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check harness for open or short between mass air flow sensor and ECM.

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK MAFS INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between mass air flow sensor terminal 1 and ECM terminal A10. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK MASS AIR FLOW SENSOR

Refer to [EC-1797, "Component Inspection"](#) .

OK or NG

OK >> GO TO 7.

NG >> Replace mass air flow sensor.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection MASS AIR FLOW SENSOR

EBS00DZ7

1. Reconnect harness connectors disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminal A10 (Mass air flow sensor signal) and ground.

Condition	Voltage V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0
Idle (Engine is warmed up to normal operating temperature.)	1.0 - 2.5
2,000 rpm (Engine is warmed up to normal operating temperature.)	2.1 - 2.7

4. If the voltage is out of specification, disconnect MAFS harness connector and connect it again. Then repeat above check.



Removal and Installation MASS AIR FLOW SENSOR

EBS00DZ8

Refer to [EM-213, "AIR CLEANER AND AIR DUCT"](#) .

DTC P0115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR (CIRCUIT)

[YD]


DTC P0115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR (CIRCUIT)

PFP:22630

Description

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.


EBS00DZ9



<Reference data>

Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.3	0.68 - 1.00
90 (194)	1.0	0.236 - 0.260

*: These data are reference values and measured between ECM terminal A11 (Engine coolant temperature sensor) and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

On Board Diagnosis Logic


EBS00DZA

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0115	<ul style="list-style-type: none"> An excessively high or low voltage from the sensor is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Engine coolant temperature sensor

DTC Confirmation Procedure WITH CONSULT-II

EBS00DZB

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1800, "Diagnostic Procedure"](#).



DTC P0115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR (CIRCUIT)



[YD]

Wiring Diagram

EBS00DZC

EC-ECTS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




MBWA0099E

Diagnostic Procedure

1. CHECK ECTS POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect engine coolant temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between ECTS terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and engine coolant temperature sensor.

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK ECTS GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between ECTS terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and engine coolant temperature sensor.

>> Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR (CIRCUIT) [YD]

5. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1801, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Replace engine coolant temperature sensor.

6. CHECK INTERMITTENT INCIDENT


Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection ENGINE COOLANT TEMPERATURE SENSOR

EBS00DZE

1. Check resistance between engine coolant temperature sensor terminals 1 and 2 as shown in the figure.




<Reference data>

Engine coolant temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

*: These data are measured between ECM terminal A11 (Engine coolant temperature sensor) and body ground.

2. If NG, replace engine coolant temperature sensor.



Removal and Installation ENGINE COOLANT TEMPERATURE SENSOR

EBS00DZF

Refer to [EM-274, "CYLINDER HEAD"](#) .

DTC P0120 ACCELERATOR PEDAL POSITION SENSOR

[YD]

DTC P0120 ACCELERATOR PEDAL POSITION SENSOR


PFP:18002

Description

EBS00DZG

The accelerator work unit is installed on the upper end of the accelerator pedal assembly. The accelerator pedal position sensor 1, 2 and accelerator pedal released position switch are built into the accelerator work unit. The sensors detect the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.

The accelerator pedal released position switch detects accelerator pedal released position and sends the signal to the ECM. The ECM will then determine engine idle conditions. The signal is also used for diagnosing the accelerator pedal position sensor.



MBIB0006E

CONSULT-II Reference Value in Data Monitor Mode

EBS00DZH

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
ACCEL POS SEN	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	0.8 - 1.3V
		Accelerator pedal: fully depressed	More than 3.5V
ACCEL SEN 2	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	0.3 - 1.8V
		Accelerator pedal: fully depressed	More than 3.0V
OFF ACCEL SW	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	ON
		Accelerator pedal: slightly depressed	OFF

ECM Terminals and Reference Value

EBS00DZI

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A21	B	Accelerator pedal released position switch ground	[Ignition switch "ON"]	Approximately 0V
A22	LG	Accelerator pedal position sensor 1 ground	[Ignition switch "ON"]	Approximately 0V

DTC P0120 ACCELERATOR PEDAL POSITION SENSOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A26	LG/R	Accelerator pedal position sensor 2 ground	[Ignition switch "ON"]	Approximately 0V
A28	PU/R	Accelerator pedal position sensor 1 power supply	[Ignition switch "ON"]	Approximately 5V
B15	W	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.8 - 1.3V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.5V
B16	L	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.3 - 1.8V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.0V
B23	GY/L	Accelerator pedal position sensor 2 power supply	[Ignition switch "ON"]	Approximately 5V
D14	G/Y	Accelerator pedal released position switch	[Ignition switch "ON"] ● Accelerator pedal slightly depressed	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Accelerator pedal fully released	Approximately 0V

On Board Diagnosis Logic

EBS00DZJ

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0120	<ul style="list-style-type: none"> An improper voltage signal from accelerator pedal position sensor 1 and/or 2 is send to ECM. 	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) Accelerator pedal position sensor 1 Accelerator pedal position sensor 2 Accelerator pedal released position switch

DTC Confirmation Procedure WITH CONSULT-II

EBS00DZK

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Depress and release fully accelerator pedal slowly.
- If DTC is detected, go to [EC-1805, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P0120 ACCELERATOR PEDAL POSITION SENSOR








[YD]

Wiring Diagram

EBS00DZL

EC-APPS-01

— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC



MBWA0104E

Diagnostic Procedure

1. CHECK ACCELERATOR PEDAL POSITION SENSOR FUNCTION

④ With CONSULT-II

1. Turn ignition switch "ON".
2. Select "ACCEL POS SEN" and "ACCEL SEN 2" in "DATA MONITOR" mode with CONSULT-II.
3. Check "ACCEL POS SEN" and "ACCEL SEN 2" signal under the following conditions.

Conditions	ACCEL POS SEN	ACCEL SEN 2
Accelerator pedal fully released	0.8 - 1.3V	0.3 - 1.8V
Accelerator pedal fully depressed	More than 3.5V	More than 3.0V

OK or NG

- OK >> GO TO 2.
 NG >> GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
ACCEL POS SEN	XXX V
ACCEL SEN 2	XXX V

PBIB0403E

2. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH FUNCTION

④ With CONSULT-II

1. Select "OFF ACCEL SW" in "DATA MONITOR" mode with CONSULT-II.
2. Check "OFF ACCEL SW" signal under the following conditions.

Conditions	OFF ACCEL SW
Accelerator pedal fully released	ON
Accelerator pedal depressed	OFF

OK or NG

- OK >> GO TO 16.
 NG >> GO TO 10.


DATA MONITOR	
MONITOR	NO DTC
OFF ACCEL SW	ON

PBIB0404E

A
EC
C
D
E
F
G
H
I
J
K
L
M

3. CHECK ACCELERATOR PEDAL POSITION SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect accelerator work unit harness connector.
3. Turn ignition switch "ON".




4. Check voltage between accelerator work unit terminals 7, 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.



4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness connectors F110, M80
- Harness for open or short between ECM and accelerator work unit

>> Repair harness or connectors.

5. CHECK ACCELERATOR PEDAL POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screw.
3. Check harness continuity between accelerator work unit terminals 2, 8 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M70
- Harness for open or short between ECM and accelerator work unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK ACCELERATOR PEDAL POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal B15 and accelerator work unit terminal 6, ECM terminal B16 and accelerator work unit terminal 3. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 9.

NG >> GO TO 8.

8. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness for open or short between ECM and accelerator work unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

9. CHECK ACCELERATOR PEDAL POSITION SENSOR

Refer to [EC-1809, "Component Inspection"](#) .


OK or NG

OK >> GO TO 16.

NG >> GO TO 15.

10. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect accelerator work unit harness connector.
3. Turn ignition switch "ON".




4. Check voltage between accelerator work unit terminal 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 12.
- NG >> GO TO 11.



11. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness for open or short between accelerator work unit and ECM

>> Repair harness or connectors.

12. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between accelerator work unit terminal 4 and ECM terminal A21. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 14.
- NG >> GO TO 13.

13. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness for open or short between ECM and accelerator work unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

14. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH

Refer to [EC-1809, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 16.
- NG >> GO TO 15.

15. REPLACE ACCELERATOR PEDAL ASSEMBLY

1. Replace accelerator work unit.
2. Perform [EC-1745, "Accelerator Pedal Released Position Learning"](#) .

>> INSPECTION END

16. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection ACCELERATOR PEDAL POSITION SENSOR

EBS00DZN

 With CONSULT-II

1. Reconnect all disconnected harness connectors.
2. Turn ignition switch "ON".
3. Select "DATA MONITOR" mode with CONSULT-II.
4. Check the indication of "ACCEL POS SEN" and "ACCEL SEN 2" under the following conditions.


Conditions	ACCEL POS SEN	ACCEL SEN 2
Accelerator pedal fully released	0.8 - 1.3V	0.3 - 1.8V
Accelerator pedal fully depressed	More than 3.5V	More than 3.0V



ACCELERATOR PEDAL RELEASED POSITION SWITCH

Check continuity between accelerator position switch terminals 4 and 5 under the following conditions.

Conditions	Continuity
Accelerator pedal fully released	Should exist.
Accelerator pedal depressed	Should not exist.



Removal and Installation ACCELERATOR WORK UNIT

EBS00DZO

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .

DTC P0190 COMMON RAIL FUEL PRESSURE SENSOR

[YD]

DTC P0190 COMMON RAIL FUEL PRESSURE SENSOR

PFP:16638

Description

EBS00DZP

The common rail fuel pressure sensor is placed to the common rail. It measures the fuel pressure in the common rail. The sensor sends voltage signal to the ECM. As the pressure increases, the voltage rises. The ECM controls the fuel pressure in the common rail by the suction control valve. The ECM uses the signal from common rail fuel pressure sensor as a feedback signal.

CONSULT-II Reference Value in Data Monitor Mode

EBS00DZQ

Specification data are reference values.

MONITOR	CONDITION	SPECIFICATOIN
ACT CR PRESS	● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load	Idle 30 - 40 MPa
	2,000 rpm	40 - 50 MPa

ECM Terminals and Reference Value

EBS00DZR

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A24	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
A27	W	Sensor's power supply	[Ignition switch "ON"]	Approximately 5V
B13 B14	Y/R Y/R	Common rail fuel pressure sensor	[Engine is running] ● Warm-up condition ● Idle speed	1.6 - 1.8V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	1.8 - 2.0V

On Board Diagnosis Logic

EBS00DZS

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0190	● An excessively high or low voltage from the sensor is entered to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Common rail fuel pressure sensor

DTC Confirmation Procedure

EBS00DZT

WITH CONSULT-II

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected, go to [EC-1812, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P0190 COMMON RAIL FUEL PRESSURE SENSOR

[YD]



Wiring Diagram

EBS00DZU

EC-CRFP5-01

A
EC
C
D
E
F
G
H
I
J
K
L
M


— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



Diagnostic Procedure

1. CHECK COMMON RAIL FUEL PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect common rail fuel pressure sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between common rail fuel pressure sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 2.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK COMMON RAIL FUEL PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between common rail fuel pressure sensor terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and common rail fuel pressure sensor.

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COMMON RAIL FUEL PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals B13, B14 and common rail fuel pressure sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

5. CHECK COMMON RAIL FUEL PRESSURE SENSOR

Refer to [EC-1813, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace common rail assembly.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection COMMON RAIL FUEL PRESSURE SENSOR

EBS00DZW

1. Reconnect harness connector disconnected.
2. Start engine and warm it up to normal operating temperature.
3. Check voltage between ECM terminals B13, B14 (Common rail fuel pressure sensor signal) and ground under the following conditions.

Condition	Voltage V
Idle	1.6 - 1.8
2,000 rpm	1.8 - 2.0

4. If the voltage is out of specification, disconnect common rail fuel pressure sensor harness connector and connect it again. Then repeat above check.
5. If NG, replace common rail.



EBS00DZX

Removal and Installation COMMON RAIL


Refer to [EM-236, "INJECTION TUBE AND FUEL INJECTOR"](#) .

DTC P0201 - P0204 FUEL INJECTOR

PFP:16600

Description

EBS00DZY




PBIB0482E

The ECM sends the fuel injection signal to EDU (Electronic Drive Unit). Then the EDU sends ON signals to fuel injectors to operate them. The EDU monitors injector ground circuit and sends the feedback signal to the ECM.

COMPONENT DESCRIPTION

The fuel injector is a small, precise solenoid valve. When fuel injector receives ON signal from EDU, the coil in the fuel injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the fuel injector into the cylinder. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the fuel injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.



PBIB0465E

CONSULT-II Reference Value in Data Monitor Mode

EBS00DZZ

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
MAIN INJ WID	<ul style="list-style-type: none"> ● Engine: After warming up ● Shift lever: Neutral position ● Idle speed 	No-load	0.68 - 0.78 msec
		Air conditioner switch: ON Rear window defogger switch: ON	0.78 - 0.88 msec

ECM Terminals and Reference Value

EBS00E00





Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

DTC P0201 - P0204 FUEL INJECTOR

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A1 A2 A3 A4	L/W Y/PU PU Y	EDU drive No. 2 EDU drive No. 4 EDU drive No. 3 EDU drive No. 1	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 4V ★  <small>2.0 V/Div 50 ms/Div</small> PBIB0387E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 4V ★  <small>2.0 V/Div 50 ms/Div</small> PBIB0388E
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
A29	W/PU	EDU injector check signal	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	1 - 5V ★  <small>2.0 V/Div 20 ms/Div</small> PBIB0391E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	1 - 5V ★  <small>2.0 V/Div 20 ms/Div</small> PBIB0392E
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" 	Approximately 0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

EBS00E01

DTC	Malfunction is detected when	Check Items (Possible cause)
P0201	● Injector No.1 does not operate normally.	<ul style="list-style-type: none"> ● Harness or connectors (Injector circuit is open or shorted.) ● Electronic drive unit ● Fuel injector
P0202	● Injector No.2 does not operate normally.	
P0203	● Injector No.3 does not operate normally.	
P0204	● Injector No.4 does not operate normally.	

DTC Confirmation Procedure

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1819, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y




DTC P0201 - P0204 FUEL INJECTOR

[YD]

Wiring Diagram

EBS00E03

EC-INJECT-01





MBWA0117E

DTC P0201 - P0204 FUEL INJECTOR

[YD]

EC-INJECT-02

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC




MBWA0118E

Diagnostic Procedure

1. CHECK ECM OUTPUT SIGNAL CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and EDU harness connector.
3. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terminals		Cylinder
	ECM	EDU	
P0201	A4	4	No.1
P0202	A1	1	No.2
P0203	A3	3	No.3
P0204	A2	2	No.4



Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG


OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

2. CHECK EDU OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect fuel injector harness connector of malfunctioning cylinder.
2. Check harness continuity between the following terminals corresponding to the malfunctioning cylinder. Refer to Wiring Diagram.

DTC	Terminals		Cylinder
	EDU	Fuel injector	
P0201	9	4	No.1
P0202	12	4	No.2
P0203	10	4	No.3
P0204	11	4	No.4



Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL INJECTOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity fuel injector terminal 3 of malfunctioning cylinder and EDU terminal 13.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL INJECTOR-I

Refer to [EC-1820, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace fuel injector.

5. CHECK FUEL INJECTOR-II

1. Remove two fuel injectors of malfunctioning cylinder and another cylinder.
2. Install fuel injectors to different cylinder.
3. Reconnect ECM harness connector, EDU harness connector and fuel injector harness connector.
4. Erase DTC. Refer to [EC-1748, "HOW TO ERASE DTC"](#) .
5. Select "DATA MONITOR" mode with CONSULT-II.
6. Start engine and warm it up to the normal operating temperature.
7. Check DTC.

Same DTC is detected. >>Replace EDU.

Another DTC is detected. >>Replace fuel injector of malfunctioning cylinder.

No DTC is detected. >>GO TO 6.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection FUEL INJECTOR

EBS00E05

1. Disconnect fuel injector.
2. Check continuity between terminals as shown in the figure.

Continuity should exist.

3. If NG, replace fuel injector.



Removal and Installation FUEL INJECTOR

EBS00E06

Refer to [EM-236, "INJECTION TUBE AND FUEL INJECTOR"](#) .

DTC P0235 CHARGE AIR PRESSURE SENSOR

[YD]



DTC P0235 CHARGE AIR PRESSURE SENSOR

PFP:22365

Component Description

EBS00G9B

The charge air pressure sensor detects pressure in the exit side of the charge air cooler. The sensor output voltage to the ECM increases as pressure increases.



ECM Terminals and Reference Value

EBS00G9D

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
46	L	Charge air pressure sensor	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 2.0V

On Board Diagnosis Logic

EBS00G9E

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0235	A ● An excessively high or low voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Charge air pressure sensor
	B ● The ECM detects the variable nozzle turbocharger control actuator is stuck. MI will not light up for this malfunction.	● Harness or connectors (The solenoid valve circuit is shorted.) ● Variable nozzle turbocharger control actuator

DTC Confirmation Procedure PROCEDURE FOR MALFUNCTION A

EBS00G9F

④ WITH CONSULT-II

DTC P0235 CHARGE AIR PRESSURE SENSOR

[YD]

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Wait at least 5 seconds.
4. If DTC is detected and MI lights up, go to [EC-1821, "PROCEDURE FOR MALFUNCTION A"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

OVERALL FUNCTION CHECK FOR MALFUNCTION B

④ WITH CONSULT-II

1. Start engine and warm it up to normal operating temperature.
2. Turn ignition switch "OFF".
3. Make sure that variable nozzle turbocharger control actuator rod moves while performing the following procedure.
 - a. Start engine and let it idle.
 - b. Turn ignition switch "OFF".
4. If NG, go to [EC-1822, "OVERALL FUNCTION CHECK FOR MALFUNCTION B"](#) .




DTC P0235 CHARGE AIR PRESSURE SENSOR

[YD]

EBS00G9G

Wiring Diagram

EC-BOOST-01




MBWA0123E

Diagnostic Procedure PROCEDURE A

1. CHECK CHARGE AIR PRESSURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect charge air pressure sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between charge air pressure sensor terminal 1 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 2.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK CHARGE AIR PRESSURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between charge air pressure sensor terminal 3 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check harness for open or short between ECM and charge air pressure sensor.

- >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK CHARGE AIR PRESSURE SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminals B2 and charge air pressure sensor terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness connectors.

5. CHECK CHARGE AIR PRESSURE SENSOR

Refer to [EC-1826, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace charge air pressure sensor.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

PROCEDURE B**1. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT**

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal B17 and variable nozzle turbocharger control solenoid valve terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

2. CHECK CHARGE AIR PRESSURE SENSOR

Refer to [EC-1826, "Component Inspection"](#) .

OK or NG

OK >> GO TO 3.

NG >> Replace charge air pressure sensor.

3. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL ACTUATOR

Refer to [EM-224, "VARIABLE NOZZLE TURBOCHARGER CONTROL ACTUATOR"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace variable nozzle turbocharger.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Component Inspection CHECK CHARGE AIR PRESSURE SENSOR

EBS00G9I


1. Remove charge air pressure sensor with its harness connected.
2. Turn ignition switch "ON".
3. Use pump to apply pressure sensor as shown in the figure.

CAUTION:

- Always calibrate the pressure pump gauge when using it.
- Inspection should be done at room temperature [10-30°C (50-86°F)].

4. Check the output voltage between charge air pressure sensor terminal 2 and engine ground.

Pressure (Relative to atmospheric pressure)	Voltage V
0 kPa (0 mbar, 0 mmHg, 0 inHg)	Approximately 2.0V
+40 kPa (400 mbar, 300mmHg, 11.81 inHg)	Approximately 2.6V



Removal and Installation CHARGE AIR PRESSURE SENSOR

EBS00G9J

Refer to [EM-220, "Removal and Installation"](#) .

DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)

[YD]


DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)

PFP:23731

Description

EBS00E07

The crankshaft position sensor (TDC) monitors engine speed by means of signals from the sensing plate (with 23 protrusions) installed to the fly wheel. The datum signal output is detected 15° signal and sent to the ECM. The sensor signal is used for fuel injection control and fuel injection timing control.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E08

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
CKPS-RPM (TDC)	<ul style="list-style-type: none"> ● Tachometer: Connect ● Run engine and compare tachometer indication with the CONSULT-II value. 	Almost the same speed as the CONSULT-II value.

ECM Terminals and Reference Value

EBS00E09

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA(DC Voltage and Pulse Sig- nal)
B20	L/R	Crankshaft position sensor (TDC) ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
B21	L/G	Crankshaft position sensor (TDC)	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 12.5V ★</p> <p>PBIB0395E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - 30V ★</p> <p>PBIB0396E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)

[YD]

On Board Diagnosis Logic

EBS00E0A

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0335	<ul style="list-style-type: none">An improper voltage signal from the sensor is sent to ECM during running and cranking.	<ul style="list-style-type: none">Harness or connectors (The sensor circuit is open or shorted.)Crankshaft position sensor (TDC)

DTC Confirmation Procedure

EBS00E0B

Before performing the following procedure, confirm that battery voltage is more than 10V.

④ WITH CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Crank engine for at least 1 second.
- Start engine and run it for at least 2 seconds at idle speed.
- If DTC is detected, go to [EC-1830, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)



[YD]

Wiring Diagram

EBS00E0C

EC-CKPS-01

A
EC
C
D
E
F
G
H
I
J
K
L
M




MBWA0112E

Diagnostic Procedure

1. CHECK CRANKSHAFT POSITION SENSOR (TDC) GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.



3. Disconnect crankshaft position sensor (TDC) harness connector and ECM harness connector.
4. Check harness continuity between ECM terminal B20 and crankshaft position sensor (TDC) terminal 1. Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK CRANKSHAFT POSITION SENSOR (TDC) INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between crankshaft position sensor (TDC) terminal 2 and ECM terminal B21. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK CRANKSHAFT POSITION SENSOR (TDC)

Refer to [EC-1830, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace crankshaft position sensor (TDC).

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection CRANKSHAFT POSITION SENSOR (TDC)

1. Loosen the fixing bolt of the sensor.

DTC P0335 CRANKSHAFT POSITION SENSOR (TDC)


[YD]

2. Disconnect crankshaft position sensor (TDC) harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Resistance: 1,850 - 2,450 Ω




Removal and Installation CRANKSHAFT POSITION SENSOR (TDC)

When installing crankshaft position sensor (TDC), tighten it with specific torque.

Tightening torque:

4.9 - 7.9 N·m (0.50 - 0.81 kg·m, 43 - 70 in·lb)



DTC P0340 CAMSHAFT POSITION SENSOR

[YD]


DTC P0340 CAMSHAFT POSITION SENSOR

PFP:23731

Description

EBS00E0G

The camshaft position sensor identifies a particular cylinder by means of signals from the sensing plate (with five protrusions) installed to the camshaft. The datum signal output is detected 90° signal and sent to the ECM. The sensor signal is used for fuel injection control and fuel injection timing control.



ECM Terminals and Reference Value

EBS00E0H

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA(DC Voltage and Pulse Sig- nal)
B18	G	Camshaft position sensor ground	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	Approximately 0V
B19	R	Camshaft position sensor	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 3V ★</p> <p>PBIB0393E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - 8V ★</p> <p>PBIB0394E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

EBS00E0I

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P0340	<ul style="list-style-type: none"> ● An improper voltage signal from the sensor is send to ECM during running and cranking. 	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Camshaft position sensor

DTC Confirmation Procedure

EBS00E0J

Before performing the following procedure, confirm that battery voltage is more than 10V.

DTC P0340 CAMSHAFT POSITION SENSOR

[YD]

④ WITH CONSULT-II

1. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
2. Crank engine for at least 1 second.
3. Start engine and run it for at least 2 seconds at idle speed.
4. If DTC is detected, go to [EC-1835, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

A

EC

C

D

E

F

G

H

I

J

K

L

M



DTC P0340 CAMSHAFT POSITION SENSOR

[YD]

Wiring Diagram

EBS00E0K

EC-CMPS-01




MBWA0113E

Diagnostic Procedure

1. CHECK CAMSHAFT POSITION SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Loosen and retighten engine ground screws.



3. Disconnect camshaft position sensor harness connector and ECM harness connector.
4. Check harness continuity between ECM terminal B18 and camshaft position sensor terminal 1. Refer to Wiring Diagram.


Continuity should exist.

5. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK CAMSHAFT POSITION SENSOR INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between camshaft position sensor terminal 2 and ECM terminal B19. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK CAMSHAFT POSITION SENSOR

Refer to [EC-1835, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace camshaft position sensor.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection CAMSHAFT POSITION SENSOR

1. Loosen the fixing bolt of the sensor.

DTC P0340 CAMSHAFT POSITION SENSOR


[YD]

2. Disconnect camshaft position sensor harness connector.
3. Remove the sensor.
4. Visually check the sensor for chipping.



5. Check resistance as shown in the figure.

Resistance: 1,850 - 2,450 Ω



Removal and Installation CAMSHAFT POSITION SENSOR

Refer to [EM-232, "VACUUM PUMP"](#) .

EBS00E0N

DTC P0500 VEHICLE SPEED SENSOR (VSS)

[YD]

DTC P0500 VEHICLE SPEED SENSOR (VSS)

PFP:32702

Description

EBS00E00

NOTE:

If DTC P0500 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1790, "DTC U1000 CAN COMMUNICATION LINE"](#).

The vehicle speed signal is sent to the combination meter from the ABS actuator and electric unit (control unit) through CAN communication line. The combination meter then sends a signal to the ECM through CAN communication line.

On Board Diagnosis Logic

EBS00E00

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P0500	Vehicle speed sensor	The almost 0 km/h (0 MPH) signal from vehicle speed sensor is sent to ECM even when vehicle is being driven.	<ul style="list-style-type: none">● Harness or connectors (The CAN communication line is open or shorted.)● Wheel sensor● Combination meter● ABS actuator and electric unit (control unit)

Overall Function Check

EBS00E00

Use this procedure to check the overall function of the vehicle speed signal circuit. During this check, a DTC might not be confirmed.

WITH CONSULT-II

1. Lift up the vehicle.
2. Start engine.
3. Read "VHCL SPEED SE" in "DATA MONITOR" mode with CONSULT-II. The vehicle speed on CONSULT-II should exceed 10 km/h (6MPH) when rotating wheels with suitable gear position.
4. If NG, go to [EC-1837, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm
VHCL SPEED SE	XXX km/h
P/N POSI SW	OFF

SEF864Y

Diagnostic Procedure

EBS00E0T

1. CHECK DTC

Check DTC with ABS actuator and electric unit (control unit), Refer to [LAN-246, "ABS Actuator and Electric Unit \(control unit\) Circuit Check"](#).

OK or NG

- OK >> GO TO 2.
NG >> Repair or replace.

2. CHECK COMBINATION METER

Check combination meter function. Refer to [LAN-247, "Combination Meter Circuit Check"](#).

>> INSPECHION END

DTC P1107 ABSOLUTE PRESSURE SENSOR

[YD]


DTC P1107 ABSOLUTE PRESSURE SENSOR

PFP:23710

Description

EBS00E0U

The absolute pressure sensor is built into ECM. The sensor detects ambient barometric pressure and sends the voltage signal to the microcomputer.



On Board Diagnosis Logic

EBS00E0V


DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1107	<ul style="list-style-type: none">An excessively high or low voltage from the absolute pressure sensor (built-into ECM) is sent to ECM.	<ul style="list-style-type: none">ECM

DTC Confirmation Procedure

EBS00E0W

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Start engine and wait at least 2 seconds.
- If DTC is detected, go to [EC-1838, "Diagnostic Procedure"](#).



Diagnostic Procedure

EBS00E0X

1. INSPECTION START

With CONSULT-II

- Turn ignition switch "ON".
- Select "SELF DIAG RESULTS" mode with CONSULT-II.
- Touch "ERASE".
- Perform [EC-1838, "DTC Confirmation Procedure"](#), again.
- Is the DTC P1107 displayed again?

Yes or No

Yes >> GO TO 2.

No >> **INSPECTION END**

DTC P1107 ABSOLUTE PRESSURE SENSOR

[YD]

2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1748](#), "[NATS \(Nissan Anti-theft System\)](#)".
3. Perform "Accelerator Pedal Released Position Learning". Refer to [EC-1745](#).

>> INSPECTION END

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1180 FUEL TEMPERATURE SENSOR

[YD]

DTC P1180 FUEL TEMPERATURE SENSOR

PFP:16700

Description

EBS00E0Y

Fuel temperature sensor is built in the fuel supply pump. The sensor detects the fuel temperature in the fuel supply pump and calibrates the fuel injection amount change by fuel temperature.

CONSULT-II Reference Value in Data Monitor Mode

EBS00E0Z

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
FUEL TEMP SEN	● Engine: After warming up	More than 40°C (104°F)

ECM Terminals and Reference Value

EBS00E10

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
A12	PU	Fuel temperature sensor	[Engine is running] ● Warm-up condition	Approximately 0 - 4.8V Output voltage varies with fuel temperature
A23	B	Sensor's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V

On Board Diagnosis Logic

EBS00E11

DTC	Malfunction is detected when ...	Check Items (Possible cause)
P1180	● An excessively high or low voltage from the sensor is sent to ECM.	● Harness or connectors (The sensor circuit is open or shorted.) ● Fuel temperature sensor

DTC Confirmation Procedure

EBS00E12

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1842, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P1180 FUEL TEMPERATURE SENSOR



[YD]

Wiring Diagram

EBS00E13

EC-FTS-01


A
EC
C
D
E
F
G
H
I
J
K
L
M



Diagnostic Procedure

1. CHECK FUEL TEMPERATURE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel temperature sensor harness connector.
3. Turn ignition switch "ON".




4. Check voltage between fuel temperature sensor terminal 2 and engine ground.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 2.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK FUEL TEMPERATURE SENSOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "ON".
2. Check harness continuity between fuel temperature sensor terminal 1 and ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check harness for open or short to between ECM and fuel temperature sensor.

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace fuel supply pump.
- NG >> Repair or replace.

Removal and Installation FUEL SUPPLY PUMP


Refer to [EM-239, "FUEL SUPPLY PUMP"](#) .

DTC P1216 EDU

PFP:22710

Description

EBS00E16



PBIB0482E

The ECM sends the fuel injection signal to EDU (Electronic Drive Unit). Then the EDU sends ON signals to fuel injectors to operate them. The EDU monitors injector ground circuit and sends the feed back signal to the ECM.

ECM Terminals and Reference Value

EBS00E17

Specification data are reference values and are measured between each terminal and ground.


CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A1 A2 A3 A4	L/W Y/PU PU Y	EDU drive No. 2 EDU drive No. 4 EDU drive No. 3 EDU drive No. 1	[Engine is running] ● Warm-up condition ● Idle speed	0 - 4V ★ PBIB0387E
			[Engine is running] ● Warm-up condition ● Engine speed is 2,000 rpm	0 - 4V ★ PBIB0388E
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
A29	W/PU	EDU injector check signal	[Engine is running] ● Warm-up condition ● Idle speed	1 - 5V ★ PBIB0391E

DTC P1216 EDU

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	1 - 5V ★  PBIB0392E
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" 	Approximately 0V
			[Ignition switch "OFF"] <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

EBS00E18

DTC	Malfunction is detected when	Check Items (Possible cause)
P1216	<ul style="list-style-type: none"> ● EDU feed back signal is not normal pattern. 	<ul style="list-style-type: none"> ● Harness or connectors (Injector drive circuit is open or shorted.) ● Electronic drive unit ● Fuel injectors

DTC Confirmation Procedure WITH CONSULT-II

EBS00E19

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1847, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

Wiring Diagram

EBS00E1A

EC-EDU-01

A

EC

C

D

E

F

G

H




I

J




K

L

M



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



Diagnostic Procedure

1. INSPECTION START


1. Turn ignition switch "START".
2. Is any cylinder ignited?

OK or NG

- OK >> GO TO 5.
NG >> GO TO 2.

2. CHECK EDU POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect EDU harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EDU terminal 6 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between EDU and ECM
- Harness for open or short between EDU and ECM relay

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK EDU GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Check harness continuity between EDU terminal 8 and ground. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to power in harness or connectors.

5. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between the following terminals. Refer to Wiring Diagram.

ECM terminal	EDU terminal
A4	4
A3	3
A2	2
A1	1

Continuity should exist

4. Also check harness for short to ground and short to power.

OK or NG


OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK EDU OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect fuel injector harness connectors.
2. Check harness continuity between the following terminals. Refer to Wiring Diagram.

EDU terminal	Fuel injector terminal
9	4
10	4
11	4
12	4



Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK FUEL INJECTOR GROUND CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between fuel injector terminal 3 of each cylinder and EDU terminal 13. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK FUEL INJECTOR

Refer to [EC-1820, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace fuel injector.

9. CHECK ECM INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and EDU harness connector.
3. Check continuity between ECM terminal A29 and EDU terminal 5. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 10.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

10. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

OK >> Replace EDU.

NG >> Repair or replace.

Removal and Installation

FUEL INJECTOR

EBS00E1C

Refer to [EM-236, "INJECTION TUBE AND FUEL INJECTOR"](#) .

DTC P1217 OVERHEAT (COOLING SYSTEM)

[YD]

DTC P1217 OVERHEAT (COOLING SYSTEM)

PFP:00021

Description SYSTEM DESCRIPTION

EBS00E1D

NOTE:


If DTC P1217 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [EC-1790, "DTC U1000 CAN COMMUNICATION LINE"](#).

COOLING FAN CONTROL

Sensor	Input signal to ECM	ECM function	Actuator
Vehicle speed signal	Vehicle speed	Cooling fan control	Cooling fan relay (s)
Engine coolant temperature sensor	Engine coolant temperature		
Air conditioner switch	Air conditioner "ON" signal		

The ECM controls the cooling fan corresponding to the vehicle speed, engine coolant temperature, air conditioner ON signal. The control system has 3-step control [HIGH/LOW/OFF].

OPERATION



CONSULT-II Reference Value in Data Monitor Mode

EBS00E1E

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
COOLING FAN	When cooling fan is stopped.	OFF
	When cooling fans operate at low speed.	LOW
	When cooling fans operate at high speed.	HIGH

ECM Terminals and Reference Value

EBS00E1F

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E2	LG	Cooling fan relay (Low)	[Engine is running] ● Cooling fan is not operating	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Cooling fan is operating	Approximately 0.1V
E7	LG/B	Cooling fan relay (High)	[Engine is running] ● Cooling fan is not operating ● Cooling fan is operating at low speed	BATTERY VOLTAGE (11 - 14V)
			[Engine is running] ● Cooling fan is operating at high speed	Approximately 0.1V

DTC P1217 OVERHEAT (COOLING SYSTEM)

[YD]

On Board Diagnosis Logic

EBS00E1G

This diagnosis continuously monitors the engine coolant temperature.

If the cooling fan or another component in the cooling system malfunctions, engine coolant temperature will rise.

When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1217	<ul style="list-style-type: none">● Cooling fan does not operate properly (Overheat).● Cooling fan system does not operate properly (Overheat).● Engine coolant was not added to the system using the proper filling method.	<ul style="list-style-type: none">● Harness or connectors (The cooling fan circuit is open or shorted.)● Harness or connectors (The CAN communication line is open or shorted.)● Cooling fan● Radiator hose● Radiator● Radiator cap● Water pump● Thermostat● Engine coolant temperature sensor <p>For more information, refer to EC-1863, "Main 12 Causes of Overheating".</p>

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the [CO-49, "Changing Engine Coolant"](#). Also, replace the engine oil.

1. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute. Be sure to use coolant with the proper mixture ratio. Refer to [MA-18, "Engine Coolant Mixture Ratio"](#).
2. After refilling coolant, run engine to ensure that no water-flow noise is emitted.

Overall Function Check

EBS00E1H

Use this procedure to check the overall function of the cooling fan. During this check, a DTC might not be confirmed.


WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around the cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

WITH CONSULT-II

1. Check the coolant level in the reservoir tank and radiator.
Allow engine to cool before checking coolant level.
If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following steps and go to [EC-1855, "Diagnostic Procedure"](#).



2. Confirm whether customer filled the coolant or not. If customer filled the coolant, skip the following steps and go to [EC-1855, "Diagnostic Procedure"](#).
3. Turn ignition switch "ON".

DTC P1217 OVERHEAT (COOLING SYSTEM)

[YD]

4. Perform "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II and make sure that cooling fans operate when touching "HIGH" or "LOW".
If NG, go to [EC-1855, "Diagnostic Procedure"](#).

ACTIVE TEST	
COOLING FAN	OFF
MONITOR	
COOLANT TEMP/S	XXX °C

SEF111X

DTC P1217 OVERHEAT (COOLING SYSTEM)



[YD]

EBS00E11

Wiring Diagram LHD MODELS

EC-COOL/F-01

A
EC
C
D
E
F
G
H
I
J
K
L
M





REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

DTC P1217 OVERHEAT (COOLING SYSTEM)









[YD]

RHD MODELS

EC-COOL/F-02



REFER TO THE FOLLOWING.
 (E106) - FUSE BLOCK-JUNCTION BOX (J/B)



DTC P1217 OVERHEAT (COOLING SYSTEM)

[YD]

EBS00E1J

Diagnostic Procedure

1. CHECK COOLING FAN LOW SPEED OPERATION

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "COOLING FAN" in "ACTIVE TEST" mode with CONSULT-II.
3. Touch "LOW".
4. Make sure that cooling fans-1 and -2 operate at low speed.

OK or NG

OK >> GO TO 2.

NG >> Check cooling fan low speed control circuit. (Go to [EC-1857, "PROCEDURE A"](#).)

ACTIVE TEST	
COOLING FAN	LOW
MONITOR	
COOLAN TEMP/S	XXX °C

SEF784Z

2. CHECK COOLING FAN HIGH SPEED OPERATION-I

With CONSULT-II

1. Touch "HIGH".
2. Make sure that cooling fan-1 operates at higher speed than low speed.

OK or NG

OK >> GO TO 3.

NG >> Check cooling fan high speed control circuit. (Go to [EC-1859, "PROCEDURE B"](#).)

ACTIVE TEST	
COOLING FAN	HIGH
MONITOR	
COOLAN TEMP/S	XXX °C

SEF785Z

3. CHECK COOLING FAN HIGH SPEED OPERATION-II

With CONSULT-II

Make sure that cooling fan-2 operates at higher speed than low speed.

OK or NG

OK >> GO TO 4.

NG >> Check cooling fan high speed control circuit. (Go to [EC-1861, "PROCEDURE C"](#).)

4. CHECK COOLING SYSTEM FOR LEAK

Apply pressure to the cooling system with a tester, and check if the pressure drops.

Testing pressure: 157 kPa (1.57 bar, 1.6 kg/cm², 23psi)

CAUTION:


Higher than the specified pressure may cause radiator damage.

Pressure should not drop.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following for leak.

- Hose
- Radiator
- Water pump (Refer to [CO-59, "WATER PUMP"](#) .)

>> Repair or replace.

6. CHECK RADIATOR CAP

Apply pressure to cap with a tester and check radiator cap relief pressure.


Radiator cap relief pressure:

78 - 98 kPa (0.59 - 0.98 bar, 0.6 - 1.0 kg/cm² , 9 - 14 psi)

OK or NG

OK >> GO TO 7.

NG >> Replace radiator cap.



7. CHECK THERMOSTAT

1. Remove thermostat.
2. Check valve seating condition at normal room temperatures.
It should seat tightly.
3. Check valve opening temperature and valve lift.

Valve opening temperature:

80.5 - 83.5 °C (177 - 182 °F)

Valve lift:


More than 8 mm/95 °C (0.31 in/203 °F)

4. Check if valve is closed at 5°C (9°F) below valve opening temperature. For details, refer to [CO-61, "THERMOSTAT AND WATER PIPING"](#) .

OK or NG

OK >> GO TO 8.

NG >> Replace thermostat.



8. CHECK ENGINE COOLANT TEMPERATURE SENSOR

Refer to [EC-1801, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace engine coolant temperature sensor.

9. CHECK MAIN 12 CAUSES


If the cause cannot be isolated, go to [EC-1863, "Main 12 Causes of Overheating"](#) .

>> INSPECTION END

PROCEDURE A

1. CHECK COOLING FAN POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-1.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-1 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART


Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-1 and fuse
- Harness for open or short between cooling fan relay-1 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK COOLING FAN MOTORS CONTROL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-1 harness connector and cooling fan motor-2 harness connector.
3. Disconnect cooling fan relay-2 and cooling fan relay-4.
4. Check harness continuity between the following.
 - Cooling fan relay-1 terminal 5 and cooling fan motor-1 terminal 1
 - Cooling fan motor-1 terminal 2 and cooling fan relay-2 terminal 3
 - Cooling fan motor-1 terminal 2 and cooling fan relay-4 terminal 3
 - Cooling fan relay-2 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan relay-4 terminal 4 and cooling fan motor-2 terminal 1
 - Cooling fan motor-2 terminal 2 and ground
 Refer to Wiring Diagram.



Continuity should exist.

5. Also check harness for short to ground and short to power.


OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-1 terminal 1 and smart entrance control unit terminal 33. Refer to Wiring Diagram.



Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-1 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK COOLING FAN RELAY-1, -2 AND 4

Refer to [EC-1864, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace cooling fan relay.

7. CHECK COOLING FAN MOTORS-1 AND -2

Refer to [EC-1864, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace cooling fan motors.

8. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Replace smart entrance control unit.

9. CHECK INTERMITTENT INCIDENT

Perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

PROCEDURE B

1. CHECK COOLING FAN RELAY GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-2 and cooling fan relay-4.
3. Check harness continuity between cooling fan relay-2 terminal 5 and ground, cooling fan relay-4 terminal 5 and ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 2.
- NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK COOLING FAN MOTOR OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT


1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-2 terminal 2 and smart entrance control unit terminal 32, cooling fan relay-4 terminal 2 and smart entrance control unit terminal 32. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 3.



3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-2 and smart entrance control unit
- Harness for open or short between cooling fan relay-4 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK COOLING FAN RELAYS-2 AND -4

Refer to [EC-1864, "Component Inspection"](#) .

OK or NG

OK >> GO TO 5.

NG >> Replace cooling fan relays.

5. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace smart entrance control unit.

6. CHECK INTERMITTENT INCIDENT


Perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

PROCEDURE C

1. CHECK COOLING FAN MOTOR-2 POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan relay-3.
3. Turn ignition switch "ON".




4. Check voltage between cooling fan relay-3 terminals 2, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART


Check the following.

- Fuse block (J/B) connector E106
- 10A fuse
- 40A fusible link
- Harness for open or short between cooling fan relay-3 and fuse
- Harness for open or short between cooling fan relay-3 and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect cooling fan motor-2 harness connector.



3. Check harness continuity between cooling fan relay-3 terminal 5 and cooling fan motor-2 terminal 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to power in harness or connectors.

4. CHECK COOLING FAN MOTOR CONTROL CIRCUIT FOR SHORT TO GROUND

Check harness continuity between cooling fan relay-3 terminal 5 or cooling fan motor-2 terminal 1 and ground. Refer to Wiring Diagram.

Continuity should not exist.

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following.

- Cooling fan relays-2 and -4 (Refer to [EC-1864](#))
- Harness for short to ground between cooling fan relay-2 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-3 and cooling fan motor-2
- Harness for short to ground between cooling fan relay-4 and cooling fan motor-2

>> Repair or replace.

6. CHECK COOLING FAN OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect smart entrance control unit harness connector.
2. Check harness continuity between cooling fan relay-3 terminal 1 and smart entrance control unit terminal 32. Refer to Wiring Diagram.


Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> GO TO 7.



7. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E123, M17 (LHD models)
- Harness connectors E110, M94 (RHD models)
- Harness for open or short between cooling fan relay-3 and smart entrance control unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK COOLING FAN RELAY-3

Refer to [EC-1864, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace cooling fan relay.

9. CHECK SMART ENTRANCE CONTROL UNIT

Refer to [BCS-39, "Trouble Diagnoses"](#) .

OK or NG

OK >> GO TO 10.

NG >> Replace smart entrance control unit.

10. CHECK INTERMITTENT INCIDENT

Perform [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END

Main 12 Causes of Overheating

EBS00E1K

Engine	Step	Inspection item	Equipment	Condition	Reference page
OFF	1	<ul style="list-style-type: none"> ● Blocked radiator ● Blocked radiator grille ● Blocked bumper 	● Visual	No blocking	—
	2	● Coolant mixture	● Coolant tester	50 - 50% coolant mixture	See MA-16, "RECOMMENDED FLUIDS AND LUBRICANTS" .
	3	● Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See CO-49, "Changing Engine Coolant" .
	4	● Radiator cap	● Pressure tester	78 - 98 kPa (0.78 - 0.98 bar, 0.8 - 1.0 kg/cm ² , 11 - 14 psi)	See CO-53, "Checking Radiator Cap" .
ON*2	5	● Coolant leaks	● Visual	No leaks	See CO-49, "LEAK CHECK" .
ON*2	6	● Thermostat	● Touch the upper and lower radiator hoses	Both hoses should be hot	See CO-61, "THERMOSTAT AND WATER PIPING" .
ON*1	7	● Cooling fan	● CONSULT-II	Operating	See Trouble Diagnosis for DTC P1217, EC-1800 .
OFF	8	● Combustion gas leak	● Color checker chemical tester 4 Gas analyzer	Negative	—

DTC P1217 OVERHEAT (COOLING SYSTEM)

[YD]

Engine	Step	Inspection item	Equipment	Condition	Reference page
ON*3	9	● Coolant temperature gauge	● Visual	Gauge less than 3/4 when driving	—
		● Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See CO-49. "Changing Engine Coolant" .
OFF*4	10	● Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See CO-50. "REFILLING ENGINE COOLANT" .
OFF	11	● Cylinder head	● Straight gauge feeler gauge	0.1mm (0.004 in) Maximum distortion (warping)	See EM-274. "CYLINDER HEAD" .
	12	● Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See EM-288. "CYLINDER BLOCK" .

*1: Turn the ignition switch ON.

*2: Engine running at 3,000 rpm for 10 minutes.

*3: Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes.

*4: After 60 minutes of cool down time.


For more information, refer to [CO-45. "OVERHEATING CAUSE ANALYSIS"](#) .

Component Inspection COOLING FAN RELAY-1 AND -3

EBS00E1L

Check continuity between terminals 3 and 5 under the following conditions.


Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No



COOLING FAN RELAY-2 AND -4

Check continuity between terminals 3 and 5, 3 and 5 under the following conditions.


Conditions	Terminals	Continuity
12V direct current supply between terminals 1 and 2	3 and 4	No
	3 and 5	Yes
No current supply	3 and 4	Yes
	3 and 5	No



COOLING FAN MOTOR-1 AND -2

1. Disconnect cooling fan motor harness connectors.
2. Supply cooling fan motor terminals with battery voltage and check operation.

	Terminals	
	(+)	(-)
Cooling fan motor	1	2



DTC P1233 - P1234 SUCTION CONTROL VALVE

[YD]

DTC P1233 - P1234 SUCTION CONTROL VALVE

PFP:16700

Description

EBS00E1M

To control the amount of the fuel inhalation of the fuel supply pump, a suction control valve is built into the fuel supply pump. When the amount of the fuel inhalation of fuel supply pump increases, the fuel supply pump raises the fuel exhalation pressure. As a result, the fuel injection pressure is raised. When the load of the engine increases, the ECM sends a signal to the suction control valve to raise the injection pressure.

CONSULT-II Reference Value in Data Monitor Mode

EBS00E1M

Remarks: Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
SUCTION CV	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load Idle	70.0 - 71.5°C
	2,000 rpm	73.5 - 75.0°C





ECM Terminals and Reference Value

EBS00E10

Specification data are reference values and are measured between each terminal and ground.



CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI-NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E1	L	Suction control valve power supply	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0399E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 12.5V ★  PBIB0400E
E8	Y/G	Suction control valve 1 signal	[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0 - 12.5V ★  PBIB0401E
			[Engine is running] <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	0 - 12.5V ★  PBIB0402E

DTC P1233 - P1234 SUCTION CONTROL VALVE

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E16	G/W	Suction control valve 2 signal	<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	<p>0 - 12.5V ★</p>  <p>PBIB0401E</p>
			<p>[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Engine speed is 2,000 rpm 	<p>0 - 12.5V ★</p>  <p>PBIB0402E</p>

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

On Board Diagnosis Logic

EBS00E1P

DTC	Malfunction is detected when	Check Items (Possible cause)
P1233	<ul style="list-style-type: none"> ● Suction control valve 1 and/or 2 dose not operate normally. 	<ul style="list-style-type: none"> ● Harness or connectors (Fuel supply pump suction control valve circuit is open or shorted.) ● Suction control valve 1 ● Suction control valve 2
P1234		

DTC Confirmation Procedure WITH CONSULT-II

EBS00E1Q

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1868, "Diagnostic Procedure"](#) .

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P1233 - P1234 SUCTION CONTROL VALVE

[YD]




Wiring Diagram

EBS00E1R

EC-SCTC/V-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



MBWA0111E

Diagnostic Procedure

1. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector and fuel supply pump harness connectors.
3. Check continuity between ECM terminal E1 and fuel supply pump terminals 1, 3.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 2.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



2. CHECK SUCTION CONTROL VALVE GROUND CIRCUIT FOR OPEN AND SHORT

1. Check continuity between ECM terminal E8 and fuel supply pump terminal 2, ECM terminal E16 and fuel supply pump terminal 4.
Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 3.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK SUCTION CONTROL VALVE

Refer to [EC-1868, "Component Inspection"](#) .

OK or NG

OK >> GO TO 4.

NG >> Replace fuel supply pump.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection SUCTION CONTROL VALVE

1. Check continuity between fuel supply pump terminals 1 and 2, 3 and 4.

Continuity should exist.

2. If NG, replace fuel supply pump.



Removal and Installation
FUEL SUPPLY PUMP

EBS00E1U

A

Refer to [EM-239, "FUEL SUPPLY PUMP"](#) .

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1301 - P1304 FUEL INJECTOR ADJUSTMENT RESISTOR

[YD]

DTC P1301 - P1304 FUEL INJECTOR ADJUSTMENT RESISTOR

PFPP:16600

Description

EBS00E1V

The fuel injector adjustment resistor is built into the fuel injector. The resistance is constant and individual. ECM uses the individual resistance to determine the fuel injection pulse.

ECM Terminals and Reference Value

EBS00E1W

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
A25	PU/W	Fuel injector's ground	[Engine is running] ● Warm-up condition ● Idle speed	Approximately 0V
B9	Y/B	Fuel injector adjustment resistor No.2	[Ignition switch "ON"]	0.2 - 4.8V (There is an individual difference in fuel injector adjustment resistor.)
B10	R/B	Fuel injector adjustment resistor No.4		
B11	G/B	Fuel injector adjustment resistor No.3		
B12	W/B	Fuel injector adjustment resistor No.1		

On Board Diagnosis Logic

EBS00E1X

DTC	Malfunction is detected when	Check Items (Possible cause)
P1301	● An excessively high or low voltage from fuel injector No.1 adjustment resistor is sent to ECM	● Harness or connectors (Injector adjustment resistor circuit is open or shorted.) ● Fuel injector adjustment resistor
P1302	● An excessively high or low voltage from fuel injector No.2 adjustment resistor is sent to ECM	
P1303	● An excessively high or low voltage from fuel injector No.3 adjustment resistor is sent to ECM	
P1304	● An excessively high or low voltage from fuel injector No.4 adjustment resistor is sent to ECM	

DTC Confirmation Procedure

EBS00E1Y

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1872, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P1301 - P1304 FUEL INJECTOR ADJUSTMENT RESISTOR

[YD]




Wiring Diagram

EBS00E1Z

EC-FIAR-01

A
EC
C
D
E
F
G
H
I
J
K
L
M

— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC




MBWA0115E

Diagnostic Procedure

1. CHECK FUEL INJECTOR ADJUSTMENT RESISTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect fuel injector harness connector of malfunctioning cylinder.
3. Turn ignition switch "ON".




4. Check voltage between fuel injector terminal 2 and ground with CONSULT-II or tester.

Voltage: Approximately 5V

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check harness continuity for open and short between ECM and fuel injector.

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK FUEL INJECTOR ADJUSTMENT RESISTOR GROUND CIRCUIT

1. Turn ignition switch "OFF".
2. Check harness continuity between fuel injector terminal 1 and ECM terminal A25.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK FUEL INJECTOR ADJUSTMENT RESISTOR

Refer to [EC-1873, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Replace fuel injector.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> INSPECTION END


Component Inspection FUEL INJECTOR ADJUSTMENT RESISTOR

EBS00E21

1. Disconnect fuel injector harness connector.
2. Check continuity between terminals as shown in the figure.

Continuity should exist.

If NG, replace fuel injector.



EBS00E22

Removal and Installation FUEL INJECTOR

Refer to [EM-236, "INJECTION TUBE AND FUEL INJECTOR"](#) .

DTC P1305 FUEL LEAK

PFP:17520

On Board Diagnosis Logic

EBS00E23


DTC	Malfunction is detected when	Check Items (Possible cause)
P1305	<ul style="list-style-type: none"> ● The relation between the output signal to suction control valve and input signal from common rail fuel pressure sensor is not in normal range. 	<ul style="list-style-type: none"> ● Suction control valve ● Fuel tube ● Common rail ● Fuel pressure relief valve

DTC Confirmation Procedure

EBS00E24

WITH CONSULT-II

1. Turn ignition switch "ON" and wait at least 2 seconds.
2. Select "DATA MONITOR" mode with CONSULT-II.
3. Start engine and run it for at least 2 seconds at idle speed.
(If engine does not run, turn ignition switch to "START" for at least 2 seconds.)
4. If DTC is detected, go to [EC-1874, "Diagnostic Procedure"](#) .



Diagnostic Procedure

EBS00E25

1. INSPECTION START

1. Start engine.
2. Visually check the following for fuel leak.
 - Fuel tube from fuel supply pump to common rail
 - Common rail
 - Fuel tube from common rail to fuel injector
3. Also check for improper connection or pinches.

OK or NG

- OK >> GO TO 2.
 NG >> Repair malfunctioning part.

2. CHECK FUEL PRESSURE RELIEF VALVE

Refer to [EC-1746, "Fuel Pressure Relief Valve"](#) .

OK or NG

- OK >> GO TO 3.
 NG >> Replace common rail.

3. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

OK or NG

- OK >> Replace fuel supply pump.
 NG >> Repair or replace.

Removal and Installation COMMON RAIL

EBS00E26

Refer to [EM-236, "INJECTION TUBE AND FUEL INJECTOR"](#) .

DTC P1305 FUEL LEAK

[YD]

FUEL SUPPLY PUMP

Refer to [EM-239, "FUEL SUPPLY PUMP"](#) .

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC P1510 ACCELERATOR PEDAL RELEASED POSITION SWITCH

[YD]

DTC P1510 ACCELERATOR PEDAL RELEASED POSITION SWITCH


PFP:18002

Description

EBS00E27

The accelerator work unit is installed on the upper end of the accelerator pedal assembly. The accelerator pedal position sensor 1, 2 and accelerator pedal released position switch are built into the accelerator work unit. The sensor detects the accelerator pedal position and sends a signal to the ECM. The ECM uses the signal to determine the amount of fuel to be injected.

The accelerator pedal released position switch detects accelerator pedal released position signal and sends this signal to the ECM. The ECM will then determine engine idle conditions. This signal is also used for diagnosing the accelerator pedal position sensor.



MBIB0006E

CONSULT-II Reference Value in Data Monitor Mode

EBS00E28

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	
ACCEL POS SEN	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	0.8 - 1.3V
		Accelerator pedal: fully depressed	More than 3.5V
ACCEL SEN 2	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	0.3 - 1.8V
		Accelerator pedal: fully depressed	More than 3.0V
OFF ACCEL SW	● Ignition switch: ON (Engine stopped)	Accelerator pedal: fully released	ON
		Accelerator pedal: slightly depressed	OFF

ECM Terminals and Reference Value

EBS00E29

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A21	B	Accelerator pedal released position switch ground	[Ignition switch "ON"]	Approximately 0V
A22	LG	Accelerator pedal position sensor 1 ground	[Ignition switch "ON"]	Approximately 0V

DTC P1510 ACCELERATOR PEDAL RELEASED POSITION SWITCH

[YD]

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A26	LG/R	Accelerator pedal position sensor 2 ground	[Ignition switch "ON"]	Approximately 0V
A28	PU/R	Accelerator pedal position sensor 1 power supply	[Ignition switch "ON"]	Approximately 5V
B15	W	Accelerator pedal position sensor 1	[Ignition switch "ON"] ● Accelerator pedal fully released	0.8 - 1.3V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.5V
B16	G	Accelerator pedal position sensor 2	[Ignition switch "ON"] ● Accelerator pedal fully released	0.3 - 1.8V
			[Ignition switch "ON"] ● Accelerator pedal fully depressed	More than 3.0V
B23	GY/L	Accelerator pedal position sensor 2 power supply	[Ignition switch "ON"]	Approximately 5V
D14	G/Y	Accelerator pedal released position switch	[Ignition switch "ON"] ● Accelerator pedal slightly depressed	BATTERY VOLTAGE (11 - 14V)
			[Ignition switch "ON"] ● Accelerator pedal fully released	Approximately 0V

On Board Diagnosis Logic

EBS00E2A

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1510	<ul style="list-style-type: none"> The relation between accelerator pedal position sensor 1, 2 signals and accelerator pedal position switch signal is not in the normal range during the specified accelerator pedal positions. 	<ul style="list-style-type: none"> Harness or connectors (Accelerator pedal released position switch circuit is open or shorted.) Accelerator pedal released position switch

DTC Confirmation Procedure

EBS00E2B

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Depress and release fully accelerator pedal slowly.
- If DTC is detected, go to [EC-1879, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y

DTC P1510 ACCELERATOR PEDAL RELEASED POSITION SWITCH






[YD]

Wiring Diagram

EBS00E2C

EC-APRSW-01

— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC




MBWA0116E

Diagnostic Procedure

1. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect accelerator work unit harness connector.
3. Turn ignition switch "ON".




4. Check voltage between accelerator work unit terminal 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness for open or short between accelerator work unit and ECM

>> Repair harness or connectors.

3. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH GROUND CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between accelerator work unit terminal 4 and ECM terminal A21. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
- NG >> GO TO 4.

4. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors F109, M77
- Harness for open or short between ECM and accelerator work unit

>> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK ACCELERATOR PEDAL RELEASED POSITION SWITCH

Refer to [EC-1880, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 6.

6. REPLACE ACCELERATOR PEDAL ASSEMBLY

1. Replace accelerator pedal assembly.
2. Perform [EC-1745, "Accelerator Pedal Released Position Learning"](#) .

>> INSPECTION END

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ACCELERATOR PEDAL RELEASED POSITION SWITCH

EBS00E2E

Check continuity between accelerator position switch terminals 4 and 5 under the following conditions.

Conditions	Continuity
Accelerator pedal fully released	Should exist.
Accelerator pedal depressed	Should not exist.



EBS00E2F

Removal and Installation ACCELERATOR WORK UNIT

Refer to [ACC-2, "ACCELERATOR CONTROL SYSTEM"](#) .


DTC P1606 ECM

PPF:23710

Description

EBS00E2G

The ECM consists of a microcomputer and connectors for signal input and output and for power supply. The ECM controls the engine.



On Board Diagnosis Logic

EBS00E2H


DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1606	● ECM calculation function is malfunctioning.	● ECM

DTC Confirmation Procedure

EBS00E2I

① **WITH CONSULT-II**

1. Turn ignition switch "ON".
2. Select "DATA MONITOR" mode with CONSULT-II.
3. If DTC is detected, go to [EC-1881, "Diagnostic Procedure"](#) .



Diagnostic Procedure

EBS00E2J

1. INSPECTION START

① **With CONSULT-II**

1. Turn ignition switch "ON".
2. Select "SELF DIAG RESULTS" mode with CONSULT-II.
3. Touch "ERASE".
4. Perform [EC-1881, "DTC Confirmation Procedure"](#) , again.
5. Is DTC P1606 displayed again?

Yes or No

- Yes >> GO TO 2.
- No >> **INSPECTION END**

2. REPLACE ECM

1. Replace ECM.
2. Perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to [EC-1748, "NATS \(Nissan Anti-theft System\)"](#) .
3. Perform "Accelerator Pedal Released Position Learning". Refer to [EC-1745, "Accelerator Pedal Released Position Learning"](#) .

>> INSPECTION END

DTC P1621 ECM RELAY

[YD]

DTC P1621 ECM RELAY

PFP:25230

ECM Terminals and Reference valve

EBS00E2K

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
D18 D19	W/R W/R	Ignition switch	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
D24 D26	G G	ECM relay (self-shutoff)	[Ignition switch "ON"] [Ignition switch "OFF"] ● For a few seconds after turning ignition switch "OFF"	Approximately 0V
			[Ignition switch "OFF"] ● A few seconds passed after turning ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)

On Board Diagnosis Logic

EBS00E2L

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1621	<ul style="list-style-type: none"> An irregular voltage signal from the ECM relay is sent to ECM. 	<ul style="list-style-type: none"> Harness or connectors (ECM relay circuit is open or shorted.) ECM relay

DTC Confirmation Procedure

EBS00E2M

WITH CONSULT-II

- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT-II.
- Turn ignition switch "OFF", wait at least 20 seconds and then turn "ON".
- If DTC is detected, go to [EC-1885, "Diagnostic Procedure"](#).

DATA MONITOR	
MONITOR	NO DTC
CKPS-RPM (TDC)	XXX rpm

SEF817Y




DTC P1621 ECM RELAY

[YD]

Wiring Diagram

EBS00E2N

EC-ECMRLY-01




REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)

Diagnostic Procedure

1. CHECK ECM POWER SUPPLY CIRCUIT


1. Turn ignition switch "OFF".
2. Disconnect ECM relay.



3. Check voltage between ECM relay terminals 1, 6 and ground with CONSULT-II or tester.

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 2.



2. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 20A fuse
- Harness for open and short between ECM relay and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

3. CHECK ECM INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals A8, A9 and ECM relay terminal 7. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK ECM OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Check harness continuity between ECM terminals D24, D26 and ECM relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

2. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 6.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

5. CHECK ECM RELAY

Refer to [EC-1886, "Component Inspection"](#) .

OK or NG

OK >> GO TO 6.

NG >> Replace ECM relay.

6. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection ECM RELAY

1. Apply 12V direct current between ECM relay terminals 1 and 2.
2. Check continuity between relay terminals 3 and 5, 6 and 7.

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
OFF	No

3. If NG, replace ECM relay.



DTC P1660 BATTERY VOLTAGE

[YD]

DTC P1660 BATTERY VOLTAGE

PFP:AYBGL

On Board Diagnosis Logic

EBS00E2Q

The ECM checks if battery voltage is within the tolerance range for the engine control system.

DTC	Malfunction is detected when ...	Check Items (Possible Cause)
P1660	<ul style="list-style-type: none">An abnormally high or low voltage from the battery is sent to ECM.	<ul style="list-style-type: none">Incorrect jump startingBatteryAlternatorECM

A

EC

C

D

E

F

G

H

I

J

K

L

M

DTC Confirmation Procedure

EBS00E2R

Ⓑ WITH CONSULT-II

- Check the following.
 - Jumper cables are connected for jump starting.
 - Battery or alternator has been replaced.
If the result is "Yes" for one item or more, skip the following steps and go to [EC-1887, "Diagnostic Procedure"](#).
- Check that the positive battery terminal is connected to battery properly. If NG, reconnect it properly.
- Check that the alternator functions properly. Refer to [SC-12, "CHARGING SYSTEM"](#).
- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT-II.
- Wait one minute.
- If DTC is detected, go to [EC-1887, "Diagnostic Procedure"](#).
If DTC is not detected, go to next step.
- Start engine and wait one minute at idle.
- If DTC is detected, go to [EC-1887, "Diagnostic Procedure"](#).

Diagnostic Procedure

EBS00E2S

1. INSPECTION START

Are jumper cables connected for the jump starting?

Yes or No

- Yes >> GO TO 3.
No >> GO TO 2.

2. CHECK BATTERY AND ALTERNATOR

Check that the proper type of battery and alternator is installed.


Refer to [SC-3, "BATTERY"](#), [SC-12, "CHARGING SYSTEM"](#).

OK or NG

- OK >> GO TO 5.
NG >> Replace with a proper one.

3. CHECK JUMPER CABLES INSTALLATION

Check that the jumper cables are connected in the correct sequence.



OK or NG

OK >> GO TO 4.

NG >> Reconnect jumper cables properly.

4. CHECK BATTERY FOR BOOSTER

Check that the battery for the booster is a 12V battery.

OK or NG

OK >> GO TO 5.

NG >> Change the vehicle for booster.

5. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

Perform [EC-1887, "DTC Confirmation Procedure"](#), again.

OK or NG

OK >> GO TO 6.

NG >> Replace ECM.

6. CHECK ELECTRICAL PARTS DAMAGE

Check the following for damage.

- Wiring harness and harness connectors for burn
- Fuses for short

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace malfunctioning part.

GLOW CONTROL SYSTEM

[YD]

GLOW CONTROL SYSTEM

PFP:25230

Description SYSTEM DESCRIPTION

EBS00E2T

Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (TDC)	Engine speed	Glow control	Glow lamp Glow relay Glow plugs
Engine coolant temperature sensor	Engine coolant temperature		

When engine coolant temperature is more than approximately 80°C (176°F), the glow relay turns off.
When coolant temperature is lower than approximately 80°C (176°F):

- Ignition switch ON
After ignition switch has turned to ON, the glow relay turns ON for a certain period of time in relation to engine coolant temperature, allowing current to flow through glow plug.
- Cranking
The glow relay turns ON, allowing current to flow through glow plug.
- Starting
After engine has started, current continues to flow through glow plug (after-glow mode) for a certain period in relation to engine coolant temperature.


The glow indicator lamp turns ON for a certain period of time in relation to engine coolant temperature at the time glow relay is turned ON.

ECM controls glow indicator lamp through CAN communication line.

COMPONENT DESCRIPTION

Glow Plug

The glow plug is provided with a ceramic heating element to obtain a high-temperature resistance. It glows in response to a signal sent from the ECM, allowing current to flow through the glow plug via the glow relay.



ECM Terminals and Reference Value

EBS00E2U

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E9	W/R	Glow relay	Refer to EC-1889. "SYSTEM DESCRIPTION"	



GLOW CONTROL SYSTEM

[YD]

Wiring Diagram


EBS00E2V

EC-GLOW-01



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B)



MBWA0101E

Diagnostic Procedure

1. INSPECTION START

Check fuel level, fuel supplying system, starter motor, etc.

OK or NG


- OK >> GO TO 2.
- NG >> Correct.

2. CHECK INSTALLATION

Check that glow plug nut and all glow plug connecting plate nuts are installed properly.

OK or NG

- OK >> GO TO 3.
- NG >> Install properly.




3. CHECK GLOW INDICATOR LAMP OPERATION

With CONSULT-II

1. Turn ignition switch "ON".
2. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
3. Confirm that "COOLAN TEMP/S" indicates below 80°C (176°F). If it indicates above 80°C (176°F), cool down engine.
4. Turn ignition switch "OFF", wait at least 5 seconds and then turn "ON".
5. Make sure that glow indicator lamp is turned "ON" for 1.5 seconds or more after turning ignition switch "ON", and then glow indicator lamp turned "OFF".


OK or NG

- OK >> GO TO 4.
- NG >> GO TO 5.



4. CHECK GLOW CONTROL SYSTEM OVERALL FUNCTION

1. Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT-II.
2. Confirm that "COOLAN TEMP/S" indicates approximately 25°C (77°F). If NG, cool down engine.
3. Turn ignition switch "OFF".
4. Set voltmeter probe between glow plug and engine body.
5. Turn ignition switch "ON".




6. Check the voltage between glow plug and engine body under the following conditions.

Conditions	Voltage
For 20 seconds after turning ignition switch "ON"	Battery voltage
More than 20 seconds after turning ignition switch "ON"	Approx. 0V

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 7.



5. CHECK DTC

Check that DTC U1000 is not displayed.

Yes or No

- Yes >> Perform trouble diagnoses for DTC U1000, refer to [EC-1790, "DTC U1000 CAN COMMUNICATION LINE"](#) .
 No >> GO TO 6.

6. CHECK COMBINATON METER OPERATION


Does combination meter operate normally?

Yes or No

- Yes >> GO TO 14.
 No >> Check combination meter circuit. Refer to [DI-5, "COMBINATION METERS \(LHD MODELS\)"](#) or [DI-34, "COMBINATION METERS \(RHD MODELS\)"](#) .

7. CHECK GLOW RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect glow relay.




3. Check voltage between glow relay terminals 1, 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 9.
- NG >> GO TO 8.



8. DETECT MALFUNCTIONING PART

Check the following.

- 60A fusible link
- Harness for open or short between glow relay and battery

>> Repair harness or connectors.

9. CHECK GLOW RELAY OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal E9 and glow relay terminal 2. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 11.
- NG >> GO TO 10.

10. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- Harness for open or short between glow relay and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

11. CHECK HARNESS CONTINUITY BETWEEN GLOW RELAY AND GLOW PLUG FOR OPEN AND SHORT

1. Disconnect glow plug harness connector.
2. Check harness continuity between glow relay terminal 5 and glow plug harness connector.
Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 12.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

12. CHECK GLOW RELAY

Refer to [EC-1894, "Component Inspection"](#) .

OK or NG

OK >> GO TO 13.

NG >> Replace glow relay.

13. CHECK GLOW PLUG

Refer to [EC-1894, "Component Inspection"](#) .

OK or NG

OK >> GO TO 14.

NG >> Replace glow plug.

14. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**


Component Inspection GLOW RELAY

EBS00E2X

Check continuity between glow relay terminals 3 and 5 under the following conditions.

Conditions	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No

Operation takes less than 1 second.



GLOW PLUG

1. Remove glow plug connecting plate.

GLOW CONTROL SYSTEM


[YD]


2. Check glow plug resistance.

Resistance: Approximately 0.8 Ω [at 25°C (77°F)]

NOTE:

- Do not bump glow plug heating element. If it is bumped, replace glow plug with a new one.
- If glow plug is dropped from a height of 10 cm (3.94 in) or higher, replace with a new one.
- If glow plug installation hole is contaminated with carbon, remove it with a reamer or suitable tool.
- Hand-tighten glow plug by turning it two or three times, then tighten using a tool to specified torque.

 : 17.7 - 22.5 N-m (1.8 - 2.3 kg-m, 13 - 16 ft-lb)



A

EC

C

D

E

EBS00E2Y

F

G

H

I

J

K

L

M

Removal and Installation GLOW PLUG

Refer to [EM-231, "GLOW PLUG"](#) .

EGR VOLUME CONTROL SYSTEM

PFP:14710

Description SYSTEM DESCRIPTION

EBS00E2Z


Sensor	Input Signal to ECM	ECM Function	Actuator
Crankshaft position sensor (TDC)	Engine speed	EGR volume control	EGR volume control valve
Vehicle speed signal*	Vehicle speed		
Engine coolant temperature sensor	Engine coolant temperature		
Ignition switch	Start signal		
Accelerator pedal position sensor	Accelerator pedal position		
Mass air flow sensor	Amount of intake air		
Air conditioner switch *	Air conditioner operation		

*: These signals are sent to the ECM through CAN communication line.

This system controls flow rate of EGR led from exhaust manifold to intake manifold. The opening of the EGR by-pass passage in the EGR volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions.

The EGR volume control valve remains close under the following conditions.


- Engine stopped
- Engine starting
- Low engine coolant temperature
- Excessively high engine coolant temperature
- High engine speed
- Wide open throttle



COMPONENT DESCRIPTION

EGR Volume Control Valve

The EGR volume control valve uses a step motor to control the flow rate of EGR from exhaust manifold. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E30

Specification data are reference values.

EGR VOLUME CONTROL SYSTEM

[YD]

MONITOR ITEM	CONDITION	SPECIFICATION
EGR VOL CONV	<ul style="list-style-type: none"> ● Engine: After warming up ● Air conditioner switch: OFF ● Shift lever: Neutral position ● No-load 	After one minute at idle More than 10 steps
	Revvng engine from idle to 3,600 rpm	0 step

ECM Terminals and Reference Value

EBS00E31

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TERMI- NAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage and Pulse Signal)
A8 A9	R R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
B3 B4 B5 B6	GY/B OR/B W/L GY	EGR volume control valve	<p style="margin: 0;">[Engine is running]</p> <ul style="list-style-type: none"> ● Warm-up condition ● Idle speed 	0.1 - 14V (Voltage signals of each ECM terminals differ according to the control position of EGR volume control valve.)
D24 D26	G G	ECM relay (self-shutoff)	<p style="margin: 0;">[Ignition switch "ON"] [Ignition switch "OFF"]</p> <ul style="list-style-type: none"> ● For a few seconds after turning ignition switch "OFF" 	Approximately 0V
			<p style="margin: 0;">[Ignition switch "OFF"]</p> <ul style="list-style-type: none"> ● A few seconds passed after turning ignition switch "OFF" 	BATTERY VOLTAGE (11 - 14V)








EGR VOLUME CONTROL SYSTEM

[YD]

Wiring Diagram

EBS00E32

EC-EGRC/V-01




MBWA0102E

Diagnostic Procedure

1. CHECK EGR VOLUME CONTROL SYSTEM OVERALL FUNCTION

1. Turn ignition switch "OFF".
2. Set the oscilloscope probe between ECM terminals B3, B4, B5, B6 and ground.
3. Start engine and let it idle.
4. Check the oscilloscope screen when revving engine up to 3,200 rpm and return to idle.




The pulse signal as shown in the figure should appear.

OK or NG

- OK >> INSPECTION END
- NG >> GO TO 2.

2. CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT-I

1. Turn ignition switch "OFF".
2. Disconnect EGR volume control valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between EGR volume control valve terminals 2, 5 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 7.
- NG >> GO TO 3.



3. CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT-II

1. Turn ignition switch "OFF".
2. Disconnect ECM relay.
3. Check harness continuity between ECM relay terminal 5 and EGR volume control valve terminals 2, 5.
Refer to Wiring Diagram.


Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 4.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



4. CHECK EGR VOLUME CONTROL VALVE POWER SUPPLY CIRCUIT-III


Check voltage between ECM relay terminal 3 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

OK >> GO TO 6.

NG >> GO TO 5.



5. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors E62, F12
- 10A fuse
- Harness for open or short between ECM relay and fuse

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK ECM RELAY

Refer to [EC-1789, "Component Inspection"](#).

OK or NG

OK >> GO TO 7.

NG >> Replace ECM relay.

7. CHECK EGR VOLUME CONTROL VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals and EGR volume control valve terminals as follows. Refer to Wiring Diagram.

ECM terminal	EGR volume control valve terminal
B3	4
B4	3
B5	6
B6	1

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK EGR VOLUME CONTROL VALVE

Refer to [EC-1901, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace EGR volume control valve.

9. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection EGR VOLUME CONTROL VALVE

EBS00E34

With CONSULT-II

1. Disconnect EGR volume control valve harness connector.



EGR VOLUME CONTROL SYSTEM

[YD]


2. Check resistance between the following terminals.

- terminal 2 and terminals 1, 3
- terminal 5 and terminals 4, 6

Temperature °C (°F)	Resistance Ω
20 (68)	13 - 17

If NG, replace EGR volume control valve.
If OK, go to next step.

- Reconnect EGR volume control valve harness connector.
- Remove EGR volume control valve from cylinder head.
(The EGR volume control valve harness connector should remain connected.)
- Turn ignition switch "ON".



MBIB0007E

6. Perform "EGR VOL CONT/V" in "ACTIVE TEST" mode with CONSULT-II. Check that EGR volume control valve shaft moves smoothly forward and backward according to the valve opening.

ACTIVE TEST	
EGR VOL CONT/V	20 step
MONITOR	
CKPS-RPM (TDC)	XXX rpm

The diagram shows a cross-section of the EGR volume control valve assembly. An arrow points to the shaft of the valve, which is the component to be monitored during the active test.

SEF819Y

If NG, replace the EGR volume control valve.

Removal and Installation EGR VOLUME CONTROL VALVE

EBS00E35

Refer to [EM-220, "EXHAUST MANIFOLD AND TURBOCHARGER"](#).

VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

[YD]


VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

PFP:14956


Description

EBS00G90

The load from the variable nozzle turbocharger control solenoid valve controls the actuator. By changing the variable nozzle vane opening through the rods, the intake air volume is adjusted.



The variable nozzle turbocharger control solenoid valve is moved by ON/OFF pulse from the ECM. The longer the ON pulse, the charge air pressure rises.



ECM Terminals and Reference Value

EBS00G90

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may damage the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
B17	L	Variable nozzle turbo-charger control solenoid valve	[Engine is running] ● Warm-up condition ● Idle speed	4.5 - 6.5V
			[Engine is running] ● Warm-up condition ● Engine speed is 2,500 rpm	7 - 9V






VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

[YD]

Wiring Diagram

EBS00G9S

EC-VNT/V-01



MBWA0121E


Diagnostic Procedure

1. CHECK OVERALL FUNCTION

1. Start engine and let it idle.
2. Make sure that variable nozzle turbocharger control actuator rod moves when revving engine up to 3,000 rpm and returning to idle.

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.




2. CHECK VACUUM SOURCE

1. Turn ignition switch "OFF".
2. Disconnect vacuum hose connected to variable nozzle turbocharger control actuator.
3. Start engine and let it idle.
4. Check vacuum hose for vacuum existence.

Vacuum should exist.

OK or NG

- OK >> GO TO 3.
 NG >> GO TO 4.




3. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL ACTUATOR

1. Turn ignition switch "OFF".
2. Install a vacuum pump to variable nozzle turbocharger control actuator.
3. Make sure that the variable nozzle turbocharger control actuator rod moves smoothly when applying vacuum of -53.3kPa (-533mbar, -400mmHg, -15.75inHg) and releasing it.

OK or NG

- OK >> GO TO 9.
 NG >> Replace turbocharger assembly.




4. CHECK VACUUM HOSES AND VACUUM GALLERY

1. Turn ignition switch "OFF".
2. Check vacuum hoses and vacuum gallery for clogging, cracks or improper connection.
Refer to Vacuum Hose Drawing.


OK or NG

- OK >> GO TO 5.
NG >> Repair or replace vacuum hoses and vacuum gallery.



5. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect variable nozzle turbocharger control solenoid valve harness connector.
3. Turn ignition switch "ON".




4. Check voltage between variable nozzle turbocharger control solenoid valve terminals 2 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 7.
NG >> GO TO 6.



6. DETECT MALFUNCTIONING PART

Check the following.

- Harness for open or short between ECM relay and variable nozzle turbocharger control solenoid valve
- Harness for open or short between variable turbocharger control solenoid valve

>> Repair open circuit or short to ground or short to power in harness or connectors.

7. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE OUTPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminals B17 and variable nozzle turbocharger control solenoid valve terminals 1. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

OK >> GO TO 8.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.

8. CHECK VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

Refer to [EC-1901, "Component Inspection"](#) .

OK or NG

OK >> GO TO 9.

NG >> Replace variable nozzle turbocharger control solenoid valve.

9. CHECK INTERMITTENT INCIDENT


Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

Component Inspection VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

EBS00G9V

1. Disconnect variable nozzle turbocharger control solenoid valve harness connector.




2. Apply 12V direct current between variable nozzle turbocharger control solenoid valve terminals.
3. Check air passage continuity of variable nozzle turbocharger control solenoid valve under the following conditions.

CONDITIONS	Air passage continuity between A and B	Air passage continuity between A and C
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

Operation takes less than 1 second.

If NG, replace variable nozzle turbocharger control solenoid valve.



VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

[YD]

Removal and Installation

VARIABLE NOZZLE TURBOCHARGER CONTROL SOLENOID VALVE

EBS00GNU

Refer to [EM-220, "Removal and Installation"](#) .

BRAKE SWITCH


[YD]

BRAKE SWITCH

PFP:25230

Description

The stop lamp switch is installed to brake pedal bracket. The switch senses brake pedal position and sends an ON-OFF signal to the ECM. The ECM uses the signal to control the fuel injection control system.



ECM Terminals and Reference Value

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
D25	R/G	Stop lamp switch	[Ignition switch "ON"] ● Brake pedal fully released	Approximately 0V
			[Ignition switch "ON"] ● Brake pedal depressed	BATTERY VOLTAGE (11 - 14V)


BRAKE SWITCH

[YD]



Wiring Diagram




EBS00E38

EC-BRK/SW-01



REFER TO PG-POWER.

 : DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.

 - FUSE BLOCK-JUNCTION BOX (J/B)

Diagnostic Procedure

1. CHECK OVERALL FUNCTION


With CONSULT-II

1. Turn ignition switch "ON".
2. Select "BRAKE SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "BRAKE SW" signal under the following conditions.

Conditions	BRAKE SW
Brake pedal released	OFF
Brake pedal slightly depressed	ON


OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch "OFF".
2. Disconnect stop lamp switch harness connector.




3. Check voltage between stop lamp switch terminal 1 and ground with CONSULT-II or tester.

Voltage: Battery voltage

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.



3. DETECT MALFUNCTION PART

Check the following

- 15A fuse
- Fuse block (J/B) connector M2
- Harness for open and short between stop lamp switch and battery

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK STOP LAMP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Turn ignition switch "OFF".
2. Disconnect ECM harness connector.
3. Check harness continuity between ECM terminal D25 and stop lamp switch terminal 2. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.

5. DETECT MALFUNCTIONING PART

Check the following

- Harness connectors F110, M80
- Harness for open and short between stop lamp switch and ECM

>> Repair open circuit or short to ground or short to power in harness or connectors.

6. CHECK STOP LAMP SWITCH

Refer to [EC-1912, "Component Inspection"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Replace stop lamp switch.

7. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection STOP LAMP SWITCH

EBS00E3A

Check continuity between stop lamp switch terminals 1 and 2 under the following conditions.

Conditions	Continuity
Brake pedal fully released	Should not exist.
Brake pedal depressed	Should exist.



PARK/NEUTRAL POSITION (PNP) SWITCH

[YD]

PARK/NEUTRAL POSITION (PNP) SWITCH

PFP:31918

Description

EBS00E3B

When the gear position is in "Neutral", neutral position is "ON". ECM detects the position because the continuity of the line (the "ON" signal) exists.

CONSULT-II Reference Value in Data Monitor Mode

EBS00E3C

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
P/N POSI SW	● Ignition switch: ON	Shift lever: Neutral	ON
		Except above	OFF

ECM Terminals and Reference Value

EBS00E3D

Specification data are reference values and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E13	G/OR	Park/Neutral position switch	[Ignition switch "ON"] ● Gear position is "Neutral"	Approximately 0V
			[Ignition switch "ON"] ● Except the above gear position	BATTERY VOLTAGE (11 - 14V)



PARK/NEUTRAL POSITION (PNP) SWITCH

[YD]

Wiring Diagram

EBS00E3E

EC-PNP/SW-01



MBWA0105E

PARK/NEUTRAL POSITION (PNP) SWITCH

[YD]

EBS00E3F

Diagnostic Procedure

1. CHECK OVERALL FUNCTION


With CONSULT-II

1. Turn ignition switch "ON".
2. Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT-II.
3. Check "P/N POSI SW" signal under the following conditions.

Shift lever position	P/N POSI SW
Neutral position	ON
Except the above position	OFF

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.



2. CHECK PNP SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect park/neutral position (PNP) switch harness connector.
3. Check harness continuity between PNP switch terminal 2 and body ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
NG >> Repair open circuit or short to power in harness or connectors.



3. CHECK PNP SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal E13 and PNP switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK PARK/NEUTRAL POSITION SWITCH

Refer to [MT-126, "POSITION SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Replace park/neutral position switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

START SIGNAL




[YD]

START SIGNAL Wiring Diagram

PFPA:48750

EBS00E3G

EC-S/SIG-01



REFER TO THE FOLLOWING.
 (M2), (E106) - FUSE BLOCK-JUNCTION BOX (J/B)

Diagnostic Procedure

1. CHECK START SIGNAL OVERALL FUNCTION

With CONSULT-II

- Turn ignition switch "ON".
- Check "START SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

Condition	"START SIGNAL"
Ignition switch "ON"	OFF
Ignition switch "START"	ON

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.

DATA MONITOR	
MONITORING	NO DTC
START SIGNAL	OFF

PBIB0433E

2. CHECK START SIGNAL INPUT SIGNAL CIRCUIT

- Turn ignition switch "OFF".
- Disconnect ECM harness connector and ignition switch harness connector.
- Check harness continuity between ECM terminal D27 and ignition switch terminal 6. Refer to Wiring Diagram.

Continuity should exist.

- Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING PART

Check the following.

- Harness connectors M77, F109
- 10A fuse
- Fuse block (J/B) connectors M2, E106
- Harness for open or short between ECM and ignition switch

>> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .

>> **INSPECTION END**

POWER STEERING OIL PRESSURE SWITCH

[YD]


POWER STEERING OIL PRESSURE SWITCH

PFP:49761

Component Description

EBS00E3I

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the fuel injector pulse width to increase the idle speed and adjust for the increased load.



CONSULT-II Reference Value in Data Monitor Mode

EBS00E3J

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel is in neutral position. (Forward direction)	OFF
		Steering wheel is turned.	ON

ECM Terminals and Reference Value

EBS00E3K

Specification data are reference values, and are measured between each terminal and ground.

CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECM's transistor. Use a ground other than ECM terminals, such as the ground.

TER-MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC Voltage)
E12	P/B	Power steering oil pressure switch	[Engine is running] <ul style="list-style-type: none"> Steering wheel is being turned 	Approximately 0V
			[Engine is running] <ul style="list-style-type: none"> Steering wheel is not being turned 	BATTERY VOLTAGE (11 - 14V)

POWER STEERING OIL PRESSURE SWITCH



[YD]

Wiring Diagram

EBS00E3L

EC-PST/SW-01

A
EC
C
D
E
F
G
H
I
J
K
L
M



MBWA0106E

Diagnostic Procedure

1. CHECK OVERALL FUNCTION


Ⓜ With CONSULT-II

1. Start engine.
2. Check "PW/ST SIGNAL" in "DATA MONITOR" mode with CONSULT-II under the following conditions.

Conditions	PW/ST SIGNAL
Steering in neutral position	OFF
Steering is turned	ON

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.



2. CHECK POWER STEERING OIL PRESSURE SWITCH GROUND CIRCUIT FOR OPEN AND SHORT


1. Turn ignition switch "OFF".
2. Disconnect power steering oil pressure switch harness connector.
3. Check harness continuity between power steering oil pressure switch terminal 2 and engine ground. Refer to Wiring Diagram.

Continuity should exist.

4. Also check harness for short to power.

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to power in harness or connectors.



3. CHECK POWER STEERING OIL PRESSURE SWITCH INPUT SIGNAL CIRCUIT FOR OPEN AND SHORT

1. Disconnect ECM harness connector.
2. Check harness continuity between ECM terminal E12 and power steering oil pressure switch terminal 1. Refer to Wiring Diagram.

Continuity should exist.

3. Also check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 4.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.

4. CHECK POWER STEERING OIL PRESSURE SWITCH

Refer to [EC-1921, "Component Inspection"](#).

OK or NG

- OK >> GO TO 5.
 NG >> Replace power steering oil pressure switch.

5. CHECK INTERMITTENT INCIDENT

Refer to [EC-1783, "TROUBLE DIAGNOSIS FOR INTERMITTENT INCIDENT"](#) .


>> INSPECTION END

Component Inspection
POWER STEERING OIL PRESSURE SWITCH

EBS00E3N

1. Disconnect power steering oil pressure switch harness connector and then start engine.
2. Check continuity between power steering oil pressure switch terminal 1 and 2 under the following conditions.

Conditions	Continuity
Steering wheel is being fully turned.	Yes
Steering wheel is not being turned.	No



EBS00E3O

Removal and Installation
POWER STEERING OIL PRESSURE SWITCH

Refer to [PS-24, "HYDRAULIC LINE"](#) .



MI & DATA LINK CONNECTORS

PFP:24814

Wiring Diagram

EBS00E30

EC-MIL/DL-01



SERVICE DATA AND SPECIFICATIONS (SDS)

[YD]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00100

General Specifications

EBS00E3R

Engine	YD22DDTi
Idle speed	725 ± 25 rpm
Maximum engine speed	4,900 rpm

Mass Air Flow Sensor

EBS00E3S

Supply voltage	5V
Ignition switch "ON" (Engine stopped.)	Approx. 1.0V
Idle (Engine is warmed up to normal operating temperature.)	1.0 - 2.5V
2,000 rpm (Engine is warmed up to normal operating temperature.)	2.1 - 2.7V

Engine Coolant Temperature Sensor

EBS00E3T

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

Common Rail Fuel Pressure Sensor

EBS00E3U

Supply voltage	Approximately 5V
Idle (Engine is warmed up to normal operating temperature.)	1.6 - 1.8V
2,000 rpm (Engine is warmed up to normal operating temperature.)	1.8 - 2.0V

Crankshaft Position Sensor (TDC)

EBS00E3V

Resistance [at 20°C (68°F)] Ω	1,850 - 2,450
-------------------------------	---------------

Camshaft Position Sensor

EBS00E3W

Resistance [at 20°C (68°F)] Ω	1,850 - 2,450
-------------------------------	---------------

Glow Plug

EBS00E3X

Resistance [at 25°C (77°F)] Ω	Approximately 0.8
-------------------------------	-------------------

EGR Volume Control Valve

EBS00E3Y

Resistance [at 25°C (77°F)] Ω	13 - 17
-------------------------------	---------

