

LT
SECTION
LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
LT
L
M

CONTENTS

<p>PRECAUTION 4</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 4</p> <p style="padding-left: 20px;">Precaution 4</p> <p style="padding-left: 20px;">Wiring Diagrams and Trouble Diagnosis 4</p> <p>HEADLAMP - CONVENTIONAL TYPE- 5</p> <p style="padding-left: 20px;">System Description 5</p> <p style="padding-left: 40px;">DESCRIPTION 5</p> <p style="padding-left: 40px;">LOW BEAM OPERATION 5</p> <p style="padding-left: 40px;">HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION 5</p> <p style="padding-left: 20px;">Wiring Diagram — H/LAMP — 6</p> <p style="padding-left: 20px;">Trouble Diagnoses 7</p> <p style="padding-left: 20px;">Aiming Adjustment 7</p> <p style="padding-left: 40px;">LOW BEAM 8</p> <p style="padding-left: 20px;">Bulb Replacement 9</p> <p style="padding-left: 40px;">HEADLAMP 9</p> <p style="padding-left: 40px;">CLEARANCE LAMP, FRONT TURN SIGNAL LAMP 9</p> <p style="padding-left: 20px;">Removal and Installation 9</p> <p style="padding-left: 40px;">REMOVAL 9</p> <p style="padding-left: 40px;">INSTALLATION 9</p> <p>HEADLAMP - XENON TYPE - 10</p> <p style="padding-left: 20px;">System Description 10</p> <p style="padding-left: 40px;">LOW BEAM OPERATION 10</p> <p style="padding-left: 40px;">HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION 10</p> <p style="padding-left: 20px;">Wiring Diagram - H/LAMP - 12</p> <p style="padding-left: 20px;">Trouble Diagnosis 14</p> <p style="padding-left: 20px;">Aiming Adjustment 15</p> <p style="padding-left: 40px;">LOW BEAM 15</p> <p style="padding-left: 20px;">Bulb Replacement 16</p> <p style="padding-left: 40px;">XENON BULB (LOW BEAM) 16</p> <p style="padding-left: 40px;">HIGH BEAM 16</p> <p style="padding-left: 40px;">CLEARANCE LAMP, FRONT TURN SIGNAL LAMP 17</p> <p style="padding-left: 20px;">Removal and Installation 17</p> <p style="padding-left: 40px;">REMOVAL 17</p> <p style="padding-left: 40px;">INSTALLATION 17</p>	<p>HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE - 18</p> <p style="padding-left: 20px;">System Description 18</p> <p style="padding-left: 40px;">DESCRIPTION 18</p> <p style="padding-left: 40px;">HEADLAMP OPERATION 18</p> <p style="padding-left: 40px;">DAYTIME LIGHT OPERATION 18</p> <p style="padding-left: 20px;">Schematic 19</p> <p style="padding-left: 20px;">Wiring Diagram — H/LAMP — 20</p> <p style="padding-left: 20px;">Trouble Diagnoses 23</p> <p style="padding-left: 20px;">Aiming Adjustment 24</p> <p style="padding-left: 20px;">Bulb Replacement 24</p> <p style="padding-left: 40px;">HEADLAMP 24</p> <p style="padding-left: 40px;">CLEARANCE LAMP, FRONT TURN SIGNAL LAMP 24</p> <p>HEADLAMP (WITH DAYTIME) - XENON TYPE - ... 25</p> <p style="padding-left: 20px;">System Description 25</p> <p style="padding-left: 20px;">Schematic 26</p> <p style="padding-left: 20px;">Wiring Diagram - DTRL - 27</p> <p style="padding-left: 20px;">Trouble Diagnoses 30</p> <p style="padding-left: 40px;">DAYTIME LIGHT UNIT INSPECTION TABLE ... 30</p> <p style="padding-left: 20px;">Bulb Replacement 30</p> <p style="padding-left: 20px;">Aiming Adjustment 30</p> <p>HEADLAMP AIMING CONTROL (MANUAL) 31</p> <p style="padding-left: 20px;">Wiring Diagram — H/AIM — 31</p> <p style="padding-left: 20px;">Removal and Installation 32</p> <p style="padding-left: 20px;">Switch Circuit Inspection 32</p> <p>HEADLAMP AIMING CONTROL (AUTO) 33</p> <p style="padding-left: 20px;">System Description 33</p> <p style="padding-left: 20px;">Component Parts and Harness 33</p> <p style="padding-left: 40px;">CONNECTOR LOCATION 33</p> <p style="padding-left: 20px;">Wiring Diagram - H/AIM - 34</p> <p style="padding-left: 20px;">CONSULT-II 36</p> <p style="padding-left: 40px;">CONSULT-II INSPECTION PROCEDURE 36</p> <p style="padding-left: 40px;">CONSULT-II DIAGNOSTIC TEST MODE FUNCTION 37</p> <p style="padding-left: 40px;">INITIALIZATION 37</p> <p style="padding-left: 40px;">SELF-DIAGNOSTIC RESULTS ITEM CHART ... 38</p> <p style="padding-left: 20px;">Check Power and Ground for Height Sensor 38</p> <p style="padding-left: 20px;">Check Lighting Switch Circuit 39</p> <p style="padding-left: 20px;">Check Speed Signal Circuit Check 39</p>
--	--

Check Headlamp Aiming Motor	40	Wiring Diagram — F/FOG —	72
Removal and installation	41	Aiming Adjustment	73
TURN SIGNAL AND HAZARD WARNING LAMPS..	42	Bulb Replacement	73
System Description	42	Removal and Installation	73
TURN SIGNAL OPERATION	42	REMOVAL	73
HAZARD LAMP OPERATION	43	INSTALLATION	74
MULTI-REMOTE CONTROL SYSTEM OPERA- TION	43	REAR FOG LAMP	75
Wiring Diagram — TURN —	45	Wiring Diagram — R/FOG — /Without Front Fog Lamp	75
Terminal and Reference Valve for Smart Entrance Control Unit	47	Wiring Diagram — R/FOG — /With Front Fog Lamp..	76
Turn Signal And Hazard Warning Lamp Do Not Operate	47	Bulb Replacement (Sedan)	79
Turn Signal Lamps Do Not Operate But Hazard Warning Lamp Do Operate	48	Bulb Replacement (Wagon)	79
Hazard Warning Lamps Do Not Operate But Turn Signal Lamp Do Operate	49	Removal and Installation	79
Turn Signal Lamps LH Do Not Operate	51	REMOVAL (SEDAN)	79
Turn Signal Lamps RH Do Not Operate	52	INSTALLATION (SEDAN)	79
LH and RH Turn Indicators Do Not Operate	53	CLEARANCE LAMP/TAIL LAMP	80
Bulb Replacement	54	Bulb Replacement (Clearance Lamp)	80
FRONT TURN SIGNAL LAMP	54	Bulb Replacement (Tail Lamp)	80
SIDE TURN SIGNAL LAMP	54	Removal and Installation of Clearance Lamp	80
REAR TURN SIGNAL LAMP	54	Removal and Installation of Tail Lamp	80
Removal and Installation for Side Turn Signal Lamp..	54	HIGH-MOUNTED STOP LAMP	81
Removal and Installation for Rear Turn Signal Lamp..	54	Bulb Replacement	81
LIGHTING AND TURN SIGNAL SWITCH	55	HIGH-MOUNTED STOP LAMP (SEDAN)	81
Removal and Installation	55	HIGH-MOUNTED STOP LAMP (WAGON)	81
Switch Circuit Inspection	55	Removal and Installation	81
HAZARD SWITCH	56	HIGH-MOUNTED STOP LAMP (SEDAN)	81
Removal and Installation	56	HIGH-MOUNTED STOP LAMP (WAGON)	81
REMOVAL	56	REAR COMBINATION LAMP	82
INSTALLATION	56	Wiring Diagram —STOP/L—	82
STOP LAMP	57	Bulb Replacement (Sedan)	84
Wiring Diagram — STOP/L —	57	Bulb Replacement (Wagon)	84
Bulb Replacement	59	Removal and Installation	84
STOP LAMP	59	REMOVAL (SEDAN)	84
Removal and Installation	59	INSTALLATION	84
STOP LAMP	59	COMBINATION SWITCH	86
BACK-UP LAMP	60	Removal and Installation	86
Wiring Diagram — BACK/L —	60	Switch Circuit Inspection	87
Bulb Replacement (Sedan)	62	ILLUMINATION	89
Bulb Replacement (Wagon)	62	System Description	89
Removal and Installation (Sedan)	62	Schematic	90
Removal and Installation (Wagon)	62	Wiring Diagram	91
PARKING, LICENSE PLATE AND TAIL LAMPS	63	INTERIOR ROOM LAMP	96
Wiring Diagram - TAIL/L -/LHD MODELS	63	System Description	96
Wiring Diagram - TAIL/L -/RHD MODELS	66	POWER SUPPLY AND GROUND	96
Bulb Replacement	69	SWITCH OPERATION	97
PARKING AND TAIL LAMPS	69	INTERIOR ROOM LAMP TIMER OPERATION... ..	97
LICENSE PLATE LAMP	69	ON-OFF CONTROL	97
Removal and Installation	69	Schematic	98
PARKING AND TAIL LAMPS	69	Wiring Diagram - ROOM/L -/LHD MODELS	99
LICENSE PLATE LAMP	69	Wiring Diagram - ROOM/L -/RHD MODELS	103
FRONT FOG LAMP	71	Terminal and Reference Valve for Smart Entrance Control Unit	107
System Description	71	CONSULT-II Inspection Procedure	107
DESCRIPTION	71	“ROOM LAMP”	107
FOG LAMP OPERATION	71	CONSULT-II Application Items	108
		ROOM LAMP	108
		Interior Room Lamp Timer Does Not Operate	109
		Interior Room Lamp Timer Does Not Cancel	114

Bulb Replacement	118	CAN Communication Unit For LHD Models without Tyre Pressure Monitoring System	132
INTERIOR ROOM LAMP	118	TYPE 7	133
STEP LAMP	119	TYPE 8	134
ASHTRAY	119	TYPE 9	135
Removal and Installation	119	TYPE 10	136
INTERIOR ROOM LAMP	119	TYPE 11	137
STEP LAMP	119	TYPE 12	138
ASHTRAY	119	CAN Communication Unit For RHD Models with Tyre Pressure Monitoring System	139
SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS	120	TYPE 13	140
Wiring Diagram — INT/L —	120	TYPE 14	141
Bulb Replacement	123	TYPE 15	142
SPOT LAMP	123	TYPE 16	143
TRUNK ROOM LAMP	123	TYPE 17	144
LUGGAGE ROOM LAMP	123	TYPE 18	145
Removal and Installation	123	CAN Communication Unit For RHD Models without Tyre Pressure Monitoring System	146
SPOT LAMP	123	TYPE 19	147
TRUNK ROOM LAMP	123	TYPE 20	148
LUGGAGE ROOM LAMP	124	TYPE 21	149
CAN COMMUNICATION	125	TYPE 22	150
System Description	125	TYPE 23	151
CAN Communication Unit For LHD Models with Tyre Pressure Monitoring System	125	TYPE 24	152
TYPE 1	126	BULB SPECIFICATIONS	153
TYPE 2	127	Headlamp	153
TYPE 3	128	Exterior Lamp	153
TYPE 4	129	Interior Lamp/Illumination	153
TYPE 5	130		
TYPE 6	131		

A
B
C
D
E
F
G
H
I
J
LT
L
M

PRECAUTION

PRECAUTION

PF0:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00377

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harness connectors.

Precaution

EKS00378

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of the headlamp. When replacing the bulb, be sure to replace it with a new one.
- Adjust aiming by tightening aiming screw. (To adjust it toward loosening side, first loosen adjusting screw, and then make adjustment by tightening.)
- To remove soil or sealant of bulbs, do not use organic solvent (thinner, gasoline, etc.)
- When replacing bulb, be sure to hold bulb socket and pull it out straight. If wiring harness of the bulb is pulled at an angle, the bulb may be caught in the lamp, making it difficult to take out.

Wiring Diagrams and Trouble Diagnosis

EKS00379

When you read wiring diagrams, refer to the following:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) in GI section
- Refer to [PG-3, "POWER SUPPLY ROUTING"](#) for power distribution circuit in PG section

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section
- Refer to [GI-24, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section

HEADLAMP -CONVENTIONAL TYPE-

HEADLAMP -CONVENTIONAL TYPE-

PPF:26010

System Description DESCRIPTION

EKS004P6

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 8
- through 15A fuse (No. 41, located in the fuse and fusible link box), and
- to lighting switch terminal 5
- through 15A fuse (No. 42, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal 10
- to terminal 5 of the headlamp LH, and
- from lighting switch terminal 7
- to terminal 5 of the headlamp RH.

Terminal 2 of each headlamp supplies ground through body grounds E10 and E58.

With power and ground supplied, the low beams will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal 9
- to terminal 4 of headlamp LH, and
- to combination meter terminal 20 (LHD models) or 7 (RHD models) for the HIGH BEAM indicator.
- from lighting switch terminal 6
- to terminal 4 of headlamp RH.

Ground is supplied to terminal 21 (LHD models) or 8 (RHD models) of the combination meter through body grounds M16, M50 and M70.

Ground is supplied to terminal 2 of each headlamp through body grounds E10 and E58.

With power and ground supplied, the high beams and the HIGH BEAM indicator illuminate.

A

B

C

D

E

F

G

H

I

J

LT

L

M






HEADLAMP - CONVENTIONAL TYPE-

Wiring Diagram — H/LAMP —

EKS004P7

LT-H/LAMP-01

- ⬡ : LHD MODELS
- ⬢ : RHD MODELS
- *1 20: ⬡
- 7: ⬢
- *2 21: ⬡
- 8: ⬢



MKWA0001E

HEADLAMP -CONVENTIONAL TYPE-

Trouble Diagnoses

EKS004P8

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 9 (BR/R) and LH headlamp terminal 4 (BR/R) for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 10 (R/Y) and LH headlamp terminal 5 (R/Y) for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 6 (Y) and RH headlamp terminal 4 (Y) for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 7 (PV) and RH headlamp terminal 5 (PV) for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) LHD or 7 (BR/R) RHD for an open circuit.

Aiming Adjustment

EKS004P9

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).



HEADLAMP -CONVENTIONAL TYPE-

CAUTION:



Be sure aiming switch is set to "0" when performing aiming adjustment.

LOW BEAM

1. Turn headlamp low beam on.
LHD models



RHD models



2. Use adjusting pots to perform aiming adjustment.

- First tighten the adjusting pot all the way and then make adjustment by loosening the pot.

If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure to the left shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines to point P in illustration show center of headlamp.

"H" : Horizontal center line of headlamps

"WL" : Distance between each headlamp center


"L" : 25 m (98.43 in)

"C" : 250 mm (9.84 in)

- Basic illuminating area for adjustment should be within the range shown in the figure. Adjust headlamps accordingly.

CAUTION:

Be sure aiming switch is set to "0" when performing aiming adjustment.



HEADLAMP -CONVENTIONAL TYPE-


Bulb Replacement HEADLAMP

EKS004PA

1. Disconnect connector of headlamp.
2. Unlock retaining spring, then remove bulb.

Headlamp (Low) : 12V - 55W (H7)

Headlamp (High) : 12V - 55W (H7)



CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

1. Turn the bulbsocket counterclockwise and unlock it.
2. Remove the bulb from its socket.

Clearance lamp : 12V - 5W

Front turn signal lamp : 12V - 21W


CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock rubber cap to ensure watertightness.

Removal and Installation REMOVAL

EKS004PB

1. Disconnect connector of headlamp and clearance lamp.
2. Remove the front grille. Refer to [EI-12, "FRONT GRILL"](#).
3. Remove the headlamp mounting bolts.
4. Pull the headlamp toward the front of the vehicle.



INSTALLATION

- Install in the reverse order of removal, taking care of the following points.
Headlamp mounting screws and nut

Tightening torque : 4.4 - 5.8 N·m (0.45 - 0.59 kg·m, 39 - 51 in·lb)

HEADLAMP - XENON TYPE -

HEADLAMP - XENON TYPE -

PFP:26010

System Description

EKS004PC

The headlamps are controlled by lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal 8
- through 15A fuse (No. 41, located in the fuse and fusible link box) and
- to lighting switch terminal 5
- through 15A fuse (No. 42, located in the fuse and fusible link box) and
- to headlamp LH relay terminal 3
- through 20A fuse (No. 37, located in the fuse and fusible link box) and
- to headlamp RH relay terminal 3
- through 20A fuse (No. 36, located in the fuse and fusible link box).

LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from terminal 5 of each headlamp relay
- to terminal 5 of each headlamps

Terminal 3 of each headlamp supplies ground through body grounds E10 and E58.

With power and ground supplied, the low beams will illuminate.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied.

- from lighting switch terminal 6
- to terminal 4 of headlamp RH, and
- from lighting switch terminal 9
- to terminal 4 of headlamp LH, and
- to combination meter terminal 20 (LHD models) or 7 (RHD models) for the HIGH BEAM indicator.

Ground is supplied to terminal 21 (LHD models) or 8 (RHD models) of the combination meter through body grounds M16, M50 and M70.

Ground is supplied to terminal 2 of each headlamp through body grounds E10 and E58.

With power and ground supplied, the high beams and HIGH BEAM indicator illuminate.

Xenon type headlamp is adopted to the low beam headlamps. Xenon bulbs do not use a filament. Instead, they produce light when a high voltage current is passed between two tungsten electrodes through a mixture of xenon (an inert gas) and certain other metal halides. In addition to added lighting power, electronic control of the power supply gives the headlamps stable quality and tone color.

Following are some of the many advantages of the xenon type headlamp.

- The light produced by the headlamps is white color approximating sunlight that is easy on the eyes.
- Light output is nearly double that of halogen headlamps, affording increased area of illumination.
- The light features a high relative spectral distribution at wavelengths to which the human eye is most sensitive, which means that even in the rain, more light is reflected back from the road surface toward the vehicle, for added visibility.


HEADLAMP - XENON TYPE -

EKS004PD

Wiring Diagram - H/LAMP -

LT-H/LAMP-02

- ⬡ : LHD MODELS
- ⬡ : RHD MODELS
- *1 20 : ⬡
- 7 : ⬡
- *2 21 : ⬡
- 8 : ⬡



26	25	24	23	22	21	20	19	18	17	16	15	14
13	12	11	10	9	8	7	6	5	4	3	2	1

(M36)
L

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

(E109)
W

2	1	3	8	25		
10	7	6	5	9	12	11




(E115)
BR

MKWA0002E

HEADLAMP - XENON TYPE -

LT-H/LAMP-03

A
B
C
D
E
F
G
H
I
J
LT
L
M



MKWA0003E

HEADLAMP - XENON TYPE -

WARNING:

- The xenon headlamp has a high-tension current generating area. Be extremely careful when removing and installing. Be certain to disconnect the battery negative cable prior to removing or installing.
- When the xenon headlamp is lit, do not touch the harness (covered with red or amber insulation), bulb itself or the bulb socket with your bare hands.
- Never service a xenon headlamp with wet hands.
- When checking body side harness with a circuit tester, be certain to disconnect the harness connector from the xenon headlamp.
- When the xenon headlamp is lit, the xenon bulb must be installed in the headlamp housing. (Never turn on xenon headlamp, if the bulb is out of the headlamp housing.)

CAUTION:

Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.

Trouble Diagnosis

EKS004PE

Symptom	Possible cause	Repair order
LH or RH xenon headlamp (low beam) blinks, lacks brightness or does not illuminate.	<ol style="list-style-type: none"> 1. 20A fuse 2. Relay 3. Power supply circuit to headlamp low beam 4. Xenon bulb 5. HID control unit and booster 	<ol style="list-style-type: none"> 1. Check 20A fuse [No. 37: LH, No. 36: RH, located in fuse and fusible link box]. 2. Check Headlamp relay. 3. Verify battery positive voltage is present at terminal 5 of headlamp harness with lighting switch in "2nd" and "Low" positions. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.) 4. Replace the xenon bulb with the other side bulb or new one. (If headlamps illuminate correctly, replace the bulb.) 5. Replace the HID control unit and booster as a headlamp assembly.
LH or RH [both headlamp high and xenon (low) beam] do not illuminate.	<ol style="list-style-type: none"> 1. Bulb 2. 15A fuse 3. Relay 4. Ground circuit 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check 15A fuse [No. 41: LH, No. 42 located in fuse and fusible link box]. 3. Check headlamp relay. 4. Check continuity between headlamp terminal 2 and body ground. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.)
LH or RH headlamp high beam does not illuminate.	<ol style="list-style-type: none"> 1. Bulb 2. Power supply circuit to headlamp high beam 	<ol style="list-style-type: none"> 1. Check bulb. 2. Verify battery positive voltage is present at terminal 2, 3 of headlamp harness with lighting switch in "2nd" and "HIGH" position. (Before inspecting headlamp terminal, disconnect headlamp connector with lighting switch in "OFF" position.)
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) LHD or 7 (BR/R) RHD for an open circuit.

HID: High Intensity Discharge

HEADLAMP - XENON TYPE -

Aiming Adjustment

EKS004PF

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:


For details, refer to the regulations in your own country.

- Keep all tires inflated to correct pressures.
- Place vehicle and tester on one and same flat surface.
- See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).


LOW BEAM

1. Turn headlamp low beam on.

LHD models



RHD models



2. Use adjusting pots to perform aiming adjustment.

- First tighten the adjusting pot all the way and then make adjustment by loosening the pot.

If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP - XENON TYPE -

- Adjust headlamps so that main axis of light is parallel to center line of body and is aligned with point P shown in illustration.
- Figure to the left shows headlamp aiming pattern for driving on right side of road; for driving on left side of road, aiming pattern is reversed.
- Dotted lines to point P in illustration show center of headlamp.


“H” : Horizontal center line of headlamps

“WL” : Distance between each headlamp center
”

“L” : 25 m (98.43 in)

“C” : 250 mm (9.84 in)

- Basic illuminating area for adjustment should be within the range shown at left. Adjust headlamps accordingly.



EKS004PG

Bulb Replacement

CAUTION:

- After replacing a new xenon bulb, be sure to make aiming adjustments.
- Hold only the plastic base when handling the bulb. Never touch the glass envelope.
- Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

1. Disconnect negative battery cable.
2. Disconnect headlamp connector.

WARNING:

Never service a xenon headlamp with wet hands.


XENON BULB (LOW BEAM)

1. Remove washer inlet. (RH bulb)
2. Remove headlamp seal cover.
Turn bulb socket counterclockwise and unlock it.
3. Release retaining pin.
4. Remove the xenon bulb.
5. Install in the reverse order of removal.

Headlamp (LOW) : 12V - 35W (D2R)

CAUTION:

- When disposing of the xenon bulb, do not break it; always dispose of it as is.
- Make sure to install the bulb securely; if the xenon bulb is improperly installed in its socket, high-tension current leaks occur. This may lead to a melted bulb and/or bulb socket.



HIGH BEAM

1. Pull off headlamp seal cover.

HEADLAMP - XENON TYPE -

2. Disconnect bulb connector.
3. Release retaining pin.
4. Remove the bulb.
5. Install in the reverse order of removal.

Headlamp (HIGH) : 12V - 55W (H7)

CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

Refer to [LT-17, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#) .

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock rubber cap to ensure watertightness.

Removal and Installation

EKS004PH

REMOVAL

Refer to [LT-17, "REMOVAL"](#) .

INSTALLATION

Refer to [LT-17, "INSTALLATION"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L

M

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

PDF:26010

System Description DESCRIPTION

EKS004PI

The headlamp system for Northern Europe vehicles contains a daytime light control unit that activates the low beam headlamps whenever the engine is running.

Power is supplied at all times

- to daytime light control unit terminal 1
- to lighting switch terminal 11
- through 10A (No. 32, located in the fuse and fusible link box), and
- to daytime light control unit terminal 3
- to lighting switch terminal 5
- through 15A (No. 42, located in the fuse and fusible link box), and
- to daytime light control unit terminal 2
- to lighting switch terminal 8
- through 15A (No. 41, located in the fuse and fusible link box)

Ground is supplied to daytime light control unit terminal 9 through body grounds E10, E58 and E122.

When the ignition switch is in the ON or START position, power is supplied

- to daytime light control unit terminal 7
- through 10A (No. 10, located in the fuse and fusible link box)

When the ignition switch is in the START position, power is also supplied

- to daytime light control unit terminal 6
- through 10A (No. 21, located in the fuse and fusible link box)

HEADLAMP OPERATION

For description, refer to [LT-5, "System Description"](#)

DAYTIME LIGHT OPERATION

When the engine running, the lighting switch in the OFF position, power is supplied


- from alternator terminal 3
- to daytime light control unit terminal 8, and
- from daytime light control unit terminal 2
- through daytime light control unit terminal 5
- to terminal of LH headlamp
- from daytime light control unit terminal 3,
- through daytime light control unit terminal 4
- to terminal of RH headlamp, and
- from daytime light control unit terminal 1
- through daytime light control unit terminal 10

Ground is supplied to terminal 2 of each headlamp through body grounds E10 and E58.

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Schematic

EKS004PJ







A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

EKS004PK

LT-DTRL-01

Wiring Diagram — H/LAMP —





REFER TO THE FOLLOWING.
 M1, M2 - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0005E

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

LT-DTRL-02


A
B
C
D
E
F
G
H
I
J
K
L
M



MKWA0006E

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

LT-DTRL-03



26	25	24	23	22	21	20	19	18	17	16	15	14
13	12	11	10	9	8	7	6	5	4	3	2	1

M36
L

1	2	3	4	5
---	---	---	---	---

E26, E47

1	2
5	7
3	6

E27
BR

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

E109
W

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Terminal and Reference Value for Daytime Light Control Unit

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)
1	B/R	Power source	Ignition switch "OFF"	Battery voltage
2	R	Power source	Ignition switch "OFF"	Battery voltage
3	R/W	Power source	Ignition switch "OFF"	Battery voltage
4	PU	RH low beam	When lighting switch is turned to the 2ND position	Battery voltage
			When engine is running and turning lighting switch to "OFF" (daytime light operation)	Battery voltage
5	R/Y	LH low beam	When lighting switch is turned to the 2ND position	Battery voltage
			When engine is running and turning lighting switch to "OFF" (daytime light operation)	Battery voltage
6	B/Y	Start signal	When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "ON" from "START"	Less than 1V
			When turning ignition switch to "OFF"	Less than 1V
7	Y/G	Power source	When turning ignition switch to "ON"	Battery voltage
			When turning ignition switch to "START"	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
8	Y/R	Alternator	When turning ignition switch to "ON"	Less than 1V
			When engine is running	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
9	B	Ground	—	—
10	R/B	Tail lamp	When turning ignition switch to "ON"	0V
			When engine is running and turning lighting switch to "OFF" (daytime light operation*)	Battery voltage
			When turning ignition switch to "OFF"	0V
11	W/R	Lighting switch	When turning lighting switch to 1ST or 2ND	Battery voltage
			When turning ignition switch to "OFF"	0V

*: Daytime light operating: Lighting switch in "OFF" position with engine running.

Trouble Diagnoses

EKS004PL

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 41, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 8 of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds E10 and E58 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds E10 and E58. 3. Check 15A fuse (No. 42, located in fuse and fusible link box). Verify battery positive voltage is present at terminal 5 of lighting switch. 4. Check lighting switch.

HEADLAMP (WITH DAYTIME) - CONVENTIONAL TYPE -

Symptom	Possible cause	Repair order
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 9 (BR/R) and LH headlamp terminal 4 (BR/R) for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 10 (R/Y) and LH headlamp terminal 5 (R/Y) for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 6 (Y) and RH headlamp terminal 4 (Y) for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check continuity between lighting switch terminal 7 (PU) and RH headlamp terminal 5 (PU) for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds M16, M50 and M70 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds M16, M50 and M70. 3. Check continuity between lighting switch terminal 9 (BR/R) and combination meter terminal 20 (BR/R) LHD or 7 (BR/R) RHD for an open circuit.

Aiming Adjustment

EKS004PN

Refer to [LT-7, "Aiming Adjustment"](#)

Bulb Replacement

EKS004PM

HEADLAMP

Refer to [LT-9, "Bulb Replacement"](#)

CLEARANCE LAMP, FRONT TURN SIGNAL LAMP

Refer to [LT-9, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#)

HEADLAMP (WITH DAYTIME) - XENON TYPE -

HEADLAMP (WITH DAYTIME) - XENON TYPE -

PFP:26010

System Description

EKS0054P

For headlamp operation, refer to [LT-5, "System Description"](#) .

For daytime operation, refer to [LT-18, "System Description"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L


M

HEADLAMP (WITH DAYTIME) - XENON TYPE -


Wiring Diagram - DTRL -

EKS004PQ

LT-DTRL-04



A
B
C
D
E
F
G
H
I
J
LT
L
M






REFER TO THE FOLLOWING.
M1, M2 - FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0009E

HEADLAMP (WITH DAYTIME) - XENON TYPE -



LT-DTRL-05



MKWA0010E

HEADLAMP (WITH DAYTIME) - XENON TYPE -

LT-DTRL-06



MKWA0011E

HEADLAMP (WITH DAYTIME) - XENON TYPE -

Trouble Diagnoses

DAYTIME LIGHT UNIT INSPECTION TABLE

EKS004PR

Refer to [LT-23, "Trouble Diagnoses"](#) .

Bulb Replacement

EKS004PS

Refer to [LT-16, "Bulb Replacement"](#) .

Aiming Adjustment

EKS004PT

Refer to [LT-15, "Aiming Adjustment"](#) .

HEADLAMP AIMING CONTROL (MANUAL)






PFP:25190

HEADLAMP AIMING CONTROL (MANUAL)

Wiring Diagram — H/AIM —

LT-H/AIM-01

EKS004T6



REFER TO THE FOLLOWING.

(E106) - FUSE BLOCK-
JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
LT
L
M


MKWA0012E

HEADLAMP AIMING CONTROL (MANUAL)

Removal and Installation

EKS00477


1. Remove the Instrument lower driver panel. Refer to [IP-8, "INSTRUMENT LOWER DRIVER PANEL"](#)
2. Press the headlamp aiming switch fixing tabs and remove the unit from the Instrument lower driver panel.



Switch Circuit Inspection

EKS00478

Using a circuit tester, check continuity between the headlamp aiming switch connector terminals in each operation status of the aiming switch.



HEADLAMP AIMING CONTROL (AUTO)

HEADLAMP AIMING CONTROL (AUTO)

PFP:53821

System Description


EKS004T9

The height sensor is designed to adjust the beam angle of the headlamp in response to the loading conditions of the vehicle and vehicle speed. It is not designed to compensate for the dynamic handling of the vehicle. The vehicle rear height is measured by height sensor attached to the rear suspension lateral link arm. Height sensor received vehicle speed signal from combination meter. The height sensor calculates the correct headlamp aiming position and sends a signal to the aiming motors.

Component Parts and Harness

EKS004TA

CONNECTOR LOCATION




A
B
C
D
E
F
G
H
I
J
LT
L
M

HEADLAMP AIMING CONTROL (AUTO)

EKS004TB

LT-H/AIM-02







Wiring Diagram - H/AIM -



REFER TO PG-POWER.

- ⬡ L : LHD MODELS
- ⬡ R : RHD MODELS
- ⬡ RE : RHD MODELS WITH ESP/TCS/ABS CONTROL UNIT
- ⬡ RO : RHD MODELS WITHOUT ESP/TCS/ABS CONTROL UNIT

- *1 10: ⬡ L
- 2: ⬡ RE
- 10: ⬡ RO
- *2 17: ⬡ L
- 3: ⬡ RE
- 17: ⬡ RO
- *3 22: ⬡ L
- 14: ⬡ RE
- 22: ⬡ RO
- *4 35: ⬡ L
- 48: ⬡ R



REFER TO THE FOLLOWING.









(M1) - FUSE BLOCK- JUNCTION BOX (J/B)

MKWA0013E

HEADLAMP AIMING CONTROL (AUTO)

LT-H/AIM-03

- L : LHD MODELS
- R : RHD MODELS
- RE : RHD MODELS WITH ESP/TCS/ABS CONTROL UNIT
- RO : RHD MODELS WITHOUT ESP/TCS/ABS CONTROL UNIT
- *1 11 : L
- 23 : RE
- 11 : RO




MKWA0014E

HEADLAMP AIMING CONTROL (AUTO)


EKS004TC

CONSULT-II CONSULT-II INSPECTION PROCEDURE


1. Turn ignition switch OFF.
2. Connect CONSULT-II to data link connector.




3. Turn ignition switch ON.
4. Touch "START".



5. Touch "Headlamp Levelizer".



6. Perform each diagnostic item according to each service procedure.



HEADLAMP AIMING CONTROL (AUTO)


CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT-II DIAGNOSTIC TEST MODE	Description	
WORK SUPPORT	SENSOR INITIALISE	Replacement or adjustment of height sensor are necessary.
	SENSOR CUSTOMIZE	Change the height sensor current setting.
SELF-DIAGNOSTIC RESULTS	Detected items (screen terms) are as shown in the LT-38, "SELF-DIAGNOSTIC RESULTS ITEM CHART"	
ACTIVE TEST	This test is able to power supply from height sensor to headlamp aiming motor. This system can be operated.	


INITIALIZATION

After the replacement or adjustment of height sensor, the system must be calibrated, This is achieved as follows.

1. Touch "WORK SUPPORT".




2. Touch "SENSOR INITIALISE".



3. Touch "START".
Confirm that "INITIALISE COMPLETE" is displayed on CONSULT-II, close by touching "END".

After successful calibration the headlamps must then be aimed in the conventional manner [LT-15, "Aiming Adjustment"](#).



HEADLAMP AIMING CONTROL (AUTO)

SELF-DIAGNOSTIC RESULTS ITEM CHART

Detected items (Screen terms)	System Condition	Reference item
ECU trouble	Height sensor error	Replace height sensor.
No initialisation	Initialisation not done	LT-37
Sensor out of range	Sensor left specified range	Replace height sensor.
Sensor not plausible	Sensor signal constant for more than 60s while car is moving.	Replace height sensor.
Supply voltage low	Supply voltage below 9V	LT-38
Light signal open line	Open line at low beam switch	LT-39
Speed frequency error	Frequency of speed line over specified limit	LT-39
Actuator shorted to ground	Calculated output value differs from measured output value.	LT-40
Actuator shorted to battery	Calculated output value differs from measured output value.	LT-40

Check Power and Ground for Height Sensor

EKS0054Z

1. POWER SUPPLY CIRCUIT CHECK

Height sensor power supply check


Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
B152	2 (Y/G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between height sensor and fuse



2. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check continuity between height sensor connector B152 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

OK >> Height sensor OK.

NG >> Repair or replace harness connector.



HEADLAMP AIMING CONTROL (AUTO)

EKS00550

Check Lighting Switch Circuit


1. LIGHTING SWITCH INPUT SIGNAL CHECK

1. Disconnect height sensor connector.
2. Turn ignition switch ON.
3. Check voltage between height sensor connector B152 terminal 6 (R/Y) and ground.

Condition for lighting switch	Voltage (V)
Lighting switch in 2ND position	Approx. 12
Except for superscription	Approx. 0

OK or NG

- OK >> Replace the height sensor.
 NG >> GO TO 2.




2. LIGHTING SWITCH OPEN CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check harness continuity between height sensor connector B152 terminal 6 (R/Y) and lighting switch terminal connector E115 terminal 10 (R/Y).

Continuity should exist.

OK or NG

- OK >> Check combination switch [LT-86, "COMBINATION SWITCH"](#).
 NG >> Repair or replace harness.



Check Speed Signal Circuit Check

EKS00551

1. SPEED SIGNAL CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Check continuity between height sensor connector B152 terminal 6 (SB) and combination meter connector M37 terminal 35 (LHD MODELS) or 48 (RHD MODELS).


Continuity should exist.

4. Check continuity between height sensor connector B152 terminal 1 (B) and ground.

Continuity should not exist.

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace harness.




HEADLAMP AIMING CONTROL (AUTO)

2. SPEED SIGNAL SHORT CIRCUIT CHECK

1. Turn ignition switch ON.
2. Check speed signal between combination meter connector M37 terminal 35 (LHD MODELS) or 48 (RHD MODELS) and ground.

Terminals		Shape of waves	
(+)		(-)	
Connector	Terminal (Wirecolor)		
M37	35 (SB)	Ground	
	48 (SB)		



OK or NG

- OK >> Replace the height sensor.
 NG >> Replace the combination meter.

Check Headlamp Aiming Motor

EKS00552


1. HEADLAMP AIMING MOTOR CIRCUIT CHECK

1. Disconnect height sensor connector.
2. Check continuity between height sensor connector B152 terminal 7 (BR/W) and headlamp aiming motor connector E25 (RH) terminal 2 (BR/W) or E50 (LH) terminal 2 (BR/W).

Continuity should exist.

OK or NG


- OK >> GO TO 2.
 NG >> Repair or replace harness.



2. POWER SUPPLY CIRCUIT CHECK

1. Connect height sensor connector.
2. Check voltage between headlamp aiming motor connector E25 (RH) terminal 3 (Y/G) or E50 (LH) terminal 3 (Y/G) and ground.

Terminals		Ignition switch position			
(+)		(-)			
Connector	Terminal (wire color)	OFF	ACC	ON	
E25	3 (Y/G)	Ground	0V	0V	Battery voltage
E50					



OK or NG


- OK >> GO TO 3.
 NG >> Check the following.
- 10A fuse [No. 10, located in fuse block (J/B)]
 - Harness for open or short between headlamp aiming motor and fuse

HEADLAMP AIMING CONTROL (AUTO)

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect headlamp aiming motor connector.
3. Check continuity between headlamp aiming motor connector E25 (RH) terminal 1 (B) or E50 (LH) terminal 1 (B) and ground.

Terminals			Continuity
(+)		(-)	
Connector	Terminal (wire color)		
E25	1 (B)	Ground	YES
E50			




OK or NG

- OK >> Replace the headlamp aiming motor.
 NG >> Repair or replace harness.

Removal and installation

EKS004TD



TURN SIGNAL AND HAZARD WARNING LAMPS

TURN SIGNAL AND HAZARD WARNING LAMPS

PFP:26120

System Description

EKS003TP

The turn signal and hazard warning lamps operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit.

Power is supplied at all time

- to smart entrance control unit terminal 56, and
- to combination meter terminal 52 (LHD models) or 39 (RHD models)
- through 10A fuse [No. 12, located in the fuse block (J/B)]

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- to smart entrance control unit terminal 29
- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to combination meter terminal 51 (LHD models) or 38 (RHD models)
- through 10A fuse [No. 30, located in the fuse block (J/B)]

LH Turn

When the turn signal switch is moved to the LH position, ground is supplied

- to smart entrance control unit terminal 25 from turn signal switch terminal 3
- through turn signal switch terminal 1
- through body grounds E10 and E58

Power is supplied from smart entrance control unit terminal 64 to

- front turn signal lamp LH terminal 1
- side turn signal lamp LH terminal 1
- rear combination lamp LH terminal 5 (for sedan models)
- rear combination lamp LH terminal 1 (for wagon models)

Ground is supplied to the front turn signal lamp LH terminal 2 through body grounds E10 and E58

Ground is supplied to the side turn signal lamp LH terminal 2 through body grounds E10 and E58

Ground is supplied to the rear combination lamp LH terminal 4 through body grounds B17 and B24 (for sedan models)

Ground is supplied to the rear combination lamp LH terminal 4 through body grounds B17, B24 and D94 (for wagon models)

With power and ground supplied, the smart entrance control unit controls the flashing of the LH turn signal lamps, and smart entrance control unit sent LH turn signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminal 8 and 11.

Turn signal LH is flushing of combination meter.

RH Turn

When the turn signal switch is moved to the RH position, ground is supplied

- to smart entrance control unit terminal 26 from turn signal switch terminal 2
- through turn signal switch terminal 1
- through body grounds E10 and E58

Power is supplied from smart entrance control unit terminal 63 to

- front turn signal lamp RH terminal 1
- side turn signal lamp RH terminal 1
- rear combination lamp RH terminal 2 (for sedan models)
- rear combination lamp RH terminal 1 (for wagon models)

Ground is supplied to the front turn signal lamp RH terminal 2 through body grounds E10 and E58

Ground is supplied to the side turn signal lamp RH terminal 2 through body grounds E10 and E58

TURN SIGNAL AND HAZARD WARNING LAMPS

Ground is supplied to the rear combination lamp RH terminal 3 through body grounds B17 and B24 (for sedan models)

Ground is supplied to the rear combination lamp RH terminal 4 through body grounds B17, B24 and D94 (for wagon models)

With power and ground supplied, the smart entrance control unit controls the flashing of the RH turn signal lamps, and smart entrance control unit sent RH turn signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminal 8 and 11.

HAZARD LAMP OPERATION

When the hazard switch in the ON position

Ground supplied

- to smart entrance control unit terminal 30 from hazard switch terminal 1
- through hazard switch terminal 3
- through body grounds M16, M48 and M50

Power is supplied from smart entrance control unit terminal 64 to

- front turn signal lamp LH terminal 1
- side turn signal lamp LH terminal 1
- rear combination lamp LH terminal 5 (for sedan models)
- rear combination lamp LH terminal 1 (for wagon models)

Power is supplied from smart entrance control unit terminal 63 to

- front turn signal lamp RH terminal 1
- side turn signal lamp RH terminal 1
- rear combination lamp RH terminal 2 (for sedan models)
- rear combination lamp RH terminal 1 (for wagon models)

Ground is supplied to terminal 2 each front turn signal lamp through body grounds E10 and E58

Ground is supplied to terminal 2 each side turn signal lamp through body grounds E10 and E58

Ground is supplied to terminal 3 each rear combination lamp through body grounds B17 and B24 (for sedan models)

Ground is supplied to terminal 4 each rear combination lamp through body grounds B17, B24 and D94 (for wagon models)

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps, and smart entrance control unit sent hazard warning signal to combination meter with CAN communication line.

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminals 8 and 11.

MULTI-REMOTE CONTROL SYSTEM OPERATION

When smart entrance control unit receives LOCK or UNLOCK signal from remote controller with all doors closed, power is supplied

- through smart entrance control unit terminal 64
- to front turn signal lamp LH terminal 1 and
- to side turn signal lamp LH terminal 1 and
- to rear combination lamp LH terminal 5 (for sedan models) and
- to rear combination lamp LH terminal 1 (for wagon models) and
- through smart entrance control unit terminal 63
- to front turn signal lamp RH terminal 1 and
- to side turn signal lamp RH terminal 1 and
- to rear combination lamp RH terminal 2 (for sedan models) and
- to rear combination lamp RH terminal 1 (for wagon models)

A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS

Ground is supplied to terminal 2 each front turn signal lamp through body grounds E10 and E58

Ground is supplied to terminal 2 each side turn signal lamp through body grounds E10 and E58

Ground is supplied to terminal 3 each rear combination lamp through body grounds B17 and B24 (for sedan models)

Ground is supplied to terminal 4 each rear combination lamp through body grounds B17, B24 and D90 (for wagon models)

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps. and smart entrance control unit sent hazard warning signal to combination meter with CAN communication line [LT-125, "CAN COMMUNICATION"](#) .

- to combination meter terminal 43 (LHD models) or 30 (RHD models) and 44 (LHD models) or 31 (RHD models)
- from smart entrance control unit terminals 8 and 11

Turn signal is flushing of combination meter.





TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

EKS0037Q

LT-TURN-01


- : DATA LINE
L : LHD MODELS
R : RHD MODELS
- *1 52: L
 - 39: R
 - *2 51: L
 - 38: R
 - *3 45: L
 - 32: R
 - *4 24: L
 - 11: R
 - *5 25: L
 - 12: R
 - *6 44: L
 - 31: R
 - *7 43: L
 - 30: R




A
B
C
D
E
F
G
H
I
J
LT
L
M

TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02



- S : SEDAN *1 16: L
- W : WAGON 19: R
- L : LHD MODELS *2 17: L
- R : RHD MODELS 20: R



MKWA0256E

TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal and Reference Valve for Smart Entrance Control Unit

EKS00553

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
8	L	CAN communication line	—	—
11	R	CAN communication line	—	—
25	G/B	Combination switch (Turn signal switch)	Turn signal switch: Neutral → Left turn position	12V → 0V
26	G/Y	Combination switch (Turn signal switch)	Turn signal switch: Neutral → Right turn position	12V → 0V
29	Y/G	Ignition key switch	Ignition key is in "ON" position	12V
30	G/R	Hazard switch	Hazard switch: OFF → ON	12V → 0V
53	B	Ground	—	0V
56	R/B	Power source	—	12V
63	G/Y	RH turn signal lamp	[When door lock or unlock is operated using remote controller] Turn signal lamp: OFF → ON → OFF	0V → 12V → 0V
64	G/B	LH turn signal lamp	[When door lock or unlock is operated using remote controller] Turn signal lamp: OFF → ON → OFF	0V → 12V → 0V

Turn Signal And Hazard Warning Lamp Do Not Operate

EKS0054Q

1. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.
Refer to [BCS-39, "Trouble Diagnoses"](#) .

Does the display of CAN appear?

YES or NO

- YES >> Check the CAN communication line.
- NO >> GO TO 2.

2. FUSE CHECK

Check if any of the following fuses in smart entrance control unit.

Unit	Power source	Fuse No.
Smart entrance control unit	Battery	12
	Ignition switch ON or START position	10

OK or NG


- OK >> GO TO 3.
- NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse.

TURN SIGNAL AND HAZARD WARNING LAMPS

3. POWER SUPPLY CIRCUIT CHECK

Check smart entrance control unit power supply.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M43	56 (R/B)	Ground	Battery voltage	Battery voltage	Battery voltage
M42	29 (Y/G)	Ground	0V	0V	Battery voltage



OK or NG

OK >> GO TO 4.

NG >> Check harness for open or short between smart entrance control unit and fuse.

4. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Disconnect smart entrance control unit connector.
3. Check continuity between smart entrance control unit harness connector M43 terminal 53 (B) and ground.

Continuity should exist.

OK or NG

OK >> Replace smart entrance control unit.

NG >> Repair or replace harness.



Turn Signal Lamps Do Not Operate But Hazard Warning Lamp Do Operate

EKS004Q4

1. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.

Refer to [BCS-39, "Trouble Diagnoses"](#).

Does the display of CAN appear?

YES or NO

YES >> Check the CAN communication line.

NO >> GO TO 2.

TURN SIGNAL AND HAZARD WARNING LAMPS


2. TURN SIGNAL SWITCH GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect turn signal switch connector.
3. Check continuity between combination switch harness connector E115 terminal 1 (B) and ground.

Continuity should exist.

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace harness.



3. TURN SIGNAL SWITCH CHECK

Check turn signal switch [LT-86, "COMBINATION SWITCH"](#) .

OK or NG

- OK >> Replace smart entrance control unit.
NG >> Replace turn signal switch.

Hazard Warning Lamps Do Not Operate But Turn Signal Lamp Do Operate

EKS0054R

1. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.

Refer to [BCS-39, "Trouble Diagnoses"](#) .

Does the display of CAN appear?

YES or NO

- YES >> Check the CAN communication line.
NO >> GO TO 2.

A
B
C
D
E
F
G
H
I
J
L
M

LT

TURN SIGNAL AND HAZARD WARNING LAMPS

2. CHECK HAZARD SWITCH INPUT SIGNAL

WITH CONSULT-II

Check hazard switch in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR			
MONITOR			
IGNITION SW	ON		
HAZARD SW	OFF		
RH TURN SW	OFF		
LH TURN SW	OFF		
RKE LOCK	OFF		
RKE UNLOCK	OFF		
RKE SEL UNLOCK	OFF		
RECORD			
MODE	BACK	LIGHT	COPY

MKIB0194E


WITHOUT CONSULT-II

Check battery voltage between smart entrance control unit harness connector M42 terminal 30 (G/R) and ground.

Condition	Voltage (V)
Hazard switch ON	0
Hazard switch OFF	Approx. 0.5

OK or NG

- OK >> Hazard switch OK.
- NG >> GO TO 3.




3. HAZARD SWITCH CHECK

1. Turn ignition switch OFF.
2. Disconnect hazard switch connector.
3. Check continuity between hazard switch terminal 1 (G/R) and 3 (B).

Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Replace the hazard switch.




4. GROUND CIRCUIT CHECK

Check continuity between hazard switch harness connector M48 terminal 3 (B) and ground.

Continuity should exist.

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and hazard switch.
- NG >> Repair or replace harness.



TURN SIGNAL AND HAZARD WARNING LAMPS

Turn Signal Lamps LH Do Not Operate

EKS004Q6

1. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.
Refer to [BCS-39, "Trouble Diagnoses"](#) .

Does the display of CAN appear?

YES or NO

- YES >> Check the CAN communication line.
- NO >> GO TO 2.

2. BULB CHECK

Check turn signal lamp LH bulb.

OK or NG

- OK >> GO TO 3.
- NG >> Replace bulb.

3. CHECK TURN SWITCH LH INPUT SIGNAL

Check turn switch LH signal in "DATA MONITOR" mode with CONSULT-II.

OK or NG

- OK >> Turn signal switch OK.
- NG >> GO TO 4.

DATA MONITOR			
MONITOR			
IGNITION SW	ON		
HAZARD SW	OFF		
RH TURN SW	OFF		
LH TURN SW	OFF		
RKE LOCK	OFF		
RKE UNLOCK	OFF		
RKE SEL UNLOCK	OFF		
		RECORD	
MODE	BACK	LIGHT	COPY

MKIB0194E


4. POWER SUPPLY CIRCUIT CHECK

Check battery voltage between smart entrance control unit harness connector M43 terminal 64 (G/B) and ground.

Condition	Voltage
Turn signal LH illuminates.	0V
Turn signal LH does not illuminate.	Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> Replace the smart entrance control unit.




TURN SIGNAL AND HAZARD WARNING LAMPS

5. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect each turn signal lamps LH connector.
3. Check continuity between the following harness connector terminal of the each turn signal lamps LH and body ground.

Terminals		(-)	Continuity
(+) Connector			
Connector	Terminal (Wire color)		
E51	2 (B)	Ground	Yes
E59	2 (B)	Ground	Yes
B38	4 (B)	Ground	Yes
B62	4 (B)	Ground	Yes



OK or NG

- OK >> Check harness for open or short smart between entrance control unit and hazard switch.
 NG >> Repair or replace harness.

Turn Signal Lamps RH Do Not Operate

EKS004Q7

1. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.
 Refer to [BCS-39, "Trouble Diagnoses"](#).

Does the display of CAN appear?

YES or NO

- YES >> Check the CAN communication line.
 NO >> GO TO 2.

2. BULB CHECK

Check turn signal lamp RH bulb.

OK or NG


- OK >> GO TO 3.
 NG >> Replace bulb.

3. CHECK TURN SWITCH LH INPUT SIGNAL

Check turn switch RH signal in "DATA MONITOR" mode with CONSULT-II.

OK or NG

- OK >> Turn signal switch OK.
 NG >> GO TO 4.



TURN SIGNAL AND HAZARD WARNING LAMPS


4. POWER SUPPLY CIRCUIT CHECK

Check battery voltage between smart entrance control unit harness connector M43 terminal 63 (G/Y) and ground.

Condition	Voltage
Turn signal RH illuminates.	0V
Turn signal RH does not illuminate.	Battery voltage

OK or NG

- OK >> GO TO 5.
- NG >> Replace the smart entrance control unit.




5. GROUND CIRCUIT CHECK

- Turn ignition switch OFF.
- Disconnect each turn signal lamps RH connector.
- Check continuity between the following harness connector terminal of the each turn signal lamps RH and body ground.

Terminals		Continuity
(+)	(-)	
Connector	Terminal (Wire color)	
E1	2 (B)	Ground Yes
E24	2 (B)	Ground Yes
B39	4 (B)	Ground Yes
B64	3 (B)	Ground Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and hazard switch.
- NG >> Repair or ground circuit.



LH and RH Turn Indicators Do Not Operate

EKS0054S

1. COMBINATION METER POWER AND GROUND CIRCUIT CHECK

Check combination meter power and ground circuit check.

Refer to [DI-29, "Power Supply and Ground Circuit Check"](#) (LHD) or [DI-58, "Power Supply and Ground Circuit Check"](#) (RHD).

OK or NG

- OK >> GO TO 2.
- NG >> Replace combination meter.

2. SELF-DIAGNOSIS FOR SMART ENTRANCE CONTROL UNIT

Perform smart entrance control unit self-diagnosis mode.

Refer to [BCS-39, "Trouble Diagnoses"](#).

Does the display of CAN appear?

YES or NO

- YES >> Check the CAN communication line.
- NO >> Replace combination meter.

TURN SIGNAL AND HAZARD WARNING LAMPS

Bulb Replacement FRONT TURN SIGNAL LAMP


EKS003TT

Refer to [LT-9, "CLEARANCE LAMP, FRONT TURN SIGNAL LAMP"](#).

Front turn signal lamp : 12V - 21W (amber)

SIDE TURN SIGNAL LAMP

1. Remove side turn signal lamp. Refer to [LT-54, "Removal and Installation for Side Turn Signal Lamp"](#).
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from its socket.



Side turn signal lamp : 12V - 5W


REAR TURN SIGNAL LAMP

Refer to [LT-82, "REAR COMBINATION LAMP"](#).

Removal and Installation for Side Turn Signal Lamp

EKS003TV

1. Push the side turn signal lamp toward A direction in the figure, and pull up B direction in the figure.
2. Disconnect the side turn signal lamp connector.



Removal and Installation for Rear Turn Signal Lamp

EKS003TW

Refer to [LT-82, "REAR COMBINATION LAMP"](#).

LIGHTING AND TURN SIGNAL SWITCH


LIGHTING AND TURN SIGNAL SWITCH

PF2:25540

Removal and Installation

EKS003TX

1. Remove the steering column cover. Refer to [PS-10, "STEERING COLUMN"](#).
2. Remove lighting and turn signal switch mounting screw and remove the lighting and turn signal switch from the spiral cable.



3. Disconnect the lighting and turn signal switch connector.

Switch Circuit Inspection

EKS003TY

Using circuit tester, check continuity between the lighting and turn signal switch connector terminals in each operation status of the switch.

- Lighting switch; refer to [LT-86, "COMBINATION SWITCH"](#).
- Turn signal lamp switch; refer to [LT-45, "Wiring Diagram — TURN —"](#).
- Front fog lamp switch; refer to [LT-72, "Wiring Diagram — F/FOG —"](#).
- Rear fog lamp switch; refer to [LT-75, "Wiring Diagram — R/FOG — /Without Front Fog Lamp"](#), [LT-76, "Wiring Diagram — R/FOG — /With Front Fog Lamp"](#).

A
B
C
D
E
F
G
H
I
J
L
M

LT

HAZARD SWITCH

HAZARD SWITCH


PFP:25290

Removal and Installation

EKS003TZ

REMOVAL

1. Remove cluster lid C. Refer to [IP-6, "CLUSTER LID C"](#) in "INSTRUMENT PANEL (IP)" section.
2. Using a flat-bladed screwdriver or other suitable tool, press pawl to remove hazard switch from cluster lid C.



INSTALLATION

Installation is in the reverse order of removal.

STOP LAMP



PFP:26550

STOP LAMP

Wiring Diagram — STOP/L —

LT-STOP/L-01

EKS003U0



REFER TO THE FOLLOWING.






(M2) - FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0021E

STOP LAMP

LT-STOP/L-02

W : WAGON



MKWA0022E

STOP LAMP

Bulb Replacement STOP LAMP

EKS003U1

A

Refer to [LT-82, "REAR COMBINATION LAMP"](#)

Removal and Installation STOP LAMP

EKS003U2

B

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

C

D

E

F

G

H

I

J

LT

L

M

BACK-UP LAMP


PFP:26550

BACK-UP LAMP


Wiring Diagram — BACK/L —

EKS003U3

LT-BACK/L-01



- (L) : LHD MODELS
- (R) : RHD MODELS
- (G) : WITH GASOLINE ENGINE
- (D) : WITH DIESEL ENGINE
- (A) : WITH A/T
- (C) : WITH CVT
- (M) : WITH M/T
- (QR) : WITH QR ENGINE
- (QG) : WITH QG ENGINE
- *1 4: (QR)
- 3: (QG)
- *2 6: (QR)
- 4: (QG)
- *3 7: (QR)
- 17: (QG)










REFER TO THE FOLLOWING.

(E106) - FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0023E

BACK-UP LAMP

LT-BACK/L-02



A
B
C
D
E
F
G
H
I
J
LT
L
M

BACK-UP LAMP

Bulb Replacement (Sedan)

EKS003U4

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

Bulb Replacement (Wagon)

EKS0055D

Refer to [LT-63, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

Removal and Installation (Sedan)

EKS003U5

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

Removal and Installation (Wagon)

EKS0055E

Refer to [LT-63, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

PARKING, LICENSE PLATE AND TAIL LAMPS






PARKING, LICENSE PLATE AND TAIL LAMPS

PFP:26550

Wiring Diagram - TAIL/L -/LHD MODELS

EKS004Q9






LT-TAIL/L-01



REFER TO THE FOLLOWING.
 (M1, E106, B1) - FUSE BLOCK- JUNCTION BOX (J/B)

PARKING, LICENSE PLATE AND TAIL LAMPS


LT-TAIL/L-02



MKWA0016E






PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-03



A
B
C
D
E
F
G
H
I
J
K
L
M

LT





MKWA0017E

PARKING, LICENSE PLATE AND TAIL LAMPS

EKS004QA

LT-TAIL/L-04

Wiring Diagram - TAIL/L -/RHD MODELS



REFER TO THE FOLLOWING.
 (E106), (B1) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0018E






PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-05

PRECEDING PAGE

NEXT PAGE






- : SEDAN
- : WAGON
- : WITH REARVIEW MONITOR
- : WITHOUT REARVIEW MONITOR



MKWA0019E

PARKING, LICENSE PLATE AND TAIL LAMPS

LT-TAIL/L-06



MKWA0020E

PARKING, LICENSE PLATE AND TAIL LAMPS

Bulb Replacement PARKING AND TAIL LAMPS


EKS003U7

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

LICENSE PLATE LAMP

1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb from its socket.

License plate lamp : 12V - 5W



Removal and Installation PARKING AND TAIL LAMPS


EKS003U8

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .


LICENSE PLATE LAMP

Removal (Sedan)

1. Remove the license lamp finisher. Refer to [EI-21, "LICENSE PLATE FINISHER"](#) .
2. Remove the harness from installation pawl for harness.



3. Push license plate lamp mounting hook.
4. Pull out license plate lamp from finisher.



Installation


- Install license plate lamp in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
LT
L
M


PARKING, LICENSE PLATE AND TAIL LAMPS

Removal (Wagon)

1. Remove the license lamp finisher. Refer to [EI-21, "LICENSE PLATE FINISHER"](#) .
2. Remove the harness from installation pawl for harness.



3. Push license plate lamp mounting hook.
4. Pull out license plate lamp from finisher.



Installation

- Install license plate lamp in the reverse order of removal.

FRONT FOG LAMP

FRONT FOG LAMP

PFP:00011

System Description DESCRIPTION

EKS003U9

Power is supplied at all times to fog lamp relay terminal 3

- through 15A fuse (No. 43, located in the fuse and fusible link box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- through 10A fuse (No. 32, located in the fuse and fusible link box).
- to lighting switch terminal 11
- through terminal 12 of the lighting switch
- to fog lamp switch terminal 32
- through terminal 31 of the fog lamp switch
- to fog lamp relay terminal 1.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 1st or 2nd position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal 2
- through the fog lamp switch and body grounds E10 and E58.

The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal 5
- to terminal 1 of each fog lamp, and
- to combination meter terminal 6 (LHD models) or 19 (RHD models) for the FRONT FOG indicator.

Ground is supplied to terminals 24, 25 and 45 (LHD models) or 11, 12 and 32 (RHD models) to the combination meter through body grounds M16, M50 and M70.

Ground is supplied to terminal 2 of each fog lamp through body grounds E10 and E58.

With power and ground supplied, the fog lamps and the FRONT FOG indicator illuminate.

A

B

C

D

E

F

G

H

I

J

LT

L


M

FRONT FOG LAMP



Wiring Diagram — F/FOG —

EKS003UA

LT-F/FOG-01



- REFER TO PG-POWER.
- (L) : LHD MODELS
 - (R) : RHD MODELS
 - *1 6: (L)
 - 19: (R)
 - *2 24: (L)
 - 11: (R)
 - *3 45: (L)
 - 32: (R)
 - *4 25: (L)
 - 12: (R)
 - *5 W/L: (L)
 - R/L: (R)




MKWA0025E

FRONT FOG LAMP


Aiming Adjustment

EKS003UB


1. Set the top edge of the fog lamp lens as shown in the figure.



2. Turn front fog lamps ON.



3. Adjust front fog lamps as shown in the figure.
 - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



Bulb Replacement


EKS003UC

1. Remove fender protector.
2. Turn bulb counterclockwise then remove it.

Front fog lamp : 12V - 55W (H11)

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of headlamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of headlamp. When replacing bulb, be sure to replace it with new one.
- When bulb is installed, be sure to lock plastic cap to ensure watertightness.



Removal and Installation

EKS003UD


REMOVAL

1. Remove fender protector. Refer to [EI-14, "FENDER PROTECTOR"](#).
2. Disconnect fog lamp connector.

A
B
C
D
E
F
G
H
I
J
LT
L
M

FRONT FOG LAMP

3. Remove fog lamp mounting bolt.
4. Pull out fog lamp from vehicle and disconnect connector.



INSTALLATION

- Install fog lamp in the reverse order of removal, observing the tightening torque shown below.
Fog lamp mounting screw

 : 3.3 - 7.7 N·m (0.33 - 0.79 kg-m, 29 - 69 in-lb)

REAR FOG LAMP

PFP:26550


REAR FOG LAMP

Wiring Diagram — R/FOG — /Without Front Fog Lamp

EKS003UE


LT-R/FOG-01

REFER TO PG-POWER.



- Ⓛ : LHD MODELS
- Ⓡ : RHD MODELS
- *1 7: Ⓛ
- 20: Ⓡ
- *2 24: Ⓛ
- 11: Ⓡ
- *3 45: Ⓛ
- 32: Ⓡ
- *4 25: Ⓛ
- 12: Ⓡ

R/G → NEXT PAGE



REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK-
 JUNCTION BOX (J/B)








MKWA0026E

REAR FOG LAMP

Wiring Diagram — R/FOG — /With Front Fog Lamp

EKS003UF


LT-R/FOG-02




MKWA0027E

REAR FOG LAMP

LT-R/FOG-03



- (L) : LHD MODELS
- (R) : RHD MODELS
- *1 7: (L) *5 W/L: (L)
- 20: (R) R/L: (R)
- *2 24: (L)
- 11: (R)
- *3 45: (L)
- 32: (R)
- *4 25: (L)
- 12: (R)





REFER TO THE FOLLOWING.
 (E105) - FUSE BLOCK - JUNCTION BOX (J/B)

A
B
C
D
E
F
G
H
I
J
K
L
M

LT

REAR FOG LAMP

LT-R/FOG-04



MKWA0029E

REAR FOG LAMP

Bulb Replacement (Sedan)

EKS003UG


Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

Bulb Replacement (Wagon)

EKS0055G

1. Remove the back door mask RH (RHD) or LH (LHD) on the back door finisher.
2. Turn bulb socket counterclockwise and unlock it.
3. Remove bulb.

Rear fog lamp : 12V - 21W



EKS003UH

Removal and Installation

REMOVAL (SEDAN)

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

REMOVAL (WAGON)

Refer to [LT-63, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

INSTALLATION (SEDAN)

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

INSTALLATION (WAGON)

Refer to [LT-63, "PARKING, LICENSE PLATE AND TAIL LAMPS"](#) .

A
B
C
D
E
F
G
H
I
J
LT
L
M

CLEARANCE LAMP/TAIL LAMP

CLEARANCE LAMP/TAIL LAMP

PFP:26010

Bulb Replacement (Clearance Lamp)

EKS003UI

Refer to [LT-5, "HEADLAMP -CONVENTIONAL TYPE-"](#) .

Bulb Replacement (Tail Lamp)

EKS003UJ

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

Removal and Installation of Clearance Lamp

EKS003UK

Refer to [LT-18, "HEADLAMP \(WITH DAYTIME\) - CONVENTIONAL TYPE -"](#) .

Removal and Installation of Tail Lamp

EKS003UL

Refer to [LT-82, "REAR COMBINATION LAMP"](#) .

HIGH-MOUNTED STOP LAMP

HIGH-MOUNTED STOP LAMP

PFP:26590


Bulb Replacement

HIGH-MOUNTED STOP LAMP (SEDAN)

EKS003UM

1. Open the trunk lid.
2. Turn the bulb socket counterclockwise and unlock it.
3. Remove the bulb from its socket.


High-mounted stop lamp : 12V - 21W



HIGH-MOUNTED STOP LAMP (WAGON)

1. Remove the high-mounted stop lamp. Refer to [LT-81, "HIGH-MOUNTED STOP LAMP"](#) in "Removal and Installation".
2. Turn the high-mounted stop lamp bulb socket counterclockwise and unlock it.
3. Remove the bulb.

High-mounted stop lamp : 12V 5W




Removal and Installation

HIGH-MOUNTED STOP LAMP (SEDAN)


EKS003UN

1. Remove the rear parcel shelf. Refer to [EI-29, "REAR PARCEL SHELF FINISHER"](#).
2. Take off front and rear nails, then remove high-mounted stop lamp from rear parcel shelf finisher.



HIGH-MOUNTED STOP LAMP (WAGON)

1. Remove the back door upper garnish. Refer to [EI-24, "BACK DOOR TRIM"](#).
2. Disconnect the high-mounted stop lamp connector.
3. Remove the high-mounted stop lamp mounting bolts.
4. Remove from the vehicle.



REAR COMBINATION LAMP



PFP:26554

REAR COMBINATION LAMP

Wiring Diagram —STOP/L—

EKS003UO






LT-STOP/L-01



MKWA0021E

REAR COMBINATION LAMP

LT-STOP/L-02



A
B
C
D
E
F
G
H
I
J
LT
L
M

MKWA0022E


REAR COMBINATION LAMP

Bulb Replacement (Sedan)

EKS003UP

1. Open the trunk lid and remove wheel house finisher.
2. Remove rear combination lamp mounting nuts (2).
3. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
4. Turn bulb socket counterclockwise and unlock it.
5. Remove bulbs.

Stop/taillight	: 12V - 21/5W
Rear turn signal lamp	: 12V - 21W
Back-up lamp	: 12V - 21W
Rear fog lamp	: 12V - 21W




Bulb Replacement (Wagon)

EKS0055F

1. Open the back door, and remove rear combination lamp mounting bolts (2).
2. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb.


Stop/taillight	: 12V - 21/5W
Rear turn signal lamp	: 12V - 21W



Removal and Installation REMOVAL (SEDAN)


EKS003UG

1. Open the trunk lid and remove wheel house finisher.
2. Remove rear combination lamp mounting nuts (2).
3. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
4. Disconnect rear combination lamp connector.
5. From outside the vehicle, remove harness.



REMOVAL (WAGON)

1. Open the back door and remove rear combination lamp mounting bolts (2).
2. Pull rear combination lamp toward rear of vehicle. Disengage locating pins (2).
3. Disconnect rear combination lamp connector.
4. From outside the vehicle, remove harness.



INSTALLATION

Install in the reverse order of removal, paying attention to the following.

REAR COMBINATION LAMP

Rear combination lamp mounting bolts and nuts:

 : 2.5 - 3.8 N·m (0.25 - 0.39 kg-m, 23 - 33 in-lb) (SEDAN)

 : 3.3 - 7.7 N·m (0.34 - 0.79 kg-m, 30 - 68 in-lb) (WAGON)

A

B

C

D

E

F

G

H

I

J

LT

L

M

COMBINATION SWITCH

COMBINATION SWITCH

PFP:25567

Removal and Installation


EKS003UR

Refer to [SRS-34, "SPIRAL CABLE"](#) in "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)" section for details.

COMBINATION SWITCH

Switch Circuit Inspection

EKS003US



LIGHTING SWITCH
(With front and rear fog lamp)

N	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
5				○			○	○	○
6				○			○	○	○
7							○	○	○
8				○			○	○	○
9				○			○	○	○
10							○	○	○
11							○	○	○
12							○	○	○

LIGHTING SWITCH
(With rear fog lamp)

N	OFF			1ST			2ND		
	A	B	C	A	B	C	A	B	C
25							○	○	○
5				○			○	○	○
6				○			○	○	○
7							○	○	○
8				○			○	○	○
9				○			○	○	○
10							○	○	○
11							○	○	○
12							○	○	○

FOG LAMP SWITCH
(With front and rear fog lamp)

N	OFF	FR	FR+RR
31		○	○
32		○	○
33			○

FOG LAMP SWITCH
(With rear fog lamp)

N	OFF	RR
34		○
33		○

TURN SIGNAL SWITCH

N	R	N	L
1	○		○
2	○		○
3			○

MKWA0295E

A
B
C
D
E
F
G
H
I
J

LT

L
M

COMBINATION SWITCH

Refer to [LT-55, "Switch Circuit Inspection"](#) in "LIGHTING AND TURN SIGNAL SWITCH" section, and [WW-8, "Terminal and Reference Values for Combination Switch"](#), [WW-38, "Terminal and Reference Values for Combination Switch"](#) in "WW Wiper/Washer Horn" section for details.

ILLUMINATION

ILLUMINATION

PFP:27545

System Description

EKS003UT

Power is supplied at all times

- through 10A fuse [No. 32, located in the fuse and fusible link box]
- to lighting switch terminal 11.

The lighting switch must be in the 1ST or 2ND position for illumination.


The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Headlamp aiming switch	E103	1	2
ESP off switch	M8	3	4
Hazard switch	M48	7	8
Combination meter (LHD models)	M36, M37	51, 52	24, 25, 45
Combination meter (RHD models)	M36, M37	38, 39	11, 12, 32
Audio	M51, M53	1	29
A/T device (With A/T)	M65	3	4
A/T device (With CVT)	M66	1	2
Heated seat switch LH	M104	5	6
Heated seat switch RH	M103	5	6
Door lock/unlock switch	M102	4	3
Glove box lamp	M71	2	1
Ashtray illumination	M57	1	2
AV and NAVI control unit	M54, M55	25	5
VFD Display	M61	20	18
LCD Display	M61	8	1, 3
Multifunction switch	M49	4	2

ILLUMINATION

Schematic

EKS003UU




MKWA0257E

ILLUMINATION

Wiring Diagram


EKS004QB

LT-ILL-01



A
B
C
D
E
F
G
H
I
J
K
L
M






LT



REFER TO THE FOLLOWING.
 (M1), (M2), (E106)
 -FUSE BLOCK-
 -JUNCTION BOX (J/B)

ILLUMINATION

LT-ILL-02




REFER TO THE FOLLOWING.
 (M1) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MKWA0259E

ILLUMINATION

LT-ILL-03



A
B
C
D
E
F
G
H
I
J
LT
L
M








REFER TO THE FOLLOWING.
 (M1), (E106) - FUSE BLOCK -
 JUNCTION BOX (J/B)

MKWA0260E

ILLUMINATION

LT-ILL-04




-  : WITH A/T
-  : WITH CVT
-  : WITH ESP/TCS/ABS CONTROL UNIT



MKWA0261E

ILLUMINATION

LT-ILL-05



LT

MKWA0262E

INTERIOR ROOM LAMP

PFP:26410

System Description POWER SUPPLY AND GROUND

EKS0054T

Power is supplied at all times:

- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to key switch terminal 1 and
- to smart entrance control unit terminal 56
- through 10A fuse [No. 13, located in the fuse block (J/B)]
- to interior room lamp terminal 1 and
- to keyhole illumination terminal 2 and
- to each door steplamp terminal 1.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal 2
- to smart entrance control unit terminal 5.

With the ignition key switch in the ON or START position, power is supplied:

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 29.

Ground is supplied:

- through body grounds terminals M16, M50 and M70
- to smart entrance control unit terminal 53.

When any door (except back door) is opened, ground is supplied:

- through case ground of each door switch
- to each door switch terminal 1
- to smart entrance control unit terminals 39, 43 and 44, 45.

When trunk (For SEDAN) is opened, ground is supplied:

- through body ground B120
- to trunk room lamp switch terminal 2
- to smart entrance control unit terminal 16.

When back door (For WAGON) is opened, ground is supplied:

- through body grounds B17, B24 and D94
- to back door switch terminal 1
- to smart entrance control unit terminal 16.

When the driver side door is unlocked by the door lock/unlock switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M16, M50 and M70
- to door lock/unlock switch terminal 3
- from door lock/unlock switch terminal 2
- to smart entrance control unit terminal 14.

When the driver side door is locked by the door lock/unlock switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M16, M50 and M70
- to door lock/unlock switch terminal 3
- from door lock/unlock switch terminal 1
- to smart entrance control unit terminal 13

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 28
- to interior room lamp terminal 2.

With power and ground supplied, the interior room lamp illuminates.

INTERIOR ROOM LAMP

SWITCH OPERATION

When interior room lamp switch is ON, ground is supplied:

- through case grounds of interior room lamp
- to interior room lamp.

A

INTERIOR ROOM LAMP TIMER OPERATION

When interior room lamp switch is in the "DOOR" position, the time control unit keeps the interior room lamp illuminated for about 30 seconds when:

B

- unlock signal is supplied from driver's door lock/unlock switch while all doors are closed and key is out of ignition key cylinder
- unlock signal is supplied from remote controller while all doors are closed and key is out of the ignition key cylinder.
- key is removed from ignition key cylinder while all doors are closed
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

C

D

E

However, ignition keyhole illumination remains on for about 30 seconds after driver's door has been locked.

F

The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or
- ignition switch is turned ON.

G

ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

H

When any door is opened, step lamps turn ON.

I

J

LT


L

M

INTERIOR ROOM LAMP

Schematic

EKS004RB






MKWA0263E

INTERIOR ROOM LAMP

Wiring Diagram - ROOM/L -/LHD MODELS

EKS004RC

LT-ROOM/L-01





REFER TO THE FOLLOWING.
 (M1), (M2), (E106)
 -FUSE BLOCK-
 JUNCTION BOX (J/B)



INTERIOR ROOM LAMP

LT-ROOM/L-02

PRECEDING PAGE





MKWA0265E

INTERIOR ROOM LAMP

LT-ROOM/L-03

A
B
C
D
E
F
G
H
I
J
K
L
M













LT



MKWA0266E

INTERIOR ROOM LAMP

LT-ROOM/L-04




MKWA0267E

INTERIOR ROOM LAMP

Wiring Diagram - ROOM/L -/RHD MODELS

EKS004RD

LT-ROOM/L-04





REFER TO THE FOLLOWING.

(M1), (M2), (E106)

-FUSE BLOCK-

JUNCTION BOX (J/B)





MKWA0268E

INTERIOR ROOM LAMP

LT-ROOM/L-05

PRECEDING PAGE



MKWA0269E

INTERIOR ROOM LAMP

LT-ROOM/L-06





ES : WITH ESP/TCS/ABS CONTROL UNIT
OE : WITHOUT ESP/TCS/ABS CONTROL UNIT

*1 11: ES

9: OE

*2 24: ES


8: OE













MKWA0270E

INTERIOR ROOM LAMP

LT-ROOM/L-08



- : SEDAN
- : WAGON
- : WITH REARVIEW MONITOR
- : WITHOUT REARVIEW MONITOR
- *1 3 :
- 1 :
- *2 4 :
- 2 :



MKWA0271E

INTERIOR ROOM LAMP

Terminal and Reference Valve for Smart Entrance Control Unit


EKS00554

Terminal No.	Wire color	Connections	Operated condition	Voltage (Approximate values)
5	B/Y	Key switch	Ignition key Removed → Inserted	0V → 12V
13	G/Y	Door lock/unlock switches	Neutral → Locks	12V → 0V
14	BR/Y	Door lock/unlock switches	Neutral → Unlocks	12V → 0V
16	G	Trunk opener switch	Trunk opener switch: OFF → ON (Only when pressed)	12V → 0V
28	R/Y	Interior room lamp	When interior lamp is operated using remote controller (Lamp switch in "DOOR" position)	12V → 0V
29	Y/G	Ignition key switch	Ignition key is in "ON" position	12V
39	BR/W	Rear door switch (Passenger side)	Rear door LH or RH: Open → Closed	0V → 12V
43	R/W	Front door switch (Driver side)	Front door (Driver side): Open → Closed	12V → 0V
44	L/OR	Front door switch (Passenger side)	Front door (Passenger side): Open → Closed	0V → 12V
45	R/Y	Rear door switch (Driver side)	Rear door LH or RH: Open → Closed	0V → 12V
53	B	Ground	—	0V
56	R/B	Power source	—	12V


CONSULT-II Inspection Procedure "ROOM LAMP"

EKS00555

1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



INTERIOR ROOM LAMP


5. Touch "SMART ENTRANCE".



6. Touch "ROOM LAMP".



7. Select diagnosis mode.
"DATA MONITOR" are available for "ROOM LAMP".



CONSULT-II Application Items ROOM LAMP

EKS00556

Data Monitor Mode

Item (CONSULT-II screen terms)	Diagnosed system
IGNITION SW	Indicates [ON/OFF] condition of ignition switch.
KEY IN DETECT	Indicates [ON/OFF] condition of electronic key switch.
DOOR SW DR RR	Indicates [ON/OFF] condition of rear door switch (driver side).
DOOR SW AS RR	Indicates [ON/OFF] condition of rear door switch (passenger side).
AS DOOR SW	Indicates [ON/OFF] condition of front door switch (passenger side).
DR DOOR SW	Indicates [ON/OFF] condition of front door switch (driver side).
CDL LOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch (lock signal).
CDL UNLOCK SW	Indicates [ON/OFF] condition of door lock/unlock switch (unlock signal).
RKE LOCK	Indicates [ON/OFF] condition of lock signal from remote controller.
RKE UNLOCK	Indicates [ON/OFF] condition of unlock signal from remote controller.
RKE SEL UNLOCK	Indicates [ON/OFF] condition of select unlock signal from remote controller.

INTERIOR ROOM LAMP

Interior Room Lamp Timer Does Not Operate

EKS0054U


1. CHECK IGNITION ON SIGNAL

④ WITH CONSULT-II

Check ignition switch ON signal ("IGNITION SW") in "DATA MONITOR" mode with CONSULT-II.

When ignition switch is ON: IGNITION SW ON

When ignition switch is OFF: IGNITION SW OFF



⊗ WITHOUT CONSULT-II

1. Disconnect smart entrance control unit.
2. Check voltage between smart entrance control unit harness connector terminal 29 and ground.


Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
M42	29 (Y/G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse



A
B
C
D
E
F
G
H
I
J
LT
L
M

INTERIOR ROOM LAMP


2. CHECK DOOR SWITCH INPUT SIGNAL

WITH CONSULT-II

Check driver door switch signal ("DR DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When driver's door switch is open: DR DOOR SW ON

When driver's door switch is closed: DR DOOR SW OFF




WITHOUT CONSULT-II

1. Connect smart entrance control unit connector.
2. Check voltage between smart entrance control unit harness connector terminal 43 (R/W) and ground.

Condition	Voltage (V)
Driver's door is open.	0
Driver's door is closed.	Approx. 3

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.




3. CHECK DRIVER SIDE DOOR SWITCH

1. Disconnect smart entrance control unit connector.
2. Check continuity between front door switch (driver side) terminal 1 and ground.

	Terminals	Condition	Continuity
Door switch	1 - Ground	Closed	No
		Open	Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and driver side door switch.
 NG >> Replace driver side door switch.



INTERIOR ROOM LAMP


4. CHECK CENTRAL UNLOCK INPUT SIGNAL

Check voltage between smart entrance control unit harness connector.

Terminals		Condition (Driver's door)	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
M41	14 (BR/Y)	Locked	Approx. 0.5
		Open	0

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.




5. CHECK DOOR LOCK/UNLOCK SWITCH

WITH CONSULT-II

Check door lock/unlock switch signal ("CDL LOCK SW" or "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT-II.

- When door lock/unlock is locked:** CDL LOCK SW ON, CDL UNLOCK SW OFF
- When door lock/unlock is unlocked:** CDL LOCK SW OFF, CDL UNLOCK SW ON




WITHOUT CONSULT-II

1. Disconnect door lock/unlock switch harness connector.
2. Check continuity between door lock/unlock switch terminals 2 and 3.

Condition	Continuity
Door lock/unlock switch is locked.	No
Door lock/unlock switch is unlocked.	Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and door lock/unlock switch.
- NG >> Replace lock/unlock switch.



INTERIOR ROOM LAMP

6. CHECK OTHER DOORS SWITCHES INPUT SIGNAL

WITH CONSULT-II

Check other doors switch signal ("AS DOOR SW", "RR DOOR SW" or "RR RH DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When each doors is open: EACH DOOR SW ON

When each doors is closed: EACH DOOR SW OFF


DATA MONITOR	
MONITOR	
AS DOOR SW	ON
RR LH DOOR SW	ON
RR RH DOOR SW	ON

MKIB0199E

WITHOUT CONSULT-II

Check voltage between smart entrance control unit and ground.

Terminals		Condition (Driver's side)	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
M42	39 (BR/W)	Locked	Approx. 0.5
		Open	0
	44 (L/OR)	Locked	Approx. 3
		Open	0
	45 (R/Y)	Locked	Approx. 0.5
		Open	0



OK or NG

- OK >> GO TO 8.
- NG >> GO TO 7.


7. CHECK DOOR SWITCHES

1. Disconnect door switch harness connector.
2. Check continuity between door switch terminal 1 and ground.

Door switches	Terminals	Condition	Continuity
	1 - Ground	Closed	No
		Open	Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and door switch.
- NG >> Replace driver side door switch.



INTERIOR ROOM LAMP


8. CHECK KEY SWITCH INPUT SIGNAL

WITH CONSULT-II

Check key switch signal ("KEY IN DETECT") in "DATA MONITOR" mode with CONSULT-II.

When key is inserted: KEY IN DETECT ON

When key is removed: KEY IN DETECT OFF




WITHOUT CONSULT-II

Check voltage between smart entrance control unit harness connector terminal 5 (B/R) and ground.

Condition	Voltage (V)
Key is inserted.	Approx. 12
Key is removed.	0

OK or NG

- OK >> Replace smart entrance control unit.
 NG >> GO TO 9.




9. CHECK KEY SWITCH (INSERT)

1. Disconnect key switch connector.
2. Check continuity between 1 and 2.

Condition	Continuity
Key is inserted.	Yes
Key is removed.	No

OK or NG

- OK >> Check the following.
- 10A fuse [No. 12, located in fuse block (J/B)]
 - Harness for open or short between key switch and fuse
 - Harness for open or short between smart entrance control unit and key switch
- NG >> Replace key switch.



INTERIOR ROOM LAMP

Interior Room Lamp Timer Does Not Cancel

EKS0054V


1. CHECK IGNITION ON SIGNAL

④ WITH CONSULT-II

Check ignition switch ON signal ("IGNITION SW") in "DATA MONITOR" mode with CONSULT-II.

When ignition switch is ON: IGNITION SW ON

When ignition switch is OFF: IGNITION SW OFF



⊗ WITHOUT CONSULT-II

1. Disconnect smart entrance control unit connector.
2. Check voltage between smart entrance control unit and ground.


Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (wire color)				
M42	29 (Y/G)	Ground	0V	0V	Battery voltage

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse



INTERIOR ROOM LAMP


2. CHECK DOOR SWITCH INPUT SIGNAL

WITH CONSULT-II

Check driver door switch signal ("DR DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When driver's door switch is open: DR DOOR SW ON

When driver's door switch is closed: DR DOOR SW OFF




WITHOUT CONSULT-II

1. Connect smart entrance control unit connector.
2. Check voltage between smart entrance control unit harness connector terminal 43 (R/W) and ground.

Condition	Voltage (V)
Driver's door is open.	0
Driver's door is closed.	Approx. 3

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.




3. CHECK DRIVER SIDE DOOR SWITCH

1. Disconnect smart entrance control unit connector.
2. Check continuity between front door switch (driver side) terminal 1 and ground.

Door switch	Terminals	Condition	Continuity
	1 - Ground	Closed	No
		Open	Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and driver side door switch.
 NG >> Replace driver side door switch.



INTERIOR ROOM LAMP


4. CHECK CENTRAL UNLOCK INPUT SIGNAL

Check voltage between smart entrance control unit harness connector.

Terminals		Condition (Driver's door)	Voltage [V]
(+)	(-)		
Connector	Terminal (wire color)		
M41	14 (BR/Y)	Locked	Approx. 0.5
		Open	0

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.




5. CHECK DOOR LOCK/UNLOCK SWITCH

WITH CONSULT-II

Check door lock/unlock switch signal ("CDL LOCK SW" or "CDL UNLOCK SW") in "DATA MONITOR" mode with CONSULT-II.

- | | |
|---|---|
| <p>When door lock/unlock is locked:</p> <p>When door lock/unlock is unlocked:</p> | <p>CDL LOCK SW ON</p> <p>CDL UNLOCK SW OFF</p> <p>CDL LOCK SW OFF</p> <p>CDL UNLOCK SW ON</p> |
|---|---|




WITHOUT CONSULT-II

- Disconnect door lock/unlock switch harness connector.
- Check continuity between door lock/unlock switch terminals 2 and 3.

Condition	Continuity
Door lock/unlock switch is locked.	No
Door lock/unlock switch is unlocked.	Yes

OK or NG

- OK >> Check harness for open or short between smart entrance control unit and door lock/unlock switch.
- NG >> Replace lock/unlock switch.



INTERIOR ROOM LAMP

6. CHECK OTHER DOORS SWITCHES INPUT SIGNAL

WITH CONSULT-II

Check other doors switch signal ("AS DOOR SW", "RR DOOR SW" or "RR RH DOOR SW") in "DATA MONITOR" mode with CONSULT-II.

When each doors is open: EACH DOOR SW ON

When each doors is closed: EACH DOOR SW OFF


DATA MONITOR	
MONITOR	
AS DOOR SW	ON
RR LH DOOR SW	ON
RR RH DOOR SW	ON

MKIB0199E

WITHOUT CONSULT-II

Check voltage between smart entrance control unit and ground.

Terminals		(-)	Condition (Driver's side)	Voltage [V]
(+)	Terminal (wire color)			
M42	39 (BR/W)	Ground	Locked	Approx. 0.5
			Open	0
	44 (L/OR)	Ground	Locked	Approx. 3
			Open	0
	45 (R/Y)	Ground	Locked	Approx. 0.5
			Open	0



OK or NG

OK >> GO TO 8.

NG >> GO TO 7.

7. CHECK DOOR SWITCHES


1. Disconnect door switch harness connector.
2. Check continuity between door switch terminal 1 and ground.

Door switches	Terminals	Condition	Continuity
Door switches	1 - Ground	Closed	No
		Open	Yes

OK or NG

OK >> Check harness for open or short between smart entrance control unit and door switch.

NG >> Replace driver side door switch.



INTERIOR ROOM LAMP


8. CHECK KEY SWITCH INPUT SIGNAL

WITH CONSULT-II

Check key switch signal ("KEY IN DETECT") in "DATA MONITOR" mode with CONSULT-II.

When key is inserted: KEY IN DETECT ON

When key is removed: KEY IN DETECT OFF




WITHOUT CONSULT-II

Check voltage between smart entrance control unit harness connector terminal 5 (B/R) and ground.

Condition	Voltage (V)
Key is inserted.	Approx. 12
Key is removed.	0

OK or NG

- OK >> Replace smart entrance control unit.
- NG >> GO TO 9.




9. CHECK KEY SWITCH (INSERT)

1. Disconnect key switch connector.
2. Check continuity between 1 and 2.

Condition	Continuity
Key is inserted.	Yes
Key is removed.	No

OK or NG

- OK >> Check the following.
 - 10A fuse [No. 12, located in fuse block (J/B)]
 - Harness for open or short between key switch and fuse.
 - Harness for open or short between smart entrance control unit and key switch.
- NG >> Replace key switch.



Bulb Replacement INTERIOR ROOM LAMP


Refer to [LT-123, "SPOT LAMP"](#).

EKS0054W

INTERIOR ROOM LAMP

STEP LAMP

1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb.



ASHTRAY


Removal and installation, refer to [LT-119, "ASHTRAY"](#) .

Removal and Installation INTERIOR ROOM LAMP

Refer to [LT-123, "SPOT LAMP"](#) .


STEP LAMP

1. Using a clips driver or a suitable tool, press and remove the metal clip of the step lamp.
2. Disconnect the interior step lamp connector.



ASHTRAY

1. Remove the A/T finisher. Refer to [IP-3, "INSTRUMENT PANEL ASSEMBLY"](#)
2. Remove the console box (front, rear).
3. Remove the instrument finisher E.
4. Remove the cluster lid C.
5. Remove the audio assembly.
6. Turn the bulb socket counterclockwise and unlock it.



A
B
C
D
E
F
G
H
I
J
LT
L
M

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS



PFP:26470

Wiring Diagram — INT/L —

EKS004TZ

LT-INT-01

(S) : SEDAN
(W) : WAGON





REFER TO THE FOLLOWING.
(M2) - FUSE BLOCK-
JUNCTION BOX (J/B)

MKWA0272E

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS






LT-INT/L-02










MKWA0273E

SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

LT-INT/L-03

-  : WAGON
-  : LHD MODELS
-  : RHD MODELS
- *1 1 : 
- 10 : 



MKWA0274E


SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

Bulb Replacement

SPOT LAMP

1. Remove the lens using a clip driver or a suitable tool.
2. Remove the bulb.

Interior room lamp : 12V - 7W
Spot lamp : 12V - 5W



TRUNK ROOM LAMP

Removal and installation, refer to [LT-123, "TRUNK ROOM LAMP"](#) .

Trunk room lamp : 12V - 3.4W

LUGGAGE ROOM LAMP


Removal and installation, refer to [LT-124, "LUGGAGE ROOM LAMP"](#) .

Luggage room lamp : 12V - 10W

Removal and Installation


SPOT LAMP

1. Using a clips driver or a suitable tool, press and remove the hook of the spot lamp.
2. Disconnect the spot lamp connector.



TRUNK ROOM LAMP


1. Remove the lens disengage nail A.
2. Pushing the nail B, remove the trunk room lamp.
3. Disconnect the trunk room lamp connector.



SPOT, VANITY MIRROR AND TRUNK (LUGGAGE) ROOM LAMPS

LUGGAGE ROOM LAMP

1. Using a clips driver or a suitable tool. Press and remove the clip of the luggage room lamp.
2. Disconnect the luggage room lamp connector.



CAN COMMUNICATION

CAN COMMUNICATION

PFP:23710

System Description

EKS00557

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit For LHD Models with Tyre Pressure Monitoring System

EKS00558


Go to CAN system, when selecting your car model from the following table.

Body type	Sedan/Wagon								
Axle	2WD								
Engine	QR20DE		QG18DE	QR20DE	QG16DE	QG18DE	QR20DE	YD22DD Ti	
Transmission	CVT		A/T	6M/T	5M/T		6M/T		
Brake control	ESP		ABS		ESP	ABS			
ICC system	Applicable	Not applicable							
CAN communication unit									
ECM	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					
ESP/TCS/ABS control unit	×	×			×				
ABS actuator and electric unit (control unit)			×	×		×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×			×				
Smart entrance control unit	×	×	×	×	×	×	×	×	×
Tyre pressure monitoring control unit	×	×	×	×	×	×	×	×	×
ICC unit	×								
ICC sensor	×								
Combination meter	×	×	×	×	×	×	×	×	×
CAN communication type	LT-126, "TYPE 1"	LT-127, "TYPE 2"	LT-128, "TYPE 3"	LT-129, "TYPE 4"	LT-130, "TYPE 5"	LT-131, "TYPE 6"			
Can system Trouble diagnosis	LAN-36, "CAN SYS-TEM (TYPE 1)"	LAN-63, "CAN SYS-TEM (TYPE 2)"	LAN-83, "CAN SYS-TEM (TYPE 3)"	LAN-102, "CAN SYS-TEM (TYPE 4)"	LAN-121, "CAN SYS-TEM (TYPE 5)"	LAN-138, "CAN SYSTEM (TYPE 6)"			

CAN COMMUNICATION

TYPE 1

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/ TCS/ ABS control unit	Steer- ing angle sensor	Smart entranc e control unit	Tyre pres- sure monitor- ing control unit	ICC unit	ICC sensor	Combi- nation meter
Engine speed signal	T	R	R				R		R
Accelerator pedal position signal	T	R	R				R		
Closed throttle position signal	T						R		
ICC steering switch signal	T						R		
Shift pattern signal		T					R		
Parking brake switch signal			T				R		
ICC system display signal							T		R
ICC sensor signal							R	T	
ESP operation signal	R		T				R		
TCS operation signal	R		T				R		
ABS operation signal	R	R	T				R		
Stop lamp switch signal		R	T						
Steering wheel angle sensor signal			R	T					
Wheel speed sensor signal			T				R		
Rear window defogger signal	R				T				
Heater fan switch signal	R								T
Air conditioner switch signal	R								T
Primary pulley revolution signal	R	T					R		
Secondary pulley revolution signal	R	T					R		
ICC operation signal	R						T		
Brake switch signal	R						T		
MI signal	T								R
Current gear position signal		T							R
Engine coolant temperature signal	T						R		R
Fuel consumption signal	T								R
Vehicle speed signal			T						R
	R								T
Seat belt reminder signal					R				T

CAN COMMUNICATION

Signals	ECM	TCM	ESP/TCS/ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	ICC unit	ICC sensor	Combination meter
Headlamp switch signal					T				R
Flashing indicator signal					T				R
Engine cooling fan speed signal	T				R				
Child lock indicator signal					T				R
Door switches state signal					T				R
Key ID signal	R				T				
	T				R				
A/C compressor signal	T				R				
Tire pressure signal						T			R

TYPE 2

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS/ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R	R				R
Accelerator pedal position signal	T	R	R				
ESP operation signal	R		T				
TCS operation signal	R		T				
ABS operation signal	R	R	T				
Stop lamp switch signal		R	T				
Steering wheel angle sensor signal			R	T			
Rear window defogger signal	R				T		
Heater fan switch signal	R						T
Air conditioner switch signal	R						T
Primary pulley revolution signal	R	T					
Secondary pulley revolution signal	R	T					
MI signal	T						R
Current gear position signal		T					R
Engine coolant temperature signal	T						R

CAN COMMUNICATION

Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Fuel consumption signal	T						R
Vehicle speed signal			T				R
	R						T
Seat belt reminder signal					R		T
Headlamp switch signal					T		R
Flashing indicator signal					T		R
Engine cooling fan speed signal	T				R		
Child lock indicator signal					T		R
Door switches state signal					T		R
Key ID signal	R				T		
	T				R		
A/C compressor signal	T				R		
Tire pressure signal						T	R

TYPE 3

System diagram



Input/output signal chart


T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tire pressure signal					T	R

TYPE 4 System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Door switches state signal				T		R
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tyre pressure signal					T	R

TYPE 5

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Tyre pressure monitoring control unit	Combination meter
Engine speed signal	T	R				R
Accelerator pedal position signal	T	R				
ESP operation signal	R	T				
TCS operation signal	R	T				
ABS operation signal	R	T				
Steering wheel angle sensor signal		R	T			
Rear window defogger signal	R			T		
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal		T				R
	R					T
Seat belt reminder signal				R		T
Headlamp switch signal				T		R
Flashing indicator signal				T		R
Engine cooling fan speed signal	T			R		
Child lock indicator signal				T		R
Door switches state signal				T		R

CAN COMMUNICATION

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sen- sor	Smart entrance control unit	Tyre pres- sure moni- toring control unit	Combina- tion meter
Key ID signal	R			T		
	T			R		
A/C compressor signal	T			R		
Tire pressure signal					T	R

TYPE 6

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance con- trol unit	Tyre pres- sure moni- toring con- trol unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R*1		T		
Heater fan switch signal	R*1				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal*2	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal			R		T
Headlamp switch signal			T		R
Flashing indicator signal			T		R
Engine cooling fan speed signal	T		R		
Child lock indicator signal			T		R
Door switches state signal			T		R
Key ID signal	R		T		
	T		R		
A/C compressor signal	T		R		
Tire pressure signal				T	R

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

CAN COMMUNICATION

CAN Communication Unit For LHD Models without Tyre Pressure Monitoring System

EKS00559


Go to CAN system, when selecting your car model from the following table.

Body type	Sedan/Wagon									
Axle	2WD									
Engine	QR20DE			QG18DE	QR20DE	QG16DE	QG18DE	QR20DE	YD22DD Ti	
Transmission	CVT			A/T	6M/T	5M/T		6M/T		
Brake control	ESP		ABS		ESP	ABS				
ICC system	Applica- ble	Not applicable								
CAN communication unit										
ECM	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×						
ESP/TCS/ABS control unit	×	×			×					
ABS actuator and electric unit (control unit)			×	×		×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×			×					
Smart entrance control unit	×	×	×	×	×	×	×	×	×	×
ICC unit	×									
ICC sensor	×									
Combination meter	×	×	×	×	×	×	×	×	×	×
Can communication type	<u>LT-133.</u> <u>"TYPE 7"</u>	<u>LT-134.</u> <u>"TYPE 8"</u>	<u>LT-135.</u> <u>"TYPE 9"</u>	<u>LT-136.</u> <u>"TYPE 10"</u>	<u>LT-137.</u> <u>"TYPE 11"</u>	<u>LT-138.</u> <u>"TYPE 12"</u>				
Can system Trouble diagnosis	<u>LAN-156.</u> <u>"CAN SYS-TEM (TYPE 7)"</u>	<u>LAN-179.</u> <u>"CAN SYS-TEM (TYPE 8)"</u>	<u>LAN-195.</u> <u>"CAN SYS-TEM (TYPE 9)"</u>	<u>LAN-210.</u> <u>"CAN SYS-TEM (TYPE 10)"</u>	<u>LAN-225.</u> <u>"CAN SYS-TEM (TYPE 11)"</u>	<u>LAN-238.</u> <u>"CAN SYSTEM (TYPE 12)"</u>				

CAN COMMUNICATION

TYPE 7

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
Engine speed signal	T	R	R			R		R
Accelerator pedal position signal	T	R	R			R		
Closed throttle position signal	T					R		
ICC steering switch signal	T					R		
Shift pattern signal		T				R		
Parking brake switch signal			T			R		
ICC system display signal						T		R
ICC sensor signal						R	T	
ESP operation signal	R		T			R		
TCS operation signal	R		T			R		
ABS operation signal	R	R	T			R		
Stop lamp switch signal		R	T					
Steering wheel angle sensor signal			R	T				
Wheel speed sensor signal			T			R		
Rear window defogger signal	R				T			
Heater fan switch signal	R							T
Air conditioner switch signal	R							T
Primary pulley revolution signal	R	T				R		
Secondary pulley revolution signal	R	T				R		
ICC operation signal	R					T		
Brake switch signal	R					T		
MI signal	T							R
Current gear position signal		T						R
Engine coolant temperature signal	T					R		R
Fuel consumption signal	T							R
Vehicle speed signal			T					R
	R							T
Seat belt reminder signal					R			T
Headlamp switch signal					T			R
Flashing indicator signal					T			R

CAN COMMUNICATION

Signals	ECM	TCM	ESP/ TCS / ABS con- trol unit	Steering angle sensor	Smart entrance control unit	ICC unit	ICC sen- sor	Combina- tion meter
Engine cooling fan speed signal	T				R			
Child lock indicator signal					T			R
Door switches state signal					T			R
Key ID signal	R				T			
	T				R			
A/C compressor signal	T				R			

TYPE 8

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Engine speed signal	T	R	R			R
Accelerator pedal position signal	T	R	R			
ESP operation signal	R		T			
TCS operation signal	R		T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R

CAN COMMUNICATION

Signals	ECM	TCM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	

TYPE 9

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance con- trol unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

TYPE 10

System diagram



Input/output signal chart


T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

CAN COMMUNICATION

TYPE 11

System diagram



Input/output signal chart


T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Accelerator pedal position signal	T	R			
ESP operation signal	R	T			
TCS operation signal	R	T			
ABS operation signal	R	T			
Steering wheel angle sensor signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

CAN COMMUNICATION

TYPE 12

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

CAN COMMUNICATION

CAN Communication Unit For RHD Models with Tyre Pressure Monitoring System

EKS0055A


Go to CAN system, when selecting your car model from the following table.

Body type	Sedan/Wagon									
Axle	2WD									
Engine	QR20DE			QG18DE	QR20DE	QG16DE	QG18DE	QR20DE	YD22DD Ti	
Transmission	CVT			A/T	6M/T	5M/T		6M/T		
Brake control	ESP			ABS		ESP	ABS			
ICC system	Applicable	Not applicable								
CAN communication unit										
ECM	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×						
ICC sensor	×									
ESP/TCS/ABS control unit	×	×			×					
ABS actuator and electric unit (control unit)			×	×		×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×
Tyre pressure monitoring control unit	×	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×			×					
ICC unit	×									
Smart entrance control unit	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×
CAN communication type	<u>LT-140.</u> <u>"TYPE</u> <u>13"</u>	<u>LT-141.</u> <u>"TYPE</u> <u>14"</u>	<u>LT-142.</u> <u>"TYPE</u> <u>15"</u>	<u>LT-143.</u> <u>"TYPE</u> <u>16"</u>	<u>LT-144.</u> <u>"TYPE</u> <u>17"</u>	<u>LT-145.</u> <u>"TYPE 18"</u>				
Can system Trouble diagnosis	<u>LAN-</u> <u>254.</u> <u>"CAN</u> <u>SYS-</u> <u>TEM</u> <u>(TYPE</u> <u>13)"</u>	<u>LAN-</u> <u>282.</u> <u>"CAN</u> <u>SYS-</u> <u>TEM</u> <u>(TYPE</u> <u>14)"</u>	<u>LAN-</u> <u>304.</u> <u>"CAN</u> <u>SYS-</u> <u>TEM</u> <u>(TYPE</u> <u>15)"</u>	<u>LAN-</u> <u>324.</u> <u>"CAN</u> <u>SYS-</u> <u>TEM</u> <u>(TYPE</u> <u>16)"</u>	<u>LAN-</u> <u>344.</u> <u>"CAN</u> <u>SYS-</u> <u>TEM</u> <u>(TYPE</u> <u>17)"</u>	<u>LAN-362.</u> <u>"CAN SYSTEM (TYPE 18)"</u>				

CAN COMMUNICATION

TYPE 13

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R		R			R		R
Accelerator pedal position signal	T	R		R			R		
Closed throttle position signal	T						R		
ICC steering switch signal	T						R		
Shift pattern signal		T					R		
Parking brake switch signal				T			R		
ICC system display signal							T		
ICC sensor signal			T				R		
ESP operation signal	R			T			R		
TCS operation signal	R			T			R		
ABS operation signal	R	R		T			R		
Stop lamp switch signal		R		T					
Steering wheel angle sensor signal				R		T			
Wheel speed sensor signal				T			R		
Rear window defogger signal	R							T	
Heater fan switch signal	R								T
Air conditioner switch signal	R								T
Primary pulley revolution signal	R	T					R		
Secondary pulley revolution signal	R	T					R		
ICC operation signal	R						T		
Brake switch signal	R						T		
MI signal	T								R
Current gear position signal		T							R
Engine coolant temperature signal	T						R		R
Fuel consumption signal	T								R
Vehicle speed signal				T					R
	R								T
Seat belt reminder signal								R	T

CAN COMMUNICATION

Signals	ECM	TCM	ICC sensor	ESP/TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Headlamp switch signal								T	R
Flashing indicator signal								T	R
Engine cooling fan speed signal	T							R	
Child lock indicator signal								T	R
Door switches state signal								T	R
Key ID signal	R							T	
	T							R	
A/C compressor signal	T							R	
Tyre pressure signal					T				R

TYPE 14

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R	R				R
Accelerator pedal position signal	T	R	R				
ESP operation signal	R		T				
TCS operation signal	R		T				
ABS operation signal	R	R	T				
Stop lamp switch signal		R	T				
Steering wheel angle sensor signal			R		T		
Rear window defogger signal	R					T	
Heater fan switch signal	R						T
Air conditioner switch signal	R						T
Primary pulley revolution signal	R	T					
Secondary pulley revolution signal	R	T					
MI signal	T						R
Current gear position signal		T					R
Engine coolant temperature	T						R

CAN COMMUNICATION

Signals	ECM	TCM	ESP/ TCS / ABS control unit	Tyre pressure monitor- ing control unit	Steering angle sensor	Smart entrance control unit	Combi- nation meter
Fuel consumption signal	T						R
Vehicle speed signal			T				R
	R						T
Seat belt reminder signal						R	T
Headlamp switch signal						T	R
Flashing indicator signal						T	R
Engine cooling fan speed signal	T					R	
Child lock indicator signal						T	R
Door switches state signal						T	R
Key ID signal	R					T	
	T					R	
A/C compressor signal	T					R	
Tire pressure signal				T			R

TYPE 15

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actua- tor and electric unit (control unit)	Tyre pres- sure moni- toring control unit	Smart entrance control unit	Combina- tion meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tyre pressure signal				T		R

TYPE 16

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Stop lamp switch signal		R	T			
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tire pressure signal				T		R

TYPE 17

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	ESP/TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R				R
Accelerator pedal position signal	T	R				
ESP operation signal	R	T				
TCS operation signal	R	T				
ABS operation signal	R	T				
Steering wheel angle sensor signal		R		T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
MI signal	T					R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal		T				R
	R					T
Seat belt reminder signal					R	T
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	

CAN COMMUNICATION

Signals	ECM	ESP/ TCS / ABS control unit	Tyre pressure monitoring control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	
Tire pressure signal			T			R

TYPE 18

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
Engine speed signal	T				R
Rear window defogger signal	R ^{*1}			T	
Heater fan switch signal	R ^{*1}				T
Air conditioner switch signal	R				T
MI signal	T				R
Glow lamp signal ^{*2}	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	

CAN COMMUNICATION

Signals	ECM	ABS actuator and electric unit (control unit)	Tyre pressure monitoring control unit	Smart entrance control unit	Combination meter
A/C compressor signal	T			R	
Tire pressure signal			T		R

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

CAN Communication Unit For RHD Models without Tyre Pressure Monitoring System

EKS0055B


Go to CAN system, when selecting your car model from the following table.

Body type	Sedan/Wagon								
Axle	2WD								
Engine	QR20DE		QG18DE	QR20DE	QG16DE	QG18DE	QR20DE	YD22DD Ti	
Transmission	CVT		A/T	6M/T	5M/T		6M/T		
Brake control	ESP		ABS		ESP	ABS			
ICC system	Applicable	Not applicable							
CAN communication unit									
ECM	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×					
ICC sensor	×								
ESP/TCS/ABS control unit	×	×			×				
ABS actuator and electric unit (control unit)			×	×		×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×			×				
ICC unit	×								
Smart entrance control unit	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×
Can communication type	LT-147, "TYPE 19"	LT-148, "TYPE 20"	LT-149, "TYPE 21"	LT-150, "TYPE 22"	LT-151, "TYPE 23"	LT-152, "TYPE 24"			
Can system Trouble Diagnosis	LAN-379, "CAN SYS-TEM (TYPE 19)"	LAN-404, "CAN SYS-TEM (TYPE 20)"	LAN-422, "CAN SYS-TEM (TYPE 21)"	LAN-438, "CAN SYS-TEM (TYPE 22)"	LAN-454, "CAN SYS-TEM (TYPE 23)"	LAN-469, "CAN SYSTEM (TYPE 24)"			

CAN COMMUNICATION

TYPE 19

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ICC sensor	ESP/TCS/ABS control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Engine speed signal	T	R		R		R		R
Accelerator pedal position signal	T	R		R		R		
Closed throttle position signal	T					R		
ICC steering switch signal	T					R		
Shift pattern signal		T				R		
Parking brake switch signal				T		R		
ICC system display signal						T		R
ICC sensor signal			T			R		
ESP operation signal	R			T		R		
TCS operation signal	R			T		R		
ABS operation signal	R	R		T		R		
Stop lamp switch signal		R		T				
Steering wheel angle sensor signal				R	T			
Wheel speed sensor signal				T		R		
Rear window defogger signal	R						T	
Heater fan switch signal	R							T
Air conditioner switch signal	R							T
Primary pulley revolution signal	R	T				R		
Secondary pulley revolution signal	R	T				R		
ICC operation signal	R					T		
Brake switch signal	R					T		
MI signal	T							R
Current gear position signal		T						R
Engine coolant temperature signal	T					R		R
Fuel consumption signal	T							R
Vehicle speed signal				T				R
	R							T
Seat belt reminder signal							R	T
Headlamp switch signal							T	R

CAN COMMUNICATION

Signals	ECM	TCM	ICC sensor	ESP/TCS / ABS control unit	Steering angle sensor	ICC unit	Smart entrance control unit	Combination meter
Flashing indicator signal							T	R
Engine cooling fan speed signal	T						R	
Child lock indicator signal							T	R
Door switches state signal							T	R
Key ID signal	R						T	
	T						R	
A/C compressor signal	T						R	

TYPE 20

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Engine speed signal	T	R	R			R
Accelerator pedal position signal	T	R	R			
ESP operation signal	R		T			
TCS operation signal	R		T			
ABS operation signal	R	R	T			
Stop lamp switch signal		R	T			
Steering wheel angle sensor signal			R	T		
Rear window defogger signal	R				T	
Heater fan switch signal	R					T
Air conditioner switch signal	R					T
Primary pulley revolution signal	R	T				
Secondary pulley revolution signal	R	T				
MI signal	T					R
Current gear position signal		T				R
Engine coolant temperature signal	T					R
Fuel consumption signal	T					R
Vehicle speed signal			T			R
	R					T
Seat belt reminder signal					R	T

CAN COMMUNICATION

Signals	ECM	TCM	ESP/TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combination meter
Headlamp switch signal					T	R
Flashing indicator signal					T	R
Engine cooling fan speed signal	T				R	
Child lock indicator signal					T	R
Door switches state signal					T	R
Key ID signal	R				T	
	T				R	
A/C compressor signal	T				R	

TYPE 21

System diagram



Input/output signal chart

T: Transmit R: Receive


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
Primary pulley revolution signal	R	T			
Secondary pulley revolution signal	R	T			
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R

CAN COMMUNICATION

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

TYPE 22

System diagram



Input/output signal chart


T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T	R			R
Stop lamp switch signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Current gear position signal		T			R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal			T		R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

CAN COMMUNICATION

TYPE 23

System diagram



Input/output signal chart


T: Transmit R: Receive

Signals	ECM	ESP/ TCS / ABS control unit	Steering angle sensor	Smart entrance control unit	Combina- tion meter
Engine speed signal	T	R			R
Accelerator pedal position signal	T	R			
ESP operation signal	R	T			
TCS operation signal	R	T			
ABS operation signal	R	T			
Steering wheel angle sensor signal		R	T		
Rear window defogger signal	R			T	
Heater fan switch signal	R				T
Air conditioner switch signal	R				T
MI signal	T				R
Engine coolant temperature signal	T				R
Fuel consumption signal	T				R
Vehicle speed signal		T			R
	R				T
Seat belt reminder signal				R	T
Headlamp switch signal				T	R
Flashing indicator signal				T	R
Engine cooling fan speed signal	T			R	
Child lock indicator signal				T	R
Door switches state signal				T	R
Key ID signal	R			T	
	T			R	
A/C compressor signal	T			R	

CAN COMMUNICATION

TYPE 24

System diagram



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	ABS actuator and electric unit (control unit)	Smart entrance control unit	Combination meter
Engine speed signal	T			R
Rear window defogger signal	R ^{*1}		T	
Heater fan switch signal	R ^{*1}			T
Air conditioner switch signal	R			T
MI signal	T			R
Glow lamp signal ^{*2}	T			R
Engine coolant temperature signal	T			R
Fuel consumption signal	T			R
Vehicle speed signal		T		R
	R			T
Seat belt reminder signal			R	T
Headlamp switch signal			T	R
Flashing indicator signal			T	R
Engine cooling fan speed signal	T		R	
Child lock indicator signal			T	R
Door switches state signal			T	R
Key ID signal	R		T	
	T		R	
A/C compressor signal	T		R	

*1: Except YD22DDTi engine model

*2: YD22DDTi engine model only

BULB SPECIFICATIONS

BULB SPECIFICATIONS

PFP:26297

Headlamp

EKS003V6

Item		Wattage (W)
High/Low	Without xenon headlamp	55/55 (H7/H7)
	With xenon headlamp	55/35 (H7/D2R)

Exterior Lamp

EKS003V7

Item		Wattage (W)
Front combination lamp	Clearance lamp	5
Front turn signal lamp		21 (amber)
Side turn signal lamp		5
Fog lamp	Front fog lamp	55 (H11)
	Rear fog lamp	21
Rear combination lamp	Stop/Tail lamp	21/5
	Turn signal lamp	21
	Back-up lamp	21
License plate lamp		5
High-mounted stop lamp (Sedan)		21
High-mounted stop lamp (Wagon)		5

Interior Lamp/Illumination

EKS0054Y

Item	Wattage (W)
Interior room lamp	7
Spot lamp	5
Trunk room lamp (Sedan)	3.4
Luggage room lamp (Wagon)	10

A
B
C
D
E
F
G
H
I
J
LT
L
M

LT

BULB SPECIFICATIONS
