

ELECTRICAL SYSTEM

SECTION **EL**

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CONTENTS

PRECAUTIONS	2	Bulb Replacement	37
Supplemental Restraint System (SRS) "AIR BAG"	2	Aiming Adjustment	38
HARNESS CONNECTOR	3	HEADLAMP — Daytime Light System —	39
Description	3	System Description (For Canada)	39
STANDARDIZED RELAY	4	Operation	40
Description	4	Schematic	41
POWER SUPPLY ROUTING	6	Wiring Diagram — DTRL —	42
Schematic	6	Trouble Diagnoses	45
Wiring Diagram — POWER —	7	Bulb Replacement	46
Fuse	12	Aiming Adjustment	46
Fusible Link	12	PARKING, LICENSE, TAIL AND STOP LAMPS	47
Circuit Breaker Inspection	12	Wiring Diagram — TAIL/L —	47
GROUND DISTRIBUTION	13	BACK-UP LAMP	49
BATTERY	16	Wiring Diagram — BACK/L —	49
How to Handle Battery	16	FRONT FOG LAMP	51
Service Data and Specifications (SDS)	19	System Description	51
STARTING SYSTEM	20	Wiring Diagram — F/FOG —	52
System Description	20	Aiming Adjustment	53
Wiring Diagram — START —/M/T Models	22	TURN SIGNAL AND HAZARD WARNING LAMPS	54
Wiring Diagram — START —/A/T Models	23	System Description	54
Construction	24	Schematic	56
Removal and Installation	24	Wiring Diagram — TURN —	57
Pinion/Clutch Check	25	Trouble Diagnoses	60
Service Data and Specifications (SDS)	25	Electrical Components Inspection	60
CHARGING SYSTEM	26	ILLUMINATION	61
System Description	26	System Description	61
Wiring Diagram — CHARGE —	27	Schematic	62
Construction	28	Wiring Diagram — ILL —	63
Removal and Installation	28	INTERIOR, SPOT AND TRUNK ROOM LAMPS	66
Trouble Diagnoses	29	System Description	66
Service Data and Specifications (SDS)	30	Wiring Diagram — INT/L —	67
COMBINATION SWITCH	31	METER AND GAUGES	69
Check	31	System Description	69
Replacement	32	Combination Meter	70
STEERING SWITCH	33	Wiring Diagram — METER —	71
Check	33	Trouble Diagnoses	72
HEADLAMP	34	Electrical Components Inspection	75
System Description (For USA)	34	WARNING LAMPS	76
Wiring Diagram — H/LAMP —	35	Schematic	76
Trouble Diagnoses	36	Wiring Diagram — WARN —	77
		Electrical Components Inspection	80

CONTENTS (Cont'd)

WARNING BUZZER	81	Wiring Diagram — ASCD —	128
System Description	81	CONSULT	133
Wiring Diagram — BUZZER —/Models With		Fail-safe System Description	135
Power Door Locks	83	Fail-safe System Check.....	136
Wiring Diagram — BUZZER —/Models Without		Trouble Diagnoses.....	137
Power Door Locks	84	Electrical Components Inspection	145
Trouble Diagnoses.....	85	ASCD Wire Adjustment	146
Electrical Components Inspection	89	POWER WINDOW	147
WIPER AND WASHER	90	System Description.....	147
System Description.....	90	Wiring Diagram — WINDOW —	149
Wiring Diagram — WIPER —/Without		Trouble Diagnoses.....	151
Intermittent Wiper	92	POWER DOOR LOCK	152
Wiring Diagram — WIPER —/With Intermittent		System Description.....	152
Wiper.....	93	Wiring Diagram — D/LOCK —.....	153
Trouble Diagnoses/With Intermittent Wiper.....	95	Trouble Diagnoses.....	155
Removal and Installation	97	MULTI-REMOTE CONTROL SYSTEM	158
Washer Nozzle Adjustment	98	System Description.....	158
Washer Tube Layout	99	Schematic	160
HORN	100	Wiring Diagram — MULTI —.....	161
Wiring Diagram — HORN —.....	100	Trouble Diagnoses.....	164
CIGARETTE LIGHTER	101	Electrical Components Inspection	170
Wiring Diagram — CIGAR —.....	101	ID Code Entry Procedure	171
CLOCK	102	THEFT WARNING SYSTEM	172
Wiring Diagram — CLOCK —.....	102	Component Parts and Harness Connector	
REAR WINDOW DEFOGGER	103	Location	172
System Description.....	103	System Description.....	173
Wiring Diagram — DEF —.....	104	Schematic	176
Trouble Diagnoses.....	106	Wiring Diagram — THEFT —.....	177
Electrical Components Inspection	108	Trouble Diagnoses.....	182
Filament Check.....	108	SMART ENTRANCE CONTROL UNIT	196
Filament Repair	109	Description.....	196
AUDIO	111	Smart Entrance Control Unit Inspection Table.....	197
System Description.....	111	Schematic	198
Wiring Diagram — AUDIO —/4-speaker.....	112	LOCATION OF ELECTRICAL UNITS	200
Wiring Diagram — AUDIO —/6-speaker.....	113	Engine Compartment.....	200
Trouble Diagnoses.....	115	Passenger Compartment.....	201
AUDIO ANTENNA	116	HARNES LAYOUT	203
System Description.....	116	Outline.....	203
Wiring Diagram — P/ANT —.....	117	Main Harness.....	204
Trouble Diagnoses.....	118	Engine Room Harness	206
Location of Antenna.....	118	Engine Harness	209
Antenna Rod Replacement	118	Engine Control Harness	210
Window Antenna Repair	119	Body Harness and Tail Harness.....	212
POWER SUNROOF	121	Room Lamp Harness.....	214
Wiring Diagram — SROOF —	121	Air Bag Harness	215
POWER DOOR MIRROR	122	Door Harness LH.....	216
Wiring Diagram — MIRROR —.....	122	Door Harness RH	216
AUTOMATIC SPEED CONTROL DEVICE (ASCD)	124	BULB SPECIFICATIONS	217
Component Parts and Harness Connector		Headlamp.....	217
Location	124	Exterior Lamp	217
System Description.....	125	Interior Lamp.....	217
Schematic	127	WIRING DIAGRAM CODES (Cell codes)	218

CONTENTS (Cont'd)

SUPER MULTIPLE JUNCTION (SMJ)Foldout	ELECTRICAL UNITSFoldout
Disconnecting and Connecting.....Foldout	Terminal Arrangement.....Foldout
Terminal Arrangement.....Foldout	

GI

WIRING DIAGRAM REFERENCE CHART

ECCS	EC SECTION
A/T CONTROL, SHIFT LOCK CONTROL	AT SECTION
ANTI-LOCK BRAKE SYSTEM	BR SECTION
SRS "AIR BAG"	RS SECTION
HEATER AND AIR CONDITIONER	HA SECTION

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) “AIR BAG”

The Supplemental Restraint System “AIR BAG”, used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or the complete harness, for easy identification.**

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS










1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)


TYPE	Outer view	Circuit	Connector symbol and connection	Case color
2M				BROWN
1M				BLUE
1T				BLACK

CI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IX

POWER SUPPLY ROUTING

Wiring Diagram — POWER —

BATTERY POWER SUPPLY — IGNITION SW. IN ANY POSITION



EL-POWER-01



FUSE AND FUSIBLE LINK BLOCK-3 (E9)

FUSE AND FUSIBLE LINK BLOCK-2 (E8)

FUSE AND FUSIBLE LINK BLOCK-1 (E59)

CIRCUIT BREAKER (M13)

Refer to last page (Foldout page). (M9) . (E109)







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-02




POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


ACCESSORY POWER SUPPLY — IGNITION SW. IN "ACC" AND "ON"

EL-POWER-03



Refer to EL-POWER-01.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
FA
EL
IDX





POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)



IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-04



POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)



Refer to last page (Foldout page).
 (M9), (E109)


G
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
iDX

POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Power window & power door lock
- Power sunroof
- Multi-remote control system
- Theft warning system

GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE
M5/M57	AIR MIX DOOR MOTOR	M33	HA-A/C
	ASCD CONTROL UNIT	M62	EL-ASCD
	ASCD HOLD RELAY	M58: M/T	EL-ASCD
		M79: A/T	
	ASCD MAIN SWITCH	M17	EL-ASCD
	CIGARETTE LIGHTER SOCKET	M47	EL-CIGAR
	COMBINATION FLASHER UNIT	M32	EL-TURN
	COMBINATION METER (AIR BAG)	M72	EL-WARN
	COMBINATION METER (CLOCK)	M72	EL-CLOCK
	COMBINATION METER (CRUISE)	M71	AT-A/T EL-ASCD
	COMBINATION METER (HIGH BEAM)	M71	EL-H/LAMP EL-DTRL
	COMBINATION METER (SPEED)	M72	EL-METER EL-ASCD EC-VSS
	COMBINATION METER (TACHO)	M72	EL-METER
	COMBINATION METER (TURN)	M71	EL-TURN
	COMBINATION METER (WATER)	M72	EL-METER
	DATA LINK CONNECTOR FOR CONSULT	M7	EC-MIL
	DATA LINK CONNECTOR FOR GST	M74	EC-MIL
	FAN SWITCH	M35	HA-A/C
	FUSE BLOCK (ACCESSORY RELAY)	M6	EL-POWER
	ILLUMINATION CONTROL SWITCH	M16	EL-ILL
	INTAKE DOOR MOTOR	M51	HA-A/C
	MODE DOOR MOTOR	M34	HA-A/C
	POWER WINDOW RELAY	M1	EL-SROOF EL-WINDOW
	PUSH CONTROL UNIT	M77	HA-A/C
	REAR WINDOW DEFOGGER SWITCH	M39	EL-DEF
	REAR WINDOW DEFOGGER TIMER	M18	EL-DEF
	SMART ENTRANCE CONTROL UNIT	M20	EL-INT/L EL-BUZZER EL-DEF EL-D/LOCK EL-THEFT
	THEFT WARNING HORN RELAY-2	M80	EL-THEFT
	WARNING BUZZER UNIT	M19	EL-BUZZER
	SHIELD WIRE (ABS CONTROL UNIT)	T32	BR-ABS
	DOOR KEY CYLINDER SWITCH LH	D10	EL-THEFT
	DOOR KEY CYLINDER SWITCH RH	D110	EL-THEFT
	DOOR LOCK ACTUATOR LH	D12	EL-MULTI EL-THEFT
	DOOR LOCK ACTUATOR RH	D111	EL-MULTI EL-THEFT
DOOR LOCK/UNLOCK SWITCH	D108	EL-D/LOCK	
POWER WINDOW MAIN SWITCH	D8	EL-WINDOW EL-D/LOCK	
SPOT LAMP	R3	EL-INT/L	
AIR BAG DIAGNOSIS SENSOR UNIT	Z1	RS-SRS	
FUSE BLOCK (IGNITION RELAY-1)	M6	EL-POWER	
FUSE BLOCK (IGNITION RELAY-2)	M6	EL-POWER	
COMBINATION METER (FUEL)	M72	EL-METER	

GI

VA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE	
E28/E42	5TH POSITION SWITCH	E215	EC-5TH/P	
	AMBIENT SWITCH	E36	EC-FICD HA-A/C	
	BRAKE FLUID LEVEL SWITCH	E45	EL-WARN	
	CLUTCH INTERLOCK SWITCH	E102	EL-START EL-THEFT	
	COOLING FAN MOTOR	E30	HA-A/C EC-COOL/F	
	DAYTIME LIGHT CONTROL UNIT	E27	EL-DTRL	
	FOG LAMP SWITCH	E108	EL-F/FOG	
	FRONT FOG LAMP LH	E39	EL-F/FOG	
	FRONT FOG LAMP RH	E33	EL-F/FOG	
	FRONT SIDE MARKER LAMP LH	E43	EL-TAIL/L	
	FRONT SIDE MARKER LAMP RH	E22	EL-TAIL/L	
	FRONT TURN SIGNAL LAMP LH	E38	EL-TURN	
	FRONT TURN SIGNAL LAMP RH	E34	EL-TURN	
	HEADLAMP RH (INSIDE)	E49	EL-H/LAMP EL-DTRL	
	HEADLAMP LH (INSIDE)	E50	EL-H/LAMP	
	HEADLAMP RH (OUTSIDE)	E32	EL-H/LAMP EL-DTRL EL-THEFT	
	HEADLAMP LH (OUTSIDE)	E40	EL-H/LAMP EL-THEFT	
	HOOD SWITCH	E21	EL-THEFT	
	NEUTRAL POSITION SWITCH	E214	EC-PNP/SW	
	PARKING LAMP LH	E41	EL-TAIL/L	
	HEADLAMP RELAY	E7	EL-H/LAMP EL-DTRL	
	FOG LAMP RELAY-2	E57	EL-F/FOG	
	PARKING LAMP RH	E31	EL-TAIL/L	
	PARK/NEUTRAL POSITION RELAY	E51	EL-ASCD	
	POWER STEERING OIL PRESSURE SWITCH	E47	EC-PST/SW	
	TRIPLE-PRESSURE SWITCH	E29	EC-FICD HA-A/C	
	WASHER FLUID LEVEL SWITCH	E25	EL-WARN	
	WIPER SWITCH	E104	EL-WIPER	
	E205	ALTERNATOR	E220	EL-CHARGE
	F15/F57	REAR HEATED OXYGEN SENSOR	E217	EC-RRO2
ABS ACTUATOR		F40	BR-ABS	
DISTRIBUTOR (CAMSHAFT POSITION SENSOR)		F31	EC-CMPS EC-IGN/SG	
ECM (ECCS CONTROL MODULE)		F1	EC-MAIN AT-AT	
IACV-AIR REGULATOR		F52	EC-AIRREG	
ABSOLUTE PRESSURE SENSOR		F36	EC-AP/SEN	
CRANKSHAFT POSITION SENSOR (OBD)		E231	EC-CKPS	
FRONT HEATED OXYGEN SENSOR		F16	EC-FRO2 EC-FRO2/H EC-FUEL	
KNOCK SENSOR		F62	EC-KS	
MASS AIR FLOW SENSOR		F30	EC-MAFS	
THROTTLE POSITION SENSOR		F22	EC-TPS	
WIPER AMPLIFIER		F9	EL-WIPER	
WIPER MOTOR		F7	EL-WIPER	
EVAP CONTROL SYSTEM PRESSURE SENSOR		T36	EC-PRE/SE	
DATA LINK CONNECTOR FOR GST		M74	EC-MIL	

GROUND DISTRIBUTION

EARTH	CONNECT TO	CONN. NO.	CELL CODE
B4/B13	DOOR MIRROR REMOTE CONTROL SWITCH	B8	EL-MIRROR
	DOOR SWITCH LH	B10	EL-BUZZER EL-MULTI EL-THEFT RS-SRS
	SEAT BELT BUCKLE SWITCH	B5	EL-WARN EL-BUZZER
	DIODE	B37	AT-SHIFT
	ABS CONTROL UNIT	T33	BR-ABS
	OVERDRIVE CONTROL SWITCH	B7	AT-A/T
	BACK-UP LAMP LH	T9	EL-BACK/L
	BACK-UP LAMP RH	T7	EL-BACK/L
	FUEL PUMP	T30	EC-F/PUMP
	FUEL TANK GAUGE UNIT	T29	EL-METER EC-TFTS EL-WARN
	HIGH-MOUNTED STOP LAMP	T5	EL-TAIL/L
	LICENSE LAMP	T14	EL-TAIL/L
	POWER ANTENNA	T10	EL-P/ANT
	REAR COMBINATION LAMP LH	T13	EL-TAIL/L EL-TURN
	REAR COMBINATION LAMP RH	T19	EL-TAIL/L EL-TURN
	REAR SIDE MARKER LAMP LH	T12	EL-TAIL/L
	REAR SIDE MARKER LAMP RH	T20	EL-TAIL/L
	SHIELD WIRE (ABS CONTROL UNIT)	T32	BR-ABS
TRUNK LID KEY CYLINDER SWITCH	T6	EL-THEFT	
TRUNK ROOM LAMP SWITCH	T8	EL-INT/L EL-THEFT	
T16	DOOR MIRROR REMOTE CONTROL SWITCH	B8	EL-MIRROR
	DOOR SWITCH LH	B10	EL-BUZZER EL-MULTI EL-THEFT
	OVERDRIVE CONTROL SWITCH	B7	AT-A/T
	SEAT BELT BUCKLE SWITCH	B5	EL-WARN EL-BUZZER
	ABS CONTROL UNIT	T33	BR-ABS
	BACK-UP LAMP LH	T9	EL-BACK/L
	BACK-UP LAMP RH	T7	EL-BACK/L
	FUEL TANK GAUGE UNIT	T29	EL-METER EL-WARN EC-TFTS
	FUEL PUMP	T30	EC-F/PUMP
	HIGH-MOUNTED STOP LAMP	T5	EL-TAIL/L
	LICENSE LAMP	T14	EL-TAIL/L
	POWER ANTENNA	T10	EL-P/ANT
	REAR COMBINATION LAMP LH	T13	EL-TAIL/L EL-TURN
	REAR COMBINATION LAMP RH	T19	EL-TAIL/L EL-TURN
	REAR SIDE MARKER LAMP LH	T12	EL-TAIL/L
	REAR SIDE MARKER LAMP RH	T20	EL-TAIL/L
	SHIELD WIRE (ABS CONTROL UNIT)	T32	BR-ABS
	TRUNK LID KEY CYLINDER SWITCH	T6	EL-THEFT
TRUNK ROOM LAMP SWITCH	T8	EL-INT/L EL-THEFT	

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA


EL

IDX

BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.





How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL



WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




SULPHATION

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

BATTERY

How to Handle Battery (Cont'd)

2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

CHARGING THE BATTERY

CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

BATTERY

How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

Service Data and Specifications (SDS)

Applied area		USA	Canada
Type		55D23R	65D26R
Capacity	V-AH	12-60	12-65
Cold cranking current (For reference value)	A	356	413

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

STARTING SYSTEM

System Description

M/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **G** , located in the fuse and fusible link box).

With the ignition switch in the START position, power is supplied

- through terminal ⑤ of the ignition switch
- to clutch interlock relay terminal ③ .

For models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. **1** , located in the fuse block)
- to theft warning relay-2 terminal ① .
- through terminal ③ of the ignition switch
- to theft warning relay-2 terminal ③ .

If the theft warning system is triggered, terminal ② of the theft warning relay-2 is grounded and power to the clutch interlock relay is interrupted.

When the theft warning system is not operating, power is supplied

- through theft warning relay-2 terminal ④
- to clutch interlock relay terminal ① .

For models without theft warning system

With the ignition switch in the ON or START position, power is supplied

- through terminal ③ of the ignition switch
- to clutch interlock relay terminal ① .

Ground is supplied to clutch interlock relay terminal ② , when the clutch pedal is depressed through the clutch interlock switch and body grounds **E42** and **E28** .

The clutch interlock relay is energized and power is supplied

- from terminal ⑤ of the clutch interlock relay
- to terminal ② of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

A/T MODELS

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **G** , located in the fuse and fusible link box).

Models with theft warning system

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. **1** , located in the fuse block)
- to theft warning relay-2 terminal ① .

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to theft warning relay-2 terminal ③ .

If the theft warning system is triggered, terminal ② of the theft warning relay-2 is grounded and power to the inhibitor switch is interrupted.

When the theft warning system is not operating, power is supplied

- through theft warning relay-2 terminal ④
- to inhibitor switch terminal ②
- through inhibitor switch terminal ① , with the selector lever in the P or N position
- to terminal ② of the starter motor windings.

STARTING SYSTEM

System Description (Cont'd)

Models without theft warning system

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ⑤
- to inhibitor switch terminal ②
- through inhibitor switch terminal ① , with the selector lever in the P or N position
- to terminal ② of the starter motor windings.

GI

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

STARTING SYSTEM

Wiring Diagram — START —/M/T Models


EL-START-01



STARTING SYSTEM

Wiring Diagram — START —/A/T Models

EL-START-02




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


STARTING SYSTEM

Construction

SEC. 233
M1T72781B



SEL547RC



Removal and Installation

REMOVAL

1. (A/T model only)
 - Support automatic transmission with a jack.
 - Remove rear mounting bracket bolts (4).
 - Slightly lower the transmission to make room.
 - Pull out ATF level gauge pipe.
2. Remove connector bracket from front mount bracket.
3. Remove harness connector.
4. Remove starter.

INSTALLATION

To install, reverse the removal procedure.

STARTING SYSTEM

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

GI
MA
EM

Service Data and Specifications (SDS)

STARTER

Type	M1T72781B		EC
	MITSUBISHI make		
	Reduction gear type		FE
System voltage	V	12	
No-load			
Terminal voltage	V	11.0	CL
Current	A	50 - 75	
Revolution	rpm	3,000 - 4,000	MT
Minimum diameter of commutator	mm (in)	28.8 (1.134)	
Minimum length of brush	mm (in)	12.0 (0.472)	AT
Brush spring tension	N (kg, lb)	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	
Clearance between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)	PD

LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX

CHARGING SYSTEM

System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal ⑤ through:

- 100A fusible link (letter **n**), located in the fuse and fusible link box), and
- 7.5A fuse (No. **47**), located in the fuse and fusible link box).

Terminal ⑥ supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal ⑤ detecting the input voltage. The charging circuit is protected by the 100A fusible link.

Terminal ⑦ of the alternator supplies ground through body ground **E205**.

With the ignition switch in the ON or START position, power is supplied


- through 7.5A fuse (No. **2**), located in the fuse block)
- to combination meter terminal **14** for the charge warning lamp.

Ground is supplied to terminal **20** of the combination meter through terminal **L** of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

CHARGING SYSTEM




Wiring Diagram — CHARGE —



EL-CHARGE-01

Refer to EL-POWER.



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to last page (Foldout page).
M9, E109

CHARGING SYSTEM

Construction




Removal and Installation

REMOVAL

1. Remove engine undercover.
2. Remove drive belt from alternator.
3. Disconnect harness connector.
4. Remove cooling fan lower shroud.
5. Remove alternator.

INSTALLATION

To install, reverse the removal procedure.




CHARGING SYSTEM

Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

WITH IC REGULATOR



Warning lamp: "CHARGE" warning lamp in combination meter

Note:

- If the inspection result is OK even though the charging system is malfunctioning, check the B terminal connection. (Check the tightening torque.)
- When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

MALFUNCTION INDICATOR

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- Excessive voltage is produced.
- No voltage is produced.

CHARGING SYSTEM







Service Data and Specifications (SDS)

ALTERNATOR

Type		LR180-742C
		HITACHI make
Nominal rating	V-A	12-80
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000
Hot output current (When 13.5 volts is applied)	A/rpm	More than 23/1,300 More than 65/2,500 More than 77/5,000
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.236)
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)
Slip ring minimum outer diameter	mm (in)	26.0 (1.024)
Rotor (field coil) resistance	Ω	2.67

COMBINATION SWITCH

Check




LIGHTING SWITCH

	OFF			1			2		
	A	B	C	A	B	C	A	B	C
5			○			○	○	○	○
6			○			○	○	○	○
7							○		
8			○			○	○	○	○
9			○			○	○	○	○
10							○		
11				○	○	○	○	○	○
12				○	○	○	○	○	○

WIPER SWITCH
(With intermittent wiper)

	OFF	INT	LO	HI	WASH
13	○	○			
14	○	○			
15		○			
16				○	
17				○	○
18					○



FOG LAMP SWITCH

	OFF	ON
31		○
32		○

TURN SIGNAL SWITCH




	L	N	R
1	○		○
2			○
3	○		

WIPER SWITCH
(Without intermittent wiper)

	OFF	LO	HI	WASH
13	○			
14	○			
15				
16			○	
17			○	○
18				○

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

COMBINATION SWITCH





Replacement

For removal and installation of spiral cable, refer to RS section [“Installation — Air Bag Module and Spiral Cable”, “SUPPLEMENTAL RESTRAINT SYSTEM (SRS)”].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

STEERING SWITCH

Check



GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

HEADLAMP

System Description (For USA)

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times

- to lighting switch terminal ⑤ and headlamp relay terminal ③
- through 15A fuse (No. ④①), located in the fuse and fusible link box), and
- to lighting switch terminal ⑧ and headlamp relay terminal ⑥
- through 15A fuse (No. ③⑨), located in the fuse and fusible link box).

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to terminal ① of the LH headlamp (Low beam), and
- from lighting switch terminal ⑦
- to terminal ① of the RH headlamp (Low beam).

Terminal ② of each headlamp supplies ground through body grounds ②②⑧ and ②④②.

With power and ground supplied, the headlamp(s) will illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ① of the RH headlamp (High beam), and
- from lighting switch terminal ⑨
- to terminal ① of the LH headlamp (High beam).
- to combination meter terminal ③⑤ for the high beam indicator, and
- to headlamp relay terminal ①.

Ground is supplied to headlamp relay terminal ② through body grounds ②②⑧ and ②④②. The headlamp relay is energized and power is supplied

- from headlamp relay terminals ⑤ and ⑦
- to terminal ① of each headlamp (Low beam).

Ground is supplied to terminal ②② of the combination meter through body grounds ②②⑤ and ②②⑦.

Terminal ② of each headlamp supplies ground through body grounds ②②⑧ and ②④②.

With power and ground supplied, all the headlamps (High and Low beams) and the high beam indicator illuminate.







Theft warning system

The theft warning system will flash all the headlamps (High and Low beams) if the system is triggered. Refer to "THEFT WARNING SYSTEM" (EL-173).

HEADLAMP

Wiring Diagram — H/LAMP —

EL-H/LAMP-01



Refer to last page (Foldout page).
(M9), (E109)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Trouble Diagnoses





Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E28) and (E42) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E28) and (E42). 3. Check 15A fuse (No. 39), located in fuse and fusible link box). Verify battery positive voltage is present at terminal ⑧ of lighting switch. 4. Check lighting switch.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E28) and (E42) 3. 15A fuse 4. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E28) and (E42). 3. Check 15A fuse (No. 40), located in fuse and fusible link box). Verify battery positive voltage is present at terminal ⑤ of lighting switch. 4. Check lighting switch.
LH high beams do not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in LH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check R/B wire between lighting switch and LH headlamps for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/Y wire between lighting switch and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beams do not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulbs 2. Open in RH high beams circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulbs. 2. Check R/G wire between lighting switch and RH headlamps for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check R/L wire between lighting switch and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (M5) and (M57) 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2. Check grounds (M5) and (M57). 3. Check R/B wire between lighting switch and combination meter for an open circuit.
Low beams do not operate in conjunction with high beams.	<ol style="list-style-type: none"> 1. Headlamp relay 2. Grounds (E28) and (E42) 3. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check headlamp relay. 2. Check grounds (E28) and (E42). 3. Check R/B wire between lighting switch and headlamp relay for an open circuit.

HEADLAMP

Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- Grasp only the plastic base when handling the bulb. Never touch the glass envelope.



1. Disconnect the battery cable.
2. For RH bulb
 - a. Remove the battery.
 For LH bulb
 - a. Remove the air intake duct.
 - b. Open air cleaner box and remove air cleaner filter.
 - c. Remove air cleaner box nuts and bolt, then move air cleaner box in the direction of arrow.
3. Remove the headlamp seal cover.
4. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
5. Disconnect the harness connector from the back side of the bulb.
6. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
7. Install in the reverse order of removal.

CAUTION:

- Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.

Bulb specifications

Item	Wattage (W)
Headlamp	
Inside	65 (HB3)
Outside	55 (H1)

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

HEADLAMP




Aiming Adjustment

Before performing aiming adjustment, make sure of the following.


- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

LOW BEAM

- Open the hood.
- Adjust the vertical indicator by turning the adjusting screw (vertical direction).
The bubble in the gauge should be centered on the "O" mark as shown in the figure.



- Adjust the horizontal indicator by turning the adjusting screw. (horizontal direction)
The inner red line should align with the indicator line.



ADJUSTMENT AFTER HEADLAMP ASSEMBLY REPLACEMENT


If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Adjust headlamps so that the main axis of light becomes:

- parallel to center line of body, and
 - aligned with point P shown in the figure.
- Dotted lines in illustration show center of headlamp.
 - "H": Horizontal center line of headlamps
 - "W_L": Distance between each headlamp center
 - "L": 7,620 mm (300.00 in)
 - "C": 75 mm (2.95 in)

After aiming adjustment using the chart, check the indications to make sure of alignment. Even if the following are observed, it is acceptable while the indications are within the OK ranges.

- Indicator does not align with the indicator line, or
- the bubble is not centered in the vertical indicator.



System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- through 15A fuse (No. 39), located in the fuse and fusible link box
- to daytime light control unit terminal ③,
- to headlamp relay terminal ⑥ and
- to lighting switch terminal ⑧.

Power is also supplied at all times

- through 15A fuse (No. 40), located in the fuse and fusible link box
- to daytime light control unit terminal ②,
- to headlamp relay terminal ③ and
- to lighting switch terminal ⑤.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 1), located in the fuse block
- to daytime light control unit terminal ⑫.

With the ignition switch in the START position, power is supplied

- through 7.5A fuse (No. 25), located in the fuse block
- to daytime light control unit terminal ①.

Ground is supplied to daytime light control unit terminal ⑨ through body grounds E28 and E42.

HEADLAMP OPERATION

Low beam operation

When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑦
- to RH headlamp terminal ①
- to daytime light control unit terminal ④.

Ground is supplied to RH headlamp terminal ② through body grounds E28 and E42.

Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied

- from lighting switch terminal ⑩
- to LH headlamp terminal ①.

Ground is supplied

- to LH headlamp terminal ②
- from daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑨
- through body grounds E28 and E42.

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") or PASS ("C") position, power is supplied

- from lighting switch terminal ⑥
- to terminal ① of RH headlamp (High beam)
- to daytime light control unit terminal ⑧.

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") or PASS ("C") position, power is supplied

- from lighting switch terminal ⑨
- to daytime light control terminal ⑤
- to combination meter terminal ③⑤ for the high beam indicator, and
- to headlamp relay terminal ①
- through daytime light control terminal ⑥
- to terminal ① of LH headlamp (High beam).

Ground is supplied to headlamp relay terminal ② through body grounds E28 and E42.

The headlamp relay is energized and power is supplied

- from headlamp relay terminals ⑤ and ⑦
- to terminal ① of each headlamp (Low beam).

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

HEADLAMP — Daytime Light System —

System Description (For Canada) (Cont'd)

Ground is supplied

- to terminal ② of each RH headlamp (High and Low beams)
- through body grounds (E28) and (E42)
- to terminal ② of each LH headlamp (High and Low beams)
- from daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑨
- through body grounds (E28) and (E42).

Ground is also supplied to terminal ⑳ of the combination meter through body grounds (M5) and (M57).

With power and ground supplied, all the headlamps (High and Low beams) and the high beam indicator illuminate.

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF position, power is supplied

- to daytime light control unit terminal ③
- through daytime light control unit terminal ⑥
- to terminal ① of LH headlamp (High beam)
- through terminal ② of LH headlamp
- to daytime light control unit terminal ⑦
- through daytime light control unit terminal ⑧
- to terminal ① of RH headlamp (High beam).

Ground is supplied to terminal ② of RH headlamp through body grounds (E28) and (E42).

Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
Lighting switch		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	○	X
Clearance and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○

A: "HIGH BEAM" position
 B: "LOW BEAM" position
 C: "FLASH TO PASS" position

○ : Lamp "ON"

X : Lamp "OFF"

△ : Lamp dims.


□ : Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light will not come ON.

HEADLAMP — Daytime Light System —

Schematic



(TW) : With theft warning system



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

HEADLAMP — Daytime Light System —

Wiring Diagram — DTRL —

EL-DTRL-01


: With theft warning system





HEADLAMP — Daytime Light System —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST



Refer to last page (Foldout page).
M9, E109

RS
BT
HA

EL






IDX

HEADLAMP — Daytime Light System —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03

Refer to EL-POWER.



Refer to last page (Foldout page).

M9, E109











M10, B1

HEADLAMP — Daytime Light System —

Trouble Diagnoses








DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	Start signal	 When turning ignition switch to "ST"	Battery voltage
		 When turning ignition switch to "ON" from "ST"	Less than 1V
		 When turning ignition switch to "OFF"	Less than 1V
2	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
3	Power source	 When turning ignition switch to "ON"	Battery voltage
		 When turning ignition switch to "OFF"	Battery voltage
4	Lighting switch (Lo beam)	When turning lighting switch to headlamp "ON" (2ND) position, "LOW BEAM"	Battery voltage
5	Lighting switch (Hi beam)	When turning lighting switch to "HIGH" ("A")	Battery voltage
		When turning lighting switch to "PASS" ("C")	Battery voltage
6	LH hi beam	When turning lighting switch to "HIGH" ("C")	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery voltage
7	LH headlamp control (ground)	When lighting switch is turned to headlamp "ON" (2ND) position, "LOW BEAM"	Less than 1V
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
8	RH hi beam	When turning lighting switch to "HIGH" ("A")	Battery voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

HEADLAMP — Daytime Light System — Trouble Diagnoses (Cont'd)

Ter- minal No.	Item		Condition	Judgement standard
9	Ground		—	—
10	Parking brake switch		When parking brake is released	Battery voltage
			When parking brake is set	1.5V or less
11	Alternator		When turning ignition switch to "ON"	Less than 1V
			When engine is running	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V
12	Power source		When turning ignition switch to "ON"	Battery voltage
			When turning ignition switch to "ST"	Battery voltage
			When turning ignition switch to "OFF"	Less than 1V

Bulb Replacement

Refer to "HEADLAMP" (EL-37).



Aiming Adjustment

Refer to "HEADLAMP" (EL-38).

PARKING, LICENSE, TAIL AND STOP LAMPS

Wiring Diagram — TAIL/L —

EL-TAIL/L-01








Refer to last page (Foldout page).
M9, E109

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

PARKING, LICENSE, TAIL AND STOP LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-02



Refer to last page (Foldout page).


(M9), (E109)

(M10), (B1)


BACK-UP LAMP

Wiring Diagram — BACK/L —

EL-BACK/L-01



CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Refer to last page (Foldout page).
M9 , E109

BACK-UP LAMP

Wiring Diagram — BACK/L — (Cont'd)

EL-BACK/L-02



: A/T models
 : M/T models



Refer to last page (Foldout page).

,

FRONT FOG LAMP

System Description

Power is supplied at all times

- to fog lamp relay terminal ③
- through 15A fuse (No. 46), located in the fusible link and fuse box
- to lighting switch terminal ⑤
- through 15A fuse (No. 40), located in the fuse and fusible link box).

With the lighting switch in the 2ND position and LOW ("B") position, power is supplied

- from terminal ⑦ of the lighting switch
- to fog lamp relay-2 terminal ④
- through fog lamp relay-2 terminal ③
- to fog lamp relay-1 terminal ① .

FOG LAMP OPERATION

Headlamp (Low beam) operation

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation.

With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay-1 terminal ②
- through the fog lamp switch and body grounds (E28) and (E42).

The fog lamp relay-1 is energized and power is supplied

- from fog lamp relay-1 terminal ⑤
- to terminal ① of each fog lamp.

Ground is supplied to terminal ② of each fog lamp through body grounds (E28) and (E42).

With power and ground supplied, the fog lamps illuminate.

Headlamp (High beam/flash-to-pass) operation

With the lighting switch in the 2ND position and HIGH ("A") position, power is supplied

- through terminal ⑥ of the lighting switch
- to fog lamp relay-2 terminal ②

The fog lamp relay-2 is energized and ground is supplied.

- through terminal ① of the fog lamp relay-2
- to body grounds (E28) and (E42).

Then, power supply to the fog lamp relay-1 is cut, turning fog lamps off.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

FRONT FOG LAMP

Wiring Diagram — F/FOG —

EL-F/FOG-01

Refer to EL-POWER.






FRONT FOG LAMP

Aiming Adjustment

- Before performing aiming adjustment, make sure of the following.
- Keep all tires inflated to correct pressure.
 - Place vehicle on level ground.
 - Check that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Loosen the front fog lamp bolts and adjust the vertical aiming by moving the front fog lamp assembly.



- Set the distance between the screen and the center of the fog lamp lens as shown at left.
- Turn front fog lamps ON.

- Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.
 - When performing adjustment, if necessary, cover the headlights and opposite fog lamp.
- Tighten the front fog lamp bolts.

Bulb specifications

Item	Wattage (W)
Front fog lamp	55 (H3)

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 10A fuse (No. [3], located in the fuse block)
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ②
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ① through body grounds (M5) and (M57).

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front turn signal lamp LH terminal ①
- rear combination lamp LH terminal ②
- combination meter terminal ⑳.

Ground is supplied to the front turn signal lamp LH terminal ② through body grounds (E28) and (E42).

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds (B4), (B13) and (T16).

Ground is supplied to combination meter terminal ⑳ through body grounds (M5) and (M57).

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front turn signal lamp RH terminal ①
- rear combination lamp RH terminal ②
- combination meter terminal ㉑.

Ground is supplied to the front turn signal lamp RH terminal ② through body grounds (E28) and (E42).

Ground is supplied to the rear combination lamp RH terminal ④ through body grounds (B4), (B13) and (T16).

Ground is supplied to combination meter terminal ㉑ through body grounds (M5) and (M57).

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse (No. [5], located in the fuse block).

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ②
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ① through body grounds (M5) and (M57).

Power is supplied through terminal ⑤ of the hazard switch to

- front turn signal lamp LH terminal ①
- rear combination lamp LH terminal ②
- combination meter terminal ㉒.

Power is supplied through terminal ⑥ of the hazard switch to

- front turn signal lamp RH terminal ①
- rear combination lamp RH terminal ②
- combination meter terminal ㉓.

Ground is supplied to terminal ② of each front turn signal lamp through body grounds (E28) and (E42).

Ground is supplied to terminal ④ of the rear combination lamps through body grounds (B4), (B13) and (T16).

Ground is supplied to combination meter terminal ㉒ through body grounds (M5) and (M57).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

- through 10A fuse (No. 5), located in the fuse block
- to multi-remote control relay-1 terminals 1, 6 and 3.

Ground is supplied to multi-remote control relay-1 terminal 2, when the multi-remote control system is triggered through the smart entrance control unit.

Refer to "MULTI-REMOTE CONTROL SYSTEM", EL-158.

The multi-remote control relay-1 is energized.

Power is supplied through terminal 7 of the multi-remote control relay-1

- to front turn signal lamp LH terminal 1
- to rear combination lamp LH terminal 2
- to combination meter terminal 21.

Power is supplied through terminal 5 of the multi-remote control relay-1

- to front turn signal lamp RH terminal 1
- to rear combination lamp RH terminal 2
- to combination meter terminal 23.

Ground is supplied to terminal 2 of each front turn signal lamp through body grounds E28 and E42.

Ground is supplied to terminal 4 of the rear combination lamps through body grounds B4, B13 and T16.

Ground is supplied to combination meter terminal 22 through body grounds M5 and M57.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

Schematic







(MR) : With multi-remote control unit

(WM) : Without multi-remote control unit

TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —

EL-TURN-01




Refer to last page (Foldout page).
(M9), (E109)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX





TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)


EL-TURN-02



MR : With multi-remote control system
OM : Without multi-remote control system





Refer to last page (Foldout page).



TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)

EL-TURN-03




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. (EL-60) 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 3), located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check Y wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 5), located in fuse block). Verify battery positive voltage is present at terminal ③ of hazard switch. 2. Check hazard switch. 3. Check Y wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E28) and (E42) 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E28) and (E42).
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (B4), (B13) and (T16) 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (B4), (B13) and (T16).
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Ground 	<ol style="list-style-type: none"> 1. Check grounds (M5) and (M57).
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.



Electrical Components Inspection

COMBINATION FLASHER UNIT CHECK

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

ILLUMINATION

System Description

Power is supplied at all times

- through 10A fuse (No. ④, located in the fuse block)
- to lighting switch terminal ⑩.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.


Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M16	①	③
Combination meter	M72	③	③
Clock	M70, M72	①	③
ASCD main switch	M17	⑤	⑥
Rear window defogger switch	M39	⑤	⑥
Push control unit	M77	⑬	⑬
Hazard switch	M38	⑦	⑧
Cigarette lighter	M78	③	④
Audio	M43	⑧	⑦
CD deck	M45, M46	③	⑤
Power window main switch	D8	⑩	⑨
A/T indicator	B7	④	③

The ground for all of the components are controlled through terminals ② and ③ of the illumination control switch and body grounds ⑤ and ⑤.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

ILLUMINATION


Schematic




ILLUMINATION

Wiring Diagram — ILL —

EL-ILL-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX









Refer to last page (Foldout page).
M9, E109

ILLUMINATION

Wiring Diagram — ILL — (Cont'd)






EL-ILL-02



ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



Refer to last page (Foldout page).

(M10), (B1)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

INTERIOR, SPOT AND TRUNK ROOM LAMPS

System Description

Power is supplied at all times

- through 10A fuse (No. 6), located in the fuse block)
- to interior lamp terminal ① ,
- to spot lamp terminal ① and
- to trunk room lamp terminal ① .
- through 25A fusible link (letter I), located in the fuse and fusible link box)
- to circuit breaker
- to smart entrance control unit terminal ① for multi-remote control system.

INTERIOR LAMP

Switch operation

With interior lamp switch ON, ground is supplied to turn interior lamp ON.

When a door switch is opened with interior lamp switch in DOOR, ground is supplied

- to interior lamp terminal ②
- through diode(s) (With theft warning system)
- through door switch RH terminal ① or
- through door switch LH terminal ② ,
- through body ground.

Interior lamp control by multi-remote control system

Smart entrance control unit receives a signal from multi-remote controller to turn interior lamp ON with interior lamp switch set to DOOR. Ground is then supplied

- to interior lamp terminal ②
- through smart entrance control unit terminal ⑨ ,
- through smart entrance control unit terminal ⑩ and
- through body grounds M5 and M57 .

With power and ground supplied, the interior lamp turns ON.

TRUNK ROOM LAMP

When the trunk room lamp switch is set to OPEN, ground is supplied

- to trunk room lamp terminal ②
- through trunk room switch terminal ① ,
- through trunk room lamp switch terminal ② and
- through body grounds B4, B13 and T16 .

With power and ground supplied, the trunk room lamp turns ON.

SPOT LAMP

With the spot lamp switch in the ON position, ground is supplied


- to spot lamp terminal ②
- through body grounds M5 and M57 .

With power and ground supplied, the spot lamp turns ON.

INTERIOR, SPOT AND TRUNK ROOM LAMPS


Wiring Diagram — INT/L —

EL-INT/L-01



CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS

Refer to last page (Foldout page).
(M10) (B1)





HA
EL
IDX

INTERIOR, SPOT AND TRUNK ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-02



Refer to last page (Foldout page).

METER AND GAUGES

System Description

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. 2), located in the fuse block)
- to combination meter terminal 14.

Ground is supplied

- to combination meter terminal 40
- through body grounds M5 and M57.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 24 for the fuel gauge
- from terminal 1 of the fuel tank gauge unit
- through terminal 4 of the fuel tank gauge unit and
- through body grounds B4, B13 and T16.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 6 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 3 of the ECM (ECCS control module)
- to combination meter terminal 17 for the tachometer.

SPEEDOMETER

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- to combination meter terminals 25 and 26 for the speedometer
- from terminals 1 and 2 of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL


IDX

METER AND GAUGES

Combination Meter





(WM) : Models with white combination meter
 (ST) : Models with standard combination meter



METER AND GAUGES

Wiring Diagram — METER —

EL-METER-01



Refer to last page (Foldout page).






- M9 . E109
- M10 . B1
- F3 . M63
- F1

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METER AND GAUGES




Trouble Diagnoses

INSPECTION/FUEL GAUGE AND/OR WATER TEMPERATURE GAUGE








METER AND GAUGES

Trouble Diagnoses (Cont'd)



INSPECTION/TACHOMETER











GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METER AND GAUGES

Trouble Diagnoses (Cont'd)


INSPECTION/SPEEDOMETER AND VEHICLE SPEED SENSOR



Electrical Components Inspection

FUEL TANK GAUGE UNIT CHECK

- For removal, refer to FE section.
- Check the resistance between terminals ① and ④.




Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm (in)		
①	④	*1	Full	356 (14.02)
		*2	1/2	245 (9.65)
		*3	Empty	50 (1.97)

*1 and *3: When float rod is in contact with stopper.

THERMAL TRANSMITTER CHECK


Check the resistance between the terminals of thermal transmitter and body ground.



Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90Ω
100°C (212°F)	Approx. 21 - 24Ω

VEHICLE SPEED SENSOR SIGNAL CHECK

- Remove vehicle speed sensor from transmission.
- Turn vehicle speed sensor pinion quickly and measure voltage across ① and ②.



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

WARNING LAMPS

Schematic


- (CN) : For Canada
- (MB) : M/T models for UAS with 4-speaker audio system
- (EB) : Except (MB)
- (TW) : With theft warning system
- (ET) : Without theft warning system



WARNING LAMPS

Wiring Diagram — WARN —


EL-WARN-01



- ⬡ MT : M/T models
- ⬡ AT : A/T models
- ⬡ WM : Models with white combination meter
- ⬡ ST : Models with standard combination meter

Refer to last page (Foldout page).

- ⬡ M9, E109
- ⬡ F3, M63
- ⬡ F1







GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



Refer to last page (Foldout page).




(M9) . (E109)

(M10) . (B1)




WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



Refer to last page (Foldout page).



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST


RS
BT
HA
EL
IDX

WARNING LAMPS

Electrical Components Inspection


FUEL WARNING LAMP SENSOR CHECK

- It will take a short time for the bulb to light.



MEL423F

OIL PRESSURE SWITCH CHECK



MEL425F


	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.


DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



SEL901F



MEL354G

- Diodes for warning lamps are built into the combination meter printed circuit.

WARNING BUZZER

System Description

MODELS WITH POWER DOOR LOCKS

The warning buzzer is controlled by the smart entrance control unit.

Power is supplied at all times

- through 10A fuse (No. [6], located in the fuse block)
- to warning buzzer terminal ③
- to key switch terminal ①.

Power is supplied at all times

- through 10A fuse (No. [4], located in the fuse block)
- to lighting switch terminal ⑩.

Power is supplied at all times

- through 25A fusible link (letter [i], located in the fuse and fusible link box).
- to smart entrance control unit terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. [1], located in the fuse block)
- to smart entrance control unit terminal ⑩.

Ground is supplied to smart entrance control unit terminal ⑩ through body grounds (M5) and (M57).

When a signal, or combination of signals, is received by the smart entrance control unit, ground is supplied

- through smart entrance control unit terminal ②③
- to warning buzzer terminal ①.

With power and ground supplied, the warning buzzer will sound.

Ignition key warning buzzer

With the key in the ignition switch in the OFF position, and the driver's door open, the warning buzzer will sound. A battery positive voltage is supplied

- from key switch terminal ②
- to smart entrance control unit terminal ②④.

Ground is supplied

- from door switch LH terminal ①
- to smart entrance control unit terminal ①⑤.

Door switch LH terminal ③ is grounded through body grounds (B4), (B13) and (T16).

Light warning buzzer

With ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning buzzer will sound. A battery positive voltage is supplied.

- from lighting switch terminal ⑫
- to smart entrance control unit terminal ②⑤.

Ground is supplied

- from door switch LH terminal ①
- to smart entrance control unit terminal ①⑤.

Door switch LH terminal ③ is grounded through body grounds (B4), (B13) and (T16).

Seat belt warning buzzer

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning buzzer will sound for approximately 6 seconds.

Ground is supplied

- from seat belt switch terminal ①
- to smart entrance control unit terminal ②④.

Seat belt switch terminal ② is grounded through body grounds (B4), (B13) and (T16).

MODELS WITHOUT POWER DOOR LOCKS

The warning buzzer is controlled by the warning buzzer unit.

Power is supplied at all times

- through 10A fuse (No. [6], located in the fuse block)
- to key switch terminal ①.

Power is supplied at all times

- through 10A fuse (No. [4], located in the fuse block)
- to lighting switch terminal ⑩.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. [2], located in the fuse block)
- to warning buzzer unit terminal ①.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WARNING BUZZER

System Description (Cont'd)

Ground is supplied to warning buzzer unit terminal ⑧ through body grounds (M5) and (M57).

When a signal, or combination of signals, is received by the warning buzzer unit.

With power and ground supplied, the warning buzzer will sound.

Ignition key warning buzzer

With the key in the ignition switch in the OFF position, and the driver's door open, the warning buzzer will sound. A battery positive voltage is supplied

- from key switch terminal ②
- to warning buzzer unit terminal ⑤.

Ground is supplied

- from door switch LH terminal ①
- to warning buzzer unit terminal ⑦.

Door switch LH terminal ③ is grounded through body grounds (B4), (B13) and (T16).

Light warning buzzer

With ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning buzzer will sound. A battery positive voltage is supplied

- from lighting switch terminal ⑫
- to warning buzzer unit terminal ④.

Ground is supplied

- from door switch LH terminal ①
- to warning buzzer unit terminal ⑦.

Door switch LH terminal ③ is grounded through body grounds (B4), (B13) and (T16).

Seat belt warning buzzer

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning buzzer will sound for approximately 6 seconds.

Ground is supplied


- from seat belt switch terminal ①
- to warning buzzer unit terminal ②.

Seat belt switch terminal ② is grounded through body grounds (B4), (B13) and (T16).

WARNING BUZZER





Wiring Diagram — BUZZER —/Models With Power Door Locks

EL-BUZZER-01



Refer to EL-POWER.

SMART ENTRANCE CONTROL UNIT (M20)



Refer to last page (Foldout page).
 M9, E109
 M10, B1
 M20

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA







EL

IDX



WARNING BUZZER

Wiring Diagram — BUZZER —/Models Without Power Door Locks

EL-BUZZER-02



Refer to last page (Foldout page).





WARNING BUZZER

Trouble Diagnoses

SYMPTOM CHART

REFERENCE PAGE	EL-85	EL-86	EL-87	EL-87	EL-88
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 4
Light warning buzzer does not activate.	X	X			X
Ignition key warning buzzer does not activate.	X		X		X
Seat belt warning buzzer does not activate.	X			X	X
All warning buzzers do not activate.	X				X



POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check (Models with power door locks)

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
②	Ground	0V	0V	Battery voltage


Power supply circuit check (Models without power door locks)

Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	0V	0V	Battery voltage


WARNING BUZZER

Trouble Diagnoses (Cont'd)

Ground circuit check (Models with power door locks)




Terminals	Continuity
⑩ - Ground	Yes



Ground circuit check (Models without power door locks)

Terminals	Continuity
⑧ - Ground	Yes



DIAGNOSTIC PROCEDURE 1

(Lighting switch input signal check)

A B

CHECK LIGHTING SWITCH INPUT SIGNAL.

A (Models with power door locks)
Check voltage between control unit terminal ⑫ and ground.

B (Models without power door locks)
Check voltage between buzzer unit terminal ④ and ground.


Condition of lighting switch	Voltage [V]
1ST or 2ND	Approx. 12
OFF	0

NG → Check the following.

- 10A fuse (No. ④, located in the fuse block)
- Harness for open or short between control/buzzer unit and lighting switch

OK ↓

Go to Procedure 4.





WARNING BUZZER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

(Key switch input signal check)



A B

CHECK KEY SWITCH INPUT SIGNAL.

- A** (Models with power door locks)
Check voltage between control unit terminal ④ and ground.
- B** (Models without power door locks)
Check voltage between buzzer unit terminal ⑤ and ground.

Condition of key switch	Voltage [V]
Key is inserted	Approx. 12
Key is withdrawn	0

NG → Check the following.



- Key switch
Refer to "Electrical Components Inspection" (EL-89).
- 10A fuse [No. ⑥], located in fuse block
- Harness for open or short between key switch and fuse
- Harness for open or short between control/buzzer unit and key switch

OK ↓

Go to Procedure 4.

DIAGNOSTIC PROCEDURE 3

(Seat belt buckle switch input signal check)



A B

CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL.

- A** (Models with power door locks)
1. Turn ignition switch "ON".
 2. Check voltage between control unit terminal ②① and ground.
- B** (Models without power door locks)
1. Turn ignition switch "ON".
 2. Check voltage between buzzer unit terminal ② and ground.

Condition of seat belt buckle switch	Voltage [V]
Fastened	Approx. 12
Unfastened	0

NG →

Check the following.

- Seat belt buckle switch
Refer to "Electrical Components Inspection" (EL-89).
- Seat belt buckle switch ground circuit
- Harness for open or short between control/buzzer unit and seat belt buckle switch

OK ↓

Go to Procedure 4.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

WARNING BUZZER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-1

(For models with power door locks)



A


CHECK DOOR SWITCH INPUT SIGNAL.
Check voltage between control unit terminal ⑮ and ground.

Condition of driver's door	Voltage [V]
Driver side door is closed.	Approx. 12
Driver side door is open.	0

NG

Check the following.

- Driver side door switch
Refer to "Electrical Components Inspection" (EL-89).
- Door switch ground circuit
- Harness for open or short between control unit and door switch




B

CHECK BUZZER POWER SUPPLY.
Measure voltage between warning buzzer terminal ③ and ground.
Battery voltage should exist.

NG

Check the following.

- 10A fuse (No. ⑥, located in fuse block)
- Harness for open or short between buzzer and fuse



C

CHECK WARNING BUZZER.
1. Disconnect warning buzzer connector.
2. Apply 12V direct current to warning buzzer and check operation.

NG


Replace warning buzzer.

OK

Check harness for open or short between control unit and warning buzzer.

DIAGNOSTIC PROCEDURE 4-2

(For models without power door locks)



A

CHECK DOOR SWITCH INPUT SIGNAL.
Check voltage between buzzer unit terminals ⑦ and ground.

Condition of driver's door	Voltage [V]
Driver side door is closed.	Approx. 12
Driver side door is open.	0

NG


Check the following.

- Driver side door switch
Refer to "Electrical Components Inspection" (EL-89).
- Door switch ground circuit
- Harness for open or short between buzzer unit and door switch

OK

Replace warning buzzer unit.

WARNING BUZZER



Electrical Components Inspection

KEY SWITCH (Insert)


Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Terminal No.	Condition	Continuity
① - ②	Key is inserted	Yes
	Key is removed	No

GI

MA

EM



DRIVER SIDE DOOR SWITCH

Check continuity between terminals when door switch is pushed and released.


Terminal No.	Condition	Continuity
① - ③, ② - Ground	Door switch is pushed.	No
	Door switch is released.	Yes

LC

EC

FE

CL



SEAT BELT BUCKLE SWITCH

Check continuity between terminals when seat belt is fastened and unfastened.

Terminal No.	Condition	Continuity
① - ②	Seat belt is fastened.	No
	Seat belt is unfastened.	Yes

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WIPER AND WASHER

System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch.

There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent — with intermittent wiper)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 16, located in the fuse block)
- to wiper motor terminal 2.

Low and high speed wiper operation

Ground is supplied to wiper switch terminal 17 through body grounds E28 and E42.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the wiper switch
- to wiper motor terminal 4.

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the wiper switch
- to wiper motor terminal 5.

With power and ground supplied, the wiper motor operates at high speed.

Auto stop operation

With wiper switch turned OFF, wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with wiper switch OFF, ground is provided

- from terminal 14 of the wiper switch
- to wiper motor terminal 4, in order to continue wiper motor operation at low speed.

Ground is also supplied

- through terminal 13 of the wiper switch
- to wiper amplifier terminal 4
- through terminal 8 of the wiper amplifier } (With intermittent wiper)
- to wiper motor terminal 1
- through terminal 6 of the wiper motor, and
- through body grounds F15 and F57.

When wiper arms reach base of windshield, wiper motor terminals 1 and 2 are connected instead of terminals 1 and 6. Wiper motor will then stop wiper arms at the PARK position.

Intermittent operation

The wiper motor operates the wiper arms one time at low speed at an interval as follows. This feature is controlled by the wiper amplifier.

- Once in approximately 7 seconds (Without variable intermittent volume)
- Once in approximately 3 to 13 seconds (With variable intermittent volume)

When the wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier terminal 1
- from wiper switch terminal 15
- through body grounds E28 and E42.
- to wiper motor terminal 4
- through the wiper switch terminal 14
- to wiper switch terminal 13
- through wiper amplifier terminal 4
- to wiper amplifier terminal 7
- through body grounds F15 and F57.

For models with variable intermittent volume, the desired interval time is input

- to wiper amplifier terminal 2
- from wiper switch terminal 19.

The wiper motor operates at low speed at the desired time interval.

WIPER AND WASHER

System Description (Cont'd)

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse (No. 16), located in the fuse block)
- to washer motor terminal ①.

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ②, and
- to wiper amplifier terminal ⑤ (With intermittent wiper)
- from terminal ⑬ of the wiper switch
- through terminal ⑰ of the wiper switch, and
- through body grounds (E28) and (E42).

With power and ground supplied, the washer motor operates.

With intermittent wiper

When the lever is pulled to the WASH position for one second or more, the wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA





EL

IDX

WIPER AND WASHER

Wiring Diagram — WIPER —/Without Intermittent Wiper

EL-WIPER-01





Refer to last page (Foldout page).

M9, E109
F3, M63

WIPER AND WASHER

Wiring Diagram — WIPER —/With Intermittent Wiper

EL-WIPER-02



Refer to last page (Foldout page).

M9, E109
F3, M63

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

WIPER AND WASHER

Wiring Diagram — WIPER —/With Intermittent Wiper (Cont'd)

EL-WIPER-03



Refer to last page (Foldout page).


- (M9) (E109)
- (F3) (M63)

WIPER AND WASHER

Trouble Diagnoses/With Intermittent Wiper

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.




Check whether wiper operates with the wiper switch at Lo position.

NG → Check the following.

- 20A fuse (No. 16, located in fuse block)
- Wiper motor
- Wiper switch
- Harness for open or short.

OK →




A

1. Turn front wiper switch to OFF.
2. Disconnect wiper amp. connector.
3. Measure voltage between wiper amp. harness terminal ④ and body ground. **Battery voltage should exist.**

NG → Check the following.

- Wiper switch
- Wiper motor
- Harness for open or short between wiper amp. terminal ④ and wiper switch harness terminal ⑬

OK →



B

CHECK INTERMITTENT SWITCH INPUT SIGNAL.


Check harness continuity between wiper amp. harness terminal ① and body ground.

Condition of wiper switch	Continuity
OFF	No
INT	Yes

NG → Check the following.

- Wiper switch
- Harness for open or short between wiper amp. terminal ① and wiper switch harness terminal ⑭
- Ground circuit for front wiper switch terminal ⑰

OK →



C

CHECK WIPER AMP. POWER SUPPLY CIRCUIT.

Check voltage between wiper amp. terminal ⑥ and ground while ignition switch is "ACC". **Battery voltage should exist.**

NG → Check the following.

- 20A fuse (No. 16, located in fuse block)
- Harness for open or short between wiper amp. and fuse

OK →

D

CHECK WIPER AMP. GROUND CIRCUIT.

Check harness continuity between wiper amp. harness terminal ⑦ and body ground. **Continuity should exist.**

NG → Repair harness or connector.

OK →

Replace wiper amp.



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

WIPER AND WASHER

Trouble Diagnoses/With Intermittent Wiper (Cont'd)



DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.




OK → Replace wiper amp.

NG



DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.




NG → Check harness for open or short between wiper amp. harness terminal ⑤ and wiper switch harness terminal ⑱.

OK

Go to DIAGNOSTIC PROCEDURE 1. NG → Replace wiper amp.


WIPER AND WASHER



Removal and Installation

WIPER ARMS

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
Clearance "L₁": 18 - 33 mm (0.71 - 1.30 in)
Clearance "L₂": 17 - 32 mm (0.67 - 1.26 in)
- Tighten wiper arm nuts to specified torque.
Front wiper: 17 - 23 N·m (1.7 - 2.3 kg·m, 12 - 17 ft·lb)



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

GI

VA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

WIPER AND WASHER

Removal and Installation (Cont'd)

WIPER LINKAGE



Removal

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.

Installation



- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

Washer Nozzle Adjustment

- Using a suitable tool, adjust windshield washer nozzle to correct its spray pattern.

Before attempting to turn the nozzle, gently tap the end of the tool to free the nozzle.

This will prevent "rounding out" the small female square in the center of the nozzle.




Unit: mm (in)

*1	358 (14.09)	*5	70 (2.76)
*2	245 (9.65)	*6	245 (9.65)
*3	300 (11.81)	*7	378 (14.88)
*4	203 (7.99)	*8	503 (19.80)

*: The diameters of these circles are less than 80 mm (3.15 in).

WIPER AND WASHER



Washer Tube Layout

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

HORN

Wiring Diagram — HORN —

EL-HORN-01



* : This connector is not shown in "HARNES LAYOUT". Refer to "COMBINATION SWITCH".



Refer to last page (Foldout page).

M9 , E109

CIGARETTE LIGHTER

Wiring Diagram — CIGAR —

EL-CIGAR-01



GI

MA

EM

LC

EC

FE

CL

MIT

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

CLOCK

Wiring Diagram — CLOCK —

EL-CLOCK-01



REAR WINDOW DEFOGGER

System Description

The rear window defogger system is controlled by the smart entrance control unit (Models with power door lock) or rear window defogger timer (Models without power door lock). The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal ③
- through 15A fuse (No. ⑨, located in the fuse block) and
- to rear window defogger relay terminal ⑥
- through 15A fuse (No. ⑩, located in the fuse block).

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① and
- to smart entrance control unit terminal ⑪ (Models with power door lock), or
- to the rear window defogger timer terminal ① (Models without power door lock).
- through 7.5A fuse (No. ①, located in the fuse block).

Ground is supplied to terminal ② of the rear window defogger switch through body grounds (M5) and (M57).

When the rear window defogger switch is turned ON, ground is supplied

- through terminal ① of the rear window defogger switch
- to smart entrance control unit terminal ⑫ (Models with power door lock) or
- to rear window defogger timer terminal ③ (Models without power door lock).

Terminal ⑬ of the smart entrance control unit (Models with power door lock) or terminal ② of the rear window defogger timer (Models without power door lock) then supplies ground to the rear window defogger relay terminal ②.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to condenser terminal ①
- through terminal ② of the condenser
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal ③ of the rear window defogger switch
- from terminal ⑤ of the rear window defogger relay.

Terminal ④ of the rear window defogger switch is grounded through body grounds (M5) and (M57).

CI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

IA





EL

IDX

REAR WINDOW DEFOGGER

Wiring Diagram — DEF —



EL-DEF-01



REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02



Refer to last page (Foldout page).

M20

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX






REAR WINDOW DEFOGGER

Trouble Diagnoses

DIAGNOSTIC PROCEDURE

SYMPTOM: Rear window defogger does not activate, or does not go off after activating.

Models with power door lock



A

REAR WINDOW DEFOGGER OUTPUT SIGNAL CHECK

1. Turn ignition switch to ON position.
2. Check voltage between control unit harness terminal ③ and ground.

Condition	Voltage [V]
Rear window defogger switch is "OFF".	Approx. 12
Rear window defogger switch is "ON".	0

OK → Check the following.

- Rear window defogger relay (Refer to EL-108.)
- Rear window defogger circuit
- Rear window defogger filament (Refer to EL-108.)

B

1. Disconnect control unit connector.
2. Turn ignition switch to ON position.
3. Check voltage between control unit harness terminal ③ and ground. **Battery voltage should exist.**

NG → Check the following.

- 7.5A fuse (No. 1, located in the fuse block)
- Rear window defogger relay
- Harness for open or short between control unit and fuse

C

REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL CHECK

Check continuity between control unit harness terminal ② and ground.

Condition of defogger switch	Continuity
Rear window defogger switch is pushed.	Yes
Rear window defogger switch is released.	No

NG → Check the following.

- Rear window defogger switch (Refer to EL-108.)
- Harness for open or short between control unit and rear window defogger switch
- Rear window defogger switch harness ground circuit

D

IGNITION INPUT SIGNAL CHECK

Check voltage between control unit harness terminal ① and ground.

Condition	Voltage [V]
Ignition switch is "ON".	Approx. 12
Ignition switch is "OFF".	0

NG → Check the following.

- 7.5A fuse (No. 1 located in the fuse block)
- Harness for open or short between control unit and fuse

E

CONTROL UNIT GROUND CIRCUIT CHECK

Check continuity between control unit harness terminal ⑩ and ground. **Continuity should exist.**






NG → Repair harness or connectors.

OK → Replace control unit.

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

Models without power door lock



A

CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL.

1. Turn ignition switch to ON position.
2. Check voltage between defogger timer harness terminal ② and ground.

Condition	Voltage [V]
Rear window defogger switch is "OFF".	Approx. 12
Rear window defogger switch is "ON".	0

- OK
- Check the following.
- Rear window defogger relay (Refer to EL-108.)
 - Rear window defogger circuit
 - Rear window defogger filament (Refer to EL-108.)

B

1. Disconnect defogger timer connector.
2. Turn ignition switch to ON position.
3. Check voltage between defogger timer terminal ② and ground. **Battery voltage should exist.**

- NG
- Check the following.
- 7.5A fuse (No. ①, located in the fuse block)
 - Rear window defogger relay
 - Harness for open or short between defogger timer and fuse

C

CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL.

Check continuity between defogger timer terminal ③ and ground.

Condition of defogger switch	Continuity
Rear window defogger switch is pushed.	Yes
Rear window defogger switch is released.	No

- NG
- Check the following.
- Rear window defogger switch (Refer to EL-108.)
 - Harness for open or short between defogger timer and rear window defogger switch
 - Rear window defogger switch ground circuit

D

CHECK IGNITION INPUT SIGNAL.

Check voltage between defogger timer terminal ① and ground.

Condition	Voltage [V]
Ignition switch is "ON".	Approx. 12
Ignition switch is "OFF".	0

- NG
- Check the following.
- 7.5A fuse (No. ①, located in the fuse block)
 - Harness for open or short between defogger timer and fuse

E

CHECK DEFOGGER TIMER GROUND CIRCUIT.

Check continuity between defogger timer terminal ④ and ground. **Continuity should exist.**

NG


Repair harness or connectors.

OK

Replace defogger timer.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

REAR WINDOW DEFOGGER




Electrical Components Inspection

REAR WINDOW DEFOGGER RELAY

Check continuity between terminals ③ and ⑤, ⑥ and ⑦.


Condition	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No



REAR WINDOW DEFOGGER SWITCH


Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
① - ②	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No



Filament Check



1. Attach probe circuit tester (in volt range) to middle portion of each filament.



- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

REAR WINDOW DEFOGGER

Filament Check (Cont'd)



2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.

Filament Repair

REPAIR EQUIPMENT


1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


REAR WINDOW DEFOGGER

Filament Repair (Cont'd)



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

AUDIO

System Description

Refer to Owner's Manual for audio system operating instructions.

4-SPEAKER MODELS

Power is supplied at all times

- through 10A fuse (No. 50, located in the fuse block)
- to radio terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 18, located in the fuse block)
- to radio terminal 10.

Ground is supplied through the case of the radio.

When the radio power knob is pushed to the ON position, audio signals are supplied

- through radio terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

6-SPEAKER MODELS

Power is supplied at all times

- through 10A fuse (No. 50, located in the fuse block)
- to radio terminal 6.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. 18, located in the fuse block)
- to radio terminal 10.

Ground is supplied through the case of the radio.

When the radio power knob is pushed to the ON position, audio signals are supplied through radio terminals

- 1, 2, 3, 4, 13, 14, 15 and 16.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

AUDIO

Wiring Diagram — AUDIO —/4-speaker

EL-AUDIO-01



Refer to last page (Foldout page).


(M10), (B1)

(M9), (E109)






AUDIO

Wiring Diagram — AUDIO —/6-speaker

EL-AUDIO-02



Refer to last page (Foldout page).






GT
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUDIO

Wiring Diagram — AUDIO —/6-speaker (Cont'd)

EL-AUDIO-03



Refer to last page (Foldout page).
(M10) . (B1)

AUDIO

Trouble Diagnoses

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 1. 10A fuse 2. Poor radio case ground 3. Radio 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 18, located in fuse block). Turn ignition switch ON and verify that battery positive voltage is present at terminal ⑩ of radio. 2. Check radio case ground. 3. Remove radio for repair.
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Radio 	<ol style="list-style-type: none"> 1. Check 10A fuse (No. 50, located in fuse block) and verify that battery positive voltage is present at terminal ⑥ of radio. 2. Remove radio for repair.
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> 1. Speaker 2. Radio output 3. Speaker circuit 4. Radio 	<ol style="list-style-type: none"> 1. Check speaker. 2. Check radio output voltage. 3. Check wires for open or short between radio and speaker. 4. Remove radio for repair.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> 1. Antenna 2. Poor radio ground 3. Radio 	<ol style="list-style-type: none"> 1. Check antenna. 2. Check radio ground. 3. Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> 1. Window antenna 2. Radio 	<ol style="list-style-type: none"> 1. Check window antenna. 2. Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> 1. Poor radio ground 2. Loose or missing ground bonding straps 3. Ignition condenser or rear window defogger noise suppressor condenser 4. Alternator 5. Ignition coil or secondary wiring 6. Radio 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check ground bonding straps. 3. Replace ignition condenser or rear window defogger noise suppressor condenser. 4. Check alternator. 5. Check ignition coil and secondary wiring. 6. Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> 1. Poor radio ground 2. Antenna 3. Accessory ground 4. Faulty accessory 	<ol style="list-style-type: none"> 1. Check radio ground. 2. Check antenna. 3. Check accessory ground. 4. Replace accessory.

SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ② .
 - The resistance should be 2 - 4 Ω.
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ② .
 - A momentary hum or pop should be heard.

ANTENNA INSPECTION

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
 - If reception improves, check antenna ground (at body surface).
 - If reception does not improve, check main feeder cable for short circuit or open circuit.

RADIO INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio connected (If radio is removed for inspection, supply a ground to the case using a jumper wire.)

GI

MA

EM

LC

EC

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUDIO ANTENNA

System Description

Power is supplied at all times

- through 7.5A fuse (No. ⑧), located in the fuse block)
- to power antenna terminal ③ .

Ground is supplied to the power antenna terminal ⑥ through body grounds ④B4, ④B13 and ④T16 .

When the radio is turned to the ON position, battery positive voltage is supplied

- through radio terminal ⑤
- to power antenna terminal ④ .

The antenna raises and is held in the extended position.

When the radio is turned to the OFF position, battery positive voltage is interrupted






- from radio terminal ⑤
- to power antenna terminal ④ .

The antenna retracts.

AUDIO ANTENNA

Wiring Diagram — P/ANT —

EL-P/ANT-01



Refer to last page (Foldout page).
M10, B1



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUDIO ANTENNA

Trouble Diagnoses

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none">7.5A fuseRadio signalGrounds (B4), (B13) and (T16)	<ol style="list-style-type: none">Check 7.5A fuse (No. 8), located in fuse block). Verify that battery positive voltage is present at terminal ③ of power antenna.Turn ignition switch and radio ON. Verify that battery positive voltage is present at terminal ④ of power antenna.Check grounds (B4), (B13) and (T16).


Location of Antenna



Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.




2. Withdraw antenna rod while raising it by operating antenna motor.

AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)

INSTALLATION


1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.




Window Antenna Repair

ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.




2. If an element is broken, no continuity will exist.



CI
MA
EM
LC
EC
FE
CL
WT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUDIO ANTENNA

Window Antenna Repair (Cont'd)




3. To locate broken point, move probe to left and right along element. Tester needle will swing abruptly when probe passes the point.
- Refer to REAR WINDOW DEFOGGER "Filament Repair" for Element Repair.

POWER SUNROOF

Wiring Diagram — SROOF —





EL-SROOF-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS

Refer to last page (Foldout page).

(M9), (E109)




BT
HA
EL
IDX

POWER DOOR MIRROR



Wiring Diagram — MIRROR —

EL-MIRROR-01



Refer to last page (Foldout page).

(M10) (B1)






Next page

POWER DOOR MIRROR

Wiring Diagram — MIRROR — (Cont'd)

EL-MIRROR-02









Refer to last page (Foldout page).

(M10), (B1)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description

Refer to Owner's Manual for ASCD operating instructions.

POWER SUPPLY AND GROUND

When ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse (No. 11, located in the fuse block)
- to ASCD hold relay terminal 5 and
- to ASCD main switch terminal 1.

When ASCD main switch is in ON position, power is supplied

- from ASCD main switch terminal 3
- to ASCD hold relay terminal 1.

Ground is supplied

- to ASCD hold relay terminal 2
- through body grounds (M5) and (M57).

With power and ground is supplied, ASCD hold relay is energized. And then power is supplied

- from ASCD hold relay terminal 3
- to ASCD control unit terminal 4 and
- to ASCD main switch terminal 2.

After the ASCD main switch is released, power remains supplied

- to the coil circuit of ASCD hold relay
- through ASCD main switch terminals 2 and 3.

This power supply is kept until one of following conditions exists.

- Ignition switch is returned to the ACC or OFF position.
- ASCD main switch is turned to OFF position.

During ASCD hold relay is energized power is also supplied to ASCD control unit terminal 5

- through ASCD clutch switch and ASCD brake switch (M/T models) or
- through ASCD brake switch, ASCD hold relay and park/neutral position relay (A/T models).

Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- park/neutral position relay (A/T models)
- ASCD clutch switch (M/T models)
- ASCD brake switch.

A vehicle speed input is supplied

- to ASCD control unit terminal 7
- from terminal 19 of the combination meter.

Power is supplied at all times

- to stop lamp switch terminal 1
- through 10A fuse (No. 7, located in the fuse block).

When the brake pedal is depressed, power is supplied

- from terminal 2 of the stop lamp switch
- to ASCD control unit terminal 11.

Power is supplied at all times

- through 10A fuse (No. 38, located in the fuse and fusible link box)
- to horn relay terminal 2
- through terminal 1 of the horn relay
- to ASCD steering switch terminal 21.

When the SET/COAST switch is depressed, power is supplied

- from terminal 22 of the ASCD steering switch
- to ASCD control unit terminal 2.

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal 23 of the ASCD steering switch
- to ASCD control unit terminal 1.

When the CANCEL switch is depressed, power is supplied to ASCD control unit terminals 1 and 2.

When the system is activated, power is supplied to ASCD control unit terminal 5.

Power is interrupted when

- the shift lever is placed in P or N (A/T models)
- the clutch pedal is depressed (M/T models) or
- the brake pedal is depressed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

Outputs

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal ⑧ of the ASCD control unit
- to ASCD pump terminal ① .

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control unit
- to ASCD pump terminal ④ .

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control unit
- to ASCD pump terminal ② .

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control unit
- to ASCD pump terminal ③ .

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ⑪ and
- to TCM (transmission control module) terminal ⑳ (A/T models).

Ground is supplied

- to combination meter terminal ⑫
- through body grounds M5 and M57 .

With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed on A/T models, a signal is sent


- from terminal ⑬ of the ASCD control unit
- to TCM (transmission control module) terminal ⑳ .

When this occurs, the TCM (transmission control module) cancels overdrive.

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic








GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —



EL-ASCD-01



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-02



Refer to last page (Foldout page).






(M9) (E109)

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03







*: This connector is not shown in "HARNESS LAYOUT". Refer to "COMBINATION SWITCH".

Refer to last page (Foldout page).
 (M9) (E109)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04






Refer to last page (Foldout page).
 (F3), (M63)

CI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)


EL-ASCD-05




Refer to last page (Foldout page).

(M9), (E109)

(M21)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)




CONSULT


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT.




3. Turn on ignition switch.
4. Turn on ASCD main switch.
5. Touch START (on CONSULT display).
6. Touch ASCD.
7. Touch SELF-DIAG RESULTS.



- Self-diagnostic results are shown on display. Refer to table on the next page.



8. Touch DATA MONITOR.



- Touch START.
- Data monitor results are shown on display. Refer to table on the next page.

For further information, read the **CONSULT Operation Manual**.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

CONSULT (Cont'd)


SELF-DIAGNOSTIC RESULTS

Diagnostic item	Description	Repair/Check order
* NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED.**	<ul style="list-style-type: none"> • Even if no self diagnostic failure is indicated, further testing may be required as far as the customer complains. 	—
POWER SUPPLY-VALVE	<ul style="list-style-type: none"> • The power supply circuit for the pump is open. (An abnormally high voltage is entered.) 	Diagnostic procedure 7 (EL-143)
VACUUM PUMP	<ul style="list-style-type: none"> • The vacuum pump circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-143)
AIR VALVE	<ul style="list-style-type: none"> • The air valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-143)
RELEASE VALVE	<ul style="list-style-type: none"> • The release valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-143)
VHCL SP-S/FAILSAFE	<ul style="list-style-type: none"> • The vehicle speed sensor or the fail-safe circuit is malfunctioning. 	Diagnostic procedure 6 (EL-142)
CONTROL UNIT	<ul style="list-style-type: none"> • The ASCD control unit is malfunctioning. 	Replace ASCD control unit.
BRAKE SW/STOP/L SW	<ul style="list-style-type: none"> • The brake switch or stop lamp switch is malfunctioning. 	Diagnostic procedure 4 (EL-140)

DATA MONITOR

Monitored item	Description
BRAKE SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the brake switch circuit.
STOP LAMP SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the stop lamp switch circuit.
SET SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the set switch circuit.
RESUME/ACC SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the resume/accelerate switch circuit.
CANCEL SW	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the cancel circuit.
VHCL SPEED SE	<ul style="list-style-type: none"> • The present vehicle speed computed from the vehicle speed sensor signal is displayed.
SET VHCL SPD	<ul style="list-style-type: none"> • The preset vehicle speed is displayed.
VACUUM PUMP	<ul style="list-style-type: none"> • The operation time of the vacuum pump is displayed.
AIR VALVE	<ul style="list-style-type: none"> • The operation time of the air valve is displayed.
PW SUP-VALVE	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the circuit for the air valve and the release valve.
CRUISE LAMP	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the cruise lamp circuit.
A/T-OD CANCEL	<ul style="list-style-type: none"> • Indicates [ON/OFF] condition of the OD cancel circuit.
FAIL SAFE-LOW	<ul style="list-style-type: none"> • The fail-safe (LOW) circuit function is displayed.
FAIL SAFE-SPD	<ul style="list-style-type: none"> • The fail-safe (SPEED) circuit function is displayed.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Fail-safe System Description

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

MALFUNCTION DETECTION CONDITIONS

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> • ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. • Vacuum motor ground circuit or power circuit is open or shorted. • Air valve ground circuit or power circuit is open or shorted. • Release valve ground circuit or power circuit is open or shorted. • Vehicle speed sensor is faulty. • ASCD control unit internal circuit is malfunctioning. 	<ul style="list-style-type: none"> • ASCD is deactivated. • Vehicle speed memory is canceled.
<ul style="list-style-type: none"> • ASCD brake switch or stop lamp switch is faulty. 	<ul style="list-style-type: none"> • ASCD is deactivated. • Vehicle speed memory is not canceled.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS




BT

HA

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Fail-safe System Check

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the "CRUISE indicator" blinks.

If the indicator lamp blinks, check the following.

- ASCD steering switch. Refer to "DIAGNOSTIC PROCEDURE 5" (EL-141).

3. Drive the vehicle at more than 48 km/h (30 MPH) and push SET/COAST switch.

If the indicator lamp blinks, check the following.

- Vehicle speed sensor. Refer to "DIAGNOSTIC PROCEDURE 6" (EL-142).
- ASCD pump circuit. Refer to "DIAGNOSTIC PROCEDURE 7" (EL-143).
- Replace control unit.

4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

If the indicator lamp blinks, check the following.

- ASCD brake/stop lamp switch. Refer to "DIAGNOSTIC PROCEDURE 4" (EL-140).

5. END. (System is OK.)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

SYMPTOM CHART

PROCEDURE	—		Diagnostic procedure								
REFERENCE PAGE	EL-134	EL-136	EL-138	EL-138	EL-139	EL-140	EL-141	EL-142	EL-143	EL-144	
SYMPTOM	Self-diagnosis in CONSULT	Fail-safe system check	DIAGNOSTIC PROCEDURE 1 (POWER SUPPLY AND GROUND CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)	DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 4 (ASCD BRAKE/STOP LAMP SWITCH CHECK)	DIAGNOSTIC PROCEDURE 5 (ASCD STEERING SWITCH CHECK)	DIAGNOSTIC PROCEDURE 6 (VEHICLE SPEED SENSOR CHECK)	DIAGNOSTIC PROCEDURE 7 (ASCD PUMP CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 8 (ASCD ACTUATOR/PUMP CHECK)	
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)	X		X	X	X		X	X			GI
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X	X				X	X	X	X		MA
Vehicle speed does not decrease after SET/COAST switch has been pressed.	X						X			X	EM
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2	X						X			X	LC
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.	X						X			X	EC
System is not released after CANCEL switch (steering) has been pressed.	X						X			X	FE
Large difference between set speed and actual vehicle speed.	X									X	CL
Deceleration is greatest immediately after ASCD has been set.	X									X	MT

★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "Fail-safe System Check" (EL-136) to verify repairs.

★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(POWER SUPPLY AND GROUND CIRCUIT CHECK)



DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)




AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(ASCD HOLD RELAY CIRCUIT CHECK)



A CHECK POWER SUPPLY CIRCUIT FOR ASCD HOLD RELAY.


1. Disconnect ASCD hold relay.
2. Do approx. 12 volts exist between ASCD hold relay harness terminal ⑤ and body ground?

Refer to wiring diagram in EL-128.

No

Check the following.

- 7.5A fuse (No. ①, located in the fuse block)
- Harness for open or short between fuse and ASCD hold relay




B CHECK GROUND CIRCUIT FOR ASCD HOLD RELAY.

Does continuity exist between ASCD hold relay harness terminal ② and body ground?

No

Repair harness.



C CHECK ASCD HOLD RELAY CIRCUIT.

Does continuity exist between ASCD hold relay harness terminals ③ and ①?

Yes

Check ASCD hold relay.

NG

CHECK ASCD MAIN SWITCH. Refer to "Electrical Components Inspection" (EL-145).

Replace ASCD main switch.

OK

ASCSD hold relay circuit is OK.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

(ASCD BRAKE/STOP LAMP SWITCH CHECK)


A

☆ MONITOR ☆ NO FAIL

BRAKE SW OFF

RECORD

SEL948P




B

☆ MONITOR ☆ NO FAIL

STOP LAMP SW ON

RECORD

SEL965P



A

CHECK BRAKE SWITCH CIRCUIT.



See "BRAKE SW" in "Data monitor" mode.
When brake pedal or clutch pedal (M/T) is depressed or A/T shift lever (A/T) is in "N" or "P" range:
BRAKE SW OFF

When both brake pedal and clutch pedal (M/T) are released and A/T shift lever (A/T) is not in "N" or "P" range:

BRAKE SW ON



1. Disconnect control unit connector.
2. Turn ignition switch ON.
3. Turn ASCD main switch "ON".
4. Measure voltage between control unit connector terminals ⑤ and ground. When brake pedal or clutch pedal (M/T) is depressed or A/T shift lever (A/T) is in "N" or "P" range:
Approx. 0V

When both brake pedal and clutch pedal (M/T) are released and A/T shift lever (A/T) is not in "N" or "P" range:

Battery voltage should exist.
Refer to wiring diagram in EL-129.

NG

Check the following.

- ASCD brake switch
Refer to "Electrical Components Inspection" (EL-145).
- ASCD clutch switch (M/T model)
Refer to "Electrical Components Inspection" (EL-146).
- Inhibitor switch (A/T model)
Refer to "Electrical Components Inspection" (EL-145).
- ASCD hold relay (A/T model)
- Harness for open or short

OK

B

CHECK STOP LAMP SWITCH CIRCUIT.



See "STOP LAMP SW" in "Data monitor" mode.
STOP LAMP SW
When brake pedal is released:
OFF
When brake pedal is depressed:
ON



1. Disconnect control unit connector.
2. Check voltage between control unit harness terminal ⑪ and ground.

NG

Check the following.

- Harness for open or short between ASCD control unit and stop lamp switch
- 10A fuse (No. 7), located in the fuse block
- Stop lamp switch
Refer to "Electrical Components Inspection" (EL-145).

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

Refer to wiring diagram in EL-130.

OK

ASCD brake/stop lamp switch is OK.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

(ASCD STEERING SWITCH CHECK)

A

☆ MONITOR ☆ NO FAIL

SET SW ON

RESUME/ACC ON

CANCEL SW ON

RECORD

SEL293U

A

CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT.


See "SET SW", "RESUME/ACC SW" and "CANCEL SW" in "Data monitor" mode.

SET SW, RESUME/ACC SW and CANCEL SW

When switch is pressed: ON

When switch is released: OFF


OK → ASCD steering switch is OK.



1. Disconnect control unit connector.
2. Check voltage between control unit harness terminals.

	Terminal No.		Switch condition	
	⊕	⊖	Pressed	Released
SET/COAST SW	②	Ground	12V	0V
RESUME/ACC SW	①	Ground	12V	0V
CANCEL SW	②	Ground	6V	0V
	①	Ground	6V	0V

Refer to wiring diagram in EL-130.



NG

CHECK POWER SUPPLY FOR ASCD STEERING SWITCH.

Does horn work?

NG → Check the following.

- 10A fuse (No. 38, located in the relay box)
- Horn relay
- Harness for open or short

B

CHECK ASCD STEERING SWITCH.

Check continuity between terminals by pushing each button.

Switch	Terminal		
	①	②	③
SET/COAST	○	○	○
RESUME/ACCEL	○	○	○
CANCEL	○	○	○
	○	○	○

NG → Replace ASCD steering switch.

OK

Check harness for open or short between ASCD steering switch and ASCD control unit.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(VEHICLE SPEED SENSOR CHECK)

A



☆MONITOR ☆NO FAIL


VHCL SPEED SE 45mph

RECORD


SEL084T

A

CHECK VEHICLE SPEED SENSOR CIRCUIT.


 See "VHCL SPEED SE" in "Data monitor" mode while driving.

OR

 1. Apply wheel chocks and jack up drive wheels.
2. Disconnect control unit connector.
3. Connect voltmeter between control unit harness terminal ⑦ and ground.
4. Slowly turn drive wheels.
5. Check deflection of voltmeter pointer.
Refer to wiring diagram in EL-132.

OK → Vehicle speed sensor is OK.

A



DISCONNECT

H.S.

ASCD control unit connector (MB2)

7

Y/G

V

MEL360G

NG

Does speedometer operate normally?

No → Check speedometer and vehicle speed sensor circuit. Refer to EL-74.

Yes


Check harness for open or short between ASCD control unit terminal ⑦ and combination meter terminal ⑱.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

(ASCD PUMP CIRCUIT CHECK)



A

CHECK ASCSD PUMP.

1. Disconnect ASCSD pump connector.
2. Measure resistance between control unit harness terminals ① and ②, ③, ④.

Terminals	Resistance [Ω]	
①	④	Approx. 3
	②	Approx. 65
	③	Approx. 65

Refer to wiring diagram in EL-131.

NG

Replace ASCSD pump.

OK

Check harness for open or short between ASCSD pump and ASCSD control unit.



If a self-diagnostic result has already been accomplished, check using the following table.

CONSULT self-diagnostic result	Check circuit	
	ASCSD control unit terminal	ASCSD pump terminal
POWER SUPPLY-VALVE	⑧	①
VACUUM PUMP	⑨	④
AIR VALVE	⑩	②
RELEASE VALVE	⑪	③

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL




IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

(ASCD ACTUATOR/PUMP CHECK)



A
CHECK VACUUM HOSE.
 Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.

NG → Repair or replace hose.

OK

CHECK ASCD WIRE.
 Check wire for improper installation, rust formation or breaks.

NG → Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-146).

OK

B
CHECK ASCD ACTUATOR.
 1. Disconnect vacuum hose from ASCD actuator.
 2. Apply -40 kPa (-0.41 kg/cm^2 , -5.8 psi) vacuum to ASCD actuator with hand vacuum pump.
ASCD wire should move to pull throttle drum.
 3. Wait 10 seconds and check for decrease in vacuum pressure.
Vacuum pressure decrease:
Less than 2.7 kPa (0.028 kg/cm^2 , 0.39 psi)

NG → Replace ASCD actuator.

OK

C
CHECK ASCD PUMP.
 1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.
 2. If necessary remove ASCD pump.
 3. Connect vacuum gauge to ASCD pump.
 4. Apply 12V direct current to ASCD pump and check operation.

NG → Replace ASCD pump.


	12V direct current supply terminals		Operation
	⊕	⊖	
Air valve	①	②	Close
Release valve		③	Close
Vacuum motor		④	Operate

A vacuum pressure of at least -35 kPa (-0.36 kg/cm^2 , -5.1 psi) should be generated.

OK

ASCD actuator/pump are OK.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)




Electrical Components Inspection

ASC MAIN SWITCH

Check continuity between terminals by pushing switch to each position.


Switch position	Terminals					
	①	②	③	④	⑤	⑥
ON	○	○	○	○	ILL. ○	○
N		○	○	○		
OFF						



ASC STEERING SWITCH

Check continuity between terminals by pushing each button.


Button	Terminal		
	②①	②③	②②
SET/COAST	○	○	○
RESUME/ACCEL	○	○	
CANCEL	○	▶	○
	○	▶	○



ASC BRAKE SWITCH AND STOP LAMP SWITCH

Condition	Continuity	
	ASC brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.



INHIBITOR SWITCH (For A/T models)


Check continuity between terminals by setting shift lever to each position.

Shift lever position	Terminal		
	③	④	⑥
"N"	○		○
"P"	○	○	
Others			

AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Electrical Components Inspection (Cont'd)

CLUTCH SWITCH (For M/T models)



Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

ASCD Wire Adjustment



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

- (1) Loosen lock nut and adjusting nut.
- (2) Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
- (3) Tighten adjusting nut just until throttle drum starts to move.
- (4) Loosen adjusting nut again 1/2 to 1 turn.
- (5) Tighten lock nut.

POWER WINDOW

System Description

Power is supplied at all times

- from 25A fusible link (Letter **I**, located in the fuse and fusible link box)
- to circuit breaker terminal **①**
- through circuit breaker terminal **②**
- to power window relay terminal **③**.

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse (No. **I**, located in the fuse block)
- to power window relay terminal **①**.

Ground is supplied

- to power window relay terminal **②**
- through body grounds **(M5)** and **(M57)**.

The power window relay is energized and power is supplied

- through power window relay terminal **⑤**
- to power window main switch terminal **①**,
- to power window sub switch terminal **④**.

MANUAL OPERATION

Door LH

Ground is supplied

- to power window main switch terminal **②**
- through body grounds **(M5)** and **(M57)**.

WINDOW UP

When the LH switch in the power window main switch is pressed in the up position, power is supplied

- to power window regulator LH terminal **①**
- through power window main switch terminal **③**.

Ground is supplied

- to power window regulator LH terminal **②**
- through power window main switch terminal **④**.

Then, the motor raises the window until the switch is released.

WINDOW DOWN

When the LH switch in the power window main switch is pressed in the down position, power is supplied

- to power window regulator LH terminal **②**
- through power window main switch terminal **④**.

Ground is supplied

- to power window regulator LH terminal **①**
- through power window main switch terminal **③**.

Then, the motor lowers the window until the switch is released.

Door RH

Ground is supplied

- to power window main switch terminal **②**
- through body grounds **(M5)** and **(M57)**.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

POWER WINDOW

System Description (Cont'd)

NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

Main switch operation

Power is supplied

- through power window main switch (⑤ , ⑥)
- to power window sub-switch (① , ⑤).

The subsequent operation is the same as the sub-switch operation.

Sub-switch operation

Power is supplied

- through power window sub-switch (② , ③)
- to power window regulator RH (① , ②).

Ground is supplied

- to power window regulator RH (② , ①)
- through power window sub-switch (③ , ②)
- to power window sub-switch (⑤ , ①)
- through power window main switch (⑥ , ⑤).

Then, the motor raises or lowers the window until the switch is released.

AUTO OPERATION

The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position.

The AUTO feature only operates on the driver's window downward movement.

POWER WINDOW LOCK


The power window lock is designed to lock window operation to door RH window.

When the lock switch is pressed to lock position, ground of the RH switch in the power window main switch is disconnected. This prevents the power window motors from operating.

POWER WINDOW




Wiring Diagram — WINDOW —

EL-WINDOW-01



CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST

Refer to last page (Foldout page).
M9, E109



RS
BT
HA



EL

IDX

POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)


EL-WINDOW-02




D2, D102
W, W



D4, D104
B, B



D8
W



D107
W

POWER WINDOW

Trouble Diagnoses

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> 1. 7.5A fuse, 25A fusible link and (M13) circuit breaker 2. Grounds (M5) and (M57) 3. Power window relay 4. Open/short in power window main switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse (No. 1, located in fuse block), 25A fusible link (letter I, located in fuse and fusible link box) and (M13) circuit breaker. Turn ignition switch "ON" and verify battery positive voltage is present at terminal ① of power window main switch and terminal ④ of sub-switch. 2. Check grounds (M5) and (M57). 3. Check power window relay. 4. Check W/B wire between power window relay and power window main switch for open/short circuit.
Driver's side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> 1. Driver's side power window regulator circuit 2. Driver's side power window regulator 	<ol style="list-style-type: none"> 1. Check driver's side power window regulator circuit. 2. Check driver's side power window regulator.
Passenger power window cannot be operated.	<ol style="list-style-type: none"> 1. Power window sub-switches 2. Passenger side power window regulators 3. Power window main switch 4. Power window circuit 	<ol style="list-style-type: none"> 1. Check power window sub-switch. 2. Check passenger's side power window regulator. 3. Check power window main switch. 4-1. Check harnesses between power window main switch and power window sub-switch for open/short circuit. 4-2. Check harnesses between power window sub-switch and power window regulator for open/short circuit.
Passenger power window cannot be operated using power window main switch but can be operated by power window sub-switch.	<ol style="list-style-type: none"> 1. Power window main switch 	<ol style="list-style-type: none"> 1. Check power window main switch.
Driver's side power window auto function cannot be operated using power window main switch.	<ol style="list-style-type: none"> 1. Power window main switch 	<ol style="list-style-type: none"> 1. Check power window main switch.

GI

MA

EM

LC

EC

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

POWER DOOR LOCK

System Description

Power is supplied at all times

- through 25A fusible link (letter **I**, located in the fuse and fusible link box)
- to circuit breaker terminal **①**
- through circuit breaker terminal **②**
- to smart entrance control unit terminal **①**.

Ground is supplied to smart entrance control unit terminal **⑩** through body grounds **(M5)** and **(M57)**.

INPUT

When the door lock & unlock switch LH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑬**
- through door lock & unlock switch LH terminal **⑦**
- to door lock & unlock switch LH terminal **②**
- through body grounds **(M5)** and **(M57)**.

When the door lock & unlock switch RH is in LOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑬**
- through door lock & unlock switch RH terminal **③**
- to door lock & unlock switch RH terminal **②**
- through body grounds **(M5)** and **(M57)**.

When the door lock & unlock switch LH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑰**
- through door lock & unlock switch LH terminal **⑧**
- to door lock & unlock switch LH terminal **②**
- through body grounds **(M5)** and **(M57)**.

When the door lock & unlock switch RH is in UNLOCKED position, ground signal is supplied

- to smart entrance control unit terminal **⑰**
- through door lock & unlock switch RH terminal **①**
- to door lock & unlock switch RH terminal **②**
- through body grounds **(M5)** and **(M57)**.

OUTPUT

Unlock

Ground is supplied

- to door lock actuator LH terminal **③**
- to door lock actuator RH terminal **③**
- through smart entrance control unit terminal **④**.

DOOR LH

Power is supplied

- to door lock actuator LH terminal **①**
- through smart entrance control unit terminal **③**.

DOOR RH

Power is supplied

- to door lock actuator RH terminal **①**,
- through smart entrance control unit terminal **②**.

Then, the door is unlocked.

Lock

Ground is supplied

- to door lock actuator LH terminal **①**
- through smart entrance control unit terminal **③**, and
- to door lock actuator RH terminal **①**
- through smart entrance control unit terminal **②**.

Power is supplied







- to door lock actuator LH terminal **③**,
- to door lock actuator RH terminal **③**,
- through terminal **④**.

Then, the door is locked.

POWER DOOR LOCK

Wiring Diagram — D/LOCK —

EL-D/LOCK-01



Refer to last page (Foldout page).

(M9), (E109)

(M20)

CI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-02



Refer to last page (Foldout page).


(M20)

POWER DOOR LOCK

Trouble Diagnoses

SYMPTOM CHART


REFERENCE PAGE	EL-155	EL-156	EL-157
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (DOOR LOCK/UNLOCK SWITCH CHECK)	DIAGNOSTIC PROCEDURE 2 (DOOR LOCK ACTUATOR CHECK)
None of the doors lock/unlock when operating both door lock/unlock switch.	X		X
One or more doors are not locked and/or unlocked.			X
LH or RH lock/unlock switch does not operate.		X	



POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check

Terminal		Ignition switch		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage



Ground circuit check




Terminals	Continuity
⑩ - Ground	Yes

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(Door lock/unlock switch check)



A

CHECK SIGNAL OF DOOR LOCK/UNLOCK SWITCH.
Check voltage between control unit terminal ⑱ or ⑲ and ground.

Terminals	Door lock/unlock switch (LH or RH) operation	Voltage (V)
⑱ - Ground	Lock	0
	N and Unlock	Approx. 12
⑲ - Ground	Unlock	0
	N and Lock	Approx. 12

Refer to wiring diagram in EL-153.

OK → Door lock/unlock switch is OK.

NG ↓

B C

CHECK DOOR LOCK/UNLOCK SWITCH.
1. Disconnect door lock/unlock switch connector.
2. Check continuity between each door lock/unlock switch terminal.

B Power window main switch (Door lock/unlock switch)

Condition	Terminals		
	2	7	8
Lock	○	○	○
N	No continuity		
Unlock	○	○	○

C Door lock/unlock switch RH

Condition	Terminals		
	1	2	3
Lock	○	○	○
N	No continuity		
Unlock	○	○	○

NG → Replace door lock/unlock switch.

OK ↓

Check the following.




- Ground circuit for door lock/unlock switch
- Harness for open or short between door lock/unlock switch and control unit connector

POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

(Door lock actuator check)



A B

CHECK DOOR LOCK ACTUATOR CIRCUIT.
Check voltage for door lock actuator.

A Door lock actuator LH

Door lock/unlock switch operation	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	Ground	Approx. 12
Unlock	③	Ground	

B Door lock actuator RH

Door lock/unlock switch operation	Terminals		Voltage (V)
	⊕	⊖	
Lock	④	Ground	Approx. 12
Unlock	②	Ground	

Refer to wiring diagram in EL-154.

NG → Replace smart entrance control unit. (Before replacing control unit, perform Diagnostic procedure 1.)

OK ↓

C

CHECK DOOR LOCK ACTUATOR.

1. Disconnect door lock actuator connector.
2. Apply 12V direct current to door lock actuator and check operation.

Door lock actuator operation	Terminals	
	⊕	⊖
Unlocked → Locked	③	①
Locked → Unlocked	①	③

NG → Replace door lock actuator.

OK ↓

Check harness for open or short between control unit connector and door lock actuator.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

System Description

INPUTS

Power is supplied at all times

- through 10A fuse (No. 6), located in the fuse block
- to key switch terminal ①.

When the key switch is ON (key is inserted in ignition key cylinder), power is supplied

- through key switch terminal ②
- to smart entrance control unit terminal 24.

When the door switch LH is OPEN, ground is supplied

- to smart entrance control unit terminal 15
- through door switch LH terminal ①
- to door switch LH terminal ③
- through body grounds B4, B13 and T16.

When the door switch RH is OPEN, ground is supplied

- to smart entrance control unit terminal 16
- through door switch RH body ground.

When the door lock actuator LH (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal 12
- through door lock actuator LH (door unlock sensor) terminal ④
- to door lock actuator LH (door unlock sensor) terminal ②
- through body grounds M5 and M57.

When the door lock actuator RH (door unlock sensor) is UNLOCKED, ground is supplied

- to smart entrance control unit terminal 13
- through door lock actuator RH (door unlock sensor) terminal ④
- to door lock actuator RH (door unlock sensor) terminal ②
- through body grounds M5 and M57.

Remote controller signal input

- through window antenna
- to smart entrance control unit terminal 37.

The multi-remote control system controls operation of the

- power door lock
- interior lamp
- panic alarm
- hazard lamp
- ID code entry.

OPERATED PROCEDURE

Power door lock operation

When the following input signals are both supplied:

- key switch OFF (when key is not inserted in ignition key cylinder);
- door switch CLOSED (when all the doors are closed);

smart entrance control unit locks all the doors with input of LOCK signal from remote controller.

Smart entrance control unit unlocks the doors with input of UNLOCK signal from remote controller.

Refer to "POWER DOOR LOCK" (EL-152).

Hazard reminder

Power is supplied at all times

- through 10A fuse (No. 5), located in the fuse block
- to multi-remote control relays-1 and 2 terminal ①.

When smart entrance control unit receives a LOCK signal, ground is supplied

- to multi-remote control relays-1 and 2 terminal ②
- through smart entrance control unit terminal 7.

Multi-remote control relays are now energized and door lock actuators lock all the doors. (Hazard warning lamps flash twice as a reminder.)

MULTI-REMOTE CONTROL SYSTEM

System Description (Cont'd)

Interior lamp operation

When the following input signals are both supplied:

- key switch OFF (when key is not inserted in ignition key cylinder);
- door switch CLOSED (when all the doors are closed);

multi-remote control system turns on interior lamp (for 30 seconds) with input of UNLOCK signal from remote controller.

GI

For detailed description, refer to "INTERIOR, SPOT AND TRUNK ROOM LAMPS" (EL-66).

MA

Panic alarm operation

When key switch is OFF (when key is not inserted in ignition key cylinder), multi-remote control system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from remote controller.

EM

For detailed description, refer to "THEFT WARNING SYSTEM" (EL-173).

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

MULTI-REMOTE CONTROL SYSTEM


Schematic



MULTI-REMOTE CONTROL SYSTEM



Wiring Diagram — MULTI —

EL-MULTI-01



Refer to EL-POWER.

- * R4 : Without sunroof
- R5 : With sunroof








Refer to last page (Foldout page).
 M9 , E109
 M20

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL
- IDX

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-02



Refer to last page (Foldout page).



M10, B1

M20

MULTI-REMOTE CONTROL SYSTEM

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03



Refer to last page (Foldout page).

(M10) (B1)

(M20)


- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

MULTI-REMOTE CONTROL SYSTEM


Trouble Diagnoses

TROUBLE SYMPTOM

- All functions of remote control system do not operate.



- Some functions of multi-remote controller do not operate.




- Note:**
- The unlock and trunk open operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
 - The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder or if one of the doors is opened.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1




A

CHECK REMOTE CONTROLLER BATTERY.
Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.

Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal	Battery negative terminal	2.5 - 3.0V
⊕	⊖	

Note:
Remote controller does not function if battery is not set correctly.

DIAGNOSTIC PROCEDURE 2




A

CHECK ANTENNA FEEDER CABLE.

1. Disconnect feeder cable connector from control unit.
2. Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna. (Feeder cable connector is the one at bottom left.)
3. Check continuity between the feeder cable connectors.
Continuity should exist.
4. Check continuity between the feeder cable connector terminal and ground.
Continuity should not exist.

Refer to wiring diagram in EL-161.

NG → Replace feeder cable.




B

CHECK REAR WINDOW GLASS ANTENNA.

1. Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna.
2. Check continuity between glass antenna terminal and end of glass antenna.
Continuity should exist.

Note: When checking continuity, wrap tin foil around top of the probe. Then press the foil against the wire with your finger.

NG → Repair glass window antenna. Refer to REAR WINDOW DEFOGGER "Filament Repair".



OK → Antenna of multi-remote control is OK.


CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

All remote controls do not function even if remote controller is operated properly.



A


CHECK MAIN POWER SUPPLY CIRCUIT FOR CONTROL UNIT.

1. Disconnect connector from control unit.
2. Check voltage between control unit terminal ① and ground.

Battery voltage should exist.

Refer to wiring diagram in EL-161.

- NG
- Check the following.
- 25A fusible link (Letter **I**, located in fuse and fusible link box)
 - **M13** circuit breaker
 - Harness for open or short



B


CHECK GROUND CIRCUIT FOR CONTROL UNIT.

Check continuity between terminal ⑩ and ground.

Continuity should exist.

Refer to wiring diagram in EL-162.

- NG
- Check ground harness.



C


CHECK DOOR SWITCH CIRCUIT.

Check voltage between control unit terminal ⑮ and ground, ⑯ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
LH door switch	⑮	Ground	Open	0
			Close	Approx. 12
RH door switches	⑯	Ground	Open	0
			Close	Approx. 12

Refer to wiring diagram in EL-162.

- NG
- Check the following.
- Door switch
 - Refer to "Electrical Components Inspection" (EL-170).
 - Door switch ground circuit (Driver side) or door switch ground condition (Passenger side)
 - Harness for open or short between control unit and door switch



D

CHECK UNLOCK SENSOR CIRCUIT.

Check voltage between control unit terminal ⑫ and ground, ⑬ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
Front LH door	⑫	Ground	Unlock	0
			Lock	Approx. 12
Front RH door	⑬	Ground	Unlock	0
			Lock	Approx. 12


Refer to wiring diagram in EL-162.

- No
- Check the following.
- Door unlock sensor
 - Refer to "Electrical Components Inspection" (EL-170).
 - Door unlock sensor ground circuit
 - Harness for open or short between control unit and unlock sensor

(Go to next page.)

MULTI-REMOTE CONTROL SYSTEM


Trouble Diagnoses (Cont'd)



E **CHECK IGNITION SWITCH "ACC" CIRCUIT.**
 1. Disconnect control unit connector.
 2. Check voltage between control unit terminal ⑰ and ground while ignition switch is "ACC".
Battery voltage should exist.
 Refer to wiring diagram in EL-161.

NG → Check the following.

- 10A fuse (No. ⑱, located in fuse block)
- Harness for open or short between control unit and fuse



F **CHECK KEY SWITCH INPUT SIGNAL.**
 Check voltage between control unit terminal ⑳ and ground.

Condition	Voltage [V]
Key is inserted	Approx. 12
Key is withdrawn	0

Refer to wiring diagram in EL-161.

NG → Check the following.

- 10A fuse (No. ⑆, located in fuse block)
- Key switch
 Refer to "Electrical Components Inspection" (EL-170).
- Harness for open or short between key switch and fuse
- Harness for open or short between control unit and key switch

OK → Check operation parts in multi-remote control system for function.


CI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

Interior lamp does not turn on for 30 seconds when pressing unlock button of remote controller. Everything else functions.



A

CHECK INTERIOR LAMP CIRCUIT.

When interior lamp switch is "DOOR" position, check voltage across control unit terminal ⑨ and ground.

Does battery voltage exist?

Refer to wiring diagram in EL-161.

No

Repair harness between control unit and interior lamp.

Yes

A

Push unlock button of remote controller and check voltage across control unit terminal ⑨ and ground.

No

Replace smart entrance control unit.

Condition of multi-remote controller button	Voltage (V)
Unlock button is pushed.	0
Unlock button is not pushed.	Battery voltage

Yes





Check system again.

MULTI-REMOTE CONTROL SYSTEM

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 5

Hazard indicator does not flash twice when pressing lock button of remote controller. Everything else functions.



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

MULTI-REMOTE CONTROL SYSTEM




Electrical Components Inspection

KEY SWITCH (Insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.


Terminal No.	Condition	Continuity
① - ②	Key is inserted.	Yes
	Key is removed.	No



DRIVER SIDE DOOR SWITCH

Check continuity between terminals when door switch is pushed and released.


Terminal No.	Condition	Continuity
① - ③, ② - Ground	Door switch is pushed.	No
	Door switch is released.	Yes



PASSENGER SIDE DOOR SWITCH

Check continuity between terminals when door switch is pushed and released.

Terminal No.	Condition	Continuity
① - Ground	Door switch is pushed.	No
	Door switch is released.	Yes



DOOR UNLOCK SENSOR

Check continuity between terminals when door lock actuator is locked and unlocked.

Terminal No.	Condition	Continuity
④ - ②	Locked	No
	Unlocked	Yes

MULTI-REMOTE CONTROL SYSTEM

ID Code Entry Procedure


Enter the identity (ID) code manually when:

- remote controller or control unit is replaced.
- an additional remote controller is activated.

ID Code Entry Procedure

To enter the ID code, follow the procedures below.

PROCEDURE



NOTE

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.
- Any ID codes entered after termination of the "setting mode" will not be accepted. Additionally remote control signals will be inhibited when an ID code has not been entered during the "setting" mode.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT







HA

EL

IDX

THEFT WARNING SYSTEM

Component Parts and Harness Connector Location




THEFT WARNING SYSTEM

System Description

DESCRIPTION

1. Operation flow



2. Setting the theft warning system

Initial condition

- (1) Close all doors.
- (2) Close hood and trunk lid.

Disarmed phase

The theft warning system is in the disarmed phase when any door(s), hood or trunk lid is opened. The security indicator lamp blinks every second.

Pre-armed phase and armed phase

The theft warning system turns into the "pre-armed" phase when hood, trunk lid and all doors are closed and locked by key or multi-remote controller. (The security indicator lamp illuminates.)

After about 30 seconds, the system automatically shifts into the "armed" phase (the system is set). (The security indicator lamp blinks every 2.4 seconds.)

3. Canceling the set theft warning system

When the following (a) or (b) operation is performed, the armed phase is canceled.

- (a) Unlock the doors with the key or multi-remote controller.
- (b) Open the trunk lid with the key. When the trunk lid is closed after opening the trunk lid with the key, the system returns to the armed phase.

4. Activating the alarm operation of the theft warning system

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.4 seconds.)

When the following operation (a) or (b) is performed, the system sounds the horns and flashes the headlamps for about 2.5 minutes. (At the same time, the system disconnects the starting system circuit.)

- (a) Engine hood, trunk lid or any door is opened before unlocking door with key or multi-remote controller.
- (b) Door is unlocked without using key or multi-remote controller.

GI
MA
EM
LC
EC
FE
CL
MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

THEFT WARNING SYSTEM

System Description (Cont'd)

Refer to Owner's Manual for theft warning system operating instructions.

Power is supplied at all times

- through 7.5A fuse (No. ⑧), located in the fuse block
- to security indicator lamp terminal ②.

Power is supplied at all times

- through 25A fusible link (letter I), located in the fuse and fusible link box)
- to smart entrance control unit terminal ①.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse (No. ⑱), located in the fuse block)
- to smart entrance control unit terminal ⑰.

Ground is supplied

- to smart entrance control unit terminal ⑩
- through body grounds (M5) and (M57).

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, the smart entrance control unit must receive signals indicating the doors, hood and trunk lid are closed and the doors are locked.

When a door is open, smart entrance control unit terminal ⑮ or ⑯ receives a ground signal from each door switch.

When a door is unlocked, smart entrance control unit terminal ⑫ or ⑬ receives a ground signal from terminal ④ of each door unlock sensor.

When the hood is open, smart entrance control unit terminal ⑲ receives a ground signal

- from terminal ② of the hood switch
- through body grounds (E28) and (E42).

When the trunk lid is open, smart entrance control unit terminal ⑳ receives a ground signal

- from terminal ① of the trunk room lamp switch
- through body grounds (B4), (B13) and (T16).

When the doors are locked with key or multi-remote controller and none of the described conditions exist, the theft warning system will automatically shift to armed phase.

THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key is used to lock doors, terminal ⑳ receives a ground signal

- from terminal ① of the key cylinder switch LH
- from terminal ② of the door key cylinder switch RH
- through body grounds (M5) and (M57).

If this signal or lock signal from remote controller is received by the smart entrance control unit, the theft warning system will activate automatically.

Once the theft warning system has been activated, smart entrance control unit terminal ⑳ supplies ground to terminal ① of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

THEFT WARNING SYSTEM

System Description (Cont'd)

THEFT WARNING SYSTEM ALARM OPERATION

The theft warning system is triggered by

- opening a door
- opening the trunk lid
- opening the hood
- unlocking door without using key or multi-remote controller.

Once the theft warning system is in armed phase, if the smart entrance control unit receives a ground signal at terminal ⑫, ⑬ (door unlock sensor), ⑮, ⑯ (door switch), ⑳ (trunk room lamp switch) or ㉑ (hood switch), the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently, and the starting system is interrupted.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse (No. ①), located in the fuse block).
- to theft warning relay-2 terminal ①.

If the theft warning system is triggered, ground is supplied

- from terminal ㉒ of the smart entrance control unit
- to theft warning relay-2 terminal ②.

With power and ground supplied, power to the clutch interlock relay (M/T models) or inhibitor switch (A/T models) is interrupted. The starter motor will not crank and the engine will not start.

Power is supplied at all times

- through 7.5A fuse (No. ④), located in fuse and fusible link box)
- to theft warning relay-1 terminal ①,
- to theft warning horn relay-1 terminal ② and theft warning horn relay-2 terminal ②.
- through 10A fuse (No. ③), located in the fuse and fusible link box)
- to horn relay terminal ②.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ⑧ of the smart entrance control unit
- to theft warning relay-1 terminal ② and
- to theft warning horn relay-2 terminal ①.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key is used to unlock a door, smart entrance control unit terminal ⑳ receives a ground signal

- from terminal ② of the LH key cylinder switch
- from terminal ① of the RH key cylinder switch.

When the key is used to unlock the trunk lid, smart entrance control unit terminal ㉓ receives a ground signal from terminal ① of the trunk lid key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently.

- from smart entrance control unit terminal ⑧
- to theft warning relay-1 terminal ② and
- to theft warning horn relay-2 terminal ②.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


THEFT WARNING SYSTEM

Wiring Diagram — THEFT —


EL-THEFT-01



GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS



Refer to last page (Foldout page).




BT
HA
EL
IDX




THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



Refer to last page (Foldout page).




(M20)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

THEFT WARNING SYSTEM

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-05




GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST

RS
BT
HA

EL

IDX

1455



Refer to last page (Foldout page).


(M9) (E109)

THEFT WARNING SYSTEM

Trouble Diagnoses

PRELIMINARY CHECK

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



After performing preliminary check, go to the corresponding diagnostic procedure(s) indicated in the symptom chart.

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

Before starting trouble diagnoses below, perform preliminary check.

Symptom numbers in the symptom chart correspond with those of Preliminary check.

SYMPTOM CHART

PROCEDURE		—	Power supply and ground circuit check			Diagnostic procedure							—	
			EL-182	EL-184	EL-184	EL-185	EL-188	EL-189	EL-190	EL-191	EL-192	EL-193		EL-194
REFERENCE PAGE														
SYMPTOM														
1	Theft warning system cannot be set by ...	All items	X	X	X	X		X						
		Door outside key	X	X	X				X					
		Multi-remote control	X	X	X									X
2	*1 Theft warning system does not alarm when ...	Any door is opened.	X	X	X	X								
		Any door is unlocked without using key or multi-remote controller	X	X	X			X						
3	Theft warning alarm does not activate.	All function	X	X	X	X		X						
		Horn alarm	X	X	X					X				
		Headlamp alarm	X	X	X						X			
		Starter interrupt	X	X	X								X	
4	Theft warning system cannot be canceled by ...	Door outside key	X	X	X				X					
		Trunk lid key								X				
		Multi-remote control	X	X	X									X
5	Theft warning indicator does not turn "ON" or blinking.	X	X	X		X								

X : Applicable

*1: Make sure the system is in the armed phase.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

POWER SUPPLY AND GROUND CIRCUIT CHECK

Power supply circuit check



Terminals		Ignition switch position		
⊕	⊖	OFF	ACC	ON
①	Ground	Battery voltage	Battery voltage	Battery voltage
⑪	Ground	0V	0V	Battery voltage
⑰	Ground	0V	Battery voltage	Battery voltage




Ground circuit check

Terminals	Continuity
⑩ - Ground	Yes

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(1) (Door switch check)



1. Turn ignition switch "OFF" and remove key from key cylinder.
2. Close all doors, hood and trunk lid. "SECURITY" indicator lamp should turn off.
3. Open LH/RH door. "SECURITY" indicator lamp should blink every second.

OK → Door switch is OK.



A

CHECK DOOR SWITCH INPUT SIGNAL.
Check voltage between control unit terminals ⑮ or ⑯ and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
LH door switch	⑮	Ground	Open	0
			Closed	Approx. 12
RH door switch	⑯	Ground	Open	0
			Closed	Approx. 12

Refer to wiring diagram in EL-177.

OK → Door switch is OK.

B

CHECK DOOR SWITCH.
1. Disconnect door switch connector.
2. Check continuity between door switch terminals.

	Terminals	Condition	Continuity
LH door switch	① - ③, ② - Ground	Closed	No
		Open	Yes
RH door switch	① - Ground	Closed	No
		Open	Yes

NG → Replace door switch.

- OK
- Check the following.
- Door switch ground circuit (Front LH) or door switch ground condition
 - Harness for open or short between control unit and door switch

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 1-(2) (Hood switch check)



1. Turn ignition switch "OFF" and remove key from key cylinder.
2. Close all doors, hood and trunk lid. "SECURITY" indicator lamp should turn off.
3. Open hood. "SECURITY" indicator lamp should blink every second.

OK → Hood switch is OK.



Check hood switch and hood fitting condition.

NG → Adjust installation of hood switch or hood.

A

CHECK HOOD SWITCH INPUT SIGNAL.
Check voltage between control unit terminal 29 and ground.

Condition	Voltage [V]
Hood is open.	0
Hood is closed.	Approx. 5

Refer to wiring diagram in EL-177.

OK → Hood switch is OK.

B

CHECK HOOD SWITCH.

1. Disconnect hood switch connector.
2. Check continuity between hood switch terminals.

Terminals	Condition	Continuity
① - ②	Pushed	No
	Released	Yes

NG → Replace hood switch.


Check the following.

- Hood switch ground circuit
- Harness for open or short between control unit and hood switch

THEFT WARNING SYSTEM


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(3) (Trunk room lamp switch check)



1. Turn ignition switch "OFF" and remove key from key cylinder.
2. Close all doors, hood and trunk lid.
"SECURITY" indicator lamp should turn off.
3. Open trunk lid.
"SECURITY" indicator lamp should blink every second.

OK → Trunk room lamp switch is OK.



- A**
- CHECK TRUNK ROOM LAMP SWITCH INPUT SIGNAL.**
Check voltage between control unit terminal ② and ground.

Condition	Voltage [V]
Trunk lid is open.	Approx. 0
Trunk lid is closed.	Approx. 12

Refer to wiring diagram in EL-178.

OK → Trunk room lamp switch is OK.

- B**
- CHECK TRUNK ROOM LAMP SWITCH.**
1. Disconnect trunk room lamp switch connector.
 2. Check continuity between trunk room lamp switch terminals.

Terminals	Condition	Continuity
① - ②	Closed	No
	Open	Yes

NG → Replace trunk room lamp switch.

- OK
- Check the following.
- Trunk room lamp switch ground circuit
 - Harness for open or short between control unit and trunk room lamp switch

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA




EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 2 (Security indicator lamp check)



THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3 (Door unlock sensor check)



A

CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.

Check voltage between control unit terminals ⑫ or ⑬, and ground.

	Terminals		Condition	Voltage [V]
	⊕	⊖		
LH door	⑫	Ground	Locked	Approx. 12
			Unlocked	0
RH door	⑬	Ground	Locked	Approx. 12
			Unlocked	0

Refer to wiring diagram in EL-178.

OK

Door unlock sensor is OK.

CI

MA

EM

LC

EC

FE

NG

B

CHECK DOOR UNLOCK SENSOR.

1. Disconnect door unlock sensor connector.
2. Check continuity between door unlock sensor terminals.

Terminals	Condition	Continuity
④ - ②	Locked	No
	Unlocked	Yes

NG

Replace door unlock sensor.

CL

MT

AT

PD

OK

Check the following.

- Door unlock sensor ground circuit
- Harness for open or short between control unit and door unlock sensor

FA

RA

BR

ST

RS

BT

HA


EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4 (Door key cylinder switch check)



A

CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL).


Check voltage between control unit terminals ③① or ③② and ground.

Terminals		Key position	Voltage [V]
⊕	⊖		
③①	Ground	Neutral	Approx. 5
		Lock	0
③②	Ground	Neutral	Approx. 5
		Unlock	0

Refer to wiring diagram in EL-179.

OK → Door key cylinder switch is OK.

NG



B

CHECK DOOR KEY CYLINDER SWITCH.

1. Disconnect door key cylinder switch connector.
2. Check continuity between door key cylinder switch terminals.

Terminals	Key position	Continuity
LH: ① - ④	Neutral	No
	Lock	Yes
LH: ② - ④	Neutral	No
	Unlock	Yes

NG → Replace door key cylinder switch.

OK



Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between control unit and door key cylinder switch

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5 (Trunk lid key cylinder switch check)



A

CHECK TRUNK LID KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/ UNLOCK SIGNAL).
Check voltage between control unit terminal 27 and ground.

Key position	Voltage [V]
Neutral	Approx. 5
Between neutral and unlock	0

Refer to wiring diagram in EL-178.

OK → Trunk lid key cylinder switch is OK.

B

CHECK TRUNK LID KEY CYLINDER SWITCH.
1. Disconnect trunk lid key cylinder switch connector.
2. Check continuity between trunk lid key cylinder switch terminals.

Key position	Continuity
Neutral and lock	No
Between neutral and unlock	Yes

NG → Replace trunk lid key cylinder switch.

OK

Check the following.





- Trunk lid key cylinder switch ground circuit
- Harness for open or short between control unit and trunk lid key cylinder switch

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 (Theft warning horn alarm check)






THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

(Theft warning headlamp alarm check)



A

CHECK THEFT WARNING HEADLAMP ALARM OPERATION.

1. Disconnect control unit connector.
2. Apply ground to control unit terminal ⑧.

Does headlamp alarm activate?

Refer to wiring diagram in EL-180.

Yes

Headlamp alarm is OK.

No

Does headlamp come on when turning lighting switch "ON"?

No

Check headlamp system. Refer to "HEADLAMP" (EL-34).

Yes

Check theft warning relay-1.

NG

Replace.

OK

B

CHECK POWER SUPPLY FOR THEFT WARNING RELAY-1.

1. Disconnect theft warning relay-1 connector.
2. Check voltage between terminal ① and ground.

Positive battery voltage should exist.

Refer to wiring diagram in EL-180.

NG

Check the following.

- 7.5A fuse (No. 49), located in the fuse and fusible link box
- Harness for open or short between theft warning relay-1 and fuse

OK

C

CHECK THEFT WARNING RELAY-1 CIRCUIT.

1. Disconnect theft warning relay-1 connector.
2. Check voltage between terminals ③ and ⑤.
3. Check voltage between terminals ⑥ and ⑦.

Positive battery voltage should exist.

Positive battery voltage should exist.

NG

Check harness for open or short.

OK

Check harness for open or short between theft warning relay-1 and control unit.

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

THEFT WARNING SYSTEM

Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 8 (Starter interrupt system check)



A

CHECK STARTER MOTOR CUT OUTPUT SIGNAL.

1. Turn ignition switch "ON".
2. Check voltage between control unit terminal ③② and ground.

Condition	Voltage [V]
Except starter killed phase	Approx. 12
Starter killed phase	0

Refer to wiring diagram in EL-180.

NG

Check the following.

- 7.5A fuse (No. ①, located in fuse block)
- Harness for open or short between theft warning relay-2 and fuse
- Harness for open or short between control unit and theft warning relay-2

OK

Check theft warning relay-2.

NG

Replace relay.

OK

Check system again.

THEFT WARNING SYSTEM

NOTE

GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

SMART ENTRANCE CONTROL UNIT

Description

The following systems are controlled by the smart entrance control unit.

- Warning buzzer
- Rear window defogger timer
- Power door lock
- Multi-remote control system
- Theft warning system

For detailed description and wiring diagrams, refer to the relevant pages for the each system.

The control unit receives data from the switches and sensors to control their corresponding system relays and actuators.

System	Input	Output
Power door lock	Door lock and unlock switch	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switch Door unlock sensor Antenna (remote controller signal)	Theft warning horn relay-1 and 2 Theft warning relay-1 (headlamp) Interior lamp Multi-remote control relay-1 and 2 Door lock actuator
Warning buzzer	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt buckle switch Front door switch LH	Warning buzzer
Rear window defogger timer	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Theft warning	Ignition switch (ACC, ON) Door switch Hood switch Trunk room lamp switch Door key cylinder switch (lock/unlock) Trunk lid key cylinder switch (unlock) Door unlock sensor	Theft warning horn relay-1 and 2 Theft warning relay-1 (headlamp) Theft warning relay-2 (Starter interrupt) Security indicator

SMART ENTRANCE CONTROL UNIT


Smart Entrance Control Unit Inspection Table

Terminal No.	Connections	Operated condition	Voltage (Approximate values)		
1	Power source (C/B)	—	12V	GI	
2	Passenger door lock actuator	Door lock & unlock switch	Unlocked	12V	MA
3	Driver door lock actuator		Free	0V	
4	Driver and passenger door lock actuators	Door lock & unlock switch	Locked	12V	EM
			Free	0V	
7	Multi-remote control relays -1 and 2	When doors are locked using remote controller	12V → 0V	LC	
8	Theft warning relay-1 (Headlamp)	When panic alarm is operated using remote controller	12V → 0V	EC	
9	Interior lamp	When interior lamp is operated using remote controller. (Lamp switch in "DOOR" position)	12V → 0V	FE	
10	Ground	—	—	FE	
11	Ignition switch (ON)	"ON" position	12V		
12	Driver door unlock sensor	Driver door: Locked → Unlocked	12V → 0V	CL	
13	Passenger door unlock sensor	Passenger door: Locked → Unlocked	12V → 0V		
15	Driver door switch	OFF (Closed) → ON (Open)	12V → 0V	MT	
16	Passenger door switch	OFF (Closed) → ON (Open)	12V → 0V		
17	Ignition switch (ACC)	"ACC" position	12V	AT	
18	Door lock & unlock switches	Neutral → Locks	12V → 0V		
19	Door lock & unlock switches	Neutral → Unlocks	12V → 0V	PD	
20	Rear window defogger switch	OFF → ON	12V → 0V	FA	
21	Seat belt buckle switch	Unfasten → Fasten (Ignition key is in "ON" position)	0V → 12V	RA	
23	Warning buzzer	OFF → ON	12V → 0V		
24	Ignition key switch (Insert)	Key inserted → Key removed from IGN key cylinder	12V → 0V	BR	
25	Lighting switch (1ST)	1ST, 2ND positions: ON → OFF	12V → 0V		
26	Trunk room lamp switch	ON (Open) → OFF (Closed)	0V → 12V	ST	
27	Trunk key unlock switch	OFF (Neutral) → ON (Unlocked)	5V → 0V		
29	Hood switch	ON (Open) → OFF (Closed)	0V → 5V	RS	
30	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)	5V → 0V		
31	Door key cylinder lock switch	OFF (Neutral) → ON (Unlocked)	5V → 0V	BT	
32	Theft warning relay-2 (Starter cut)	OFF → ON	12V → 0V	HA	
33	Security indicator	Goes off → Illuminates	12V → 0V		
36	Rear window defogger relay	OFF → ON	12V → 0V	EL	
37	Multi-remote antenna	—	—		

IDX


SMART ENTRANCE CONTROL UNIT

Schematic



SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)





GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Engine Compartment



LOCATION OF ELECTRICAL UNITS

Passenger Compartment



GI

MA

EM

LC

EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


LOCATION OF ELECTRICAL UNITS

Passenger Compartment (Cont'd)



HARNESSES LAYOUT

Outline




MEL329D

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

HARNES LAYOUT

Main Harness



*: Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.


HARNES LAYOUT

Main Harness (Cont'd)

B5 A5 B5 B5 B4 A4 A5 A3 A3 B3 A2 B2 B2 C3 C3 C3 B4 B4 A2 A3 C3 D2 D2 D4 C4 C4 C4 D4 D4 D4 D2 E3 D3 D3 E3 E3 D4 D4 E4 E4 E4	: Power window relay : Recirculation relay : Fuel pump relay : Body ground : Fuse block : Data link connector for CONSULT : Rear window defogger relay : To (E109) (SMJ) : To (B1) (SMJ) : To (E113) : Circuit breaker : Tweeter LH (Models with 6-speaker audio system) : Illumination control switch : ASCD main switch : Rear window defogger timer (Models without power door locks) : Warning buzzer unit (Models without power door locks) : Smart entrance control unit (Models with power door locks) : TCM (Transmission control module) (A/T models) : To (D1) : To (D2) : ASCD clutch switch (M/T models) : Diode (Models with theft warning system) : Diode (Models with 6-speaker system) : ASCD brake switch (M/T models) : Stop lamp switch : Warning buzzer (Models with power door locks) : Combination flasher unit : Air mix door motor : Mode door motor : Fan switch : Security indicator lamp (Models with theft warning system) : Hazard switch : Rear window defogger switch : Bi-level door motor : To (Z5) : Audio : Audio : CD deck illumination : CD deck : Cigarette lighter
--	--

E2 E2 F4 F2 F1 G1 G3 G3 G2 G2 G3 F4 F4 F4	: Joint connector (Models with 6-speaker audio system) : Intake door motor : Fan resistor : Blower motor : To (R1) : Tweeter RH (Models with 6-speaker audio system) : Body ground : ASCD hold relay (M/T models) : To (D101) : To (D102) : ASCD control unit : To (F3) : To (F4) : To (B23) (Models with ABS)
--	---

D2 C3 C2 C2 B3 C3 D2 D2 E4 G3 G3 A5	: Diode (Models with theft warning system) : Combination meter : Combination meter : Combination meter : Data link connector for GST : ASCD brake switch (Shift lock brake switch) (A/T models) : Push control unit : Push control unit : Cigarette lighter illumination : ASCD hold relay (A/T models) : Theft warning horn relay-2 : Fog lamp relay-1
--	--




*: Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNES LAYOUT

Engine Room Harness





*: Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNES LAYOUT

Engine Room Harness (Cont'd)

E3	: Cooling fan relay-1	C5	: Fog lamp LH
E4	: Clutch interlock relay (M/T models)	D4	: Headlamp LH
E5	: Air conditioner relay	D4	: Parking lamp LH
E6	: Horn relay	D4*	: Body ground
E7	: Headlamp relay	E5	: Front side marker lamp LH
E8	: Fuse and fusible link block-2	F3	: Theft warning horn
E9	: Fuse and fusible link block-3	F2	: Brake fluid level switch
E10	: Theft warning relay-2 (Models with theft warning system)	D3	: Compressor
E11	: Theft warning relay-1 (Models with theft warning system)	E3	: Power steering oil pressure switch
C2*	: Inhibitor switch (A/T models)	E3	: Dropping resistor (A/T models)
C2*	: Inhibitor switch (A/T models)	A3	: Headlamp RH
C2*	: A/T solenoid valve (A/T models)	C4	: Headlamp LH
C2*	: Revolution sensor (A/T models)	E51	: Park/Neutral position relay (A/T models with ASCD)
C3	: To E203 (A/T models)	F3	: Fuse and fusible link box
C3	: To E201 (M/T models)	B1	: Front wheel sensor LH (Models with ABS)
C3*	: To E202	B1	: Battery
B1	: Hood switch (Models with theft warning system)	B1	: Battery
A2	: Front side marker lamp RH	E53	: Theft warning horn relay-1
B2	: To F13	E54	: Cooling fan relay-2
B3	: Washer motor	E55	: Fog lamp relay-2
B3	: Washer fluid level switch	E56	: Fuse and fusible link box
A2	: Daytime light control unit (For Canada)		
A2	: Daytime light control unit (For Canada)		
A2*	: Body ground		
B3	: Triple-pressure switch		
B3	: Cooling fan motor		
A2	: Parking lamp RH		
A3	: Headlamp RH		
A4	: Fog lamp RH		
A4	: Front turn signal lamp RH		
B4	: Horn		
B4	: Ambient temperature switch		
C5	: Front turn signal lamp LH		




Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

HARNESS LAYOUT

Engine Room Harness (Cont'd)


*: Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.



- (E100) : Fuse block
- (E101) : Fuse block
- (E102) : Clutch interlock switch (M/T models)
- (E103) : Ignition switch
- (E104) : Wiper switch
- (E105) : Combination switch (Lighting)
- (E106) : Combination switch (Turn signal)
- (E107) : Key switch
- (E108) : Fog lamp switch
- (E109) : To (M9) (SMJ)
- (E110) : To (M11)
- (E111) : To (M11)
- (E113) : To (M11)

HARNESS LAYOUT

Engine Harness




- E201 : To E17 (M/T models)
- * E202 : To E19
- E203 : To E16 (A/T models)
- E205 : Body ground
- E206 : Battery
- E207 : Fusible link block
- * E208 : To F11
- E210 : Oil pressure switch
- * E212 : To E230
- E213 : Back-up lamp switch (M/T models)
- E214 : Neutral position switch (M/T models)
- E215 : 5th position switch (M/T models)
- * E216 : Vehicle speed sensor
- * E217 : Rear heated oxygen sensor
- E218 : Alternator
- E219 : Alternator
- E220 : Alternator
- E221 : Starter motor
- E222 : Starter motor
- * E230 : To E212
- * E231 : Crankshaft position sensor (OBD)

*: Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

G
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 !DX

HARNESS LAYOUT

Engine Control Harness




*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNES LAYOUT

Engine Control Harness (Cont'd)

- * (F1) : ECM (ECCS control module)
- * (F2) : ECCS relay
- * (F3) : To (M63)
- * (F4) : To (M64)
- (F5) : To (B24)
- (F6) : Diode
- (F7) : Wiper motor
- (F8) : ASCD pump
- (F9) : Wiper amplifier
- * (F11) : To (E208)
- (F12) : Front wheel sensor RH
- (F13) : To (E23)
- * (F15) : Engine ground
- * (F16) : Front heated oxygen sensor
- * (F17) : To (F71)
- * (F18) : Injector No. 4
- * (F19) : Injector No. 3
- * (F20) : Injector No. 2
- * (F21) : Injector No. 1
- * (F22) : Throttle position sensor
- (F23) : To (F90)
- * (F24) : Engine coolant temperature sensor
- * (F25) : Throttle position switch
- * (F26) : To (F61)
- (F27) : Thermal transmitter

- * (F28) : Resistor
- * (F29) : Intake air temperature sensor
- * (F30) : Mass air flow sensor
- * (F31) : Distributor (Camshaft position sensor is built-in.)
- * (F32) : Ignition coil
- (F33) : Condenser
- * (F34) : EVAP canister purge control solenoid valve
- * (F35) : MAP/BAPO switch solenoid valve
- * (F36) : Absolute pressure sensor
- * (F37) : To (F55)
- (F38) : ABS relay unit
- (F39) : ABS actuator
- (F40) : ABS relay unit
- * (F41) : To (B85)
- * (F50) : To (F23)
- * (F51) : EGR temperature sensor
- (F52) : IACV-air regulator
- (F53) : IACV-AAC valve
- (F54) : IACV-FICD solenoid valve
- * (F55) : To (F37)
- * (F56) : EVAP canister purge volume control valve
- * (F57) : Engine ground
- * (F61) : To (F26)
- * (F62) : Knock sensor
- * (F71) : To (F17)
- * (F72) : EGRC-solenoid valve



*: Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX

HARNESS LAYOUT

Body Harness and Tail Harness



*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

HARNES LAYOUT


Body Harness and Tail Harness (Cont'd)

Body harness

A2	(B1)	: To (M10) (SMJ)
B2*	(B4)	: Body ground
B3	(B5)	: Seat belt buckle switch
C2	(B6)	: Parking brake switch
B2	(B7)	: A/T device
C2	(B8)	: Door mirror remote control switch
C3	(B9)	: To (B25)
B2	(B10)	: Door switch LH
C3	(B11)	: Multi-remote control relay-2 (Models with theft warning system)
B2	(B12)	: Multi-remote control relay-1 (Models with theft warning system)
C3*	(B13)	: Body ground
C2	(B14)	: Rear window defogger
D2	(B16)	: Rear speaker LH
E2	(B18)	: Trunk room lamp
E2	(B19)	: Rear speaker RH
D3	(B20)	: To (T1)
D3*	(B21)	: To (T2)
C2	(B23)	: To (M85) (Models with ABS)
D2	(B24)	: To (F5) (Models with ABS)
C3	(B25)	: To (B9)
E2	(B27)	: Door switch RH
F2*	(B32)	: To (T21) (Models with ABS)
F2*	(B33)	: To (T22) (Models with ABS)
D2*	(B35)	: To (F41)
F3*	(B36)	: To (T31) (Models without ABS)
B3	(B37)	: Diode (A/T models)
D2	(B38)	: Diode (Models with theft warning system)

Tail harness

D3	(T1)	: To (B20)
D3*	(T2)	: To (B21)
G2	(T5)	: High-mounted stop lamp
G3	(T6)	: Trunk lid key cylinder switch (Models with theft warning system)
G3	(T7)	: Back-up lamp RH
G3	(T8)	: Trunk room lamp switch
F4	(T9)	: Back-up lamp LH
D4	(T10)	: Power antenna
E3	(T12)	: Rear side marker lamp LH
E4	(T13)	: Rear combination lamp LH
G4	(T14)	: License plate lamp
G3*	(T16)	: Body ground
G3	(T19)	: Rear combination lamp RH
G2	(T20)	: Rear side marker lamp RH
G2*	(T21)	: To (B32) (Models with ABS)
G2*	(T22)	: To (B33) (Models with ABS)
E4	(T26)	: Rear wheel sensor (Models with ABS)
E4*	(T29)	: Fuel tank gauge unit
E4	(T30)	: Fuel pump
G3*	(T31)	: To (B36) (Models without ABS)
D3	(T32)	: ABS control unit
D3	(T33)	: ABS control unit
G2	(T34)	: Check connector
F4*	(T35)	: EVAP canister vent control valve
F4*	(T36)	: EVAP control system pressure sensor
F4	(T37)	: Vacuum cut valve bypass valve
G2	(T38)	: Check connector




*: Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection.

CI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


HARNES LAYOUT

Room Lamp Harness



HARNES LAYOUT

Air Bag Harness



- (Z1) : Air bag diagnosis sensor unit
- (Z3) : To air bag module (Driver side), ASCD steering switch and horn switch via spiral cable
- (Z4) : Air bag module (Passenger side)
- (Z5) : To (M42)


GI
MA
EM
LC
EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

HARNESS LAYOUT

Door Harness LH



Door Harness RH



BULB SPECIFICATIONS

Headlamp

Item		Wattage (W)
High/Low (Semi-sealed beam)	Inside	65 (HB3)
	Outside	55 (H1)

CI

Exterior Lamp

Item		Wattage (W)
Front fog lamp		55 (H3)
Front turn signal lamp		27
Parking lamp		8
Front side marker lamp		3.8
Rear side marker lamp		3.8
Rear combination lamp	Turn signal lamp	27
	Stop/Tail lamp	27/8
Back-up lamp		27
License plate lamp		5
High-mounted stop lamp (BULB/LED)		5

MA

EM

LC

EC

FE

CL

Interior Lamp

Item		Wattage (W)
Interior lamp		10
Spot lamp		10
Trunk room lamp		3.4

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WIRING DIAGRAM CODES (Cell codes)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
5TH/P	EC	5th Position Switch
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C	HA	Air Conditioner
AIRREG	EC	IACV-Air Regulator
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device (ASCD)
A/T	AT	A/T
AT/C	EC	A/T Control
ATDIAG	EC	A/T Diagnosis Communication Line
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BUZZER	EL	Warning Buzzer
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Valve/ Solenoid Valve
CHARGE	EL	Charging System
CIGAR	EL	Cigarette Lighter
CKPS	EC	Crankshaft Position Sensor
CLOCK	EL	Clock
CMPS	EC	Camshaft Position Sensor
COOL/F	EC	Cooling Fan Control
DEF	EL	Rear Window Defogger
D/LOCK	EL	Power Door Lock
DTRL	EL	Headlamp - With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
EGRC	EC	EGR Function
EGRC/V	EC	EGR and Canister Control Solenoid Valve
EGR/TS	EC	EGR Temperature Sensor
F/FOG	EL	Front Fog Lamp
FICD	EC	IACV-FICD Solenoid Valve
F/PUMP	EC	Fuel Pump Control
FRO2	EC	Front Heated Oxygen Sensor
FRO2/H	EC	Front Heated Oxygen Sensor Heater
FUEL	EC	Fuel Injection System Function
H/LAMP	EL	Headlamp
HORN	EL	Horn
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal

Code	Section	Wiring Diagram Name
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Spot and Trunk Room Lamps
KS	EC	Knock Sensor
LD/SIG	EC	Electrical Load Signal
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil and Fuel Gauges
MIL	EC	MIL, Data Link Connector For CONSULT, GST
MIRROR	EL	Door Mirror
MULTI	EL	Multi-remote Control System
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Volume Control Valve
PNP/SW	EC	Park/Neutral Position Switch
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PST/SW	EC	Power Steering Oil Pressure Switch
RRO2	EC	Rear Heated Oxygen Sensor
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
S/SIG	EC	Start Signal
START	EL	Starting System
SW/V	EC	MAP/BARO Switch Solenoid Valve
TAIL/L	EL	Parking, License, Tail and Stop Lamps
TFTS	EC	Tank Fuel Temperature Sensor
THEFT	EL	Theft Warning System
TPS	EC	Throttle Position Sensor
TP/SW	EC	Throttle Position Switch
TURN	EL	Turn Signal and Hazard Warning Lamps
VENT/V	EC	EVAP Canister Vent Control Valve
VSS	EC	Vehicle Speed Sensor
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIPER	EL	Front Wiper and Washer