

SERVICE MANUAL

DATSUN 280Z
MODEL S30 SERIES



SECTION EL

ENGINE LUBRICATION SYSTEM

EL

ENGINE LUBRICATION SYSTEM	EL- 2
SERVICE DATA AND SPECIFICATIONS	EL- 4
TROUBLE DIAGNOSES AND CORRECTIONS	EL- 5
SPECIAL SERVICE TOOL	EL- 5


NISSAN

NISSAN MOTOR CO., LTD.
TOKYO, JAPAN

ENGINE LUBRICATION SYSTEM

CONTENTS

LUBRICATION CIRCUIT	EL-2	INSPECTION	EL-3
OIL PUMP	EL-2	OIL PRESSURE REGULATOR VALVE	EL-3
REMOVAL	EL-2	OIL FILTER	EL-4
INSTALLATION	EL-2	OIL PRESSURE RELIEF VALVE	EL-4
DISASSEMBLY AND ASSEMBLY	EL-3		



EL072

Fig. EL-1 Lubricating circuit

From this gallery, oil holes go directly to all camshaft bearings through cam brackets.

Oil supplied through the No. 2 and No. 4 camshaft bearings is then fed to the rocker arm, valve and cam lobe through the oil gallery in the camshaft and the small hole at the base circle portion of each cam.

OIL PUMP

The oil pump is located in the bottom of the front cover attached by four bolts and driven by the oil pump drive spindle assembly which is driven by the helical gear on the crankshaft.


The oil pump assembly consists of an oil pressure regulator valve and outer and inner rotors.

The spring-loaded oil pressure regulator valve limits the oil pressure to a maximum of 5.6 kg/cm² (80 psi) at 3,000 rpm.

LUBRICATION CIRCUIT

The pressure lubrication of the engine is accomplished by a trochoid-type oil pump. This pump draws the oil through the oil strainer into the pump housing and then forces it through the full flow type oil filter into the main oil gallery. Part of the oil is supplied to all crankshaft bearings, the chain tensioner and the timing chain. Oil supplied to the crankshaft bearings is fed to the connecting rod bearings through the drilled passages in the crankshaft. Oil injected from jet holes on the connecting rods lubricates the cylinder walls and piston pins. The other part

of the oil is brought to the oil gallery in the cylinder head to provide lubrication of the valve mechanism and timing chain as shown in Figure EL-2.



EL069

Fig. EL-2 Lubricating cylinder head


REMOVAL

1. Remove distributor.
2. Remove splash shield board.
3. Remove oil pump body with drive spindle assembly.

INSTALLATION

1. Before installing oil pump in engine, turn crankshaft so that No. 1 piston is at T.D.C.
2. Fill pump housing with engine oil, then align punch mark of drive spindle with hole in oil pump as shown in Figure EL-3.


Engine Lubrication System



EL009


Fig. EL-3 Aligning punch mark and oil hole

3. Using a new gasket, install oil pump and drive spindle assembly so that the projection on its top is located in an 11 : 25 a.m. position. At this time, the smaller bow-shape will be placed toward the front as shown in Figure EL-4.



EL010

Fig. EL-4 Setting drive spindle



EL011

Fig. EL-5 Installing oil pump

Ascertain whether the engagement is in order or not by checking the top of spindle through distributor fitting hole.

4. Tighten bolts securing oil pump to front cover.

DISASSEMBLY AND ASSEMBLY


1. Remove pump cover attaching bolts, pump cover and oil pump gasket, and slide out pump rotors.

2. Remove regulator cap, regulator valve and spring.
3. Assemble oil pump in reverse order of disassembly.

Note:

The mark dotted on outer and inner rotor should face to oil pump body.

- 1 Oil pump body
- 2 Outer rotor
- 3 Inner rotor and shaft
- 4 Gasket
- 5 Oil pump cover
- 6 Regulator valve
- 7 Regulator spring



EL032

Fig. EL-6 Oil pump


INSPECTION

Wash all parts in cleaning solvent and dry with compressed air.

Use a brush to clean the inside of pump housing and pressure regulator valve chamber. Be sure all dirt and metal particles are removed.

1. Inspect pump body and cover for cracks or excessive wear.
2. Inspect pump rotors for damage or excessive wear.

3. Check inner rotor shaft for looseness in pump body.
4. Inspect regulator valve for wear or scoring.
5. Check regulator spring to see that it is not worn on its side or collapsed.
6. Using a feeler gauge, check tip clearance ② and outer rotor-to-body clearance ① shown in Figure EL-7.



EL059

- 1 Outer rotor to body clearance
- 2 Tip clearance
- 3 Gap between rotor and straight edge
- 4 Gap between body and straight edge

Fig. EL-7 Checking rotor clearances

7. Place a straight edge across the face of pump and depress it slightly as shown in Figure EL-7. Check gap ④ between body and straight edge or gap ③ between rotor and straight edge.

The gap should be -0.03 to 0.06 mm (-0.0012 to 0.0024 in), then rotor side clearance (rotor to bottom cover clearance) with gasket should satisfy the specifications.

	Standard	Wear limit
Rotor side clearance (rotor to bottom cover) mm (in)	0.04 to 0.08 (0.0016 to 0.0031)	0.20 (0.0079)
Rotor tip clearance ② mm (in)	Less than 0.12 (0.0047)	0.20 (0.0079)
Outer rotor to body clearance ① mm (in)	0.15 to 0.21 (0.0059 to 0.0083)	0.5 (0.0197)


Note:

Pump rotors and body are not serviced separately. If the oil pump body is damaged or worn, replace the entire oil pump assembly.

OIL PRESSURE REGULATOR VALVE

The oil pressure regulator valve is

not adjustable. At the released position, the valve permits the oil to by-pass through the passage in the pump cover to the inlet side of the pump. Check regulator valve spring to ensure that spring tension is correct.



EL014
Fig. EL-8 Regulator valve


placed periodically with the use of Oil Filter Wrench ST19320000. See Figure EL-9.

When removing an oil filter, loosen it after stopping engine about several minutes to drain out the oil from oil filter to oil pan.

When installing an oil filter, fasten it on cylinder block by hand.

Note:

Do not overtighten filter, or oil leakage may occur.




EL015
Fig. EL-9 Removing oil filter

OIL PRESSURE RELIEF VALVE

The relief valve located at the center portion securing oil filter in the cylinder block by-passes the oil into the main gallery when the oil filter element is excessively clogged.

With oil filter removed, check valve unit for operation. Inspect for a cracked or broken valve. If replacement is necessary, remove valve by prying it out with a screwdriver. Install a new valve in place by tapping it in.



EL061
Fig. EL-10 Relief valve

OIL FILTER

The oil filter is of a cartridge type. The oil filter element should be re-

SERVICE DATA AND SPECIFICATIONS

Oil pump

		Standard	Wear limit
Rotor side clearance (rotor to bottom cover)	mm (in)	0.04 to 0.08 (0.0016 to 0.0031)	0.20 (0.0079)
Rotor tip clearance	mm (in)	less than 0.12 (0.0047)	0.20 (0.0079)
Outer rotor to body clearance	mm (in)	0.15 to 0.21 (0.0059 to 0.0083)	0.5 (0.0197)

Oil pressure regulator valve

Regulator valve spring:

Free length	mm (in)	52.5 (2.067)
Installed length/load	mm/kg (in/lb)	34.8/7.9 to 8.7 (1.370/17.4 to 19.2)

Tightening torque:

Oil pump mounting bolts	kg-m (ft-lb)	1.1 to 1.5 (8 to 11)
Oil pump cover bolts	kg-m (ft-lb)	0.7 to 1.0 (5.1 to 7.2)
Regulator valve cap nut	kg-m (ft-lb)	4 to 5 (29 to 36)

TROUBLE DIAGNOSES AND CORRECTIONS

Condition	Probable causes	Corrective actions
Oil leakage	Damaged or cracked body cover. Oil leakage from gasket. Oil leakage from regulator valve. Oil leakage from blind plug.	Replace. Replace. Tighten or replace. Replace.
Decreased oil pressure	Leak of oil in engine oil pan. Dirty oil strainer. Damaged or worn pump rotors. Inoperative regulator. Use of poor quality engine oil.	Correct. Clean or replace. Replace. Replace. Replace.
Warning light remains "on" - engine running	Decreased oil pressure. Oil pressure switch unserviceable. Electrical fault.	Previously mentioned. Replace. Check circuit.
Noise	Excessive backlash in pump rotors.	Replace.

SPECIAL SERVICE TOOL

Tool number & tool name	Kent-Moore No.	Tool number & tool name	Kent-Moore No.
	Reference page or Fig. No.		Reference page or Fig. No.
ST19320000 Oil filter wrench	J 25664 Fig. EL-9		

