

SECTION HAC

HEATER & AIR CONDITIONING CONTROL SYSTEM

CONTENTS

AUTOMATIC AIR CONDITIONER	MODE DOOR CONTROL SYSTEM	32
BASIC INSPECTION	System Diagram	32
	System Description	32
DIAGNOSIS AND REPAIR WORKFLOW	AIR MIX DOOR CONTROL SYSTEM	34
Work Flow	System Diagram	34
	System Description	34
INSPECTION AND ADJUSTMENT	INTAKE DOOR CONTROL SYSTEM	36
Description & Inspection	System Diagram	36
	System Description	36
FUNCTION DIAGNOSIS	BLOWER MOTOR CONTROL SYSTEM	38
	System Diagram	38
COMPRESSOR CONTROL FUNCTION	System Description	38
Description		
Component Part Location	MAGNET CLUTCH CONTROL SYSTEM	40
Component Description	System Diagram	40
	System Description	40
AUTOMATIC AIR CONDITIONER SYSTEM	PTC HEATER CONTROL SYSTEM	41
System Diagram	System Diagram	41
System Description	System Description	41
Component Part Location	COMPONENT DIAGNOSIS	42
Component Description		
CAN COMMUNICATION SYSTEM	MODE DOOR MOTOR	42
System Description		
DIAGNOSIS SYSTEM (AUTO AMP.)	MR20DE/QR25DE	42
Diagnosis Description	MR20DE/QR25DE : Description	42
CONSULT-III Function	MR20DE/QR25DE : Component Function Check42
	MR20DE/QR25DE : Diagnosis Procedure	42
DIAGNOSIS SYSTEM (HVAC)	M9R	43
CONSULT-III Function (HVAC)	M9R : Description	44
	M9R : Component Function Check	44
DIAGNOSIS SYSTEM (BCM)	M9R : Diagnosis Procedure	44
	AIR MIX DOOR MOTOR	46
COMMON ITEM	MR20DE/QR25DE	46
COMMON ITEM : CONSULT-III Function (BCM -	MR20DE/QR25DE : Description	46
COMMON ITEM)		
AIR CONDITIONER		
AIR CONDITIONER : CONSULT-III Function		
(BCM - AUTO AIR CONDITIONER)		

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

MR20DE/QR25DE : Component Function Check	MR20DE/QR25DE : Diagnosis Procedure	79
MR20DE/QR25DE : Diagnosis Procedure	MR20DE/QR25DE : Component Inspection	81
M9R	M9R	81
M9R : Description	M9R : Description	81
M9R : Component Function Check	M9R : Component Function Check	82
M9R : Diagnosis Procedure	M9R : Diagnosis Procedure	82
M9R : Component Inspection	M9R : Component Inspection	83
INTAKE DOOR MOTOR	IN-VEHICLE SENSOR	84
MR20DE/QR25DE	MR20DE/QR25DE	84
MR20DE/QR25DE : Description	MR20DE/QR25DE : Description	84
MR20DE/QR25DE : Component Function Check	MR20DE/QR25DE : Component Function Check	85
MR20DE/QR25DE : Diagnosis Procedure	MR20DE/QR25DE : Diagnosis Procedure	85
MR20DE/QR25DE : Component Inspection	MR20DE/QR25DE : Component Inspection	86
M9R	M9R	86
M9R : Description	M9R : Description	86
M9R : Component Function Check	M9R : Component Function Check	87
M9R : Diagnosis Procedure	M9R : Diagnosis Procedure	87
M9R : Component Inspection	M9R : Component Inspection	89
BLOWER MOTOR	SUNLOAD SENSOR	90
MR20DE/QR25DE	MR20DE/QR25DE	90
MR20DE/QR25DE : Description	MR20DE/QR25DE : Description	90
MR20DE/QR25DE : Component Function Check	MR20DE/QR25DE : Component Function Check	90
MR20DE/QR25DE : Diagnosis Procedure	MR20DE/QR25DE : Diagnosis Procedure	90
MR20DE/QR25DE : Component Inspection	MR20DE/QR25DE : Component Inspection	92
M9R	M9R	92
M9R : Description	M9R : Description	92
M9R : Component Function Check	M9R : Component Function Check	93
M9R : Diagnosis Procedure	M9R : Diagnosis Procedure	93
M9R : Component Inspection	M9R : Component Inspection	95
MAGNET CLUTCH	INTAKE SENSOR	96
MR20DE/QR25DE	MR20DE/QR25DE	96
MR20DE/QR25DE : Description	MR20DE/QR25DE : Description	96
MR20DE/QR25DE : Component Function Check	MR20DE/QR25DE : Component Function Check	96
MR20DE/QR25DE : Diagnosis Procedure	MR20DE/QR25DE : Diagnosis Procedure	96
MR20DE/QR25DE : Component Inspection	MR20DE/QR25DE : Component Inspection	98
M9R	M9R	98
M9R : Description	M9R : Description	98
M9R : Component Function Check	M9R : Component Function Check	98
M9R : Diagnosis Procedure	M9R : Diagnosis Procedure	99
M9R : Component Inspection	M9R : Component Inspection	100
PTC HEATER	POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.	101
Description	MR20DE/QR25DE	101
Component Function Check	MR20DE/QR25DE : Description	101
Diagnosis Procedure	MR20DE/QR25DE : Component Function Check	101
Component Inspection	MR20DE/QR25DE : Diagnosis Procedure	102
OAT SENSOR	M9R	102
MR20DE/QR25DE		
MR20DE/QR25DE : Description		
MR20DE/QR25DE : Component Function Check		
MR20DE/QR25DE : Diagnosis Procedure		
MR20DE/QR25DE : Component Inspection		

M9R : Description	102	Description	180	
M9R : Component Function Check	103	Inspection procedure	180	A
M9R : Diagnosis Procedure	103			
ECU DIAGNOSIS	105	INSUFFICIENT HEATING	183	
ECM	105	Description	183	B
MR20DE	105	Inspection procedure	183	
MR20DE : Reference Value	105	NOISE	185	
QR25DE	115	Description	185	C
QR25DE : Reference Value	115	Inspection procedure	185	
M9R	124	SELF-DIAGNOSIS CANNOT BE PER- FORMED	187	
M9R : Reference Value	124	Description	187	D
BCM (BODY CONTROL MODULE)	141	Inspection procedure	187	E
Reference Value	141	PRECAUTION	188	
AUTO AMP.	158	PRECAUTIONS	188	
MR20DE/QR25DE	158	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	188	F
MR20DE/QR25DE : Reference Value	158	Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	188	G
MR20DE/QR25DE : Wiring Diagram — AIR CON- DITIONER CONTROL SYSTEM —	161	Precaution for Procedure without Cowl Top Cover.	189	
M9R	167	Precautions For Xenon Headlamp Service	189	H
M9R : Reference Value	167	Working with HFC-134a (R-134a)	189	
M9R : Wiring Diagram — AIR CONDITIONER CONTROL SYSTEM —	171	General Refrigerant Precaution	189	
SYMPTOM DIAGNOSIS	179	Refrigerant Connection	190	
AIR CONDITIONER CONTROL	179	Service Equipment	192	HAC
Diagnosis Chart By Symptom	179	COMPRESSOR	195	
INSUFFICIENT COOLING	180	General Precautions	195	J
		FLUORESCENT LEAK DETECTOR	196	
		General Precautions	196	K
				L
				M
				N
				O
				P

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001162136

DETAILED FLOW

1. LISTEN TO CUSTOMER COMPLAINT

Listen to customer complaint. (Get detailed information about the conditions and environment when the symptom occurs.)

>> GO TO 2.

2. VERIFY THE SYMPTOM WITH OPERATIONAL CHECK

Verify the symptom with operational check. Refer to [HAC-5, "Description & Inspection"](#).

>> GO TO 3.

3. GO TO APPROPRIATE TROUBLE DIAGNOSIS

Go to appropriate trouble diagnosis (Refer to [HAC-179, "Diagnosis Chart By Symptom"](#) below).

>> GO TO 4.

4. REPAIR OR REPLACE

Repair or replace the specific parts.

>> GO TO 5.

5. FINAL CHECK

Final check.

Is the inspection result normal?

YES >> CHECK OUT

NO >> GO TO 3.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[AUTOMATIC AIR CONDITIONER]

INSPECTION AND ADJUSTMENT

Description & Inspection

INFOID:000000001162137

DESCRIPTION

The purpose of the operational check is to check that the individual system operates normally.

Conditions : Engine running at normal operating temperature

INSPECTION PROCEDURE

Blower

1. Turn fan control dial to 1st speed. Blower should operate on low speed.
2. Turn fan control dial to 2nd speed, and continue checking blower speed until all speeds are checked.
3. Leave blower on max. speed.

If NG, go to trouble diagnosis procedure for [HAC-54, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-58, "M9R : Diagnosis Procedure"](#) (M9R).

If OK, continue the check.

Discharge Air

1. Turn mode control dial to each position.
2. Confirm that discharge air comes out according to the air distribution table. Refer to [HAC-13, "System Description"](#).

If NG, go to trouble diagnosis procedure for [HAC-42, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-44, "M9R : Diagnosis Procedure"](#) (M9R).

If OK, continue the check.

NOTE:

Confirm that the magnet clutch is engaged (sound or visual inspection) and intake door position is at FRE when the D/F or DEF is selected.

Mode door position	Air outlet/distribution		
	Vent	Foot	Defroster
	100%	-	-
	60%	40%	-
	18% (22%)	62% (78%)	20% (-)
	15%	40%	45%
	22%	-	78%

() : Manually control JPIIA0218GB

Intake Air

1. Press intake switch. Recirculation LED should illuminate.
2. Press intake switch again. Fresh LED should illuminate.
3. Listen for intake door position change. (Slight change of blower sound can be heard.)

If NG, go to trouble diagnosis procedure for [HAC-50, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-52, "M9R : Diagnosis Procedure"](#) (M9R).

If OK, continue the check.

NOTE:

Confirm that the magnet clutch is engaged (sound or visual inspection) and intake door position is at FRE when the D/F or DEF is selected.

Temperature Decrease

1. Turn temperature control dial counterclockwise until 16°C.
2. Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for [HAC-180, "Inspection procedure"](#).

If OK, continue the check.

Temperature Increase

1. Turn temperature control dial clockwise until 28°C.
2. Check for warm air at discharge air outlets.

If NG, go to trouble diagnosis procedure for [HAC-183, "Inspection procedure"](#).

If OK, continue the check.

A/C Switch

1. Turn fan control dial to AUTO position.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[AUTOMATIC AIR CONDITIONER]

2. Press A/C switch. A/C switch LED should illuminate.
 - Confirm that the magnet clutch engages (sound or visual inspection). (Discharge air and blower speed depend on ambient, in-vehicle, and set temperatures.)

If NG, go to trouble diagnosis procedure for [HAC-102, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-103, "M9R : Diagnosis Procedure"](#) (M9R), then if necessary, trouble diagnosis procedure for [HAC-62, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-66, "M9R : Diagnosis Procedure"](#) (M9R).

Go to Incident Simulation Tests in [GI-38, "Work Flow"](#) and perform tests as outlined to simulate driving conditions environment if all operational checks are OK (symptom cannot be duplicated). Refer to [HAC-179, "Diagnosis Chart By Symptom"](#) and perform applicable trouble diagnosis procedures if symptom appears.

AUXILIARY MECHANISM

Temperature Setting Trimmer

The trimmer compensates for differences in range of $\pm 3^{\circ}\text{C}$ between temperature setting (temperature control dial position) and temperature felt by customer.

Operating procedures for this trimmer are as per the following:

1. Set fan control dial to OFF.
2. Turn ignition switch ON.
3. Set in self-diagnosis mode as per the following. Press intake switch for at least 5 seconds within 10 seconds after starting engine (ignition switch is turned ON.).
4. When intake switch is pressed, temperature shifts in following order: $0^{\circ}\text{C} \rightarrow 1^{\circ}\text{C} \rightarrow 2^{\circ}\text{C} \rightarrow 3^{\circ}\text{C} \rightarrow -3^{\circ}\text{C} \rightarrow -2^{\circ}\text{C} \rightarrow -1^{\circ}\text{C} \rightarrow$ return to 0°C .

Setting temperature	LED status of each switch		
	FRE	REC	A/C
3°C	OFF	ON	ON
2°C	OFF	ON	OFF
1°C	OFF	OFF	ON
0°C (Initial setting)	OFF	OFF	OFF
-1°C	ON	OFF	ON
-2°C	ON	ON	OFF
-3°C	ON	ON	ON

NOTE:

When battery cable is disconnected or battery voltage is below 9 V, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C .

Inlet Port Memory Function

When ignition switch is turned from OFF to ON, inlet port can be set to AUTO or manual.

Operating procedures for this trimmer are as per the following:

1. Set fan control dial to OFF.
2. Turn ignition switch ON.
3. Set in self-diagnosis mode as per the following. Press intake switch for at least 5 seconds within 10 seconds after starting engine (ignition switch is turned ON.).
4. Set fan control dial to 1st - 12th speed.
5. Press intake switch as desired.

LED status of FRE switch	LED status of REC switch	Setting status		Setting changeover method
		FRE	REC	
OFF	ON	AUTO control (Initial setting)	Manual REC status is memorized. (Initial setting)	Intake switch: ON
ON	ON	Manual FRE status is memorized.	Manual REC status is memorized.	
ON	OFF	Manual FRE status is memorized.	AUTO control	
OFF	OFF	AUTO control	AUTO control	

NOTE:

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[AUTOMATIC AIR CONDITIONER]

When battery cable is disconnected or battery voltage is below 9 V, memory function is canceled. Memory function set becomes that of initial condition.

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

COMPRESSOR CONTROL FUNCTION

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

FUNCTION DIAGNOSIS

COMPRESSOR CONTROL FUNCTION


Description

INFOID:000000001162138

PRINCIPLE OF OPERATION

Compressor is not activated.

Functional circuit diagram



- L (1) : Fan SW signal
- L (2) : A/C SW signal
- S (1) : Fan ON signal
- S (2) : A/C SW signal
- S (3) : Defogger signal
- CAN (1) : A/C signal
- CAN (2) : Compressor request signal

Functional initial inspection chart

Location		A	B	C	D	E	F
CONSULT-III	ECM DATA MONITOR				Yes	Yes	
	BCM DATA MONITOR		Yes	Yes			
	IPDM E/R DATA MONITOR					Yes	
AUTO ACTIVE TEST							Yes
Self-diagnosis function (except CAN diagnosis)		Yes	Yes				

Component Part Location

INFOID:000000001162139


ENGINE COMPARTMENT

COMPRESSOR CONTROL FUNCTION

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P



1. Refrigerant pressure sensor

2. Compressor

3. OAT sensor

PASSENGER COMPARTMENT


LHD Models

JPIIA0186ZZ

COMPRESSOR CONTROL FUNCTION

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



JPIIA0187ZZ


- | | | |
|-----------------------|---------------------------------|--------------------|
| 1. Air mix door motor | 2. Intake door motor | 3. Mode door motor |
| 4. Blower motor | 5. Fan control amp. | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. PTC heater (With M9R engine) | 9. Auto amp. |
| 10. Intake sensor | | |

RHD Models

COMPRESSOR CONTROL FUNCTION

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



- | | | |
|---------------------------------|----------------------|-----------------------|
| 1. Sunload sensor | 2. Intake door motor | 3. Air mix door motor |
| 4. Mode door motor | 5. Blower motor | 6. Fan control amp. |
| 7. PTC heater (With M9R engine) | 8. Auto amp. | 9. Intake sensor |
| 10. In-vehicle sensor | | |

JSIIA0426ZZ

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

COMPRESSOR CONTROL FUNCTION

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Component Description

INFOID:000000001162140

Component	Reference
Air mix door motor	HAC-46, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-47, "M9R : Description" (M9R)
Auto amp.	HAC-101, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-102, "M9R : Description" (M9R)
Blower motor	HAC-54, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-58, "M9R : Description" (M9R)
Compressor	HAC-62, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-66, "M9R : Description" (M9R)
Fan control amp.	HAC-57, "MR20DE/QR25DE : Component Inspection" (MR20DE/QR25DE) or HAC-61, "M9R : Component Inspection" (M9R)
Intake door motor	HAC-50, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-51, "M9R : Description" (M9R)
Intake sensor	HAC-96, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-98, "M9R : Description" (M9R)
In-vehicle sensor	HAC-84, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-86, "M9R : Description" (M9R)
Mode door motor	HAC-42, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-44, "M9R : Description" (M9R)
OAT sensor	HAC-79, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-81, "M9R : Description" (M9R)
PTC heater	HAC-77, "Component Inspection"
Refrigerant pressure sensor	HAC-65, "MR20DE/QR25DE : Component Inspection" (MR20DE/QR25DE) or HAC-70, "M9R : Component Inspection" (M9R)
Sunload sensor	HAC-90, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-92, "M9R : Description" (M9R)

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]


AUTOMATIC AIR CONDITIONER SYSTEM

System Diagram

INFOID:000000001162141

CONTROL SYSTEM

The control system consists of input sensors, switches, auto amp. (microcomputer) and outputs. The relationship of these components is as shown in the figure below:



System Description

INFOID:000000001162142

CONTROL OPERATION


Controller

AUTOMATIC AIR CONDITIONER SYSTEM


< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

LHD models



RHD models



1. Fan Control Dial

The blower speed is automatically or manually controlled with this dial. Twenty-five speeds are available for manual control.

2. Temperature Control Dial (Potentio Temperature Control)

The set temperature is increased or decreased with this dial.

3. MODE Control Dial

The air discharge outlets is controlled with by this dial.

Mode doors are set to the defrost position with this dial. Also, intake doors are set to the outside air position. When shifting mode control dial to DEF (and D/F or D/F2: LHD models only) position under the following conditions, compressor is turned ON. (A/C LED ON)

- FAN: ON
- A/C: OFF

4. Rear Window Defogger Switch

When illumination is ON, rear window is defogged.

5. Intake Switch

- When intake switch is ON, FRE LED turns ON, and air inlet is fixed to FRE.
- When intake switch is pressed again, REC LED turns ON, and air inlet is fixed to REC.
- When intake switch is pressed for approximately 1.5 seconds or longer, REC and FRE LEDs blink twice. Then, automatic control mode is entered. Inlet status is displayed even during automatic control.

AUTOMATIC AIR CONDITIONER SYSTEM

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >


- Intake switch is automatically fixed to FRE mode when mode control dial is turned in DEF (and D/F or D/F2: LHD models only), or when compressor is turned from ON to OFF. Press intake switch to enter REC mode.

6. A/C Switch

Compressor is ON or OFF with this switch.

(Pressing the A/C switch when the fan control dial is ON turns OFF the A/C switch and compressor.)

DISCHARGE AIR FLOW



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


HAC

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

SWITCHES AND THEIR CONTROL FUNCTION



JPIIA0221GB

Position or switch	MODE control dial								Intake SW		Temperature control dial				
	VENT	B/L	FOOT	FOOT2	D/F	D/F2	DEF	AUTO				16°C	↔	28°C	
Door				—		—		—				16°C	↔	28°C	
Ventilator door	(A)	(B)	(C)	(C)	(C)	(C)	(C)	AUTO	—	—	—	—	—	—	
Foot door	(A)	(B)	(C)	(B)	(C)	(B)	(A)		—	—	—	—	—	—	—
Defroster door	(A)	(A)	(A) or (B) ^{*1}	(B-C)	(C)	(C-D)	(D)		—	—	—	—	—	—	—
Intake door	—							(B)	—	(A) ^{*2} AUTO	(B) ^{*2} AUTO	—			
Air mix door	—							—	AUTO	—		(A)	AUTO	(B)	

*1: This door position is selected only when the mode door is automatically controlled.


*2: Inlet status is displayed during automatic control.

JPIIA0222GB

AIR CONDITIONER LAN CONTROL SYSTEM

The LAN (Local Area Network) system consists of auto amp., mode door motor, air mix door motor and intake door motor.

A configuration of these components is as shown in the figure below.



JPIIA0060GB

AUTOMATIC AIR CONDITIONER SYSTEM

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >


SYSTEM CONSTRUCTION

A small network is constructed between the auto amp., mode door motor, air mix door motor and intake door motor. The auto amp. and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of each door motor.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the auto amp. and each door motor.

The following functions are contained in LCUs built into the mode door motor, the air mix door motor and the intake door motor.


- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (Auto amp. indicated value and motor opening angle comparison)



Operation

The auto amp. receives data from each of the sensors. The auto amp. sends mode door, air mix door and intake door opening angle data to the mode door motor LCU, air mix door motor LCU and intake door motor LCU.

The mode door motor, air mix door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors is compared by the LCUs in each door motor with the existing decision and opening angles. Subsequently, HOT/COLD, DEF/VENT and FRE/REC operation is selected. The new selection data is returned to the auto amp.



Transmission Data and Transmission Order

Auto amp. data is transmitted consecutively to each of the doors motor following the form as shown in the figure below.

START:

- Initial compulsory signal is sent to each of the door motors.

ADDRESS:

- Data sent from the auto amp. are selected according to data-based decisions made by the mode door motor, air mix door motor and intake door motor.
- If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data have no error, door control begins.
- If an error exists, the received data are rejected and corrected data received. Finally, door control is based upon the corrected opening angle data.

AUTOMATIC AIR CONDITIONER SYSTEM

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

OPENING ANGLE:


- Data that shows the indicated door opening angle of each door motor.

ERROR CHECK:

- In this procedure, transmitted and received data is checked for errors. Error data are then compiled. The error check prevents corrupted data from being used by the mode door motor, the air mix door motor and the intake door motor. Error data can be related to the following symptoms.
 - Malfunction of electrical frequency
 - Poor electrical connections
 - Signal leakage from transmission lines
 - Signal level fluctuation

STOP SIGNAL:

- At the end of each transmission, a stop operation, in-operation, or internal malfunction message is delivered to the auto amp. This completes one data transmission and control cycle.



Component Part Location

INFOID:000000001301477


ENGINE COMPARTMENT

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P



1. Refrigerant pressure sensor

2. Compressor

3. OAT sensor

PASSENGER COMPARTMENT


LHD Models

JPIIA0186ZZ

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



JPIIA0187ZZ

- | | | |
|-----------------------|---------------------------------|--------------------|
| 1. Air mix door motor | 2. Intake door motor | 3. Mode door motor |
| 4. Blower motor | 5. Fan control amp. | 6. Sunload sensor |
| 7. In-vehicle sensor | 8. PTC heater (With M9R engine) | 9. Auto amp. |
| 10. Intake sensor | | |


RHD Models

HAC-20

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

- | | | |
|---------------------------------|----------------------|-----------------------|
| 1. Sunload sensor | 2. Intake door motor | 3. Air mix door motor |
| 4. Mode door motor | 5. Blower motor | 6. Fan control amp. |
| 7. PTC heater (With M9R engine) | 8. Auto amp. | 9. Intake sensor |
| 10. In-vehicle sensor | | |

JSIIA0426ZZ

AUTOMATIC AIR CONDITIONER SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Component Description

INFOID:000000001301478

Component	Reference
Air mix door motor	HAC-46, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-47, "M9R : Description" (M9R)
Auto amp.	HAC-101, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-102, "M9R : Description" (M9R)
Blower motor	HAC-54, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-58, "M9R : Description" (M9R)
Compressor	HAC-62, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-66, "M9R : Description" (M9R)
Fan control amp.	HAC-57, "MR20DE/QR25DE : Component Inspection" (MR20DE/QR25DE) or HAC-61, "M9R : Component Inspection" (M9R)
Intake door motor	HAC-50, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-51, "M9R : Description" (M9R)
Intake sensor	HAC-96, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-98, "M9R : Description" (M9R)
In-vehicle sensor	HAC-84, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-86, "M9R : Description" (M9R)
Mode door motor	HAC-42, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-44, "M9R : Description" (M9R)
OAT sensor	HAC-79, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-81, "M9R : Description" (M9R)
PTC heater	HAC-77, "Component Inspection"
Refrigerant pressure sensor	HAC-65, "MR20DE/QR25DE : Component Inspection" (MR20DE/QR25DE) or HAC-70, "M9R : Component Inspection" (M9R)
Sunload sensor	HAC-90, "MR20DE/QR25DE : Description" (MR20DE/QR25DE) or HAC-92, "M9R : Description" (M9R)

CAN COMMUNICATION SYSTEM

System Description

INFOID:000000001162145

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. For details, refer to [LAN-21, "CAN System Specification Chart"](#).

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

DIAGNOSIS SYSTEM (AUTO AMP.)

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (AUTO AMP.)

Diagnosis Description

INFOID:000000001246518

SELF-DIAGNOSIS SYSTEM


The self-diagnosis system is built into the auto amp. to quickly locate the cause of malfunctions.

SELF-DIAGNOSIS FUNCTION

The self-diagnosis system diagnoses sensors, door motors, blower motor, etc. by system line.

- Switching to self-diagnosis STEP-1 to 4.

Shifting from normal control to the self-diagnosis system is accomplished by starting the engine (turning the ignition switch from OFF to ON) and pressing A/C switch for at least 5 seconds. The A/C switch must be pressed within 10 seconds after starting the engine (ignition switch is turned ON). This system is canceled by either pressing intake switch or turning the ignition switch OFF. Shifting to the next step is accomplished by means of turning fan control dial, as required.



JS1IA0446GB

FUNCTION CONFIRMATION PROCEDURE

1. SET IN SELF-DIAGNOSIS MODE

1. Set the fan control dial to OFF position.
2. Turn ignition switch ON.
3. Set in self-diagnosis mode as per the following. Press A/C switch for at least 5 seconds within 10 seconds after starting engine (ignition switch is turned ON.).

CAUTION:

DIAGNOSIS SYSTEM (AUTO AMP.)

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

If battery voltage drops below 12 V during diagnosis STEP-3, door motor speed becomes slower and as a result, the system may generate an error even when operation is normal. Start engine before performing this diagnosis to avoid this.

>> GO TO 2.


2. STEP-1: LEDS ARE CHECKED

Check LEDs illumination.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Malfunctioning fan control dial or auto amp. Refer to [HAC-187, "Inspection procedure"](#).



3. STEP-2: SENSOR CIRCUITS ARE CHECKED FOR OPEN OR SHORT CIRCUIT

1. Turn mode control dial to AUTO position.
2. Turn fan control dial to AUTO position.

CAUTION:


When switched to STEP-2, LED of REC position blinks for approximately 25 seconds.

3. Check A/C switch LED illumination.

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 7.



4. STEP-3: MODE DOOR AND INTAKE DOOR POSITIONS ARE CHECKED

1. Turn fan control dial to 1st - 12th speed.

CAUTION:


When switched to STEP-3, LED of REC position blinks for approximately 50 seconds.

2. Check A/C switch LED illumination.

Is the inspection result normal?

YES >> GO TO 5.


NO >> GO TO 8.



5. STEP-4: OPERATION OF EACH ACTUATOR IS CHECKED

1. Turn fan control dial to 13th - 25th speed.
2. Change operation status of air conditioner by changing mode control dial position.

>> GO TO 6.



6. CHECK ACTUATORS

DIAGNOSIS SYSTEM (AUTO AMP.)

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

Refer to the following chart and confirm discharge air flow, air temperature, blower motor voltage and compressor operation.

Discharge air flow			
Mode door position	Air outlet/distribution		
	Vent	Foot	Defroster
	100%	-	-
	60%	40%	-
	18% (22%)	62% (78%)	20% (-)
	15%	40%	45%
	22%	-	78%

() : Manually control JPIIA0218GB

STEP-No.*	STEP-41	STEP-42	STEP-43	STEP-44	STEP-45	STEP-46
Mode control dial position	AUTO	VENT	B/L	FOOT	D/F	DEF
Mode door position	VENT	VENT	B/L	FOOT*2	D/F	DEF
Intake door position	REC	REC	REC	FRE	FRE	FRE
Air mix door position	FULL COLD	FULL COLD	FULL COLD	FULL HOT	FULL HOT	FULL HOT
Blower motor voltage	Approx. 4.5 V	Approx. 10.5 V	Approx. 8.5 V	Approx. 8.5 V	Approx. 8.5 V	Approx. 12 V
Compressor	ON	ON	OFF	OFF	ON	ON

Checks must be made visually, by listening to any noise, or by touching air outlets with hand, etc. for improper operation.

*: STEP-Nos. 41 to 46 are for differentiation and they are not displayed.

Is the inspection result normal?

YES >> 1. Turn ignition switch OFF or intake switch ON.
2. INSPECTION END


- NO >>
- Air outlet does not change.
Go to Mode Door Motor Circuit. Refer to [HAC-42. "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-44. "M9R : Diagnosis Procedure"](#) (M9R).
 - Intake door does not change.
Go to Intake Door Motor Circuit. Refer to [HAC-50. "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-52. "M9R : Diagnosis Procedure"](#) (M9R).
 - Discharge air temperature does not change.
Go to Air Mix Door Motor Circuit. Refer to [HAC-46. "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-48. "M9R : Diagnosis Procedure"](#) (M9R).
 - Blower motor operation is malfunctioning.
Go to Blower Motor Circuit. Refer to [HAC-54. "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-58. "M9R : Diagnosis Procedure"](#) (M9R).
 - Magnet clutch does not engage.
Go to Magnet Clutch Circuit. Refer to [HAC-62. "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-66. "M9R : Diagnosis Procedure"](#) (M9R).

7. CHECK MALFUNCTIONING SENSOR

Refer to the following chart.

CAUTION:

When switched to STEP-2, LED of REC position blinks for approximately 25 seconds.



DIAGNOSIS SYSTEM (AUTO AMP.)

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

Mode control dial position	Unusual	Malfunctioning sensor or motor (Including circuits)	Reference
VENT	A/C LED: OFF	OAT sensor	*2
B/L		In-vehicle sensor	*3
FOOT		Sunload sensor *1	*4
D/F		Intake sensor	*5
DEF		Air mix door motor (LCU) PBR	*6

*1: Perform self-diagnosis STEP-2 under sunshine.

When performing indoors, aim a light (more than 60 W) at sunload sensor, otherwise LED of A/C switch does not indicate despite that sunload sensor is functioning normally.

*2: [HAC-79, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-82, "M9R : Diagnosis Procedure"](#) (M9R).

*3: [HAC-85, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-87, "M9R : Diagnosis Procedure"](#) (M9R).

*4: [HAC-90, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-93, "M9R : Diagnosis Procedure"](#) (M9R).

*5: [HAC-96, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-99, "M9R : Diagnosis Procedure"](#) (M9R).

*6: [HAC-46, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-48, "M9R : Diagnosis Procedure"](#) (M9R).

>> INSPECTION END

8. CHECK MALFUNCTIONING DOOR MOTOR POSITION SWITCH

Mode and/or intake door motor PBR (s) is/are malfunctioning.


CAUTION:

When switched to STEP-3, LED of REC position blinks for approximately 50 seconds.

Unusual	Mode or intake door position	Reference
REC LED: ON	Mode door motor	*1
FRE LED: ON	Intake door motor	*2

*1: [HAC-42, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-44, "M9R : Diagnosis Procedure"](#) (M9R).

*2: [HAC-50, "MR20DE/QR25DE : Diagnosis Procedure"](#) (MR20DE/QR25DE) or [HAC-52, "M9R : Diagnosis Procedure"](#) (M9R).



>> INSPECTION END

CONSULT-III Function

INFOID:000000001162147

CONSULT-III APPLICATION ITEMS

CONSULT-III can display each diagnosis item using the diagnosis test modes shown as per the following.

System part	Check item, diagnosis mode	Description
ECM	Data monitor	Displays ECM input data in real time.
BCM	Data monitor	Displays BCM input data in real time.

DATA MONITOR

Display Item List (ECM)

DIAGNOSIS SYSTEM (AUTO AMP.)

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

With Gasoline Engine

Monitor Item	Condition	Value/Status
AC PRESS SEN	<ul style="list-style-type: none"> • Engine is running • Warm-up condition • Both A/C switch and blower fan motor switch: ON (Compressor operates.) 	1.0 - 4.0 V

With Diesel Engine

Monitor Item	Condition	Value/Status
RFRGERNT PRSS	<ul style="list-style-type: none"> • Engine is running • Warm-up condition • Air conditioner switch: OFF • Shift lever: Neutral position • No load 	Approx. 5.7 bar

Display Item List (BCM)

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF → ON	Off → On
FAN ON SIG	Ignition switch ON	Blower fan motor switch ON
		Blower fan motor switch OFF
AIR COND SW	Ignition switch ON	Compressor ON
		Compressor OFF

DIAGNOSIS SYSTEM (HVAC)

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

DIAGNOSIS SYSTEM (HVAC)

CONSULT-III Function (HVAC)

INFOID:000000001283125

APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with auto amp.

Diagnosis mode	Function Description
DATA MONITOR	The auto amp. input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from auto amp.

SYSTEM APPLICATION

HVAC can perform the following functions for each system.

DATA MONITOR

Display Item List

Monitor Item [Unit]	Description
ELEC PWR CUT [OFF/FREEZ/INHBT]	Displays [OFF/FREEZ/INHBT] condition of the PTC heater states.
FAN ON SIG [On/Off]	Displays [FAN (ON)/FAN (OFF)] status as judged from blower fan motor signal.
ENGINE STATUS [STOP/STALL/RUN/CRA]	Displays [STOP/STALL/RUN/CRA] condition of the engine states.
ENG COOLNT T [°C]	The engine coolant temperature (judged by the signal voltage of the engine coolant temperature sensor) is displayed.
BATTERY VOLT [V]	The power supply voltage of BCM is displayed.
ENGINE RPM [rpm]	Displays the engine speed calculated from the signal of the crankshaft position sensor.
OUTSIDE TEMP [°C]	The outside air temperature (judged by the signal voltage of the OAT sensor) is displayed.

ACTIVE TEST

Test item

Test Item	Operation	Description
PTC HEATER	OFF PTC 1 PTC 2 PTC 3	This test is able to check PTC heater operation.

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000001403986

APPLICATION ITEM

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis mode	Function description
ECU Identification	BCM part number is displayed.
Self-Diagnostic Results	Displays the diagnosis results judged by BCM. Refer to BCS-65. "DTC Index" .
Data Monitor	BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Work Support	Changes the setting for each system function.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	CONSULT-III sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
—	BCM	×		
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER	×	×	×
Warning chime	BUZZER		×	×
Interior room lamp control	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
Air conditioner	AIR CONDITONER		×	
Intelligent Key system	INTELLIGENT KEY		×	
Combination switch	COMB SW		×	
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
Signal buffer system	SIGNAL BUFFER		×	×
—	PTC HEATER*			

*: This item is displayed, but is not function.

AIR CONDITIONER

AIR CONDITIONER : CONSULT-III Function (BCM - AUTO AIR CONDITIONER)

INFOID:000000001162149

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Display Item List

Monitor Item [Unit]		Contents
IGN SW	[On/Off]	Displays [ignition switch position (On)/(Off), ACC position (Off)] status as judged form ignition switch signal.
FAN ON SIG	[On/Off]	Displays [FAN (On)/FAN (Off)] status as judged form blower fan motor switch signal.
AIR COND SW	[On/Off]	Displays [COMP (On)/COMP (Off)] status as judged form air conditioner switch signal.

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P


MODE DOOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MODE DOOR CONTROL SYSTEM

System Diagram



System Description


INFOID:000000001162151

The mode door is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

SYSTEM OPERATION

- The auto amp. receives data from each of the sensors.
- The auto amp. sends air mix door, mode door and intake door opening angle data to the air mix door LCU, mode door motor LCU and intake door motor LCU.
- The air mix door motor, mode door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Subsequently, HOT/COLD, DEF/VENT and FRE/REC operation is selected. The new selection data are returned to the auto amp.

Door Motor Circuit




Mode Door Control Specification

MODE DOOR CONTROL SYSTEM

[AUTOMATIC AIR CONDITIONER]

< FUNCTION DIAGNOSIS >

The mode position (auto-control or manual control) can be selected by mode control dial of the controller. Under automatic control, a mode door position (VENT, B/L, FOOT, or D/F) is selected depending on the (wind/air) temperature calculated by auto amp. based on a target air mix door opening angle and sunload. Also, D/F is selected to prevent windshield fogging especially when ambient temperature is extremely low with mode position FOOT.



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AIR MIX DOOR CONTROL SYSTEM


< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

AIR MIX DOOR CONTROL SYSTEM

System Diagram

INFOID:000000001307365



JPIIA0206GB

System Description


INFOID:000000001162153

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a preset value by the temperature setting, ambient temperature, intake temperature, in-vehicle temperature and amount of sunload.

SYSTEM OPERATION

- The auto amp. receives data from each of the sensors.
- The auto amp. sends air mix door, mode door and intake door opening angle data to the air mix door motor LCU, mode door motor LCU and intake door motor LCU.
- The air mix door motor, mode door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Subsequently, HOT/COLD, DEF/VENT and FRE/REC operation is selected. The new selection data are returned to the auto amp.

Door Motor Circuit



JSIIA0443GB


Air Mix Door Control Specification

AIR MIX DOOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

When ignition switch is ON, auto amp. continuously and automatically controls temperatures regardless of air conditioner operational condition. When setting a target temperature with temperature control dial, auto amp. corrects the set temperature and decides a target air mix door opening angle. Auto amp. controls air mix door according to the target air mix door opening angle and current air mix door opening angle for keeping an optimum air mix door opening angle. When a temperature is set at 16°C, air mix door is fixed at full cold, and when a temperature is set at 28°C, it is set at full hot.



- A
- B
- C
- D
- E
- F
- G
- H
- J
- K
- L
- M
- N
- O
- P

HAC


INTAKE DOOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

INTAKE DOOR CONTROL SYSTEM

System Diagram



System Description


INFOID:000000001162154

The intake doors are automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON/OFF operation of the compressor.

SYSTEM OPERATION

- The auto amp. receives data from each of the sensors.
- The auto amp. sends air mix door, mode door and intake door opening angle data to the air mix door LCU, mode door motor LCU and intake door motor LCU.
- The air mix door motor, mode door motor and intake door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amp. and each of the motor position sensors are compared by the LCUs in each door motor with the existing decision and opening angles.
- Subsequently, HOT/COLD, DEF/VENT and FRE/REC operation is selected. The new selection data are returned to the auto amp.
- The intake door control judges intake door position based on the ambient temperature, the intake air temperature and the in-vehicle temperature. When setting mode control dial to DEF (and D/F or D/F2: LHD models only) position, fan control dial OFF position, the auto amp. sets the intake door at the FRE position.

Door Motor Circuit



Intake Door Control Specification


INTAKE DOOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Intake door position is basically fixed at FRE when FRE LED of intake switch turn ON or mode control dial to DEF position, and fixed at REC when REC LED of intake switch turns ON.

Intake door automatic control selects FRE, 20%FRE, or REC depending on a target air mix door opening angle, based on in-vehicle temperature, ambient temperature, and sunload.



A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P


BLOWER MOTOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

BLOWER MOTOR CONTROL SYSTEM

System Diagram



System Description

INFOID:000000001162155

Blower speed is automatically controlled by the temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.

With shifting fan control dial to AUTO, the blower motor starts to increase gradually air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

SYSTEM OPERATION

Automatic Mode

In the automatic mode, the blower motor speed is calculated by the auto amp. based on the input from the PBR, in-vehicle sensor, sunload sensor, intake sensor and OAT sensor.

The blower motor applied voltage ranges from approximately 4 V (lowest speed) to 12 V (highest speed).

The control blower speed (in the range of 4 to 12 V), auto amp. supplies a gate voltage to the fan control amp. Based on this voltage, fan control amp. control voltage supplied to the blower motor.

Starting Fan Speed Control

Start up from COLD SOAK Condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 56°C (133°F), the blower does not operate for a short period of time (up to 150 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient temperature) the blower start delay is 150 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 56°C (133°F), and then the blower speed increases to the objective speed.

Start up from usual or HOT SOAK Condition (Automatic mode)

The blower will begin operation momentarily after the AUTO switch is pressed. The blower speed rises gradually to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).

Blower Speed Compensation

Sunload


When the in-vehicle temperature and the set temperature are very close, the blower operates at low speed. The low speed varies depending on the sunload. During conditions of low or no sunload, the blower speed is low (approximately 4 V). During high sunload conditions, the auto amp. raise the blower speed (approximately 4.5 V).

BLOWER MOTOR CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Fan Speed Control Specification



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MAGNET CLUTCH CONTROL SYSTEM


< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MAGNET CLUTCH CONTROL SYSTEM

System Diagram

INFOID:000000001307755



System Description

INFOID:000000001162156

Auto amp. controls compressor operation by ambient temperature, intake air temperature and signal from ECM.

SYSTEM OPERATION

Turn fan control dial to ON or set mode control dial to DEF (and D/F or D/F2: LHD models only) position when A/C switch is pressed, auto amp. transmits compressor ON signal to BCM.

BCM sends compressor ON signal to ECM, via CAN communication.

ECM judges whether compressor can be turned ON, based on each sensor status (refrigerant-pressure sensor signal, throttle angle, etc.). If it judges compressor can be turned ON, it sends compressor ON signal to IPDM E/R, via CAN communication.

Upon receipt of compressor ON signal from ECM, IPDM E/R turns air conditioner relay ON to operate compressor.

When sending compressor ON signal to IPDM E/R via CAN communication, ECM simultaneously sends compressor feedback signal to auto amp. via CAN communication.

Auto amp., then, uses input compressor feedback signal to control air inlet.


Compressor Protection Control

When the high-pressure side detected by the refrigerant pressure sensor is either approximately 2.74 MPa (approximately 27.9 kg/cm²·G) or more, or approximately 0.14 MPa (approximately 1.4 kg/cm²·G) or less, ECM turns the A/C relay OFF and stops the compressor.

Low Temperature Protection Control

Auto amp. turns compressor ON or OFF as judged by a signal detected by OAT sensor and intake sensor.

When ambient temperature is higher than 3°C (37°F), the compressor turns ON. The compressor turns OFF when ambient temperature is lower than 0°C (32°F).




PTC HEATER CONTROL SYSTEM

< FUNCTION DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

PTC HEATER CONTROL SYSTEM

System Diagram



System Description

INFOID:000000001162157

Auto amp. controls PTC (Positive Temperature Coefficient) heater correspond to fan ON signal, ambient temperature, engine coolant temperature, engine speed, engine status, electrical power cut freeze signal and battery voltage.

Auto amp. judges whether PTC can be turned ON, based on each sensor status (ambient temperature, engine speed, engine coolant temperature, etc.).

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

COMPONENT DIAGNOSIS

MODE DOOR MOTOR

MR20DE/QR25DE

MR20DE/QR25DE : Description


INFOID:000000001162158

COMPONENT DESCRIPTION

Mode Door Motor

The mode door motor (1) is attached to the A/C unit assembly. It rotates so that air is discharged from the outlet set by the auto amp. Motor rotation is conveyed to a link which activates the mode door.

←: Vehicle front



MR20DE/QR25DE : Component Function Check

INFOID:000000001162159

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn mode control dial to each position.
2. Confirm that discharge air comes out according to the air distribution table at below. Refer to [HAC-13, "System Description"](#).

NOTE:

Confirm that the magnet clutch is engaged (Sound or visual inspection) and intake door position is at FRE when DEF or D/F is selected.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-42, "MR20DE/QR25DE : Diagnosis Procedure"](#).

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162160

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2. PERFORM SELF-DIAGNOSIS STEP-3

Perform self-diagnosis STEP-3. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 4.

Is the inspection result normal?

YES >> GO TO 6.

NO-1 >> REC LED ON: GO TO 3.

NO-2 >> FRE LED ON: Go to Intake Door Motor Circuit. Refer to [HAC-50, "MR20DE/QR25DE : Diagnosis Procedure"](#).

3. CHECK POWER SUPPLY FOR MODE DOOR MOTOR

Check voltage between mode door motor harness connector M310 terminal 1 and ground.

MODE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4.CHECK SIGNAL FOR MODE DOOR MOTOR

Confirm A/C LAN signal between mode door motor harness connector M310 terminal 2 and ground using an oscilloscope.

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	2	Ground	 <p style="text-align: right; font-size: small;">SJIA1453J</p>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK MODE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor connector.
3. Check continuity between mode door motor harness connector M310 terminal 3 and ground.

Mode door motor		—	Continuity
Connector	Terminal		
M310	3	Ground	Existed

Is the inspection result normal?

YES >> Replace mode door motor.

NO >> Repair harness or connector.

6.PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 7.

7.CHECK MODE DOOR CONTROL LINKAGE

Check mode door control linkage.

Is it installed normally?

YES >> Refer to [VTL-25, "Exploded View"](#) (LHD models) or [VTL-71, "Exploded View"](#) (RHD models).

NO >> Repair or adjust control linkage.

M9R

MODE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

M9R : Description


INFOID:000000001303620

COMPONENT DESCRIPTION

Mode Door Motor

The mode door motor (1) is attached to the A/C unit assembly. It rotates so that air is discharged from the outlet set by the auto amp. Motor rotation is conveyed to a link which activates the mode door.

←: Vehicle front



M9R : Component Function Check

INFOID:000000001303618

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn mode control dial to each position.
2. Confirm that discharge air comes out according to the air distribution table at below. Refer to [HAC-13, "System Description"](#).

NOTE:

Confirm that the magnet clutch is engaged (Sound or visual inspection) and intake door position is at FRE when DEF or D/F is selected.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-44, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001303619

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2. PERFORM SELF-DIAGNOSIS STEP-3

Perform self-diagnosis STEP-3. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 4.

Is the inspection result normal?

YES >> GO TO 6.

NO-1 >> REC LED ON: GO TO 3.

NO-2 >> FRE LED ON: Go to Intake Door Motor Circuit. Refer to [HAC-52, "M9R : Diagnosis Procedure"](#).

3. CHECK POWER SUPPLY FOR MODE DOOR MOTOR

Check voltage between mode door motor harness connector M310 terminal 1 and ground.

(+)		(-)	Voltage
Mode door motor		—	
Connector	Terminal		
M310	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.


MODE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

4. CHECK SIGNAL FOR MODE DOOR MOTOR

Confirm A/C LAN signal between mode door motor harness connector M310 terminal 2 and ground using an oscilloscope.

(+)		(-)	Voltage
Connector	Terminal	—	
M310	2	Ground	 <p style="text-align: right; font-size: small;">SJIA1453J</p>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK MODE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect mode door motor connector.
3. Check continuity between mode door motor harness connector M310 terminal 3 and ground.

Mode door motor		—	Continuity
Connector	Terminal	—	
M310	3	Ground	Existed

Is the inspection result normal?

YES >> Replace mode door motor.

NO >> Repair harness or connector.

6. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 7.

7. CHECK MODE DOOR CONTROL LINKAGE

Check mode door control linkage.

Is it installed normally?

YES >> Refer to [VTL-25, "Exploded View"](#) (LHD models) or [VTL-71, "Exploded View"](#) (RHD models).

NO >> Repair or adjust control linkage.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AIR MIX DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

AIR MIX DOOR MOTOR MR20DE/QR25DE

MR20DE/QR25DE : Description


INFOID:000000001162165

COMPONENT DESCRIPTION

Air Mix Door Motor

The air mix door motor (1) is attached to the A/C unit assembly. It rotates so that the air mix door is opened or closed to a position set by the auto amp. Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the auto amp. by PBR built-in air mix door motor.

←: Vehicle front



MR20DE/QR25DE : Component Function Check

INFOID:000000001162166

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn temperature control dial clockwise until 28°C.
2. Check for hot air at discharge air outlets.
3. Turn temperature control dial counterclockwise until 16°C.
4. Check for cold air at discharge air outlets.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-46, "MR20DE/QR25DE : Diagnosis Procedure"](#).

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162167

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 3.

3. CHECK AIR MIX DOOR MOTOR

Check air mix door motor. Refer to [VTL-26, "Exploded View"](#) (LHD models) or [VTL-72, "Exploded View"](#) (RHD models).

Is it installed normally?

YES >> GO TO 4.

NO >> Replace air mix door motor.

4. CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR

Check voltage between air mix door motor harness connector M306 terminal 1 and ground.

AIR MIX DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Voltage
Air mix door motor		—	
Connector	Terminal		
M306	1	Ground	Battery voltage


Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK SIGNAL FOR AIR MIX DOOR MOTOR

Confirm A/C LAN signal between air mix door motor harness connector M306 terminal 2 and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor		—	
Connector	Terminal		
M306	2	Ground	

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6. CHECK AIR MIX DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor connector.
3. Check continuity between air mix door motor harness connector M306 terminal 3 and ground.

Air mix door motor		—	Continuity
Connector	Terminal		
M306	3	Ground	Existed

Is the inspection result normal?

YES >> Replace air mix door motor.

NO >> Repair harness or connector.

M9R

M9R : Description

INFOID:000000001298138

COMPONENT DESCRIPTION


Air Mix Door Motor

AIR MIX DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

The air mix door motor (1) is attached to the A/C unit assembly. It rotates so that the air mix door is opened or closed to a position set by the auto amp. Motor rotation is then conveyed through a shaft and the air mix door position feedback is then sent to the auto amp. by PBR built-in air mix door motor.



←: Vehicle front

JPIIA0211ZZ

M9R : Component Function Check

INFOID:000000001303621

1.CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn temperature control dial clockwise until 28°C.
2. Check for hot air at discharge air outlets.
3. Turn temperature control dial counterclockwise until 16°C.
4. Check for cold air at discharge air outlets.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-48, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001303622

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2.PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos.1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 3.

3.CHECK AIR MIX DOOR MOTOR

Check air mix door motor. Refer to [VTL-26, "Exploded View"](#) (LHD models) or [VTL-72, "Exploded View"](#) (RHD models).

Is it installed normally?

YES >> GO TO 4.

NO >> Replace air mix door motor.

4.CHECK POWER SUPPLY FOR AIR MIX DOOR MOTOR

Check voltage between air mix door motor harness connector M306 terminal 1 and ground.

(+)		(-)	Voltage
Air mix door motor		—	
Connector	Terminal		
M306	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.


AIR MIX DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

5. CHECK SIGNAL FOR AIR MIX DOOR MOTOR

Confirm A/C LAN signal between air mix door motor harness connector M306 terminal 2 and ground using an oscilloscope.

(+)		(-)	Voltage
Air mix door motor		—	
Connector	Terminal		
M306	2	Ground	

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair harness or connector.

6. CHECK AIR MIX DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air mix door motor connector.
3. Check continuity between air mix door motor harness connector M306 terminal 3 and ground.

Air mix door motor		—	Continuity
Connector	Terminal		
M306	3	Ground	Existed

Is the inspection result normal?

- YES >> Replace air mix door motor.
 NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INTAKE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

INTAKE DOOR MOTOR

MR20DE/QR25DE

MR20DE/QR25DE : Description


INFOID:000000001162168

COMPONENT DESCRIPTION

Intake Door Motor

The intake door motor (1) is attached to the A/C unit assembly. It rotates so that air is drawn from inlets set by the auto amp. Motor rotation is conveyed to a lever which activates the intake door.

← Vehicle front



MR20DE/QR25DE : Component Function Check

INFOID:000000001162169

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Press intake switch.
2. REC LED should illuminate.
3. Listen for intake door position change. (Slight change of blower sound can be heard.)
4. Press intake switch again.
5. FRE LED should illuminate.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-50, "MR20DE/QR25DE : Diagnosis Procedure"](#).

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162170

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2. PERFORM SELF-DIAGNOSIS STEP-3

Perform self-diagnosis STEP-3. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 4.

Is the inspection result normal?

YES >> GO TO 6.

NO-1 >> REC LED ON: Go to Mode Door Motor Circuit. Refer to [HAC-42, "MR20DE/QR25DE : Diagnosis Procedure"](#).

NO-2 >> FRE LED ON: GO TO 3.

3. CHECK POWER SUPPLY FOR INTAKE DOOR MOTOR

Check voltage between intake door motor harness connector M304 terminal 1 and ground.

(+)		(-)	Voltage
Intake door motor		—	
Connector	Terminal		
M304	1	Ground	Battery voltage

INTAKE DOOR MOTOR

[AUTOMATIC AIR CONDITIONER]


< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair harness or connector.

4. CHECK SIGNAL FOR INTAKE DOOR MOTOR

Confirm A/C LAN signal between intake door motor harness connector M304 terminal 2 and ground using an oscilloscope.

(+)		(-)	Voltage
Connector	Terminal	—	
M304	2	Ground	 <p style="text-align: right; font-size: small;">SJIA1453J</p>

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair harness or connector.

5. CHECK INTAKE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Check continuity between intake door motor harness connector M304 terminal 3 and ground.

Intake door motor		—	Continuity
Connector	Terminal	—	
M304	3	Ground	Existed

Is the inspection result normal?

- YES >> Replace intake door motor.
- NO >> Repair harness or connector.

6. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is the inspection result normal?

- YES >> END.
- NO-1 >> GO TO 7.

7. CHECK INTAKE DOOR CONTROL LINKAGE

Check intake door control linkage.

Is it installed normally?

- YES >> Refer to [VTL-27, "Exploded View"](#) (LHD models) or [VTL-73, "Exploded View"](#) (RHD models).
- NO >> Repair or adjust control linkage.

M9R

M9R : Description

INFOID:000000001298139

COMPONENT DESCRIPTION

Intake Door Motor


INTAKE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

The intake door motor (1) is attached to the A/C unit assembly. It rotates so that air is drawn from inlets set by the auto amp. Motor rotation is conveyed to a lever which activates the intake door.

←: Vehicle front



M9R : Component Function Check

INFOID:000000001303623

1.CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Press intake switch.
2. REC LED should illuminate.
3. Listen for intake door position change. (Slight change of blower sound can be heard.)
4. Press intake switch again.
5. FRE LED should illuminate.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-52, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001308684

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

2.PERFORM SELF-DIAGNOSIS STEP-3

Perform self-diagnosis STEP-3. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 4.

Is the inspection result normal?

YES >> GO TO 6.

NO-1 >> REC LED ON: Go to Mode Door Motor Circuit. Refer to [HAC-44, "M9R : Diagnosis Procedure"](#).

NO-2 >> FRE LED ON: GO TO 3.

3.CHECK POWER SUPPLY FOR INTAKE DOOR MOTOR

Check voltage between intake door motor harness connector M304 terminal 1 and ground.

(+)		(-)	Voltage
Connector	Terminal	—	
M304	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.


4.CHECK SIGNAL FOR INTAKE DOOR MOTOR

Confirm A/C LAN signal between intake door motor harness connector M304 terminal 2 and ground using an oscilloscope.

INTAKE DOOR MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Voltage
Connector	Terminal	—	
M304	2	Ground	 <p style="text-align: right; font-size: small;">S/JIA1453J</p>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5.CHECK INTAKE DOOR MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect intake door motor connector.
3. Check continuity between intake door motor harness connector M304 terminal 3 and ground.

Intake door motor		—	Continuity
Connector	Terminal	—	
M304	3	Ground	Existed

Is the inspection result normal?

YES >> Replace intake door motor.

NO >> Repair harness or connector.

6.PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24. "Diagnosis Description"](#), see Nos. 1 to 6.

Is the inspection result normal?

YES >> END.

NO-1 >> GO TO 7.

7.CHECK INTAKE DOOR CONTROL LINKAGE

Check intake door control linkage.

Is it installed normally?

YES >> Refer to [VTL-27. "Exploded View"](#) (LHD models) or [VTL-73. "Exploded View"](#) (RHD models).

NO >> Repair or adjust control linkage.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

BLOWER MOTOR MR20DE/QR25DE


MR20DE/QR25DE : Description

INFOID:000000001162171

COMPONENT DESCRIPTION


The blower motor (1) utilizes a brush motor with a sirocco fan type.

← Vehicle front



JPIIA0213ZZ

Blower motor circuit



RHA467GA

MR20DE/QR25DE : Component Function Check

INFOID:000000001162172

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial clockwise to 1st speed. Blower should operate on low speed.
2. Turn fan control dial clockwise to 2nd speed, and continue checking blower speed until all speeds are checked.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-54, "MR20DE/QR25DE : Diagnosis Procedure"](#).

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162173

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is there any malfunction displayed?

YES >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see to No. 7.

NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Code No.	41	42	43	44	45	46
Blower motor voltage	4.5 V	10.5 V		8.5 V		12.0 V

Does blower motor speed change according to each code No.?

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

- YES >> GO TO 3.
NO >> GO TO 5.

3. CHECK ENGINE COOLANT TEMPERATURE

Check engine coolant temperature.

Is engine coolant temperature below 56°C (133°F)?

- YES >> GO TO 4.
NO >> Blower motor operation is normal.

4. CHECK BLOWER MOTOR OPERATING

Check blower motor operating.

Is blower motor operation under starting blower speed control?

- YES >> END.
NO >> GO TO 5.

5. CHECK POWER SUPPLY FOR BLOWER MOTOR

1. Turn ignition switch ON.
2. Check voltage between blower motor harness connector M312 terminal 1 and ground.

(+)		(-)	Voltage
Blower motor		—	
Connector	Terminal		
M312	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 10.

6. CHECK POWER SUPPLY FOR FAN CONTROL AMP.

Check voltage between fan control amp. harness connector M311 terminal 1 and ground.

(+)		(-)	Voltage
Fan control amp.		—	
Connector	Terminal		
M311	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 14.

7. CHECK BLOWER MOTOR CONTROL SIGNAL

1. Turn mode control dial to VENT.
2. Turn fan control dial to 1st speed.
3. Check voltage between fan control amp. harness connector M311 terminal 2 and ground.

(+)		(-)	Voltage
Fan control amp.		—	
Connector	Terminal		
M311	2	Ground	Approx. 2.5 V

Is the inspection result normal?

- YES >> GO TO 8.
NO-1 >> In the case of less than approximately 2.5 V: GO TO 15.
NO-2 >> In the case of more than approximately 9 V: Replace auto amp.

8. CHECK FAN CONTROL AMP. GROUND CIRCUIT

1. Disconnect fan control amp. connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

2. Check continuity between fan control amp. harness connector M311 terminal 3 and ground.

Fan control amp.		—	Continuity
Connector	Terminal		
M311	3	Ground	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair harness or connector.

9. CHECK BLOWER MOTOR FEEDBACK SIGNAL

1. Reconnect fan control amp. connector.
2. Turn ignition switch ON.
3. Turn fan control dial to 1st speed.
4. Check voltage between auto amp. harness connector M50 terminal 18 and ground.

Auto amp.		(+)	(-)	Condition	Voltage
Connector	Terminal	—			
M50	18	Ground		Blower speed: 1st (Blower motor operate.)	Approx. 10 V

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

10. CHECK POWER VOLTAGE OF BLOWER RELAY

1. Turn ignition switch OFF.
2. Remove blower relay. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn ignition switch ON.
4. Check voltage between blower relay fuse block terminals 1, 3 and ground. Refer to [PG-123, "Description"](#) for relay terminal assignment.

Blower relay		(+)	(-)	Voltage
		—		
		1	Ground	Battery voltage
		3		

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. CHECK IGNITION SWITCH CIRCUIT

Check ignition switch circuit. Refer to [SEC-61, "Diagnosis Procedure"](#) (WITH INTELLIGENT KEY SYSTEM), [SEC-268, "Diagnosis Procedure"](#) (WITHOUT INTELLIGENT KEY SYSTEM).

Is the inspection result normal?

YES >> Repair harness or connector.

NG >> Replace malfunctioning parts.

12. CHECK BLOWER RELAY

1. Turn ignition switch OFF.
2. Install blower relay. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).
3. Check operation sound of the blower relay after switching ignition switch ON.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Replace blower relay.

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

13. CHECK FUSE

Check 15A fuse [Nos. 15 and 16, located in the fuse block (J/B)]. Refer to [PG-125. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> Repair harness or connector.

NG >> Replace fuse.

14. CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND FAN CONTROL AMP.

1. Turn ignition switch OFF.
2. Disconnect fan control amp. connector.
3. Check continuity between blower motor harness connector M312 terminal 2 and fan control amp. harness connector M311 terminal 1.

Blower motor		Fan control amp.		Continuity
Connector	Terminal	Connector	Terminal	
M312	2	M311	1	Existed

Is the inspection result normal?

YES >> Replace blower motor.

NO >> Repair harness or connector.

15. CHECK CIRCUIT FAN CONTROL AMP.

Check fan control amp. Refer to [HAC-57. "MR20DE/QR25DE : Component Inspection"](#).

Is the inspection result normal?

YES >> Replace auto amp.


NO >> Replace fan control amp.

MR20DE/QR25DE : Component Inspection

INFOID:000000001162174

Blower motor


Confirm smooth rotation of the blower motor.



Fan control amp.

Check continuity between terminal 3 and 2 using analog circuit tester.

Terminal		Continuity
(+)	(-)	
3	2	Existed
2	3	Not existed



M9R

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >


M9R : Description

INFOID:000000001298140

COMPONENT DESCRIPTION


The blower motor (1) utilizes a brush motor with a sirocco fan type.

←: Vehicle front



JPIIA0213ZZ

Blower motor circuit



JSIIA0444GB

M9R : Component Function Check

INFOID:000000001298073

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial clockwise. Blower should operate on low speed.
2. Turn fan control dial clockwise, and continue checking blower speed and fan LEDs until all speeds checked.

Is the inspection result normal?

YES >> END.

NO >> Go to diagnosis procedure. Refer to [HAC-58, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001308690

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is there any malfunction displayed?

YES >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see to No. 7.

NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Code No.	41	42	43	44	45	46
Blower motor voltage	4.5 V	10.5 V		8.5 V		12.0 V

Does blower motor speed change according to each code No.?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK ENGINE COOLANT TEMPERATURE

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

Check engine coolant temperature.

Is engine coolant temperature below 56°C (133°F)?

- YES >> GO TO 4.
NO >> Blower motor operation is normal.

4.CHECK BLOWER MOTOR OPERATING

Check blower motor operating.

Is blower motor operation under starting blower speed control?

- YES >> END.
NO >> GO TO 5.

5.CHECK POWER SUPPLY FOR BLOWER MOTOR

1. Turn ignition switch ON.
2. Check voltage between blower motor harness connector M312 terminal 1 and ground.

(+)		(-)	Voltage
Blower motor		—	
Connector	Terminal		
M312	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 10.

6.CHECK POWER SUPPLY FOR FAN CONTROL AMP.

Check voltage between fan control amp. harness connector M311 terminal 1 and ground.

(+)		(-)	Voltage
Fan control amp.		—	
Connector	Terminal		
M311	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 14.

7.CHECK BLOWER MOTOR CONTROL SIGNAL

1. Turn mode control dial to VENT.
2. Turn fan control dial to 1st speed.
3. Check voltage between fan control amp. harness connector M311 terminal 2 and ground.

(+)		(-)	Voltage
Fan control amp.		—	
Connector	Terminal		
M311	2	Ground	Approx. 2.5 V

Is the inspection result normal?

- YES >> GO TO 8.
NO-1 >> In the case of less than approximately 2.5 V: GO TO 15.
NO-2 >> In the case of more than approximately 9 V: Replace auto amp.

8.CHECK FAN CONTROL AMP. GROUND CIRCUIT

1. Disconnect fan control amp. connector.
2. Check continuity between fan control amp. harness connector M311 terminal 3 and ground.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BLOWER MOTOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Fan control amp.		—	Continuity
Connector	Terminal		
M311	3	Ground	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair harness or connector.

9. CHECK BLOWER MOTOR FEEDBACK SIGNAL

1. Reconnect fan control amp. connector.
2. Turn ignition switch ON.
3. Turn fan control dial to 1st speed.
4. Check voltage between auto amp. harness connector M53 terminal 8 and ground.

(+) Auto amp.		(-)	Condition	Voltage
Connector	Terminal	—		
M53	8	Ground	Blower speed: 1st (Blower motor operate.)	Approx. 10 V

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

10. CHECK POWER VOLTAGE OF BLOWER RELAY

1. Turn ignition switch OFF.
2. Remove blower relay. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).
3. Turn ignition switch ON.
4. Check voltage between blower relay fuse block terminals 1, 3 and body ground. Refer to [PG-123, "Description"](#) for relay terminal assignment.

(+) Blower relay		(-)	Voltage
1	3	—	
		Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. CHECK IGNITION SWITCH CIRCUIT

Check ignition switch circuit. Refer to [SEC-61, "Diagnosis Procedure"](#) (WITH INTELLIGENT KEY SYSTEM), [SEC-268, "Diagnosis Procedure"](#) (WITHOUT INTELLIGENT KEY SYSTEM).

Is the inspection result normal?

YES >> Repair harness or connector.

NG >> Replace malfunctioning parts.

12. CHECK BLOWER RELAY

1. Turn ignition switch OFF.
2. Install blower relay. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).
3. Check operation sound of the blower relay after switching ignition switch ON.

Is the inspection result normal?

YES >> GO TO 13.

NO >> Replace blower relay.

13. CHECK FUSE

BLOWER MOTOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

Check 15A fuse [Nos. 15 and 16, located in the fuse block (J/B)]. Refer to [PG-125. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> Repair harness or connector.

NG >> Replace fuse.

14. CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND FAN CONTROL AMP.

1. Turn ignition switch OFF.
2. Disconnect fan control amp. connector.
3. Check continuity between blower motor harness connector M312 terminal 2 and fan control amp. harness connector M311 terminal 1.

Blower motor		Fan control amp.		Continuity
Connector	Terminal	Connector	Terminal	
M312	2	M311	1	Existed

Is the inspection result normal?

YES >> Replace blower motor.

NO >> Repair harness or connector.

15. CHECK CIRCUIT FAN CONTROL AMP.

Check fan control amp. Refer to [HAC-61. "M9R : Component Inspection"](#).

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Replace fan control amp.


M9R : Component Inspection

INFOID:000000001298141

HAC

Blower motor


Confirm smooth rotation of the blower motor.



Fan control amp.

Check continuity between terminal 3 and 2 using analog circuit tester.

Terminal		Continuity
(+)	(-)	
3	2	Existed
2	3	Not existed



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

MAGNET CLUTCH

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

MAGNET CLUTCH

MR20DE/QR25DE

MR20DE/QR25DE : Description

INFOID:000000001162175

Magnet clutch drives a compressor, by a signal of IPDM E/R.

MR20DE/QR25DE : Component Function Check

INFOID:000000001162176

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial to AUTO position.
2. Press A/C switch.
3. A/C switch LED should illuminate. Confirm that the magnet clutch engages (sound or visual inspection). (Discharge air and blower speed depend on ambient, in-vehicle and set temperatures.)

Does the magnet clutch operate?

YES >> END.

NO >> Go to Diagnosis Procedure. Refer to [HAC-62, "MR20DE/QR25DE : Diagnosis Procedure"](#).

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162177

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is there any malfunction displayed?

YES >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see to No. 7.

NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 3.

3. PERFORM IPDM E/R AUTO ACTIVE TEST

Perform "IPDM E/R auto active test". Refer to [PCS-8, "Diagnosis Description"](#).

Does the magnet clutch operate?

YES >> • WITH CONSULT-III: GO TO 7.

• WITHOUT CONSULT-III: GO TO 8.

NO >> Check 10A fuse (No. 53, located in IPDM E/R), and GO TO 4.

4. CHECK CIRCUIT CONTINUITY BETWEEN IPDM E/R AND COMPRESSOR

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and compressor connector.
3. Check continuity between IPDM E/R harness connector E13 terminal 23 and compressor harness connector F17 terminal 1.

IPDM E/R		Compressor		Continuity
Connector	Terminal	Connector	Terminal	
E13	23	F17	1	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK CIRCUIT CONTINUITY BETWEEN COMPRESSOR GROUND

Check continuity between compressor harness connector F17 terminal 2 and ground.

MAGNET CLUTCH

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Compressor		—	Continuity
Connector	Terminal		
F17	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

6.CHECK MAGNET CLUTCH CIRCUIT

Check for operation sound when applying battery voltage direct current to terminal.

Is the inspection result normal?

YES >> 1. Replace IPDM E/R.

2. Refer to self-diagnosis procedure [HAC-24, "Diagnosis Description"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation normal.

NO >> 1. Replace compressor.

2. Refer to self-diagnosis procedure [HAC-24, "Diagnosis Description"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation normal.

7.CHECK BCM INPUT (COMPRESSOR ON) SIGNAL

Check compressor ON/OFF signal in "Data monitor". Refer to [HAC-27, "CONSULT-III Function"](#).

A/C SW ON : AIR COND SW On

A/C SW OFF : AIR COND SW Off

Is the inspection result normal?

YES >> GO TO 11.

NO >> GO TO 8.

8.CHECK CIRCUIT CONTINUITY BETWEEN BCM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector and auto amp. harness connector.
3. Check continuity between BCM harness connector M65 terminal 27 and auto amp. harness connector M50 terminal 4.

BCM		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M65	27	M50	4	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair harness or connector.

9.CHECK BCM

1. Connect BCM harness connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M65 terminal 27 and ground.

(+)		(-)		Voltage
BCM		—		
Connector	Terminal			
M65	27	Ground		Battery voltage

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace BCM. Refer to [BCS-68, "Exploded View"](#).

10.CHECK COMPRESSOR ON SIGNAL

MAGNET CLUTCH

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

1. Turn ignition switch OFF.
2. Connect auto amp. harness connector.
3. Turn ignition switch ON.
4. Check voltage between auto amp. harness connector M50 terminal 4 and ground.

(+)		(-)	Condition	Voltage
Auto amp.		—		
Connector	Terminal			
M50	4	Ground	A/C switch: ON (Blower motor operates.)	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace auto amp.

11. CHECK REFRIGERANT PRESSURE SENSOR

WITH CONSULT-III

1. Start the engine.
2. Check voltage of refrigerant pressure sensor in "Data monitor". Refer to [ECM-308. "Reference Value"](#) (MR20DE), [ECQ-314. "Reference Value"](#) [QR25DE (WITH EURO-OBD)], or [ECQ-605. "Reference Value"](#) [QR25DE (WITHOUT EURO-OBD)].

WITHOUT CONSULT-III

1. Start the engine.
2. Check voltage between ECM harness connector F8 terminal 41 (MR20DE engine) or F43 terminal 37 (QR25DE engine) and ground.

MR20DE engine

(+)		(-)	Condition	Voltage
ECM		—		
Connector	Terminal			
F8	41	Ground	A/C switch: ON (Blower motor operates.)	Approx. 1.0 - 4.0 V

QR25DE engine

(+)		(-)	Condition	Voltage
ECM		—		
Connector	Terminal			
F43	37	Ground	A/C switch: ON (Blower motor operates.)	Approx. 1.0 - 4.0 V

Is the inspection result normal?

YES >> • WITH CONSULT-III: GO TO 12.

• WITHOUT CONSULT-III: GO TO 13.

NO >> Refer to [ECM-306. "Diagnosis Procedure"](#) (MR20DE), [ECQ-312. "Diagnosis Procedure"](#) [QR25DE (WITH EURO-OBD)], or [ECQ-603. "Diagnosis Procedure"](#) [QR25DE (WITHOUT EURO-OBD)].

12. CHECK BCM INPUT (FAN ON) SIGNAL

Check FAN ON/OFF signal in "Data monitor". Refer to [HAC-27. "CONSULT-III Function"](#).

FAN CONTROL DIAL ON : FAN ON SIG On

FAN CONTROL DIAL OFF : FAN ON SIG Off

Is the inspection result normal?

YES >> GO TO 16.

NO >> GO TO 13.

13. CHECK CIRCUIT CONTINUITY BETWEEN BCM AND AUTO AMP.

MAGNET CLUTCH

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector and auto amp. connector.
3. Check continuity between BCM harness connector M65 terminal 26 and auto amp. harness connector M50 terminal 19.

BCM		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M65	26	M50	19	Existed

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair harness or connector.

14.CHECK BCM

1. Connect BCM harness connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M65 terminal 26 and ground.

BCM		—	Voltage
Connector	Terminal		
M65	26	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 15.

NO >> Replace BCM. Refer to [BCS-68, "Exploded View"](#).

15.CHECK FAN ON SIGNAL

1. Turn ignition switch OFF.
2. Connect auto amp. connector.
3. Turn ignition switch ON.
4. Check voltage between auto amp. harness connector M50 terminal 19 and ground.

(+)		(-)		Condition	Voltage
Auto amp.		—			
Connector	Terminal				
M50	19	Ground		Fan control dial: ON	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 16.

NO >> Replace auto amp.

16.CHECK CAN COMMUNICATION

Check CAN communication. Refer to [LAN-25, "CAN Communication Signal Chart"](#).

- ECM – IPDM E/R
- ECM – BCM

Is the inspection result normal?

YES >> Replace ECM.

NO >> Repair or replace malfunctioning part(s).

MR20DE/QR25DE : Component Inspection

INFOID:000000001162178



Refrigerant Pressure Sensor

MAGNET CLUTCH

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

The refrigerant pressure sensor (1) is attached to the liquid tank. Check that the A/C refrigerant pressure and the sensor output voltage are within the specified range as shown in the A/C operating condition figure. Refer to [ECM-306, "Description"](#) (MR20DE) or [ECQ-312, "Description"](#) [QR25DE (WITH EURO-OBD)] or [ECQ-603, "Description"](#) [QR25DE (WITHOUT EURO-OBD)].



M9R

M9R : Description

INFOID:000000001298145

Magnet clutch drives a compressor, by a signal of IPDM E/R.

M9R : Component Function Check

INFOID:000000001298078

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial to AUTO position.
2. Press A/C switch.
3. A/C switch LED should illuminate. Confirm that the magnet clutch engages (sound or visual inspection). (Discharge air and blower speed depend on ambient, in-vehicle and set temperatures.)

Does the magnet clutch operate?

YES >> END.

NO >> Go to Diagnosis Procedure. Refer to [HAC-66, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001298079

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is there any malfunction displayed?

YES >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see to No. 7.

NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 6.

Is it operated normally?

YES >> END.

NO >> GO TO 3.

3. PERFORM IPDM E/R AUTO ACTIVE TEST

Perform "IPDM E/R auto active test". Refer to [HAC-24, "Diagnosis Description"](#).

MAGNET CLUTCH

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

Does the magnet clutch operate?

- YES >> • WITH CONSULT-III: GO TO 7.
• WITHOUT CONSULT-III: GO TO 8.
- NO >> Check 10A fuse (No. 53, located in IPDM E/R), and GO TO 4.

4.CHECK CIRCUIT CONTINUITY BETWEEN IPDM E/R AND COMPRESSOR

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and compressor connector.
3. Check continuity between IPDM E/R harness connector E15 terminal 55 and compressor harness connector F17 terminal 1.

IPDM E/R		Compressor		Continuity
Connector	Terminal	Connector	Terminal	
E15	55	F17	1	Existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair harness or connector.

5.CHECK CIRCUIT CONTINUITY BETWEEN COMPRESSOR GROUND

Check continuity between compressor harness connector F17 terminal 2 and ground.

Compressor		—	Continuity
Connector	Terminal		
F17	2	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair harness or connector.

6.CHECK MAGNET CLUTCH CIRCUIT

Check for operation sound when applying battery voltage direct current to terminal.

Is the inspection result normal?

- YES >> 1. Replace IPDM E/R.
2. Refer to self-diagnosis procedure [HAC-24, "Diagnosis Description"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation normal.
- NO >> 1. Replace compressor.
2. Refer to self-diagnosis procedure [HAC-24, "Diagnosis Description"](#) and perform self-diagnosis STEP-4. Confirm that magnet clutch operation normal.

7.CHECK BCM INPUT (COMPRESSOR ON) SIGNAL

Check compressor ON/OFF signal in "Data monitor". Refer to [HAC-27, "CONSULT-III Function"](#).

A/C SW ON : AIR COND SW On
A/C SW OFF : AIR COND SW Off

Is the inspection result normal?

- YES >> GO TO 11.
NO >> GO TO 8.

8.CHECK CIRCUIT CONTINUITY BETWEEN BCM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector and auto amp. harness connector.
3. Check continuity between BCM harness connector M65 terminal 27 and auto amp. harness connector M53 terminal 13.

MAGNET CLUTCH

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

BCM		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M65	27	M53	13	Existed

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair harness or connector.

9.CHECK BCM

1. Connect BCM harness connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M65 terminal 27 and ground.

BCM		(+)	(-)	Voltage
Connector	Terminal	—		
M65	27	Ground		Battery voltage

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace BCM. Refer to [BCS-68. "Exploded View"](#).

10.CHECK COMPRESSOR ON SIGNAL

1. Turn ignition switch OFF.
2. Connect auto amp. harness connector.
3. Turn ignition switch ON.
4. Check voltage between auto amp. harness connector M53 terminal 13 and ground.

Auto amp.		(+)	(-)	Condition	Voltage
Connector	Terminal	—			
M53	13	Ground		A/C switch: ON (Blower motor operates.)	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace auto amp.

11.CHECK REFRIGERANT PRESSURE SENSOR

WITH CONSULT-III

1. Start the engine.
2. Check voltage of refrigerant pressure sensor in "Data monitor". Refer to [ECR-289. "Reference Value"](#).

WITHOUT CONSULT-III

1. Start the engine.
2. Check voltage between ECM harness connector F85 terminal 31 and ground.

ECM		(+)	(-)	Condition	Voltage
Connector	Terminal	—			
F85	31	Ground		A/C switch: ON (Blower motor operates.)	Approx. 2.3 V

Is the inspection result normal?

YES >> • WITH CONSULT-III: GO TO 12.

• WITHOUT CONSULT-III: GO TO 13.

NO >> Refer to [ECR-185. "Diagnosis Procedure"](#).

MAGNET CLUTCH

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

12.CHECK BCM INPUT (FAN ON) SIGNAL

Check FAN ON/OFF signal in "Data monitor". Refer to [HAC-27. "CONSULT-III Function"](#).

FAN CONTROL DIAL ON : FAN ON SIG On
FAN CONTROL DIAL OFF : FAN ON SIG Off

Is the inspection result normal?

YES >> GO TO 16.
NO >> GO TO 13.

13.CHECK CIRCUIT CONTINUITY BETWEEN BCM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect BCM connector and auto amp. connector.
3. Check continuity between BCM harness connector M65 terminal 26 and auto amp. harness connector M53 terminal 12.

BCM		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M65	26	M53	12	Existed

Is the inspection result normal?

YES >> GO TO 14.
NO >> Repair harness or connector.

14.CHECK BCM

1. Connect BCM harness connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M65 terminal 26 and ground.

BCM		—	Voltage
Connector	Terminal		
M65	26	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 15.
NO >> Replace BCM. Refer to [BCS-68. "Exploded View"](#).

15.CHECK FAN ON SIGNAL

1. Turn ignition switch OFF.
2. Connect auto amp. connector.
3. Turn ignition switch ON.
4. Check voltage between auto amp. harness connector M53 terminal 12 and ground.

(+)		(-)		Condition	Voltage
Auto amp.		—			
Connector	Terminal				
M53	12	Ground		Fan control dial: ON	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 16.
NO >> Replace auto amp.

16.CHECK CAN COMMUNICATION

Check CAN communication. Refer to [LAN-25. "CAN Communication Signal Chart"](#).

- ECM – IPDM E/R
- ECM – BCM

Is the inspection result normal?

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

MAGNET CLUTCH

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >



- YES >> Replace ECM.
- NO >> Repair or replace malfunctioning part(s).

M9R : Component Inspection

INFOID:000000001298080

Refrigerant Pressure Sensor

The refrigerant pressure sensor (1) is attached to the liquid tank. Check that the A/C refrigerant pressure and the sensor output voltage are within the specified range as shown in the A/C operating condition figure. Refer to [ECR-185, "Description"](#).



PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

PTC HEATER

Description

INFOID:0000000001162179

Auto amp. operate a PTC heater, by a signal of ECM.

Component Function Check

INFOID:0000000001162180

1. CONFIRM SYMPTOM BY PERFORMING ACTIVE TEST

CONSULT-III ACTIVE TEST

1. Start engine.
2. Select "PTC HEATER" of BCM active test item.
CAUTION:
 - Engine must be cold.
 - Battery must be charged.
3. Turn fan control dial clockwise.
4. Turn temperature control dial to full hot position.
5. Check PTC heater operation with operating the test item.
6. Check for warm air at discharge air outlet.

PTC 3 : PTC heater HI operation
PTC 2 : PTC heater MID operation
PTC 1 : PTC heater LO operation
OFF : Stop the PTC heater operation

Does the PTC heater operate?

YES >> END.

NO >> Go to Diagnosis Procedure. Refer to [HAC-71, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000001162181

1. CHECK PTC HEATER-1 OPERATION

CONSULT -III ACTIVE TEST

1. Disconnect PTC heater connector.
2. Start engine.
3. Select "PTC HEATER" of BCM active test item.
4. Check voltage between PTC heater harness connector E117 terminal 3 and ground with operating the item.

(+)		(-)	Test item	Voltage
Connector	Terminal	—	PTC HEATER	
E117	3	Ground	OFF	Approx. 0 V
			PTC 1	Battery voltage
			PTC 2	Approx. 0 V
			PTC 3	Approx. 0 V

In the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 6.

2. CHECK GROUND CIRCUIT FOR PTC HEATER-1

1. Turn ignition switch OFF.
2. Check continuity between PTC heater harness connector E116 terminal 1 and ground.

PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

PTC heater		—	Continuity
Connector	Terminal		
E116	1	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK PTC HEATER-2 OPERATION

1. Start engine.
2. Select "PTC HEATER" of BCM active test item.
3. Check voltage between PTC heater harness connector E117 terminal 4 and ground with operating the item.

(+)		(-)	Test item	Voltage
PTC heater		—	PTC HEATER	
Connector	Terminal	Ground	OFF	Approx. 0 V
E117	4		PTC 1	Battery voltage
			PTC 2	Battery voltage
			PTC 3	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 13.

4. CHECK GROUND CIRCUIT FOR PTC HEATER-2

1. Turn ignition switch OFF.
2. Check continuity between PTC heater harness connector E116 terminal 2 and ground.

PTC heater		—	Continuity
Connector	Terminal		
E116	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair harness or connector.

5. CHECK PTC HEATER-3 OPERATION

1. Start engine.
2. Select "PTC HEATER" of BCM active test item.
3. Check voltage between PTC heater harness connector E117 terminal 5 and ground with operating the item.

(+)		(-)	Test item	Voltage
PTC heater		—	PTC HEATER	
Connector	Terminal	Ground	OFF	Approx. 0 V
E117	5		PTC 1	Battery voltage
			PTC 2	Battery voltage
			PTC 3	Battery voltage

Is the inspection result normal?

YES >> Replace PTC heater.

PTC HEATER

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

NO >> GO TO 19.

6. CHECK VOLTAGE FOR PTC RELAY-1

1. Turn ignition switch OFF.
2. Disconnect PTC relay-1. Refer to [PG-126, "Fuse and Fusible Link Arrangement"](#).
3. Turn ignition switch ON.
4. Check voltage between PTC relay-1 harness connector E66 terminal 3 and ground.

(+)		(-)		Voltage
PTC relay-1		—		
Connector	Terminal			
E66	3	Ground		Battery voltage

Is the inspection result normal?

YES >> GO TO 8.

NO >> GO TO 7.

7. CHECK FUSE

Check 30A fuse (No. 37, located in the fuse, fusible link and relay box). Refer to [PG-126, "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

YES >> Repair harness or connector.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

8. CHECK PTC RELAY-1

Check PTC relay-1. Refer to [HAC-77, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace PTC relay-1.

9. CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-1 AND PTC HEATER

Check continuity between PTC relay-1 harness connector E66 terminal 5 and PTC heater harness connector E117 terminal 3.

PTC relay-1		PTC heater		Continuity
Connector	Terminal	Connector	Terminal	
E66	5	E117	3	Existed

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair harness or connector.

10. CHECK POWER SUPPLY FOR PTC RELAY-1

1. Turn ignition switch ON.
2. Check voltage between PTC relay-1 harness connector E66 terminal 2 and ground.

(+)		(-)		Voltage
PTC relay-1		—		
Connector	Terminal			
E66	2	Ground		Battery voltage

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 11.

11. CHECK FUSE

PTC HEATER

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

Check 10A fuse [No. 1, located in the fuse block (J/B)]. Refer to [PG-125. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

YES >> Repair harness or connector.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

12.CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-1 AND AUTO AMP.

Check continuity between PTC relay-1 harness connector E66 terminal 1 and auto amp. harness connector M53 terminal 4.

PTC relay-1		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E66	1	M53	4	Existed

Is the inspection result normal?

YES >> GO TO 25.

NO >> Repair harness or connector.

13.CHECK VOLTAGE FOR PTC RELAY-2

1. Turn ignition switch OFF.
2. Disconnect PTC relay-2. Refer to [PG-126. "Fuse and Fusible Link Arrangement"](#).
3. Turn ignition switch ON.
4. Check voltage between PTC relay-2 harness connector E67 terminal 3 and ground.

PTC relay-2		(-)	Voltage
Connector	Terminal	—	
E67	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 15.

NO >> GO TO 14.

14.CHECK FUSE

Check 30A fuse (No. 36, located in the fuse, fusible link and relay box). Refer to [PG-126. "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

YES >> Repair harness or connector.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

15.CHECK PTC RELAY-2

Check PTC relay-2. Refer to [HAC-77. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 16.

NO >> Replace PTC relay-2.

16.CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-2 AND PTC HEATER

Check continuity between PTC relay-2 harness connector E67 terminal 5 and PTC heater harness connector E117 terminal 4.

PTC relay-2		PTC heater		Continuity
Connector	Terminal	Connector	Terminal	
E67	5	E117	4	Existed

Is the inspection result normal?

YES >> GO TO 17.

NO >> Repair harness or connector.

PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

17. CHECK POWER SUPPLY FOR PTC RELAY-2

1. Turn ignition switch ON.
2. Check voltage between PTC relay-2 harness connector E67 terminal 2 and ground.

(+)		(-)	Voltage
PTC relay-2		—	
Connector	Terminal		Ground
E67	2		

Is the inspection result normal?

- YES >> GO TO 18.
NO >> GO TO 11.

18. CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-2 AND AUTO AMP.

Check continuity between PTC relay-2 harness connector E67 terminal 1 and auto amp. harness connector M53 terminal 5.

PTC relay-1		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E67	1	M53	5	

Is the inspection result normal?

- YES >> GO TO 25.
NO >> Repair harness or connector.

19. CHECK VOLTAGE FOR PTC RELAY-3

1. Turn ignition switch OFF.
2. Disconnect PTC relay-3. Refer to [PG-126. "Fuse and Fusible Link Arrangement"](#).
3. Turn ignition switch ON.
4. Check voltage between PTC relay-3 harness connector E68 terminal 3 and ground.

(+)		(-)	Voltage
PTC relay-3		—	
Connector	Terminal		Ground
E68	3		

Is the inspection result normal?

- YES >> GO TO 21.
NO >> GO TO 20.

20. CHECK FUSE

Check 30A fuse (No. 21, located in the fuse, fusible link and relay box). Refer to [PG-126. "Fuse and Fusible Link Arrangement"](#).

Is the inspection result normal?

- YES >> Repair harness or connector.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

21. CHECK PTC RELAY-3

Check PTC relay-3. Refer to [HAC-77. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 22.
NO >> Replace PTC relay-3.

22. CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-3 AND PTC HEATER

Check continuity between PTC relay-3 harness connector E68 terminal 5 and PTC heater harness connector E117 terminal 4.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

PTC relay-2		PTC heater		Continuity
Connector	Terminal	Connector	Terminal	
E68	5	E117	5	Existed

Is the inspection result normal?

YES >> GO TO 23.

NO >> Repair harness or connector.

23.CHECK POWER SUPPLY FOR PTC RELAY-3

1. Turn ignition switch ON.
2. Check voltage between PTC relay-3 harness connector E68 terminal 2 and ground.

(+)		(-)		Voltage
PTC relay-2		—		
Connector	Terminal			
E68	2	Ground		Battery voltage

Is the inspection result normal?

YES >> GO TO 24.

NO >> GO TO 11.

24.CHECK CIRCUIT CONTINUITY BETWEEN PTC RELAY-3 AND AUTO AMP.

Check continuity between PTC relay-3 harness connector E68 terminal 1 and auto amp. harness connector M53 terminal 27.

PTC relay-1		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E68	1	M53	27	Existed

Is the inspection result normal?

YES >> GO TO 25.

NO >> Repair harness or connector.

25.CHECK BCM INPUT (FAN ON) SIGNAL

Check FAN ON/OFF signal in "DATA MONITOR". Refer to [HAC-27, "CONSULT-III Function"](#).

FAN CONTROL DIAL ON : FAN ON SIG ON

FAN CONTROL DIAL OFF : FAN ON SIG OFF

Is the inspection result normal?

YES >> GO TO 28.

NO >> GO TO 26.

26.CHECK FAN ON SIGNAL

1. Turn ignition switch ON.
2. Check voltage between auto amp. harness connector M53 terminal 12 and ground.

(+)		(-)		Condition	Voltage
Auto amp.		—			
Connector	Terminal				
M53	12	Ground		Fan control dial: OFF	Approx. 12

3. Turn fan control dial clockwise.
4. Check voltage between auto amp. harness connector M53 terminal 12 and ground.

PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Condition	Voltage
Auto amp.		—		
Connector	Terminal			
M53	12	Ground	Fan control dial: ON (Blower motor operates.)	Approx. 0

Is the inspection result normal?

YES >> GO TO 27.

NO >> Replace auto amp.

27. CHECK CIRCUIT CONTINUITY BETWEEN BCM AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check continuity between BCM harness connector M65 terminal 26 and auto amp. harness connector M53 terminal 12.

BCM		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M65	26	M53	12	Existed

Is the inspection result normal?

YES >> GO TO 28.

NO >> Repair harness or connector.

28. CHECK CAN COMMUNICATION

Check CAN communication. Refer to [LAN-25. "CAN Communication Signal Chart"](#).

- ECM – Auto amp.

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair or replace malfunctioning part(s).

Component Inspection


INFOID:000000001162182

PTC HEATER

The PTC heater (1) is attached to the A/C unit assembly. It generates heat electrically.

LHD models

←: Vehicle front




RHD models

PTC HEATER

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]


← Vehicle front



PTC RELAY

Check continuity between terminal 3 and 5.

Terminal	Condition	Continuity
3 and 5	12V direct current supply between terminal 1 and 2	Existed
	No current supply	Not existed



OAT SENSOR

MR20DE/QR25DE


MR20DE/QR25DE : Description

INFOID:000000001162183


COMPONENT DESCRIPTION

OAT (Outside Air Temperature) Sensor

The OAT sensor (1) is attached on the radiator core support. It detects ambient temperature and converts it into a resistance value which is then input into the auto amp.



OAT Sensor Circuit



AMBIENT TEMPERATURE INPUT PROCESS

The auto amp. equips a processing circuit for the OAT sensor input. However, when the temperature detected by the OAT sensor increases quickly, the processing circuit retards the auto amp. function. It only allows the auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds.

As an example, consider stopping for a few minutes after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the OAT sensor increases. This is because the heat from the engine compartment can radiate to the front bumper area, location of the OAT sensor.

MR20DE/QR25DE : Component Function Check

INFOID:000000001162184

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24. "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-79. "MR20DE/QR25DE : Diagnosis Procedure"](#).
 NO >> END.

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162185

1.CHECK VOLTAGE BETWEEN OAT SENSOR AND GROUND

1. Disconnect OAT sensor connector.
2. Turn ignition switch ON.
3. Check voltage between OAT sensor harness connector E44 terminal 2 and ground.

OAT SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Voltage
OAT sensor		—	
Connector	Terminal		
E44	2	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN OAT SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between OAT sensor harness connector E44 terminal 1 and auto amp. harness connector M51 terminal 24.

OAT sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E44	1	M51	24	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK OAT SENSOR

Refer to [HAC-81. "MR20DE/QR25DE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Replace OAT sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN OAT SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between OAT sensor harness connector E44 terminal 2 and auto amp. harness connector M50 terminal 9.

OAT sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E44	2	M50	9	Existed

4. Check continuity between OAT sensor harness connector E44 terminal 2 and ground.

OAT sensor		(-)	Continuity
Connector	Terminal		
E44	2	Ground	Not existed

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Repair harness or connector.

OAT SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MR20DE/QR25DE : Component Inspection

INFOID:000000001162186

Measure resistance between terminals 1 and 2 at sensor side after disconnecting OAT sensor (1) connector E44. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (90)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace OAT sensor.

M9R


M9R : Description

COMPONENT DESCRIPTION

OAT (Outside Air Temperature) Sensor

The OAT sensor (1) is attached on the radiator core support. It detects ambient temperature and converts it into a resistance value which is then input into the auto amp.

OAT Sensor Circuit




JSIIA0429ZZ


INFOID:000000001298043

A
B
C
D
E
F
G
H

HAC



JSIIA0380ZZ



JSIIA0421GB

J
K
L
M
N
O
P

AMBIENT TEMPERATURE INPUT PROCESS

OAT SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

The auto amp. equips a processing circuit for the OAT sensor input. However, when the temperature detected by the OAT sensor increases quickly, the processing circuit retards the auto amp. function. It only allows the auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds.

As an example, consider stopping for a few minutes after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the OAT sensor increases. This is because the heat from the engine compartment can radiate to the front bumper area, location of the OAT sensor.

M9R : Component Function Check

INFOID:000000001298044

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-82, "M9R : Diagnosis Procedure"](#).
NO >> END.

M9R : Diagnosis Procedure

INFOID:000000001298045

1.CHECK VOLTAGE BETWEEN OAT SENSOR AND GROUND

1. Disconnect OAT sensor connector.
2. Turn ignition switch ON.
3. Check voltage between OAT sensor harness connector E44 terminal 2 and ground.

(+)		(-)	Voltage
OAT sensor		—	
Connector	Terminal		
E44	2	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK CIRCUIT CONTINUITY BETWEEN OAT SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between OAT sensor harness connector E44 terminal 1 and auto amp. harness connector M53 terminal 16.

OAT sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E44	1	M53	16	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK OAT SENSOR

Refer to [HAC-83, "M9R : Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Replace OAT sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN OAT SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between OAT sensor harness connector E44 terminal 2 and auto amp. harness connector M53 terminal 18.

OAT SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

OAT sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
E44	2	M53	18	Existed

4. Check continuity between OAT sensor harness connector E44 terminal 2 and ground.

OAT sensor		—	Continuity
Connector	Terminal		
E44	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.


M9R : Component Inspection

INFOID:000000001298147

Measure resistance between terminals 1 and 2 at sensor side after disconnecting OAT sensor (1) connector E44. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (90)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace OAT sensor.



JSIIA0429ZZ

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

IN-VEHICLE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

IN-VEHICLE SENSOR


MR20DE/QR25DE

MR20DE/QR25DE : Description


INFOID:000000001162187

In-vehicle Sensor

The in-vehicle sensor (1) is located on lower instrument panel, driver side. It converts variations in compartment air temperature drawn from the aspirator into a resistance value. It is then input into the auto amp.





In-vehicle Sensor Circuit



Aspirator

The aspirator (1) is located on right side of A/C unit assembly. It produces vacuum pressure due to air discharged from the A/C unit assembly, continuously taking compartment air in the aspirator.

← Vehicle front



IN-VEHICLE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MR20DE/QR25DE : Component Function Check

INFOID:000000001162188

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-85, "MR20DE/QR25DE : Diagnosis Procedure"](#).
- NO >> END.

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162189

1.CHECK VOLTAGE BETWEEN IN-VEHICLE SENSOR AND GROUND

1. Disconnect in-vehicle sensor connector.
2. Turn ignition switch ON.
3. Check voltage between in-vehicle sensor harness connector M41 terminal 1 and ground.

(+)		(-)	Voltage
In-vehicle sensor		—	
Connector	Terminal		
M41	1	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 4.

2.CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector M41 terminal 2 and auto amp. harness connector M51 terminal 24.

In-vehicle sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	2	M51	24	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3.CHECK IN-VEHICLE SENSOR

Refer to [HAC-86, "MR20DE/QR25DE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
- NO >> Replace in-vehicle sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector M41 terminal 1 and auto amp. harness connector M50 terminal 8.

In-vehicle sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	1	M50	8	Existed

4. Check continuity between in-vehicle sensor harness connector M41 terminal 1 and ground.

IN-VEHICLE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

In-vehicle sensor		—	Continuity
Connector	Terminal		
M41	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace auto amp.


NO >> Repair harness or connector.

MR20DE/QR25DE : Component Inspection

INFOID:000000001162190

Measure resistance between terminals 1 and 2 at sensor side after disconnecting in-vehicle sensor (1) connector M41. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07



If NG, replace in-vehicle sensor.


M9R

M9R : Description

INFOID:000000001298047

In-vehicle Sensor

The in-vehicle sensor (1) is located on lower instrument panel, driver side. It converts variations in compartment air temperature drawn from the aspirator into a resistance value. It is then input into the auto amp.




IN-VEHICLE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



In-vehicle Sensor Circuit



Aspirator

The aspirator (1) is located on right side of A/C unit assembly. It produces vacuum pressure due to air discharged from the A/C unit assembly, continuously taking compartment air in the aspirator.

← Vehicle front



M9R : Component Function Check

INFOID:000000001298048

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-87, "M9R : Diagnosis Procedure"](#).
- NO >> END.

M9R : Diagnosis Procedure

INFOID:000000001298049

1.CHECK VOLTAGE BETWEEN IN-VEHICLE SENSOR AND GROUND

1. Disconnect in-vehicle sensor connector.
2. Turn ignition switch ON.
3. Check voltage between in-vehicle sensor harness connector M41 terminal 1 and ground.

(+)		(-)	Voltage
In-vehicle sensor		—	
Connector	Terminal		
M41	1	Ground	Approx. 5

IN-VEHICLE SENSOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector M41 terminal 2 and auto amp. harness connector M53 terminal 16.

In-vehicle sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	2	M53	16	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK IN-VEHICLE SENSOR

Refer to [HAC-89, "M9R : Component Inspection"](#).

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Replace in-vehicle sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN IN-VEHICLE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between in-vehicle sensor harness connector M41 terminal 1 and auto amp. harness connector M53 terminal 17.

In-vehicle sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M41	1	M53	17	Existed

4. Check continuity between in-vehicle sensor harness connector M41 terminal 1 and ground.

In-vehicle sensor		—	Continuity
Connector	Terminal		
M41	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

IN-VEHICLE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]


M9R : Component Inspection

INFOID:000000001298148

Measure resistance between terminals 1 and 2 at sensor side after disconnecting in-vehicle sensor (1) connector M41. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace in-vehicle sensor.



A
B
C
D
E
F
G
H

HAC

J
K
L
M
N
O
P

SUNLOAD SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

SUNLOAD SENSOR

MR20DE/QR25DE


MR20DE/QR25DE : Description

INFOID:000000001162191


COMPONENT DESCRIPTION

Sunload Sensor

The sunload sensor (1) is located on the instrument mask (driver side). It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the auto amp.



Sunload Sensor Circuit



SUNLOAD INPUT PROCESS

The auto amp. also equips a processing circuit which averages the variations in detected sunload over a period of time. This prevents drastic swings in the HAC system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor varies whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the HAC system operation. On the other hand, shortly after entering a long tunnel, the system recognizes the change in sunload, and the system reacts accordingly.

MR20DE/QR25DE : Component Function Check

INFOID:000000001162192

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24. "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-90. "MR20DE/QR25DE : Diagnosis Procedure"](#).
NO >> END.

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162193

1.CHECK VOLTAGE BETWEEN SUNLOAD SENSOR AND GROUND

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector M74 terminal 1 and ground.

SUNLOAD SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+)		(-)	Voltage
Sunload sensor		—	
Connector	Terminal		
M74	1	Ground	

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.

- Turn ignition switch OFF.
- Disconnect auto amp. connector.
- Check continuity between sunload sensor harness connector M74 terminal 2 and auto amp. harness connector M51 terminal 24.

Sunload sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	2	M51	24	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK SUNLOAD SENSOR

- Reconnect sunload sensor connector and auto amp. connector.
- Refer to [HAC-92, "MR20DE/QR25DE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Replace sunload sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.

- Turn ignition switch OFF.
- Disconnect auto amp. connector.
- Check continuity between sunload sensor harness connector M74 terminal 1 and auto amp. harness connector M50 terminal 10.

Sunload sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	1	M50	10	Existed

- Check continuity between sunload sensor harness connector M74 terminal 1 and ground.

Sunload sensor		(-)	Continuity
Connector	Terminal		
M74	1	Ground	Not existed

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Repair harness or connector.

SUNLOAD SENSOR

< COMPONENT DIAGNOSIS >


[AUTOMATIC AIR CONDITIONER]

MR20DE/QR25DE : Component Inspection


INFOID:000000001162194

Measure voltage between auto amp. harness connector (2) M50 terminal 10 and ground.

1. Sunload sensor



- Select a place where sunshine directly on it when checking sunload sensor.



If NG, replace sunload sensor.

M9R

M9R : Description

INFOID:000000001298051

COMPONENT DESCRIPTION


Sunload Sensor

SUNLOAD SENSOR


[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

The sunload sensor (1) is located on the instrument mask (driver side). It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the auto amp.



Sunload Sensor Circuit



SUNLOAD INPUT PROCESS

The auto amp. also equips a processing circuit which averages the variations in detected sunload over a period of time. This prevents drastic swings in the HAC system operation due to small or quick variations in detected sunload.

For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor varies whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily obstructing the sunlight does not cause any change in the HAC system operation. On the other hand, shortly after entering a long tunnel, the system recognizes the change in sunload, and the system reacts accordingly.

M9R : Component Function Check

INFOID:000000001298052

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-93, "M9R : Diagnosis Procedure"](#).
 NO >> END.

M9R : Diagnosis Procedure

INFOID:000000001298053

1.CHECK VOLTAGE BETWEEN SUNLOAD SENSOR AND GROUND

1. Disconnect sunload sensor connector.
2. Turn ignition switch ON.
3. Check voltage between sunload sensor harness connector M74 terminal 1 and ground.

(+)		(-)	Voltage
Sunload sensor		—	
Connector	Terminal		
M74	1	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

SUNLOAD SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

2. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between sunload sensor harness connector M74 terminal 2 and auto amp. harness connector M53 terminal 16.

Sunload sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	2	M53	16	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK SUNLOAD SENSOR

1. Reconnect sunload sensor connector and auto amp. connector.
2. Refer to [HAC-95. "M9R : Component Inspection"](#).

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Replace sunload sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN SUNLOAD SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between sunload sensor harness connector M74 terminal 1 and auto amp. harness connector M53 terminal 19.

Sunload sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M74	1	M53	19	Existed

4. Check continuity between sunload sensor harness connector M74 terminal 1 and ground.

Sunload sensor		—	Continuity
Connector	Terminal		
M74	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

SUNLOAD SENSOR

< COMPONENT DIAGNOSIS >


[AUTOMATIC AIR CONDITIONER]

M9R : Component Inspection


INFOID:000000001298054

Measure voltage between auto amp. harness connector (2) M53 terminal 19 and ground.

1. Sunload sensor



- Select a place where sunshine directly on it when checking sunload sensor.



If NG, replace sunload sensor.

INTAKE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

INTAKE SENSOR


MR20DE/QR25DE

MR20DE/QR25DE : Description


INFOID:000000001162195

Intake Sensor

The intake sensor (1) is located on the A/C unit assembly. It converts air temperature after it passes through the evaporator into a resistance value which is then input to the auto amp.



Intake Sensor Circuit



MR20DE/QR25DE : Component Function Check

INFOID:000000001162196

1.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> Go to Diagnosis Procedure. Refer to [HAC-96, "MR20DE/QR25DE : Diagnosis Procedure"](#).
NO >> END.

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162197

1.CHECK VOLTAGE BETWEEN INTAKE SENSOR AND GROUND

1. Disconnect intake sensor connector.
2. Turn ignition switch ON.
3. Check voltage between intake sensor harness connector M42 terminal 1 and ground.

(+)		(-)	Voltage
Intake sensor		—	
Connector	Terminal		
M42	1	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.

INTAKE SENSOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

3. Check continuity between intake sensor harness connector M42 terminal 2 and auto amp. harness connector M51 terminal 24.

Intake sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	2	M51	24	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK INTAKE SENSOR

Refer to [HAC-98. "MR20DE/QR25DE : Component Inspection"](#).

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Replace intake sensor.

4.CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between intake sensor harness connector M42 terminal 1 and auto amp. harness connector M51 terminal 25.

Intake sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	1	M51	25	Existed

4. Check continuity between intake sensor harness connector M42 terminal 1 and ground.

Intake sensor		—	Continuity
Connector	Terminal		
M42	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INTAKE SENSOR

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MR20DE/QR25DE : Component Inspection

INFOID:000000001162198

Measure resistance between terminals 1 and 2 at sensor side after disconnecting intake sensor (1) connector M42. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.34
-10 (14)	9.62
-5 (23)	7.56
0 (32)	6.00
5 (41)	4.80
10 (50)	3.87
15 (59)	3.15
20 (68)	2.57
25 (77)	2.12
30 (86)	1.76
35 (95)	1.47
40 (104)	1.23
45 (113)	1.04


If NG, replace intake sensor.

M9R



M9R : Description

Intake Sensor

The intake sensor (1) is located on the A/C unit assembly. It converts air temperature after it passes through the evaporator into a resistance value which is then input to the auto amp.



Intake Sensor Circuit



M9R : Component Function Check

1. PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

INFOID:000000001298056

INTAKE SENSOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

- YES >> Go to Diagnosis Procedure. Refer to [HAC-99, "M9R : Diagnosis Procedure"](#).
NO >> END.

M9R : Diagnosis Procedure

INFOID:000000001298057

1. CHECK VOLTAGE BETWEEN INTAKE SENSOR AND GROUND

1. Disconnect intake sensor connector.
2. Turn ignition switch ON.
3. Check voltage between intake sensor harness connector M42 terminal 1 and ground.

(+)		(-)	Voltage
Connector	Terminal	—	
M42	1	Ground	Approx. 5

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between intake sensor harness connector M42 terminal 2 and auto amp. harness connector M53 terminal 16.

Intake sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	2	M53	16	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK INTAKE SENSOR

Refer to [HAC-100, "M9R : Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Replace intake sensor.

4. CHECK CIRCUIT CONTINUITY BETWEEN INTAKE SENSOR AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect auto amp. connector.
3. Check continuity between intake sensor harness connector M42 terminal 1 and auto amp. harness connector M53 terminal 14.

Intake sensor		Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
M42	1	M53	14	Existed

4. Check continuity between intake sensor harness connector M42 terminal 1 and ground.

Intake sensor		(-)	Continuity
Connector	Terminal	—	
M42	1	Ground	Not existed

Is the inspection result normal?

- YES >> Replace auto amp.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

INTAKE SENSOR

[AUTOMATIC AIR CONDITIONER]

< COMPONENT DIAGNOSIS >

NO >> Repair harness or connector.


M9R : Component Inspection

INFOID:000000001298149

Measure resistance between terminals 1 and 2 at sensor side after disconnecting intake sensor (1) connector M42. Refer to table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.34
-10 (14)	9.62
-5 (23)	7.56
0 (32)	6.00
5 (41)	4.80
10 (50)	3.87
15 (59)	3.15
20 (68)	2.57
25 (77)	2.12
30 (86)	1.76
35 (95)	1.47
40 (104)	1.23
45 (113)	1.04

If NG, replace intake sensor.



POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.

MR20DE/QR25DE

MR20DE/QR25DE : Description

INFOID:000000001162199


COMPONENT DESCRIPTION

Auto Amp. (Automatic Amplifier)


The auto amp. (1) has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled.

The auto amp. is unitized with control mechanisms. Signal from various switches and potentiometer temperature control (PTC) are directly entered into auto amp.

Self-diagnosis functions are also built into auto amp. to provide quick check of malfunctions in the auto air conditioner system.




Power Supply and Ground Circuit for Auto Amp.



Potentiometer Temperature Control (PTC)

The PTC (1) is built into the auto amp. It can be set at an interval of 1°C in the 16°C to 28°C temperature range by turning temperature control dial.



MR20DE/QR25DE : Component Function Check

INFOID:000000001162200

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial to AUTO position.
2. Press A/C switch.
3. A/C switch LED turns ON. Confirm that the magnet clutch engages (sound or visual inspection). (Discharge air and blower speed depend on ambient, in-vehicle and set temperatures.)

Does magnet clutch engaged?

YES >> END.

NO >> Go to Diagnosis Procedure. Refer to [HAC-102, "MR20DE/QR25DE : Diagnosis Procedure"](#).

POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

MR20DE/QR25DE : Diagnosis Procedure

INFOID:000000001162201

1. CHECK POWER SUPPLY CIRCUIT FOR AUTO AMP.

1. Disconnect auto amp. connector.
2. Check voltage between auto amp. harness connector M50 terminals 1, 2 and 20 and ground.

Auto amp.		(-)	Ignition switch position		
Connector	Terminal		OFF	ACC	ON
M50	1	Ground	Approx. 0 V	Approx. 0 V	Battery voltage
	2		Battery voltage	Battery voltage	Battery voltage
	20		Approx. 0 V	Approx. 0 V	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK FUSE

Check 10A fuses [Nos. 4, 8 and 17, located in the fuse block (J/B)]. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?

- YES >> Check harness for open circuit. Repair or replace if necessary.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

3. CHECK GROUND CIRCUIT FOR AUTO AMP.

1. Turn ignition switch OFF.
2. Check continuity between auto amp. harness connector M50 terminal 3 and ground.

Auto amp.		(-)	Continuity
Connector	Terminal		
M50	3	Ground	Existed

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Repair harness or connector.

M9R

M9R : Description


INFOID:000000001298059

COMPONENT DESCRIPTION

Auto Amp. (Automatic Amplifier)

The auto amp. (1) has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled. The auto amp. is unitized with control mechanisms. Signal from various switches and potentiometer temperature control (PTC) are directly entered into auto amp.

Self-diagnosis functions are also built into auto amp. to provide quick check of malfunctions in the auto air conditioner system.




JPIIA0192ZZ

POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.

< COMPONENT DIAGNOSIS >


[AUTOMATIC AIR CONDITIONER]

Power Supply and Ground Circuit for Auto Amp.



Potential Temperature Control (PTC)

The PTC (1) is built into the auto amp. It can be set at an interval of 1°C in the 16°C to 28°C temperature range by turning temperature control dial.



M9R : Component Function Check

INFOID:000000001298060

1. CONFIRM SYMPTOM BY PERFORMING THE FOLLOWING OPERATIONAL CHECK

1. Turn fan control dial to AUTO position.
2. Press A/C switch.
3. A/C switch LED turns ON. Confirm that the magnet clutch engages (sound or visual inspection). (Discharge air and blower speed depend on ambient, in-vehicle and set temperatures.)

Does magnet clutch engaged?

YES >> END.

NO >> Go to Diagnosis Procedure. Refer to [HAC-103, "M9R : Diagnosis Procedure"](#).

M9R : Diagnosis Procedure

INFOID:000000001298061

1. CHECK POWER SUPPLY CIRCUIT FOR AUTO AMP.

1. Disconnect auto amp. connector.
2. Check voltage between auto amp. harness connector M53 terminals 9, 21 and 22 and ground.

(+)		(-)	Ignition switch position		
Auto amp.		—	OFF	ACC	ON
Connector	Terminal				
M53	9	Ground	Approx. 0 V	Approx. 0 V	Battery voltage
	21		Approx. 0 V	Approx. 0 V	Battery voltage
	22		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK FUSE

Check 10A fuses [Nos. 4, 8 and 17, located in the fuse block (J/B)]. Refer to [PG-125, "Fuse, Connector and Terminal Arrangement"](#).

POWER SUPPLY AND GROUND CIRCUIT FOR AUTO AMP.

< COMPONENT DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Is the inspection result normal?

YES >> Check harness for open circuit. Repair or replace if necessary.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

3. CHECK GROUND CIRCUIT FOR AUTO AMP.

1. Turn ignition switch OFF.
2. Check continuity between auto amp. harness connector M53 terminal 23 and ground.

Auto amp.		—	Continuity
Connector	Terminal		
M53	23	Ground	Existed

Is the inspection result normal?

YES >> Replace auto amp.

NO >> Repair harness or connector.

ECU DIAGNOSIS

ECM

MR20DE

MR20DE : Reference Value

INFOID:000000001323006

VALUES ON THE DIAGNOSIS TOOL

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

I.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. this IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

Monitor Item	Condition		Values/Status
ENG SPEED	• Run engine and compare CONSULT-III value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See ECM-97. "Diagnosis Procedure" .		
B/FUEL SCHDL	See ECM-97. "Diagnosis Procedure" .		
A/F ALPHA-B1	See ECM-97. "Diagnosis Procedure" .		
COOLAN TEMP/S	• Engine: After warming up		More than 70°C (158°F)
HO2S1 (B1)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 (B1)	<ul style="list-style-type: none"> • Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3V ↔ Approx. 0.6 - 1.0V
HO2S2 MNTR (B1)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Change more than 5 times during 10 seconds.
HO2S2 MNTR (B1)	<ul style="list-style-type: none"> • Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		LEAN ↔ RICH
VHCL SPEED SE	• Turn drive wheels and compare CONSULT-III value with the speedometer indication.		Almost the same speed as speedometer indication
BATTERY VOLT	• Ignition switch: ON (Engine stopped)		11 - 14V
ACCEL SEN 1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0V
		Accelerator pedal: Fully depressed	4.2 - 4.8V
ACCEL SEN 2*	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.5 - 1.0V
		Accelerator pedal: Fully depressed	4.2 - 4.8V
THRL SEN 1-B1	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) • Shift lever: D (CVT), 1st (M/T) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
THRL SEN 2-B1*	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) • Shift lever: D (CVT), 1st (M/T) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
INT/A TEMP SE	• Ignition switch: ON		Indicates intake air temperature
START SIGNAL	• Ignition switch: ON → START → ON		OFF → ON → OFF
CLSD THL POS	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Values/Status	
AIR COND SIG	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	<ul style="list-style-type: none"> Ignition switch: ON 	Shift lever: P or N (CVT), Neutral (M/T)	ON
		Selector lever: Except above	OFF
PW/ST SIGNAL	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Steering wheel: Not being turned	OFF
		Steering wheel: Being turned	ON
LOAD SIGNAL	<ul style="list-style-type: none"> Ignition switch: ON 	Rear window defogger switch: ON and/or Lighting switch: 2nd position	ON
		Rear window defogger switch and lighting switch: OFF	OFF
IGNITION SW	<ul style="list-style-type: none"> Ignition switch: ON → OFF → ON 		ON → OFF → ON
HEATER FAN SW	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Heater fan switch: ON	ON
		Heater fan switch: OFF	OFF
BRAKE SW	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1	<ul style="list-style-type: none"> Engine: After warming up Shift lever: P or N (CVT), Neutral (M/T) Air conditioner switch: OFF No load 	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
IGN TIMING	<ul style="list-style-type: none"> Engine: After warming up Shift lever: P or N (CVT), Neutral (M/T) Air conditioner switch: OFF No load 	Idle	10° - 20° BTDC
		2,000 rpm	25° - 45° BTDC
PURG VOL C/V	<ul style="list-style-type: none"> Engine: After warming up Shift lever: P or N (CVT), Neutral (M/T) Air conditioner switch: OFF No load 	Idle (Accelerator pedal: Not depressed even slightly, after engine starting.)	0%
		2,000 rpm	20% - 90%
INT/V TIM (B1)	<ul style="list-style-type: none"> Engine: After warming up Shift lever: P or N (CVT), Neutral (M/T) Air conditioner switch: OFF No load 	Idle	-5° - 5°CA
		2,000 rpm	Approx. 0° - 20°CA
INT/V SOL (B1)	<ul style="list-style-type: none"> Engine: After warming up Shift lever: P or N (CVT), Neutral (M/T) Air conditioner switch: OFF No load 	Idle	0%
		2,000 rpm	Approx. 0% - 60%
AIR COND RLY	<ul style="list-style-type: none"> Engine: After warming up, idle the engine 	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
FUEL PUMP RLY	<ul style="list-style-type: none"> For 1 seconds after turning ignition switch: ON Engine running or cranking 		ON
	<ul style="list-style-type: none"> Except above 		OFF
THRTL RELAY	<ul style="list-style-type: none"> Ignition switch: ON 		ON

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition		Values/Status
COOLING FAN	<ul style="list-style-type: none"> Engine: After warming up, idle the engine Air conditioner switch: OFF 	Engine coolant temperature is 94 °C (201°F) or less.	OFF
		Engine coolant temperature is between 95°C (203°F) and 99°C (210°F)	LOW*2
		Engine coolant temperature is 100°C (212°F) or more	HIGH*2
HO2S1 HTR (B1)	<ul style="list-style-type: none"> Engine: After warming up Engine speed: Above 3,600 rpm 		ON
	Engine speed: Above 3,600 rpm		OFF
HO2S2 HTR (B1)	<ul style="list-style-type: none"> Engine speed: Below 3,600 rpm after the following conditions are met. <ul style="list-style-type: none"> Engine: After warming up Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		ON
	<ul style="list-style-type: none"> Engine speed: Above 3,600 rpm 		OFF
VEHICLE SPEED	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT-III value with the speedometer indication. 		Almost the same speed as the speedometer indication
IDL A/V LEARN	<ul style="list-style-type: none"> Engine: running 	Idle air volume learning has not been performed yet.	YET
		Idle air volume learning has already been performed successfully.	CMPLT
O2SEN HTR DTY	<ul style="list-style-type: none"> Engine coolant temperature when engine started: More than 80°C (176°F) Engine speed: below 3,600 rpm 		Approx. 30%
AC PRESS SEN	<ul style="list-style-type: none"> Engine: Idle Both A/C switch and blower fan switch: ON (Compressor operates) 		1.0 - 4.0V
VHCL SPEED SE	<ul style="list-style-type: none"> Turn drive wheels and compare CONSULT-III value with the speedometer indication. 		Almost the same speed as the speedometer indication
SET VHCL SPD	<ul style="list-style-type: none"> Engine: Running 	ASCD: Operating	The preset vehicle speed is displayed
MAIN SW	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed	ON
		MAIN switch: Released	OFF
CANCEL SW	<ul style="list-style-type: none"> Ignition switch: ON 	CANCEL switch: Pressed	ON
		CANCEL switch: Released	OFF
RESUME/ACC SW	<ul style="list-style-type: none"> Ignition switch: ON 	RESUME/ACCELERATE switch: Pressed	ON
		RESUME/ACCELERATE switch: Released	OFF
SET SW	<ul style="list-style-type: none"> Ignition switch: ON 	SET/COAST switch: Pressed	ON
		SET/COAST switch: Released	OFF
BRAKE SW1 (ASCD brake switch)	<ul style="list-style-type: none"> Ignition switch: ON 	<ul style="list-style-type: none"> Brake pedal: Fully released (CVT) Brake pedal and clutch pedal: Fully released (M/T) 	ON
		<ul style="list-style-type: none"> Brake pedal: Slightly depressed (CVT) Brake pedal and/or clutch pedal: Slightly depressed (M/T) 	OFF
BRAKE SW2 (Stop lamp switch)	<ul style="list-style-type: none"> Ignition switch: ON 	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
VHCL SPD CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
LO SPEED CUT	<ul style="list-style-type: none"> Ignition switch: ON 		NON
AT OD MONITOR	<ul style="list-style-type: none"> Ignition switch: ON 		OFF
AT OD CANCEL	<ul style="list-style-type: none"> Ignition switch: ON 		OFF

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM


< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Values/Status
CRUISE LAMP	<ul style="list-style-type: none"> Ignition switch: ON 	MAIN switch: Pressed at the 1st time → at the 2nd time ON → OFF
SET LAMP	<ul style="list-style-type: none"> MAIN switch: ON When vehicle speed: Between 40 km/h (25 MPH) and 144 km/h (89 MPH) 	ASCD: Operating ON
		ASCD: Not operating OFF

*: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

TERMINAL LAYOUT




PHYSICAL VALUES

NOTE:

- ECM is located in the engine room left side near battery.
- When disconnecting ECM harness connector (A), loosen (C) it with levers as far as they will go as shown in the figure.

1 : ECM
B : Fasten

- Connect a break-out box (EG17550000) and harness adapter (EG17550400) between the ECM and ECM harness connector.
- Use extreme care not to 2 pins at one time.
- Data is for comparison and may not be exact.
- Specification data are reference values and are measured between each terminal and ground.
- Pulse signal is measured by CONSULT-III.



Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	---		Signal name	Input/Output		
1	Ground	L	Throttle control motor (Open)	Output	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	3.2V★
2	Ground	Y/R	Throttle control motor relay power supply	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

JMBIA0324GB

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
3	Ground	BR/Y	Heated oxygen sensor 1 heater	Output	[Engine is running] • Warm-up condition • Engine speed: Below 3,600 rpm	2.9 - 8.8V★
					[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: below 3,600 rpm	BATTERY VOLTAGE (11-14V)
4	Ground	P	Throttle control motor (Close)	Output	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	1.8V★
5	Ground	R	Heated oxygen sensor 2 heater	Output	[Engine is running] • Engine speed: Below 3,600 rpm after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	10V★
					[Ignition switch: ON] • Engine stopped [Engine is running] • Engine speed: Above 3,600 rpm	BATTERY VOLTAGE (11 - 14V)
9	Ground	W/D	EVAP canister purge volume control solenoid valve	Output	[Engine is running] • Idle speed • Accelerator pedal: Not depressed even slightly, after engine starting	BATTERY VOLTAGE (11 - 14V)★
					[Engine is running] • Engine speed: About 2,000 rpm (More than 100 seconds after starting engine.)	
10 11	Ground	B	ECM ground	—	[Engine is running] • Idle speed	Body ground





A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
15	Ground	G	Throttle control motor relay	Output	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)
					[Ignition switch: ON]	0 - 1.0V
17 18 21 22	Ground	V BR/Y O Y	Ignition signal No. 1 Ignition signal No. 2 Ignition signal No. 4 Ignition signal No. 3	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	0 - 0.3V★  JMBIA0329GB
					[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0.2 - 0.5V★  JMBIA0330GB
23	Ground	B/O	Fuel pump relay	Output	[Ignition switch: ON] • For 1 second after turning ignition switch ON [Engine is running]	0 - 1.0V
25 29 30 31	Ground	R U GR L	Fuel injector No. 4 Fuel injector No. 3 Fuel injector No. 2 Fuel injector No. 1	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	BATTERY VOLTAGE (11 - 14V)★  JMBIA0331GB
					[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	BATTERY VOLTAGE (11 - 14V)★  JMBIA0332GB
32	Ground	R/B	ECM relay (Self shut-off)	Output	[Engine is running] [Ignition switch: OFF] • A few seconds after turning ignition switch OFF	0 - 1.0V
					[Ignition switch: OFF] • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
33	Ground	Y	Throttle position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	More than 0.36V
					[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	Less than 4.75V
34	Ground	R	Throttle position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	Less than 4.75V
					[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	More than 0.36V
36	Ground	B	Sensor ground (Throttle position sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V
37	Ground	W	Knock sensor	Input	[Engine is running] • Idle speed	2.5V
38	Ground	P	Engine coolant temperature sensor	Input	[Engine is running]	0 - 4.8V Output voltage varies with engine coolant temperature.
40	Ground	B	Sensor ground (Knock sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V
41	Ground	G	Refrigerant pressure sensor	Input	[Engine is running] • Warm-up condition • Both A/C switch and blower fan motor switch: ON (Compressor operates)	1.0 - 4.0V
44	Ground	O	Sensor ground (Engine coolant temperature sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V
45	Ground	BR	Mass air flow sensor	Input	[Engine is running] • Warm-up condition • Idle speed	0.9 - 1.2V
					[Engine is running] • Warm-up condition • Engine speed: 2,500 rpm	1.5 - 1.8V
46	Ground	Y	Intake air temperature sensor	Input	[Engine is running]	0 - 4.8V Output voltage varies with intake air temperature.
48	Ground	R/B	Sensor ground (Refrigerant pressure sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >




[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
49	Ground	Y	Heated oxygen sensor 1	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0 - 1.0V
50	Ground	Y	Heated oxygen sensor 2	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0V
52	Ground	LG	Sensor ground (Mass air flow sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V
55	Ground	O	Sensor power supply (Intake air temperature sensor)	—	[Engine is running] • Warm-up condition • Idle speed	0V
56	Ground	B	Sensor ground (Heated oxygen sensor 1)	—	[Engine is running] • Warm-up condition • Idle speed	0 - 4.8V Output voltage varies with engine coolant temperature.
59	Ground	SB	Sensor ground (Heated oxygen sensor 2)	—	[Engine is running] • Warm-up condition • Idle speed	0V
61	Ground	Y	Crankshaft position sensor (POS)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	4.0V★ 
					[Engine is running] • Engine speed: 2,000 rpm	4.0V★ 
62	Ground	B	Sensor ground [Crankshaft position sensor (POS)]	—	[Engine is running] • Warm-up condition • Idle speed	0V
63	Ground	B	Sensor ground [Camshaft position sensor (PHASE)]	—	[Engine is running] • Warm-up condition • Idle speed	0V

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
65	Ground	R	Camshaft position sensor (PHASE)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	1.0 - 2.0★  JMBIA0335GB
					[Engine is running] • Engine speed is 2,000 rpm	1.0 - 2.0★  JMBIA0336GB
69	Ground	W/B	PNP switch	Input	[Ignition switch: ON] • Shift lever: P or N (CVT), Neutral (M/T)	BATTERY VOLTAGE (11 - 14V)
					[Ignition switch: ON] • Shift lever: Except above	0V
72	Ground	L	Sensor power supply (Throttle position sensor)	—	[Ignition switch: ON]	5V
73	Ground	Y/R	Intake valve timing control solenoid valve	Output	[Engine is running] • Warm-up condition • Idle speed	0V
					[Engine is running] • Warm-up condition • Engine speed: 2,000rpm	7 - 10V★  JMBIA0337GB
74	Ground	L	Sensor power supply (Refrigerant pressure sensor)	Input	[Ignition switch: ON]	5V
75	Ground	G	Sensor power supply [Crankshaft position sensor (POS)]	—	[Ignition switch: ON]	5V
78	Ground	LG	Sensor power supply [Camshaft position sensor (PHASE)]	—	[Ignition switch: ON]	5V
83	Ground	P	CAN communication line	Input/Output	—	—
84	Ground	L	CAN communication line	Input/Output	—	—
88	Ground	O	Data link connector	Input/Output	[Ignition switch: ON] • CONSULT-III or GST: Disconnected	10.5V
93	Ground	W/L	Ignition switch	Input	[Ignition switch: OFF]	0V
					[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/ Output		
94	Ground	V	ASCSD steering switch	Input	[Ignition switch: ON] • ASCD steering switch: OFF	4V
					[Ignition switch: ON] • MAIN switch: Pressed	0V
					[Ignition switch: ON] • CANCEL switch: Pressed	1V
					[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3V
					[Ignition switch: ON] • SET/COAST switch: Pressed	2V
95	Ground	B	Sensor ground (ASCSD steering switch)	—	[Engine is running] • Warm-up condition • Idle speed	0V
99	Ground	R/W	Stop lamp switch	Input	[Ignition switch: OFF] • Brake pedal: Fully released	0V
					[Ignition switch: OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)
100	Ground	G/B	ASCSD brake switch	Input	[Ignition switch: ON] • Brake pedal: Slightly depressed (CVT) • Brake pedal and clutch pedal: Slightly depressed (M/T)	0V
					[Ignition switch: ON] • Brake pedal: Fully released (CVT) • Brake pedal and/or clutch pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)
102	Ground	BR/Y	Sensor power supply (Accelerator pedal position sensor 2)	—	[Ignition switch: ON]	5V
104	Ground	B	Sensor ground (Accelerator pedal position sensor 2)	—	[Engine is running] • Warm-up condition • Idle speed	0V
105	Ground	G	Power supply for ECM	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
106	Ground	O	Sensor power supply (Accelerator pedal position sensor 1)	—	[Ignition switch: ON]	5V
108	Ground	B	ECM ground	—	[Engine is running] • Idle speed	Body ground
110	Ground	R	Accelerator pedal position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.6 - 0.9V
					[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	3.9 - 4.7V

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No.		Wire color	Description		Condition	Value (Approx.)
+	—		Signal name	Input/Output		
103	Ground	GR	Accelerator pedal position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.3 - 0.6V
					[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	1.95 - 2.4V
111	Ground	B/Y	Sensor ground (Accelerator pedal position sensor 1)	—	[Engine is running] • Warm-up condition • Idle speed	0V

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

QR25DE

QR25DE : Reference Value

INFOID:000000001323003

VALUES ON THE DIAGNOSIS TOOL

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

I.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. this IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

Monitor Item	Condition		Values/Status
ENG SPEED	• Run engine and compare CONSULT-III value with the tachometer indication.		Almost the same speed as the tachometer indication.
MAS A/F SE-B1	See ECQ-99, "Diagnosis Procedure" .		
B/FUEL SCHDL	See ECQ-99, "Diagnosis Procedure" .		
A/F ALPHA-B1	See ECQ-99, "Diagnosis Procedure" .		
COOLAN TEMP/S	• Engine: After warming up		More than 70°C (158°F)
A/F SEN1 (B1)	• Engine: After warming up	Maintaining engine speed at 2,000 rpm	Fluctuates around 2.2 V
HO2S2 (B1)	<ul style="list-style-type: none"> • Revving engine from idle up to 3,000 rpm quickly after the following conditions are met. - Engine: After warming up - After keeping engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 		0 - 0.3V ↔ Approx. 0.6 - 1.0V
VHCL SPEED SE	• Turn drive wheels and compare CONSULT-III value with the speedometer indication.		Almost the same speed as speedometer indication
BATTERY VOLT	• Ignition switch: ON (Engine stopped)		11 - 14V
ACCEL SEN 1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.9V
		Accelerator pedal: Fully depressed	4.0 - 4.8V
ACCEL SEN 2*1	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	0.6 - 0.9V
		Accelerator pedal: Fully depressed	3.9 - 4.8V
THRL SEN 1-B1	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) • Shift lever: D (CVT), 1st (M/T) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
THRL SEN 2-B1*1	<ul style="list-style-type: none"> • Ignition switch: ON (Engine stopped) • Shift lever: D (CVT), 1st (M/T) 	Accelerator pedal: Fully released	More than 0.36V
		Accelerator pedal: Fully depressed	Less than 4.75V
INT/A TEMP SE	• Ignition switch: ON		Indicates intake air temperature

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Values/Status	
START SIGNAL	• Ignition switch: ON → START → ON	OFF → ON → OFF	
CLSD THL POS	• Ignition switch: ON (Engine stopped)	Accelerator pedal: Fully released	ON
		Accelerator pedal: Slightly depressed	OFF
AIR COND SIG	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates.)	ON
P/N POSI SW	• Ignition switch: ON	Shift lever: P or N (CVT), Neutral (M/T)	ON
		Selector lever: Except above	OFF
LOAD SIGNAL	• Ignition switch: ON	Rear window defogger switch: ON and/or Lighting switch: 2nd position	ON
		Rear window defogger switch and lighting switch: OFF	OFF
IGNITION SW	• Ignition switch: ON → OFF → ON	ON → OFF → ON	
BRAKE SW	• Ignition switch: ON	Brake pedal: Fully released	OFF
		Brake pedal: Slightly depressed	ON
INJ PULSE-B1	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle	2.0 - 3.0 msec
		2,000 rpm	1.9 - 2.9 msec
IGN TIMING	• Engine: After warming up, idle the engine	BTDC 9.75°	
CAL/LD VALUE	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle	10% - 35%
		2,500 rpm	10% - 35%
MASS AIRFLOW	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle	1.0 - 4.0 g·m/s
		2,500 rpm	4.0 - 10.0 g·m/s
PURG VOL C/V	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle (Accelerator pedal: Not depressed even slightly, after engine starting.)	0%
		2,000 rpm	20% - 90%
INT/V TIM (B1)	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle	-5° - 5°C
		2,000 rpm	Approx. 0° - 20°C
INT/V SOL (B1)	• Engine: After warming up • Shift lever: P or N (CVT), Neutral (M/T) • Air conditioner switch: OFF • No load	Idle	0%
		2,000 rpm	Approx. 0% - 60%
AIR COND RLY	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	OFF
		Air conditioner switch: ON (Compressor operates)	ON
FUEL PUMP RLY	• For 1 seconds after turning ignition switch: ON • Engine running or cranking		ON
	• Except above		OFF
THRTL RELAY	• Ignition switch: ON		ON

ECM


< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Values/Status
COOLING FAN	Engine coolant temperature is 94°C (201°F) or less.	OFF
	Engine coolant temperature is between 94°C (203°F) and 99°C (210°F)	LOW
	Engine coolant temperature is between 94°C (203°F) and 99°C (210°F)	MID
	Engine coolant temperature is 100°C (212°F) or more	HIGH
HO2S2 HTR (B1)	<ul style="list-style-type: none"> • After the following conditions are met. - Engine: After warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	ON
	• For 2 minutes after starting engine	OFF
I/P PULLY SPD	• Vehicle speed: More than 20 km/h (12 MPH)	Almost the same speed as the tachometer indication
A/F LEARN-B1	• Engine: After warming up, idle the engine	-16.500 - 10.359%
VEHICLE SPEED	• Turn drive wheels and compare CONSULT-III value with the speedometer indication.	Almost the same speed as the speedometer indication
TRVL AFTER MIL	<ul style="list-style-type: none"> • Ignition switch: ON 	Vehicle has traveled after MI has turned ON. 0 - 65,535 km (0 - 40,723 miles)
A/F S1 HTR (B1)	• Engine: After warming up, idle the engine (More than 140 seconds after starting engine.)	4 - 100%
AC PRESS SEN	<ul style="list-style-type: none"> • Engine: Idle • Both A/C switch and blower fan switch: ON (Compressor operates) 	1.0 - 4.0V
VHCL SPEED SE	• Turn drive wheels and compare CONSULT-III value with the speedometer indication.	Almost the same speed as the speedometer indication
SET VHCL SPD	<ul style="list-style-type: none"> • Engine: Running 	ASCD: Operating The preset vehicle speed is displayed

*1: Accelerator pedal position sensor 2 signal and throttle position sensor 2 signal are converted by ECM internally. Thus, they differ from ECM terminals voltage signal.

TERMINAL LAYOUT



PHYSICAL VALUES





NOTE:

- ECM is located near the battery in the engine room.
- Specification data are reference values and are measured between each terminal and ground.
- Pulse signal is measured by CONSULT-III.

ECM

< ECU DIAGNOSIS >



[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
1 (L/Y)	121 (B)	Throttle control motor (Open)	Output	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	0 - 14V★  JMBIA0083GB
2 (R)	121 (B)	Throttle control motor relay power supply	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
3 (P)	121 (B)	Throttle control motor (Close)	Output	[Ignition switch: ON] • For 10 second after turning ignition switch ON • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	0 - 14V★
4 (R)	121 (B)	A/F sensor 1 heater	Output	[Engine is running] • Warm-up condition • Idle speed	0 - 14V★  JMBIA0082GB
5 (B)	—	ECM ground	—	—	—
6 (W)	121 (B)	Crankshaft position sensor (POS)	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	1.0 - 4.0V★  JMBIA0091GB
				[Engine is running] • Engine speed: 2,000 rpm	1.0 - 4.0V★  JMBIA0092GB

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]




Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
9 (R)	121 (B)	Ignition signal No. 3	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	0 - 4.0V★  20mSec/div 2V/div <small>JMBIA0085GB</small>
10 (SB)		Ignition signal No. 2			
28 (W)		Ignition signal No. 1			
29 (G)		Ignition signal No. 4			
11 (B)	—	Sensor ground [Crankshaft position sensor (POS)]	—	—	—
12 (P)	121 (B)	Sensor power supply [Crankshaft position sensor (POS)]	—	[Ignition switch: ON]	5V
15 (L)	121 (B)	Sensor power supply (Refrigerant pressure sensor)	—	[Ignition switch: ON]	5V
18 (V)	—	Sensor ground (Refrigerant pressure sensor)	—	—	—
20 (G)	121 (B)	ECM relay (Self shut-off)	Output	[Engine is running] [Ignition switch: OFF] • A few seconds after turning ignition switch OFF	0 - 1.5V
				[Ignition switch: OFF] • More than a few seconds after turning ignition switch OFF	BATTERY VOLTAGE (11 - 14V)
21 (P)	121 (B)	Fuel injector No. 4	Output	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	BATTERY VOLTAGE (11 - 14V)★  50mSec/div 10V/div <small>JMBIA0089GB</small>
23 (BR)		Fuel injector No. 3			
59 (GR)		Fuel injector No. 2			
60 (LG)		Fuel injector No. 1			

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS >




[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
22 (LG)	121 (B)	Throttle control motor relay	Output	[Ignition switch: ON → OFF]	0 - 1.5V ↓ BATTERY VOLTAGE (11 - 14V)
				[Ignition switch: ON]	0 - 1.0V
25 (G)	121 (B)	Camshaft position sensor (PHASE)	Input	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle	1.0 - 4.0★  2V/div <small>JMBIA0093GB</small>
				[Engine is running] <ul style="list-style-type: none"> • Engine speed is 2,000 rpm 	1.0 - 4.0★  2V/div <small>JMBIA0094GB</small>
27 (LG)	121 (B)	PNP switch	Input	[Ignition switch: ON] <ul style="list-style-type: none"> • Shift lever: P or N (CVT), Neutral (M/T) 	BATTERY VOLTAGE (11 - 14V)
				[Ignition switch: ON] <ul style="list-style-type: none"> • Shift lever: Except above 	0V
30 (Y)	—	Sensor ground [Camshaft position sensor (PHASE)]	—	—	—
33 (P)	121 (B)	Sensor power supply [Camshaft position sensor (PHASE)]	—	[Ignition switch: ON]	5V
34 (W)	121 (B)	Sensor power supply (Throttle position sensor)	—	[Ignition switch: ON]	5V
37 (LG)	18 (V)	Refrigerant pressure sensor	Input	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Both A/C switch and blower fan motor switch: ON (Compressor operates) 	1.0 - 4.0V
39 (Y)	121 (B)	Heated oxygen sensor 2 heater	Output	[Engine is running] <ul style="list-style-type: none"> • After the following conditions are met <ul style="list-style-type: none"> - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load 	0 - 14V★  5V/div <small>JMBIA0037GB</small>
				[Ignition switch: ON] <ul style="list-style-type: none"> • Engine stopped [Engine is running] <ul style="list-style-type: none"> • For 2 minutes after starting engine • Idle speed 	BATTERY VOLTAGE (11 - 14V)

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
42 (Y)	121 (B)	EVAP canister purge volume control solenoid valve	Output	[Engine is running] • Idle speed	BATTERY VOLTAGE (11 - 14V)★ 50mSec/div  20V/div <small>JMBIA0087GB</small>
				[Engine is running] • Engine speed: About 2,000 rpm (More than 100 seconds after starting engine.)	BATTERY VOLTAGE (11 - 14V)★ 50mSec/div  10V/div <small>JMBIA0088GB</small>
44 (O)	121 (B)	Knock sensor 2	—	[Engine is running] • Warm-up condition • Idle speed	2.4V
46 (L)	—	Sensor ground (Heated oxygen sensor 2)	—	—	—
48 (Y)	—	Sensor ground (Intake air temperature sensor)	—	—	—
51 (L)	—	Sensor ground (Mass air flow sensor)	—	—	—
52 (R)	—	Sensor ground (Throttle position sensor)	—	—	—
53 (LG)	121 (B)	A/F sensor 1	Input	[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8V Output voltage varies with air fuel ratio.
54 (Y)	121 (B)	A/F sensor 1 (bank 1)	Input	[Ignition switch: ON]	2.2V
56 (O)	—	Sensor ground (Engine coolant temperature sensor)	—	—	—
62 (O)	121 (B)	Intake valve timing control solenoid valve	Output	[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14V)
				[Engine is running] • Warm-up condition • Engine speed: 2,000rpm	0 - 14V★ 2mSec/div  5V/div <small>JMBIA0095GB</small>
63 (W)	121 (B)	Knock sensor 1	Input	[Engine is running] • Idle speed	2.4V

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
65 (P)	46 (L)	Heated oxygen sensor 2	Input	[Engine is running] • Revving engine from idle to 3,000 rpm quickly after the following conditions are met - Engine: after warming up - Keeping the engine speed between 3,500 and 4,000 rpm for 1 minute and at idle for 1 minute under no load	0 - 1.0V
67 (W)	48 (Y)	Intake air temperature sensor	Input	[Engine is running]	0 - 4.8V Output voltage varies with intake air temperature.
71 (G)	52 (R)	Throttleposition sensor 1	Input	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	More than 0.36V
				[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	Less than 4.75V
72 (B)	52 (R)	Throttle position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully released	Less than 4.75V
				[Ignition switch: ON] • Engine stopped • Shift lever: D (CVT), 1st (M/T) • Accelerator pedal: Fully depressed	More than 0.36V
73 (P)	51 (L)	Mass air flow sensor	Input	[Engine is running] • Warm-up condition • Idle speed	0.9 - 1.1V
				[Engine is running] • Warm-up condition • Engine speed: 2,500 rpm	1.4 - 1.7V
75 (P)	56 (O)	Engine coolant temperature sensor	Input	[Engine is running]	0 - 4.8V Output voltage varies with engine coolant temperature.
78 (L)	121 (B)	Fuel pump relay	Output	[Ignition switch: ON] • For 1 second after turning ignition switch ON	0 - 1.5V
				[Engine is running] [Ignition switch: ON] • More than 1 second after turning ignition switch ON	BATTERY VOLTAGE (11 - 14V)
82 (L)	121 (B)	CAN communication line	Input/ Output	—	—
84 (R)	121 (B)	Stop lamp switch	Input	[Ignition switch: OFF] • Brake pedal: Fully released	0V
				[Ignition switch: OFF] • Brake pedal: Slightly depressed	BATTERY VOLTAGE (11 - 14V)

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	—	Signal name	Input/ Output			
87 (Y)	121 (B)	Data link connector	Input/ Output	[Ignition switch: ON] • CONSULT-III or GST: Dis- connected	BATTERY VOLTAGE (11 - 14V)	A B
89 (O)	121 (B)	Power supply for ECM (Back- up)	Input	[Ignition switch: OFF]	BATTERY VOLTAGE (11 - 14V)	C
90 (P)	121 (B)	CAN communication line	Input/ Output	—	—	D
93 (O)	121 (B)	Ignition switch	Input	[Ignition switch: OFF]	0V	E
				[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)	
94 (GR)	121 (B)	ASCD brake switch	Input	[Ignition switch: ON] • Brake pedal: Slightly de- pressed (CVT) • Brake pedal or clutch pedal: Slightly depressed (M/T)	0V	F
				[Ignition switch: ON] • Brake pedal: Fully released (CVT) • Brake pedal and clutch pedal: Fully released (M/T)	BATTERY VOLTAGE (11 - 14V)	G
98 (B)	—	Sensor ground (Accelerator pedal position sen- sor 2)	—	—	—	H
99 (W)	—	Sensor ground (Accelerator pedal position sen- sor 1)	—	—	—	HAC
100 (B)	—	Sensor ground (ASCD steering switch)	—	—	—	J
105 (V)	121 (B)	Sensor power supply (Accelerator pedal position sen- sor 2)	—	[Ignition switch: ON]	5V	K
106 (G)	99 (W)	Accelerator pedal position sen- sor 2	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully re- leased	0.3 - 0.6V	L
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully de- pressed	1.95 - 2.4V	M
107 (R)	98 (B)	Accelerator pedal position sen- sor 1	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully re- leased	0.6 - 0.9V	N
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully de- pressed	3.9 - 4.7V	O P

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	—	Signal name	Input/ Output		
108 (V)	100 (B)	ASCD steering switch	Input	[Ignition switch: ON] • ASCD steering switch: OFF	4V
				[Ignition switch: ON] • MAIN switch: Pressed	0V
				[Ignition switch: ON] • CANCEL switch: Pressed	1V
				[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3V
				[Ignition switch: ON] • SET/COAST switch: Pressed	2V
113 (LG)	121 (B)	Sensor power supply (Accelerator pedal position sensor 1)	—	[Ignition switch: ON]	5V
115 (R)	121 (B)	Power supply for ECM	Input	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14V)
118 (B) 119 (B) 120 (B) 121 (B)	—	ECM ground	—	—	—

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

M9R

M9R : Reference Value

INFOID:000000001529819

VALUES ON THE DIAGNOSIS TOOL

Remarks:

- Specification data are reference values.
 - Specification data are output/input values which are detected or supplied by the ECM at the connector.
- * Specification data may not be directly related to their components signals/values/operations.

I.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. this IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.

Monitor item	condition		Values/Status
IGN SW	• Ignition switch: ON → OFF → ON		PRESENT → ABSENT → PRESENT
GLOW CONT	• Engine: Running (Less than 60 seconds after starting engine.)	Engine coolant: Less than 50°C (122°F)	ACTIV
		Engine coolant: More than 80°C (176°F)	INACT
CLUTCH STATUS	• Ignition switch: ON	Clutch pedal: Fully released	NO
		Clutch pedal: Slightly depressed	YES
A/C RELAY	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	NODON
		Air conditioner switch: ON	DONE
ENGINE STATUS	• Ignition switch: ON		+APC
	• Engine: Running (Less than 60 seconds after starting engine.)		RUN
	• Ignition switch: OFF (A few seconds after turning ignition switch OFF)		OFF

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition	Values/Status		
BPP SW	• Ignition switch: ON	Brake pedal: Fully released	RELS D	A
		Brake pedal: Slightly depressed	PRSS D	
A/C APPLD	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	NO	B
		Air conditioner switch: ON	YES	
GLOW CONT SIGNAL	• Engine: Running (Less than 60 seconds after starting engine.)	Engine coolant: Less than 50°C (122°F)	PRESENT	C
		Engine coolant: More than 80°C (176°F)	ABSENT	
COOLING FAN LOW	• Engine: After warming up, idle the engine • Air conditioner switch: OFF	Engine coolant: 99°C (210°F) or less	ACTIV	D
		Engine coolant: 102°C (216°F) or more	INACT	
COOLING FAN HIGH	• Engine: After warming up, idle the engine • Air conditioner switch: OFF	Engine coolant: 99°C (210°F) or less	INACT	E
		Engine coolant: 102°C (216°F) or more	ACTIV	
ECM-TCM COMM	• Ignition switch: ON	ECM-TCM communication: Communicated	PRESENT	F
		ECM-TCM communication: Not communicated	ABSENT	
A/C COMP	• Engine: After warming up, idle the engine	Air conditioner switch: OFF	INACT	G
		Air conditioner switch: ON	ACTIV	
NATS CODE RGST	• Ignition switch: ON	NATS code registration: Not registered.	NO	H
		NATS code registration: Registered.	YES	
CPP SW	• Ignition switch: ON	Clutch pedal: Fully released	INACT	I
		Clutch pedal: Slightly depressed	ACTIV	
EGR BYPAS S/V	• Engine Running	Not warm-up condition	INACT	HAC
		Warm-up condition	ACTIV	
TURBO COOL PUMP	• Engine Running	Engine coolant temperature: Less than 79°C (174°)	INACT	J
		Engine coolant temperature: More than 80°C (176°)	ACTIV	
RGN INCMP STAT1	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC	K
		Incomplete condition of DPF regeneration: Engine is running.	RUN	L
		Incomplete condition of DPF regeneration: During self shut-off	OFF	
RGN INCMP STAT2	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC	M
		Incomplete condition of DPF regeneration: Engine is running.	RUN	N
		Incomplete condition of DPF regeneration: During self shut-off	OFF	
RGN INCMP STAT3	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC	O
		Incomplete condition of DPF regeneration: Engine is running.	RUN	P
		Incomplete condition of DPF regeneration: During self shut-off	OFF	

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition	Values/Status	
RGN INCMP STAT4	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT5	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT6	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT7	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT8	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT9	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN INCMP STAT10	• Ignition switch: ON	Incomplete condition of DPF regeneration: Ignition switch ON	+APC
		Incomplete condition of DPF regeneration: Engine is running.	RUN
		Incomplete condition of DPF regeneration: During self shut-off	OFF
RGN REQ STAT1	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1
		Incomplete condition of DPF regeneration: Engine starting	STAT2
		Incomplete condition of DPF regeneration: Engine running	STAT3
		Incomplete condition of DPF regeneration: During self shut-off	STAT4

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition	Values/Status		
RGN REQ STAT2	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	A
		Incomplete condition of DPF regeneration: Engine starting	STAT2	B
		Incomplete condition of DPF regeneration: Engine running	STAT3	C
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	
RGN REQ STAT3	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	D
		Incomplete condition of DPF regeneration: Engine starting	STAT2	E
		Incomplete condition of DPF regeneration: Engine running	STAT3	F
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	
RGN REQ STAT4	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	G
		Incomplete condition of DPF regeneration: Engine starting	STAT2	H
		Incomplete condition of DPF regeneration: Engine running	STAT3	HAC
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	
RGN REQ STAT5	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	J
		Incomplete condition of DPF regeneration: Engine starting	STAT2	K
		Incomplete condition of DPF regeneration: Engine running	STAT3	
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	
RGN REQ STAT6	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	L
		Incomplete condition of DPF regeneration: Engine starting	STAT2	M
		Incomplete condition of DPF regeneration: Engine running	STAT3	N
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	
RGN REQ STAT7	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1	O
		Incomplete condition of DPF regeneration: Engine starting	STAT2	P
		Incomplete condition of DPF regeneration: Engine running	STAT3	
		Incomplete condition of DPF regeneration: During self shut-off	STAT4	

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition	Values/Status	
RGN REQ STAT8	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1
		Incomplete condition of DPF regeneration: Engine starting	STAT2
		Incomplete condition of DPF regeneration: Engine running	STAT3
		Incomplete condition of DPF regeneration: During self shut-off	STAT4
RGN REQ STAT9	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1
		Incomplete condition of DPF regeneration: Engine starting	STAT2
		Incomplete condition of DPF regeneration: Engine running	STAT3
		Incomplete condition of DPF regeneration: During self shut-off	STAT4
RGN REQ STAT10	• Ignition switch: ON	Incomplete condition of DPF regeneration: Engine stopped	STAT1
		Incomplete condition of DPF regeneration: Engine starting	STAT2
		Incomplete condition of DPF regeneration: Engine running	STAT3
		Incomplete condition of DPF regeneration: During self shut-off	STAT4
EGR COOL BYPAS/V	• Engine Running	Not warm-up condition	INACT
		Warm-up condition	ACTIV
EGR/V TRG ANGLE	• Ignition switch: ON		Less than 1%
	• Engine idle		Approx. 20 - 30%
TRG RAIL PRES	• Engine Running		Approx. 10 bar
TRG BOOST PRES	• Engine Running	Idle speed	Approx. Atmospheric pressure
		Engine speed: 2000 rpm	Approx. 10 bar (1000 mbar)
INJ VOLUME	• Engine Running	Idle speed	Approx. 5 - 10 mg/cp
		Engine speed: 2000 rpm	Approx. 5 - 10 mg/cp
ACCEL PDL POS	• Ignition switch: ON	Accelerator pedal: Fully released	0%
		Accelerator pedal: Fully depressed	100%
BARO PRES	• Ignition switch: ON		Altitude Approx. 0 m: Approx. 1.0062 bar (100.62 mbar, 1.062kg / cm ² , 14.59 psi) Approx. 1,000 m: Approx. 0.8895 bar (88.95 mbar, 0.907kg /cm ² , 12.90 psi) Approx. 1,500 m: Approx. 0.8316 bar (83.16 mbar, 0.848 kg /cm ² , 12.06 psi) Approx. 2,000 m: Approx. 0.7836 bar (78.36 mbar, 0.799 kg /cm ² , 11.36 psi)
FUEL RAIL PRES	• Engine Running		Approx. 9 - 11 bar

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition		Values/Status
TC BOOST PRES	• Engine Running	Idle speed	Approx. Atmospheric pressure
		Engine speed: 2000 rpm	Approx. 10 bar (1000 mbar)
EGR VALVE POS	• Engine idle		Approx. 20 - 90%
ENG SPEED	• Run engine and compare CONSULT-III value with the tachometer indication.		Almost the same speed as the tachometer indication
INT AIR TEMP	• Ignition switch: ON		Indicates intake air temperature
EXT AIR TEMP	• Ignition switch: ON		Indicates external air temperature
FUEL TEMP	• Ignition switch: ON		Indicates fuel temperature
ENG COOLAN TEMP	• Ignition switch: ON		Indicates engine coolant temperature
BAT VOLT	• Ignition switch: ON		11 - 14V
EGR POS/S VOLT	• Engine idle		Approx. 1 - 4.2V
FRP SEN VOLT	• Engine Running	Idle speed	Approx. 1V (1000 mV)
		Engine speed: 2000 rpm	Approx. 1.8V (1800 mV)
FUEL TEMP/S VOLT	• Engine Running		0.3 - 5.0V (300 - 5000 mV) Output voltage varies with fuel temperature.
IAT SEN VOLT	• Engine Running		0.3 - 5.0V (300 - 5000 mV) Output voltage varies with intake air temperature.
ECT SEN VOLT	• Engine Running		0.3 - 5.0V (300 - 5000 mV) Output voltage varies with engine coolant temperature.
APP SEN1 VOLT	• Ignition switch: ON	Accelerator pedal: Fully released	0.6 - 4.6V (600 - 4600 mV)
		Accelerator pedal: Fully depressed	Less than 5V (5000 mV)
APP SEN2 VOLT	• Ignition switch: ON	Accelerator pedal: Fully released	More than 0.3V (300 mV)
		Accelerator pedal: Fully depressed	Less than 2.5V (2500 mV)
TRG IDLE SPD	• Engine: After warming up, idle the engine		750 ± 50 tr/min
TC BST PR/S VOLT	• Engine Running	Idle speed	Approx. 1.2V (1200 mV)
		Engine speed: 2000 rpm	Approx. 1.8V (1800 mV)
MAF SEN VOLT	<ul style="list-style-type: none"> • Engine: After warming up • Air conditioner switch: OFF • Shift lever: P or N (A/T), Neutral (M/T) • No load 	Ignition switch: ON (Engine stopped)	Approx. 0.4V (400 mV)
		Idle speed	1.1 - 1.4V (1100 - 1400 mV)
		Engine is revving from idle to about 4,000 rpm	1.1 - 1.4V (1100 - 1400 mV) to 4.0V (40000 mV) (Check for liner voltage rise in response to engine being increased to about 4,000 rpm.)
RFRG PRE/S VOLT	<ul style="list-style-type: none"> • Engine: After warming up • Both A/C switch and blower fan switch: ON (Compressor operates) 		1 - 1.25 V (1000 - 1250 mV)
INJ1 ADJ VALUE	• Engine Running	Idle speed	Approx. 5- 10 mg/cp
		Engine speed: 2000 rpm	Approx. 5- 10 mg/cp
INJ2 ADJ VALUE	• Engine Running	Idle speed	Approx. 5- 10 mg/cp
		Engine speed: 2000 rpm	Approx. 5- 10 mg/cp
INJ3 ADJ VALUE	• Engine Running	Idle speed	Approx. 5- 10 mg/cp
		Engine speed: 2000 rpm	Approx. 5- 10 mg/cp

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor item	condition		Values/Status
INJ4 ADJ VALUE	• Engine Running	Idle speed	Approx. 5- 10 mg/cp
		Engine speed: 2000 rpm	Approx. 5- 10 mg/cp
EXH GAS TEMP2	<ul style="list-style-type: none"> • Engine: After warming up • Drive the vehicle at a speed of 120 km/h (75 MPH) for at least 2 minutes 		Approx. 60°C (140°F) - 950°C (1742°F)
EXH GAS TEMP3	<ul style="list-style-type: none"> • Engine: After warming up • Reving engine from idle up to 3000rpm at least 60 seconds. 		Approx. 230°C (446°F) - 950°C (1742°F)
DIFF EXH PRES	• Engine: 2000 rpm		Approx. 30 mbar
ASCD SET SPEED	• Engine Running	ASCD: Operating	Almost the same speed as the tachometer indication.
EX GAS PR/S VOLT	• Engine Running	Idle speed	Approx. 1 V (1000 mV)
		Engine speed: 2000 rpm	Approx. 1.4 V (1400 mV)
A/T GEAR POS	• Ignition switch: ON	A/T gear position: Neutral	STAT1
		A/T gear position: 1st gear	STAT1
		A/T gear position: 2nd gear	STAT2
		A/T gear position: 3rd gear	STAT3
		A/T gear position: 4th gear	STAT4
		A/T gear position: 5th gear	STAT5
		A/T gear position: 6th gear	STAT6
		A/T gear position: Reverse gear	BACK

TERMINAL LAYOUT



PHYSICAL VALUES

NOTE:

- ECM is located near the battery in the engine room.
- Specification data are reference values and are measured between each terminal and ground.
- Pulse signal is measured by CONSULT-III.






CAUTION:

Do not use ECM ground terminals when measuring input/output voltage. Doing so may result in damage to the ECMs transistor. Use a ground other than ECM terminals, such as the ground.

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (GR)	128 (B)	Fuel injector No. 4	Input	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle.	0 - 5 V★ 
2 (W)		Fuel injector No. 1			5 - 8 V★ 
3 (Y)		Fuel injector No. 2			
4 (G)		Fuel injector No. 3			
5 (O)	128 (B)	Fuel injector power supply No. 4	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle.	0 - 4 V★ 
6 (R)		Fuel injector power supply No. 1			4 - 6 V★ 
7 (L)		Fuel injector power supply No. 2			
8 (BR)		Fuel injector power supply No. 3			
9 (B)	128 (B)	Glow control unit ground	—	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0 V
10 (Y)	—	Sensor ground (Exhaust gas temperature sensor 1)	—	—	—
12 (P)	128 (B)	Air fuel ratio sensor heater	Output	[Engine is running] <ul style="list-style-type: none"> • After the vehicle is driven for 6 minutes under the following conditions <ul style="list-style-type: none"> - Warm-up condition - Vehicle speed: 80 km/h - Shift lever: Suitable gear position 	6 - 14 V★ 
				[Ignition switch ON] <ul style="list-style-type: none"> • Engine: Stopped 	BATTERY VOLTAGE (11 - 14 V)
14 (SB)	10 (Y)	Exhaust gas temperature sensor 1	Input	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0.3 - 5.0 V Output voltage varies with exhaust gas temperature.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >



[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
16 (Y)	—	Sensor ground (Exhaust gas pressure sensor)	—	—	—
17 (O)	—	Sensor ground (Turbocharger boost sen- sor)	—	—	—
18 (LG)	17 (O)	Turbocharger boost sensor	Input	[Engine is running] • Warm-up condition • Idle speed	1.2 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.3 V
19 (G)	23 (Y)	Exhaust gas temperature sensor 3	Input	[Engine is running] • Warm-up condition • Idle speed	0.3 - 5.0 V Output voltage varies with exhaust gas temperature.
20 (R)	25 (O)	Exhaust gas pressure sen- sor	Input	[Engine is running] • Warm-up condition • Idle speed	1 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.4 V
21 (BR)	17 (O)	Sensor power supply (Turbocharger boost sen- sor)	—	[Ignition switch: ON]	5 V
22 (W)	—	Sensor ground (Fuel temperature sensor)	—	—	—
23 (Y)	—	Sensor ground (Exhaust gas temperature sensor 3)	—	—	—
24 (O)	—	Sensor ground (Engine coolant tempera- ture sensor)	—	—	—
25 (SB)	16 (Y)	Sensor power supply (Exhaust gas pressure sensor)	—	[Ignition switch: ON]	5 V
26 (V)	22 (W)	Fuel temperature sensor	Input	[Engine is running] • Warm-up condition	0.3 - 5.0 V Output voltage varies with fuel tem- perature.
27 (GR)	39 (L)	Exhaust gas temperature sensor 2	Input	[Engine is running] • Warm-up condition • Idle speed	0.3 - 5.0 V Output voltage varies with exhaust gas temperature.
28 (P)	24 (O)	Engine coolant tempera- ture sensor	Input	[Engine is running] • Warm-up condition	0.3 - 5.0 V Output voltage varies with engine coolant temperature.
29 (G)	34 (Y)	Sensor power supply (Fuel rail pressure sensor)	—	[Ignition switch: ON]	5 V
30 (L)	34 (Y)	Fuel rail pressure sensor	Input	[Engine is running] • Warm-up condition • Idle speed	1 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	1.8 V

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
31 (SB)	35 (V)	Refrigerant pressure sensor	Input	[Engine is running] • Warm-up condition • Both A/C switch and blower fan switch: ON (Compressor operates)	1 - 2.5 V
32 (BR)	36 (R)	EGR volume control valve control position sensor	Input	[Engine is running] • Warm-up condition • Idle speed	1 - 4.2 V
33 (GR)	36 (R)	Sensor power supply (EGR volume control valve control position sensor)	—	[Ignition switch: ON]	5 V
34 (Y)	—	Sensor ground (Fuel rail pressure sensor)	—	—	—
35 (V)	—	Sensor ground (Refrigerant pressure sensor)	—	—	—
36 (R)	—	Sensor ground (EGR volume control valve control position sensor)	—	—	—
37 (W)	42 (R)	Sensor power supply (Differential exhaust pressure sensor)	—	[Ignition switch: ON]	5 V
38 (LG)	42 (R)	Differential exhaust pressure sensor	Input	[Engine is running] • Warm-up condition • Idle speed	1.6 - 4.9 V
39 (L)	—	Sensor ground (Exhaust gas temperature sensor 2)	—	—	—
41 (L)	35 (V)	Sensor power supply (Refrigerant pressure sensor)	—	[Ignition switch: ON]	5 V
42 (R)	—	Sensor ground (Differential exhaust pressure sensor)	—	—	—
46 (B)	—	Sensor ground (Camshaft position sensor)	—	—	—
48 (Y)	46 (B)	Camshaft position sensor	Input	[Engine is running] • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle.	0 - 14 V★  JMBIA0535GB
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0 - 14 V★  JMBIA0536GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

ECM

< ECU DIAGNOSIS >



[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
49 (L)	128 (B)	Crankshaft position sensor (+)	Input	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed NOTE: The pulse cycle changes depending on rpm at idle.	0 - 3 V★  <small>JMBIA0537GB</small>
				[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Engine speed: 2,000 rpm 	2.5 V★  <small>JMBIA0538GB</small>
50 (Y)	128 (B)	Crankshaft position sensor (-)	-	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0 - 4 V★  <small>JMBIA0539GB</small>
				[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Engine speed: 2,000 rpm 	2.5 V★  <small>JMBIA0540GB</small>
53 (GR)	128 (B)	Glow control unit	Output	[Engine is running] <ul style="list-style-type: none"> • Idle speed • Engine coolant temperature: Less than 50 °C (122 °F) 	BATTERY VOLTAGE (11 - 14 V)
				[Engine is running] <ul style="list-style-type: none"> • Idle speed • Engine coolant temperature: More than 80 °C (176 °F) 	BATTERY VOLTAGE (11 - 14 V)
56 (R)	128 (B)	Turbocharger cooling pump relay	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition (Engine coolant temperature is more than 80 °C) • Idle speed (For 5 minutes) 	0 - 1 V
				Except above conditions	BATTERY VOLTAGE (11 - 14 V)

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
57 (V)	128 (B)	Turbocharger boost control solenoid valve	Output	[Engine is running] • Warm-up condition • Idle speed	0 - 5 V★  JMBIA0541GB
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	0 - 5 V★  JMBIA0542GB
59 (SB)	128 (B)	EGR cooler bypass valve control solenoid valve	Output	[Engine is running] • Not warm-up condition • Idle speed	1.5 V
				[Engine is running] • Warm-up condition • Idle speed	BATTERY VOLTAGE (11 - 14 V)
62 (W)	128 (B)	ECM relay (Self shut-off)	Output	[Ignition switch: ON] [Ignition switch: OFF] • For 20 seconds after turning ignition switch OFF	0 - 1 V
				[Ignition switch: OFF] • More than 20 seconds after turning ignition switch OFF	BATTERY VOLTAGE (11-14 V)
63 (O)	128 (B)	Glow control unit	Output	[Engine is running] • Idle speed • Engine coolant temperature: Less than 50 °C (122 °F)	Less than 12 V
				[Engine is running] • Idle speed • Engine coolant temperature: More than 80 °C (176 °F)	BATTERY VOLTAGE (11 - 14 V)
75 (BR)	85 (P)	Sensor power supply (Throttle position sensor)	—	[Ignition switch: ON]	5 V
77 (O)	128 (B)	Air fuel ratio sensor	Input	[Engine is running] • Warm-up condition • Idle speed	3 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	3 V
78 (GR)	128 (B)	Air fuel ratio sensor	Input	[Engine is running] • Warm-up condition • Idle speed	2.5 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	2.5 V



A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >





[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
80 (R)	87 (W)	Mass air flow sensor	Input	[Ignition switch: ON] • Engine stopped	0.4 V
				[Engine is running] • Warm-up condition • Idle speed	1.1 - 1.4 V
				[Engine is running] • Warm-up condition • Engine is revving from idle to about 4,000 rpm	1.1 - 1.4 V to 4.0 V (Check for linear voltage rise in response to engine being increased to about 4,000 rpm.)
81 (SB)	128 (B)	Air fuel ratio sensor	Input	[Engine is running] • Warm-up condition • Idle speed	3.1 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	3.1 V
82 (V)	128 (B)	Air fuel ratio sensor	Input	[Engine is running] • Warm-up condition • Idle speed	3.2 V
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	3.2 V
83 (V)	85 (P)	Throttle position sensor	Input	[Ignition switch: OFF] • For 20 seconds after turning ignition switch OFF	0 - 5 V Output voltage fluctuates between 0 V and 5 V.
				[Ignition switch: OFF] • More than 20 seconds after turning ignition switch OFF	0.7 V
84 (B)	87 (W)	Intake air temperature sensor	Input	[Engine is running] • Warm-up condition	0.3 - 5.0 V Output voltage varies with intake air temperature.
85 (P)	—	Sensor ground (Throttle position sensor)	—	—	—
87 (W)	—	Sensor ground (Mass air flow sensor/ Intake air temperature sensor)	—	—	—
89 (BR)	128 (B)	Fuel pump	Output	[Engine is running] • Warm-up condition • Idle speed	11 - 14 V★  JMBIA0543GB
				[Engine is running] • Warm-up condition • Engine speed: 2,000 rpm	8 - 10 V★  JMBIA0544GB

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
90 (GR)	128 (B)	Fuel rail pressure control valve	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0.4 V★  <small>JMBIA0545GB</small>
				[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Engine speed: 2,000 rpm 	0.4 V★  <small>JMBIA0546GB</small>
91 (SB)	128 (B)	Throttle control motor (+)	Output	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0 - 2 V★  <small>JMBIA0547GB</small>
				[Ignition switch: OFF] <ul style="list-style-type: none"> • For 20 seconds after turning ignition switch OFF 	0 - 2 V★  <small>JMBIA0548GB</small>
				[Ignition switch: OFF] <ul style="list-style-type: none"> • More than 20 seconds after turning ignition switch OFF 	0.1 V
92 (LG)	128 (B)	Throttle control motor (-)	—	[Engine is running] <ul style="list-style-type: none"> • Warm-up condition • Idle speed 	0 V
93 (G) 94 (V)	128 (B)	Power supply for ECM	—	[Ignition switch: ON]	BATTERY VOLTAGE (11 - 14 V)






A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
95 (P)	128 (B)	EGR volume control valve (DC motor)	Output	[Ignition switch: OFF] <ul style="list-style-type: none"> For 20 seconds after the following conditions are met and ignition switch is turned OFF. <ul style="list-style-type: none"> - Warm-up condition - Start engine and let it idle for 3 minutes. 	0 - 1 V★ 
				[Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed NOTE: The duty cycle changes depending on EGR volume control valve operation.	0 - 5 V★ 
96 (O)	128 (B)	EGR volume control valve (DC motor)	Output	[Ignition switch: ON] <ul style="list-style-type: none"> For 3 seconds after ignition switch is turned ON 	0 - 1 V★ 
				[Ignition switch: ON] <ul style="list-style-type: none"> More than 3 seconds after ignition switch is turned ON 	0 - 1 V★ 
				[Engine is running] <ul style="list-style-type: none"> Warm-up condition Idle speed NOTE: The duty cycle changes depending on EGR volume control valve operation.	0 - 5 V★ 
99 (P)	—	CAN signal (low)	—	—	—
100 (L)	—	CAN signal (high)	—	—	—
104 (Y)	128 (B)	Data link connector	—	[Ignition switch: ON] <ul style="list-style-type: none"> GST: Disconnected 	BATTERY VOLTAGE (11 - 14 V)
108 (G)*1 (SB)*2	128 (B)	Clutch pedal position switch	Input	[Ignition switch: ON] <ul style="list-style-type: none"> Clutch pedal: Slightly depressed 	0 V
				[Ignition switch: ON] <ul style="list-style-type: none"> Clutch pedal: Fully released 	BATTERY VOLTAGE (11 - 14 V)

ECM

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
109 (LG)	128 (B)	Ignition switch	Input	[Ignition switch: OFF]	0 V	A
				[Ignition switch: ON]	BATTERY VOLATGE (11 - 14 V)	B
110 (V)	111 (B)	ASC D steering switch	Input	[Ignition switch: ON] • ASCD steering switch: OFF	4 V	C
				[Ignition switch: ON] • MAIN switch: Pressed	0 V	D
				[Ignition switch: ON] • CANCEL switch: Pressed	1 V	E
				[Ignition switch: ON] • RESUME/ACCELERATE switch: Pressed	3 V	F
				[Ignition switch: ON] • SET/COAST switch: Pressed	2 V	F
111 (B)	—	ASC D steering switch ground	—	—	—	G
116 (GR)	128 (B)	Brake pedal position switch	Input	[Ignition switch: ON] • Brake pedal: Slightly depressed	0V	H
				[Ignition switch: ON] • Brake pedal: Fully released	BATTERY VAOLTAGE (11 - 14 V)	H
118 (L)	120 (P)	Sensor power supply (Accelerator pedal position sensor 2)	—	[Ignition switch: ON]	5 V	HAC
119 (V)	120 (P)	Accelerator pedal position sensor 2	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	More than 0.3 V	J
				[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully depressed	Less than 2.5 V	K
120 (P)	—	Sensor ground (Accelerator pedal position sensor 2)	—	—	—	L
122 (G)	127 (Y)	Sensor power supply (Accelerator pedal position sensor 1)	—	[Ignition switch: ON]	5 V	M
123 (B)	—	ECM ground	—	—	—	N
124 (B)						
125 (B)						
126 (W)	127 (Y)	Accelerator pedal position sensor 1	Input	[Ignition switch: ON] • Engine stopped • Accelerator pedal: Fully released	0.6 - 4.6 V	O
				[Ignition switch ON] • Engine stopped • Accelerator pedal: Fully depressed	Less than 5 V	P
127 (Y)	—	Sensor ground (Accelerator pedal position sensor 1)	—	—	—	
128 (B)	—	ECM ground	—	—	—	

★: Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

*1: M/T models with ESP

*2: M/T models without ESP

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000001298753

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
VEHICLE SPEED	While driving	Equivalent to speedometer reading
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
I-KEY LOCK	"LOCK" button of Intelligent Key or door request switch are not pressed	Off
	"LOCK" button of Intelligent Key or door request switch are pressed	On
I-KEY UNLOCK	"UNLOCK" button of Intelligent Key or door request switch are not pressed	Off
	"UNLOCK" button of Intelligent Key or door request switch are pressed	On
PUSH SW	Return to ignition switch to "LOCK" position	Off
	Press ignition switch	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
SHOCK SENSOR	Ignition switch ON	NOMAL
	After the reception of air bag deployment signal from air bag diagnosis sensor unit	Off
	During the reception of air bag deployment signal from air bag diagnosis sensor unit	On
UNLOCK SHOCK	Other than the following	Off
	During the unlock operation interlocked with air bag	On
UNLOCK WITH DR	NOTE: The item is indicated, but not monitored	On
		Off

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Value/Status
LOCK WITH SPEED	Vehicle speed sensing auto door lock function does not operate	Off
	Vehicle speed sensing auto door lock function is operating	On
ACC ON SW	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TAIL LAMP SW	Lighting switch OFF	Off
	Lighting switch 1ST	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
HI BEAM SW	Lighting switch OFF	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Lighting switch OFF	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Lighting switch OFF	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	Rear fog lamp switch OFF	Off
	Rear fog lamp switch ON	On
ENGINE RUN	Engine stopped	Off
	Engine running	On
LIT-SEN FAIL	Light & rain sensor is in normal condition	OK
	Light & rain sensor is with error	NOTOK
AUT LIGHT SYS	Outside of the room is dark	On
	Outside of the room is bright	Off
HD LIGHT TIME	—	Displays a setting time of the follow me home function set by the work support
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Monitor Item	Condition	Value/Status
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
RR WIPER ON	Rear wiper switch OFF	Off
	Rear wiper switch ON	On
RR WIPER INT	Rear wiper switch OFF	Off
	Rear wiper switch INT	On
RR WIPER STOP	Rear wiper stop position	Off
	Other than rear wiper stop position	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
REVERSE SW CAN	NOTE: The item is indicated, but not monitored	Off
		On
H/L WASH SW	When headlamp washer switch is not pressed	Off
	When headlamp washer switch is pressed	On
FAN ON SIG	Blower fan motor switch OFF	Off
	Blower fan motor switch ON (other than OFF)	On
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	Off
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	On
HAZARD SW	Hazard switch OFF	Off
	Hazard switch ON	On
BRAKE SW	Brake pedal is not depressed	Off
	Brake pedal is depressed	On
TRNK OPNR SW	When back door opener switch is not pressed	Off
	When back door opener switch is pressed	On
HOOD SW	Close the hood NOTE: Vehicles without theft warning system are OFF-fixed	Off
	Open the hood	On
AUTO RELOCK	Auto lock function does not operate	Off
	Auto lock function is operating	On
GLS BREAK SEN	The vehicle without glass break sensor	Off
	The vehicle with glass break sensor	On
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	Off
	Ignition switch ON	On


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

TERMINAL LAYOUT



PHYSICAL VALUES

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-28, "COMB SW : CONSULT-III Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9, "System Description"](#).

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
1 (W)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
2 (G)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
3 (W)	Ground	Ignition power supply	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON or START	Battery voltage
4 (SB)	Ground	ACC power supply	Input	Ignition switch OFF	0 V
				Ignition switch ON or ACC	Battery voltage
5 (LG) ^{*1} (R) ^{*2}	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage
				Remove mechanical key from ignition key cylinder	0 V






A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]






< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
6 (L)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right;">1.4 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>
					Rear washer switch ON	 <p style="text-align: right;">1.3 V</p>
					Any of the condition below with all switch OFF	<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3  <p style="text-align: right;">1.3 V</p>

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
7 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; margin-right: 50px;">1.4 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; margin-right: 50px;">1.3 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right; margin-right: 50px;">1.3 V</p>
					Any of the condition below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 6	 <p style="text-align: right; margin-right: 50px;">1.3 V</p>
					Rear wiper INT (Wiper intermittent dial 4)	 <p style="text-align: right; margin-right: 50px;">1.3 V</p>






A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]






< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
8 (V)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 <p style="text-align: center;">1.4 V</p>
					Turn signal switch RH	 <p style="text-align: center;">1.3 V</p>
					Turn signal switch LH	 <p style="text-align: center;">1.3 V</p>
					Front wiper switch LO	 <p style="text-align: center;">1.3 V</p>
					Front washer switch ON	 <p style="text-align: center;">1.3 V</p>

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
9 (G) ^{*3} (B) ^{*4}	Ground	Combination switch INPUT 2	Input	All switch OFF	 <p style="text-align: center;">1.4 V</p> <p style="text-align: right; font-size: small;">JPMA0165GB</p>
				Lighting switch 2ND	 <p style="text-align: center;">1.3 V</p> <p style="text-align: right; font-size: small;">JPMA0166GB</p>
				Lighting switch PASS	 <p style="text-align: center;">1.3 V</p> <p style="text-align: right; font-size: small;">JPMA0167GB</p>
				Front wiper switch INT	 <p style="text-align: center;">1.3 V</p> <p style="text-align: right; font-size: small;">JPMA0168GB</p>
				Front wiper switch HI	 <p style="text-align: center;">1.3 V</p> <p style="text-align: right; font-size: small;">JPMA0196GB</p>





A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]





< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
10 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0165GB</p> <p style="text-align: center;">1.3 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0167GB</p> <p style="text-align: center;">1.3 V</p>
					Rear fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0168GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0169GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the condition below with all switch OFF	<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7
11 (B)	Ground	Audio link	Input/ Output	—	—	

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
12 (LG)	Ground	Rear door switch RH	Input	Rear door switch RH	OFF (When rear door RH closed)	 11.2 V
					ON (When rear door RH opened)	0 V
13 (V)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed)	 11.2 V
					ON (When back door opened)	0 V
14 (P) ^{*3} (BR) ^{*4}	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 11.2 V
					ON (When passenger door opened)	0 V
15 (BR) ^{*3} (P) ^{*4}	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	 11.2 V
					ON (When driver door opened)	0 V

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]






< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
16 (GR)	Ground	Rear door switch LH	Input	Rear door switch LH	OFF (When rear door LH closed)	 <small>PKID0924E</small> 11.2 V
				ON (When rear door LH opened)	0 V	
17 (L)	Ground	Door lock status indicator	Output	Door lock status indicator	ON	12 V
				OFF	0 V	
20 (SB)	Ground	Rear window defogger switch	Input	Rear window defogger switch	Not pressed	 <small>JPMIA0154GB</small> 1.1 V
				While pressing	0 V	
21 (P)	—	CAN-L	Input/ Output	—	—	
22 (L)	—	CAN-H	Input/ Output	—	—	
23 (V)	Ground	Security indicator	Output	Security indicator	ON	0 V
				Blinking	 <small>JPMIA0014GB</small> 10.3 V	
24 (GR)	Ground	Light & rain sensor serial link	Input/ Output	Ignition switch OFF or ACC	OFF	12 V
				Ignition switch ON	 <small>JPMIA0156GB</small> 8.7 V	
25 (G)	Ground	Alarm link	Output	—	—	

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
26 (GR) ^{*5} (LG) ^{*6}	Ground	Blower fan motor switch	Input	Blower fan motor switch	OFF	 PKID0924E 11.2 V
					ON (other than OFF)	0 V
27 (P) ^{*5} (Y) ^{*6}	Ground	A/C switch	Input	Ignition switch ON	Compressor ON is not re- quested from auto amp. (A/C indicator OFF, blow- er fan motor switch OFF or etc.)	 PKID0924E 11.2 V
					Compressor ON is re- quested from auto amp. (A/C indicator ON and blower fan motor switch ON).	0 V
28 (LG) ^{*7} (R) ^{*8}	Ground	Shock detect sensor	Input	Ignition switch OFF or ACC		0 V
				Ignition switch ON		 JPMIA0155GB 6.0 V
29 (LG) ^{*3} (O) ^{*4}	Ground	Back door opener switch	Input	Back door opener switch	Not pressed	 JPMIA0154GB 1.2 V
					Pressed	0 V
32 (BR)	Ground	Door lock/unlock switch (Unlock)	Input	Door lock/un- lock switch	Not pressed	 JPMIA0154GB 1.2 V
					Pressed to the unlock side	0 V






A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
33 (W) ^{*9} (Y) ^{*10}	Ground	Hazard switch	Input	Hazard switch	OFF	 <small>JPMIA0154GB</small> 1.3 V
					ON	0 V
34 (SB) ^{*3} (P) ^{*4}	Ground	Door lock/unlock switch (Lock)	Input	Door lock/un- lock switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed to the lock side	0 V
35 (G)	Ground	Headlamp washer switch	Input	Headlamp washer switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed to the lock side	0 V
36 (G)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch RH	 <small>JPMIA0164GB</small> 9.1 V
					Lighting switch 2ND	
					Lighting switch HI	
					Lighting switch 1ST	
37 (R)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	 <small>JPMIA0161GB</small> 9.1 V
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
					Rear wiper switch ON (Wiper intermittent dial 4)	

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
38 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Front wiper switch LO	
					Front wiper switch MIST	
					Front wiper switch INT	
					Lighting switch AUTO	
Rear fog lamp switch ON	9.3 V					
39 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch LH	
					Lighting switch PASS	
					Lighting switch 2ND	
					Front fog lamp switch ON	
40 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	
Rear wiper switch INT (Wiper intermittent dial 4)	9.1 V					
41 (LG)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage	
42 (V)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver activation	0 V	
				Interior room lamp battery saver no activation	12 V	
43 (SB)	Ground	Rear wiper motor	Output	Rear wiper switch OFF	0 V	
				Rear wiper switch ON	12 V	
44 (B)	Ground	Rear wiper auto stop	Input	Ignition switch ON		
				Any position other than rear wiper stop position	0 V	

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N





O

P

BCM (BODY CONTROL MODULE)

[AUTOMATIC AIR CONDITIONER]



< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
45 (V)	Ground	Back door lock actuator	Output	Back door opener switch	Pressed	 SKIA9232E
					Not pressed	0 V
47 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch LH	 PKID0926E 6.5 V
48 (GR)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF	0 V
					Turn signal switch RH	 PKID0926E 6.5 V
49 (Y)	Ground	Rear fog lamp	Output	Rear fog lamp	OFF	0 V
					ON	12 V
50 (G)	Ground	Unlock sensor	Input	Driver's door	Unlock	5 V
					lock	0 V
51 (R)	Ground	Stop lamp switch	Input	Depress the brake pedal		Battery voltage
				Release the brake pedal		0 V
52 (R)	Ground	Room lamp timer control	Output	Interior room lamp	OFF	12 V
					ON	0 V
53 (L)	Ground	Power window power supply (IGN)	Output	Ignition switch	OFF or ACC	0 V
					ON	12 V
54 (O)	Ground	Door unlock (All other than driver's door)	Output	Door lock/unlock switch	Pressed to the unlock side	 SKIA9232E
					Not pressed	0 V
55 (B)	Ground	Ground	—	Ignition switch ON		0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
56 (V)	Ground	Door lock (All) and fuel lid lock	Output	Door lock/un- lock switch	Not pressed 0 V
				Door lock/un- lock switch	Pressed to the lock side 
57 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage
58 (P)	Ground	Power window pow- er supply (BAT)	Output	Ignition switch OFF	12 V
59 (R)	Ground	Super lock	Output	When lock button of key fob or Intelligent Key is not pressed	0 V
				When lock button of key fob or Intelligent Key is pressed	12 V
60 (G)	Ground	Driver's door unlock and fuel lid unlock	Output	Door lock/un- lock switch	Pressed to the unlock side 
				Door lock/un- lock switch	Not pressed 0 V

- *1: With Intelligent Key
- *2: Without Intelligent Key
- *3: RHD models
- *4: LHD models
- *5: With gasoline engine
- *6: With diesel engine
- *7: RHD models with side air bag
- *8: LHD models with side air bag
- *9: With xenon headlamp and daytime light system
- *10: Except with xenon headlamp and daytime light system

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AUTO AMP.

< ECU DIAGNOSIS >


[AUTOMATIC AIR CONDITIONER]

AUTO AMP.
MR20DE/QR25DE

MR20DE/QR25DE : Reference Value

INFOID:000000001162206

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Power supply for IGN	—	Ignition switch ON	Battery voltage
2 (Y)	Ground	Power supply for BATT	—	Ignition switch OFF	Battery voltage
3 (B)	Ground	Ground	—	Ignition switch ON	0 V
4 (P)	Ground	A/C (Compressor ON) signal	Output	Compressor OFF	12 V
				Compressor ON	0 V
5 (W)	Ground	Power supply for each door motor	—	Ignition switch ON	Battery voltage
7 (GR)	Ground	ECV (Electrical Control Valve)	Input	<ul style="list-style-type: none"> Ignition switch ON Self-diagnosis: STEP4 (Code No.45) 	<p style="text-align: right;">SJIA1607E</p>
8 (LG)	Ground	In-vehicle sensor	Input	—	—
9 (BR)	Ground	OAT sensor	Input	—	—
10 (Y)	Ground	Sunload sensor	Input	—	—
11 (B)	Ground	Illumination ground	—	Light switch ON	0 V
12 (GR)	Ground	Power supply for illumination	—	Light switch OFF	0 V
				Light switch ON	12 V

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
15 (V)	Ground	LAN signal	—	—	 <p style="text-align: right; font-size: small;">SJIA1453J</p>
17 (L)	Ground	Fan control amp. control signal	Output	• Ignition switch ON • Blower speed: OFF	0 V
				• Ignition switch ON • Blower speed: 1st - 23rd	2.5 - 3.5 V
				• Ignition switch ON • Blower speed: 24th - 25th	10 V
18 (R)	Ground	Blower motor feedback	Input	• Ignition switch ON • Blower speed: OFF	Battery voltage
				• Ignition switch ON • Blower speed: 1st	10 V
				• Ignition switch ON • Blower speed: 25th	0 V
19 (GR)	Ground	Blower motor ON signal	Output	Fan control dial: OFF	12 V
				Fan control dial: ON (Blower motor operate.)	0 V
20 (Y)	Ground	Power supply from IGN 2	—	Ignition switch ON	Battery voltage
21 (O)	Ground	Engine coolant temperature sensor	Input	At idle [after warming up, approx. 20°C (68°F)] NOTE: The wave forms vary depending on coolant temperature.	 <p style="text-align: right; font-size: small;">JSIIA0459GB</p>
				At idle [after warming up, approx. 80°C (176°F)] NOTE: The wave forms vary depending on coolant temperature.	 <p style="text-align: right; font-size: small;">JSIIA0460GB</p>
22 (SB)	Ground	Rear window defogger ON signal	Output	When rear window defogger switch is released.	 <p style="text-align: right; font-size: small;">JP1IA0013GB</p>
				When rear window defogger switch is being pressed.	0 V

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
23 (G)	Ground	Rear window defogger feed- back signal	Input	Rear window defogger switch: OFF	0 V
				Rear window defogger switch: ON	12 V
24 (R)	Ground	Sensor ground	—	Ignition switch ON	0 V
25 (G)	Ground	Intake sensor	Input	—	—
28 (BR)	Ground	Power supply for ambient temperature display	Output	Ignition switch ON	5 V
30 (SB)	Ground	Compressor feedback signal	Input	Ignition switch ON	0 V

MR20DE/QR25DE : Wiring Diagram — AIR CONDITIONER CONTROL SYSTEM —

INFOID:000000001162207

- : With MR engine
- : With QR engine
- *1 84
- 82
- *2 83
- 90
- *3 74
- 15
- *4 41
- 37
- *5 48
- 18

AIR CONDITIONER CONTROL (GASOLINE ENGINE)



* : This connector is not shown in "Harness Layout".

2007/2/28


JCIWA0052GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]




*: This connector is not shown in "Harness Layout".

JCIWA0053GB


AIR CONDITIONER CONTROL (GASOLINE ENGINE)

Connector No.	E6
Connector Name	WIRE TO WIRE
Connector Type	TK24MW-1V




Terminal No.	Color of Wire	Signal Name [Specification]
9	SHIELD	- [With OR engine]
18	L	-
19	SB	- [Without OR engine]
18	LG	- [With OR engine]
20	V	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
7	V	- [With gasoline engine]
10	B	-
15	O	-
16	GR	-

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
25	B	-
26	P	-
27	L	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
55	O	-

Connector No.	E16
Connector Name	ECM
Connector Type	MAA24FB-MEA8-LH



Terminal No.	Color of Wire	Signal Name [Specification]
83	P	CAN-L1
84	L	CAN-H1

Connector No.	E19
Connector Name	ECM
Connector Type	BAA27B-AH3



Terminal No.	Color of Wire	Signal Name [Specification]
82	L	VEHCAN-H
80	P	VEHCAN-L

Connector No.	E44
Connector Name	OAT SENSOR
Connector Type	RS02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


AIR CONDITIONER CONTROL (GASOLINE ENGINE)

Connector No.	E48
Connector Name	REFRIGERANT PRESSURE SENSOR
Connector Type	RK03FB




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	SB	-[Without OR engine]
3	LG	-[With OR engine]

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	T180FW-CS1E-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
12	P	-
13	R	-
20	P	-
22	L	-
23	BR	-
30	L	-
79	GR	-
89	V	-

Connector No.	F8
Connector Name	ECM
Connector Type	MAA4DFBR-MAA8-LH



Terminal No.	Color of Wire	Signal Name [Specification]
41	SB	PDPRES
48	V	GNDA-PDPRES
74	L	AVCC-PDPRES

Connector No.	F17
Connector Name	COMPRESSOR
Connector Type	RK02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	F43
Connector Name	ECM
Connector Type	BAA7BEP-AH5




Terminal No.	Color of Wire	Signal Name [Specification]
15	L	AVCC-PDPRES
18	V	GNDA-PDPRES
37	LG	PDPRES

Connector No.	F61
Connector Name	COMPRESSOR
Connector Type	RK02FG




Terminal No.	Color of Wire	Signal Name [Specification]
3	W	-
4	GR	-

Connector No.	F121
Connector Name	WIRE TO WIRE
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
7	W	-
10	B	-
15	Y	-
16	GR	-

Connector No.	F123
Connector Name	WIRE TO WIRE
Connector Type	TK24FW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
9	SHIELD	-[With OR engine]
18	L	-
19	SB	-[Without OR engine]
19	LG	-[With OR engine]
20	V	-

AIR CONDITIONER CONTROL (GASOLINE ENGINE)

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
16	O	WATER TEMP OUT
17	SB	A/C PD OUT
18	BR	OUTSIDE TEMP POWER
21	L	CAN-H
22	P	CAN-L

Connector No.	M41
Connector Name	IN-VEHICLE SENSOR
Connector Type	AQ2FW



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-

Connector No.	M42
Connector Name	INTAKE SENSOR
Connector Type	CJ2FW



1	2
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-

Connector No.	M50
Connector Name	AUTO AMP.
Connector Type	TK20FGY



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	IGN
2	Y	BAT
3	B	GRD/POWER
4	P	COMP ON
5	W	LAMP+
7	GR	ECV OUT
8	LG	INCAR SENS
9	BR	AMS SENS
10	Y	SUN SENS
15	V	LAMP-
17	L	FR/FAN OUT

18	R	FR/FAN F/B
19	GR	FAN ON
20	Y	FR/IGN 2

Connector No.	M51
Connector Name	AUTO AMP.
Connector Type	TK10FGY



21	22	23	24	25	26	27	28
29	30	31	32	33	34	35	36

Terminal No.	Color of Wire	Signal Name [Specification]
21	O	WATER TEMP
24	R	SENS GND
25	C	INT SENS
28	BR	OUTSIDE TEMP POWER
30	SB	PD CUT

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	A4B40FB



31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60

Terminal No.	Color of Wire	Signal Name [Specification]
21	P	CAN-L
22	L	CAN-H
26	GR	BLOWER FAN SW
27	P	AIR/CON SW (with gasoline engine)


AIR CONDITIONER CONTROL (GASOLINE ENGINE)

Connector No.	M74
Connector Name	SUNLOAD SENSOR
Connector Type	K02FE




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	T180MW-C516-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
12	P	-
13	R	-
20	P	-
22	L	-
23	BR	-
30	L	-
79	GR	-
89	W	-

Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Type	M08FW-GY-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	R	-
4	LG	-
5	B	-
6	V	-
7	L	-
8	Y	-

Connector No.	M301
Connector Name	WIRE TO WIRE
Connector Type	M08MW-GY-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	R	-
4	Y	-
5	B	-
6	V	-
7	L	-
8	Y	-

Connector No.	M304
Connector Name	INTAKE DOOR MOTOR
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M306
Connector Name	AIR MIX DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M310
Connector Name	MODE DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M311
Connector Name	FAN CONTROL AMP.
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	L	-
3	B	-

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AIR CONDITIONER CONTROL (GASOLINE ENGINE)

Connector No.	M312
Connector Name	BLOWER MOTOR
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name (Specification)
1	Y	-
2	R	-

M9R

M9R : Reference Value

TERMINAL LAYOUT


JCIWA0058GB

INFOID:000000001204218

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
2 (B)	Ground	Illumination ground	—	Light switch ON	0 V
3 (R)	Ground	Power supply for illumination	—	Light switch OFF	0 V
				Light switch ON	12 V
4 (Y)	Ground	PTC 1	—	PTC heater 1: OFF	12 V
				PTC heater 1: ON	0 V
5 (O)	Ground	PTC 2	—	PTC heater 1: OFF	12 V
				PTC heater 1: ON	0 V
6 (V)	Ground	LAN signal	—	—	<p style="text-align: right; font-size: small;">SJIA1453J</p>
7 (L)	Ground	Fan control amp. control signal	Output	• Ignition switch ON • Blower speed: OFF	0 V
				• Ignition switch ON • Blower speed: 1st - 23rd	2.5 - 3.5 V
				• Ignition switch ON • Blower speed: 24th - 25th	10 V
8 (R)	Ground	Blower motor feedback	Input	• Ignition switch ON • Blower speed: OFF	Battery voltage
				• Ignition switch ON • Blower speed: 1st	10 V
				• Ignition switch ON • Blower speed: 25th	0 V
9 (Y)	Ground	Power supply from IGN 2	—	Ignition switch ON	Battery voltage
10 (GR)	Ground	Compressor feedback signal	Input	Ignition switch ON	0 V
11 (BR)	Ground	Power supply for ambient temperature display	Output	Ignition switch ON	5 V
12 (LG)	Ground	Blower motor ON signal	Output	Fan control dial: OFF	12 V
				Fan control dial: ON (Blower motor operate)	0 V

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
13 (Y)	Ground	A/C (Compressor ON) signal	Output	Compressor OFF	12 V
				Compressor ON	0 V
14 (O)	Ground	Intake sensor	Input	—	—
15 (O)	Ground	Engine coolant temperature sensor	Input	At idle [after warming up, approx. 20°C (68°F)] NOTE: The wave forms vary depending on coolant temperature.	<p style="text-align: right; font-size: small;">JSIIA0459GB</p>
				At idle [after warming up, approx. 80°C (176°F)] NOTE: The wave forms vary depending on coolant temperature.	<p style="text-align: right; font-size: small;">JSIIA0460GB</p>
16 (R)	Ground	Sensor ground	—	Ignition switch ON	0 V
17 (LG)	Ground	In-vehicle sensor	Input	—	—
18 (BR)	Ground	OAT sensor	Input	—	—
19 (Y)	Ground	Sunload sensor	Input	—	—
21 (W)	Ground	Power supply for IGN	—	Ignition switch ON	Battery voltage
22 (Y)	Ground	Power supply for BATT	—	Ignition switch OFF	Battery voltage
23 (B)	Ground	Ground	—	Ignition switch ON	0 V
24 (G)	Ground	Rear window defogger feedback signal	Input	Rear window defogger switch: OFF	0 V
				Rear window defogger switch: ON	12 V
25 (SB)	Ground	Rear window defogger ON signal	Output	When rear window defogger switch is released.	<p style="text-align: right; font-size: small;">JPIIA0013GB</p>
				When rear window defogger switch is being pressed.	0 V
26 (W)	Ground	Power supply for each door motor	—	Ignition switch ON	Battery voltage

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

AUTO AMP.

< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
27 (V)	Ground	PTC 3	—	PTC heater 1: OFF	12 V
				PTC heater 1: ON	0 V
39 (P)	Ground	CAN-L	—	—	—
40 (L)	Ground	CAN-H	—	—	—

AUTO AMP.


< ECU DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

M9R : Wiring Diagram — AIR CONDITIONER CONTROL SYSTEM —

INFOID:000000001204219

AIR CONDITIONER CONTROL (DIESEL ENGINE)



*: This connector is not shown in "Harness Layout".

2007/2/28


JCIWA0059GB

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

AUTO AMP.

< ECU DIAGNOSIS >


[AUTOMATIC AIR CONDITIONER]



*: This connector is not shown in "Harness Layout".

JCIWA0060GB


A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P



JCIWA0061GB


AIR CONDITIONER CONTROL (DIESEL ENGINE)

Connector No.	E8
Connector Name	WIRE TO WIRE
Connector Type	TK24MW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
18	L	-
19	SB	- [Without QR engine]
20	V	-

Connector No.	E7
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
10	B	-
15	O	-

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
25	B	-
26	P	-
27	L	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
55	O	-

Connector No.	E44
Connector Name	OAT SENSOR
Connector Type	RS02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-

Connector No.	E49
Connector Name	REFRIGERANT PRESSURE SENSOR
Connector Type	RK03FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	SB	- [Without QR engine]
3	L	-

Connector No.	E60
Connector Name	ECM
Connector Type	MAA2FB-MEA8-LH



Terminal No.	Color of Wire	Signal Name [Specification]
99	P	MAIN CAN-L (BODY)
100	L	MAIN CAN-H (BODY)


AIR CONDITIONER CONTROL (DIESEL ENGINE)

Connector No.	E16
Connector Name	PTC RELAY-1
Connector Type	MS02FL-M2




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	W	-
3	GR	-
5	L	-

Connector No.	E17
Connector Name	PTC RELAY-2
Connector Type	MS02FL-M2




Terminal No.	Color of Wire	Signal Name [Specification]
1	O	-
2	W	-
3	P	-
5	G	-

Connector No.	E18
Connector Name	PTC RELAY-3
Connector Type	MS02FL-M2



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	W	-
3	O	-
5	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
12	P	-
13	R	-
20	P	-
22	L	-
23	BR	-
30	L	-
80	O	-
81	W	-
87	V	-
90	Y	-

Connector No.	E116
Connector Name	PTC HEATER
Connector Type	SNAGFW-TV



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-

Connector No.	E117
Connector Name	PTC HEATER
Connector Type	SNAG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
4	G	-
5	Y	-

Connector No.	F17
Connector Name	COMPRESSOR
Connector Type	RH02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	B	-

Connector No.	F35
Connector Name	ECM
Connector Type	M4A4GF8-ME48-RH




Terminal No.	Color of Wire	Signal Name [Specification]
31	SB	FREON PRESS
35	V	GND FREON PRESS
41	L	AVCC-FREON PRESS

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


AIR CONDITIONER CONTROL (DIESEL ENGINE)

Connector No.	F121
Connector Name	WIRE TO WIRE
Connector Type	1K24FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
10	B	-
15	Y	-

Connector No.	F123
Connector Name	WIRE TO WIRE
Connector Type	1K24FW-1V



Terminal No.	Color of Wire	Signal Name [Specification]
18	L	-
19	SB	-[Without QR engine]
20	V	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
16	O	WATER TEMP OUT
17	SB	A/G PD OUT
18	BR	OUTSIDE TEMP POWER
21	L	CAN-H
22	P	CAN-L

Connector No.	M41
Connector Name	IN-VEHICLE SENSOR
Connector Type	A02FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	-

Connector No.	M42
Connector Name	INTAKE SENSOR
Connector Type	020FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-


Connector No.	M53
Connector Name	AUTO AMP.
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
4	Y	PTC1
5	O	PTC2
6	V	LAN(-)
7	L	FR FAN OUT
8	R	FR FAN 1/2
9	Y	FR IGN 2
10	SB	PD OUT
11	BR	OUTSIDE TEMP POWER
12	GR	FAN ON
13	P	COMP ON
14	G	INT SENS

15	O	WATER TEMP
16	R	SENS GND
17	LG	INCAR SENS
18	BR	AMB SENS
19	Y	SUN SENS
21	W	IGN
22	Y	BAT
23	B	GND(POWER)
26	W	LAN(+)
27	V	PTCS
39	P	CAN-L
40	L	CAN-H

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	A4B40FB



Terminal No.	Color of Wire	Signal Name [Specification]
21	P	CAN-L
22	L	CAN-H
26	GR	BLOWER FAN SW
27	Y	AIRCON SW[With diesel engine]


AIR CONDITIONER CONTROL (DIESEL ENGINE)

Connector No.	M74
Connector Name	SUNLOAD SENSOR
Connector Type	M02FE




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TF180MW-C51B-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
12	P	-
13	R	-
20	P	-
22	L	-
23	BR	-
30	L	-
80	O	-
81	W	-
87	V	-
90	Y	-

Connector No.	M89
Connector Name	WIRE TO WIRE
Connector Type	M08FW-GY-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	R	-
4	LG	-
5	B	-
6	V	-
7	L	-
8	Y	-

Connector No.	M301
Connector Name	WIRE TO WIRE
Connector Type	M08MW-GY-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	B	-
3	R	-
4	Y	-
5	B	-
6	V	-
7	L	-
8	Y	-

Connector No.	M304
Connector Name	INTAKE DOOR MOTOR
Connector Type	A03FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M306
Connector Name	AIR MIX DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M310
Connector Name	MODE DOOR MOTOR
Connector Type	A03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	B	-

Connector No.	M311
Connector Name	FAN CONTROL AMP.
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	L	-
3	B	-

AIR CONDITIONER CONTROL (DIESEL ENGINE)

Connector No.	M312
Connector Name	BLOWER MOTOR
Connector Type	M02FW-LC



Terminal No.	Color of Wire	Signal Name (Specification)
1	Y	-
2	R	-

JCIWA0066GB

AIR CONDITIONER CONTROL

[AUTOMATIC AIR CONDITIONER]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

AIR CONDITIONER CONTROL

Diagnosis Chart By Symptom

INFOID:000000001162208

Symptom	Reference
A/C system does not come on.	Go to Trouble Diagnosis Procedure for A/C System. HAC-102. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-103. "M9R : Diagnosis Procedure" (M9R)
Air outlet does not change.	Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN) HAC-42. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-44. "M9R : Diagnosis Procedure" (M9R)
Mode door motor does not operate normally.	
Discharge air temperature does not change.	Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN) HAC-46. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-48. "M9R : Diagnosis Procedure" (M9R)
Air mix door motor does not operate normally.	
Intake door does not change.	Go to Trouble Diagnosis Procedure for Intake Door Motor. (LAN) HAC-50. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-52. "M9R : Diagnosis Procedure" (M9R)
Intake door motor does not operate normally.	
Blower motor operation is malfunctioning.	Go to Trouble Diagnosis Procedure for Blower Motor. HAC-54. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-58. "M9R : Diagnosis Procedure" (M9R)
Magnet clutch does not engage.	Go to Trouble Diagnosis Procedure for Magnet Clutch. HAC-62. "MR20DE/QR25DE : Diagnosis Procedure" (MR20DE/QR25DE) or HAC-66. "M9R : Diagnosis Procedure" (M9R)
Insufficient cooling	Go to Trouble Diagnosis Procedure for Insufficient Cooling. HAC-180. "Inspection procedure"
Insufficient heating	Go to Trouble Diagnosis Procedure for Insufficient Heating. HAC-183. "Inspection procedure"
Noise	Go to Trouble Diagnosis Procedure for Noise. HAC-185. "Inspection procedure"
Self-diagnosis cannot be performed.	Go to Trouble Diagnosis Procedure for Self-diagnosis. HAC-187. "Inspection procedure"

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

INSUFFICIENT COOLING**Description**

INFOID:000000001162209

Symptom

- Insufficient cooling
- No cold air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:000000001162210

1.CHECK WITH A GAUGE OF ACR4

Connect the ACR4 to the vehicle and perform the pressure inspection with the gauge.

Is there refrigerant?

- YES >> GO TO 2.
 NO-1 >> Check for refrigerant leakages with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-31, "Inspection"](#).
 NO-2 >> GO TO 2 after repairing or replacing the parts according to the inspection results.

2.CHECK CHARGED REFRIGERANT AMOUNT

1. Connect ACR4 to the vehicle and discharge the refrigerant.
2. Recharge with the proper amount of refrigerant and perform the inspection with the refrigerant leakage detecting fluorescent leak detector. Refer to [HA-31, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Refill the refrigerant and repair or replace the parts according to the inspection results.

3.CHECK REFRIGERANT CYCLE PRESSURE

Connect ACR4 to the vehicle and perform the performance test. Refer to [HA-27, "MR20DE/QR25DE : Performance Chart"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Perform the diagnosis with the gauge pressure. Refer to [HA-9, "Trouble Diagnosis For Unusual Pressure"](#).

4.CHECK SETTING OF TEMPERATURE SETTING TRIMMER

Check the setting of temperature setting trimmer. Refer to [HAC-5, "Description & Inspection"](#).

1. Check that the temperature setting trimmer is set to "+ direction".

NOTE:

The control temperature can be set with the setting of temperature setting trimmer.

2. Set temperature control dial to "0".

Are the symptoms solved?

- YES >> Perform the setting separately if necessary. END.
 NO >> GO TO 5.

5.PERFORM SELF-DIAGNOSIS STEP-2

Perform self-diagnosis STEP-2. Refer to [HAC-24, "Diagnosis Description"](#), see Nos. 1 to 3.

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24, "Diagnosis Description"](#), see No. 7.

6.PERFORM SELF-DIAGNOSIS STEP-4

Perform self-diagnosis STEP-4. Refer to [HAC-24, "Diagnosis Description"](#), see Nos.1 to 6.

Is it operated normally?

- YES >> GO TO 7.
 NO >> Perform the diagnosis applicable to each output device.

INSUFFICIENT COOLING

[AUTOMATIC AIR CONDITIONER]

< SYMPTOM DIAGNOSIS >

7. CHECK A/C COMPRESSOR BELT

Check the A/C compressor belt. Refer to [EM-15. "Checking"](#) (MR20DE), [EM-138. "Checking"](#) (QR25DE) or [EM-257. "Checking"](#) (M9R).

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Adjust or replace the A/C compressor belt.

8. CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc. of A/C system for air leakage.

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Repair or replace parts according to the inspection results.

9. CHECK POWER SUPPLY FOR ECV (ELECTRIC CONTROL VALVE)

1. Disconnect compressor (ECV) connector.
2. Turn ignition switch ON.
3. Check voltage between compressor (ECV) harness connector F61 terminal 3 and ground.

(+)		(-)	Voltage
Compressor (ECV)		—	
Connector	Terminal		
F61	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 11.
- NO >> GO TO 10.

10. CHECK FUSE

Check power supply circuit and 10A fuse [No. 1, located in the fuse block (J/B)]. Refer to [PG-125. "Fuse, Connector and Terminal Arrangement"](#).

Is the inspection result normal?


- YES >> Check harness for open circuit. Repair or replace if necessary.
- NO >> Replace fuse and check harness for short circuit. Repair or replace if necessary.

11. CHECK ECV CONTROL SIGNAL

1. Turn ignition switch OFF.
2. Reconnect compressor (ECV) connector.
3. Perform self-diagnosis. Refer to [HAC-24. "Diagnosis Description"](#).
4. Set in self-diagnosis STEP-4 (Code No. 45).
5. Confirm ECV control signal between auto amp. harness connector M50 terminal 7 and ground using an oscilloscope.

Is the inspection result normal?

- YES >> Replace compressor.
- NO >> GO TO 12.



12. CHECK CIRCUIT CONTINUITY BETWEEN ECV AND AUTO AMP.

1. Turn ignition switch OFF.
2. Disconnect compressor (ECV) connector and auto amp. connector.
3. Check continuity between compressor (ECV) harness connector F61 terminals 4 and auto amp. harness connector M50 terminal 7.

INSUFFICIENT COOLING

< SYMPTOM DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

(+) Compressor (ECV)		(-) Auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
F61	4	M50	7	

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair the harnesses or connectors.

13.CHECK ECV

Check continuity between compressor (ECV) connector F61 terminals 3 and 4.

(+) Compressor (ECV)		(-) Compressor (ECV)		Continuity
Connector	Terminal	Connector	Terminal	
F61	3	F61	4	

Is the inspection result normal?

YES >> Replace the auto amp.

NO >> Replace the compressor.

INSUFFICIENT HEATING

Description

INFOID:000000001162211

Symptom

- Insufficient heating
- No warm air comes out. (Air flow volume is normal.)

Inspection procedure

INFOID:000000001162212

1. CHECK COOLING SYSTEM

1. Check engine coolant level and check for leakage. Refer to [CO-10. "Inspection"](#) (MR20DE), [CO-41. "Inspection"](#) (QR25DE) or [CO-68. "Inspection"](#) (M9R).
2. Check radiator cap. Refer to [CO-14. "RADIATOR CAP : Inspection"](#) (MR20DE), [CO-45. "RADIATOR CAP : Inspection"](#) (QR25DE) or [CO-71. "RESERVOIR TANK CAP : Inspection"](#) (M9R).
3. Check water flow sounds of engine coolant. Refer to [CO-11. "Refilling"](#) (MR20DE), [CO-42. "Refilling"](#) (QR25DE) or [CO-69. "Refilling"](#) (M9R).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refill the engine coolant and repair or replace the parts according to the inspection results.

2. CHECK SETTING OF TEMPERATURE SETTING TRIMMER

1. Check the setting of temperature setting trimmer. Refer to [HAC-5. "Description & Inspection"](#).
2. Check that the temperature setting trimmer is set to "– direction".

NOTE:

The control temperature can be set with the setting of temperature setting trimmer.

3. Set temperature control dial to "0".

Are the symptoms solved?

YES >> Perform the setting separately if necessary. END.

NO >> • WITH DIESEL ENGINE: GO TO 3.
• WITH GASOLINE ENGINE: GO TO 4.**3. CHECK PTC HEATER OPERATION**Check PTC heater. Refer to [HAC-71. "Component Function Check"](#).Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning part(s).

4. CHECK OPERATION

1. Turn temperature control dial and raise temperature setting to 28°C after warming up the engine.
2. Check that warm air blows from outlets.

Is the inspection result normal?

YES >> END.

NO >> GO TO 5.

5. PERFORM SELF-DIAGNOSIS STEP-2Perform self-diagnosis STEP-2. Refer to [HAC-24. "Diagnosis Description"](#), see Nos. 1 to 3.Is the inspection result normal?

YES >> GO TO 6.

NO >> Go to appropriate malfunctioning sensor circuit. Refer to [HAC-24. "Diagnosis Description"](#), see No. 7.**6. PERFORM SELF-DIAGNOSIS STEP-4**Perform self-diagnosis STEP-4. Refer to [HAC-24. "Diagnosis Description"](#), see Nos. 1 to 6.Is it installed normally?

YES >> GO TO 7.

NO >> Perform the diagnosis applicable to each output device.

INSUFFICIENT HEATING

< SYMPTOM DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

7. CHECK AIR LEAKAGE FROM DUCT

Check duct and nozzle, etc. of A/C system for air leakage.

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace parts according to the inspection results.

8. CHECK HEATER HOSE INSTALLATION CONDITION

Check the heater hose installation condition visually (for twist, crush, etc.).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace parts according to the inspection results.

9. CHECK TEMPERATURE OF HEATER HOSE

1. Check the temperature of inlet hose and outlet hose of heater core.
2. Check that the inlet side of heater core is hot and the outlet side is slightly lower than/almost equal to the inlet side.

CAUTION:

The temperature inspection should be performed in a short time because the engine coolant temperature is too hot.

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace the heater core after performing the procedures after the cooling system inspection again. GO TO 1.

10. REPLACE HEATER CORE

Replace the heater core. Refer to [VTL-35, "Exploded View"](#) (LHD models) or [VTL-81, "Exploded View"](#) (RHD models).

Are the symptoms solved?

YES >> END.

NO >> Perform the procedures after the cooling system inspection again. GO TO 1.

NOISE

Description

INFOID:000000001162213

Symptom

- Noise
- Noise is heard when the A/C system operates.

Inspection procedure

INFOID:000000001162214

1.CHECK OPERATION

1. Operate the A/C system and check the operation. Refer to [HAC-5. "Description & Inspection"](#).
2. Check the parts where noise is occurring.

Can the parts where noise is occurring be checked?

- YES-1 >> Noise from blower fan motor: GO TO 2.
- YES-2 >> Noise from compressor: GO TO 3.
- YES-3 >> Noise from expansion valve: GO TO 4.
- YES-4 >> Noise from A/C piping (pipe, flexible hose): GO TO 6.
- YES-5 >> Noise from A/C compressor belt: GO TO 7.
- NO >> END.

2.CHECK BLOWER FAN MOTOR

1. Remove blower fan motor. Refer to [VTL-33. "Removal and Installation"](#) (LHD models) or [VTL-79. "Removal and Installation"](#) (RHD models).
2. Remove foreign materials that are in the A/C unit assembly.
3. Check the noise from blower fan motor again.

Is the inspection result normal?

- YES >> END.
- NO >> Replace blower fan motor.

3.REPLACE COMPRESSOR

1. Correct the refrigerant with ACR4.
2. Recharge with the proper amount of the collected refrigerant after recycling or new refrigerant.
3. Check for the noise from compressor again.

Is the inspection result normal?

- YES >> END.
- NO >> Replace compressor.

4.CHECK WITH GAUGE PRESSURE

Perform the diagnosis with the gauge pressure. Refer to [HA-9. "Trouble Diagnosis For Unusual Pressure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace malfunctioning part(s).

5.REPLACE EXPANSION VALVE

1. Correct the refrigerant with ACR4.
2. Recharge with the proper amount of the collected refrigerant after recycling or new refrigerant.
3. Check for the noise from expansion valve again.

Are the symptoms solved?

- YES >> END.
- NO >> Replace expansion valve.

6.CHECK A/C PIPING (PIPE, FLEXIBLE HOSE)

1. Check A/C piping [pipe, flexible hose (for deformation and damage, etc.)].
2. Check the installation condition of clips and brackets, etc. of A/C piping (pipe, flexible hose).

Is the inspection result normal?

- YES >> Fix the line with rubber or some vibration absorbing material.

A

B

C

D

E

F

G

H

HAC

J

K

L

M

N

O

P

NOISE

< SYMPTOM DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

NO >> Repair or replace parts according to the inspection results.

7.CHECK A/C COMPRESSOR BELT

Check tension of the A/C compressor belt. Refer to [EM-15, "Checking"](#) (MR20DE), [EM-138, "Checking"](#) (QR25DE) or [EM-257, "Checking"](#) (M9R).

Is the inspection result normal?

YES >> Check the noise from compressor: GO TO 3.

NO >> Adjust or replace the A/C compressor belt according to the inspection results.

SELF-DIAGNOSIS CANNOT BE PERFORMED

< SYMPTOM DIAGNOSIS >

[AUTOMATIC AIR CONDITIONER]

SELF-DIAGNOSIS CANNOT BE PERFORMED

Description

INFOID:000000001162215

Symptom: Self-diagnosis function does not operate normally.

Inspection procedure

INFOID:000000001162216

1. CHECK SELF-DIAGNOSIS FUNCTION

1. Set the fan control dial to OFF position.
2. Turn ignition switch ON.
3. Set in self-diagnosis mode as per the following. Within 10 seconds after starting engine (ignition switch is turned ON.), press A/C switch for at least 5 seconds.

NOTE:

If battery voltage drops below 12 V during diagnosis STEP-3, door motor speed becomes slower and as a result, the system may generate an error even when operation is normal. Start engine before performing this diagnosis to avoid this.

Does self-diagnosis function operate?

- YES >> END.
NO >> GO TO 2.

2. CHECK POWER SUPPLY AND GROUND CIRCUIT OF AUTO AMP.

Check power supply and ground circuit of auto amp. Refer to [HAC-101. "MR20DE/QR25DE : Component Function Check"](#) (MR20DE/QR25DE) or [HAC-103. "M9R : Component Function Check"](#) (M9R).

Is the inspection result normal?

- YES >> Replace auto amp.
NO >> Repair or replace malfunctioning part(s).

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001555660

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000001555661

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.
5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

PRECAUTIONS


< PRECAUTION >

[AUTOMATIC AIR CONDITIONER]

Precaution for Procedure without Cowl Top Cover

INFOID:000000001555683

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



Precautions For Xenon Headlamp Service

INFOID:000000001555705

WARNING:

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

Working with HFC-134a (R-134a)

INFOID:000000001280610

CAUTION:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. Compressor malfunction is likely occur if the refrigerants are mixed.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. Compressor malfunction is likely to occur if lubricant other than that specified is used.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - Cap (seal) immediately the component to minimize the entry of moisture from the atmosphere when removing refrigerant components from a vehicle.
 - Never remove the caps (unseal) until just before connecting the components when installing refrigerant components to a vehicle. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - Use only the specified lubricant from a sealed container. Reseal immediately containers of lubricant. Lubricant becomes moisture saturated and should not be used without proper sealing.
 - Never allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrene foam parts. Damage may result.

General Refrigerant Precaution

INFOID:000000001280611

WARNING:

- Never breath A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Use only approved recovery/recycling equipment to discharge HFC-134a (R-134a) refrigerant.

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >

[AUTOMATIC AIR CONDITIONER]

- Ventilate work area before resuming service if accidental system discharge occurs. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
- Never release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant each time an air conditioning system is discharged.
- Wear always eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.
- Never store or heat refrigerant containers above 52°C (126°F).
- Never heat a refrigerant container with an open flame; Place the bottom of the container in a warm pail of water if container warming is required.
- Never intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas is produced if refrigerant burns.
- Refrigerant displaces oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Never pressure test or leakage test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and HFC-134a (R-134a) have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.

Refrigerant Connection


INFOID:000000001280612

A new type refrigerant connection has been introduced to all refrigerant lines except the following location.

- Expansion valve to evaporator
- Refrigerant pressure sensor to liquid tank

O-RING AND REFRIGERANT CONNECTION

MR20DE/QR25DE



JSIIA0376ZZ

F. Former type refrigerant connection N. New type refrigerant connection


□: O-ring size

PRECAUTIONS

< PRECAUTION >

[AUTOMATIC AIR CONDITIONER]

M9R



F. Former type refrigerant connection N. New type refrigerant connection

□: O-ring size

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Never confuse O-rings since they are not interchangeable. Refrigerant may leak at the connection if a wrong O-ring is installed.

O-Ring Part Numbers and Specifications

Connection type	Piping connection point		Part number	QTY	O-ring size
New	Low-pressure flexible hose to expansion valve		92473 N8210	1	16
	Low-pressure flexible hose to low-pressure pipe (M9R)		92474 N8210	1	19
	Low-pressure pipe to expansion valve (M9R)		92473 N8210	1	16
	Compressor to low-pressure flexible hose		92474 N8210	1	19
	Compressor to high-pressure flexible hose		92472 N8210	1	12
	Condenser to high-pressure flexible hose		92472 N8210	1	12
	Condenser to high-pressure pipe		92471 N8210	1	8
	High-pressure pipe to expansion valve		92471 N8210	1	8
	Liquid tank to condenser	Inlet	92471 N8210	1	8
		Outlet		1	
Former	Refrigerant pressure sensor to liquid tank		J2476 89956	1	10
	Cooler pipe assembly	High-pressure side	92475 71L00	1	12
		Low-pressure side	92475 72L00	1	16

WARNING:

Check that all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:

A
B
C
D
E
F
G
H

HAC

J
K
L
M
N
O
P

PRECAUTIONS

< PRECAUTION >


[AUTOMATIC AIR CONDITIONER]

Observe the following when replacing or cleaning refrigerant cycle components.

- Store it in the same way as it is when mounted on the car when the compressor is removed. Failure to do so causes lubricant to enter the low-pressure chamber.
- Use always a torque wrench and a back-up wrench when connecting tubes.
- Plug immediately all openings to prevent entry of dust and moisture after disconnecting tubes.
- Connect the pipes at the final stage of the operation when installing an air conditioner in the vehicle. Never remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Remove thoroughly moisture from the refrigeration system before charging the refrigerant.
- Replace always used O-rings.
- Apply lubricant to circle of the O-rings shown in illustration when connecting tube. Be careful not to apply lubricant to threaded portion.

Name : Nissan A/C System Oil Type S

- O-ring must be closely attached to the groove portion of tube.
- Be careful not to damage O-ring and tube when replacing the O-ring.
- Connect tube until a click can be heard. Then tighten the nut or bolt by hand. Check that the O-ring is installed to tube correctly.
- Perform leakage test and make sure that there is no leakage from connections after connecting line. Disconnect that line and replace the O-ring when the refrigerant leaking point is found. Then tighten connections of seal seat to the specified torque.



Service Equipment

INFOID:000000001280613

RECOVERY/RECYCLING EQUIPMENT

Be certain to follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRICAL LEAK DETECTOR

Be certain to follow the manufacturer's instructions for tester operation and tester maintenance.

VACUUM PUMP

PRECAUTIONS


< PRECAUTION >

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched OFF after evacuation (vacuuming) and hose is connected to it. To prevent this migration, use a manual valve placed near the hose-to-pump connection, as per the following.

- Vacuum pumps usually have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- Use a hose equipped with a manual shut-off valve near the pump end for pumps without an isolator. Close the valve to isolate the hose from the pump.
- Disconnect the hose from the pump if the hose has an automatic shut-off valve. As long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.

[AUTOMATIC AIR CONDITIONER]




MANIFOLD GAUGE SET

Be certain that the gauge face indicates HFC-134a or R-134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES

Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must equip positive shut-off devices (either manual or automatic) near the end of the hoses opposite to the manifold gauge.



SERVICE COUPLERS

A
B
C
D
E
F
G
H
HAC
J
K
L
M
N
O
P


PRECAUTIONS

< PRECAUTION >

Never attempt to connect HFC-134a (R-134a) service couplers to a CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers do not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.


Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

[AUTOMATIC AIR CONDITIONER]



REFRIGERANT WEIGHT SCALE

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. The hose fitting must be 1/2"-16 ACME if the scale controls refrigerant flow electronically.



CALIBRATING ACR4 WEIGHT SCALE

Calibrate the scale each three month.

To calibrate the weight scale on the ACR4:

1. Press "**Shift/Reset**" and "**Enter**" at the same time.
2. Press "**8787**". "**A1**" is displayed.
3. Remove all weight from the scale.
4. Press "**0**", then press "**Enter**". "**0.00**" is displayed and change to "**A2**".
5. Place a known weight (dumbbell or similar weight), between 4.5 and 8.6 kg (10 and 19 lb.) on the center of the weight scale.
6. Enter the known weight using four digits. (Example 10 lb. = 10.00, 10.5 lb. = 10.50)
7. Press "**Enter**"— the display returns to the vacuum mode.
8. Press "**Shift/Reset**" and "**Enter**" at the same time.
9. Press "**6**"— the known weight on the scale is displayed.
10. Remove the known weight from the scale. "**0.00**" is displayed.
11. Press "**Shift/Reset**" to return the ACR4 to the program mode.

CHARGING CYLINDER

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

COMPRESSOR

General Precautions

INFOID:000000001280614

CAUTION:

- Plug all openings to prevent moisture and foreign matter from entering.
- Store it in the same way as it is when mounted on the car when the compressor is removed.
- Follow “LUBRICANT ADJUSTING PROCEDURE FOR COMPRESSOR REPLACEMENT” exactly when replacing or repairing compressor. Refer to [HA-25, "Adjustment"](#).
- Keep friction surfaces between clutch and pulley clean. Wipe it off by using a clean waste cloth moistened with thinner if the surface is contaminated with lubricant.
- Turn the compressor shaft by hand more than five turns in both directions after compressor service operation. This distributes equally lubricant inside the compressor. Let the engine idle and operate the compressor for one hour after the compressor is installed.
- Apply voltage to the new one and check for normal operation after replacing the compressor magnet clutch.

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

HAC

FLUORESCENT LEAK DETECTOR

< PRECAUTION >

[AUTOMATIC AIR CONDITIONER]

FLUORESCENT LEAK DETECTOR

General Precautions

INFOID:000000001280615

CAUTION:

- The A/C system contains a fluorescent leak detection dye used for locating refrigerant leakages. An ultraviolet (UV) lamp is required to illuminate the dye when inspecting for leakages.
- Wear always fluorescence enhancing UV safety goggles to protect eyes and enhance the visibility of the fluorescent dye.
- The fluorescent dye leak detector is not a replacement for an electrical leak detector (SST). The fluorescent dye leak detector should be used in conjunction with an electrical leak detector (SST) to pinpoint refrigerant leakages.
- Read and follow all manufacturer's operating instructions and precautions prior to performing the work for the purpose of safety and customer's satisfaction.
- A compressor shaft seal should not necessarily be repaired because of dye seepage. The compressor shaft seal should only be repaired after confirming the leakage with an electrical leak detector (SST).
- Remove always any remaining dye from the leakage area after repairs are completed to avoid a misdiagnosis during a future service.
- Never allow dye to come into contact with painted body panels or interior components. Clean immediately with the approved dye cleaner if dye is spilled. Fluorescent dye left on a surface for an extended period of time cannot be removed.
- Never spray the fluorescent dye cleaning agent on hot surfaces (engine exhaust manifold, etc.).
- Never use more than one refrigerant dye bottle (1/4 ounce /7.4 cc) per A/C system.
- Leak detection dyes for HFC-134a (R-134a) and CFC-12 (R-12) A/C systems are different. Never use HFC-134a (R-134a) leak detection dye in CFC-12 (R-12) A/C system, or CFC-12 (R-12) leak detection dye in HFC-134a (R-134a) A/C system, or A/C system damage may result.
- The fluorescent properties of the dye remains for three years or a little over unless a compressor malfunction occurs.

IDENTIFICATION

NOTE:

Vehicles with factory installed fluorescent dye have a green label.

Vehicles without factory installed fluorescent dye have a blue label.

IDENTIFICATION LABEL FOR VEHICLE

Vehicles with factory installed fluorescent dye have the identification label on the front side of hood.