

# SECTION **PWC**

## POWER WINDOW CONTROL SYSTEM

A

B

C

D

E

### CONTENTS

<p><b>BASIC INSPECTION</b> ..... 3</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> ..... 3</p> <p style="padding-left: 20px;">WorkFlow .....3</p> <p><b>INSPECTION AND ADJUSTMENT</b> ..... 4</p> <p><b>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL</b> .....4</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description .....4</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement .....4</p> <p><b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....4</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....4</p> <p style="padding-left: 20px;">ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement .....4</p> <p><b>FUNCTION DIAGNOSIS</b> ..... 6</p> <p><b>POWER WINDOW SYSTEM</b> ..... 6</p> <p style="padding-left: 20px;">System Diagram .....6</p> <p style="padding-left: 20px;">System Description .....6</p> <p style="padding-left: 20px;">Component Parts Location .....8</p> <p style="padding-left: 20px;">Component Description .....8</p> <p><b>COMPONENT DIAGNOSIS</b> ..... 9</p> <p><b>POWER SUPPLY AND GROUND CIRCUIT</b> ..... 9</p> <p><b>BCM</b> .....9</p> <p style="padding-left: 20px;">BCM : Diagnosis Procedure .....9</p> <p><b>POWER WINDOW MAIN SWITCH</b> .....9</p> <p style="padding-left: 20px;">POWER WINDOW MAIN SWITCH : Diagnosis Procedure .....9</p> <p><b>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)</b> ..... 11</p>	<p>FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure .....11</p> <p><b>REAR POWER WINDOW SWITCH</b> .....12</p> <p style="padding-left: 20px;">REAR POWER WINDOW SWITCH : Diagnosis Procedure .....12</p> <p><b>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)</b> ..... 14</p> <p style="padding-left: 20px;">Description .....14</p> <p style="padding-left: 20px;">Component Function Check .....14</p> <p style="padding-left: 20px;">Diagnosis Procedure .....14</p> <p style="padding-left: 20px;">Component Inspection .....15</p> <p><b>REAR POWER WINDOW SWITCH</b> .....16</p> <p style="padding-left: 20px;">Description .....16</p> <p style="padding-left: 20px;">Component Function Check .....16</p> <p style="padding-left: 20px;">Diagnosis Procedure .....16</p> <p style="padding-left: 20px;">Component Inspection .....17</p> <p><b>POWER WINDOW MOTOR</b> ..... 19</p> <p><b>DRIVER SIDE</b> .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Description .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Function Check .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Diagnosis Procedure .....19</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Inspection .....20</p> <p><b>PASSENGER SIDE</b> .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Description .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Function Check .....20</p> <p style="padding-left: 20px;">PASSENGER SIDE : Diagnosis Procedure .....21</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Inspection .....22</p> <p><b>REAR LH</b> .....22</p> <p style="padding-left: 20px;">REAR LH : Description .....22</p> <p style="padding-left: 20px;">REAR LH : Component Function Check .....22</p> <p style="padding-left: 20px;">REAR LH : Diagnosis Procedure .....22</p> <p style="padding-left: 20px;">REAR LH : Component Inspection .....23</p> <p><b>REAR RH</b> .....23</p> <p style="padding-left: 20px;">REAR RH : Description .....24</p>
---	---

F

G

H

I

J

PWC

L

M

N

O

P

REAR RH : Component Function Check .....	24	WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH : Di- agnosis Procedure .....	76
REAR RH : Diagnosis Procedure .....	24		
REAR RH : Component Inspection .....	25		
<b>ENCODER CIRCUIT .....</b>	<b>26</b>	<b>WITH REAR POWER WINDOW SWITCH LH ONLY .....</b>	<b>76</b>
Description .....	26	WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure .....	76
Component Function Check .....	26		
Diagnosis Procedure .....	26		
<b>ECU DIAGNOSIS .....</b>	<b>29</b>	<b>REAR RH SIDE POWER WINDOW DOES NOT OPERATE .....</b>	<b>77</b>
<b>BCM (BODY CONTROL MODULE) .....</b>	<b>29</b>	<b>WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH .....</b>	<b>77</b>
Reference Value .....	29	WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Di- agnosis Procedure .....	77
Wiring Diagram - POWER WINDOW CONTROL SYSTEM (LHD MODELS) - .....	46		
Wiring Diagram - POWER WINDOW CONTROL SYSTEM (RHD MODELS) - .....	52		
Fail Safe .....	56		
DTC Inspection Priority Chart .....	57		
DTC Index .....	58		
<b>POWER WINDOW MAIN SWITCH .....</b>	<b>59</b>	<b>WITH REAR POWER WINDOW SWITCH RH ONLY .....</b>	<b>77</b>
Reference Value .....	59	WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure .....	77
Wiring Diagram - POWER WINDOW CONTROL SYSTEM (LHD MODELS) - .....	61		
Wiring Diagram - POWER WINDOW CONTROL SYSTEM (RHD MODELS) - .....	67		
Fail Safe .....	71		
<b>SYMPTOM DIAGNOSIS .....</b>	<b>73</b>	<b>ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE) .....</b>	<b>78</b>
<b>NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH .....</b>	<b>73</b>	Diagnosis Procedure .....	78
Diagnosis Procedure .....	73		
<b>DRIVER SIDE POWER WINDOW DOES NOT OPERATE .....</b>	<b>74</b>	<b>AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE) .....</b>	<b>79</b>
Diagnosis Procedure .....	74	Diagnosis Procedure .....	79
<b>FRONT PASSENGER SIDE POWER WIN- DOW DOES NOT OPERATE .....</b>	<b>75</b>	<b>POWER WINDOW LOCK SWITCH DOES NOT FUNCTION .....</b>	<b>80</b>
<b>WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WIN- DOW SWITCH .....</b>	<b>75</b>	Diagnosis Procedure .....	80
WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WIN- DOW SWITCH : Diagnosis Procedure .....	75		
<b>WITH FRONT POWER WINDOW SWITCH ONLY... ..</b>	<b>75</b>	<b>POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE .....</b>	<b>81</b>
WITH FRONT POWER WINDOW SWITCH ONLY : Diagnosis Procedure .....	75	<b>PASSENGER SIDE .....</b>	<b>81</b>
		PASSENGER SIDE : Diagnosis Procedure .....	81
<b>REAR LH SIDE POWER WINDOW DOES NOT OPERATE .....</b>	<b>76</b>	<b>REAR LH .....</b>	<b>81</b>
<b>WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH .....</b>	<b>76</b>	REAR LH : Diagnosis Procedure .....	81
		<b>REAR RH .....</b>	<b>81</b>
		REAR RH : Diagnosis Procedure .....	81
		<b>PRECAUTION .....</b>	<b>82</b>
		<b>PRECAUTIONS .....</b>	<b>82</b>
		Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	82
		<b>ON-VEHICLE REPAIR .....</b>	<b>83</b>
		<b>POWER WINDOW MAIN SWITCH .....</b>	<b>83</b>
		Exploded View .....	83
		Removal and Installation .....	83

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

WorkFlow

INFOID:000000001515862

DETAILED FLOW

#### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

#### 2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

#### 3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

#### 4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

#### 5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

#### 6.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 3.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000001515863

If any of the following work has been done Initial setting is necessary.

- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of glass.
- Removal and installation of door glass run.

#### NOTE:

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

#### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000001515864

### INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.
5. Inspect anti-pinch function.

### CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
  2. Place a piece of wood near fully closed position.
  3. Close door glass completely with AUTO-UP.
- Check that glass lowers for approximately 150 mm or 2 seconds without pinching piece of wood and stops.
  - Check that glass does not rise when operating the power window main switch while lowering.

#### CAUTION:

- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- Do not check with hands and other body parts because they may be pinched. Do not get pinched.
- It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-71, "Fail Safe"](#).
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000001515865

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Re-

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

quirement

INFOID:000000001515866

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#) for initialization procedure and check anti-pinch function.

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- L
- M
- N
- O
- P

PWC

# POWER WINDOW SYSTEM


< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS

### POWER WINDOW SYSTEM

#### System Diagram

INFOID:000000001505594



JMKIA0280GB

#### System Description

INFOID:000000001505595

#### POWER WINDOW MAIN SWITCH INPUT/OUTPUT SIGNAL CHART

Item	Input signal to power window main switch	Power window main switch function	Actuator
Encoder	Encoder pulse signal	Power window control	Front power window motor (driver side)
Power window main switch	Front power window motor (driver side) UP/DOWN signal		
Front power window switch (passenger side)	Front power window motor (passenger side) UP/DOWN signal		Front power window motor (passenger side)
Rear power window switch	Rear power window motor UP/DOWN signal		Rear power window motor (LH & RH)

#### FRONT POWER WINDOW SWITCH (PASSENGER SIDE) & REAR POWER WINDOW SWITCH (LH & RH)

#### INPUT/OUTPUT SIGNAL CHART

# POWER WINDOW SYSTEM

## < FUNCTION DIAGNOSIS >

Item	Input signal to front power window switch (passenger side) & rear power window switch (LH & RH)	Front power window switch (passenger side) & rear power window switch (LH & RH) function	Actuator
Front power window switch (passenger side)	Front power window motor (passenger side) UP/DOWN signal	Power window control	Front power window motor (passenger side)
Rear power window switch (LH & RH)	Rear power window motor (LH & RH) UP/DOWN signal		Rear power window motor (LH & RH)

### POWER WINDOW OPERATION

- Power window main switch (driver side) can open/close all windows.
- Front & rear power window switch can open/close the corresponding windows.

### POWER WINDOW AUTO-OPERATION (FRONT DRIVER SIDE)

- AUTO UP/DOWN operation can be performed when power window main switch turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

### POWER WINDOW LOCK

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

### ANTI-PINCH OPERATION (FRONT DRIVER SIDE)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm or 2 seconds when detected.
- Encoder continues detecting the movement of front power window motor (driver side) and transmits to power window main switch as the encoder pulse signal while front power window motor (driver side) is operating.
- Resistance is applied to the front power window motor (driver side) rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window main switch controls to lower the window glass for 150 mm or 2 seconds after it detects encoder pulse signal frequency change.

### OPERATION CONDITION

- When front door glass (driver side) AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

### NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


PWC

# POWER WINDOW SYSTEM

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000001505596



JMKIA0662ZZ

- |   |  |  |
|---|--|--|
| 1. BCM<br>M65, M66, M67                                   | 2. Front power window motor (driver side)<br>LHD:D7<br>RHD:D27 | 3. Rear power window motor LH<br>LHD:D82<br>RHD:D112 |
| 4. Power window main switch<br>LHD:D5, D6<br>RHD:D25, D26 | 5. Rear power window switch LH<br>LHD:D83<br>RHD:D113          |  |

- |  |   |  |
|--|---|--|
| A. View with dash side lower. (passenger side) | B. View with front door finisher removed. | C. View with rear door finisher removed. |
|--|---|--|

## Component Description

INFOID:000000001505597

Component	Function
BCM	<ul style="list-style-type: none"> <li>Supplies power supply to power window switch.</li> </ul>
Power window main switch	<ul style="list-style-type: none"> <li>Directly controls all power window motor of all doors.</li> <li>Controls anti-pinch operation of power window.</li> </ul>
Front power window switch	Controls power window motor of front passenger side door.
Rear power window switch (LH & RH)	Controls power window motor of rear right and left doors.
Front power window motor (driver side)	<ul style="list-style-type: none"> <li>Integrates the encoder and power window motor.</li> <li>Starts operating with signals from power window main switch.</li> <li>Transmits front power window motor (driver side) rotation as a pulse signal to power window main switch.</li> </ul>
Front door window motor (passenger side)	Starts operating with signals from power window main switch & front power window switch (passenger side).
Rear power window motor (LH & RH)	Starts operating with signals from power window main switch & rear power window switch (LH & RH).



# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM

#### BCM : Diagnosis Procedure

INFOID:000000001505599

#### 1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
3	Ignition power supply	1 (10A)
41	Battery power supply	10 (10A)
57		J (50A)

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Ground	Battery voltage
Connector	Terminal		
M65	3		
M66	41		
M67	57		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M67	55		Existed

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Repair harness or connector.

### POWER WINDOW MAIN SWITCH

#### POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000001505600

#### 1.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between power window main switch harness connector and ground.

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

Terminal		Voltage (V) (Approx.)
(+)	(-)	
Power window main switch connector	Terminal	Ground
D5 (D25)	10	
D6 (D26)	19	

():RHD models

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

### 2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and ground.

Power window main switch connector	Terminal	Ground	Continuity
D6 (D26)	17		

():RHD models

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Repair or replace harness.

### 3.CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM connector and power window main switch connector.
3. Check continuity between BCM harness connector and power window main switch harness connector.

BCM connector	Terminal	Power window main switch connector	Terminal	Continuity
M67	53	D5 (D25)	10	Existed
	58	D6 (D26)	19	

4. Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity	
M67	53			Not existed
	58			

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (V) (Approx.)
(+)	(-)	
BCM connector	Terminal	Ground
M67	53	
	58	

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace BCM. Refer to [BCS-68, "Exploded View"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000001505601

## 1.CHECK POWER SUPPLY CIRCUIT

Check voltage between front power window switch (passenger side) harness connector and ground.

Terminal		Condition	Voltage (V) (Approx.)
(+)	(-)		
Front power window switch (passenger side) connector	Terminal		
D45 (D65)	1	Ignition switch ON	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 2. (LHD models)

YES >> INSPECTION END. (RHD models)

NO >> GO TO 3.

## 2.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side) connector	Terminal	Ground	Continuity
D45	7		Existed

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Repair or replace harness.

## 3.CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM connector and front power window switch (passenger side) connector.
3. Check continuity between BCM harness connector and front power window switch (passenger side) harness connector.

BCM connector	Terminal	Front power window switch (passenger side) connector	Terminal	Continuity
M67	53	D45 (D65)	1	Existed

4. Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M67	53		Not existed

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

NO >> Repair or replace harness.

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## REAR POWER WINDOW SWITCH

### REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000001505602

### 1.CHECK POWER SUPPLY CIRCUIT

Check voltage between rear power window switch harness connector and ground.

Terminal		Terminal	Condition	Voltage (V) (Approx.)
(+)				
Rear power window switch connector		1	Ground	Ignition switch ON
LH	D83 (D113)			
RH	D103 (D93)			

():RHD models

Is the inspection result normal?

- YES >> GO TO 2. (LHD models)  
 YES >> INSPECTION END. (RHD models)  
 NO >> GO TO 3.

### 2.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect rear power window switch connector.
- Check continuity between rear power window switch harness connector and ground.

Rear power window switch connector		Terminal	Ground	Continuity
LH	D83	7		
RH	D103			

Is the inspection result normal?

- YES >> INSPECTION END.  
 NO >> Repair or replace harness.

### 3.CHECK HARNESS CONTINUITY

- Disconnect BCM connector and rear power window switch connector.
- Check continuity between BCM harness connector and rear power window switch harness connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M67	53	LH	D83 (D113)	1	Existed
		RH	D103 (D93)		

- Check continuity between BCM harness connector and ground.

BCM connector	Terminal	Ground	Continuity
M67	53		

():RHD models

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

---

## 4.CHECK INTERMITTENT INCIDENT

---

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< COMPONENT DIAGNOSIS >

## FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

### Description

INFOID:000000001505603

- Front power window motor (passenger side) will be operated if front power window switch (passenger side) is operated.

### Component Function Check

INFOID:000000001505604

#### 1. CHECK POWER WINDOW MOTOR FUNCTION

Check front power window motor (passenger side) operation with front power window switch (passenger side)

Is the inspection result normal?

YES >> Front power window switch (passenger side) is OK.

NO >> Refer to [PWC-14, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001505605

#### 1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between front power window switch (passenger side) harness connector and ground.

Terminal		Power window main switch condition	Voltage (V) (Approx.)
(+)	(-)		
Front power window switch (passenger side)	Terminal		
D45 (D65)	2	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).

Refer to [PWC-15, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front power window switch (passenger side). Refer to [PWC-83, "Removal and Installation"](#).

#### 3. CHECK FRONT WINDOW SWITCH (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window switch (passenger side) connector.
3. Check continuity between power window main switch harness connector and front power window switch (passenger side) harness connector.

Power window main switch connector	Terminal	Front power window switch (passenger side) connector	Terminal	Continuity
D5 (D25)	8	D45 (D65)	2	Existed
	11		3	

4. Check continuity between power window main switch harness connector and ground.

# FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

## < COMPONENT DIAGNOSIS >

Power window main switch connector	Terminal	Ground	Continuity
D5 (D25)	8		
	11		

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between power window main switch harness connector and ground.

Terminal		Power window switch condition	Voltage (V) (Approx.)
(+)	(-)		
Power window main switch connector	Terminal		
D5 (D25)	8	UP	Battery voltage
		DOWN	0
	11	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window main switch. Refer to [PWC-83. "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END.

## Component Inspection

INFOID:000000001505606

PWC

### 1.CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).

Front power window switch (passenger side)	Terminal		Front power window switch condition	Continuity
D45 (D65)	1	5	UP	Existed
	3	4		
	3	4	NEUTRAL	
	2	5		
	1	4	DOWN	
	2	5		

():RHD models

Is the inspection result normal?

YES >> Front power window switch (passenger side) is OK.

NO >> Replace front power window switch (passenger side). Refer to [PWC-83. "Removal and Installation"](#).

# REAR POWER WINDOW SWITCH

< COMPONENT DIAGNOSIS >

## REAR POWER WINDOW SWITCH

### Description

INFOID:000000001505607

- Rear power window motor will be operated if rear power window switch is operated.

### Component Function Check

INFOID:000000001505608

#### 1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch is OK.  
NO >> Refer to [PWC-16, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001505609

#### 1. CHECK REAR POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between rear power window switch harness connector and ground.

Terminal (+)		Terminal (-)	Power window main switch condition		Voltage (V) (Approx.)
Rear power window switch connector	Terminal				
LH: D83 (D113)	2	Ground	LH	UP	Battery voltage
				DOWN	0
	3		UP	0	
			DOWN	Battery voltage	
RH: D103 (D93)	2		RH	UP	Battery voltage
				DOWN	0
	3			UP	0
				DOWN	Battery voltage

():RHD models

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-17, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Replace rear power window switch. Refer to [PWC-83, "Removal and Installation"](#).

#### 3. CHECK REAR POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and rear power window switch connector.
3. Check continuity between power window main switch harness connector and rear power window switch harness connector.



# REAR POWER WINDOW SWITCH

## < COMPONENT DIAGNOSIS >

Power window main switch connector	Terminal	Rear power window switch connector		Terminal	Continuity
D5 (D25)	1	LH	D83 (D113)	2	Existed
	3			3	
	5	RH	D103(D93)	3	
	7			2	

4. Check continuity between power window main switch harness connector and ground.

Power window main switch		Ground	Continuity
Connector	Terminal		
D5 (D25)	1	Ground	Not existed
	3		
	5		
	7		

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 4.CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

- Turn ignition switch ON.
- Check voltage between power window main switch harness connector and ground.

Terminal (+)		Terminal (-)	Power window main switch condition		Voltage (V) (Approx.)
Power window main switch connector	Terminal				
D5 (D25)	1	Ground	REAR LH	UP	Battery voltage
				DOWN	0
	3		REAR LH	UP	0
				DOWN	Battery voltage
	5		REAR RH	UP	Battery voltage
				DOWN	0
	7		REAR RH	UP	0
				DOWN	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window main switch. Refer to [PWC-83, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## Component Inspection

INFOID:000000001505610

### 1.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

## REAR POWER WINDOW SWITCH

### < COMPONENT DIAGNOSIS >

Rear power window switch	Terminal		Rear power window switch condition	Continuity
LH:D83 (D113) RH:D103 (D93)	1	5	UP	Existed
	3	4		
	3	4	NEUTRAL	
	2	5		
	1	4	DOWN	
	2	5		

():RHD models

Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-83. "Removal and Installation"](#).

# POWER WINDOW MOTOR

< COMPONENT DIAGNOSIS >

## POWER WINDOW MOTOR DRIVER SIDE

### DRIVER SIDE : Description

INFOID:000000001505611

Door glass moves UP/DOWN by receiving the signal from power window main switch.

### DRIVER SIDE : Component Function Check

INFOID:000000001505612

#### 1. CHECK POWER WINDOW MOTOR CIRCUIT

Check power window motor operation with power window main switch.

Is the inspection result normal?

- YES >> Power window motor (driver side) is OK.  
 NO >> Refer to [PWC-19. "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000001505613

#### 1. CHECK POWER WINDOW MOTOR (DRIVER SIDE) INPUT SIGNAL

1. Disconnect front power window motor (driver side) connector.
2. Turn ignition switch ON.
3. Check voltage between power window motor (driver side) harness connector and ground.

Terminal		Power window main switch Condition	Voltage (V) (Approx.)
(+)	(-)		
Power window motor (driver side) connector	Terminal		
D7 (D27)	2	UP	Battery voltage
		DOWN	0
	1	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window motor (driver side) connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch connector	Terminal	Front power window motor (driver side) connector	Terminal	Continuity
D5 (D25)	16	D7 (D27)	2	Existed
	12		1	

4. Check continuity between power window main switch harness connector and ground.

Power window main switch connector	Terminal	Ground	Continuity
D5 (D25)	16		
	12		

():RHD models

Is the inspection result normal?

- YES >> GO TO 3.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P



# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

NO >> Repair or replace harness.

### 3. CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between power window main switch harness connector and ground.

Terminal		(-)	Power window main switch condition		Voltage (V) (Approx.)
(+)	Terminal				
D5 (D25)	16	Ground	Driver side	UP	Battery voltage
				DOWN	0
	12		UP	0	
			DOWN	Battery voltage	

():RHD models

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window main switch. Refer to [PWC-83, "Removal and Installation"](#).

### 4. CHECK POWER WINDOW MOTOR

Check front power window motor (driver side).

Refer to [PWC-20, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power window motor (driver side). Refer to [GW-20, "Removal and Installation"](#).

### 5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## DRIVER SIDE : Component Inspection

INFOID:000000001505614

### 1. CHECK POWER WINDOW MOTOR

Does motor operate by connecting the battery voltage directly to power window motor connector?

Front power window motor (driver side) connector	Terminal		Motor condition
	(+)	(-)	
D7 (D27)	1	2	DOWN
	2	1	UP

():RHD models

Is the inspection result normal?

YES >> Power window motor (driver side) is OK.

NO >> Replace front power window motor (driver side). Refer to [GW-20, "Removal and Installation"](#).

## PASSENGER SIDE

### PASSENGER SIDE : Description

INFOID:000000001505615

Door glass moves UP/DOWN by receiving the signal from power window main switch or front power window switch (passenger side).

### PASSENGER SIDE : Component Function Check

INFOID:000000001505616

### 1. CHECK POWER WINDOW MOTOR CIRCUIT

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

Check power window motor operation with power window main switch or front power window switch (passenger side).

Is the inspection result normal?

- YES >> Power window motor (passenger side) is OK.  
 NO >> Refer to [PWC-21. "PASSENGER SIDE : Diagnosis Procedure"](#).

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000001505617

### 1. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) INPUT SIGNAL

1. Disconnect front power window motor (passenger side) connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (passenger side) harness connector and ground.

Terminal		Front power window switch (passenger side) condition	Voltage (V) (Approx.)
(+)	(-)		
Front power window motor (passenger side) connector	Terminal		
D46 (D66)	2	UP	Battery voltage
		DOWN	0
	1	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

### 2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector and front power window motor (passenger side) connector.
3. Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

Front power window switch (passenger side) connector	Terminal	Front power window motor (passenger side) connector	Terminal	Continuity
D45 (D65)	4	D46 (D66)	1	Existed
	5		2	

4. Check continuity between front power window switch (passenger side) harness connector and ground.

Front power window switch (passenger side) connector	Terminal	Ground	Continuity
D45 (D65)	4		Not existed
	5		

():RHD models

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.

### 3. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check front power window motor (passenger side).  
 Refer to [PWC-22. "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Replace front power window motor (passenger side). Refer to [GW-25. "Removal and Installation"](#).

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END.

### PASSENGER SIDE : Component Inspection

INFOID:000000001505618

#### 1.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check motor operation by connecting the battery voltage directly to front power window motor (passenger side) connector.

Front power window motor (passenger side) connector	Terminal		Motor condition
	(+)	(-)	
D46 (D66)	1	2	DOWN
	2	1	UP

():RHD models

Is the inspection result normal?

YES >> Power window motor (passenger side) is OK.

NO >> Replace front power window motor (passenger side). Refer to [GW-25. "Removal and Installation"](#).

### REAR LH

### REAR LH : Description

INFOID:000000001505619

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

### REAR LH : Component Function Check

INFOID:000000001505620

#### 1.CHECK POWER WINDOW MOTOR CURCUIT

Check rear power window motor LH operation with power window main switch or rear power window switch LH.

Is the inspection result normal?

YES >> Power window motor LH is OK.

NO >> Refer to [PWC-22. "REAR LH : Diagnosis Procedure"](#)

### REAR LH : Diagnosis Procedure

INFOID:000000001505621

#### 1.CHECK REAR POWER WINDOW MOTOR LH INPUT SIGNAL

1. Disconnect rear power window motor LH connector.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor LH harness connector and ground.

Terminal		Power window switch condition	Voltage (V) (Approx.)
(+)	(-)		
Rear power window motor LH connector	Terminal		
D82 (D112)	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 3.

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

NO >> GO TO 2.

### 2.CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector and rear power window motor LH connector.
3. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D83 (D113)	4	D82 (D112)	3	Existed
	5		1	

4. Check continuity between rear power window switch LH connector and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D83 (D113)	4		Not existed
	5		

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

### 3.CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-23, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## REAR LH : Component Inspection

INFOID:000000001505622

### COMPONENT INSPECTION

#### 1.CHECK POWER WINDOW MOTOR

Does motor operate by connecting the battery voltage directly to rear power window motor LH connector?

Rear power window motor LH connector	Terminal		Motor condition
	(+)	(-)	
D82 (D112)	3	1	DOWN
	1	3	UP

():RHD models

Is the inspection result normal?

YES >> Power window motor LH is OK.

NO >> Replace rear power window motor LH. Refer to [GW-25, "Removal and Installation"](#).

## REAR RH

# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

### REAR RH : Description

INFOID:000000001505623

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch RH.

### REAR RH : Component Function Check

INFOID:000000001505624

## 1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor RH operation with power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Power window motor RH is OK.  
 NO >> Refer to [PWC-24. "REAR RH : Diagnosis Procedure"](#).

### REAR RH : Diagnosis Procedure

INFOID:000000001505625

## 1. CHECK REAR POWER WINDOW MOTOR RH INPUT SIGNAL

1. Disconnect rear power window motor RH connector.
2. Turn ignition switch ON.
3. Check voltage between rear power window motor RH harness connector and ground.

Terminal		Rear power window switch RH condition	Voltage (V) (Approx.)
(+)	(-)		
Rear power window motor RH connector	Terminal		
D102 (D92)	1	UP	Battery voltage
		DOWN	0
	3	UP	0
		DOWN	Battery voltage

():RHD models

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

## 2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector and rear power window motor RH connector.
3. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D103 (D93)	4	D102 (D92)	3	Existed
	5		1	

4. Check continuity between rear power window switch RH harness connector and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D103 (D93)	4	Ground	Not existed
	5		

():RHD models

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness.



# POWER WINDOW MOTOR

## < COMPONENT DIAGNOSIS >

### 3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-25, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

### 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END.

## REAR RH : Component Inspection

INFOID:000000001505626

### COMPONENT INSPECTION

#### 1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH connector.

Rear power window motor RH connector	Terminal		Motor condition
	(+)	(-)	
D102 (D92)	3	1	DOWN
	1	3	UP

():RHD models

Is the inspection result normal?

YES >> Power window motor RH is OK.

NO >> Replace rear power window motor RH. Refer to [GW-25, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ENCODER CIRCUIT

< COMPONENT DIAGNOSIS >

## ENCODER CIRCUIT

### Description

INFOID:000000001529999

Detects condition of the front power window motor (driver side) operation and transmits to power window main switch as pulse signal.

### Component Function Check

INFOID:000000001530001

#### 1.CHECK ENCODER OPERATION

Check front driver side door glass perform AUTO open/close operation normally when power window main switch.

Is the inspection result normal?

- YES >> Encoder operation is OK.  
 NO >> Refer to [PWC-26. "Diagnosis Procedure"](#)

### Diagnosis Procedure


INFOID:000000001530001

#### Encoder Circuit Check

#### 1.CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between power window main switch harness connector and ground with oscilloscope.

Terminals		Signal (Reference value)
(+)	(-)	
Power window main switch connector	Terminal	Ground
D5 (D25)	9	
	13	Refer to following signal



():RHD models

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> GO TO 2.

#### 2.CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window motor (driver side) connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch connector	Terminal	Front power window motor (driver side) connector	Terminal	Continuity
D5 (D25)	9	D7 (D27)	3	Existed
	13		5	

4. Check continuity between power window main switch harness connector and ground.

# ENCODER CIRCUIT

## < COMPONENT DIAGNOSIS >

Power window main switch connector	Terminal	Ground	Continuity	
D5 (D25)	9			Not existed
	13			

():RHD models

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK ENCODER POWER SUPPLY CIRCUIT

1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (driver side) harness connector and ground.

Terminal		Voltage (V) (Approx.)
(+)	(-)	
Front power window motor (driver side) connector	Terminal	
D7 (D27)	4	Battery voltage

():RHD models

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

### 4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window motor (driver side) harness connector and ground.

Front power window motor (driver side) connector	Terminal	Ground	Continuity
D7 (D27)	6		

():RHD models

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

### 5.CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch connector	Terminal	Front power window motor (driver side) connector	Terminal	Continuity
D5 (D25)	15	D7 (D27)	4	Existed

3. Check continuity between power window main switch harness connector and ground.

Power window main switch connector	Terminal	Ground	Continuity
D5 (D25)	15		

():RHD models

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-83. "Removal and Installation"](#).

NO >> Repair or replace harness.

# ENCODER CIRCUIT

< COMPONENT DIAGNOSIS >

## 6. CHECK HARNESS CONTINUITY 2

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

Power window main switch connector	Terminal	Front power window motor (driver side) connector	Terminal	Continuity
D5 (D25)	2	D7 (D27)	6	Existed

():RHD models

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-83. "Removal and Installation"](#).

NO >> Repair or replace harness.

## 7. CHECK INTERMITTENT INCIDENT

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END.

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000001548868

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
VEHICLE SPEED	While driving	Equivalent to speedometer reading
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
I-KEY LOCK	"LOCK" button of Intelligent Key or door request switch are not pressed	Off
	"LOCK" button of Intelligent Key or door request switch are pressed	On
I-KEY UNLOCK	"UNLOCK" button of Intelligent Key or door request switch are not pressed	Off
	"UNLOCK" button of Intelligent Key or door request switch are pressed	On
PUSH SW	Return to ignition switch to "LOCK" position	Off
	Press ignition switch	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
SHOCK SENSOR	Ignition switch ON	NOMAL
	After the reception of air bag deployment signal from air bag diagnosis sensor unit	Off
	During the reception of air bag deployment signal from air bag diagnosis sensor unit	On
UNLOCK SHOCK	Other than the following	Off
	During the unlock operation interlocked with air bag	On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
UNLOCK WITH DR	<b>NOTE:</b> The item is indicated, but not monitored	On
		Off
LOCK WITH SPEED	Vehicle speed sensing auto door lock function does not operate	Off
	Vehicle speed sensing auto door lock function is operating	On
ACC ON SW	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TAIL LAMP SW	Lighting switch OFF	Off
	Lighting switch 1ST	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
HI BEAM SW	Lighting switch OFF	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Lighting switch OFF	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Lighting switch OFF	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	Rear fog lamp switch OFF	Off
	Rear fog lamp switch ON	On
ENGINE RUN	Engine stopped	Off
	Engine running	On
LIT-SEN FAIL	Light & rain sensor is in normal condition	OK
	Light & rain sensor is with error	NOTOK
AUT LIGHT SYS	Outside of the room is dark	On
	Outside of the room is bright	Off
HD LIGHT TIME	—	Displays a setting time of the follow me home function set by the work support
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
FR WASHER SW	Front washer switch OFF	Off	A
	Front washer switch ON	On	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	B
FR WIPER STOP	Any position other than front wiper stop position	Off	
	Front wiper stop position	On	
RR WIPER ON	Rear wiper switch OFF	Off	C
	Rear wiper switch ON	On	
RR WIPER INT	Rear wiper switch OFF	Off	D
	Rear wiper switch INT	On	
RR WIPER STOP	Rear wiper stop position	Off	
	Other than rear wiper stop position	On	E
RR WASHER SW	Rear washer switch OFF	Off	
	Rear washer switch ON	On	F
REVERSE SW CAN	<b>NOTE:</b> The item is indicated, but not monitored	Off	
		On	
H/L WASH SW	When headlamp washer switch is not pressed	Off	G
	When headlamp washer switch is pressed	On	
FAN ON SIG	Blower fan motor switch OFF	Off	
	Blower fan motor switch ON (other than OFF)	On	H
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	Off	
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	On	I
HAZARD SW	Hazard switch OFF	Off	
	Hazard switch ON	On	J
BRAKE SW	Brake pedal is not depressed	Off	
	Brake pedal is depressed	On	PWC
TRNK OPNR SW	When back door opener switch is not pressed	Off	
	When back door opener switch is pressed	On	L
HOOD SW	Close the hood <b>NOTE:</b> Vehicles without theft warning system are OFF-fixed	Off	
	Open the hood	On	M
AUTO RELOCK	Auto lock function does not operate	Off	
	Auto lock function is operating	On	N
GLS BREAK SEN	The vehicle without glass break sensor	Off	
	The vehicle with glass break sensor	On	O
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	Off	
	Ignition switch ON	On	P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## TERMINAL LAYOUT



### PHYSICAL VALUES

#### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-28, "COMB SW : CONSULT-III Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9, "System Description"](#).



## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
1 (W)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
2 (G)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
3 (W)	Ground	Ignition power supply	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON or START	Battery voltage
4 (SB)	Ground	ACC power supply	Input	Ignition switch OFF	0 V
				Ignition switch ON or ACC	Battery voltage
5 (LG) <sup>*1</sup> (R) <sup>*2</sup>	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage
				Remove mechanical key from ignition key cylinder	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
6 (L)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0165GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0166GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0167GB</p> <p style="text-align: center;">1.3 V</p>
					Rear washer switch ON	 <p style="text-align: right; font-size: small;">JPMIA0169GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the condition below with all switch OFF	<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>  <p style="text-align: right; font-size: small;">JPMIA0196GB</p> <p style="text-align: center;">1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
7 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0165GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0166GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0168GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the condition below with all switch OFF	 <p style="text-align: right;">JPMIA0169GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper INT (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0196GB</p> <p style="text-align: center;">1.3 V</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
8 (V)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p>1.4 V</p>
					Turn signal switch RH	 <p>1.3 V</p>
					Turn signal switch LH	 <p>1.3 V</p>
					Front wiper switch LO	 <p>1.3 V</p>
					Front washer switch ON	 <p>1.3 V</p>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
9 (G) <sup>*3</sup> (B) <sup>*4</sup>	Ground	Combination switch INPUT 2	Input	All switch OFF	 <p style="text-align: center;">1.4 V</p>
				Lighting switch 2ND	 <p style="text-align: center;">1.3 V</p>
				Lighting switch PASS	 <p style="text-align: center;">1.3 V</p>
				Front wiper switch INT	 <p style="text-align: center;">1.3 V</p>
				Front wiper switch HI	 <p style="text-align: center;">1.3 V</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
10 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0165GB</p> <p style="text-align: center;">1.3 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0167GB</p> <p style="text-align: center;">1.3 V</p>
					Rear fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0168GB</p> <p style="text-align: center;">1.3 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right;">JPMIA0169GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the condition below with all switch OFF	 <p style="text-align: right;">JPMIA0196GB</p> <p style="text-align: center;">1.3 V</p>
11 (B)	Ground	Audio link	Input/ Output	—	—	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
12 (LG)	Ground	Rear door switch RH	Input	Rear door switch RH	OFF (When rear door RH closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
				ON (When rear door RH opened)	0 V
13 (V)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
				ON (When back door opened)	0 V
14 (P) <sup>*3</sup> (BR) <sup>*4</sup>	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
				ON (When passenger door opened)	0 V
15 (BR) <sup>*3</sup> (P) <sup>*4</sup>	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
				ON (When driver door opened)	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
16 (GR)	Ground	Rear door switch LH	Input	Rear door switch LH	 <p style="text-align: right;">PKID0924E</p> <p style="text-align: center;">11.2 V</p>
				ON (When rear door LH opened)	0 V
17 (L)	Ground	Door lock status indicator	Output	Door lock status indicator	ON 12 V
				OFF	0 V
20 (SB)	Ground	Rear window defogger switch	Input	Rear window defogger switch	 <p style="text-align: right;">JPMIA0154GB</p> <p style="text-align: center;">1.1 V</p>
				While pressing	0 V
21 (P)	—	CAN-L	Input/ Output	—	—
22 (L)	—	CAN-H	Input/ Output	—	—
23 (V)	Ground	Security indicator	Output	Security indicator	ON 0 V
				Blinking	 <p style="text-align: right;">JPMIA0014GB</p> <p style="text-align: center;">10.3 V</p>
24 (GR)	Ground	Light & rain sensor serial link	Input/ Output	Ignition switch OFF or ACC	12 V
				Ignition switch ON	 <p style="text-align: right;">JPMIA0156GB</p> <p style="text-align: center;">8.7 V</p>
25 (G)	Ground	Alarm link	Output	—	—



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
26 (GR) <sup>*5</sup> (LG) <sup>*6</sup>	Ground	Blower fan motor switch	Input	Blower fan mo- tor switch	OFF	 <small>PKID0924E</small> 11.2 V
					ON (other than OFF)	0 V
27 (P) <sup>*5</sup> (Y) <sup>*6</sup>	Ground	A/C switch	Input	Ignition switch ON	Compressor ON is not re- quested from auto amp. (A/C indicator OFF, blow- er fan motor switch OFF or etc.)	 <small>PKID0924E</small> 11.2 V
					Compressor ON is re- quested from auto amp. (A/C indicator ON and blower fan motor switch ON).	0 V
28 (LG) <sup>*7</sup> (R) <sup>*8</sup>	Ground	Shock detect sensor	Input	Ignition switch ON	Ignition switch OFF or ACC	0 V
					Ignition switch ON	 <small>JPMIA0155GB</small> 6.0 V
29 (LG) <sup>*3</sup> (O) <sup>*4</sup>	Ground	Back door opener switch	Input	Back door opener switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed	0 V
32 (BR)	Ground	Door lock/unlock switch (Unlock)	Input	Door lock/un- lock switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed to the unlock side	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
33 (W) <sup>*9</sup> (Y) <sup>*10</sup>	Ground	Hazard switch	Input	Hazard switch	OFF	 <p style="text-align: right; font-size: small;">JPMIA0154GB</p> <p style="text-align: center;">1.3 V</p>
					ON	0 V
34 (SB) <sup>*3</sup> (P) <sup>*4</sup>	Ground	Door lock/unlock switch (Lock)	Input	Door lock/un- lock switch	Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0154GB</p> <p style="text-align: center;">1.2 V</p>
					Pressed to the lock side	0 V
35 (G)	Ground	Headlamp washer switch	Input	Headlamp washer switch	Not pressed	 <p style="text-align: right; font-size: small;">JPMIA0154GB</p> <p style="text-align: center;">1.2 V</p>
					Pressed to the lock side	0 V
36 (G)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">JPMIA0164GB</p> <p style="text-align: center;">9.1 V</p>
					Lighting switch 2ND	
					Lighting switch HI	
					Lighting switch 1ST	
37 (R)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0161GB</p> <p style="text-align: center;">9.1 V</p>
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
					<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	
Rear wiper switch ON (Wiper intermittent dial 4)						

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
38 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0 V
				Front wiper switch LO	<p style="text-align: right;">JPMA0162GB 9.3 V</p>	
				Front wiper switch MIST		
				Front wiper switch INT		
				Lighting switch AUTO		
				Rear fog lamp switch ON		
39 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermittent dial 4)	All switch OFF	0 V
				Turn signal switch LH	<p style="text-align: right;">JPMA0163GB 9.3 V</p>	
				Lighting switch PASS		
				Lighting switch 2ND		
				Front fog lamp switch ON		
40 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
				<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	Front wiper switch HI (Wiper intermittent dial 4)	<p style="text-align: right;">JPMA0160GB 9.1 V</p>
					Any of the condition below with all switch OFF	
					Rear wiper switch INT (Wiper intermittent dial 4)	
41 (LG)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
42 (V)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver activation	0 V	
				Interior room lamp battery saver no activation	12 V	
43 (SB)	Ground	Rear wiper motor	Output	Rear wiper switch OFF	0 V	
				Rear wiper switch ON	12 V	
44 (B)	Ground	Rear wiper auto stop	Input	Ignition switch ON	<p style="text-align: right;">JPMA0197GB</p>	
				Any position other than rear wiper stop position	0 V	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
45 (V)	Ground	Back door lock actuator	Output	Back door opener switch	 <p style="text-align: right; font-size: small;">SKIA9232E</p>
				Pressed	0 V
47 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
				Turn signal switch OFF	0 V
48 (GR)	Ground	Turn signal RH	Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">PKID0926E</p> <p style="text-align: center;">6.5 V</p>
				Turn signal switch OFF	0 V
49 (Y)	Ground	Rear fog lamp	Output	Rear fog lamp	OFF 0 V ON 12 V
50 (G)	Ground	Unlock sensor	Input	Driver's door	Unlock 5 V lock 0 V
51 (R)	Ground	Stop lamp switch	Input	Depress the brake pedal	Battery voltage
				Release the brake pedal	0 V
52 (R)	Ground	Room lamp timer control	Output	Interior room lamp	OFF 12 V ON 0 V
				Ignition switch	OFF or ACC 0 V ON 12 V
53 (L)	Ground	Power window power supply (IGN)	Output	Ignition switch	OFF or ACC 0 V ON 12 V
54 (O)	Ground	Door unlock (All other than driver's door)	Output	Door lock/unlock switch	 <p style="text-align: right; font-size: small;">SKIA9232E</p>
				Pressed to the unlock side	0 V
55 (B)	Ground	Ground	—	Ignition switch ON	0 V

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
56 (V)	Ground	Door lock (All) and fuel lid lock	Output	Door lock/un- lock switch	Not pressed	0 V
					Pressed to the lock side	 <p>Timing diagram for terminal 56 showing a pulse from 0V to approximately 10V for 0.1s. The y-axis is labeled (V) with markings at 0, 5, 10, and 15. The x-axis is labeled 0.1s. The pulse is labeled SKIA9232E.</p>
57 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage	
58 (P)	Ground	Power window pow- er supply (BAT)	Output	Ignition switch OFF	12 V	
59 (R)	Ground	Super lock	Output	When lock button of key fob or Intelligent Key is not pressed	0 V	
				When lock button of key fob or Intelligent Key is pressed	12 V	
60 (G)	Ground	Driver's door unlock and fuel lid unlock	Output	Door lock/un- lock switch	Pressed to the unlock side	 <p>Timing diagram for terminal 60 showing a pulse from 0V to approximately 10V for 0.1s. The y-axis is labeled (V) with markings at 0, 5, 10, and 15. The x-axis is labeled 0.1s. The pulse is labeled SKIA9232E.</p>
					Not pressed	0 V

\*1: With Intelligent Key

\*2: Without Intelligent Key

\*3: RHD models

\*4: LHD models

\*5: With gasoline engine

\*6: With diesel engine

\*7: RHD models with side air bag

\*8: LHD models with side air bag

\*9: With xenon headlamp and daytime light system

\*10: Except with xenon headlamp and daytime light system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## Wiring Diagram - POWER WINDOW CONTROL SYSTEM (LHD MODELS) -

INFOID:000000001505631

### POWER WINDOW SYSTEM (LHD MODELS)



2007/02/28

JCKWA0443GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

A

B

C

D

E

F


G

H

I

J

PWC



L

M

N

O


P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
7	Y	-
94	L	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-
13	Y	-

Connector No.	B88
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

Connector No.	B88
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-
12	B	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	R	-
14	O	-
15	LG	-
16	Y	-

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	O	-
5	Y	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	SB	-
12	GR	-
13	P	-

Terminal No.	15	G	-
Terminal No.	16	L	-

Connector No.	D6
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS36FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
19	P	-

JCKWA0445GE




# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	D7
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	L	-
3	V	-
4	G	-
5	P	-
6	W	-

Connector No.	D42
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	B	-
15	L	-

Connector No.	D45
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	SB	-
4	Y	-
5	R	-
7	B	-

Connector No.	D48
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	D81
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

Connector No.	D82
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	RS08FG-DG3



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D83
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-
7	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

JCKWA0446GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	D102
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	RS06FG-DGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D103
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-
7	B	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
7	Y	-
9A	L	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-[LHD models]
13	Y	-[LHD models]

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	LG	-
14	Y	-
15	LG	-
16	Y	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	A4B40FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	IGN SW

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA12FBR



Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	BAT(FUSE)

JCKWA0447GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	M87
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FHA08FEB



Terminal No.	Color of Wire	Signal Name [Specification]
53	L	P/W POWER SUPPLY(IGN)
55	B	GND
57	Y	BAT1E/L
58	P	P/W POWER SUPPLY(BAT)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-C51B-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M82
Connector Name	WIRE TO WIRE
Connector Type	NS18MW-GS



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SP	-
6	B	-
15	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

JCKWA0448GE




# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THROW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
7	Y	-
94	L	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-
13	Y	-

Connector No.	B7
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-

Connector No.	B89
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8					

Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	R	-
14	O	-
15	LG	-
16	Y	-

Connector No.	D25
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	O	-
5	Y	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	SB	-
12	GR	-
13	P	-

15	G
16	SB

Connector No.	D26
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS06FW-CS



17	18	19
----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
19	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


PWC

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	D27
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	SB	-
3	V	-
4	G	-
5	P	-
6	W	-

Connector No.	D82
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
15	L	-

Connector No.	D85
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	SB	-
4	Y	-
5	R	-

Connector No.	D88
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	D91
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-

Connector No.	D82
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	RS08FG-DG3



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D83
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-

Connector No.	D111
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-

JCKWA0451GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	D112
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	RS30FG-DDGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D113
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS30FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	Y	-
4	G	-
5	R	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
7	Y	-
9A	L	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	P	-[RHD models]
13	R	-[RHD models]

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	P	-
14	R	-
15	LG	-
16	Y	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	4A40FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	IGM SW

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA12FBR



Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	BAT(FUSE)

JCKWA0452GE


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FHA08FEF




Terminal No.	Color of Wire	Signal Name [Specification]
53	L	P/W POWER SUPPLY(IGN)
55	B	GND
57	Y	BAT(F/L)
58	P	P/W POWER SUPPLY(BAT)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	T180MM-CST6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Type	NS18MM-GS



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
15	L	-

## Fail Safe

### FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC is detected.

JCKWA0453GE

INFOID:000000001548870



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

DTC	Fail-safe	Cancellation	
B2190: NATS ANTENNA AMP	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC	A
B2191: DIFFERENCE OF KEY	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC	B
B2192: ID DISCORD BCM-ECM	Fuel cut (ECM)	Erase DTC	C
B2193: CHAIN OF BCM-ECM	Fuel cut (ECM)	Erase DTC	
B2194: DISCORD BCM-I-KEY	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC	D
B2195: ANTI SCANNING	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC	E
B2196: DONGLE NG	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC	F

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal. When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

- Turn ignition switch OFF.
- Pass more than 1 minute after the rear wiper stop.
- Turn ignition switch ON.
- Operate the rear wiper switch.

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status from the terminal voltage. BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### FAIL-SAFE CONTROL BY LIGHT & RAIN SENSOR MALFUNCTION

BCM detects the light & rain sensor serial link error and the light & rain sensor malfunction. BCM controls the following fail-safe when light & rain sensor has a malfunction.

Fail-safe Control

- Auto light control: Headlamp is turned ON.
- Front wiper control: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.

### DTC Inspection Priority Chart

INFOID:000000001548871

Priority	DTC	
1	<ul style="list-style-type: none"> <li>U1000: CAN COMM CIRCUIT</li> <li>U1010: CONTROL UNIT (CAN)</li> </ul>	
2	<ul style="list-style-type: none"> <li>B2190: NATS ANTENNA AMP</li> <li>B2191: DIFFERNCE OF KEY</li> <li>B2192: ID DISCORD BCM-ECM</li> <li>B2193: CHAIN OF BCM-ECM</li> <li>B2194: DISCORD BCM-I-KEY</li> <li>B2195: ANTI SCANNING</li> <li>B2196: DONGLE NG</li> </ul>	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## DTC Index

INFOID:000000001548872

### NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- PAST: Displays when there is a malfunction that is detected in the past and stored.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

DTC	TIME		Fail-safe	Reference
	0	1 - 39		
U1000: CAN COMM CIRCUIT	0	1 - 39	—	<a href="#">BCS-33</a>
U1010: CONTROL UNIT (CAN)	0	1 - 39	—	<a href="#">BCS-34</a>
B2190: NATS ANTENNA AMP	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-41</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-254</a></li> </ul>
B2191: DIFFERENCE OF KEY	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-43</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-256</a></li> </ul>
B2192: ID DISCORD BCM-ECM	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-38</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-251</a></li> </ul>
B2193: CHAIN OF BCM-ECM	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-40</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-253</a></li> </ul>
B2194: DISCORD BCM-I-KEY	CRNT	PAST	×	<a href="#">SEC-53</a>
B2195: ANTI SCANNING	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-54</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-264</a></li> </ul>
B2196: DONGLE NG	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-55</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-265</a></li> </ul>

# POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS >

## POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000001515861

### TERMINAL LAYOUT



A. LHD:D5  
RHD:D25

B. LHD:D6  
RHD:D26

### PHYSICAL VALUES

#### POWER WINDOW MAIN SWITCH

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
1 (R)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is UP at operated.	Battery voltage
2 (W)	Ground	Encoder ground	—	—	0
3 (O)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is DOWN at operated.	Battery voltage
5 (Y)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is DOWN at operated.	Battery voltage
6 (BR)	Ground	Door lock and unlock switch UNLOCK signal	Input	When door lock and unlock switch in power window main switch is UNLOCK signal	Battery voltage
7 (LG)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is UP at operated.	Battery voltage
8 (BR)	Ground	Front power window motor (passenger side) UP signal	Output	When front RH switch in power window main switch is UP at operated.	Battery voltage
9 (V)	2	Encoder pulse signal 2	Input	When power window motor operates.	


JMKIA0070GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Voltage [V] (Approx.)
+	-	Signal name	Input/ Output		
10 (L)	Ground	Ignition switch power supply	Input	IGN SW ON	Battery voltage
				Other than above	0
11 (SB)	Ground	Front power window motor (passenger side) DOWN signal	Output	When front RH switch in power window main switch is DOWN at operated.	Battery voltage
12 (GR)	16	Front power window motor (driver side) DOWN signal	Output	When front LH switch in power window main switch is DOWN at operated.	Battery voltage
13 (P)	2	Encoder pulse signal 1	Input	When front power window motor (driver side) operates.	
15 (G)	Ground	Encoder power supply	Output	When ignition switch ON.	Battery voltage
16 (L)	12	Front power window motor (driver side) UP signal	Output	When front LH switch in power window main switch is UP at operated.	Battery voltage
17 (B)	Ground	Ground	—	—	0
18 (G)	Ground	Door lock and unlock switch LOCK signal	Input	When door lock and unlock switch in power window main switch is LOCK signal	Battery voltage
19 (P)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage

JMKIA0070GB


# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

## Wiring Diagram - POWER WINDOW CONTROL SYSTEM (LHD MODELS) -

INFOID:000000001551242

### POWER WINDOW SYSTEM (LHD MODELS)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


PWC

2007/02/28

JCKWA0443GE

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >




JCKWA0444GE

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THROW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
7	Y	-
94	L	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-
13	Y	-

Connector No.	B8F
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

Connector No.	B8B
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-
12	B	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	R	-
14	O	-
15	LG	-
16	Y	-

Connector No.	D5
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	O	-
5	Y	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	SB	-
12	GR	-
13	P	-

Terminal No.	15	G	-
Terminal No.	16	L	-

Connector No.	D6
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
18	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


PWC

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	D7
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	L	-
3	V	-
4	G	-
5	P	-
6	W	-

Connector No.	D42
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	B	-
15	L	-

Connector No.	D45
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	SB	-
4	Y	-
5	R	-
7	B	-

Connector No.	D48
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	D81
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

Connector No.	D82
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	RS08FG-DG3




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D83
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-
7	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-
12	B	-

JCKWA0446GE



# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	D102
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	RSJ06G-DDY




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D103
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NSJ08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-
7	B	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
7	Y	-
9A	L	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-[LHD models]
13	Y	-[LHD models]

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	LG	-
14	Y	-
15	LG	-
16	Y	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	4AB40FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	IGM SW

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA12FBR



Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	BAT(FUSE)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (LHD MODELS)

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FHA08FE8



Terminal No.	Color of Wire	Signal Name [Specification]
53	L	P/W POWER SUPPLY(IGN)
55	B	GND
57	Y	BAT(F/L)
58	P	P/W POWER SUPPLY(BAT)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	T180MM-CST6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M82
Connector Name	WIRE TO WIRE
Connector Type	NS18MM-GS



Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	B	-
15	L	-

JCKWA0448GE


# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

## Wiring Diagram - POWER WINDOW CONTROL SYSTEM (RHD MODELS) -

INFOID:000000001551243

### POWER WINDOW SYSTEM (RHD MODELS)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

2007/2/28

JCKWA0449GE

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	W	-
7	Y	-
94	L	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	LG	-
13	Y	-

Connector No.	B87
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-

Connector No.	B89
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
4	BR	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	R	-
14	O	-
15	LG	-
16	Y	-

Connector No.	D25
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	O	-
5	Y	-
7	LG	-
8	BR	-
9	V	-
10	L	-
11	SB	-
12	GR	-
13	P	-

Terminal No.	15	G	-
Terminal No.	16	SB	-

Connector No.	D26
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS36FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
17	B	-
19	P	-


JCKWA0450GE

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	D27
Connector Name	FRONT POWER WINDOW MOTOR (DRIVER SIDE)
Connector Type	NS08FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	SB	-
3	V	-
4	G	-
5	P	-
6	W	-

Connector No.	D82
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
15	L	-

Connector No.	D85
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	SB	-
4	Y	-
5	R	-

Connector No.	D88
Connector Name	FRONT POWER WINDOW MOTOR (PASSENGER SIDE)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-

Connector No.	D91
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	LG	-
10	Y	-
11	L	-

Connector No.	D92
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Type	RS08FG-DG3



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D83
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-
3	Y	-
4	G	-
5	R	-

Connector No.	D111
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
9	W	-
10	Y	-
11	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >


## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	D112
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Type	RS06FG-DGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
3	G	-

Connector No.	D113
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	Y	-
4	G	-
5	R	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	-
7	Y	-
9A	L	-

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
11	L	-
12	P	-[RHD models]
13	R	-[RHD models]

Connector No.	M21
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
6	L	-
7	P	-
12	B	-
13	P	-
14	R	-
15	LG	-
16	Y	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	A4B40FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	IGN SW

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA12FBR



Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	BAT(FUSE)

JCKWA0452GE



# POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P



## POWER WINDOW SYSTEM (RHD MODELS)

Connector No.	M87
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FHA08FEB



Terminal No.	Color of Wire	Signal Name [Specification]
53	L	P/W POWER SUPPLY(IGN)
55	B	GND
57	Y	BAT(+/L)
58	P	P/W POWER SUPPLY(BAT)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TR80MW-CSTB-TM4

Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Type	NS18MW-GS

Terminal No.	Color of Wire	Signal Name [Specification]
4	W	-
5	SB	-
15	L	-

## Fail Safe

### FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

JCKWA0453GE

INFOID:000000001505639

# POWER WINDOW MAIN SWITCH

## < ECU DIAGNOSIS >

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window main switch or front power window motor (driver side).



# NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

### Diagnosis Procedure

INFOID:000000001505640

#### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.  
Refer to [PWC-9, "BCM : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK POWER WINDOW MAIN SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window main switch power supply and ground circuit.  
Refer to [PWC-9, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# DRIVER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## DRIVER SIDE POWER WINDOW DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000001505641

#### 1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

---

Check power window motor.

Refer to [PWC-19, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

# FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WINDOW SWITCH

WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE  
POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000001505642

### 1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).  
Refer to [PWC-14, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts

### 2. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check front power window motor (passenger side).  
Refer to [PWC-20, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

## WITH FRONT POWER WINDOW SWITCH ONLY

WITH FRONT POWER WINDOW SWITCH ONLY : Diagnosis Procedure

INFOID:000000001505643

### 1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) POWER SUPPLY AND GROUND CIRCUIT

Check front power window switch (passenger side) power supply and ground circuit.  
Refer to [PWC-11, "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).  
Refer to [PWC-14, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts

### 3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## REAR LH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

REAR LH SIDE POWER WINDOW DOES NOT OPERATE  
WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW  
SWITCH LH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW  
SWITCH LH : Diagnosis Procedure

INFOID:000000001505644

### 1. CHECK REAR POWER WINDOW SWITCH

---

Check rear power window switch.

Refer to [PWC-16, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CHECK REAR POWER WINDOW MOTOR LH

---

Check rear power window motor LH.

Refer to [PWC-22, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

WITH REAR POWER WINDOW SWITCH LH ONLY

WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure

INFOID:000000001505645

### 1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

---

Check rear power window switch power supply and ground circuit.

Refer to [PWC-12, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

### 2. CHECK REAR POWER WINDOW SWITCH

---

Check rear power window switch.

Refer to [PWC-16, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

### 3. CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

# REAR RH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW DOES NOT OPERATE  
WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Diagnosis Procedure

INFOID:000000001505646

## 1.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.  
Refer to [PWC-16, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

## 2.CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.  
Refer to [PWC-24, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

## 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> GO TO 1.

WITH REAR POWER WINDOW SWITCH RH ONLY

WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure

INFOID:000000001505647

## 1.CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.  
Refer to [PWC-12, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

## 2.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.  
Refer to [PWC-16, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

## 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).
- NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

## ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000001505648

#### 1.PERFORM INITIALIZATION PROCEDURE

---

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END.

NO >> GO TO 2.

#### 2.CHECK ENCODER CIRCUIT

---

Check encoder circuit.

Refer to [PWC-26, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

# AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

## AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

### Diagnosis Procedure

INFOID:000000001505649

#### 1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END.

NO >> GO TO 2.

#### 2.CHECK ENCODER

Check encoder.

Refer to [PWC-26, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

## POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

---

### POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

#### Diagnosis Procedure

INFOID:000000001505650

#### 1. REPLACE POWER WINDOW MAIN SWITCH

---

Replace power window main switch.

>> Refer to [PWC-83. "Removal and Installation"](#).



# POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

## POWER WINDOW SWITCH ILLUMINATION DOES NOT ILLUMINATE PASSENGER SIDE

### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000001518891

#### 1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) POWER SUPPLY AND GROUND CIRCUIT

Check front power window switch (passenger side) power supply and ground circuit.

Refer to [PWC-11. "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. REPLACE FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Replace front power window switch (passenger side).

>> Refer to [PWC-83. "Removal and Installation"](#).

### REAR LH

### REAR LH : Diagnosis Procedure

INFOID:000000001518892

#### 1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-12. "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.

>> Refer to [PWC-83. "Removal and Installation"](#).

### REAR RH

### REAR RH : Diagnosis Procedure

INFOID:000000001518893

#### 1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-12. "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.

>> Refer to [PWC-83. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

PWC

# PRECAUTIONS

< PRECAUTION >

---

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001557126

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# POWER WINDOW MAIN SWITCH


< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### POWER WINDOW MAIN SWITCH

Exploded View

INFOID:000000001505653



1. Power window main switch
2. Power window main switch finisher

#### NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power switch (LH & RH).


Refer to removal and installation procedure. Refer to [PWC-83. "Removal and Installation"](#).

### Removal and Installation

INFOID:000000001505654

#### REMOVAL

1. Remove the power window main switch finisher (2).  
Refer to [INT-10. "FRONT DOOR FINISHER : Exploded View"](#) and [INT-10. "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Power window main switch (1) is removed from power window main switch finisher (2) using flat-head screw driver (A) etc.


 : Pawl

#### CAUTION:

**Do not fold the pawl of power window main switch finisher.**

#### NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power window switch (LH & RH).



#### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

Power window main switch is exchanged or is detached it is necessary to do the initialization procedure. Refer to [PWC-4. "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
PWC  
L  
M  
N  
O  
P