

SECTION **RF**  
ROOF

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

CONTENTS

<b>BASIC INSPECTION</b> .....	3	Reference Value .....	12
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	3	Wiring Diagram— SUNROOF CONTROL SYS-	
Work Flow .....	3	TEM — .....	29
<b>INSPECTION AND ADJUSTMENT</b> .....	4	Fail Safe .....	31
<b>ADDITIONAL SERVICE WHEN REPLACING</b>		DTC Inspection Priority Chart .....	32
<b>CONTROL UNIT</b> .....	4	DTC Index .....	33
ADDITIONAL SERVICE WHEN REPLACING		<b>SUNROOF MOTOR ASSEMBLY</b> .....	34
CONTROL UNIT : Description .....	4	Reference Value .....	34
ADDITIONAL SERVICE WHEN REPLACING		Wiring Diagram— SUNROOF CONTROL SYS-	
CONTROL UNIT : Special Repair Requirement .....	4	TEM — .....	35
<b>FUNCTION DIAGNOSIS</b> .....	5	<b>SYMPTOM DIAGNOSIS</b> .....	38
<b>SUNROOF SYSTEM</b> .....	5	<b>SUNROOF DOES NOT OPERATE PROPER-</b>	
System Diagram .....	5	<b>LY</b> .....	38
System Description .....	5	Diagnosis Procedure .....	38
Component Parts Location .....	6	<b>AUTO OPERATION DOES NOT OPERATE</b> ....	39
Component Description .....	6	Diagnosis Procedure .....	39
<b>COMPONENT DIAGNOSIS</b> .....	7	<b>DOES NOT STOP FULLY-OPEN OR FULLY-</b>	
<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	7	<b>CLOSED POSITION</b> .....	40
<b>BCM (BODY CONTROL MODULE)</b> .....	7	Diagnosis Procedure .....	40
BCM (BODY CONTROL MODULE) : Diagnosis		<b>SUNROOF DOES NOT OPERATE ANTI-</b>	
Procedure .....	7	<b>PINCH FUNCTION</b> .....	41
<b>SUNROOF MOTOR ASSEMBLY</b> .....	7	Diagnosis Procedure .....	41
SUNROOF MOTOR ASSEMBLY :		<b>SQUEAK AND RATTLE TROUBLE DIAG-</b>	
Diagnosis Procedure .....	8	<b>NOSES</b> .....	42
<b>SUNROOF SWITCH</b> .....	10	Work Flow .....	42
Description .....	10	Inspection Procedure .....	44
Component Function Check .....	10	Diagnostic Worksheet .....	46
Diagnosis Procedure .....	10	<b>PRECAUTION</b> .....	48
Component Inspection .....	11	<b>PRECAUTIONS</b> .....	48
<b>ECU DIAGNOSIS</b> .....	12	Precaution for Supplemental Restraint System	
<b>BCM (BODY CONTROL MODULE)</b> .....	12	(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	
		SIONER" .....	48
		Service Notice .....	48

RF

Precaution for Work .....	48	<b>SUNROOF MOTOR ASSEMBLY .....</b>	<b>53</b>
<b>PREPARATION .....</b>	<b>49</b>	SUNROOF MOTOR ASSEMBLY : Exploded View	... 53
<b>PREPARATION .....</b>	<b>49</b>	SUNROOF MOTOR ASSEMBLY : Removal and	
Commercial Service Tool .....	49	Installation .....	53
<b>ON-VEHICLE MAINTENANCE .....</b>	<b>50</b>	<b>SUNROOF UNIT ASSEMBLY .....</b>	<b>54</b>
<b>PRE-INSPECTION FOR DIAGNOSTIC .....</b>	<b>50</b>	SUNROOF UNIT ASSEMBLY : Exploded View ....	54
Basic Inspection .....	50	SUNROOF UNIT ASSEMBLY : Removal and In-	
<b>ON-VEHICLE REPAIR .....</b>	<b>51</b>	stallation .....	56
<b>SUNROOF .....</b>	<b>51</b>	SUNROOF UNIT ASSEMBLY : Disassembly and	
<b>GLASS LID .....</b>	<b>51</b>	Assembly .....	57
GLASS LID : Exploded View .....	51	<b>SUNSHADE .....</b>	<b>57</b>
GLASS LID : Removal and Installation .....	51	SUNSHADE : Exploded View .....	58
GLASS LID : Adjustment .....	52	SUNSHADE : Removal and Installation .....	58
		<b>SUNROOF SWITCH .....</b>	<b>59</b>
		SUNROOF SWITCH : Exploded View .....	59
		SUNROOF SWITCH : Removal and Installation ...	59

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001160366

DETAILED FLOW

#### 1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicles in.

>> GO TO 2.

#### 2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.  
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

#### 3.PERFORM "BASIC INSPECTION"

Perform the basic inspection.  
Refer to [RF-50. "Basic Inspection"](#).

>> GO TO 4.

#### 4.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2. Then identify where to start performing the diagnosis based on possible causes and symptom.

>> GO TO 5.

#### 5.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 6.

#### 6.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 7.

#### 7.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END  
NO >> GO TO 3.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

---

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000001160367

#### MEMORY RESET PROCEDURE

Initialization of system should be conducted after the following conditions.

- When the sunroof motor is changed.
- When the sunroof does not operate normally. (Incomplete initialization conditions)

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000001160368

#### INTERRUPTION DETECTION FUNCTION

The CPU of sunroof motor monitors the sunroof motor operation and the sunroof position (fully-closed or other) by the signals from sunroof motor.

When sunroof motor detects an interruption during the following sliding close operation, sunroof switch controls the motor for open and the sunroof will operate until full open position.

- automatic close operation when ignition switch is in the ON position.
- automatic close operation during retained power operation.

#### INITIALIZATION PROCEDURE

If the sunroof does not close or open automatically, use the following procedure to return sunroof operation to normal.

1. Close the sunroof if it is not in the closed position. It may be necessary to repeatedly push the switch to close the sunroof.
2. Press and hold the TILT UP switch the sunroof will tilt up. Release the button.
3. Press and hold the TILT UP switch again. Do not release the switch, keep pressure on it. After 4 seconds of depressing, the sunroof will full close.
4. Initializing procedure is complete. Confirm proper operation of the sunroof (slide open, slide close, tilt up, tilt down.)

#### ANTI-PINCH FUNCTION

1. Full open the sunroof.
2. Place a piece of wood near fully closed position.
3. Close the sunroof completely with auto-slide close.

Check that sunroof lowers for approximately 150mm or 2seconds without pinching a piece of wood and stops.

#### **CAUTION:**

- Check that auto-slide operates before inspection when system initialization is performed.
- Depending on environment and driving conditions, if a similar impact or load is applied to the sunroof it may lower.
- Do not check with hands and other part of body because they may be pinched. Do not get pinched.
- Perform initial setting when auto-slide operation or anti-pinch function does not operate normally.

# SUNROOF SYSTEM

< FUNCTION DIAGNOSIS >


## FUNCTION DIAGNOSIS

### SUNROOF SYSTEM

#### System Diagram

INFOID:000000001160369

#### SUNROOF SYSTEM



#### System Description

INFOID:000000001160370

#### SUNROOF SYSTEM

#### INPUT/OUTPUT SIGNAL CHART

Item	Input signal to sunroof motor assembly	Sunroof motor function	Actuator
Sunroof switch	Sunroof switch signal (tilt down or slide open)	Sunroof control	Sunroof motor
	Sunroof switch signal (tilt up or slide close)		
Combination meter	Vehicle speed signal		

#### SUNROOF OPERATION

- Sunroof motor assembly operates with the power supply that is output from BCM while ignition switch is ON or retained power is operating.
- Tilt up/down & slide open/close signals from sunroof switch enables operate sunroof motor to move arbitrarily.
- Sunroof motor assembly receives a vehicle speed signal from combination meter and controls the sunroof motor torque of tilt-down at the time of high speed operation.

#### AUTO OPERATION

Sunroof AUTO feature makes it possible to slide open and slide close or tilt up and tilt down the sunroof without holding the sunroof switch in the slide open/tilt down or slide close/tilt up position.

#### ANTI-PINCH FUNCTION

The CPU of sunroof motor assembly monitors the sunroof motor operation and the sunroof position (fully-closed or other) by the signals from sunroof motor.

When sunroof motor detects an interruption during the following slide close and tilt down operation, sunroof switch controls the motor for open and the sunroof will operate until full up position (when tilt down operate) or 150mm (5.91 in) or more in an open direction (when slide close operate):


- Close operation and tilt down when ignition switch is in the "ON" position

# SUNROOF SYSTEM

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000001160371



JMKIA0654ZZ

- |                          |                                 |                             |
|--------------------------|---------------------------------|-----------------------------|
| 1. BCM<br>M65, M66, M67  | 2. Sunroof motor assembly<br>R5 | 3. Combination meter<br>M34 |
| 4. Sunroof switch<br>R16 |                                 |                             |

- |                       |                                 |
|-----------------------|---------------------------------|
| A. Over the glove box | B. View with headlining removed |
|-----------------------|---------------------------------|

## Component Description

INFOID:000000001160372

Component	Function
BCM	Supplies the power supply to sunroof motor assembly.
Sunroof switch	Transmits tilt up/down & slides open/close operation signal to sunroof motor assembly.
Sunroof motor assembly	It is sunroof motor and CPU integrated type that enables tilt up/down & slide open/close by sunroof switch operation
Combination meter	Transmits vehicle speed signal to sunroof motor assembly.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL MODULE)

#### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000001551384

### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Terminal No.	Signal name	Fuses and fusible link No.
41	Battery power supply	10
57		J
4	ACC power supply	20
3	Ignition power supply	1

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
(+)	(-)		OFF	ACC	ON
BCM		Ground			
Connector	Terminal				
M67	57		Battery voltage	Battery voltage	Battery voltage
M66	41		Battery voltage	Battery voltage	Battery voltage
M65	4	Approx. 0 V	Battery voltage	Battery voltage	
	3	Approx. 0 V	Approx. 0 V	Battery voltage	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M67	55		Existed

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

### SUNROOF MOTOR ASSEMBLY

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure

INFOID:000000001160375

### SUNROOF MOTOR ASSEMBLY

#### 1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector.
3. Turn ignition switch ON.
4. Check voltage between sunroof motor assembly harness connector and ground.

Sunroof motor assembly		Ground	Voltage (V) (Approx.)
Connector	Terminal		
R5	2	Ground	Battery voltage
	4		

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between sunroof motor assembly harness connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R5	6	Ground	Exists

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

#### 3. CHECK SONROOF MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and sunroof motor assembly harness connector.

BCM		Sunroof motor assembly		Continuity
Connector	Terminal	Connector	Terminal	
M65	53	R5	4	Exists
	58		2	

4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M65	53	Ground	Does not exist
	58		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

#### 4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector and ground.



# POWER SUPPLY AND GROUND CIRCUIT

## < COMPONENT DIAGNOSIS >

BCM		Ground	Voltage (V) (Approx.)
Connector	Terminal		
M65	53	Ground	Battery voltage
	58		

Is the inspection result normal?

YES >> Check condition of harness and connector.

NO >> Replace BCM. Refer to [BCS-68, "Removal and Installation"](#).

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

RF

# SUNROOF SWITCH

< COMPONENT DIAGNOSIS >

## SUNROOF SWITCH

### Description

INFOID:000000001366045

- BCM supplies power.
- It is sunroof motor and CPU integrated type.
- Tilts up/down & slides open/close by sunroof switch operation.
- In order to close sunroof lid certainly with the signal from unified meter and A/C amp. at the time of high speed run, the sunroof motor torque at the time of tilt-down operation is controlled.

### Component Function Check

INFOID:000000001366046

#### 1.CHECK SUNROOF MOTOR FUNCTION

Check tilt up/down & slide open/close operations with sunroof switch.

Is the inspection result normal?

- YES >> Sunroof motor assembly is OK.  
 NO >> Refer to [RF-10, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001366047

## SUNROOF MOTOR ASSEMBLY

#### 1.CHECK SUNROOF SWITCH INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between sunroof motor assembly harness connector and ground.

Sunroof motor assembly connector	Terminals		Condition	Voltage (V) (Approx.)
	(+)	(-)		
R5	5	Ground	Sunroof switch is operated TILT DOWN or SLIDE OPEN	0
			Other than above	Battery voltage
	1		Sunroof switch is operated TILT UP or SLIDE CLOSE	0
			Other than above	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2.CHECK SUNROOF SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sunroof motor assembly connector and sunroof switch connector.
3. Check continuity between sunroof motor assembly harness connector and sunroof switch harness connector.

Sunroof motor assembly		Sunroof switch		Continuity
Connector	Terminal	Connector	Terminal	
R5	5	R6	1	Exists
	1		3	

4. Check continuity between sunroof motor assembly connector and ground.

Sunroof motor assembly		Ground	Continuity
Connector	Terminal		
R5	5	Ground	Does not exist
	1		

# SUNROOF SWITCH

## < COMPONENT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3.CHECK SUNROOF SWITCH GROUND CIRCUIT

Check continuity between sunroof switch harness connector and ground.

Sunroof switch		Ground	Continuity
Connector	Terminal		
R5	2	Ground	Exists

Is the inspection result normal?

YES >> Refer to [RF-11, "Component Inspection"](#).

NO >> Repair or replace harness.

### 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000001160376

## SUNROOF SWITCH

### 1.CHECK SUNROOF SWITCH

1. Turn ignition switch OFF.
2. Disconnect sunroof switch connector.
3. Check continuity sunroof switch terminals.

Terminals		Condition	Continuity
1	2	Sunroof switch is operated TILT DOWN or SLIDE OPEN	Exists
		Other than above	Does not exist
3		Sunroof switch is operated TILT UP or SLIDE CLOSE	Exists
		Other than above	Does not exist

Is the inspection result normal?

YES >> Sunroof switch is OK.

NO >> Replace sunroof switch (built in map lamp assembly). Refer to [RF-59, "SUNROOF SWITCH : Removal and Installation"](#).

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

### ECU DIAGNOSIS

#### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000001551386

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
VEHICLE SPEED	While driving	Equivalent to speedometer reading
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
I-KEY LOCK	"LOCK" button of Intelligent Key or door request switch are not pressed	Off
	"LOCK" button of Intelligent Key or door request switch are pressed	On
I-KEY UNLOCK	"UNLOCK" button of Intelligent Key or door request switch are not pressed	Off
	"UNLOCK" button of Intelligent Key or door request switch are pressed	On
PUSH SW	Return to ignition switch to "LOCK" position	Off
	Press ignition switch	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
SHOCK SENSOR	Ignition switch ON	NOMAL
	After the reception of air bag deployment signal from air bag diagnosis sensor unit	Off
	During the reception of air bag deployment signal from air bag diagnosis sensor unit	On
UNLOCK SHOCK	Other than the following	Off
	During the unlock operation interlocked with air bag	On

## BCM (BODY CONTROL MODULE)

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
UNLOCK WITH DR	<b>NOTE:</b> The item is indicated, but not monitored	On	A
		Off	
LOCK WITH SPEED	Vehicle speed sensing auto door lock function does not operate	Off	B
	Vehicle speed sensing auto door lock function is operating	On	
ACC ON SW	Ignition switch OFF	Off	C
	Ignition switch ACC or ON	On	
REAR DEF SW	Rear window defogger switch OFF	Off	D
	Rear window defogger switch ON	On	
TAIL LAMP SW	Lighting switch OFF	Off	E
	Lighting switch 1ST	On	
TURN SIGNAL R	Turn signal switch OFF	Off	F
	Turn signal switch RH	On	
TURN SIGNAL L	Turn signal switch OFF	Off	G
	Turn signal switch LH	On	
HI BEAM SW	Lighting switch OFF	Off	H
	Lighting switch HI	On	
HEAD LAMP SW 1	Lighting switch OFF	Off	I
	Lighting switch 2ND	On	
HEAD LAMP SW 2	Lighting switch OFF	Off	J
	Lighting switch 2ND	On	
PASSING SW	Other than lighting switch PASS	Off	RF
	Lighting switch PASS	On	
AUTO LIGHT SW	Lighting switch OFF	Off	L
	Lighting switch AUTO	On	
FR FOG SW	Front fog lamp switch OFF	Off	M
	Front fog lamp switch ON	On	
RR FOG SW	Rear fog lamp switch OFF	Off	N
	Rear fog lamp switch ON	On	
ENGINE RUN	Engine stopped	Off	O
	Engine running	On	
LIT-SEN FAIL	Light & rain sensor is in normal condition	OK	P
	Light & rain sensor is with error	NOTOK	
AUT LIGHT SYS	Outside of the room is dark	On	
	Outside of the room is bright	Off	
HD LIGHT TIME	—	Displays a setting time of the follow me home function set by the work support	
IGN SW CAN	Ignition switch OFF or ACC	Off	
	Ignition switch ON	On	
FR WIPER HI	Front wiper switch OFF	Off	
	Front wiper switch HI	On	
FR WIPER LOW	Front wiper switch OFF	Off	
	Front wiper switch LO	On	
FR WIPER INT	Front wiper switch OFF	Off	
	Front wiper switch INT	On	

## BCM (BODY CONTROL MODULE)


### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
RR WIPER ON	Rear wiper switch OFF	Off
	Rear wiper switch ON	On
RR WIPER INT	Rear wiper switch OFF	Off
	Rear wiper switch INT	On
RR WIPER STOP	Rear wiper stop position	Off
	Other than rear wiper stop position	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
REVERSE SW CAN	<b>NOTE:</b> The item is indicated, but not monitored	Off
		On
H/L WASH SW	When headlamp washer switch is not pressed	Off
	When headlamp washer switch is pressed	On
FAN ON SIG	Blower fan motor switch OFF	Off
	Blower fan motor switch ON (other than OFF)	On
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	Off
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	On
HAZARD SW	Hazard switch OFF	Off
	Hazard switch ON	On
BRAKE SW	Brake pedal is not depressed	Off
	Brake pedal is depressed	On
TRNK OPNR SW	When back door opener switch is not pressed	Off
	When back door opener switch is pressed	On
HOOD SW	Close the hood <b>NOTE:</b> Vehicles without theft warning system are OFF-fixed	Off
	Open the hood	On
AUTO RELOCK	Auto lock function does not operate	Off
	Auto lock function is operating	On
GLS BREAK SEN	The vehicle without glass break sensor	Off
	The vehicle with glass break sensor	On
OIL PRESS SW	<ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• Engine running</li> </ul>	Off
	Ignition switch ON	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## TERMINAL LAYOUT



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

### PHYSICAL VALUES

#### CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-28, "COMB SW : CONSULT-III Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9, "System Description"](#).

## BCM (BODY CONTROL MODULE)






### < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
1 (W)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
2 (G)	Ground	NATS antenna amp.	Input/ Output	Insert mechanical key into ignition key cylinder	Just after Insert mechanical key into ignition key cylinder. Pointer of tester should move
3 (W)	Ground	Ignition power supply	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON or START	Battery voltage
4 (SB)	Ground	ACC power supply	Input	Ignition switch OFF	0 V
				Ignition switch ON or ACC	Battery voltage
5 (LG) <sup>*1</sup> (R) <sup>*2</sup>	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage
				Remove mechanical key from ignition key cylinder	0 V



# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
6 (L)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="text-align: right;">1.4 V</p> </div>
					Lighting switch HI (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Lighting switch 2ND (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Rear washer switch ON <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul> <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
7 (GR)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right;">1.4 V</p>	
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>	
					Lighting switch AUTO (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>	
					Any of the condition below with all switch OFF	<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 6</li> </ul>	 <p style="text-align: right;">1.3 V</p>
					Rear wiper INT (Wiper intermittent dial 4)	 <p style="text-align: right;">1.3 V</p>	

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
8 (V)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF <div style="text-align: right;">  <p style="text-align: right;">1.4 V</p> </div>
					Turn signal switch RH <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Turn signal switch LH <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Front wiper switch LO <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Front washer switch ON <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

RF






# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
9 (G) <sup>*3</sup> (B) <sup>*4</sup>	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF <div style="text-align: right;">  <p style="text-align: right;">1.4 V</p> </div>
					Lighting switch 2ND <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Lighting switch PASS <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Front wiper switch INT <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>
					Front wiper switch HI <div style="text-align: right;">  <p style="text-align: right;">1.3 V</p> </div>

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
10 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: center;">1.3 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: center;">1.3 V</p>
					Rear fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: center;">1.3 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: center;">1.3 V</p>
					Any of the condition below with all switch OFF	 <p style="text-align: center;">1.3 V</p>
11 (B)	Ground	Audio link	Input/ Output	—	—	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

RF





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
12 (LG)	Ground	Rear door switch RH	Input	Rear door switch RH	OFF (When rear door RH closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
					ON (When rear door RH opened) <div style="text-align: right;">0 V</div>
13 (V)	Ground	Back door switch	Input	Back door switch	OFF (When back door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
					ON (When back door opened) <div style="text-align: right;">0 V</div>
14 (P) <sup>*3</sup> (BR) <sup>*4</sup>	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
					ON (When passenger door opened) <div style="text-align: right;">0 V</div>
15 (BR) <sup>*3</sup> (P) <sup>*4</sup>	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">PKID0924E</p> </div>
					ON (When driver door opened) <div style="text-align: right;">0 V</div>

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
16 (GR)	Ground	Rear door switch LH	Input	Rear door switch LH	 11.2 V
				ON (When rear door LH opened)	0 V
17 (L)	Ground	Door lock status indicator	Output	Door lock status indicator	ON 12 V
				OFF	0 V
20 (SB)	Ground	Rear window defogger switch	Input	Rear window defogger switch	 1.1 V
				While pressing	0 V
21 (P)	—	CAN-L	Input/ Output	—	—
22 (L)	—	CAN-H	Input/ Output	—	—
23 (V)	Ground	Security indicator	Output	Security indicator	ON 0 V
				Blinking	 10.3 V
24 (GR)	Ground	Light & rain sensor serial link	Input/ Output	Ignition switch OFF or ACC	12 V
				Ignition switch ON	 8.7 V
25 (G)	Ground	Alarm link	Output	—	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)






## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
26 (GR) <sup>*5</sup> (LG) <sup>*6</sup>	Ground	Blower fan motor switch	Input	Blower fan mo- tor switch	OFF	 <small>PKID0924E</small> 11.2 V
					ON (other than OFF)	0 V
27 (P) <sup>*5</sup> (Y) <sup>*6</sup>	Ground	A/C switch	Input	Ignition switch ON	Compressor ON is not re- quested from auto amp. (A/C indicator OFF, blow- er fan motor switch OFF or etc.)	 <small>PKID0924E</small> 11.2 V
					Compressor ON is re- quested from auto amp. (A/C indicator ON and blower fan motor switch ON).	0 V
28 (LG) <sup>*7</sup> (R) <sup>*8</sup>	Ground	Shock detect sensor	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	 <small>JPMIA0155GB</small> 6.0 V	
29 (LG) <sup>*3</sup> (O) <sup>*4</sup>	Ground	Back door opener switch	Input	Back door opener switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed	0 V
32 (BR)	Ground	Door lock/unlock switch (Unlock)	Input	Door lock/un- lock switch	Not pressed	 <small>JPMIA0154GB</small> 1.2 V
					Pressed to the unlock side	0 V



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
33 (W) <sup>*9</sup> (Y) <sup>*10</sup>	Ground	Hazard switch	Input	Hazard switch	OFF	 <p style="text-align: center;">1.3 V</p>
					ON	0 V
34 (SB) <sup>*3</sup> (P) <sup>*4</sup>	Ground	Door lock/unlock switch (Lock)	Input	Door lock/un- lock switch	Not pressed	 <p style="text-align: center;">1.2 V</p>
					Pressed to the lock side	0 V
35 (G)	Ground	Headlamp washer switch	Input	Headlamp washer switch	Not pressed	 <p style="text-align: center;">1.2 V</p>
					Pressed to the lock side	0 V
36 (G)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch RH	 <p style="text-align: center;">9.1 V</p>
					Lighting switch 2ND	
					Lighting switch HI	
					Lighting switch 1ST	
37 (R)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	 <p style="text-align: center;">9.1 V</p>
					Rear washer switch ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
					<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	
Rear wiper switch ON (Wiper intermittent dial 4)						

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
38 (W)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Front wiper switch LO	
					Front wiper switch MIST	
					Front wiper switch INT	
					Lighting switch AUTO	
Rear fog lamp switch ON	9.3 V					
39 (Y)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch LH	
					Lighting switch PASS	
					Lighting switch 2ND	
					Front fog lamp switch ON	
40 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
					<ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	
Rear wiper switch INT (Wiper intermittent dial 4)	9.1 V					
41 (LG)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage	
42 (V)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver activation	0 V	
				Interior room lamp battery saver no activation	12 V	
43 (SB)	Ground	Rear wiper motor	Output	Rear wiper switch OFF	0 V	
				Rear wiper switch ON	12 V	
44 (B)	Ground	Rear wiper auto stop	Input	Ignition switch ON		
				Any position other than rear wiper stop position	0 V	

# BCM (BODY CONTROL MODULE)



## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
45 (V)	Ground	Back door lock actuator	Output	Back door opener switch	<p style="text-align: right; font-size: small;">SKIA9232E</p>
				Pressed	0 V
47 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	<p style="text-align: right; font-size: small;">PKID0926E</p>
				Turn signal switch LH	6.5 V
48 (GR)	Ground	Turn signal RH	Output	Ignition switch ON	<p style="text-align: right; font-size: small;">PKID0926E</p>
				Turn signal switch RH	6.5 V
49 (Y)	Ground	Rear fog lamp	Output	Rear fog lamp	OFF 0 V ON 12 V
				OFF	0 V
50 (G)	Ground	Unlock sensor	Input	Driver's door	Unlock 5 V lock 0 V
				lock	0 V
51 (R)	Ground	Stop lamp switch	Input	Depress the brake pedal	Battery voltage
				Release the brake pedal	0 V
52 (R)	Ground	Room lamp timer control	Output	Interior room lamp	OFF 12 V ON 0 V
				OFF	12 V
53 (L)	Ground	Power window power supply (IGN)	Output	Ignition switch	OFF or ACC 0 V ON 12 V
				OFF or ACC	0 V
54 (O)	Ground	Door unlock (All other than driver's door)	Output	Door lock/unlock switch	<p style="text-align: right; font-size: small;">SKIA9232E</p>
				Pressed to the unlock side	0 V
55 (B)	Ground	Ground	—	Ignition switch ON	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
56 (V)	Ground	Door lock (All) and fuel lid lock	Output	Door lock/un- lock switch	Not pressed	0 V
					Pressed to the lock side	 <p style="text-align: right; font-size: small;">SKIA9232E</p>
57 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage	
58 (P)	Ground	Power window pow- er supply (BAT)	Output	Ignition switch OFF	12 V	
59 (R)	Ground	Super lock	Output	When lock button of key fob or Intelligent Key is not pressed	0 V	
				When lock button of key fob or Intelligent Key is pressed	12 V	
60 (G)	Ground	Driver's door unlock and fuel lid unlock	Output	Door lock/un- lock switch	Pressed to the unlock side	 <p style="text-align: right; font-size: small;">SKIA9232E</p>
					Not pressed	0 V

\*1: With Intelligent Key

\*2: Without Intelligent Key

\*3: RHD models

\*4: LHD models

\*5: With gasoline engine

\*6: With diesel engine

\*7: RHD models with side air bag

\*8: LHD models with side air bag

\*9: With xenon headlamp and daytime light system


\*10: Except with xenon headlamp and daytime light system

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## Wiring Diagram— SUNROOF CONTROL SYSTEM —

INFOID:000000001551391



SUNROOF

2007/02/28

JCKWA0454GE


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## SUNROOF SYSTEM


Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-


Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
30	V	VEHICLE SPEED (2-PULSE)


Connector No.	M3
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	-


  

Connector No.	M38
Connector Name	WIRE TO WIRE
Connector Type	NSC8FW-GS



Terminal No.	Color of Wire	Signal Name [Specification]
3	P	-
7	B	-
8	L	-


Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	AAB40FB



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	IGN SW


Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FHA08FB



Terminal No.	Color of Wire	Signal Name [Specification]
53	L	P/W POWER SUPPLY(IGN)
55	B	GND
57	Y	BAT(L)
58	P	P/W POWER SUPPL (BAT)


Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA12FB



Terminal No.	Color of Wire	Signal Name [Specification]
41	LG	BAT(FUSE)

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-


JCKWA0455GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## SUNROOF SYSTEM

Connector No.	Connector Name	Connector Type	Terminal No.	Color of Wire	Signal Name [Specification]
R1	WIRE TO WIRE	TH16AW-NH	9	Y	-
R2	WIRE TO WIRE	NSJ08MW-CS	3	P	-
			7	B	-
			8	L	-
R5	SUNROOF MOTOR ASSEMBLY	NSJ08FW-CS	1	R	BIT3
			2	P	GND
			3	Y	IGN
			4	L	SPEED (2P/R)
			5	G	BIT4
			6	B	*B
R6	SUNROOF SWITCH	TKG3FW	1	G	-
			2	B	-
			3	R	-



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

## Fail Safe

**FAIL-SAFE CONTROL BY DTC**  
BCM performs fail-safe control when any DTC is detected.

JCKWA0456GE

INFOID:000000001551388

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

DTC	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC
B2191: DIFFERENCE OF KEY	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC
B2192: ID DISCORD BCM-ECM	Fuel cut (ECM)	Erase DTC
B2193: CHAIN OF BCM-ECM	Fuel cut (ECM)	Erase DTC
B2194: DISCORD BCM-I-KEY	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC
B2195: ANTI SCANNING	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC
B2196: DONGLE NG	<ul style="list-style-type: none"> <li>Inhibits engine cranking</li> <li>Inhibits steering lock unlocking (Intelligent Key unit)</li> <li>Fuel cut (ECM)</li> </ul>	Erase DTC

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal.

When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

1. Turn ignition switch OFF.
2. Pass more than 1 minute after the rear wiper stop.
3. Turn ignition switch ON.
4. Operate the rear wiper switch.

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status from the terminal voltage.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### FAIL-SAFE CONTROL BY LIGHT & RAIN SENSOR MALFUNCTION

BCM detects the light & rain sensor serial link error and the light & rain sensor malfunction.

BCM controls the following fail-safe when light & rain sensor has a malfunction.

Fail-safe Control

- Auto light control: Headlamp is turned ON.
- Front wiper control: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.

### DTC Inspection Priority Chart

INFOID:000000001551389

Priority	DTC
1	<ul style="list-style-type: none"> <li>U1000: CAN COMM CIRCUIT</li> <li>U1010: CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>B2190: NATS ANTENNA AMP</li> <li>B2191: DIFFERENCE OF KEY</li> <li>B2192: ID DISCORD BCM-ECM</li> <li>B2193: CHAIN OF BCM-ECM</li> <li>B2194: DISCORD BCM-I-KEY</li> <li>B2195: ANTI SCANNING</li> <li>B2196: DONGLE NG</li> </ul>



# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

## DTC Index

INFOID:000000001551390

### NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- PAST: Displays when there is a malfunction that is detected in the past and stored.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

DTC	TIME		Fail-safe	Reference
U1000: CAN COMM CIRCUIT	0	1 - 39	—	<a href="#">BCS-33</a>
U1010: CONTROL UNIT (CAN)	0	1 - 39	—	<a href="#">BCS-34</a>
B2190: NATS ANTENNA AMP	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-41</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-254</a></li> </ul>
B2191: DIFFERENCE OF KEY	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-43</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-256</a></li> </ul>
B2192: ID DISCORD BCM-ECM	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-38</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-251</a></li> </ul>
B2193: CHAIN OF BCM-ECM	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-40</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-253</a></li> </ul>
B2194: DISCORD BCM-I-KEY	CRNT	PAST	×	<a href="#">SEC-53</a>
B2195: ANTI SCANNING	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-54</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-264</a></li> </ul>
B2196: DONGLE NG	CRNT	PAST	×	<ul style="list-style-type: none"> <li>• With Intelligent Key system: <a href="#">SEC-55</a></li> <li>• Without Intelligent Key system: <a href="#">SEC-265</a></li> </ul>

RF

# SUNROOF MOTOR ASSEMBLY


< ECU DIAGNOSIS >

## SUNROOF MOTOR ASSEMBLY

Reference Value

INFOID:000000001160383

TERMINAL LAYOUT



PHYSICAL VALUES


Terminal No.		Wire color	Description		Condition	Voltage (V) (Approx.)
+	-		Signal name	Input/ Output		
1	Ground	R	Sunroof close switch signal	Input	Sunroof switch in following position • TILT UP • SLIDE CLOSE	0
					Other than above	Battery voltage
2	Ground	P	Sunroof power supply	Input	—	Battery voltage
3	Ground	Y	Vehicle speed signal (2-pulse)	Input	Speedometer operated [When vehicle speed is approx.40km/ h (25MPH)]	
4	Ground	L	Ignition switch power supply	Input	Ignition switch ON	Battery voltage
					Other than above	0
5	Ground	G	Sunroof open switch signal	Input	Sunroof switch in following position • TILT DOWN • SLIDE OPEN	0
					Other than above	Battery voltage
6	Ground	B	Ground	—	—	0

# SUNROOF MOTOR ASSEMBLY

< ECU DIAGNOSIS >

## Wiring Diagram— SUNROOF CONTROL SYSTEM —

INFOID:000000001160384



SUNROOF

2007/02/28









JCKWA0454GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# SUNROOF MOTOR ASSEMBLY

< ECU DIAGNOSIS >

## SUNROOF SYSTEM

Connector No. E105	Connector Name WIRE TO WIRE	Connector Type TH80FW-GS16-TM4		Terminal No. 5	Color of Wire Y	Signal Name [Specification] -
Connector No. M33	Connector Name WIRE TO WIRE	Connector Type TH116FW-NH		Terminal No. 9	Color of Wire Y	Signal Name [Specification] -
Connector No. M34	Connector Name COMBINATION METER	Connector Type SAB40FW		Terminal No. 21	Color of Wire L	Signal Name [Specification] CAN-H
				Terminal No. 22	Color of Wire P	Signal Name [Specification] CAN-L
				Terminal No. 30	Color of Wire V	Signal Name [Specification] VEHICLE SPEED (2-PULSE)
Connector No. M36	Connector Name WIRE TO WIRE	Connector Type NSC8FW-GS		Terminal No. 3	Color of Wire P	Signal Name [Specification] -
				Terminal No. 7	Color of Wire B	Signal Name [Specification] -
				Terminal No. 8	Color of Wire L	Signal Name [Specification] -
Connector No. M65	Connector Name BCM (BODY CONTROL MODULE)	Connector Type AAB40FB		Terminal No. 3	Color of Wire W	Signal Name [Specification] IGN SW
Connector No. M67	Connector Name BCM (BODY CONTROL MODULE)	Connector Type FH408FB		Terminal No. 53	Color of Wire L	Signal Name [Specification] P/W POWER SUPPLY(IGN)
				Terminal No. 55	Color of Wire B	Signal Name [Specification] GND
				Terminal No. 57	Color of Wire Y	Signal Name [Specification] BAT(L)
				Terminal No. 58	Color of Wire P	Signal Name [Specification] P/W POWER SUPPL (BAT)
Connector No. M68	Connector Name BCM (BODY CONTROL MODULE)	Connector Type FEA12FB		Terminal No. 41	Color of Wire LG	Signal Name [Specification] BAT(FUSE)
Connector No. M77	Connector Name WIRE TO WIRE	Connector Type TH80MW-GS16-TM4		Terminal No. 5	Color of Wire Y	Signal Name [Specification] -

JCKWA0455GE

# SUNROOF MOTOR ASSEMBLY

< ECU DIAGNOSIS >


## SUNROOF SYSTEM

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH16AW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	NSJ08MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	P	-
7	B	-
8	L	-

Connector No.	R5
Connector Name	SUNROOF MOTOR ASSEMBLY
Connector Type	NSJ09FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	BIT3
2	P	GND
3	Y	IGN
4	L	SPEED (2P/R)
5	G	BIT4
6	B	#B

Connector No.	R6
Connector Name	SUNROOF SWITCH
Connector Type	TKG3FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

JCKWA0456GE

# SUNROOF DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

---

## SYMPTOM DIAGNOSIS

### SUNROOF DOES NOT OPERATE PROPERLY

#### Diagnosis Procedure

INFOID:000000001160385

#### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

---

Check BCM power supply and ground circuit.

Refer to [RF-7, "BCM \(BODY CONTROL MODULE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK SUNROOF MOTOR ASSEMBLY POWER SUPPLY AND GROUND CIRCUIT

---

Check sunroof motor assembly power supply and ground circuit.

Refer to [RF-8, "SUNROOF MOTOR ASSEMBLY : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK SUNROOF SWITCH

---

Check sunroof switch.

Refer to [RF-10, "Component Function Check"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

# AUTO OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## AUTO OPERATION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000001160386

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-4, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

## DOES NOT STOP FULLY-OPEN OR FULLY-CLOSED POSITION

< SYMPTOM DIAGNOSIS >

---

## DOES NOT STOP FULLY-OPEN OR FULLY-CLOSED POSITION

### Diagnosis Procedure

INFOID:000000001160387

#### 1. PERFORM INITIALIZATION PROCEDURE

---

Perform initialization procedure.

Refer to [RF-4, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).



# SUNROOF DOES NOT OPERATE ANTI-PINCH FUNCTION

< SYMPTOM DIAGNOSIS >

## SUNROOF DOES NOT OPERATE ANTI-PINCH FUNCTION

### Diagnosis Procedure

INFOID:000000001160388

#### 1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [RF-4, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P


# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000001160389



### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of the customer's comments; refer to [RF-46, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by a test drive with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Engine Ear or mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
  - tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - placing a piece of paper between components that you suspect are causing the noise.
  - looking for loose components and contact marks.  
Refer to [RF-44. "Inspection Procedure"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - separate components by repositioning or loosening and retightening the component, if possible.
  - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape are available through your authorized Nissan Parts Department.

### **CAUTION:**

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

### **NOTE:**

- URETHANE PADS  
Insulates connectors, harness, etc.
- INSULATOR (Foam blocks)  
Insulates components from contact. Can be used to fill space behind a panel.
- INSULATOR (Light foam block)
- FELT CLOTHTAPE  
Used to insulate where movement does not occur. Ideal for instrument panel applications.  
The following materials, not available through NISSAN Parts Department, can also be used to repair squeaks and rattles.
- UHMW(TEFLON) TAPE  
Insulates where slight movement is present. Ideal for instrument panel applications.
- SILICONE GREASE  
Used in place of UHMW tape that will be visible or not fit.  
Note: Will only last a few months.
- SILICONE SPRAY  
Use when grease cannot be applied.
- DUCT TAPE  
Use to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

### Inspection Procedure

INFOID:000000001160390

Refer to Table of Contents for specific component removal and installation information.

#### INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

#### **CAUTION:**

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

#### CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

#### DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks to repair the noise.

#### TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. Trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

#### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

### SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. Rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

RF

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000001160391







### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8740E

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> anytime                      | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> when it is raining or wet     |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions       |
| <input type="checkbox"/> only when it is hot outside  | <input type="checkbox"/> other:                        |

### III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about \_\_\_\_ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: \_\_\_\_\_
- after driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

#### Test Drive Notes:

---

---

---

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_  
W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

PIIB8742E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011557125

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

#### Service Notice

INFOID:000000001160393

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

#### Precaution for Work

INFOID:000000001160394

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
  - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.  
Then rub with a soft and dry cloth.
  - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.



# PREPARATION



< PREPARATION >

## PREPARATION

### PREPARATION

#### Commercial Service Tool

INFOID:000000001160395

Tool name	Description
<p data-bbox="159 520 267 546">Engine ear</p>  <p data-bbox="795 630 860 651">SIIA0995E</p>	<p data-bbox="1006 520 1193 546">Locating the noise</p>
<p data-bbox="159 772 292 798">Remover tool</p>  <p data-bbox="795 882 860 903">PIIB7923J</p>	<p data-bbox="1006 772 1412 798">Remove the clip and pawl and metal clip</p>

A

B

C

D

E

F

G

H

I

J

**RF**

L

M

N

O

P

## PRE-INSPECTION FOR DIAGNOSTIC

< ON-VEHICLE MAINTENANCE >

---

# ON-VEHICLE MAINTENANCE

## PRE-INSPECTION FOR DIAGNOSTIC

### Basic Inspection

INFOID:000000001160396

#### BASIC INSPECTION

#### 1.INSPECTION START

---

1. Check the service history.
2. Check the following parts.
  - Fuse/circuit breaker blown.
  - Poor connection, open or short circuit of harness connector.
  - Battery voltage.

Is the inspection result normal?

- YES >> Inspection end.  
NO >> Repair or replace the malfunctioning parts.

# SUNROOF

< ON-VEHICLE REPAIR >


## ON-VEHICLE REPAIR

### SUNROOF

#### GLASS LID

#### GLASS LID : Exploded View

INFOID:000000001348648



- |                                  |                                   |                                 |
|----------------------------------|-----------------------------------|---------------------------------|
| 1. TORX bolt                     | 2. Glass lid                      | 3. Drain hose                   |
| 4. TORX bolt                     | 5. Sunroof motor assembly         | 6. Sunroof motor cover          |
| 7. Front sunroof bracket (LH/RH) | 8. Center sunroof bracket (LH/RH) | 9. Rear sunroof bracket (LH/RH) |
| 10. Sunroof unit assembly        | 11. Drain connector               |                                 |

Refer to [GI-4, "Components"](#) for symbols in the figure.

#### GLASS LID : Removal and Installation

INFOID:000000001348649

#### REMOVAL

**CAUTION:**


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# SUNROOF

## < ON-VEHICLE REPAIR >

### Always work with a helper.

1. Remove the headlining. Refer to [INT-25, "SUNROOF : Removal and Installation"](#).
2. Remove the side cover upper side, and then fold the side cover so that the TORX bolt can be seen.
3. Remove the TORX bolt (A), and then remove the glass lid and rear drain joint (1).



4. Remove the sunroof lid from the vehicle.

### INSTALLATION

#### CAUTION:


After installing the glass lid, perform the leak test and check that there is no malfunction.

#### NOTE:

After installation carry out fitting adjustment. Refer to [RF-52, "GLASS LID : Adjustment"](#).  
Install in the reverse order of removal.

### GLASS LID : Adjustment

INFOID:000000001348650



### LID WEATHERSTRIP OVERLAP ADJUSTMENT AND SURFACE MISMATCH ADJUSTMENT

1. Remove the side cover upper side, and then fold the side cover so that the TORX bolt can be seen.
2. After loosening glass lid from TORX bolts (left and right), tilt down glass lid.
3. Adjust glass lid from outside of vehicle so it resembles "A-A" "B-B" "C-C" as shown in the figure.

	a	b
A-A	0.3 - 1.7 mm (0.012 - 0.067 in)	-1.5 - 1.5 mm (-0.059 - 0.059 in)
B-B	0.3 - 1.7 mm (0.012 - 0.067 in)	-1.5 - 1.5 mm (-0.059 - 0.059 in)
C-C	0.3 - 1.7 mm (0.012 - 0.067 in)	-1.5 - 1.5 mm (-0.059 - 0.059 in)

4. To prevent glass lid from moving after adjustment, first tighten the TORX bolts of front left, and then tighten the TORX bolts of rear right.
5. Tighten remaining TORX bolts, being careful to prevent glass lid from moving.

# SUNROOF

< ON-VEHICLE REPAIR >

6. Tilt glass lid up and down several times to check that it moves smoothly.


## NOTE:

After adjustment the sunroof unit assembly, perform additional service. Refer to [RF-4. "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

## SUNROOF MOTOR ASSEMBLY

### SUNROOF MOTOR ASSEMBLY : Exploded View

INFOID:000000001537500



- |                                  |                                   |                                 |
|----------------------------------|-----------------------------------|---------------------------------|
| 1. TORX bolt                     | 2. Glass lid                      | 3. Drain hose                   |
| 4. TORX bolt                     | 5. Sunroof motor assembly         | 6. Sunroof motor cover          |
| 7. Front sunroof bracket (LH/RH) | 8. Center sunroof bracket (LH/RH) | 9. Rear sunroof bracket (LH/RH) |
| 10. Sunroof unit assembly        | 11. Drain connector               |                                 |

Refer to [GI-4. "Components"](#) for symbols in the figure.

### SUNROOF MOTOR ASSEMBLY : Removal and Installation

INFOID:000000001160483

#### REMOVAL


# SUNROOF

## < ON-VEHICLE REPAIR >

### CAUTION:

- Before removing sunroof motor, check that glass lid is fully closed.
- After removing sunroof motor, do not attempt to rotate sunroof motor assembly as a single unit.

1. Remove the headlining. Refer to [INT-25. "SUNROOF : Removal and Installation"](#).
2. Disconnect connector (A) and terminal (B) from sunroof motor assembly. Remove sunroof motor assembly mounting TORX bolt (C), and then remove sunroof motor assembly (1) and sunroof motor cover (2).



## INSTALLATION

### CAUTION:

Before installing the sunroof motor assembly, be sure to place the link and wire assembly in the symmetrical and fully closed position.

1. Move the sunroof motor assembly laterally by little so that the gear is completely engaged into the wire on the sunroof unit assembly and mounting surface becomes parallel. Then secure the sunroof motor assembly with TORX bolt.
2. Install the headlining. Refer to [INT-25. "SUNROOF : Removal and Installation"](#).

## SUNROOF UNIT ASSEMBLY


### SUNROOF UNIT ASSEMBLY : Exploded View

INFOID:000000001348697

## REMOVAL

# SUNROOF

< ON-VEHICLE REPAIR >



- |                                  |                                   |                                 |
|----------------------------------|-----------------------------------|---------------------------------|
| 1. TORX bolt                     | 2. Glass lid                      | 3. Drain hose                   |
| 4. TORX bolt                     | 5. Sunroof motor assembly         | 6. Sunroof motor cover          |
| 7. Front sunroof bracket (LH/RH) | 8. Center sunroof bracket (LH/RH) | 9. Rear sunroof bracket (LH/RH) |
| 10. Sunroof unit assembly        | 11. Drain connector               |                                 |


Refer to [GI-4, "Components"](#) for symbols in the figure.

## DISASSEMBLY

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P

# SUNROOF

< ON-VEHICLE REPAIR >



- |                             |              |                   |
|-----------------------------|--------------|-------------------|
| 1. Sunshade stopper (LH/RH) | 2. Sunshade  | 3. Rear drain     |
| 4. Side cover (LH/RH)       | 5. TORX bolt | 6. Wind deflector |
| 7. Sunroof frame            |              |                   |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## SUNROOF UNIT ASSEMBLY : Removal and Installation

INFOID:000000001160478

### REMOVAL

#### CAUTION:

- Always work with a helper.
- Fully close the glass lid, before removal, then do not operate sunroof motor assembly after removal.
- When taking sunroof unit assembly out, use cloths to protect the seats and trim from damage.

1. Remove the headlining. Refer to [INT-25, "SUNROOF : Removal and Installation"](#).
2. Remove the glass lid. Refer to [RF-51, "GLASS LID : Removal and Installation"](#).
3. Disconnect drain hoses.
4. Remove the sunroof motor assembly. Refer to [RF-53, "SUNROOF MOTOR ASSEMBLY : Removal and Installation"](#).



# SUNROOF

## < ON-VEHICLE REPAIR >

5. Remove the assistance grip bracket.
6. Remove the front sunroof brackets (LH/RH).
7. Remove the center sunroof brackets (LH/RH).
8. Remove the rear sunroof brackets (LH/RH).
9. Remove nuts from the front end and side rail, and then remove sunroof unit assembly from roof panel.
10. Remove sunroof unit assembly through the back door while being careful not to damage the seats and trim.

## INSTALLATION

### CAUTION:

**After installing the sunroof unit assembly and glass lid, perform the leak test and check that there is no malfunction.**

1. Temporarily tighten the mounting bolts to the rear sunroof brackets (RH/LH).
2. Bring sunroof unit into back door, and then place the rear end of the rail onto the sunroof brackets.
3. Temporarily tighten the mounting nuts to the front end of sunroof unit assembly.
4. Temporarily tighten the mounting bolts to the front, center, rear sunroof brackets (RH/LH)
5. Tighten the installation points diagonally excluding the installation point of the sunroof bracket around the roof opening.
6. Tighten the mounting nuts to the front end and side rail.
7. Tighten the sunroof bracket bolts of the vehicle side, and then tighten the bolt of the rail side.
8. Install the sunroof motor assembly. Refer to [RF-53. "SUNROOF MOTOR ASSEMBLY : Removal and Installation"](#).
9. Connect drain hoses.
10. Install the glass lid. Refer to [RF-51. "GLASS LID : Removal and Installation"](#).

### NOTE:

After installation, carry out fitting adjustment. Refer to [RF-52. "GLASS LID : Adjustment"](#).


11. Install the headlining. Refer to [INT-25. "SUNROOF : Removal and Installation"](#).

## SUNROOF UNIT ASSEMBLY : Disassembly and Assembly

INFOID:000000001160479

### DISASSEMBLY

1. Remove sunshade stopper (LH/RH) from the rear end of sunroof frame.
2. Remove sunshade from the rear end of sunroof frame.
3. Remove the rear drain from the rear end of sunroof frame.
4. Remove the side cover (LH/RH) from the rear end of sunroof frame.
5. Remove the nuts (A) and TORX bolt (B), and then remove wind deflector (1).



### ASSEMBLY

Assemble in the reverse order of disassembly.


### SUNSHADE

# SUNROOF

< ON-VEHICLE REPAIR >

## SUNSHADE : Exploded View

INFOID:000000001348708



- |                             |              |                   |
|-----------------------------|--------------|-------------------|
| 1. Sunshade stopper (LH/RH) | 2. Sunshade  | 3. Rear drain     |
| 4. Side cover (LH/RH)       | 5. TORX bolt | 6. Wind deflector |
| 7. Sunroof frame            |              |                   |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## SUNSHADE : Removal and Installation

INFOID:000000001160505

### REMOVAL

1. Remove the headlining. Refer to [INT-25, "SUNROOF : Removal and Installation"](#).
2. Remove the sunroof unit assembly. Refer to [RF-56, "SUNROOF UNIT ASSEMBLY : Removal and Installation"](#).
3. Remove the sunshade stopper (LH/RH) from the sunroof frame end.
4. Remove the sunshade from the sunroof frame end.

### INSTALLATION

# SUNROOF

< ON-VEHICLE REPAIR >

Install in the reverse order of removal.

## SUNROOF SWITCH

### SUNROOF SWITCH : Exploded View

INFOID:000000001160405

Refer to [INL-77, "Exploded View"](#).

### SUNROOF SWITCH : Removal and Installation

INFOID:000000001160406

#### Removal

Remove the sunroof switch. Refer to [INL-77, "Removal and Installation"](#).

#### Installation

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
RF  
L  
M  
N  
O  
P