

SECTION **SBC**

SEAT BELT CONTROL SYSTEM

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

CONTENTS

| | | | |
|--|---|----|----|
| BASIC INSPECTION | REAR SEAT BELT BUCKLE SWITCH | 3 | 17 |
| DIAGNOSIS AND REPAIR WORKFLOW | REAR LH | 3 | 17 |
| Work Flow | REAR LH : Description | 3 | 17 |
| FUNCTION DIAGNOSIS | REAR LH : Component Function Check | 4 | 17 |
| SEAT BELT WARNING LAMP | REAR LH : Diagnosis Procedure | 4 | 17 |
| System Diagram | REAR LH : Component Inspection | 4 | 18 |
| System Description | REAR RH AND CENTER | 4 | 18 |
| Component Parts Location | REAR RH AND CENTER : Description | 6 | 18 |
| Component Description | REAR RH AND CENTER : Component Function | 6 | 19 |
| COMPONENT DIAGNOSIS | Check | 8 | 19 |
| POWER SUPPLY AND GROUND CIRCUIT | REAR RH AND CENTER : Diagnosis Procedure..... | 8 | 19 |
| FRONT SEAT BELT WARNING UNIT | REAR RH AND CENTER : Component Inspection | 8 | 20 |
| FRONT SEAT BELT WARNING UNIT : Diagnosis | FRONT SEAT BELT WARNING LAMP | 8 | 21 |
| Procedure | Description | 8 | 21 |
| REAR SEAT BELT WARNING UNIT | Component Function Check | 8 | 21 |
| REAR SEAT BELT WARNING UNIT : Diagnosis | Diagnosis Procedure | 8 | 21 |
| Procedure | REAR SEAT BELT WARNING LAMP | 8 | 23 |
| FRONT SEAT BELT BUCKLE SWITCH | Description | 10 | 23 |
| DRIVER SIDE | Component Function Check | 10 | 23 |
| DRIVER SIDE : Description | Diagnosis Procedure | 10 | 23 |
| DRIVER SIDE : Component Function Check | VEHICLE SPEED SIGNAL | 10 | 25 |
| DRIVER SIDE : Diagnosis Procedure | Description | 10 | 25 |
| DRIVER SIDE : Component Inspection | Component Function Check | 12 | 25 |
| PASSENGER SIDE | Diagnosis Procedure | 13 | 25 |
| PASSENGER SIDE : Description | ALTERNATOR SIGNAL CIRCUIT | 13 | 27 |
| PASSENGER SIDE : Component Function Check | Description | 13 | 27 |
| 13 | Component Function Check | 13 | 27 |
| PASSENGER SIDE : Diagnosis Procedure | Diagnosis Procedure | 13 | 27 |
| PASSENGER SIDE : Component Inspection | ECU DIAGNOSIS | 15 | 29 |
| (Passenger side seat belt buckle switch) | FRONT SEAT BELT WARNING UNIT | 15 | 29 |
| PASSENGER SIDE : Component Inspection (Oc- | LHD MODELS | 16 | 29 |
| cupant detection unit) | LHD MODELS : Reference Value | 16 | 29 |

| | | | |
|--|-----------|--|-----------|
| LHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM - | 29 | REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE | 58 |
| | | Diagnosis Procedure | 58 |
| RHD MODELS | 35 | FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF | 59 |
| RHD MODELS : Reference Value | 36 | Diagnosis Procedure | 59 |
| RHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM - | 36 | REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF | 60 |
| | | Diagnosis Procedure | 60 |
| REAR SEAT BELT WARNING UNIT | 43 | SEAT BELT WARNING CHIME DOES NOT SOUND | 61 |
| LHD MODELS | 43 | Diagnosis Procedure | 61 |
| LHD MODELS : Reference Value | 43 | PRECAUTION | 62 |
| LHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM - | 43 | PRECAUTIONS | 62 |
| | | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 62 |
| RHD MODELS | 49 | | |
| RHD MODELS : Reference Value | 50 | | |
| RHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM - | 50 | | |
| | | | |
| SYMPTOM DIAGNOSIS | 57 | | |
| FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE | 57 | | |
| Diagnosis Procedure | 57 | | |

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001279915

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brought the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of between the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2. Then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are all malfunctions crrected?

YES >> INSPECTION END

NO >> GO TO 3.

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P


SEAT BELT WARNING LAMP

< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

SEAT BELT WARNING LAMP

System Diagram



System Description

INFOID:000000001279917

FRONT SEAT BELT WARNING LAMP

- The front seat belt warning lamp illuminates/blinks to warn the occupants when the seat belt is unfastened.
- Front seat belt warning lamp is built in combination meter.
- As there is one seat belt warning lamp for both driver seat and passenger seats, if both seat belts are unfastened, the warning lamp will remain ON.
- There is an occupant detection unit inside the passenger seat, which is connecting in series with the passenger seat belt buckle switch.
- The occupant detection unit detects if the seat is occupied or not.
- When the passenger seat is unoccupied, the front seat belt warning unit detects only the driver seat belt status.

Condition of operation

The front seat belt warning unit operates according to the following speed conditions by illuminating or blinking the lamp:

Vehicle speed less than 25 km/h

- Ignition switch in ON position while driver and passenger seat belts are unfastened. The seat belt warning lamp will light up.
- Passenger seat is occupied while both driver and passenger seat belts are unfastened, the warning lamp will remain ON.
- Passenger seat is unoccupied; the warning lamp goes out as soon as the driver will fasten his seat belt.

Vehicle speed more than 25 km/h

- While driving at more than 25 km/h with any of driver or passenger seats unfastened, the warning lamp will start blinking.

NOTE:

The warning lamp will continue blinking even after decreasing the vehicle speed under 25 km/h.

- When sitting on the passenger seat, the warning lamp will remain ON until both driver and passenger seat belts are fastened.
- When the passenger seat is unoccupied, the warning lamp goes out as soon as the seat belt is fastened.

REAR SEAT BELT WARNING LAMP

The rear seat belt warning lamps are located on the center console and alert the driver and front passenger if any of the rear passenger seat belts have not been securely fastened.

Condition of operation

SEAT BELT WARNING LAMP

< FUNCTION DIAGNOSIS >

- After the engine has been started, the rear seat belt warning lights up for approximately 35 seconds if the seat belt is unfastened. A
- After the engine has been started for approximately 35 seconds, all the rear seat belts warning lamps will turn OFF regardless of the seat belts status. Therefore if any of the rear seat belts are fastened/unfastened, the unfastened warning lamps will illuminate for 35 seconds. B

SEAT BELT WARNING CHIME

- When driving the vehicle with the driver or passenger's seat belt unfastened, the buzzer will sound to warn the driver or passenger. C
- The buzzer is built in the front seat belt warning unit.

Condition of operation

The front seat belt warning unit sounds the buzzer for 90 seconds when all the following conditions are met: D

- Ignition switch is in the ON position.
- Any of the driver or passenger seat belt is not fastened.
- Vehicle speed more than 25 km/h. E

NOTE:

The buzzer continues sounding even after decreasing the vehicle speed under 25km/h but stops after fastening the seat belt. F

Stop the buzzer sound

The buzzer will stop sounding under the following conditions:

- After 90 seconds
- Ignition switch is turned to OFF. G
- The driver and passenger have fastened their seat belts.

SBC

I

J

K

L

M

N

O


P

SEAT BELT WARNING LAMP

< FUNCTION DIAGNOSIS >

Component Parts Location

INFOID:000000001279918



JMHIA0366ZZ

- | | | |
|--|--|--|
| 1. Front seat belt warning lamp (built in combination meter M34) | 2. Rear seat belt warning lamp M87 | 3. Rear seat belt warning unit B49 |
| 4. Front seat belt warning unit M63, M64 | 5. Front seat belt warning unit M63, M64 | 6. Seat belt buckle switch (Driver side) B22 |
| 7. Occupant detection unit | | |
| A. View with luggage side lower finisher removed | B. LHD models | C. RHD models |
| D. Behind seat cushion trim | | |

Component Description

INFOID:000000001279919

| Item | Function |
|-----------------------------|--|
| Combination meter | <ul style="list-style-type: none"> • Driver and passenger seat belt warning lamp is built in combination meter. |
| Rear seat belt warning unit | <ul style="list-style-type: none"> • Detects the status of rear seat belt buckle switch and controls the warning lamp illumination. • Judges the status of engine by detection of the signal transmitted by alternator and performs the control of seat belt warning lamp ON/OFF function. |

SEAT BELT WARNING LAMP

< FUNCTION DIAGNOSIS >

| Item | Function |
|--|--|
| Seat belt buckle switch (driver/passenger/rear) | Detects seat belt feature status transmits signal to front or rear seat belt warning unit. |
| Front seat belt warning unit | <ul style="list-style-type: none">• Detects the status of driver and passenger seat buckle switch and controls warning lamp operation.• Judges the vehicle speed by detection of the signal transmitted by combination meter and performs the control of seat belt warning chime ON/OFF function. |
| Rear seat belt warning lamp Occupant detection unit | <ul style="list-style-type: none">• Detects the seat status (occupied or unoccupied) and then transmits signal to combination meter or to indicator unit. |

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT FRONT SEAT BELT WARNING UNIT

FRONT SEAT BELT WARNING UNIT : Diagnosis Procedure

INFOID:000000001279921

1.CHECK FUSE

Check 10A fuse (No.1, located in the fuse and fusible link box).

Is the fuse fusing?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse or fusible link is blown.
NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit connectors.
3. Turn ignition switch ON.
4. Check voltage between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Voltage (Approx.) |
|------------------------------|----------|--------|----------------------|
| Connector | Terminal | | |
| M64 | 17 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M63 | 16 | Ground | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.

REAR SEAT BELT WARNING UNIT

REAR SEAT BELT WARNING UNIT : Diagnosis Procedure

INFOID:000000001548700

1.CHECK FUSE

Check that the following fuse is not fusing.
10A fuse (No. 1, located in the fuse and fusible link box).

Is the fuse fusing?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.
NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seat belt warning unit connectors.
3. Turn ignition switch ON.
4. Check voltage between rear seat belt warning unit harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

| BCM | | Ground | Voltage (Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal | | |
| M64 | 17 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between rear seat belt warning unit harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M63 | 16 | Ground | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

FRONT SEAT BELT BUCKLE SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000001279922

- Detects if the seat belt is fastened or unfastened.
- Warning lamp turns OFF if the seat belt is fastened.

DRIVER SIDE : Component Function Check

INFOID:000000001559378

1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) FUNCTION

1. Turn ignition switch ON.
2. Sits in the passenger seat.
3. Front seat belt (passenger side) is fastened.
4. Check if the warning lamp turns OFF as soon as the seat belt (driver side) is fastened.

Is the inspection results normal?

- YES >> Seat belt buckle switch (driver side) is OK.
NO >> Refer to [SBC-10, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000001279924

1. INSPECTION START

Check which type of seat the vehicle is equipped with.

Which type of seat

- Power seat>>GO TO 2.
Manual seat>>GO TO 7.

2. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------------------------------|--------------------------|
| connector | Terminal | | |
| M64 | (+) | Driver seat belt is unfastened | 0 |
| | 21 | | |
| M64 | 21 | Ground | 5 |
| | | Driver seat belt is fastened | 5 |

Is the inspection result normal?

- YES >> GO TO 12.
NO >> GO TO 3.

3. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit and seat belt buckle switch (driver side) connector.
3. Check continuity between front seat belt warning unit harness connector and seat belt buckle switch (driver side) harness connector.

| Front seat belt warning unit | | Seat belt buckle switch (driver side) | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| connector | Terminal | connector | terminal | |
| M64 | 21 | B22 | 5 | Existed |

4. Check continuity between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| connector | Terminal | | |
| M64 | 21 | Ground | Not existed |

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (driver side) harness connector and ground.

| Seat belt buckle switch (driver side) | | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| connector | Terminal | | |
| B22 | 6 | Ground | Existed |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace harness.

5. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side).
 Refer to [SBC-12, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace seat belt buckle switch (driver side). Refer to [SB-7, "SEAT BELT BUCKLE : Removal and Installation"](#).

6. CHECK FRONT SEAT BELT WARNING UNIT OUTPUT SIGNAL

- Turn ignition switch ON.
- Connect front seat belt warning unit connector.
- Check voltage between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Voltage (V) (Approx.) |
|------------------------------|----------|--------|--------------------------|
| connector | Terminal | | |
| M34 | 35 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 12.
 NO >> Replace front seat belt warning unit.

7. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

- Turn ignition switch ON.
- Check voltage between front seat belt warning unit connector and ground.

| Combination meter | | Ground | Condition | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------------|--------------------------|
| connector | Terminal | | | |
| M64 | 21 | Ground | Driver seat belt is unfastened | 0 |
| | | | Driver seat belt is fastened | 5 |

Is the inspection result normal?

- YES >> GO TO 12.
 NO >> GO TO 8.

8. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT HARNESS

- Turn ignition switch OFF.
- Disconnect front seat belt warning unit and seat belt buckle switch (driver side) connector.
- Check continuity between front seat belt warning unit and seat belt buckle switch (driver side) harness connector.

| Front seat belt warning unit | | Seat belt buckle switch (driver side) | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| connector | Terminal | connector | terminal | |
| M64 | 21 | B22 | 1 | Existed |

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

4. Check continuity between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| connector | Terminal | | |
| M64 | 21 | Ground | Not existed |

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

9. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (driver side) harness connector and ground.

| Seat belt buckle switch (driver side) | | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| connector | Terminal | | |
| B22 | 2 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace harness.

10. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side).

Refer to [SBC-12. "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 11.

NO >> Replace seat belt buckle switch (driver side). Refer to [SB-7. "SEAT BELT BUCKLE : Removal and Installation"](#).

11. CHECK FRONT SEAT BELT WARNING UNIT OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Connect front seat belt warning unit connector.
3. Check voltage between front seat belt warning unit harness connector and ground.

| Combination meter | | | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| connector | Terminal | | |
| M64 | (+) | (-) | 5 |
| | 21 | Ground | |

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace front seat belt warning unit.

12. CHECK INTERMITTENT INCIDENT

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000001279925

1. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity between seat belt buckle switch (driver side) terminal.

| Seat belt buckle switch (driver side) | | Condition | Continuity |
|---------------------------------------|----------|-----------|------------|
| connector | Terminal | | |

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

| | | | | |
|-----|---|---|------------------------------|-------------|
| B22 | 5 | 6 | When seat belt is unfastened | Existed |
| | | | When seat belt is fastened | Not existed |

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace seat belt buckle switch (driver side). Refer to [SB-7, "SEAT BELT BUCKLE : Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000001279926

- Detects if the passenger side seat belt is fastened or unfastened.
- Warning lamp turns OFF if the seat belt is fastened.

PASSENGER SIDE : Component Function Check

INFOID:000000001279927

1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) FUNCTION

1. Turn ignition switch ON.
2. Front seat belt (driver side) is fastened.
3. Sits in the passenger seat.
4. Check if the warning lamp turns OFF as soon as the seat belt (passenger side) is fastened.

Is the inspection results normal?

YES >> Seat belt buckle switch (passenger side) is OK.

NO >> Refer to [SBC-13, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000001279928

1. INSPECTION START

Check which type of seat the vehicle is equipped with

Which type of seat

Power seat >> GO TO 2.

Manual seat >> GO TO 7.

2. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|-----------------------------------|--------------------------|
| connector | Terminal | | |
| M64 | (+) | Passenger seat belt is unfastened | 0 |
| | 21 | | |
| M64 | (-) | Passenger seat belt is fastened | 5 |
| | Ground | | |

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 3.

3. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit and seat belt buckle switch (passenger side) connector.
3. Check continuity between front seat belt warning unit harness connector and seat belt buckle switch (passenger side) harness connector.

| Front seat belt warning unit | | Seat belt buckle switch (passenger side) | | terminal | Continuity |
|------------------------------|----------|--|--|----------|------------|
| connector | Terminal | connector | | | |
| M64 | 21 | B22 | | 5 | Existed |

4. Check continuity between front seat belt warning unit harness connector and ground.

A
B
C
D
E
F
G

SBC

I
J
K
L
M
N
O
P

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| connector | Terminal | | |
| M64 | 21 | Ground | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (passenger side) harness connector and ground.

| Seat belt buckle switch (passenger side) | | Ground | Continuity |
|--|----------|--------|------------|
| connector | Terminal | | |
| B22 | 6 | Ground | Existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side).

Refer to [SBC-15. "PASSENGER SIDE : Component Inspection \(Passenger side seat belt buckle switch\)".](#)

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace seat belt buckle switch (passenger side). Refer to [SB-7. "SEAT BELT BUCKLE : Removal and Installation".](#)

6.CHECK FRONT SEAT BELT WARNING UNIT OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Connect front seat belt warning unit connector.
3. Check voltage between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit | | Ground | Voltage (V) (Approx.) |
|------------------------------|----------|--------|--------------------------|
| connector | Terminal | | |
| M34 | 35 | Ground | 5 |

Is the inspection result normal?

YES >> GO TO 12.

NO >> Replace front seat belt warning unit.

7.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between front seat belt warning unit harness connector and ground.

| Combination meter | | Ground | Condition | Voltage (V) (Approx.) |
|-------------------|----------|--------|-----------------------------------|--------------------------|
| connector | Terminal | | | |
| M64 | 21 | Ground | Passenger seat belt is unfastened | 0 |
| | | | Passenger seat belt is fastened | 5 |

Is the inspection result normal?

YES >> GO TO 12.

NO >> GO TO 8.

8.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit and seat belt buckle switch (passenger side) connector.

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

3. Check continuity between front seat belt warning unit harness connector and seat belt buckle switch (passenger side) harness connector.

| Front seat belt warning unit | | Seat belt buckle switch (passenger side) | | Continuity |
|------------------------------|----------|--|----------|------------|
| connector | Terminal | connector | terminal | |
| M64 | 21 | B22 | 1 | Existed |

4. Check continuity between front seat belt warning unit harness connector and ground.

| Front seat belt warning unit connector | | Ground | Continuity |
|--|----|--------|-------------|
| Terminal | | | |
| M64 | 21 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Repair or replace harness.

9.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (passenger side) harness connector and ground.

| Seat belt buckle switch (passenger side) | | Ground | Continuity |
|--|----------|--------|------------|
| connector | Terminal | | |
| B22 | 2 | Ground | Existed |

Is the inspection result normal?

- YES >> GO TO 10.
 NO >> Repair or replace harness.

10.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side).

Refer to [SBC-15, "PASSENGER SIDE : Component Inspection \(Passenger side seat belt buckle switch\)"](#).

Is the inspection result normal?

- YES >> GO TO 11.
 NO >> Replace seat belt buckle switch (passenger side). Refer to [SB-7, "SEAT BELT BUCKLE : Removal and Installation"](#).

11.CHECK FRONT SEAT BELT WARNING UNIT OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Connect front seat belt warning unit connector.
3. Check voltage between front seat belt warning unit harness connector and ground.

| Combination meter | | Ground | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| connector | Terminal | | |
| M64 | 21 | Ground | 5 |

Is the inspection result normal?

- YES >> GO TO 12.
 NO >> Replace front seat belt warning unit.

12.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection (Passenger side seat belt buckle switch)

INFOID:000000001279929

1.CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

FRONT SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch (passenger side) connector.
3. Check continuity between seat belt buckle switch (passenger side) terminal.

| Seat belt buckle switch (passenger side) | | Condition | Continuity |
|--|----------|-----------|---|
| connector | Terminal | | |
| B23 | 1 | 2 | When seat belt is unfastened Existed |
| | | | When seat belt is fastened Not existed |

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace seat belt buckle switch (passenger side). Refer to [SB-7. "SEAT BELT BUCKLE : Removal and Installation"](#).

PASSENGER SIDE : Component Inspection (Occupant detection unit)

INFOID:000000001521453

1. CHECK OCCUPANT DETECTION UNIT

1. Turn ignition switch OFF.
2. Disconnect occupant detection unit connector.
3. Check continuity between occupant detection unit terminal.

| Occupant detection unit | | Condition | Continuity |
|-------------------------|----------|-----------|---|
| connector | Terminal | | |
| B48 | 1 | 2 | When getting in the passenger seat Existed |
| | | | Other than above Not existed |

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace occupant detection unit. Refer to [SE-36. "Disassembly and Assembly"](#).

REAR SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

REAR SEAT BELT BUCKLE SWITCH

REAR LH

REAR LH : Description

INFOID:000000001279931

- Detects if the rear seat belt LH is fastened or unfastened.
- Warning lamp turns OFF if the rear seat belt LH is fastened.

REAR LH : Component Function Check

INFOID:000000001279932

1.CHECK REAR SEAT BELT BUCKLE SWITCH FUNCTION

1. Start the engine.
2. Check if the warning lamp turns OFF as soon as the rear seat belt LH is fastened.

Is the inspection results normal?

- YES >> Rear seat belt buckle switch is OK.
 NO >> Refer to [SBC-17, "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000001279933

1.CHECK REAR SEAT BELT WARNING UNIT OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between rear seat belt warning unit harness connector and ground.

| Rear seat belt buckle switch | | Ground | Condition | Voltage (V) (Approx.) |
|------------------------------|----------|--------|-----------------------------------|--------------------------|
| Connector | Terminal | | | |
| B49 | 7 | Ground | Rear seat belt (LH) is fastened | Battery voltage |
| | | | Rear seat belt (LH) is unfastened | 0 |

SBC

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2.CHECK REAR SEAT BELT BUCKLE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seat belt and rear seat belt buckle switch connector.
3. Check continuity between rear seat belt warning unit harness connector and rear seat belt buckle switch harness connector.

| Rear seat belt warning unit | | Rear seat belt buckle switch | | Continuity |
|-----------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | terminal | |
| M49 | 7 | B63 | 1 | Existed |

4. Check continuity between rear seat belt warning unit connector and ground.

| Rear seat belt warning unit | | Ground | Continuity |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M49 | 7 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK REAR LH SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between rear LH seat belt buckle switch harness connector and ground.

REAR SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

| Rear seat belt buckle switch | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| connector | Terminal | | |
| B63 | 2 | Ground | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK REAR LH SEAT BELT BUKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-18, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace rear LH seat belt buckle switch. Refer to [SB-13, "SEAT BELT BUCKLE : Removal and Installation"](#).

5.CHECK REAR LH SEAT BELT WARNING UNIT OUTPUT SIGANL

Check voltage between rear seat belt warning unit harness connector and ground.

| Rear seat belt warning unit connector | | Ground | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------|--------------------------|
| Connector | Terminal | | |
| M91 | 7 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace rear seat belt warning unit.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

REAR LH : Component Inspection

INFOID:000000001279934

1.CHECK SEAT BELT BUCKLE SWITCH

- Turn ignition switch OFF.
- Disconnect rear seat buckle switch connector.
- Check continuity between rear seat belt buckle switch terminals.

| Rear seat belt buckle switch | | | Condition | Continuity |
|------------------------------|----------|---|-----------------------------------|-------------|
| Connector | Terminal | | | |
| B63 | 1 | 2 | Rear seat belt (LH) is unfastened | Existed |
| | | | Rear seat belt (LH) is fastened | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END.
 NO >> Replace rear LH seat belt buckle switch. Refer to [SB-13, "SEAT BELT BUCKLE : Removal and Installation"](#).

REAR RH AND CENTER

REAR RH AND CENTER : Description

INFOID:000000001524224

- Detects if the rear seat belt (Center or RH) is fastened or unfastened.
- Warning lamp turns OFF if the seat belt (Center or RH) is fastened.

REAR SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

REAR RH AND CENTER : Component Function Check

INFOID:000000001524225

1.CHECK REAR SEAT BELT BUCKLE SWITCH FUNCTION

1. Start the engine.
2. Check if the warning lamp turns OFF as soon as the rear seat belt (Center or RH) is fastened.

Is the inspection results normal?

- YES >> Rear seat belt buckle switch is OK.
 NO >> Refer to [.SBC-19, "REAR RH AND CENTER : Diagnosis Procedure".](#)

REAR RH AND CENTER : Diagnosis Procedure

INFOID:000000001524226

1.CHECK REAR SEAT BELT WARNING UNIT OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between rear seat belt warning unit harness connector and ground.

| Rear seat belt buckle switch | | | Ground | Condition | Voltage (V) (Approx.) |
|------------------------------|-----------|----------|--------|---------------------------------------|--------------------------|
| | Connector | Terminal | | | |
| Center | B49 | 6 | Ground | Rear seat belt (RH) is fastened | Battery voltage |
| | | | | Rear seat belt (RH) is unfastened | 0 |
| RH | | 1 | | Rear seat belt (center) is fastened | Battery voltage |
| | | | | Rear seat belt (center) is unfastened | 0 |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 2.

2.CHECK REAR SEAT BELT BUCKLE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seat belt warning unit and rear seat belt buckle switch connector.
3. Check continuity between rear seat warning unit harness connector and rear seat belt buckle switch harness connector.

| Rear seat belt warning unit | | Rear seat belt buckle switch | | Continuity |
|-----------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | terminal | |
| M49 | 6 | B64 (RH and center) | 1 | Existed |
| | 1 | | 3 | |

4. Check continuity between rear seat belt warning unit connector and ground.

| | Rear seat belt warning unit | | Ground | Continuity |
|--------|-----------------------------|----------|--------|-------------|
| | Connector | Terminal | | |
| Center | M49 | 6 | Ground | Not existed |
| RH | | 1 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between rear seat belt buckle switch connector and ground.

| | Rear seat belt buckle switch | | Ground | Continuity |
|--------|------------------------------|----------|--------|------------|
| | connector | Terminal | | |
| Center | B64 | 2 | Ground | Existed |
| RH | | 4 | | |

REAR SEAT BELT BUCKLE SWITCH

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

4.CHECK REAR SEAT BELT BUKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-20, "REAR RH AND CENTER : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace rear seat belt buckle switch. Refer to [SB-13, "SEAT BELT BUCKLE : Removal and Installation"](#).

5.CHECK REAR SEAT BELT WARNING UNIT OUTPUT SIGNAL

Check voltage between rear seat belt warning unit harness connector and ground.

| | Rear seat belt warning unit connector | | Ground | Voltage (V) (Approx.) |
|--------|---------------------------------------|----------|--------|--------------------------|
| | Connector | Terminal | | |
| Center | M91 | 6 | Ground | Battery voltage |
| RH | | 1 | | |

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Replace rear seat belt warning unit.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

REAR RH AND CENTER : Component Inspection

INFOID:000000001524227

1.CHECK SEAT BELT BUCKLE SWITCH

1. Turn ignition switch OFF.
2. Disconnect rear seat buckle switch connector.
3. Check continuity between rear seat belt buckle switch terminals.

| Rear seat belt buckle switch | | | Condition | Continuity |
|------------------------------|----------|---|---------------------------------------|-------------|
| Connector | Terminal | | | |
| B64 | 1 | 2 | Rear seat belt (RH) is unfastened | Existed |
| | | | Rear seat belt (RH) is fastened | Not existed |
| | 3 | 4 | Rear seat belt (center) is unfastened | Existed |
| | | | Rear seat belt (center) is fastened | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END.
- NO >> Replace seat belt buckle switch. Refer to [SB-13, "SEAT BELT BUCKLE : Removal and Installation"](#).

FRONT SEAT BELT WARNING LAMP

< COMPONENT DIAGNOSIS >

FRONT SEAT BELT WARNING LAMP

Description

INFOID:000000001534948

The front seat belt warning lamp is located in combination meter.
The combination meter illuminate front seat belt warning lamp when seat belts (driver side and passenger side) are fastened.

Component Function Check

INFOID:000000001534949

1. SEAT BELT WARNING LAMP FUNCTION

1. Turn ignition switch ON.
2. Sits in the passenger seat.
3. Fasten the seat belt (passenger side).
4. Check front seat belt warning lamp function.

| Condition | Front seat belt warning lamp |
|---------------------------------------|------------------------------|
| Seat belt (driver side) is fastened | Not illuminated |
| Seat belt (driver side) is unfastened | Illuminated |

Is the inspection results normal?

- YES >> Seat belt warning lamp is OK.
NO >> Refer to [SBC-21, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001534953

SBC

1. CHECK SEAT BELT WARNING LAMP INPUT SIGNAL

1. Turn ignition switch ON.
2. Sits in the passenger seat.
3. Fasten the seat belt (passenger side).
4. Check signal between front seat belt warning unit harness connector and ground oscilloscope.

| Front seat belt warning unit | | Ground | Condition | Signal |
|------------------------------|----------|--------|---------------------------------------|-----------------|
| Connector | Terminal | | | |
| M63 | 8 | Ground | Seat belt (driver side) is fastened | Battery voltage |
| | | | Seat belt (driver side) is unfastened | 0 |

Is the inspection results normal?

- YES >> GO TO 4
NO >> GO TO 2

2. CHECK SEAT BELT WARNING LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit connector and combination meter connector.
3. Check continuity between front seat belt warning unit harness connector and combination meter harness connector.

| Front seat belt warning unit | | Combination meter | | Continuity |
|------------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M63 | 8 | M34 | 35 | Existed |

4. Check continuity between front seat belt warning unit and ground.

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M63 | 8 | Ground | Not existed |

FRONT SEAT BELT WARNING LAMP

< COMPONENT DIAGNOSIS >

YES >> GO TO 3

NO >> Repair or replace harness.

3.CHECK COMBINATION METER

Refer to [MWI-64. "DTC Index"](#).

>> INSPECTION END

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39. "Intermittent Incident"](#).

>> INSPECTION END

REAR SEAT BELT WARNING LAMP

< COMPONENT DIAGNOSIS >

REAR SEAT BELT WARNING LAMP

Description

INFOID:000000001308624

- Detects if the rear seat belt is fastened or unfastened.
- Warning lamp turns OFF if the seat belt is fastened.

Component Function Check

INFOID:000000001308625

1.CHECK REAR SEAT BELT BUCKLE SWITCH FUNCTION

Check if the warning lamp turns OFF as soon as the seat belt is fastened.

Is the inspection results normal?

- YES >> Rear seat belt buckle switch is OK.
 NO >> Refer to [SBC-23. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001308626

1.CHECK SEAT BELT WARNING LAMP POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect rear seat belt warning lamp connector.
3. Check voltage between rear seat belt warning lamp harness connector and ground.

| Rear seat belt warning lamp | | Ground | Condition | Voltage |
|-----------------------------|----------|--------|--------------------|-----------------|
| Connector | Terminal | | | |
| M87 | 1 | Ground | Ignition switch ON | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Check harness open or short between rear seat belt warning lamp and fuse.

2.CHECK REAR SEAT BELT WARNING LAMP OUTPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between rear seat belt warning lamp harness connector and ground.

| | Rear seat belt buckle switch | | Ground | Condition | Voltage (V) (Approx.) |
|--------|------------------------------|----------|--------|---------------------------------------|--------------------------|
| | Connector | Terminal | | | |
| LH | M87 | 4 | Ground | Rear seat belt (LH) is fastened | Battery voltage |
| | | | | Rear seat belt (LH) is unfastened | 0 |
| Center | | 3 | | Rear seat belt (center) is fastened | Battery voltage |
| | | | | Rear seat belt (center) is unfastened | 0 |
| RH | | 2 | | Rear seat belt (RH) is fastened | Battery voltage |
| | | | | Rear seat belt (RH) is unfastened | 0 |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> GO TO 3.

3.CHECK REAR SEAT BELT WARNING UNIT OUTPUT SIGNAL

Check voltage between rear seat belt warning unit harness connector and ground.

| Rear seat belt warning unit | | Ground | Voltage (V) (Approx.) |
|-----------------------------|----------|--------|--------------------------|
| connector | Terminal | | |
| M91 | 3 | Ground | Battery voltage |
| | 4 | | |
| | 5 | | |

REAR SEAT BELT WARNING LAMP

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace rear seat belt warning unit.

4. CHECK REAR SEAT BELT WARNING LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear seat belt warning unit and rear seat belt buckle switch connector.
3. Check continuity between rear seat belt warning unit harness connector and rear seat belt buckle switch harness connector.

| Rear seat belt warning unit | | Rear seat belt warning unit | | Continuity |
|-----------------------------|----------|-----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M87 | 3 | B49 | 4 | Existed |
| | 4 | | 3 | |
| | 5 | | 2 | |

4. Check continuity between rear seat belt warning unit harness connector and ground.

| Rear seat belt warning unit | | Ground | Continuity |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M87 | 2 | Ground | Not existed |
| | 3 | | |
| | 4 | | |

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace harness.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

>> INSPECTION END

VEHICLE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

VEHICLE SPEED SIGNAL

Description

INFOID:000000001534943

The front seat belt warning unit receives vehicle speed signal from combination meter.
The front seat belt warning unit use the signal for seat belt warning chime.

Component Function Check

INFOID:000000001534944

1.CHECK VEHICLE SPEED SIGNAL

1. Lift up the vehicle.
2. Seat belt warning chime will sound, when seat belt is unfastened and vehicle speed is more than 25 km/h.

Is the inspection results normal?

- YES >> Vehicle speed signal is OK.
NO >> Refer to [SBC-25, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001534954

1.CHECK VEHICLE SPEED SIGNAL

1. Lift up the vehicle.
2. Check signal between front seat belt warning unit harness connector and ground oscilloscope.

| Front seat belt warning unit | | Ground | Condition | Signal |
|------------------------------|----------|--------|-----------------------------|-----------|
| Connector | Terminal | | | |
| M64 | 36 | Ground | Vehicle speed is at 40 km/h | PKIA1935E |

Is the inspection results normal?

- YES >> GO TO 4
NO >> GO TO 2

2.CHECK VEHICLE SPEED CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front seat belt warning unit connector and combination meter connector.
3. Check continuity between front seat belt warning unit harness connector and combination meter harness connector.

| Front seat belt warning unit | | Combination meter | | Continuity |
|------------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M64 | 36 | M34 | 30 | Existed |

4. Check continuity between front seat belt warning unit and ground.

| Front seat belt warning unit | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M64 | 36 | Ground | Not existed |

- YES >> GO TO 3
NO >> Repair or replace harness.

3.CHECK COMBINATION METER

Refer to [MWI-64, "DTC Index"](#).

>> INSPECTION END

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

VEHICLE SPEED SIGNAL

< COMPONENT DIAGNOSIS >

>> INSPECTION END

ALTERNATOR SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

ALTERNATOR SIGNAL CIRCUIT

Description

INFOID:000000001279935

Transmits the "engine started" signal to indicator unit.

Component Function Check

INFOID:000000001279936

1.CHECK ALTERNATOR SIGNAL CIRCUIT

Check if the warning lamp turns OFF, approximately 35 seconds after the engine has started.

Is the inspection results normal?

- YES >> Alternator signal circuit is OK.
NO >> Refer to [SBC-27, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000001279937

1.CHECK REAR SEAT BELT WARNING UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear seat belt warning unit connector.
3. Turn ignition switch ON.
4. Check voltage between rear seat belt warning unit harness connector and ground.

| Rear seat belt warning unit | | Ground | Condition | Voltage (V) (Approx.) |
|-----------------------------|----------|--------|------------------|--------------------------|
| Connector | Terminal | | | |
| B49 | 6 | Ground | Engine running | Battery voltage |
| | | | Other than above | 0 |

Is the inspection result normal?

- YES >> Replace rear seat belt warning unit.
NO >> GO TO 2.

2.CHECK ALTERNATOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect alternator connector.
3. Check continuity between rear seat belt warning unit harness connector and alternator harness connector.

| Rear seat belt warning unit | | Alternator | | Continuity |
|-----------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B49 | 2 | F15 ^{*1} | 3 | Existed |
| | | F60 ^{*2} | | |

*1 QR engine models

*2 Except QR engine models

4. Check continuity between rear seat belt warning unit harness connector and ground.

| Rear seat belt warning unit | | Ground | Continuity |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B49 | 2 | Ground | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-39, "Intermittent Incident"](#).

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

ALTERNATOR SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

>> INSPECTION END

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

ECU DIAGNOSIS


FRONT SEAT BELT WARNING UNIT

LHD MODELS

LHD MODELS : Reference Value

INFOID:000000001279938

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Value |
|------------------------------|--------|-------------------------------------|------------------|--------------------|---|-----------------|
| + | - | Signal name | Input/ Output | | | (Approx.) |
| 8 | Ground | Seat belt warning lamp signal | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 16 | Ground | Ground | — | — | — | 0 V |
| 17 | Ground | IGN signal | Input | Ignition switch ON | — | Battery voltage |
| 21 | Ground | Seat belt buckle switch signalInput | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 36 | Ground | Vehicle speed signal | Input | Ignition switch ON | When vehicle speed is approx. 40km (25MPH). | |


LHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

INFOID:000000001279939

SEAT BELT WARNING LAMP (LHD MODELS)



PS: With power seat
OS: Without power seat

*: This connector is not shown in "Harness Layout".


JCHWA0049GE

2007/02/28

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

QR : With QR engine
XQ : Without QR engine



JCHWA0050GE


A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

| | |
|----------------|--------------|
| Connector No. | B3 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | GR | - |

| | |
|----------------|---|
| Connector No. | B22 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B23 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|-----------------------------|
| Connector No. | B49 |
| Connector Name | REAR SEAT BELT WARNING UNIT |
| Connector Type | TK00FY |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | RR RH BUCKLE SW |
| 2 | L | CHARGE IN |
| 3 | G | RR LH IND OUT |
| 4 | R | RR CTR IND OUT |
| 5 | O | RR RH IND OUT |
| 6 | Y | RR CTR BUCKLE SW |
| 7 | V | RR LH BUCKLE SW |
| 8 | B | GND |
| 10 | W | IGN |

| | |
|----------------|--------------|
| Connector No. | B54 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|--------------|
| Connector No. | B55 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|---------------------------------|
| Connector No. | B63 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH LH |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | B | - |

JCHWA0051GE

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|--|
| Connector No. | B64 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH RH AND CENTER |
| Connector Type | TK04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | B | - |
| 3 | GR | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | B67 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B88 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B401 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|---|
| Connector No. | B409 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------|
| Connector No. | B410 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--|
| Connector No. | B416 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------------------|
| Connector No. | B423 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO 6088-2220 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 13 | L | - |
| 14 | B | - |


A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|-------------------------|
| Connector No. | B424 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO:8096-Z20 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | E6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24MW-1V |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | O | - |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 14 | O | - |

| | |
|----------------|------------|
| Connector No. | F15 |
| Connector Name | ALTERNATOR |
| Connector Type | HSC0FB |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|------------|
| Connector No. | F42 |
| Connector Name | ALTERNATOR |
| Connector Type | - |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | - | GND |

| | |
|----------------|------------|
| Connector No. | F60 |
| Connector Name | ALTERNATOR |
| Connector Type | X02FW |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|--------------|
| Connector No. | F123 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24FW-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | L | - |

| | |
|----------------|-----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

JCHWA0053GE

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|------------------------------|
| Connector No. | M64 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TK2JFGY |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17 | W | IGN |
| 21 | GR | BUJCKLE SW |
| 36 | V | 2P/R |

| | |
|----------------|------------------------------|
| Connector No. | M63 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TAS16FGY |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 8 | O | DR BELT IND |
| 16 | B | GND |

| | |
|----------------|-------------------|
| Connector No. | M64 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB40FW |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 21 | L | CAN-H |
| 22 | P | CAN-L |
| 30 | V | VEHICLE SPEED (2-PULSE) |
| 35 | O | |

| | |
|----------------|--------------|
| Connector No. | M13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | GR | - |

| | |
|----------------|-----------------------------|
| Connector No. | M87 |
| Connector Name | REAR SEAT BELT WARNING LAMP |
| Connector Type | TH04FW-NH |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | O | - |
| 3 | R | - |
| 4 | G | - |

| | |
|----------------|-----------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 14 | BR | - |

RHD MODELS

JCHWA0054GE

A
B
C
D
E
F
G
SBC

I
J
K
L
M
N
O
P


FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

RHD MODELS : Reference Value

INFOID:000000001551299

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Value |
|------------------------------|--------|--------------------------------|------------------|--------------------|---|-----------------|
| + | - | Signal name | Input/ Output | | | (Approx.) |
| 8 | Ground | Seat belt warning lamp signal | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 16 | Ground | Ground | — | — | — | 0 V |
| 17 | Ground | IGN signal | Input | Ignition switch ON | — | Battery voltage |
| 21 | Ground | Seat belt buckle switch signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 36 | Ground | Vehicle speed signal | Input | Ignition switch ON | When vehicle speed is approx. 40km (25MPH). | |


RHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

INFOID:000000001551300

SEAT BELT WARNING LAMP (RHD MODELS)



PS : With power seat
OS : Without power seat

*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SBC


2007/02/28

JCHWA0055GE

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

QR : With QR engine
XO : Without QR engine



JCHWA0056GE

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

SEAT BELT WARNING LAMP (RHD MODELS)

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

| | |
|----------------|--------------|
| Connector No. | B3 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | GR | - |

| | |
|----------------|---|
| Connector No. | B2 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B23 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|-----------------------------|
| Connector No. | B49 |
| Connector Name | REAR SEAT BELT WARNING UNIT |
| Connector Type | TK0FGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | RR RH BUCKLE SW |
| 2 | L | CHARGE IN |
| 3 | G | RR LH IND OUT |
| 4 | R | RR CTR IND OUT |
| 5 | O | RR RH IND OUT |
| 6 | Y | RR CTR BUCKLE SW |
| 7 | V | RR LH BUCKLE SW |
| 8 | B | GND |
| 10 | W | IGN |

| | |
|----------------|--------------|
| Connector No. | B54 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|--------------|
| Connector No. | B55 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|---------------------------------|
| Connector No. | B63 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH LH |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | B | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SBC

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (RHD MODELS)

| | |
|----------------|--|
| Connector No. | B64 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH RH AND CENTER |
| Connector Type | TK04FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | B | - |
| 3 | GR | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | B77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B88 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B401 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|---|
| Connector No. | B409 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------|
| Connector No. | B410 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--|
| Connector No. | B416 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------------------|
| Connector No. | B423 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO 6098-2220 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 13 | L | - |
| 14 | B | - |

JCHWA0058GE

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (RHD MODELS)

| | |
|----------------|--------------------------|
| Connector No. | B424 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO:8198-Z220 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | |
| 4 | B | |

| | |
|----------------|--------------|
| Connector No. | E6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24MW-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | O | |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-GS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 14 | O | |

| | |
|----------------|------------|
| Connector No. | F15 |
| Connector Name | ALTERNATOR |
| Connector Type | HSC3FB |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | |

| | |
|----------------|------------|
| Connector No. | F42 |
| Connector Name | ALTERNATOR |
| Connector Type | |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | - | GND |

| | |
|----------------|------------|
| Connector No. | F60 |
| Connector Name | ALTERNATOR |
| Connector Type | X02FW |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | |

| | |
|----------------|--------------|
| Connector No. | F123 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24W-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | L | |

| | |
|----------------|-----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-GS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 74 | L | |
| 75 | R | |
| 82 | GR | |
| 83 | W | |
| 84 | G | |
| 85 | O | |


A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

FRONT SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (RHD MODELS)

| | |
|----------------|--------------|
| Connector No. | M13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |



| | | | | | |
|--------------|---|---------------|----|-----------------------------|---|
| Terminal No. | 2 | Color of Wire | GR | Signal Name [Specification] | - |
|--------------|---|---------------|----|-----------------------------|---|

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB40FW |



| | | | | | |
|--------------|----|---------------|---|-----------------------------|-------------------------|
| Terminal No. | 21 | Color of Wire | L | Signal Name [Specification] | CAN-H |
| | 22 | | P | | CAN-L |
| | 30 | | V | | VEHICLE SPEED (2-PULSE) |
| | 35 | | O | | - |

| | |
|----------------|------------------------------|
| Connector No. | M63 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TAS16FGY |




| | | | | | |
|--------------|----|---------------|---|-----------------------------|-------------|
| Terminal No. | 8 | Color of Wire | O | Signal Name [Specification] | DR BELT IND |
| | 16 | | B | | GND |

| | |
|----------------|------------------------------|
| Connector No. | M64 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TK20FGY |



| | | | | | |
|--------------|----|---------------|----|-----------------------------|-----------|
| Terminal No. | 17 | Color of Wire | W | Signal Name [Specification] | IGN |
| | 21 | | GR | | BUCKLE SW |
| | 36 | | V | | 2P/R |

| | |
|----------------|-----------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | THB0MW-CS16-TM4 |



| | | | | | |
|--------------|----|---------------|----|-----------------------------|---|
| Terminal No. | 14 | Color of Wire | BR | Signal Name [Specification] | - |
|--------------|----|---------------|----|-----------------------------|---|

| | |
|----------------|-----------------------------|
| Connector No. | M87 |
| Connector Name | REAR SEAT BELT WARNING LAMP |
| Connector Type | TH04FW-NH |



| | | | | | |
|--------------|---|---------------|---|-----------------------------|---|
| Terminal No. | 1 | Color of Wire | W | Signal Name [Specification] | - |
| | 2 | | O | | - |
| | 3 | | R | | - |
| | 4 | | G | | - |

JCHWA0060GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


REAR SEAT BELT WARNING UNIT

LHD MODELS

LHD MODELS : Reference Value

INFOID:000000001350920

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Value |
|------------------------------|--------|--|------------------|--------------------|--|-----------------|
| + | - | Signal name | Input/ Output | | | (Approx.) |
| 1 | Ground | Rear seat belt buckle switch (RH) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 2 | Ground | — | — | — | — | 0 V |
| 3 | Ground | Seat belt warning lamp signal (LH) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 4 | Ground | Seat belt warning lamp signal (Center) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 5 | Ground | Seat belt warning lamp signal (RH) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 8 | Ground | Ground | — | — | — | 0 V |
| 10 | Ground | IGN signal | Input | Ignition switch ON | — | Battery voltage |
| 7 | Ground | Rear seat belt buckle switch (LH) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 6 | Ground | Rear seat belt buckle switch (center) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |


LHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

INFOID:000000001551308

SEAT BELT WARNING LAMP (LHD MODELS)



(PS) : With power seat
 (OS) : Without power seat
 * : This connector is not shown in "Harness Layout".


JCHWA0049GE

2007/02/28

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

QR : With QR engine
XQ : Without QR engine



JCHWA0050GE


A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|-----------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

| | |
|----------------|--------------|
| Connector No. | B3 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | GR | - |

| | |
|----------------|---|
| Connector No. | B22 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B23 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |

| | |
|----------------|-----------------------------|
| Connector No. | B49 |
| Connector Name | REAR SEAT BELT WARNING UNIT |
| Connector Type | TK0FGY |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | RR RH BUCKLE SW |
| 2 | L | CHARGE IN |
| 3 | G | RR LH IND OUT |
| 4 | R | RR CTR IND OUT |
| 5 | O | RR RH IND OUT |
| 6 | Y | RR CTR BUCKLE SW |
| 7 | V | RR LH BUCKLE SW |
| 8 | B | GND |
| 10 | W | IGN |

| | |
|----------------|--------------|
| Connector No. | B54 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|--------------|
| Connector No. | B55 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH42FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 22 | V | - |

| | |
|----------------|---------------------------------|
| Connector No. | B63 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH LH |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | B | - |

JCHWA0051GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|--|
| Connector No. | B64 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH RH AND CENTER |
| Connector Type | TK04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | B | - |
| 3 | GR | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | B67 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B88 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B401 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|---|
| Connector No. | B409 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------|
| Connector No. | B410 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--|
| Connector No. | B416 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------------------|
| Connector No. | B423 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO 6088-2220 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 13 | L | - |
| 14 | B | - |

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P



JCHWA0052GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >



SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|-------------------------|
| Connector No. | B424 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO:8096-Z20 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | E6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24MW-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | O | - |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 14 | O | - |

| | |
|----------------|------------|
| Connector No. | F15 |
| Connector Name | ALTERNATOR |
| Connector Type | HSC3FB |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|------------|
| Connector No. | F42 |
| Connector Name | ALTERNATOR |
| Connector Type | - |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | - | GND |

| | |
|----------------|------------|
| Connector No. | F60 |
| Connector Name | ALTERNATOR |
| Connector Type | X02FW |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|--------------|
| Connector No. | F123 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24FW-1V |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | L | - |

| | |
|----------------|-----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

JCHWA0053GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|------------------------------|
| Connector No. | M64 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TK2JFGY |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 17 | W | IGN |
| 21 | GR | BUCKLE SW |
| 36 | V | 2P/R |

| | |
|----------------|------------------------------|
| Connector No. | M63 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TAS16FGY |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 8 | O | DR BELT IND |
| 16 | B | GND |

| | |
|----------------|-------------------|
| Connector No. | M64 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB40FW |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 21 | L | GAN-H |
| 22 | P | GAN-L |
| 30 | V | VEHICLE SPEED (2-PULSE) |
| 35 | O | - |

| | |
|----------------|--------------|
| Connector No. | M13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | GR | - |

| | |
|----------------|-----------------------------|
| Connector No. | M87 |
| Connector Name | REAR SEAT BELT WARNING LAMP |
| Connector Type | TH04FW-NH |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1 | W | - |
| 2 | O | - |
| 3 | R | - |
| 4 | G | - |

| | |
|----------------|-----------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |

| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 14 | BR | - |

RHD MODELS

JCHWA0054GE

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P


REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

RHD MODELS : Reference Value

INFOID:000000001551305

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Value |
|------------------------------|--------|--|------------------|--------------------|--|-----------------|
| + | - | Signal name | Input/ Output | | | (Approx.) |
| 1 | Ground | Rear seat belt buckle switch (RH) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 2 | Ground | — | — | — | — | 0 V |
| 3 | Ground | Seat belt warning lamp signal (LH) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 4 | Ground | Seat belt warning lamp signal (Center) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 5 | Ground | Seat belt warning lamp signal (RH) | Output | Ignition switch ON | Seat belt warning lamp is illuminated. | 0 V |
| | | | | | Seat belt warning lamp is not illuminated. | Battery voltage |
| 8 | Ground | Ground | — | — | — | 0 V |
| 10 | Ground | IGN signal | Input | Ignition switch ON | — | Battery voltage |
| 7 | Ground | Rear seat belt buckle switch (LH) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |
| 6 | Ground | Rear seat belt buckle switch (center) signal | Input | Ignition switch ON | Seat belt buckle switch is fastened. | Battery voltage |
| | | | | | Seat belt buckle switch is unfastened. | 0 V |


RHD MODELS : Wiring Diagram - SEAT BELT WARNING LAMP CONTROL SYSTEM

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

INFOID:000000001551309

- L : LHD models
- R : RHD models
- G : With gasoline engine
- D : With diesel engine
- *1 3 : G D
- 4 : G D



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SBC

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP

| | |
|----------------|--------------|
| Connector No. | B1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | O | - |
| 8 | Y | - |
| 10 | O | - |
| 14 | GR | - |
| 20 | GR | - |

| | |
|----------------|---|
| Connector No. | B22 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | CO2FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B23 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | CO2FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | LG | - |

| | |
|----------------|-------------------------|
| Connector No. | B48 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SO2FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B63 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH LH AND CENTER |
| Connector Type | TH04FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | B | - |
| 3 | Y | - |
| 4 | B | - |

| | |
|----------------|--|
| Connector No. | B64 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH RH AND CENTER |
| Connector Type | TH04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | B | - |
| 3 | Y | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | E6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TR24MM-IV |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | L | - |

| | |
|----------------|------------------|
| Connector No. | E05 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH60MW-NS(6-7M4) |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 59 | L | - |

JCHWA0032GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >

SEAT BELT WARNING LAMP

| | |
|----------------|------------|
| Connector No. | F1B |
| Connector Name | ALTERNATOR |
| Connector Type | HS03FB |



| | | | |
|-----------------------------|---|---|---|
| Terminal No. | 3 | L | L |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|------------|
| Connector No. | F42 |
| Connector Name | ALTERNATOR |
| Connector Type | - |




| | | | |
|-----------------------------|---|---|-----|
| Terminal No. | 2 | - | GND |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|------------|
| Connector No. | F80 |
| Connector Name | ALTERNATOR |
| Connector Type | FEA02FB |




| | | | |
|-----------------------------|---|---|---|
| Terminal No. | 4 | L | S |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|--------------|
| Connector No. | F123 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24FW-IV |




| | | | |
|-----------------------------|----|---|--|
| Terminal No. | 10 | L | |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|--------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW |




| | | | |
|-----------------------------|----|----|---|
| Terminal No. | 3 | O | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 8 | Y | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 10 | O | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 14 | GR | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 20 | GR | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|-------------------|
| Connector No. | M84 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB40FW |




| | | | |
|-----------------------------|----|----|--------------------------------------|
| Terminal No. | 1 | Y | BAT |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 2 | GR | IGN |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 3 | B | GND |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 14 | O | AS BELT REMIND |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 23 | B | GND |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 35 | O | SEAT BELT BUCKLE SW (DRIVER SIDE) |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 36 | GR | SEAT BELT BUCKLE SW (PASSENGER SIDE) |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|--------------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH60FW-NSI (P-TM4) |



| | | | |
|-----------------------------|----|---|---|
| Terminal No. | 59 | L | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|----------------|
| Connector No. | M81 |
| Connector Name | INDICATOR UNIT |
| Connector Type | TH08FW-IV |



| | | | |
|-----------------------------|---|-----|---|
| Terminal No. | 1 | O | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 3 | O | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 4 | Y | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 5 | GR | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 6 | GR | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |
| Terminal No. | 7 | W/L | - |
| Color of Wire | | | |
| Signal Name [Specification] | | | |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SBC

JCHWA0033GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|--|
| Connector No. | B64 |
| Connector Name | REAR SEAT BELT BUCKLE SWITCH RH AND CENTER |
| Connector Type | TK04FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | B | - |
| 3 | GR | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | B77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B88 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06FW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | GR | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B401 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|---|
| Connector No. | B409 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------|
| Connector No. | B410 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS06MW-CS |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--|
| Connector No. | B416 |
| Connector Name | FRONT SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | TK03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | O | - |

| | |
|----------------|--------------------------|
| Connector No. | B423 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO 6098-2220 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 13 | L | - |
| 14 | B | - |

JCHWA0052GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|--------------------------|
| Connector No. | B424 |
| Connector Name | OCCUPANT DETECTION UNIT |
| Connector Type | SUMITOMO DENSO:8198-2220 |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | E6 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24MW-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | O | - |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 14 | O | - |

| | |
|----------------|------------|
| Connector No. | F15 |
| Connector Name | ALTERNATOR |
| Connector Type | HSC3FB |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|------------|
| Connector No. | F42 |
| Connector Name | ALTERNATOR |
| Connector Type | - |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 2 | - | GND |

| | |
|----------------|------------|
| Connector No. | F60 |
| Connector Name | ALTERNATOR |
| Connector Type | X02FW |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3 | L | L |

| | |
|----------------|--------------|
| Connector No. | F123 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TK24W-1V |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 24 | L | - |

| | |
|----------------|-----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 74 | L | - |
| 75 | R | - |
| 82 | GR | - |
| 83 | W | - |
| 84 | G | - |
| 85 | O | - |

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P


JCHWA0053GE

REAR SEAT BELT WARNING UNIT

< ECU DIAGNOSIS >


SEAT BELT WARNING LAMP (LHD MODELS)

| | |
|----------------|--------------|
| Connector No. | M13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |



| | | | | | |
|--------------|---|---------------|----|-----------------------------|---|
| Terminal No. | 2 | Color of Wire | GR | Signal Name [Specification] | - |
|--------------|---|---------------|----|-----------------------------|---|

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | SAB40FW |



| | | | | | |
|--------------|----|-------------------------|---|-----------------------------|-------|
| Terminal No. | 21 | Color of Wire | L | Signal Name [Specification] | CAN-H |
| 22 | P | CAN-L | | | |
| 30 | V | VEHICLE SPEED (2-PULSE) | | | |
| 35 | O | - | | | |

| | |
|----------------|------------------------------|
| Connector No. | M63 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TAS16FGY |




| | | | | | |
|--------------|---|---------------|---|-----------------------------|-------------|
| Terminal No. | 8 | Color of Wire | O | Signal Name [Specification] | DR BELT IND |
| 16 | B | GND | | | |

| | |
|----------------|------------------------------|
| Connector No. | M64 |
| Connector Name | FRONT SEAT BELT WARNING UNIT |
| Connector Type | TRK20FGY |




| | | | | | |
|--------------|----|---------------|---|-----------------------------|-----|
| Terminal No. | 17 | Color of Wire | W | Signal Name [Specification] | IGN |
| 21 | GR | BUCKLE SW | | | |
| 36 | V | 2P/R | | | |

| | |
|----------------|-----------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | THB0MW-CS16-TM4 |



| | | | | | |
|--------------|----|---------------|----|-----------------------------|---|
| Terminal No. | 14 | Color of Wire | BR | Signal Name [Specification] | - |
|--------------|----|---------------|----|-----------------------------|---|

| | |
|----------------|-----------------------------|
| Connector No. | M87 |
| Connector Name | REAR SEAT BELT WARNING LAMP |
| Connector Type | TH04FW-NH |



| | | | | | |
|--------------|---|---------------|---|-----------------------------|---|
| Terminal No. | 1 | Color of Wire | W | Signal Name [Specification] | - |
| 2 | O | - | | | |
| 3 | R | - | | | |
| 4 | G | - | | | |

JCHWA0054GE

FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

FRONT SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000001279942

1. CHECK FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check front seat belt buckle switch.

Refer to [SBC-10, "DRIVER SIDE : Component Function Check"](#) or [SBC-13, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT SEAT BELT WARNING LAMP

Check front seat belt warning lamp.

Refer to [SBC-21, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check front seat belt warning unit power supply and ground circuit.

Refer to [SBC-8, "FRONT SEAT BELT WARNING UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

REAR SEAT BELT WARNING LAMP DOES NOT ILLUMINATE

Diagnosis Procedure

INFOID:000000001279944

1. CHECK REAR SEAT BELT BUCKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-17, "REAR LH : Component Function Check"](#) or [SBC-19, "REAR RH AND CENTER : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR SEAT BELT WARNING LAMP

Check rear seat belt warning lamp circuit.

Refer to [SBC-23, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check rear seat belt warning unit power supply and ground circuit.

Refer to [SBC-8, "REAR SEAT BELT WARNING UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

FRONT SEAT BELT WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000001279946

1. CHECK FRONT SEAT BELT BUCKLE SWITCH

Check front seat belt buckle switch.

Refer to [SBC-10, "DRIVER SIDE : Component Function Check"](#) or [SBC-13, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT SEAT BELT WARNING LAMP

Check front seat belt warning lamp.

Refer to [SBC-21, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

REAR SEAT BELT WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000001279948

1. CHECK REAR SEAT BELT BUCKLE SWITCH

Check rear seat belt buckle switch.

Refer to [SBC-17. "REAR LH : Component Function Check"](#) or [SBC-19. "REAR RH AND CENTER : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ALTERNATOR SIGNAL CIRCUIT

Check alternator signal circuit.

Refer to [SBC-27. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-39. "Intermittent Incident"](#).

NO >> GO TO 1.

SEAT BELT WARNING CHIME DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

SEAT BELT WARNING CHIME DOES NOT SOUND

Diagnosis Procedure

INFOID:000000001534878

1. CHECK FRONT SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check front seat belt buckle switch.

Refer to [SBC-10, "DRIVER SIDE : Component Function Check"](#) or [SBC-13, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK VEHICLE SPEED SIGNAL

Check vehicle speed signal circuit.

Refer to [SBC-25, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check front seat belt warning unit power supply and ground circuit.

Refer to [SBC-8, "FRONT SEAT BELT WARNING UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check internal incident. Refer to [GI-39, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000001557118

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.