

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN

PRECAUTIONS	3	CAN Communication Circuit Check	43
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	IPDM E/R Ignition Relay Circuit Check	44
Precautions When Using CONSULT-II	3	Component Inspection	44
CHECK POINTS FOR USING CONSULT-II	3	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	44
Precautions For Trouble Diagnosis	3	CAN SYSTEM (TYPE 2)	45
CAN SYSTEM	3	System Description	45
Precautions For Harness Repair	4	Component Parts and Harness Connector Location	45
CAN SYSTEM	4	Schematic	46
CAN COMMUNICATION	5	Wiring Diagram - CAN -	47
System Description	5	Work Flow	50
CAN Communication Unit	5	CHECK SHEET	51
TYPE 1/ TYPE 2	6	CHECK SHEET RESULTS (EXAMPLE)	53
TYPE 3	8	Circuit Check Between TCM and Driver Seat Control Unit	67
TYPE 4/ TYPE 5	11	Circuit Check Between Driver Seat Control Unit and Data Link Connector	68
TYPE 6	13	Circuit Check Between Data Link Connector and IPDM E/R	69
CAN SYSTEM (TYPE 1)	16	ECM Circuit Check	70
System Description	16	TCM Circuit Check	70
Component Parts and Harness Connector Location	16	Driver Seat Control Unit Circuit Check	71
Schematic	17	Combination Meter Circuit Check	71
Wiring Diagram - CAN -	18	BCM Circuit Check	72
Work Flow	21	Data Link Connector Circuit Check	72
CHECK SHEET	22	Steering Angle Sensor Circuit Check	73
CHECK SHEET RESULTS (EXAMPLE)	24	Front Air Control Circuit Check	73
Circuit Check Between TCM and Data Link Connector	36	ABS Actuator and Electric Unit (Control Unit) Circuit Check	74
Circuit Check Between Data Link Connector and IPDM E/R	37	IPDM E/R Circuit Check	74
ECM Circuit Check	38	CAN Communication Circuit Check	75
TCM Circuit Check	39	IPDM E/R Ignition Relay Circuit Check	75
Combination Meter Circuit Check	39	Component Inspection	76
BCM Circuit Check	40	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	76
Data Link Connector Circuit Check	40	CAN SYSTEM (TYPE 3)	77
Steering Angle Sensor Circuit Check	41	System Description	77
Front Air Control Circuit Check	41	Component Parts and Harness Connector Location	77
ABS Actuator and Electric Unit (Control Unit) Circuit Check	42	Schematic	78
IPDM E/R Circuit Check	42	Wiring Diagram - CAN -	79

F
G
H
I
J
LAN

L
M

Work Flow	82	Work Flow	148
CHECK SHEET	84	CHECK SHEET	150
CHECK SHEET RESULTS (EXAMPLE)	86	CHECK SHEET RESULTS (EXAMPLE)	152
Circuit Check Between TCM and Driver Seat Control Unit	101	Circuit Check Between TCM and Driver Seat Control Unit	167
Circuit Check Between Driver Seat Control Unit and Data Link Connector	102	Circuit Check Between Driver Seat Control Unit and Data Link Connector	168
Circuit Check Between Data Link Connector and IPDM E/R	103	Circuit Check Between Data Link Connector and IPDM E/R	169
ECM Circuit Check	104	ECM Circuit Check	170
TCM Circuit Check	104	TCM Circuit Check	170
Driver Seat Control Unit Circuit Check	105	Driver Seat Control Unit Circuit Check	171
Combination Meter Circuit Check	105	Combination Meter Circuit Check	171
Display Control Unit Circuit Check	106	BCM Circuit Check	172
BCM Circuit Check	106	Data Link Connector Circuit Check	172
Data Link Connector Circuit Check	107	Steering Angle Sensor Circuit Check	173
Steering Angle Sensor Circuit Check	107	Front Air Control Circuit Check	173
Front Air Control Circuit Check	108	Transfer Control Unit Circuit Check	174
ABS Actuator and Electric Unit (Control Unit) Circuit Check	108	ABS Actuator and Electric Unit (Control Unit) Circuit Check	174
IPDM E/R Circuit Check	109	IPDM E/R Circuit Check	175
CAN Communication Circuit Check	109	CAN Communication Circuit Check	175
IPDM E/R Ignition Relay Circuit Check	110	IPDM E/R Ignition Relay Circuit Check	176
Component Inspection	110	Component Inspection	176
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	110	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	176
CAN SYSTEM (TYPE 4)	111	CAN SYSTEM (TYPE 6)	177
System Description	111	System Description	177
Component Parts and Harness Connector Location	111	Component Parts and Harness Connector Location	177
Schematic	112	Schematic	178
Wiring Diagram - CAN -	113	Wiring Diagram - CAN -	179
Work Flow	116	Work Flow	182
CHECK SHEET	118	CHECK SHEET	184
CHECK SHEET RESULTS (EXAMPLE)	120	CHECK SHEET RESULTS (EXAMPLE)	186
Circuit Check Between TCM and Data Link Connector	133	Circuit Check Between TCM and Driver Seat Control Unit	202
Circuit Check Between Data Link Connector and IPDM E/R	134	Circuit Check Between Driver Seat Control Unit and Data Link Connector	203
ECM Circuit Check	135	Circuit Check Between Data Link Connector and IPDM E/R	204
TCM Circuit Check	136	ECM Circuit Check	205
Combination Meter Circuit Check	136	TCM Circuit Check	205
BCM Circuit Check	137	Driver Seat Control Unit Circuit Check	206
Data Link Connector Circuit Check	137	Combination Meter Circuit Check	206
Steering Angle Sensor Circuit Check	138	Display Control Unit Circuit Check	207
Front Air Control Circuit Check	138	BCM Circuit Check	207
Transfer Control Unit Circuit Check	139	Data Link Connector Circuit Check	208
ABS Actuator and Electric Unit (Control Unit) Circuit Check	139	Steering Angle Sensor Circuit Check	208
IPDM E/R Circuit Check	140	Front Air Control Circuit Check	209
CAN Communication Circuit Check	141	Transfer Control Unit Circuit Check	209
IPDM E/R Ignition Relay Circuit Check	141	ABS Actuator and Electric Unit (Control Unit) Circuit Check	210
Component Inspection	142	IPDM E/R Circuit Check	210
ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	142	CAN Communication Circuit Check	211
CAN SYSTEM (TYPE 5)	143	IPDM E/R Ignition Relay Circuit Check	211
System Description	143	Component Inspection	212
Component Parts and Harness Connector Location	143	ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION	212
Schematic	144		
Wiring Diagram - CAN -	145		

PRECAUTIONS

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00LET

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions When Using CONSULT-II

EKS00LEU

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

CHECK POINTS FOR USING CONSULT-II

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
 - If YES, GO TO 2.
 - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
 - If YES, GO TO 3.
 - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "CAN Communication Unit"](#) .

**Precautions For Trouble Diagnosis
CAN SYSTEM**

EKS00LEV


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.

A
B
C
D
E
F
G
H
I
J
L
M


LAN

Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



CAN COMMUNICATION

System Description

EKS00LEX

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

EKS00LEY

Go to CAN system, when selecting your CAN system type from the following table.


Body type	Wagon					
Axle	2WD			4WD		
Engine	VK56DE					
Transmission	A/T					
Brake control	VDC					
Automatic drive positioner		×	×		×	×
Navigation system			×			×
Automatic air conditioner			×			×
CAN system type	1	2	3	4	5	6
CAN system trouble diagnosis	LAN-16	LAN-45	LAN-77	LAN-111	LAN-143	LAN-177

×: Applicable


NOTE:

Confirming the presence of the following items helps to identify CAN system type.

- Models with automatic drive positioner




- Models with 4WD



CAN COMMUNICATION


[CAN]

- Models with navigation system




TYPE 1/ TYPE 2 System diagram

- Type 1



- Type 2



CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Frontair control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R			R	R	
Engine status signal	T				R		R		
Engine coolant temperature signal	T			R			R		
A/T self-diagnosis signal	R	T							
Accelerator pedal position signal	T	R						R	
Closed throttle position signal	T	R							
Wide open throttle position signal	T	R							
Battery voltage signal	T	R							
Key switch signal			R		T				
Ignition switch signal			R		T				
P range signal		T	R	R					
Stop lamp switch signal		R		T	R				
Turbine revolution signal	R	T							
Output shaft revolution signal	R	T							
A/C switch signal	R				T		R		
A/C compressor request signal	T								R
Blower fan motor switch signal	R				T		R		
Cooling fan speed request signal	T						R		R
Position light request signal				R	T				R
Low beam request signal					T				R
Low beam status signal	R								T
High beam request signal				R	T				R
High beam status signal	R								T
Front fog light request signal					T				R
Day time running light request signal				R	T				
Vehicle speed signal	R	R	R	T	R		R	T	
Sleep wake up signal			R	R	T				R
Door switch signal			R	R	T				R
Turn indicator signal				R	T				
Key fob ID signal			R		T				
Key fob door unlock signal			R		T				
Buzzer output signal				R	T				
Fuel level sensor signal	R			T					
ASCD SET lamp signal	T			R					
ASCD CRUISE lamp signal	T			R					
Malfunction indicator lamp signal	T			R					
ASCD operation signal	T	R							
ASCD OD cancel request	T	R							

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Front wiper request signal					T				R
Front wiper stop position signal					R				T
Rear window defogger switch signal					T		R		R
Rear window defogger control signal	R								T
Theft warning horn request signal					T				R
Horn chirp signal					T				R
Steering angle sensor signal						T		R	
ABS warning lamp signal				R				T	
VDC OFF indicator lamp signal				R				T	
SLIP indicator lamp signal				R				T	
Brake warning lamp signal				R				T	
A/T CHECK indicator lamp signal		T		R					
System setting signal			T		R				
			R		T				
A/T position indicator lamp signal		T		R					
1st position switch signal		R		T					
4th position switch signal		R		T					
Tow mode switch signal		R		T					
A/T fluid temperature sensor signal		T		R					

TYPE 3

System diagram

- Type 3



CAN COMMUNICATION

[CAN]

Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R			R	R	
Engine status signal	T					R		R		
Engine coolant temperature signal	T			R				R		
A/T self-diagnosis signal	R	T								
Accelerator pedal position signal	T	R							R	
Closed throttle position signal	T	R								
Wide open throttle position signal	T	R								
Battery voltage signal	T	R								
Key switch signal			R			T				
Ignition switch signal			R			T				
P range signal		T	R	R						
Stop lamp switch signal		R		T		R				
Fuel consumption monitor signal	T			R						
				T	R					
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T								
A/C switch signal	R					T				
A/C compressor request signal	T									R
Blower fan motor switch signal	R					T		R		
A/C switch/indicator signal					T			R		
					R			T		
Cooling fan speed request signal	T							R		R
Position light request signal				R		T				R
Low beam request signal						T				R
Low beam status signal	R									T
High beam request signal				R		T				R
High beam status signal	R									T
Front fog light request signal						T				R
Day time running light request signal				R		T				
Vehicle speed signal				R				R	T	
	R	R	R	T	R	R		R		
Sleep wake up signal			R	R		T				R
Door switch signal			R	R	R	T				R
Turn indicator signal				R		T				
Key fob ID signal			R			T				
Key fob door unlock signal			R			T				
Buzzer output signal				R		T				
Fuel level sensor signal	R			T						

A
B
C
D
E
F
G
H
I
J
K
L
M

LAN

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	ABS actuator and electric unit (control unit)	IPDM E/R
Fuel level low warning signal				T	R					
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Front wiper request signal						T				R
Front wiper stop position signal						R				T
Rear window defogger switch signal						T		R		R
Rear window defogger control signal	R				R					T
Theft warning horn request signal						T				R
Horn chirp signal						T				R
Steering angle sensor signal							T		R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	
Brake warning lamp signal				R					T	
System setting signal			R		T	R				
			T		R	T				
Distance to empty signal				T	R					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R						
Tire pressure signal					R	T				
Tire pressure data signal					R	T				
1st position switch signal		R		T						
4th position switch signal		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						


TYPE 4/ TYPE 5

System diagram

- Type 4



- Type 5



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T								
Stop lamp switch signal		R		T	R					
Battery voltage signal	T	R								
Key switch signal			R		T					
Ignition switch signal			R		T					
P range signal		T	R	R						
Closed throttle position signal	T	R								

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Wide open throttle position signal	T	R								
Engine speed signal	T	R		R			R	R	R	
Engine status signal	T				R		R			
Engine coolant temperature signal	T			R			R			
Accelerator pedal position signal	T	R						R	R	
Turbine revolution signal	R	T								
Output shaft revolution signal	R	T						R		
A/C switch signal	R				T		R			
A/C compressor request signal	T									R
Blower fan motor switch signal	R				T		R			
Cooling fan speed request signal	T						R			R
Position light request signal				R	T					R
Low beam request signal					T					R
Low beam status signal	R									T
High beam request signal				R	T					R
High beam status signal	R									T
Front fog light request signal					T					R
Day time running light request signal				R	T					
Vehicle speed signal				R			R	R	T	
	R	R	R	T	R		R			
Sleep wake up signal			R	R	T					R
Door switch signal			R	R	T					R
Turn indicator signal				R	T					
Key fob ID signal			R		T					
Key fob door unlock signal			R		T					
Buzzer output signal				R	T					
Fuel level sensor signal	R			T						
ASCD SET lamp signal	T			R						
ASCD CRUISE lamp signal	T			R						
Malfunction indicator lamp signal	T			R						
Front wiper request signal					T					R
Front wiper stop position signal					R					T
Rear window defogger switch signal					T		R			R
Rear window defogger control signal	R									T
Theft warning horn request signal					T					R
Horn chirp signal					T					R
Steering angle sensor signal						T			R	
ABS warning lamp signal				R					T	
VDC OFF indicator lamp signal				R					T	
SLIP indicator lamp signal				R					T	

CAN COMMUNICATION


[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Brake warning lamp signal				R					T	
System setting signal			R		R					
			T		T					
ASCD operation signal	T	R								
ASCD OD cancel request	T	R								
A/T CHECK indicator lamp signal		T		R						
A/T position indicator lamp signal		T		R				R		
1st position switch signal		R		T						
4th position switch signal		R		T						
Tow mode switch signal		R		T						
A/T fluid temperature sensor signal		T		R						

TYPE 6

System diagram

- Type 6



Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
A/T self-diagnosis signal	R	T									
Stop lamp switch signal		R		T		R					
Battery voltage signal	T	R									

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Key switch signal			R			T					
Ignition switch signal			R			T					
P range signal		T	R	R							
Closed throttle position signal	T	R									
Wide open throttle position signal	T	R									
Engine speed signal	T	R		R	R			R	R	R	
Engine status signal	T					R					
Engine coolant temperature signal	T			R				R			
Accelerator pedal position signal	T	R							R	R	
Fuel consumption monitor signal	T			R							
				T	R						
Turbine revolution signal	R	T									
Output shaft revolution signal	R	T							R		
A/C switch signal	R					T					
A/C compressor request signal	T							R			R
Blower fan motor switch signal	R					T		R			
A/C switch/indicator signal					T			R			
					R			T			
Cooling fan speed request signal	T						R				R
Position light request signal				R		T					R
Low beam request signal						T					R
Low beam status signal	R										T
High beam request signal				R		T					R
High beam status signal	R										T
Front fog light request signal						T					R
Day time running light request signal				R		T					
Vehicle speed signal				R				R	R	T	
	R	R	R	T	R	R		R			
Sleep wake up signal			R	R		T					R
Door switch signal			R	R	R	T					R
Key fob ID signal			R			T					
Key fob door unlock signal			R			T					
Buzzer output signal				R		T					
Fuel level sensor signal	R			T							
ASCD SET lamp signal	T			R							
ASCD CRUISE lamp signal	T			R							
Malfunction indicator lamp signal	T			R							
Fuel level low warning signal				T	R						

CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Driver seat control unit	Combination meter	Display control unit	BCM	Steering angle sensor	Front air control	Transfer control unit	ABS actuator and electric unit (control unit)	IPDM E/R
Front wiper request signal						T					R
Front wiper stop position signal						R					T
Rear window defogger switch signal						T		R			R
Rear window defogger control signal	R				R						T
Theft warning horn request signal						T					R
Horn chirp signal						T					R
Steering angle sensor signal							T			R	
ABS warning lamp signal				R						T	
VDC OFF indicator lamp signal				R						T	
SLIP indicator lamp signal				R						T	
Brake warning lamp signal				R						T	
System setting signal			R		T	R					
			T		R	T					
Distance to empty signal				T	R						
ASCD operation signal	T	R									
ASCD OD cancel request	T	R									
A/T CHECK indicator lamp signal		T		R							
A/T position indicator lamp signal		T		R					R		
Tire pressure signal					R	T					
Tire pressure data signal					R	T					
1st position switch signal		R		T							
4th position switch signal		R		T							
Tow mode switch signal		R		T							
A/T fluid temperature sensor signal		T		R							

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


System Description

EKS00LEZ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LF0




BKIA0122E

CAN SYSTEM (TYPE 1)

[CAN]

EKS00LF1

Schematic



A
B
C
D
E
F
G
H
I
J
LAN
L
M

BKWA0184E

CAN SYSTEM (TYPE 1)


[CAN]

EKS00LF2


Wiring Diagram - CAN -

LAN-CAN-01

— : DATA LINE



NEXT PAGE



REFER TO THE FOLLOWING.



(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0407E

CAN SYSTEM (TYPE 1)

[CAN]




LAN-CAN-02



BKWA0408E

LAN-CAN-03

▬ : DATA LINE



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0409E

Work Flow

- When there are no indications of "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN CONSULT-II	➔	SELECT SYSTEM
ENGINE		ENGINE
START (NISSAN BASED VHCL)		A/T
START (RENAULT BASED VHCL)		ABS
SUB MODE		AIR BAG
LIGHT COPY		BCM
		METER A/C AMP
		BACK LIGHT COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	➔	SELF-DIAG RESULTS
WORK SUPPORT		DTC RESULTS TIME
SELF-DIAG RESULTS		CAN COMM CIRCUIT (U1000) 0
DATA MONITOR		
DATA MONITOR (SPEC)		
CAN DIAG SUPPORT MNTR		
ACTIVE TEST		
Scroll Down		F.F.DATA
BACK LIGHT COPY		ERASE PRINT
		MODE BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	➔	CAN DIAG SUPPORT MNTR
WORK SUPPORT		ENGINE
SELF-DIAG RESULTS		PRSRNT
DATA MONITOR		INITIAL DIAG OK
DATA MONITOR (SPEC)		TRANSMIT DIAG OK
CAN DIAG SUPPORT MNTR		TCM OK
ACTIVE TEST		VDC/TCS/ABS OK
Scroll Down		METER/M&A OK
BACK LIGHT COPY		ICC UNKWN
		BCM/SEC OK
		IPDM E/R OK
		AWD/4WD/e4WD UNKWN
		PRINT Scroll Down
		MODE BACK LIGHT COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-22, "CHECK SHEET"](#) .

- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-22, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-24, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 1)

[CAN]

A
B
C
D
E
F
G
H
I
J
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
HVAC
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
HVAC
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

LAN

PKIB6628E

CAN SYSTEM (TYPE 1)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-36, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

PKIB6643E



PKIA9251E

CAN SYSTEM (TYPE 1)


[CAN]

Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-37, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6644E



PKIA9252E

CAN SYSTEM (TYPE 1)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-38, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	UNKW ^N	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	—
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	UNKW ^N
HVAC	No indication	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	UNKW ^N	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—	—	—

PKIB6645E



PKIA9253E

CAN SYSTEM (TYPE 1)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-39, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB664E



PKIA9254E

CAN SYSTEM (TYPE 1)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-39, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6647E



PKIA9255E

CAN SYSTEM (TYPE 1)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-40, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6648E



PKIA9256E

A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 1)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-40, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6649E



PKIA9257E

CAN SYSTEM (TYPE 1)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-41, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6651E



CAN SYSTEM (TYPE 1)


[CAN]

Case 9

Check front air control circuit. Refer to [LAN-41, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6650E



SKIB3450E

CAN SYSTEM (TYPE 1)


[CAN]

Case 10

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-42, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	✓	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6652E



CAN SYSTEM (TYPE 1)


[CAN]

Case 11

Check IPDM E/R circuit. Refer to [LAN-42, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6653E



PKIA9260E

CAN SYSTEM (TYPE 1)

[CAN]

Case 12

Check CAN communication circuit. Refer to [LAN-43, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—

PKIB6654E

Case 13

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-44, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—

PKIB6655E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-44, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	✓	—	✓	—	—	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	✓	UNKWN	—	—	✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

PKIB6656E

Circuit Check Between TCM and Data Link Connector

EKS00LF4

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

3 (L) - 12 (L) : Continuity should exist.
8 (P) - 11 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and harness connector B69 terminals 51J (L), 52J (P).

24 (L) - 51J (L) : Continuity should exist.
23 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness.




5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.
52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-21, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00LF5

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

A
B
C
D
E
F
G
H
I
J
L
M

LAN

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-21, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

EKS00LF6


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



EKS00LF7

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



EKS00LF8

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



EKS00LF9

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



EKS00LFA

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-21, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

EKS00LFD

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E125.



IPDM E/R Circuit Check

EKS00LFE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



EKS00LFF

CAN Communication Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



PKIA2077E

3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-44, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

NG >> Repair harness.



EKS00LFG

IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .


Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

EKS00LFH

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 2)

PFP:23710


System Description

EKS00LFI

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LFJ



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 2)

[CAN]

Schematic

EKS00LFX



BKWA0186E

CAN SYSTEM (TYPE 2)


[CAN]

Wiring Diagram - CAN -



EKS00LFL

LAN-CAN-04


— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M40) - SUPER MULTIPLE JUNCTION (SMJ)









*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0683E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-05






BKWA0411E

CAN SYSTEM (TYPE 2)

[CAN]

LAN-CAN-06

■ ■ ■ : DATA LINE




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0412E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-51, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-51, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- According to the check sheet results (example), start inspection. Refer to [LAN-53, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

CAN SYSTEM (TYPE 2)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
HVAC
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
HVAC
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

PKIB6658E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-67, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3431E



CAN SYSTEM (TYPE 2)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-68, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

SKIB3432E



PKIA9262E

CAN SYSTEM (TYPE 2)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-69, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3433E



PKIA9263E

CAN SYSTEM (TYPE 2)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-70, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—

SKIB3434E



PKIA9264E

CAN SYSTEM (TYPE 2)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-70, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3435E



CAN SYSTEM (TYPE 2)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-71, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3436E



PKIA9266E

CAN SYSTEM (TYPE 2)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-71, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3437E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-72. "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	—	—	—

SKIB3438E



PKIA9268E

CAN SYSTEM (TYPE 2)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-72, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3439E



CAN SYSTEM (TYPE 2)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-73, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3440E



PKIA9270E

CAN SYSTEM (TYPE 2)


[CAN]

Case 11

Check front air control circuit. Refer to [LAN-73, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3441E



CAN SYSTEM (TYPE 2)


[CAN]

Case 12

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-74, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3442E



PKIA9271E

CAN SYSTEM (TYPE 2)


[CAN]

Case 13

Check IPDM E/R circuit. Refer to [LAN-74, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—

SKIB3443E



A
B
C
D
E
F
G
H
I
J
LAN
L
M

CAN SYSTEM (TYPE 2)

[CAN]

Case 14

Check CAN communication circuit. Refer to [LAN-75, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN ✓	-	UNKWN ✓	UNKWN ✓	UNKWN ✓	-	UNKWN ✓	UNKWN ✓
A/T	-	NG	UNKWN	UNKWN ✓	-	UNKWN ✓	-	-	UNKWN ✓	-
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	-	-	-
BCM	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
HVAC	No indication ✓	-	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-
ABS	-	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	-	-	UNKWN ✓	-	-
IPDM E/R	No indication ✓	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

SKIB3444E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-75, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN ✓	UNKWN	UNKWN	-	UNKWN ✓	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN ✓	UNKWN	UNKWN	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
HVAC	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN ✓	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	UNKWN	-	-	-

SKIB3445E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-75, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	METER /M&A	BCM/SEC	STRG	VDC/TCS /ABS	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW
A/T	—	NG	UNKW	✓	—	✓	—	—	UNKW	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	—
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	UNKW
HVAC	No indication	—	UNKW	UNKW	—	—	UNKW	—	UNKW	—
ABS	—	NG	UNKW	✓	UNKW	—	—	✓	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—

SKIB3446E

Circuit Check Between TCM and Driver Seat Control Unit

EKS00LFN

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


3 (L) - 12 (L) : Continuity should exist.

8 (P) - 11 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and driver seat control unit harness connector P2 terminals 3 (L), 19 (P).

24 (L) - 3 (L) : Continuity should exist.
23 (P) - 19 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-50, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

EKS00LFO

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and harness connector B69 terminals 51J (L), 52J (P).

3 (L) - 51J (L) : Continuity should exist.
19 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.

52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-50, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00LFP

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-50, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) - 19 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



BCM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-50, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.

**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

2. CHECK HARNESS FOR SHORT CIRCUIT


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.

**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-76, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .

NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 3)

PFP:23710


System Description

EKS00LG3

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LG4



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 3)

[CAN]

Schematic

EKS00LG5



BKWA0007E

CAN SYSTEM (TYPE 3)


[CAN]

Wiring Diagram - CAN -



EKS00LG6

LAN-CAN-07




— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M40) - SUPER MULTIPLE JUNCTION (SMJ)



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.



BKWA0684E

CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08

— — — — : DATA LINE




BKWA0414E

CAN SYSTEM (TYPE 3)



[CAN]

LAN-CAN-09

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M




REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)


BKWA0415E

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-84, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-84, "CHECK SHEET"](#) .

NOTE:

- If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.
- The "CAN DIAG SUPPORT MNTR" items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the "CAN DIAG SUPPORT MNTR" items not in check sheet table.

- Check CAN communication line of the navigation system. Refer to [AV-147, "CAN Communication Line Check"](#) .
- Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-84, "CHECK SHEET"](#) .

CAN SYSTEM (TYPE 3)

[CAN]

8. Mark the "NG" or "UNKWN" item of the check sheet table with "v" from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-84, "CHECK SHEET"](#) .

NOTE:

If "NG" is displayed on "CAN COMM" as "CAN DIAG SUPPORT MONITOR" for the diagnosed control unit, replace the control unit. Refer to [AV-147, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-86, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L

M

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

CAN SYSTEM (TYPE 3)

[CAN]

A
B
C
D
E
F
G
H
I
J
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
AUTO DRIVE POS.
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
HVAC
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
AUTO DRIVE POS.
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
HVAC
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

LAN

PKIB6658E

CAN SYSTEM (TYPE 3)

[CAN]

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-101, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6659E



CAN SYSTEM (TYPE 3)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-102, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	✓	—	—	—	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	—	✓	—
AUTO DRIVE POS.	✓ No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	✓ CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	—
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	UNKWN	—
HVAC	No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	UNKWN	—	—	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—

PKIB660E



CAN SYSTEM (TYPE 3)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-103, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6661E



PKIA9275E

CAN SYSTEM (TYPE 3)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-104, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	UNKW ^N	UNKW ^N
A/T	—	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	—	UNKW ^N	—
AUTO DRIVE POS.	No indication	NG	UNKW ^N	—	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW ^N	UNKW ^N	—	UNKW ^N	—	—	—	—	—	UNKW ^N
HVAC	No indication	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	UNKW ^N	—	—	UNKW ^N	—
ABS	—	NG	UNKW ^N	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—	—	—
IPDM E/R	No indication	—	UNKW ^N	UNKW ^N	—	—	—	UNKW ^N	—	—	—	—

PKIB6662E



CAN SYSTEM (TYPE 3)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-104, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UN KN WN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UN KN WN	—	UN KN WN	—	—	—	—	UN KN WN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UN KN WN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UN KN WN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6663E



CAN SYSTEM (TYPE 3)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-105, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	UNKW	UNKW
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	—	—	UNKW	—
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	—	UNKW
HVAC	No indication	—	UNKW	UNKW	—	—	UNKW	UNKW	—	—	UNKW	—
ABS	—	NG	UNKW	UNKW	UNKW	—	—	—	UNKW	—	—	—
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—

PKIB6664E



CAN SYSTEM (TYPE 3)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-105, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	✓	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	✓	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	✓	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6665E



CAN SYSTEM (TYPE 3)


[CAN]

Case 8

Check display control unit circuit. Refer to [LAN-106, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB666E



CAN SYSTEM (TYPE 3)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-106, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2 ✓	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—	—	—	

PKIB6667E



CAN SYSTEM (TYPE 3)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-107, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB668E



CAN SYSTEM (TYPE 3)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-107, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6669E



CAN SYSTEM (TYPE 3)


[CAN]

Case 12

Check front air control circuit. Refer to [LAN-108, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6670E



CAN SYSTEM (TYPE 3)


[CAN]

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-108, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—

PKIB6671E



CAN SYSTEM (TYPE 3)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-109, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN ✓	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	

PKIB6672E



CAN SYSTEM (TYPE 3)

[CAN]

Case 15

Check CAN communication circuit. Refer to [LAN-109, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW N ✓N	—	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	UNKW N ✓N	UNKW N ✓N	
A/T	—	NG	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	UNKW N ✓N	—	
AUTO DRIVE POS.	No indication	NG	UNKW N ✓N	—	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	—	UNKW N ✓N	
HVAC	No indication	—	UNKW N ✓N	UNKW N ✓N	—	—	UNKW N ✓N	UNKW N ✓N	—	—	UNKW N ✓N	—	
ABS	—	NG	UNKW N ✓N	UNKW N ✓N	UNKW N ✓N	—	—	—	UNKW N ✓N	—	—	—	
IPDM E/R	No indication	—	UNKW N ✓N	UNKW N ✓N	—	—	—	UNKW N ✓N	—	—	—	—	

PKIB6673E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-110, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW N ✓N	—	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	UNKW N ✓N	UNKW N ✓N	
A/T	—	NG	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	UNKW N ✓N	—	
AUTO DRIVE POS.	No indication	NG	UNKW N ✓N	—	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	CAN CIRC 7 ✓	
BCM	No indication	NG	UNKW N ✓N	UNKW N ✓N	—	UNKW N ✓N	—	—	—	—	—	UNKW N ✓N	
HVAC	No indication	—	UNKW N ✓N	UNKW N ✓N	—	—	UNKW N ✓N	UNKW N ✓N	—	—	UNKW N ✓N	—	
ABS	—	NG	UNKW N ✓N	UNKW N ✓N	UNKW N ✓N	—	—	—	UNKW N ✓N	—	—	—	
IPDM E/R	No indication	—	UNKW N ✓N	UNKW N ✓N	—	—	—	UNKW N ✓N	—	—	—	—	

PKIB6674E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-110, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									IPDM E/R
				ECM	TCM	METER /M&A	DISPLAY	BCM/SEC	STRG	Front air control	VDC/TCS /ABS		
ENGINE	—	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	UNKW	UNKW	
A/T	—	NG	UNKW	✓	—	✓	—	—	—	—	UNKW	—	
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	—	UNKW	—	—	—	—	
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	CAN CIRC 7	
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	—	UNKW	
HVAC	No indication	—	UNKW	UNKW	—	—	UNKW	UNKW	—	—	UNKW	—	
ABS	—	NG	UNKW	✓	UNKW	—	—	—	✓	—	—	—	
IPDM E/R	No indication	—	UNKW	UNKW	—	—	—	UNKW	—	—	—	—	

PKIB6675E

Circuit Check Between TCM and Driver Seat Control Unit

EKS00LG8

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).


3 (L) - 12 (L) : Continuity should exist.

8 (P) - 11 (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and driver seat control unit harness connector P2 terminals 3 (L), 19 (P).

24 (L) - 3 (L) : Continuity should exist.
23 (P) - 19 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-82, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

EKS00LG9

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and harness connector B69 terminals 51J (L), 52J (P).

3 (L) - 51J (L) : Continuity should exist.
19 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.

52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-82, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00LGA

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-82, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) - 19 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
NG >> Repair harness between display control unit and data link connector.



EKS00LGG

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-82, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-110, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 4)

PFP:23710


System Description

EKS00LGP

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LGO



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 4)

[CAN]

Schematic

EKS00LGR



BKWA0188E

CAN SYSTEM (TYPE 4)



[CAN]

Wiring Diagram - CAN -

EKS00LGS

LAN-CAN-10

— : DATA LINE



REFER TO THE FOLLOWING.







(M40) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0416E

CAN SYSTEM (TYPE 4)

[CAN]

LAN-CAN-11




BKWA0417E

CAN SYSTEM (TYPE 4)


[CAN]

LAN-CAN-12

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0418E

CAN SYSTEM (TYPE 4)

[CAN]

EKS00LGT

Work Flow

- When there are no indications of "BCM", "HVAC", "ALL MODE AWD/4WD" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".

(Example)

NISSAN	
CONSULT-II	
ENGINE	
START (NISSAN BASED VHCL)	
START (RENAULT BASED VHCL)	
SUB MODE	
	LIGHT COPY

➔

SELECT SYSTEM		
ENGINE		
A/T		
ABS		
AIR BAG		
BCM		
METER A/C AMP		
BACK	LIGHT	COPY

PKIA2093E

- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
BACK	LIGHT COPY

➔

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT (U1000)	0
F.F.DATA	
ERASE	PRINT
MODE	BACK LIGHT COPY

PKIA8260E

- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.

(Example)

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
DATA MONITOR (SPEC)	
CAN DIAG SUPPORT MNTR	
ACTIVE TEST	
Scroll Down	
BACK	LIGHT COPY

➔

CAN DIAG SUPPORT MNTR		
ENGINE		
	PRSNT	
INITIAL DIAG	OK	
TRANSMIT DIAG	OK	
TCM	OK	
VDC/TCS/ABS	OK	
METER/M&A	OK	
ICC	UNKWN	
BCM/SEC	OK	
IPDM E/R	OK	
AWD/4WD/e4WD	UNKWN	
PRINT		Scroll Down
MODE	BACK	LIGHT COPY

PKIA8343E

- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-118, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-118, "CHECK SHEET"](#) .

CAUTION:

"ALL MODE AWD/4WD" puts a check mark on the check sheet when "Present" is "UNKWN" and "Past" is "0".

(Example)

CAN DIAG SUPPORT MNTR		
ALL MODE AWD/4WD		
	PRSNT	PAST
TRANSMIT DIAG	OK	OK
ECM	UNKWN	0
VDC/TCS/ABS	UNKWN	39
TCM	UNKWN	0
STRG	OK	OK
PRINT		
MODE	BACK	LIGHT COPY

SKIB3244E

NOTE:

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 - The “CAN DIAG SUPPORT MNTR” items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
6. According to the check sheet results (example), start inspection. Refer to [LAN-120, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 4)

[CAN]

A
B
C
D
E
F
G
H
I
J
L
M

Attach copy of
ENGINE
SELF-DIAG RESULTS

Attach copy of
A/T
SELF-DIAG RESULTS

Attach copy of
BCM
SELF-DIAG RESULTS

Attach copy of
HVAC
SELF-DIAG RESULTS

Attach copy of
ALL MODE AWD/4WD
SELF-DIAG RESULTS

Attach copy of
ABS
SELF-DIAG RESULTS

Attach copy of
IPDM E/R
SELF-DIAG RESULTS

Attach copy of
ENGINE
CAN DIAG SUPPORT
MNTR

Attach copy of
A/T
CAN DIAG SUPPORT
MNTR

Attach copy of
BCM
CAN DIAG SUPPORT
MNTR

Attach copy of
HVAC
CAN DIAG SUPPORT
MNTR

Attach copy of
ALL MODE AWD/4WD
CAN DIAG SUPPORT
MNTR

Attach copy of
ABS
CAN DIAG SUPPORT
MNTR

Attach copy of
IPDM E/R
CAN DIAG SUPPORT
MNTR

LAN

PKIB6772E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and data link connector. Refer to [LAN-133, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	

SKIB3333E



CAN SYSTEM (TYPE 4)


[CAN]

Case 2

Check harness between data link connector and IPDM E/R. Refer to [LAN-134, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3334E



CAN SYSTEM (TYPE 4)


[CAN]

Case 3

Check ECM circuit. Refer to [LAN-135, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	UNKW [✓] N	
HVAC	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	UNKW [✓] N	—	
ALL MODE AWD/4WD	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	UNKW [✓] N	—	
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	—	
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—	

SKIB3335E



CAN SYSTEM (TYPE 4)


[CAN]

Case 4

Check TCM circuit. Refer to [LAN-136, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3336E



CAN SYSTEM (TYPE 4)


[CAN]

Case 5

Check combination meter circuit. Refer to [LAN-136, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3337E



CAN SYSTEM (TYPE 4)


[CAN]

Case 6

Check BCM circuit. Refer to [LAN-137, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3338E



CAN SYSTEM (TYPE 4)


[CAN]

Case 7

Check data link connector circuit. Refer to [LAN-137, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3339E



CAN SYSTEM (TYPE 4)


[CAN]

Case 8

Check steering angle sensor circuit. Refer to [LAN-138. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3340E



CAN SYSTEM (TYPE 4)


[CAN]

Case 9

Check front air control circuit. Refer to [LAN-138, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3425E



CAN SYSTEM (TYPE 4)


[CAN]

Case 10

Check transfer control unit circuit. Refer to [LAN-139, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3341E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)


[CAN]

Case 11

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-139, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3342E



CAN SYSTEM (TYPE 4)


[CAN]

Case 12

Check IPDM E/R circuit. Refer to [LAN-140, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

SKIB3343E



A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 4)

[CAN]

Case 13

Check CAN communication circuit. Refer to [LAN-141, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

SKIB3344E

Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-141, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

SKIB3345E

Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-141, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3346E

Circuit Check Between TCM and Data Link Connector

EKS00LGU

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

3 (L) - 12 (L) : Continuity should exist.
8 (P) - 11 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector B69.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and harness connector B69 terminals 51J (L), 52J (P).

24 (L) - 51J (L) : Continuity should exist.
23 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 5.
 NG >> Repair harness.




5. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.
52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-116, "Work Flow"](#).
 NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00LGV

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).


6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).


31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-116, "Work Flow"](#).

NG >> Repair harness.



ECM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.



EKS00LGX

TCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



EKS00LGY

Combination Meter Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



EKS00LGZ

BCM Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



EKS00LH0

Data Link Connector Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-116, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



EKS00LH1

Steering Angle Sensor Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



EKS00LH2

Front Air Control Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



EKS00LH3

Transfer Control Unit Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (L) and 8 (P).

7 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



EKS00LH4

ABS Actuator and Electric Unit (Control Unit) Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.
14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-142, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
 NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection

ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 5)

PFP:23710


System Description

EKS00LH9

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LHA



BKIA0126E

A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 5)

[CAN]

Schematic

EKS00LHB



BKWA0190E

CAN SYSTEM (TYPE 5)


[CAN]

Wiring Diagram - CAN -


EKS00LHC

LAN-CAN-13


— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



E16
B




E34
W


REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE
 JUNCTION (SMJ)




F9
G



F33
W



B37
W



P2
W*







*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0685E

CAN SYSTEM (TYPE 5)

[CAN]

LAN-CAN-14




BKWA0420E


CAN SYSTEM (TYPE 5)

[CAN]

LAN-CAN-15



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
(M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0421E


CAN SYSTEM (TYPE 5)

[CAN]


EKS00LHD

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.




- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-150, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-150, "CHECK SHEET"](#) .

CAUTION:

"ALL MODE AWD/4WD" puts a check mark on the check sheet when "Present" is "UNKWN" and "Past" is "0".



NOTE:

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
 - The “CAN DIAG SUPPORT MNTR” items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
6. According to the check sheet results (example), start inspection. Refer to [LAN-152, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 5)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of HVAC SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of HVAC CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6773E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-167, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	—	—	—	—	

SKIB3348E



CAN SYSTEM (TYPE 5)


[CAN]

Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-168, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW	—	UNKW	UNKW	UNKW	—	UNKW	UNKW	UNKW	
A/T	—	NG	UNKW	UNKW	—	UNKW	—	—	UNKW	UNKW	—	
AUTO DRIVE POS.	No indication	NG	UNKW	—	UNKW	UNKW	UNKW	—	—	—	—	
BCM	No indication	NG	UNKW	UNKW	—	UNKW	—	—	—	—	UNKW	
HVAC	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	UNKW	—	
ALL MODE AWD/4WD	No indication	—	UNKW	UNKW	UNKW	—	—	UNKW	—	UNKW	—	
ABS	—	NG	UNKW	UNKW	UNKW	—	—	UNKW	UNKW	—	—	
IPDM E/R	No indication	—	UNKW	UNKW	—	—	UNKW	—	—	—	—	

SKIB3349E



PKIA9299E

CAN SYSTEM (TYPE 5)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-169, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

SKIB3350E



CAN SYSTEM (TYPE 5)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-170, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	
A/T	—	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	
AUTO DRIVE POS.	No indication	NG	UNKW [✓] N	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	—	—	
BCM	No indication	NG	UNKW [✓] N	UNKW [✓] N	—	UNKW [✓] N	—	—	—	—	UNKW [✓] N	
HVAC	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	UNKW [✓] N	—	
ALL MODE AWD/4WD	No indication	—	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	UNKW [✓] N	—	
ABS	—	NG	UNKW [✓] N	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	UNKW [✓] N	—	—	
IPDM E/R	No indication	—	UNKW [✓] N	UNKW [✓] N	—	—	UNKW [✓] N	—	—	—	—	

SKIB3351E



CAN SYSTEM (TYPE 5)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-170, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3352E



PKIA9302E

CAN SYSTEM (TYPE 5)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-171, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3353E



CAN SYSTEM (TYPE 5)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-171, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3354E



PKIA9304E

CAN SYSTEM (TYPE 5)


[CAN]

Case 8

Check BCM circuit. Refer to [LAN-172, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3355E



CAN SYSTEM (TYPE 5)


[CAN]

Case 9

Check data link connector circuit. Refer to [LAN-172, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3356E



PKIA9306E

CAN SYSTEM (TYPE 5)


[CAN]

Case 10

Check steering angle sensor circuit. Refer to [LAN-173. "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3357E



CAN SYSTEM (TYPE 5)


[CAN]

Case 11

Check front air control circuit. Refer to [LAN-173, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3426E



SKIB3449E

CAN SYSTEM (TYPE 5)


[CAN]

Case 12

Check transfer control unit circuit. Refer to [LAN-174, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3358E



CAN SYSTEM (TYPE 5)


[CAN]

Case 13

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-174, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3359E



CAN SYSTEM (TYPE 5)


[CAN]

Case 14

Check IPDM E/R circuit. Refer to [LAN-175, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—

SKIB3360E



CAN SYSTEM (TYPE 5)

[CAN]

Case 15

Check CAN communication circuit. Refer to [LAN-175, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

SKIB3361E

Case 16

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-176, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	UNKW N	—	—	—	—
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	UNKW N	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	UNKW N	—	—	—	—

SKIB3362E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-176, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	METER/M&A	BCM/SEC	STRG	AWD/4WD/e4WD	VDC/TCS/ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN	—	
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	UNKWN	—	
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	UNKWN ✓	UNKWN ✓	—	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—	

SKIB3363E

Circuit Check Between TCM and Driver Seat Control Unit

EKS00LHE

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

3 (L) - 12 (L) : Continuity should exist.
8 (P) - 11 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and driver seat control unit harness connector P2 terminals 3 (L), 19 (P).

24 (L) - 3 (L) : Continuity should exist.
23 (P) - 19 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-148, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

EKS00LHF

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and harness connector B69 terminals 51J (L), 52J (P).

3 (L) - 51J (L) : Continuity should exist.
19 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.

52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-148, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00LHG

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-148, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) - 19 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



BCM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-148, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.



Steering Angle Sensor Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.

**Front Air Control Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.



Transfer Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (L) and 8 (P).

7 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.



IPDM E/R Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-176, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
- NG >> Repair harness.



IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	



CAN SYSTEM (TYPE 6)

PFP:23710


System Description

EKS00LHV

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Component Parts and Harness Connector Location

EKS00LHV



A
B
C
D
E
F
G
H
I
J
L
M


LAN

CAN SYSTEM (TYPE 6)

[CAN]

Schematic

EKS00LHX



BKWA0001E

CAN SYSTEM (TYPE 6)


[CAN]

Wiring Diagram - CAN -



EKS00LHY

LAN-CAN-16





— : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE
 JUNCTION (SMJ)





*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0686E

LAN-CAN-17

— : DATA LINE




BKWA0423E

CAN SYSTEM (TYPE 6)




[CAN]

LAN-CAN-18

▬ : DATA LINE



A
B
C
D
E
F
G
H
I
J
LAN
L
M



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0424E


CAN SYSTEM (TYPE 6)

[CAN]


EKS00LHZ

Work Flow


- When there are no indications of "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.




- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "A/T", "AUTO DRIVE POS.", "BCM", "HVAC", "ALL MODE AWD/4WD", "ABS" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-184, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", puts a check mark onto the items with "No indication", "NG", or "UNKWN" in the check sheet table. Refer to [LAN-184, "CHECK SHEET"](#) .

CAUTION:

"ALL MODE AWD/4WD" puts a check mark on the check sheet when "Present" is "UNKWN" and "Past" is "0".



NOTE:

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
- The “CAN DIAG SUPPORT MNTR” items, which are not in check sheet table, are not related to diagnostic procedure on service manual.
So it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.

6. Check CAN communication line of the navigation system. Refer to [AV-147, "CAN Communication Line Check"](#) .
7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-184, "CHECK SHEET"](#) .
8. Mark the “NG” or “UNKWN” item of the check sheet table with “v” from the result of CAN DIAG SUPPORT MONITOR check sheet. Refer to [LAN-184, "CHECK SHEET"](#) .

NOTE:

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MONITOR” for the diagnosed control unit, replace the control unit. Refer to [AV-147, "CAN Communication Line Check"](#) .

9. According to the check sheet results (example), start inspection. Refer to [LAN-186, "CHECK SHEET RESULTS \(EXAMPLE\)"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

LAN

CAN SYSTEM (TYPE 6)

[CAN]

CHECK SHEET

NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	-	UNKWN	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	CAN CIRC 5	-	CAN CIRC 2	-	CAN CIRC 4	-	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	-	-	-	UNKWN
HVAC	No indication	-	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-	UNKWN	-
ALL MODE AWD/4WD	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-	-

Symptoms :

Attach copy of
SELECT SYSTEM

Attach copy of
SELECT SYSTEM

Attach copy of
display control unit
CAN DIAG SUPPORT MONITOR check sheet

SKIB3364E

CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS
Attach copy of HVAC SELF-DIAG RESULTS	Attach copy of ALL MODE AWD/4WD SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR
Attach copy of HVAC CAN DIAG SUPPORT MNTR	Attach copy of ALL MODE AWD/4WD CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

A
B
C
D
E
F
G
H
I
J
L
M

LAN

PKIB6773E

CHECK SHEET RESULTS (EXAMPLE)

NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" for the diagnosed control unit, replace the control unit.

Case 1

Check harness between TCM and driver seat control unit. Refer to [LAN-202, "Circuit Check Between TCM and Driver Seat Control Unit"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	✓	—	✓	—	—	—	✓	✓	✓
A/T	—	NG	UNKWN	UNKWN	—	✓	—	—	—	—	—	✓	✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	✓	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	✓	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	✓	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	✓	✓	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	✓	✓	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	✓	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3365E




Case 2

Check harness between driver seat control unit and data link connector. Refer to [LAN-203, "Circuit Check Between Driver Seat Control Unit and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	UNKWN ✓	UNKWN ✓	—
AUTO DRIVE POS.	No indication ✓	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	—	—

SKIB3366E



CAN SYSTEM (TYPE 6)


[CAN]

Case 3

Check harness between data link connector and IPDM E/R. Refer to [LAN-204, "Circuit Check Between Data Link Connector and IPDM E/R"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3367E



PKIA9313E

CAN SYSTEM (TYPE 6)


[CAN]

Case 4

Check ECM circuit. Refer to [LAN-205, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—	UNKWN ✓	UNKWN ✓	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	—	—	UNKWN	—	—	—	—	—

SKIB3368E



PKIA9314E

CAN SYSTEM (TYPE 6)


[CAN]

Case 5

Check TCM circuit. Refer to [LAN-205, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3369E



PKIA9315E

CAN SYSTEM (TYPE 6)


[CAN]

Case 6

Check driver seat control unit circuit. Refer to [LAN-206, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3370E



CAN SYSTEM (TYPE 6)


[CAN]

Case 7

Check combination meter circuit. Refer to [LAN-206, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5 ✓	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3371E




PKIA9317E

Case 8

Check display control unit circuit. Refer to [LAN-207, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1 ✓	CAN CIRC 3 ✓	—	CAN CIRC 5 ✓	—	CAN CIRC 2 ✓	—	CAN CIRC 4 ✓	—	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN ✓	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3372E



CAN SYSTEM (TYPE 6)


[CAN]

Case 9

Check BCM circuit. Refer to [LAN-207, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3373E



CAN SYSTEM (TYPE 6)


[CAN]

Case 10

Check data link connector circuit. Refer to [LAN-208, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	—

SKIB3374E



PKIA9320E

CAN SYSTEM (TYPE 6)


[CAN]

Case 11

Check steering angle sensor circuit. Refer to [LAN-208, "Steering Angle Sensor Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN ✓	—	UNKWN	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3375E



PKIA9321E

CAN SYSTEM (TYPE 6)


[CAN]

Case 12

Check front air control circuit. Refer to [LAN-209, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3429E



CAN SYSTEM (TYPE 6)


[CAN]

Case 13

Check transfer control unit circuit. Refer to [LAN-209, "Transfer Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3376E




PKIA9323E

Case 14

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-210, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN ✓	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN ✓	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN ✓	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN ✓	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	UNKWN ✓	—	UNKWN ✓	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3377E



CAN SYSTEM (TYPE 6)


[CAN]

Case 15

Check IPDM E/R circuit. Refer to [LAN-210, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	UNKWN	UNKWN	UNKWN ✓
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	UNKWN ✓
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—

SKIB3378E



PKIA9325E

CAN SYSTEM (TYPE 6)

[CAN]

Case 16

Check CAN communication circuit. Refer to [LAN-211, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	—

SKIB3379E

Case 17

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-211, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR											
		Initial diagnosis	Transmit diagnosis	Receive diagnosis									
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R
ENGINE	—	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	UNKW N	UNKW N	UNKW N
A/T	—	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	UNKW N	UNKW N	—
AUTO DRIVE POS.	No indication	NG	UNKW N	—	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	CAN CIRC 7
BCM	No indication	NG	UNKW N	UNKW N	—	UNKW N	—	—	—	—	—	—	UNKW N
HVAC	No indication	—	UNKW N	UNKW N	—	—	UNKW N	UNKW N	—	—	—	UNKW N	—
ALL MODE AWD/4WD	No indication	—	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	—	UNKW N	—
ABS	—	NG	UNKW N	UNKW N	UNKW N	—	—	—	UNKW N	—	UNKW N	—	—
IPDM E/R	No indication	—	UNKW N	UNKW N	—	—	—	UNKW N	—	—	—	—	—

SKIB3380E

Case 18

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-211, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR												
		Initial diagnosis	Transmit diagnosis	Receive diagnosis										
				ECM	TCM	METER /M&A	DISPLAY	BCM /SEC	STRG	Front air control	AWD/4WD /e4WD	VDC/TCS /ABS	IPDM E/R	
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	UNKWN	UNKWN	UNKWN
A/T	—	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	UNKWN	UNKWN	—
AUTO DRIVE POS.	No indication	NG	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—
Display control unit	—	CAN COMM	CAN CIRC 1	CAN CIRC 3	—	CAN CIRC 5	—	CAN CIRC 2	—	CAN CIRC 4	—	—	—	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—	—	—	UNKWN
HVAC	No indication	—	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—
ALL MODE AWD/4WD	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	UNKWN	—	UNKWN	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—	—	—	—

SKIB3381E

Circuit Check Between TCM and Driver Seat Control Unit

EKS00L10

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F33
 - Harness connector E19
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector and harness connector F33.
2. Check continuity between A/T assembly harness connector F9 terminals 3 (L), 8 (P) and harness connector F33 terminals 12 (L), 11 (P).

3 (L) - 12 (L) : Continuity should exist.
8 (P) - 11 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.




3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector E34.
2. Check continuity between harness connector E19 terminals 12 (L), 11 (P) and harness connector E34 terminals 24 (L), 23 (P).

12 (L) - 24 (L) : Continuity should exist.
11 (P) - 23 (P) : Continuity should exist.

OK or NG

- OK >> GO TO 4.
 NG >> Repair harness.




4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check continuity between harness connector B40 terminals 24 (L), 23 (P) and driver seat control unit harness connector P2 terminals 3 (L), 19 (P).

24 (L) - 3 (L) : Continuity should exist.
23 (P) - 19 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-182, "Work Flow"](#) .
 NG >> Repair harness.



Circuit Check Between Driver Seat Control Unit and Data Link Connector

EKS00L11

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector and harness connector B69.
2. Check continuity between driver seat control unit harness connector P2 terminals 3 (L), 19 (P) and harness connector B69 terminals 51J (L), 52J (P).

3 (L) - 51J (L) : Continuity should exist.
19 (P) - 52J (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.



A
B
C
D
E
F
G
H
I
J

LAN

3. CHECK HARNESS FOR OPEN CIRCUIT


Check continuity between harness connector M40 terminals 51J (L), 52J (P) and data link connector M22 terminals 6 (L), 14 (P).

51J (L) - 6 (L) : Continuity should exist.

52J (P) - 14 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-182, "Work Flow"](#).
- NG >> Repair harness.



Circuit Check Between Data Link Connector and IPDM E/R

EKS00L12

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect harness connector M31.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M31 terminals 31G (L), 42G (P).

6 (L) - 31G (L) : Continuity should exist.

14 (P) - 42G (P) : Continuity should exist.

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness.



3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector E152 terminals 31G (L), 42G (P) and IPDM E/R harness connector E122 terminals 39 (L), 40 (P).

31G (L) - 39 (L) : Continuity should exist.

42G (P) - 40 (P) : Continuity should exist.

OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-182, "Work Flow"](#).
- NG >> Repair harness.



ECM Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
 - ECM connector
 - Harness connector E19
 - Harness connector F33

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector E16 terminals 94 (L) and 86 (P).

94 (L) - 86 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace ECM.
 NG >> Repair harness between ECM and A/T assembly.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of A/T assembly for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect A/T assembly connector.
2. Check resistance between A/T assembly harness connector F9 terminals 3 (L) and 8 (P).

3 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace A/T assembly.
 NG >> Repair harness between A/T assembly and harness connector F33.



Driver Seat Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of driver seat control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect driver seat control unit connector.
2. Check resistance between driver seat control unit harness connector P2 terminals 3 (L) and 19 (P).

3 (L) - 19 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace driver seat control unit.
 NG >> Repair harness between driver seat control unit and harness connector B40.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 11 (L) and 12 (P).

11 (L) - 12 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace combination meter.
 NG >> Repair harness between combination meter and data link connector.



Display Control Unit Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

25 (L) - 26 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace display control unit.
 NG >> Repair harness between display control unit and data link connector.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .
 NG >> Repair harness between BCM and data link connector.



Data Link Connector Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check the terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Diagnose again. Refer to [LAN-182, "Work Flow"](#) .
 NG >> Repair harness between data link connector and combination meter.

**Steering Angle Sensor Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of steering angle sensor for damage, bend and loose connection (sensor side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect steering angle sensor connector.
2. Check resistance between steering angle sensor harness connector M47 terminals 3 (L) and 4 (P).

3 (L) - 4 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace steering angle sensor.
 NG >> Repair harness between steering angle sensor and data link connector.



Front Air Control Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of front air control for damage, bend and loose connection (unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect front air control connector.
2. Check resistance between front air control harness connector M50 terminals 34 (L) and 35 (P).

34 (L) - 35 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace front air control.
 NG >> Repair harness between front air control and data link connector.

**Transfer Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of transfer control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect transfer control unit connector.
2. Check resistance between transfer control unit harness connector E142 terminals 7 (L) and 8 (P).

7 (L) - 8 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace transfer control unit.
 NG >> Repair harness between transfer control unit and harness connector E152.



ABS Actuator and Electric Unit (Control Unit) Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 11 (L) and 15 (P).

11 (L) - 15 (P) : Approx. 54 - 66 Ω

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).
 NG >> Repair harness between ABS actuator and electric unit (control unit) and harness connector E152.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.
 NG >> Repair terminal or connector.


2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E122 terminals 39 (L) and 40 (P).

39 (L) - 40 (P) : Approx. 108 - 132 Ω

OK or NG

- OK >> Replace IPDM E/R.
 NG >> Repair harness between IPDM E/R and harness connector E152.



CAN Communication Circuit Check**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
 - ECM
 - A/T assembly
 - Driver seat control unit
 - Combination meter
 - Display control unit
 - BCM
 - Steering angle sensor
 - Front air control
 - Transfer control unit
 - ABS actuator and electric unit (control unit)
 - IPDM E/R

OK or NG

- OK >> GO TO 2.
 NG >> Repair or replace as necessary.


2. CHECK HARNESS FOR SHORT CIRCUIT

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

6 (L) - 14 (P) : Continuity should not exist.

OK or NG

- OK >> GO TO 3.
 NG >> Repair harness.

**3. CHECK HARNESS FOR SHORT CIRCUIT**


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

6 (L) - Ground : Continuity should not exist.

14 (P) - Ground : Continuity should not exist.

OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-212, "ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION"](#) .
 NG >> Repair harness.

**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-26, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-13, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

Component Inspection**ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Remove ECM and IPDM E/R from vehicle.
- Check resistance between ECM terminals 94 and 86.
- Check resistance between IPDM E/R terminals 39 and 40.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	39 - 40	

