

MWI

SECTION

METER, WARNING LAMP & INDICATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

CONTENTS

<p>BASIC INSPECTION 4</p> <p>DIAGNOSIS AND REPAIR WORKFLOW 4</p> <p style="padding-left: 20px;">Work flow4</p> <p>FUNCTION DIAGNOSIS 5</p> <p>METER SYSTEM 5</p> <p>METER SYSTEM5</p> <p style="padding-left: 20px;">METER SYSTEM : System Diagram5</p> <p style="padding-left: 20px;">METER SYSTEM : System Description5</p> <p style="padding-left: 20px;">METER SYSTEM : Component Parts Location9</p> <p style="padding-left: 20px;">METER SYSTEM : Component Description9</p> <p>SPEEDOMETER 10</p> <p style="padding-left: 20px;">SPEEDOMETER : System Diagram 10</p> <p style="padding-left: 20px;">SPEEDOMETER : System Description 10</p> <p style="padding-left: 20px;">SPEEDOMETER : Component Parts Location 11</p> <p style="padding-left: 20px;">SPEEDOMETER : Component Description 11</p> <p>TACHOMETER 12</p> <p style="padding-left: 20px;">TACHOMETER : System Diagram 12</p> <p style="padding-left: 20px;">TACHOMETER : System Description 12</p> <p style="padding-left: 20px;">TACHOMETER : Component Parts Location 13</p> <p style="padding-left: 20px;">TACHOMETER : Component Description 13</p> <p>ENGINE COOLANT TEMPERATURE GAUGE 14</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : System Diagram 14</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : System Description 14</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location 15</p> <p style="padding-left: 20px;">ENGINE COOLANT TEMPERATURE GAUGE : Component Description 15</p> <p>FUEL GAUGE 16</p> <p style="padding-left: 20px;">FUEL GAUGE : System Diagram 16</p> <p style="padding-left: 20px;">FUEL GAUGE : System Description 16</p> <p style="padding-left: 20px;">FUEL GAUGE : Component Parts Location 17</p> <p style="padding-left: 20px;">FUEL GAUGE : Component Description 17</p>	<p>ODO/TRIP METER18</p> <p style="padding-left: 20px;">ODO/TRIP METER : System Diagram18</p> <p style="padding-left: 20px;">ODO/TRIP METER : System Description18</p> <p style="padding-left: 20px;">ODO/TRIP METER : Component Parts Location19</p> <p style="padding-left: 20px;">ODO/TRIP METER : Component Description19</p> <p>SHIFT POSITION INDICATOR20</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : System Diagram...20</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : System Description20</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : Component Parts Location21</p> <p style="padding-left: 20px;">SHIFT POSITION INDICATOR : Component De- scription21</p> <p>WARNING LAMPS/INDICATOR LAMPS22</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : System Diagram22</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : System Description22</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : Com- ponent Parts Location23</p> <p style="padding-left: 20px;">WARNING LAMPS/INDICATOR LAMPS : Com- ponent Description23</p> <p>METER ILLUMINATION CONTROL24</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : System Di- agram24</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : System De- scription24</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : Component Parts Location25</p> <p style="padding-left: 20px;">METER ILLUMINATION CONTROL : Component Description26</p> <p>INFORMATION DISPLAY26</p> <p style="padding-left: 20px;">INFORMATION DISPLAY : System Diagram26</p> <p style="padding-left: 20px;">INFORMATION DISPLAY : System Description26</p> <p style="padding-left: 20px;">INFORMATION DISPLAY : Component Parts Lo- cation30</p> <p style="padding-left: 20px;">INFORMATION DISPLAY : Component Descrip- tion30</p>
--	--

MWI

COMPASS	32	BCM (BODY CONTROL MODULE) : Diagnosis Procedure	50
Description	32	BCM (BODY CONTROL MODULE) : Special Repair Requirement	51
Component Parts Location	33		
Special Repair Requirement	33		
CLOCK	34	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	51
Component Parts Location	34	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure	51
DIAGNOSIS SYSTEM (METER)	35		
Diagnosis Description	35		
DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)	37	FUEL LEVEL SENSOR SIGNAL CIRCUIT	53
CONSULT-III Function (METER/M&A)	37	Description	53
		Component Function Check	53
		Diagnosis Procedure	53
		Component Inspection	54
COMPONENT DIAGNOSIS	40		
U1000 CAN COMM CIRCUIT	40	METER CONTROL SWITCH SIGNAL CIRCUIT	56
Description	40	Description	56
DTC Logic	40	Diagnosis Procedure	56
Diagnosis Procedure	40	Component Inspection	57
U1010 CONTROL UNIT (CAN)	41		
Description	41	OIL PRESSURE SWITCH SIGNAL CIRCUIT ...	58
DTC Logic	41	Description	58
Diagnosis Procedure	41	Component Function Check	58
		Diagnosis Procedure	58
		Component Inspection	58
B2201 COMMUNICATION ERROR 1	42		
Description	42	PARKING BRAKE SWITCH SIGNAL CIRCUIT	59
DTC Logic	42	Description	59
Diagnosis Procedure	42	Diagnosis Procedure (A/T model)	59
		Diagnosis Procedure (M/T model)	59
		Component Inspection	60
B2202 COMMUNICATION ERROR 2	44		
Description	44	WASHER LEVEL SWITCH SIGNAL CIRCUIT..	61
DTC Logic	44	Description	61
Diagnosis Procedure	44	Diagnosis Procedure	61
		Component Inspection	61
B2205 VEHICLE SPEED	46		
Description	46	COMPASS	62
DTC Logic	46	Wiring Diagram — COMPASS —	62
Diagnosis Procedure	46		
		CLOCK	64
B2267 ENGINE SPEED	47	Wiring Diagram — CLOCK —	64
Description	47		
DTC Logic	47	ECU DIAGNOSIS	66
Diagnosis Procedure	47		
		COMBINATION METER	66
B2268 WATER TEMP	48	Reference Value	66
Description	48	Wiring Diagram — METER —	69
DTC Logic	48	Fail Safe	78
Diagnosis Procedure	48	DTC Index	79
POWER SUPPLY AND GROUND CIRCUIT	49	UNIFIED METER AND A/C AMP.	80
		Reference Value	80
COMBINATION METER	49	Wiring Diagram — METER —	87
COMBINATION METER : Diagnosis Procedure ...	49	Fail Safe	96
		DTC Index	97
UNIFIED METER AND A/C AMP.	49		
UNIFIED METER AND A/C AMP. : Diagnosis Procedure	49	BCM (BODY CONTROL MODULE)	98
BCM (BODY CONTROL MODULE)	50		

Reference Value	98	Description	151	
Wiring Diagram — BCM —	121	Diagnosis Procedure	151	A
Fail Safe	126	THE TRUNK OPEN WARNING CONTINUES		
DTC Inspection Priority Chart	128	DISPLAYING, OR DOES NOT DISPLAY	152	B
DTC Index	129	Description	152	
IPDM E/R (INTELLIGENT POWER DISTRI-		Diagnosis Procedure	152	
BUTION MODULE ENGINE ROOM)	132	THE AMBIENT TEMPERATURE DISPLAY IS		
Reference Value	132	INCORRECT	153	C
Wiring Diagram — IPDM E/R —	139	Description	153	
Fail Safe	142	Diagnosis Procedure	153	D
DTC Index	144	NORMAL OPERATING CONDITION	154	
SYMPTOM DIAGNOSIS	145	COMPASS	154	E
THE FUEL GAUGE POINTER DOES NOT		COMPASS : Description	154	
MOVE	145	INFORMATION DISPLAY	154	F
Description	145	INFORMATION DISPLAY : Description	154	
Diagnosis Procedure	145	PRECAUTION	155	
THE METER CONTROL SWITCH IS INOPER-		AIR BAG (PATTERN 2)	155	G
ATIVE	146	Precaution for Supplemental Restraint System		
Description	146	(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		
Diagnosis Procedure	146	SIONER"	155	H
THE OIL PRESSURE SWITCH DOES NOT		ON-VEHICLE REPAIR	156	
TURN ON	147	COMBINATION METER	156	I
Description	147	Exploded View	156	
Diagnosis Procedure	147	Removal and Installation	156	
THE OIL PRESSURE SWITCH DOES NOT		Disassembly and Assembly	157	J
TURN OFF	148	UNIFIED METER AND A/C AMP.	158	
Description	148	Exploded View	158	
Diagnosis Procedure	148	Removal and Installation	158	K
THE PARKING BRAKE RELEASE WARNING		METER CONTROL SWITCH	159	
CONTINUES DISPLAYING, OR DOES NOT		Exploded View	159	L
DISPLAY	149	Removal and Installation	159	
Description	149	COMPASS	160	M
Diagnosis Procedure	149	Exploded View	160	
THE LOW WASHER FLUID WARNING CON-		Removal and Installation	160	
TINUES DISPLAYING, or DOES NOT DIS-		CLOCK	161	MWI
PLAY	150	Exploded View	161	
Description	150	Removal and Installation	161	O
Diagnosis Procedure	150			P
THE DOOR OPEN WARNING CONTINUES				
DISPLAYING, OR DOES NOT DISPLAY	151			

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work flow

INFOID:000000000964325

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2.CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

3.CHECK ON BOARD DIAGNOSIS OPERATION

Check that the on board diagnosis function operates. Refer to [MWI-35. "Diagnosis Description"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

4.CHECK CONSULT-III SELF-DIAGNOSIS RESULTS

Connect CONSULT-III and perform self-diagnosis. Refer to [MWI-37. "CONSULT-III Function \(METER/M&A\)"](#).

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning part and go to 7.

5.NARROW DOWN THE MALFUNCTIONING PART BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and repair or replace the identified malfunctioning parts.

>> GO TO 7.

6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

Inspect combination meter power supply and ground circuits. Refer to [MWI-49. "COMBINATION METER : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> Replace combination meter and go to 7.

NO >> Repair or replace malfunctioning part and go to 7.

7.FINAL CHECK

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

METER SYSTEM


< FUNCTION DIAGNOSIS >

FUNCTION DIAGNOSIS

METER SYSTEM

METER SYSTEM

METER SYSTEM : System Diagram



METER SYSTEM : System Description

INFOID:000000000964327

COMBINATION METER

- The combination meter retrieves the information required for controlling the operations of the meters, indicator lamps/warning lamps and information display from the communication signals from the unified meter and A/C amp. and the signals from various switches and sensors.
- The combination meter incorporates a trip computer that displays warnings and messages on the information display according to the information received from various units.
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-4. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter integrates the meter circuit check function and the segment check function that checks the information display operation.

UNIFIED METER AND A/C AMP.

- Receives information required by the combination meter from various units via CAN communication line and transmits it to the combination meter with communication line.
- The unified meter and A/C amp. incorporates a power saving control function that reduces the power consumption according to the vehicle status. Refer to [BCS-10. "System Description"](#) for details.
- The unified meter and A/C amp. incorporates a diagnosis function that allows the technician to perform diagnoses with CONSULT-III.

METER SYSTEM

< FUNCTION DIAGNOSIS >

Between unified meter and A/C amp. and combination meter.

Unit	Communication line	Input from combination meter	Output to combination meter
Unified meter and A/C amp.	Communication line (METER <-> AMP.)	<ul style="list-style-type: none"> • Parking brake switch signal • Washer level switch signal • Meter day/night condition signal • Illumination control switch signal • Refuel status signal • Low fuel warning lamp signal • Odo data signal 	<ul style="list-style-type: none"> • Vehicle speed signal • Turn indicator signal • High beam request signal • Front fog light request signal • Engine speed signal • Fuel level sensor signal • Engine coolant temperature signal • A/T CHECK indicator signal • Oil pressure switch signal • Door switch signal • Buzzer output signal • AFS OFF indicator lamp signal • Tire pressure signal • AWD warning lamp signal • VDC OFF indicator signal • ABS warning lamp signal • Brake warning lamp signal • Malfunction indicator lamp signal • 4WAS warning lamp signal • Master warning signal
	Communication line (LCD <-> AMP.)	<ul style="list-style-type: none"> • Average fuel consumption reset signal • Travel time reset signal • Possible driving distance reset signal • Average vehicle speed reset signal • Select switch signal • Enter switch signal • Trip A/B reset switch signal • Ambient air temperature display signal 	<ul style="list-style-type: none"> • Shift position signal • Meter display signal • Door switch signal • Trunk switch signal • Fuel level sensor signal • Parking brake switch signal • Washer level switch signal • Charge warning signal • Instantaneous fuel consumption display signal • Ambient air temperature display signal • Average fuel consumption display signal • Average vehicle speed display signal • Possible driving distance display signal • Engine speed signal • Vehicle speed signal

IPDM E/R

- IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.
- IPDM E/R is equipped with the diagnosis function. It can perform the operation check of oil pressure warning lamp with the auto active test and the diagnosis with CONSULT-III.

METER CONTROL FUNCTION LIST

X: Applicable

System		Description	Signal source	Via unified meter and A/C amp.
Meter/gauge	Speedometer	Receives vehicle speed signal and indicates vehicle speed.	ABS actuator and electric unit (control unit)	X
	Tachometer	Receives engine speed signal and indicates engine speed.	ECM	X
	Fuel gauge	Receives fuel level sensor signal and indicates fuel level.	Fuel level sensor unit	X
	Engine coolant temperature gauge	Receives engine coolant temperature signal and indicates coolant temperature.	ECM	X
Warning lamp/indicator lamp	Oil pressure warning lamp	Receives oil pressure warning lamp signal and illuminates warning lamp.	IPDM E/R	X
	Master warning	Illuminates according to warning output on information display.	—	X

METER SYSTEM

< FUNCTION DIAGNOSIS >

System		Description	Signal source	Via unified meter and A/C amp.		
Information display	Door open warning	Receives door switch signals and displays warning.	BCM	X	A	
	Trunk open warning	Receives trunk lid opener switch signal and displays warning.	BCM	X	B	
	Parking brake release warning	Receives parking brake switch signal and vehicle speed signal and displays warnings.	Parking brake switch			C
			ABS actuator and electric unit (control unit)	X		
	Low fuel warning	Receives fuel gauge signal and displays warning if fuel level decreases to 12 ℓ (3-1/8 US gal, 2-5/8 Imp gal) or less.	Fuel level sensor unit	X		D
	Low washer fluid warning	Receives washer level switch signal and displays warning.	Washer level switch			E
	Low outside temperature warning	Monitors ambient sensor signal and displays warning if ambient temperature decreases to 3°C (37°F) or less. (If enabled)	Ambient sensor	X		F
	Instantaneous fuel consumption	Calculates instantaneous fuel consumption based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X		
			ABS actuator and electric unit (control unit)	X		G
	Average fuel consumption	Calculates average fuel consumption in a reset-to-reset interval based on received vehicle speed signals and fuel consumption monitor signal and displays it.	ECM	X		
			ABS actuator and electric unit (control unit)	X		H
	Average vehicle speed	Calculates average vehicle speed in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X		I
	Travel time	Displays accumulated key switch ON time from reset to reset.	—	X		J
	Travel distance	Calculates accumulated travel distance in a reset-to-reset interval based on received vehicle speed signals and displays it.	ABS actuator and electric unit (control unit)	X		K
Possible driving distance	The unified meter and A/C amp. calculates the possible driving distance according to the vehicle speed signal and the fuel level sensor unit received with CAN communication line, and transmits it to the combination meter by means of communication line.	ABS actuator and electric unit (control unit)	X			
		Fuel level sensor unit	X		L	
Ambient air temperature	Corrects ambient temperature value based on received ambient sensor signals and displays it.	Ambient sensor	X		M	

MWI


O

P

METER SYSTEM

< FUNCTION DIAGNOSIS >

ARRANGEMENT OF COMBINATION METER



A. U.S.A.


B. Canada

METER SYSTEM

< FUNCTION DIAGNOSIS >

METER SYSTEM : Component Parts Location

INFOID:000000000964328



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

METER SYSTEM : Component Description

INFOID:000000000964329

Unit	Description
Combination meter	<p>Controls the following with the signals from the unified meter and A/C amp, switches and sensors.</p> <ul style="list-style-type: none"> • Speedometer • Engine coolant temperature gauge • Warning lamps • Information display • Tachometer • Fuel gauge • Indicator lamps • Warning chime

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
Unified meter and A/C amp.	<ul style="list-style-type: none"> The combination meter receives the necessary information from various units via CAN communication line and transmits them to the unified meter and A/C amp. with the communication line that connects both of them. Transmits the fuel gauge signal from the fuel gauge unit with the communication line that connects the unified meter and A/C amp. and the combination meter. Reads the signals from the A/T device and paddle shifter and transmits them to TCM with CAN communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals of the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with CAN communication line.
Fuel level sensor unit	Refer to MWI-53. "Description" .
Oil pressure switch	Refer to MWI-58. "Description" .
ECM	Transmits the following signals to the unified meter and A/C amp. with CAN communication line. <ul style="list-style-type: none"> Engine speed signal Engine coolant temperature signal Fuel consumption monitor signal
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.
BCM	<ul style="list-style-type: none"> Transmits signals provided by various units to the unified meter and A/C amp. with CAN communication line. Transmits the security signal to the combination meter.
A/T device	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> Manual mode signal Not manual mode signal Manual mode shift up signal Manual mode shift down signal
Paddle shifter	Transmits the paddle shifter up signal and paddle shifter down signal to the unified meter and A/C amp.
TCM	Transmits shift position signal to the unified meter and A/C amp.
Meter control switch	Refer to MWI-56. "Description" .
Washer level switch	Transmits the washer level signal to the combination meter.
Brake fluid level switch	Transmits the brake fluid level switch signal to the combination meter.
Parking brake switch	Refer to MWI-59. "Description" .

SPEEDOMETER

SPEEDOMETER : System Diagram



SPEEDOMETER : System Description

INFOID:000000000964331


- The ABS actuator and electric unit (control unit) converts the pulse signal provided by the wheel sensor to a vehicle speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line and transmits it to the combination meter by means of communication line.
- The combination meter indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.

METER SYSTEM

< FUNCTION DIAGNOSIS >

SPEEDOMETER : Component Parts Location

INFOID:000000000964332



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

SPEEDOMETER : Component Description

INFOID:000000000964333

Unit	Description
Combination meter	Indicates the vehicle speed according to the vehicle speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line to the combination meter by means of communication line.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

TACHOMETER

TACHOMETER : System Diagram



TACHOMETER : System Description

INFOID:000000000964335


- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine speed signal to combination meter with communication line.
- The unified meter and A/C amp. receives the engine speed signal from ECM with CAN communication line and transmits it to the combination meter by means of communication line.
- Combination meter converses engine speed signal to the angle signal, and commands to tachometer.

METER SYSTEM

< FUNCTION DIAGNOSIS >

TACHOMETER : Component Parts Location

INFOID:000000000964336



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

TACHOMETER : Component Description

INFOID:000000000964337

Unit	Description
Combination meter	Indicates the engine speed according to the engine speed signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the engine speed signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine speed signal to the unified meter and A/C amp. with CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

ENGINE COOLANT TEMPERATURE GAUGE

ENGINE COOLANT TEMPERATURE GAUGE : System Diagram



ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:000000000964339


- ECM converts a signal from engine coolant temperature sensor to engine coolant temperature signal, and transmits to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits engine coolant temperature signal to combination meter with communication line.
- Combination meter converts engine coolant temperature signal to the angle signal, and commands to engine coolant temperature gauge.

METER SYSTEM

< FUNCTION DIAGNOSIS >

ENGINE COOLANT TEMPERATURE GAUGE : Component Parts Location

INFOID:000000000964340



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

ENGINE COOLANT TEMPERATURE GAUGE : Component Description

INFOID:000000000964341

Unit	Description
Combination meter	Indicates the water temperature gauge according to the engine coolant temperature signal received from the unified meter and A/C amp. by means of communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
Unified meter and A/C amp.	Transmits the engine coolant temperature signal received from ECM with CAN communication line to the combination meter by means of communication line.
ECM	Transmits the engine coolant temperature signal to the unified meter and A/C amp. with CAN communication line.

FUEL GAUGE

FUEL GAUGE : System Diagram



FUEL GAUGE : System Description

INFOID:000000000964343

CONTROL OUTLINE

- The unified meter and A/C amp. reads the fuel level sensor signal from the fuel gauge unit and transmits it to the combination meter with the communication line.
- The combination meter indicates the fuel level on the fuel gauge according to the received fuel level sensor signal.

REFUEL CONTROL


The unit judges that the driver is refueling the vehicle and accelerates the fuel gauge needle movement if the fuel level changes by 15 ℓ (4 US gal, 3-3/10 Imp gal) or more.

METER SYSTEM

< FUNCTION DIAGNOSIS >

FUEL GAUGE : Component Parts Location

INFOID:000000000964344



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

FUEL GAUGE : Component Description

INFOID:000000000964345

Unit	Description
Combination meter	Indicates the fuel gauge according to the fuel level sensor signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the fuel level sensor signal from the fuel level sensor unit to the combination meter by means of communication line.
Fuel level sensor unit	Refer to MWI-53, "Description" .

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

ODO/TRIP METER

ODO/TRIP METER : System Diagram



ODO/TRIP METER : System Description

INFOID:000000000964347


- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

METER SYSTEM

< FUNCTION DIAGNOSIS >

ODO/TRIP METER : Component Parts Location

INFOID:000000000964348



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

ODO/TRIP METER : Component Description

INFOID:000000000964349

Unit	Description
Combination meter	The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.
Unified meter and A/C amp.	The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. with CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

SHIFT POSITION INDICATOR

SHIFT POSITION INDICATOR : System Diagram



SHIFT POSITION INDICATOR : System Description

INFOID:000000000964351

Shift position is displayed in the information display LCD in the combination meter.

MANUAL MODE

When operated with A/T device

- Unified meter and A/C amp. inputs manual mode signal and shift-up/down signal from A/T device (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM processes manual mode signal and shift-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line.
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal.

When operated with paddle shifter

- The unified meter and A/C amp. receives the manual mode signal from the A/T device (manual mode switch) or the shifter-up/down signal from the paddle shifter and transmits them to TCM via CAN communication line.
- TCM processes manual mode signal and paddle shifter-up/down signal, and transmits manual mode indicator signal and shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits manual mode indicator signal and shift position signal to combination meter with the communication line.
- Combination meter indicates A/T gear position and manual mode indicator, when receiving manual mode indicator signal and shift position signal.

NOT MANUAL MODE


- Unified meter and A/C amp. inputs not manual mode signal from A/T device (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM transmits shift position signal to unified meter and A/C amp. with CAN communication line.
- Unified meter and A/C amp. transmits shift position signal to combination meter with the communication line.
- Combination meter indicates A/T shift position when receiving shift position signal.

METER SYSTEM

< FUNCTION DIAGNOSIS >

SHIFT POSITION INDICATOR : Component Parts Location

INFOID:000000000964352



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

SHIFT POSITION INDICATOR : Component Description

INFOID:000000000964353

Unit	Description
Combination meter	Displays the shift position on the information display with shift position signal and manual mode indicator signal received from unified meter and A/C amp.
Unified meter and A/C amp.	<ul style="list-style-type: none"> Transmits the signals from the A/T device and paddle shifter switch to TCM with CAN communication line. Transmits shift position signal and manual mode indicator signal received from TMC with CAN communication line to the combination meter by means of communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
A/T device	Transmits the following signals to the unified meter and A/C amp. <ul style="list-style-type: none"> • Manual mode signal • Not manual mode signal • Manual mode shift up signal • Manual mode shift down signal
Paddle shifter	Transmits the paddle shifter up signal and paddle shifter down signal to the unified meter and A/C amp.
TCM	Transmits shift position signal and manual mode indicator signal to the unified meter and A/C amp.

WARNING LAMPS/INDICATOR LAMPS

WARNING LAMPS/INDICATOR LAMPS : System Diagram



WARNING LAMPS/INDICATOR LAMPS : System Description

INFOID:000000000964355

OIL PRESSURE WARNING LAMP


- IPDM E/R inputs oil pressure switch signal from oil pressure switch, and transmits the signal to unified meter and A/C amp. through BCM with CAN communication line.
- Unified meter and A/C amp. transmits oil pressure switch signal to combination meter with communication line.
- Let the combination meter turn oil pressure warning lamp ON with received oil pressure switch signal.

METER SYSTEM

< FUNCTION DIAGNOSIS >

WARNING LAMPS/INDICATOR LAMPS : Component Parts Location

INFOID:000000000964356



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

WARNING LAMPS/INDICATOR LAMPS : Component Description

INFOID:000000000964357

Unit	Description
Combination meter	Turns the oil pressure warning lamp ON/OFF according to the oil pressure switch signal received from the unified meter and A/C amp. by means of communication line.
Unified meter and A/C amp.	Transmits the oil pressure switch signal received from the IPDM E/R with BCM to the combination meter by means of communication line.
IPDM E/R	IPDM E/R reads the ON/OFF signals from the oil pressure switch and transmits the oil pressure switch signal to the unified meter and A/C amp. via BCM with the CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
Oil pressure switch	Refer to MWI-58, "Description" .
BCM	Transmits the oil pressure switch signal received from IPDM E/R via CAN communication to the unified meter and A/C amp. via CAN communication line.

METER ILLUMINATION CONTROL

METER ILLUMINATION CONTROL : System Diagram



METER ILLUMINATION CONTROL : System Description

INFOID:000000000964359


SYSTEM DESCRIPTION

Meter illumination Control Function

- The combination meter controls the meter illumination by the illumination control switch signal from the meter control switch and the position light request signal transmitted by BCM with unified meter and A/C amp.

Daytime Mode

Meter Illumination is adjusted to 5 steps by meter illumination control switch (1) in daytime mode.




Nighttime Mode

- Combination meter is transferred to nighttime mode with position light request signal from BCM with CAN communication line.

METER SYSTEM


< FUNCTION DIAGNOSIS >

- Meter illumination is adjusted to 22 steps by illumination control switch (1) in nighttime.



METER ILLUMINATION CONTROL : Component Parts Location

INFOID:000000000964360



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

METER SYSTEM

< FUNCTION DIAGNOSIS >

METER ILLUMINATION CONTROL : Component Description


INFOID:000000000964361

Unit	Description
Combination meter	Controls the meter illumination with the illumination control signal from the meter control switch and the position light request signal from unified meter and A/C amp.
Unified meter and A/C amp.	Transmits the position light request signal received from BCM via CAN communication to the combination meter by means of communication.
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Illumination control signal (+) • Illumination control signal (-)

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:000000000964362



JSNIA0032GB

INFORMATION DISPLAY : System Description

INFOID:000000000964363

DISCRIPTION

- The combination meter retrieves the information required for controlling the operations of the information display from the communication signals from the unified meter and A/C amp., etc.
- The combination meter incorporates a trip computer that displays the warning / information according to the information received from various units.

PARKING BRAKE RELEASE WARNING

Control outline

The combination meter indicates PARKING BRAKE RELEASE WARNING judged with the vehicle speed signal received from the unified meter and A/C amp. by means of communication line and the parking brake switch signal from the parking brake switch.

Warning operation condition

PARKING BRAKE RELEASE is judged if all of the following conditions are fulfilled.

- Vehicle speed is 7 km/h (4.3 MPH) or higher
- Parking brake switch ON

LOW FUEL WARNING

Control outline

- The combination meter indicates LOW FUEL WARNING judged with the fuel level sensor signal received from the unified meter and A/C amp.

Warning operation condition

- Fuel level: Approx. 12 ℓ (3 - 1/8 US gal, 2 - 5/8 Imp gal) or less

LOW WASHER FLUID WARNING

METER SYSTEM


< FUNCTION DIAGNOSIS >

Control outline

The combination meter indicates LOW WASHER FLUID WARNING judged with the signal from the washer level switch.

Warning operation condition

- Indicates the warning when it is in washer level switch ON condition for 180 seconds or more. Release the warning when it is in washer level switch OFF condition for 30 seconds or more.



DOOR/TRUNK OPEN WARNING

Control outline

- The combination meter indicates DOOR OPEN WARNING judged with each door switch signal received from the unified meter and A/C amp. by means of communication line.
- The combination meter indicates TRUNK OPEN WARNING judged with the trunk switch signal received from the unified meter and A/C amp. by means of communication line.

MPG

Control outline

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the instantaneous fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.

MPG

Control outline

- The unified meter and A/C amp. receives the fuel consumption monitor signal from ECM and the vehicle speed signal from the ABS actuator and electric unit (control unit) with CAN communication line.
- The unified meter and A/C amp. calculates the average fuel consumption according to the fuel consumption monitor signal and the vehicle speed signal received with CAN communication line, and transmits it to the combination meter.
- The average fuel consumption displayed on the information display is uploaded at approximately 30-second intervals.

NOTE:

“—” is displayed for approximately 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).

MPH

Control outline

- The unified meter and A/C amp. receives the vehicle speed signal from the ABS actuator and electric unit (control unit) via CAN communication line.
- Measures the time during the ignition switch ON with the unified meter and A/C amp.
- The unified meter and A/C amp. calculates the average vehicle speed according to the above signals. These signals are transmitted to the combination meter with the communication line.
- The average vehicle speed displayed on the information display is uploaded at approximately 30-second intervals.

NOTE:

“—” is displayed for 30 seconds just after the reset operation and after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).

TIME

METER SYSTEM

< FUNCTION DIAGNOSIS >

Control outline

Measures the time during the ignition switch ON with the unified meter and A/C amp, and transmits it to the combination meter by means of communication line.

MILES

Control outline

- The unified meter and A/C amp. transmits the vehicle speed signal from ABS actuator and electric unit (control unit) to the combination meter.
- The combination meter calculates the vehicle distance according to the vehicle speed signal. The vehicle distance is displayed.

RANGE

Control outline

The unified meter and A/C amp. calculates possible driving distance according to the vehicle speed signal transmitted through CAN communication and the fuel level sensor signal transmitted from the fuel level sensor. These signals are transmitted to the combination meter with the communication line.

NOTE:

- “—” is displayed for 30 seconds after the ignition switch is OFF → ON. It is displayed simultaneously until the vehicle drives approximately 500 m (0.31 mile).
- The indicated values may not match each other when filling the fuel with the ignition switch ON. Refer to [MWI-154, "INFORMATION DISPLAY : Description"](#).

OUTSIDE TEMP

Control outline

- - The unified meter and A/C amp. receives the ambient sensor signal from the ambient sensor.
- - The unified meter and A/C amp. calculates the ambient temperature according to the ambient sensor signal, and transmits it to the combination meter.
- - The indicated temperature is corrected by the ignition switch signal, the ambient sensor detection temperature, and the vehicle speed signal. It does not increase if the vehicle speed is less than 20 km/h (12 MPH).

Correction process (Ignition switch OFF → ON)

The ambient temperature sensor detection temperature is not displayed in real time if all of the following conditions are fulfilled. The indicated temperature before the ignition switch OFF is displayed.

- The ignition switch OFF time is less than 3.5 hours
- The ambient temperature sensor detection temperature is higher than the indicated temperature before the ignition switch OFF

Correction process (Ignition switch ON)

Perform the following correction if the ambient sensor detection temperature is higher than the indicated temperature when the vehicle speed is 20 km/h (12 MPH) or more.

- Shorten the update time of the indicated temperature according to the increase of the vehicle speed.
- Increase the indicated temperature by 1°C per 1 minute until it reaches to the ambient temperature detection value when the ambient sensor detection temperature is higher than the indicated temperature at 8°C or more.

NOTE:

The ambient sensor input value that is displayed on DATA MONITOR of CONSULT-III is the value before the correction. It may not match the indicated temperature on the information display.

SETTING

Setting item list

Items		Setting range	Setting unit	Description
ALERT	TIME TO REST	No setting - 6 hours	30 minutes, [60 minutes]*	TIME TO REST is displayed on the information display if the vehicle reached the set travel distance.
	ICY	ON/OFF	—	LOW OUTSIDE TEMP is displayed on the information display if the ambient temperature is 3°C (37°F) or less.

METER SYSTEM

< FUNCTION DIAGNOSIS >

Items		Setting range	Setting unit	Description
MAINTENANCE	ENGINE OIL	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The engine oil replacement interval is displayed on the information display if the vehicle reached the set distance.
	OIL FILTER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The oil filter replacement interval is displayed on the information display if the vehicle reached the set distance.
	TIRE	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The tire replacement interval is displayed on the information display if the vehicle reached the set distance.
	OTHER	No setting - 18,500 miles, (No setting - 30,000 km)	250 miles (500 km), [500 miles (1000 km)]*	The OTHER replacement interval is displayed on the information display if the vehicle reached the set distance.
DISPLAY	LANGUAGE	ENGLISH/FRANCAIS	—	Changing the language setting can be performed.
	UNIT	US/METRIC	—	Changing the unit setting can be performed.

* : Press and hold the switch (1 second or more).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P




METER SYSTEM

< FUNCTION DIAGNOSIS >

INFORMATION DISPLAY : Component Parts Location

INFOID:000000000964364



- | | | |
|----------------------------------|---|----------------------------------|
| 1. Unified meter and A/C amp. | 2. BCM | 3. IPDM E/R |
| 4. Oil pressure switch | 5. Ambient sensor | 6. Combination meter |
| 7. Fuel level sensor unit (main) | 8. Fuel level sensor unit and fuel pump (sub) | |
| A. Behind cluster lid C | B. 2WD [oil pan (upper) RH side] | C. AWD (oil filter bracket part) |
| D. Condenser (front) | E. Rear seat (lower right) | F. Rear seat (lower left) |

INFORMATION DISPLAY : Component Description

INFOID:000000000964365

Unit	Description
Combination meter	Controls the information display with the signals received from the unified meter and A/C amp. by means of communication and the signals from various switches and sensors.
Unified meter and A/C amp.	Transmits signals received from various units to the combination meter by means of communication.
Fuel level sensor unit	Refer to MWI-53, "Description" .

METER SYSTEM

< FUNCTION DIAGNOSIS >

Unit	Description
ECM	Transmits the following signals to the unified meter and A/C amp. via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Fuel consumption monitor signal
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the unified meter and A/C amp. via CAN communication.
BCM	Transmits signals provided by various units to the unified meter and A/C amp. via CAN communication.
Meter control switch	Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Enter switch signal • Select switch signal
Washer level switch	Transmits the washer level signal to the combination meter.
Parking brake switch	Refer to MWI-59, "Description" .
Door switch	Transmits the door switch signals to BCM.
Trunk room lamp switch	Transmits the room lamp switch signal to BCM.
Ambient sensor	Detects the ambient temperature and transmits the ambient sensor signal to the unified meter and A/C amp.

A
B
C
D
E
F

G

H

I

J

K

L

M

MWI

O

P

COMPASS

< FUNCTION DIAGNOSIS >

COMPASS

Description


INFOID:000000000964366

DISCRIPTION

- This electronic compass is able to display 8 primary directions: N, NE, E, SE, S, SW, W, NW.
- The compass switch (1) is used to operate the compass.

Switch Operation


Press	Compass is turned ON/OFF
Press and hold (for 3- 9 sec.)	Compass display (2) turns to zone variation change mode Compass
Press and hold (for more than 9 sec.)	Compass display turns to calibration mode



- All standard compasses determine direction relative to Magnetic North; however, this electronic compass is designed to display direction relative to True North.
- The difference between Magnetic North and True North varies from place to place across the surface of the earth.
- This electronic compass must be “told” approximately where it is on the earth’s surface so that the Magnetic North reading can be properly converted into a True North display.
- To tell the electronic compass where it’s at, the earth is separated into numbered “Zone Variances”. The Zone Variance number in which the compass is to function must be entered into this electronic compass.
- Each zone is magnetically about 4.2° wide. Typically, anything under 22.5° total zone change is not noticed on the electronic compass display. However, over 22.5°, a reading may be off by one or more primary directions.
- On long trips, a vehicle may leave its original zone and enter one or more new zones. Generally, you do not need to reset the compass zone if you travel between 3 or 4 zones, such as business travel or vacation. The typical driver will not notice any difference on the display within 3 or 4 zones. However, if the vehicle is “permanently” moved to a new location, it is recommended that the compass zone be reset.

ZONE VARIATION SETTING PROCEDURE

1. Press and hold the compass switch for 3 – 9 seconds.
2. The current zone setting appears on the compass display.
3. Find the current geographical location number in the Zone Variation Chart.
4. Select the new zone number. (Press the compass switch until the new zone number appears on the compass display.)
5. After select the new zone number, the compass display will automatically shows a direction within a few seconds.
6. Perform the following Calibration Procedure for more accurate indications.



COMPASS

< FUNCTION DIAGNOSIS >

CALIBRATION PROCEDURE

NOTE:

The compass calibrates itself under normal driving conditions. However, occasional circumstances may cause the compass to operate inaccurately. Example: Driving from rural (wide open) areas to crowded city areas, or if an aftermarket (i.e., non original equipment) antenna with a magnetic base is attached to the vehicle. Calibrate the mirror compass if the display shows only one direction or a limited number of directions.

NOTE:

- If “magnetic hats” are used in the dealership for vehicle identification, remove the hat from the vehicle before performing the following steps. Do NOT put the hat back on the vehicle after the procedure is completed.
- Drive the vehicle to an open level area; away from large metallic objects, structures, and overhead power lines.
- Turn off “non-essential” electrical accessories (rear window defrost, heater/air conditioning, wipers) and close the doors.

1. Verify the correct compass zone setting for the geographical location.
2. Press and hold the compass switch for more than 9 seconds.
3. “C” is displayed on the compass display, when calibration starts.
4. Drive slowly [less than 8 km/h (5 MPH)] in a circle until the “C / CAL” is replaced with primary headings (N, NE, E, SE, S, SW, W, or NW).

NOTE:

This will require driving at least 2 complete 360 degree circles; 3 complete circles may be required.

5. The compass calibration procedure is now complete. The compass should operate normally.


NOTE:

If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, repeat the calibration procedure.

Component Parts Location

INFOID:000000000964367

- 1 : Compass switch
- 2 : Compass display



Special Repair Requirement

INFOID:000000000964368

1.PERFORM ZONE VARIATION SETTING

Perform the zone variation setting. Refer to [MWI-32. "Description"](#).

>> GO TO 2.

2.PERFORM CALIBRATION

Perform the calibration. Refer to [MWI-32. "Description"](#).

>> Setting completion

CLOCK


< FUNCTION DIAGNOSIS >

CLOCK

Component Parts Location

INFOID:000000000964369

1 : Clock



DIAGNOSIS SYSTEM (METER)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (METER)

Diagnosis Description

INFOID:000000000964370

SELF-DIAGNOSIS MODE

- Information display LCD segment operation can be checked in self-diagnosis mode.
- Meters/gauges can be checked in self-diagnosis mode.


OPERATION PROCEDURE

1. Turn ignition switch ON, and switch the trip meter to "trip A" or "trip B".


NOTE:

If the diagnosis function is activated with "trip A" displayed, the mileage on "trip A" is reset to "0000.0". (The same way for "trip B".)

2. Turn ignition switch OFF.
3. While pressing the trip A/B reset switch (1), turn ignition switch ON again.
4. Make sure that the trip meter displays "0000.0".
5. Press the trip A/B reset switch at least 3 times. (Within 7 seconds after the ignition switch is turned ON.)



6. The unified meter control unit is turned to self-diagnosis mode.
 - Displays "888888" and "8888.8" in the information display LCD (1) for approximately 5 seconds and then blinks the segment dots of the information display LCD alternately.
 - Water temperature gauge and fuel gauge return to zero, and at the same time.



NOTE:

- Check combination meter power supply and ground circuit when self-diagnosis mode of combination meter does not start. Replace combination meter if normal.
- If any of the segments is not displayed, replace combination meter.


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



DIAGNOSIS SYSTEM (METER)

< FUNCTION DIAGNOSIS >

7. Each meter activates during pressing trip A/B reset switch.



NOTE:

If any of the meter and gages is not activated, replace combination meter.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

CONSULT-III Function (METER/M&A)

INFOID:000000000964371

CONSULT-III APPLICATION ITEMS

CONSULT-III can perform the following diagnosis modes with CAN communication with the unified meter and A/C amp.

System	Diagnosis mode	Description
METER/M&A	Self Diagnostic Result	Unified meter and A/C amp. checks the conditions and displays memorized error.
	Data Monitor	Displays unified meter and A/C amp. input/output data in real time.

SELF DIAG RESULT

Refer to [MWI-97, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER [km/h]	X	Value of vehicle speed signal received from ABS actuator and electric unit (control unit) with CAN communication line. NOTE: 655.35 is displayed when the malfunction signal is received.
SPEED OUTPUT [km/h]	X	Vehicle speed signal value transmitted to other units with CAN communication line. NOTE: 655.35 is displayed when the malfunction signal is received.
ODO OUTPUT [km/h or mph]		Odometer signal value transmitted to other units with CAN communication line.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM with CAN communication line. NOTE: 8191.875 is displayed when the malfunction signal is received.
FUEL METER [lit.]	X	Fuel level indicated on combination meter.
W TEMP METER [°C]	X	Value of engine coolant temperature signal received from ECM with CAN communication line. NOTE: 215 is displayed when the malfunction signal is input.
ABS W/L [On/Off]		Status of ABS warning lamp judged from ABS warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
VDC/TCS IND [On/Off]		Status of VDC indicator lamp judged from VDC OFF indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
SLIP IND [On/Off]		Status of slip indicator lamp judged from slip indicator lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line.
BRAKE W/L [On/Off]		Status of brake warning lamp judged from brake warning lamp signal received from ABS actuator and electric unit (control unit) with CAN communication line. NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON.
DOOR W/L [On/Off]		Status of door warning judged from door switch signal received from BCM with CAN communication line.
TRUNK/GLAS-H [On/Off]		Status of trunk warning judged from trunk switch signal received from BCM with CAN communication line.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

Display item [Unit]	MAIN SIGNALS	Description
HI-BEAM IND [On/Off]		Status of high beam indicator lamp judged from high beam request signal received from BCM with CAN communication line.
TURN IND [On/Off]		Status of turn indicator lamp judged from turn indicator signal received from BCM with CAN communication line.
FR FOG IND [On/Off]		Status of front fog light indicator lamp judged from front fog light request signal received from BCM with CAN communication line.
RR FOG IND [Off]		This item is displayed, but cannot be monitored.
LIGHT IND [On/Off]		Status of light indicator lamp judged from position light request signal received from BCM with CAN communication line.
OIL W/L [On/Off]		Status of oil pressure warning lamp judged from oil pressure switch signal received from IPDM E/R with CAN communication line.
MIL [On/Off]		Status of malfunction indicator lamp judged from malfunctioning indicator lamp signal received from ECM with CAN communication line.
CRUISE IND [On/Off]		Status of CRUISE indicator judged from ASCD status signal received from ECM with CAN communication line.
SET IND [On/Off]		Status of set indicator judged from ASCD SET indicator signal received from ECM with CAN communication line.
CRUISE W/L [On/Off]		Status of CRUISE warning lamp judged from ASCD status signal received from ECM with CAN communication line.
BA W/L [Off]		This item is displayed, but cannot be monitored.
ATC/T-AMT W/L [On/Off]		Status of A/T check warning lamp judged from A/T check indicator signal received from TCM with CAN communication line.
4WD W/L [On/Off]		Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line.
4WD LOCK IND [Off]		This item is displayed, but cannot be monitored.
FUEL W/L [On/Off]		Low-fuel warning status judged by the identified fuel level.
WASHER W/L [On/Off]		Status of washer warning lamp judged from washer level switch input to combination meter.
AIR PRES W/L [On/Off]		Status of tire pressure warning lamp judged from tire pressure signal received from BCM with CAN communication line.
KEY G/Y W/L [On/Off]		Status of key warning lamp (G/Y) judged from key warning signal received from BCM with CAN communication line.
AFS OFF IND [On/Off]		Status of AFS OFF indicator lamp judged from AFS OFF indicator lamp signal received from AFS control unit with CAN communication line.
4WAS/RAS W/L [On/Off]		Status of 4WAS warning lamp judged from 4WAS warning lamp signal received from 4WAS main control unit with CAN communication line.
LCD [B&P N, B&P I, ID NG, ROTAT, SFT P, INSRT, BATT, NO KY,OUTKY, LK WN, C&P N,C&P I]		Displays status of Intelligent Key system warning judged from meter display signal received from BCM with CAN communication line.
ACC TARGET [On/Off]		Status of vehicle ahead detection indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC DISTANCE [Off, SHOR, MID, LONG]		Status of set distance indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC OWN VHL [On/Off]		Status of own vehicle indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
ACC SET SPEED [On/Off]		Status of set vehicle speed indicator judged from meter display signal received from ICC sensor integrated unit with CAN communication line.

DIAGNOSIS SYSTEM (UNIFIED METER AND A/C AMP.)

< FUNCTION DIAGNOSIS >

Display item [Unit]	MAIN SIGNALS	Description
ACC UNIT [On/Off]		Status of display unit judged from meter display signal received from ICC sensor integrated unit with CAN communication line.
SHIFT IND [P, R, N, D, M1, M2, M3, M4, M5]		Status of A/T position indicator judged from shift position signal and manual mode indicator signal received from TCM with CAN communication line.
AT S MODE SW [On/Off]		Status of snow mode switch.
AT P MODE SW [On/Off]		This item is displayed, but cannot be monitored.
M RANGE SW [On/Off]		Status of manual mode switch.
NM RANGE SW [On/Off]		Status of not manual mode switch.
AT SFT UP SW [On/Off]		Status of A/T shift up switch.
AT SFT DWN SW [On/Off]		Status of A/T shift down switch.
ST SFT UP SW [On/Off]		Status of paddle shifter up switch.
ST SFT DWN SW [On/Off]		Status of paddle shifter down switch.
COMP FB SIG [On/Off]		A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.
4WD LOCK SW [Off]		This item is displayed, but cannot be monitored.
PKB SW [On/Off]		Status of parking brake switch.
BUCKLE SW [On/Off]		Status of seat belt buckle switch.
BRAKE OIL SW [On/Off]		Status of brake fluid level switch.
DISTANCE [km]		Value of possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C or °F]		Ambient temperature value converted from ambient sensor signal received from ambient sensor. NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.)
FUEL LOW SIG [On/Off]		Status of fuel level low warning signal to output to AV control unit with CAN communication line.
BUZZER [On/Off]		Buzzer status (in the combination meter) is judged with the buzzer output signal received from each unit with CAN communication line and the warning output condition of the combination meter.

NOTE:

Some items are not available according to vehicle specification.

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

U1000 CAN COMM CIRCUIT

< COMPONENT DIAGNOSIS >

COMPONENT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000000964372

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with two communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-28, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000000964373

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000000964374

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-18, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-39, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< COMPONENT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000000964375

Initial diagnosis of unified meter and A/C amp.

DTC Logic

INFOID:000000000964376

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	If any malfunction is detected during initial diagnosis of unified meter and A/C amp. CAN controller	Unified meter and A/C amp.

Diagnosis Procedure

INFOID:000000000964377

1. REPLACE UNIFIED METER AND A/C AMP.

When DTC U1010 is detected, replace unified meter and A/C amp.

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



B2201 COMMUNICATION ERROR 1

< COMPONENT DIAGNOSIS >

B2201 COMMUNICATION ERROR 1

Description

INFOID:000000000964378

The communication line (LCD <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

DTC Logic

INFOID:000000000964379

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2201	COMM ERROR 1	If a communication error is present in the communication line (LCD <-> AMP.) for 2 seconds or more	Communication line (LCD <-> AMP.) circuit

Diagnosis Procedure

INFOID:000000000964380

1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector M53 terminals 24, 25 and unified meter and A/C amp. harness connector M66 terminals 14, 34.

24 - 14 : Continuity should exist.

25 - 34 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminals 24, 25 and ground.

24, 25 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Connect unified meter and A/C amp. connector.
2. Turn ignition switch ON.
3. Check voltage between unified meter and A/C amp. harness connector M66 terminal 14 and ground.

14 - Ground : Approx 12 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.
4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector M53 terminal 25 and ground.

B2201 COMMUNICATION ERROR 1

< COMPONENT DIAGNOSIS >

25 - Ground

: Approx. 5 V

A

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace combination meter.

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

B2202 COMMUNICATION ERROR 2

< COMPONENT DIAGNOSIS >

B2202 COMMUNICATION ERROR 2

Description

INFOID:000000000964381

The communication line (METER <-> AMP.) is used to communicate signals between the combination meter and the unified meter and A/C amp. in order to control the information display.

DTC Logic

INFOID:000000000964382

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2202	COMM ERROR 2	If a communication error is present in the communication line (METER <-> AMP.) for 2 seconds or more	Communication line (METER <-> AMP.) circuit

Diagnosis Procedure

INFOID:000000000964383

1. CHECK CONNECTOR

Check combination meter, unified meter and A/C amp. and terminals (combination meter side, unified meter and A/C amp. side, and harness side) for looseness or bent.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal or connector.

2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and unified meter and A/C amp. connector.
3. Check continuity between combination meter harness connector M53 terminals 2, 3 and unified meter and A/C amp. harness connector M66 terminals 27, 7.

2 - 27 : Continuity should exist.

3 - 7 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminals 2, 3 and ground.

2, 3 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK UNIFIED METER AND A/C AMP. OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Connect unified meter and A/C amp. connector.
4. Turn ignition switch ON.
5. Check voltage between unified meter and A/C amp. harness connector M66 terminal 27 and ground.

27 - Ground : Approx. 5 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace unified meter and A/C amp.

4. CHECK COMBINATION METER OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Connect combination meter connector.

B2202 COMMUNICATION ERROR 2

< COMPONENT DIAGNOSIS >

4. Turn ignition switch ON.
5. Check voltage between combination meter harness connector M53 terminal 3 and ground.

3 - Ground : Approx. 5 V

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace combination meter.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

B2205 VEHICLE SPEED

< COMPONENT DIAGNOSIS >

B2205 VEHICLE SPEED

Description

INFOID:000000000964384

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication to unified meter and A/C amp.

DTC Logic

INFOID:000000000964385

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2205	VEHICLE SPEED	If the abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more	ABS actuator and electric unit (control unit)

Diagnosis Procedure

INFOID:000000000964386

1. PERFORM SELF DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnosis Result" of ABS actuator and electric unit (control unit), and repair or replace malfunctioning parts.

>> Refer to [BRC-26, "CONSULT-III Function \(ABS\)"](#).

B2267 ENGINE SPEED

< COMPONENT DIAGNOSIS >

B2267 ENGINE SPEED

Description

INFOID:000000000964387

The engine speed signal is transmitted from ECM to the unified meter and A/C amp. with CAN communication.

DTC Logic

INFOID:000000000964388

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2267	ENGINE SPEED	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more	ECM

Diagnosis Procedure

INFOID:000000000964389

1. PERFORM SELF DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-113. "CONSULT-III Function"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



B2268 WATER TEMP

< COMPONENT DIAGNOSIS >

B2268 WATER TEMP

Description

INFOID:000000000964390

The engine coolant temperature signal is transmitted from ECM to the unified meter and A/C amp. via CAN communication.

DTC Logic

INFOID:000000000964391

DTC DETECTION LOGIC

DTC	Display contents of CONSULT-III	Diagnostic item is detected when ...	Probable malfunction location
B2268	WATER TEMP	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more	ECM

Diagnosis Procedure

INFOID:000000000964392

1. PERFORM SELF DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-113. "CONSULT-III Function"](#).

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000000964393

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	11
Ignition switch ON or START	4

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector M53 terminals 1, 21 and ground.

Terminal No.	Signal name	Ignition switch position	Value (Approx.)
1	Battery power supply	OFF	Battery voltage
21	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector M53 terminals 5, 15, 22 and ground.

5, 15, 22 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

UNIFIED METER AND A/C AMP.

UNIFIED METER AND A/C AMP. : Diagnosis Procedure

INFOID:000000000964394

1.CHECK FUSE

Check for blown fuses.

Power source	Fuse No.
Battery	6
Ignition switch ACC or ON	19
Ignition switch ON or START	3

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between unified meter and A/C amp. harness connector M67 terminals 54, 41, 53 and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

Terminal No.	Signal name	Ignition switch position	Value (Approx.)
54	Battery power supply	OFF	Battery voltage
41	ACC power supply	ACC	Battery voltage
53	Ignition signal	ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between unified meter and A/C amp. and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector.
3. Check continuity between unified meter and A/C amp. harness connector M67 terminals 55, 71 and ground.

55, 71 - Ground : Continuity should exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000000964395

1.CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power supply	K
11		10

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM		Ground Battery voltage
Connector	Terminal	
M118	1	
M119	11	

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M119	13		Existed

Does continuity exist?

- YES >> INSPECTION END
 NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE) : Special Repair Requirement

INFOID:000000000964396

1. REQUIRED WORK WHEN REPLACING BCM

Initialize IVIS by CONSULT-III. For the details of initialization refer to CONSULT-III operation manual NATS-IVIS/NVIS.

>> Work end.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000000964397

1. CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
1	Battery power supply	C
—		50
—		51

Is the fuse fusing?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.
 NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check voltage between IPDM E/R harness connector and ground.

Terminals		Ground	Voltage (Approx.)
(+)	(-)		
IPDM E/R		Ground	Battery voltage
Connector	Terminal		
E4	1 2		

Is the measurement value normal?

- YES >> GO TO 3.
 NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	12		Existed
E6	41		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Description

INFOID:000000000964398

The fuel level sensor unit and fuel pump (main) and the fuel level sensor unit (sub) detect the fuel level in the fuel tank and transmit the fuel gauge signal to the unified meter and A/C amp.

Component Function Check

INFOID:000000000964399

1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter.

Fuel gauge pointer	Reference value of data monitor [lit.]
Full	Approx. 68.8
Three quarters	Approx. 60
Half	Approx. 39.2
A quarter	Approx. 20.8
Empty	Approx. 5.6

Does monitor value match fuel gauge reading?

- YES >> INSPECTION END
NO >> Replace combination meter.


Diagnosis Procedure

INFOID:000000000964400

1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between unified meter and A/C amp. harness connector M67 terminal 42 and ground.

42 - Ground :



Does it match fuel gauge reading?

- YES >> GO TO 2.
NO >> Replace the unified meter and A/C amp.

2. CHECK FUEL LEVEL SENSOR (SUB) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect unified meter and A/C amp. connector and fuel level sensor unit (sub) connector.
3. Check continuity between unified meter and A/C amp. harness connector M67 terminal 42 and fuel level sensor unit (sub) harness connector B21 terminal 1.

42 - 1 : Continuity should exist.

4. Check continuity between unified meter and A/C amp. harness connector M67 terminal 42 and ground.

42 - Ground : Continuity should not exist.

Is the inspection result normal?

- OK >> GO TO 3.
NG >> Repair harness or connector.

3. CHECK FUEL LEVEL SENSOR (MAIN-SUB) CIRCUIT

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

1. Disconnect fuel level sensor unit and fuel pump (main) connector.
2. Check continuity between fuel level sensor unit (sub) harness connector B21 terminal 2 and fuel level sensor unit and fuel pump (main) harness connector B22 terminal 2.

2 - 2 : Continuity should exist.

3. Check continuity between fuel level sensor unit (sub) harness connector B22 terminal 2 and ground.

2 - Ground :Continuity should not exist.

Is the inspection result normal?

OK >> GO TO 4.

NG >> Repair harness or connector.

4.CHECK FUEL LEVEL SENSOR (MAIN) CIRCUIT

Check continuity between fuel level sensor unit and fuel pump (main) harness connector B22 terminal 5 and unified meter and A/C amp. harness connector M67 terminal 58.

5 - 58 : Continuity should exist.

Is the inspection result normal?

OK >> GO TO 5.

NG >> Repair harness or connector.

5.CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Install the fuel level sensor unit properly.

Component Inspection

INFOID:000000000964401

1.REMOVE FUEL LEVEL SENSOR UNIT

Remove the fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

>> GO TO 2.


2.CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)

Check the resistance between fuel level sensor unit and fuel pump (main).

2 - 5

Full : Approx. 3 Ω

Empty : Approx. 80 Ω



Standard float position

Full (A) [mm (in)] : Approx. 210 (8.27)

Empty (B) [mm (in)] : Approx. 30 (1.18)

Is inspection result OK?

YES >> GO TO 3.

NO >> Replace fuel level sensor unit and fuel pump (main).

3.CHECK FUEL LEVEL SENSOR UNIT (SUB)

FUEL LEVEL SENSOR SIGNAL CIRCUIT


< COMPONENT DIAGNOSIS >

Inspect the resistance of fuel level sensor unit (sub).

1 - 2

Full : Approx. 3 Ω

Empty : Approx. 43 Ω



Standard float position

Full (A) [mm (in)] : Approx. 9 (0.35)

Empty (B) [mm (in)] : Approx. 179 (7.05)

Is inspection result OK?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



METER CONTROL SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

METER CONTROL SWITCH SIGNAL CIRCUIT

Description

INFOID:000000000964402

Transmits the following signals to the combination meter.





- Illumination control signal (+)
- Illumination control signal (-)
- Trip A/B reset signal
- Select switch signal
- Enter switch signal

Diagnosis Procedure

INFOID:000000000964403

1. CHECK METER CONTROL SWITCH INPUT SIGNAL

1. Turn the ignition switch ON.
2. Measure voltage between the following terminals of the combination meter.

Terminal No.	Condition	Voltage
36 - 16	When  switch is pressed	0 V
	Other than the above	5 V
37 - 16	When  switch is pressed	0 V
	Other than the above	5 V
38 - 16	When trip A/B reset switch is pressed	0 V
	Other than the above	5 V
39 - 16	When  switch is pressed	0 V
	Other than the above	5 V
40 - 16	When  switch is pressed	0 V
	Other than the above	5 V

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the combination meter and meter control switch connectors.
3. Check continuity between combination meter harness connector M53 terminals 16, 36, 37, 39, 40, 38 and meter control switch harness connector M54 terminals 7, 2, 1, 10, 9, 5.

- 16 - 7 : Continuity should exist.
- 36 - 2 : Continuity should exist.
- 37 - 1 : Continuity should exist.
- 39 - 10 : Continuity should exist.
- 40 - 9 : Continuity should exist.
- 38 - 5 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminals 16, 36, 37, 39, 40, 38 and ground.

- 16 - Ground : Continuity should not exist.
- 36 - Ground : Continuity should not exist.
- 37 - Ground : Continuity should not exist.
- 39 - Ground : Continuity should not exist.
- 40 - Ground : Continuity should not exist.
- 38 - Ground : Continuity should not exist.

METER CONTROL SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

Is the inspection result normal?





- YES >> INSPECTION END
 NO >> Repair harness or connector.

Component Inspection

INFOID:000000000964404

1. CHECK METER CONTROL SWITCH UNIT

1. Turn the ignition switch OFF.
2. Disconnect the meter control switch connector.
3. Check continuity of the meter control switch.

Connector	Terminal No.		Operation and status	Continuity
M54	2	7	Press  switch	Yes
			Other than the above	No
	1	7	Press  switch	Yes
			Other than the above	No
	5	7	Press the trip A/B reset switch.	Yes
			Other than the above	No
	10	7	Press  switch	Yes
			Other than the above	No
	9	7	Press  switch	Yes
			Other than the above	No

Is inspection result OK?

- YES >> INSPECTION END
 NO >> Replace the meter control switch.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



OIL PRESSURE SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

OIL PRESSURE SWITCH SIGNAL CIRCUIT

Description

INFOID:000000000964405

Detects the engine oil pressure and transmits the oil pressure switch signal to IPDM E/R.

Component Function Check

INFOID:000000000964406

1. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

OIL W/L

Ignition switch ON : ON

Engine running : OFF

>> INSPECTION END

Diagnosis Procedure

INFOID:000000000964407

1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector E6 terminal 75 and oil pressure switch harness connector F37 terminal 1.

75 - 1 : Continuity should exist.

4. Check continuity between IPDM E/R harness connector E6 terminal 75 and ground.

75 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.


Component Inspection

INFOID:000000000964408

1. CHECK OIL PRESSURE SWITCH UNIT

Check continuity between oil pressure switch and ground.

Condition	Oil pressure [kPa (kg/cm ² , psi)]	Continuity
Engine stopped	Less than 29 (0.3, 4)	Yes
Engine running	More than 29 (0.3, 4)	No



Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the oil pressure switch.

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

PARKING BRAKE SWITCH SIGNAL CIRCUIT

Description

INFOID:000000000964409

Transmits the parking brake switch signal to the combination meter.

Diagnosis Procedure (A/T model)

INFOID:000000000964410


1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the voltage and waveform between combination meter harness connector M53 terminal 27 and ground.

27 - Ground

Parking brake ON : Approx. 0 V

Parking brake OFF :



JSNIA0007GB

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector M53 terminal 27 and parking brake switch harness connector E107 terminal 1.

27 - 1 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminal 27 and ground.

27 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Diagnosis Procedure (M/T model)

INFOID:000000000964411


1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the voltage and waveform between combination meter harness connector M53 terminal 27 and ground.

27 - Ground

Parking brake ON : Approx. 0 V

Parking brake OFF :



JSNIA0007GB

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2.CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and parking brake switch connector.
3. Check continuity between combination meter harness connector M53 terminal 27 and parking brake switch harness connector B14 terminal 1.

27 - 1 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminal 27 and ground.

27 - Ground : Continuity should not exist.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.

Component Inspection

INFOID:000000000964412

1.CHECK PARKING BRAKE SWITCH

Check parking brake switch. Refer to [BRC-69. "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END.
NO >> Replace parking brake switch.

WASHER LEVEL SWITCH SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

WASHER LEVEL SWITCH SIGNAL CIRCUIT

Description

INFOID:000000000964413

Transmits the washer level switch signal to the combination meter.

Diagnosis Procedure

INFOID:000000000964414

1. CHECK WASHER LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and washer level switch connector.
3. Check continuity between combination meter harness connector M53 terminal 31 and washer level switch harness connector E32 terminal 1.

31 - 1 : Continuity should exist.

4. Check continuity between combination meter harness connector M53 terminal 31 and ground.

31 - Ground : Continuity should not exist.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:000000000964415

1. CHECK WASHER LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect washer level switch connector.
3. Check washer level switch.

Terminal	Washer level switch	Continuity
1 - 2	ON	Yes
	OFF	No

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace washer level switch. Refer to [WW-81, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P




COMPASS

< COMPONENT DIAGNOSIS >

COMPASS

Wiring Diagram — COMPASS —

INFOID:000000000964416



COMPASS

2006/09/15

JCNWA0012GE

COMPASS

< COMPONENT DIAGNOSIS >

COMPASS

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FV-MZ



Terminal No.	Color of Wire	Signal Name
2A	G	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	Color of Wire	Signal Name
6B	Y	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	TK10MW-NSB



Terminal No.	Color of Wire	Signal Name
9	B	-
12	Y	-
13	BR	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TK10FW-NSB



Terminal No.	Color of Wire	Signal Name
9	B	-
12	G	-
13	BR	-

Connector No.	R3
Connector Name	AUTO ANTI-DAZZLING INSIDE MIRROR
Connector Type	TH10FB-NH



Terminal No.	Color of Wire	Signal Name
6	BR	IGN
8	B	GND
10	G	BAT

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

JCNWA0013GE


CLOCK

< COMPONENT DIAGNOSIS >

CLOCK

Wiring Diagram — CLOCK —

INFOID:000000000964417



CLOCK

2006/09/15

JCNWA0014GE

CLOCK

< COMPONENT DIAGNOSIS >

CLOCK

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-CS



Terminal No.	4B	Color of Wire	Y	Signal Name	—
Terminal No.	3B	Color of Wire	Y	Signal Name	—

Connector No.	M74
Connector Name	CLOCK
Connector Type	TH04FW-NH



Terminal No.	3	Color of Wire	B	Signal Name	GND
Terminal No.	4	Color of Wire	Y	Signal Name	BAT

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



JCNWA0015GE

COMBINATION METER

< ECU DIAGNOSIS >

ECU DIAGNOSIS

COMBINATION METER


Reference Value

INFOID:000000000964418

VALUES ON THE DAIAGNOSIS TOOL

Refer to [MWI-80. "Reference Value"](#).

TERMINAL LAYOUT







PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (LG)	Ground	Communication signal (METER→ AMP.)	Output	Ignition switch ON	—	<p style="text-align: right;">JSNIA0027GB</p>
3 (GR)	Ground	Communication signal (AMP.→ METER)	Input	Ignition switch ON	—	<p style="text-align: right;">JSNIA0027GB</p>
5 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6 (W)	Ground	Alternator signal	Input	Ignition switch ON	Charge warning lamp ON	0 V
					Charge warning lamp OFF	12 V
7 (LG)	Ground	Air bag signal	Input	Ignition switch ON	Air bag warning lamp ON	4 V
					Air bag warning lamp OFF	0 V
10 (G)	Ground	Security signal	Input	Ignition switch OFF	Security warning lamp ON	0 V
					Security warning lamp OFF	12 V

COMBINATION METER

< ECU DIAGNOSIS >



Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
16 (B)	Ground	Meter control switch ground	—	Ignition switch ON	—	0 V
21 (R)	Ground	Ignition signal	Input	Ignition switch ON	—	12 V
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (BR)	Ground	Communication signal (LCD→ AMP.)	Output	Ignition switch ON	—	 <small>JSNIA0028GB</small>
25 (Y)	Ground	Communication signal (AMP.→ LCD)	Input	Ignition switch ON	—	 <small>JSNIA0027GB</small>
26 (R)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p>  <small>JSNIA0012GB</small>
27 (V)	Ground	Parking brake switch signal	Input	Ignition switch ON	Parking brake ON	0 V
					Parking brake OFF	 <small>JSNIA0007GB</small>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



COMBINATION METER

< ECU DIAGNOSIS >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
28 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.  JSNIA0008GB
					The brake fluid level is lower than the low level
29 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When driver seat belt is fastened
					When driver seat belt is unfastened
31 (L)	Ground	Washer level switch signal	Input	Ignition switch ON	Washer level switch ON
					Washer level switch OFF
34 (R)	Ground	Illumination control signal	Output	Ignition switch ON	Lighting switch ON, then operate the illumination control switch.  NOTE: When brightness level is midway JSNIA0010GB
36 (LG)	16 (B)	Select switch signal	Input	Ignition switch ON	When ● is pressed
					Other than the above
37 (SB)	16 (B)	Enter switch signal	Input	Ignition switch ON	When □ is pressed
					Other than the above
38 (L)	16 (B)	Trip A/B reset switch signal	Input	Ignition switch ON	When trip A/B reset switch is pressed
					Other than the above
39 (P)	16 (B)	Illumination control switch signal (-)	Input	Ignition switch ON	When ⚙️- switch is pressed
					Other than the above
40 (O)	16 (B)	Illumination control switch signal (+)	Input	Ignition switch ON	When ⚙️+ switch is pressed
					Other than the above

COMBINATION METER

< ECU DIAGNOSIS >

Wiring Diagram — METER —

INFOID:00000000964419



2006/09/15

JCNWA0001GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




COMBINATION METER

< ECU DIAGNOSIS >

- ◊ A : With A/T
- ◊ NV : With NAVI
- ◊ ON : Without NAVI
- ◊ IC : With ICC
- ◊ AS : With 4WAS
- ◊ PA : With automatic drive positioner or 4WAS
- ◊ AP : Without automatic drive positioner and 4WAS
- ◊ SS : With paddle shifter switch

*: This connector is not shown in "Harness Layout".




JCNWA0002GE

COMBINATION METER

< ECU DIAGNOSIS >

⬠: With ICC



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P











JCNWA0003GE

COMBINATION METER

< ECU DIAGNOSIS >

METER











Connector No. Connector Name Connector Type	B1 WIRE TO WIRE TH08FW-TM4		Terminal No. Color of Wire Signal Name 23 L - 24 P - 25 L - 26 P - 80 Y - 82 B - 96 V - 97 SB -
Connector No. Connector Name Connector Type	B13 SEAT BELT BUCKLE SWITCH (DRIVER SIDE) A03FW		Terminal No. Color of Wire Signal Name 1 SB - 2 B -
Connector No. Connector Name Connector Type	B14 PARKING BRAKE SWITCH P01FB-A		Terminal No. Color of Wire Signal Name 1 V -
Connector No. Connector Name Connector Type	B21 FUEL LEVEL SENSOR UNIT (SUB) E02FGY-RS		Terminal No. Color of Wire Signal Name 1 Y - 2 W -
Connector No. Connector Name Connector Type	B22 FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN) E08FGY-RS		Terminal No. Color of Wire Signal Name 2 W - 5 B -
Connector No. Connector Name Connector Type	B54 4WS MAIN CONTROL UNIT A30FW-M4		Terminal No. Color of Wire Signal Name 1 L - 8 P - CAN-H CAN-L
Connector No. Connector Name Connector Type	E5 WIRE TO WIRE SAA30MB-RS10-SJ2Z		Terminal No. Color of Wire Signal Name 35 Y -
Connector No. Connector Name Connector Type	E6 IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) TH08FW-NH		Terminal No. Color of Wire Signal Name 39 P - 40 L -

JCNWA0004GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

<table border="1"> <tr><td>Connector No.</td><td>E7</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Type</td><td>TH20FW-CS12-M4</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>75</td><td>Y</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E7	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type	TH20FW-CS12-M4	Terminal No.	75	Y	-	Color of Wire				Signal Name				<table border="1"> <tr><td>Connector No.</td><td>E47</td></tr> <tr><td>Connector Name</td><td>BRAKE FLUID LEVEL SWITCH</td></tr> <tr><td>Connector Type</td><td>YV02F5Y</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>1</td><td>W</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E47	Connector Name	BRAKE FLUID LEVEL SWITCH	Connector Type	YV02F5Y	Terminal No.	1	W	-	Color of Wire				Signal Name																																							
Connector No.	E7																																																																								
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																																																								
Connector Type	TH20FW-CS12-M4																																																																								
Terminal No.	75	Y	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Connector No.	E47																																																																								
Connector Name	BRAKE FLUID LEVEL SWITCH																																																																								
Connector Type	YV02F5Y																																																																								
Terminal No.	1	W	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
<table border="1"> <tr><td>Connector No.</td><td>E41</td></tr> <tr><td>Connector Name</td><td>ABS ACTUATOR AND ELECTRIC UNIT</td></tr> <tr><td>Connector Type</td><td>BAA42FB-AH24-LH</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>14</td><td>P</td><td>CAN-L</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td>CAN-H</td></tr> </table>	Connector No.	E41	Connector Name	ABS ACTUATOR AND ELECTRIC UNIT	Connector Type	BAA42FB-AH24-LH	Terminal No.	14	P	CAN-L	Color of Wire				Signal Name			CAN-H	<table border="1"> <tr><td>Connector No.</td><td>E103</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (J/B)</td></tr> <tr><td>Connector Type</td><td>NS18FW-S5</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>2F</td><td>W</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E103	Connector Name	FUSE BLOCK (J/B)	Connector Type	NS18FW-S5	Terminal No.	2F	W	-	Color of Wire				Signal Name																																							
Connector No.	E41																																																																								
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT																																																																								
Connector Type	BAA42FB-AH24-LH																																																																								
Terminal No.	14	P	CAN-L																																																																						
Color of Wire																																																																									
Signal Name			CAN-H																																																																						
Connector No.	E103																																																																								
Connector Name	FUSE BLOCK (J/B)																																																																								
Connector Type	NS18FW-S5																																																																								
Terminal No.	2F	W	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
<table border="1"> <tr><td>Connector No.</td><td>E32</td></tr> <tr><td>Connector Name</td><td>WASHER LEVEL SWITCH</td></tr> <tr><td>Connector Type</td><td>Z02FBR</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>1</td><td>LG</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E32	Connector Name	WASHER LEVEL SWITCH	Connector Type	Z02FBR	Terminal No.	1	LG	-	Color of Wire				Signal Name				<table border="1"> <tr><td>Connector No.</td><td>E76</td></tr> <tr><td>Connector Name</td><td>AMBIENT SENSOR</td></tr> <tr><td>Connector Type</td><td>RS02FB</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>1</td><td>G</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E76	Connector Name	AMBIENT SENSOR	Connector Type	RS02FB	Terminal No.	1	G	-	Color of Wire				Signal Name																																							
Connector No.	E32																																																																								
Connector Name	WASHER LEVEL SWITCH																																																																								
Connector Type	Z02FBR																																																																								
Terminal No.	1	LG	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Connector No.	E76																																																																								
Connector Name	AMBIENT SENSOR																																																																								
Connector Type	RS02FB																																																																								
Terminal No.	1	G	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
<table border="1"> <tr><td>Connector No.</td><td>E7</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Type</td><td>TH20FW-CS12-M4</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>75</td><td>Y</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E7	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type	TH20FW-CS12-M4	Terminal No.	75	Y	-	Color of Wire				Signal Name				<table border="1"> <tr><td>Connector No.</td><td>E67</td></tr> <tr><td>Connector Name</td><td>ICG SENSOR INTEGRATED UNIT</td></tr> <tr><td>Connector Type</td><td>RS06FB-PR</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>2</td><td>V</td><td>BRK LMP RLY</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td>CAN-H</td></tr> <tr><td>Terminal No.</td><td>3</td><td>L</td><td>CAN-H</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td>CAN-L</td></tr> <tr><td>Terminal No.</td><td>4</td><td>P</td><td>CAN-L</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E67	Connector Name	ICG SENSOR INTEGRATED UNIT	Connector Type	RS06FB-PR	Terminal No.	2	V	BRK LMP RLY	Color of Wire				Signal Name			CAN-H	Terminal No.	3	L	CAN-H	Color of Wire				Signal Name			CAN-L	Terminal No.	4	P	CAN-L	Color of Wire				Signal Name															
Connector No.	E7																																																																								
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																																																								
Connector Type	TH20FW-CS12-M4																																																																								
Terminal No.	75	Y	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Connector No.	E67																																																																								
Connector Name	ICG SENSOR INTEGRATED UNIT																																																																								
Connector Type	RS06FB-PR																																																																								
Terminal No.	2	V	BRK LMP RLY																																																																						
Color of Wire																																																																									
Signal Name			CAN-H																																																																						
Terminal No.	3	L	CAN-H																																																																						
Color of Wire																																																																									
Signal Name			CAN-L																																																																						
Terminal No.	4	P	CAN-L																																																																						
Color of Wire																																																																									
Signal Name																																																																									
<table border="1"> <tr><td>Connector No.</td><td>E51</td></tr> <tr><td>Connector Name</td><td>ICG BRAKE HOLD RELAY</td></tr> <tr><td>Connector Type</td><td>HS02FL-M2</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>1</td><td>B</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> <tr><td>Terminal No.</td><td>2</td><td>V</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> <tr><td>Terminal No.</td><td>3</td><td>R</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> <tr><td>Terminal No.</td><td>4</td><td>P</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E51	Connector Name	ICG BRAKE HOLD RELAY	Connector Type	HS02FL-M2	Terminal No.	1	B	-	Color of Wire				Signal Name				Terminal No.	2	V	-	Color of Wire				Signal Name				Terminal No.	3	R	-	Color of Wire				Signal Name				Terminal No.	4	P	-	Color of Wire				Signal Name				<table border="1"> <tr><td>Connector No.</td><td>E103</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (J/B)</td></tr> <tr><td>Connector Type</td><td>NS18FW-S5</td></tr> </table>  <p>H.S.</p> <table border="1"> <tr><td>Terminal No.</td><td>2F</td><td>W</td><td>-</td></tr> <tr><td>Color of Wire</td><td></td><td></td><td></td></tr> <tr><td>Signal Name</td><td></td><td></td><td></td></tr> </table>	Connector No.	E103	Connector Name	FUSE BLOCK (J/B)	Connector Type	NS18FW-S5	Terminal No.	2F	W	-	Color of Wire				Signal Name			
Connector No.	E51																																																																								
Connector Name	ICG BRAKE HOLD RELAY																																																																								
Connector Type	HS02FL-M2																																																																								
Terminal No.	1	B	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Terminal No.	2	V	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Terminal No.	3	R	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Terminal No.	4	P	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									
Connector No.	E103																																																																								
Connector Name	FUSE BLOCK (J/B)																																																																								
Connector Type	NS18FW-S5																																																																								
Terminal No.	2F	W	-																																																																						
Color of Wire																																																																									
Signal Name																																																																									

















JCNWA0005GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	E106	Connector No.	E107	Connector No.	E110	Connector No.	F103
Connector Name	WIRE TO WIRE	Connector Name	PARKING BRAKE SWITCH (A/T)	Connector Name	STOP LAMP SWITCH	Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4	Connector Type	TE01FW	Connector Type	M04FW-LC	Connector Type	TK38FW-NS10
							
Terminal No.	6	Terminal No.	1	Terminal No.	1	Terminal No.	35
Color of Wire	P	Color of Wire	O	Color of Wire	L	Color of Wire	Y
Signal Name	-	Signal Name	-	Signal Name	-	Signal Name	-
Terminal No.	7	Terminal No.	2	Terminal No.	2	Terminal No.	36
Color of Wire	L	Color of Wire	W	Color of Wire	W	Color of Wire	G
Signal Name	-	Color of Wire	L	Color of Wire	L	Color of Wire	L
Terminal No.	80	Color of Wire	SB	Color of Wire	L	Color of Wire	L
Color of Wire	W	Color of Wire	-	Color of Wire	L	Color of Wire	L
Signal Name	-	Color of Wire	-	Color of Wire	L	Color of Wire	L
Terminal No.	81	Color of Wire	-	Color of Wire	L	Color of Wire	L
Color of Wire	P	Color of Wire	-	Color of Wire	L	Color of Wire	L
Signal Name	-	Color of Wire	-	Color of Wire	L	Color of Wire	L
Terminal No.	82	Color of Wire	-	Color of Wire	L	Color of Wire	L
Color of Wire	G	Color of Wire	-	Color of Wire	L	Color of Wire	L
Signal Name	-	Color of Wire	-	Color of Wire	L	Color of Wire	L
Terminal No.	93	Color of Wire	-	Color of Wire	L	Color of Wire	L
Color of Wire	LG	Color of Wire	-	Color of Wire	L	Color of Wire	L
Signal Name	-	Color of Wire	-	Color of Wire	L	Color of Wire	L
Connector No.	F38	Connector No.	F37	Connector No.	F51	Connector No.	F103
Connector Name	ALTERNATOR	Connector Name	OIL PRESSURE SWITCH	Connector Name	A/T ASSEMBLY	Connector Name	WIRE TO WIRE
Connector Type	HS03FB	Connector Type	ED1FGY-RS-AR	Connector Type	RK10FG-DGY	Connector Type	TK38FW-NS10
							
Terminal No.	2	Terminal No.	1	Terminal No.	3	Terminal No.	2
Color of Wire	G	Color of Wire	Y	Color of Wire	L	Color of Wire	G
Signal Name	L	Color of Wire	-	Color of Wire	P	Color of Wire	-
Terminal No.	35	Color of Wire	-	Color of Wire	P	Color of Wire	-
Color of Wire	L	Color of Wire	-	Color of Wire	P	Color of Wire	-
Signal Name	-	Color of Wire	-	Color of Wire	P	Color of Wire	-
Terminal No.	36	Color of Wire	-	Color of Wire	P	Color of Wire	-
Color of Wire	P	Color of Wire	-	Color of Wire	P	Color of Wire	-
Signal Name	-	Color of Wire	-	Color of Wire	P	Color of Wire	-
Terminal No.	43	Color of Wire	-	Color of Wire	P	Color of Wire	-
Color of Wire	L	Color of Wire	-	Color of Wire	P	Color of Wire	-
Signal Name	-	Color of Wire	-	Color of Wire	P	Color of Wire	-
Terminal No.	44	Color of Wire	-	Color of Wire	P	Color of Wire	-
Color of Wire	L	Color of Wire	-	Color of Wire	P	Color of Wire	-
Signal Name	-	Color of Wire	-	Color of Wire	P	Color of Wire	-


JCNWA0006GE

COMBINATION METER

< ECU DIAGNOSIS >


METER

Connector No.	F108
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
16	P	CAN-L

Connector No.	F151
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SF10FEGY




Terminal No.	Color of Wire	Signal Name
1	BR	CAN-H
2	L/Y	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS09FW-M2




Terminal No.	Color of Wire	Signal Name
1A	GR	-
2A	G	-
5A	V	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-GS




Terminal No.	Color of Wire	Signal Name
3B	P	-
6B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-GS




Terminal No.	Color of Wire	Signal Name
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS19-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
18	V	-
80	W	-
81	BR	-
93	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4



Terminal No.	Color of Wire	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
80	Y	-
82	B	-
96	V	-
97	SB	-

Connector No.	M16
Connector Name	AFS CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
7	P	CAN-L
30	L	CAN-H

JCNWA0007GE


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	M32
Connector Name	PADDLE SHIFTER (SHIFT DOWN)
Connector Type	AC3FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	G	-

Connector No.	M39
Connector Name	PADDLE SHIFTER (SHIFT UP)
Connector Type	AC4FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	O	-

Connector No.	M63
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name
1	GR	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	LG	AIR BAG
10	G	SECURITY
15	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	L	-
7	B	-
9	O	-
10	P	-

Connector No.	M68
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
4	P	STOP LAMP SW
5	L	SHIFT UP SW
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE SW
11	G	AUTO MODE SW
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN SW
26	G	PADDLE DOWN

24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	BRAKE FLUID LEVEL SW
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
31	L	WASHER LEVEL SW
34	R	ILLUMINATION CONTROL
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

27	LG	COMM (METER->AMP)
28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)

JCNWA0008GE

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH2FW-NH

Terminal No.	Color of Wire	Signal Name
41	V	ACC
42	Y	FUEL LEVEL SENS
43	P	AMB SENS
44	G	IGN
45	Y	BAT
46	B	GND
47	L	CAN-H
48	W	BRAKE FLUID LEVEL SW
49	B	FUEL LEVEL SENS GND
50	BR	AMB SENS GND
51	B	GND

Terminal No.	Color of Wire	Signal Name
52	L	CAN-H
53	P	CAN-L

Connector No.	M87
Connector Name	AV CONTROL UNIT
Connector Type	TH4FW-NH

Terminal No.	Color of Wire	Signal Name
22	BR	12V
23	BR	24
24	BR	25
25	BR	26
26	BR	27
27	BR	28
28	BR	29
29	BR	30
30	BR	31
31	BR	32
32	BR	33
33	BR	34
34	BR	35
35	BR	36
36	BR	37
37	BR	38
38	BR	39
39	BR	40
40	BR	41
41	BR	42
42	BR	43
43	BR	44
44	BR	45
45	BR	46
46	BR	47
47	BR	48
48	BR	49
49	BR	50

Terminal No.	Color of Wire	Signal Name
52	L	CAN-H
53	P	CAN-L

Terminal No.	Color of Wire	Signal Name
72	P	CAN-L

Connector No.	M83
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH

Terminal No.	Color of Wire	Signal Name									
47	46	45	44	43	42	41	40	39	38	37	36
59	58	57	56	55	54	53	52	51	50	49	48

Terminal No.	Color of Wire	Signal Name
44	BR	COMM (DISP->CONT)
55	SHIELD	SHIELD
56	Y	COMM (CONT->DISP)

Connector No.	M107
Connector Name	ECM
Connector Type	MAA24FGY-MEA8-LH-Z

Terminal No.	Color of Wire	Signal Name
113	P	VHECANL1
114	L	VHECANLH1

Terminal No.	Color of Wire	Signal Name
2	W	-
35	L	-
36	P	-
43	P	-
44	L	-

Connector No.	M85
Connector Name	AV CONTROL UNIT
Connector Type	TH22FW-NH

Terminal No.	Color of Wire	Signal Name													
91	90	89	88	87	86	85	84	83	82	81	80	79	78	77	76
101	100	99	98	97	96	95	94	93	92						

Terminal No.	Color of Wire	Signal Name
86	L	CAN-H
87	P	CAN-L

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38NW-1S10

Terminal No.	Color of Wire	Signal Name																																															
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50

Terminal No.	Color of Wire	Signal Name
2	W	-
35	L	-
36	P	-
43	P	-
44	L	-

JCNWA0009GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

COMBINATION METER

< ECU DIAGNOSIS >

METER

Connector No.	M122
Connector Name	BOM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH

Terminal No.	Color of Wire	Signal Name
90	P	CAN-L
91	L	CAN-H

Connector No.	M123
Connector Name	BOM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH

Terminal No.	Color of Wire	Signal Name
141	G	SECURITY INDICATOR OUTPUT

Connector No.	M137
Connector Name	A/T DEVICE
Connector Type	TH12FW-NH

Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	L	-
4	B	-
5	G	-

Connector No.	M147
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	TK28FY-EX-5C

Terminal No.	Color of Wire	Signal Name
15	LG	AIR BAG W/L

JCNWA0010GE

INFOID:000000000964420

Fail Safe

FAIL SAFE

Combination meter performs fail-safe operation when unified meter and A/C amp. communication is malfunction.

Solution for communication error between the unified meter and A/C amp. and combination meter.

COMBINATION METER

< ECU DIAGNOSIS >

Function		Specifications	
Speedometer		Reset to zero by suspending communication.	A
Tachometer			B
Fuel gauge			C
Water temperature gauge			D
Illumination control		When suspending communication, change to nighttime mode.	E
Information display		The display turns off by suspending communication.	F
Buzzer		The buzzer turns off by suspending communication.	G
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.	H
	VDC OFF indicator lamp		I
	SLIP indicator lamp		J
	Brake warning lamp		K
	CRUISE warning lamp		L
	BA warning lamp		M
	High beam indicator	The lamp turns off by suspending communication.	N
	Turn signal indicator lamp		O
	Front fog indicator lamp		P
	Oil pressure warning lamp		
	Malfunction indicator lamp		
	A/T CHECK warning lamp		
	AWD warning lamp		
	Low tire pressure warning lamp		
	Key warning lamp		
	AFS OFF indicator lamp		
4WAS warning lamp			
Master warning lamp			

DTC Index

INFOID:000000000964421

Refer to [MWI-97, "DTC Index"](#).

MWI

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

UNIFIED METER AND A/C AMP.

Reference Value

INFOID:000000000964422

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
SPEED METER [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
SPEED OUTPUT [km/h]	Ignition switch ON	While driving	Equivalent to speedometer reading NOTE: 655.35 is displayed when the malfunction signal is received
ODO OUTPUT [km/h] or [mph]	Ignition switch ON	—	Equivalent to odometer reading in combination meter
TACHO METER [rpm]	Ignition switch ON	While driving	Equivalent to tachometer reading NOTE: 8191.875 is displayed when the malfunction signal is received
FUEL METER [lit.]	Ignition switch ON	—	Values according to fuel level
W TEMP METER [°C]	Ignition switch ON	—	Values according to engine coolant temperature NOTE: 215 is displayed when the malfunction signal is input
ABS W/L	Ignition switch ON	ABS warning lamp ON	On
		ABS warning lamp OFF	Off
VDC/TCS IND	Ignition switch ON	VDC indicator lamp ON	On
		VDC indicator lamp OFF	Off
SLIP IND	Ignition switch ON	Slip indicator lamp ON	On
		Slip indicator lamp OFF	Off
BRAKE W/L	Ignition switch ON	Brake warning lamp ON	On
		Brake warning lamp OFF	Off
DOOR W/L	Ignition switch ON	Door warning displayed	On
		Door warning not displayed	Off
TRUNK/GLAS-H	Ignition switch ON	Trunk warning displayed	On
		Trunk warning not displayed	Off
HI-BEAM IND	Ignition switch ON	Hi-beam indicator lamp ON	On
		Hi-beam indicator lamp OFF	Off
TURN IND	Ignition switch ON	Turn indicator lamp ON	On
		Turn indicator lamp OFF	Off
FR FOG IND	Ignition switch ON	Front fog indicator lamp ON	On
		Front fog indicator lamp OFF	Off
RR FOG IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
LIGHT IND	Ignition switch ON	Light indicator lamp ON	On
		Light indicator lamp OFF	Off

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status	
OIL W/L	Ignition switch ON	Oil pressure warning lamp ON	On	A
		Oil pressure warning lamp OFF	Off	
MIL	Ignition switch ON	Malfunction warning lamp ON	On	B
		Malfunction warning lamp OFF	Off	
CRUISE IND	Ignition switch ON	Cruise indicator displayed	On	C
		Cruise indicator not displayed	Off	
SET IND	Ignition switch ON	Set indicator lamp ON	On	D
		Set indicator lamp OFF	Off	
CRUISE W/L	Ignition switch ON	Cruise warning lamp ON	On	E
		Cruise warning lamp OFF	Off	
BA W/L	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off	E
ATC/T-AMT W/L	Ignition switch ON	A/T check warning lamp ON	On	F
		A/T check warning lamp OFF	Off	
4WD W/L	Ignition switch ON	AWD warning lamp ON	On	G
		AWD warning lamp OFF	Off	
4WD LOCK IND	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off	H
FUEL W/L	Ignition switch ON	Low-fuel warning displayed	On	I
		Low-fuel warning not displayed	Off	
WASHER W/L	Ignition switch ON	Washer warning displayed	On	J
		Washer warning not displayed	Off	
AIR PRES W/L	Ignition switch ON	Low tire pressure lamp ON	On	J
		Low tire pressure lamp OFF	Off	
KEY G/Y W/L	Ignition switch ON	Key warning lamp ON	On	K
		Key warning lamp OFF	Off	
AFS OFF IND	Ignition switch ON	AFS OFF indicator lamp ON	On	L
		AFS OFF indicator lamp OFF	Off	
4WAS/RAS W/L	Ignition switch ON	4WAS warning lamp ON	On	M
		4WAS warning lamp OFF	Off	

MWI

O

P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status
LCD	Ignition switch ON	Engine start information display (A/T model)	B&P I
		Engine start information display (M/T model)	C&P I
	Ignition switch ACC	Engine start information display (A/T model)	B&P N
		Engine start information display (M/T model)	C&P N
	Ignition switch LOCK	Key ID warning display	ID NG
	Ignition switch LOCK	Steering lock information display	ROTAT
	Ignition switch LOCK	P position warning display	SFT P
	Ignition switch LOCK	Intelligent Key insert information display	INSRT
	Ignition switch LOCK	Intelligent Key low battery warning display	BATT
	Ignition switch ON	Take away warning display	NO KY
	Ignition switch LOCK	Key warning display	OUTKY
Ignition switch ON	ICC sensor integrated unit warning display	LK WN	
ACC TARGET	Ignition switch ON	Vehicle ahead detection indicator displayed	On
		Vehicle ahead detection indicator not displayed	Off
ACC DISTANCE	Ignition switch ON	When following distance set to "LONG"	LONG
		When following distance set to "MIDDLE"	MID
		When following distance set to "SHORT"	SHORT
		Set distance indicator not displayed	Off
ACC OWN VHL	Ignition switch ON	Own vehicle indicator displayed	On
		Own vehicle indicator not displayed	Off
ACC SET SPEED	Ignition switch ON	Set vehicle speed indicator not displayed	Off
		Set vehicle speed indicator displayed	On
ACC UNIT	Ignition switch ON	Set vehicle speed indicator unit display ON	On
		Set vehicle speed indicator unit display OFF	Off
SHIFT IND	Ignition switch ON	Shift position indicator P display	P
		Shift position indicator R display	R
		Shift position indicator N display	N
		Shift position indicator D display	D
		Shift position indicator M1 display	M1
		Shift position indicator M2 display	M2
		Shift position indicator M3 display	M3
		Shift position indicator M4 display	M4
Shift position indicator M5 display	M5		
AT S MODE SW	Ignition switch ON	Snow mode switch ON	On
		Snow mode switch OFF	Off
AT P MODE SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off

UNIFIED METER AND A/C AMP.


< ECU DIAGNOSIS >

Monitor Item	Condition		Value/Status
M RANGE SW	Ignition switch ON	Selector lever manual mode position	On
		Other than the above	Off
NM RANGE SW	Ignition switch ON	Selector lever manual mode position	Off
		Other than the above	On
AT SFT UP SW	Ignition switch ON	Selector lever + position	On
		Other than the above	Off
AT SFT DWN SW	Ignition switch ON	Selector lever – position	On
		Other than the above	Off
ST SFT UP SW	Ignition switch ON	Paddle shifter switch up operation	On
		Other than the above	Off
ST SFT DWN SW	Ignition switch ON	Paddle shifter switch down operation	On
		Other than the above	Off
COMP FB SIG	Ignition switch ON	A/C compressor activation condition	On
		A/C compressor deactivation condition	Off
4WD LOCK SW	Ignition switch ON	NOTE: This item is displayed, but cannot be monitored.	Off
PKB SW	Ignition switch ON	Parking brake switch ON	On
		Parking brake switch OFF	Off
BUCKLE SW	Ignition switch ON	Seat belt not fastened	On
		Seat belt fastened	Off
BRAKE OIL SW	Ignition switch ON	Brake fluid level switch ON	On
		Brake fluid level switch OFF	Off
DISTANCE [km]	Ignition switch ON	—	Possible driving distance calculated by unified meter and A/C amp.
OUTSIDE TEMP [°C] or [°F]	Ignition switch ON	—	Equivalent to ambient temperature NOTE: This may not match the indicated value on the information display.
FUEL LOW SIG	Ignition switch ON	Low-fuel warning displayed	
BUZZER	Ignition switch ON	Buzzer ON	On
		Buzzer OFF	Off

NOTE:

Some items are not available according to vehicle specification.




TERMINAL LAYOUT



PHYSICAL VALUES






UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
4 (P)	Ground	Stop lamp switch signal	Input	Ignition switch OFF	Brake pedal is depressed	12 V
					Other than the above	0 V
5 (L)	Ground	Manual mode shift up signal	Input	Ignition switch ON	Selector lever UP operation	0 V
					Other than the above	12 V
6 (O)	Ground	Paddle shifter up signal	Input	Ignition switch ON	<ul style="list-style-type: none"> • Selector lever DS position • Paddle shift up operation 	0 V
					Other than the above	12 V
7 (GR)	Ground	Communication signal (AMP. → METER)	Output	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIA3362E</p>
8 (L)	Ground	Vehicle speed signal output (2-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0015GB</p>
9 (SB)	Ground	Seat belt buckle switch signal (driver side)	Input	Ignition switch ON	When seat belt is fastened	12 V
					When seat belt is not fastened	0 V
10 (W)	Ground	Manual mode signal	Input	Ignition switch ON	Selector lever DS position	0 V
					Other than the above	12 V
11 (G)	Ground	Not manual mode signal	Input	Ignition switch ON	Selector lever DS position	12 V
					Other than the above	0 V
14 (BR)	Ground	Communication signal (LCD → AMP.)	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">JSNIA0028GB</p>
23 (Y)	Ground	A/T snow switch signal	Input	Ignition switch ON	Snow mode switch ON	12 V
					Snow mode switch OFF	0 V
25 (V)	Ground	Manual mode shift down signal	Input	Ignition switch ON	Selector lever down operation	0 V
					Other than the above	12 V

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
26 (G)	Ground	Paddle shift down signal	Input	Ignition switch ON	0 V
				Other than the above	12 V
27 (LG)	Ground	Communication signal (METER → AMP.)	Input	Ignition switch ON	—  SKIA3361E
28 (R)	Ground	Vehicle speed signal output (8-pulse)	Output	Ignition switch ON	Speedometer operated [When vehicle speed is approx. 40 km/h (25 MPH)]  JSNIA0012GB
30 (V)	Ground	Parking brake switch signal	Input	Parking brake ON	0 V
				Parking brake OFF	 JSNIA0007GB
34 (Y)	Ground	Communication signal (AMP. → LCD)	Output	Ignition switch ON	—  JSNIA0027GB
41 (V)	Ground	ACC power supply	Input	Ignition switch ACC	Battery voltage
42 (Y)	Ground	Fuel level sensor signal	Input	Ignition switch ON	—  JSNIA0013GB

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
45 (P)	Ground	Ambient sensor signal	Input	—	—	<p style="text-align: right; font-size: small;">JSNIA0014GB</p>
53 (G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
54 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
55 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
56 (L)	Ground	CAN-H	—	—	—	—
57 (W)	Ground	Brake fluid level switch signal	Input	Ignition switch ON	Brake fluid level is normal.	<p style="text-align: right; font-size: small;">JSNIA0008GB</p>
				—	The brake fluid level is lower than the low level	0 V
58 (B)	Ground	Fuel level sensor signal ground	—	Ignition switch ON	—	0 V
61 (BR)	Ground	Ambient sensor signal ground	—	Ignition switch ON	—	0 V
71 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
72 (P)	Ground	CAN-L	—	—	—	—

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Wiring Diagram — METER —

INFOID:00000000964423



2006/09/15

JCNWA0001GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

- ◊ A : With A/T
- ◊ NV : With NAVI
- ◊ ON : Without NAVI
- ◊ IC : With ICC
- ◊ AS : With 4WAS
- ◊ PA : With automatic drive positioner or 4WAS
- ◊ AP : Without automatic drive positioner and 4WAS
- ◊ SS : With paddle shifter switch

*: This connector is not shown in "Harness Layout".




JCNWA0002GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

⬡: With ICC



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P























JCNWA0003GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

















Connector No.	B1	Connector No.	B13	Connector No.	B14	Connector No.	B21	Connector No.	E6	Connector No.	B32	Connector No.	E5	Connector No.	E53	Connector No.	E54	Connector No.	E56	
Connector Name	WIRE TO WIRE	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	SEAT BELT BUCKLE SWITCH (DRIVER SIDE)	PARKING BRAKE SWITCH	FUEL LEVEL SENSOR UNIT (SUB)	FUEL LEVEL SENSOR UNIT (SUB)	FUEL LEVEL SENSOR UNIT (SUB)	FUEL LEVEL SENSOR UNIT (SUB)	IPDM F/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	FUEL LEVEL SENSOR UNIT AND FUEL PUMP (MAIN)	4WAS MAIN CONTROL UNIT	4WAS MAIN CONTROL UNIT	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	4WAS MAIN CONTROL UNIT	4WAS MAIN CONTROL UNIT	4WAS MAIN CONTROL UNIT	IPDM F/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	
Connector Type	TH80FW-TM4	AQ3FW	AQ3FW	PROTB-A	E02FGY-RS	E02FGY-RS	E02FGY-RS	E02FGY-RS	TH08FW-NH	E02FGY-RS	A38FW-M4	A38FW-M4	SAA38MB-RS10-SJZ2	SAA38MB-RS10-SJZ2	SAA38MB-RS10-SJZ2	A38FW-M4	A38FW-M4	A38FW-M4	TH08FW-NH	
																				
Terminal No.	23	24	25	26	80	82	96	97	1	2	1	2	1	35	35	1	2	1	39	40
Color of Wire	L	P	L	P	Y	B	V	SB	L	Y	SB	B	V	Y	Y	L	P	L	P	L
Signal Name	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

JCNWA0004GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No. E7	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	TH20FW-CS12-M4			Terminal No. 75	Color of Wire Y	Signal Name -
Connector No. E47	BRAKE FLUID LEVEL SWITCH	YV02F5Y			Terminal No. 1 2	Color of Wire W B/W	Signal Name -
Connector No. E41	ABS ACTUATOR AND ELECTRIC UNIT	BAA42FB-AH24-LH			Terminal No. 14 35	Color of Wire P L	Signal Name CAN-L CAN-H
Connector No. E32	WASHER LEVEL SWITCH	Z02FBR			Terminal No. 1 2	Color of Wire LG B	Signal Name -
Connector No. E51	ICC BRAKE HOLD RELAY	HS20FL-M2			Terminal No. 1 2 3 5	Color of Wire B V R P	Signal Name -
Connector No. E76	AMBIENT SENSOR	RS02FB			Terminal No. 1 2	Color of Wire G P	Signal Name -
Connector No. E67	ICC SENSOR INTEGRATED UNIT	RS06FB-PR			Terminal No. 2 3 4 5 6	Color of Wire V L P	Signal Name BRK LMP RLY CAN-H CAN-L
Connector No. E103	FUSE BLOCK (J/B)	NS18FW-S5			Terminal No. 2F 8F	Color of Wire W L	Signal Name -

JCNWA0005GE


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >


METER

Connector No.	F1
Connector Name	WIRE TO WIRE
Connector Type	SAA38FB-RS10-SJZ2



Terminal No.	Color of Wire	Signal Name
35	Y	-

Connector No.	E110
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name
1	L	-
2	W	-
3	L	-
4	SB	-

Connector No.	E107
Connector Name	PARKING BRAKE SWITCH (A/T)
Connector Type	TE01FW




Terminal No.	Color of Wire	Signal Name
1	O	-

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH06FW-CS16-TM4




Terminal No.	Color of Wire	Signal Name
6	P	-
7	L	-
16	O	-
80	W	-
81	P	-
82	G	-
93	LG	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK38FW-NS10



Terminal No.	Color of Wire	Signal Name
2	G	-
35	L	-
36	P	-
43	P	-
44	L	-

Connector No.	F51
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY



Terminal No.	Color of Wire	Signal Name
3	L	-
8	P	-

Connector No.	F37
Connector Name	OIL PRESSURE SWITCH
Connector Type	ED1FGY-RS-AR



Terminal No.	Color of Wire	Signal Name
1	Y	-

Connector No.	F38
Connector Name	ALTERNATOR
Connector Type	HS03FB



Terminal No.	Color of Wire	Signal Name
2	G	L


JCNWA0006GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No.	F108
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH




Terminal No. of Wire	Color	Signal Name
8	L	CAN-H
16	P	CAN-L

Connector No.	F151
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	SF10FEGY




Terminal No. of Wire	Color	Signal Name
1	BR	CAN-H
2	L/Y	CAN-L

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS09FW-M2




Terminal No. of Wire	Color	Signal Name
1A	GR	-
2A	G	-
5A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FW-GS




Terminal No. of Wire	Color	Signal Name
10B	P	-
16B	Y	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FW-GS




Terminal No. of Wire	Color	Signal Name
12C	R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS19-TM4




Terminal No. of Wire	Color	Signal Name
6	P	-
7	L	-
18	V	-
80	VI	-
81	BR	-
93	L	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4



Terminal No. of Wire	Color	Signal Name
23	L	-
24	P	-
25	L	-
26	P	-
80	Y	-
82	B	-
96	V	-
97	SB	-

Connector No.	M16
Connector Name	AFS CONTROL UNIT
Connector Type	TH40FW-NH



Terminal No. of Wire	Color	Signal Name
7	P	CAN-L
30	L	CAN-H

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




JCNWA0007GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER

Connector No.	M32
Connector Name	PADDLE SHIFTER (SHIFT DOWN)
Connector Type	AC3FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	G	-

Connector No.	M39
Connector Name	PADDLE SHIFTER (SHIFT UP)
Connector Type	AC4FW




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-
3	O	-

Connector No.	M63
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name
1	GR	BAT
2	LG	COMM (METER->AMP)
3	GR	COMM (AMP->METER)
5	B	GND
6	W	ALTERNATOR
7	LG	AIR BAG
10	G	SECURITY
15	B	GND
16	B	METER CONTROL SW GND
21	R	IGN
22	B	GND

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-RH



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	L	-
7	B	-
9	O	-
10	P	-

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name
4	P	STOP LAMP SW
5	L	SHIFT UP SW
6	O	PADDLE UP
7	GR	COMM (AMP->METER)
8	L	VEHICLE SPEED (2-PULSE)
9	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
10	W	MANUAL MODE SW
11	G	AUTO MODE SW
14	BR	COMM (LCD->AMP)
25	V	SHIFT DOWN SW
26	G	PADDLE DOWN

24	BR	COMM (LCD->AMP)
25	Y	COMM (AMP->LCD)
26	R	VEHICLE SPEED (8-PULSE)
27	V	PARKING BRAKE SW
28	W	BRAKE FLUID LEVEL SW
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
31	L	WASHER LEVEL SW
34	R	ILLUMINATION CONTROL
36	LG	SELECT SW
37	SB	ENTER SW
38	L	TRIP A/B RESET SW
39	P	ILLUMINATION CONTROL SW (-)
40	O	ILLUMINATION CONTROL SW (+)

27	LG	COMM (METER->AMP)
28	R	VEHICLE SPEED (8-PULSE)
30	V	PARKING BRAKE SW
34	Y	COMM (AMP->LCD)


JCNWA0008GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >


METER

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH2FW-NH



Terminal No.	Color of Wire	Signal Name
41	V	ACC
42	Y	FUEL LEVEL SENS
43	P	AMB SENS
44	G	IGN
45	Y	BAT
46	B	GND
47	L	CAN-H
48	W	BRAKE FLUID LEVEL SW
49	B	FUEL LEVEL SENS GND
50	BR	AMB SENS GND
51	B	GND

Connector No.	M87
Connector Name	AV CONTROL UNIT
Connector Type	TH4FW-NH



Terminal No.	Color of Wire	Signal Name
22	L	CAN-H
23	P	CAN-L


Terminal No.	72
Color of Wire	P
Signal Name	CAN-L

Connector No.	M83
Connector Name	AV CONTROL UNIT
Connector Type	TH2FW-NH




Terminal No.	Color of Wire	Signal Name
44	BR	COMM (DISP->CONT)
55	SHIELD	SHIELD
56	Y	COMM (CONT->DISP)

Connector No.	M107
Connector Name	ECM
Connector Type	MAA24GY-NEA8-LH-Z




Terminal No.	Color of Wire	Signal Name
113	P	VHECANL1
114	L	VHECANLH1

Connector No.	M116
Connector Name	WIRE TO WIRE
Connector Type	TK38NW-1S10



Terminal No.	Color of Wire	Signal Name
2	W	-
35	L	-
36	P	-
43	P	-
44	L	-

Connector No.	M85
Connector Name	AV CONTROL UNIT
Connector Type	TH2FW-NH



Terminal No.	Color of Wire	Signal Name
86	L	CAN-H
87	P	CAN-L

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



JCNWA0009GE

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

METER		M122		M123		M137		M147	
Connector No.	BOM (BODY CONTROL MODULE)	Connector No.	BOM (BODY CONTROL MODULE)	Connector No.	A/T DEVICE	Connector No.	AIR BAG DIAGNOSIS SENSOR UNIT	Connector No.	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Name	TH40FB-NH	Connector Name	TH40FG-NH	Connector Name	TH12FW-NH	Connector Name	TK28FY-EX-5C	Connector Name	TK28FY-EX-5C
Connector Type	TH40FB-NH	Connector Type	TH40FG-NH	Connector Type	TH12FW-NH	Connector Type	TK28FY-EX-5C	Connector Type	TK28FY-EX-5C

Terminal No.	Color of Wire	Signal Name
90	P	CAN-L
91	L	CAN-H

Terminal No.	Color of Wire	Signal Name
141	G	SECURITY INDICATOR OUTPUT

Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	L	-
4	B	-
5	G	-

Terminal No.	Color of Wire	Signal Name
15	LG	AIR BAG W/L

Fail Safe

FAIL SAFE

The unified meter and A/C amp. activates the fail-safe control if CAN communication with each unit is malfunctioning.

JCNWA0010GE

INFOID:000000000964424

UNIFIED METER AND A/C AMP.

< ECU DIAGNOSIS >

Function		Specifications
Speedometer		Reset to zero by suspending communication.
Tachometer		
Fuel gauge		
Water temperature gauge		
Illumination control		When suspending communication, change to nighttime mode.
Information display		The display turns off by suspending communication.
Buzzer		The buzzer turns off by suspending communication.
Warning lamp/indicator lamp	ABS warning lamp	The lamp turns on by suspending communication.
	VDC OFF indicator lamp	
	SLIP indicator lamp	
	Brake warning lamp	
	CRUISE warning lamp	
	BA warning lamp	
	AWD warning lamp	
	Low tire pressure warning lamp	
	4WAS warning lamp	The lamp blinking caused by communication malfunction
	AFS OFF indicator lamp	
	High beam indicator	The lamp turns off by suspending communication.
	Turn signal indicator lamp	
	Front fog indicator lamp	
	Oil pressure warning lamp	
	Malfunction indicator lamp	
	A/T CHECK warning lamp	
Key warning lamp		
Master warning lamp		

DTC Index

INFOID:000000000964425

Display contents of CONSULT-III	Time	Diagnostic item is detected when ...	Refer to
CAN COMM CIRCUIT [U1000]	CRNT, 1 - 39	When unified meter and A/C amp. is not transmitting or receiving CAN communication signal for 2 seconds or more.	MWI-40
CONTROL UNIT (CAN) [U1010]	CRNT, 1 - 39	When detecting error during the initial diagnosis of CAN controller of unified meter and A/C amp.	MWI-41
COMM ERROR 1 [B2201]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-42
COMM ERROR 2 [B2202]	CRNT, 1 - 39	If a communication error is present in the communication line between unified meter and A/C amp. and combination meter for 2 seconds or more.	MWI-44
VEHICLE SPEED [B2205]	CRNT, 1 - 39	The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more.	MWI-46
ENGINE SPEED [B2267]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.	MWI-47
WATER TEMP [B2268]	CRNT, 1 - 39	If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.	MWI-48

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000000964426

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
FR WIPER HI	Other than front wiper switch HI	OFF
	Front wiper switch HI	ON
FR WIPER LOW	Other than front wiper switch LO	OFF
	Front wiper switch LO	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER INT	Other than front wiper switch INT	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Front wiper is not in STOP position	OFF
	Front wiper is in STOP position	ON
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	Wiper intermittent dial position
TURN SIGNAL R	Other than turn signal switch RH	OFF
	Turn signal switch RH	ON
TURN SIGNAL L	Other than turn signal switch LH	OFF
	Turn signal switch LH	ON
TAIL LAMP SW	Other than lighting switch 1ST and 2ND	OFF
	Lighting switch 1ST or 2ND	ON
HI BEAM SW	Other than lighting switch HI	OFF
	Lighting switch HI	ON
HEAD LAMP SW 1	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
HEAD LAMP SW 2	Other than lighting switch 2ND	OFF
	Lighting switch 2ND	ON
PASSING SW	Other than lighting switch PASS	OFF
	Lighting switch PASS	ON
AUTO LIGHT SW	Other than lighting switch AUTO	OFF
	Lighting switch AUTO	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
RR FOG SW	NOTE: The item is indicated, but not monitored.	OFF
DOOR SW-DR	Driver door closed	OFF
	Driver door opened	ON
DOOR SW-AS	Passenger door closed	OFF
	Passenger door opened	ON
DOOR SW-RR	Rear RH door closed	OFF
	Rear RH door opened	ON
DOOR SW-RL	Rear LH door closed	OFF
	Rear LH door opened	ON

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	OFF	A
CDL LOCK SW	Other than power door lock switch LOCK	OFF	B
	Power door lock switch LOCK	ON	
CDL UNLOCK SW	Other than power door lock switch UNLOCK	OFF	C
	Power door lock switch UNLOCK	ON	
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	OFF	D
	Driver door key cylinder LOCK position	ON	
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	OFF	D
	Driver door key cylinder UNLOCK position	ON	
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	OFF	E
HAZARD SW	Hazard switch is not pressed	OFF	F
	Hazard switch is pressed	ON	
REAR DEF SW	NOTE: The item is indicated, but not monitored.	OFF	
H/L WASH SW	NOTE: The item is indicated, but not monitored.	OFF	G
TR CANCEL SW	Trunk lid opener cancel switch OFF	OFF	H
	Trunk lid opener cancel switch ON	ON	
TR/BD OPEN SW	Trunk lid opener switch OFF	OFF	I
	While the trunk lid opener switch is turned ON	ON	
TRNK/HAT MNTR	Trunk lid closed	OFF	J
	Trunk lid opened	ON	
RKE-LOCK	LOCK button of Intelligent Key is not pressed	OFF	J
	LOCK button of Intelligent Key is pressed	ON	
RKE-UNLOCK	UNLOCK button of Intelligent Key is not pressed	OFF	K
	UNLOCK button of Intelligent Key is pressed	ON	
RKE-TR/BD	TRUNK OPEN button of Intelligent Key is not pressed	OFF	L
	TRUNK OPEN button of Intelligent Key is pressed	ON	
RKE-PANIC	PANIC button of Intelligent Key is not pressed	OFF	M
	PANIC button of Intelligent Key is pressed	ON	
RKE-P/W OPEN	UNLOCK button of Intelligent Key is not pressed	OFF	M
	UNLOCK button of Intelligent Key is pressed and held	ON	
RKE-MODE CHG	LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously	OFF	MWI
	LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously	ON	
OPTICAL SENSOR	Outside of the vehicle bright	Close to 5 V	O
	Outside of the vehicle dark	Close to 0 V	
REQ SW-DR	Driver door request switch is not pressed	OFF	P
	Driver door request switch is pressed	ON	
REQ SW-AS	Passenger door request switch is not pressed	OFF	P
	Passenger door request switch is pressed	ON	
REQ SW-BD/TR	Trunk request switch is not pressed	OFF	P
	Trunk request switch is pressed	ON	

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
PUSH SW	Push-button ignition switch (push switch) is not pressed	OFF
	Push-button ignition switch (push switch) is pressed	ON
IGN RLY2 -F/B	Ignition switch in OFF or ACC position	OFF
	Ignition switch in ON position	ON
ACC RLY -F/B	Ignition switch in OFF position	OFF
	Ignition switch in ACC or ON position	ON
CLUCH SW	The clutch pedal is not depressed	OFF
	The clutch pedal is depressed	ON
BRAKE SW 1	The brake pedal is not depressed	ON
	The brake pedal is depressed	OFF
DETE/CANCL SW	Selector lever in P position	OFF
	Selector lever in any position other than P	ON
SFT PN/N SW	Selector lever in any position other than P and N	OFF
	Selector lever in P or N position	ON
S/L -LOCK	Steering is locked	OFF
	Steering is unlocked	ON
S/L -UNLOCK	Steering is unlocked	OFF
	Steering is locked	ON
S/L RELAY-F/B	Ignition switch is OFF or ACC position	OFF
	Ignition switch is ON position	ON
UNLK SEN-DR	Driver door is unlocked	OFF
	Driver door is locked	ON
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed	OFF
	Push-button ignition switch (push-switch) is pressed	ON
IGN RLY1 -F/B	Ignition switch is OFF or ACC position	OFF
	Ignition switch is ON position	ON
DETE SW -IPDM	Selector lever in P position	OFF
	Selector lever in any position other than P	ON
SFT PN -IPDM	Selector lever in any position other than P and N	OFF
	Selector lever in P or N position	ON
SFT P -MET	Selector lever in any position other than P	OFF
	Selector lever in P position	ON
SFT N -MET	Selector lever in any position other than N	OFF
	Selector lever in N position	ON
ENGINE STATE	Engine stopped	STOP
	While the engine stalls	STALL
	At engine cranking	CRANK
	Engine running	RUN
S/L LOCK-IPDM	Steering is locked	OFF
	Steering is unlocked	ON
S/L UNLK-IPDM	Steering is unlocked	OFF
	Steering is locked	ON
S/L RELAY-REQ	Ignition switch in OFF or ACC position	OFF
	Ignition switch in ON position	ON

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
VEH SPEED 1	While driving	Equivalent to speedometer reading	A
VEH SPEED 2	While driving	Equivalent to speedometer reading	
DOOR STAT-DR	Driver door is locked	LOCK	B
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Driver door is unlocked	UNLK	
DOOR STAT-AS	Passenger door is locked	LOCK	C
	Wait with selective UNLOCK operation (5 seconds)	READY	
	Passenger door is unlocked	UNLK	D
ID OK FLAG	Ignition switch in ACC or ON position	RESET	
	Ignition switch in OFF position	SET	E
PRMT ENG STRT	The engine start is prohibited	RESET	
	The engine start is permitted	SET	F
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	RESET	
KEY SW -SLOT	Intelligent Key is not inserted into key slot	OFF	G
	Intelligent Key is inserted into key slot	ON	
RKE OPE COUN1	During the operation of Intelligent Key	Operation frequency of Intelligent Key	
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—	H
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire	I
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire	J
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire	
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire	K
ID REGST FL1	ID of front LH tire transmitter is registered	DONE	
	ID of front LH tire transmitter is not registered	YET	L
ID REGST FR1	ID of front RH tire transmitter is registered	DONE	
	ID of front RH tire transmitter is not registered	YET	M
ID REGST RR1	ID of rear RH tire transmitter is registered	DONE	
	ID of rear RH tire transmitter is not registered	YET	
ID REGST RL1	ID of rear LH tire transmitter is registered	DONE	
	ID of rear LH tire transmitter is not registered	YET	
WARNING LAMP	Tire pressure indicator OFF	OFF	MWI
	Tire pressure indicator ON	ON	
BUZZER	Tire pressure warning alarm is not sounding	OFF	O
	Tire pressure warning alarm is sounding	ON	P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


TERMINAL LAYOUT



PHYSICAL VALUES

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (Y)	Ground	P/W power supply (BAT)	Output	Ignition switch OFF		Battery voltage
3 (O)	Ground	P/W power supply (RAP)	Output	Ignition switch ON		Battery voltage
4 (LG)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time		0 V
				Any other time after passing the interior room lamp battery saver operation time		Battery voltage
5 (V)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
7 (Y)	Ground	Step lamp	Output	Step lamp	ON	0 V
					OFF	Battery voltage
8 (V)	Ground	All doors, fuel lid LOCK	Output	All doors, fuel lid	LOCK (Actuator is activated)	Battery voltage
					Other than LOCK (Actuator is not activated)	0 V
9 (G)	Ground	Driver door, fuel lid UNLOCK	Output	Driver door, fuel lid	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
10 (BR)	Ground	Rear RH door and rear LH door UN- LOCK	Output	Rear RH door and rear LH door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V
11 (R)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
13 (B)	Ground	Ground	—	Ignition switch ON		0 V
14 (W)	Ground	Push-button ignition switch illumination ground	Output	Tail lamp	OFF	0 V
					ON	<p>NOTE: When the illumination brightening/dimming level is in the neutral position</p>  <p style="text-align: right; font-size: small;">JSNIA0010GB</p>
15 (Y)	Ground	ACC indicator lamp	Output	Ignition switch	OFF	Battery voltage
					ACC or ON	0 V

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
17 (W)	Ground	Turn signal (front RH)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	 6.5 V
18 (O)	Ground	Turn signal (front LH)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	 6.5 V
19 (V)	Ground	Room lamp timer control	Output	Interior room lamp	OFF Battery voltage
				ON	0 V
20 (V)	Ground	Turn signal (rear RH)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	 6.5 V
23 (G)	Ground	Trunk lid opening.	Output	Trunk lid	Open (Trunk lid opener ac- tuator is activated) Battery voltage
				Close (Trunk lid opener ac- tuator is not activated)	0 V
25 (G)	Ground	Turn signal (rear LH)	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	 6.5 V
30 (R)	Ground	Trunk room lamp	Output	Trunk room lamp	ON 0 V
				OFF	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
34 (SB)	Ground	Trunk room antenna 1 (-)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
35 (V)	Ground	Trunk room antenna 1 (+)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
38 (B)	Ground	Rear bumper anten- na (-)	Output	When the trunk lid request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P








BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
39 (W)	Ground	Rear bumper antenna (+)	Output	When Intelligent Key is in the antenna detection area	 JMKIA0062GB
				When Intelligent Key is not in the antenna detection area	 JMKIA0063GB
47 (Y)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC Battery voltage ON 0 V
50 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	 JPMIA0011GB 11.8 V
					0 V
52 (SB)	Ground	Starter relay control	Output	Ignition switch OFF (M/T models)	When the clutch pedal is depressed Battery voltage When the clutch pedal is not depressed 0 V
				Ignition switch ON (A/T models)	When selector lever is in P or N position and the brake is depressed Battery voltage
					When selector lever is in P or N position and the brake is not depressed 0 V
					0 V
61 (W)	Ground	Trunk request switch	Input	Trunk request switch	ON (Pressed) 0 V OFF (Not pressed)
				 JPMIA0016GB 1.0 V	
64 (V)	Ground	Request switch buzzer	Output	Request switch buzzer	Sounding 0 V Not sounding Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
67 (GR)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	Pressed	0 V
					Not pressed	 <p style="text-align: right; margin-right: 50px;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
68 (BR)	Ground	Rear RH door switch	Input	Rear RH door switch	OFF (When rear RH door closes)	 <p style="text-align: right; margin-right: 50px;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (When rear RH door opens)	0 V
69 (R)	Ground	Rear LH door switch	Input	Rear LH door switch	OFF (When rear LH door closes)	 <p style="text-align: right; margin-right: 50px;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					ON (When rear LH door opens)	0 V
72 (R)	Ground	Room antenna 2 (-) (center console)	Output	Ignition switch OFF	When Intelligent Key is in the passenger compart- ment	 <p style="text-align: right; margin-right: 50px;">JMKIA0062GB</p>
					When Intelligent Key is not in the passenger compart- ment	 <p style="text-align: right; margin-right: 50px;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
73 (G)	Ground	Room antenna 2 (+) (center console)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compart- ment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
74 (SB)	Ground	Passenger door an- tenna (-)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
75 (BR)	Ground	Passenger door an- tenna (+)	Output	When the pas- senger door re- quest switch is operated with ig- nition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
+	-				
76 (V)	Ground	Driver door antenna (-)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the driver door request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
77 (LG)	Ground	Driver door antenna (+)	Output	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When the driver door request switch is operated with ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>
78 (Y)	Ground	Room antenna (-) (instrument panel)	Output	Ignition switch OFF	<p style="text-align: right; font-size: small;">JMKIA0062GB</p>
				When Intelligent Key is not in the passenger compartment	<p style="text-align: right; font-size: small;">JMKIA0063GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
79 (BR)	Ground	Room antenna (+) (instrument panel)	Output	Ignition switch OFF		
				When Intelligent Key is not in the passenger compart- ment		
80 (GR)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
81 (W)	Ground	NATS antenna amp (built in key slot)	Input/ Output	During waiting	Ignition switch is pressed while inserting the Intelli- gent Key into the key slot.	Just after pressing ignition switch. Pointer of tester should move.
82 (R)	Ground	Ignition relay (relay box) control	Output	Ignition switch	OFF or ACC	0 V
				ON	Battery voltage	
83 (Y)	Ground	Remote keyless entry receiver signal	Input/ Output	During waiting		
				When operating either button on Intelligent Key		

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
87 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switch OFF (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0041GB</p> <p style="margin: 0;">1.4 V</p> </div>
				Combination switch	Front fog lamp switch ON (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0037GB</p> <p style="margin: 0;">1.3 V</p> </div>
				Any of the conditions below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 6 • Wiper intermittent dial 7 	<div style="text-align: right;">  <p style="font-size: small; margin: 0;">JPMIA0040GB</p> <p style="margin: 0;">1.3 V</p> </div>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
88 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <small>JPMIA0041GB</small> 1.4 V
					Lighting switch HI (Wiper intermittent dial 4)	 <small>JPMIA0036GB</small> 1.3 V
					Lighting switch 2ND (Wiper intermittent dial 4)	 <small>JPMIA0037GB</small> 1.3 V
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 	 <small>JPMIA0040GB</small> 1.3 V
89 (BR)	Ground	Push-button ignition switch (push switch)	Input	Push-button igni- tion switch (push switch)	Pressed	0 V
					Not pressed	Battery voltage
90 (P)	Ground	CAN - L	Input/ Output	—	—	
91 (L)	Ground	CAN - H	Input/ Output	—	—	
92 (LG)	Ground	Key slot illumination	Output	Key slot illumina- tion	OFF	0 V
					Blinking	 <small>JPMIA0015GB</small> 6.5 V
					ON	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
93 (V)	Ground	ON indicator lamp	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
95 (O)	Ground	ACC relay control	Output	Ignition switch	OFF	0 V
					ACC or ON	Battery voltage
96 (GR)	Ground	A/T device (detention switch) power supply	Output	—		Battery voltage
97 (L)	Ground	Steering lock condition No. 1	Input	Steering lock	LOCK status	0 V
					UNLOCK status	Battery voltage
98 (P)	Ground	Steering lock condition No. 2	Input	Steering lock	LOCK status	Battery voltage
					UNLOCK status	0 V
99 (R)	Ground	Selector lever P position switch	Input	Selector lever	P position	0 V
					Any position other than P	Battery voltage
100 (G)	Ground	Passenger door request switch	Input	Passenger door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p style="text-align: center;">1.0 V</p>
101 (SB)	Ground	Driver door request switch	Input	Driver door request switch	ON (Pressed)	0 V
					OFF (Not pressed)	 <p style="text-align: center;">1.0 V</p>
102 (O)	Ground	Blower fan motor relay control	Output	Ignition switch	OFF or ACC	0 V
					ON	Battery voltage
103 (LG)	Ground	Remote keyless entry receiver power supply	Output	Ignition switch OFF		Battery voltage
106 (W)	Ground	Steering wheel lock unit power supply	Output	Ignition switch	OFF or ACC	Battery voltage
					ON	0 V

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P







BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
107 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	<p style="text-align: right;">1.4 V</p>
					Turn signal switch LH	<p style="text-align: right;">1.3 V</p>
					Turn signal switch RH	<p style="text-align: right;">1.3 V</p>
					Front wiper switch LO	<p style="text-align: right;">1.3 V</p>
					Front washer switch ON	<p style="text-align: right;">1.3 V</p>

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >







Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
108 (R)	Ground	Combination switch INPUT 4	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)  <p style="text-align: right;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Lighting switch AUTO (Wiper intermittent dial 4)  <p style="text-align: right;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)  <p style="text-align: right;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Any of the conditions below with all switches OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6  <p style="text-align: right;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
109 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch (Wiper intermittent dial 4)	All switch OFF	 1.4 V
					Lighting switch PASS	 1.3 V
					Lighting switch 2ND	 1.3 V
					Front wiper switch INT	 1.3 V
					Front wiper switch HI	 1.3 V
					Pressed	0 V
110 (G)	Ground	Hazard switch	Input	Hazard switch	Not pressed	 1.1 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
111 (Y)	Ground	Steering lock unit communication	Input/ Output	Steering lock	LOCK status	Battery voltage	
					LOCK or UNLOCK	 <p style="text-align: right; font-size: small;">JMKIA0066GB</p>	
					For 15 seconds after UN- LOCK	Battery voltage	
				15 seconds or later after UNLOCK	0 V		
113 (P)	Ground	Optical sensor signal	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V	
					When dark outside of the vehicle	Close to 0 V	
114 (R)	Ground	Clutch interlock switch	Input	Clutch interlock switch	OFF (Clutch pedal is not depressed)	0 V	
						ON (Clutch pedal is de- pressed)	Battery voltage
116 (SB)	Ground	Stop lamp switch 1	Input	—	Battery voltage		
118 (P)	Ground	Stop lamp switch 2	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V	
						ON (Brake pedal is de- pressed)	Battery voltage
				ICC brake hold relay (With ICC)	OFF	0 V	
					ON	Battery voltage	
119 (SB)	Ground	Front door lock as- sembly driver side (unlock sensor)	Input	Driver door	LOCK status	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p>	
						UNLOCK status	0 V
121 (R)	Ground	Key slot switch	Input	When Intelligent Key is inserted into key slot	Battery voltage		
					When Intelligent Key is not inserted into key slot	0 V	
122 (V)	Ground	ACC feedback signal	Input	Ignition switch	OFF	0 V	
					ACC or ON	Battery voltage	
123 (W)	Ground	IGN feedback signal	Input	Ignition switch	OFF or ACC	0 V	
					ON	Battery voltage	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P








BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
124 (LG)	Ground	Passenger door switch	Input	Passenger door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				OFF (When passenger door closes)	0 V
129 (O)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p>
				CANCEL	0 V
132 (V)	Ground	Power window switch communication	Input/ Output	Ignition switch ON	 <p style="text-align: right; font-size: small;">JPMIA0013GB</p> <p style="text-align: center;">10.2 V</p>
				Ignition switch OFF or ACC	0 V
133 (W)	Ground	Push-button ignition switch illumination	Output	Push-button ignition switch illumination	<p>NOTE: The pulse width of this wave is varied by the illumination bright- ening/dimming level.</p>  <p style="text-align: right; font-size: small;">JPMIA0159GB</p>
				ON (When tail lamps OFF)	5.5 V
				ON (When tail lamps ON)	
134 (GR)	Ground	LOCK indicator lamp	Output	LOCK indicator lamp	0 V
				OFF	Battery voltage
137 (O)	Ground	Receiver and sensor ground	Input	Ignition switch ON	0 V
138 (V)	Ground	Receiver and sensor power supply output	Output	Ignition switch	0 V
				OFF	5.0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
139 (L)	Ground	Tire pressure receiver signal	Input/ Output	Ignition switch ON	Standby state  OCC3881D
				When receiving the signal from the transmitter  OCC3880D	
140 (GR)	Ground	Selector lever P/N position signal	Input	Selector lever	P or N position 12.0 V
				Except P and N positions 0 V	
141 (G)	Ground	Security indicator signal	Output	Security indicator	ON 0 V
				Blinking  JPMIA0014GB 11.3 V	
142 (O)	Ground	Combination switch OUTPUT 5	Output	Combination switch (Wiper intermittent dial 4)	OFF 0 V
				Lighting switch 1ST Lighting switch HI Lighting switch 2ND Turn signal switch RH  JPMIA0031GB 10.7 V	
143 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switch OFF (Wiper intermittent dial 4) 0 V
				Front wiper switch HI (Wiper intermittent dial 4) Any of the conditions below with all switch OFF • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 • Wiper intermittent dial 6 • Wiper intermittent dial 7  JPMIA0032GB 10.7 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >


Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
144 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">JPMIA0033GB</p>
Any of the conditions below with all switches OFF					10.7 V	
<ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 						
145 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch (Wiper intermit- tent dial 4)	All switches OFF	0 V
					Front wiper switch INT	 <p style="text-align: right; font-size: small;">JPMIA0034GB</p>
					Front wiper switch LO	
					Lighting switch AUTO	
					10.7 V	
146 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Front fog lamp switch ON	 <p style="text-align: right; font-size: small;">JPMIA0035GB</p>
					Lighting switch 2ND	
					Lighting switch PASS	
					Turn signal switch LH	
					10.7 V	
149 (W)	Ground	Tire pressure warn- ing check switch	Input	—	5 V	
150 (GR)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closes)	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p>
					ON (When driver door opens)	
151 (G)	Ground	Rear window defog- ger relay	Output	Rear window de- fogger	Active	0 V
					Not activated	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Wiring Diagram — BCM —

INFOID:000000000964427



BCM (BODY CONTROL MODULE)

◀ A ▶ : With AT
◀ M ▶ : With M/T
◀ IC ▶ : With ICC

2006/09/15


JCMWA0005GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





JCMWA0006GE

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

- A** : With AT
- NV** : With NAVI
- ON** : Without NAVI
- RE** : With sunroof
- AN** : With rear anti-pinch system
- OA** : Without rear anti-pinch system
- SP** : With sports seat
- PM** : With automatic drive positioner



*: This connector is not shown in "Harness Layout".


JCMWA0007GE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




JCMWA0008Gf

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

BCM (BODY CONTROL MODULE)

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH



Terminal No.	Color of Wire	Signal Name
2	SB	OUTPUT 4
5	L	OUTPUT 3
7	V	INPUT 3
8	O	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name
20	V	REAR FLASHER OUTPUT(RIGHT)
23	G	TRUNK OPENER OUTPUT
25	G	REAR FLASHER OUTPUT(LEFT)
30	R	TRUNK LAMP OUTPUT

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	IM3FB-LC




Terminal No.	Color of Wire	Signal Name
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY(BAT)
3	O	POWER WINDOW POWER SUPPLY(BAP)

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FGY-NH



Terminal No.	Color of Wire	Signal Name
34	SB	TRUNK ANTI+
35	V	TRUNK ANTI+
38	B	BACK ANTI-
39	W	BACK ANTI+
47	Y	ING USM CONTI
50	R	TRUNK SW
52	SB	ST CONT USM
61	W	TRUNK REQUEST SW
64	V	BUZZER
67	GR	INTERIOR TRUNK SW
68	BR	DOOR SW (RR RH)

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name
4	LG	BAT SAVER OUTPUT
5	V	DOOR UNLOCK OUTPUT (AS)
7	Y	STEP LAMP OUTPUT
8	V	DOOR LOCK OUTPUT (ALL)
9	G	DOOR UNLOCK OUTPUT (BR)
10	BR	DOOR UNLOCK OUTPUT (RR)
11	R	BAT (FUSE)
13	B	GND
14	W	RING/SW LED GND
15	Y	ACC LED
17	W	FRONT FLASHER OUTPUT(RIGHT)

69	R	DOOR SW (RR LH)
----	---	-----------------

18	O	FRONT FLASHER OUTPUT(LEFT)
19	V	ROOM LAMP OUTPUT

JCMWA0009GE


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

133	W	RING/SW LED
134	GR	LOCK LED
137	O	SENSOR GND
138	V	AUTO LIGHT SENSOR POWER SUPPLY
139	L	RECEIVER SIGNAL
140	GR	SHIFT N/P
141	G	SECURITY INDICATOR OUTPUT
142	O	COMBI SW OUTPUT 5
143	P	COMBI SW OUTPUT 1
144	G	COMBI SW OUTPUT 2
145	L	COMBI SW OUTPUT 3
146	SB	COMBI SW OUTPUT 4
149	W	MODE TRG SW
150	GR	DOOR SW (DR)
151	G	REAR DEFOGGER OUTPUT

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FC-NH




Terminal No.	Color of Wire	Signal Name
113	P	AUTO LIGHT SENSOR INPUT
114	R	CLUTCH SW
116	SB	STOP LAMP LOW
118	P	STOP LAMP HIGH
119	SB	DR CONDITION SW
121	R	KEY SWITCH SIGNAL
122	V	ACC F/B
123	W	IGN F/B
124	LG	DOOR SW (AS)
129	O	TRUNK CANCEL SW
132	V	POWER WINDOW SERIAL LINK

83	Y	KEYLESS TUNER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	BR	ENG SW
90	P	GAN-L
91	L	GAN-H
92	LG	KEY SLOT ILL
93	V	ON LED
95	O	ACC CONT
96	GR	A-T DEVICE
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P
100	G	AS REQUEST SW
101	SB	DR REQUEST SW
102	O	IGN2 CONT
103	LG	KEYLESS TUNER POWER SUPPLY
106	W	S/L 12V (CPU)
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	Y	S/L (K LINE)

BCM (BODY CONTROL MODULE)

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	AS DOOR ANT-
75	BR	AS DOOR ANT+
76	V	DR DOOR ANT-
77	LG	DR DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	IMMOBI ANTENNA CONTROL
81	W	IMMOBI ANTENNA SIGNAL
82	R	IGN ELEC CONT

JCMWA0010GE

INFOID:000000000964428

Fail Safe

Display contents of CONSULT	Fail-safe	Cancellation
B2013: ID DISCORD BCM-S/L	Inhibit engine cranking	Erase DTC
B2014: CHAIN OF S/L-BCM	Inhibit engine cranking	Erase DTC
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2557: VEHICLE SPEED	Inhibit steering lock	When normal vehicle speed signals have been received from ABS actuator and electric unit (control unit) for 500 ms
B2560: STARTER CONT RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Starter control relay signal • Starter relay status signal
B2563: HI VOLTAGE	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	500 ms after the power supply voltage decreases to less than 18 V
B2601: SHIFT POSITION	Inhibit steering lock	500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Selector lever P position switch signal • P range signal (CAN)
B2602: SHIFT POSITION	Inhibit steering lock	5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Vehicle speed: 4 /h or more
B2603: SHIFT POSI STATUS	Inhibit steering lock	500 ms after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Selector lever P position switch signal: Except P position (battery voltage) • Selector lever P/N position signal: Except P and N positions (0 V)
B2604: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P and N position (battery voltage) - P range signal or N range signal (CAN): ON • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: Except P and N positions (0 V) - P range signal and N range signal (CAN): OFF
B2605: PNP SW	Inhibit steering lock	500 ms after any of the following BCM recognition conditions is fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position <ul style="list-style-type: none"> - Power position: IGN - Selector lever P/N position signal: Except P and N positions (0 V) - Interlock/PNP switch signal (CAN): OFF • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Selector lever P/N position signal: P or N position (battery voltage) - PNP switch signal (CAN): ON
B2606: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)
B2607: S/L RELAY	Inhibit engine cranking	500 ms after the following CAN signal communication status has become consistent <ul style="list-style-type: none"> • Steering lock relay signal (Request signal) • Steering lock relay signal (Condition signal)

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN)
B2609: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When the following steering lock conditions agree <ul style="list-style-type: none"> • BCM steering lock control status • Steering lock condition No. 1 signal status • Steering lock condition No. 2 signal status
B260A: IGNITION RELAY	Inhibit engine cranking	500 ms after the following conditions are fulfilled <ul style="list-style-type: none"> • IGN relay (IPDM E/R) control signal: OFF (Battery voltage) • Ignition ON signal (CAN to IPDM E/R): OFF (Request signal) • Ignition ON signal (CAN from IPDM E/R): OFF (Condition signal)
B260F: ENG STATE SIG LOST	Maintains the power supply position attained at the time of DTC detection	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)
B2612: S/L STATUS	<ul style="list-style-type: none"> • Inhibit engine cranking • Inhibit steering lock 	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Steering lock unit status signal (CAN) is received normally • The BCM steering lock control status matches the steering lock status recognized by the steering lock unit status signal (CAN from IPDM E/R)
B2617: STARTER RELAY CIRC	Inhibit engine cranking	1 second after the starter motor relay control inside BCM becomes normal
B2618: BCM	Inhibit engine cranking	1 second after the ignition relay (IPDM E/R) control inside BCM becomes normal
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B261E: VEHICLE TYPE	Inhibit engine cranking	BCM initialization
B26E1: ENG STATE NO RECIV	Inhibit engine cranking	When any of the following conditions is fulfilled <ul style="list-style-type: none"> • Power position changes to ACC • Receives engine status signal (CAN)

DTC Inspection Priority Chart

INFOID:000000000964429

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> • B2562: LOW VOLTAGE • B2563: HI VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2190: NATS ANTENA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Priority	DTC	A
4	<ul style="list-style-type: none"> • B2013: ID DISCORD BCM-S/L • B2014: CHAIN OF S/L-BCM • B2553: IGNITION RELAY • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2560: STARTER CONT RELAY • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP SW • B2605: PNP SW • B2606: S/L RELAY • B2607: S/L RELAY • B2608: STARTER RELAY • B2609: S/L STATUS • B260A: IGNITION RELAY • B260B: STEERING LOCK UNIT • B260C: STEERING LOCK UNIT • B260D: STEERING LOCK UNIT • B260F: ENG STATE SIG LOST • B2611: ACC RELAY • B2612: S/L STATUS • B2614: ACC RELAY CIRC • B2615: BLOWER RELAY CIRC • B2616: IGN RELAY CIRC • B2617: STARTER RELAY CIRC • B2618: BCM • B2619: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26E1: ENG STATE NO RECIV • C1729: VHCL SPEED SIG ERR • U0415: VEHICLE SPEED SIG 	A B C D E F G H I J
5	<ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL • C1734: CONTROL UNIT 	K L M O P
6	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA 	MWI

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
 - 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	BCS-33
U1010: CONTROL UNIT (CAN)	—	—	—	BCS-34
U0415: VEHICLE SPEED SIG	—	—	—	BCS-35
B2013: ID DISCORD BCM-S/L	×	—	—	SEC-43
B2014: CHAIN OF S/L-BCM	×	—	—	SEC-44
B2190: NATS ANTENNA AMP	×	—	—	SEC-37
B2191: DIFFERENCE OF KEY	×	—	—	SEC-40
B2192: ID DISCORD BCM-ECM	×	—	—	SEC-41
B2193: CHAIN OF BCM-ECM	×	—	—	SEC-42
B2553: IGNITION RELAY	—	—	—	PCS-48
B2555: STOP LAMP	—	—	—	SEC-47
B2556: PUSH-BTN IGN SW	—	×	—	SEC-49
B2557: VEHICLE SPEED	×	×	—	SEC-51
B2560: STARTER CONT RELAY	×	×	—	SEC-52
B2562: LOW VOLTAGE	—	—	—	BCS-36
B2563: HI VOLTAGE	×	×	—	BCS-37
B2601: SHIFT POSITION	×	×	—	SEC-53
B2602: SHIFT POSITION	×	×	—	SEC-56
B2603: SHIFT POSI STATUS	×	×	—	SEC-58
B2604: PNP SW	×	×	—	SEC-61
B2605: PNP SW	×	×	—	SEC-63
B2606: S/L RELAY	×	×	—	SEC-65
B2607: S/L RELAY	×	×	—	SEC-66
B2608: STARTER RELAY	×	×	—	SEC-68
B2609: S/L STATUS	×	×	—	SEC-70
B260A: IGNITION RELAY	×	×	—	PCS-50
B260B: STEERING LOCK VNIT	—	×	—	SEC-74
B260C: STEERING LOCK VNIT	—	×	—	SEC-75
B260D: STEERING LOCK VNIT	—	×	—	SEC-76
B260F: ENG STATE SIG LOST	×	×	—	SEC-77
B2611: ACC RELAY	—	—	—	PCS-52
B2612: S/L STATUS	×	×	—	SEC-79
B2614: ACC RELAY CIRC	—	×	—	PCS-54
B2615: BLOWER RELAY CIRC	—	×	—	PCS-57

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page	
B2616: IGN RELAY CIRC	—	×	—	PCS-60	A
B2617: STARTER RELAY CIRC	×	×	—	SEC-83	B
B2618: BCM	×	×	—	PCS-63	
B2619: BCM	×	×	—	SEC-85	C
B261A: PUSH-BTN IGN SW	—	×	—	SEC-86	
B261E: VEHICLE TYPE	×	× (Turn ON for 15 seconds)	—	SEC-88	D
B2621: INSIDE ANTENNA	—	—	—	DLK-58	
B2622: INSIDE ANTENNA	—	—	—	DLK-60	
B2623: INSIDE ANTENNA	—	—	—	DLK-62	E
B26E1: ENG STATE NO RES	×	×	—	SEC-78	
C1704: LOW PRESSURE FL	—	—	×	WT-14	F
C1705: LOW PRESSURE FR	—	—	×	WT-14	
C1706: LOW PRESSURE RR	—	—	×	WT-14	
C1707: LOW PRESSURE RL	—	—	×	WT-14	G
C1708: [NO DATA] FL	—	—	×	WT-16	
C1709: [NO DATA] FR	—	—	×	WT-16	
C1710: [NO DATA] RR	—	—	×	WT-16	H
C1711: [NO DATA] RL	—	—	×	WT-16	
C1712: [CHECKSUM ERR] FL	—	—	×	WT-19	I
C1713: [CHECKSUM ERR] FR	—	—	×	WT-19	
C1714: [CHECKSUM ERR] RR	—	—	×	WT-19	
C1715: [CHECKSUM ERR] RL	—	—	×	WT-19	J
C1716: [PRESSDATA ERR] FL	—	—	×	WT-22	
C1717: [PRESSDATA ERR] FR	—	—	×	WT-22	
C1718: [PRESSDATA ERR] RR	—	—	×	WT-22	K
C1719: [PRESSDATA ERR] RL	—	—	×	WT-22	
C1720: [CODE ERR] FL	—	—	×	WT-24	L
C1721: [CODE ERR] FR	—	—	×	WT-24	
C1722: [CODE ERR] RR	—	—	×	WT-24	
C1723: [CODE ERR] RL	—	—	×	WT-24	M
C1724: [BATT VOLT LOW] FL	—	—	×	WT-27	
C1725: [BATT VOLT LOW] FR	—	—	×	WT-27	MWI
C1726: [BATT VOLT LOW] RR	—	—	×	WT-27	
C1727: [BATT VOLT LOW] RL	—	—	×	WT-27	
C1729: VHCL SPEED SIG ERR	—	—	×	WT-30	O
C1734: CONTROL UNIT	—	—	×	WT-31	P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000000964431

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
RADFAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 - 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI		On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF	Off
		<ul style="list-style-type: none"> • Front fog lamp switch ON • Daytime running light activated (Only for Canada) 	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	STOP
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	A/T selector lever in any position other than P or N (A/T models)	Off
		Release clutch pedal (M/T models)	
	Ignition switch ON	A/T selector lever in P or N position (A/T models)	On
		Depress clutch pedal (M/T models)	
ST RLY REQ	Ignition switch ON		Off
	At engine cranking		On

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >


Monitor Item	Condition	Value/Status	
ST RLY CONT	Ignition switch ON	Off	A
	At engine cranking	On	
IHBT RLY -REQ	Ignition switch ON	Off	B
	At engine cranking	On	
ST/INHI RLY	Ignition switch ON	Off	C
	At engine cranking	ST →INHI	
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF	UNKWN	D
DETENT SW	Ignition switch ON	Off	E
	Release the A/T selector button with A/T selector lever in P position NOTE: The lever is fixed ON for M/T	On	F
S/L RLY -REQ	None of the conditions below are present	Off	
	<ul style="list-style-type: none"> Open the driver door after the ignition switch is turned OFF (for a few seconds) Press the push-button ignition switch when the steering lock is activated Depress the clutch pedal when the steering lock is activated 	On	G
			H
S/L STATE	Steering lock is activated	LOCK	
	Steering lock is deactivated	UNLK	I
	[DTC B210A] is detected	UNKWN	
DTRL REQ	NOTE: The item is indicated, but not monitored.	Off	J
OIL P SW	Ignition switch OFF, ACC or engine running	Open	
	Ignition switch ON	Close	K
HOOD SW	Close the hood	Off	
	Open the hood	On	L
HL WASHER REQ	NOTE: The item is indicated, but not monitored.	Off	
THFT HRN REQ	Not operation	Off	M
	<ul style="list-style-type: none"> Panic alarm is activated Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM 	On	
HORN CHIRP	Not operating	Off	
	Door locking with Intelligent Key (horn chirp mode)	On	MWI
CRNRNG LMP REQ	NOTE: The item is indicated, but not monitored.	Off	O

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
4 (V)	Ground	Front wiper LO	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch LO	Battery voltage
5 (L)	Ground	Front wiper HI	Output	Ignition switch OFF	Front wiper switch OFF	0 V
				Ignition switch ON	Front wiper switch HI	Battery voltage
7 (R)	Ground	Tail, license plate lamps & interior lamps	Output	Ignition switch OFF	Lighting switch OFF	0 V
				Ignition switch ON	Lighting switch 1ST	Battery voltage
11 (BR)	Ground	Steering lock unit power supply	Output	Ignition switch OFF	A few seconds after opening the driver door	Battery voltage
				Ignition switch LOCK	Press the push-button ignition switch	Battery voltage
				Ignition switch ACC or ON		0 V
12 (B/W)	Ground	Ground	—	Ignition switch ON		0 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
13 (Y)	Ground	Fuel pump power supply	Output	Approximately 1 second or more after turning the ignition switch ON	0 V	
				<ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running 	Battery voltage	
16 (LG)	Ground	Front wiper auto stop	Input	Ignition switch ON	0 V	
				<ul style="list-style-type: none"> Front wiper stop position Any position other than front wiper stop position 	Battery voltage	
19 (W)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
25 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
26*1 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
27 (O)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC	Battery voltage	
				Ignition switch ON	0 V	
28 (L)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	0 V	
				Release the push-button ignition switch	Battery voltage	
30 (GR)	Ground	Starter relay control	Input	A/T models	A/T selector lever in any position other than P or N (ignition switch ON)	0 V
					A/T selector lever P or N (ignition switch ON)	Battery voltage
				M/T models	Release the clutch pedal	0 V
					Depress the clutch pedal	Battery voltage
32 (L)	Ground	Steering lock unit condition-1	Input	Steering lock is activated	0 V	
				Steering lock is deactivated	Battery voltage	
33 (P)	Ground	Steering lock unit condition-2	Input	Steering lock is activated	Battery voltage	
				Steering lock is deactivated	0 V	
36 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
39 (P)	—	CAN - L	Input/ Output	—	—	
40 (L)	—	CAN - H	Input/ Output	—	—	
41 (B/W)	Ground	Ground	—	Ignition switch ON	0 V	
42 (Y)	Ground	Cooling fan relay control	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	0.7 V	
43 (SB)	Ground	A/T device (Detention switch)	Input	Ignition switch ON	Press the A/T selector button (A/T selector lever P)	Battery voltage
					<ul style="list-style-type: none"> A/T selector lever in any position other than P Release the A/T selector button (A/T selector lever P) 	0 V
44 (W)	Ground	Horn relay control	Input	The horn is deactivated	Battery voltage	
				The horn is activated	0 V	

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI




IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
45 (G)	Ground	Anti theft horn relay control	Input	The horn is deactivated		Battery voltage
				The horn is activated		0 V
46 (BR)	Ground	Starter relay control	Input	A/T models	A/T selector lever in any position other than P or N (ignition switch ON)	0 V
					A/T selector lever P or N (ignition switch ON)	Battery voltage
				M/T models	Release the clutch pedal	0 V
					Depress the clutch pedal	Battery voltage
48 (L)	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
49 (R)	Ground	ECM relay power supply	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (More than a few seconds after turning ignition switch OFF) 		Battery voltage
51 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
53 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (More than a few seconds after turning ignition switch OFF) 		Battery voltage
54 (R)	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (More than a few seconds after turning ignition switch OFF) 		Battery voltage
55 (BR)	Ground	ECM power supply	Output	Ignition switch OFF		Battery voltage
56 (V)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
57 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
58 (Y)	Ground	Ignition relay power supply	Output	Ignition switch OFF		0 V
				Ignition switch ON		Battery voltage
69 (W)	Ground	ECM relay control	Output	Ignition switch OFF (For a few seconds after turning ignition switch OFF)		Battery voltage
				<ul style="list-style-type: none"> Ignition switch ON Ignition switch OFF (More than a few seconds after turning ignition switch OFF) 		0 - 1.5 V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
70 (O)	Ground	Throttle control motor re- lay control	Output	Ignition switch ON → OFF	0 -1.0 V ↓ Battery voltage ↓ 0 V	
				Ignition switch ON	0 - 1.0 V	
73*2 (P)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
74 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF	0 V	
				Ignition switch ON	Battery voltage	
75 (Y)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped 0 V	
				Engine running Battery voltage		
76 (V)	Ground	Power generation com- mand signal	Output	Ignition switch ON	 <p style="text-align: center;">6.3 V</p>	
				40% is set on "ACTIVE TEST", "AL- TERNATOR DUTY" of "ENGINE"	 <p style="text-align: center;">3.8 V</p>	
				80% is set on "ACTIVE TEST", "AL- TERNATOR DUTY" of "ENGINE"	 <p style="text-align: center;">1.4 V</p>	
77 (L)	Ground	Fuel pump relay control	Output	<ul style="list-style-type: none"> Approximately 1 second after turning the ignition switch ON Engine running 	0 - 1.0 V	
				Approximately 1 second or more after turning the ignition switch ON	Battery voltage	
80 (W)	Ground	Starter motor	Output	At engine cranking	Battery voltage	
83 (R)	Ground	Headlamp LO (RH)	Output	Ignition switch ON	Lighting switch OFF 0 V	
				Lighting switch 2ND Battery voltage		
84 (P)	Ground	Headlamp LO (LH)	Output	Ignition switch ON	Lighting switch OFF 0 V	
				Lighting switch 2ND Battery voltage		

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
86 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> • Front fog lamp switch ON • Daytime running light activated (Only for Canada) 	Battery voltage
					Front fog lamp switch OFF	0 V
87 (L)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	<ul style="list-style-type: none"> • Front fog lamp switch ON • Daytime running light activated (Only for Canada) 	Battery voltage
					Front fog lamp switch OFF	0 V
88 (G)	Ground	Washer pump power supply	Output	Ignition switch ON		Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output	Ignition switch ON	<ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 	Battery voltage
					Lighting switch OFF	0 V
90 (P)	Ground	Headlamp HI (LH)	Output	Ignition switch ON	<ul style="list-style-type: none"> • Lighting switch HI • Lighting switch PASS 	Battery voltage
					Lighting switch OFF	0 V
91 (P)	Ground	Parking lamp (RH)	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
					Lighting switch OFF	0 V
92 (O)	Ground	Parking lamp (LH)	Output	Ignition switch ON	Lighting switch 1ST	Battery voltage
					Lighting switch OFF	0 V
97 (V)	Ground	Cooling fan control	Output	Engine idling		0 - 5 V
104 (LG)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V

*1: Only for the models with ICC system

*2: M/T models only


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Wiring Diagram — IPDM E/R —

INFOID:00000000964432

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



2006/09/15


JCMWA0017GE

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

IPDM E/R
(INTELLIGENT POWER
DISTRIBUTION MODULE
ENGINE ROOM)
E4 E5 E6
E7 E8 E9



JCMWA0019GE

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Connector No.	E4
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	L02FB-MC




Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	E5
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-TV




Terminal No.	Color of Wire	Signal Name
4	V	-
5	L	-
6	-	-
7	R	-
10	-	-
11	BR	-
12	B/W	-
13	Y	-
15	-	-
16	LG	-
17	-	-

Connector No.	E7
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH20FW-CS12-M4



Terminal No.	Color of Wire	Signal Name
48	L	-
49	R	-
51	G	-
52	-	-
53	W	-
54	R	-
55	BR	-
56	V	-
57	R	-
58	Y	-
69	W	-

Connector No.	E8
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS08FW-CS



Terminal No.	Color of Wire	Signal Name
83	R	-
84	P	-
86	W	-
87	L	-
88	G	-
89	BR	-
80	P	-


19	W	-
20	-	-
21	-	-
22	-	-
23	-	-
24	-	-
25	G	-
26	R	-
27	O	-
28	L	-
30	GR	-
31	-	-
32	L	-
33	P	-
34	-	-
36	G	-
37	-	-

Connector No.	E6
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH08FW-NH



Terminal No.	Color of Wire	Signal Name
39	P	-
40	L	-
41	B/W	-
43	SB	-
44	W	-
45	G	-
46	BR	-

Connector No.	E9
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name
91	P	-
92	O	-
93	-	-
94	-	-
97	V	-
99	-	-
100	-	-
101	-	-
102	-	-
103	-	-
104	LG	-
105	-	-

Fail Safe

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

JCMWA0020GE

INFOID:000000000964433

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> • Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON • Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> • Turns ON the headlamp low relay when the ignition switch is turned ON • Turns OFF the headlamp low relay when the ignition switch is turned OFF • Headlamp high relay OFF
<ul style="list-style-type: none"> • Parking lamps • License plate lamps • Side maker lamps • Illuminations • Tail lamps 	<ul style="list-style-type: none"> • Turns ON the tail lamp relay when the ignition switch is turned ON • Turns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none"> • The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed. • The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Front fog lamps	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF
Steering lock unit	Steering lock relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

DTC	Ignition switch	Ignition relay	Tail lamp relay
—	ON	ON	—
—	OFF	OFF	—
B2098: IGN RELAY ON	OFF	ON	ON (10 minutes)
B2099: IGN RELAY OFF	ON	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000000964434

CONSULT display	Fail-safe	TIME ^{NOTE}		Refer to
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39 ^{*1} CRNT ^{*2}	PCS-15
B2098: IGN RELAY ON	×	CRNT	1 – 39	PCS-16
B2099: IGN RELAY OFF	—	CRNT	1 – 39	PCS-17
B2108: STRG LCK RELAY ON	—	CRNT	1 – 39	SEC-89
B2109: STRG LCK RELAY OFF	—	CRNT	1 – 39	SEC-90
B210A: STRG LCK STATE SW	—	CRNT	1 – 39	SEC-91
B210B: START CONT RLY ON	—	CRNT	1 – 39	SEC-95
B210C: START CONT RLY OFF	—	CRNT	1 – 39	SEC-96
B210D: STARTER RELAY ON	—	CRNT	1 – 39	SEC-97
B210E: STARTER RELAY OFF	—	CRNT	1 – 39	SEC-98
B210F: INTRLCK/PNP SW ON	—	CRNT	1 – 39	SEC-100
B2110: INTRLCK/PNP SW OFF	—	CRNT	1 – 39	SEC-104

*1: Only for the models with AFS

*2: Only for the models without AFS (The display is fixed to CRNT until the self-diagnosis results are erased when the malfunctions were found in the past.)

NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 . . . 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

THE FUEL GAUGE POINTER DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE FUEL GAUGE POINTER DOES NOT MOVE

Description

INFOID:000000000964435

Fuel gauge needle will not move from a certain position.

Diagnosis Procedure

INFOID:000000000964436

1. CHECK UNIFIED METER AND A/C AMP. OUTPUT SIGNAL

1. Connect CONSULT-III.
2. Select the "Data Monitor" for the "METER/M&A" and compare the "FUEL METER" monitor value with the fuel gauge reading on the combination meter. Refer to [MWI-53, "Component Function Check"](#).

Does monitor value match fuel gauge reading?

- YES >> GO TO 2.
NO >> Replace combination meter.

2. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Inspect the fuel level sensor signal circuit. Refer to [MWI-53, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair harness or connector.

3. CHECK FUEL LEVEL SENSOR UNIT

Perform a unit inspection for the fuel level sensor unit. Refer to [MWI-54, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace fuel level sensor unit. Refer to [FL-5, "Removal and Installation"](#).

4. CHECK FLOAT INTERFERENCE

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

- YES >> Replace unified meter and A/C amp.
NO >> Repair or replace malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE METER CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

THE METER CONTROL SWITCH IS INOPERATIVE

Description

INFOID:000000000964437

If any of the following malfunctions is found for the meter control switch operation

- All switches are inoperative
- The specified switch cannot be operated

Diagnosis Procedure

INFOID:000000000964438

1.CHECK METER CONTROL SWITCH SIGNAL CIRCUIT

Inspect the meter control switch signal circuit. Refer to [MWI-56, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK METER CONTROL SWITCH UNIT

Perform a unit inspection for the meter control switch. Refer to [MWI-57, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NG >> Replace meter control switch.

THE OIL PRESSURE SWITCH DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE SWITCH DOES NOT TURN ON

Description

INFOID:000000000964439

The oil pressure warning lamp stays off when the ignition switch is turned ON

Diagnosis Procedure

INFOID:000000000964440

1.CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-10, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

- YES >> GO TO 2.
- NO >> GO TO 4.

2.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Inspect the oil pressure switch signal circuit. Refer to [MWI-58, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

3.CHECK OIL PRESSURE SWITCH UNIT

Perform a unit inspection for the oil pressure switch. Refer to [MWI-58, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R.
- NO >> Replace oil pressure switch.

4.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Connect CONSULT-III and perform an input signal inspection for the unified meter and A/C amp.

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



THE OIL PRESSURE SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE SWITCH DOES NOT TURN OFF

Description

INFOID:000000000964441

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure)

Diagnosis Procedure

INFOID:000000000964442

1.CHECK OIL PRESSURE WARNING LAMP

Perform auto active test. Refer to [PCS-10, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

- YES >> GO TO 2.
- NO >> GO TO 5.

2.CHECK IPDM E/R OUTPUT VOLTAGE

-
1. Disconnect the oil pressure switch connector.
 2. Turn ignition switch ON.
 3. Check voltage between the oil pressure switch harness connector terminal 1 and ground.

1- Ground : Approx. 12 V

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 4.

3.CHECK OIL PRESSURE SWITCH UNIT

Perform a unit inspection for the oil pressure switch. Refer to [MWI-58, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation"](#).
- NO >> Replace oil pressure switch.

4.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Inspect the oil pressure switch signal circuit. Refer to [MWI-58, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair harness or connector.

5.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Connect CONSULT-III and perform an input signal inspection for the unified meter and A/C amp. Refer to [MWI-58, "Component Function Check"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000000964443

- The parking brake warning is displayed during vehicle travel even though the parking brake is released
- The parking brake warning is not displayed even though driving the vehicle with the parking brake applied

Diagnosis Procedure

INFOID:000000000964444

1. CHECK PARKING BRAKE WARNING LAMP OPERATION

1. Start engine.
2. Check the operation of the parking brake warning lamp when operating the parking brake.

Condition	Warning lamp status
Parking brake ON	ON
Parking brake OFF	OFF

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Perform an inspection for the parking brake switch signal circuit. Refer to [MWI-59. "Diagnosis Procedure \(A/T model\)".](#)

Is the inspection result normal?

- YES >> GO TO 3.
- NG >> Repair harness or connector.

3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit inspection for the parking brake switch. Refer to [BRC-69. "Component Inspection".](#)

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace parking brake switch.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000000964445

- The warning is still displayed even after washer fluid is added
- The warning is not displayed even though the washer tank is empty

Diagnosis Procedure

INFOID:000000000964446

1.CHECK LOW WASHER LEVEL SWITCH SIGNAL CIRCUIT

Inspect the low washer level switch signal circuit. Refer to [MWI-61. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK LOW WASHER LEVEL SWITCH UNIT

Perform a unit inspection for the low washer level switch. Refer to [MWI-61. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace washer level switch. Refer to [WW-81. "Removal and Installation"](#).

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000000964447

- The door ajar warning is displayed even though all of the doors are closed.
- The door ajar warning is not displayed even though a door is ajar.

Diagnosis Procedure

INFOID:000000000964448

1. CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT-III and inspect the BCM input signals. Refer to [DLK-65. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "DOOR W/L" monitor value.

DOOR W/L

Door open : ON

Door closed : OFF

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace BCM.

3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Inspect the door switch signal circuit. Refer to [DLK-65. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair harness or connector.

4. CHECK DOOR SWITCH UNIT

Perform a unit inspection for the door switch. Refer to [DLK-67. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace applicable door switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

THE TRUNK OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

Description

INFOID:000000000964449

- The trunk ajar warning is displayed continuously even though the trunk lid is closed.
- The trunk ajar warning is not displayed even though the trunk lid is open.

Diagnosis Procedure

INFOID:000000000964450

1.CHECK BCM INPUT/OUTPUT SIGNAL

Connect CONSULT-III and inspect the BCM input signals. Refer to [DLK-80. "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2.CHECK UNIFIED METER AND A/C AMP. INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "TRUNK/GLAS-H" monitor value.

TRUNK/GLAS-H	
Trunk lid open	: ON
Trunk lid closed	: OFF

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace BCM.

3.CHECK TRUNK LID OPENER SWITCH SIGNAL CIRCUIT

Inspect the trunk lid opener switch signal circuit. Refer to [DLK-80. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair harness or connector.

4.CHECK TRUNK LID OPENER SWITCH UNIT

Perform a unit inspection for the trunk lid opener switch. Refer to [DLK-81. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter.
- NO >> Replace the trunk lid switch. Refer to [DLK-216. "TRUNK LID LOCK : Removal and Installation"](#).

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

Description

INFOID:000000000964451

- The displayed ambient temperature is higher than the actual temperature.
- The displayed ambient temperature is lower than the actual temperature.

Diagnosis Procedure

INFOID:000000000964452

NOTE:

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-154, "INFORMATION DISPLAY : Description"](#).

1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Inspect the ambient sensor signal circuit. Refer to [HAC-93, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK AMBIENT SENSOR UNIT

Perform a unit inspection for the ambient sensor. Refer to [HAC-94, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace unified meter and A/C amp.

NO >> Replace ambient sensor. Refer to [VTL-25, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION COMPASS

COMPASS : Description

INFOID:000000000964453

COMPASS

- The electronic compass is highly protected from changes in most magnetic fields. However, some large changes in magnetic fields can affect it. Some examples are (but not limited to): high tension power lines, large steel buildings, subways, steel bridges, automatic car washes, large piles of scrap metal, etc. While this does not happen very often, it is possible.
- During normal operation, the Compass Mirror will continuously update the compass calibration to adjust for gradual changes in the vehicle's magnetic "remnant" field. If the vehicle is subjected to high magnetic influences, the compass may appear to indicate false headings, become locked, or appear that it is unable to be calibrated. If this occurs, perform the calibration procedure.
- If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, verify the correct zone variance.

Symptom Chart

Symptom	Cause	Solution / Reference
The compass display reads "C".	<ul style="list-style-type: none">• Compass is not calibrated.• Incorrect zone variance setting.• Large change in magnetic field (Steel bridges, subways, concentrations of metal, carwashes, etc.)• Compass was calibrated incorrectly or in the presence of a strong magnetic field.	Perform Calibration. Refer to MWI-32, "Description" .
Compass shows the wrong direction.		
Compass does not change direction appears "Locked".		
Compass does not show all the directions, one or more is missing.		
The compass was calibrated but it "loses" calibration.		
On long trips the compass shows the wrong direction.	Perform Zone Variation Setting if correct reading is desired in that location. Refer to MWI-32, "Description" .	

INFORMATION DISPLAY

INFORMATION DISPLAY : Description

INFOID:000000000964454

OUTSIDE TEMP

The displayed ambient temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the unified meter and A/C amp. Refer to [MWI-26, "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

RANGE

The calculated possible driving distance may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3-3/10 Imp gal) or less. This is because the refuel control (moves the fuel gauge needle quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

AIR BAG (PATTERN 2)

< PRECAUTION >

PRECAUTION

AIR BAG (PATTERN 2)

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000000964455

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR

COMBINATION METER

Exploded View


INFOID:000000000964456

REMOVAL

Cluster lid A assembly


Refer to [IP-11. "Exploded View"](#).

Combination meter



- | | | |
|----------------------------|-------------------------|--------------------------------|
| 1. Cluster lid A | 2. Meter control switch | 3. Cluster lid A under cover |
| 4. Bracket (LH) | 5. Bracket (RH) | 6. Steering column cover upper |
| 7. Steering column blind | 8. Blind | 9. Meter housing |
| 10. Combination meter stay | 11. Combination meter | 12. Cluster lid A cover |

DISASSEMBLY



- | | |
|----------------|-------------------------------|
| 1. Front cover | 2. Unified meter control unit |
|----------------|-------------------------------|

Removal and Installation


INFOID:000000000964457

REMOVAL


COMBINATION METER

< ON-VEHICLE REPAIR >

1. Remove cluster lid A assembly. Refer to [IP-12, "Removal and Installation"](#).
2. Remove screw (A) and remove combination meter stay (1).
3. Remove screws (B) and remove cluster lid A cover (2).



4. Remove screws (A), (B) and remove combination meter (1).
5. Remove meter control switch connector (2) from combination meter (1).



INSTALLATION

Install in the reverse order of removal.

Disassembly and Assembly

INFOID:000000000964458

DISASSEMBLY

Disengage the tabs to separate front cover.

ASSEMBLY

Assemble in the reverse order of disassembly.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



UNIFIED METER AND A/C AMP.

< ON-VEHICLE REPAIR >

UNIFIED METER AND A/C AMP.


Exploded View

INFOID:000000000964459

REMOVAL

Refer to [IP-11, "Exploded View"](#).

DISASSEMBLY



1. Unified meter and A/C amp.
2. Bracket (LH)
3. AV control unit
4. Bracket (RH)

Removal and Installation

INFOID:000000000964460

REMOVAL

1. Remove the display unit. Refer to [AV-112, "Removal and Installation"](#).
2. Remove the unified meter and A/C amp and AV control unit as an assembly.
3. Remove the bracket screws and remove the unified meter and A/C amp.

INSTALLATION

Install in the reverse order of removal.

NOTE:

Unified meter and A/C amp. screws are different from other screws. Never confuse them when installing.

METER CONTROL SWITCH

< ON-VEHICLE REPAIR >

METER CONTROL SWITCH


Exploded View

INFOID:000000000964461

REMOVAL

Refer to [JP-11, "Exploded View"](#).

DISASSEMBLY




- | | | |
|--------------------------|-------------------------|--------------------------------|
| 1. Cluster lid A | 2. Meter control switch | 3. Cluster lid A under cover |
| 4. Bracket (LH) | 5. Bracket (RH) | 6. Steering column cover upper |
| 7. Steering column blind | 8. Meter housing | |

Removal and Installation

INFOID:000000000964462

REMOVAL

1. Remove combination meter.
2. Remove screws (A) and remove bracket RH (1), LH (2).
3. Remove screws (B) and remove meter control switch.



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



COMPASS

< ON-VEHICLE REPAIR >

COMPASS

Exploded View

INFOID:000000000964463

Refer to [MIR-66. "Exploded View"](#).

Removal and Installation

INFOID:000000000964464

Refer to [MIR-66. "Removal and Installation"](#).

CLOCK

< ON-VEHICLE REPAIR >

CLOCK


Exploded View

INFOID:000000000964465

REMOVAL

Refer to [IP-11, "Exploded View"](#).

DISASSEMBLY



1. Clock

2. Cluster lid C


3. Multifunction switch

Removal and Installation

INFOID:000000000964466

REMOVAL

1. Remove cluster lid C assembly. Refer to [IP-12, "Removal and Installation"](#).
2. Remove screws (A), (B), (C) and remove clock (2) in conjunction with multifunction switch (1) from cluster lid C.
3. Disengage the tabs to separate clock (2).



INSTALLATION

Install in the reverse order of removal.

NOTE:

Never confuse screws when installing.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P