

# ELECTRICAL SYSTEM

## SECTION **EL**

### CONTENTS

<b>PRECAUTIONS</b> .....	2	Rear Cover Installation .....	30
Precautions for Supplemental Restraint System Supplemental "AIR BAG" .....	2	Service Data and Specifications (SDS) .....	30
<b>HARNES CONNECTOR</b> .....	3	<b>COMBINATION SWITCH</b> .....	31
Description .....	3	Combination Switch/Check .....	31
<b>STANDARDIZED RELAY</b> .....	4	Combination Switch/Replacement .....	32
Description .....	4	<b>HEADLAMP</b> .....	34
<b>POWER SUPPLY ROUTING</b> .....	6	System Description (For USA) .....	34
Wiring Diagram -POWER- .....	6	Schematic (For USA) .....	35
Fuse .....	13	Wiring Diagram (For USA) -H/LAMP- .....	36
Fusible Link .....	13	Trouble Diagnoses (For USA) .....	40
<b>BATTERY</b> .....	14	System Description (For Canada) .....	42
How to Handle Battery .....	14	Schematic (For Canada) .....	44
Methods Of Preventing Battery Discharge .....	14	Wiring Diagram (For Canada) -DTRL- .....	45
Checking Electrolyte Level .....	15	Trouble Diagnoses (For Canada) .....	50
Sulphation .....	15	Daytime Lamp Control Module Inspection Table .....	50
Specific Gravity Check .....	15	Bulb Replacement .....	52
Hydrometer temperature correction .....	16	Aiming Adjustment .....	52
Charging The Battery .....	16	Aimer Adjustment Mark .....	52
Voltage chart .....	18	Low Beam .....	53
Service Data and Specifications (SDS) .....	18	<b>AUTOLAMP</b> .....	54
<b>STARTING SYSTEM</b> .....	20	System Description .....	54
System Description .....	20	Trouble Diagnoses .....	55
Wiring Diagram -START- .....	21	<b>EXTERIOR LAMP</b> .....	60
<b>STARTING SYSTEM — Starter —</b> .....	22	Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- .....	60
Construction .....	22	Back-up Lamp/Wiring Diagram -BACK/L- .....	63
Removal and Installation .....	23	Turn Signal and Hazard Warning Lamps/System Description .....	64
Pinion/Clutch Check .....	24	Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN- .....	66
Service Data and Specifications (SDS) .....	24	Turn Signal and Hazard Warning Lamps/ Trouble Diagnoses .....	68
<b>CHARGING SYSTEM</b> .....	25	Cornering Lamp/System Description .....	70
System Description .....	25	Cornering Lamp/Wiring Diagram -CORN/L- .....	71
Wiring Diagram -CHARGE- .....	26	Combination Flasher Unit Check .....	72
Trouble Diagnoses .....	27	Bulb Specifications .....	72
<b>CHARGING SYSTEM — Generator —</b> .....	28	<b>INTERIOR LAMP</b> .....	73
Construction .....	28		
Removal and Installation .....	28		
Diode Check .....	29		
Assembly .....	29		

# CONTENTS (Cont'd.)

Illumination/System Description.....	73	Washer Nozzle Adjustment.....	128
Illumination/Wiring Diagram -ILL-.....	74	Check Valve.....	128
Interior, Map, Step and Tailgate Lamps/ Wiring Diagram -INT/L-.....	78	<b>HORN, CIGARETTE LIGHTER, CLOCK</b> .....	129
<b>METER AND GAUGES</b> .....	82	Wiring Diagram -HORN-.....	129
System Description.....	82	<b>REAR WINDOW DEFOGGER</b> .....	130
Combination Meter.....	83	System Description.....	130
Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER-.....	84	Wiring Diagram -DEF-.....	131
Inspection/Water Temperature Gauge.....	86	Filament Check.....	132
Inspection/Fuel Gauge.....	87	Filament Repair.....	133
Inspection/Tachometer.....	88	<b>AUDIO AND POWER ANTENNA</b> .....	134
Inspection/Speedometer and Vehicle Speed Sensor.....	89	Audio/System Description.....	134
Inspection/Speedometer and Fuse.....	90	Audio/Wiring Diagram -AUDIO-.....	135
Fuel Tank Gauge Unit Check.....	91	Power Antenna/System Description.....	138
Thermal Transmitter Check.....	91	Power Antenna/Wiring Diagram -P/ANT-.....	139
Oil Pressure Switch Check.....	91	Trouble Diagnoses.....	140
Vehicle Speed Sensor Signal Check.....	91	Location of Antenna.....	143
<b>WARNING LAMPS AND CHIME</b> .....	92	Antenna Rod Replacement.....	143
Warning Lamps/System Description.....	92	Removal.....	143
Warning Lamps/Schematic.....	94	Installation.....	144
Warning Lamps/Wiring Diagram -WARN-.....	95	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	145
Warning Chime/System Description.....	100	System Description.....	145
Warning Chime/Wiring Diagram -CHIME-.....	101	Component Parts and Harness Connector Location.....	147
Diode Check.....	102	Schematic.....	148
Warning Chime Check.....	102	Wiring Diagram -ASCD-.....	149
Oil Level Timer/Trouble Diagnoses.....	103	Trouble Diagnoses.....	152
<b>TIME CONTROL SYSTEM</b> .....	104	Preparation For Trouble-Diagnosis.....	152
System Description.....	104	Ground Circuit Check.....	152
Function.....	105	ASCD Wire Adjustment.....	156
Operating Conditions.....	106	Electrical Components Inspection.....	157
Schematic.....	107	ASCD main switch.....	157
Wiring Diagram -TIME-.....	108	ASCD steering switch.....	157
Trouble Diagnoses.....	112	ASCD cancel switch and stop lamp switch.....	157
Preparation For Trouble Diagnosis.....	112	Inhibitor switch.....	157
Power Supply Circuit Check.....	112	Vehicle speed sensor.....	158
<b>WIPER AND WASHER</b> .....	120	ASCD actuator/ASCD pump.....	159
Front Wiper and Washer/System Description.....	120	<b>DIGITAL TOUCH ENTRY SYSTEM</b> .....	160
Front Wiper and Washer/Wiring Diagram -WIPER-.....	121	System Description.....	160
Rear Wiper and Washer (Except for Glass Hatch Model)/System Description.....	122	Location of Electrical Units.....	162
Rear Wiper and Washer (Except for Glass Hatch Model)/Wiring Diagram -WIP/R-.....	123	Wiring Diagram -ENTRY-.....	164
Rear Wiper and Washer (For Glass Hatch Model)/System Description.....	124	Trouble Diagnoses.....	168
Rear Wiper and Washer (For Glass Hatch Model)/Wiring Diagram -WIP/HR-.....	125	How To Perform Trouble Diagnoses For Quick And Accurate Repair.....	168
Removal and Installation — Windshield Wiper..	127	Work flow.....	168
		Symptom Chart.....	169
		Diagnostic table.....	169
		Circuit Diagram For Quick Pinpoint Check....	170
		Preliminary Check.....	172

# CONTENTS (Cont'd.)

Preliminary check 1.....	172	Engine Compartment.....	186	GI
Preliminary check 2.....	172	Passenger Compartment.....	188	
Main Power Supply And Ground Circuit		Main Harness.....	190	
Check.....	172	Engine Control Harness.....	194	MA
Diagnostic Procedure.....	173	Body Harness.....	196	
Electrical Components Inspection.....	178	Air Bag Harness.....	198	EW
Keyboard.....	178	Back Door Harness.....	199	
Beeper.....	178	Room Lamp Harness.....	200	LC
Key switch.....	178	Door Harness.....	201	
Door switches.....	179	LH Side.....	201	
Lock & Unlock switches.....	179	RH Side.....	202	
Digital touch entry control module.....	180	<b>SUPER MULTIPLE JUNCTION (SMJ)</b> .....	Foldout page	EF & EC
<b>LOCATION OF ELECTRICAL UNITS</b> .....	181	Installation.....	Foldout page	
Engine Compartment.....	181	Ignition Switch.....	Foldout page	
Passenger Compartment.....	182	Terminal Arrangement.....	Foldout page	FE
Luggage Compartment.....	183	<b>JOINT CONNECTOR (J/C)</b> .....	Foldout page	
<b>HARNESS LAYOUT</b> .....	184	Location.....	Foldout page	AT
Outline.....	184	Terminal Arrangement.....	Foldout page	
Engine Room Harness.....	186			FA

**When you read wiring diagrams:**

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

**When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES".**

## WIRING DIAGRAM REFERENCE CHART

ECCS (Ignition system).....	EF & EC SECTION
AUTOMATIC TRANSAXLE CONTROL SYSTEM, SHIFT LOCK SYSTEM.....	AT SECTION
ANTI-LOCK BRAKE SYSTEM.....	BR SECTION
POWER WINDOW, POWER DOOR LOCK, AUTOMATIC SEAT BELT SYSTEM, POWER SEAT, SUN ROOF, DOOR MIRROR, SRS SUPPLEMENTAL (AIR BAG).....	BF SECTION
HEATER AND AIR CONDITIONING.....	HA SECTION

EL

IDX

## PRECAUTIONS



### Precautions for Supplemental Restraint System Supplemental "AIR BAG"

The Supplemental Restraint System Supplemental "Air Bag", used along with seat belts, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of a supplemental air bag module (located in the center of the steering wheel), sensors, a diagnosis (control) unit, warning lamp, wiring harness and spiral cables. Information necessary to service the system safely is included in the **BF** section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could lead to personal injury or death in the event of a severe frontal collision, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS Supplemental "Air Bag".

# HARNESS CONNECTOR

## Description


### HARNESS CONNECTOR

- The connector can be disconnected by pushing or lifting the locking section.

#### CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX


AEL050

# STANDARDIZED RELAY

## Description

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

### TYPE OF STANDARDIZED RELAYS













1M .... 1 Make    2M .... 2 Make  
 1T .... 1 Transfer    1M-1B 1 Make 1 Brake



SEL882H

# STANDARDIZED RELAY

## Description (Cont'd)


Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
1M				BLUE, GREEN or YELLOW
2M				BROWN
1M-1B				GRAY

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# POWER SUPPLY ROUTING




## Wiring Diagram -POWER-

### EL-POWER-01



- AS : MODELS WITH ANTI-LOCK BRAKE SYSTEM
- DT : MODELS WITH DIGITAL TOUCH ENTRY SYSTEM



Refer to Foldout  
Page in EL Section  
for details.





# POWER SUPPLY ROUTING

## Wiring Diagram -POWER- (Cont'd)




Refer to Foldout Page in EL Section for details. (E52)


Refer to Foldout Page in EL Section for details. (E44, M9)

# POWER SUPPLY ROUTING


## Wiring Diagram -POWER- (Cont'd)



Refer to Foldout Page in EL Section for details. (E52)




Refer to Foldout Page in EL Section for details. (E44) (M9)



# POWER SUPPLY ROUTING



## Wiring Diagram -POWER- (Cont'd)

EL-POWER-04



10A	n	a	20A
20A	o	b	20A
20A	p	c	5A
15A	q	d	15A
15A	r	e	15A
15A	s	f	20A
10A	t	g	10A
10A	u	h	15A
10A	v	i	10A
10A	w	j	20A
15A	x	k	20A
15A	y	l	10A
10A	z	m	10A


UP  
↑  
M15



# POWER SUPPLY ROUTING

## Wiring Diagram -POWER- (Cont'd)

EL-POWER-05



**R** : MODELS WITH REAR A/C

**DT** : MODELS WITH DIGITAL TOUCH ENTRY SYSTEM

10A	n	a	20A
20A	o	b	20A
20A	p	c	5A
15A	q	d	15A
15A	r	e	15A
15A	s	f	20A
10A	t	g	10A
10A	u	h	15A
10A	v	i	10A
10A	w	j	20A
15A	x	k	20A
15A	y	l	10A
10A	z	m	10A




M15

# POWER SUPPLY ROUTING

## Wiring Diagram -POWER- (Cont'd)

EL-POWER-06

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



10A	n	a	20A
20A	o	b	20A
20A	p	c	5A
15A	q	d	15A
15A	r	e	15A
15A	s	f	20A
10A	t	g	10A
10A	u	h	15A
10A	v	i	10A
10A	w	j	20A
15A	x	k	20A
15A	y	l	10A
10A	z	m	10A



UP  
↑

M15


# POWER SUPPLY ROUTING

## Wiring Diagram -POWER- (Cont'd)

EL-POWER-07



# POWER SUPPLY ROUTING



## Fuse


- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for clock if vehicle is not used for a long period of time.

GI

MA

EM

LC



## Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

EF &

EC

### CAUTION:

- If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Extreme care should be taken with this link to ensure that it does not come into contact with any other wiring harness, or vinyl or rubber parts.

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

# BATTERY

## CAUTION:

- a. If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- b. After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.




## How to Handle Battery

### METHODS OF PREVENTING BATTERY DISCHARGE


The following precautions must be taken to prevent battery discharge.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- **During every routine maintenance, check the electrolyte level.**

This applies also to batteries designated as "low maintenance" and "maintenance free".



- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal.



- Check the condition of the battery by checking the specific gravity of the electrolyte. Refer to EL-15.



# BATTERY


## How to Handle Battery (Cont'd) CHECKING ELECTROLYTE LEVEL

### WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If the acid contacts the eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.


Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.

- Remove the vent cap with a suitable tool.
- Add distilled water up to the MAX. level.




### SULPHATION

If a battery is left unattended for a long period of time and has a specific gravity of less than 1.100, it will be completely discharged, resulting in sulphation on the cell plates. A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



### SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.



- When electrolyte level is too low, tilt battery case to raise it for easy measurement.

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# BATTERY

## How to Handle Battery (Cont'd)

- Use the chart below to correct your hydrometer reading according to electrolyte temperature.

### Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (129)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012
4 (39)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.270 - 1.290	Fully charged
1.240 - 1.260	3/4 charged
1.210 - 1.230	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

## CHARGING THE BATTERY

### CAUTION:

- Do not "quick charge" a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

### Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

## BATTERY

### How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to **initial** charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.
- After the battery is charged, always perform a "capacity test" as follows, to assure that the battery is serviceable.

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST


BF

HA

EL

IDX


# BATTERY



- Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT (Load tester)

Type	Current (A)
35	180
24R	195



SEL008Z

## Voltage chart

Estimated electrolyte temperature °C (°F)	Minimum voltage under 15 second load
21 (70) or above	9.6
16 (60)	9.5
10 (50)	9.4
4 (40)	9.3
-1 (30)	9.1
-7 (20)	8.9
-12 (10)	8.7
-18 (0)	8.5

## Service Data and Specifications (SDS)

Applied model	USA	USA option and Canada
Type	35	24R
Capacity	V-AH 12-60	12-65

NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

# STARTING SYSTEM

---

## System Description

Power is supplied at all times:

- to ignition switch terminal ⑦
- through 30A fusible link (No. ⑩, located in the fusible link box-1).

With the ignition switch in the START position, power is supplied:

- through terminal ⑧ of the ignition switch
- to inhibitor relay terminal ⑦.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter Z, located in the fuse block)
- to terminal ② of the inhibitor switch
- through terminal ① of the inhibitor switch, with the selector lever in the P or N position
- to terminal ① of the inhibitor relay.

Ground is supplied:

- to inhibitor relay terminal ②
- through body grounds (E7), (E41), and (E61).


With power and ground supplied, the inhibitor relay is energized, and power is supplied:

- from terminal ⑥ of the inhibitor relay
- to the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

# STARTING SYSTEM

## Wiring Diagram -START-



GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**  
FDX

Refer to POWER SUPPLY ROUTING in EL Section. (M15)

Refer to POWER SUPPLY ROUTING in EL Section. (E27)

Refer to POWER SUPPLY ROUTING in EL Section. (E35)

Refer to Foldout Page in EL Section for details. (E52)

(E29)

(E1)

(F1)

(F29)

(E24)


(F52)

(M65)

# STARTING SYSTEM — Starter —

## Construction

M1T64285




AEL433

- ① Cap
- ② Stopper set
- ③ Pinion set
- ④ Front bracket
- ⑤ Lever set
- ⑥ Magnetic switch assembly

- ⑦ Clutch gear
- ⑧ Internal gear
- ⑨ Gear shaft
- ⑩ Planetary gear
- ⑪ Ball
- ⑫ Center bracket

- ⑬ Yoke assembly
- ⑭ Armature
- ⑮ Brush assembly
- ⑯ Brush holder
- ⑰ Rear bracket
- ⑱ Support






## Removal and Installation

1. Remove battery negative cable from battery.
2. Remove intake air duct.
3. Remove battery cable from starter motor.
4. Remove brush cable from magnetic switch assembly.
5. Disconnect starter motor harness connector.
6. Remove starter motor mounting bolts.
7. Remove starter motor.

When installing, tighten starter motor mounting bolts.

: 23 - 26 N·m (2.35 - 2.7 kg-m, 17.0 - 19.2 ft-lb)

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

## STARTING SYSTEM — Starter —

### Pinion/Clutch Check

1. inspect pinion teeth.
  - Replace pinion gear if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
  - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
  - If it locks or rotates in both directions, or unusual resistance is evident. ... Replace.

### Service Data and Specifications (SDS)

#### STARTER

Type		M001T64285
System voltage	V	12
No-load		
Terminal voltage	V	11.0
Current	A	Less than 90
Revolution	rpm	More than 2,900
Minimum diameter of commutator	mm (in)	28.8 (1.134)
Minimum length of brush	mm (in)	11.0 (0.433)
Brush spring tension	N (kg, lb)	17.7 - 21.6 (1.8 - 2.2, 4.0 - 4.9)
Clearance of bearing metal and armature shaft	mm (in)	0.01 - 0.20 (0.0004 - 0.0079)
Clearance "t" between pinion front edge and pinion stopper	mm (in)	0.05 - 1.5 (0.0020 - 0.0591)
Installed current	A	150

# CHARGING SYSTEM

## System Description

The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to generator terminal (S) through:

- 10A fuse (No. 3, located in the fusible link box-1).

Voltage output through generator terminal (B), to charge the battery and operate the vehicle's electrical system, is controlled by the amount of field voltage detected by the IC voltage regulator at terminal (S). The charging circuit is protected by the 120A fusible link (No. 9, located in the fusible link box-2).

Terminal (E) of the generator supplies ground through a body ground.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter U, located in the fuse block)
- to combination meter terminal (8) for the charge indicator.

Ground is supplied:

- to terminal (9) of the combination meter
- through terminal (L) of the generator.

With power and ground supplied, the charge indicator will illuminate. When the generator is providing sufficient voltage with the engine running, the ground is opened and the charge indicator will go off. If the charge indicator illuminates with the engine running, a fault is indicated. Refer to "Trouble Diagnoses", "CHARGING SYSTEM" (EL-27).

GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR

ST

BF

HA



EL

IDX

# CHARGING SYSTEM

## Wiring Diagram -CHARGE-

### EL-CHARGE-01




Refer to Foldout Page in EL Section for details. **(M24)**

Refer to POWER SUPPLY ROUTING in EL Section. **(E27)**

Refer to POWER SUPPLY ROUTING in EL Section. **(M15)**

Refer to Foldout Page in EL Section for details. **(M9)**  
**(E44)**

Refer to POWER SUPPLY ROUTING in EL Section. **(E35)**




Refer to Foldout Page in EL Section for details. **(M125)**

# CHARGING SYSTEM

## Trouble Diagnoses

Before conducting a generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The generator can be checked easily by referring to the Inspection Table.


**Before starting diagnosis, inspect the fusible link.**



- 1) Use fully charged battery.
- 2) Light: Charge warning light  
ACG: Generator parts except IC voltage regulator  
IC-RG : IC voltage regulator  
OK : Generator is in good condition.
- 3) When reaching "Damaged ACG", or "Damaged IC-RG" remove generator from vehicle and disassemble, inspect and correct or replace faulty parts.
- 4) Terminals "S", "L" and "B" are marked on rear cover of generator.

Make sure connector (S, L) is connected correctly.

Construction



- ① Pulley assembly
- ② Front cover
- ③ Front bearing
- ④ Bearing retainer

- ⑤ Rotor
- ⑥ Rear bearing
- ⑦ Stator

- ⑧ IC voltage regulator assembly
- ⑨ Diode assembly
- ⑩ Rear cover

Removal and Installation


1. Disconnect battery cable.
2. Loosen idler pulley adjusting bolt.
3. Remove A/C compressor belt.
4. Remove engine undercover.
5. Remove generator harness and bracket.
6. Loosen generator mounting bolt.
7. Remove drive belt.
8. Remove generator.
- Install in the reverse order of removal.

## Diode Check


### MAIN DIODES

- In order to check diodes, they must first be unsoldered from the stator.
- Use an ohmmeter to check condition of diodes as indicated in chart below.
- If any of the test results is not satisfactory, replace diode assembly.

	Ohmmeter probes		Judgement
	Positive ⊕	Negative ⊖	
Diodes check (Positive side)	Positive diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Positive diode plate	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one direction.
	Diode terminals	Negative diode plate	



SEL385L



AEL222

### SUB-DIODES

- Attach ohmmeter's probe to each end of diode to check for continuity.
- Continuity:**  
**Diode conducts in only one direction.**
- Continuity is NG ... Replace diode assembly.

### Assembly

Carefully observe the following instructions.

- When soldering each stator coil lead wire to diode assembly terminal, carry out the operation as fast as possible.



GE  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

## CHARGING SYSTEM — Generator —

### Assembly (Cont'd)

#### REAR COVER INSTALLATION

- (1) Before installing front cover with pulley and rotor with rear cover, push brush up with fingers and retain brush by inserting brush lift wire into brush lift hole from outside.
- (2) After installing front and rear sides of generator, pull out brush lift wire.




#### Service Data and Specifications (SDS)

Type		A4T02591ZC
Nominal rating	V-A	12-110
Ground polarity		Negative
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	1,300
Hot output current	A/rpm	More than 33/1,300 More than 85/2,500
Regulated output voltage	V	14.1 - 14.7
Minimum length of brush	mm (in)	8.0 (0.315)
Brush spring pressure	N (g, oz)	3.138 - 4.315 (320 - 440, 11.29 - 15.52)
Slip ring minimum outer diameter	mm (in)	More than 22.1 (0.870)
Rotor (Field coil) resistance	$\Omega$	2.3 - 2.7




# COMBINATION SWITCH

## Combination Switch/Check



Light switch



Lighting switch


	Off	1st	2nd
1			○
2			○
3			○
4			○
5		○	○
6		○	○
7			○
8			○

Turn signal and cornering lamp switch

	L	N	R
1	○	○	○
2	○	○	○
3	○	○	○
4	○	○	○
5	○	○	○
6			○

Lighting switch - 2

	A	B	C
11	○	○	○
12	○	○	○
13			○
14			○
15			○
16			○




Wiper switch

	Off	Int Max	Int Min	LO	HI	Wash
7	○	○	○	○	○	○
8	○	○	○	○	○	○
9	47.6 kΩ	103.3 kΩ	11.3 kΩ	103.3 kΩ	11.3 kΩ	3.3 kΩ
					4.08 kΩ	3.3 kΩ
						3.3 kΩ

CI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

## COMBINATION SWITCH



### Combination Switch/Replacement

- To remove combination switch, remove attaching screws.

# COMBINATION SWITCH

---

## NOTE

GI

MA

EW

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

# HEADLAMP

## System Description (For USA)

The headlamps are controlled by the lighting switch.

Power is supplied at all times:

- to lighting switch terminal ③, and
- to combination switch terminal ⑭
- through 15A fuse (No. ④, located in the fusible link box-1), and
- to lighting switch terminal ①, and
- to combination switch terminal ⑯
- through 15A fuse (No. ⑤, located in the fusible link box-1).

### LOW BEAM OPERATION

When the lighting switch is turned to the HEAD position, power is supplied:

- from the lighting switch terminal ②
- to the LH headlamp relay terminal ③
- through the LH headlamp relay terminal ④
- to the LH headlamp terminal ①, and
- from lighting switch terminal ④
- to the RH headlamp relay terminal ③
- through the RH headlamp relay terminal ④
- to the RH headlamp terminal ①.

Terminal ③ of each headlamp supplies ground through body grounds: (E7), (E41), (E61), (M5), and (M75).

With power and ground supplied, the headlamps will illuminate.

### HIGH BEAM OPERATION

When the combination switch is placed in the HI BEAM position, with the lighting switch in the HEAD position, power is supplied:

- to the combination switch terminal ⑫
- through the combination switch terminal ⑪
- to the LH headlamp relay terminal ①, and
- to the RH headlamp relay terminal ①.

Ground is supplied to the LH headlamp relay terminal ② and the RH headlamp relay terminal ② through body grounds: (E7), (E41), (E61), (M5), and (M75).

With power and ground supplied, the headlamp relays energize, and power is supplied:

- through the LH headlamp relay terminal ⑤
- to the LH headlamp terminal ②, and
- through the RH headlamp relay terminal ⑤
- to RH headlamp terminal ②, and
- to the combination meter terminal ⑥ for the hi beam indicator.

Terminal ③ of each headlamp, and terminal ⑫ of the combination meter supplies ground through body grounds: (E7), (E41), (E61), (M5), and (M75). With power and ground supplied, the high beams, and the hi beam indicator will illuminate.

### FLASH-TO-PASS OPERATION


When the combination switch is placed in the FLASH-TO-PASS position, power is supplied:

- to the LH headlamp terminal ②
- through the combination switch terminal ⑮, and
- to the RH headlamp terminal ②, and
- to the combination meter terminal ⑥ for the hi beam indicator,
- through the combination switch terminal ⑬.

With ground supplied through body grounds: (E7), (E41), (E61), (M5), and (M75), the high beams, and the hi beam indicator will illuminate until the combination switch is released from the FLASH-TO-PASS position.

# HEADLAMP

## Schematic (For USA)





Ⓐ : Models equipped with autolamp system

- GI
- MA
- EM
- LC
- EF & EC
- FE
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL
- IDX


# HEADLAMP

## Wiring Diagram (For USA) -H/LAMP-

### EL-H/LAMP-01




Refer to Foldout Page in EL Section for details.



AEL320-A

# HEADLAMP

## Wiring Diagram (For USA) -H/LAMP- (Cont'd)





Refer to POWER SUPPLY ROUTING in EL Section. (E35)

Refer to POWER SUPPLY ROUTING in EL Section. (M15)

Refer to Foldout Page in EL Section for details. (E44)


(M9)




# HEADLAMP

## Wiring Diagram (For USA) -H/LAMP- (Cont'd)



### EL-H/LAMP-03



Refer to Foldout Page in EL Section for details.



Refer to POWER SUPPLY ROUTING in EL Section.







# HEADLAMP

## Wiring Diagram (For USA) -H/LAMP- (Cont'd)



**EL-H/LAMP-04**

**A** : MODELS WITH AUTOLAMP SYSTEM

CI  
 MA  
 EM  
 LG  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX



Refer to Foldout Page in EL Section for details. M24



# HEADLAMP

## Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order
Headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E7), (E41), (E61), (M5), (M75)</li> <li>3. 15A fuses</li> <li>4. Headlamp relays</li> <li>5. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulbs.</li> <li>2. Check grounds (E7), (E41), (E61), (M5), (M75).</li> <li>3. Check 15A fuses (No. 4) and 5 located in fusible link box-1). Verify that battery positive voltage is present at terminals 1 and 3 of lighting switch.</li> <li>4. Check relays (LH headlamp relay located in RH engine compartment relay block; RH headlamp relay located in LH engine compartment relay block). Verify that battery positive voltage is present at terminal 3 of the LH and RH headlamp relays with the lighting switch in the HEAD position.</li> <li>5. Check lighting switch.</li> </ol>
LH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E7), (E41), (E61), (M5), (M75)</li> <li>3. 15A fuse</li> <li>4. LH headlamp relay</li> <li>5. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E7), (E41), (E61), (M5), (M75).</li> <li>3. Check 15A fuse (No. 5) located in fusible link box-1). Verify that battery positive voltage is present at terminal 1 of lighting switch.</li> <li>4. Check relay (located in RH engine compartment relay block). Verify that battery positive voltage is present at terminal 3 of the LH headlamp relay with the lighting switch in the HEAD position.</li> <li>5. Check lighting switch.</li> </ol>
RH headlamps do not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds (E7), (E41), (E61), (M5), (M75)</li> <li>3. 15A fuse</li> <li>4. RH headlamp relay</li> <li>5. Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds (E7), (E41), (E61), (M5), (M75).</li> <li>3. Check 15A fuse (No. 4) located in fusible link box-1). Verify that battery positive voltage is present at terminal 3 of lighting switch.</li> <li>4. Check relay (located in LH engine compartment relay block). Verify that battery positive voltage is present at terminal 3 of the RH headlamp relay with the lighting switch in the HEAD position.</li> <li>5. Check lighting switch.</li> </ol>
LH low beam headlamp does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. LH headlamp relay</li> <li>3. Open in LH low beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check relay (located in RH engine compartment relay block).</li> <li>3. Check OR/Y wire between LH headlamp relay and LH headlamp for an open circuit.</li> </ol>

# HEADLAMP

## Trouble Diagnoses (For USA) (Cont'd)

Symptom	Possible cause	Repair order
LH high beam headlamp does not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. LH headlamp relay</li>   <li>3. Combination switch</li>   <li>4. Open in LH high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check relay (located in RH engine compartment relay block). Verify that battery positive voltage is present at terminal ① of relay with lighting switch in HEAD position and combination switch in HI BEAM position.</li> <li>3. Check combination switch. Verify that battery positive voltage is present at terminal ⑫ of the combination switch with the lighting switch in the HEAD position.</li> <li>4. Check OR wire between LH headlamp relay and LH headlamp for an open circuit.</li> </ol>
RH low beam headlamp does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. RH headlamp relay</li>   <li>3. Open in RH low beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check relay (located in LH engine compartment relay block).</li> <li>3. Check OR wire between RH headlamp relay and RH headlamp for an open circuit.</li> </ol>
RH high beam headlamp does not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. RH headlamp relay</li>   <li>3. Combination switch</li>   <li>4. Open in RH high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check relay (located in LH engine compartment relay block). Verify that battery positive voltage is present at terminal ① of relay with lighting switch in HEAD position and combination switch in HI BEAM position.</li> <li>3. Check combination switch. Verify that battery positive voltage is present at terminal ⑫ of the combination switch with the lighting switch in the HEAD position.</li> <li>4. Check OR/L wire between RH headlamp relay and RH headlamp for an open circuit.</li> </ol>
Flash-to-pass switch does not work.	<ol style="list-style-type: none"> <li>1. Combination switch</li>   <li>2. Open in flash-to-pass circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check combination switch. Verify that battery positive voltage is present at terminals ⑭ and ⑮ of the combination switch.</li> <li>2. Check wires between combination switch and headlamps for an open circuit.</li> </ol>
High beam indicator does not work.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in high beam indicator circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> <li>2. Check OR/L wire for an open circuit.</li> </ol>

GI  
 MA  
 EM  
 LG  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 DX

# HEADLAMP

## System Description (For Canada)

The headlamp system for Canadian vehicles contains a daytime lamp control module that activates the high beams at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started, the daytime lamps will not be illuminated. The daytime lamps will illuminate once the parking brake is released. Thereafter, the daytime lamps will continue to operate when the parking brake is released.

Power is supplied at all times:

- to lighting switch terminal ③
- to combination switch terminal ⑭
- to daytime lamp control module terminal ③
- through 15A fuse (No. ④, located in the fusible link box-1), and
- to lighting switch terminal ①
- to combination switch terminal ⑯
- to daytime lamp control module terminal ④
- through 15A fuse (No. ⑤, located in the fusible link box-1).

With the ignition switch in the ON or START position, power is supplied:

- to the daytime lamp control module terminal ⑤
- through 10A fuse (Letter ①, located in the fuse block).

With the ignition switch in the START position, power is supplied:

- to the daytime lamp control module terminal ①
- through 5A fuse (Letter ②, located in the fuse block).

Ground is supplied to the daytime lamp control module terminal ⑩ through body grounds: ⑦, ④①, ⑥①, ⑤, and ⑦⑤.

### LOW BEAM OPERATION

When the lighting switch is turned to the HEAD position, power is supplied:

- from the lighting switch terminal ②
- to the LH headlamp relay terminal ③
- through the LH headlamp relay terminal ④
- to the LH headlamp terminal ①, and
- from the lighting switch terminal ④
- to the RH headlamp relay terminal ③
- through the RH headlamp relay terminal ④
- to RH headlamp terminal ①.

Terminal ③ of the LH headlamp supplies ground through body grounds: ⑦, ④①, ⑥①, ⑤, and ⑦⑤.

Terminal ③ of the RH headlamp supplies ground:

- through terminal ⑧ of the daytime lamp control module
- to terminal ⑩ of the daytime lamp control module
- through body grounds: ⑦, ④①, ⑥①, ⑤, and ⑦⑤.

With power and ground supplied, the headlamps will illuminate.

### HIGH BEAM OPERATION

When the combination switch is placed in the HI BEAM position, and the lighting switch is the HEAD position, power is supplied:

- to the combination switch terminal ⑫
- through the combination switch terminal ⑬
- to the LH headlamp relay terminal ①, and
- to the RH headlamp relay terminal ①.

Ground is supplied to the LH headlamp relay terminal ②, and the RH headlamp relay terminal ② through body grounds: ⑦, ④①, ⑥①, ⑤, and ⑦⑤.

With power and ground supplied, the headlamp relays energize, and power is supplied:

- through the LH headlamp relay terminal ⑤
- to the LH headlamp terminal ②, and
- through the RH headlamp relay terminal ⑤

# HEADLAMP

## System Description (For Canada) (Cont'd)

- to the combination meter terminal ⑥ for the hi beam indicator, and
- to the daytime lamp control module terminal ⑥
- through the daytime lamp control module terminal ⑦
- to the RH headlamp terminal ②.

Terminal ③ of the LH headlamp, and terminal ⑫ of the combination meter supply ground through body grounds: ⑦, ④, ⑥, ⑤, and ⑦.

Terminal ③ of the RH headlamp supplies ground:

- through terminal ⑧ of the daytime lamp control module
- to terminal ⑩ of the daytime lamp control module
- through body grounds: ⑦, ④, ⑥, ⑤, and ⑦.

With power and ground supplied, the high beams, and the hi beam indicator illuminate.

### DAYTIME LAMP OPERATION

With the engine running and the lighting switch in the OFF position, and the parking brake released, power is supplied:

- to the daytime lamp control module terminal ④
- through the daytime lamp control module terminal ⑦
- to the RH headlamp terminal ②
- through the RH headlamp terminal ③
- to the daytime lamp control module terminal ⑧
- through the daytime lamp control module terminal ⑨
- to the LH headlamp terminal ②.

Ground is supplied to the LH headlamp terminal ③ through body grounds: ⑦, ④, ⑥, ⑤, and ⑦. Because the high beams are now wired in series, they operate at half illumination.

CI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

# HEADLAMP

## Schematic (For Canada)




(A) Models equipped with autolamp system

# HEADLAMP

## Wiring Diagram (For Canada) -DTRL-

EL-DTRL-01



Refer to POWER SUPPLY ROUTING in EL Section. (M15)

Refer to Foldout Page in EL Section for details. (M24)

Refer to Foldout Page in EL Section for details. (M9, E44)

(1) (M19)

(9 2) (11 3 4)  
(10 12 1) (5) (E3)





(L) (E20)

AEL321-A

# HEADLAMP

## Wiring Diagram (For Canada) -DTRL- (Cont'd)

EL-DTRL-02






# HEADLAMP


## Wiring Diagram (For Canada) -DTRL- (Cont'd)

**EL-DTRL-03**


**A** : MODELS WITH  
AUTOLAMP SYSTEM



Refer to POWER  
SUPPLY ROUTING (E35)  
in EL Section.



Refer to POWER  
SUPPLY ROUTING (M15)  
in EL Section.




Refer to Foldout  
Page in EL Section  
for details. (E44)  
(M9)

AEL321-C


# HEADLAMP

## Wiring Diagram (For Canada) -DTRL- (Cont'd)



EL-DTRL-04



Refer to Foldout  
Page in EL Section  
for details.



Refer to POWER  
SUPPLY ROUTING  
in EL Section.






# HEADLAMP

## Wiring Diagram (For Canada) -DTRL- (Cont'd)


**A** : MODELS WITH AUTOLAMP SYSTEM

**EL-DTRL-05**

GI  
WA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**  
IDX



Refer to Foldout Page in EL Section for details. M24















# HEADLAMP

## Trouble Diagnoses (For Canada)








### DAYTIME LAMP CONTROL MODULE INSPECTION TABLE

(Data are reference values)

Terminal No.	Item	Condition	Judgement standard
1	Start signal	 When turning ignition switch to "ST".	Battery positive voltage
		 When turning ignition switch to "ON".	1V or less
		 When turning ignition switch to "OFF".	1V or less
2	Lighting switch (Low beam)	When turning lighting switch to "HEAD" (2nd position).	Battery positive voltage
3	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
4	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "OFF".	Battery positive voltage
5	Power source	 When turning ignition switch to "ON".	Battery positive voltage
		 When turning ignition switch to "ST".	Battery positive voltage
		 When turning ignition switch to "OFF".	1V or less
6	Combination switch (High beam)	When placing combination switch to "HI BEAM" with lighting switch in "HEAD" position.	Battery positive voltage
		When placing combination switch to "FLASH TO PASS".	Battery positive voltage
7	RH headlamp control (power)	When placing combination switch to "HI BEAM" with lighting switch in "HEAD" position.	Battery positive voltage
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime lamp operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Battery positive voltage
8	RH headlamp control (ground)	When lighting switch is turned to "HEAD".	1V or less
		 When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime lamp operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage


# HEADLAMP

## Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition	Judgement standard
9	Daytime lamp control		Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime lamp operation). <b>CAUTION: Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage
10	Ground	—	—
11	Generator	 When turning ignition switch to "ON".	4.6V or less
		 When engine is running.	Battery positive voltage
		 When turning ignition switch to "OFF".	1V or less
12	Parking brake switch	 When parking brake is released.	Battery positive voltage
		 When parking brake is set.	1.5V or less

GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# HEADLAMP



## Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**
1. Disconnect the battery cable.
  2. Disconnect the harness connector from the back side of the bulb.
  3. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
  4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
  5. Install in the reverse order of removal.

### CAUTION:

- **Do not leave the bulb out of the headlamp reflector for a long period of time as dust, moisture, smoke, etc. may enter the headlamp body and affect the performance of the headlamp. Thus, the headlamp bulb should not be removed from the headlamp reflector until just before a replacement bulb is to be installed.**


## Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Before operating any aimer, it should be in good repair, calibrated and used according to respective operation manuals supplied with the unit.

If an aimer is not available, aiming adjustment can be done as follows:

**For details, refer to the regulations in your own country.**

- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**



## AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Example:

4H2V

Horizontal side: 4

Vertical side: 2

# HEADLAMP

## Aiming Adjustment (Cont'd)

### LOW BEAM

1. Turn headlamp low beam "ON".
2. Use adjusting screws to perform aiming adjustment.

GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR



ST

BF

HA

EL

IDX



- Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown at left.
  - Dotted lines in illustration show center of headlamp.
- "H": Horizontal center line of headlamp.  
 "W<sub>L</sub>": Distance between each headlamp center

## System Description

The autolamps are controlled by the autolamp switch and the autolamp control module. Power is supplied at all times:

- to the autolamp control module terminal (5), and
- to the autolamp relay-1 terminal (3)
- through 15A fuse (No. (5), located in the fusible link box-1), and
- to autolamp relay-1 terminals (1) and (6)
- through 15A fuse (No. (4), located in the fusible link box-1), and
- to autolamp relay-2 terminal (3)
- through 15A fuse (Letter (S), located in the fuse block).

When the ignition switch is in the ON or START position, power is supplied:

- to the autolamp relay-2 terminal (1), and
- to the autolamp control module terminal (1)
- through 10A fuse (Letter (T), located in the fuse block), and
- to the autolamp control module terminal (4)
- through 10A fuse (Letter (Z), located in the fuse block).

## AUTOMATIC ILLUMINATION

With the autolamp switch turned to the ON position, ground is supplied to the autolamp control module terminal (7):

- through the autolamp switch terminal (17)
- to the autolamp switch terminal (16)
- through body grounds: (E7), (E41), (E61), (M5), and (M75).

With power at terminals (1), (4), and (5); and ground supplied, the autolamp control module will measure the ambient light intensity through terminals (11) and (12). If the autolamp sensor does not detect sufficient light, then ground is supplied:

- through autolamp control module terminal (3)
- to terminal (2) of the autolamp relays.

With power and ground supplied, the autolamp relays energize and power is supplied:

- through autolamp relay-1 terminal (5)
- to LH headlamp relay terminal (3)
- through LH headlamp relay terminal (4)
- to LH headlamp terminal (1), and
- through autolamp relay-1 terminal (7)
- to RH headlamp relay terminal (3)
- through RH headlamp relay terminal (4)
- to RH headlamp terminal (1), and
- through autolamp relay-2 terminal (5)
- to the parking lamps.

Ground is supplied to terminal (3) of the headlamps and to the parking lamps through body grounds: (E7), (E41), (E61), (M5), and (M75).

With power and ground supplied, the headlamps and parking lamps illuminate.

## DELAYED EXIT

With the autolamp switch turned to the ON position, and both the lighting switch and the ignition switch turned from the ON position to the OFF position, the autolamp control module will not read a voltage signal at terminals (1) and (4). This will start the autolamp control module's internal timer. The timer is set based on the resistance value at terminal (2) of the autolamp control module. With the timer running, the headlamps and parking lamps illuminate. When the timer reaches the end of its cycle, the headlamps and parking lamps will turn off.







# AUTOLAMP



## Trouble Diagnoses

### DIAGNOSTIC PROCEDURE 1

**SYMPTOM:** Lamps do not turn on or off with environmental light levels.



Condition of autolamp switch	Continuity
Off	No
On	Yes



Ⓐ



GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA

EL

IDX

# AUTOLAMP

## Trouble Diagnoses (Cont'd)



(A)

**D**

**AUTOLAMP SENSOR OUTPUT CHECK**

- 1) Keep ignition switch "ON".
- 2) Turn autolamp switch to ON position.
- 3) Block autolamp sensor to environmental light. Wait at least 4 seconds.
- 4) Measure voltage between control module harness terminal (3) and body ground with autolamp switch "ON".

**Voltage should be less than 2V.**

OK → Check harness and headlamp and taillamp relays.

NG

**E**

**AUTOLAMP SENSOR CONTINUITY CHECK**

- 1) Remove autolamp sensor.
- 2) Check continuity between autolamp sensor connector terminals (11) and (12) with positive lead on pin (11) and negative lead on pin (12).  
**Continuity should exist.**
- 3) Reverse leads.  
**Continuity should not exist.**

**NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for your tester.**

NG → Replace autolamp sensor.

OK




Replace autolamp control module.

# AUTOLAMP

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE 2

**SYMPTOM:** Headlamp shutoff delay does not work properly.



**A**

**AUTOLAMP SWITCH AND GROUND CHECK**

- 1) Turn ignition switch to "OFF".
- 2) Check continuity between autolamp control module harness terminal ⑦ and body ground.

Condition of autolamp switch	Continuity
Off	No
On	Yes

NG → Check harness and autolamp switch.

**B**

**BATTERY INPUT CHECK**

- 1) Keep ignition switch "OFF".
- 2) Measure voltage between control module harness terminal ⑤ and body ground.

**Battery positive voltage should exist.**

NG → Check battery, fuses and harness.

**C**

**IGNITION POWER CHECK**

- 1) Turn ignition switch to "ON".
- 2) Measure voltage between control module harness terminals ①, ④ and body ground.

**Battery positive voltage should exist.**

NG → Check battery, fuses and harness.

OK → (A)

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

# AUTOLAMP

## Trouble Diagnoses (Cont'd)



**D**

- DELAY RESISTANCE CHECK**
- 1) Turn ignition switch to "OFF".
  - 2) Measure resistance between control module harness terminal ② and body ground.
  - 3) Verify that resistance steadily increases as autolamp switch is turned from minimum to maximum.

Condition of autolamp switch	Resistance [kΩ]
Minimum	3.5
Maximum	196

NG → Replace autolamp switch.

OK

Replace autolamp control module.

# AUTOLAMP

---

NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA


**EL**

IDX


# EXTERIOR LAMP

## Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L-

EL-TAIL/L-01




Refer to POWER SUPPLY ROUTING in EL Section. (M15)




Refer to Foldout Page in EL Section for details. (M125)

Refer to Foldout Page in EL Section for details. (M9, E44)






# EXTERIOR LAMP

## Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- (Cont'd)




G1  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

Refer to POWER SUPPLY ROUTING in EL Section.



Refer to Foldout Page in EL Section for details.




EL-61

AEL322-B




# EXTERIOR LAMP

## Clearance, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L- (Cont'd)



EL-TAIL/L-03



Refer to POWER SUPPLY ROUTING in EL Section. (E35)



Refer to Foldout Page in EL Section for details. (M9, E44)






# EXTERIOR LAMP

## Back-up Lamp/Wiring Diagram -BACK/L-


### EL-BACK/L-01



GI  
NA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**

IDX

Refer to POWER SUPPLY ROUTING in EL Section. (M15)



# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/System Description

### TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter **v**, located in the fuse block)
- to hazard switch terminal **2**
- through terminal **1** of the hazard switch
- to combination flasher unit terminal **1**
- through terminal **3** of the combination flasher unit
- to turn signal switch terminal **1**.

Ground is supplied to combination flasher unit terminal **2** through body grounds **(B2)**, **(M5)**, and **(M75)**.

### LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal **2** to:

- front turn signal lamp LH terminal **3**
- rear combination lamp LH terminal **2**, and
- combination meter terminal **15**.

Ground is supplied to the front turn signal lamp LH terminal **1** through body grounds **(E7)**, **(E41)**, and **(E61)**.

Ground is supplied to the rear combination lamp LH terminal **4** through body grounds **(B2)**, **(M5)**, and **(M75)**.

Ground is supplied to combination meter terminal **22** through body grounds **(B2)**, **(M5)**, and **(M75)**.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

### RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal **3** to:

- front turn signal lamp RH terminal **3**
- rear combination lamp RH terminal **2**, and
- combination meter terminal **21**.

Ground is supplied to the front turn signal lamp RH terminal **1** through body grounds **(E7)**, **(E41)**, and **(E61)**.

Ground is supplied to the rear combination lamp RH terminal **4** through body grounds **(B2)**, **(M5)**, and **(M75)**.

Ground is supplied to combination meter terminal **22** through body grounds **(B2)**, **(M5)**, and **(M75)**.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

### HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal **3** through:

- 15A fuse (Letter **q**, located in the fuse block).

With the hazard switch in the ON position, power is supplied:

- through terminal **1** of the hazard switch
- to combination flasher unit terminal **1**
- through terminal **3** of the combination flasher unit
- to hazard switch terminal **5**.

Ground is supplied to combination flasher unit terminal **2** through body grounds **(B2)**, **(M5)**, and **(M75)**.

Power is supplied through terminal **4** of the hazard switch to:

- front turn signal lamp LH terminal **3**
- rear combination lamp LH terminal **2**, and
- combination meter terminal **15**.

## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/System Description (Cont'd)

Power is supplied through terminal ⑥ of the hazard switch to:

- front turn signal lamp RH terminal ③
- rear combination lamp RH terminal ②, and
- combination meter terminal ⑳.

Ground is supplied to terminal ① of the front turn signal lamps through body grounds (E7), (E41), and (E61).

Ground is supplied to terminal ④ of the rear combination lamps through body grounds (B2), (M5), and (M75).

Ground is supplied to combination meter terminal ⑳ through body grounds (B2), (M5), and (M75).

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

# EXTERIOR LAMP



## Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN-

EL-TURN-01






Refer to POWER SUPPLY ROUTING in EL Section. (M15)

Refer to Foldout Page in EL Section for details. (M9, E44)



(M35)





EL-66

# EXTERIOR LAMP

## Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN- (Cont'd)

EL-TURN-02



Refer to Foldout Page in EL Section for details.

## EXTERIOR LAMP

### Turn Signal and Hazard Warning Lamps/ Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Hazard switch</li> <li>3. Turn signal switch</li> <li>4. Open in turn signal switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (Letter <b>V</b>, located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal <b>②</b> of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check turn signal switch.</li> <li>4. Check PU wire between combination flasher unit and turn signal switch for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse (Letter <b>Q</b>, located in fuse block). Verify battery positive voltage is present at terminal <b>③</b> of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check PU wire between combination flasher unit and hazard switch for open circuit.</li> </ol>
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds <b>(E7)</b>, <b>(E41)</b>, and <b>(E61)</b></li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds <b>(E7)</b>, <b>(E41)</b>, and <b>(E61)</b>.</li> </ol>
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds <b>(B2)</b>, <b>(M5)</b>, and <b>(M75)</b></li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds <b>(B2)</b>, <b>(M5)</b>, and <b>(M75)</b>.</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds <b>(B2)</b>, <b>(M5)</b> and <b>(M75)</b>.</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> </ol>

# EXTERIOR LAMP

---

## NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

# EXTERIOR LAMP

---

## Cornering Lamp/System Description

The lighting switch must be in PARK or HEAD position for the cornering lamps to operate. The cornering lamp switch is part of the combination switch and is controlled by the turn signal lever. The cornering lamps provide additional lighting in the direction of the turn.

Power is supplied at all times to terminal ⑤ of the lighting switch through:

- 15A fuse (Letter **S**, located in the fuse block).

With the lighting switch in the PARK or HEAD position, power is supplied:

- from terminal ⑥ of the lighting switch
- to cornering lamp switch terminal ④.

### RH turn

When the turn signal lever is moved to the RH position, power is supplied:

- from terminal ④ of the cornering lamp switch
- through terminal ⑥ of the cornering lamp switch
- to cornering lamp RH terminal ③.

Ground is supplied to terminal ① of cornering lamp RH through body grounds **(E7)**, **(E41)**, **(E61)**, **(M5)**, and **(M75)**. The RH cornering lamp illuminates until the turn is completed.

### LH turn

When the turn signal lever is moved to the LH position, power is supplied:

- from terminal ④ of the cornering lamp switch
- through terminal ⑤ of the cornering lamp switch
- to cornering lamp LH terminal ③.


Ground is supplied to terminal ① of cornering lamp LH through body grounds **(E7)**, **(E41)**, **(E61)**, **(M5)**, and **(M75)**. The LH cornering lamp illuminates until the turn is completed.




# EXTERIOR LAMP

## Cornering Lamp/Wiring Diagram -CORN/L- EL-CORN/L-01





CI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**  
IDX



Refer to POWER SUPPLY ROUTING in EL Section. (M15)




Refer to Foldout Page in EL Section for details. (M9) (E44)



### EL-71

## EXTERIOR LAMP



### Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

### Bulb Specifications

Item	Wattage (W)	Bulb No.
Headlamp (Semi-sealed beam)		
High/Low	65/45	9004
Front combination lamp		
Front side marker	3.8	194
Clearance/Cornering	8.25/27	3157
Front turn signal lamp	27	3156
Rear combination lamp		
Turn signal	27	2057
Stop/Tail	27	2057
Back-up	27	3156
Rear side marker lamp	3.8	194
License plate lamp	3.8	194
High-mounted stop lamp	12.8	912
Interior lamp	12	211-2
Tailgate lamp	12	211-2
Step lamp	3.8	194
Map lamp	10	—

# INTERIOR LAMP

## Illumination/System Description

Power is supplied at all times:

- through 15A fuse (Letter **S**, located in the fuse block)
- to the lighting switch terminal **5**.

With the lighting switch in the PARK or HEAD position, power is supplied:

- from lighting switch terminal **6**
- to time control module terminal **10**, and
- to the power terminal on all the illuminated components.

Ground is supplied:

- to the illumination control switch terminal **11**
- through body grounds **M5** and **M75**.

The illumination control switch and the time control module control the amount of current flow through the illumination system.

When the illumination control switch is pressed in the LIGHTEN position, ground is supplied:

- to the time control module terminal **22**
- through the illumination control switch terminal **13**. The time control module reduces the voltage on terminal **13**, increasing the illumination.

When the illumination control switch is pressed in the DARKEN position, ground is supplied:

- to the time control module terminal **23**
- through the illumination control switch terminal **12**. The time control module increases the voltage on terminal **13**, reducing the illumination.

The rear A/C control module illumination and the rear remote control module illumination, if equipped, are not controlled by the illumination control switch. The intensity of these lamps does not change. The rear A/C control module terminal **4** and the rear remote control module terminal **7** are both grounded directly through body grounds **M5** and **M75**.

The following chart shows the power and ground terminals for the components included in the illumination system.



Component	Power terminal	Ground terminal
Radio	<b>4</b>	<b>2</b>
C/D player*	<b>3</b>	<b>1</b>
Rear wiper switch	<b>4</b>	<b>5</b>
A/C control module	<b>25</b>	<b>26</b>
Rear fan switch (front)*	<b>27</b>	<b>28</b>
Power mode switch	<b>6</b>	<b>7</b>
Hazard switch	<b>7</b>	<b>8</b>
Rear A/C control module*	<b>11</b>	<b>4</b>
Cigarette lighter	<b>1</b>	<b>2</b>
Rear remote control module*	<b>8</b>	<b>7</b>
Combination meter	<b>23</b> and <b>10</b>	<b>24</b> and <b>11</b>
ASCD main switch	<b>5</b>	<b>6</b>
Rear window defogger switch	<b>5</b>	<b>6</b>
Lighting switch	<b>7</b>	<b>8</b>
Illumination control switch	<b>14</b>	<b>15</b>

\* If equipped.

# INTERIOR LAMP

## Illumination/Wiring Diagram -ILL-



EL-ILL-01



Refer to POWER SUPPLY ROUTING in EL Section. (M15)

Refer to Foldout Page in EL Section for details. (M24)

Refer to Foldout Page in EL Section for details. (M125)



# INTERIOR LAMP

## Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-02

GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR


ST

BF

HA


EL

IDX





PRECEDING PAGE

NEXT PAGE



Refer to Foldout Page in EL Section for details. M125










# INTERIOR LAMP

## Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-03

CD : MODELS WITH C/D PLAYER



Refer to Foldout Page in EL Section for details. M126

# INTERIOR LAMP


## Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-04





**R** : MODELS WITH REAR A/C

**RR** : MODELS WITH REAR REMOTE RADIO

PRECEDING PAGE



PRECEDING PAGE



Refer to Foldout Page in EL Section for details. **M126**

AEL326-D

GI

MA

EM

LC

EF & EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

# INTERIOR LAMP

## Interior, Map, Step and Tailgate Lamps/ Wiring Diagram -INT/L-

EL-INT/L-01



Refer to POWER  
SUPPLY ROUTING  
in EL Section.

(M15)



(R4)

Refer to Foldout  
Page in EL Section  
for details.

(M24)



(R8)



(R1)



(R7)



(M12)



(R9)

EL-78


AEL327-A



# INTERIOR LAMP

## Interior, Map, Step and Tailgate Lamps/ Wiring Diagram -INT/L- (Cont'd)

EL-INT/L-02



Refer to Foldout Page in EL Section for details.




M126

R10

Refer to Foldout Page in EL Section for details.

E52

Refer to Foldout Page in EL Section for details.



M9

E44

M12



R1



M45




M58




M67



D64



M74



D52


AEL327-B

EL-79

# INTERIOR LAMP











## Interior, Map, Step and Tailgate Lamps/ Wiring Diagram -INT/L- (Cont'd)

EL-INT/L-03



Refer to Foldout Page in EL Section for details. (M126)

Refer to Foldout Page in EL Section for details. (M24)




EL-80

AEL327-C







# INTERIOR LAMP

## Interior, Map, Step and Tailgate Lamps/ Wiring Diagram -INT/L- (Cont'd)

EL-INT/L-04



GF  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
**EL**  
IDX



EL-81

AEL327-D

## System Description

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter **U**, located in the fuse block)
- to combination meter terminals **14** and **33**; and
- through ignition switch terminal **4**
- to ignition coil terminal **1**, and
- to resistor and condenser terminal **3**.

Ground is supplied:

- to combination meter terminals **17** and **30**
- through body ground **M60**.

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter. As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal **13** of the combination meter for the water temperature gauge. The needle on the gauge moves from C to H.

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal:

- from terminal **2** of the ECM (ECCS control module)
- to combination meter terminal **29** for the tachometer.

The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable ground signal supplied:

- to combination meter terminal **20**
- from terminal **4** of the fuel tank gauge unit
- through terminal **3** of the fuel tank gauge unit
- through body grounds **M5** and **M75**.

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.




Voltage is supplied:

- to combination meter terminals **30** and **32**
- from terminals **1** and **2** of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.

# METER AND GAUGES

## Combination Meter




CI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# METER AND GAUGES






## Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER- EL-METER-01

POWER WITH IGNITION SWITCH ON OR START

NEXT PAGE  
A



Refer to POWER SUPPLY ROUTING in EL Section. (M15)






AEL328-A

# METER AND GAUGES


## Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER- (Cont'd)

EL-METER-02


GI  
WA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX






Refer to Foldout Page in EL Section for details.



Refer to Foldout Page in EL Section for details.






Refer to Foldout Page in EL Section for details.




AEL328-B

# METER AND GAUGES





## Inspection/Water Temperature Gauge






# METER AND GAUGES



## Inspection/Fuel Gauge



GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST



BF

HA


EL





IDX

# METER AND GAUGES




## Inspection/Tachometer





## Inspection/Speedometer and Vehicle Speed Sensor



**SYMPTOM: Speedometer stays at 0 km/h (0 MPH).**




GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# METER AND GAUGES

## Inspection/Speedometer and Vehicle Speed Sensor (Cont'd)





**SYMPTOM: Speedometer indication flutters.**



## Inspection/Speedometer and Fuse

**SYMPTOM: Speedometer does not go back to 0 km/h (0 MPH).**





## Fuel Tank Gauge Unit Check

Ohmmeter		Float position mm (in)			Resistance value (Ω)
(+)	(-)	*3	Full	23 (0.91)	Approx. 160
④	③	*2	1/2	93 (3.66)	78
		*1	Empty	151 (5.94)	15

- For removal, refer to FE section ("Removal", "FUEL PUMP AND GAUGE").

Check the resistance between terminals ④ and ③.

GI

WA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR


ST

BF

HA

EL


IDX



## Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
75°C (167°F)	Approx. 179 - 219Ω
100°C (212°F)	Approx. 60 - 72Ω



## Oil Pressure Switch Check

Check the continuity between the terminals of oil pressure switch and body ground.

	Oil pressure kPa (kg/cm <sup>2</sup> , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	YES



## Vehicle Speed Sensor Signal Check

- Remove vehicle speed sensor from transaxle.
- Turn vehicle speed sensor pinion quickly and measure voltage across ① and ②.

## Warning Lamps/System Description

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter **U**, located in the fuse block)
- to combination meter terminals **8**, **14**, **33**
- to oil level timer terminal **5**, and
- through 10A fuse (Letter **I**, located in the fuse block)
- to time control module terminal **3**, and
- to bulb check relay terminal **2**.

Ground is supplied:

- to combination meter terminal **12**
- to oil level timer terminal **1**
- to fuel tank gauge unit terminal **3**, and
- to automatic seat belt control module terminals **6** and **19**
- through body grounds **(M5)** and **(M75)**.

Ground is supplied to combination meter terminal **17** through body ground **(M60)**.

Ground is supplied to ABS control module terminal **10** through body ground **(M61)**.

Ground is supplied:

- to bulb check relay terminal **5**
- to brake fluid level switch terminal **2**
- to washer level switch terminal **1**, and
- to ignition switch terminal **12**
- through body grounds **(E7)**, **(E41)** and **(E61)**.

Ground is supplied to back door latch switch terminal **2** through body ground **(B54)**.

### SUPPLEMENTAL AIR BAG WARNING LAMP

During prove out or when a supplemental air bag malfunction occurs, the ground path is interrupted:

- from the diagnosis (control) unit terminal **17**
- to combination meter terminal **7**

Ground is then supplied:

- through combination meter terminal **12**.

With power and ground supplied, the supplemental air bag warning lamp (LEDs) illuminate.

### LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by a float in the tank. A signal is sent from fuel tank gauge unit terminal **4** to combination meter terminal **20**. The low fuel indicator unit will illuminate the low fuel level lamp when the fuel level is low.

### LOW OIL LEVEL WARNING LAMP

When a low oil level causes the oil level sensor to provide a ground signal to the oil level timer terminal **2**, ground is supplied:

- to combination meter terminal **26**
- from the oil level timer terminal **4**.

With power and ground supplied, the low oil level lamp illuminates.

### LOW OIL PRESSURE WARNING LAMP

Low oil pressure causes the oil pressure switch terminal **1** to provide ground to combination meter terminal **4**.

With power and ground supplied, the low oil pressure lamp illuminates.

### DOOR AJAR WARNING LAMP

When a door is open, a ground signal is received by the time control module at terminals **6**, **9**, **19**, or **20**. Ground is then supplied:

- to combination meter terminal **5**
- from time control module terminal **14**.

With power and ground supplied, the door ajar lamp illuminates.

## WARNING LAMPS AND CHIME

### Warning Lamps/System Description (Cont'd)

#### LOW WASHER FLUID LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied:

- to combination meter terminal (34)
- from washer level switch terminal (2).

With power and ground supplied, the low washer fluid level lamp illuminates.

#### SEAT BELT WARNING LAMP

When the automatic seat belt control module receives a signal indicating the shoulder belts are not fastened, ground is supplied:

- to combination meter terminal (2)
- from automatic seat belt control module terminal (16).

When the time control module receives a signal indicating the LH lap belt is not fastened, ground is supplied:

- to combination meter terminal (2)
- from time control module terminal (24).

With power and ground supplied, the seat belt warning lamp illuminates.

#### MALFUNCTION INDICATOR LAMP

During prove out or when an engine control malfunction occurs, ground is supplied:

- to combination meter terminal (27)
- from ECM terminal (24).

With power and ground supplied, the malfunction indicator lamp illuminates.

#### ABS WARNING LAMP

During prove out or when an ABS malfunction occurs, ground is supplied:

- to combination meter terminal (25)
- from ABS control module terminal (29).

With power and ground supplied, the ABS warning lamp illuminates.

#### BRAKE WARNING LAMP

When the parking brake is set, or the brake fluid level is low, ground is supplied:

- to combination meter terminal (3)
- from parking brake switch terminal (1), or
- from brake fluid level switch terminal (1).

With power and ground supplied, the brake warning lamp illuminates.

#### BULB CHECK RELAY (brake warning lamp prove out)

When the ignition switch is in the ON or START position, and the generator grounds terminal (L), ground is supplied to the bulb check relay terminal (1). With power and ground supplied, the bulb check relay is energized, providing a ground path for the brake warning lamp.

With power and ground supplied, the brake warning lamp illuminates.

#### CHARGE WARNING LAMP

During prove out or when a generator malfunction occurs, ground is supplied:

- to combination meter terminal (9)
- from generator terminal (L)

With power and ground supplied, the charge warning lamp illuminates.

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF


HA

EL

IDX

# WARNING LAMPS AND CHIME





## Warning Lamps/Schematic






# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram -WARN- EL-WARN-01




Refer to Foldout  
Page in EL Section  
for details.




GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram -WARN- (Cont'd)





Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (E52)





Refer to Foldout Page in EL Section for details. (M9, E44)



# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram -WARN- (Cont'd)

EL-WARN-03





AEL329-C

# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram -WARN- (Cont'd)


### EL-WARN-04




(M28)

Refer to Foldout Page in EL Section for details.


(M24)  
(M125)




(M64)



(M30)




(M19)



(F51)


Refer to Foldout Page in EL Section for details.

(M9)  
(E44)





(M63)

(F54)



# WARNING LAMPS AND CHIME

## Warning Lamps/Wiring Diagram -WARN- (Cont'd)



CI  
 MA  
 EM  
 LC  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

# WARNING LAMPS AND CHIME

---

## Warning Chime/System Description

The warning chime is controlled by the Time Control System.

Power is supplied at all times:

- through 15A fuse (Letter **V**), located in the fuse block)
- to warning chime terminal **①**, and
- through 15A fuse (Letter **S**), located in the fuse block)
- to lighting switch terminal **⑤**.

Ground is supplied to the LH lap belt buckle switch terminal **⑦②** through body grounds **①M5**, and **①M75**. Ground is supplied to the key switch terminal **⑤** through body grounds **①E7**, **①E41** and **①E61**. The LH front door switch is internally grounded to the body.

When a signal, or combination of signals is received by the time control module, ground is supplied:

- through time control module terminal **⑫**
- to warning chime terminal **②**.

With power and ground supplied, the warning chime will sound.

### IGNITION KEY WARNING CHIME

With the key in the ignition switch in the OFF position, and the driver door open, the warning chime will sound.

Ground is supplied:

- to time control module terminal **⑧**
- from key switch terminal **④**, and
- to time control module terminal **⑱**
- from LH front door switch terminal **②**.

### LIGHT WARNING CHIME

With the ignition switch in the OFF position, driver door open, and the lighting switch in the PARK or HEAD position, the warning chime will sound.

Power is supplied:

- to time control module terminal **⑩**
- from the lighting switch terminal **⑦**.

Ground is supplied:

- to time control module terminal **⑱**
- from LH front door switch terminal **②**.

### SEAT BELT WARNING CHIME

With the ignition switch turned from the OFF position to the ON position, and the seat belt unfastened (LH lap belt buckle switch ON), the warning chime will sound for approximately 6 seconds.

Ground is supplied:

- to time control module terminal **④**
- from LH lap belt buckle switch terminal **⑦①**.


For diagnosis, refer to "Trouble Diagnoses", "TIME CONTROL SYSTEM" (EL-112).

# WARNING LAMPS AND CHIME

## Warning Chime/Wiring Diagram -CHIME-



EL-CHIME-01

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX





Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (M24)



Refer to Foldout Page in EL Section for details. (M125) (M126)




Refer to Foldout Page in EL Section for details. (M9) (E44)



AEL330


## WARNING LAMPS AND CHIME



### Diode Check






- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

**NOTE:** Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for your tester.



### Warning Chime Check






## Oil Level Timer/Trouble Diagnoses

### DIAGNOSTIC PROCEDURE

Oil level warning does not operate properly.



GI  
 MA  
 EM  
 LG  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

## System Description

Power is supplied at all times:

- to time control module terminal ⑩
- through 10A fuse (Letter **m**, located in the fuse block).

With the ignition switch in the ON or START position, power is supplied:

- to time control module terminal ③
- through 10A fuse (Letter **I**, located in the fuse block).

Terminals ②, ⑤, and ⑮ of the time control module are grounded through body grounds **(E7)**, **(E41)**, **(E61)**, **(M5)**, and **(M75)**.

The time control system controls operation of the

- rear window defogger,
- warning chime,
- illumination control,
- seat belt warning lamp, and
- interior illumination.

### REAR WINDOW DEFOGGER

The time control module will operate the rear window defogger for 12 to 17 minutes as long as the rear window defogger switch is in the ON position. For detailed description, refer to "System Description", "REAR WINDOW DEFOGGER" (EL-130).

### WARNING CHIME

The time control system will operate the warning chime under the following conditions:

- key in ignition, ignition switch in OFF position, and driver's door open.
- ignition switch in the OFF position, driver's door open, and lighting switch in the PARK or HEAD position.
- ignition switch turned from the OFF position to the ON position and the seat belts unfastened.

For detailed description, refer to "Warning Chime/System Description", "WARNING LAMPS AND CHIME" (EL-100).

### ILLUMINATION CONTROL

The time control system controls the instrument illumination level when the lighting switch is in the PARK or HEAD position. For detailed description refer to "Illumination/System Description", "INTERIOR LAMP" (EL-73).

### SEAT BELT WARNING LAMP

The time control system controls the operation of the seat belt warning lamp. The warning lamp will remain illuminated until the driver's lap belt and both shoulder belts are buckled. If all the belts are buckled before the ignition switch is in the ON or START position, the warning lamp will illuminate for 6 seconds, then go out.

### INTERIOR ILLUMINATION

The time control system controls the operation of the following lamps:

- front interior lamp
- step lamps
- rear interior lamp
- tailgate lamps.

The lamps remain illuminated or fade out based on inputs from the following:

- digital touch entry system (if equipped)
- door switches.

# TIME CONTROL SYSTEM

## System Description (Cont'd)

### FUNCTION

- Time control module has the following functions.

	Item	Details of control	
1	Illumination control	Regulates brightness of illumination depending on the illumination control switch setting.	GI MA
2	Light warning chime timer	When driver's door is opened with light switch "ON" and ignition switch "OFF", warning chime sounds.	EM
3	Seat belt warning chime timer	Sounds warning chime for about 6 seconds if ignition switch is turned "ON" when seat belt switch is "ON" (seat belt is unfastened).	LC
4*	Seat belt warning lamp timer	Seat belt warning lamp illuminates when ignition switch is turned to "ON".	EF & EC
5	Rear defogger timer	Operates rear defogger for about 12 to 17 minutes when rear defogger switch is turned to "ON".	FE
6	Ignition key warning chime	Sounds warning chime while opening driver's door if ignition key is in ignition switch.	AT
7	Illuminated entry system Interior lamp	Illuminates for about 10 seconds then fades out when key pad of digital touch entry system is pressed.	FA
8	Interior lamp timer	Fades out front interior lamp and step lamps when driver's, passenger's, or sliding door is opened and closed when ignition is "OFF".	RA
9	Battery saver	Interior lamps shut off in 30 minutes when driver's, passenger's, or sliding door is left open, or in 60 minutes if back door is left open when ignition switch is "OFF". The battery saver will reset if the ignition switch is cycled or any door is opened or closed.	BR

\* Seat belt warning lamp always illuminates unless driver's lab belt and both shoulder belts are buckled.

GI

MA

EM

LC

EF &amp;

EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# TIME CONTROL SYSTEM

## System Description (Cont'd) OPERATING CONDITIONS

Item & Output terminal	Input signal & Input terminal												
	Power source from battery	Ignition switch	Light switch	Driver's door switch*1	Seat belt switch*2	Illumination control switch	Rear window defogger switch	Key switch	Digital touch entry key-board*3	Passenger's door switch*1	Sliding door switch*1	Back door switch*1	Select
⑬ Illumination control	⑮ ON	③	⑩ ON	⑰	④	⑲ or ⑳	⑦	⑧	⑰	⑥	⑨	⑳	⑤
⑫ Light warning chime timer	ON	OFF or ACC	ON	ON		ON							
⑫ Seat belt warning chime timer	ON	OFF or ACC → ON			ON								
⑭ Seat belt warning lamp timer	ON	OFF or ACC → ON			ON								*4
⑮ Rear defogger timer	ON	ON or START					ON						
⑯ Ignition key warning chime	ON	OFF		ON				ON					
⑰ Front interior lamp, step lamps - Digital touch entry system	ON								ON → OFF				
⑱ Front interior lamp, step lamps - Interior lamp timer	ON			ON → OFF						ON → OFF	ON → OFF		
⑲ Front interior lamp, step lamps	ON			ON						ON	ON	ON	
⑳ Rear interior lamp	ON			ON						ON	ON	ON	
㉑ Tailgate lamps	ON											ON	
㉒ Isolated sliding door	ON											ON	

\*1: Door switch is turned "ON" when door is opened.


\*2: Seat belt switch is turned "ON" when driver's lap belt is unfastened.

\*3: Digital touch entry keyboard is turned "ON" when keyboard is pressed.

\*4: Ground — continuous if seat belt switch "ON".

# TIME CONTROL SYSTEM

## Schematic




GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
JDX

# TIME CONTROL SYSTEM


## Wiring Diagram -TIME-

EL-TIME-01



Refer to POWER SUPPLY ROUTING in EL Section.


(M15)



(M1)

Refer to Foldout Page in EL Section for details.

(M24)




(M14)

Refer to Foldout Page in EL Section for details.

(M9)

(E44)




(M36)

# TIME CONTROL SYSTEM


## Wiring Diagram -TIME- (Cont'd)

EL-TIME-02

CI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL



Refer to POWER SUPPLY ROUTING in EL Section.




AEL331-B

# TIME CONTROL SYSTEM


## Wiring Diagram -TIME- (Cont'd)

EL-TIME-03




Refer to POWER SUPPLY ROUTING in EL Section.


M15



M105




M28



M21



M83




M30

Refer to Foldout Page in EL Section for details.


M125



M81



M48





M1

AEL331-C



# TIME CONTROL SYSTEM

## Wiring Diagram -TIME- (Cont'd)




GI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses

Symptom		DIAGNOSTIC PROCEDURE
Illumination	Illumination control system does not actuate.	1
Warning	Light warning chime does not activate.	2
	Set belt warning chime does not activate.	3
	Seat belt warning lamp does not go off nor come on.	4
	Ignition key warning chime does not activate.	5
Rear defogger	Rear defogger does not activate or does not go off.	6
Illuminated entry system	<ul style="list-style-type: none"> <li>Interior lamp does not come on or fade out.</li> <li>Battery saver does not work.</li> </ul>	7




### PREPARATION FOR TROUBLE DIAGNOSIS

1. Remove LH A-pillar lower trim.
2. Remove time control module with harness connected.

### POWER SUPPLY CIRCUIT CHECK

1. Disconnect the harness connector from the control module.
2. Connect ohmmeter from harness side.
3. Check continuity between terminals ②, ⑤, ⑮ and body ground.

Ohmmeter terminals		Continuity
(+)	(-)	
②, ⑤, ⑮	Body ground	Yes



4. Connect the harness connector to the control module.
5. Connect voltmeter from harness side.
6. Measure voltage across terminal ② or ⑮ and terminals ⑯, ⑳.





Voltmeter terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
⑯	② or ⑮	Approx. 12V	Approx. 12V	Approx. 12V
⑳	② or ⑮	0V	0V	Approx. 12V

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE-1

Illumination control system does not actuate.








GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)


### DIAGNOSTIC PROCEDURE-2

Light warning chime does not activate.



### DIAGNOSTIC PROCEDURE-3

Seat belt warning chime does not activate.








# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)








### DIAGNOSTIC PROCEDURE-4

**Seat belt warning lamp does not go off nor comes on.**



### DIAGNOSTIC PROCEDURE-5

**Ignition key warning chime does not activate.**



GI  
 MA  
 EM  
 LC  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE-6

Rear defogger does not activate, or does not go off.

**A TCM OUTPUT FOR REAR DEFOGGER CIRCUIT CHECK**  
 Measure voltage across (25) and (2) while operating rear defogger switch.

Rear defogger switch → ON


- Rear defogger switch "OFF": Approx. 12V
- Rear defogger switch "ON": Approx. 0V

AEL370

**B DEFOGGER SWITCH CIRCUIT CHECK**

- Rear defogger switch is depressed: continuity exists
- Rear defogger switch is released: no continuity

AEL371



# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE-7

- Interior lamp does not come on, or fade out.
- Battery saver does not work.

**A DRIVER'S DOOR SWITCH CIRCUIT CHECK**

Check continuity between (19) and (2) when driver's door is opened and closed.

Driver's door  
Open: 0Ω  
Closed: Except 0Ω

AEL372

**B PASSENGER'S DOOR SWITCH CIRCUIT CHECK**

Check continuity between (6) and (2) when passenger's door is opened and closed.

Passenger's door  
Open: 0Ω  
Closed: Except 0Ω

AEL373

**C SLIDING DOOR SWITCH CIRCUIT CHECK**

Check continuity between (9) and (2) when sliding door is opened and closed.

Sliding door  
Open: 0Ω  
Closed: Except 0Ω

AEL374

**D BACK DOOR SWITCH CIRCUIT CHECK**

Check continuity between (20) and (2) when back door is opened and closed.

Back door  
Open: 0Ω  
Closed: Except 0Ω

AEL375

Perform "PREPARATION FOR TROUBLE DIAGNOSIS." Refer to EL-112.

NG

**A** Check continuity between terminals (19) and (2) when driver's door is opened and closed.

NG → Repair door switch and harness.

Driver's door	Continuity
Open	Yes
Closed	No

Driver's door	Continuity
Open	Yes
Closed	No

OK

**B** Check continuity between terminals (6) and (2) when passenger's door is opened and closed.

NG → Repair door switch and harness.

Passenger's door	Continuity
Open	Yes
Closed	No

Passenger's door	Continuity
Open	Yes
Closed	No

OK

**C** Check continuity between terminals (9) and (2) when sliding door is opened and closed.

NG → Repair door switch and harness.

Sliding door	Continuity
Open	Yes
Closed	No

Sliding door	Continuity
Open	Yes
Closed	No

OK

**D** Check continuity between terminals (20) and (2) when back door is opened and closed.

NG → Repair door switch and harness.

Back door	Continuity
Open	Yes
Closed	No

Back door	Continuity
Open	Yes
Closed	No

OK

(A)

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# TIME CONTROL SYSTEM

## Trouble Diagnoses (Cont'd)

**E KEYBOARD INPUT CHECK**

Measure voltage across (17) and (2) when keyboard is operated.

• Approx. 12V when keyboard is pressed.

AEL376

**F FRONT INTERIOR LAMP CIRCUIT CHECK**

Measure voltage across (26) and (2) when driver's door is opened and closed.

Driver's, passengers', sliding door.  
Open: Less than 2V.  
Closed: Approx. 12V.

AEL377

**G REAR INTERIOR LAMP CIRCUIT CHECK**

Measure voltage across (14) and (2) when any door is opened and closed.

Any door  
Open: Less than 2V.  
Closed: Approx. 12V.

AEL378

**H TAILGATE LAMP CIRCUIT CHECK**

Measure voltage across (1) and (2) when back door is opened and closed.

Back door  
Open: Less than 2V.  
Closed: Approx. 12V.

AEL379

**A**

**E** Keyboard input check

Check voltage between terminals (17) and (2) when keyboard is operated.

Keyboard	pressed	released
Battery positive voltage	Exists	Does not exist

NG → Check keyboard and harness. Refer to EL-178.

OK

**Lamp check**

Switch front interior lamp to "ON".

NG → Check switch and bulb.

OK

**F** Switch front interior lamp to "DOOR" position. Check the voltage between (26) and (2).

Door open	Door closed
Ⓚ Less than 2V. light "ON"	Ⓜ Approx. 12V. light "OFF" after fade out.

Ⓜ NG → Check harness.

Ⓚ NG → Replace time control module.

OK

**G** Switch rear interior lamp to "DOOR" position. Check the voltage between (14) and (2).

Door open	Door closed
Ⓚ Less than 2V. light "ON"	Ⓜ Approx. 12V. light "OFF"

Ⓜ NG → Check harness.

Ⓚ NG → Replace time control module.

OK

**H** Tailgate lamp check

Check the voltage between (1) and (2).

Door open	Door closed
Ⓚ Less than 2V. light "ON"	Ⓜ Approx. 12V. light "OFF"

Ⓜ NG → Check harness.

Ⓚ NG → Replace time control module.

OK

Replace time control module.



# TIME CONTROL SYSTEM

---

NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX

# WIPER AND WASHER

## Front Wiper and Washer/System Description

The wiper switch is controlled by a lever built into the combination switch. There are three wiper positions:

- LO speed
- HI speed
- Intermittent

With the ignition switch in the ACC or ON position, power is supplied:

- through 20A fuse (Letter **f**, located in the fuse block)
- to the wiper motor terminal **d**
- to the washer motor terminal **①**, and
- to the wiper amplifier assembly terminal **②**.

Ground is supplied:

- to the wiper motor terminal **f**, and
- to the wiper amplifier assembly terminals **③** and **⑨**
- through body grounds **(E7)**, **(E41)**, **(E61)**, **(M5)** and **(M75)**.

### LOW SPEED OPERATION

With the wiper switch in the LO position, ground is supplied:

- to wiper motor terminal **b**
- from terminal **⑥** of the wiper amplifier assembly.

With power and ground supplied, the wiper motor operates at low speed.

### HIGH SPEED OPERATION

With the wiper switch in the HI position, ground is supplied:

- to wiper motor terminal **c**
- from terminal **④** of the wiper amplifier assembly.

With power and ground supplied, the wiper motor operates at high speed.

### INTERMITTENT OPERATION

When the wiper switch is set to intermittent operation, the wiper motor operates the wiper arms one time at low speed at an interval of approximately one to fourteen seconds. This feature is controlled by the wiper amplifier assembly.

### AUTO STOP OPERATION

When the wiper switch is placed in the OFF position, the wiper motor will continue to operate until the wiper arms reach the base of the windshield.

When the wiper switch is placed in the OFF position, the wiper amplifier assembly no longer supplies a ground circuit to the wiper motor. The ground circuit is now routed through the wiper motor terminal **f**. This allows the wiper motor to operate until the wiper arms reach the base of the windshield. The wiper motor ground is interrupted when the wiper arms reach the base of the windshield, and the wiper motor stops.

### WASHER OPERATION

When the end of the combination switch is pushed in, ground is supplied:

- to the washer motor terminal **②**
- from terminal **⑤** of the wiper amplifier assembly.


With power and ground supplied, the washer motor operates.

The washer motor will continue to operate as the end of the combination switch is held in. The wiper will operate at low speed to clean the windshield.


# WIPER AND WASHER

## Front Wiper and Washer/Wiring Diagram -WIPER-




EL-WIPER-01



Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (M9, E44)



## WIPER AND WASHER

---

### Rear Wiper and Washer (Except for Glass Hatch Model)/System Description

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (Letter **I**, located in the fuse block)
- to rear wiper amplifier terminal **7**
- to rear wiper motor terminal **2**, and
- to rear washer motor terminal **1**.

Ground is supplied:

- to rear wiper amplifier terminal **6**
- to rear wiper motor terminal **1**, and
- to rear wiper switch terminal **3**
- through body grounds **(B54)**, **(M5)** and **(M75)**.

#### WIPER OPERATION

When the rear wiper switch is in the WIPER position, ground is supplied:

- to the rear wiper amplifier terminal **1**
- through the rear wiper switch terminal **1**.

An intermittent ground is then supplied:

- to the rear wiper motor terminal **4**
- through terminal **4** of the rear wiper amplifier.

With power and ground supplied, the rear wiper motor operates intermittently, with approximately a 15 second interval between cycles.

#### WASHER OPERATION

When the rear wiper switch is in the WASH position, ground is supplied:

- to the rear washer motor terminal **2**, and
- to the rear wiper amplifier terminal **5**
- through the rear wiper switch terminal **2**.

With power and ground supplied, the rear washer motor operates. The rear wiper amplifier then operates the rear wiper motor to clean the glass.

#### AUTO STOP OPERATION

When the rear wiper switch is placed in the OFF position, the rear wiper motor will continue to operate until the rear wiper arm reaches the base of the glass.


When the rear wiper switch is placed in the OFF position, the rear wiper amplifier no longer supplies a ground circuit to the rear wiper motor. The ground circuit is now routed through the rear wiper motor terminal **1**. This allows the wiper motor to operate until the rear wiper arm reaches the base of the glass. The rear wiper motor ground is interrupted when the wiper arm reaches the base of the glass, and the rear wiper motor stops.

# WIPER AND WASHER



## Rear Wiper and Washer (Except for Glass Hatch Model)/Wiring Diagram -WIP/R-

EL-WIP/R-01





CI  
MA  
EM  
LG  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (M9) (E44)



AEL334

# WIPER AND WASHER

---

## Rear Wiper and Washer (For Glass Hatch Model)/System Description

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (Letter **I**, located in the fuse block)
- through the diode junction connector-2
- to the rear wiper relay terminals **①** and **④**.

With the glass hatch switch open (glass hatch closed), power is supplied:

- through the rear wiper relay terminal **③**
- to the rear wiper motor terminal **②**, and
- to the rear washer motor terminal **①**.

Ground is supplied:

- to the rear wiper motor terminal **①**
- to the rear wiper switch terminal **③**, and
- to the glass hatch switch terminal **②**
- through body grounds **(B54)**, **(M5)** and **(M75)**.

With the glass hatch switch closed (glass hatch open), ground is supplied:

- to the rear wiper relay terminals **②** and **⑥**
- through the glass hatch switch terminal **①**.

With power and ground supplied, the rear wiper relay is energized, and power is removed:

- from the rear washer motor terminal **①**, and
- from the rear wiper motor terminal **②**.

With power removed, the rear wiper motor and rear washer motor become inoperative for as long as the glass hatch is open.

### WIPER OPERATION

When the rear wiper switch is in the WIPER position, ground is supplied:

- to the rear wiper motor terminal **④**
- through the diode junction connector-2
- from the rear wiper switch terminal **①**.

With power and ground supplied, the rear wiper motor operates intermittently, with approximately a 15 second interval between cycles.

### WASHER OPERATION

When the rear wiper switch is in the WASH position, ground is supplied:

- to the rear washer motor terminal **②**, and
- to the rear wiper motor terminal **③**
- through the diode junction connector-2
- from the rear wiper switch terminal **②**.

With power and ground supplied, to the rear washer motor and rear wiper motor, both motors operate until the rear wiper switch is taken out of the WASH position. If the switch is momentarily pressed the rear wiper motor will only cycle one time.


### AUTO STOP OPERATION

When the rear wiper switch is placed in the OFF position, the rear wiper motor will continue to operate until the rear wiper arm reaches the stop position.


# WIPER AND WASHER

## Rear Wiper and Washer (For Glass Hatch Model)/Wiring Diagram -WIP/HR-

EL-WIP/HR-01



Refer to POWER SUPPLY ROUTING in EL Section.




Refer to Foldout Page in EL Section for details.

# WIPER AND WASHER

## Rear Wiper and Washer (For Glass Hatch Model)/Wiring Diagram -WIP/HR- (Cont'd)







EL-WIP/HR-02



Refer to Foldout Page in EL Section for details.

M9

E44



EL-126

AEL335-B



## Removal and Installation — Windshield Wiper

1. Tilt wiper arm to upright position.
2. Pull out and hold locking lever at base of wiper arm.
3. Pull wiper arm off pivot shaft.
- Installation is the reverse order of removal.

### Adjustment — Wiper arm

1. With wiper arm removed, turn wipers on and allow them to cycle two or three times and then turn wiper switch to OFF so that wipers will return to “park” position.
2. Install wiper arm and align splines so that wiper blade rests within clearance “C”.
3. Operate wipers and ensure that wipers “park” within clearance “C”. Readjust if necessary.




**Clearance “C”:** 47 - 87 mm (1.85 - 3.43 in)

### Adjustment — Washer nozzle

1. Operate washers and ensure that spray patterns fall within target areas illustrated.
2. Adjust washer nozzle spray pattern by inserting a suitable tool (needle) into nozzle and pivoting the nozzle until spray is within target area.

### Installation


- Push windshield wiper arm onto wiper motor shaft.



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.


## Washer Nozzle Adjustment

- Adjust washer nozzle by inserting a suitable tool (needle) into nozzle and pivot until spray pattern is at proper target area.




## Check Valve

- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.




# HORN, CIGARETTE LIGHTER, CLOCK




## Wiring Diagram -HORN-



Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (M9, E44)



GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX

# REAR WINDOW DEFOGGER

---

## System Description

The rear window defogger is controlled by the time control module. The rear window defogger operates only for approximately 12 to 17 minutes.

Power is supplied at all times:

- to rear window defogger relay terminal ⑥
- through 20A fuse (Letter ①, located in the fuse block) and
- to rear window defogger relay terminal ③
- through 20A fuse (Letter ②, located in the fuse block).

With the ignition switch in the ON or START position, power is supplied:

- to the rear window defogger relay terminal ②
- through 10A fuse (Letter ①, located in the fuse block).

Ground is supplied to terminal ② of the rear window defogger switch through body grounds ⑤ and ⑦.

When the rear window defogger switch is activated, ground is supplied:

- through terminal ① of the rear window defogger switch
- to time control module terminal ⑦.

Terminal ② of the time control module then supplies ground to the rear window defogger relay terminal ①.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied:

- through terminals ⑤ and ⑦ of the rear window defogger relay
- to the rear window defogger.

The rear window defogger has an independent ground.


With power and ground supplied, the rear window defogger filaments heat and defog the rear window. When the system is activated, the rear window defogger indicator illuminates on the rear window defogger switch.

For diagnosis, refer to "Trouble Diagnosis", "TIME CONTROL SYSTEM"(EL-112).


# REAR WINDOW DEFOGGER

## Wiring Diagram -DEF-

EL-DEF-01




Refer to POWER SUPPLY ROUTING in EL Section.




CI  
 MA  
 EM  
 LC  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 IDX

# REAR WINDOW DEFOGGER




## Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.



2. If a filament is burned out, circuit tester registers 0 or 12 volts.



3. To locate burned out point, move probe to left and right along filament to determine point where tester needle swings abruptly.

# REAR WINDOW DEFOGGER

## Filament Repair

### REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

GI

MA

EM

LC

EF &amp;

EC

FE

AT

FA

RA

BR




ST

BF

HA

EL

IDX



### REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

**Shake silver composition container before use.**

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.

4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

**Do not touch repaired area while test is being conducted.**

5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

## Audio/System Description

Refer to the Owner's Manual for audio system operating instructions.

There are four different audio systems available:

- a mid line AM/FM stereo cassette radio with 4-channel amplifier
- a mid line AM/FM stereo cassette radio with 4-channel amplifier and C/D player
- a high line AM/FM stereo cassette radio with 4-channel amplifier and subwoofer, and
- a high line AM/FM stereo cassette radio with 4-channel amplifier, subwoofer and C/D player.

A rear remote control module and power antenna are available with all four audio systems.

Power is supplied at all times:

- through 10A fuse (Letter **W**), located in the fuse block)
- to radio terminal **1**, and
- to C/D player terminal **6**.

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (Letter **I**), located in the fuse block)
- to radio terminal **3**
- to C/D player terminal **4**, and
- to rear remote control module terminal **4**, and
- through 20A fuse (Letter **I**), located in the fuse block)
- to 4-channel amplifier terminal **6**, and
- to subwoofer amplifier terminal **5**.

Ground is supplied through the case of the radio and C/D player.

Ground is supplied:

- to 4-channel amplifier terminal **5**
- to subwoofer amplifier terminal **1**, and
- to rear remote control module terminals **11** and **13**
- through body grounds **M5**, **M75**, **B2** and **B12**.

When the radio, rear remote control module or C/D player is operating, audio signals are supplied:

- through radio terminals **15**, **16**, **17**, **18**, **19**, **20**, **21** and **22**
- to 4-channel amplifier terminals **15**, **18**, **19**, **20**, **21**, **22**, **23** and **24**
- through 4-channel amplifier terminals **7**, **8**, **9**, **10**, **11**, **12**, **13**, **14**, **31**, **32** and **33**
- to the door speakers, rear speakers and subwoofer amplifier.




# AUDIO AND POWER ANTENNA





## Audio/Wiring Diagram -AUDIO-

EL-AUDIO-01

CI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX




Refer to POWER SUPPLY ROUTING in EL Section. (M15)




# AUDIO AND POWER ANTENNA

## Audio/Wiring Diagram -AUDIO- (Cont'd)

### EL-AUDIO-02




Refer to POWER SUPPLY ROUTING in EL Section.






# AUDIO AND POWER ANTENNA

## Audio/Wiring Diagram -AUDIO- (Cont'd)



GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



## Power Antenna/System Description

Power is supplied at all times:

- through 10A fuse (Letter **W**, located in the fuse block)
- to power antenna timer terminal **③**, and
- to radio terminal **①**.

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (Letter **I**, located in the fuse block)
- to power antenna timer terminal **⑥**, and
- to radio terminal **③**.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (Letter **I**, located in the fuse block)
- to power antenna timer terminal **⑤**.

Ground is supplied to the power antenna timer terminal **⑦** through body grounds **Ⓜ5** and **Ⓜ75**.

When the radio is turned ON, battery positive voltage is supplied:

- through radio terminal **⑤**
- to power antenna timer terminal **④**.

The power antenna timer controls the operation of the power antenna motor through terminal **⑧** and **⑨**. The antenna raises and is held in the extended position.

When the radio is turned OFF, or a cassette tape or compact disc is played, battery positive voltage is interrupted:


- from radio terminal **⑤**
- to power antenna timer terminal **④**.

The antenna retracts.

# AUDIO AND POWER ANTENNA




## Power Antenna/Wiring Diagram -P/ANT-

**EL-P/ANT-01**



Refer to POWER SUPPLY ROUTING in EL Section.

(M15)



# AUDIO AND POWER ANTENNA

## Trouble Diagnoses

Symptom	Possible causes	Repair order
Radio, C/D player and/or rear remote control module inoperative (no digital display and no sound from speakers.)	<ol style="list-style-type: none"> <li>1. 10A fuses</li> <li>2. Poor radio or C/D player case ground, or rear remote control module body ground.</li> <li>3. Radio, C/D player or rear remote control module</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuses (Letters <b>i</b> and <b>w</b>, located in the fuse block). Verify battery positive voltage is present at terminal ① of radio and terminal ⑥ of C/D player. Turn ignition switch ON and verify battery positive voltage is present at terminal ③ of radio, terminal ④ of C/D player and terminal ④ of rear remote control module.</li> <li>2. Check radio or C/D player case ground, or rear remote control module body ground.</li> <li>3. Remove radio, C/D player, or rear remote control module for repair.</li> </ol>
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>1. 20A fuse</li> <li>2. Poor 4-channel amplifier and subwoofer amplifier body grounds.</li> <li>3. 4-channel amplifier and subwoofer amplifier.</li> <li>4. 4-channel amplifier circuits</li> <li>5. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 20A fuse (Letter <b>i</b>, located in the fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ⑥ of 4-channel amplifier and terminal ⑤ of subwoofer amplifier.</li> <li>2. Check 4-channel amplifier and subwoofer body grounds.</li> <li>3. Check 4-channel amplifier and subwoofer amplifier voltages.</li> <li>4. Check wires for open or short between radio, 4-channel amplifier, subwoofer amplifier and speakers.</li> <li>5. Remove radio for repair.</li> </ol>
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>1. Speaker</li> <li>2. 4-channel amplifier output</li> <li>3. Speaker circuit</li> <li>4. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check speaker.</li> <li>2. Check 4-channel amplifier output voltages.</li> <li>3. Check wires for open or short between 4-channel amplifier and speaker.</li> <li>4. Remove radio for repair.</li> </ol>
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> <li>1. Antenna</li> <li>2. Poor radio case ground</li> <li>3. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check antenna.</li> <li>2. Check radio case ground.</li> <li>3. Remove radio for repair.</li> </ol>
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> <li>1. Diversity antenna</li> <li>2. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check diversity antenna.</li> <li>2. Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> <li>1. Poor radio case ground</li> <li>2. Loose or missing ground bonding straps</li> <li>3. Ignition condenser</li> <li>4. Generator</li> <li>5. Ignition coil or secondary wiring</li> <li>6. Radio</li> </ol>	<ol style="list-style-type: none"> <li>1. Check radio case ground.</li> <li>2. Check ground bonding straps.</li> <li>3. Replace ignition condenser.</li> <li>4. Check generator.</li> <li>5. Check ignition coil and secondary wiring.</li> <li>6. Remove radio for repair.</li> </ol>
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> <li>1. Poor radio case ground</li> <li>2. Antenna</li> <li>3. Accessories ground</li> <li>4. Faulty accessory</li> </ol>	<ol style="list-style-type: none"> <li>1. Check radio case ground.</li> <li>2. Check antenna.</li> <li>3. Check accessory ground.</li> <li>4. Replace accessory.</li> </ol>
Power antenna does not operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. 10A fuse</li> <li>3. 10A fuse</li> <li>4. Radio signal</li> <li>5. Poor power antenna timer body ground</li> <li>6. Power antenna circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (Letter <b>w</b>, located in the fuse block). Verify battery positive voltage is present at terminal ③ of power antenna timer.</li> <li>2. Check 10A fuse (Letter <b>t</b>, located in the fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ⑤ of power antenna timer.</li> <li>3. Check 10A (Letter <b>i</b>, located in the fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal ⑥ of power antenna timer.</li> <li>4. Turn radio ON and verify battery positive voltage is present at terminal ④ of power antenna timer.</li> <li>5. Check power antenna timer body ground.</li> <li>6. Check wires for open or short between power antenna timer and power antenna motor.</li> </ol>

# AUDIO AND POWER ANTENNA

## Trouble Diagnoses (Cont'd)

### SPEAKER INSPECTION

1. Disconnect speaker harness connector.
2. Measure the resistance between speaker terminals ① and ②.
  - The resistance should be 2-4  $\Omega$
3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ②.
  - A momentary hum or pop should be heard

### ANTENNA INSPECTION

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
  - If reception improves, check antenna ground (at body surface)
  - If reception does not improve, check main feeder cable for short circuit or open circuit.

### RADIO, C/D PLAYER, REAR REMOTE CONTROL MODULE, 4-CHANNEL AMPLIFIER AND SUBWOOFER AMPLIFIER INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio or C/D player ON
- Radio, C/D player, rear remote control module, 4-channel amplifier and subwoofer amplifier connected (If the radio or C/D player is removed from the audio mounting bracket to make the inspection, supply a ground to the case using a jumper wire.)

### RADIO VOLTAGES

Terminal	Voltage (V)	
	Mid Line Model	High Line Model
1	10.8 - 15.6V (Battery)	10.8 - 15.6V (Battery)
2	Greater than 3.0V (Illumination on)	Greater than 3.0V (Illumination on)
3	10.8 - 15.6V (Ignition ACC or ON)	10.8 - 15.6V (Ignition ACC or ON)
4	10.8 - 15.6V (Illumination on)	10.8 - 15.6V (Illumination on)
5	10.8 - 15.6V (Radio on)	10.8 - 15.6V (Radio on)
6	—	—
7	10.8 - 15.6V (Radio on)	10.8 - 15.6V (Radio on)
8	10.8 - 15.6V (Radio on)	10.8 - 15.6V (Radio on)
9	Check continuity between radio harness connector (M50A) and C/D player harness connector (M56A).	
10		
11		
12		
13		
14		
15	0 - 2.3V	0 - 5V
16	0 - 2.3V	0 - 5V
17	0 - 2.3V	0 - 5V
18	0 - 2.3V	0 - 5V
19	0 - 2.3V	0 - 5V
20	0 - 2.3V	0 - 5V
21	0 - 2.3V	0 - 5V

Terminal	Voltage (V)	
	Mid Line Model	High Line Model
22	0 - 2.3V	0 - 5V
31	Data line	Data line
32	Data line	Data line

The radio is case grounded through the audio mounting bracket.

### REAR REMOTE CONTROL MODULE VOLTAGES

Terminal	Voltage (V)
1	0 - 5V input
2	—
3	—
4	10.8 - 15.6V (Ignition ACC or ON)
5	Data line
6	Data line
7	0 - 5V input
8	0 - 5V input
9	0 - 5V input
10	—
11	Body ground
12	—
13	Body ground
14	10.8 - 15.6V (Illumination on)

# AUDIO AND POWER ANTENNA

## Trouble Diagnoses (Cont'd)

### C/D PLAYER VOLTAGES

Terminal	Voltage (V)
1	Greater than 3.0V (Illumination on)
2	—
3	10.8 - 15.6V (Illumination on)
4	10.8 - 15.6V (Ignition ACC or ON)
5	10.8 - 15.6V (Radio on)
6	10.8 - 15.6V
9	Check continuity between C/D player harness connector (M56A) and radio harness connector (M50A).
10	
11	
12	
13	
14	

The C/D player is case grounded through the audio mounting bracket.

### SUB-WOOFER AMP. VOLTAGES

Terminal	Voltage (V)
1	Body ground
2	—
3	0 - 1.5V input
4	0 - 5V
5	10.8 - 15.6V (Ignition ACC or ON)
6	0 - 1.5V input


### 4-CHANNEL AMP. VOLTAGES

Terminal	Voltage (V)	
	Mid Line Model	High Line Model
1	—	—
2	—	—
3	—	—
4	10.8 - 15.6V (Radio on)	10.8 - 15.6V (Radio on)
5	Body ground	Body ground
6	10.8 - 15.6V (Ignition ACC or ON)	10.8 - 15.6V (Ignition ACC or ON)
7	0 - 7.5V	0 - 7.5V
8	0 - 7.5V	0 - 7.5V
9	0 - 7.5V	0 - 7.5V
10	0 - 7.5V	0 - 7.5V
11	0 - 7.5V	0 - 7.5V
12	0 - 7.5V	0 - 7.5V
13	0 - 7.5V	0 - 7.5V
14	0 - 7.5V	0 - 7.5V
15	Check continuity between 4-channel amplifier harness connector (M123) and radio harness connector (M54).	
16	—	—
17	—	—
18	Check continuity between 4-channel amplifier harness connector (M123) and radio harness connector (M54).	
19		
20		
21		
21		
22		
23		
24		
31	—	0 - 1.5V
32	—	0 - 1.5V
33	—	0 - 1.5V
34	—	—



# AUDIO AND POWER ANTENNA

## Location of Antenna



GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA

RA

BR


ST

BF

HA


EL

IDX



## Antenna Rod Replacement REMOVAL

1. Remove antenna nut and antenna base.




2. Withdraw antenna rod while raising it by operating antenna motor.

## AUDIO AND POWER ANTENNA

### Antenna Rod Replacement (Cont'd)

#### INSTALLATION

1. Insert gear section of antenna rope into place with it facing toward antenna motor.
2. Lower antenna rod by operating antenna motor.
3. As soon as antenna rope is wound onto antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied:

- through 10A fuse (Letter **L**, located in the fuse block)
- to the ASCD main switch terminal **①**, and
- to the ASCD hold relay terminal **⑤**.

When the ASCD main switch is in the ON position, power is supplied:

- from terminal **②** of the ASCD main switch
- to ASCD control module terminal **④**, and
- from terminal **③** of the ASCD main switch
- to ASCD hold relay terminal **①**.

Ground is supplied:

- to ASCD hold relay terminal **②**
- through body grounds **E7**, **E41** and **E61**.

With power and ground supplied, the ASCD hold relay is energized, and power is supplied:

- from terminal **③** of the ASCD hold relay
- to ASCD control module terminal **④** and
- to inhibitor relay terminal **④**.

Power remains supplied to the ASCD control module terminal **④** when the ASCD switch is released to the N (neutral) position.

Ground is supplied:

- to ASCD control module terminal **③**
- through body grounds **M5** and **M75**.

## INPUTS

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- inhibitor relay
- ASCD cancel switch.

A vehicle speed input is supplied:

- to ASCD control module terminal **⑦**
- from terminal **③1** of the combination meter.

Power is supplied at all times:

- to stop lamp switch terminal **①**
- through 15A fuse (Letter **X**, located in the fuse block).

With the brake pedal depressed, power is supplied:

- from terminal **②** of the stop lamp switch
- to ASCD control module terminal **⑩**.

Power is supplied at all times:

- through 15A fuse (Letter **R**, located in the fuse block)
- to horn relay terminal **②**
- through terminal **①** of the horn relay
- to ASCD steering switch terminal **①**.

When the SET/COAST button is depressed, power is supplied:

- from terminal **②** of the ASCD steering switch
- to ASCD control module terminal **②**.

When the RESUME/ACCEL button is depressed, power is supplied:

- from terminal **③** of the ASCD steering switch
- to ASCD control module terminal **①**.

When the CANCEL button is depressed, a 5V signal is supplied:

- to ASCD control module terminals **①** and **②**.

When the system is activated, power is supplied:

- to ASCD control module terminal **⑤**.

Power is interrupted when:

- the shift lever is placed in P or N, or
- the brake pedal is depressed.

GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## System Description (Cont'd)

### OUTPUTS

The ASCD actuator controls the throttle drum via the ASCD wire based on inputs from the ASCD control module. The ASCD actuator consists of a vacuum motor, an air valve, and a release valve.

Power is supplied:

- from terminal ⑧ of the ASCD control module
- to ASCD actuator terminal ①.

Ground is supplied to the vacuum motor:

- from terminal ⑨ of the ASCD control module
- to ASCD actuator terminal ④.

Ground is supplied to the air valve:

- from terminal ⑩ of the ASCD control module
- to ASCD actuator terminal ②.

Ground is supplied to the release valve:

- from terminal ⑭ of the ASCD control module
- to ASCD actuator terminal ③.

When the system is activated, power is supplied:

- from terminal ⑬ of the ASCD control module
- to the combination meter terminal ①, and
- to A/T control unit terminal ⑳.

Ground is supplied:

- to combination meter terminal ⑫
- through body grounds ①M5 and ①M75.

With power and ground supplied, the CRUISE indicator illuminates.






When the RESUME/ACCEL button is depressed, a signal is sent:

- from terminal ⑫ of the ASCD control module
- to A/T control unit terminal ④①.

When this occurs, the A/T control unit cancels overdrive.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Component Parts and Harness Connector Location



GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF


HA

**EL**

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


## Schematic





# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram -ASCD-

EL-ASCD-01






Refer to POWER SUPPLY ROUTING in EL Section. (M15)



Refer to Foldout Page in EL Section for details. (M24)

Refer to Foldout Page in EL Section for details. (M9, E44)




AEL332-A

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram -ASCD- (Cont'd)





EL-ASCD-02



Refer to POWER SUPPLY ROUTING in EL Section. M15

Refer to Foldout Page in EL Section for details. M9  
E44



Refer to Foldout Page in EL Section for details. M24





# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Wiring Diagram -ASCD- (Cont'd)



GI  
 MA  
 EM  
 LG  
 EF & EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL

IDX



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses

Symptom	DIAGNOSTIC PROCEDURE
ASCD control module cannot be set properly.	1
Resume switch will not operate.	2
Cancel switch will not operate.	3
Engine hunts.	4
Large difference between set vehicle speed and actual speed.	5
Set speed cannot be cancelled.	6

### PREPARATION FOR TROUBLE-DIAGNOSIS

1. Remove lower trim.
2. Remove ASCD control module with harness connected.
3. Perform check from harness side using circuit tester, with harness connector connected.



### GROUND CIRCUIT CHECK

Check for continuity between ASCD control module harness connector terminal ③ and body ground.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE-1

**ASCD control module cannot be set properly.**

**A POWER SUPPLY CIRCUIT CHECK**

- Turn ASCD main switch to "ON".
- Check voltage between (4) and (3).

Approx. 12V

**B CUT-OFF CIRCUIT CHECK**

- Turn ASCD main switch to "ON".
- Step on brake pedal.
- Shift to "N" range.
- Check voltage between (5) and (3).

0V

Brake pedal → Step on.  
A/T control → "N" range lever

AEL415

**C SET SWITCH CIRCUIT CHECK**

- Push set switch.
- Check voltage between (2) and (3).

Approx. 12V


**D VEHICLE SPEED SENSOR CIRCUIT CHECK**

- Remove vehicle speed sensor from transaxle.
- Connect a voltmeter between (7) and (3).
- Slowly turn vehicle speed sensor by hand to make sure voltmeter pointer deflects.

- Voltmeter pointer deflects twice per rotation of pinion.

Approx. 0.5V

AEL416






GI  
 MA  
 EM  
 LG  
 EF & EG  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)


### DIAGNOSTIC PROCEDURE-2

Resume switch will not operate.




### DIAGNOSTIC PROCEDURE-3

Cancel switch will not operate.



### DIAGNOSTIC PROCEDURE-4

Engine hunts.




# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE-5

Large difference between set vehicle speed and actual speed.



**A CUT-OFF CIRCUIT CHECK**

- Turn ASCD main switch to "ON".
- Step on brake pedal.
- Shift to "N" range.
- Check voltage between ⑤ and ③.


**B STOP LAMP CIRCUIT CHECK**

- Step on brake pedal.
- Check voltage between ⑪ and ③.

AEL419


### DIAGNOSTIC PROCEDURE-6

Set speed cannot be canceled.



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd) ASCD WIRE ADJUSTMENT



### CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not overly tighten ASCD wire during adjustment.

Confirm that accelerator wire is properly adjusted.

- For accelerator cable adjustment, refer to FE section ("Adjusting Accelerator Cable", "ACCELERATOR CONTROL SYSTEM").

Adjust the ASCD wire as follows.

- (1) Loosen lock nut and tighten adjusting nut until throttle drum starts to move.
- (2) From that position turn back adjusting nut 0.5 to 1 turn, and secure lock nut.

(This prevents a delay in the operation of the ASCD.)

- For ASCD cancel switch adjustment, refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)


### ELECTRICAL COMPONENTS INSPECTION

#### ASCD main switch

Check continuity between terminals by pushing switch to each position.




Switch position	Terminal					
	1	2	3	4	5	6
ON	○	○	○	○		
N		○	○	○	ILL.	
OFF						



#### ASCD steering switch

Check continuity between terminals by pushing each button.


Button	Terminal		
	1	2	3
SET/COAST	○	○	
RESUME/ACCEL	○		○
CANCEL	○	⚡	○
	○	⚡	○



#### ASCD cancel switch and stop lamp switch

Condition	Continuity	
	ASCD cancel switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section (“Adjustment”, “BRAKE PEDAL AND BRACKET”).



#### Inhibitor switch


Shift lever position	Terminal	
	1	2
“P” or “N”	○	○
Except “N” or “P”		

## AUTOMATIC SPEED CONTROL DEVICE (ASCD)

### Trouble Diagnoses (Cont'd)

#### Vehicle speed sensor

- 1 Remove vehicle speed sensor from transaxle.
- 2 Turn vehicle speed sensor pinion quickly and measure voltage across ② and ①.










# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Trouble Diagnoses (Cont'd)

### ASCD actuator/ASCD pump

1. Disconnect ASCD actuator/ASCD pump connector.
2. Check ASCD actuator/ASCD pump operations as shown.



GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA

EL

IDX

## System Description

Refer to Owner's Manual for digital touch entry system operating instructions.

Power is supplied at all times:

- through circuit breaker-1 terminal ②
- to digital touch entry control module terminal ⑳, and
- through 10A fuse (Letter **m**), located in the fuse block)
- to digital touch entry control module terminal ②, and
- through 15A fuse (Letter **y**), located in the fuse block)
- to digital touch entry system beeper terminal ①.

Ground is supplied:

- to digital touch entry control module terminals ⑫ and ⑬
- through body grounds **(M5)**, and **(M75)**.

### KEYBOARD OPERATION

Ground is supplied:

- to keyboard terminal ⑦
- through body grounds **(M5)** and **(M75)**.

When a keyboard pad is pressed, ground is supplied:

- to digital touch entry control module terminal ⑤, ⑥, ⑦, ⑧ or ⑨.

Power is then supplied:

- from digital touch entry control module terminal ⑳
- to keyboard terminal ⑥ for illumination.

Ground is supplied:

- to beeper terminal ②
- from digital touch entry control module terminal ⑱, causing the beeper to sound each time a keyboard pad is pressed.

### UNLOCK

After the vehicle's personal entry code has been entered, power is supplied:

- from digital touch entry control module terminal ⑳
- to the front door actuator terminal ②.

Ground is supplied:

- to the front door actuator terminal ①
- through digital touch entry control module terminal ⑳.

With power and ground supplied, the door actuator operates and unlocks the LH front door.

If terminal ⑥ of the digital touch entry control module is grounded (by pressing the 3/4 keyboard pad) within 5 seconds of the vehicle's personal entry code being entered, power is supplied:

- from digital touch entry control module terminal ⑳
- to the RH front door actuator terminal ②, and
- to the sliding door actuator terminal ②.

Ground is supplied:

- to the RH front door actuator terminal ①, and
- to the sliding door actuator terminal ①
- from digital touch entry control module terminal ⑳.

With power and ground supplied, the door actuators operate and unlock the RH front door and the sliding door.

If terminal ⑦ of the digital touch entry control module is grounded (by pressing the 5/6 keyboard pad) within 5 seconds of the vehicle's personal entry code being entered, power is supplied:

- from digital touch entry control module terminal ⑳
- to the back door actuator terminal ②.

Ground is supplied:

- to the back door actuator terminal ①
- from digital touch entry control module terminal ⑳.

With power and ground supplied, the door actuator operates and unlocks the back door.

When either door lock and unlock switch is pressed to the UNLOCK position, ground is supplied:

- to digital touch entry control module terminal ⑱
- from the lock and unlock switch terminal ②.

# DIGITAL TOUCH ENTRY SYSTEM

## System Description (Cont'd)

When the digital touch entry control module receives this ground input, power is supplied:

- from digital touch entry control module terminal ⑫
- to the LH front door actuator terminal ②, and
- from digital touch entry control module terminal ⑫
- to the RH front door actuator terminal ② and
- to sliding door actuator terminal ②, and
- from digital touch entry control module terminal ⑫
- to the back door actuator terminal ②.

GI

MA

EM

Ground is supplied:

- from digital touch entry control module terminal ⑫
- to each door actuator terminal ①.

LC

With power and ground supplied, the door actuators operate and unlock all doors.

### LOCK

When ground is supplied to the digital touch entry control module terminals ⑧ and ⑨ simultaneously (by pressing the 7/8 and 9/0 keyboard pads); if the key is out of the ignition switch, and all the doors are closed, power is supplied:

EF &  
EC

- from digital touch entry control module terminal ⑫
- to each door actuator terminal ①.

FE

Ground is supplied:

- to the LH front door actuator terminal ②
- from digital touch entry control module terminal ⑫, and
- to the RH front door actuator terminal ②, and
- to the sliding door actuator terminal ②
- from digital touch entry control module terminal ⑫, and
- to the back door actuator terminal ②
- from digital touch entry control module terminal ⑫.

AT

FA

RA

With power and ground supplied, the door actuators operate and lock all doors.

When ground is supplied to the digital touch entry control module terminals ⑧ and ⑨ simultaneously; if the key is in the ignition switch, or any door is open, ground is supplied:

BR

- to the beeper terminal ②
- from digital touch entry control module terminal ⑫, causing the beeper to sound for approximately 5 seconds.

ST

When either door lock and unlock switch is pressed to the LOCK position, ground is supplied:

- to digital touch entry control module terminal ⑫
- from the lock and unlock switch terminal ①.

BF

When the door key or lock knob switch is moved to the LOCK position, ground is removed:

- from the digital touch entry control module terminal ⑫
- through the front door actuator LH terminal ③.

HA

When the digital touch entry control module receives either of these inputs, power is supplied:

- from digital touch entry control module terminal ⑫
- to each door actuator terminal ①.

EL

Ground is supplied:

- to the LH front door actuator terminal ②
- from digital touch entry control module terminal ⑫, and
- to the RH front door actuator terminal ②, and
- to the sliding door actuator terminal ②
- from digital touch entry control module terminal ⑫, and
- to the back door actuator terminal ②
- from digital touch entry control module terminal ⑫.

IDX

With power and ground supplied, the door actuators operate and lock all doors.



### LOCK – sliding door delay

When any door lock switch is pressed to the LOCK position, with the sliding door open, all door lock actuators, except the sliding door lock actuator, move to the LOCK position.

When the sliding door is closed, the time control module sends a signal to the digital touch entry control module terminal ⑫. The digital touch entry control module then operates the sliding door actuator and the sliding door locks.

# DIGITAL TOUCH ENTRY SYSTEM







## Location of Electrical Units



AEL397-A

# DIGITAL TOUCH ENTRY SYSTEM

## Location of Electrical Units (Cont'd)










- GI
- KA
- EM
- LC
- EF & EC
- FE
- AT
- FA
- RA
- BR
- ST
- BF
- HA
- EL**

IDX

# DIGITAL TOUCH ENTRY SYSTEM

## Wiring Diagram -ENTRY-

EL-ENTRY-01




AEL342-A

# DIGITAL TOUCH ENTRY SYSTEM

## Wiring Diagram -ENTRY- (Cont'd)


EL-ENTRY-02

CI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX



Refer to Foldout Page in EL Section for details.

Refer to POWER SUPPLY ROUTING in EL Section for details.





Refer to Foldout Page in EL Section for details.

AEL342-B

# DIGITAL TOUCH ENTRY SYSTEM

## Wiring Diagram -ENTRY- (Cont'd)

### EL-ENTRY-03






# DIGITAL TOUCH ENTRY SYSTEM

## Wiring Diagram -ENTRY- (Cont'd)


### EL-ENTRY-04



GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA

**EL**

IDX




# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses

### HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

#### Work flow



# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd) SYMPTOM CHART

**Diagnostic table**

PROCEDURE	Preliminary Check		Main Power Supply and Ground Circuit Check		Diagnostic Procedure						Electrical Components Inspection					
	EL-172	EL-172	EL-172	EL-172	EL-173	EL-174	EL-175	EL-176	EL-176	EL-177	EL-178	EL-178	EL-178	EL-179	EL-179	EL-180
SYMPTOM	Preliminary check 1	Preliminary check 2	Power supply circuit	Ground circuit	Diagnostic procedure 1	Diagnostic procedure 2	Diagnostic procedure 3	Diagnostic procedure 4	Diagnostic procedure 5	Diagnostic procedure 6	Keyboard	Beeper	Key switch	Door switches	Lock & Unlock switches	Digital touch entry control module
When keyboard is pressed, it does not beep and light does not glow.			○	○	○						○	○				
When keyboard is pressed, it beeps but light does not glow.			○			○					○					
When keyboard is pressed, it does not beep but light glows.				○			○				○	○				
When the program code is entered, a long beep is not heard.	○							○			○	○				
After a valid personal code has been entered, registration sound (repeated beeps) is not heard even if code number is entered.	○								○							
Doors do not lock or unlock properly with keyboard operation.	①	②								○			○	○	○	○

①, ②: The number means checking order.

GE  
MA  
EM  
LC  
E & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA


EL

IDX

# DIGITAL TOUCH ENTRY SYSTEM


## Trouble Diagnoses (Cont'd)

### CIRCUIT DIAGRAM FOR QUICK PINPOINT CHECK



# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)



GI

MA

EM

LC

EF &

EC

FE

AT

FA

RA

BR

ST

BF

HA

**EL**

IDX


# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### PRELIMINARY CHECK



#### Preliminary check 1

- Door lock system does not work normally with keyboard operation.



#### Preliminary check 2


Power door lock system does not work with keyboard operation.



### MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

#### Ground circuit check for digital touch entry control module

Check for continuity between digital touch entry control module harness connector terminals 12 and 23 and body ground.



#### Power supply circuit check for digital touch entry control module

Check if 12V exists across digital touch entry control module harness connector terminals 2, 24 and 12.

# DIGITAL TOUCH ENTRY SYSTEM



## Trouble Diagnoses (Cont'd)

### DIAGNOSTIC PROCEDURE

#### Diagnostic procedure 1

**SYMPTOM:** When keyboard is pressed, it does not beep and light does not glow.

Perform Main Power Supply And Ground Circuit Check before referring to the following flow chart.



**A** Keyboard check

Check continuity between terminals No. ⑫ and ⑤, ⑥, ⑦, ⑧ and ⑨.

OK → Perform Diagnostic procedure 2 and 3. Refer to EL-174 and EL-175.

Pushed keyboard pad	One terminal	Other terminals				
		⑤	⑥	⑦	⑧	⑨
1/2	⑫	○				
3/4			○			
5/6				○		
7/8					○	
9/0						○

NG

**B** Check circuit continuity between each terminal on keyboard and control module.

NG → Repair harness and connector.

Terminal No.		Continuity
Keyboard	control module	
①	⑤	Yes
②	⑥	
③	⑦	
④	⑧	
⑤	⑨	
⑥	⑫	
⑦	⑫	

OK

Check keyboard. Refer to EL-178.

NG

Replace keyboard.

GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX






# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 2

**SYMPTOM: When keyboard is pressed, it beeps but light does not glow.**

- Perform Main Power Supply Circuit Check before referring to the following flow chart.










# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 3

**SYMPTOM:** When keyboard is pressed, it does not beep but light glows.

- Perform Ground Circuit Check before referring to the following flow chart.



GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 4

**SYMPTOM:** When the program code is entered, a long beep is not heard.


- Perform Preliminary check 1 before referring to the following flow chart.



### Diagnostic procedure 5

**SYMPTOM:** After a valid personal code has been entered, registration sound (repeated beeps) is not heard even if code number is entered.

- Perform Preliminary check 1 before referring to the following flow chart.







# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### Diagnostic procedure 6

**SYMPTOM: Doors do not lock or unlock properly with keyboard operation.**

- Perform Preliminary check 1 and 2 before referring to the following flow chart.



GI  
MA  
EM  
LC  
EF & EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)

### ELECTRICAL COMPONENTS INSPECTION

#### Keyboard


Check continuity between terminals by pushing each keyboard pad.



Pushed keyboard pad	One terminal	Other terminals				
		①	②	③	④	⑤
1/2	⑦	○				
3/4			○			
5/6				○		
7/8					○	
9/0						○


#### Beeper

Check if it beeps when 12V is supplied.



#### Key switch

Check continuity between terminals when key is inserted in, and removed from key cylinder.




KEY	INSERTED	REMOVED
④	○	
⑤	○	

# DIGITAL TOUCH ENTRY SYSTEM


## Trouble Diagnoses (Cont'd)

### Door switches

Check continuity of switches.



Door switch	Terminals	Switch position	Continuity
Driver side	② and switch body	Door open	Yes
		Door closed	No
Passenger side	① and switch body	Door open	Yes
		Door closed	No
Sliding door	① and switch body	Door open	Yes
		Door closed	No
Back door	① and ②	Door open	Yes
		Door closed	No



### Lock & Unlock switches

Check continuity between control module harness terminal No. ⑩ or ⑱, and body ground with the switch held in lock or unlock position.

Switch position	Lock		Unlock	
	Terminal No. 10	Terminal No. 19	Terminal No. 10	Terminal No. 19
Driver side	○	X	X	○
Passenger side	○	X	X	○


Continuity: ○: Yes  
X: No

# DIGITAL TOUCH ENTRY SYSTEM

## Trouble Diagnoses (Cont'd)



### Digital touch entry control module

Check the voltage between terminal ②①, ②②, ②⑤, ②⑧ and ground when the driver's Lock & Unlock switch is operated. When the Lock is pressed, battery positive voltage should exist for approximately 0.5 sec between terminal ②① and ground. When the Unlock is pressed, battery positive voltage should exist for approximately 0.5 sec between terminal ②②, ②⑤, ②⑧ and ground.



# LOCATION OF ELECTRICAL UNITS


## Engine Compartment



GI  
 MA  
 EM  
 LC  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 ICX

# LOCATION OF ELECTRICAL UNITS


## Passenger Compartment





# LOCATION OF ELECTRICAL UNITS

## Luggage Compartment



GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF


HA

**EL**

IDX

# HARNESS LAYOUT

## Outline



AEL383

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Engine Room Harness (Engine Compartment)
- Main Harness
- Body Harness

The grid reference is placed on the page where connectors are listed in number order.

To the left of the connector number code there is a grid reference.

Example:

C2 **(E5)**: ASCD actuator

└ grid reference

### To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

The approximate on-vehicle location of the connector has been found.

# HARNES LAYOUT

---

NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA


**EL**

IDX

# HARNESS LAYOUT

## Engine Room Harness

ENGINE COMPARTMENT



EL-186

AEL384-A

# HARNES LAYOUT

## Engine Room Harness (Cont'd)


D2 (E1) : To (F1)  
D2 (E2) : To (F2)  
C1 (E3) : Daytime lamp control module  
C2 (E4) : Low pressure switch  
C2 (E5) : ASCD actuator  
B2 (E7) : Body ground  
B2 (E8) : Relay box RH  
B2 (E10) : Front side marker RH  
A2 (E11) : Front combination lamp RH  
B2 (E12) : Actuator (For ABS)  
B4 (E13) : Front turn signal lamp RH  
C3 (E14) : Rear washer motor  
C3 (E15) : Front washer motor  
C3 (E16) : Washer level switch  
B3 (E17) : Headlamp RH  
C3 (E18) : Oil pressure switch  
C3 (E19) : Oil level sensor  
C3 (E20) : Generator  
D4 (E23) : Headlamp LH  
D3 (E24) : Relay box LH  
C3 (E25) : Cooling - fan motor  
C4 (E26) : Cooling - fan motor  
C3 (E27) : Fusible link box - 2  
D3 (E28) : Dropping resistor  
D2 (E29) : Starter motor  
D3 (E30) : To (F20)  
D3 (E31) : Battery  
E2 (E32) : Brake fluid level switch  
D2 (E33) : Front wiper motor  
E4 (E34) : Front combination lamp LH  
D3 (E35) : Fusible link box - 1  
E3 (E36) : Front side marker LH  
E4 (E37) : Horn high  
E4 (E38) : Horn low  
C4 (E39) : Front turn signal lamp LH  
E3 (E40) : Body ground (For ABS)  
E3 (E41) : Body ground  
E2 (E42) : Front sensor LH (For ABS)  
E3 (E43) : Front wiper amp  
C3 (E49) : Heated oxygen sensor  
D3 (E50) : Vehicle speed sensor  
E3 (E51) : Body ground  
D2 (E1) : To (F1)  
D2 (E2) : To (F2)  
C1 (E3) : Daytime lamp control module  
C2 (E4) : Low pressure switch  
C2 (E5) : ASCD actuator  
B2 (E7) : Body ground  
B2 (E8) : Relay box RH  
B2 (E10) : Front side marker RH  
A2 (E11) : Front combination lamp RH  
B2 (E12) : Actuator (For ABS)  
B4 (E13) : Front turn signal lamp RH  
C3 (E14) : Rear washer motor  
C3 (E15) : Front washer motor  
C3 (E16) : Washer level switch  
B3 (E17) : Headlamp RH  
C3 (E18) : Oil pressure switch  
C3 (E19) : Oil level sensor  
C3 (E20) : Generator  
D4 (E23) : Headlamp LH  
D3 (E24) : Relay box LH  
C3 (E25) : Cooling - fan motor  
C4 (E26) : Cooling - fan motor  
C3 (E27) : Fusible link box - 2  
D3 (E28) : Dropping resistor  
D2 (E29) : Starter motor  
D3 (E30) : To (F20)  
D3 (E31) : Battery  
E2 (E32) : Brake fluid level switch  
D2 (E33) : Front wiper motor  
E4 (E34) : Front combination lamp LH  
D3 (E35) : Fusible link box - 1  
E3 (E36) : Front side marker LH  
E4 (E37) : Horn high  
E4 (E38) : Horn low  
C4 (E39) : Front turn signal lamp LH  
E3 (E40) : Body ground (For ABS)  
E3 (E41) : Body ground  
E2 (E42) : Front sensor LH (For ABS)  
E3 (E43) : Front wiper amp  
C3 (E49) : Heated oxygen sensor  
D3 (E50) : Vehicle speed sensor  
E3 (E51) : Body ground

GI  
MA  
EM  
LC  
EF &  
EC  
FE  
AT  
FA  
RA  
BR  
ST  
BF  
HA  
EL  
IDX


# HARNESS LAYOUT

## Engine Room Harness (Cont'd)

### PASSENGER COMPARTMENT



- (E44) : To (M9) (SIMJ)
- (E45) : Fuse block
- (E46) : Fuse block
- (E47) : Fuse block
- (E48) : To (M17)
- (E49) : To (M18)
- (E50) : Shift lock solenoid
- (E51) : Horn and ASCD switch
- (E52) : Ignition switch
- (E53) : Transaxle gear selection switch - OD
- (E54) : Combination switch - 1
- (E55) : Combination switch - 2
- (E57) : Diode



# HARNES LAYOUT

---

NOTE

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF


HA

**EL**

IDX

# HARNESS LAYOUT

## Main Harness




AEL386-A



# HARNES LAYOUT

## Main Harness (Cont'd)


- A5 (M1) : Time control module
- A5 (M2) : Inertia fuel shutoff switch
- A4 (M3) : Circuit breaker - 1
- A5 (M4) : Circuit breaker - 2
- A4 (M5) : Body ground
- A4 (M6) : To (D1)
- A4 (M8) : To (D3)
- A4 (M9) : To (E44) (SMJ)
- A3 (M10) : Power window relay
- A4 (M11) : Blower motor relay
- A3 (M12) : To (R1)
- A3 (M13) : To (R2)
- B4 (M14) : Rear window defogger relay
- B4 (M15) : Fuse block
- B5 (M16) : Data link connector for CONSULT
- B5 (M17) : To (E48)
- B4 (M18) : To (E49)
- B4 (M19) : Parking brake switch
- C4 (M20) : Door mirror switch
- B4 (M21) : Headlamp switch
- B3 (M22) : Illumination control switch and autolamp switch
- B3 (M23) : ASCD main switch
- B3 (M24) : Diode junction connector - 1\*
- D5 (M25) : To door lock timer sub-harness (Without digital touch entry system models)
- B4 (M26) : Stop lamp switch
- C5 (M27) : ASCD cancel switch
- C4 (M28) : Combination meter
- C4 (M29) : Combination meter
- C3 (M30) : Combination meter
- C3 (M31) : Warning chime
- F2 (M32) : Shift lock relay
- C5 (M33) : Combination flasher unit
- C4 (M34) : A/T power mode switch
- C4 (M35) : Hazard switch
- D4 (M36) : Rear window defogger switch
- D3 (M37) : Rear window wiper switch
- E3 (M38) : Rear fan switch (Front)
- E3 (M39) : Air conditioning control module
- D4 (M41) : Front fan switch
- D3 (M42) : Air conditioning control module
- D4 (M43) : Mode door motor
- D4 (M44) : Cigarette lighter
- C4 (M45) : Foot lamp LH
- C4 (M46) : Digital touch entry control module (With digital touch entry system models) (Without digital touch entry system models)
- C5 (M47) : Digital touch entry control module
- C5 (M48) : Automatic seat belt control module
- E4 (M50) : Radio
- E4 (M54) : Radio
- E4 (M55) : Radio
- E4 (M56) : C/D player
- F4 (M57) : Front air mix door motor
- E5 (M58) : Foot lamp RH
- D5 (M59) : ASCD control module
- E4 (M60) : Body ground
- E4 (M61) : Body ground
- E4 (M62) : Body ground
- D4 (M63) : Anti-lock brake system control module
- E2 (M64) : To (F51)
- E2 (M65) : To (F52)
- E3 (M66) : Oil level timer
- F3 (M67) : Glove box lamp
- E3 (M68) : Auto lamp control module
- F3 (M69) : Intake door motor
- F3 (M70) : Front blower motor
- F3 (M71) : Front fan resistor
- G1 (M72) : Front limit switch RH
- F3 (M73) : To (D51)
- F3 (M74) : To (D52)
- F2 (M75) : Body ground
- F4 (M76) : Power antenna motor
- F4 (M77) : Power antenna amplifier
- B3 (M124) : To (A3)
- B3 (M125) : Joint connector - 2
- D3 (M126) : Joint connector - 1
- C5 (M33) : Combination flasher unit
- C4 (M34) : A/T power mode switch
- C4 (M35) : Hazard switch
- D4 (M36) : Rear window defogger switch
- D3 (M37) : Rear window wiper switch
- E3 (M38) : Rear fan switch (Front)
- E3 (M39) : Air conditioning control module
- D4 (M41) : Front fan switch
- D3 (M42) : Air conditioning control module
- D4 (M43) : Mode door motor
- D4 (M44) : Cigarette lighter
- C4 (M45) : Foot lamp LH
- C4 (M46) : Digital touch entry control module (With digital touch entry system models) (Without digital touch entry system models)
- C5 (M47) : Digital touch entry control module
- C5 (M48) : Automatic seat belt control module
- E4 (M50) : Radio
- E4 (M54) : Radio
- E4 (M55) : Radio
- E4 (M56) : C/D player
- F4 (M57) : Front air mix door motor
- E5 (M58) : Foot lamp RH
- D5 (M59) : ASCD control module
- E4 (M60) : Body ground
- E4 (M61) : Body ground
- E4 (M62) : Body ground
- D4 (M63) : Anti-lock brake system control module
- E2 (M64) : To (F51)
- E2 (M65) : To (F52)
- E3 (M66) : Oil level timer
- F3 (M67) : Glove box lamp
- E3 (M68) : Auto lamp control module
- F3 (M69) : Intake door motor
- F3 (M70) : Front blower motor
- F3 (M71) : Front fan resistor
- G1 (M72) : Front limit switch RH
- F3 (M73) : To (D51)
- F3 (M74) : To (D52)
- F2 (M75) : Body ground
- F4 (M76) : Power antenna motor
- F4 (M77) : Power antenna amplifier
- B3 (M124) : To (A3)
- B3 (M125) : Joint connector - 2
- D3 (M126) : Joint connector - 1



CI  
 MA  
 EM  
 LC  
 FF &  
 FC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
**EL**  
 DX

# HARNESS LAYOUT

## Main Harness (Cont'd)



AEL387-A

# HARNES LAYOUT

## Main Harness (Cont'd)

D3 (M79) : To power seat harness RH	C3 (M111) : Rear fan switch (Rear)
C3 (M79) : Shoulder belt retractor switch RH	C3 (M112) : Rear air conditioning control module
F4 (M80) : Slide door step lamp	C4 (M113) : Rear air mix door motor
E4 (M81) : Door switch RH	C3 (M114) : Rear intake door motor
F4 (M82) : Door switch (slide door)	D4 (M115) : To (E20) (For glass hatch models)
E3 (M84) : Sliding door contact switch	: Rear wiper amplifier (Except for glass hatch models)
E3 (M85) : Rear limit switch and drive motor RH	D4 (M116) : To (B10)
C4 (M100) : To power seat harness LH	D3 (M117) : Body ground
C3 (M102) : Shoulder belt retractor switch LH	D4 (M119) : To (B1)
C4 (M103) : Lap belt buckle switch	D4 (M120) : To (E51)
B4 (M104) : Rear limit switch and drive motor LH	D4 (M121) : To (E20) (For glass hatch models)
B4 (M105) : Door switch LH	: To (E52) (Except for glass hatch models)
B4 (M109) : Rear blower motor	D4 (M122) : To (E53)
B4 (M107) : Rear fan resistor	E4 (M123) : 4-channel amplifier
C3 (M110) : Rear remote control module	

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF




HA

EL

IDX

# HARNES LAYOUT

## Engine Control Harness



# HARNES LAYOUT

## Engine Control Harness (Cont'd)

- (F1) : To (E1)
- (F2) : To (E2)
- (F4) : Power steering oil pressure switch
- (F5) : Water cock solenoid valve
- (F6) : To (F6)
- (F7) : To (F7)
- (F8) : Engine coolant temperature sensor
- (F9) : Thermal transmitter
- (F10) : To (F10)
- (F11) : Camshaft position sensor
- (F12) : Camshaft position sensor (ground)
- (F13) : Power transistor unit
- (F14) : Ignition coil
- (F15) : Resistor & condenser
- (F16) : Compressor
- (F17) : High pressure switch
- (F18) : Injector No. 2
- (F19) : Injector No. 4
- (F20) : Injector No. 6
- (F21) : Engine ground
- (F22) : Engine ground
- (F23) : EGR control - solenoid valve
- (F24) : Throttle position sensor
- (F25) : Closed throttle position switch
- (F26) : Vehicle speed pulse generator
- (F27) : Terminal cord assembly
- (F28) : To (E30)
- (F29) : Inhibitor switch
- (F30) : Inhibitor switch
- (F31) : Mass air flow sensor
- (F51) : To (M64)
- (F52) : To (M65)
- (F53) : A/T control unit
- (F54) : ECM (ECCS control module)
- (F55) : Front sensor RH (For ABS)
- (F56) : Body ground (For ABS)
- (F101) : To (F6)
- (F102) : To (F7)
- (F103) : Injector No. 1
- (F104) : Injector No. 3
- (F105) : Injector No. 5
- (F106) : To (F10)
- (F107) : IAC valve - Air regulator
- (F108) : IAC valve - AAC valve
- (F109) : EGR temperature sensor
- (F110) : IAC valve - FICD solenoid valve
- (F111) : Knock sensor

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF





HA

EL

IDX

# HARNESS LAYOUT

## Body Harness



AEL389-A

# HARNES LAYOUT

## Body Harness (Cont'd)

A3 (B1) : To (M119)	B3 (B53) : To (M122)
A2 (B2) : Body ground	C3 (B54) : Body ground
C3 (B3) : Rear speaker LH	D1 (B55) : High-mounted stop lamp
C3 (B4) : 4-Channel amplifier	C1 (B56) : Rear defogger (+) (For glass hatch models)
C3 (B5) : Rear power window regulator LH	C2 (B57) : Rear defogger (+) (Except for glass hatch models)
C3 (B6) : Rear combination lamp LH	D2 (B58) : To (D101)
C4 (B7) : Rear side marker LH	D3 (B59) : To (D103)
E3 (B8) : Rear combination lamp RH	B2 (B10) : To (M118)
E3 (B9) : Rear side marker RH	E4 (B102) : Rear sensor RH (For ABS)
E2 (B10) : Rear power window regulator RH	D4 (B103) : Fuel pump
E2 (B11) : Rear speaker RH	D4 (B104) : Rear sensor LH (For ABS)
E3 (B12) : Body ground	B3 (B105) : To (B14)
D2 (B13) : Sub woofer amplifier	D4 (B106) : Trailer tow connector
B3 (B14) : To (B105)	C2 (B201) : To (M121) (For glass hatch models)
C3 (B15) : Trailer tow control module	B2 (B202) : To (B52) (For glass hatch models)
B3 (B51) : To (M120)	B2 (B203) : To (M119) (For glass hatch models)
B3 (B52) : To (B202) (For glass hatch models)	B2 (B204) : Diode J/C-2 (For glass hatch models)
: To (M121) (Except for glass hatch models)	A2 (B205) : Rear wiper relay (For glass hatch models)

GI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF



HA

EL

IDX

# HARNES LAYOUT

## Air Bag Harness




- (A1) : Front crash zone sensor
- (A2) : Tunnel and safing sensor
- (A3) : To (M12)
- (A4) : Supplemental air bag module (Through spiral cable)
- (A5) : Diagnosis (control) unit
- (A6) : Diagnosis (control) unit



# HARNESS LAYOUT


## Back Door Harness



GI  
 MA  
 EM  
 LC  
 EF &  
 EC  
 FE  
 AT  
 FA  
 RA  
 BR  
 ST  
 BF  
 HA  
 EL  
 IDX

# HARNES LAYOUT

## Room Lamp Harness




- |                                  |                            |
|----------------------------------|----------------------------|
| (R1) : To (M12)                  | (R6) : Sunroof motor       |
| (R2) : To (M13)                  | (R7) : Map lamp            |
| (R3) : Front limit switch LH     | (R8) : Vanity lamp RH      |
| (R4) : Vanity lamp LH            | (R9) : Front interior lamp |
| (R5) : Rear window opener switch | (R10) : Rear interior lamp |

AEL392

# HARNESS LAYOUT

## Door Harness

LH SIDE



CI

MA

EM

LC

EF &  
EC

FE

AT

FA

RA

BR

ST

BF

HA


EL

IDX

# HARNESS LAYOUT

## Door Harness (Cont'd)

RH SIDE



AEL039