

A
B
AT
D
E
F
G
H
I
J
K
L
M

SECTION **AT**

AUTOMATIC TRANSMISSION

CONTENTS

INDEX FOR DTC	5	How to Perform Trouble Diagnosis for Quick and Accurate Repair	46
Alphabetical Index	5	A/T Electrical Parts Location	51
DTC No. Index	6	Circuit Diagram	52
PRECAUTIONS	7	Inspections before Trouble Diagnosis	53
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	7	Check before Engine Is Started	57
Precautions for On Board Diagnostic (OBD) System of A/T and Engine	7	Check at Idle	57
Precautions	8	Cruise Test - Part 1	59
Service Notice or Precautions	9	Cruise Test - Part 2	61
PREPARATION	10	Cruise Test - Part 3	61
Special Service Tools	10	Vehicle Speed at Which Gear Shifting Occurs	63
Commercial Service Tools	11	Vehicle Speed at Which Lock-Up Occurs/Releases..	63
A/T FLUID	12	Symptom Chart	64
Changing A/T Fluid	12	TCM Input/Output Signal Reference Values	89
Checking A/T Fluid	13	CONSULT-II Function (A/T)	90
A/T Fluid Cooler Cleaning	14	Diagnostic Procedure without CONSULT-II	103
A/T CONTROL SYSTEM	17	DTC U1000 CAN COMMUNICATION LINE	105
Cross-Sectional View (VQ35DE Models for 2WD)..	17	Description	105
Cross-Sectional View (VK45DE Models for 2WD)..	18	On Board Diagnosis Logic	105
Cross-Sectional View (AWD Models)	19	Possible Cause	105
Shift Mechanism	20	DTC Confirmation Procedure	105
TCM Function	31	Wiring Diagram — AT — CAN	106
CAN Communication	32	Diagnostic Procedure	107
Input/Output Signal of TCM	32	DTC P0615 START SIGNAL CIRCUIT	108
Line Pressure Control	33	Description	108
Shift Control	34	CONSULT-II Reference Value	108
Lock-up Control	37	On Board Diagnosis Logic	108
Engine Brake Control	38	Possible Cause	108
Control Valve	38	DTC Confirmation Procedure	108
ON BOARD DIAGNOSTIC (OBD) SYSTEM	40	Wiring Diagram — AT — STSIG	109
Introduction	40	Diagnostic Procedure	110
OBD-II Function for A/T System	40	DTC P0700 TCM	112
One or Two Trip Detection Logic of OBD-II	40	Description	112
OBD-II Diagnostic Trouble Code (DTC)	40	On Board Diagnosis Logic	112
Malfunction Indicator Lamp (MIL)	43	Possible Cause	112
TROUBLE DIAGNOSIS	44	DTC Confirmation Procedure	112
DTC Inspection Priority Chart	44	Diagnostic Procedure	112
Fail-safe	44	DTC P0705 PARK/NEUTRAL POSITION SWITCH	113
		Description	113
		CONSULT-II Reference Value	113

On Board Diagnosis Logic	113	Description	135
Possible Cause	113	CONSULT-II Reference Value	135
DTC Confirmation Procedure	113	On Board Diagnosis Logic	135
Wiring Diagram — AT — PNP/SW	114	Possible Cause	135
Diagnostic Procedure	115	DTC Confirmation Procedure	135
DTC P0717 TURBINE REVOLUTION SENSOR ... 117		Wiring Diagram — AT — FTS	136
Description	117	Diagnostic Procedure	137
CONSULT-II Reference Value	117	Component Inspection	139
On Board Diagnosis Logic	117	DTC P1721 VEHICLE SPEED SENSOR MTR140	
Possible Cause	117	Description	140
DTC Confirmation Procedure	117	CONSULT-II Reference Value	140
Diagnostic Procedure	118	On Board Diagnosis Logic	140
DTC P0720 VEHICLE SPEED SENSOR A/T (REV- OLUTION SENSOR) 119		Possible Cause	140
Description	119	DTC Confirmation Procedure	140
CONSULT-II Reference Value	119	Diagnostic Procedure	141
On Board Diagnosis Logic	119	DTC P1730 A/T INTERLOCK142	
Possible Cause	119	Description	142
DTC Confirmation Procedure	119	On Board Diagnosis Logic	142
Wiring Diagram — AT — VSSA/T	121	Possible Cause	142
Diagnostic Procedure	122	DTC Confirmation Procedure	142
DTC P0725 ENGINE SPEED SIGNAL124		Judgement of A/T Interlock	143
Description	124	Diagnostic Procedure	143
CONSULT-II Reference Value	124	DTC P1731 A/T 1ST ENGINE BRAKING145	
On Board Diagnosis Logic	124	Description	145
Possible Cause	124	CONSULT-II Reference Value	145
DTC Confirmation Procedure	124	On Board Diagnosis Logic	145
Diagnostic Procedure	125	Possible Cause	145
DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE 126		DTC Confirmation Procedure	145
Description	126	Diagnostic Procedure	146
CONSULT-II Reference Value	126	DTC P1752 INPUT CLUTCH SOLENOID VALVE .147	
On Board Diagnosis Logic	126	Description	147
Possible Cause	126	CONSULT-II Reference Value	147
DTC Confirmation Procedure	126	On Board Diagnosis Logic	147
Diagnostic Procedure	127	Possible Cause	147
DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP).128		DTC Confirmation Procedure	147
Description	128	Diagnostic Procedure	148
CONSULT-II Reference Value	128	DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION149	
On Board Diagnosis Logic	128	Description	149
Possible Cause	128	CONSULT-II Reference Value	149
DTC Confirmation Procedure	128	On Board Diagnosis Logic	149
Diagnostic Procedure	129	Possible Cause	149
DTC P0745 LINE PRESSURE SOLENOID VALVE 130		DTC Confirmation Procedure	149
Description	130	Diagnostic Procedure	150
CONSULT-II Reference Value	130	DTC P1757 FRONT BRAKE SOLENOID VALVE ..151	
On Board Diagnosis Logic	130	Description	151
Possible Cause	130	CONSULT-II Reference Value	151
DTC Confirmation Procedure	130	On Board Diagnosis Logic	151
Diagnostic Procedure	131	Possible Cause	151
DTC P1705 THROTTLE POSITION SENSOR132		DTC Confirmation Procedure	151
Description	132	Diagnostic Procedure	152
CONSULT-II Reference Value	132	DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION153	
On Board Diagnosis Logic	132	Description	153
Possible Cause	132	CONSULT-II Reference Value	153
DTC Confirmation Procedure	132	On Board Diagnosis Logic	153
Diagnostic Procedure	133	Possible Cause	153
DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT 135		DTC Confirmation Procedure	153
		Diagnostic Procedure	154

DTC P1762 DIRECT CLUTCH SOLENOID VALVE	155	On Board Diagnosis Logic	172
Description	155	Possible Cause	172
CONSULT-II Reference Value	155	DTC Confirmation Procedure	172
On Board Diagnosis Logic	155	Diagnostic Procedure	173
Possible Cause	155	DTC P1843 ATF PRESSURE SWITCH 3	174
DTC Confirmation Procedure	155	Description	174
Diagnostic Procedure	156	CONSULT-II Reference Value	174
DTC P1764 DIRECT CLUTCH SOLENOID VALVE		On Board Diagnosis Logic	174
FUNCTION	157	Possible Cause	174
Description	157	DTC Confirmation Procedure	174
CONSULT-II Reference Value	157	Diagnostic Procedure	175
On Board Diagnosis Logic	157	DTC P1845 ATF PRESSURE SWITCH 5	176
Possible Cause	157	Description	176
DTC Confirmation Procedure	157	CONSULT-II Reference Value	176
Diagnostic Procedure	158	On Board Diagnosis Logic	176
DTC P1767 HIGH AND LOW REVERSE CLUTCH		Possible Cause	176
SOLENOID VALVE	159	DTC Confirmation Procedure	176
Description	159	Diagnostic Procedure	177
CONSULT-II Reference Value	159	DTC P1846 ATF PRESSURE SWITCH 6	178
On Board Diagnosis Logic	159	Description	178
Possible Cause	159	CONSULT-II Reference Value	178
DTC Confirmation Procedure	159	On Board Diagnosis Logic	178
Diagnostic Procedure	160	Possible Cause	178
DTC P1769 HIGH AND LOW REVERSE CLUTCH		DTC Confirmation Procedure	178
SOLENOID VALVE FUNCTION	161	Diagnostic Procedure	179
Description	161	MAIN POWER SUPPLY AND GROUND CIRCUIT.	180
CONSULT-II Reference Value	161	Wiring Diagram — AT — MAIN	180
On Board Diagnosis Logic	161	Diagnostic Procedure	181
Possible Cause	161	CLOSED THROTTLE POSITION AND WIDE OPEN	
DTC Confirmation Procedure	161	THROTTLE POSITION CIRCUIT	184
Diagnostic Procedure	162	CONSULT-II Reference Value	184
DTC P1772 LOW COAST BRAKE SOLENOID		Diagnostic Procedure	184
VALVE	163	BRAKE SIGNAL CIRCUIT	185
Description	163	CONSULT-II Reference Value	185
CONSULT-II Reference Value	163	Diagnostic Procedure	185
On Board Diagnosis Logic	163	A/T INDICATOR CIRCUIT	186
Possible Cause	163	Description	186
DTC Confirmation Procedure	163	CONSULT-II Reference Value	186
Diagnostic Procedure	164	Diagnostic Procedure	186
DTC P1774 LOW COAST BRAKE SOLENOID		TROUBLE DIAGNOSIS FOR SYMPTOMS	187
VALVE FUNCTION	165	Wiring Diagram — AT — NONDTC	187
Description	165	A/T CHECK Indicator Lamp Does Not Come On .	190
CONSULT-II Reference Value	165	Engine Cannot Be Started in “P” or “N” Position .	190
On Board Diagnosis Logic	165	In “P” Position, Vehicle Moves When Pushed	191
Possible Cause	165	In “N” Position, Vehicle Moves	192
DTC Confirmation Procedure	165	Large Shock (“N” to “D” Position)	193
Diagnostic Procedure	166	Vehicle Does Not Creep Backward in “R” Position	195
DTC P1815 MANUAL MODE SWITCH	167	Vehicle Does Not Creep Forward in “D” Position .	197
Description	167	Vehicle Cannot Be Started from D1	199
CONSULT-II Reference Value	167	A/T Does Not Shift: D1 → D2	201
On Board Diagnosis Logic	167	A/T Does Not Shift: D2 → D3	203
Possible Cause	167	A/T Does Not Shift: D3 → D4	205
DTC Confirmation Procedure	167	A/T Does Not Shift: D4 → D5	207
Wiring Diagram — AT — MMSW	168	A/T Does Not Lock-up	209
Diagnostic Procedure	170	A/T Does Not Hold Lock-up Condition	210
Component Inspection	171	Lock-up Is Not Released	212
DTC P1841 ATF PRESSURE SWITCH 1	172	Engine Speed Does Not Return to Idle	212
Description	172	Cannot Be Changed to Manual Mode	213
CONSULT-II Reference Value	172	A/T Does Not Shift: 5th Gear → 4th Gear	214

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T Does Not Shift: 4th Gear → 3rd Gear	215	Oil Channel	295
A/T Does Not Shift: 3rd Gear → 2nd Gear	217	Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings	298
A/T Does Not Shift: 2nd Gear → 1st Gear	218	DISASSEMBLY	301
Vehicle Does Not Decelerate by Engine Brake ...	220	Disassembly	301
SHIFT CONTROL SYSTEM	222	REPAIR FOR COMPONENT PARTS	322
Control Device Removal and Installation	222	Oil Pump	322
Control Rod Removal and Installation	226	Front Sun Gear, 3rd One-Way Clutch	325
Adjustment of A/T Position	227	Front Carrier, Input Clutch, Rear Internal Gear	327
Checking of A/T Position	228	Mid Sun Gear, Rear Sun Gear, High and Low Reverse Clutch Hub	333
A/T SHIFT LOCK SYSTEM	229	High and Low Reverse Clutch	339
Description	229	Direct Clutch	341
Shift Lock System Electrical Parts Location	229	ASSEMBLY	344
Wiring Diagram — AT — SHIFT	230	Assembly (1)	344
Diagnostic Procedure	232	Adjustment	360
ON-VEHICLE SERVICE	236	Assembly (2)	362
Control Valve With TCM and A/T Fluid Temperature Sensor 2	236	SERVICE DATA AND SPECIFICATIONS (SDS) ...	370
Parking Components (2WD Models Only)	250	General Specifications	370
Rear Oil Seal (VQ35DE Models Only)	262	Vehicle Speed at Which Gear Shifting Occurs	370
Revolution Sensor Components (2WD Models Only)	263	Vehicle Speed at Which Lock-Up Occurs/Releases	371
AIR BREATHER HOSE	272	Stall Speed	371
Removal and Installation	272	Line Pressure	371
TRANSMISSION ASSEMBLY	274	A/T Fluid Temperature Sensor	371
Removal and Installation (2WD Models)	274	Turbine Revolution Sensor	372
Removal and Installation (AWD Models)	278	Vehicle Speed Sensor A/T (Revolution Sensor) ..	372
OVERHAUL	281	Reverse Brake	372
Components	281	Total End Play	372

INDEX FOR DTC

PF0:00024

INDEX FOR DTC

Alphabetical Index

NCS001JA

NOTE:

If DTC "U1000" is displayed with other DTC, first perform the trouble diagnosis for "DTC U1000 CAN COMMUNICATION LINE". Refer to [AT-105](#).

Items (CONSULT-II screen terms)	DTC		Reference page
	OBD-II	Except OBD-II	
	CONSULT-II GST (*1)	CONSULT-II only "A/T"	
A/T 1ST E/BRAKING	—	P1731	AT-145
ATF PRES SW 1/CIRC	—	P1841	AT-172
ATF PRES SW 3/CIRC	—	P1843	AT-174
ATF PRES SW 5/CIRC	—	P1845	AT-176
ATF PRES SW 6/CIRC	—	P1846	AT-178
A/T INTERLOCK	P1730	P1730	AT-142
A/T TCC S/V FNCTN	P0744	P0744	AT-128
ATF TEMP SEN/CIRC	P0710	P1710	AT-135
CAN COMM CIRCUIT	U1000	U1000	AT-105
D/C SOLENOID/CIRC	P1762	P1762	AT-155
D/C SOLENOID FNCTN	P1764	P1764	AT-157
ENGINE SPEED SIG	P0725 (*2)	P0725	AT-124
FR/B SOLENOID/CIRC	P1757	P1757	AT-151
FR/B SOLENOID FNCT	P1759	P1759	AT-153
HLR/C SOL/CIRC	P1767	P1767	AT-159
HLR/C SOL FNCTN	P1769	P1769	AT-161
I/C SOLENOID/CIRC	P1752	P1752	AT-147
I/C SOLENOID FNCTN	P1754	P1754	AT-149
L/PRESS SOL/CIRC	P0745	P0745	AT-130
LC/B SOLENOID/CIRC	P1772	P1772	AT-163
LC/B SOLENOID FNCT	P1774	P1774	AT-165
MANU MODE SW/CIRC	—	P1815	AT-167
PNP SW/CIRC	P0705	P0705	AT-113
STARTER RELAY/CIRC	—	P0615	AT-108
TCC SOLENOID/CIRC	P0740	P0740	AT-126
TCM	P0700	P0700	AT-112
TP SEN/CIRC A/T	P1705 (*2)	P1705	AT-132
TURBINE REV S/CIRC	P0717	P0717	AT-117
VEH SPD SE/CIR-MTR	—	P1721	AT-140
VEH SPD SEN/CIR AT	P0720	P0720	AT-119

*1: These numbers are prescribed by SAE J2012.

*2: For VQ35DE engine.

INDEX FOR DTC

DTC No. Index

NCS001JB

NOTE:

If DTC “U1000” is displayed with other DTC, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [AT-105](#).

DTC		Items (CONSULT-II screen terms)	Reference page
OBD-II CONSULT-II GST (*1)	Except OBD-II CONSULT-II only “A/T”		
—	P0615	STARTER RELAY/CIRC	AT-108
P0700	P0700	TCM	AT-112
P0705	P0705	PNP SW/CIRC	AT-113
P0710	P1710	ATF TEMP SEN/CIRC	AT-135
P0717	P0717	TURBINE REV S/CIRC	AT-117
P0720	P0720	VEH SPD SEN/CIR AT	AT-119
P0725 (*2)	P0725	ENGINE SPEED SIG	AT-124
P0740	P0740	TCC SOLENOID/CIRC	AT-126
P0744	P0744	A/T TCC S/V FNCTN	AT-128
P0745	P0745	L/PRESS SOL/CIRC	AT-130
P1705 (*2)	P1705	TP SEN/CIRC A/T	AT-132
—	P1721	VEH SPD SE/CIR-MTR	AT-140
P1730	P1730	A/T INTERLOCK	AT-142
—	P1731	A/T 1ST E/BRAKING	AT-145
P1752	P1752	I/C SOLENOID/CIRC	AT-147
P1754	P1754	I/C SOLENOID FNCTN	AT-149
P1757	P1757	FR/B SOLENOID/CIRC	AT-151
P1759	P1759	FR/B SOLENOID FNCT	AT-153
P1762	P1762	D/C SOLENOID/CIRC	AT-155
P1764	P1764	D/C SOLENOID FNCTN	AT-157
P1767	P1767	HLR/C SOL/CIRC	AT-159
P1769	P1769	HLR/C SOL FNCTN	AT-161
P1772	P1772	LC/B SOLENOID/CIRC	AT-163
P1774	P1774	LC/B SOLENOID FNCT	AT-165
—	P1815	MANU MODE SW/CIRC	AT-167
—	P1841	ATF PRES SW 1/CIRC	AT-172
—	P1843	ATF PRES SW 3/CIRC	AT-174
—	P1845	ATF PRES SW 5/CIRC	AT-176
—	P1846	ATF PRES SW 6/CIRC	AT-178
U1000	U1000	CAN COMM CIRCUIT	AT-105

*1: These numbers are prescribed by SAE J2012.

*2: For VQ35DE engine.

PRECAUTIONS

PRECAUTIONS

PPF:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

NCS001JC

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for On Board Diagnostic (OBD) System of A/T and Engine

NCS001JD

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:


- Be sure to turn the ignition switch OFF and disconnect the battery cable from the negative terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.

PRECAUTIONS


Precautions

NCS001JE


- Before connecting or disconnecting the A/T assembly harness connector, turn ignition switch OFF and disconnect the battery cable from the negative terminal. Because battery voltage is applied to TCM even if ignition switch is turned OFF.



- After performing each TROUBLE DIAGNOSIS, perform "DTC (Diagnostic Trouble Code) Confirmation Procedure". If the repair is completed the DTC should not be displayed in the "DTC Confirmation Procedure".



- When removing the transmission from a vehicle, do not use the companion flange section at the rear end of the transmission as a support point. (VK45DE models only)
- Always use the specified brand of ATF. Refer to [MA-12, "Fluids and Lubricants"](#).
- Use lint-free paper not cloth rags during work.
- After replacing the ATF, dispose of the waste oil using the methods prescribed by law, ordinance, etc.
- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free paper or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transmission is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place disassembled valve body parts in order for easier and proper assembly. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, or hold bearings and washers in place during assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.



PRECAUTIONS

- Clean or replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer. Refer to [AT-9, "ATF COOLER SERVICE"](#) .
- After overhaul, refill the transmission with new ATF.
- When the A/T drain plug is removed, only some of the ATF is drained. Old ATF will remain in torque converter and ATF cooling system.
Always follow the procedures under "Changing A/T Fluid" in the AT section when changing A/T fluid. Refer to [AT-12, "Changing A/T Fluid"](#) , [AT-13, "Checking A/T Fluid"](#) .

Service Notice or Precautions ATF COOLER SERVICE

NCS001JF

If ATF contains frictional material (clutches, bands, etc.), or if an A/T is repaired, overhauled, or replaced, inspect and clean the A/T fluid cooler mounted in the radiator or replace the radiator. Flush cooler lines using cleaning solvent and compressed air after repair. For A/T fluid cooler cleaning procedure, refer to [AT-14, "A/T Fluid Cooler Cleaning"](#) . For radiator replacement, refer to [CO-14, "RADIATOR"](#) (for VQ35DE engine), [CO-43, "RADIATOR"](#) (for VK45DE engine).

OBD-II SELF-DIAGNOSIS

- A/T self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the A/T CHECK indicator or the malfunction indicator lamp (MIL). Refer to the table on [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.
Always perform the procedure on [AT-41, "HOW TO ERASE DTC"](#) to complete the repair and avoid unnecessary blinking of the MIL.

For details of OBD-II, refer to [EC-54, "ON BOARD DIAGNOSTIC \(OBD\) SYSTEM"](#) (for VQ35DE engine), [EC-756, "ON BOARD DIAGNOSTIC \(OBD\) SYSTEM"](#) (for VK45DE engine).

- **Certain systems and components, especially those related to OBD, may use the new style slide-locking type harness connector. For description and how to disconnect, refer to [PG-104, "HARNESS CONNECTOR"](#) .**

PREPARATION






PREPARATION

PF0:00002

Special Service Tools

NCS001JG




The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST2505S001 (J-34301-C) Oil pressure gauge set 1. ST25051001 (—) Oil pressure gauge 2. ST25052000 (—) Hose 3. ST25053000 (—) Joint pipe 4. ST25054000 (—) Adapter 5. ST25055000 (—) Adapter	Measuring line pressure 
KV31103600 (J-45674) Joint pipe adapter (With ST25054000)	Measuring line pressure  <p style="text-align: center;">ZZA1227D</p>
ST33400001 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.	<ul style="list-style-type: none"> ● Installing rear oil seal (VQ35DE models for 2WD) ● Installing oil pump housing oil seal  <p style="text-align: center;">NT086</p>
KV31102400 (J-34285 and J-34285-87) Clutch spring compressor a: 320 mm (12.60 in) b: 174 mm (6.85 in)	Installing reverse brake return spring retainer  <p style="text-align: center;">NT423</p>
ST25850000 (J-25721-A) Sliding hammer a: 179 mm (7.05 in) b: 70 mm (2.76 in) c: 40 mm (1.57 in) d: M12X1.75P	Remove oil pump assembly  <p style="text-align: center;">NT422</p>

PREPARATION

Commercial Service Tools

NCS001JH

Tool name	Description
<p>Power tool</p>  <p>PBIC0190E</p>	<p>Loosening bolts and nuts</p>
<p>Drift a: 22 mm (0.87 in) dia.</p>  <p>NT083</p>	<p>Installing manual shaft oil seals</p>
<p>Drift a: 64 mm (2.52 in) dia.</p>  <p>SCIA5338E</p>	<p>Installing rear oil seal (AWD models)</p>

A
B
AT
D
E
F
G
H
I
J
K
L
M


A/T FLUID

PFP:KLE40

Changing A/T Fluid

NCS001JI

1. Warm up ATF.
2. Stop engine.
3. Loosen the level gauge bolt.
4. Drain ATF from drain plug and refill with new ATF. Always refill same volume with drained ATF.
 - To replace the ATF, pour in new ATF at the A/T fluid charging pipe with the engine idling and at the same time drain the old ATF from the radiator cooler hose return side.
 - When the color of the ATF coming out is about the same as the color of the new ATF, the replacement is complete. The amount of new ATF to use should be 30 to 50% increase of the stipulated amount.



ATF: **Genuine NISSAN Matic J ATF**

Fluid capacity: **10.3 ℓ (10-7/8 US qt, 9-1/8 Imp qt)**

CAUTION:

- Use only **Genuine NISSAN Matic J ATF**. Do not mix with other ATF.
- Using ATF other than **Genuine NISSAN Matic J ATF** will cause deterioration in driveability and A/T durability, and may damage the A/T, which is not covered by the warranty.
- When filling ATF, take care not to scatter heat generating parts such as exhaust.
- Do not reuse drain plug gasket.

Drain plug

 : **34 N·m (3.5 kg·m, 25 ft·lb)**

5. Run engine at idle speed for 5 minutes.
6. Check A/T fluid level and condition. Refer to [AT-13, "Checking A/T Fluid"](#) . If ATF is still dirty, repeat step 2. through 5.
7. Install the removed A/T fluid level gauge into A/T fluid charging pipe.
8. Tighten the level gauge bolt.

Level gauge bolt

 : **5.1 N·m (0.52 kg·m, 45 in·lb)**

Checking A/T Fluid

1. Warm up engine.
2. Check for A/T fluid leakage.
3. Loosen the level gauge bolt.
4. Before driving, A/T fluid level can be checked at A/T fluid temperatures of 30 to 50°C (86 to 122°F) using “COLD” range on A/T fluid level gauge as follows.
 - a. Park vehicle on level surface and set parking brake.
 - b. Start engine and move selector lever through each gear position. Leave selector lever in “P” position.
 - c. Check A/T fluid level with engine idling.
 - d. Remove A/T fluid level gauge and wipe clean with lint-free paper.

CAUTION:

When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.

- e. Re-insert A/T fluid level gauge into A/T fluid charging pipe as far as it will go.

CAUTION:

To check A/T fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the A/T fluid level gauge reversed from the normal attachment conditions.

- f. Remove A/T fluid level gauge and note reading. If reading is at low side of range, add ATF to the A/T fluid charging pipe.



CAUTION:

Do not overfill.

5. Drive vehicle for approximately 5 minutes in urban areas.
6. Make the A/T fluid temperature approximately 65°C (149°F).

NOTE:

A/T fluid level will be greatly affected by temperature as shown in figure. Therefore, be certain to perform operation while checking data with CONSULT-II.



- a. Connect CONSULT-II to data link connector. Refer to [GI-38, "CONSULT-II Start Procedure"](#).
- b. Select “MAIN SIGNALS” in “DATA MONITOR” mode for “A/T” with CONSULT-II.
- c. Read out the value of “ATF TEMP 1”.
7. Re-check A/T fluid level at A/T fluid temperatures of approximately 65°C (149°F) using “HOT” range on A/T fluid level gauge.

A/T FLUID

CAUTION:

- When wiping away the A/T fluid level gauge, always use lint-free paper, not a cloth one.
- To check A/T fluid level, insert the A/T fluid level gauge until the cap contacts the end of the A/T fluid charging pipe, with the A/T fluid level gauge reversed from the normal attachment conditions as shown.

8. Check A/T fluid condition.



- If ATF is very dark or smells burned, check operation of A/T. Flush cooling system after repair of A/T.
- If A/T fluid contains frictional material (clutches, bands, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of A/T. Refer to [CO-14, "RADIATOR"](#) (for VQ35DE engine), [CO-43, "RADIATOR"](#) (for VK45DE engine) and [AT-14, "A/T Fluid Cooler Cleaning"](#).

9. Install the removed A/T fluid level gauge in the A/T fluid charging pipe.

10. Tighten level gauge bolt.

Level gauge bolt

 : 5.1 N·m (0.52 kg·m, 45 in·lb)



A/T Fluid Cooler Cleaning

NCS001JK

Whenever an A/T is replaced, the A/T fluid cooler mounted in the radiator must be inspected and cleaned. Metal debris and friction material, if present, can become trapped in the A/T fluid cooler. This debris can contaminate the newly serviced A/T or, in severe cases, can block or restrict the flow of ATF. In either case, malfunction of the newly serviced A/T may result.

Debris, if present, may build up as ATF enters the cooler inlet. It will be necessary to back flush the cooler through the cooler outlet in order to flush out any built up debris.


A/T FLUID COOLER CLEANING PROCEDURE

1. Position an oil pan under the A/T inlet and outlet cooler hoses.
2. Identify the inlet and outlet fluid cooler hoses.
3. Disconnect the A/T fluid cooler inlet and outlet rubber hoses from the steel cooler tubes or bypass valve.

NOTE:

Replace the cooler hoses if rubber material from the hose remains on the tube fitting.

4. Allow any ATF that remains in the cooler hoses to drain into the oil pan.





A/T FLUID

5. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:

- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

6. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until ATF flows out of the cooler inlet hose for 5 seconds.
7. Insert the tip of an air gun into the end of the cooler outlet hose.
8. Wrap a shop rag around the air gun tip and of the cooler outlet hose.
9. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose for 10 seconds to force out any remaining ATF.
10. Repeat steps 5 through 9 three additional times.
11. Position an oil pan under the banjo bolts that connect the A/T fluid cooler steel lines to the A/T.
12. Remove the banjo bolts.
13. Flush each steel line from the cooler side back toward the A/T by spraying Transmission Cooler Cleaner in a continuous stream for 5 seconds.
14. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through each steel line from the cooler side back toward the A/T for 10 seconds to force out any remaining ATF.
15. Ensure all debris is removed from the steel cooler lines.
16. Ensure all debris is removed from the banjo bolts and fittings.
17. Perform [AT-15, "A/T FLUID COOLER DIAGNOSIS PROCEDURE"](#).



A/T FLUID COOLER DIAGNOSIS PROCEDURE

NOTE:


Insufficient cleaning of the cooler inlet hose exterior may lead to inaccurate debris identification.

1. Position an oil pan under the A/T inlet and outlet cooler hoses.
2. Clean the exterior and tip of the cooler inlet hose.
3. Insert the extension adapter hose of a can of Transmission Cooler Cleaner (Nissan P/N 999MP-AM006) into the cooler outlet hose.

CAUTION:


- Wear safety glasses and rubber gloves when spraying the Transmission Cooler Cleaner.
- Spray Transmission Cooler Cleaner only with adequate ventilation.
- Avoid contact with eyes and skin.
- Do not breath vapors or spray mist.

4. Hold the hose and can as high as possible and spray Transmission Cooler Cleaner in a continuous stream into the cooler outlet hose until ATF flows out of the cooler inlet hose for 5 seconds.




A/T FLUID

5. Tie a common white, basket-type coffee filter to the end of the cooler inlet hose.





6. Insert the tip of an air gun into the end of the cooler outlet hose.
7. Wrap a shop rag around the air gun tip and end of cooler outlet hose.
8. Blow compressed air regulated to 5 to 9 kg/cm² (70 to 130 psi) through the cooler outlet hose to force any remaining ATF into the coffee filter.
9. Remove the coffee filter from the end of the cooler inlet hose.
10. Perform [AT-16, "A/T FLUID COOLER INSPECTION PROCEDURE"](#).



A/T FLUID COOLER INSPECTION PROCEDURE

1. Inspect the coffee filter for debris.
 - a. If small metal debris less than 1mm (0.040 in) in size or metal powder is found in the coffee filter, this is normal. If normal debris is found, the A/T fluid cooler/radiator can be re-used and the procedure is ended.
 - b. If one or more pieces of debris are found that are over 1 mm (0.040 in) in size and/or peeled clutch facing material is found in the coffee filter, the A/T fluid cooler is not serviceable. The A/T fluid cooler/radiator must be replaced and the inspection procedure is ended. Refer to [CO-14, "RADIATOR"](#) (for VQ35DE engine), [CO-43, "RADIATOR"](#) (for VK45DE engine).



A/T FLUID COOLER FINAL INSPECTION

After performing all procedures, ensure that all remaining oil is cleaned from all components.


A/T CONTROL SYSTEM

A/T CONTROL SYSTEM

PFP:31036

Cross-Sectional View (VQ35DE Models for 2WD)

NCS001JL




- | | | |
|-------------------------|--------------------------------|----------------------------|
| 1. Front planetary gear | 2. Mid planetary gear | 3. Rear planetary gear |
| 4. Direct clutch | 5. High and low reverse clutch | 6. Reverse brake |
| 7. Drum support | 8. Forward brake | 9. Low coast brake |
| 10. Input shaft | 11. Torque converter | 12. Oil pump |
| 13. 3rd one-way clutch | 14. Front brake | 15. Input clutch |
| 16. 1st one-way clutch | 17. Control valve with TCM | 18. Forward one-way clutch |
| 19. Rear extension | 20. Output shaft | |

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T CONTROL SYSTEM

Cross-Sectional View (VK45DE Models for 2WD)

NCS001JM




SCIA6948E

- | | | |
|-------------------------|--------------------------------|----------------------------|
| 1. Front planetary gear | 2. Mid planetary gear | 3. Rear planetary gear |
| 4. Direct clutch | 5. High and low reverse clutch | 6. Reverse brake |
| 7. Drum support | 8. Forward brake | 9. Low coast brake |
| 10. Input shaft | 11. Torque converter | 12. Oil pump |
| 13. 3rd one-way clutch | 14. Front brake | 15. Input clutch |
| 16. 1st one-way clutch | 17. Control valve with TCM | 18. Forward one-way clutch |
| 19. Rear extension | 20. Intermediate shaft | 21. Output shaft |
| 22. Companion flange | | |

A/T CONTROL SYSTEM

Cross-Sectional View (AWD Models)

NCS001JN



- | | | |
|-------------------------|--------------------------------|----------------------------|
| 1. Front planetary gear | 2. Mid planetary gear | 3. Rear planetary gear |
| 4. Direct clutch | 5. High and low reverse clutch | 6. Reverse brake |
| 7. Drum support | 8. Forward brake | 9. Low coast brake |
| 10. Input shaft | 11. Torque converter | 12. Oil pump |
| 13. 3rd one-way clutch | 14. Front brake | 15. Input clutch |
| 16. 1st one-way clutch | 17. Control valve with TCM | 18. Forward one-way clutch |
| 19. Adapter case | 20. Output shaft | |

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T CONTROL SYSTEM


NC5001JO

Shift Mechanism

The A/T uses compact triple planetary gear systems to improve power transmission efficiency, simplify construction and reduce weight.

It also employs an optimum shift control and super wide gear ratios. They improve starting performance and acceleration during medium and high-speed operation.

CONSTRUCTION



PCIA0002J

- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

FUNCTION OF CLUTCH AND BRAKE

Name of the Part	Abbreviation	Function
Front brake (1)	FR/B	Fastens the front sun gear (11).
Input clutch (2)	I/C	Connects the input shaft (12), the front internal gear (14) and the mid internal gear (13).
Direct clutch (3)	D/C	Connects the rear carrier (15) and the rear sun gear (16).
High and low reverse clutch (4)	HLR/C	Connects the mid sun gear (17) and the rear sun gear (16).
Reverse brake (5)	R/B	Fastens the rear carrier (15).
Forward brake (6)	Fwd/B	Fastens the mid sun gear (17).
Low coast brake (7)	LC/B	Fastens the mid sun gear (17).
1st one-way clutch (8)	1st OWC	Allows the rear sun gear (16) to turn freely forward relative to the mid sun gear (17) but fastens it for reverse rotation.
Forward one-way clutch (9)	Fwd OWC	Allows the mid sun gear (17) to turn freely in the forward direction but fastens it for reverse rotation.
3rd one-way clutch (10)	3rd OWC	Allows the front sun gear (11) to turn freely in the forward direction but fastens it for reverse rotation.

A/T CONTROL SYSTEM

CLUTCH AND BAND CHART

Shift position	I/C	HLR/C	D/C	R/B	FR/B	LC/B	Fwd/B	1st OWC	Fwd OWC	3rd OWC	Remarks
P		△			△						PARK POSITION
R		○		○	○			◎		◎	REVERSE POSITION
N		△			△						NEUTRAL POSITION
D	1st	△ *			△	△ **	○	◎	◎	◎	Automatic shift 1↔2↔3↔4↔5
	2nd		○		△		○		◎	◎	
	3rd		○	○		○	△	◇		◎	
	4th	○	○	○			△	◇			
	5th	○	○			○	△	◇		◇	
M5	5th	○	○				△	◇		◇	Locks* (held stationary) in 5th gear
M4	4th	○	○	○			△	◇			Locks* (held stationary) in 4th gear
M3	3rd		○	○			△	◇		◎	Locks* (held stationary) in 3rd gear
M2	2nd			○		○	○		◎	◎	Locks* (held stationary) in 2nd gear
M1	1st		○			○	○	◎	◎	◎	Locks* (held stationary) in 1st gear

○ — Operates

◎ — Operates during "progressive" acceleration.


◇ — Operates and affects power transmission while coasting.

△ — Line pressure is applied but does not affect power transmission.

△ * — Operates under conditions shown in illustration ①.

△ ** — Operates under conditions shown in illustration ②. Delay control is applied during D (4,3,2,1) → N shift.

* : Down shift automatically according to the vehicle speed.



SCIA6962E

A/T CONTROL SYSTEM


POWER TRANSMISSION

“N” Position

Since both the forward brake and the reverse brake are released, torque from the input shaft drive is not transmitted to the output shaft.

“P” Position

- The same as for the “N” position, both the forward brake and the reverse brake are released, so torque from the input shaft drive is not transmitted to the output shaft.
- The parking pawl linked with the selector lever meshes with the parking gear and fastens the output shaft mechanically.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D1 ” Position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 1st one-way clutch regulates reverse rotation of the rear sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and the engine brake is not activated.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“M1” Position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- High and low reverse clutch connects the rear sun gear and the mid sun gear.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

"D2" Position

- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- During deceleration, the mid sun gear turns forward, so the forward one-way clutch idles and engine brake is not activated.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T CONTROL SYSTEM

"M2" Position

- The front brake fastens the front sun gear.
- The forward brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The low coast brake fastens the mid sun gear.
- During deceleration, the low coast brake regulates forward rotation of the mid sun gear and the engine brake functions.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D3” and “M3” Positions

- The front brake fastens the front sun gear.
- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T CONTROL SYSTEM

“D4 ” and “M4” Positions

- The direct clutch is coupled, and the rear carrier and rear sun gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The drive power is conveyed to the front internal gear, mid internal gear, and rear carrier and the three planetary gears rotate forward as one unit.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

“D5” and “M5” Positions

- The front brake fastens the front sun gear.
- The input clutch is coupled, and the front internal gear and mid internal gear are connected.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.




- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A
B
AT
D
E
F
G
H
I
J
K
L
M

A/T CONTROL SYSTEM

“R” Position

- The front brake fastens the front sun gear.
- The high and low reverse clutch is coupled, and the mid sun gear and rear sun gear are connected.
- The reverse brake fastens the rear carrier.



- | | | |
|--------------------------------|-------------------------|---------------------------|
| 1. Front brake | 2. Input clutch | 3. Direct clutch |
| 4. High and low reverse clutch | 5. Reverse brake | 6. Forward brake |
| 7. Low coast brake | 8. 1st one-way clutch | 9. Forward one-way clutch |
| 10. 3rd one-way clutch | 11. Front sun gear | 12. Input shaft |
| 13. Mid internal gear | 14. Front internal gear | 15. Rear carrier |
| 16. Rear sun gear | 17. Mid sun gear | 18. Front carrier |
| 19. Mid carrier | 20. Rear internal gear | 21. Output shaft |
| 22. Parking gear | 23. Parking pawl | |

A/T CONTROL SYSTEM

NCS001JP

TCM Function

The function of the TCM is to:


- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

CONTROL SYSTEM OUTLINE

The A/T senses vehicle operating conditions through various sensors or signals. It always controls the optimum shift position and reduces shifting and lock-up shocks.

SENSORS (or SIGNAL)		TCM		ACTUATORS
PNP switch Accelerator pedal position signal Closed throttle position signal Wide open throttle position signal Engine speed signal A/T fluid temperature sensor Revolution sensor Vehicle speed signal Manual mode switch signal Stop lamp switch signal Turbine revolution sensor ATF pressure switch	⇒	Shift control Line pressure control Lock-up control Engine brake control Timing control Fail-safe control Self-diagnosis CONSULT-II communication line Duet-EA control CAN system	⇒	Input clutch solenoid valve Direct clutch solenoid valve Front brake solenoid valve High and low reverse clutch solenoid valve Low coast brake solenoid valve Torque converter clutch solenoid valve Line pressure solenoid valve A/T CHECK indicator lamp Back-up lamp relay Starter relay

CONTROL SYSTEM DIAGRAM



SCIA5325E

A/T CONTROL SYSTEM

CAN Communication SYSTEM DESCRIPTION

NCS001JQ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. Refer to [LAN-50, "CAN System Specification Chart"](#) .

Input/Output Signal of TCM

NCS001JR

Control item		Line pressure control	Vehicle speed control	Shift control	Lock-up control	Engine brake control	Fail-safe function (*3)	Self-diagnostics function
Input	Accelerator pedal position signal (*5)	X	X	X	X	X	X	X
	Vehicle speed sensor A/T (revolution sensor)	X	X	X	X	X	X	X
	Vehicle speed sensor MTR(*1) (*5)						X	
	Closed throttle position signal(*5)		X(*2)	X	X		X	X(*4)
	Wide open throttle position signal(*5)						X	X(*4)
	Turbine revolution sensor 1		X		X	X	X	X
	Turbine revolution sensor 2 (for 4th speed only)		X		X	X	X	X
	Engine speed signals(*5)	X	X	X	X	X	X	X
	Stop lamp switch signal(*5)		X	X	X			X(*4)
	A/T fluid temperature sensors 1, 2	X	X	X	X		X	X
	ASCD or ICC sensor integrated unit	Operation signal(*5)		X	X	X		
Overdrive cancel signal(*5)			X					
Out-put	Direct clutch solenoid (ATF pressure switch 5)		X	X			X	X
	Input clutch solenoid (ATF pressure switch 3)		X	X			X	X
	High and low reverse clutch solenoid (ATF pressure switch 6)		X	X			X	X
	Front brake solenoid (ATF pressure switch 1)		X	X			X	X
	Low coast brake solenoid (ATF pressure switch 2)		X	X		X	X	X
	Line pressure solenoid	X	X	X	X	X	X	X
	TCC solenoid				X		X	X
	Self-diagnostics table(*6)							X
	Starter relay						X	X

*1: Spare for vehicle speed sensor-A/T (revolution sensor)

*2: Spare for accelerator pedal position signal

*3: If these input and output signals are different, the TCM triggers the fail-safe function.

*4: Used as a condition for starting self-diagnostics; if self-diagnostics are not started, it is judged that there is some kind of error.

*5: Input by CAN communications.


*6: Output by CAN communications.

A/T CONTROL SYSTEM

NCS001JS

Line Pressure Control

- When an input torque signal equivalent to the engine drive force is sent from the ECM to the TCM, the TCM controls the line pressure solenoid.
- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving state.




LINE PRESSURE CONTROL IS BASED ON THE TCM LINE PRESSURE CHARACTERISTIC PATTERN

- The TCM has stored in memory a number of patterns for the optimum line pressure characteristic for the driving state.
- In order to obtain the most appropriate line pressure characteristic to meet the current driving state, the TCM controls the line pressure solenoid current value and thus controls the line pressure.


Normal Control

Each clutch is adjusted to the necessary pressure to match the engine drive force.



Back-up Control (Engine Brake)


When the select operation is performed during driving and the A/T is shifted down, the line pressure is set according to the vehicle speed.



A/T CONTROL SYSTEM


During Shift Change

The necessary and adequate line pressure for shift change is set. For this reason, line pressure pattern setting corresponds to input torque and gearshift selection. Also, line pressure characteristic is according to engine speed, during engine brake operation.




At Low Fluid Temperature

When the A/T fluid temperature drops below the prescribed temperature, in order to speed up the action of each friction element, the line pressure is set higher than the normal line pressure characteristic.



Shift Control

The clutch pressure control solenoid is controlled by the signals from the switches and sensors. Thus, the clutch pressure is adjusted to be appropriate to the engine load state and vehicle driving state. It becomes possible to finely control the clutch hydraulic pressure with high precision and a smoother shift change characteristic is attained.




A/T CONTROL SYSTEM

SHIFT CHANGE

The clutch is controlled with the optimum timing and oil pressure by the engine speed, engine torque information, etc.

Shift Change System Diagram



*1: Full phase real-time feedback control monitors movement of gear ratio at gear change, and controls oil pressure at real-time to achieve the best gear ratio.


BLIPPING CONTROL

This system makes transmission clutch engage readily by controlling (synchronizing) engine revolution according to the (calculation of) engine revolution after shifting down.

- "BLIPPING CONTROL" functions.
 - When downshifting by accelerator pedal depression at "D" position.
 - When downshifting under the manual mode.
- TCM selects "BLIPPING CONTROL" or "NORMAL SHIFT CONTROL" according to the gear position, the select lever position, the engine torque and the speed when accelerating by pedal depression.
- Revolution control demand signal is transmitted from TCM to ECM under "BLIPPING CONTROL".
- TCM synchronizes engine revolution according to the revolution control demand signal.


A/T CONTROL SYSTEM

Shift Change System Diagram



ASC (ADOPTIVE SHIFT CONTROL)

ASC automatically shifts or holds at the 3rd or 4th gear on certain roads (up/down slope and curve) and driving condition.



When Driving on an Up/Down Slope

- ASC judges up/down slope according to the angle of accelerator pedal and vehicle speed. Holding gear at the 3rd or 4th on an up-slope prevents shift hunting and controls the vehicle to gain maximum driving force. On a down-slope, automatic shift-down to the 3rd or 4th gear controls to gain maximum engine brake.

When Driving on a Curve

- TCM receives side G sensor signal from ABS actuator and electric unit (control unit). Holding gear at the 3rd or 4th based on the signal prevents shift-up and kick-down and controls to drive smoothly.

A/T CONTROL SYSTEM

NCS001JU

Lock-up Control

The torque converter clutch piston in the torque converter is engaged to eliminate torque converter slip to increase power transmission efficiency.


The torque converter clutch control valve operation is controlled by the torque converter clutch solenoid valve, which is controlled by a signal from TCM, and the torque converter clutch control valve engages or releases the torque converter clutch piston.

Lock-up operation condition table

Selector lever	"D" position			"M" position	
Gear position	5	4	3	5	4
Lock-up	×	–	–	×	×
Slip lock-up	×	×	×	–	–

TORQUE CONVERTER CLUTCH CONTROL VALVE CONTROL

Lock-up Control System Diagram



Lock-up Released

- In the lock-up released state, the torque converter clutch control valve is set into the unlocked state by the torque converter clutch solenoid and the lock-up apply pressure is drained. In this way, the torque converter clutch piston is not coupled.

Lock-up Applied

- In the lock-up applied state, the torque converter clutch control valve is set into the locked state by the torque converter clutch solenoid and lock-up apply pressure is generated. In this way, the torque converter clutch piston is pressed and coupled.

SMOOTH LOCK-UP CONTROL

When shifting from the lock-up released state to the lock-up applied state, the current output to the torque converter clutch solenoid is controlled with the TCM. In this way, when shifting to the lock-up applied state, the torque converter clutch is temporarily set to the half-clutched state to reduce the shock.

Half-clutched State

- The current output from the TCM to the torque converter clutch solenoid is varied to steadily increase the torque converter clutch solenoid pressure. In this way, the lock-up apply pressure gradually rises and while the torque converter clutch piston is put into half-clutched status, the torque converter clutch piston operating pressure is increased and the coupling is completed smoothly.

Slip Lock-up Control


- In the slip region, the torque converter clutch solenoid current is controlled with the TCM to put it into the half-clutched state. This absorbs the engine torque fluctuation and lock-up operates from low speed. This raises the fuel efficiency for 3rd, 4th and 5th gears at both low speed and when the accelerator has a low degree of opening.

A/T CONTROL SYSTEM

Engine Brake Control

NCS001JV

- The forward one-way clutch transmits the drive force from the engine to the rear wheels. But the reverse drive from the rear wheels is not transmitted to the engine because the one-way clutch is idling. Therefore, the low coast brake solenoid is operated to prevent the forward one-way clutch from idling and the engine brake is operated in the same manner as conventionally.



SCIA1520E

- The operation of the low coast brake solenoid switches the low coast brake switching valve and controls the coupling and releasing of the low coast brake. The low coast brake reducing valve controls the low coast brake coupling force.

Control Valve FUNCTION OF CONTROL VALVE

NCS001JV

Name	Function
Torque converter regulator valve	In order to prevent the pressure supplied to the torque converter from being excessive, the line pressure is adjusted to the optimum pressure (torque converter operating pressure).
Pressure regulator valve Pressure regulator plug Pressure regulator sleeve	Adjusts the oil discharged from the oil pump to the optimum pressure (line pressure) for the driving state.
Front brake control valve	When the front brake is coupled, adjusts the line pressure to the optimum pressure (front brake pressure) and supplies it to the front brake. (In 1st, 2nd, 3rd, and 5th gears, adjusts the clutch pressure.)
Accumulator control valve	Adjusts the pressure (accumulator control pressure) acting on the accumulator piston and low coast reducing valve to the pressure appropriate to the driving state.
Pilot valve A	Adjusts the line pressure and produces the constant pressure (pilot pressure) required for line pressure control, shift change control, and lock-up control.
Pilot valve B	Adjusts the line pressure and produces the constant pressure (pilot pressure) required for shift change control.
Low coast brake switching valve	During engine braking, supplies the line pressure to the low coast brake reducing valve.
Low coast brake reducing valve	When the low coast brake is coupled, adjusts the line pressure to the optimum pressure (low coast brake pressure) and supplies it to the low coast brake.
N-R accumulator	Produces the stabilizing pressure for when N-R is selected.
Direct clutch piston switching valve	Operates in 4th gear and switches the direct clutch coupling capacity.
High and low reverse clutch control valve	When the high and low reverse clutch is coupled, adjusts the line pressure to the optimum pressure (high and low reverse clutch pressure) and supplies it to the high and low reverse clutch. (In 1st, 3rd, 4th and 5th gears, adjusts the clutch pressure.)

A/T CONTROL SYSTEM

Name	Function
Input clutch control valve	When the input clutch is coupled, adjusts the line pressure to the optimum pressure (input clutch pressure) and supplies it to the input clutch. (In 4th and 5th gears, adjusts the clutch pressure.)
Direct clutch control valve	When the direct clutch is coupled, adjusts the line pressure to the optimum pressure (direct clutch pressure) and supplies it to the direct clutch. (In 2nd, 3rd, and 4th gears, adjusts the clutch pressure.)
TCC control valve TCC control plug TCC control sleeve	Switches the lock-up to operating or released. Also, by performing the lock-up operation transiently, lock-up smoothly.
Torque converter lubrication valve	Operates during lock-up to switch the torque converter, cooling, and lubrication system oil passage.
Cool bypass valve	Allows excess oil to bypass cooler circuit without being fed into it.
Line pressure relief valve	Discharges excess oil from line pressure circuit.
N-D accumulator	Produces the stabilizing pressure for when N-D is selected.
Manual valve	Sends line pressure to each circuit according to the select position. The circuits to which the line pressure is not sent drain.

FUNCTION OF PRESSURE SWITCH

Name	Function
ATF pressure switch 1 (FR/B)	Detects any malfunction in the front brake hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 2 (LC/B)	Detects any malfunction in the low coast brake hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 3 (I/C)	Detects any malfunction in the input clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 5 (D/C)	Detects any malfunction in the direct clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.
ATF pressure switch 6 (HLR/C)	Detects any malfunction in the high and low reverse clutch hydraulic pressure. When it detects any malfunction, it puts the system into fail-safe mode.

A
B
AT
D
E
F
G
H
I
J
K
L
M

ON BOARD DIAGNOSTIC (OBD) SYSTEM

ON BOARD DIAGNOSTIC (OBD) SYSTEM

PDF:00028

Introduction

NCS001JX

The A/T system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory but not the TCM memory.

The second is the TCM original self-diagnosis indicated by the A/T CHECK indicator lamp. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to [AT-92, "Display Items List"](#).

OBD-II Function for A/T System

NCS001JY

The ECM provides emission-related on board diagnostic (OBD-II) functions for the A/T system. One function is to receive a signal from the TCM used with OBD-related parts of the A/T system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in "One or Two Trip Detection Logic" when a malfunction is sensed in relation to A/T system parts.

One or Two Trip Detection Logic of OBD-II ONE TRIP DETECTION LOGIC

NCS001JZ

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

TWO TRIP DETECTION LOGIC

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — 1st trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — 2nd trip

The "Trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II Diagnostic Trouble Code (DTC) HOW TO READ DTC AND 1ST TRIP DTC

NCS001K0

DTC and 1st trip DTC can be read by the following methods.


( with **CONSULT-II** or ( **GST**) CONSULT-II or GST (Generic Scan Tool) Examples: P0705, P0720 etc.

These DTC are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST, they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal.**
CONSULT-II can identify them as shown below, therefore, CONSULT-II (if available) is recommended.

A sample of CONSULT-II display for DTC and 1st trip DTC is shown on the next page. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.



ON BOARD DIAGNOSTIC (OBD) SYSTEM

If the DTC is being detected currently, the time data will be "0".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	0

SAT015K

If a 1st trip DTC is stored in the ECM, the time data will be "1t".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	1 t

SAT016K

Freeze Frame Data and 1st Trip Freeze Frame Data

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For detail, refer to [EC-123, "CONSULT-II Function \(ENGINE\)"](#) (for VQ35DE engine), [EC-826, "CONSULT-II Function \(ENGINE\)"](#) (for VK45DE engine).

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306* ¹ or P0300 - P0308* ² Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

*1: For VQ35DE engine.

*2: For VK45DE engine.

Both 1st trip freeze frame data and freeze frame data (along with the DTC) are cleared when the ECM memory is erased.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by CONSULT-II, GST or ECM DIAGNOSTIC TEST MODE as described following.

- If the battery cable is disconnected from the terminal, the DTC will be lost within 24 hours.
- When you erase the DTC, using CONSULT-II or GST is easier and quicker than switching the mode selector on the ECM.

ON BOARD DIAGNOSTIC (OBD) SYSTEM

The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to [EC-55, "Emission-Related Diagnostic Information"](#) (for VQ35DE engine), [EC-757, "Emission-Related Diagnostic Information"](#) (for VK45DE engine).

- Diagnostic trouble codes (DTC)
- 1st trip diagnostic trouble codes (1st trip DTC)
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

Ⓟ HOW TO ERASE DTC (WITH CONSULT-II)

- If a DTC is displayed for both ECM and TCM, it is necessary to be erased for both ECM and TCM.
1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
 2. Turn CONSULT-II ON and touch "A/T".
 3. Touch "SELF-DIAG RESULTS".
 4. Touch "ERASE". (The DTC in the TCM will be erased.) Then touch "BACK" twice.
 5. Touch "ENGINE".
 6. Touch "SELF-DIAG RESULTS".
 7. Touch "ERASE". (The DTC in the ECM will be erased.)

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 10 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
A/T
ENGINE


2. Turn CONSULT-II "ON", and touch "A/T".

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
CAN DIAG SUPPORT MNTR
FUNCTION TEST
DTC WORK SUPPORT
ECU PART NUMBER

3. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS
DTC RESULTS
TCC SOLENOID/CIRC [P0740]

4. Touch "ERASE". (The DTC in the TCM will be erased.)



SELECT SYSTEM
A/T
ENGINE

5. Touch "ENGINE".

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
DATA MONITOR(SPEC)
CAN DIAG SUPPORT MNTR
ACTIVE TEST

6. Touch "SELF-DIAG RESULTS".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
TCC SOLENOID/CIRC [P0740]	0

7. Touch "ERASE". (The DTC in the TCM will be erased.)

SCIA5671E

ON BOARD DIAGNOSTIC (OBD) SYSTEM

HOW TO ERASE DTC (WITH GST)

1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Perform [AT-103, "OBD-II SELF-DIAGNOSTIC PROCEDURE \(WITH GST\)"](#) . (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with GST (Generic Scan Tool). For details, refer to [EC-135, "Generic Scan Tool \(GST\) Function"](#) (for VQ35DE engine), [EC-838, "Generic Scan Tool \(GST\) Function"](#) (for VK45DE engine).

HOW TO ERASE DTC (NO TOOLS)

The A/T CHECK indicator lamp is located on the instrument panel.


1. If the ignition switch stays ON after repair work, be sure to turn ignition switch OFF once. Wait at least 10 seconds and then turn it ON (engine stopped) again.
2. Perform [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) . (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Perform "OBD-II SELF-DIAGNOSTIC PROCEDURE (No tools)". Refer to [EC-68, "How to Erase DTC"](#) (for VQ35DE engine), [EC-770, "How to Erase DTC"](#) (for VK45DE engine).

Malfunction Indicator Lamp (MIL) DESCRIPTION

NCS001K1

The MIL is located on the combination meters.

1. The MIL will light up when the ignition switch is turned ON without the engine running. This is a bulb check.
 - If the MIL does not light up, refer to [DI-39, "WARNING LAMPS"](#) , or see [EC-714, "MIL AND DATA LINK CONNECTOR"](#) (for VQ35DE engine), [EC-1438, "MIL AND DATA LINK CONNECTOR"](#) (for VK45DE engine).
2. When the engine is started, the MIL should go off. If the MIL remains on, the on board diagnostic system has detected an engine system malfunction.



TROUBLE DIAGNOSIS

TROUBLE DIAGNOSIS

PFP:00004

DTC Inspection Priority Chart

NCS001K2

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

NOTE:

If DTC “U1000” is displayed with other DTC, first perform the trouble diagnosis for “DTC U1000 CAN COMMUNICATION LINE”. Refer to [AT-105](#).

Priority	Detected items (DTC)
1	U1000 CAN communication line
2	Except above

Fail-safe

NCS001K3

The TCM has an electrical fail-safe mode. This mode makes it possible to operate even if there is an error in a main electronic control input/output signal circuit.

In fail-safe mode, even if the selector lever is “D” or “M” mode, the A/T is fixed in 2nd, 4th and 5th (depending on the breakdown position), so the customer should feel “slipping” or “poor acceleration”.

Even when the electronic circuits are normal, under special conditions (for example, when slamming on the brake with the wheels spinning drastically and stopping the tire rotation), the A/T can go into fail-safe mode. If this happens, switch OFF the ignition switch for 10 seconds, then switch it ON again to return to the normal shift pattern. Therefore, the customer's vehicle has returned to normal, so handle according to the “WORK FLOW” (Refer to [AT-47](#)).

FAIL-SAFE FUNCTION

If any malfunction occurs in a sensor or solenoid, this function controls the A/T to mark driving possible.

Vehicle Speed Sensor

- Signals are input from two systems - from vehicle speed sensor A/T (revolution sensor) installed on the A/T and from combination meter so normal driving is possible even if there is a malfunction in one of the systems. And if vehicle speed sensor A/T (revolution sensor) has unusual cases, 5th gear and manual mode are prohibited.

Accelerator Pedal Position Sensor

- If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the engine speed is fixed by ECM to a pre-determined engine speed to make driving possible.

Throttle Position Sensor

- If there is a malfunction in one of the systems, the accelerator opening angle is controlled by ECM according to a pre-determined accelerator angle to make driving possible. And if there are malfunctions in tow systems, the accelerator opening angle is controlled by the idle signal sent from the ECM which is based on input indicating either idle condition or off-idle condition (pre-determined accelerator opening) in order to make driving possible.

PNP Switch

- In the unlikely event that a malfunction signal enters the TCM, the position indicator is switched OFF, the starter relay is switched OFF (starter starting is disabled), the back-up lamp relay switched OFF (back-up lamp is OFF) and the position is fixed to the “D” position to make driving possible.

Starter Relay

- The starter relay is switched OFF. (Starter starting is disabled.)

TROUBLE DIAGNOSIS

A/T Interlock

- If there is an A/T interlock judgment malfunction, the A/T is fixed in 2nd gear to make driving possible.

NOTE:

When the vehicle is driven fixed in 2nd gear, a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.

- When the coupling pattern below is detected, the fail-safe action corresponding to the pattern is performed.

A/T INTERLOCK COUPLING PATTERN TABLE

●: NG X: OK

Gear position		ATF pressure switch output					Fail-safe function	Clutch pressure output pattern after fail-safe function					
		SW3 (I/C)	SW6 (HLR/C)	SW5 (D/C)	SW1 (FR/B)	SW2 (LC/B)		I/C	HLR/C	D/C	FR/B	LC/B	L/U
A/T interlock coupling pattern	3rd	–	X	X	–	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	4th	–	X	X	–	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	5th	X	X	–	X	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF

A/T 1st Engine Braking

- When there is an A/T first gear engine brake judgment malfunction, the low coast brake solenoid is switched OFF to avoid the engine brake operation.

Line Pressure Solenoid

- The solenoid is switched OFF and the line pressure is set to the maximum hydraulic pressure to make driving possible.

Torque Converter Clutch Solenoid

- The solenoid is switched OFF to release the lock-up.

Low Coast Brake Solenoid

- When a malfunction (electrical or functional) occurs, in order to make driving possible. If the solenoid is ON, the A/T is held in 2nd gear. If the solenoid is OFF, the A/T is held in 4th gear. (Engine brake is not applied in 1st and 2nd gear.)

Input Clutch Solenoid

- If a malfunction (electrical or functional) occurs with the solenoid either ON or OFF, the A/T is held in 4th gear to make driving possible.

Direct Clutch Solenoid

- If a malfunction (electrical or functional) occurs with the solenoid either ON or OFF, the A/T is held in 4th gear to make driving possible.

Front Brake Solenoid

- If a malfunction (electrical or functional) occurs with the solenoid ON, in order to make driving possible. The A/T is held in 5th gear. If the solenoid is OFF, the A/T is 4th gear.

High and Low Reverse Clutch Solenoid

- If a (electrical or functional) malfunction occurs with the solenoid either ON or OFF, the A/T is held in 4th gear to make driving possible.

Turbine Revolution Sensor 1 or 2

- The control is the same as if there were no turbine revolution sensors, 5th gear and manual mode are prohibited.

TROUBLE DIAGNOSIS


How to Perform Trouble Diagnosis for Quick and Accurate Repair INTRODUCTION

NCS001K4

The TCM receives a signal from the vehicle speed sensor, accelerator pedal position sensor (throttle position sensor) or PNP switch and provides shift control or lock-up control via A/T solenoid valves.


The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the A/T system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.



It is much more difficult to diagnose a error that occurs intermittently rather than continuously. Most intermittent errors are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.


A visual check only may not find the cause of the errors. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the [AT-47, "WORK FLOW"](#) .



Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such errors, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "DIAGNOSTIC WORKSHEET" as shown on the example (Refer to [AT-48](#)) should be used.

Start your diagnosis by looking for "conventional" errors first. This will help troubleshoot driveability errors on an electronically controlled engine vehicle.

Also check related Service bulletins.




TROUBLE DIAGNOSIS

WORK FLOW

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a malfunction. It is important to fully understand the symptoms or conditions for a customer's complaint. Make good use of the two sheets provided, [AT-48, "Information from Customer"](#) and [AT-48, "Diagnostic Worksheet Chart"](#), to perform the best troubleshooting possible.

Work Flow Chart



- *1. [AT-48](#)
- *4. [AT-53](#)
- *7. [AT-90](#)
- *10. [AT-105](#)
- *13. [AT-64](#)
- *16. [AT-178](#)

- *2. [AT-48](#)
- *5. [AT-53, AT-55](#)
- *8. [AT-40](#)
- *11. [AT-178](#)
- *14. [AT-41](#)
- *17. [EC-55](#) (for VQ35DE engine), [EC-757](#) (for VK45DE engine)

- *3. [AT-44](#)
- *6. [AT-57](#)
- *9. [AT-44](#)
- *12. [AT-187](#)
- *15. [AT-105](#)

SCIA7037E

TROUBLE DIAGNOSIS

DIAGNOSTIC WORKSHEET

Information from Customer

KEY POINTS

- **WHAT**..... Vehicle and A/T model
- **WHEN**..... Date, Frequencies
- **WHERE**..... Road conditions
- **HOW**..... Operating conditions, Symptoms

Customer name	MR/MS	Model and Year	VIN
Trans. Model		Engine	Mileage
Malfunction Date		Manuf. Date	In Service Date
Frequency	<input type="checkbox"/> Continuous <input type="checkbox"/> Intermittent (times a day)		
Symptoms	<input type="checkbox"/> Vehicle does not move. (<input type="checkbox"/> Any position <input type="checkbox"/> Particular position)		
	<input type="checkbox"/> No up-shift (<input type="checkbox"/> 1st → 2nd <input type="checkbox"/> 2nd → 3rd <input type="checkbox"/> 3rd → 4th <input type="checkbox"/> 4th → 5th)		
	<input type="checkbox"/> No down-shift (<input type="checkbox"/> 5th → 4th <input type="checkbox"/> 4th → 3rd <input type="checkbox"/> 3rd → 2nd <input type="checkbox"/> 2nd → 1st)		
	<input type="checkbox"/> Lock-up malfunction		
	<input type="checkbox"/> Shift point too high or too low.		
	<input type="checkbox"/> Shift shock or slip (<input type="checkbox"/> N → D <input type="checkbox"/> N → R <input type="checkbox"/> Lock-up <input type="checkbox"/> Any drive position)		
	<input type="checkbox"/> Noise or vibration		
	<input type="checkbox"/> No kick down		
	<input type="checkbox"/> No pattern select		
	<input type="checkbox"/> Others ()		
A/T CHECK indicator lamp	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit	
Malfunction indicator lamp (MIL)	<input type="checkbox"/> Continuously lit	<input type="checkbox"/> Not lit	

Diagnostic Worksheet Chart

1	<input type="checkbox"/> Read the item on cautions concerning fail-safe and understand the customer's complaint.	AT-44		
2	<input type="checkbox"/> A/T fluid inspection	AT-53		
	<input type="checkbox"/> Leak (Repair leak location.) <input type="checkbox"/> State <input type="checkbox"/> Amount			
3	<input type="checkbox"/> Stall test and line pressure test	AT-53 , AT-55		
	<input type="checkbox"/> Stall test <table style="width: 100%; border: none;"> <tr> <td style="width: 50%; border: none;"> <input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Front brake <input type="checkbox"/> High and low reverse clutch <input type="checkbox"/> Low coast brake <input type="checkbox"/> Forward brake <input type="checkbox"/> Reverse brake <input type="checkbox"/> Forward one-way clutch </td> <td style="width: 50%; border: none;"> <input type="checkbox"/> 1st one-way clutch <input type="checkbox"/> 3rd one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure low <input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK </td> </tr> </table>	<input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Front brake <input type="checkbox"/> High and low reverse clutch <input type="checkbox"/> Low coast brake <input type="checkbox"/> Forward brake <input type="checkbox"/> Reverse brake <input type="checkbox"/> Forward one-way clutch	<input type="checkbox"/> 1st one-way clutch <input type="checkbox"/> 3rd one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure low <input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK	
	<input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Front brake <input type="checkbox"/> High and low reverse clutch <input type="checkbox"/> Low coast brake <input type="checkbox"/> Forward brake <input type="checkbox"/> Reverse brake <input type="checkbox"/> Forward one-way clutch	<input type="checkbox"/> 1st one-way clutch <input type="checkbox"/> 3rd one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure low <input type="checkbox"/> Except for input clutch and direct clutch, clutches and brakes OK		
<input type="checkbox"/> Line pressure inspection - Suspected part:				

TROUBLE DIAGNOSIS

	<input type="checkbox"/> Perform all road tests and enter checks in required inspection items.	AT-57	A
4	4-1. Check before engine is started AT-57	<input type="checkbox"/> AT-190, "A/T CHECK Indicator Lamp Does Not Come On" <input type="checkbox"/> Perform self-diagnostics. Enter checks for detected items. AT-92 , AT-103	B
	4-1. <input type="checkbox"/> AT-105, "DTC U1000 CAN COMMUNICATION LINE" <input type="checkbox"/> AT-108, "DTC P0615 START SIGNAL CIRCUIT" <input type="checkbox"/> AT-112, "DTC P0700 TCM" <input type="checkbox"/> AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH" <input type="checkbox"/> AT-117, "DTC P0717 TURBINE REVOLUTION SENSOR" <input type="checkbox"/> AT-119, "DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)" <input type="checkbox"/> AT-124, "DTC P0725 ENGINE SPEED SIGNAL" <input type="checkbox"/> AT-126, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-128, "DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)" <input type="checkbox"/> AT-130, "DTC P0745 LINE PRESSURE SOLENOID VALVE" <input type="checkbox"/> AT-132, "DTC P1705 THROTTLE POSITION SENSOR" <input type="checkbox"/> AT-135, "DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT" <input type="checkbox"/> AT-140, "DTC P1721 VEHICLE SPEED SENSOR MTR" <input type="checkbox"/> AT-142, "DTC P1730 A/T INTERLOCK" <input type="checkbox"/> AT-145, "DTC P1731 A/T 1ST ENGINE BRAKING" <input type="checkbox"/> AT-147, "DTC P1752 INPUT CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-149, "DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-151, "DTC P1757 FRONT BRAKE SOLENOID VALVE" <input type="checkbox"/> AT-153, "DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-155, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-157, "DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-159, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-161, "DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-163, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE" <input type="checkbox"/> AT-165, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-167, "DTC P1815 MANUAL MODE SWITCH" <input type="checkbox"/> AT-172, "DTC P1841 ATF PRESSURE SWITCH 1" <input type="checkbox"/> AT-174, "DTC P1843 ATF PRESSURE SWITCH 3" <input type="checkbox"/> AT-176, "DTC P1845 ATF PRESSURE SWITCH 5" <input type="checkbox"/> AT-178, "DTC P1846 ATF PRESSURE SWITCH 6"		AT
	4-2. Check at Idle AT-57	<input type="checkbox"/> AT-190, "Engine Cannot Be Started in "P" or "N" Position" <input type="checkbox"/> AT-191, "In "P" Position, Vehicle Moves When Pushed" <input type="checkbox"/> AT-192, "In "N" Position, Vehicle Moves" <input type="checkbox"/> AT-193, "Large Shock ("N" to "D" Position)" <input type="checkbox"/> AT-195, "Vehicle Does Not Creep Backward in "R" Position" <input type="checkbox"/> AT-197, "Vehicle Does Not Creep Forward in "D" Position"	
4-3. Cruise Test AT-59	Part 1 <input type="checkbox"/> AT-199, "Vehicle Cannot Be Started from D1" <input type="checkbox"/> AT-201, "A/T Does Not Shift: D1 → D2" <input type="checkbox"/> AT-203, "A/T Does Not Shift: D2 → D3" <input type="checkbox"/> AT-205, "A/T Does Not Shift: D3 → D4" <input type="checkbox"/> AT-207, "A/T Does Not Shift: D4 → D5" <input type="checkbox"/> AT-209, "A/T Does Not Lock-up" <input type="checkbox"/> AT-210, "A/T Does Not Hold Lock-up Condition" <input type="checkbox"/> AT-212, "Lock-up Is Not Released" <input type="checkbox"/> AT-212, "Engine Speed Does Not Return to Idle"		E

TROUBLE DIAGNOSIS

4	4-3	Part 2 <input type="checkbox"/> AT-199, "Vehicle Cannot Be Started from D1" <input type="checkbox"/> AT-201, "A/T Does Not Shift: D1 → D2" <input type="checkbox"/> AT-203, "A/T Does Not Shift: D2 → D3" <input type="checkbox"/> AT-205, "A/T Does Not Shift: D3 → D4"	AT-61
		Part 3 <input type="checkbox"/> AT-213, "Cannot Be Changed to Manual Mode" <input type="checkbox"/> AT-214, "A/T Does Not Shift: 5th Gear → 4th Gear" <input type="checkbox"/> AT-215, "A/T Does Not Shift: 4th Gear → 3rd Gear" <input type="checkbox"/> AT-217, "A/T Does Not Shift: 3rd Gear → 2nd Gear" <input type="checkbox"/> AT-218, "A/T Does Not Shift: 2nd Gear → 1st Gear" <input type="checkbox"/> AT-220, "Vehicle Does Not Decelerate by Engine Brake" <input type="checkbox"/> Perform self-diagnostics. Enter checks for detected items. AT-92 , AT-103	AT-61
		<input type="checkbox"/> AT-105, "DTC U1000 CAN COMMUNICATION LINE" <input type="checkbox"/> AT-108, "DTC P0615 START SIGNAL CIRCUIT" <input type="checkbox"/> AT-112, "DTC P0700 TCM" <input type="checkbox"/> AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH" <input type="checkbox"/> AT-117, "DTC P0717 TURBINE REVOLUTION SENSOR" <input type="checkbox"/> AT-119, "DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)" <input type="checkbox"/> AT-124, "DTC P0725 ENGINE SPEED SIGNAL" <input type="checkbox"/> AT-126, "DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-128, "DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)" <input type="checkbox"/> AT-130, "DTC P0745 LINE PRESSURE SOLENOID VALVE" <input type="checkbox"/> AT-132, "DTC P1705 THROTTLE POSITION SENSOR" <input type="checkbox"/> AT-135, "DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT" <input type="checkbox"/> AT-140, "DTC P1721 VEHICLE SPEED SENSOR MTR" <input type="checkbox"/> AT-142, "DTC P1730 A/T INTERLOCK" <input type="checkbox"/> AT-145, "DTC P1731 A/T 1ST ENGINE BRAKING" <input type="checkbox"/> AT-147, "DTC P1752 INPUT CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-149, "DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-151, "DTC P1757 FRONT BRAKE SOLENOID VALVE" <input type="checkbox"/> AT-153, "DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-155, "DTC P1762 DIRECT CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-157, "DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-159, "DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE" <input type="checkbox"/> AT-161, "DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-163, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE" <input type="checkbox"/> AT-165, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION" <input type="checkbox"/> AT-167, "DTC P1815 MANUAL MODE SWITCH" <input type="checkbox"/> AT-172, "DTC P1841 ATF PRESSURE SWITCH 1" <input type="checkbox"/> AT-174, "DTC P1843 ATF PRESSURE SWITCH 3" <input type="checkbox"/> AT-176, "DTC P1845 ATF PRESSURE SWITCH 5" <input type="checkbox"/> AT-178, "DTC P1846 ATF PRESSURE SWITCH 6"	
		<input type="checkbox"/> Inspect each system for items found to be NG in the self-diagnostics and repair or replace the malfunctioning parts.	

5

Perform all road tests and enter the checks again for the required items.

6

[AT-57](#)

7

For any remaining NG items, perform the "Diagnostics Procedure" and repair or replace the malfunctioning parts. See the chart for diagnostics by symptoms. (This chart also contains other symptoms and inspection procedures.)

[AT-64](#)

8

Erase the results of the self-diagnostics from the TCM.







[AT-96, AT-104](#)

TROUBLE DIAGNOSIS

A/T Electrical Parts Location

NCS001K5

A
B
AT
D
E
F
G
H
I
J
K
L
M




- TCM
- Turbine revolution sensor 1, 2
- Revolution sensor
- A/T fluid temperature sensor 1, 2
- PNP switch
- Line pressure solenoid valve
- Torque converter clutch solenoid valve
- Direct clutch solenoid valve, ATF pressure SW 5
- High and low reverse clutch solenoid Valve, ATF pressure SW 6
- Input clutch solenoid valve, ATF pressure SW 3
- Front brake solenoid valve, ATF pressure SW 1
- Low coast brake solenoid valve, ATF pressure SW 2

SCIA6772E

TROUBLE DIAGNOSIS

Circuit Diagram

NCS001K6



TCWT0341E

TROUBLE DIAGNOSIS

NCS001K7

A
B
AT
D
E
F
G
H
I
J
K
L
M

Inspections before Trouble Diagnosis

A/T FLUID CHECK

A/T Fluid Leakage and A/T Fluid Level Check

Inspect for A/T fluid leakage and check the A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

A/T Fluid Condition Check

Inspect the A/T fluid condition.


Fluid condition	Conceivable Cause	Required Operation
Varnished (viscous varnish state)	Clutch, brake scorched	Replace the ATF and check the A/T main unit and the vehicle for malfunctions (wire harnesses, cooler pipes, etc.)
Milky white or cloudy	Water in the fluid	Replace the ATF and check for places where water is getting in.
Large amount of metal powder mixed in	Unusual wear of sliding parts within A/T	Replace the ATF and check for improper operation of the A/T.




STALL TEST

Stall Test Procedure


1. Inspect the amount of engine oil. Replenish the engine oil if necessary.
2. Drive for about 10 minutes to warm up the vehicle so that the A/T fluid temperature is 50 to 80°C (122 to 176°F). Inspect the amount of ATF. Replenish if necessary.



3. Securely engage the parking brake so that the tires do not turn.



4. Engine start, apply foot brake, and place selector lever in "D" position.



TROUBLE DIAGNOSIS

5. While holding down the foot brake, gradually press down the accelerator pedal.
6. Quickly read off the stall speed, then quickly remove your foot from the accelerator pedal.


CAUTION:

Do not hold down the accelerator pedal for more than 5 seconds during this test.


Stall speed

VQ35DE models: 2,650 - 2,950 rpm

VK45DE models: 2,260 - 2,560 rpm



7. Move the selector lever to the "N" position.
 8. Cool down the ATF.
- CAUTION:**
Run the engine at idle for at least 1 minute.
9. Repeat steps 5 through 8 with selector lever in "R" position.



Judgement of Stall Test

	Selector lever position		Possible location of malfunction
	"D", "M"	"R"	
Stall speed	H	O	<ul style="list-style-type: none"> ● Forward brake ● Forward one-way clutch ● 1st one-way clutch ● 3rd one-way clutch
	O	H	<ul style="list-style-type: none"> ● Reverse brake
	L	L	<ul style="list-style-type: none"> ● Engine and torque converter one-way clutch
	H	H	<ul style="list-style-type: none"> ● Line pressure low

O: Stall speed within standard value position

H: Stall speed higher than standard value

L: Stall speed lower than standard value


Stall test standard value position

Does not shift-up "D" or "M" position 1 → 2	Slipping in 2nd, 3rd or 4th gear	Direct clutch slippage
Does not shift-up "D" or "M" position 2 → 3	Slipping in 3rd, 4th or 5th gear	High and low reverse clutch slippage
Does not shift-up "D" or "M" position 3 → 4	Slipping in 4th or 5th gear	Input clutch slippage
Does not shift-up "D" or "M" position 4 → 5	Slipping in 5th gear	Front brake slippage

TROUBLE DIAGNOSIS

LINE PRESSURE TEST

Line Pressure Test Port



Line Pressure Test Procedure

1. Inspect the amount of engine oil and replenish if necessary.
2. Drive the car for about 10 minutes to warm it up so that the ATF reaches in range of 50 to 80°C (122 to 176°F), then inspect the amount of ATF and replenish if necessary.


NOTE:

The A/T fluid temperature rises in range of 50 to 80°C (122 to 176°F) during 10 minutes of driving.


3. Remove the front propeller shaft from vehicle (with AWD models). Refer to [PR-5, "Removal and Installation"](#).
4. After warming up remove the oil pressure detection plug and install the oil pressure gauge [ST2505S001(J-34301-C)].

CAUTION:

When using the oil pressure gauge, be sure to use the O-ring attached to the oil pressure detection plug.



5. Securely engage the parking brake so that the tires do not turn.




6. Start the engine, then measure the line pressure at both idle and the stall speed.

CAUTION:

- Keep the brake pedal pressed all the way down during measurement.
- When measuring the line pressure at the stall speed, refer to [AT-53, "STALL TEST"](#).

7. After the measurements are complete, install the oil pressure detection plug and tighten to the specified torque.

 : 7.3 N·m (0.74 kg·m, 65 in·lb)



TROUBLE DIAGNOSIS

CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.

Line Pressure

Engine speed	Line pressure [kPa (kg/cm ² , psi)]	
	"R" position	"D", "M" positions
At idle speed	425 - 465 (4.3 - 4.7, 62 - 67)	379 - 428 (3.9 - 4.4, 55 - 62)
At stall speed	1,605 - 1,950 (16.4 - 19.9, 233 - 283)	1,310 - 1,500 (13.4 - 15.3, 190 - 218)

Judgement of Line Pressure Test

Judgement		Possible cause
Idle speed	Low for all positions ("P", "R", "N", "D", "M")	<p>Possible causes include malfunctions in the pressure supply system and low oil pump output. For example</p> <ul style="list-style-type: none"> ● Oil pump wear ● Pressure regulator valve or plug sticking or spring fatigue ● Oil strainer ⇒ oil pump ⇒ pressure regulator valve passage oil leak ● Engine idle speed too low
	Only low for a specific position	<p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p>
	High	<p>Possible causes include a sensor malfunction or malfunction in the line pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● A/T fluid temperature sensor malfunction ● Line pressure solenoid malfunction (sticking in OFF state, filter clog, cut line) ● Pressure regulator valve or plug sticking
Stall speed	Oil pressure does not rise higher than the oil pressure for idle.	<p>Possible causes include a sensor malfunction or malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● TCM breakdown ● Line pressure solenoid malfunction (shorting, sticking in ON state) ● Pressure regulator valve or plug sticking ● Pilot valve sticking or pilot filter clogged
	The pressure rises, but does not enter the standard position.	<p>Possible causes include malfunctions in the pressure supply system and malfunction in the pressure adjustment function. For example</p> <ul style="list-style-type: none"> ● Accelerator pedal position signal malfunction ● Line pressure solenoid malfunction (sticking, filter clog) ● Pressure regulator valve or plug sticking ● Pilot valve sticking or pilot filter clogged
	Only low for a specific position	<p>Possible causes include an oil pressure leak in a passage or device related to the position after the pressure is distributed by the manual valve.</p>

TROUBLE DIAGNOSIS

ROAD TEST

Description

- The road test inspects overall performance of the A/T and analyzes possible malfunction causes.
- The road test is performed out in the following three stages.
 1. Check before engine is started. Refer to [AT-57](#) .
 2. Check at idle. Refer to [AT-57](#) .
 3. Cruise test
 - Inspect all the items from Part 1 to Part 3. Refer to [AT-59](#) , [AT-61](#) , [AT-61](#) .
 - Before beginning the road test, check the test procedure and inspection items.
 - Test all inspection items until the symptom is uncovered. Diagnose NG items when all road tests are complete.

Check before Engine Is Started

NCS001K8

1. CHECK A/T CHECK INDICATOR LAMP

1. Park vehicle on level surface.
2. Move selector lever to "P" position.
3. Turn ignition switch OFF and wait at least 10 seconds.
4. Turn ignition switch ON. (Do not start engine.)

Does A/T CHECK indicator lamp light up for about 2 seconds?

YES >> 1. Turn ignition switch OFF.

2. Perform self-diagnostics and record all NG items on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) . Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .
3. Go to [AT-57, "Check at Idle"](#) .

NO >> Stop the road test and go to [AT-190, "A/T CHECK Indicator Lamp Does Not Come On"](#) .

Check at Idle

NCS001K9

1. CHECK STARTING THE ENGINE

1. Park vehicle on level surface.
2. Move selector lever to "P" or "N" position.
3. Turn ignition switch OFF.
4. Start engine.

Does the engine start?

YES >> GO TO 2.

NO >> Stop the road test and go to [AT-190, "Engine Cannot Be Started in "P" or "N" Position"](#) .

2. CHECK STARTING THE ENGINE

1. Turn ignition switch ON.
2. Move selector lever to "D", "M" or "R" position.
3. Start engine.

Does the engine start in any positions?

YES >> Stop the road test and go to [AT-190, "Engine Cannot Be Started in "P" or "N" Position"](#) .

NO >> GO TO 3.

TROUBLE DIAGNOSIS

3. CHECK "P" POSITION FUNCTIONS

1. Move selector lever to "P" position.
2. Turn ignition switch OFF.
3. Release the parking brake.
4. Push the vehicle forward or backward.
5. Engage the parking brake.

When you push the vehicle with disengaging the parking brake, does it move?

- YES >> Enter a check mark at [AT-191, "In "P" Position, Vehicle Moves When Pushed"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.
- NO >> GO TO 4.

4. CHECK "N" POSITION FUNCTIONS

1. Start engine.
2. Move selector lever to "N" position.
3. Release the parking brake.

Does vehicle move forward or backward?

- YES >> Enter a check mark at [AT-192, "In "N" Position, Vehicle Moves"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.
- NO >> GO TO 5.

5. CHECK SHIFT SHOCK

1. Engage the brake.
2. Move selector lever to "D" position.

When the A/T is shifted from "N" to "D", is there an excessive shock?

- YES >> Enter a check mark at [AT-193, "Large Shock \("N" to "D" Position\)"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.
- NO >> GO TO 6.

6. CHECK "R" POSITION FUNCTIONS

1. Engage the brake.
2. Move selector lever to "R" position.
3. Release the brake for 4 to 5 seconds.

Does the vehicle creep backward?

- YES >> GO TO 7.
- NO >> Enter a check mark at [AT-195, "Vehicle Does Not Creep Backward in "R" Position"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

7. CHECK "D" POSITION FUNCTIONS

Inspect whether the vehicle creep forward when the A/T is put into the "D" position.

Does the vehicle creep forward in the "D" position?

- YES >> Go to [AT-59, "Cruise Test - Part 1"](#), [AT-61, "Cruise Test - Part 2"](#) and [AT-61, "Cruise Test - Part 3"](#).
- NO >> Enter a check mark at [AT-197, "Vehicle Does Not Creep Forward in "D" Position"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

TROUBLE DIAGNOSIS

NCS001KA

Cruise Test - Part 1

1. CHECK STARTING OUT FROM D1

1. Drive the vehicle for about 10 minutes to warm up the engine oil and ATF. Appropriate temperature for the ATF: 50 to 80°C (122 to 176°F)
2. Park the vehicle on a level surface.
3. Move selector lever to "P" position.
4. Start the engine.
5. Move selector lever to "D" position.
6. Press the accelerator pedal about half way down to accelerate the vehicle.

With CONSULT-II

Read the gear position. Refer to [AT-96, "DATA MONITOR MODE"](#).

Starts from D1?

YES >> GO TO 2.

NO >> Enter a check mark at [AT-199, "Vehicle Cannot Be Started from D1"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

2. CHECK SHIFT-UP D1 → D2

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D1 → D2) at the appropriate speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#).

With CONSULT-II

Read the gear position, throttle degree of opening and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at [AT-201, "A/T Does Not Shift: D1 → D2"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

3. CHECK SHIFT-UP D2 → D3

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D2 → D3) at the appropriate speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#).

With CONSULT-II

Read the gear position, throttle degree of opening and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at [AT-203, "A/T Does Not Shift: D2 → D3"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

4. CHECK SHIFT-UP D3 → D4

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D3 → D4) at the appropriate speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#).

With CONSULT-II

Read the gear position, throttle degree of opening and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D3 → D4 at the correct speed?

YES >> GO TO 5.

NO >> Enter a check mark at [AT-205, "A/T Does Not Shift: D3 → D4"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

TROUBLE DIAGNOSIS

5. CHECK SHIFT-UP D4 → D5

Press down the accelerator pedal about half-way and inspect if the vehicle shifts up (D4 → D5) at the appropriate speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#) .

Ⓟ **With CONSULT-II**

Read the gear position, throttle degree of opening and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#) .

Does the A/T shift-up D4 → D5 at the correct speed?

YES >> GO TO 6.

NO >> Enter a check mark at [AT-207, "A/T Does Not Shift: D4 → D5"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

6. CHECK LOCK-UP

When releasing accelerator pedal (closed throttle position signal: OFF) from D5, check lock-up from D5 to L/U. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#) .

Ⓟ **With CONSULT-II**

Select "TCC SOLENOID" with the "MAIN SIGNAL" mode for "A/T". Refer to [AT-90, "CONSULT-II REFERENCE VALUE"](#) .

Does it lock-up?

YES >> GO TO 7.

NO >> Enter a check mark at [AT-209, "A/T Does Not Lock-up"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

7. CHECK LOCK-UP HOLD

Check hold lock-up.

Ⓟ **With CONSULT-II**

Select "TCC SOLENOID" with the "MAIN SIGNAL" mode for "A/T". Refer to [AT-90, "CONSULT-II REFERENCE VALUE"](#) .

Does it maintain lock-up status?

YES >> GO TO 8.

NO >> Enter a check mark at [AT-210, "A/T Does Not Hold Lock-up Condition"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

8. CHECK LOCK-UP RELEASE

Check lock-up cancellation by depressing brake pedal lightly to decelerate.

Ⓟ **With CONSULT-II**

Select "TCC SOLENOID" with the "MAIN SIGNAL" mode for A/T. Refer to [AT-90, "CONSULT-II REFERENCE VALUE"](#) .

Does lock-up cancel?

YES >> GO TO 9.

NO >> Enter a check mark at [AT-212, "Lock-up Is Not Released"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

9. CHECK SHIFT-DOWN D5 → D4

Decelerate by pressing lightly on the brake pedal.

Ⓟ **With CONSULT-II**

Read the gear position and engine speed. Refer to [AT-96, "DATA MONITOR MODE"](#) .

When the A/T shift-down D5 → D4, does the engine speed drop smoothly back to idle?

YES >> 1. Stop the vehicle.

2. Go to [AT-61, "Cruise Test - Part 2"](#) .

NO >> Enter a check mark at [AT-212, "Engine Speed Does Not Return to Idle"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test. Go to [AT-61, "Cruise Test - Part 2"](#) .

TROUBLE DIAGNOSIS

Cruise Test - Part 2

NCS001KB

1. CHECK STARTING FROM D1

1. Move selector lever to "D" position.
2. Accelerate at half throttle.

With CONSULT-II

Read the gear position. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does it start from D1?

YES >> GO TO 2.

NO >> Enter a check mark at [AT-199, "Vehicle Cannot Be Started from D1"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

2. CHECK SHIFT-UP D1 → D2

Press the accelerator pedal down all the way and inspect whether or not the A/T shifts up (D1 → D2) at the correct speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#).

With CONSULT-II

Read the gear position, throttle position and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D1 → D2 at the correct speed?

YES >> GO TO 3.

NO >> Enter a check mark at [AT-201, "A/T Does Not Shift: D1 → D2"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

3. CHECK SHIFT-UP D2 → D3

Press the accelerator pedal down all the way and inspect whether or not the A/T shifts up (D2 → D3) at the correct speed. Refer to [AT-63, "Vehicle Speed at Which Gear Shifting Occurs"](#).

With CONSULT-II

Read the gear position, throttle position and vehicle speed. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D2 → D3 at the correct speed?

YES >> GO TO 4.

NO >> Enter a check mark at [AT-203, "A/T Does Not Shift: D2 → D3"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test.

4. CHECK SHIFT-UP D3 → D4 AND ENGINE BRAKE

When the A/T changes speed D3 → D4, return the accelerator pedal.

With CONSULT-II

Read the gear position. Refer to [AT-96, "DATA MONITOR MODE"](#).

Does the A/T shift-up D3 → D4 and apply the engine brake?

YES >> 1. Stop the vehicle.

2. Go to [AT-61, "Cruise Test - Part 3"](#).

NO >> Enter a check mark at [AT-205, "A/T Does Not Shift: D3 → D4"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#), then continue the road test. Go to [AT-61, "Cruise Test - Part 3"](#).

Cruise Test - Part 3

NCS001KC

1. MANUAL MODE FUNCTION

Move to manual mode from "D" position.

Does it switch to manual mode?

YES >> GO TO 2.

NO >> Continue road test and add check mark to [AT-213, "Cannot Be Changed to Manual Mode"](#) on [AT-48, "DIAGNOSTIC WORKSHEET"](#).

TROUBLE DIAGNOSIS

2. CHECK SHIFT-DOWN

During manual mode driving, is downshift from M5 → M4 → M3 → M2 → M1 performed?

④ **With CONSULT-II**

Read the gear position. Refer to [AT-96, "DATA MONITOR MODE"](#) .

Is downshifting correctly performed?

YES >> GO TO 2.

NO >> Enter a check mark at "A/T Does Not Shift" at the corresponding position (5th → 4th, 4th → 3rd, 3rd → 2nd, 2nd → 1st) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue the road test.

3. CHECK ENGINE BRAKE

Check engine brake.

Does engine braking effectively reduce speed in M1 position?

YES >> 1. Stop the vehicle.

2. Perform self-diagnostics. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

NO >> Enter a check mark at [AT-220, "Vehicle Does Not Decelerate by Engine Brake"](#) on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) , then continue trouble diagnosis.

TROUBLE DIAGNOSIS

Vehicle Speed at Which Gear Shifting Occurs

NCS001KD

2WD MODELS

Engine model	VQ35DE							
Throttle position	Vehicle speed km/h (MPH)							
	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	52 - 56 (32 - 35)	85 - 93 (53 - 58)	126 - 136 (78 - 85)	195 - 205 (121 - 127)	191 - 201 (119 - 125)	113- 123 (70 - 76)	70 - 78 (44 - 48)	28 - 32 (17 - 20)
Half throttle	42 - 46 (26 - 29)	70 - 76 (44 - 47)	107 - 115 (67 - 71)	140 - 148 (87 - 92)	111 - 119 (69 - 74)	67 - 75 (42 - 47)	35 - 41 (22 - 25)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

Engine model	VK45DE							
Throttle position	Vehicle speed km/h (MPH)							
	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	56 - 60 (35 - 37)	89 - 97 (55 - 60)	121 - 131 (75 - 81)	206 - 216 (128 - 134)	202 - 212 (126 - 132)	121 - 131 (75 - 81)	73 - 81 (45 - 50)	30 - 34 (19 - 21)
Half throttle	48 - 52 (30 - 32)	82 - 88 (51 - 55)	126 - 134 (78 - 83)	155 - 163 (96 - 101)	128 - 136 (80 - 85)	70 - 78 (43 - 48)	29 - 35 (18 - 22)	9 - 13 (6 - 8)

- At half throttle, the accelerator opening is 4/8 of the full opening.

AWD MODELS

Engine model	VQ35DE							
Throttle position	Vehicle speed km/h (MPH)							
	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	50 - 54 (31 - 34)	81 - 89 (50 - 55)	120 - 130 (75 - 81)	187 - 197 (116 - 122)	183 - 193 (114 - 120)	108 - 118 (67 - 73)	66 - 74 (41 - 46)	27 - 31 (17 - 19)
Half throttle	40 - 44 (25 - 27)	67 - 73 (42 - 45)	102 - 110 (63 - 68)	133 - 141 (83 - 88)	106 - 114 (66 - 71)	64 - 72 (40 - 45)	33 - 39 (21 - 24)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

Vehicle Speed at Which Lock-Up Occurs/Releases

NCS001KE

2WD MODELS

Engine model	VQ35DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	53 - 61 (33 - 38)	50 - 58 (31 - 36)
Half throttle	196 - 204 (122 - 127)	138 - 146 (86 - 91)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

Engine model	VK45DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	67 - 75 (42 - 47)	50 - 58 (31 - 36)
Half throttle	181 - 189 (112 - 117)	160 - 168 (99 - 104)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

TROUBLE DIAGNOSIS

AWD MODELS

Engine model	VQ35DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	51 - 59 (32 - 37)	48 - 56 (30 - 35)
Half throttle	188 - 196 (117 - 122)	132 - 140 (82 - 87)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

Symptom Chart

NCS001KF

- The diagnostics item numbers show the sequence for inspection. Inspect in order from item 1.
- Overhaul and inspection inside the A/T only if A/T fluid condition is NG. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
1	Shift Shock	Large shock. ("N" → "D" position) Refer to AT-193, "Large Shock ("N" to "D" Position)" .	ON vehicle	1. Engine idle speed	EC-83 (for VQ35DE engine), EC-785 (for VK45DE engine)
				2. Engine speed signal	AT-124
				3. Accelerator pedal position sensor	AT-132
				4. A/T position	AT-227
				5. A/T fluid temperature sensor	AT-135
				6. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				7. CAN communication line	AT-105
				8. A/T fluid level and state	AT-53
				9. Line pressure test	AT-55
				10. Control valve with TCM	AT-236
			OFF vehicle	11. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
2		Shock is too large when changing D1 → D2 or M1 → M2 .	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				4. CAN communication line	AT-105
				5. Engine speed signal	AT-124
				6. Turbine revolution sensor	AT-117
				7. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				8. A/T fluid level and state	AT-53
				9. Control valve with TCM	AT-236
			OFF vehicle	10. Direct clutch	AT-341
3	Shift Shock	Shock is too large when changing D2 → D3 or M2 → M3 .	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178, AT-159
				4. CAN communication line	AT-105
				5. Engine speed signal	AT-124
				6. Turbine revolution sensor	AT-117
				7. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				8. A/T fluid level and state	AT-53
				9. Control valve with TCM	AT-236
			OFF vehicle	10. High and low reverse clutch	AT-339
4		Shock is too large when changing D3 → D4 or M3 → M4 .	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. ATF pressure switch 3 and input clutch solenoid valve	AT-174, AT-147
				4. CAN communication line	AT-105
				5. Engine speed signal	AT-124
				6. Turbine revolution sensor	AT-117
				7. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				8. A/T fluid level and state	AT-53
				9. Control valve with TCM	AT-236
			OFF vehicle	10. Input clutch	AT-327

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
5		Shock is too large when changing D4 → D5 or M4 → M5 .	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. CAN communication line	AT-105
				5. Engine speed signal	AT-124
				6. Turbine revolution sensor	AT-117
				7. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				8. A/T fluid level and state	AT-53
				9. Control valve with TCM	AT-236
			OFF vehicle	10. Front brake (brake band)	AT-301
				11. Input clutch	AT-327
6	Shift Shock	Shock is too large for downshift when accelerator pedal is pressed.	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. CAN communication line	AT-105
				4. Engine speed signal	AT-124
				5. Turbine revolution sensor	AT-117
				6. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				7. A/T fluid level and state	AT-53
				8. Control valve with TCM	AT-236
			OFF vehicle	9. Front brake (brake band)	AT-301
				10. Input clutch	AT-327
				11. High and low reverse clutch	AT-339
				12. Direct clutch	AT-341
7		Shock is too large for upshift when accelerator pedal is released.	ON vehicle	1. Accelerator pedal position sensor	AT-132
				2. A/T position	AT-227
				3. Engine speed signal	AT-124
				4. CAN communication line	AT-105
				5. Turbine revolution sensor	AT-117
				6. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				7. A/T fluid level and state	AT-53
				8. Control valve with TCM	AT-236
			OFF vehicle	9. Front brake (brake band)	AT-301
				10. Input clutch	AT-327
				11. High and low reverse clutch	AT-339
				12. Direct clutch	AT-341

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page			
8	Shift Shock	Shock is too large for lock-up.	ON vehicle	1. Accelerator pedal position sensor	AT-132			
				2. A/T position	AT-227			
				3. Engine speed signal	AT-124			
				4. CAN communication line	AT-105			
				5. Turbine revolution sensor	AT-117			
				6. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140			
				7. Torque converter clutch solenoid valve	AT-126			
				8. A/T fluid level and state	AT-53			
				9. Control valve with TCM	AT-236			
			OFF vehicle	10. Torque converter	AT-301			
9		Shock is too large during engine brake.	ON vehicle	1. Accelerator pedal position sensor	AT-132			
				2. A/T position	AT-227			
				3. CAN communication line	AT-105			
				4. A/T fluid level and state	AT-53			
				5. Control valve with TCM	AT-236			
			OFF vehicle	6. Front brake (brake band)	AT-301			
				7. Input clutch	AT-327			
				8. High and low reverse clutch	AT-339			
				9. Direct clutch	AT-341			
10	No Up Shift	Gear does not change from D1 → D2 or from M1 → M2 . Refer to AT-201, "A/T Does Not Shift: D1 → D2" .	ON vehicle	1. A/T fluid level and state	AT-53			
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140			
				3. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155			
				4. Line pressure test	AT-55			
				5. CAN communication line	AT-105			
				6. Control valve with TCM	AT-236			
			OFF vehicle	7. Direct clutch	AT-341			
			11		Gear does not change from D2 → D3 or from M2 → M3 . Refer to AT-203, "A/T Does Not Shift: D2 → D3" .	ON vehicle	1. A/T fluid level and state	AT-53
							2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
							3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178, AT-159
							4. Line pressure test	AT-55
							5. CAN communication line	AT-105
							6. Control valve with TCM	AT-236
OFF vehicle	7. High and low reverse clutch	AT-339						

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
12		Gear does not change from D3 → D4 or from M3 → M4 . Refer to AT-205, "A/T Does Not Shift: D3 → D4" .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 3 and input clutch solenoid valve	AT-174, AT-147
				4. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				5. Line pressure test	AT-55
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Input clutch	AT-327
13	No Up Shift	Gear does not change from D4 → D5 or from M4 → M5 . Refer to AT-207, "A/T Does Not Shift: D4 → D5" .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				5. Turbine revolution sensor	AT-117
				6. Line pressure test	AT-55
				7. CAN communication line	AT-105
				8. Control valve with TCM	AT-236
			OFF vehicle	9. Front brake (brake band)	AT-301
				10. Input clutch	AT-327
14	No Down Shift	In "D" or "M" position, does not downshift to 4th gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
				9. Input clutch	AT-327

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
15		In "D" or "M" position, does not downshift to 3rd gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 3 and input clutch solenoid valve	AT-174, AT-147
				4. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Input clutch	AT-327
16	No Down Shift	In "D" or "M" position, does not downshift to 2nd gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178, AT-159
				4. CAN communication line	AT-105
				5. Line pressure test	AT-55
				6. Control valve with TCM	AT-236
			OFF vehicle	7. High and low reverse clutch	AT-339
17		In "D" or "M" position, does not downshift to 1st gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				4. CAN communication line	AT-105
				5. Line pressure test	AT-55
				6. Control valve with TCM	AT-236
				OFF vehicle	7. Direct clutch

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
18	Slips/Will Not Engage	When "D" or "M" position, remains in 1st gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. Direct clutch solenoid valve	AT-155
				4. Line pressure test	AT-55
				5. CAN communication line	AT-105
				6. Control valve with TCM	AT-236
			OFF vehicle	7. 3rd one-way clutch	AT-325
				8. 1st one-way clutch	AT-333
				9. Gear system	AT-281
				10. Reverse brake	AT-301
				11. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
				12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
19		When "D" or "M" position, remains in 2nd gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. Low coast brake solenoid valve	AT-163
				4. Line pressure test	AT-55
				5. CAN communication line	AT-105
				6. Control valve with TCM	AT-236
			OFF vehicle	7. 3rd one-way clutch	AT-325
				8. Gear system	AT-281
				9. Direct clutch	AT-341
				10. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
20	Slips/Will Not Engage	When "D" or "M" position, remains in 3rd gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. Line pressure test	AT-55
				4. CAN communication line	AT-105
				5. Control valve with TCM	AT-236
			OFF vehicle	6. 3rd one-way clutch	AT-325
				7. Gear system	AT-281
				8. High and low reverse clutch	AT-339
				9. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301
				10. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301
21	Slips/Will Not Engage	When "D" or "M" position, remains in 4th gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 3 and input clutch solenoid valve	AT-174, AT-147
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				5. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178, AT-159
				6. Low coast brake solenoid valve	AT-163
				7. Front brake solenoid valve	AT-151
				8. Line pressure test	AT-55
				9. CAN communication line	AT-105
				10. Control valve with TCM	AT-236
			OFF vehicle	11. Input clutch	AT-327
				12. Gear system	AT-281
				13. High and low reverse clutch	AT-339
				14. Direct clutch	AT-341

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
22		When "D" or "M" position, remains in 5th gear.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172 , AT-151
				4. Line pressure test	AT-55
				5. CAN communication line	AT-105
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Front brake (brake band)	AT-301
				8. Input clutch	AT-327
				9. Gear system	AT-281
				10. High and low reverse clutch	AT-339
23	Slips/Will Not Engage	Vehicle cannot be started from D1 . Refer to AT-199 . " Vehicle Cannot Be Started from D1 ".	ON vehicle	1. A/T fluid level and state	AT-53
				2. Accelerator pedal position sensor	AT-132
				3. Line pressure test	AT-55
				4. CAN communication line	AT-105
				5. Control valve with TCM	AT-236
			OFF vehicle	6. Torque converter	AT-301
				7. Oil pump assembly	AT-322
				8. 3rd one-way clutch	AT-325
				9. 1st one-way clutch	AT-333
				10. Gear system	AT-281
				11. Reverse brake	AT-301
				12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
				13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
24		Does not lock-up. Refer to AT-209 , " A/T Does Not Lock-up ".	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Engine speed signal	AT-124
				4. Turbine revolution sensor	AT-117
				5. Torque converter clutch solenoid valve	AT-126
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
25		Does not hold lock-up condition. Refer to AT-210, "A/T Does Not Hold Lock-up Condition" .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Engine speed signal	AT-124
				4. Turbine revolution sensor	AT-117
				5. Torque converter clutch solenoid valve	AT-126
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
26	Slips/Will Not Engage	Lock-up is not released. Refer to AT-212, "Lock-up Is Not Released" .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Engine speed signal	AT-124
				4. Turbine revolution sensor	AT-117
				5. Torque converter clutch solenoid valve	AT-126
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
27		No shock at all or the clutch slips when vehicle changes speed D1 → D2 or M1 → M2 .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				4. CAN communication line	AT-105
				5. Line pressure test	AT-55
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. 3rd one-way clutch	AT-325
				10. Gear system	AT-281
				11. Direct clutch	AT-341
				12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
28	Slips/Will Not Engage	No shock at all or the clutch slips when vehicle changes speed D2 → D3 or M2 → M3 .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178 , AT-159
				4. CAN communication line	AT-105
				5. Line pressure test	AT-55
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. 3rd one-way clutch	AT-325
				10. Gear system	AT-281
				11. High and low reverse clutch	AT-339
				12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
				13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
29	No shock at all or the clutch slips when vehicle changes speed D3 → D4 or M3 → M4 .	ON vehicle	1. A/T fluid level and state	AT-53	
			2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140	
			3. ATF pressure switch 3 and input clutch solenoid valve	AT-174 , AT-147	
			4. ATF pressure switch 1 and front brake solenoid valve	AT-172 , AT-151	
			5. CAN communication line	AT-105	
			6. Line pressure test	AT-55	
			7. Control valve with TCM	AT-236	
		OFF vehicle	8. Torque converter	AT-301	
			9. Oil pump assembly	AT-322	
			10. Input clutch	AT-327	
			11. Gear system	AT-281	
			12. High and low reverse clutch	AT-339	
			13. Direct clutch	AT-341	

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
30	Slips/Will Not Engage	No shock at all or the clutch slips when vehicle changes speed D4 → D5 or M4 → M5 .	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
				10. Front brake (brake band)	AT-301
				11. Input clutch	AT-327
				12. Gear system	AT-281
				13. High and low reverse clutch	AT-339
31	Slips/Will Not Engage	When you press the accelerator pedal and shift speed D5 → D4 or M5 → M4 the engine idles or the A/T slips.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
				10. Input clutch	AT-327
				11. Gear system	AT-281
				12. High and low reverse clutch	AT-339
				13. Direct clutch	AT-341

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
32	Slips/Will Not Engage	When you press the accelerator pedal and shift speed D4 → D3 or M4 → M3 the engine idles or the A/T slips.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. ATF pressure switch 3 and input clutch solenoid valve	AT-174 , AT-147
				4. ATF pressure switch 1 and front brake solenoid valve	AT-172 , AT-151
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
				10. 3rd one-way clutch	AT-325
				11. Gear system	AT-281
				12. High and low reverse clutch	AT-339
				13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301				
33		When you press the accelerator pedal and shift speed D3 → D2 or M3 → M2 the engine idles or the A/T slips.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178 , AT-159
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176 , AT-155
				5. CAN communication line	AT-105
				6. Line pressure test	AT-55
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
				10. 3rd one-way clutch	AT-325
				11. Gear system	
				12. Direct clutch	AT-341
				13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
34	Slips/Will Not Engage	When you press the accelerator pedal and shift speed D2 → D1 or M2 → M1 the engine idles or the A/T slips.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				3. ATF pressure switch 5 and direct clutch solenoid valve	AT-176 , AT-155
				4. CAN communication line	AT-105
				5. Line pressure test	AT-55
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. 3rd one-way clutch	AT-325
				10. 1st one-way clutch	AT-333
				11. Gear system	AT-281
				12. Reverse brake	AT-301
				13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
				14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
35	With selector lever in "D" position, acceleration is extremely poor.		ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. PNP switch	AT-113
				6. A/T position	AT-227
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322
				10. 1st one-way clutch	AT-333
				11. Gear system	AT-281
				12. Reverse brake	AT-301
				13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
				14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
36		With selector lever in "R" position, acceleration is extremely poor.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178 , AT-159
				5. CAN communication line	AT-105
				6. PNP switch	AT-113
				7. A/T position	AT-227
				8. Control valve with TCM	AT-236
			OFF vehicle	9. Gear system	AT-281
				10. Output shaft	AT-301
				11. Reverse brake	AT-301
37	Slips/Will Not Engage	While starting off by accelerating in 1st, engine races or slippage occurs.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. Control valve with TCM	AT-236
			OFF vehicle	6. Torque converter	AT-301
				7. Oil pump assembly	AT-322
				8. 3rd one-way clutch	AT-325
				9. 1st one-way clutch	AT-333
				10. Gear system	AT-281
				11. Reverse brake	AT-301
				12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
				13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
38		While accelerating in 2nd, engine races or slippage occurs.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. 3rd one-way clutch	AT-325
				10. Gear system	AT-281
				11. Direct clutch	AT-341
				12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18, " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19, " Cross-Sectional View (AWD Models) ".)	AT-301
39	Slips/Will Not Engage	While accelerating in 3rd, engine races or slippage occurs.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. ATF pressure switch 6, high and low reverse clutch solenoid valve	AT-178, AT-159
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. 3rd one-way clutch	AT-325
				10. Gear system	AT-281
				11. High and low reverse clutch	AT-339
				12. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18, " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19, " Cross-Sectional View (AWD Models) ".)	AT-301
				13. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18, " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19, " Cross-Sectional View (AWD Models) ".)	AT-301

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
40		While accelerating in 4th, engine races or slippage occurs.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. ATF pressure switch 3 and input clutch solenoid valve	AT-174, AT-147
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. Input clutch	AT-327
				10. Gear system	AT-281
				11. High and low reverse clutch	AT-339
				12. Direct clutch	AT-341
41	Slips/Will Not Engage	While accelerating in 5th, engine races or slippage occurs.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. Front brake (brake band)	AT-301
				10. Input clutch	AT-327
				11. Gear system	AT-281
				12. High and low reverse clutch	AT-339
42		Slips at lock-up.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Engine speed signal	AT-124
				4. Turbine revolution sensor	AT-117
				5. Torque converter clutch solenoid valve	AT-126
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Torque converter	AT-301
				9. Oil pump assembly	AT-322

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
43	Slips/Will Not Engage	No creep at all. Refer to AT-195 , " Vehicle Does Not Creep Backward in "R" Position ", AT-197 , " Vehicle Does Not Creep Forward in "D" Position ".	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. ATF pressure switch 5 and direct clutch solenoid valve	AT-176 , AT-155
				5. PNP switch	AT-113
				6. CAN communication line	AT-105
				7. A/T position	AT-227
				8. Control valve with TCM	AT-236
			OFF vehicle	9. Torque converter	AT-301
				10. Oil pump assembly	AT-322
				11. 1st one-way clutch	AT-333
				12. Gear system	AT-281
				13. Reverse brake	AT-301
				14. Direct clutch	AT-341
				15. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
				16. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
44	Vehicle cannot run in all positions.	ON vehicle	1. A/T fluid level and state	AT-53	
			2. Line pressure test	AT-55	
			3. PNP switch	AT-113	
			4. A/T position	AT-227	
			5. Control valve with TCM	AT-236	
		OFF vehicle	6. Oil pump assembly	AT-322	
			7. Gear system	AT-281	
			8. Output shaft	AT-301	

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
45	Slips/Will Not Engage	With selector lever in "D" position, driving is not possible.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. PNP switch	AT-113
				4. A/T position	AT-227
				5. Control valve with TCM	AT-236
			OFF vehicle	6. Torque converter	AT-301
				7. Oil pump assembly	AT-322
				8. 1st one-way clutch	AT-333
				9. Gear system	AT-281
				10. Reverse brake	AT-301
				11. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
				12. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) " .)	AT-301
46		With selector lever in "R" position, driving is not possible.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. PNP switch	AT-113
				4. A/T position	AT-227
				5. Control valve with TCM	AT-236
			OFF vehicle	6. Gear system	AT-281
				7. Output shaft	AT-301
				8. Reverse brake	AT-301
47	Does Not Change	Does not change M5 → M4. Refer to AT-214 , " A/T Does Not Shift: 5th Gear → 4th Gear ".	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 1	AT-172
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
48		Does not change M4 → M3. Refer to AT-215, "A/T Does Not Shift: 4th Gear → 3rd Gear" .	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 1 and ATF pressure switch 3	AT-172, AT-174
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
	OFF vehicle		8. Front brake (brake band)	AT-301	
			9. Input clutch	AT-327	
49	Does Not Change	Does not change M3 → M2. Refer to AT-217, "A/T Does Not Shift: 3rd Gear → 2nd Gear" .	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 6	AT-178
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
				9. Input clutch	AT-327
				10. High and low reverse clutch	AT-339
50		Does not change M2 → M1. Refer to AT-218, "A/T Does Not Shift: 2nd Gear → 1st Gear" .	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 5	AT-176
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Input clutch	AT-327
				9. High and low reverse clutch	AT-339
				10. Direct clutch	AT-341
51		Cannot be changed to manual mode. Refer to AT-213, "Cannot Be Changed to Manual Mode" .	ON vehicle	1. Manual mode switch	AT-167
				2. Turbine revolution sensor	AT-117
				3. CAN communication line	AT-105
52	Others	Shift point is high in "D" position.	ON vehicle	1. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				2. Accelerator pedal position sensor	AT-132
				3. CAN communication line	AT-105
				4. A/T fluid temperature sensor	AT-135
				5. Control valve with TCM	AT-236

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
53		Shift point is low in "D" position.	ON vehicle	1. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				2. Accelerator pedal position sensor	AT-132
				3. CAN communication line	AT-105
				4. Control valve with TCM	AT-236
54		Judder occurs during lock-up.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. Turbine revolution sensor	AT-117
				4. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119 , AT-140
				5. Accelerator pedal position sensor	AT-132
				6. CAN communication line	AT-105
				7. Torque converter clutch solenoid valve	AT-126
			8. Control valve with TCM	AT-236	
OFF vehicle	9. Torque converter	AT-301			
55	Others	Strange noise in "R" position.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. CAN communication line	AT-105
				4. Control valve with TCM	AT-236
			OFF vehicle	5. Torque converter	AT-301
				6. Oil pump assembly	AT-322
				7. Gear system	AT-281
				8. High and low reverse clutch	AT-339
				9. Reverse brake	AT-301
56		Strange noise in "N" position.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. CAN communication line	AT-105
				4. Control valve with TCM	AT-236
			OFF vehicle	5. Torque converter	AT-301
				6. Oil pump assembly	AT-322
				7. Gear system	AT-281

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
57		Strange noise in "D" position.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. CAN communication line	AT-105
				4. Control valve with TCM	AT-236
			OFF vehicle	5. Torque converter	AT-301
				6. Oil pump assembly	AT-322
				7. Gear system	AT-281
			8. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18 , "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19 , "Cross-Sectional View (AWD Models)" .)	AT-301	
58	Others	Vehicle dose not decelerate by engine brake. Refer to AT-220 , "Vehicle Does Not Decelerate by Engine Brake" .	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 5	AT-176
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Input clutch	AT-327
				9. High and low reverse clutch	AT-339
				10. Direct clutch	AT-341
59		Engine brake does not work M5 → M4.	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 1	AT-172
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
60		Engine brake does not work M4 → M3.	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 1 and ATF pressure switch 3	AT-172 , AT-174
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
				9. Input clutch	AT-327

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
61		Engine brake does not work M3 → M2.	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 6	AT-178
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
				9. Input clutch	AT-327
				10. High and low reverse clutch	AT-339
62	Others	Engine brake does not work M2 → M1.	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Manual mode switch	AT-167
				5. ATF pressure switch 5	AT-176
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Input clutch	AT-327
				9. High and low reverse clutch	AT-339
				10. Direct clutch	AT-341
63	Others	Maximum speed low.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Line pressure test	AT-55
				3. Accelerator pedal position sensor	AT-132
				4. CAN communication line	AT-105
				5. Direct clutch solenoid valve	AT-155
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
				8. Oil pump assembly	AT-322
				9. Input clutch	AT-327
				10. Gear system	AT-281
				11. High and low reverse clutch	AT-339
				12. Direct clutch	AT-341
				13. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301
				14. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17 , " Cross-Sectional View (VQ35DE Models for 2WD) ", AT-18 , " Cross-Sectional View (VK45DE Models for 2WD) " or AT-19 , " Cross-Sectional View (AWD Models) ".)	AT-301

TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
64		Extremely large creep.	ON vehicle	1. Engine idle speed	EC-83 (for VQ35DE engine), EC-785 (for VK45DE engine)
				2. CAN communication line	AT-105
				3. ATF pressure switch 5	AT-176
			OFF vehicle	4. Torque converter	AT-301
65	Others	With selector lever in "P" position, vehicle does not enter parking condition or, with selector lever in another position, parking condition is not cancelled. Refer to AT-191, "In "P" Position, Vehicle Moves When Pushed"	ON vehicle	1. PNP switch	AT-113
			ON vehicle	2. A/T position	AT-227
			OFF vehicle	3. Parking components	AT-250 (2WD models) or AT-301 (AWD models)
66	Others	Vehicle runs with A/T in "P" position.	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Control valve with TCM	AT-236
			OFF vehicle	5. Parking components	AT-250 (2WD models) or AT-301 (AWD models)
				6. Gear system	AT-281
67	Others	Vehicle runs with A/T in "N" position. Refer to AT-192, "In "N" Position, Vehicle Moves"	ON vehicle	1. PNP switch	AT-113
				2. A/T fluid level and state	AT-53
				3. A/T position	AT-227
				4. Control valve with TCM	AT-236
			OFF vehicle	5. Input clutch	AT-327
				6. Gear system	AT-281
				7. Direct clutch	AT-341
				8. Reverse brake	AT-301
				9. Forward one-way clutch (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301
				10. Forward brake (Parts behind drum support is impossible to perform inspection by disassembly. Refer to AT-17, "Cross-Sectional View (VQ35DE Models for 2WD)" , AT-18, "Cross-Sectional View (VK45DE Models for 2WD)" or AT-19, "Cross-Sectional View (AWD Models)" .)	AT-301


TROUBLE DIAGNOSIS

No.	Item	Symptom	Condition	Diagnostic Item	Reference page
68		Engine does not start in "N" or "P" position. Refer to AT-190 . " Engine Cannot Be Started in "P" or "N" Position ".	ON vehicle	1. Push-button ignition switch and starter	PG-3, SC-8
				2. A/T position	AT-227
				3. PNP switch	AT-113
69		Engine starts in positions other than "N" or "P".	ON vehicle	1. Push-button ignition switch and starter	PG-3, SC-8
				2. A/T position	AT-227
				3. PNP switch	AT-113
70		Engine stall.	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. Turbine revolution sensor	AT-117
				4. Torque converter clutch solenoid valve	AT-126
				5. CAN communication line	AT-105
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
71	Others	Engine stalls when selector lever shifted "N" → "D" or "R".	ON vehicle	1. A/T fluid level and state	AT-53
				2. Engine speed signal	AT-124
				3. Turbine revolution sensor	AT-117
				4. Torque converter clutch solenoid valve	AT-126
				5. CAN communication line	AT-105
				6. Control valve with TCM	AT-236
			OFF vehicle	7. Torque converter	AT-301
72		Engine speed does not return to idle. Refer to AT-212 . " Engine Speed Does Not Return to Idle ".	ON vehicle	1. A/T fluid level and state	AT-53
				2. ATF pressure switch 5 and direct clutch solenoid valve	AT-176, AT-155
				3. ATF pressure switch 1 and front brake solenoid valve	AT-172, AT-151
				4. Accelerator pedal position sensor	AT-132
				5. Vehicle speed sensor-A/T and vehicle speed sensor-MTR	AT-119, AT-140
				6. CAN communication line	AT-105
				7. Control valve with TCM	AT-236
			OFF vehicle	8. Front brake (brake band)	AT-301
				9. Direct clutch	AT-341

TROUBLE DIAGNOSIS





TCM Input/Output Signal Reference Values A/T ASSEMBLY HARNESS CONNECTOR TERMINAL LAYOUT

NCS001KG



TCM INSPECTION TABLE

Data are reference value and are measured between each terminal and ground.

Terminal	Wire color	Item		Condition	Data (Approx.)
1	R/W	Power supply (Memory back-up)		Always	Battery voltage
2	R/W	Power supply (Memory back-up)		Always	Battery voltage
3	L	CAN-H		-	-
4	V	K-line (CONSULT-II signal)		The terminal is connected to the data link connector for CONSULT-II.	-
5	B	Ground		Always	0 V
6	Y/R	Power supply		-	Battery voltage
				-	0 V
7	R/L	Back-up lamp relay		Selector lever in "R" position.	0 V
				Selector lever in other positions.	Battery voltage
8	P	CAN-L		-	-
9	GR/R	Starter relay		Selector lever in "N", "P" positions.	Battery voltage
				Selector lever in "R", "D" positions.	0 V
10	B	Ground		Always	0 V

TROUBLE DIAGNOSIS

CONSULT-II Function (A/T)

NCS001KH

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

FUNCTION

Diagnostic test mode	Function	Reference page
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	AT-92
Data monitor	Input/Output data in the ECU can be read.	AT-96
CAN diagnostic support monitor	The results of transmit/receive diagnosis of CAN communication can be read.	AT-100
Function test	Performed by CONSULT-II instead of a technician to determine whether each system is "OK" or "NG".	—
DTC work support	Select the operating condition to confirm Diagnostic Trouble Codes.	AT-100
ECU part number	ECU part number can be read.	—

CONSULT-II REFERENCE VALUE

NOTICE:

- The CONSULT-II electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).
Check for time difference between actual shift timing and the CONSULT-II display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- Shift schedule (which implies gear position) displayed on CONSULT-II and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
 - Actual shift schedule has more or less tolerance or allowance,
 - Shift schedule indicated in Service Manual refers to the point where shifts start, and
 - Gear position displayed on CONSULT-II indicates the point where shifts are completed.
- Display of solenoid valves on CONSULT-II changes at the start of shifting, while gear position is displayed upon completion of shifting (which is computed by TCM).

Item name	Condition	Display value (Approx.)
VHCL/S SE-A/T	During driving	Approximately matches the speed meter reading.
VHCL/S SE-MTR		
ACCELE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8.0/8
CLSD THL POS	Released accelerator pedal.	ON
	Fully depressed accelerator pedal.	OFF
W/O THL POS	Fully depressed accelerator pedal.	ON
	Released accelerator pedal.	OFF
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF
ENGINE SPEED	Engine running	Closely matches the tachometer reading.
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.
ATF TEMP SE 1	0°C (32° F) - 20°C (68°F) - 80°C (176°F)	3.3 - 2.7 - 0.9 V
ATF TEMP SE 2		3.3 - 2.5 - 0.7 V
TCC SOLENOID	Lock-up is active	0.4 - 0.6 A
LINE PRES SOL	During driving	0.2 - 0.6 A

TROUBLE DIAGNOSIS

Item name	Condition	Display value (Approx.)	
FR/B SOLENOID	Front brake engaged. Refer to AT-21 .	0.6 - 0.8 A	A
	Front brake disengaged. Refer to AT-21 .	0 - 0.05 A	B
I/C SOLENOID	Input clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A	B
	Input clutch engaged. Refer to AT-21 .	0 - 0.05 A	
D/C SOLENOID	Direct clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A	AT
	Direct clutch engaged. Refer to AT-21 .	0 - 0.05 A	
HLR/C SOL	High and low reverse clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A	D
	High and low reverse clutch engaged. Refer to AT-21 .	0 - 0.05 A	
STARTER RELAY	Selector lever in "N", "P" positions.	ON	E
	Selector lever in "R", "D" positions.	OFF	
SLCT LVR POSI	Selector lever in "N", "P" positions.	N/P	F
	Selector lever in "R" position.	R	
	Selector lever in "D" position.	D	
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON	G
	Low coast brake disengaged. Refer to AT-21 .	OFF	
ATF PRES SW 1	Front brake engaged. Refer to AT-21 .	ON	H
	Front brake disengaged. Refer to AT-21 .	OFF	
ATF PRES SW 2	Low coast brake engaged. Refer to AT-21 .	ON	I
	Low coast brake disengaged. Refer to AT-21 .	OFF	
ATF PRES SW 3	Input clutch engaged. Refer to AT-21 .	ON	J
	Input clutch disengaged. Refer to AT-21 .	OFF	
ATF PRES SW 5	Direct clutch engaged. Refer to AT-21 .	ON	K
	Direct clutch disengaged. Refer to AT-21 .	OFF	
ATF PRES SW 6	High and low reverse clutch engaged. Refer to AT-21 .	ON	L
	High and low reverse clutch disengaged Refer to AT-21 .	OFF	
MANU MODE SW	Manual shift gate position (neutral)	ON	M
	Other than the above	OFF	
NON M-MODE SW	Manual shift gate position	OFF	
	Other than the above	ON	
UP SW LEVER	Selector lever: + side	ON	
	Other than the above	OFF	
DOWN SW LEVER	Selector lever: - side	ON	
	Other than the above	OFF	
GEAR	During driving	1, 2, 3, 4, 5	

TROUBLE DIAGNOSIS

CONSULT-II SETTING PROCEDURE


Refer to [GI-38, "CONSULT-II Start Procedure"](#) .

SELF-DIAGNOSTIC RESULT MODE

After performing self-diagnosis, place check marks for results on the [AT-48, "DIAGNOSTIC WORKSHEET"](#) . Reference pages are provided following the items.

Operation Procedure

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
Display shows malfunction experienced since the last erasing operation.



Display Items List

X: Applicable, —: Not applicable

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis	OBD-II (DTC)	Reference page
		"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST	
CAN COMM CIRCUIT	<ul style="list-style-type: none"> ● When TCM is not transmitting or receiving CAN communication signal for 2 seconds or more. 	U1000	U1000	AT-105
STARTER RELAY/CIRC	<ul style="list-style-type: none"> ● If this signal is ON other than in "P" or "N" position, this is judged to be a malfunction. (And if it is OFF in "P" or "N" position, this too is judged to be a malfunction.) 	P0615	—	AT-108
TCM	<ul style="list-style-type: none"> ● TCM is malfunctioning 	P0700	P0700	AT-112
PNP SW/CIRC	<ul style="list-style-type: none"> ● PNP switch 1-4 signals input with impossible pattern. ● "P" position is detected from "N" position without any other position being detected in between. 	P0705	P0705	AT-113
TURBINE REV S/CIRC	<ul style="list-style-type: none"> ● TCM does not receive the proper voltage signal from the sensor. ● TCM detects an irregularity only at position of 4th gear for turbine revolution sensor 2. 	P0717	P0717	AT-117
VEH SPD SEN/CIR AT	<ul style="list-style-type: none"> ● Signal from vehicle speed sensor A/T (revolution sensor) not input due to cut line or the like. ● Unexpected signal input during running. ● After ignition switch is turned ON, unexpected signal input from vehicle speed sensor MTR before the vehicle starts moving. 	P0720	P0720	AT-119
ENGINE SPEED SIG	<ul style="list-style-type: none"> ● TCM does not receive the CAN communication signal from the ECM. 	P0725	P0725*3	AT-124
TCC SOLENOID/CIRC	<ul style="list-style-type: none"> ● Normal voltage not applied to solenoid due to cut line, short, or the like. 	P0740	P0740	AT-126
A/T TCC S/V FNCTN	<ul style="list-style-type: none"> ● A/T cannot perform lock-up even if electrical circuit is good. ● TCM detects as irregular by comparing difference value with slip rotation. 	P0744	P0744*2	AT-128

TROUBLE DIAGNOSIS

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis	OBD-II (DTC)	Reference page	
		"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST		
L/PRESS SOL/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. 	P0745	P0745	AT-130	AT
TP SEN/CIRC A/T	<ul style="list-style-type: none"> TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM. 	P1705	P1705*3	AT-132	D
ATF TEMP SEN/CIRC	<ul style="list-style-type: none"> During running, the A/T fluid temperature sensor signal voltage is excessively high or low. 	P1710	P0710	AT-135	E
VEH SPD SE/CIR-MTR	<ul style="list-style-type: none"> Signal (CAN communication) from vehicle speed sensor MTR not input due to cut line or the like. Unexpected signal input during running. 	P1721	—	AT-140	F
A/T INTERLOCK	<ul style="list-style-type: none"> Except during shift change, the gear position and ATF pressure switch states are monitored and comparative judgment made. 	P1730	P1730	AT-142	G
A/T 1ST E/BRAKING	<ul style="list-style-type: none"> Each ATF pressure switch and solenoid current is monitored and if a pattern is detected having engine braking 1st gear other than in the M1 position, a malfunction is detected. 	P1731	—	AT-145	H
I/C SOLENOID/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. 	P1752	P1752	AT-147	I
I/C SOLENOID FNCTN	<ul style="list-style-type: none"> TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change.) TCM detects that relation between gear position and condition of ATF pressure switch 3 is irregular during releasing accelerator pedal. (Other than during shift change.) 	P1754	P1754*2	AT-149	J K
FR/B SOLENOID/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. 	P1757	P1757	AT-151	L M
FR/B SOLENOID FNCT	<ul style="list-style-type: none"> TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change.) TCM detects that relation between gear position and condition of ATF pressure switch 1 is irregular during releasing accelerator pedal. (Other than during shift change.) 	P1759	P1759*2	AT-153	
D/C SOLENOID/CIRC	<ul style="list-style-type: none"> Normal voltage not applied to solenoid due to cut line, short, or the like. TCM detects as irregular by comparing target value with monitor value. 	P1762	P1762	AT-155	

TROUBLE DIAGNOSIS

Items (CONSULT-II screen terms)	Malfunction is detected when...	TCM self-diagnosis	OBD-II (DTC)	Reference page
		"A/T" with CONSULT-II	MIL indicator lamp*1, "ENGINE" with CONSULT-II or GST	
D/C SOLENOID FNCTN	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change.) ● TCM detects that relation between gear position and condition of ATF pressure switch 5 is irregular during releasing accelerator pedal. (Other than during shift change.) 	P1764	P1764*2	AT-157
HLR/C SOL/CIRC	<ul style="list-style-type: none"> ● Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like. ● TCM detects as irregular by comparing target value with monitor value. 	P1767	P1767	AT-159
HLR/C SOL FNCTN	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change.) ● TCM detects that relation between gear position and condition of ATF pressure switch 6 is irregular during releasing accelerator pedal. (Other than during shift change.) 	P1769	P1769*2	AT-161
LC/B SOLENOID/CIRC	<ul style="list-style-type: none"> ● Normal voltage not applied to solenoid due to functional malfunction, cut line, short, or the like. 	P1772	P1772	AT-163
LC/B SOLENOID FNCT	<ul style="list-style-type: none"> ● TCM detects an improper voltage drop when it tries to operate the solenoid valve. ● Condition of ATF pressure switch 2 is different from monitor value, and relation between gear position and actual gear ratio is irregular. 	P1774	P1774*2	AT-165
MANU MODE SW/CIRC	<ul style="list-style-type: none"> ● When an impossible pattern of switch signals is detected, a malfunction is detected. 	P1815	—	AT-167
ATF PRES SW 1/CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change.) 	P1841	—	AT-172
ATF PRES SW 3/CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change.) 	P1843	—	AT-174
ATF PRES SW 5/CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change.) 	P1845	—	AT-176
ATF PRES SW 6/CIRC	<ul style="list-style-type: none"> ● TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change.) 	P1846	—	AT-178
NO DTC IS DETECTED FURTHER TESTING MAY BE REQUIRED	<ul style="list-style-type: none"> ● No NG item has been detected. 	X	X	—

*1: Refer to [EC-70, "Malfunction Indicator Lamp \(MIL\)"](#) (for VQ35DE engine), [EC-772, "Malfunction Indicator Lamp \(MIL\)"](#) (for VK45DE engine).

*2: These malfunctions cannot be displayed MIL if another malfunction is assigned to MIL.

TROUBLE DIAGNOSIS

*3: For VQ35DE engine.

A

B

AT

D

E

F

G

H

I

J

K


L

M


TROUBLE DIAGNOSIS

How to Erase Self-diagnostic Results

1. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.



2. Touch "ERASE". (The self-diagnostic results will be erased.)




DATA MONITOR MODE

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.

NOTE:

When malfunctions detected, CONSULT-II performs "REAL-TIME DIAGNOSIS". Also, any malfunction detected while in this mode will be displayed at real time.



Display Items List

X: Standard, —: Not applicable, ▼: Option

Monitored item (Unit)	Monitor Item Selection			Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
VHCL/S SE-A/T (km/h)	X	X	▼	Revolution sensor
VHCL/S SE-MTR (km/h)	X	—	▼	
ACCELE POSI (0.0/8)	X	—	▼	Accelerator pedal position signal
THROTTLE POSI (0.0/8)	X	X	▼	Degree of opening for accelerator recognized by the TCM. For fail-safe operation, the specific value used for control is displayed.
CLSD THL POS (ON/OFF)	X	—	▼	Signal input with CAN communications.
W/O THL POS (ON/OFF)	X	—	▼	
BRAKE SW (ON/OFF)	X	—	▼	Stop lamp switch

TROUBLE DIAGNOSIS

Monitored item (Unit)	Monitor Item Selection			Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU		
GEAR	—	X	▼	Gear position recognized by the TCM updated after gear-shifting.	A
ENGINE SPEED (rpm)	X	X	▼		AT
TURBINE REV (rpm)	X	X	▼		B
OUTPUT REV (rpm)	X	X	▼		D
GEAR RATIO	—	X	▼		
TC SLIP SPEED (rpm)	—	X	▼	Difference between engine speed and torque converter input shaft speed.	E
F SUN GR REV (rpm)	—	—	▼		
F CARR GR REV (rpm)	—	—	▼		F
ATF TEMP SE 1 (V)	X	—	▼		
ATF TEMP SE 2 (V)	X	—	▼		G
ATF TEMP 1 (°C)	—	X	▼		
ATF TEMP 2 (°C)	—	X	▼		H
BATTERY VOLT (V)	X	—	▼		
ATF PRES SW 1 (ON/OFF)	X	X	▼	(for FR/B solenoid)	I
ATF PRES SW 2 (ON/OFF)	X	X	▼	(for LC/B solenoid)	
ATF PRES SW 3 (ON/OFF)	X	X	▼	(for I/C solenoid)	J
ATF PRES SW 5 (ON/OFF)	X	X	▼	(for D/C solenoid)	
ATF PRES SW 6 (ON/OFF)	X	X	▼	(for HLR/C solenoid)	K
PNP SW 1 (ON/OFF)	X	—	▼		
PNP SW 2 (ON/OFF)	X	—	▼		L
PNP SW 3 (ON/OFF)	X	—	▼		
PNP SW 4 (ON/OFF)	X	—	▼		M
1 POSITION SW (ON/OFF)	X	—	▼		
SLCT LVR POSI	—	X	▼	Selector lever position is recognized by the TCM. For fail-safe operation, the specific value used for control is displayed.	
OD CONT SW (ON/OFF)	X	—	▼		
POWERSHIFT SW (ON/OFF)	X	—	▼	Not mounted but displayed.	
HOLD SW (ON/OFF)	X	—	▼		
MANU MODE SW (ON/OFF)	X	—	▼		
NON M-MODE SW (ON/OFF)	X	—	▼		
UP SW LEVER (ON/OFF)	X	—	▼		
DOWN SW LEVER (ON/OFF)	X	—	▼		

TROUBLE DIAGNOSIS

Monitored item (Unit)	Monitor Item Selection			Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
SFT UP ST SW (ON/OFF)	—	—	▼	Not mounted but displayed.
SFT DWN ST SW (ON/OFF)	—	—	▼	
ASCD-OD CUT (ON/OFF)	—	—	▼	
ASCD-CRUISE (ON/OFF)	—	—	▼	
ABS SIGNAL (ON/OFF)	—	—	▼	
ACC OD CUT (ON/OFF)	—	—	▼	Intelligent cruise control (ICC) system
ACC SIGNAL (ON/OFF)	—	—	▼	
TCS GR/P KEEP (ON/OFF)	—	—	▼	
TCS SIGNAL 2 (ON/OFF)	—	—	▼	
TCS SIGNAL 1 (ON/OFF)	—	—	▼	
TCC SOLENOID (A)	—	X	▼	
LINE PRES SOL (A)	—	X	▼	
I/C SOLENOID (A)	—	X	▼	
FR/B SOLENOID (A)	—	X	▼	
D/C SOLENOID (A)	—	X	▼	
HLR/C SOL (A)	—	X	▼	
ON OFF SOL (ON/OFF)	—	—	▼	LC/B solenoid
TCC SOL MON (A)	—	—	▼	
L/P SOL MON (A)	—	—	▼	
I/C SL MON (A)	—	—	▼	
FR/B SOL MON (A)	—	—	▼	
D/C SOL MON (A)	—	—	▼	
HLR/C SOL MON (A)	—	—	▼	
ON OFF SOL MON (ON/OFF)	—	—	▼	LC/B solenoid
P POSI IND (ON/OFF)	—	—	▼	
R POSI IND (ON/OFF)	—	—	▼	
N POSI IND (ON/OFF)	—	—	▼	
D POSI IND (ON/OFF)	—	—	▼	
4TH POSI IND (ON/OFF)	—	—	▼	
3RD POSI IND (ON/OFF)	—	—	▼	
2ND POSI IND (ON/OFF)	—	—	▼	
1ST POSI IND (ON/OFF)	—	—	▼	
MANU MODE IND (ON/OFF)	—	—	▼	
POWER M LAMP (ON/OFF)	—	—	▼	
F-SAFE IND/L (ON/OFF)	—	—	▼	

TROUBLE DIAGNOSIS


Monitored item (Unit)	Monitor Item Selection			Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS	SELECTION FROM MENU		
ATF WARN LAMP (ON/OFF)	—	—	▼	Not mounted but displayed.	A
BACK-UP LAMP (ON/OFF)	—	—	▼		B
STARTER RELAY (ON/OFF)	—	—	▼		AT
PNP SW3 MON (ON/OFF)	—	—	▼		
C/V CLB ID1	—	—	▼		D
C/V CLB ID2	—	—	▼		
C/V CLB ID3	—	—	▼		E
UNIT CLB ID1	—	—	▼		
UNIT CLB ID2	—	—	▼		F
UNIT CLB ID3	—	—	▼		
TRGT GR RATIO	—	—	▼		G
TRGT PRES TCC (kPa)	—	—	▼		
TRGT PRES L/P (kPa)	—	—	▼		H
TRGT PRES I/C (kPa)	—	—	▼		
TRGT PRE FR/B (kPa)	—	—	▼		I
TRGT PRES D/C (kPa)	—	—	▼		
TRG PRE HLR/C (kPa)	—	—	▼		J
SHIFT PATTERN	—	—	▼		
DRV CST JUDGE	—	—	▼		K
START RLY MON	—	—	▼		
NEXT GR POSI	—	—	▼		L
SHIFT MODE	—	—	▼		
MANU GR POSI	—	—	▼		
VEHICLE SPEED (km/h)	—	X	▼	Vehicle speed recognized by the TCM.	M
Voltage (V)	—	—	▼	Displays the value measured by the voltage probe.	
Frequency (Hz)	—	—	▼	The value measured by the pulse probe is displayed.	
DUTY-HI (high) (%)	—	—	▼		
DUTY-LOW (low) (%)	—	—	▼		
PLS WIDTH-HI (ms)	—	—	▼		
PLS WIDTH-LOW (ms)	—	—	▼		

TROUBLE DIAGNOSIS

CAN DIAGNOSTIC SUPPORT MONITOR MODE

Operation Procedure


1. Touch "CAN DAIG SUPPORT MNTR" on "SELECT DIAG MODE" screen. Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).




DTC WORK SUPPORT MODE

Operation Procedure


1. Touch "DTC WORK SUPPORT" on "SELECT DIAG MODE" screen.



2. Touch select item menu.



3. Touch "START".



TROUBLE DIAGNOSIS

4. Perform driving test according to "DTC Confirmation Procedure" in "TROUBLE DIAGNOSIS FOR DTC".

TCC SOL FUNCTN CHECK	
OUT OF CONDITION	
MONITOR	
ACCELE POSI	XXX
GEAR	XXX
TCC SOLENOID	XXXXA
VEHICLE SPEED	XXXkm/h

SCIA5160E

A
B
AT

- When testing conditions are satisfied, CONSULT-II screen changes from "OUT OF CONDITION" to "TESTING".

TCC SOL FUNCTN CHECK	
TESTING	
MONITOR	
ACCELE POSI	XXX
GEAR	XXX
TCC SOLENOID	XXXXA
VEHICLE SPEED	XXXkm/h

SCIA5161E

D
E
F
G

5. Stop vehicle.

TCC SOL FUNCTN CHECK	
STOP VEHICLE	

SCIA5164E

H
I
J
K

- If "NG" appears on the screen, malfunction may exit. Go to "Diagnostic Procedure".


TCC SOL FUNCTN CHECK	
NG	

SCIA5162E


L
M

TROUBLE DIAGNOSIS

6. Perform test drive to check gear shift feeling in accordance with instructions displayed.
7. Touch "YES" or "NO".
8. CONSULT-II procedure is ended.



- If "NG" appears on the screen, a malfunction may exit. Go to "Diagnostic Procedure"



Display Items List

DTC work support item	Description	Check item
I/C SOL FUNCTN CHECK*	—	—
FR/B SOL FUNCTN CHECK*	—	—
D/C SOL FUNCTN CHECK*	—	—
HLR/C SOL FUNCTN CHECK*	—	—
LC/B SOL FUNCTN CHECK*	—	—
TCC SOL FUNCTN CHECK	Following items for "TCC solenoid function (lock-up) " can be confirmed. ● Self-diagnosis status (whether the diagnosis is being performed or not) ● Self-diagnostic results (OK or NG)	● TCC solenoid valve ● Hydraulic control circuit

*: Do not use, but displayed.

TROUBLE DIAGNOSIS

Diagnostic Procedure without CONSULT-II

NCS001K1

OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)

A

Refer to [EC-135, "Generic Scan Tool \(GST\) Function"](#) (for VQ35DE engine), [EC-838, "Generic Scan Tool \(GST\) Function"](#) (for VK45DE engine).

B

OBD-II SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Refer to [EC-70, "Malfunction Indicator Lamp \(MIL\)"](#) (for VQ35DE engine), [EC-772, "Malfunction Indicator Lamp \(MIL\)"](#) (for VK45DE engine).

AT

TCM SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Description

As a method for locating the suspect circuit, when the self-diagnostics start signal is input, the memory for the malfunction location is output and the A/T CHECK indicator lamp flashes to display the corresponding DTC.

D

Operation Procedure

1. CHECK A/T CHECK INDICATOR LAMP

E

1. Start the engine with selector lever in "P" position. Warm engine to normal operating temperature.
2. Turn ignition switch ON and OFF at least twice, then leave it in the OFF position.
3. Wait 10 seconds.
4. Turn ignition switch ON. (Do not start engine.)

F

Does A/T CHECK indicator lamp come on for about 2 seconds?

YES >> GO TO 2.

NO >> GO TO [AT-190, "A/T CHECK Indicator Lamp Does Not Come On"](#) .

G

H

2. JUDGEMENT PROCEDURE

1. Turn ignition switch OFF.
2. Keep pressing shift lock release button.
3. Move selector lever from "P" to "D" position.
4. Release accelerator pedal. (Set the closed throttle position signal ON.)
5. Depress brake pedal. (Stop lamp switch signal ON.)
6. Turn ignition switch ON.
7. Wait 3 seconds.
8. Move the selector lever to the manual shift gate side. (Manual mode signal ON.)
9. Release brake pedal. (Stop lamp switch signal OFF.)
10. Move the selector lever to "D" position. (Manual mode signal OFF.)
11. Depress brake pedal. (Stop lamp switch signal ON.)
12. Release brake pedal. (Stop lamp switch signal OFF.)
13. Depress accelerator pedal fully and release it.

I

J

K

L

M

>> GO TO 3.

3. CHECK SELF-DIAGNOSIS CODE

Check A/T CHECK indicator lamp.

Refer to [AT-104, "Judgement Self-diagnosis Code"](#) .

If the system does not go into self-diagnostics. Refer to [AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) , [AT-184, "CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT"](#) , [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) , [AT-185, "BRAKE SIGNAL CIRCUIT"](#) .

>> DIAGNOSIS END


TROUBLE DIAGNOSIS

Judgement Self-diagnosis Code


If there is a malfunction, the lamp lights up for the time corresponding to the suspect circuit.

No.	Malfunctioning item	No.	Malfunctioning item
1	Revolution sensor AT-119	10	A/T fluid temperature sensor AT-135
2	Direct clutch solenoid valve AT-155 , AT-157	11	Turbine revolution sensor AT-117
3	Torque converter clutch solenoid valve AT-126 , AT-128	12	A/T interlock AT-142
4	Line pressure solenoid valve AT-130	13	A/T 1st engine braking AT-145
5	Input clutch solenoid valve AT-147 , AT-149	14	Start signal AT-108
6	Front brake solenoid valve AT-151 , AT-153	15	Accelerator pedal position sensor AT-132
7	Low coast brake solenoid valve AT-163 , AT-165	16	Engine speed signal AT-124
8	High and low reverse clutch solenoid valve AT-159 , AT-161	17	CAN communication line AT-105
9	PNP switch AT-113		

All circuits that can be confirmed by self-diagnosis are OK.



Example: No.4 Line pressure solenoid valve



Unit : seconds

SCIA5767E

Erase Self-diagnosis

- In order to make it easier to find the cause of hard-to-duplicate malfunctions, malfunction information is stored into the control unit as necessary during use by the user. This memory is not erased no matter how many times the ignition switch is turned ON and OFF.
- However, this information is erased by turning ignition switch OFF after performing self-diagnostics or by erasing the memory using the CONSULT-II.

DTC U1000 CAN COMMUNICATION LINE

DTC U1000 CAN COMMUNICATION LINE

PPF:23710

Description

NCS001KJ

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

On Board Diagnosis Logic

NCS001KK

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "U1000 CAN COMM CIRCUIT" with CONSULT-II or 17th judgement flicker without CONSULT-II is detected when TCM cannot communicate to other control units.

Possible Cause

NCS001KL

Harness or connectors
(CAN communication line is open or shorted.)

DTC Confirmation Procedure

NCS001KM


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNAL" or "MAIN SIGNAL" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine and wait for at least 6 seconds.
4. If DTC is detected, go to [AT-107, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".



DTC U1000 CAN COMMUNICATION LINE

Wiring Diagram — AT — CAN

NCS001KN

AT-CAN-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC
 : DATA LINE



*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT", PG SECTION.

TCWT0342E

DTC U1000 CAN COMMUNICATION LINE

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Item	Condition	Data (Approx.)
3	CAN-H	-	-
8	CAN-L	-	-

Diagnostic Procedure

NCS001KO

1. CHECK CAN COMMUNICATION CIRCUIT

④ With CONSULT-II

- Turn ignition switch ON and start engine.
- Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.

Is any malfunction of the "CAN COMM CIRCUIT" indicated?

YES >> Print out CONSULT-II screen, GO TO LAN section.

Refer to [LAN-50, "CAN System Specification Chart"](#).

NO >> **INSPECTION END**

The screenshot shows the following screen layout:

- Top bar: SELF-DIAG RESULTS
- Sub-bar: DTC RESULTS
- Main display area: CAN COMM CIRCUIT [U1000]
- Bottom navigation bar:

ERASE		PRINT	
MODE	BACK	LIGHT	COPY

PCIA0061E

DTC P0615 START SIGNAL CIRCUIT

DTC P0615 START SIGNAL CIRCUIT

PFP:25230

Description

NCS001KP

TCM prohibits cranking other than at "P" or "N" position.

CONSULT-II Reference Value

NCS001KQ

Item name	Condition	Display value
STARTER RELAY	Selector lever in "N", "P" positions.	ON
	Selector lever in "R", "D" positions.	OFF

On Board Diagnosis Logic

NCS001KR

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0615 STARTER RELAY/CIRC" with CONSULT-II or 14th judgement flicker without CONSULT-II is detected when starter relay is switched ON other than at "P" or "N" position. (Or when switched OFF at "P" or "N" position).

Possible Cause

NCS001KS

- Harness or connectors
(Starter relay and TCM circuit is open or shorted.)
- Starter relay circuit

DTC Confirmation Procedure

NCS001KT


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "STARTER RELAY" ON/OFF.
3. Start engine.
4. Drive vehicle for at least 2 consecutive seconds.
5. If DTC is detected, go to [AT-110, "Diagnostic Procedure"](#) .










DTC P0615 START SIGNAL CIRCUIT

Wiring Diagram — AT — STSIG

NCS001KU

AT-STSIG-01

-  : DETECTABLE LINE FOR DTC
-  : NON-DETECTABLE LINE FOR DTC
-  : WITH VK ENGINE
-  : WITH VQ ENGINE




*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0343E

DTC P0615 START SIGNAL CIRCUIT

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Item	Condition	Data (Approx.)
9	Starter relay	 Selector lever in "N", "P" positions.	Battery voltage
		Selector lever in "R", "D" positions.	0 V

Diagnostic Procedure


NCS001KV

1. CHECK STARTER RELAY

④ With CONSULT-II

- Turn ignition switch ON.
- Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "STARTER RELAY" ON/OFF.

Item name	Condition	Display value
STARTER RELAY	Selector lever in "N", "P" positions.	ON
	Selector lever in "R", "D" positions.	OFF




⊗ Without CONSULT-II

- Turn ignition switch ON.
- Check voltage between the IPDM E/R connector and ground.

Item	Connector	Terminal	Shift position	Voltage (Approx.)	
Starter relay	E9	53	Ground	"N", "P"	Battery voltage
				"R", "D"	0 V

OK or NG

- OK >> GO TO 5.
 NG >> GO TO 2.



2. CHECK HARNESS BETWEEN A/T ASSEMBLY HARNESS CONNECTOR AND IPDM E/R CONNECTOR


- Turn ignition switch OFF.
- Disconnect A/T assembly harness connector and IPDM E/R connector.
- Check continuity between A/T assembly harness connector and IPDM E/R connector.

Item	Connector	Terminal	Continuity
A/T assembly harness connector	F42	9	Yes
IPDM E/R connector	E9	53	

- If OK, check harness for short to ground and short to power.
- Reinstall any part removed.

OK or NG

- OK >> GO TO 3.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



DTC P0615 START SIGNAL CIRCUIT

3. CHECK TERMINAL CORD ASSEMBLY


1. Remove control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disconnect A/T assembly harness connector and TCM connector.
3. Check continuity between A/T assembly harness connector terminal and TCM connector terminal.

Item	Connector	Terminal	Continuity
A/T assembly harness connector	F42	9	Yes
TCM connector	F502	8	

4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

OK or NG

- OK >> GO TO 4.
- NG >> Replace open circuit or short to ground and short to power in harness or connectors.



4. DETECT MALFUNCTIONING ITEM

Check the following.

- Starter relay, Refer to [SC-8, "STARTING SYSTEM"](#) .
- IPDM E/R, Refer to [PG-18, "IPDM E/R \(INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM\)"](#) .

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- NG >> Repair or replace damaged parts.

5. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-108, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P0700 TCM

DTC P0700 TCM

PFP:31036

Description

NCS001KW

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The TCM controls the A/T.

On Board Diagnosis Logic

NCS001KX

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0700 TCM" with CONSULT-II is detected when TCM is malfunctioning.

Possible Cause

NCS001KY

TCM.

DTC Confirmation Procedure

NCS001KZ


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Start engine.
5. Run engine for at least 2 consecutive seconds at idle speed.
6. If DTC is detected, go to [AT-112, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".

Diagnostic Procedure

NCS001L0

1. CHECK DTC


With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELF DIAG RESULTS" mode for "A/T" with CONSULT-II.
3. Touch "ERASE".
4. Turn ignition switch OFF and wait for at least 10 seconds.
5. Perform "DTC confirmation procedure". Refer to [AT-112, "DTC Confirmation Procedure"](#).

Is the "TCM" displayed again?

YES >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).

NO >> **INSPECTION END**



DTC P0705 PARK/NEUTRAL POSITION SWITCH

DTC P0705 PARK/NEUTRAL POSITION SWITCH

PF3:32006

Description

NCS001L1

- The PNP switch includes a transmission range switch.
- The transmission range switch detects the selector lever position and sends a signal to the TCM.

CONSULT-II Reference Value

NCS001L2

Item name	Condition	Display value
SLCT LVR POSI	Selector lever in "N", "P" positions.	N/P
	Selector lever in "R" position.	R
	Selector lever in "D" position.	D

On Board Diagnosis Logic

NCS001L3

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0705 PNP SW/CIRC" with CONSULT-II or 9th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the correct voltage signal from the PNP switches 1, 2, 3 and 4 based on the gear position.
 - When no other position but "P" position is detected from "N" position.

Possible Cause

NCS001L4

- Harness or connectors
PNP switches 1, 2, 3, 4 and TCM circuit is open or shorted.
- Park/neutral position (PNP) switches 1, 2, 3 and 4

DTC Confirmation Procedure

NCS001L5

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
ACCELE POSI: More than 1.0/8
6. If DTC is detected, go to [AT-115, "Diagnostic Procedure"](#).



Ⓟ WITH GST

Follow the procedure "WITH CONSULT-II".


DTC P0705 PARK/NEUTRAL POSITION SWITCH

Wiring Diagram — AT — PNP/SW


NCS001L6

AT-PNP/SW-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



A/T ASSEMBLY



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0344E

DTC P0705 PARK/NEUTRAL POSITION SWITCH

NCS001L7

Diagnostic Procedure

1. CHECK PNP SW CIRCUIT

With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Check if correct selector lever position (N/P, R or D) is displayed as selector lever is moved into each position.

Item name	Condition	Display value
SLCT LVR POSI	Selector lever in "N", "P" positions.	N/P
	Selector lever in "R" position.	R
	Selector lever in "D" position.	D

DATA MONITOR			
MONITOR		NO DTC	
ATF PRES SW 2	OFF		
ATF PRES SW 3	OFF		
ATF PRES SW 5	OFF		
ATF PRES SW 6	OFF		
SLCT LVR POSI	N·P		

△		▽	
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0034E

OK or NG

- OK >> GO TO 5.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG


- OK >> GO TO 4.
NG >> Repair or replace damaged parts.

DTC P0705 PARK/NEUTRAL POSITION SWITCH

4. CHECK SUB-HARNESS

1. Remove control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disconnect park/neutral position switch connector and TCM connector.
3. Check continuity between park/neutral position switch connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
Park/neutral position switch connector	F505	1	Yes
TCM connector	F503	13	
Park/neutral position switch connector	F505	2	Yes
TCM connector	F503	11	
Park/neutral position switch connector	F505	3	Yes
TCM connector	F503	12	
Park/neutral position switch connector	F505	5	Yes
TCM connector	F503	14	



4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- NG >> Replace open circuit or short to ground and short to power in harness or connectors.

5. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-113, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 2.

DTC P0717 TURBINE REVOLUTION SENSOR

DTC P0717 TURBINE REVOLUTION SENSOR

PFP:31935

Description

NCS001L8

The turbine revolution sensor detects input shaft rpm (revolutions per minute). It is located on the input side of the automatic A/T. Monitors revolution of sensor 1 and sensor 2 for non-standard conditions.

CONSULT-II Reference Value

NCS001L9

Item name	Condition	Display value
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.

On Board Diagnosis Logic

NCS001LA

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0717 TURBINE REV S/CIRC" with CONSULT-II or 11th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - When TCM detects an irregularity only at position of 4th gear for turbine revolution sensor 2.

Possible Cause

NCS001LB

- Harness or connectors
(Sensor circuit is open or shorted.)
- Turbine revolution sensor 1 and/or 2

DTC Confirmation Procedure

NCS001LC

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "VHCL/S SE-A/T", "ENGINE SPEED", "ACCELE POSI", "SLCT LVR POSI" and "GEAR".
3. Touch "START".
4. Start engine and maintain the following conditions for at least 5 consecutive seconds.
 - VHCL/S SE-A/T: 40 km/h (25 MPH) or more**
 - ENGINE SPEED: 1,500 rpm or more**
 - ACCELE POSI: More than 0.5/8**
 - SLCT LVR POSI: "D" position**
 - GEAR (Turbine revolution sensor 1): "4" or "5" position**
 - GEAR (Turbine revolution sensor 2): All positions**
 - Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.**
5. If DTC is detected, go to [AT-118, "Diagnostic Procedure"](#).

WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P0717 TURBINE REVOLUTION SENSOR

NCS001LD

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Vehicle start and read out the value of "TURBINE REV".

Item name	Condition	Display value
TURBINE REV	During driving (lock-up ON)	Approximately matches the engine speed.

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

DATA MONITOR			
MONITOR	NO. DTC		
W/O THL POS	OFF		
BRAKE SW	OFF		
ENGINE SPEED	0 rpm		
TURBINE REV	0 rpm		
OUTPUT REV	0 rpm		
▼			
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0041E

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-117, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

PPF:32702

Description

NCS001LE

The revolution sensor detects the revolution of the parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

CONSULT-II Reference Value

NCS001LF

Item name	Condition	Display value
VHCL/S SE-A/T	During driving	Approximately matches the speedometer reading.

On Board Diagnosis Logic

NCS001LG

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0720 VEH SPD SEN/CIR AT" with CONSULT-II or 1st judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - After ignition switch is turned ON, irregular signal input from vehicle speed sensor MTR before the vehicle starts moving.

Possible Cause

NCS001LH

- Harness or connectors
(Sensor circuit is open or shorted.)
- Revolution sensor
- Vehicle speed sensor MTR

DTC Confirmation Procedure

NCS001LI

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "VHCL/S SE-A/T", "ENGINE SPEED", "ACCELE POSI" and "SLCT LVR POSI".
3. Touch "START".
4. Drive vehicle and check for an increase of "VHCL/S SE-A/T" value in response to "VHCL/S SE-MTR" value.
If the check result is NG, go to [AT-122, "Diagnostic Procedure"](#).
If the check result is OK, go to following step.
5. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
6. Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL/S SE-A/T: 30 km/h (19 MPH) or more
ACCELE POSI: More than 1.0/8
SLCT LVR POSI: "D" position
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
If the check result is NG, go to [AT-122, "Diagnostic Procedure"](#).
If the check result is OK, go to following step.
7. Maintain the following conditions for at least 5 consecutive seconds.
ENGINE SPEED: 3,500 rpm or more
ACCELE POSI: More than 1.0/8



DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

SLCT LVR POSI: “D” position

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

8. If DTC is detected, go to [AT-122, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure “WITH CONSULT-II”.



DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

Wiring Diagram — AT — VSSA/T

NCS001LJ

AT-VSSA/T-01

— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0345E

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

NCS001LK

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed.

DATA MONITOR	
MONITOR	NO DTC
VHCL/S SE-A/T	0km/h
VHCL/S SE-MTR	0km/h
ACCELE POSI	0.0/8
THROTTLE POS	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
	▽
RECORD	
MODE	BACK
LIGHT	COPY

SCIA2148E

Item name	Condition	Display value
VHCL/S SE-A/T	During driving	Approximately matches the speedometer reading.

OK or NG

- OK >> GO TO 6.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG


- OK >> GO TO 4.
NG >> Repair or replace damaged parts.

DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)

4. CHECK SUB-HARNESS

1. Remove control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disconnect park/neutral position switch connector and TCM connector.
3. Check continuity between park/neutral position switch connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
Park/neutral position switch connector	F505	8	Yes
TCM connector	F503	20	
Park/neutral position switch connector	F505	9	Yes
TCM connector	F503	17	
Park/neutral position switch connector	F505	10	Yes
TCM connector	F503	16	



4. If OK, check harness for short to ground and short to power.
5. Reinstall any part removed.

OK or NG

- OK >> GO TO 5.
 NG >> Replace open circuit or short to ground and short to power in harness or connectors.

5. REPLACE THE REVOLUTION SENSOR AND CHECK DTC

1. Replace the revolution sensor. Refer to [AT-263, "Revolution Sensor Components \(2WD Models Only\)"](#) (2WD models) or [AT-301, "DISASSEMBLY"](#) , [AT-281, "Components"](#) (AWD models).
2. Perform "DTC Confirmation Procedure". Refer to [AT-119, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
 NG >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

6. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-119, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 2.

DTC P0725 ENGINE SPEED SIGNAL

DTC P0725 ENGINE SPEED SIGNAL

PFP:24825

Description

NCS001LL

The engine speed signal is sent from the ECM to the TCM.

CONSULT-II Reference Value

NCS001LM

Item name	Condition	Display value
ENGINE SPEED	Engine running	Closely matches the tachometer reading.

On Board Diagnosis Logic

NCS001LN

- This is an OBD-II self-diagnostic item. (For VQ35DE engine)
- Diagnostic trouble code "P0725 ENGINE SPEED SIG" with CONSULT-II or 16th judgement flicker without CONSULT-II is detected when TCM does not receive the ignition signal from ECM during engine cranking or running.

Possible Cause

NCS001LO

Harness or connectors
(ECM to TCM circuit is open or shorted.)

DTC Confirmation Procedure

NCS001LP

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "VHCL/S SE-A/T", "ACCELE POSI" and "SLCT LVR POSI".
3. Touch "START".
4. Start engine and maintain the following conditions for at least 10 consecutive seconds.
VHCL/S SE-A/T: 10 km/h (6 MPH) or more
ACCELE POSI: More than 1.0/8
SLCT LVR POSI: "D" position
5. If DTC is detected, go to [AT-125, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P0725 ENGINE SPEED SIGNAL

NCS001LQ

Diagnostic Procedure

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .

NO >> GO TO 2.

2. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. While monitoring engine speed, check for engine speed change corresponding to wide-open throttle position signal.

Item name	Condition	Display value
ENGINE SPEED	Engine running	Closely matches the tachometer reading.

OK or NG

OK >> GO TO 3.

NG >> Check the ignition signal circuit. Refer to [EC-691, "IGNITION SIGNAL"](#) (for VQ35DE engine), [EC-1411, "IGNITION SIGNAL"](#) (for VK45DE engine).

DATA MONITOR			
MONITOR	NO DTC		
W/O THL POS	OFF		
BRAKE SW	OFF		
ENGINE SPEED	0 rpm		
TURBINE REV	0 rpm		
OUTPUT REV	0 rpm		
▼			
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0041E

3. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-124, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 4.

4. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

NG >> Repair or replace damaged parts.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

PFP:31940

Description

NCS001LR

- The torque converter clutch solenoid valve is activated, with the gear in D3 , D4 , D5 , M4 and M5 by the TCM in response to signals sent from the vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Torque converter clutch piston operation will then be controlled.
- Lock-up operation, however, is prohibited when A/T fluid temperature is too low.
- When the accelerator pedal is depressed (less than 1/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

CONSULT-II Reference Value

NCS001LS

Item name	Condition	Display value (Approx.)
TCC SOLENOID	Lock-up is active	0.4 - 0.6 A

On Board Diagnosis Logic

NCS001LT

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0740 TCC SOLENOID/CIRC" with CONSULT-II or 3rd judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS001LU

- Torque converter clutch solenoid valve
- Harness or connectors
(Solenoid circuit is open or shorted.)

DTC Confirmation Procedure

NCS001LV

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch "OFF" and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "VHCL/S SE-A/T", "ACCELE POSI" and "SLCT LVR POSI" . .
3. Touch "START".
4. Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL/S SE-A/T: 80 km/h (50 MPH) or more
ACCELE POSI: 0.5/8 - 1.0/8
SLCT LVR POSI: "D" position
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
5. If DTC is detected go to [AT-127, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Diagnostic Procedure

NCS001LW

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "TCC SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
TCC SOLENOID	Lock-up is active	0.4 - 0.6 A

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

DATA MONITOR			
MONITOR		NO DTC	
TCC SOLENOID	XXXX		
LINE PRES SOL	XXXX		
I/C SOLENOID	XXXX		
FR/B SOLENOID	XXXX		
D/C SOLENOID	XXXX		
HLR/C SOL	XXXX		
			▽
			RECORD
MODE	BACK	LIGHT	COPY

SCIA4793E

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-126, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

PFP:31940

Description

NCS001LX

This malfunction is detected when the A/T does not shift into 5th gear position or the torque converter clutch does not lock-up as instructed by the TCM. This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

CONSULT-II Reference Value

NCS001LY

Item name	Condition	Display value (Approx.)
TCC SOLENOID	Lock-up is active	0.4 - 0.6 A

On Board Diagnosis Logic

NCS001LZ

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0744 A/T TCC S/V FNCTN" with CONSULT-II or 3rd judgement flicker without CONSULT-II is detected under the following conditions.
 - When A/T cannot perform lock-up even if electrical circuit is good.
 - When TCM detects as irregular by comparing difference value with slip rotation.

Possible Cause

NCS001M0

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Torque converter clutch solenoid valve
- Hydraulic control circuit

DTC Confirmation Procedure

NCS001M1

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II


1. Start engine and Select "TCC SOL FUNCTN CHECK" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
2. Accelerate vehicle to more than 80 km/h (50 MPH) and maintain the following condition continuously until "TESTING" has turned to "COMPLETE". (It will take approximately 30 seconds after "TESTING" shows.)
ACCELE POSI: More than 1.0/8 (at all times during step 4)
TCC SOLENOID: 0.4 - 0.6A
SLCT LVR POSI: "D" position
[Reference speed: Constant speed of more than 80 km/h (50 MPH)]

- Make sure "GEAR" shows "5".
- For shift schedule, refer to [AT-371, "Vehicle Speed at Which Lock-Up Occurs/Releases"](#) .
- If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than P0744 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".

3. Make sure that "OK" is displayed. (If "NG" is displayed, refer to [AT-129, "Diagnostic Procedure"](#) . Refer to shift schedule, [AT-371, "Vehicle Speed at Which Lock-Up Occurs/Releases"](#) .

WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

NCS001M2

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "TCC SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
TCC SOLENOID	Lock-up is active	0.4 - 0.6 A

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

DATA MONITOR			
MONITOR		NO DTC	
TCC SOLENOID	XXXX		
LINE PRES SOL	XXXX		
I/C SOLENOID	XXXX		
FR/B SOLENOID	XXXX		
D/C SOLENOID	XXXX		
HLR/C SOL	XXXX		
			▽
			RECORD
MODE	BACK	LIGHT	COPY

SCIA4793E

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-128, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P0745 LINE PRESSURE SOLENOID VALVE

DTC P0745 LINE PRESSURE SOLENOID VALVE

PF3:31940

Description

NCS001M3

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

CONSULT-II Reference Value

NCS001M4

Item name	Condition	Display value (Approx.)
LINE PRES SOL	During driving	0.2 - 0.6 A

On Board Diagnosis Logic

NCS001M5

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P0745 L/PRESS SOL/CIRC" with CONSULT-II or 4th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS001M6

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Line pressure solenoid valve

DTC Confirmation Procedure

NCS001M7


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Engine start and wait for at least 5 seconds.
5. If DTC is detected, go to [AT-131, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P0745 LINE PRESSURE SOLENOID VALVE

Diagnostic Procedure

NCS001M8

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "LINE PRES SOL" during driving.

Item name	Condition	Display value (Approx.)
LINE PRES SOL	During driving	0.2 - 0.6 A

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-130, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1705 THROTTLE POSITION SENSOR

DTC P1705 THROTTLE POSITION SENSOR

PF2:22620

Description

NCS001M9

Electric throttle control actuator consists of throttle control motor, accelerator pedal position sensor, throttle position sensor, etc. The actuator sends a signal to the ECM, and ECM sends signals to TCM with CAN communication.

CONSULT-II Reference Value

NCS001MA

Item name	Condition	Display value (Approx.)
ACCELE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8.0/8

On Board Diagnosis Logic

NCS001MB

- This is an OBD-II self-diagnostic item. (For VQ35DE engine)
- Diagnostic trouble code "P1705 TP SEN/CIRC A/T" with CONSULT-II or 15th judgement flicker without CONSULT-II is detected when TCM does not receive the proper accelerator pedal position signals (input by CAN communication) from ECM.

Possible Cause

NCS001MC

Harness or connectors
(Sensor circuit is open or shorted.)

DTC Confirmation Procedure

NCS001MD


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Start engine and let it idle for 1 second.
5. If DTC is detected, go to [AT-133, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P1705 THROTTLE POSITION SENSOR

NCS001ME

Diagnostic Procedure

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

Is a malfunction in the CAN communication indicated in the results?

YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .

NO >> GO TO 2.

2. CHECK DTC WITH TCM

With CONSULT-II

- Turn ignition switch ON.
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Depress accelerator pedal and read out the value of "ACCELE POSI".

Item name	Condition	Display value (Approx.)
ACCELE POSI	Released accelerator pedal.	0.0/8
	Fully depressed accelerator pedal.	8.0/8

DATA MONITOR	
MONITOR	NO DTC
ACCELE POSI	0.0/8
THROTTLE POSI	0.0/8
CLSD THL POS	ON
W/O THL POS	OFF
BRAKE SW	OFF

▼			
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0070E

- Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#)

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

3. CHECK DTC WITH ECM

With CONSULT-II

- Turn ignition switch ON.
- Select "SELF-DIAG RESULTS" mode for "ENGINE" with CONSULT-II. Refer to [EC-123, "CONSULT-II Function \(ENGINE\)"](#) (for VQ35DE engine), [EC-826, "CONSULT-II Function \(ENGINE\)"](#) (for VK45DE engine).

OK or NG

OK >> GO TO 4.

NG >> Check the DTC detected item. Refer to [EC-123, "CONSULT-II Function \(ENGINE\)"](#) (for VQ35DE engine), [EC-826, "CONSULT-II Function \(ENGINE\)"](#) (for VK45DE engine).

- If CAN communication line is detected, go to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .

SELECT SYSTEM			
ENGINE			
A/T			
ABS			
AIR BAG			
IPDM E/R			
BCM			

Page Down		
BACK	LIGHT	COPY

NOTE: EXAMPLE SHOWN. ACTUAL DISPLAY MAY DIFFER. BCIA0030E

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-132, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 5.

DTC P1705 THROTTLE POSITION SENSOR

5. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

PFP:31940

Description

NCS001MF

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.

CONSULT-II Reference Value

NCS001MG

Item name	Condition °C (°F)	Display value (Approx.)
ATF TEMP SE 1	0 (32) - 20 (68) - 80 (176)	3.3 - 2.7 - 0.9 V
ATF TEMP SE 2		3.3 - 2.5 - 0.7 V

On Board Diagnosis Logic

NCS001MH

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1710 (A/T), P0710 (ENGINE) ATF TEMP SEN/CIRC" with CONSULT-II or 10th judgement flicker without CONSULT-II is detected when TCM receives an excessively low or high voltage from the sensor.

Possible Cause

NCS001MI

- Harness or connectors
(Sensor circuit is open or shorted.)
- A/T fluid temperature sensors 1 and/or 2

DTC Confirmation Procedure

NCS001MJ

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "VHCL/S SE-A/T", "ACCELE POSI" and "SLCT LVR POSI".
3. Touch "START".
4. Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)
VHCL/S SE-A/T: 10 km/h (6 MPH) or more
ACCELE POSI: More than 1.0/8
SLCT LVR POSI: "D" position
5. If DTC is detected, go to [AT-137, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".


DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

Wiring Diagram — AT — FTS


NCS001MK

AT-FTS-01

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



A/T ASSEMBLY



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0346E

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

NCS001ML

Diagnostic Procedure

1. CHECK A/T FLUID TEMPERATURE SENSOR 1 SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Read out the value of "ATF TEMP SE 1".

Item name	Condition °C (°F)	Display value (Approx.)
ATF TEMP SE 1	0 (32) - 20 (68) - 80 (176)	3.3 - 2.7 - 0.9 V

OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.

DATA MONITOR	
MONITOR	NO DTC
OUTPUT REV	0 rpm
ATF TEMP SE 1	1.84 v
ATF TEMP SE 2	1.72 v
BATTERY BOLT	11.5 v
ATF PRES SW 1	OFF

△	▽
RECORD	
MODE	BACK
LIGHT	COPY

PCIA0039E

2. CHECK A/T FLUID TEMPERATURE SENSOR 2 SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Read out the value of "ATF TEMP SE 2".

Item name	Condition °C (°F)	Display value (Approx.)
ATF TEMP SE 2	0 (32) - 20 (68) - 80 (176)	3.3 - 2.5 - 0.7 V

OK or NG

- OK >> GO TO 8.
NG >> GO TO 5.

DATA MONITOR	
MONITOR	NO DTC
OUTPUT REV	0 rpm
ATF TEMP SE 1	1.84 v
ATF TEMP SE 2	1.72 v
BATTERY BOLT	11.5 v
ATF PRES SW 1	OFF

△	▽
RECORD	
MODE	BACK
LIGHT	COPY

SCIA0039E

3. CHECK A/T FLUID TEMPERATURE SENSOR 1

Check A/T fluid temperature sensor 1. Refer to [AT-139, "A/T FLUID TEMPERATURE SENSOR 1"](#).

OK or NG

- OK >> GO TO 4.
NG >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).

4. CHECK SUB-HARNESS


1. Disconnect park/neutral position switch connector and TCM connector.
2. Check continuity between park/neutral position switch connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
Park/neutral position switch connector	F505	6	Yes
TCM connector	F503	19	
Park/neutral position switch connector	F505	7	Yes
TCM connector	F503	18	

3. If OK, check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 7.
NG >> Replace open circuit or short to ground and short to power in harness or connectors.



DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

5. CHECK A/T FLUID TEMPERATURE SENSOR 2

Check A/T fluid temperature sensor 2. Refer to [AT-139, "A/T FLUID TEMPERATURE SENSOR 2"](#) .

OK or NG


OK >> GO TO 6.

NG >> Replace the A/T fluid temperature sensor 2. Refer to [AT-246, "A/T FLUID TEMPERATURE SENSOR 2 REMOVAL AND INSTALLATION"](#) .

6. CHECK TERMINAL CORD ASSEMBLY

1. Disconnect A/T fluid temperature sensor 2 connector and TCM connector.
2. Check continuity between A/T fluid temperature sensor 2 connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
A/T fluid temperature sensor 2 connector	F507	1	Yes
TCM connector	F502	3	
A/T fluid temperature sensor 2 connector	F507	2	Yes
TCM connector	F502	5	



3. If OK, check harness for short to ground and short to power.

OK or NG

OK >> GO TO 7.

NG >> Replace open circuit or short to ground and short to power in harness or connectors.

7. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

1. Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .
2. Reinstall any part removed.

OK or NG

OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

NG >> Repair or replace damaged parts.

8. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-135, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 1.

DTC P1710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

NCS001MM


Component Inspection

A/T FLUID TEMPERATURE SENSOR 1

1. Remove control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check resistance between terminals.

Item	Connector	Terminal	Temperature °C (°F)	Resistance (Approx.)
A/T fluid temperature sensor 1	F505	6 - 7	0 (32)	15 kΩ
			20 (68)	6.5 kΩ
			80 (176)	0.9 kΩ

3. If NG, replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .




A/T FLUID TEMPERATURE SENSOR 2

1. Remove A/T fluid temperature sensor 2. Refer to [AT-246, "A/T FLUID TEMPERATURE SENSOR 2 REMOVAL AND INSTALLATION"](#) .
2. Check resistance between terminals.

Item	Connector	Terminal	Temperature °C (°F)	Resistance (Approx.)
A/T fluid temperature sensor 2	F507	1 - 2	0 (32)	10 kΩ
			20 (68)	4 kΩ
			80 (176)	0.5 kΩ

3. If NG, replace the A/T fluid temperature sensor 2. Refer to [AT-246, "A/T FLUID TEMPERATURE SENSOR 2 REMOVAL AND INSTALLATION"](#) .



DTC P1721 VEHICLE SPEED SENSOR MTR

DTC P1721 VEHICLE SPEED SENSOR MTR

PFP:24814

Description

NCS001MN

The vehicle speed sensor-MTR signal is transmitted from combination meter to TCM by CAN communication line. The signal functions as an auxiliary device to the revolution sensor when it is malfunctioning. The TCM will then use the vehicle speed sensor-MTR signal.

CONSULT-II Reference Value

NCS001MO

Item name	Condition	Display value
VHCL/S SE-MTR	During driving	Approximately matches the speedometer reading.

On Board Diagnosis Logic

NCS001MP

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1721 VHE SPD SE/CIR-MTR" with CONSULT-II is detected when TCM does not receive the proper vehicle speed sensor MTR signal (input by CAN communication) from unified meter and A/C amp.

Possible Cause

NCS001MQ

Harness or connectors
(Sensor circuit is open or shorted.)

DTC Confirmation Procedure

NCS001MR

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

④ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Start engine and maintain the following conditions for at least 5 consecutive seconds.
ACCELE POSI: 1.0/8 or less
VHCL/S SE-MTR: 30 km/h (17 MPH) or more
5. If DTC is detected, go to [AT-141, "Diagnostic Procedure"](#).



DTC P1721 VEHICLE SPEED SENSOR MTR

NCS001MS

Diagnostic Procedure

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

Is malfunction in the CAN communication indicated in the result?

YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .

NO >> GO TO 2.

2. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle and read out the value of "VHCL/S SE-MTR".

Item name	Condition	Display value
VHCL/S SE-MTR	During driving	Approximately matches the speedometer reading.

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.

DATA MONITOR			
MONITOR	NO DTC		
VHCL/S SE-A/T	0km/h		
VHCL/S SE-MTR	0km/h		
ACCELE POSI	0.0/8		
THROTTLE POS	0.0/8		
CLSD THL POS	ON		
W/O THL POS	OFF		
▽			
RECORD			
MODE	BACK	LIGHT	COPY

SCIA2148E

3. CHECK UNIFIED METER AND A/C AMP

Check unified meter and A/C amp. Refer to [DI-28, "UNIFIED METER AND A/C AMP"](#) .

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-140, "DTC Confirmation Procedure"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 5.

5. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

OK >> GO TO 6.

NG >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

NG >> Repair or replace damaged parts.

DTC P1730 A/T INTERLOCK

DTC P1730 A/T INTERLOCK

PFP:00000

Description

NCS001MT

Fail-safe function to detect interlock conditions.

On Board Diagnosis Logic

NCS001MU

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1730 A/T INTERLOCK" with CONSULT-II or 12th judgement flicker without CONSULT-II is detected when TCM does not receive the proper voltage signal from the sensor and switch.
- TCM monitors and compares gear position and conditions of each ATF pressure switch when gear is steady.

NOTE:

When the vehicle is driven fixed in 2nd gear, a turbine revolution sensor malfunction is displayed, but this is not a turbine revolution sensor malfunction.

Possible Cause

NCS001MV

- Harness or connectors
(Solenoid and switch circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

NCS001MW


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Touch "START".
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
SLCT LVR POSI: "D" position
6. If DTC is detected, go to [AT-143, "Diagnostic Procedure"](#).



WITH GST

Follow the procedure "WITH CONSULT-II".

DTC P1730 A/T INTERLOCK

NCS001MX

Judgement of A/T Interlock

When A/T Interlock is judged to be malfunctioning, the vehicle should be fixed in 2nd gear, and should be set in a condition in which it can travel.

When one of the following fastening patterns is detected, the fail-safe function in correspondence with the individual pattern should be performed.

A/T INTERLOCK COUPLING PATTERN TABLE

●: NG, X: OK

Gear position		ATF pressure switch output					Fail-safe function	Clutch pressure output pattern after fail-safe function					
		SW3 (I/C)	SW6 (HLR/C)	SW5 (D/C)	SW1 (FR/B)	SW2 (LC/B)		I/C	HLR/C	D/C	FR/B	LC/B	L/U
A/T interlock coupling pattern	3rd	-	X	X	-	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	4th	-	X	X	-	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF
	5th	X	X	-	X	●	Held in 2nd gear	OFF	OFF	ON	OFF	OFF	OFF


Diagnostic Procedure

NCS001MY

1. CHECK SELF-DIAGNOSTIC RESULTS

Ⓟ With CONSULT-II

1. Drive vehicle.
2. Stop vehicle and turn ignition switch OFF.
3. Turn ignition switch ON.
4. Select "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II.



ⓧ Without CONSULT-II

1. Drive vehicle.
2. Stop vehicle and turn ignition switch OFF.
3. Turn ignition switch ON.
4. Perform self-diagnosis. Refer to [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#).

OK or NG

OK >> GO TO 2.

NG >> Check low coast brake solenoid valve circuit and function. Refer to [AT-163, "DTC P1772 LOW COAST BRAKE SOLENOID VALVE"](#), [AT-165, "DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION"](#).

2. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-142, "DTC Confirmation Procedure"](#).

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 3.

DTC P1730 A/T INTERLOCK

3. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace damaged parts.

4. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
- NG >> Repair or replace damaged parts.

DTC P1731 A/T 1ST ENGINE BRAKING

DTC P1731 A/T 1ST ENGINE BRAKING

PPF:00000

Description

NCS001MZ

Fail-safe function to prevent sudden decrease in speed by engine brake other than at M1 position.

CONSULT-II Reference Value

NCS001N0

Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF
ATF PRES SW 2	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001N1

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1731 A/T 1ST E/BRAKING” with CONSULT-II or 13th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM does not receive the proper voltage signal from the sensor.
 - When TCM monitors each ATF pressure switch and solenoid monitor value, and detects as irregular when engine brake of 1st gear acts other than at M1 position.

Possible Cause

NCS001N2

- Harness or connectors
(Sensor circuit is open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

NCS001N3

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.


NOTE:

If “DTC Confirmation Procedure” has been previously preformed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “SELECTION FROM MENU” in “DATA MONITOR” mode for “A/T” with CONSULT-II and check monitor “ENGINE SPEED”, “MANU MODE SW” and “GEAR”.
3. Touch “START”.
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
ENGINE SPEED: 1,200 rpm
MANU MODE SW: ON
GEAR: “1” position
6. If DTC is detected, go to [AT-146](#). "[Diagnostic Procedure](#)".



DTC P1731 A/T 1ST ENGINE BRAKING

NCS001N4

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "M" position (1st gear), and confirm the ON/OFF actuation of "ATF PRES SW 2" and "ON OFF SOL".

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 2	xxx
ON OFF SOL	xxx
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4670E

Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF
ATF PRES SW 2	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-145, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1752 INPUT CLUTCH SOLENOID VALVE

DTC P1752 INPUT CLUTCH SOLENOID VALVE

PDF:31940

Description

NCS001N5

Input clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

NCS001N6

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Input clutch engaged. Refer to AT-21 .	0 - 0.05 A

On Board Diagnosis Logic

NCS001N7

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1752 I/C SOLENOID/CIRC" with CONSULT-II or 5th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS001N8

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Input clutch solenoid valve

DTC Confirmation Procedure

NCS001N9

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "ACCELE POSI", "SLCT LVR POSI" and "GEAR".
3. Touch "START".
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

ACCELE POSI: 1.5/8 - 2.0/8

SLCT LVR POSI: "D" position


GEAR: "3" ⇒ "4" (I/C ON/OFF)

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

6. If DTC is detected go to [AT-148, "Diagnostic Procedure"](#) .

Ⓟ WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P1752 INPUT CLUTCH SOLENOID VALVE

NCS001NA

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "I/C SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Input clutch engaged. Refer to AT-21 .	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-147, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

PFP:31940

Description

NCS001NB

- Input clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

NCS001NC

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Input clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 3	Input clutch engaged. Refer to AT-21 .	ON
	Input clutch disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001ND

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1754 I/C SOLENOID FNCTN” with CONSULT-II or 5th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change.)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 3 is irregular during releasing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001NE

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Input clutch solenoid valve
- ATF pressure switch 3

DTC Confirmation Procedure

NCS001NF

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “3” ⇒ “4” (I/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II. If DTC (P1754) is detected, go to [AT-150, "Diagnostic Procedure"](#) .
If DTC (P1752) is detected, go to [AT-148, "Diagnostic Procedure"](#) .
If DTC (P1843) is detected, go to [AT-175, "Diagnostic Procedure"](#) .



DTC P1754 INPUT CLUTCH SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "WITH CONSULT-II".

Diagnostic Procedure

NCS001NG

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of "ATF PRES SW 3" and electrical current value of "I/C SOLENOID".

DATA MONITOR			
MONITOR		NO DTC	
I/C SOLENOID		XXX A	
ATF PRES SW 3		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4795E

Item name	Condition	Display value (Approx.)
I/C SOLENOID	Input clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Input clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 3	Input clutch engaged. Refer to AT-21 .	ON
	Input clutch disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-149, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1757 FRONT BRAKE SOLENOID VALVE

DTC P1757 FRONT BRAKE SOLENOID VALVE

PPF:31940

Description

NCS001NH

Front brake solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

NCS001NI

Item name	Condition	Display value (Approx.)
FR/B SOLENOID	Front brake engaged. Refer to AT-21 .	0.6 - 0.8 A
	Front brake disengaged. Refer to AT-21 .	0 - 0.05 A

On Board Diagnosis Logic

NCS001NJ

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1757 FR/B SOLENOID/CIRC" with CONSULT-II or 6th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS001NK

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Front brake solenoid valve

DTC Confirmation Procedure

NCS001NL

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "ACCELE POSI", "SLCT LVR POSI" and "GEAR".
3. Touch "START".
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

ACCELE POSI: 1.5/8 - 2.0/8

SLCT LVR POSI: "D" position


GEAR: "3" ⇒ "4" (FR/B ON/OFF)

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

6. If DTC is detected go to [AT-152, "Diagnostic Procedure"](#).

Ⓟ WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P1757 FRONT BRAKE SOLENOID VALVE

NCS001NM

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "FR/B SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
FR/B SOLENOID	Front brake engaged. Refer to AT-21 .	0.6 - 0.8 A
	Front brake disengaged. Refer to AT-21 .	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-151, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

PFP:31940

Description

NCS001NN

- Front brake solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

NCS001NO

Item name	Condition	Display value (Approx.)
FR/B SOLENOID	Front brake engaged. Refer to AT-21 .	0.6 - 0.8 A
	Front brake disengaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 1	Front brake engaged. Refer to AT-21 .	ON
	Front brake disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001NP

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1759 FR/B SOLENOID FNCT" with CONSULT-II or 6th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change.)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 1 is irregular during releasing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001NQ

- Harness or connectors
(Solenoid and switch circuits are open or shorted.)
- Front brake solenoid valve
- ATF pressure switch 1

DTC Confirmation Procedure

NCS001NR

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: "D" position
GEAR: "3" ⇒ "4" (FR/B ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1759) is detected, go to [AT-154, "Diagnostic Procedure"](#) .
If DTC (P1757) is detected, go to [AT-152, "Diagnostic Procedure"](#) .
If DTC (P1841) is detected, go to [AT-173, "Diagnostic Procedure"](#) .



DTC P1759 FRONT BRAKE SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "WITH CONSULT-II".


Diagnostic Procedure

NCS001NS

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 1" and electrical current value of "FR/B SOLENOID".



Item name	Condition	Display value (Approx.)
FR/B SOLENOID	Front brake engaged. Refer to AT-21 .	0.6 - 0.8 A
	Front brake disengaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 1	Front brake engaged. Refer to AT-21 .	ON
	Front brake disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-153, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1762 DIRECT CLUTCH SOLENOID VALVE

DTC P1762 DIRECT CLUTCH SOLENOID VALVE

PDF:31940

Description

NCS001NT

Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

NCS001NU

Item name	Condition	Display value (Approx.)
D/C SOLENOID	Direct clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Direct clutch engaged. Refer to AT-21 .	0 - 0.05 A

On Board Diagnosis Logic

NCS001NV

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1762 D/C SOLENOID/CIRC" with CONSULT-II or 2nd judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS001NW

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Direct clutch solenoid valve

DTC Confirmation Procedure

NCS001NX

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II and check monitor "ACCELE POSI", "SLCT LVR POSI" and "GEAR".
3. Touch "START".
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

ACCELE POSI: 1.5/8 - 2.0/8

SLCT LVR POSI: "D" position


GEAR: "1" ⇒ "2" (D/C ON/OFF)

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

6. If DTC is detected, go to [AT-156, "Diagnostic Procedure"](#) .

Ⓟ WITH GST

Follow the procedure "WITH CONSULT-II".



DTC P1762 DIRECT CLUTCH SOLENOID VALVE

NCS001NY

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "D/C SOLENOID" while driving.

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
	RECORD
MODE	BACK
LIGHT	COPY

SCIA4793E

Item name	Condition	Display value (Approx.)
D/C SOLENOID	Direct clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Direct clutch engaged. Refer to AT-21 .	0 - 0.05 A

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-155, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

PFP:31940

Description

NCS001NZ

- Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

NCS00100

Item name	Condition	Display value (Approx.)
D/C SOLENOID	Direct clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Direct clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 5	Direct clutch engaged. Refer to AT-21 .	ON
	Direct clutch disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS00101

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1764 D/C SOLENOID FNCTN” with CONSULT-II or 2nd judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change.)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 5 is irregular during releasing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS00102

- Harness or connectors (Solenoid and switch circuits are open or shorted.)
- Direct clutch solenoid valve
- ATF pressure switch 5

DTC Confirmation Procedure

NCS00103

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “1” ⇒ “2” (D/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II. If DTC (P1764) is detected, go to [AT-158, "Diagnostic Procedure"](#) .
If DTC (P1762) is detected, go to [AT-156, "Diagnostic Procedure"](#) .
If DTC (P1845) is detected, go to [AT-177, "Diagnostic Procedure"](#) .



DTC P1764 DIRECT CLUTCH SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "WITH CONSULT-II".

Diagnostic Procedure

NCS00104

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (1st ⇒ 2nd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 5" and electrical current value of "D/C SOLENOID".

DATA MONITOR			
MONITOR		NO DTC	
D/C SOLENOID		XXXXA	
ATF PRES SW 5		OFF	
		RECORD	
MODE	BACK	LIGHT	COPY

SCIA4797E

Item name	Condition	Display value (Approx.)
D/C SOLENOID	Direct clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	Direct clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 5	Direct clutch engaged. Refer to AT-21 .	ON
	Direct clutch disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-157, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

PPF:31940

Description

NCS00105

High and low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

NCS00106

Item name	Condition	Display value (Approx.)
HLR/C SOL	High and low reverse clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	High and low reverse clutch engaged. Refer to AT-21 .	0 - 0.05 A

On Board Diagnosis Logic

NCS00107

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1767 HLR/C SOL/CIRC” with CONSULT-II or 8th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects an improper voltage drop when it tries to operate the solenoid valve.
 - When TCM detects as irregular by comparing target value with monitor value.

Possible Cause

NCS00108

- Harness or connectors
(Solenoid circuit is open or shorted.)
- High and low reverse clutch solenoid valve

DTC Confirmation Procedure

NCS00109

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “SELECTION FROM MENU” in “DATA MONITOR” mode for “A/T” with CONSULT-II and check monitor “ACCELE POSI”, “SLCT LVR POSI” and “GEAR”.
3. Touch “START”.
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.

ACCELE POSI: 1.5/8 - 2.0/8

SLCT LVR POSI: “D” position


GEAR: “2” ⇒ “3” (HLR/C ON/OFF)

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

6. If DTC is detected, go to [AT-160, "Diagnostic Procedure"](#) .

Ⓟ WITH GST

Follow the procedure “WITH CONSULT-II”.



DTC P1767 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE

NCS0010A

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "HLR/C SOLENOID" while driving.

Item name	Condition	Display value (Approx.)
HLR/C SOL	High and low reverse clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	High and low reverse clutch engaged. Refer to AT-21 .	0 - 0.05 A

DATA MONITOR	
MONITOR	NO DTC
TCC SOLENOID	XXXX
LINE PRES SOL	XXXX
I/C SOLENOID	XXXX
FR/B SOLENOID	XXXX
D/C SOLENOID	XXXX
HLR/C SOL	XXXX
	▽
RECORD	
MODE	BACK
LIGHT	COPY

SCIA4793E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-159, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

PPF:31940

Description

NCS0010B

- High and low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

NCS0010C

Item name	Condition	Display value (Approx.)
HLR/C SOL	High and low reverse clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	High and low reverse clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 6	High and low reverse clutch engaged. Refer to AT-21 .	ON
	High and low reverse clutch disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS0010D

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1769 HLR/C SOL FNCTN" with CONSULT-II or 8th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change.)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 6 is irregular during releasing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS0010E

- Harness or connectors (Solenoid and switch circuits are open or shorted.)
- High and low reverse clutch solenoid valve
- ATF pressure switch 6

DTC Confirmation Procedure

NCS0010F

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: "D" position
GEAR: "2" ⇒ "3" (HLR/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check "SELF-DIAG RESULTS" mode for "A/T" with CONSULT-II. If DTC (P1769) is detected, go to [AT-162, "Diagnostic Procedure"](#) .
If DTC (P1767) is detected, go to [AT-160, "Diagnostic Procedure"](#) .
If DTC (P1846) is detected, go to [AT-179, "Diagnostic Procedure"](#) .



DTC P1769 HIGH AND LOW REVERSE CLUTCH SOLENOID VALVE FUNCTION

WITH GST

Follow the procedure "WITH CONSULT-II".


Diagnostic Procedure

NCS0010G

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (2nd ⇒ 3rd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 6" and electrical current value of "HLR/C SOL".



Item name	Condition	Display value (Approx.)
HLR/C SOL	High and low reverse clutch disengaged. Refer to AT-21 .	0.6 - 0.8 A
	High and low reverse clutch engaged. Refer to AT-21 .	0 - 0.05 A
ATF PRES SW 6	High and low reverse clutch engaged. Refer to AT-21 .	ON
	High and low reverse clutch disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-161, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

PFP:31940

Description

NCS0010H

Low coast brake solenoid valve is turned ON or OFF by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

CONSULT-II Reference Value

NCS0010J

Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS0010J

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1772 LC/B SOLENOID/CIRC” with CONSULT-II or 7th judgement flicker without CONSULT-II is detected when TCM detects an improper voltage drop when it tries to operate the solenoid valve.

Possible Cause

NCS0010K

- Harness or connectors
(Solenoid circuit is open or shorted.)
- Low coast brake solenoid valve

DTC Confirmation Procedure

NCS0010L

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓟ WITH CONSULT-II

1. Turn ignition switch ON.
2. Select “SELECTION FROM MENU” in “DATA MONITOR” mode for “A/T” with CONSULT-II and check monitor “MANU SW” and “GEAR”.
3. Touch “START”.
4. Start engine.
5. Drive vehicle and maintain the following conditions for at least 5 consecutive seconds.
MANU MODE SW: ON
GEAR: “1” or “2” (LC/B ON/OFF)
6. If DTC is detected, go to [AT-164, "Diagnostic Procedure"](#) .



Ⓟ WITH GST

Follow the procedure “WITH CONSULT-II”.

DTC P1772 LOW COAST BRAKE SOLENOID VALVE

NCS0010M

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Turn ignition switch ON.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Read out the value of "ON OFF SOL" while driving.

Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG


- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-163, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.



DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION

PF3:31940

Description

NCS0010N

- Low coast brake solenoid valve is turned ON or OFF by the TCM in response to signals sent from the PNP switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.
- This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

CONSULT-II Reference Value

NCS0010O

Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF
ATF PRES SW 2	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS0010P

- This is an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1774 LC/B SOLENOID FNCT” with CONSULT-II or 7th judgement flicker without CONSULT-II is detected under the following conditions.
 - When TCM detects that actual gear ratio is irregular, and relation between gear position and condition of ATF pressure switch 2 is irregular during depressing accelerator pedal. (Other than during shift change.)
 - When TCM detects that relation between gear position and condition of ATF pressure switch 2 is irregular during releasing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS0010Q

- Harness or connectors (Solenoid and switch circuits are open or shorted.)
- Low coast brake solenoid valve
- ATF pressure switch 2

DTC Confirmation Procedure

NCS0010R

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
MANU MODE SW: ON
GEAR: “1” or “2” (LC/B ON/OFF)
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II. If DTC (P1774) is detected, go to [AT-166, "Diagnostic Procedure"](#) .
If DTC (P1772) is detected, go to [AT-164, "Diagnostic Procedure"](#) .



WITH GST

Follow the procedure “WITH CONSULT-II”.

DTC P1774 LOW COAST BRAKE SOLENOID VALVE FUNCTION


NCS0010S

Diagnostic Procedure

1. CHECK INPUT SIGNALS

With CONSULT-II

1. Start engine.
2. Select "SELECTION FROM MENU" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the manual mode ("1st" or "2nd" gear), and confirm the ON/OFF actuation of the "ATF PRES SW 2" and "ON OFF SOL".



Item name	Condition	Display value
ON OFF SOL	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF
ATF PRES SW 2	Low coast brake engaged. Refer to AT-21 .	ON
	Low coast brake disengaged. Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-165, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1815 MANUAL MODE SWITCH

DTC P1815 MANUAL MODE SWITCH

PFP:34901

Description

NCS0010T

Manual mode switch is installed in A/T device. It sends manual mode switch, shift up and shift down switch signals to TCM.

TCM sends the switch signals to combination meters. By CAN communication line. Then manual mode switch position is indicated on the A/T indicator. For inspection, refer to [AT-186, "A/T INDICATOR CIRCUIT"](#).

CONSULT-II Reference Value

NCS0010U

Item name	Condition	Display Value
MANU MODE SW	Manual shift gate position (neutral)	ON
	Other than the above	OFF
NON M-MODE SW	Manual shift gate position	OFF
	Other than the above	ON
UP SW LEVER	Selector lever: + side	ON
	Other than the above	OFF
DOWN SW LEVER	Selector lever: - side	ON
	Other than the above	OFF

On Board Diagnosis Logic

NCS0010V

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code "P1815 MANU MODE SW/CIRC" with CONSULT-II is detected when TCM monitors Manual mode, Non manual mode, Up or Down switch signal, and detects as irregular when impossible input pattern occurs 1 second or more.

Possible Cause

NCS0010W

- Harness or connectors
(These switches circuit is open or shorted.)
- Manual mode select switch (Into control device)
- Manual mode position select switch (Into control device)

DTC Confirmation Procedure

NCS0010X

CAUTION:

Always drive vehicle at a safe speed.


NOTE:

If "DTC Confirmation Procedure" has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Turn ignition switch ON.
2. Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Start engine.
4. Drive vehicle and maintain the following conditions for at least 2 consecutive seconds.
MANU MODE SW: ON
5. If DTC is detected, go to [AT-170, "Diagnostic Procedure"](#).





DTC P1815 MANUAL MODE SWITCH

NCS0010Y

Wiring Diagram — AT — MMSW

AT-MMSW-01



REFER TO THE FOLLOWING.
 (F102) -SUPER MULTIPLE JUNCTION (SMJ)
 (M4) -FUSE BLOCK-JUNCTION BOX (J/B)



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0347E


DTC P1815 MANUAL MODE SWITCH

AT-MMSW-02

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC




REFER TO THE FOLLOWING.
 (M4), (M5) - FUSE BLOCK-JUNCTION BOX (J/B)



TCWT0420E

DTC P1815 MANUAL MODE SWITCH

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Item	Condition	Data (Approx.)
3	CAN-H	-	-
8	CAN-L	-	-
9	Starter relay	 Selector lever in "N", "P" positions.	Battery voltage
		Selector lever in "R", "D" positions.	0 V

Diagnostic Procedure

NCS0010Z

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .
 NO >> GO TO 2.

2. CHECK MANUAL MODE SWITCH CIRCUIT

With CONSULT-II

- Turn ignition switch ON.
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Read out ON/OFF switching action of "MANU MODE SW", "NON M-MODE SW", "UP SW LEVER", "DOWN SW LEVER".

DATA MONITOR			
MONITOR	NO DTC		
MANU MODE SW	OFF		
NON M-MODE SW	ON		
UP SW LEVER	OFF		
DOWN SW LEVER	OFF		
△			
RECORD			
MODE	BACK	LIGHT	COPY

SCIA4988E

Item name	Condition	Display Value
MANU MODE SW	Manual shift gate position (neutral)	ON
	Other than the above	OFF
NON M-MODE SW	Manual shift gate position	OFF
	Other than the above	ON
UP SW LEVER	Selector lever: +side	ON
	Other than the above	OFF
DOWN SW LEVER	Selector lever: -side	ON
	Other than the above	OFF

Without CONSULT-II

Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ⇔ 5th gear).

OK or NG

- OK >> GO TO 4.
 NG >> GO TO 3.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- Manual mode switch. Refer to [AT-171, "Component Inspection"](#) .
- Pin terminals for damage or loose connection with harness connector.
- Open circuit or short to ground or short to power in harness or connector for A/T device (manual mode switch).
- Unified meter and A/C amp. Refer to [DI-5, "COMBINATION METERS"](#) .

OK or NG

- OK >> GO TO 4.
 NG >> Repair or replace damaged parts.

DTC P1815 MANUAL MODE SWITCH

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-167, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 5.

5. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

6. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG


- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- NG >> Repair or replace damaged parts.

Component Inspection MANUAL MODE SWITCH

NCS001P0

Check continuity between terminals.

Item	Position	Connector	Terminal	Continuity
Manual mode select switch	Auto	M133	4 - 5	Yes
	Manual		1 - 4	
Manual mode position select switch	UP		3 - 4	
	DOWN		2 - 4	



DTC P1841 ATF PRESSURE SWITCH 1

DTC P1841 ATF PRESSURE SWITCH 1

PFP:25240

Description

NCS001P1

Fail-safe function to detect front brake solenoid valve condition.

CONSULT-II Reference Value

NCS001P2

Item name	Condition	Display value
ATF PRES SW 1	Front brake engaged. Refer to AT-21 .	ON
	Front brake disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001P3

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1841 ATF PRES SW 1/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 1 is irregular during depressing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001P4

- ATF pressure switch 1
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

NCS001P5

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “3” ⇒ “4” (FR/B ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.

If DTC (P1841) is detected, go to [AT-173, "Diagnostic Procedure"](#) .

If DTC (P1757) is detected, go to [AT-152, "Diagnostic Procedure"](#) .



DTC P1841 ATF PRESSURE SWITCH 1

Diagnostic Procedure

NCS001P6

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 1".

Item name	Condition	Display value
ATF PRES SW 1	Front brake engaged. Refer to AT-21 .	ON
	Front brake disengaged. Refer to AT-21 .	OFF

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF

△	▽		
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0067E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#).

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#).
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-172, "DTC Confirmation Procedure"](#).

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1843 ATF PRESSURE SWITCH 3

DTC P1843 ATF PRESSURE SWITCH 3

PFP:25240

Description

NCS001P7

Fail-safe function to detect input clutch solenoid valve condition.

CONSULT-II Reference Value

NCS001PB

Item name	Condition	Display value
ATF PRES SW 3	Input clutch engaged. Refer to AT-21 .	ON
	Input clutch disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001P9

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1843 ATF PRES SW 3/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 3 is irregular during depressing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001PA

- ATF pressure switch 3
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

NCS001PB

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “3” ⇒ “4” (I/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.

If DTC (P1843) is detected, go to [AT-175, "Diagnostic Procedure"](#) .

If DTC (P1752) is detected, go to [AT-148, "Diagnostic Procedure"](#) .



DTC P1843 ATF PRESSURE SWITCH 3

Diagnostic Procedure

NCS001PC

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (3rd ⇒ 4th gear), and confirm the ON/OFF actuation of the "ATF PRES SW 3".

Item name	Condition	Display value
ATF PRES SW 3	Input clutch engaged. Refer to AT-21 .	ON
	Input clutch disengaged. Refer to AT-21 .	OFF

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF

△	▽		
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0067E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-174, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1845 ATF PRESSURE SWITCH 5

DTC P1845 ATF PRESSURE SWITCH 5

PFP:25240

Description

NCS001PD

Fail-safe function to detect direct clutch solenoid valve condition.

CONSULT-II Reference Value

NCS001PE

Item name	Condition	Display value
ATF PRES SW 5	Direct clutch engaged. Refer to AT-21 .	ON
	Direct clutch disengaged. Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001PF

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1845 ATF PRES SW 5/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 5 is irregular during depressing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001PG

- ATF pressure switch 5
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

NCS001PH

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “1” ⇒ “2” (D/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.

If DTC (P1845) is detected, go to [AT-177, "Diagnostic Procedure"](#) .

If DTC (P1762) is detected, go to [AT-156, "Diagnostic Procedure"](#) .



DTC P1845 ATF PRESSURE SWITCH 5

Diagnostic Procedure

NCS001PI

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (1st ⇒ 2nd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 5".

Item name	Condition	Display value
ATF PRES SW 5	Direct clutch engaged. Refer to AT-21 .	ON
	Direct clutch disengaged. Refer to AT-21 .	OFF

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF

△	▽		
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0067E

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-176, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

DTC P1846 ATF PRESSURE SWITCH 6

DTC P1846 ATF PRESSURE SWITCH 6

PFP:25240

Description

NCS001PJ

Fail-safe function to detect high and low reverse clutch solenoid valve condition.

CONSULT-II Reference Value

NCS001PK

Item name	Condition	Display value
ATF PRES SW 6	High and low reverse clutch engaged. Refer to AT-21 .	ON
	High and low reverse clutch disengaged Refer to AT-21 .	OFF

On Board Diagnosis Logic

NCS001PL

- This is not an OBD-II self-diagnostic item.
- Diagnostic trouble code “P1846 ATF PRES SW 6/CIRC” with CONSULT-II is detected when TCM detects that actual gear ratio is normal, and relation between gear position and condition of ATF pressure switch 6 is irregular during depressing accelerator pedal. (Other than during shift change.)

Possible Cause

NCS001PM

- ATF pressure switch 6
- Harness or connectors
(Switch circuit is open or shorted.)

DTC Confirmation Procedure

NCS001PN

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DTC Confirmation Procedure” has been previously performed, always turn ignition switch OFF and wait at least 10 seconds before performing the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

WITH CONSULT-II

1. Start engine.
2. Accelerate vehicle to maintain the following conditions.
ACCELE POSI: 1.5/8 - 2.0/8
SLCT LVR POSI: “D” position
GEAR: “2” ⇒ “3” (HLR/C ON/OFF)
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
3. Perform step 2 again.
4. Turn ignition switch OFF, then perform step 1 to 3 again.
5. Check “SELF-DIAG RESULTS” mode for “A/T” with CONSULT-II.

If DTC (P1846) is detected, go to [AT-179, "Diagnostic Procedure"](#) .

If DTC (P1767) is detected, go to [AT-160, "Diagnostic Procedure"](#) .



DTC P1846 ATF PRESSURE SWITCH 6

NCS001PO

Diagnostic Procedure

1. CHECK INPUT SIGNAL

With CONSULT-II

1. Start engine.
2. Select "ECU INPUT SIGNALS" or "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
3. Drive vehicle in the "D" position (2nd ⇒ 3rd gear), and confirm the ON/OFF actuation of the "ATF PRES SW 6".

DATA MONITOR	
MONITOR	NO DTC
ATF PRES SW 1	OFF
ATF PRES SW 2	OFF
ATF PRES SW 3	OFF
ATF PRES SW 5	OFF
ATF PRES SW 6	OFF

△	▽		
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0067E

Item name	Condition	Display value
ATF PRES SW 6	High and low reverse clutch engaged. Refer to AT-21 .	ON
	High and low reverse clutch disengaged Refer to AT-21 .	OFF

OK or NG

- OK >> GO TO 4.
NG >> GO TO 2.

2. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Repair or replace damaged parts.

3. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector pin terminals for damage or loose connection with harness connector.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
NG >> Repair or replace damaged parts.

4. CHECK DTC

Perform "DTC Confirmation Procedure". Refer to [AT-178, "DTC Confirmation Procedure"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 2.

MAIN POWER SUPPLY AND GROUND CIRCUIT





MAIN POWER SUPPLY AND GROUND CIRCUIT

PF0:00100

Wiring Diagram — AT — MAIN

NCS001PP

AT-MAIN-01



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



REFER TO THE FOLLOWING.

(E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)

TCWT0349E

MAIN POWER SUPPLY AND GROUND CIRCUIT

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Item	Condition		Data (Approx.)
1	Power supply (Memory back-up)	Always		Battery voltage
2	Power supply (Memory back-up)	Always		Battery voltage
5	Ground	Always		0 V
6	Power supply		-	Battery voltage
			-	0 V
10	Ground	Always		0 V


Diagnostic Procedure

NCS001PQ

1. CHECK TCM POWER SOURCE STEP 1

- Turn ignition switch OFF.
- Disconnect A/T assembly harness connector.
- Check voltage between A/T assembly harness connector terminals and ground.

Item	Connector	Terminal	Voltage
TCM	F42	1 - Ground	Battery voltage
		2 - Ground	
		6 - Ground	0 V




OK or NG

- OK >> GO TO 2.
NG >> GO TO 3.

2. CHECK TCM POWER SOURCE STEP 2

- Disconnect A/T assembly harness connector.
- Turn ignition switch ON.
- Check voltage between A/T assembly harness connector terminals and ground.

Item	Connector	Terminal	Voltage
TCM	F42	1 - Ground	Battery voltage
		2 - Ground	
		6 - Ground	0 V



OK or NG

- OK >> GO TO 4.
NG >> GO TO 3.

MAIN POWER SUPPLY AND GROUND CIRCUIT

3. DETECT MALFUNCTIONING ITEM

Check the following.

- Harness for short or open between battery and A/T assembly harness connector terminals 1, 2
- Harness for short or open between push-button ignition switch and A/T assembly harness connector terminal 6
- 10A fuse (No. 34, located in the fuse and fusible link block) and 10A fuse (No. 83, located in the IPDM E/R)
- Push-button ignition switch (Refer to [PG-3, "POWER SUPPLY ROUTING CIRCUIT"](#))

OK or NG

- OK >> GO TO 4.
NG >> Repair or replace damaged parts.

4. CHECK TCM GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect A/T assembly harness connector.
3. Check continuity between A/T assembly harness connector terminals and ground.

Continuity should exist.

If OK, check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 5.
NG >> Repair open circuit or short to ground or short to power in harness or connectors.



5. DETECT MALFUNCTIONING ITEM

Check the following.

- The A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> GO TO 6.
NG >> Repair or replace damaged parts.

6. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) .

OK or NG


- OK >> **INSPECTION END**
NG-1 >> Self-diagnosis does not activate: GO TO 7.
NG-2 >> DTC is displayed: Check the malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) .

MAIN POWER SUPPLY AND GROUND CIRCUIT

7. CHECK TERMINAL CORD ASSEMBLY


1. Remove control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disconnect A/T assembly harness connector and TCM connector.
3. Check continuity between A/T assembly harness connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
A/T assembly harness connector	F42	1	Yes
TCM connector	F502	9	
A/T assembly harness connector	F42	2	Yes
TCM connector	F502	10	
A/T assembly harness connector	F42	6	Yes
TCM connector	F502	4	



4. Check continuity between A/T assembly harness connector terminals and TCM connector terminals.

Item	Connector	Terminal	Continuity
A/T assembly harness connector	F42	5	Yes
TCM connector	F504	21	
A/T assembly harness connector	F42	10	Yes
TCM connector	F504	22	



5. If OK, check harness for short to ground and short to power.

OK or NG

- OK >> Replace the control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- NG >> Replace open circuit or short to ground and short to power in harness or connectors.

CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

CLOSED THROTTLE POSITION AND WIDE OPEN THROTTLE POSITION CIRCUIT

PFP:18002

CONSULT-II Reference Value

NCS001PR

Item name	Condition	Display value
CLSD THL POS	Released accelerator pedal.	ON
	Fully depressed accelerator pedal.	OFF
W/O THL POS	Fully depressed accelerator pedal.	ON
	Released accelerator pedal.	OFF

Diagnostic Procedure

NCS001PS

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .
 NO >> GO TO 2.

2. CHECK THROTTLE POSITION SIGNAL CIRCUIT

With CONSULT-II

- Turn ignition switch ON.
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Depress accelerator pedal and read out the value of "CLSD THL POS" and "W/O THL POS".

Accelerator Pedal Operation	Monitor Item	
	CLSD THL POS	W/O THL POS
Released	ON	OFF
Fully depressed	OFF	ON

DATA MONITOR			
MONITOR		NO DTC	
ACCELE POSI	0.0/8		
THROTTLE POSI	0.0/8		
CLSD THL POS	ON		
W/O THL POS	OFF		
BRAKE SW	OFF		
		▽	
RECORD			
MODE	BACK	LIGHT	COPY

PCIA0070E

OK or NG

OK >> **INSPECTION END**

NG >> Check the following. If NG, repair or replace damaged parts.

- Perform the self-diagnosis for "ENGINE" with CONSULT-II. Refer to [EC-126, "SELF-DIAG RESULTS MODE"](#) (for VQ35DE engine), [EC-829, "SELF-DIAG RESULTS MODE"](#) (for VK45DE engine).
- Open circuit or short to ground or short to power in harness or connectors.
- Pin terminals for damage or loose connection with harness connector.

BRAKE SIGNAL CIRCUIT

BRAKE SIGNAL CIRCUIT

PFP:25320

CONSULT-II Reference Value

NCS001PT

Item name	Condition	Display value
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF

Diagnostic Procedure

NCS001PU

1. CHECK CAN COMMUNICATION LINE

Perform the self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "Diagnostic Procedure without CONSULT-II"](#) .

Is a malfunction in the CAN communication indicated in the results?


- YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .
 NO >> GO TO 2.

2. CHECK STOP LAMP SWITCH CIRCUIT

With CONSULT-II

- Turn ignition switch ON.
- Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Read out ON/OFF switching action of the "BRAKE SW".

Item name	Condition	Display value
BRAKE SW	Depressed brake pedal.	ON
	Released brake pedal.	OFF



OK or NG

- OK >> **INSPECTION END**
 NG >> GO TO 3.

3. CHECK STOP LAMP SWITCH


Check continuity between stop lamp switch harness connector terminals. Refer to [AT-187, "Wiring Diagram — AT — NONDTC"](#) .

Condition	Continuity
When brake pedal is depressed	Yes
When brake pedal is released	No

Check stop lamp switch after adjusting brake pedal — refer to [BR-6, "BRAKE PEDAL"](#) .

OK or NG

- OK >> Check the following. If NG, repair or replace damaged parts.
- Harness for short or open between battery and stop lamp switch.
 - Harness for short or open between stop lamp switch and unified meter and A/C amp.
 - 10A fuse (No.20, located in fuse block).
- NG >> Repair or replace the stop lamp switch.



A/T INDICATOR CIRCUIT

A/T INDICATOR CIRCUIT

PFP:24810

Description

NCS001PV

TCM sends the switch signals to unified meter and A/C amp. By CAN communication line. Then manual mode switch position is indicated on the A/T indicator.

CONSULT-II Reference Value

NCS001PW

Item name	Condition	Display value
GEAR	During driving	1, 2, 3, 4, 5

Diagnostic Procedure

NCS001PX

1. CHECK INPUT SIGNALS

Ⓟ With CONSULT-II

- Start engine.
- Select "MAIN SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II and read out the value of "GEAR".
- Drive vehicle in the manual mode, and confirm that the actual gear position and the meter's indication of the position mutually coincide when the selector lever is shifted to the "+ (up)" or "- (down)" side (1st ↔ 5th gear).

OK or NG

- OK >> **INSPECTION END**
 NG >> Check the following.

DATA MONITOR	
MONITOR	NO. DTC
VHCLS SE-A/T	0 km/h
THROTTLE POSI	0. 0/8
GEAR	1
ENGINE SPEED	0 rpm
TURBINE REV	0 rpm
▼	
RECORD	
MODE	BACK LIGHT COPY

PCIA0065E

A/T INDICATOR SYMPTOM CHART

Items	Possible location of malfunction
The actual gear position does not change, or shifting into the manual mode is not possible (no gear shifting in the manual mode possible). The A/T indicator is not indicated.	Manual mode switch Refer to AT-167, "DTC P1815 MANUAL MODE SWITCH" . A/T main system (Fail-safe function actuated) ● Refer to AT-92, "SELF-DIAGNOSTIC RESULT MODE" .
The actual gear position changes, but the A/T indicator is not indicated.	Perform the self-diagnosis function. ● Refer to AT-92, "SELF-DIAGNOSTIC RESULT MODE" .
The actual gear position and the indication on the A/T indicator do not coincide.	Perform the self-diagnosis function. ● Refer to AT-92, "SELF-DIAGNOSTIC RESULT MODE" .
Only a specific position or positions is/are not indicated on the A/T indicator.	Check the unified meter and A/C amp. Refer to DI-5, "COMBINATION METERS" .

TROUBLE DIAGNOSIS FOR SYMPTOMS




TROUBLE DIAGNOSIS FOR SYMPTOMS

PFP:00007

Wiring Diagram — AT — NONDTC

NCS001PY

AT-NONDTC-01





REFER TO THE FOLLOWING.

(F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)






*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.



TCWT0421E

TROUBLE DIAGNOSIS FOR SYMPTOMS

AT-NONDTC-02



REFER TO THE FOLLOWING.

(E108), (F102) -SUPER MULTIPLE JUNCTION (SMJ)

(M4) -FUSE BLOCK-JUNCTION BOX (J/B)



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TCWT0351E

TROUBLE DIAGNOSIS FOR SYMPTOMS

AT-NONDTC-03

: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC
 (IC) : WITH ICC




REFER TO THE FOLLOWING.

- (E108) -SUPER MULTIPLE JUNCTION (SMJ)
- (E101) -FUSE BLOCK-JUNCTION BOX (J/B)

TCWT0352E

TROUBLE DIAGNOSIS FOR SYMPTOMS

TCM terminals and data are reference value. Measured between each terminal and ground.

Terminal	Item	Condition		Data (Approx.)
3	CAN-H	-		-
4	K-line (CONSULT-II signal)	The terminal is connected to the data link connector for CONSULT-II.		-
7	Back-up lamp relay		Selector lever in "R" position.	0 V
			Selector lever in other positions.	Battery voltage
8	CAN-L	-		-

A/T CHECK Indicator Lamp Does Not Come On SYMPTOM:

NCS001PZ

A/T CHECK indicator lamp does not come on for about 2 seconds when turning ignition switch to ON.

DIAGNOSTIC PROCEDURE

1. CHECK CAN COMMUNICATION LINE

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is a malfunction in the CAN communication indicated in the results?

- YES >> Check CAN communication line. Refer to [AT-105, "DTC U1000 CAN COMMUNICATION LINE"](#) .
 NO >> GO TO 2.

2. CHECK A/T CHECK INDICATOR LAMP CIRCUIT

Check combination meters. Refer to [DI-5, "COMBINATION METERS"](#) .

OK or NG

- OK >> GO TO 3
 NG >> Repair or replace damaged parts.

3. CHECK TCM POWER SUPPLY AND GROUND CIRCUIT

Check TCM power supply and ground circuit. Refer to [AT-180, "MAIN POWER SUPPLY AND GROUND CIRCUIT"](#) .

OK or NG

- OK >> **INSPECTION END**
 NG >> Repair or replace damaged parts.

Engine Cannot Be Started in "P" or "N" Position SYMPTOM:

NCS001Q0

- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D" or "R" position.

DIAGNOSTIC PROCEDURE

1. CHECK PNP SWITCH CIRCUIT

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnostic results indicate PNP switch?

- YES >> Check malfunctioning system. Refer to [AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .
 NO >> GO TO 2.

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

3. CHECK STARTING SYSTEM

Check starting system. Refer to [SC-8, "STARTING SYSTEM"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

In "P" Position, Vehicle Moves When Pushed SYMPTOM:

NCS001Q1

Even though the selector lever is set in "P" position, the parking mechanism is not actuated, allowing the vehicle to be moved when it is pushed.

DIAGNOSTIC PROCEDURE

1. CHECK PNP SWITCH CIRCUIT

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnostic results indicate PNP switch?

YES >> Check malfunctioning system. Refer to [AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .

NO >> GO TO 2.

2. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

3. CHECK PARKING COMPONENTS

Check parking components. Refer to [AT-250, "REMOVAL AND INSTALLATION \(VQ35DE MODELS\)"](#) (VQ35DE models for 2WD), [AT-301, "DISASSEMBLY"](#) (VQ35DE models for AWD), [AT-257, "REMOVAL AND INSTALLATION \(VK45DE MODELS\)"](#) (VK45DE models).

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

4. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.65).

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS001Q2

In "N" Position, Vehicle Moves

SYMPTOM:

Vehicle moves forward or backward when selecting "N" position.

DIAGNOSTIC PROCEDURE

1. CHECK PNP SWITCH CIRCUIT

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Do the self-diagnostic results indicate PNP switch?

- YES >> Check malfunctioning system. Refer to [AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#) .
NO >> GO TO 2.

2. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 4.
NG >> Refill ATF.

4. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.67).

5. CHECK SYMPTOM

Check again. Refer to [AT-57, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 6.

6. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS001Q3

Large Shock (“N” to “D” Position)

SYMPTOM:

A noticeable shock occurs when the selector lever is shifted from “N” to “D” position.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. ENGINE IDLE SPEED

Check engine idle speed. Refer to [EC-83, "Idle Speed and Ignition Timing Check"](#) (for VQ35DE engine), [EC-785, "Idle Speed and Ignition Timing Check"](#) (for VK45DE engine).

OK or NG

- OK >> GO TO 3.
- NG >> Adjust engine idle speed. Refer to [EC-83, "Idle Speed and Ignition Timing Check"](#) (for VQ35DE engine), [EC-785, "Idle Speed and Ignition Timing Check"](#) (for VK45DE engine).

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Refill ATF.

5. CHECK LINE PRESSURE

Check line pressure at idle with selector lever in “D” position. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 8.
- NG - 1 >> Line pressure high: GO TO 6.
- NG - 2 >> Line pressure low: GO TO 7.

6. DETECT MALFUNCTIONING

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 8.
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

8. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 10.
NG >> GO TO 9.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.1).

OK or NG

- OK >> GO TO 10.
NG >> Repair or replace damaged parts.

10. CHECK SYMPTOM

Check again. Refer to [AT-57, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 11.

11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

Vehicle Does Not Creep Backward in “R” Position

NCS001Q4

SYMPTOM:

The vehicle does not creep in “R” position. Or an extreme lack of acceleration is observed.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnosis results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

4. CHECK STALL TEST

Check stall revolution with selector lever in “M” and “R” positions.

Refer to [AT-53, "STALL TEST"](#) .

OK or NG

- OK >> GO TO 6.
- OK in “M” position, NG in “R” position>>GO TO 5
- NG in both “M” and “R” positions>>GO TO 8.

5. DETECT MALFUNCTIONING ITEM

1. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
2. Check the following.
 - Reverse brake. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 9.
- NG >> Repair or replace damaged parts.

6. CHECK LINE PRESSURE

Check line pressure with the engine idling. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 9.
- NG - 1 >> Line pressure high: GO TO 7.
- NG - 2 >> Line pressure low: GO TO 8.

TROUBLE DIAGNOSIS FOR SYMPTOMS

7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

8. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

9. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 10.
NG >> GO TO 13.

10. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.43).

OK or NG

- OK >> GO TO 11.
NG >> Repair or replace damaged parts.

11. CHECK SYMPTOM

Check again. Refer to [AT-57, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 12.

12. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

13. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.43).

OK or NG

OK >> GO TO 11.

NG >> Repair or replace damaged parts.

Vehicle Does Not Creep Forward in "D" Position SYMPTOM:

NCS001Q5

AT

Vehicle does not creep forward when selecting "D" position.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 2.

2. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 3.

NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK STALL TEST

Check stall revolution with selector lever in "D" position. Refer to [AT-53, "STALL TEST"](#) .

OK or NG

OK >> GO TO 5.

NG >> GO TO 7.

5. CHECK LINE PRESSURE

Check line pressure at idle with selector lever in "D" position. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 8.

NG - 1 >> Line pressure high: GO TO 6.

NG - 2 >> Line pressure low: GO TO 7.

A

B

AT

D

E

F

G

H

I

J

K

L

M

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

8. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 9.
NG >> GO TO 12.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.43).

OK or NG

- OK >> GO TO 10.
NG >> Repair or replace damaged parts.

10. CHECK SYMPTOM

Check again. Refer to [AT-57, "Check at Idle"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 11.

11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

12. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.43).

OK or NG

OK >> GO TO 10.

NG >> Repair or replace damaged parts.

Vehicle Cannot Be Started from D1

NCS001Q6

SYMPTOM:

Vehicle cannot be started from D1 on cruise test - Part 1.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creeps in "R" position.

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-195, "Vehicle Does Not Creep Backward in "R" Position"](#) .

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 3.

3. CHECK ACCELERATOR PEDAL POSITION (APP) SENSOR

Check accelerator pedal position (APP) sensor. Refer to [AT-113, "DTC P0705 PARK/NEUTRAL POSITION SWITCH"](#)

OK or NG

OK >> GO TO 4.

NG >> Repair or replace accelerator pedal position (APP) sensor.

4. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 5.

NG >> Refill ATF.

5. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 8.

NG - 1 >> Line pressure high: GO TO 6.

NG - 2 >> Line pressure low: GO TO 7.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

7. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

8. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 9.
NG >> GO TO 12.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.23).

OK or NG

- OK >> GO TO 10.
NG >> Repair or replace damaged parts.

10. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) , [AT-61, "Cruise Test - Part 2"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 11.

11. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

12. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.23).

OK or NG

- OK >> GO TO 10.
- NG >> Repair or replace damaged parts.

A/T Does Not Shift: D1 → D2

NCS001Q7

SYMPTOM:

The vehicle does not shift-up from the D1 to D2 gear at the specified speed.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creep forward in "D" position and vehicle can be started from D1.

OK or NG

- OK >> GO TO 2.
- NG >> Refer to [AT-197, "Vehicle Does Not Creep Forward in "D" Position"](#) , [AT-199, "Vehicle Cannot Be Started from D1"](#) .

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 7.
- NG - 1 >> Line pressure high: GO TO 5.
- NG - 2 >> Line pressure low: GO TO 6.

5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 8.
NG >> GO TO 11.

8. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.10).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

9. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) , [AT-61, "Cruise Test - Part 2"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 10.

10. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

11. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.10).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS001Q8

A/T Does Not Shift: D2 → D3

SYMPTOM:

The vehicle does not shift-up from D2 to D3 gear at the specified speed.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creep forward in "D" position and vehicle can be started from D1.

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-197, "Vehicle Does Not Creep Forward in "D" Position"](#) , [AT-199, "Vehicle Cannot Be Started from D1"](#) .

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 7.

NG - 1 >> Line pressure high: GO TO 5.

NG - 2 >> Line pressure low: GO TO 6.

5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .

3. Check the following.

- Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 8.
NG >> GO TO 11.

8. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.11).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

9. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) , [AT-61, "Cruise Test - Part 2"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 10.

10. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

11. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.11).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

A/T Does Not Shift: D3 → D4

NCS001Q9

SYMPTOM:

The vehicle does not shift-up from the D3 to D4 gear at the specified speed.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creep forward in "D" position and vehicle can be started from D1.

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-197, "Vehicle Does Not Creep Forward in "D" Position"](#) , [AT-199, "Vehicle Cannot Be Started from D1"](#) .

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 7.

NG - 1 >> Line pressure high: GO TO 5.

NG - 2 >> Line pressure low: GO TO 6.

5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .

3. Check the following.

- Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 8.
NG >> GO TO 11.

8. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.12).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

9. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) , [AT-61, "Cruise Test - Part 2"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 10.

10. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

11. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.12).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

A/T Does Not Shift: D4 → D5

NCS001QA

SYMPTOM:

- The vehicle does not shift-up from the D4 to D5 gear at the specified speed.
- The vehicle does not shift-up from the D4 to D5 gear unless A/T is warmed up.

DIAGNOSTIC PROCEDURE

1. CONFIRM THE SYMPTOM

Check if vehicle creep forward in "D" position and vehicle can be started from D1.

OK or NG

OK >> GO TO 2.

NG >> Refer to [AT-197, "Vehicle Does Not Creep Forward in "D" Position"](#) , [AT-199, "Vehicle Cannot Be Started from D1"](#) .

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 3.

3. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 4.

NG >> Refill ATF.

4. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

OK >> GO TO 7.

NG - 1 >> Line pressure high: GO TO 5.

NG - 2 >> Line pressure low: GO TO 6.

5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .

3. Check the following.

- Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

7. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 8.
NG >> GO TO 11.

8. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.13).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

9. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 10.

10. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

11. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.13).

OK or NG

- OK >> GO TO 9.
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS001QB

A/T Does Not Lock-up

SYMPTOM:

A/T does not lock-up at the specified speed.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK LINE PRESSURE

Check line pressure at the engine stall point. Refer to [AT-55, "LINE PRESSURE TEST"](#) .

OK or NG

- OK >> GO TO 6.
- NG - 1 >> Line pressure high: GO TO 4.
- NG - 2 >> Line pressure low: GO TO 5.

4. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

5. DETECT MALFUNCTIONING ITEM

1. Check control valve with TCM. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Disassemble A/T. Refer to [AT-301, "DISASSEMBLY"](#) .
3. Check the following.
 - Oil pump assembly. Refer to [AT-322, "Oil Pump"](#) .
 - Power train system. Refer to [AT-301, "DISASSEMBLY"](#) .
 - Transmission case. Refer to [AT-301, "DISASSEMBLY"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 7.
NG >> GO TO 10.

7. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.24).

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

8. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 9.

9. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

10. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.24).

OK or NG

- OK >> GO TO 8.
NG >> Repair or replace damaged parts.

A/T Does Not Hold Lock-up Condition **SYMPTOM:**

NCS001QC

The lock-up condition cannot be maintained for more than 30 seconds.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
NO >> GO TO 2.

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 7.

4. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.25).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

7. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.25).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

Lock-up Is Not Released

NCS001QD

SYMPTOM:

The lock-up condition cannot be cancelled even after releasing the accelerator pedal.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 3.

3. CHECK TCM

-
1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
 2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

Engine Speed Does Not Return to Idle

NCS001QE

SYMPTOM:

When a shift-down is performed, the engine speed does not smoothly return to the idling speed.

DIAGNOSTIC PROCEDURE

1. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Refill ATF.

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 3.

TROUBLE DIAGNOSIS FOR SYMPTOMS

3. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 7.

4. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.72).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK SYMPTOM

Check again. Refer to [AT-59, "Cruise Test - Part 1"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 6.

6. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

7. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.72).

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

Cannot Be Changed to Manual Mode SYMPTOM:

NCS001QF

Does not change to manual mode when manual shift gate is used.

DIAGNOSTIC PROCEDURE

1. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 2.
- NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

2. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#)

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> **INSPECTION END**

A/T Does Not Shift: 5th Gear → 4th Gear **SYMPTOM:**

NCS001QG

When shifted from M5 to M4 position in manual mode, does not downshift from 5th to 4th gear.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .

NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

OK >> GO TO 3.

NG >> Refill ATF.

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 4.

NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 9.

TROUBLE DIAGNOSIS FOR SYMPTOMS

6. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.47).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

7. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 3"](#).

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#).
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
- NG >> Repair or replace damaged parts.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.47).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

A/T Does Not Shift: 4th Gear → 3rd Gear

NCS001QH

SYMPTOM:

When shifted from M4 to M3 position in manual mode, does not downshift from 4th to 3rd gear.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

TROUBLE DIAGNOSIS FOR SYMPTOMS

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

OK >> GO TO 4.

NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

OK >> GO TO 5.

NG >> Repair or replace damaged parts.

5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .

2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

OK >> GO TO 6.

NG >> GO TO 9.

6. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.48).

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

7. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 3"](#) .

OK or NG

OK >> **INSPECTION END**

NG >> GO TO 8.

8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .

2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

OK >> **INSPECTION END**

NG >> Repair or replace damaged parts.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.48).

OK or NG

OK >> GO TO 7.

NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS001Q1

A/T Does Not Shift: 3rd Gear → 2nd Gear

SYMPTOM:

When shifted from M3 to M2 position in manual mode, does not downshift from 3rd to 2nd gear.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

6. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.49).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

7. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 3"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS FOR SYMPTOMS

8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.49).

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

A/T Does Not Shift: 2nd Gear → 1st Gear

NCS0010J

SYMPTOM:

When shifted from M2 to M1 position in manual mode, does not downshift from 2nd to 1st gear.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
NG >> Refill ATF.

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace damaged parts.

TROUBLE DIAGNOSIS FOR SYMPTOMS

5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 6.
NG >> GO TO 9.

6. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.50).

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

7. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 3"](#) .

OK or NG

- OK >> **INSPECTION END**
NG >> GO TO 8.

8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.50).

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

A
B
AT
D
E
F
G
H
I
J
K
L
M

TROUBLE DIAGNOSIS FOR SYMPTOMS

NCS0010K

Vehicle Does Not Decelerate by Engine Brake

SYMPTOM:

No engine brake is applied when the gear is shifted from the 2nd to 1st gear.

DIAGNOSTIC PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULTS

Perform self-diagnosis. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-103, "TCM SELF-DIAGNOSTIC PROCEDURE \(NO TOOLS\)"](#) .

Is any malfunction detected by self-diagnostic results?

- YES >> Check malfunctioning system. Refer to [AT-92, "SELF-DIAGNOSTIC RESULT MODE"](#) , [AT-104, "Judgement Self-diagnosis Code"](#) .
- NO >> GO TO 2.

2. CHECK A/T FLUID LEVEL

Check A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Refill ATF.

3. CHECK A/T POSITION

Check A/T position. Refer to [AT-228, "Checking of A/T Position"](#) .

OK or NG

- OK >> GO TO 4.
- NG >> Adjust A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) .

4. CHECK MANUAL MODE SWITCH

Check manual mode switch. Refer to [AT-167, "DTC P1815 MANUAL MODE SWITCH"](#) .

OK or NG

- OK >> GO TO 5.
- NG >> Repair or replace damaged parts.

5. CHECK A/T FLUID CONDITION

1. Remove oil pan. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
2. Check A/T fluid condition. Refer to [AT-53, "A/T Fluid Condition Check"](#) .

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 9.

6. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.58).

OK or NG

- OK >> GO TO 7.
- NG >> Repair or replace damaged parts.

7. CHECK SYMPTOM

Check again. Refer to [AT-61, "Cruise Test - Part 3"](#) .

OK or NG

- OK >> **INSPECTION END**
- NG >> GO TO 8.

TROUBLE DIAGNOSIS FOR SYMPTOMS

8. CHECK TCM

1. Check TCM input/output signals. Refer to [AT-89, "TCM Input/Output Signal Reference Values"](#) .
2. If NG, recheck A/T assembly harness connector terminals for damage or loose connection with harness connector.

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damaged parts.

9. DETECT MALFUNCTIONING ITEM

Check malfunction items. If any items are damaged, repair or replace damaged parts. Refer to [AT-64, "Symptom Chart"](#) (Symptom No.58).

OK or NG

- OK >> GO TO 7.
NG >> Repair or replace damaged parts.

A
B
AT
D
E
F
G
H
I
J
K
L
M


SHIFT CONTROL SYSTEM

SHIFT CONTROL SYSTEM

PF:34901

Control Device Removal and Installation CONTROL DEVICE COMPONENTS (2WD MODELS)

NCS001QL



- | | | |
|------------------------|----------------------|----------------------------|
| 1. Selector lever knob | 2. Lock pin | 3. Control device assembly |
| 4. Snap pin | 5. Plain washer | 6. Color |
| 7. Plain washer | 8. Pivot pin | 9. Control rod |
| 10. Insulator | 11. Dust cover plate | 12. Dust cover |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).


SHIFT CONTROL SYSTEM

REMOVAL

CAUTION:

Make sure that parking brake is applied before removal/installation.

1. Move selector lever to "N" position.
2. Remove knob cover (1) below selector lever downward.
3. Pull lock pin (3) out of selector lever knob (2).
4. Remove selector lever knob (2).
5. Remove cup holder, switch finisher, cluster lid C and A/T console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#)
6. Remove center console. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
7. Disconnect A/T device harness connector.
8. Remove control device assembly.



INSTALLATION

Note the following, and install in the reverse order of removal.


- After installation is completed, adjust and check A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) and [AT-228, "Checking of A/T Position"](#).

A
B
AT
D
E
F
G
H
I
J
K
L
M

SHIFT CONTROL SYSTEM

CONTROL DEVICE COMPONENTS (AWD MODELS)

SEC.349



SCIA6756E

- | | | |
|------------------------|----------------------|----------------------------|
| 1. Selector lever knob | 2. Lock pin | 3. Control device assembly |
| 4. Snap pin | 5. Plain washer | 6. Color |
| 7. Plain washer | 8. Control rod | 9. Bracket |
| 10. Insulator | 11. Dust cover plate | 12. Dust cover |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .





SHIFT CONTROL SYSTEM

REMOVAL

CAUTION:

Make sure that parking brake is applied before removal/installation.

1. Disconnect lower lever of control device and control rod.
2. Move selector lever to "N" position.
3. Remove knob cover (1) below selector lever downward.
4. Pull lock pin (3) out of selector lever knob (2).
5. Remove selector lever knob (2).
6. Remove cup holder, switch finisher, cluster lid C and A/T console finisher. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
7. Remove center console. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#).
8. Disconnect A/T device harness connector.
9. Move selector lever to "P" position.
10. Move driver side seat to the end.
11. Remove one of floor carpet attachment clips (1).
12. Remove control device assembly mounting bolts.
13. Lift control device assembly (1). Then slide to the right till touching floor carpet.
14. Pull control device assembly out in the right-slanting direction while pressing to the right.



A
B
AT
D
E
F
G
H
I
J
K
L
M

SHIFT CONTROL SYSTEM


INSTALLATION

Note the following, and install in the reverse order of removal.

NOTE:

Bend control device assembly (1) to vehicle, then insert lower lever (2) to the rear of vehicle.


- After installation is completed, adjust and check A/T position. Refer to [AT-227, "Adjustment of A/T Position"](#) and [AT-228, "Checking of A/T Position"](#).



Control Rod Removal and Installation CONTROL ROD COMPONENTS (2WD MODELS)

NCS001QM

Refer to the figure below for control rod removal and installation procedure.




- Control device assembly
- A/T assembly
- Manual lever
- Control rod
- Lower lever

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).

SHIFT CONTROL SYSTEM

CONTROL ROD COMPONENTS (AWD MODELS)

Refer to the figure below for control rod removal and installation procedure.




- | | | |
|----------------------------|-----------------|-----------------|
| 1. Control device assembly | 2. A/T assembly | 3. Manual lever |
| 4. Control rod | 5. Lower lever | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#).

Adjustment of A/T Position 2WD MODELS


NCS001QN

1. Loosen nut (2) of pivot pin (1).
2. Place PNP switch and selector lever in "P" position.
3. While pressing lower lever (3) toward rear of vehicle (in "P" position direction), tighten nut (2) to specified torque.
Refer to [AT-226. "CONTROL ROD COMPONENTS \(2WD MODELS\)"](#).



AWD MODELS

1. Loosen nut (2) of bracket (1).
2. Place PNP switch and selector lever in "P" position.
3. While pressing lower lever (3) toward rear of vehicle (in "P" position direction), tighten nut (2) to specified torque.
Refer to [AT-227. "CONTROL ROD COMPONENTS \(AWD MODELS\)"](#).




A
B
AT
D
E
F
G
H
I
J
K
L
M

SHIFT CONTROL SYSTEM

NCS001Q0

Checking of A/T Position

1. Place selector lever in "P" position, and turn ignition switch ON (engine stop).
2. Make sure that selector lever can be shifted to other than "P" position when brake pedal is depressed. Also make sure that selector lever can be shifted from "P" position only when brake pedal is depressed.
3. Move the selector lever and check for excessive effort, sticking, noise or rattle.
4. Confirm the selector lever stops at each position with the feel of engagement when it is moved through all the positions. Check whether or not the actual position the selector lever is in matches the position shown by the shift position indicator and the A/T body.
5. The method of operating the lever to individual positions correctly should be as shown in the figure.
6. When selector button is pressed in "P", "R", or "N" position without applying forward/backward force to selector lever, check button operation for sticking.
7. Confirm the back-up lamps illuminate only when lever is placed in the "R" position. Confirm the back-up lamps does not illuminate when selector lever is pushed against "R" position in the "P" or "N" position.
8. Confirm the engine can only be started with the selector lever in the "P" and "N" positions. (With selector lever in the "P" position, engine can be started even when selector lever is moved forward and backward.)
9. Make sure that A/T is locked completely in "P" position.
10. When selector lever is set to manual shift gate, make sure that manual mode is displayed on combination meter.
Shift selector lever to "+" and "-" sides, and check that set shift position changes.



A/T SHIFT LOCK SYSTEM

A/T SHIFT LOCK SYSTEM

PFP:34950


Description

NCS001QP

The mechanical key interlock mechanism also operates as a shift lock:
With the ignition switch turned to ON, the selector lever cannot be shifted from "P" position to any other positions unless the brake pedal is depressed.

Shift Lock System Electrical Parts Location

NCS001QQ



- | | | |
|--|---------------------------------|-----------------------|
| A. Control device assembly | B. Engine room, right side | C. Brake pedal, upper |
| 1. Shift lock unit (Shift lock solenoid installed) | 2. A/T device harness connector | 3. Shift lock relay |
| 4. Brake pedal | 5. Stop lamp switch | |

A
B
AT
D
E
F
G
H
I
J
K
L
M



A/T SHIFT LOCK SYSTEM

Wiring Diagram — AT — SHIFT

NCS001QR

AT-SHIFT-01

: WITH ICC







REFER TO THE FOLLOWING.
 - FUSE BLOCK-JUNCTION BOX (J/B)

TCWT0353E

A/T SHIFT LOCK SYSTEM

AT-SHIFT-02



REFER TO THE FOLLOWING.

(E108) -SUPER MULTIPLE JUNCTION (SMJ)

(E102) -FUSE BLOCK-JUNCTION BOX (J/B)

TCWT0354E

A/T SHIFT LOCK SYSTEM

NCS001QS

Diagnostic Procedure

SYMPTOM:

- Selector lever cannot be moved from "P" position with key in ON position and brake pedal applied.
- Selector lever can be moved from "P" position with key in ON position and brake pedal released.

1. CHECK SELECTOR LEVER POSITION

Check the selector lever position for damage. Refer to [AT-228, "Checking of A/T Position"](#).

OK or NG

OK >> GO TO 2.

NG >> Adjust control linkage. Refer to [AT-227, "Adjustment of A/T Position"](#).

2. CHECK POWER SOURCE

1. Turn ignition switch OFF.
2. Disconnect shift lock relay.
3. Check voltage between shift lock relay E35 terminal 2 and ground.

Voltage


Brake pedal depressed: Battery voltage

Brake pedal released: 0 V

OK or NG

OK >> GO TO 4.

NG >> GO TO 3.




A/T SHIFT LOCK SYSTEM

3. DETECT MALFUNCTIONING ITEM

Check the following.

- Harness for short or open between battery and stop lamp switch harness connector E124 terminal 1
- Harness for short or open between stop lamp switch harness connector E124 terminal 2 and shift lock relay E35 terminal 2
- 10A fuse [No.20, located in the fuse block (J/B)]
- Stop lamp switch
- Check continuity between stop lamp switch harness connector E124 terminals 1 and 2



Check stop lamp switch after adjusting brake pedal — refer to [BR-6, "BRAKE PEDAL"](#) .

- ICC brake hold relay. Refer to [ACS-69, "ICC Brake Hold Relay"](#) . (With ICC only)
- Harness for short or open between battery and ICC brake hold relay E80 terminal 3. Refer to [ACS-50, "DTC 13 STOP LAMP RLY FIX"](#) . (With ICC only)
- Harness for short or open between ICC brake hold relay E80 terminal 5 and shift lock relay E35 terminal 2. (With ICC only)
- Harness for short or open between ICC sensor integrated unit harness connector E61 terminal 2 and ICC brake hold relay E80 terminal 2. Refer to [ACS-50, "DTC 13 STOP LAMP RLY FIX"](#) . (With ICC only)
- Harness for short or open between ICC brake hold relay E80 terminal 1 and ground. Refer to [ACS-50, "DTC 13 STOP LAMP RLY FIX"](#) . (With ICC only)

OK or NG

OK >> GO TO 4.

NG >> Repair or replace damaged parts.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect shift lock relay.
3. Check continuity between shift lock relay E35 terminal 1 and ground.

CAUTION:

Connect test probe (BLACK) to shift lock relay, and test probe (RED) to ground.


Continuity should exist.

If OK, check harness for short to ground and short to power.

OK or NG

OK >> GO TO 5.

NG >> Repair open circuit or short to ground or short to power in harness or connectors.



A/T SHIFT LOCK SYSTEM

5. CHECK INPUT SIGNAL A/T DEVICE


1. Turn ignition switch OFF.
2. Disconnect A/T device harness connector.
3. Turn ignition switch ON.
4. Check voltage between A/T device harness connector M133 terminal 7 and ground.

Voltage

Brake pedal depressed: Battery voltage
Brake pedal released: 0 V

OK or NG

- OK >> GO TO 7.
 NG >> GO TO 6.



6. DETECT MALFUNCTIONING ITEM


Check the following.

- Harness for short or open between push-button ignition switch and shift lock relay E35 terminal 5
- Harness for short or open between shift lock relay E35 terminal 3 and A/T device harness connector M133 terminal 7
- 10A fuse [No.12, located in the fuse block (J/B)]
- Push-button ignition switch (Refer to [PG-3. "POWER SUPPLY ROUTING CIRCUIT"](#) .)
- Shift lock relay
- Check continuity between shift lock relay E35 terminal 3 and 5

Condition	Continuity
12V direct current supply between terminal 1 and 2	Yes
OFF	No

OK or NG

- OK >> GO TO 7.
 NG >> Repair or replace damaged parts.



7. CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect A/T device harness connector.
3. Check continuity between A/T device harness connector M133 terminal 8 and ground.

Continuity should exist.

If OK, check harness for short to ground and short to power.

OK or NG

- OK >> GO TO 8.
 NG >> Repair open circuit or short to ground or short to power in harness or connectors.



A/T SHIFT LOCK SYSTEM

8. CHECK SHIFT LOCK SOLENOID

1. Connect A/T device harness connector.
2. Turn ignition switch ON.
3. Check shift lock solenoid operation.

Condition	Brake pedal	Operation
When ignition switch is turned to ON position and selector lever is set in "P" position.	Depressed	Yes
	Released	No

OK or NG

- OK >> **INSPECTION END**
NG >> Repair or replace damage parts.

A
B
AT
D
E
F
G
H
I
J
K
L
M


ON-VEHICLE SERVICE

PFP:00000

Control Valve With TCM and A/T Fluid Temperature Sensor 2 COMPONENTS

NCS001QT

SEC. 313•314•315•316•317•319



SCIA8045E

- | | | |
|----------------------------|---------------------------|-----------------------------------|
| 1. A/T | 2. Snap ring | 3. Sub-harness |
| 4. Control valve with TCM | 5. Bracket | 6. A/T fluid temperature sensor 2 |
| 7. Oil pan gasket | 8. Clip | 9. Bracket (VK45DE) |
| 10. Bracket (VK45DE) | 11. Oil pan mounting bolt | 12. Oil pan |
| 13. Magnet | 14. Drain plug | 15. Drain plug gasket |
| 16. Terminal cord assembly | 17. O-ring | |


Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .

ON-VEHICLE SERVICE

CONTROL VALVE WITH TCM REMOVAL AND INSTALLATION


Removal

1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain plug.
3. Disconnect heated oxygen sensor 2 harness connector.
4. Disconnect A/T assembly harness connector.
5. Remove snap ring from A/T assembly harness connector.



6. Push A/T assembly harness connector.


CAUTION:
Be careful not to damage connector.



7. Remove oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.


a. VQ35DE models

- i. Remove clips (1).
- ii. Remove oil pan (2) and oil pan gasket.
⇐: Front
←: Bolt (22)



b. VK45DE models

- i. Remove clips (1) and brackets (2).
- ii. Remove oil pan (3) and oil pan gasket.
⇐: Front
←: Bolt (22)




A
B
AT
D
E
F
G
H
I
J
K
L
M


ON-VEHICLE SERVICE

8. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.

- If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#) .




9. Remove magnets from oil pan.




10. Disconnect A/T fluid temperature sensor 2 connector.

- CAUTION:**
Be careful not to damage connector.




11. Straighten terminal clip to free terminal cord assembly A/T fluid temperature sensor 2 harness.




12. Disconnect revolution sensor connector.

- CAUTION:**
Be careful not to damage connector.




ON-VEHICLE SERVICE

13. Straighten terminal clip to free revolution sensor harness.



14. Remove bolts A, B and C from control valve with TCM.


Bolt symbol	Length mm (in)	Number of bolts
A	42 (1.65)	5
B	55 (2.17)	6
C	40 (1.57)	1




15. Remove control valve with TCM from transmission case.

CAUTION:


When removing, be careful with the manual valve notch and manual plate height. Remove it vertically.



16. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.




17. Remove bracket from A/T fluid temperature sensor 2.



A
B
AT
D
E
F
G
H
I
J
K
L
M


ON-VEHICLE SERVICE

18. Remove O-ring from A/T assembly harness connector.




19. Disconnect TCM connectors.

CAUTION:
Be careful not to damage connectors.




20. Remove A/T assembly harness connector from control valve with TCM using flat-blade screwdriver.



21. Disconnect TCM connector and park/neutral position switch connector

CAUTION:
Be careful not to damage connectors.




Installation

CAUTION:


After completing installation, check A/T fluid leakage and A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

ON-VEHICLE SERVICE


1. Connect TCM connector and park/neutral position switch connector.



2. Install A/T assembly harness connector to control valve with TCM.




3. Connect TCM connectors.




4. Install new O-ring in A/T assembly harness connector.

CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.



5. Install A/T fluid temperature sensor 2 to bracket.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

6. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM. Tighten A/T fluid temperature sensor 2 bolt to the specified torque. Refer to [AT-236, "COMPONENTS"](#) .

CAUTION:


Adjust bolt hole of bracket to bolt hole of control valve with TCM.




7. Install control valve with TCM in transmission case.

CAUTION:

- Make sure that turbine revolution sensor securely installs turbine revolution sensor hole.
- Hang down revolution sensor harness toward outside so as not to disturb installation of control valve with TCM.
- Adjust A/T assembly harness connector of control valve with TCM to terminal hole of transmission case.




- Assemble it so that manual valve cutout is engaged with manual plate projection.




8. Install bolts A, B and C in control valve with TCM.

Bolt symbol	Length mm (in)	Number of bolts
A	42 (1.65)	5
B	55 (2.17)	6
C	40 (1.57)	1




ON-VEHICLE SERVICE


9. Tighten bolt 1, 2 and 3 temporarily to prevent dislocation. After that tighten them in order (1 → 2 → 3), and then tighten other bolts. Tighten control valve with TCM bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#).




10. Connect A/T fluid temperature sensor 2 connector.




11. Securely fasten terminal cord assembly and A/T fluid temperature sensor 2 harness with terminal clips.



12. Connect revolution sensor connector.




13. Securely fasten revolution sensor harness with terminal clip.



A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

14. Install magnets in oil pan.



15. Install oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.

a. VQ35DE models

i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


ii. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

⇐: Front

⬅: Bolt (22)

CAUTION:


- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.



iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#).

CAUTION:

Do not reuse oil pan mounting bolts.



b. VK45DE models

i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.

ON-VEHICLE SERVICE


- ii. Install oil pan (3) (with oil pan gasket), clips (1) and brackets (2) to transmission case.

⇐: Front

←: Bolt (22)

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.
- Be careful with installation direction of brackets (2).



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#).


CAUTION:

Do not reuse oil pan mounting bolts.

16. Install drain plug to oil pan. Tighten drain plug to the specified torque. Refer to [AT-236, "COMPONENTS"](#).

CAUTION:


Do not reuse drain plug gasket.




17. Pull up A/T assembly harness connector.

CAUTION:

Be careful not to damage connector.



18. Install snap ring to A/T assembly harness connector.
 19. Connect A/T assembly harness connector.
 20. Connect heated oxygen sensor 2 harness connector.
 21. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).
 22. Connect the battery cable to the negative terminal.



A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

A/T FLUID TEMPERATURE SENSOR 2 REMOVAL AND INSTALLATION

Removal


1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain plug.
3. Disconnect heated oxygen sensor 2 harness connector.
4. Remove oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.

a. VQ35DE models

- i. Remove clips (1).
- ii. Remove oil pan (2) and oil pan gasket.

⇐: Front

←: Bolt (22)




b. VK45DE models

- i. Remove clips (1) and brackets (2).
- ii. Remove oil pan (3) and oil pan gasket.


⇐: Front

←: Bolt (22)



5. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.


- If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).



6. Disconnect A/T fluid temperature sensor 2 connector.


CAUTION:

Be careful not to damage connector.




ON-VEHICLE SERVICE


7. Straighten terminal clip to free A/T fluid temperature sensor 2 harness.



8. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.



9. Remove bracket from A/T fluid temperature sensor 2.




Installation

CAUTION:

After completing installation, check for A/T fluid leakage and A/T fluid level. Refer to [AT-13. "Checking A/T Fluid"](#).


1. Install A/T fluid temperature sensor 2 to bracket.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE


2. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM. Tighten A/T fluid temperature sensor 2 bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#) .



3. Connect A/T fluid temperature sensor 2 connector.



4. Securely fasten A/T fluid temperature sensor 2 harness with terminal clip.



5. Install oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.

- a. VQ35DE models

- i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


- ii. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

⇐: Front

◄: Bolt (22)

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.




ON-VEHICLE SERVICE

- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#) .

CAUTION:

Do not reuse oil pan mounting bolts.



- b. VK45DE models

- i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


- ii. Install oil pan (3) (with oil pan gasket), clips (1) and brackets (2) to transmission case.

⇐: Front

←: Bolt (22)

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.
- Be careful with installation direction of brackets (2).



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-236, "COMPONENTS"](#) .

CAUTION:


Do not reuse oil pan mounting bolts.

6. Install drain plug to oil pan. Tighten drain plug to the specified torque. Refer to [AT-236, "COMPONENTS"](#) .

CAUTION:

Do not reuse drain plug gasket.

7. Connect heated oxygen sensor 2 harness connector.
 8. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#) .
 9. Connect the battery cable to the negative terminal.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

NCS001QU

Parking Components (2WD Models Only) REMOVAL AND INSTALLATION (VQ35DE MODELS)

Components



Removal

1. Drain ATF through drain plug.
2. Remove exhaust front tube and center muffler with power tool. Refer to [EX-5, "Removal and Installation"](#) .
3. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
4. Remove control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#) .
5. Support A/T assembly with a transmission jack.


CAUTION:

When setting transmission jack, be careful not to allow it to collide against the drain plug.


6. Remove rear engine mounting member with power tool. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
7. Remove engine mounting insulator (rear). Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .

ON-VEHICLE SERVICE


8. Remove tightening bolts for rear extension assembly and transmission case.




9. Tap rear extension assembly with a soft hammer.




10. Remove rear extension assembly from transmission case. (With needle bearing.)



11. Remove bearing race from output shaft.




12. Remove output shaft from transmission case by rotating left/right.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE


13. Remove parking gear from output shaft.




14. Remove seal rings from output shaft.




15. Remove needle bearing (1) from rear extension.



16. Remove parking actuator support from rear extension.




17. Remove parking pawl (with return spring) and pawl shaft from rear extension.




ON-VEHICLE SERVICE

18. Remove return spring (1) from parking pawl (2).





19. Remove rear oil seal from rear extension.

CAUTION:
Be careful not to scratch rear extension.



Inspection

- If the contact surface on parking actuator support, parking pawl, etc. has excessive wear, abrasion, bend, or any other damage, replace the components.



A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

Installation


CAUTION:

After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-13, "Checking A/T Fluid"](#) , [AT-228, "Checking of A/T Position"](#) .


1. As shown in the figure, use a drift to drive rear oil seal into the rear extension until it is flush.

CAUTION:


- Apply ATF to rear oil seal.
- Do not reuse rear oil seal.




2. Install return spring (1) to parking pawl (2).



3. Install parking pawl (with return spring) and pawl shaft to rear extension.



4. Install parking actuator support to rear extension.



ON-VEHICLE SERVICE


5. Install bearing (1) to rear extension.

CAUTION:

- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).

- Apply petroleum jelly to needle bearing.

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).




6. Install seal rings to output shaft.


CAUTION:

- Do not reuse seal rings.


- Apply petroleum jelly to seal rings.




7. Install parking gear to output shaft



8. Install output shaft in transmission case.



9. Install bearing race to output shaft.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

10. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to rear extension assembly as shown in the figure.

CAUTION:


Completely remove all moisture, oil and old sealant, etc. from the transmission case and rear extension assembly mounting surfaces.



11. Install rear extension assembly to transmission case. (With needle bearing.)

CAUTION:


Insert the tip of parking rod between the parking pawl and the parking actuator support when assembling the rear extension assembly.



12. Tighten rear extension assembly bolts to the specified torque. Refer to [AT-250, "Components"](#) .

CAUTION:

Do not reuse self-sealing bolts.




13. Install engine mounting insulator (rear). Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
14. Install rear engine mounting member. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
15. Install control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#) .
16. Install rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
17. Install exhaust front tube and center muffler. Refer to [EX-5, "Removal and Installation"](#) .
18. Install drain plug to oil pan. Tighten a necessary drain plug with specified torque. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- CAUTION:**
- Do not reuse drain plug gasket.**
19. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#) .

ON-VEHICLE SERVICE

REMOVAL AND INSTALLATION (VK45DE MODELS)

Components



- | | | |
|---|-----------------------------|----------------------|
| 1. Output shaft & companion flange complement | 2. Parking actuator support | 3. Return spring |
| 4. Parking pawl | 5. Pawl shaft | 6. Self-sealing bolt |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .

However, refer to the following symbols for others.

: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)

Removal

1. Drain ATF through drain plug.
2. Remove exhaust front tube and center muffler with a power tool. Refer to [EX-7, "Removal and installation"](#)
3. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
4. Remove control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#) .
5. Support A/T assembly with a transmission jack.


CAUTION:

When setting transmission jack, be careful not to allow it to collide against the drain plug.


6. Remove rear engine mounting member with a power tool. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
7. Remove engine mounting insulator (rear). Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .

ON-VEHICLE SERVICE


8. Remove tightening bolts (1) for output shaft & companion flange complement and transmission case.
- ←: Bolt (10)
 - Self-sealing bolts (2)




9. Tap output shaft & companion flange complement with a soft hammer.




10. Remove output shaft & companion flange complement from transmission case.



11. Remove parking actuator support (1) from output shaft & companion flange complement.




12. Remove parking pawl (with return spring) (1) and pawl shaft (2) from output shaft & companion flange complement.





ON-VEHICLE SERVICE

13. Remove return spring (1) from parking pawl (2).



Inspection

- If the contact surface on parking actuator support, parking pawl, etc. has excessive wear, abrasion, bend, or any other damage, replace the components.




Installation

CAUTION:

After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-13, "Checking A/T Fluid"](#), [AT-228, "Checking of A/T Position"](#).


1. Install return spring (1) to parking pawl (2).




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

2. Install parking pawl (with return spring) (1) and pawl shaft (2) in output shaft & companion flange complement.




3. Install parking actuator support (1) in output shaft & companion flange complement.




4. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to output shaft & companion flange complement as shown in the figure.

CAUTION:

Completely remove all moisture, oil and old sealant, etc. from the transmission case and output shaft & companion flange complement mounting surfaces.



5. Install output shaft & companion flange complement to transmission case.




6. Tighten output shaft & companion flange complement bolts (1) to the specified torque. Refer to [AT-257, "Components"](#) .

◀: Bolt (10)

CAUTION:

Do not reuse self-sealing bolts (2).

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .



ON-VEHICLE SERVICE

7. Install engine mounting insulator (rear). Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
 8. Install rear engine mounting member. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
 9. Install control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#) .
 10. Install rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
 11. Install exhaust front tube and center muffler. Refer to [EX-7, "Removal and installation"](#) .
 12. Install drain plug to oil pan. Tighten a necessary drain plug with specified torque. Refer to [AT-236, "Control Valve With TCM and A/T Fluid Temperature Sensor 2"](#) .
- CAUTION:**
Do not reuse drain plug gasket.
13. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#) .

A

B

AT

D

E

F

G

H

I

J

K

L

M


Rear Oil Seal (VQ35DE Models Only) REMOVAL AND INSTALLATION

Removal

1. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .
2. Remove transfer assembly from A/T assembly (AWD models). Refer to [TF-44, "Removal and Installation"](#) .
3. Remove rear oil seal using a flat-bladed screwdriver.

CAUTION:

Be careful not to scratch rear extension assembly (2WD models) or adapter case assembly (AWD models).



Installation


CAUTION:

After completing installation, check for A/T fluid leakage and A/T fluid level. Refer to [AT-13, "Checking A/T Fluid"](#) .

1. As shown in the figure, use the drift to drive rear oil seal into rear extension assembly (2WD models) or adapter case assembly (AWD models) until it is flush.

CAUTION:

- Do not reuse rear oil seal.
 - Apply ATF to rear oil seal.
2. Install transfer assembly to A/T assembly (AWD models). Refer to [TF-44, "Removal and Installation"](#) .
 3. Install rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#) .




ON-VEHICLE SERVICE

Revolution Sensor Components (2WD Models Only) REMOVAL AND INSTALLATION

NCS001QW

Components

VQ35DE models




SCIA8043E

- | | | |
|-----------------------|--------------------------|----------------------|
| 1. Rear extension | 2. A/T | 3. Oil pan gasket |
| 4. Clip | 5. Oil pan mounting bolt | 6. Oil pan |
| 7. Drain plug | 8. Drain plug gasket | 9. Revolution sensor |
| 10. Self-sealing bolt | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).


However, refer to the following symbols for others.

: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)

ON-VEHICLE SERVICE

VK45DE models

SEC. 313•314•319



SCIA8047E

- | | | |
|---|-----------------------|-----------------------|
| 1. Output shaft & companion flange complement | 2. A/T | 3. Oil pan gasket |
| 4. Clip | 5. Bracket | 6. Bracket |
| 7. Oil pan mounting bolt | 8. Oil pan | 9. Drain plug |
| 10. Drain plug gasket | 11. Revolution sensor | 12. Self-sealing bolt |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).

However, refer to the following symbols for others.


: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#)

Removal


1. Disconnect the battery cable from the negative terminal.
2. Drain ATF through drain plug.
3. Remove exhaust front tube and center muffler with power tool. Refer to [EX-5, "Removal and Installation"](#)
4. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#).
5. Remove control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#).
6. Remove oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.
 - a. VQ35DE models

ON-VEHICLE SERVICE

- i. Remove clips (1).
- ii. Remove oil pan (2) and oil pan gasket.
 - ↔: Front
 - ←: Bolt (22)



- b. VK45DE models
 - i. Remove clips (1) and brackets (2).
 - ii. Remove oil pan (3) and oil pan gasket.
 - ↔: Front
 - ←: Bolt (22)




7. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.

- If frictional material is detected, perform **A/T fluid cooler cleaning**. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).

8. Support A/T assembly with a transmission jack.

CAUTION:

When setting transmission jack, place wooden blocks to prevent from damaging control valve with TCM and transmission case.




9. Remove rear engine mounting member with power tool. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#).

10. Remove rear extension assembly (VQ35DE models) or output shaft & companion flange complement (VK45DE models) according to the following procedures.

a. VQ35DE models


- i. Remove tightening bolts for rear extension assembly and transmission case.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE

ii. Tap rear extension assembly with a soft hammer.



iii. Remove rear extension assembly from transmission case. (With needle bearing.)




b. VK45DE models


i. Remove tightening bolts (1) for output shaft & companion flange complement and transmission case.

◄: Bolt (10)

●: Self-sealing bolts (2)




ii. Tap output shaft & companion flange complement with a soft hammer.




ON-VEHICLE SERVICE

- iii. Remove output shaft & companion flange complement from transmission case




11. Disconnect revolution sensor connector.

CAUTION:
Be careful not to damage connector




12. Straighten terminal clip to free revolution sensor harness.



13. Remove revolution sensor from transmission case.

- CAUTION:**
- Do not subject it to impact by dropping or hitting it.
 - Do not disassemble.
 - Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
 - Do not place in an area affected by magnetism.



Installation

CAUTION:

After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-13, "Checking A/T Fluid"](#) , [AT-228, "Checking of A/T Position"](#) .


A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE


1. Install revolution sensor in transmission case. Tighten a necessary bolt for revolution sensor with specified torque. Refer to [AT-263, "Components"](#).

CAUTION:


- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.



2. Connect revolution sensor connector.



3. Securely fasten revolution sensor harness with clip.




4. Install rear extension assembly (VQ35DE models) or output shaft & companion flange complement (VK45DE models) according to the following procedures.

a. **VQ35DE models**

- i. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#).) to rear extension assembly as shown in the figure.

CAUTION:

Completely remove all moisture, oil and old sealant, etc. from transmission case and rear extension assembly mounting surfaces.




ON-VEHICLE SERVICE

- ii. Install rear extension assembly to transmission case. (With needle bearing.)

CAUTION:


Insert the tip of parking rod between the parking pole and the parking actuator support when assembling the rear extension assembly.



- iii. Tighten rear extension assembly bolts to the specified torque. Refer to [AT-263, "REMOVAL AND INSTALLATION"](#).

CAUTION:

Do not reuse self-sealing bolts.




b. **VK45DE models**


- i. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to output shaft & companion flange complement as shown in the figure.

CAUTION:

Completely remove all moisture, oil and old sealant, etc. from the transmission case and output shaft & companion flange complement mounting surfaces.



- ii. Install output shaft & companion flange complement to transmission case.



A
B
AT
D
E
F
G
H
I
J
K
L
M

ON-VEHICLE SERVICE


- iii. Tighten output shaft & companion flange complement bolts (1) to the specified torque. Refer to [AT-263, "REMOVAL AND INSTALLATION"](#) .

←: Bolt (10)

CAUTION:

Do not reuse self-sealing bolts (2).

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .



5. Install rear engine mounting member. Refer to [AT-274, "Removal and Installation \(2WD Models\)"](#) .
6. Install oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.
- a. VQ35DE models
- i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


- ii. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

↔: Front

←: Bolt (22)

CAUTION:


- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-263, "Components"](#) .

CAUTION:

Do not reuse oil pan mounting bolts.



- b. VK45DE models

- i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.

ON-VEHICLE SERVICE


- ii. Install oil pan (3) (with oil pan gasket), clips (1) and brackets (2) to transmission case.

⇐: Front

←: Bolt (22)

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.
- Be careful with installation direction of brackets (2).



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-263, "Components"](#).

CAUTION:

Do not reuse oil pan mounting bolts.

7. Install drain plug to oil pan. Tighten a necessary drain plug with specified torque. Refer to [AT-263, "Components"](#).

CAUTION:

Do not reuse drain plug gasket.


8. Install control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#).

9. Install rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#).

10. Install exhaust front tube and center muffler. Refer to [EX-5, "Removal and Installation"](#).

11. Pour ATF into A/T assembly. Refer to [AT-12, "Changing A/T Fluid"](#).

12. Connect the battery cable to the negative terminal.



A
B
AT
D
E
F
G
H
I
J
K
L
M

AIR BREATHER HOSE


PF3:31098

AIR BREATHER HOSE

Removal and Installation VQ35DE ENGINE MODEL

NCS001QX

Refer to the figure below for air breather hose removal and installation procedure.




CAUTION:

- When installing an air breather hose, be careful not to be crushed or blocked by folding or bending the hose.
- When inserting a hose to the transmission tube, be sure to insert it fully until its end reaches the tube bend "R" portion.

AIR BREATHER HOSE

VK45DE ENGINE MODEL

Refer to the figure below for air breather hose removal and installation procedure.



CAUTION:

- When installing an air breather hose, be careful not to be crushed or blocked by folding or bending the hose.
- When inserting a hose to the transmission tube, be sure to insert it fully until its end reaches the tube bend "R" portion.
- When inserting a hose to the air breather tube, be sure to insert it fully until its end reaches the tube spool portion.

A
B
AT
D
E
F
G
H
I
J
K
L
M

TRANSMISSION ASSEMBLY

PFP:31020


TRANSMISSION ASSEMBLY

Removal and Installation (2WD Models) COMPONENTS

NCS001QY

VQ35DE models

SEC.112 • 310



SCIA6751E

- | | | |
|-----------------|--------------------------------|-------------------------------------|
| 1. A/T assembly | 2. A/T fluid level gauge | 3. A/T fluid charging pipe |
| 4. O-ring | 5. Copper washer | 6. Fluid cooler tube |
| 7. Bracket | 8. Rear engine mounting member | 9. Engine mounting insulator (rear) |


Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .

However, refer to the following symbols for others.

Δ: For tightening torque, refer to [AT-277. "INSTALLATION"](#) .

TRANSMISSION ASSEMBLY

VK45DE models



- | | | |
|-----------------|--------------------------------|-------------------------------------|
| 1. A/T assembly | 2. A/T fluid level gauge | 3. A/T fluid charging pipe |
| 4. O-ring | 5. Copper washer | 6. Fluid cooler tube |
| 7. Bracket | 8. Rear engine mounting member | 9. Engine mounting insulator (rear) |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).

However, refer to following symbols for others.

△: For tightening torque, refer to [AT-277, "INSTALLATION"](#).

REMOVAL

CAUTION:

- When removing the A/T assembly from engine, first remove the crankshaft position sensor (POS) from the A/T assembly.

- Be careful not to damage sensor edge.


1. Disconnect the battery cable from the negative terminal.
2. Remove engine under cover with power tool.
3. Remove A/T fluid level gauge.
4. Remove exhaust front tube and center muffler with power tool. Refer to [EX-5, "Removal and Installation"](#) (for VQ35DE engine), [EX-7, "Removal and installation"](#) (for VK45DE engine).
5. Remove heat insulator.
6. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#).
7. Remove rack stay. Refer to [FSU-9, "Removal and Installation"](#).
8. Remove exhaust mounting bracket. Refer to [EX-5, "Removal and Installation"](#) (for VQ35DE engine), [EX-7, "Removal and installation"](#) (for VK45DE engine).
9. Remove control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#).

TRANSMISSION ASSEMBLY

10. Remove crankshaft position sensor (POS) (1) from A/T assembly.

CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.



11. Remove starter motor. Refer to [SC-14, "VQ35DE ENGINE MODELS \(2WD\)"](#), [SC-16, "VK45DE ENGINE MODELS"](#).

12. Remove rear cover plate. Refer to [EM-31, "Removal and Installation \(2WD Models\)"](#) (for VQ35DE engine).

13. Remove rear plate cover. Refer to [EM-31, "Removal and Installation \(2WD Models\)"](#) (for VQ35DE engine), [EM-187, "Removal and Installation"](#) (for VK45DE engine).

14. Turn crankshaft, and remove the four tightening bolts for drive plate and torque converter.


CAUTION:

When turning the crankshaft, turn it clockwise as viewed from the front of the engine.

15. Support A/T assembly with a transmission jack.

CAUTION:

When setting the transmission jack, be careful not to allow it to collide against the drain plug.



16. Remove rear engine mounting member with power tool.

17. Remove engine mounting insulator (rear).

18. Disconnect A/T assembly harness connector.

19. Remove air breather hose. Refer to [AT-272, "Removal and Installation"](#).

20. Remove A/T fluid charging pipe from A/T assembly.

21. Remove O-ring from A/T fluid charging pipe.

22. Disconnect fluid cooler tube from A/T assembly.


23. Plug up openings such as the A/T fluid charging pipe hole, etc.

24. Remove bolts fixing A/T assembly to engine assembly with power tool.

25. Remove A/T assembly from vehicle.

CAUTION:

- Secure torque converter to prevent it from dropping.
- Secure A/T assembly to a transmission jack.



TRANSMISSION ASSEMBLY

INSPECTION


Installation and Inspection of Torque Converter

- After inserting a torque converter to a A/T, be sure to check distance "A" to ensure it is within the reference value limit.

Distance "A"

VQ35DE models: 25.0 mm (0.98 in) or more

VK45DE models: 22.0 mm (0.87 in) or more




INSTALLATION

Install the removed parts in the reverse order of the removal, while paying attention to the following work.

- When installing A/T assembly to the engine assembly, attach the fixing bolts in accordance with the following standard.


VQ35DE models

Bolt No.	1	2	3	4
Number of bolts	1	5	2	2
Bolt length "ℓ"mm (in)	55 (2.17)	65 (2.56)	65 (2.56)	35 (1.38)
Tightening torque N-m (kg-m, ft-lb)	75 (7.7, 55)		55 (5.6, 41)	47 (4.8, 35)



VK45DE models

Bolt No.	1	2*	3
Number of bolts	5	1	4
Bolt length "ℓ"mm (in)	70 (2.76)	70 (2.76)	65 (2.56)
Tightening torque N-m (kg-m, ft-lb)	113 (12, 83)		74 (7.5, 55)




*: No.2 bolt also secures A/T fluid charging pipe.

- Align the positions of tightening bolts for drive plate with those of the torque converter, and temporarily tighten the bolts. Then, tighten the bolts with the specified torque. Refer to [AT-274, "COMPONENTS"](#).

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening bolts for the torque converter after fixing the crankshaft pulley bolts, be sure to confirm the tightening torque of the crankshaft pulley mounting bolts. Refer to [EM-74, "INSTALLATION"](#) (for VQ35DE engine), [EM-208, "INSTALLATION"](#) (for VK45DE engine).
- After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that A/T rotates freely without binding.




TRANSMISSION ASSEMBLY

- Install crankshaft position sensor (POS). Refer to [EM-31, "Removal and Installation \(2WD Models\)"](#) (for VQ35DE engine), [EM-187, "Removal and Installation"](#) (for VK45DE engine).
- After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-13, "Checking A/T Fluid"](#), [AT-228, "Checking of A/T Position"](#).

Removal and Installation (AWD Models) COMPONENTS

NCS001QZ



SCIA6753E

- | | | |
|--------------------------------------|--------------------------|--------------------------------|
| 1. A/T assembly | 2. A/T fluid level gauge | 3. A/T fluid charging pipe |
| 4. O-ring | 5. Copper washer | 6. Fluid cooler tube |
| 7. Bracket | 8. Heat insulator | 9. Rear engine mounting member |
| 10. Engine mounting insulator (rear) | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).

However, refer to the following symbols for others.

△: For tightening torque, refer to [AT-280, "INSTALLATION"](#).

REMOVAL

CAUTION:

- When removing the A/T assembly from engine, first remove the crankshaft position sensor (POS) from the A/T assembly.
 - Be careful not to damage sensor edge.
1. Disconnect the battery cable from the negative terminal.
 2. Remove engine under cover with power tool.
 3. Remove A/T fluid level gauge.
 4. Remove exhaust front tube and center muffler and with power tool. Refer to [EX-5, "Removal and Installation"](#).

TRANSMISSION ASSEMBLY

5. Remove heat insulator.
6. Remove rear propeller shaft. Refer to [PR-8, "Removal and Installation"](#).
7. Remove front cross bar with power tool. Refer to [FSU-27, "Removal and Installation"](#).
8. Remove exhaust mounting bracket. Refer to [EX-5, "Removal and Installation"](#).
9. Remove three way catalyst. Refer to [EX-5, "Removal and Installation"](#).
10. Remove front propeller shaft. Refer to [PR-5, "Removal and Installation"](#).
11. Remove control rod. Refer to [AT-226, "Control Rod Removal and Installation"](#).

12. Remove crankshaft position sensor (POS) (1) from A/T assembly.

CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.

13. Remove starter motor. Refer to [SC-15, "VQ35DE ENGINE MODELS \(AWD\)"](#).

14. Remove rear plate cover. Refer to [EM-38, "Removal and Installation \(AWD Models\)"](#).

15. Turn crankshaft, and remove the four tightening bolts for drive plate and torque converter.

CAUTION:

When turning the crankshaft, turn it clockwise as viewed from the front of the engine.

16. Support A/T assembly with a transmission jack.

CAUTION:

When setting the transmission jack, be careful not to allow it to collide against the drain plug.

17. Remove rear engine mounting member with power tool.

18. Remove engine mounting insulator (rear).

19. Disconnect A/T assembly harness connector.

20. Remove air breather hose. Refer to [AT-272, "Removal and Installation"](#).

21. Remove A/T fluid charging pipe from A/T assembly.

22. Remove O-ring from A/T fluid charging pipe.

23. Disconnect fluid cooler tube from the A/T assembly.

24. Plug up openings such as the A/T fluid charging pipe hole, etc.




25. Remove bolts fixing A/T assembly to engine assembly with power tool.

26. Remove A/T assembly with transfer assembly from vehicle.

CAUTION:

- Secure torque converter to prevent it from dropping.
- Secure A/T assembly to a transmission jack.

27. Remove transfer assembly from A/T assembly with power tool.



A
B
AT
D
E
F
G
H
I
J
K
L
M


TRANSMISSION ASSEMBLY

INSPECTION

Installation and Inspection of Torque Converter

- After inserting a torque converter to a A/T, be sure to check distance "A" to ensure it is within the reference value limit.

Distance "A": 25.0 mm (0.98 in) or more




INSTALLATION

Install the removed parts in the reverse order of the removal, while paying attention to the following work.

- When installing A/T assembly to the engine assembly, attach the fixing bolts in accordance with the following standard.


Bolt No.	1	2	3	4
Number of bolts	1	5	2	1
Bolt length "ℓ"mm (in)	55 (2.17)	65 (2.56)	35 (1.38)	40 (1.57)
Tightening torque N-m (kg-m, ft-lb)	75 (7.7, 55)		47 (4.8, 35)	34 (3.5, 25)



- Align the positions of tightening bolts for drive plate with those of the torque converter, and temporarily tighten the bolts. Then, tighten the bolts with the specified torque. Refer to [AT-278, "COMPONENTS"](#).

CAUTION:

- When turning crankshaft, turn it clockwise as viewed from the front of the engine.
- When tightening the tightening bolts for the torque converter after fixing the crankshaft pulley bolts, be sure to confirm the tightening torque of the crankshaft pulley mounting bolts. Refer to [EM-74, "INSTALLATION"](#).
- After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that A/T rotates freely without binding.
- Install crankshaft position sensor (POS). Refer to [EM-38, "Removal and Installation \(AWD Models\)"](#).
- After completing installation, check A/T fluid leakage, A/T fluid level and A/T position. Refer to [AT-13, "Checking A/T Fluid"](#), [AT-228, "Checking of A/T Position"](#).



OVERHAUL


OVERHAUL Components

PF0:0000

NCS001R0

VQ35DE models

SEC. 311•313•314•315



SCIA7983E

A
B
AT
D
E
F
G
H
I
J
K
L
M

OVERHAUL

- | | | |
|---------------------------|------------------------------|-------------------------------------|
| 1. O-ring | 2. Oil pump cover | 3. O-ring |
| 4. Oil pump housing | 5. Self-sealing bolt | 6. Torque converter |
| 7. Converter housing | 8. Oil pump housing oil seal | 9. Bearing race |
| 10. Needle bearing | 11. O-ring | 12. Front carrier assembly |
| 13. Needle bearing | 14. Snap ring | 15. Front sun gear |
| 16. Snap ring | 17. Bearing race | 18. Needle bearing |
| 19. 3rd one-way clutch | 20. Seal ring | 21. Input clutch assembly |
| 22. Needle bearing | 23. Rear internal gear | 24. Brake band |
| 25. Mid carrier assembly | 26. Needle bearing | 27. Bearing race |
| 28. Rear carrier assembly | 29. Needle bearing | 30. Mid sun gear |
| 31. Seal ring | 32. Rear sun gear | 33. 1st one-way clutch |
| 34. Snap ring | 35. Needle bearing | 36. High and low reverse clutch hub |
| 37. Snap ring | 38. Bearing race | 39. Needle bearing |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .

However, refer to the following symbols for others.



Apply Genuine RTV silicone sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .


OVERHAUL

VK45DE models

SEC. 311•313•314•315

5 61 (6.2, 45)

52 (5.3, 38)



A
B
AT
D
E
F
G
H
I
J
K
L
M

- | | | |
|---------------------|----------------------|---------------------|
| 1. O-ring | 2. Oil pump cover | 3. O-ring |
| 4. Oil pump housing | 5. Self-sealing bolt | 6. Torque converter |


SCIA7984E

OVERHAUL

- | | | |
|---------------------------|------------------------------|-------------------------------------|
| 7. Converter housing | 8. Oil pump housing oil seal | 9. Bearing race |
| 10. Needle bearing | 11. O-ring | 12. Front carrier assembly |
| 13. Needle bearing | 14. Snap ring | 15. Front sun gear |
| 16. 3rd one-way clutch | 17. Snap ring | 18. Bearing race |
| 19. Needle bearing | 20. Seal ring | 21. Input clutch assembly |
| 22. Needle bearing | 23. Rear internal gear | 24. Brake band |
| 25. Mid carrier assembly | 26. Needle bearing | 27. Bearing race |
| 28. Rear carrier assembly | 29. Needle bearing | 30. Mid sun gear |
| 31. Seal ring | 32. Rear sun gear | 33. 1st one-way clutch |
| 34. Snap ring | 35. Needle bearing | 36. High and low reverse clutch hub |
| 37. Snap ring | 38. Bearing race | 39. Needle bearing |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .


However, refer to the following symbols for others.

: Apply Genuine RTV silicone sealant or equivalent. Refer to [GI-47. "Recommended Chemical Products and Sealants"](#) .

OVERHAUL

VQ35DE models

SEC.315•316



A
B
AT
D
E
F
G
H
I
J
K
L
M

- | | | |
|-------------------|---------------------------|---|
| 1. Needle bearing | 2. Bearing race | 3. High and low reverse clutch assembly |
| 4. Needle bearing | 5. Direct clutch assembly | 6. Reverse brake dish plate |

SCIA7001E

OVERHAUL


- | | | |
|-------------------------------|-----------------------------------|--------------------------|
| 7. Reverse brake dish plate | 8. Reverse brake driven plate | 9. N-spring |
| 10. Reverse brake drive plate | 11. Reverse brake retaining plate | 12. Snap ring |
| 13. D-ring | 14. D-ring | 15. Reverse brake piston |
| 16. Return spring | 17. Spring retainer | 18. Snap ring |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .

OVERHAUL

VK45DE models

SEC.315•316



A
B
AT
D
E
F
G
H
I
J
K
L
M

- | | | |
|---------------------------|---|-----------------------------|
| 1. Bearing race | 2. High and low reverse clutch assembly | 3. Needle bearing |
| 4. Direct clutch assembly | 5. Needle bearing | 6. Reverse brake dish plate |

SCIA6982E

OVERHAUL


- | | | |
|-----------------------------|-----------------------------------|-------------------------------|
| 7. Reverse brake dish plate | 8. Reverse brake driven plate | 9. N-spring |
| 10. Snap ring | 11. Reverse brake retaining plate | 12. Reverse brake drive plate |
| 13. Snap ring | 14. Spring retainer | 15. Return spring |
| 16. Reverse brake piston | 17. D-ring | 18. D-ring |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#)

OVERHAUL

VQ35DE models for 2WD

SEC. 313•314•315•316•317•319




- | | | |
|-----------------------------|----------------------|-------------------|
| 1. Rear oil seal | 2. Self-sealing bolt | 3. Rear extension |
| 4. Parking actuator support | 5. Parking pawl | 6. Return spring |

OVERHAUL

- | | | |
|----------------------------|------------------------------------|----------------------------|
| 7. Pawl shaft | 8. Seal ring | 9. Needle bearing |
| 10. Revolution sensor | 11. Parking gear | 12. Output shaft |
| 13. Bearing race | 14. Needle bearing | 15. Manual plate |
| 16. Parking rod | 17. Manual shaft oil seal | 18. Manual shaft |
| 19. O-ring | 20. Band servo anchor end pin | 21. Detent spring |
| 22. Spacer | 23. Seal ring | 24. Snap ring |
| 25. Return spring | 26. O-ring | 27. Servo assembly |
| 28. Snap ring | 29. Sub-harness | 30. Control valve with TCM |
| 31. Bracket | 32. A/T fluid temperature sensor 2 | 33. Clip |
| 34. Oil pan mounting bolt | 35. Oil pan | 36. Magnet |
| 37. Drain plug | 38. Drain plug gasket | 39. Oil pan gasket |
| 40. Terminal cord assembly | 41. O-ring | 42. Retaining pin |
| 43. Transmission case | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .


However, refer to the following symbols for others.

: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47. "Recommended Chemical Products and Sealants"](#)

OVERHAUL

VK45DE models for 2WD

SEC. 313•314•315•316•317•319



A
B
AT
D
E
F
G
H
I
J
K
L
M


SCIA8048E

OVERHAUL

- | | | |
|---|------------------------------------|----------------------------|
| 1. Output shaft & companion flange complement | 2. Parking actuator support | 3. Parking pawl |
| 4. Return spring | 5. Pawl shaft | 6. Self-sealing bolt |
| 7. Seal ring | 8. Needle bearing | 9. Revolution sensor |
| 10. Intermediate shaft | 11. Manual plate | 12. Parking rod |
| 13. Manual shaft oil seal | 14. Manual shaft | 15. Retaining pin |
| 16. O-ring | 17. Band servo anchor end pin | 18. Detent spring |
| 19. Spacer | 20. Return spring | 21. Seal ring |
| 22. O-ring | 23. Servo assembly | 24. Snap ring |
| 25. Snap ring | 26. Sub-harness | 27. Control valve with TCM |
| 28. Bracket | 29. A/T fluid temperature sensor 2 | 30. Terminal cord assembly |
| 31. O-ring | 32. Clip | 33. Bracket |
| 34. Bracket | 35. Oil pan mounting bolt | 36. Oil pan |
| 37. Magnet | 38. Drain plug | 39. Drain plug gasket |
| 40. Oil pan gasket | 41. Transmission case | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .


However, refer to the following symbols for others.

: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47. "Recommended Chemical Products and Sealants"](#) .

OVERHAUL

AWD models

SEC. 313•314•315•316•317•319



- | | | |
|-----------------------------|-----------------|------------------|
| 1. Rear oil seal | 2. Bracket | 3. Adapter case |
| 4. Parking actuator support | 5. Parking pawl | 6. Return spring |

A
B
AT
D
E
F
G
H
I
J
K
L
M

SCIA8042E

OVERHAUL

- | | | |
|------------------------------------|----------------------------|----------------------------|
| 7. Pawl shaft | 8. Self-sealing bolt | 9. Seal ring |
| 10. Needle bearing | 11. Gasket | 12. Revolution sensor |
| 13. Parking gear | 14. Output shaft | 15. Bearing race |
| 16. Needle bearing | 17. Manual plate | 18. Parking rod |
| 19. Manual shaft oil seal | 20. Manual shaft | 21. O-ring |
| 22. Band servo anchor end pin | 23. Detent spring | 24. Spacer |
| 25. Seal ring | 26. Snap ring | 27. Return spring |
| 28. O-ring | 29. Servo assembly | 30. Snap ring |
| 31. Sub-harness | 32. Control valve with TCM | 33. Bracket |
| 34. A/T fluid temperature sensor 2 | 35. Clip | 36. Oil pan mounting bolt |
| 37. Oil pan | 38. Magnet | 39. Drain plug |
| 40. Drain plug gasket | 41. Oil pan gasket | 42. Terminal cord assembly |
| 43. O-ring | 44. Retaining pin | 45. Transmission case |


Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .

OVERHAUL

Oil Channel

NCS001R1

VQ35DE models for 2WD




A
B
AT
D
E
F
G
H
I
J
K
L
M

SCIA5185E

OVERHAUL

VK45DE models for 2WD




SCIA5678E

OVERHAUL

AWD models

A
B
AT
D
E
F
G
H
I
J
K
L
M




SCIA5189E

OVERHAUL

Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings

NCS001R2

VQ35DE models for 2WD



Outer diameter of snap rings

Item number	Outer diameter mm (in)
①	63 (2.48)
②	183 (7.20)
③	173 (6.81)
④	70 (2.76)
⑤	170 (6.69)
⑥	135 (5.31)
⑦	180 (7.09)
⑧	185 (7.28)
⑨	48 (1.89)


Outer diameter of needle bearings

Item number	Outer diameter mm (in)
⑩	80 (3.15)
⑪	77 (3.03)
⑫	77 (3.03)
⑬	47 (1.85)
⑭	84 (3.31)
⑮	80 (3.15)
⑯	92 (3.62)
⑰	60 (2.36)
⑱	63 (2.48)
⑲	92 (3.62)
⑳	65 (2.56)
㉑	60 (2.36)

SCIA7019E

OVERHAUL

VK45DE models for 2WD



Outer diameter of snap rings

Item number	Outer diameter mm (in)
1	63 (2.48)
2	183 (7.20)
3	173 (6.81)
4	70 (2.76)
5	170 (6.69)
6	135 (5.31)
7	180 (7.09)
8	185 (7.28)
9	48 (1.89)

Outer diameter of needle bearings


Item number	Outer diameter mm (in)
10	80 (3.15)
11	77 (3.03)
12	77 (3.03)
13	47 (1.85)
14	84 (3.31)
15	84 (3.31)
16	92 (3.62)
17	60 (2.36)
18	63 (2.48)
19	92 (3.62)
20	65 (2.56)

A
B
AT
D
E
F
G
H
I
J
K
L
M

SCIA7021E

OVERHAUL

AWD models



Outer diameter of snap rings

Item number	Outer diameter mm (in)
1	63 (2.48)
2	183 (7.20)
3	173 (6.81)
4	70 (2.76)
5	170 (6.69)
6	135 (5.31)
7	180 (7.09)
8	185 (7.28)
9	48 (1.89)

Outer diameter of needle bearings

Item number	Outer diameter mm (in)
10	80 (3.15)
11	77 (3.03)
12	77 (3.03)
13	47 (1.85)
14	84 (3.31)
15	80 (3.15)
16	92 (3.62)
17	60 (2.36)
18	63 (2.48)
19	92 (3.62)
20	65 (2.56)
22	60 (2.36)

SCIA7020E

DISASSEMBLY

DISASSEMBLY

PF3:31020


Disassembly

NCS001R3


CAUTION:

Do not disassemble parts behind Drum Support. Refer to [AT-17, "Cross-Sectional View \(VQ35DE Models for 2WD\)"](#) , [AT-18, "Cross-Sectional View \(VK45DE Models for 2WD\)"](#) , [AT-19, "Cross-Sectional View \(AWD Models\)"](#) .

1. Drain ATF through drain plug.
2. Remove torque converter by holding it firmly and turing while pulling straight out.



3. Check torque converter one-way clutch using a check tool as shown at figure.
 - a. Insert a check tool into the groove of bearing support built into one-way clutch outer race.
 - b. When fixing bearing support with a check tool, rotate one-way clutch spline using a screwdriver.
 - c. Make sure that inner race rotates clockwise only. If not, replace torque converter assembly.



4. Remove tightening bolts (1) for converter housing and transmission case.


←: Bolt (8)

- Self-sealing bolts (2)

5. Remove converter housing from transmission case.


CAUTION:

Be careful not to scratch converter housing.




DISASSEMBLY

6. Remove O-ring from input clutch assembly.




7. Remove tightening bolts for oil pump assembly and transmission case.




8. Attach the sliding hammers to oil pump assembly and extract it evenly from transmission case.

CAUTION:

- Fully tighten the sliding hammer screws.
- Make sure that bearing race is installed to the oil pump assembly edge surface.




9. Remove O-ring from oil pump assembly.




DISASSEMBLY

10. Remove bearing race from oil pump assembly.




11. Remove needle bearing from front sun gear.




12. Remove front sun gear assembly from front carrier assembly.

NOTE:
Remove front sun gear by rotating left/right.




13. Remove seal rings from input clutch assembly.



14. Remove front carrier assembly from rear carrier assembly. (With input clutch assembly and rear internal gear.)


CAUTION:
Be careful to remove it with needle bearing.




A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


15. Loosen lock nut and remove band servo anchor end pin from transmission case.




16. Remove brake band from transmission case.




- To prevent brake linings from cracking or peeling, do not stretch the flexible band unnecessarily. When removing the brake band, always secure it with a clip as shown in the figure at right. Leave the clip in position after removing the brake band.
- Check brake band facing for damage, cracks, wear or burns.



17. Remove mid carrier assembly and rear carrier assembly as a unit.




18. Remove mid carrier assembly from rear carrier assembly.




DISASSEMBLY


19. Remove needle bearing (front side) from mid carrier assembly.




20. Remove needle bearing (rear side) from mid carrier assembly.



21. Remove bearing race from rear carrier assembly.




22. Remove needle bearing from rear carrier assembly.



23. Remove mid sun gear assembly, rear sun gear assembly and high and low reverse clutch hub as a unit.

CAUTION:

Be careful to remove them with bearing race and needle bearing.




A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


24. Remove high and low reverse clutch assembly from direct clutch assembly.

CAUTION:


Make sure that needle bearing is installed to the high and low reverse clutch assembly edge surface.




25. Remove direct clutch assembly from reverse brake.



26. Remove needle bearing from drum support.




27. Remove snap ring from A/T assembly harness connector.



28. Push A/T assembly harness connector.

CAUTION:

Be careful not to damage connector.




DISASSEMBLY

29. Remove oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.


a. VQ35DE models

- i. Remove clips (1).
- ii. Remove oil pan (2) and oil pan gasket.
⇐: Front
←: Bolt (22)




b. VK45DE models

- i. Remove clips (1) and brackets (2).
- ii. Remove oil pan (3) and oil pan gasket.
⇐: Front
←: Bolt (22)




30. Check foreign materials in oil pan to help determine causes of malfunction. If the ATF is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and can inhibit pump pressure.

- **If frictional material is detected, perform A/T fluid cooler cleaning. Refer to [AT-14, "A/T Fluid Cooler Cleaning"](#).**



31. Remove magnets from oil pan.




A
B
AT
D
E
F
G
H
I
J
K
L
M


DISASSEMBLY

32. Disconnect A/T fluid temperature sensor 2 connector.

CAUTION:
Be careful not to damage connector.




33. Straighten terminal clips to free terminal cord assembly and A/T fluid temperature sensor 2 harness.




34. Disconnect revolution sensor connector.

CAUTION:
Be careful not to damage connector.




35. Straighten terminal clip to free revolution sensor harness.



36. Remove bolts A, B and C from control valve with TCM.

Bolt symbol	Length mm (in)	Number of bolts
A	42 (1.65)	5
B	55 (2.17)	6
C	40 (1.57)	1




DISASSEMBLY


37. Remove control valve with TCM from transmission case.

CAUTION:


When removing, be careful with the manual valve notch and manual plate height. Remove it vertically.




38. Remove A/T fluid temperature sensor 2 with bracket from control valve with TCM.



39. Remove bracket from A/T fluid temperature sensor 2.




40. Remove O-ring from A/T assembly harness connector.



41. Disconnect TCM connectors.

CAUTION:


Be careful not to damage connectors.



A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


42. Remove A/T assembly harness connector from control valve with TCM using a flat-bladed screwdriver.



43. Disconnect TCM connector and park/neutral position switch connector.

CAUTION:

Be careful not to damage connectors.




44. Remove one of the following parts.


- Rear extension assembly (VQ35DE models for 2WD)
- Output shaft & companion flange complement (VK45DE models for 2WD)
- Adapter case assembly (AWD models)

a. **VQ35DE models for 2WD**

- i. Remove tightening bolts for rear extension assembly and transmission case.




- ii. Tap rear extension assembly with a soft hammer.




DISASSEMBLY


- iii. Remove rear extension assembly from transmission case. (With needle bearing.)




- iv. Remove bearing race from output shaft.




- v. Remove output shaft from transmission case by rotating left/right.



- vi. Remove parking gear from output shaft.



- vii. Remove seal rings from output shaft.



A
B
AT
D
E
F
G
H
I
J
K
L
M


DISASSEMBLY

b. VK45DE models for 2WD


- i. Remove tightening bolts (1) for output shaft & companion flange complement and transmission case.

◄: Bolt (10)


- Self-sealing bolts (2)




- ii. Tap output shaft & companion flange complement with a soft hammer.




- iii. Remove output shaft & companion flange complement from transmission case.



- iv. Remove intermediate shaft from transmission case by rotating left/right.



- v. Remove seal rings from intermediate shaft.




DISASSEMBLY

c. AWD models


i. Remove tightening bolts (1) for adapter case assembly and transmission case. (With bracket (2).)

←: Bolt (10)


● Self-sealing bolts (3)




ii. Tap adapter case assembly with a soft hammer.



iii. Remove adapter case assembly from transmission case. (With needle bearing)




iv. Remove gasket from transmission case.




A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


v. Remove bearing race from output shaft.




vi. Remove output shaft from transmission case by rotating left/right.




vii. Remove parking gear from output shaft.



viii. Remove seal rings from output shaft.



45. Remove needle bearing from transmission case.




DISASSEMBLY

46. Remove revolution sensor from transmission case.

CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.




47. Remove reverse brake snap ring (fixing plate) using 2 flat-bladed screwdrivers.

NOTE:


Press out snap ring from the transmission case oil pan side gap using a flat-bladed screwdriver, and remove it using a another screwdriver.

48. Remove reverse brake retaining plate from transmission case.

- Check facing for burns, cracks or damage. If necessary, replace the plate.




49. Remove N-spring from transmission case.




50. Remove reverse brake drive plates, driven plates and dish plates from transmission case.

- Check facing for burns, cracks or damage. If necessary, replace the plate.




51. Remove snap ring (fixing spring retainer) using a flat-bladed screwdriver.




A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


52. Remove spring retainer and return spring from transmission case.



53. Remove seal rings from drum support.




54. Remove needle bearing from drum support edge surface.



55. Remove reverse brake piston from transmission case with compressed air. Refer to [AT-295, "Oil Channel"](#) .


CAUTION:

Care should be taken not to abruptly blow air. It makes pistons incline, as the result, it becomes hard to disassemble the pistons.




DISASSEMBLY


56. Remove D-rings from reverse brake piston.




57. Use a pin punch [4 mm (0.16 in) dia. commercial service tool] to knock out retaining pin.




58. Remove manual shaft retaining pin with a pair of nippers.



59. Remove manual plate (with parking rod) from manual shaft.




60. Remove parking rod from manual plate.



A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY


61. Remove manual shaft from transmission case.




62. Remove manual shaft oil seals using a flat-bladed screwdriver.

CAUTION:


Be careful not to scratch transmission case.




63. Remove detent spring and spacer from transmission case.



64. Using a pair of snap ring pliers, remove snap ring from transmission case.




65. Remove servo assembly (with return spring) from transmission case.




DISASSEMBLY

66. Remove return spring from servo assembly.



67. Remove O-rings from servo assembly.




68. Remove one of the following parts.


- Rear extension assembly (VQ35DE models for 2WD)
- Adapter case assembly (AWD models)
- Output shaft & companion flange complement (VK45DE models for 2WD)

a. **VQ35DE models**

i. Remove needle bearing (1) from rear extension (2WD models) or adapter case (AWD models).




ii. Remove parking actuator support from rear extension (2WD models) or adapter case (AWD models).




A
B
AT
D
E
F
G
H
I
J
K
L
M

DISASSEMBLY

- iii. Remove parking pawl (with return spring) and pawl shaft from rear extension (2WD models) or adapter case (AWD models).




- iv. Remove return spring (1) from parking pawl (2).



- v. Remove rear oil seal from rear extension (2WD models) or adapter case (AWD models).


CAUTION:

Be careful not to scratch rear extension (2WD models) or adapter case (AWD models).




- b. **VK45DE models**

- i. Remove parking actuator support (1) from output shaft & companion flange complement.




DISASSEMBLY

- ii. Remove parking pawl (with return spring) (1) and pawl shaft (2) from output shaft & companion flange complement.



- iii. Remove return spring (1) from parking pawl (2).



A
B
AT
D
E
F
G
H
I
J
K
L
M


REPAIR FOR COMPONENT PARTS

PFP:00000

NCS001R4


REPAIR FOR COMPONENT PARTS

Oil Pump COMPONENTS



DISASSEMBLY


1. Remove oil pump housing from oil pump cover.



2. Remove oil pump housing oil seal using a flat-bladed screwdriver.


CAUTION:

Be careful not to scratch oil pump housing.




REPAIR FOR COMPONENT PARTS

3. Remove O-ring from oil pump housing.



4. Remove O-ring from oil pump cover.




ASSEMBLY

1. Install O-ring to oil pump cover.

CAUTION:


- Do not reuse O-ring.
- Apply ATF to O-ring.



2. Install O-ring to oil pump housing.

CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.




A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS


- Using the drift, install oil pump housing oil seal to the oil pump housing until it is flush.

CAUTION:

- Do not reuse oil seal.
- Apply ATF to oil seal.



- Install oil pump housing to oil pump cover.
- Tighten bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Refer to [AT-322](#). "[COMPONENTS](#)".




REPAIR FOR COMPONENT PARTS

Front Sun Gear, 3rd One-Way Clutch COMPONENTS

NCS001R5


A
B
AT
D
E
F
G
H
I
J
K
L
M




1. Front sun gear
2. 3rd one-way clutch
3. Snap ring

DISASSEMBLY

1. Using a flat-bladed screwdriver, remove snap ring from front sun gear.



2. Remove 3rd one-way clutch from front sun gear.



REPAIR FOR COMPONENT PARTS

INSPECTION

3rd One-way Clutch

- Check frictional surface for wear or damage.

CAUTION:

If necessary, replace the 3rd one-way clutch.

Front Sun Gear Snap Ring

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the snap ring.

Front Sun Gear

- Check for deformation, fatigue or damage.

CAUTION:


If necessary, replace the front sun gear.

ASSEMBLY


1. Install 3rd one-way clutch in front sun gear.

CAUTION:

Apply ATF to 3rd one-way clutch.




2. Using a flat-bladed screwdriver, install snap ring in front sun gear.



3. Check operation of 3rd one-way clutch.
 - a. Hold oil pump assembly and turn front sun gear.
 - b. Check 3rd one-way clutch for correct locking and unlocking directions.

CAUTION:

If not as shown in figure, check installation direction of 3rd one-way clutch.



REPAIR FOR COMPONENT PARTS


Front Carrier, Input Clutch, Rear Internal Gear COMPONENTS

NCS001R6

VQ35DE models

A
B
AT
D
E
F
G
H
I
J
K
L
M

SEC.314 • 315



SCIA6734E


- | | | |
|------------------------|---------------------------|--------------------|
| 1. Seal ring | 2. O-ring | 3. Needle bearing |
| 4. Bearing race | 5. Front carrier assembly | 6. Needle bearing |
| 7. Snap ring | 8. Snap ring | 9. Retaining plate |
| 10. Driven plate | 11. Input clutch drum | 12. Drive plate |
| 13. Rear internal gear | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).

REPAIR FOR COMPONENT PARTS

VK45DE models

SEC.314•315



SCIA7070E


- | | | |
|------------------------|---------------------------|--------------------|
| 1. Seal ring | 2. O-ring | 3. Needle bearing |
| 4. Bearing race | 5. Front carrier assembly | 6. Needle bearing |
| 7. Snap ring | 8. Snap ring | 9. Retaining plate |
| 10. Driven plate | 11. Input clutch drum | 12. Drive plate |
| 13. Rear internal gear | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).


REPAIR FOR COMPONENT PARTS

DISASSEMBLY


1. Compress snap ring using 2 flat-bladed screwdrivers.
2. Remove front carrier assembly and input clutch assembly from rear internal gear.
3. Remove front carrier assembly from input clutch assembly.



- a. Remove bearing race from front carrier assembly.




- b. Remove needle bearing from front carrier assembly.



- c. Remove snap ring from front carrier assembly.


CAUTION:
Do not expand snap ring excessively.




A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS


4. Disassemble input clutch assembly.
 - a. Remove O-ring and seal rings from input clutch assembly.



- b. Remove needle bearing from input clutch assembly.



- c. Using a flat-bladed screwdriver, remove snap ring from input clutch drum.
 - d. Remove drive plates, driven plates and retaining plate from input clutch drum.



INSPECTION

Front Carrier Snap Ring

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the snap ring.

Input Clutch Snap Ring

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the input clutch assembly.

Input Clutch Drum

- Check for deformation, fatigue or damage or burns.

CAUTION:

If necessary, replace the input clutch assembly.

Input Clutch Drive Plates

- Check facing for burns, cracks or damage.

CAUTION:

If necessary, replace the input clutch assembly.

Input Clutch Retaining Plate and Driven Plates

- Check facing for burns, cracks or damage.

REPAIR FOR COMPONENT PARTS

CAUTION:

If necessary, replace the input clutch assembly.

Front Carrier

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the front carrier assembly.

Rear Internal Gear

- Check for deformation, fatigue or damage.

CAUTION:


If necessary, replace the rear internal gear.

ASSEMBLY


1. Install input clutch.
 - a. Install drive plates, driven plates and retaining plate in input clutch drum.
 - Snap ring (1)
 - Retaining plate (2)
 - Drive plate (3)
 - Driven plate (4)
 - Drive plate/Driven plate: 7/7

CAUTION:

Take care with order of plates.




- b. Using a flat-bladed screwdriver, install snap ring in input clutch drum.



- c. Install needle bearing in input clutch assembly.

CAUTION:

- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS

- d. Install O-ring and seal rings in input clutch assembly.

CAUTION:


- Do not reuse O-ring and seal rings.
- Apply ATF to O-ring.
- Apply petroleum jelly to seal rings.



2. Install front carrier assembly.
- a. Install snap ring to front carrier assembly.

CAUTION:


Do not expand snap ring excessively.



- b. Install needle bearing in front carrier assembly.

CAUTION:

- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




- c. Install bearing race in front carrier assembly.


CAUTION:

Apply petroleum jelly to bearing race.

- d. Install front carrier assembly to input clutch assembly.



3. Compress snap ring using 2 flat-bladed screwdrivers.
4. Install front carrier assembly and input clutch assembly to rear internal gear.




REPAIR FOR COMPONENT PARTS

Mid Sun Gear, Rear Sun Gear, High and Low Reverse Clutch Hub COMPONENTS

NCS001R7


VQ35DE models



- | | | |
|------------------------------------|-------------------|--------------|
| 1. Needle bearing | 2. Bearing race | 3. Snap ring |
| 4. High and low reverse clutch hub | 5. Needle bearing | 6. Snap ring |
| 7. 1st one-way clutch | 8. Rear sun gear | 9. Seal ring |
| 10. Mid sun gear | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .

VK45DE models



- | | | |
|------------------------------------|-------------------|--------------|
| 1. Needle bearing | 2. Bearing race | 3. Snap ring |
| 4. High and low reverse clutch hub | 5. Needle bearing | 6. Snap ring |
| 7. 1st one-way clutch | 8. Rear sun gear | 9. Seal ring |
| 10. Mid sun gear | | |

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11. "Components"](#) .


A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS


DISASSEMBLY

1. Remove needle bearing and bearing races from high and low reverse clutch hub.

- VQ35DE models




- VK45DE models




2. Using a pair of snap ring pliers, remove snap ring from mid sun gear assembly.

CAUTION:

Do not expand snap ring excessively.




3. Remove high and low reverse clutch hub from mid sun gear assembly.




REPAIR FOR COMPONENT PARTS


- a. Remove needle bearing from high and low reverse clutch hub.




4. Remove rear sun gear assembly from mid sun gear assembly.




- a. Using a flat-bladed screwdriver, remove snap ring from rear sun gear.



- b. Remove 1st one-way clutch from rear sun gear.



5. Remove seal rings from mid sun gear.



A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS

INSPECTION

High and Low Reverse Clutch Hub Snap Ring, Rear Sun Gear Snap Ring

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the snap ring.

1st One-way Clutch

- Check frictional surface for wear or damage.

CAUTION:

If necessary, replace the 1st one-way clutch.

Mid Sun Gear

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the mid sun gear.

Rear Sun Gear

- Check for deformation, fatigue or damage.

CAUTION:

If necessary, replace the rear sun gear.

High and Low Reverse Clutch Hub

- Check for deformation, fatigue or damage.

CAUTION:


If necessary, replace the high and low reverse clutch hub.

ASSEMBLY

1. Install seal rings to mid sun gear.

CAUTION:


- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.



2. Install 1st one-way clutch to rear sun gear.


CAUTION:

Apply petroleum jelly to 1st one-way clutch.




REPAIR FOR COMPONENT PARTS

3. Using a flat-bladed screwdriver, install snap ring to rear sun gear.




4. Install rear sun gear assembly to mid sun gear assembly.




5. Install needle bearing to high and low reverse clutch hub.

CAUTION:

- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




6. Install high and low reverse clutch hub to mid sun gear assembly.



7. Using a pair of snap ring pliers, install snap ring to mid sun gear assembly.

CAUTION:

- Do not expand snap ring excessively.




A
B
AT
D
E
F
G
H
I
J
K
L
M

REPAIR FOR COMPONENT PARTS

8. Check operation of 1st one-way clutch.
 - a. Hold mid sun gear and turn rear sun gear.
 - b. Check 1st one-way clutch for correct locking and unlocking directions.

CAUTION:

If not as shown in the figure, check installation direction of 1st one-way clutch.




9. Install needle bearing and bearing races to high and low reverse clutch hub.


CAUTION:

Apply petroleum jelly to needle bearing and bearing races.

- VQ35DE models



- VK45DE models



REPAIR FOR COMPONENT PARTS

High and Low Reverse Clutch COMPONENTS

NCS001R8

A

B

AT

D

E

F

G

H


I

J

K

L


M




- | | | |
|-------------------------------------|-----------------|--------------------|
| 1. High and low reverse clutch drum | 2. Driven plate | 3. Retaining plate |
| 4. Snap ring | 5. Drive plate | 6. Bearing race |

DISASSEMBLY

1. Remove bearing race from high and low reverse clutch drum.



2. Using a flat-bladed screwdriver, remove snap ring from high and low reverse clutch drum.
3. Remove drive plates, driven plates and retaining plate from high and low reverse clutch drum.



INSPECTION

- Check the following, and replace high and low reverse clutch assembly if necessary.

High and Low Reverse Clutch Snap Ring

- Check for deformation, fatigue or damage.

High and Low Reverse Clutch Drive Plates

- Check facing for burns, cracks or damage.

REPAIR FOR COMPONENT PARTS

High and Low Reverse Clutch Retaining Plate and Driven Plates

- Check facing for burns, cracks or damage.

ASSEMBLY


1. Install drive plates, driven plates and retaining plate in high and low reverse clutch drum.

CAUTION:

Take care with the order of plates.


- VQ35DE models

- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Drive plate/Driven plate: 4/4




- VK45DE models

- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Drive plate/Driven plate: 5/5




2. Using a flat-bladed screwdriver, install snap ring in high and low reverse clutch drum.



3. Install bearing race to high and low reverse clutch drum.

CAUTION:

Apply petroleum jelly to bearing race.



REPAIR FOR COMPONENT PARTS

Direct Clutch COMPONENTS

NCS001R9

A

B

AT

D

E

F

G

H

I


J

K

L


M

VQ35DE models



- | | | |
|-----------------------|--------------------|--------------------|
| 1. Direct clutch drum | 2. Dish plate | 3. Retaining plate |
| 4. Driven plate | 5. Retaining plate | 6. Snap ring |
| 7. Drive plate | | |

VK45DE models




- | | | |
|-----------------------|-----------------|--------------------|
| 1. Direct clutch drum | 2. Driven plate | 3. Retaining plate |
| 4. Snap ring | 5. Drive plate | 6. Dish plate |

REPAIR FOR COMPONENT PARTS

DISASSEMBLY

1. Using a flat-bladed screwdriver, remove snap ring from direct clutch drum.
2. Remove drive plates, driven plates, dish plate and retaining plates from direct clutch drum.



INSPECTION

- Check the following, and replace direct clutch assembly if necessary.

Direct Clutch Snap Ring

- Check for deformation, fatigue or damage.

Direct Clutch Drive Plates and Driven Plates

- Check facing for burns, cracks or damage.

Direct Clutch Dish Plate and Retaining Plates

- Check facing for burns, cracks or damage.

ASSEMBLY


1. Install drive plates, driven plates, dish plate and retaining plates in direct clutch drum.

CAUTION:

Take care with the order of plates.


- VQ35DE models

- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Dish plate (5)
- Drive plate/Driven plate: 5/4




- VK45DE models

- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Dish plate (5)
- Drive plate/Driven plate: 6/6



REPAIR FOR COMPONENT PARTS

- Using a flat-bladed screwdriver, install snap ring in direct clutch drum.



A

B

AT

D

E

F

G

H

I

J

K

L

M

ASSEMBLY

ASSEMBLY

PFP:00000


Assembly (1)

NCS001RA


1. As shown in the figure, use a drift [22 mm (0.87 in) dia. commercial service tool] to drive manual shaft oil seals into the transmission case until it is flush.

CAUTION:


- Do not reuse manual shaft oil seals.
- Apply ATF to manual shaft oil seals.




2. Install detent spring and spacer in transmission case. Tighten detent spring and spacer bolts to the specified torque. Refer to [AT-281, "Components"](#).



3. Install manual shaft to transmission case.




4. Install parking rod to manual plate.



ASSEMBLY


5. Install manual plate (with parking rod) to manual shaft.



6. Install retaining pin into the manual plate and manual shaft.
- Fit pinhole of the manual plate to pinhole of the manual shaft with a pin punch.
 - Use a hammer to tap the retaining pin into the manual plate.

CAUTION:


- Do not reuse retaining pin.
- Drive retaining pin to 2 ± 0.5 mm (0.08 ± 0.020 in) over the manual plate.



7. Install retaining pin into the transmission case and manual shaft.
- Fit pinhole of the transmission case to pinhole of the manual shaft with a pin punch.
 - Use a hammer to tap the retaining pin into the transmission case.

CAUTION:


- Do not reuse retaining pin.
- Drive retaining pin to 5 ± 1 mm (0.20 ± 0.04 in) over the transmission case.




8. Install O-rings to servo assembly.

CAUTION:

- Do not reuse O-rings.
- Apply petroleum jelly to O-rings.




9. Install return spring to servo assembly.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

10. Install servo assembly in transmission case.




11. Using a pair of snap ring pliers, install snap ring to transmission case.




12. Install D-rings in reverse brake piston.

CAUTION:

- Do not reuse D-rings.
- Apply ATF to D-rings.




13. Install reverse brake piston in transmission case.



14. Install needle bearing to drum support edge surface.

CAUTION:

- Apply petroleum jelly to needle bearing.




ASSEMBLY


15. Install seal rings to drum support.

CAUTION:

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




16. Install spring retainer and return spring in transmission case.



17. Set the SST on spring retainer and install snap ring (fixing spring retainer) in transmission case while compressing return spring.

CAUTION:

Securely assemble them using a flat-bladed screwdriver so that snap ring tension is slightly weak.




18. Install reverse brake drive plates, driven plates and dish plates in transmission case.

CAUTION:

Take care with order of plates.


- Snap ring (1)
- Retaining plate (2)
- Drive plate (3)
- Driven plate (4)
- Dish plate (5)
- Drive plate/Driven plate: 6/6




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

19. Assemble N-spring.
20. Install reverse brake retaining plate in transmission case.



21. Install snap ring in transmission case.




22. Measure clearance between retaining plate and snap ring. If not within specified clearance, select proper retaining plate.

Specified clearance A

Standard: 0.7 - 1.1 mm (0.028 - 0.043 in)

Retaining plate


Refer to [AT-372, "Reverse Brake"](#) .



23. Install needle bearing to transmission case.

CAUTION:

- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#) .
- Apply petroleum jelly to needle bearing.




ASSEMBLY

24. Install revolution sensor to transmission case. Tighten revolution sensor bolt to the specified torque. Refer to [AT-281, "Components"](#).

CAUTION:

- Do not subject it to impact by dropping or hitting it.
- Do not disassemble.
- Do not allow metal filings, etc., to get on the sensor's front edge magnetic area.
- Do not place in an area affected by magnetism.



25. Assemble one of the following parts.


- Rear extension assembly (VQ35DE models for 2WD)
- Adapter case assembly (AWD models)
- Output shaft & companion flange complement (VK45DE models for 2WD)

a. **VQ35DE models**


- i. As shown in the figure, use the drift to drive rear oil seal into the rear extension (2WD models) or adapter case (AWD models) until it is flush.

CAUTION:

- Apply ATF to rear oil seal.
- Do not reuse rear oil seal.




- ii. Install return spring (1) to parking pawl (2).




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

- iii. Install parking pawl (with return spring) and pawl shaft to rear extension (2WD models) or adapter case (AWD models).



- iv. Install parking actuator support from rear extension (2WD models) or adapter case (AWD models).




- v. Install needle bearing (1) to rear extension (2WD models) or adapter case (AWD models).

CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#) .
- Apply petroleum jelly to needle bearing.

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .




b. **VK45DE models**

- i. Install return spring (1) to parking pawl (2).




ASSEMBLY

- ii. Install parking pawl (with return spring) (1) and pawl shaft (2) to output shaft & companion flange complement.



- iii. Install parking actuator support (1) from output shaft & companion flange complement.



26. Assemble one of the following parts.


- Rear extension assembly (VQ35DE models for 2WD)
- Adapter case assembly (AWD models)
- Output shaft & companion flange complement (VK45DE models for 2WD)

- a. **VQ35DE models for 2WD**


- i. Install seal rings to output shaft.

CAUTION:

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.



- ii. Install parking gear to output shaft.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY


- iii. Install output shaft in transmission case.

CAUTION:

Be careful not to mistake front for rear because both sides looks similar. (Thinner end is front side.)




- iv. Install bearing race to output shaft.



- v. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to rear extension assembly as shown in the figure.

CAUTION:


Completely remove all moisture, oil and old sealant, etc. from the transmission case and rear extension assembly mounting surfaces.



- vi. Install rear extension assembly to transmission case.

CAUTION:


Insert the tip of parking rod between the parking pawl and the parking actuator support when assembling the rear extension assembly.



- vii. Tighten rear extension assembly bolts to the specified torque. Refer to [AT-281, "Components"](#) .

CAUTION:

Do not reuse self-sealing bolts.




ASSEMBLY

b. VK45DE models for 2WD

- i. Install seal rings to intermediate shaft.

CAUTION:


- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.



- ii. Install intermediate shaft in transmission case.

CAUTION:


Be careful not to mistake front for rear because both sides looks similar. (Thinner end is front side.)



- iii. Apply recommended sealant (Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to output shaft & companion flange complement as shown in the figure.

CAUTION:


Completely remove all moisture, oil and old sealant, etc. from the transmission case and output shaft & companion flange complement mounting surfaces.



- iv. Install output shaft & companion flange complement in transmission case.

CAUTION:

Insert the tip of parking rod between the parking pawl and the parking actuator support when assembling the output shaft & companion flange complement.



A
B
AT
D
E
F
G
H
I
J
K
L
M


ASSEMBLY

- v. Tighten output shaft & companion flange complement bolts (1) to the specified torque. Refer to [AT-281, "Components"](#) .
←: Bolt (10)

CAUTION:

Do not reuse self-sealing bolts (2).

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#) .




c. **AWD models**


- i. Install seal rings to output shaft.

CAUTION:

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




- ii. Install parking gear to output shaft.



- iii. Install output shaft in transmission case.


CAUTION:

Be careful not to mistake front for rear because both sides looks similar. (Thinner end is front side.)



ASSEMBLY


iv. Install bearing race to output shaft.



v. Install gasket onto transmission case.

CAUTION:

- Completely remove all moisture, oil and old gasket, etc. from the transmission case and adapter case assembly mounting surfaces.
- Do not reuse gasket.




⊗ : Always replace after every disassembly.

vi. Install adapter case assembly to transmission case.

CAUTION:

Insert the tip of parking rod between the parking pawl and the parking actuator support when assembling the adapter case assembly.




vii. Tighten adapter case assembly bolts (1) to the specified torque. [With bracket (2).] Refer to [AT-281, "Components"](#).

←: Bolt (10)

CAUTION:

Do not reuse self-sealing bolts (3).

Refer to GI section to make sure icons (symbol marks) in the figure. Refer to [GI-11, "Components"](#).



← : ①


A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

27. Install needle bearing in drum support.

CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#) .
- Apply petroleum jelly to needle bearing.




28. Install direct clutch assembly in reverse brake.

CAUTION:


Make sure that drum support edge surface and direct clutch inner boss edge surface come to almost same place.




29. Install high and low reverse clutch assembly in direct clutch.



30. Using a flat-bladed screwdriver, align the drive plate.




31. Install high and low reverse clutch hub, mid sun gear assembly and rear sun gear assembly as a unit.



ASSEMBLY

CAUTION:


Make sure that portion "A" of high and low reverse clutch drum protrudes approximately 2 mm (0.08 in) beyond portion "B" of rear sun gear.



32. Install needle bearing in rear carrier assembly.

CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#).
- Apply petroleum jelly to needle bearing.




33. Install bearing race in rear carrier assembly.

CAUTION:

Apply petroleum jelly to bearing race.



34. Install rear carrier assembly in direct clutch drum.




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

35. Install needle bearing (rear side) to mid carrier assembly.

CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#) .
- Apply petroleum jelly to needle bearing.




36. Install needle bearing (front side) to mid carrier assembly.

CAUTION:


- Take care with the direction of needle bearing. Refer to [AT-298, "Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings"](#) .
- Apply petroleum jelly to needle bearing.



37. Install mid carrier assembly in rear carrier assembly.




38. Install front carrier assembly, input clutch assembly and rear internal gear as a unit.



39. Install seal rings in input clutch assembly.

CAUTION:

- Do not reuse seal rings.
- Apply petroleum jelly to seal rings.




ASSEMBLY

40. Install band servo anchor end pin and lock nut in transmission case.

CAUTION:


Do not reuse band servo anchor end pin.



41. Install brake band in transmission case.

CAUTION:


Assemble it so that identification to avoid incorrect installation faces servo side.



42. Install front sun gear to front carrier assembly.

CAUTION:


Apply ATF to front sun gear bearing and 3rd one-way clutch end bearing.




43. Install needle bearing to front sun gear.

CAUTION:

Apply petroleum jelly to needle bearing.



44. Adjust brake band tilting using a clip so that brake band contacts front sun gear drum evenly.



A
B
AT
D
E
F
G
H
I
J
K
L
M


ASSEMBLY

45. Adjust brake band.

- a. Loosen lock nut.
- b. Tighten band servo anchor end pin to specified torque.


 : 5.0 N·m (0.51 kg·m, 44 in·lb)

- c. Back of band servo anchor end pin three turns.
- d. Holding band servo anchor end pin, tighten lock nut to the specified torque. Refer to [AT-281, "Components"](#).




Adjustment TOTAL END PLAY


- Measure clearance between front sun gear and bearing race for oil pump cover.
- Select proper thickness of bearing race so that end play is within specifications.



1. Measure dimensions "K" and "L" and then calculate dimension "J".



- a. Measure dimension "K".



ASSEMBLY

- b. Measure dimension "L".
- c. Calculate dimension "J".

"J": Distance between oil pump fitting surface of transmission case and needle bearing mating surface of front sun gear.






$$J = K - L$$

- 2. Measure dimensions "M1" and "M2" and then calculate dimension "M".

- a. Place bearing race and needle bearing on oil pump assembly.

- b. Measure dimension "M1".

- c. Measure dimension "M2".




A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY

d. Calculate dimension "M".

"M": Distance between transmission case fitting surface of oil pump and needle bearing on oil pump.

$$M = M_1 - M_2$$




3. Adjust total end play "T1".

$$T_1 = J - M$$

Total end play "T1": 0.25 - 0.55 mm (0.0098 - 0.0217 in)

- Select proper thickness of bearing race so that total end play is within specifications.

Bearing races: Refer to [AT-372, "BEARING RACE FOR ADJUSTING TOTAL END PLAY"](#).




Assembly (2)

1. Install O-ring to oil pump assembly.

CAUTION:


- Do not reuse O-ring.
- Apply ATF to O-ring.



2. Install bearing race to oil pump assembly.

CAUTION:

Apply petroleum jelly to bearing race.




ASSEMBLY

3. Install oil pump assembly in transmission case.

CAUTION:


Apply ATF to oil pump baring.



4. Apply recommended sealant (Genuine RTV Silicone Sealant or equivalent. Refer to [GI-47, "Recommended Chemical Products and Sealants"](#) .) to oil pump assembly as shown in the figure.

CAUTION:


Completely remove all moisture, oil and old sealant, etc. from the oil pump mounting bolts and oil pump mounting bolt mounting surfaces.



5. Tighten oil pump bolts to the specified torque. Refer to [AT-281, "Components"](#) .

CAUTION:


Apply ATF to oil pump bushing.



6. Install O-ring to input clutch assembly.

CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.




7. Install converter housing to transmission case. Tighten converter housing bolts (1) to the specified torque. Refer to [AT-281, "Components"](#) .

←: Bolt (8)

CAUTION:


Do not reuse self-sealing bolt (2).



A
B
AT
D
E
F
G
H
I
J
K
L
M


ASSEMBLY

8. Make sure that brake band does not close turbine revolution sensor hole.




9. Install control valve with TCM.


- a. Connect TCM connector and park/neutral position switch connector.



- b. Install A/T assembly harness connector to control valve with TCM.



- c. Connect TCM connectors.




ASSEMBLY


d. Install O-ring to A/T assembly harness connector.

CAUTION:

- Do not reuse O-ring.
- Apply ATF to O-ring.




e. Install A/T fluid temperature sensor 2 to bracket.



f. Install A/T fluid temperature sensor 2 (with bracket) in control valve with TCM. Tighten A/T fluid temperature sensor 2 bolt to the specified torque. Refer to [AT-281, "Components"](#).

CAUTION:


Adjust bolt hole of bracket to bolt hole of control valve.




g. Install control valve with TCM in transmission case.

CAUTION:

- Make sure that turbine revolution sensor securely installs turbine revolution sensor hole.
- Hang down revolution sensor harness toward outside so as not to disturb installation of control valve with TCM.
- Adjust A/T assembly harness connector of control valve with TCM to terminal hole of transmission case.



- Assemble it so that manual valve cutout is engaged with manual plate projection.




A
B
AT
D
E
F
G
H
I
J
K
L
M


ASSEMBLY

h. Install bolts A, B and C to control valve with TCM.


Bolt symbol	Length mm (in)	Number of bolts
A	42 (1.65)	5
B	55 (2.17)	6
C	40 (1.57)	1




i. Tighten bolt 1, 2 and 3 temporarily to prevent dislocation. After that tighten them in order (1 → 2 → 3), and then tighten other bolts. Tighten control valve bolts to the TCM with specified torque. Refer to [AT-281, "Components"](#).




10. Connect A/T fluid temperature sensor 2 connector.



11. Securely fasten terminal cord assembly and A/T fluid temperature sensor 2 harness with terminal clips.




12. Connect revolution sensor connector.




ASSEMBLY

13. Securely fasten revolution sensor harness with terminal clip.




14. Pull down A/T assembly harness connector.


CAUTION:
Be careful not to damage connector.



15. Install snap ring to A/T assembly harness connector.



16. Install magnets in oil pan.



17. Install oil pan, oil pan gasket and clips (VQ35DE models) or oil pan, oil pan gasket, brackets and clips (VK45DE models) according to the following procedures.

a. VQ35DE models

i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.

A
B
AT
D
E
F
G
H
I
J
K
L
M

ASSEMBLY


- ii. Install oil pan (2) (with oil pan gasket) and clips (1) to transmission case.

↔: Front

←: Bolt (22)

CAUTION:


- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-281, "Components"](#).

CAUTION:

Do not reuse oil pan mounting bolts.



- b. VK45DE models

- i. Install oil pan gasket to oil pan.

CAUTION:

- Do not reuse oil pan gasket.
- Install it in the direction to align hole positions.
- Complete remove all moisture, oil and old gasket, etc. from oil pan gasket mounting surface.


- ii. Install oil pan (3) (with oil pan gasket), clips (1) and brackets (2) to transmission case.

↔: Front

←: Bolt (22)

CAUTION:

- Install it so that drain plug comes to the position as shown in the figure.
- Be careful not to pinch harnesses.
- Completely remove all moisture, oil and old gasket, etc. from oil pan mounting surface.
- Be careful with installation direction of brackets (2).



- iii. Tighten oil pan mounting bolts to the specified torque in numerical order shown in the figure after temporarily tightening them. Tighten oil pan mounting bolts to the specified torque. Refer to [AT-281, "Components"](#).

CAUTION:


Do not reuse oil pan mounting bolts.

18. Install drain plug to oil pan. Tighten drain plug to the specified torque. Refer to [AT-281, "Components"](#).

CAUTION:

Do not reuse drain plug gasket.


19. Install torque converter.



ASSEMBLY


a. Pour ATF into torque converter.

- Approximately 2 liter (2-1/8 US qt, 1-3/4 Imp qt) of ATF is required for a new torque converter.
- When reusing old torque converter, add the same amount of ATF as was drained.



b. Install torque converter while aligning notches of torque converter with notches of oil pump.

CAUTION:
Install torque converter while rotating it.




c. Measure distance "A" to make sure that torque converter is in proper position.

Distance "A"

VQ35DE models: 25.0 mm (0.98 in) or more

VK45DE models: 22.0 mm (0.87 in) or more



A
B
AT
D
E
F
G
H
I
J
K
L
M

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications

NCS001RD

Applied model		VQ35DE engine		VK45DE engine
		2WD	AWD	2WD
Automatic transmission model		RE5R05A		
Transmission model code number		98X1D, 98X6C	98X1C, 98X6D	95X7A
Stall torque ratio		1.74: 1		1.87: 1
Transmission gear ratio	1st	3.842		3.827
	2nd	2.353		2.368
	3rd	1.529		1.519
	4th	1.000		1.000
	5th	0.839		0.834
	Reverse	2.765		2.613
Recommended fluid		Genuine NISSAN Matic J ATF*1		
Fluid capacity		10.3 liter (10-7/8 US qt, 9-1/8 Imp qt)		

CAUTION:

- Use only Genuine NISSAN Matic J ATF. Do not mix with other fluid.
- Using ATF other than Genuine NISSAN Matic J ATF will deteriorate in driveability and A/T durability, and may damage the A/T, which is not covered by the warranty.

*1: Refer to [MA-12, "Fluids and Lubricants"](#) .

Vehicle Speed at Which Gear Shifting Occurs 2WD MODELS

NCS001RE

Engine model	VQ35DE							
	Vehicle speed km/h (MPH)							
Throttle position	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	52 - 56 (32 - 35)	85 - 93 (53 - 58)	126 - 136 (78 - 85)	195 - 205 (121 - 127)	191 - 201 (119 - 125)	113- 123 (70 - 76)	70 - 78 (44 - 48)	28 - 32 (17 - 20)
Half throttle	42 - 46 (26 - 29)	70 - 76 (44 - 47)	107 - 115 (67 - 71)	140 - 148 (87 - 92)	111 - 119 (69 - 74)	67 - 75 (42 - 47)	35 - 41 (22 - 25)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

Engine model	VK45DE							
	Vehicle speed km/h (MPH)							
Throttle position	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	56 - 60 (35 - 37)	89 - 97 (55 - 60)	121 - 131 (75 - 81)	206 - 216 (128 - 134)	202 - 212 (126 - 132)	121 - 131 (75 - 81)	73 - 81 (45 - 50)	30 - 34 (19 - 21)
Half throttle	48 - 52 (30 - 32)	82 - 88 (51 - 55)	126 - 134 (78 - 83)	155 - 163 (96 - 101)	128 - 136 (80 - 85)	70 - 78 (43 - 48)	29 - 35 (18 - 22)	9 - 13 (6 - 8)

- At half throttle, the accelerator opening is 4/8 of the full opening.

AWD MODELS

Engine model	VQ35DE							
	Vehicle speed km/h (MPH)							
Throttle position	D1 →D2	D2 →D3	D3 →D4	D4 →D5	D5 →D4	D4 →D3	D3 →D2	D2 →D1
Full throttle	50 - 54 (31 - 34)	81 - 89 (50 - 55)	120 - 130 (75 - 81)	187 - 197 (116 - 122)	183 - 193 (114 - 120)	108 - 118 (67 - 73)	66 - 74 (41 - 46)	27 - 31 (17 - 19)
Half throttle	40 - 44 (25 - 27)	67 - 73 (42 - 45)	102 - 110 (63 - 68)	133 - 141 (83 - 88)	106 - 114 (66 - 71)	64 - 72 (40 - 45)	33 - 39 (21 - 24)	11 - 15 (7 - 9)

- At half throttle, the accelerator opening is 4/8 of the full opening.

SERVICE DATA AND SPECIFICATIONS (SDS)

Vehicle Speed at Which Lock-Up Occurs/Releases

NCS001RF

2WD MODELS

Engine model	VQ35DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	53 - 61 (33 - 38)	50 - 58 (31 - 36)
Half throttle	196 - 204 (122 - 127)	138 - 146 (86 - 91)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

Engine model	VK45DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	67 - 75 (42 - 47)	50 - 58 (31 - 36)
Half throttle	181 - 189 (112 - 117)	160 - 168 (99 - 104)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

AWD MODELS

Engine model	VQ35DE	
Throttle position	Vehicle speed km/h (MPH)	
	Lock-up ON	Lock-up OFF
Closed throttle	51 - 59 (32 - 37)	48 - 56 (30 - 35)
Half throttle	188 - 196 (117 - 122)	132 - 140 (82 - 87)

- At closed throttle, the accelerator opening is less than 1/8 condition. (Closed throttle position signal: OFF)
- At half throttle, the accelerator opening is 4/8 of the full opening.

Stall Speed

NCS001RG

Engine model	Stall speed
VQ35DE	2,650 - 2,950 rpm
VK45DE	2,260 - 2,560 rpm

Line Pressure

NCS001RH

Engine speed	Line pressure [kPa (kg/cm ² , psi)]	
	"R" position	"D", "M" positions
At idle speed	425 - 465 (4.3 - 4.7, 62 - 67)	379 - 428 (3.9 - 4.4, 55 - 62)
At stall speed	1,605 - 1,950 (16.4 - 19.9, 233 - 283)	1,310 - 1,500 (13.4 - 15.3, 190 - 218)

A/T Fluid Temperature Sensor

NCS001RI

Name	Condition	CONSULT-II "DATA MONITOR" (Approx.)	Resistance (Approx.)
ATF TEMP SE 1	0°C (32°F)	3.3 V	15 kΩ
	20°C (68°F)	2.7 V	6.5 kΩ
	80°C (176°F)	0.9 V	0.9 kΩ
ATF TEMP SE 2	0°C (32°F)	3.3 V	10 kΩ
	20°C (68°F)	2.5 V	4 kΩ
	80°C (176°F)	0.7 V	0.5 kΩ

SERVICE DATA AND SPECIFICATIONS (SDS)

Turbine Revolution Sensor

NCS001RJ

Name	Condition	Data (Approx.)
Turbine revolution sensor 1	When running at 50 km/h (31 MPH) in 4th speed with the closed throttle position signal "OFF".	1.3 kHz
Turbine revolution sensor 2	When running at 20 km/h (12 MPH) in 1st speed with the closed throttle position signal "OFF".	

Vehicle Speed Sensor A/T (Revolution Sensor)

NCS001RK

Name	Condition	Data (Approx.)
Revolution sensor	When running at 20 km/h (12 MPH).	185 Hz

Reverse Brake

NCS001RL

Model code number	98X1D, 98X6C, 98X1C, 98X6D, 95X7A	
Number of drive plates	6	
Number of driven plates	6	
Clearance mm (in)	Standard	0.7 - 1.1 (0.028 - 0.043)
Thickness of retaining plates	Thickness mm (in)	Part number*
	4.2 (0.165)	31667 90X14
	4.4 (0.173)	31667 90X15
	4.6 (0.181)	31667 90X16
	4.8 (0.189)	31667 90X17
	5.0 (0.197)	31667 90X18
	5.2 (0.205)	31667 90X19

*: Always check with the Parts Department for the latest parts information.

Total End Play

NCS001RM

Total end play mm (in)	0.25 - 0.55 (0.0098 - 0.0217)
------------------------	-------------------------------

BEARING RACE FOR ADJUSTING TOTAL END PLAY

Thickness mm (in)	Part number*
0.8 (0.031)	31435 95X00
1.0 (0.039)	31435 95X01
1.2 (0.047)	31435 95X02
1.4 (0.055)	31435 95X03
1.6 (0.063)	31435 95X04
1.8 (0.071)	31435 95X05

*: Always check with the Parts Department for the latest parts information.