

SECTION **SBC**

SEAT BELT CONTROL SYSTEM

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

CONTENTS

| | |
|---|--|
| <p>BASIC INSPECTION 2</p> <p>DIAGNOSIS AND REPAIR WORK FLOW 2</p> <p style="padding-left: 20px;">Work Flow2</p> <p>SYSTEM DESCRIPTION 3</p> <p>SEAT BELT WARNING SYSTEM 3</p> <p style="padding-left: 20px;">System Diagram3</p> <p style="padding-left: 20px;">System Description3</p> <p style="padding-left: 20px;">Component Parts Location4</p> <p style="padding-left: 20px;">Component Description4</p> <p>DTC/CIRCUIT DIAGNOSIS 5</p> <p>SEAT BELT BUCKLE SWITCH 5</p> <p>DRIVER SIDE5</p> <p style="padding-left: 20px;">DRIVER SIDE : Description5</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Function Check5</p> <p style="padding-left: 20px;">DRIVER SIDE : Diagnosis Procedure5</p> <p style="padding-left: 20px;">DRIVER SIDE : Component Inspection (Belt Buckle Switch)6</p> <p>PASSENGER SIDE6</p> <p style="padding-left: 20px;">PASSENGER SIDE : Description6</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Function Check6</p> <p style="padding-left: 20px;">PASSENGER SIDE : Diagnosis Procedure7</p> <p style="padding-left: 20px;">PASSENGER SIDE : Component Inspection (Belt Buckle Switch)8</p> | <p>SEAT BELT WARNING LAMP CIRCUIT 9</p> <p style="padding-left: 20px;">Diagnosis Procedure 9</p> <p>SEAT BELT WARNING SYSTEM10</p> <p style="padding-left: 20px;">Wiring Diagram - SRS AIR BAG CONTROL SYSTEM -10</p> <p>ECU DIAGNOSIS INFORMATION13</p> <p>DIAGNOSIS SENSOR UNIT13</p> <p style="padding-left: 20px;">DTC Index13</p> <p style="padding-left: 20px;">Wiring Diagram - SRS AIR BAG CONTROL SYSTEM -17</p> <p>SYMPTOM DIAGNOSIS23</p> <p>SEAT BELT WARNING LAMP DOES NOT TURN OFF23</p> <p style="padding-left: 20px;">Diagnosis Procedure23</p> <p>SEAT BELT WARNING LAMP DOES NOT TURN ON24</p> <p style="padding-left: 20px;">Diagnosis Procedure24</p> <p>PRECAUTION25</p> <p>PRECAUTIONS25</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"25</p> <p style="padding-left: 20px;">Precaution Necessary for Steering Wheel Rotation after Battery Disconnect25</p> |
|---|--|

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000005142327

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much malfunction information (conditions and environment when the malfunction occurs) as possible when the customer brings the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that the malfunction is not reproduced, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END
NO >> GO TO 3.


SEAT BELT WARNING SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

SEAT BELT WARNING SYSTEM

System Diagram



System Description

INFOID:000000005142329

- Turns ON seat belt warning lamp, when the Occupant Detection System judges adult or child in the front passenger seat and the passenger seat belt buckle switch is OFF.
- Operation of air bag diagnosis sensor unit when air bag diagnosis sensor unit receives information from Occupant Detection System.
- In addition, seat belt warning lamp illuminates, when the driver side seat belt is not fasten. This does not relate to the air bag diagnosis sensor unit.
- For driver seat belt function, refer to [MWI-6. "METER SYSTEM : System Diagram"](#)


| Status (front passenger seat) | Seat belt warning lamp (When front passenger seat is unbuckled) |
|-------------------------------|---|
| Empty | OFF |
| An object | OFF |
| Child/ child-seat | ON |
| Adult | ON |
| Malfunction | OFF |

SEAT BELT WARNING SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000005142330



JMHIA1136ZZ

1. Air bag diagnosis sensor unit B13, B14, M59
Refer to [SRC-12. "Component Parts Location"](#)
2. Seat belt buckle switch (passenger side) B23
3. Occupant Detection System control unit B12
Refer to [SRC-12. "Component Parts Location"](#)
4. Seat belt buckle switch (driver side) B22

Component Description

INFOID:000000005142331

| Component parts | Outline of function |
|--|--|
| Seat belt buckle switch (Driver side) | Detects if the seat belt buckle switch (driver side) is fastened or unfastened |
| Seat belt buckle switch (Passenger side) | Detects if the seat belt buckle switch (passenger side) is fastened or unfastened |
| Seat belt warning lamp | Turns the seat belt warning lamp ON when the seat belt is unfastened |
| Occupant Detection System control unit | Judges the passenger seat condition based on the information from Occupant Detection System control unit |
| Occupant Detection System seat sensor | Detects if the passenger seat is empty or occupied |
| Air bag diagnosis sensor unit | Turns ON seat belt warning lamp based on the information from Occupant Detection System control unit |
| Front passenger air bag OFF indicator | Turns the front passenger air bag OFF indicator lamp ON when the front passenger seat is occupied by a child or a child seat |

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

SEAT BELT BUCKLE SWITCH DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000005142332

- Detects whether or not the seat belt is fastened when the ignition switch turns ON. If the seat belt is not fastened, it illuminates the seat belt warning lamp on the combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

DRIVER SIDE : Component Function Check

INFOID:000000005142333

1.CHECK SEAT BELT BUCKLE SWITCH

④ With CONSULT-III

When checking "BUCKLE SW" in DATA MONITOR in METER/M&A, check that ON/OFF display changes synchronized with the insertion operation to the seat belt buckle.

| Monitor item | Condition |
|--------------|--|
| BUCKLE SW | When driver side seat belt is not fastened: ON |
| | When driver side seat belt is fastened: OFF |

Is the inspection result normal?

- YES >> Seat belt buckle switch (driver side) circuit is normal.
NO >> Refer to [SBC-5, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000005142334

1.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch ON.
2. Disconnect seat belt buckle switch (driver side) connector.
3. Check voltage between seat belt buckle switch (driver side) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|---------------------------------------|----------|--------|--|--------------------------|
| Seat belt buckle switch (driver side) | | | | |
| Connector | Terminal | Ground | When driver side seat belt is fastened | Battery voltage |
| B22 | 1 | | When driver side seat belt is not fastened | 0 |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and seat belt buckle switch (driver side) harness connector.

| Combination meter | | Seat belt buckle switch (driver side) | | Continuity |
|-------------------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M34 | 9 | B22 | 1 | Existed |

4. Check continuity between combination meter harness connector and ground.

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Combination meter | | Ground | Continuity |
|-------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M34 | 9 | | Not existed |

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-97, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (driver side) harness connector and ground.

| Seat belt buckle switch (driver side) | | Ground | Continuity |
|---------------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B22 | 2 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side). Refer to [SBC-6, "DRIVER SIDE : Component Inspection \(Belt Buckle Switch\)"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (driver side). Refer to [SB-8, "SEAT BELT BUCKLE : Removal and Installation"](#).

DRIVER SIDE : Component Inspection (Belt Buckle Switch)

INFOID:000000005142335

1.CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

1. Turn ignition switch OFF
2. Disconnect seat belt buckle switch connector.
3. Check continuity of seat belt buckle (driver side).

| Seat belt buckle switch (driver side) | | Condition | Continuity |
|---------------------------------------|---|--|-------------|
| Terminal | | | |
| 1 | 2 | When driver side seat belt is not fastened | Existed |
| | | When driver side seat belt is fastened | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle (driver side). Refer to [SB-8, "SEAT BELT BUCKLE : Exploded View"](#)

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000005142336

- Detects whether or not the seat belt is fastened when the ignition switch turns ON. If the seat belt switch is not fastened, it illuminates the seat belt warning lamp on the combination meter.
- The seat belt buckle switch is installed in the seat belt buckle.

PASSENGER SIDE : Component Function Check

INFOID:000000005142337

1.CHECK SEAT BELT WARNING FUNCTION

1. Sit down in passenger seat.
2. Check that seat belt warning lamp turns OFF when passenger seat belt is fastened, and then turns ON when passenger seat belt is unfastened.

Is the inspection result normal?

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Seat belt buckle switch (passenger side) circuit is normal.
 NO >> Refer to [SBC-7, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000005142338

1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT

- Turn ignition switch ON.
- Disconnect seat belt buckle switch (passenger side) connector.
- Check that voltage between seat belt buckle switch (passenger side) and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|--|----------|--------|---|--------------------------|
| Seat belt buckle switch (passenger side) | | | | |
| Connector | Terminal | | | |
| B23 | 1 | Ground | When passenger side seat belt is fastened | Battery voltage |
| | | | When passenger side seat belt is not fastened | 0 |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) CIRCUIT

- Turn ignition switch OFF.
- Disconnect air bag diagnosis sensor unit connector.
- Check continuity between air bag diagnosis sensor unit harness connector and seat belt buckle switch (passenger side) harness connector.

| Air bag diagnosis sensor unit | | Seat belt buckle switch (passenger side) | | Continuity |
|-------------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B14 | 29 | B23 | 1 | Existed |

- Check continuity between air bag diagnosis sensor unit harness connector and ground.

| Air bag diagnosis sensor unit | | Ground | Continuity |
|-------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B14 | 29 | | Not existed |

Is the inspection result normal?

- YES >> Replace air bag diagnosis sensor unit. Refer to [SR-20, "Removal and Installation"](#).
 NO >> Repair or replace harness between air bag diagnosis sensor unit and seat belt buckle switch (passenger side).

3. CHECK SEAT BELT BUCKLE SWITCH GROUND CIRCUIT

Check continuity between seat belt buckle switch (passenger side) harness connector and ground.

| Seat belt buckle switch (passenger side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| B23 | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side). Refer to [SBC-8, "PASSENGER SIDE : Component Inspection \(Belt Buckle Switch\)"](#).

Is the inspection result normal?

- YES >> INSPECTION END

SEAT BELT BUCKLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace seat belt buckle (passenger side). Refer to [SB-8, "SEAT BELT BUCKLE : Removal and Installation"](#).

PASSENGER SIDE : Component Inspection (Belt Buckle Switch)

INFOID:000000005142339

1. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

1. Turn ignition switch OFF.
2. Disconnect seat belt buckle switch connector.
3. Check continuity of seat belt (passenger side).

| Seat belt buckle switch (passenger side) | | Condition | Continuity |
|--|---|---|-------------|
| Terminal | | | |
| 1 | 2 | When passenger side seat belt is not fastened | Existed |
| | | When passenger side seat belt is fastened | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace seat belt buckle switch (passenger side). Refer to [SB-8, "SEAT BELT BUCKLE : Removal and Installation"](#).

SEAT BELT WARNING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT WARNING LAMP CIRCUIT

Diagnosis Procedure

INFOID:000000005142340

1. CHECK SEAT BELT WARNING LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Turn ignition switch ON.
4. Check that voltage between combination meter harness connector and ground.

| Combination meter | | Ground | Voltage (V) (Approx.) |
|-------------------|----------|--------|--------------------------|
| Connector | Terminal | | Battery voltage |
| M34 | 29 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace combination meter. Refer to [MWI-97, "Removal and Installation"](#).

2. CHECK SEAT BELT WARNING LAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect air bag diagnosis sensor unit connector.
3. Check continuity between combination meter harness connector and air bag diagnosis sensor unit harness connector.

| Combination meter | | Air bag diagnosis sensor unit | | Continuity |
|-------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M34 | 29 | M59 | 24 | Existed |

4. Check continuity between combination meter and ground.

| Combination meter | | Ground | Continuity |
|-------------------|----------|--------|-------------|
| Connector | Terminal | | Not existed |
| M34 | 29 | | |

Is the inspection result normal?

YES >> Replace air bag diagnosis sensor unit. Refer to [SR-20, "Removal and Installation"](#).

NO >> Repair or replace harness.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC


SEAT BELT WARNING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT WARNING SYSTEM

Wiring Diagram - SRS AIR BAG CONTROL SYSTEM -

INFOID:000000005142341



2009/02/27


JCHWM0430GB

SEAT BELT WARNING SYSTEM

< DTC/CIRCUIT DIAGNOSIS >


SEAT BELT WARNING SYSTEM

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FV-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 9 | O | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 28 | GR | IGNITION SIGNAL |
| 29 | BR | PASSENGER SEAT BELT WARNING SIGNAL |

| | |
|----------------|--------------|
| Connector No. | M80 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FV-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11 | O | - |

| | |
|----------------|-------------------------------|
| Connector No. | M59 |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH28FY-EX |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R/L | IGN |
| 2 | B | GND |
| 24 | BR | SEAT BELT W/L |
| 25 | R/B | CUTOFF TELLTALE |
| 59 | L | CAN-H |
| 60 | P | CAN-L |

| | |
|----------------|---------------------------------|
| Connector No. | M64 |
| Connector Name | PASSENGER AIR BAG OFF INDICATOR |
| Connector Type | JAB05FB |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R/B | - |
| 2 | B | - |

| | |
|----------------|--------------|
| Connector No. | M79 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FV-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 15 | R/L | - |
| 16 | GR/R | - |

JCHWM0432GB

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

DIAGNOSIS SENSOR UNIT

DTC Index

INFOID:000000005175400

| DTC | Diagnostic item | Explanation | Reference page |
|-------------------------|---------------------------------|---|--|
| — | NO DTC IS DETECTED. | Low battery voltage (Less than 9 V) | SRC-23, "CONSULT-III Function" . |
| | | When malfunction is indicated by the "AIR BAG" warning lamp in the user mode | SRC-17, "Diagnosis with Air Bag Warning Lamp" , SRC-23, "CONSULT-III Function" . |
| | | Self-diagnostic result is not erased after repair | GI-34, "Intermittent Incident" |
| | | Intermittent malfunction is detected in the past | |
| | No malfunction is detected | — | |
| B1001-B1015 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | <ul style="list-style-type: none"> SRC-25, "DTC Logic". SRC-27, "DTC Logic". SRC-29, "DTC Logic". |
| B1017 B1020 B1021 | OCCUPANT SENS C/U [UNIT FAIL] | Malfunction occurs in Occupant Detection System control unit | SRC-31, "DTC Logic" . |
| B1018 | OCCUPANT SENS [UNIT FAIL] | Malfunction occurs in Occupant Detection System sensor | SRC-33, "DTC Logic" . |
| B1022 | OCCUPANT SENS C/U [COMM FAIL] | Malfunction occurs in Occupant Detection System control unit, circuit of Occupant Detection System control unit air bag diagnosis sensor unit, or air bag diagnosis sensor unit | SRC-35, "DTC Logic" . |
| B1023 | PASS A/B INDCTR CKT | Passenger air bag OFF indicator circuit is open or shorted to ground or the circuits are shorted each other | SRC-37, "DTC Logic" . |
| B1025 B1032 B1048 | OCS SENSOR | Malfunction occurs in Occupant Detection System control unit, circuit of Occupant Detection System control unit air bag diagnosis sensor unit, or air bag diagnosis sensor unit | SRC-39, "DTC Logic" . |
| B1026-B1031 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning or out of the specified specification | SRC-41, "DTC Logic" . |
| B1033 B1034 | CRASH ZONE SEN [UNIT FAIL] | Crash zone sensor is malfunctioning | SRC-43, "DTC Logic" . |
| B1035 | CRASH ZONE SEN [COMM FAIL] | Crash zone sensor is malfunctioning | SRC-45, "DTC Logic" . |
| B1036 | CRASH ZONE SEN [UNMATCH] | Crash zone sensor is out of the specified specification | SRC-47, "DTC Logic" . |
| B1037 B1039 B1041 | CRASH ZONE SEN1 | Crash zone sensor is malfunctioning | SRC-49, "DTC Logic" . |
| B1042-B1047 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-51, "DTC Logic" . |
| B1049 B1054 | DRIVER AIRBAG MODULE [OPEN] | Driver air bag module circuit is open (including the spiral cable) | SRC-53, "DTC Logic" . |
| B1050 B1055 | DRIVER AIRBAG MODULE [VB-SHORT] | Driver air bag module circuit is shorted to power supply circuit (including the spiral cable) | SRC-55, "DTC Logic" . |

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

| DTC | Diagnostic item | Explanation | Reference page |
|----------------|-------------------------------------|---|--|
| B1051 B1056 | DRIVER AIRBAG MODULE [GND-SHORT] | Driver air bag module circuit is shorted to ground (including the spiral cable) | SRC-57, "DTC Logic" . |
| B1052 B1057 | DRIVER AIRBAG MODULE [SHORT] | Driver air bag module circuits are shorted to each other (including spiral cable) | SRC-59, "DTC Logic" . |
| B1058-B1063 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-61, "DTC Logic" . |
| B1065 B1070 | ASSIST A/B MODULE [OPEN] | Passenger air bag module circuit is open | SRC-63, "DTC Logic" . |
| B1066 B1071 | ASSIST A/B MODULE [VB-SHORT] | Passenger air bag module circuit is shorted to power supply circuit | SRC-65, "DTC Logic" . |
| B1067 B1072 | ASSIST A/B MODULE [GND-SHORT] | Passenger air bag module circuit is shorted to ground | SRC-67, "DTC Logic" . |
| B1068 B1073 | ASSIST A/B MODULE [SHORT] | Passenger air bag module circuits are shorted to each other | SRC-69, "DTC Logic" . |
| B1074-B1079 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-71, "DTC Logic" . |
| B1080 B1096 | DRIVER AIRBAG MODULE [SHORT] | Driver air bag module circuits are shorted to each other (including spiral cable) | SRC-73, "DTC Logic" . |
| B1081 | PRE-TEN FRONT RH [OPEN] | Seat belt pre-tensioner RH circuit is open | SRC-75, "DTC Logic" . |
| B1082 | PRE-TEN FRONT RH [VB-SHORT] | Seat belt pre-tensioner RH circuit is shorted to power supply circuit | SRC-77, "DTC Logic" . |
| B1083 | PRE-TEN FRONT RH [GND-SHORT] | Seat belt pre-tensioner RH circuit is shorted to ground | SRC-79, "DTC Logic" . |
| B1084 | PRE-TEN FRONT RH [SHORT] | Seat belt pre-tensioner RH circuits are shorted to each other | SRC-81, "DTC Logic" . |
| B1086 | PRE-TEN FRONT LH [OPEN] | Seat belt pre-tensioner LH circuit is open | SRC-83, "DTC Logic" . |
| B1087 | PRE-TEN FRONT LH [VB-SHORT] | Seat belt pre-tensioner LH circuit is shorted to power supply circuit | SRC-85, "DTC Logic" . |
| B1088 | PRE-TEN FRONT LH [GND-SHORT] | Seat belt pre-tensioner LH circuit is shorted to ground | SRC-87, "DTC Logic" . |
| B1089 | PRE-TEN FRONT LH [SHORT] | Seat belt pre-tensioner LH circuits are shorted to each other | SRC-89, "DTC Logic" . |
| B1090-B1095 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-91, "DTC Logic" . |
| B1106-B1111 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-93, "DTC Logic" . |
| B1113 B1114 | SATELLITE SENS RH [UNIT FAIL] | Satellite sensor RH is malfunctioning | SRC-95, "DTC Logic" . |
| B1115 | SATELLITE SENS RH [COMM FAIL] | Satellite sensor RH is malfunctioning | SRC-97, "DTC Logic" . |
| B1116 | SATELLITE SENS RH [UNMATCH] | Satellite sensor RH is out of the specified specification | SRC-99, "DTC Logic" . |
| B1118 B1119 | SATELLITE SENS LH [UNIT FAIL] | Satellite sensor LH is malfunctioning | SRC-101, "DTC Logic" . |
| B1120 | SATELLITE SENS LH [COMM FAIL] | Satellite sensor LH is malfunctioning | SRC-103, "DTC Logic" . |
| B1121 | SATELLITE SENS LH [UNMATCH] | Satellite sensor LH is out of the specified specification | SRC-105, "DTC Logic" . |
| B1122-B1127 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-107, "DTC Logic" . |

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

| DTC | Diagnostic item | Explanation | Reference page |
|-------------|-------------------------------|--|--|
| B1129 | SIDE MODULE RH [OPEN] | Side air bag module RH circuit is open | SRC-109, "DTC Logic" . |
| B1130 | SIDE MODULE RH [VB-SHORT] | Side air bag module RH circuit is shorted to power supply circuit | SRC-111, "DTC Logic" . |
| B1131 | SIDE MODULE RH [GND-SHORT] | Side air bag module RH circuit is shorted to ground | SRC-113, "DTC Logic" . |
| B1132 | SIDE MODULE RH [SHORT] | Seat belt pre-tensioner RH circuits are shorted to each other | SRC-115, "DTC Logic" . |
| B1134 | SIDE MODULE LH [OPEN] | Side air bag module LH circuit is open | SRC-117, "DTC Logic" . |
| B1135 | SIDE MODULE LH [VB-SHORT] | Side air bag module LH circuit is shorted to power supply circuit | SRC-119, "DTC Logic" . |
| B1136 | SIDE MODULE LH [GND-SHORT] | Side air bag module LH circuit is shorted to ground | SRC-121, "DTC Logic" . |
| B1137 | SIDE MODULE LH [SHORT] | Side air bag module LH circuits are shorted to each other | SRC-123, "DTC Logic" . |
| B1138-B1143 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-125, "DTC Logic" |
| B1144 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning or out of the specified specification | SRC-127, "DTC Logic" . |
| B1145 | CURTAIN MODULE RH [OPEN] | Curtain air bag module RH circuit is open | SRC-128, "DTC Logic" . |
| B1146 | CURTAIN MODULE RH [VB-SHORT] | Curtain air bag module RH circuit is shorted to power supply circuit | SRC-130, "DTC Logic" . |
| B1147 | CURTAIN MODULE RH [GND-SHORT] | Curtain air bag module RH circuit is shorted to ground | SRC-132, "DTC Logic" . |
| B1148 | CURTAIN MODULE RH [SHORT] | Curtain air bag module RH circuits are shorted to each other | SRC-134, "DTC Logic" . |
| B1150 | CURTAIN MODULE LH [OPEN] | Curtain air bag module LH circuit is open | SRC-136, "DTC Logic" . |
| B1151 | CURTAIN MODULE LH [VB-SHORT] | Curtain air bag module LH circuit is shorted to power supply circuits | SRC-138, "DTC Logic" . |
| B1152 | CURTAIN MODULE LH [GND-SHORT] | Curtain air bag module LH circuit is shorted to ground | SRC-140, "DTC Logic" . |
| B1153 | CURTAIN MODULE LH [SHORT] | Curtain air bag module LH circuits are shorted to each other | SRC-142, "DTC Logic" . |
| B1154-B1159 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-144, "DTC Logic" . |
| B1170-B1175 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-146, "DTC Logic" . |
| B1186-B1191 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-148, "DTC Logic" . |
| B1202-B1207 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-150, "DTC Logic" . |
| B1209 | FRONTAL COLLISION DETECTION | Seat belt pre-tensioner, driver side air bag and passenger air bag are deployed | SRC-152, "DTC Logic" . |
| B1210 | SIDE COLLISION DETECTION | Side air bag and curtain air bag are deployed | SRC-154, "DTC Logic" . |
| B1211 | ROLLOVER DETECTION | Seat belt pre-tensioner side curtain air bag module are deployed because of rollover detection | SRC-156, "DTC Logic" . |
| B1212-B1214 | RH1 SAT-SENS | Satellite sensor RH is malfunctioning | SRC-158, "DTC Logic" . |

A

B

C

D

E

F

G

SBC

I

J

K

L

M

N

O

P

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

| DTC | Diagnostic item | Explanation | Reference page |
|-------------|-----------------|---|--|
| B1215-B1217 | LH1 SAT-SENS | Satellite sensor LH is malfunctioning | SRC-160, "DTC Logic" . |
| B1218-B1223 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-162, "DTC Logic" . |
| B1239 | CONTROL UNIT | Air bag diagnosis sensor unit is malfunctioning | SRC-164, "DTC Logic" . |


DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - SRS AIR BAG CONTROL SYSTEM -

INFOID:000000005142549

SRS AIR BAG CONTROL SYSTEM



*: This connector is not shown in "Harness Layout".


2009/02/27

JCHWM0433GB

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >




JCHWM0434GB

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

SRS AIR BAG CONTROL SYSTEM

| | |
|----------------|--------------|
| Connector No. | B4 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 15 | R | - |
| 16 | GR | - |

| | |
|----------------|------------------------|
| Connector No. | B8 |
| Connector Name | SIDE AIR BAG MODULE LH |
| Connector Type | TK02FY-EX-1V |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | Y | - |

| | |
|----------------|------------------------|
| Connector No. | B9 |
| Connector Name | SIDE AIR BAG MODULE RH |
| Connector Type | TK02FY-EX-1V |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | Y | - |

| | |
|----------------|--|
| Connector No. | B12 |
| Connector Name | OCCUPANT DETECTION SYSTEM CONTROL UNIT |
| Connector Type | TH03FW-NH |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | V | - |
| 4 | R | - |
| 5 | B | - |
| 7 | GR | - |

| | |
|----------------|-------------------------------|
| Connector No. | B13 |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH22FY-1V-EX |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | Y | PRH (+) |
| 11 | Y | PRH (-) |
| 26 | V | ODS INPUT |
| 29 | LG | RH BUCKLE SW INPUT |
| 31 | Y | SRH (+) |
| 32 | Y | SRH (-) |
| 35 | P | GRH (+) |
| 36 | L | GRH (-) |
| 47 | G | SATELLITE RH (+) |
| 48 | R | SATELLITE RH (-) |
| 55 | SHIELD | GND |

| | |
|----------------|-------------------------------|
| Connector No. | B14 |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH22FY-2V-EX |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 12 | Y | PLH (+) |
| 13 | Y | PLH (-) |
| 30 | O | LH BUCKLE SW INPUT |
| 33 | Y | SLH (-) |
| 34 | Y | SLH (+) |
| 37 | G | QLH (+) |
| 38 | R | QLH (-) |
| 49 | P | SATELLITE LH (+) |
| 50 | L | SATELLITE LH (-) |
| 56 | SHIELD | GND |

| | |
|----------------|---------------------------------------|
| Connector No. | B22 |
| Connector Name | SEAT BELT BUCKLE SWITCH (DRIVER SIDE) |
| Connector Type | A03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B23 |
| Connector Name | SEAT BELT BUCKLE SWITCH (PASSENGER SIDE) |
| Connector Type | A03FW |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | B | - |

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

JCHWM0435GB

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

SRS AIR BAG CONTROL SYSTEM

| | |
|----------------|----------------------------|
| Connector No. | B29 |
| Connector Name | SEAT BELT PRE-TENSIONER RH |
| Connector Type | ACA02FY-2V |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | Y | - |

| | |
|----------------|---------------------|
| Connector No. | B30 |
| Connector Name | SATELLITE SENSOR RH |
| Connector Type | HK02FY-1V-EX |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | R | - |

| | |
|----------------|----------------------------|
| Connector No. | B36 |
| Connector Name | SEAT BELT PRE-TENSIONER LH |
| Connector Type | ACA02FY-2V |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | Y | - |

| | |
|----------------|---------------------|
| Connector No. | B37 |
| Connector Name | SATELLITE SENSOR LH |
| Connector Type | HK02FY-1V-EX |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | - |
| 2 | L | - |

| | |
|----------------|---------------------------|
| Connector No. | B56 |
| Connector Name | CURTAIN AIR BAG MODULE RH |
| Connector Type | ACA02FY-2V |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | - |
| 2 | L | - |

| | |
|----------------|---------------------------|
| Connector No. | B72 |
| Connector Name | CURTAIN AIR BAG MODULE LH |
| Connector Type | ACA02FY-2V |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | R | - |

| | |
|----------------|-------------------|
| Connector No. | E33 |
| Connector Name | CRASH ZONE SENSOR |
| Connector Type | HK02FY-1V-EX |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | - |
| 2 | L | - |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TR80MY-C516-TM4 |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 59 | L | - |
| 69 | P | - |
| 70 | SHIELD | - |


JCHWM0436GB

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >


SRS AIR BAG CONTROL SYSTEM

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 6 | L | - |
| 7 | GF/R | - |
| 14 | P | - |

| | |
|----------------|-----------------------------------|
| Connector No. | M32 |
| Connector Name | COMBINATION SWITCH (SPIRAL CABLE) |
| Connector Type | TK08FY-EX-TV |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 23 | Y | - |
| 29 | L/Y | - |
| 30 | Y/R | - |

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | TH46FW-NH |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7 | R/G | AIR BAG SIGNAL |
| 22 | B | GROUND |
| 23 | B | GROUND |
| 28 | GR | IGNITION SIGNAL |


| | |
|----------------|-------------------------------|
| Connector No. | M59 |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH28FY-EX |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R/L | IGN |
| 2 | B | GND |
| 3 | Y | DR1 (+) |
| 4 | Y/R | DR1 (-) DR2 (-) |
| 5 | L/Y | DR2 (+) |
| 6 | Y/G | AS1 (+) |
| 7 | Y/B | AS1 (-) |
| 8 | Y/L | AS2 (+) |
| 9 | G/Y | AS2 (-) |
| 18 | LG | EGS2 (+) |
| 18 | Y | EGS2 (-) |


| | | | |
|--------------|----|--------|-----------------|
| Terminal No. | 22 | SHIELD | SHIELD |
| Terminal No. | 23 | R/G | AIR BAG W/L |
| Terminal No. | 25 | R/B | OUTOFF TELLTALE |
| Terminal No. | 59 | L | CAN-H |
| Terminal No. | 60 | P | CAN-L |

| | |
|----------------|--------------------------|
| Connector No. | M62 |
| Connector Name | PASSENGER AIR BAG MODULE |
| Connector Type | RK06FY-BD |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y/G | - |
| 2 | Y/B | - |
| 3 | Y/L | - |
| 4 | G/Y | - |

| | |
|----------------|---------------------------------|
| Connector No. | M64 |
| Connector Name | PASSENGER AIR BAG OFF INDICATOR |
| Connector Type | LJ40GF8B |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R/B | - |
| 2 | B | - |

JCHWM0437GB

A
B
C
D
E
F
G
SBC
I
J
K
L
M
N
O
P

DIAGNOSIS SENSOR UNIT

< ECU DIAGNOSIS INFORMATION >

SRS AIR BAG CONTROL SYSTEM

| | | | |
|----------------|-----------------|----------------|-----------------------|
| Connector No. | M77 | Connector No. | M351 |
| Connector Name | WIRE TO WIRE | Connector Name | DRIVER AIR BAG MODULE |
| Connector Type | TH807W-C516-TM4 | Connector Type | ACA02FOR |

| | | | |
|-----------------------------|--------|-----------------------------|----|
| Terminal No. | 59 | Terminal No. | 9 |
| | 69 | | 12 |
| | 70 | | |
| Color of Wire | V | Color of Wire | - |
| | LG | | - |
| | SHIELD | | - |
| Signal Name [Specification] | - | Signal Name [Specification] | - |

| | | | |
|----------------|--------------|----------------|-----------------------|
| Connector No. | M79 | Connector No. | M350 |
| Connector Name | WIRE TO WIRE | Connector Name | DRIVER AIR BAG MODULE |
| Connector Type | TH24FW-NH | Connector Type | ACA02FY-2V |

| | | | |
|-----------------------------|------|-----------------------------|----|
| Terminal No. | 15 | Terminal No. | 10 |
| | 16 | | 11 |
| Color of Wire | R/L | Color of Wire | - |
| | GR/R | | - |
| Signal Name [Specification] | - | Signal Name [Specification] | - |

| | | | |
|----------------|--------------|----------------|-----------------------|
| Connector No. | M79 | Connector No. | M350 |
| Connector Name | WIRE TO WIRE | Connector Name | DRIVER AIR BAG MODULE |
| Connector Type | TH24FW-NH | Connector Type | ACA02FY-2V |

| | | | |
|--------------|----|--------------|----|
| Terminal No. | 12 | Terminal No. | 10 |
| | 11 | | 11 |
| | 10 | | 10 |
| | 9 | | 11 |
| | 8 | | 10 |
| | 7 | | 11 |
| | 6 | | 10 |
| | 5 | | 11 |
| | 4 | | 10 |
| | 3 | | 11 |
| | 2 | | 10 |
| | 1 | | 11 |
| | 24 | | 10 |
| | 23 | | 11 |
| | 22 | | 10 |
| | 21 | | 11 |
| | 20 | | 10 |
| | 19 | | 11 |
| | 18 | | 10 |
| | 17 | | 11 |
| | 16 | | 10 |
| | 15 | | 11 |
| | 14 | | 10 |
| | 13 | | 11 |
| | 12 | | 10 |
| | 11 | | 11 |
| | 10 | | 10 |
| | 9 | | 11 |
| | 8 | | 10 |
| | 7 | | 11 |
| | 6 | | 10 |
| | 5 | | 11 |
| | 4 | | 10 |
| | 3 | | 11 |
| | 2 | | 10 |
| | 1 | | 11 |

JCHWM0438GB

SEAT BELT WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

SEAT BELT WARNING LAMP DOES NOT TURN OFF

Diagnosis Procedure

INFOID:000000005142344

1. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side). Refer to [SBC-5. "DRIVER SIDE : Component Function Check"](#)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side). Refer to [SBC-6. "PASSENGER SIDE : Component Function Check"](#)

NOTE:

Except for Mexico

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK SEAT BELT WARNING LAMP CIRCUIT

Check seat belt warning lamp circuit. Refer to [SBC-9. "Diagnosis Procedure"](#)

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-34. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
I
J
K
L
M
N
O
P

SBC

SEAT BELT WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

SEAT BELT WARNING LAMP DOES NOT TURN ON

Diagnosis Procedure

INFOID:000000005142345

1. CHECK SELF-DIAGNOSIS RESULT

Perform "COMBINATION METER" self-diagnosis result. Refer to [MWI-30, "CONSULT-III Function \(METER/M&A\)"](#)

Is DTC detected?

- YES >> Repair or replace the malfunctioning parts.
- NO >> GO TO 2.

2. CHECK POWER SUPPLY

Check that fuses are not blown.

Check ignition power supply of combination meter. Refer to [MWI-39, "COMBINATION METER : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK SEAT BELT BUCKLE SWITCH (DRIVER SIDE)

Check seat belt buckle switch (driver side). Refer to [SBC-5, "DRIVER SIDE : Component Function Check"](#)

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK SEAT BELT BUCKLE SWITCH (PASSENGER SIDE)

Check seat belt buckle switch (passenger side). Refer to [SBC-6, "PASSENGER SIDE : Component Function Check"](#)

NOTE:

Except for Mexico

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. CHECK SEAT BELT WARNING LAMP CIRCUIT

Check seat belt warning lamp circuit. Refer to [SBC-9, "Diagnosis Procedure"](#)

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-34, "Intermittent Incident"](#).
- NO >> GO TO 1.

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005142550

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000005142551

NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.