

# SECTION SN

## SONAR SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
SN  
O  
P

## CONTENTS

|  |    |  |    |
|--|----|--|----|
| <b>BASIC INSPECTION .....</b>                      | 3  | Description .....                              | 15 |
| <b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>         | 3  | DTC Logic .....                                | 15 |
| Work Flow .....                                    | 3  | Diagnosis Procedure .....                      | 15 |
| <b>SYSTEM DESCRIPTION .....</b>                    | 5  | <b>B270A CENTER SENSOR [BR] .....</b>          | 16 |
| <b>SONAR SYSTEM .....</b>                          | 5  | Description .....                              | 16 |
| System Diagram .....                               | 5  | DTC Logic .....                                | 16 |
| System Description .....                           | 5  | <b>B270B SENSOR HARNESS OPEN [CT-BR] ...</b>   | 17 |
| Component Parts Location .....                     | 7  | Description .....                              | 17 |
| Component Description .....                        | 7  | DTC Logic .....                                | 17 |
| <b>DIAGNOSIS SYSTEM (SONAR CONTROL UNIT) .....</b> | 8  | Diagnosis Procedure .....                      | 17 |
| CONSULT-III Function (SONAR) .....                 | 8  | <b>POWER SUPPLY AND GROUND CIRCUIT ....</b>    | 18 |
| <b>DTC/CIRCUIT DIAGNOSIS .....</b>                 | 10 | <b>SONAR CONTROL UNIT .....</b>                | 18 |
| <b>B2704 CORNER SENSOR [RL] .....</b>              | 10 | SONAR CONTROL UNIT : Diagnosis Procedure....18 |    |
| Description .....                                  | 10 | <b>R RANGE SIGNAL CIRCUIT .....</b>            | 19 |
| DTC Logic .....                                    | 10 | Description .....                              | 19 |
| <b>B2705 SENSOR HARNESS OPEN [CR-RL] ....</b>      | 11 | Diagnosis Procedure .....                      | 19 |
| Description .....                                  | 11 | <b>BUZZER DRIVE SIGNAL CIRCUIT .....</b>       | 20 |
| DTC Logic .....                                    | 11 | Description .....                              | 20 |
| Diagnosis Procedure .....                          | 11 | Diagnosis Procedure .....                      | 20 |
| <b>B2706 CORNER SENSOR [RR] .....</b>              | 12 | <b>ECU DIAGNOSIS INFORMATION .....</b>         | 21 |
| Description .....                                  | 12 | <b>SONAR CONTROL UNIT .....</b>                | 21 |
| DTC Logic .....                                    | 12 | Reference Value .....                          | 21 |
| <b>B2707 SENSOR HARNESS OPEN [CR-RR] ....</b>      | 13 | Wiring Diagram - SONAR SYSTEM - .....          | 24 |
| Description .....                                  | 13 | Fail Safe .....                                | 27 |
| DTC Logic .....                                    | 13 | DTC Index .....                                | 28 |
| Diagnosis Procedure .....                          | 13 | <b>SYMPTOM DIAGNOSIS .....</b>                 | 29 |
| <b>B2708 CENTER SENSOR [BL] .....</b>              | 14 | <b>SONAR SYSTEM SYMPTOMS .....</b>             | 29 |
| Description .....                                  | 14 | Symptom Table .....                            | 29 |
| DTC Logic .....                                    | 14 | <b>PRECAUTION .....</b>                        | 30 |
| <b>B2709 SENSOR HARNESS OPEN [CT-BL] ....</b>      | 15 | <b>PRECAUTIONS .....</b>                       | 30 |

---

|  |    |   |                |
|--|----|---|----------------|
| Precaution for Supplemental Restraint System<br>(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-<br>SIONER" ..... | 30 | <b>CENTER SENSOR</b> .....<br>CENTER SENSOR : Exploded View .....<br>CENTER SENSOR : Removal and Installation ..... | 32<br>32<br>32 |
| <b>REMOVAL AND INSTALLATION</b> .....  | 31 | <b>CORNER SENSOR</b> .....<br>CORNER SENSOR : Exploded View .....<br>CORNER SENSOR : Removal and Installation ..... | 32<br>32<br>33 |
| <b>SONAR CONTROL UNIT</b> .....  | 31 | <b>BUZZER</b> .....   | 34             |
| Exploded View .....  | 31 | Exploded View .....   | 34             |
| Removal and Installation .....   | 31 | Removal and Installation .....  | 34             |
| <b>SONAR SENSOR</b> .....  | 32 |   |                |

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000004964334

#### OVERALL SEQUENCE



JSNIA0732GB

- Reference 1... Refer to [SN-8, "CONSULT-III Function \(SONAR\)".](#)
- Reference 2... Refer to [SN-28, "DTC Index".](#)
- Reference 3... Refer to [SN-29, "Symptom Table".](#)

SN

#### DETAILED FLOW

##### 1. INTERVIEW AND SYMPTOM CONFIRMATION

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check if mud, or other foreign objects are not adhering to the sonar sensor.
- Check if there is no deformation, scratches, or other damage to the sonar sensor.
- Check if water has not accumulated in the sonar sensor.
- Check the symptom.

Is the occurred symptom malfunction?

O

P

YES >> GO TO 2.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NO    >> INSPECTION END

## 2. DIAGNOSIS WITH CONSULT-III

1. Connect CONSULT-III and perform a self-diagnosis for "SONAR". Refer to [SN-8, "CONSULT-III Function \(SONAR\)".](#)
2. Check if any DTC is displayed in the self-diagnosis results.

Is DTC displayed?

YES    >> GO TO 3.

NO    >> GO TO 4.

## 3. TROUBLE DIAGNOSIS FOR DTC

1. Check the DTC indicated in the self-diagnosis results.
2. Perform the relevant diagnosis referring to the DTC Index. Refer to [SN-28, "DTC Index".](#)

    >> GO TO 5.

## 4. TROUBLE DIAGNOSIS FOR SYMPTOMS

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [SN-29, "Symptom Table".](#)

    >> GO TO 5.

## 5. ERROR PART REPAIR

1. Repair or replace the identified malfunctioning parts.
2. Perform a self-diagnosis for "SONAR" with CONSULT-III.
3. Check that the symptom does not occur.

Does the symptom occur?

YES    >> GO TO 1.

NO    >> INSPECTION END


# SONAR SYSTEM

< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### SONAR SYSTEM

#### System Diagram



INFOID:000000004964339

#### System Description

INFOID:000000004964340

- The sonar sensor installed to the rear bumper detects obstacles around the bumper.
- The distance between a bumper and obstacles is informed to the driver with different frequency of buzzer.

#### ACTIVATION CONDITION


The rear sensor activates and outputs the warning buzzer in the following conditions.

- Reverse signal ON
- Obstacle detection

#### OBSTACLE DETECTION DISTANCE

- The sonar control unit controls the obstacle detection distance. The detection distance differs between the corner sensor and the center sensor.
- The sonar control unit outputs the warning buzzer frequency at 3 levels according to the corner sensor detection condition.
- The sonar control unit outputs the warning buzzer frequency at 4 levels according to the center sensor detection condition.
- The detection condition setting is adjustable to 4 levels with CONSULT-III. Refer to [SN-8, "CONSULT-III Function \(SONAR\)".](#)
- CONSULT-III enables the center sensor (rear) not to detect the range of 40 cm (15.7 in) or less to prevent from the trailer hitch vehicles misdetection. Refer to [SN-8, "CONSULT-III Function \(SONAR\)".](#)

Obstacle detection range image



JPNIA1708ZZ

A. Approx. 60 cm (23.6 in)

B. Approx. 100 cm (39.3 in)

C. Approx. 50 cm (19.6 in)

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

# SONAR SYSTEM


## < SYSTEM DESCRIPTION >

Detection distance (Default)

| Warning item         | Corner sensor               | Center sensor                |
|----------------------|-----------------------------|------------------------------|
| First stage warning  | —                           | 60 – 100 cm (23.6 – 39.3 in) |
| Second stage warning | 50 – 60 cm (19.6 – 23.6 in) | 50 – 60 cm (19.6 – 23.6 in)  |
| Third stage warning  | 30 – 50 cm (11.8 – 19.6 in) | 30 – 50 cm (11.8 – 19.6 in)  |
| Fourth stage warning | Less than 30 cm (11.8 in)   | Less than 30 cm (11.8 in)    |

### Warning Buzzer Frequency

- The warning buzzer output frequency changes 4 levels (for center) and 3 levels (for corner) according to the detection distance.
- The nearest sensor from the detected obstacle applies the buzzer output frequency if plural sensors detect any obstacle simultaneously.



### NOTE:

The warning buzzer of the corner sensor sounds as follows.


- As for the first, second, and third stages, the warning buzzer sounds 3 seconds at maximum.
- As for the fourth stage, the warning buzzer does not stop even after a lapse of 3 seconds.

# SONAR SYSTEM

< SYSTEM DESCRIPTION >

## Component Parts Location

INFOID:000000004964341



JPNIA1709ZZ

- |                                   |   |                          |
|-----------------------------------|---|--------------------------|
| 1. Corner sensor rear LH          | 2. Center sensor rear LH                  | 3. Center sensor rear RH |
| 4. Corner sensor rear RH          | 5. Sonar control unit                     | 6. Buzzer                |
| A. Glove box is removed condition | B. Combination meter is removed condition |                          |

## Component Description

INFOID:000000004964342

| Component            | Description  |
|----------------------|--|
| SONAR CONTROL UNIT   | <ul style="list-style-type: none"><li>The warning buzzer outputs by inputting the sensor signal from corner/center sensor. The warning buzzer outputs the separated buzzer.</li><li>When reverse signal is input, a power supply is input into sonar control unit.</li></ul> |
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit.  |
| BUZZER               | The warning buzzer outputs with the signal from the sonar control unit.  |

SN

O

P

# DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

### CONSULT-III Function (SONAR)

INFOID:000000004964343

#### DESCRIPTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown as follows:

| Test mode               | Function   |
|-------------------------|--|
| Ecu Identification      | Sonar control unit part number can be read.                            |
| Self Diagnostic Results | Sonar control unit checks the conditions and displays memorized error. |
| Data Monitor            | Sonar control unit input/output data in real time.                     |
| Work support            | Changes setting of each function.                                      |
| Active Test             | Gives a drive signal to a load to check the operation.                 |

#### ECU PART NUMBER

Displays the part number of the sonar control unit.

#### SELF-DIAGNOSTIC RESULTS

For details, refer to [SN-28, "DTC Index"](#).

#### DATA MONITOR

| Monitor Item                 | Display | Description   |
|------------------------------|---------|---|
| REAR BUZZER                  | On      | Buzzer (backward) output condition.   |
|                              | Off     | Buzzer (backward) non-output condition.   |
| REVERSE RANGE                | On      | Selector lever in R position.   |
|                              | Off     | Other than selector lever in R position.  |
| CR SEN [RL]<br>CR SEN [RR]   | ERROR   | When a sensor is abnormal.  |
|                              | LV.0    | When a sensor is not detection.   |
|                              | LV.2    | The distance between the corner sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|                              | LV.3    | The distance between the corner sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|                              | LV.4    | The distance between corner sensor and an obstacle less than 30 cm (11.8 in).                                     |
| CTR SEN [RL]<br>CTR SEN [RR] | ERROR   | When a sensor is abnormal.  |
|                              | LV.0    | When a sensor is not detection.   |
|                              | LV.1    | The distance between the center sensor and an obstacle is 60 cm (23.6 in) or more and less than 100 cm (39.3 in). |
|                              | LV.2    | The distance between the center sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|                              | LV.3    | The distance between the center sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|                              | LV.4    | The distance between center sensor and an obstacle less than 30 cm (11.8 in).                                     |

#### ACTIVE TEST

| Active test item | Function  |
|------------------|---|
| BUZZER           | This test is able to check buzzer (backward) operation. |
| SONAR SENSOR     | This test is able to check each sonar sensor operation. |

#### WORK SUPPORT

# DIAGNOSIS SYSTEM (SONAR CONTROL UNIT)

## < SYSTEM DESCRIPTION >

| Work support item       | Function  |
|-------------------------|---|
| CORNER SEN DISTANCE SET | Corner sensor warning buzzer distance is adjustable to 4 phases.  |
| CENTER SEN DISTANCE SET | Center sensor warning buzzer distance is adjustable to 4 phases.  |
| TRAILER HITCH MODE      | Center sensor (RR, RL) only is adjustable not to detect the distance less than 40 cm (15.7 in).<br><b>NOTE:</b><br>This adjustment is for preventing to miss detect the distance when installing the trailer hitch. |

### CORNER SEN DISTANCE SET

Corner sensor warning buzzer distance can set it to 4 phases as follows.

| Warning item         | FARTHER                     | FAR                         | NORMAL                      | NEAR                        |
|----------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| Second stage warning | 70 – 80 cm (27.5 – 31.4 in) | 60 – 70 cm (23.6 – 27.5 in) | 50 – 60 cm (19.6 – 23.6 in) | 40 – 50 cm (15.7 – 19.6 in) |
| Third stage warning  | 50 – 70 cm (19.6 – 27.5 in) | 40 – 60 cm (15.7 – 23.6 in) | 30 – 50 cm (11.8 – 19.6 in) | 30 – 40 cm (11.8 – 15.7 in) |
| Fourth stage warning | Less than 50 cm (19.6 in)   | Less than 40 cm (15.7 in)   | Less than 30 cm (11.8 in)   | Less than 30 cm (11.8 in)   |

### CENTER SEN DISTANCE SET

Center sensor warning buzzer distance can set it to 4 phases as follows.

| Warning item         | FARTHER                      | FAR                          | NORMAL                       | NEAR                        |
|----------------------|------------------------------|------------------------------|------------------------------|-----------------------------|
| First stage warning  | 80 – 120 cm (31.4 – 47.2 in) | 70 – 110 cm (27.5 – 43.3 in) | 60 – 100 cm (23.6 – 39.3 in) | 50 – 90 cm (19.6 – 35.4 in) |
| Second stage warning | 70 – 80 cm (27.5 – 31.4 in)  | 60 – 70 cm (23.6 – 27.5 in)  | 50 – 60 cm (19.6 – 23.6 in)  | 40 – 50 cm (15.7 – 19.6 in) |
| Third stage warning  | 50 – 70 cm (19.6 – 27.5 in)  | 40 – 60 cm (15.7 – 23.6 in)  | 30 – 50 cm (11.8 – 19.6 in)  | 30 – 40 cm (11.8 – 15.7 in) |
| Fourth stage warning | Less than 50 cm (19.6 in)    | Less than 40 cm (15.7 in)    | Less than 30 cm (11.8 in)    | Less than 30 cm (11.8 in)   |

### TRAILER HITCH MODE

Center sensor (RR, RL) only is adjustable not to detect the distance less than 40 cm (15.7 in).

**When installing the trailer hitch : ON**

**When not installing the trailer hitch : OFF**

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

## B2704 CORNER SENSOR [RL]

< DTC/CIRCUIT DIAGNOSIS >

### DTC/CIRCUIT DIAGNOSIS

#### B2704 CORNER SENSOR [RL]

##### Description

INFOID:000000004964365

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

##### DTC Logic

INFOID:000000004964366

##### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication | DTC detection condition                    | Troubleshooting                |
|---------|------------------------|--|--------------------------------|
| B2704   | CORNER SENSOR [RL]     | Corner sensor rear left is malfunctioning. | Replace corner sensor rear LH. |

# B2705 SENSOR HARNESS OPEN [CR-RL]

< DTC/CIRCUIT DIAGNOSIS >

## B2705 SENSOR HARNESS OPEN [CR-RL]

### Description

INFOID:000000004964367

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

### DTC Logic

INFOID:000000004964368

### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication      | DTC detection condition                          | Troubleshooting                      |
|---------|-----------------------------|--|--------------------------------------|
| B2705   | SENSOR HARNESS OPEN [CR-RL] | Corner sensor rear left harness circuit is open. | Check corner sensor rear LH circuit. |

### Diagnosis Procedure

INFOID:000000004964369

#### 1. CHECK HARNESS CORNER SENSOR REAR LH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector and corner sensor rear LH connector.
3. Check continuity between sonar control unit harness connector and corner sensor rear LH harness connector.

| Sonar control unit | Corner sensor rear LH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 5                     | T6        | 1          |

4. Check continuity between sonar control unit harness connector and ground.

| Sonar control unit | Ground   |           | Continuity  |
|--------------------|----------|-----------|-------------|
| Connector          | Terminal | Connector | Terminal    |
| M36                | 5        |           | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK HARNESS CORNER SENSOR REAR LH GROUND CIRCUIT

Check continuity between sonar control unit harness connector and corner sensor rear LH harness connector.

| Sonar control unit | Corner sensor rear LH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 12                    | T6        | 2          |

Is the inspection result normal?

YES >> Replace sonar control unit.

NO >> Repair harness or connector.

SN

O

P

## B2706 CORNER SENSOR [RR]

< DTC/CIRCUIT DIAGNOSIS >

### B2706 CORNER SENSOR [RR]

#### Description

INFOID:000000004964370

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

#### DTC Logic

INFOID:000000004964371

#### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication | DTC detection condition                     | Troubleshooting                |
|---------|------------------------|---|--------------------------------|
| B2706   | CORNER SENSOR [RR]     | Corner sensor rear right is malfunctioning. | Replace corner sensor rear RH. |

# B2707 SENSOR HARNESS OPEN [CR-RR]

< DTC/CIRCUIT DIAGNOSIS >

## B2707 SENSOR HARNESS OPEN [CR-RR]

### Description

INFOID:000000004964372

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

### DTC Logic

INFOID:000000004964373

### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication      | DTC detection condition                           | Troubleshooting                      |
|---------|-----------------------------|---|--------------------------------------|
| B2707   | SENSOR HARNESS OPEN [CR-RR] | Corner sensor rear right harness circuit is open. | Check corner sensor rear RH circuit. |

### Diagnosis Procedure

INFOID:000000004964374

#### 1. CHECK HARNESS CORNER SENSOR REAR RH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector and corner sensor rear RH connector.
3. Check continuity between sonar control unit harness connector and corner sensor rear RH harness connector.

| Sonar control unit | Corner sensor rear RH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 6                     | T9        | 1          |

4. Check continuity between sonar control unit harness connector and ground.

| Sonar control unit | Ground   |           | Continuity  |
|--------------------|----------|-----------|-------------|
| Connector          | Terminal | Connector | Terminal    |
| M36                | 6        |           | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK HARNESS CORNER SENSOR REAR RH GROUND CIRCUIT

Check continuity between sonar control unit harness connector and corner sensor rear RH harness connector.

| Sonar control unit | Corner sensor rear RH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 12                    | T9        | 2          |

Is the inspection result normal?

YES >> Replace sonar control unit.

NO >> Repair harness or connector.

SN

## B2708 CENTER SENSOR [BL]

< DTC/CIRCUIT DIAGNOSIS >

### B2708 CENTER SENSOR [BL]

#### Description

INFOID:000000004964375

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

#### DTC Logic

INFOID:000000004964376

#### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication | DTC detection condition                    | Troubleshooting                |
|---------|------------------------|--|--------------------------------|
| B2708   | CENTER SENSOR [BL]     | Center sensor rear left is malfunctioning. | Replace center sensor rear LH. |

# B2709 SENSOR HARNESS OPEN [CT-BL]

< DTC/CIRCUIT DIAGNOSIS >

## B2709 SENSOR HARNESS OPEN [CT-BL]

### Description

INFOID:000000004964377

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

### DTC Logic

INFOID:000000004964378

### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication      | DTC detection condition                          | Troubleshooting                      |
|---------|-----------------------------|--|--------------------------------------|
| B2709   | SENSOR HARNESS OPEN [CT-BL] | Center sensor rear left harness circuit is open. | Check center sensor rear LH circuit. |

### Diagnosis Procedure

INFOID:000000004964379

#### 1. CHECK HARNESS CENTER SENSOR REAR LH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector and center sensor rear LH connector.
3. Check continuity between sonar control unit harness connector and center sensor rear LH harness connector.

| Sonar control unit | Center sensor rear LH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 3                     | T7        | 1          |

4. Check continuity between sonar control unit harness connector and ground.

| Sonar control unit | Ground   |           | Continuity  |
|--------------------|----------|-----------|-------------|
| Connector          | Terminal | Connector | Terminal    |
| M36                | 3        |           | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK HARNESS CENTER SENSOR REAR LH GROUND CIRCUIT

Check continuity between sonar control unit harness connector and center sensor rear LH harness connector.

| Sonar control unit | Center sensor rear LH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 12                    | T7        | 2          |

Is the inspection result normal?

YES >> Replace sonar control unit.

NO >> Repair harness or connector.

SN

O

P

## B270A CENTER SENSOR [BR]

< DTC/CIRCUIT DIAGNOSIS >

### B270A CENTER SENSOR [BR]

#### Description

INFOID:000000004964380

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

#### DTC Logic

INFOID:000000004964381

#### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication | DTC detection condition                     | Troubleshooting                |
|---------|------------------------|---|--------------------------------|
| B270A   | CENTER SENSOR [BR]     | Center sensor rear right is malfunctioning. | Replace center sensor rear RH. |

# B270B SENSOR HARNESS OPEN [CT-BR]

< DTC/CIRCUIT DIAGNOSIS >

## B270B SENSOR HARNESS OPEN [CT-BR]

### Description

INFOID:000000004964382

| Component            | Description   |
|----------------------|---|
| CORNER/CENTER SENSOR | The obstacle distance is detected. The signal is transmitted to the sonar control unit. |

### DTC Logic

INFOID:000000004964383

### DTC DETECTION LOGIC

| DTC No. | CONSULT-III indication      | DTC detection condition                           | Troubleshooting                      |
|---------|-----------------------------|---|--------------------------------------|
| B270B   | SENSOR HARNESS OPEN [CT-BR] | Center sensor rear right harness circuit is open. | Check center sensor rear RH circuit. |

### Diagnosis Procedure

INFOID:000000004964384

#### 1. CHECK HARNESS CENTER SENSOR REAR RH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector and center sensor rear RH connector.
3. Check continuity between sonar control unit harness connector and center sensor rear RH harness connector.

| Sonar control unit | Center sensor rear RH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 4                     | T8        | 1          |
|                    |                       |           | Existed    |

4. Check continuity between sonar control unit harness connector and ground.

| Sonar control unit | Ground   |  | Continuity  |
|--------------------|----------|--|-------------|
| Connector          | Terminal |  |             |
| M36                | 4        |  | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

#### 2. CHECK HARNESS CENTER SENSOR REAR RH GROUND CIRCUIT

Check continuity between sonar control unit harness connector and center sensor rear RH harness connector.

| Sonar control unit | Center sensor rear RH |           | Continuity |
|--------------------|-----------------------|-----------|------------|
| Connector          | Terminal              | Connector | Terminal   |
| M36                | 12                    | T8        | 2          |
|                    |                       |           | Existed    |

Is the inspection result normal?

YES >> Replace sonar control unit.

NO >> Repair harness or connector.

SN

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT SONAR CONTROL UNIT

### SONAR CONTROL UNIT : Diagnosis Procedure

INFOID:000000004964385

#### 1.CHECK FUSE

Check for blown fuses.

| Power source                | Fuse No. |
|-----------------------------|----------|
| Ignition switch ON or START | 2        |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate the cause of malfunction before installing new fuse.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between sonar control unit harness connector and ground.

| Signal name  | Connector No. | Terminal No. | Ignition switch position | Value           |
|--------------|---------------|--------------|--------------------------|-----------------|
| Power supply | M36           | 13           | ON                       | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace sonar control unit power supply circuit.

#### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector.
3. Check continuity between sonar control unit harness connector and ground.

| Signal name | Connector No. | Terminal No. | Ignition switch position | Continuity |
|-------------|---------------|--------------|--------------------------|------------|
| Ground      | M36           | 24           | OFF                      | Existed    |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace sonar control unit ground circuit.

## R RANGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### R RANGE SIGNAL CIRCUIT

#### Description

INFOID:0000000004964386

The sonar control unit turns the sonar system activation OFF when inputting the reverse signal.

#### Diagnosis Procedure

INFOID:0000000004964387

#### 1.CHECK R RANGE SIGNAL

1. Turn ignition switch ON.
2. Check voltage between sonar control unit harness connector and ground.

| (+)       |          | (-)    | Condition   | Voltage<br>(Approx.) |
|-----------|----------|--------|---|----------------------|
| Connector | Terminal |        |   |                      |
| M36       | 17       | Ground | Shift the selector lever to "R"position.          | Battery voltage      |
|           |          |        | Shift the selector lever other than "R" position. | 0 V                  |

Is the inspection result normal?

- YES    >> INSPECTION END  
NO     >> Repair harness or connector.

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

# BUZZER DRIVE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## BUZZER DRIVE SIGNAL CIRCUIT

### Description

INFOID:0000000004964388

The sonar control unit outputs the buzzer drive signal when the sonar detects the obstacle.

### Diagnosis Procedure

INFOID:0000000004964389

#### 1.CHECK HARNESS BUZZER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sonar control unit connector and buzzer connector.
3. Check continuity between sonar control unit harness connector and buzzer harness connector.

| Sonar control unit |          | Buzzer    |          | Continuity |
|--------------------|----------|-----------|----------|------------|
| Connector          | Terminal | Connector | Terminal |            |
| M36                | 23       | M31       | 2        | Existed    |

4. Check continuity between sonar harness connector and ground.


| Sonar control unit |          | Ground | Continuity  |
|--------------------|----------|--------|-------------|
| Connector          | Terminal |        |             |
| M36                | 23       |        | Not existed |

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair harness or connector.

#### 2.CHECK BUZZER DRIVE SIGNAL

1. Connect sonar control unit connector and buzzer connector.
2. Bring an obstacle near to sound the buzzer.
3. Check signal between sonar control unit harness connector terminal and ground.

| (+) Sonar control unit |          | (-)    | Condition              | Signal  |
|------------------------|----------|--------|------------------------|---|
| Connector              | Terminal |        |                        |   |
| M36                    | 23       | Ground | When buzzer operation. | Waveform period changes according to the distance to an obstacle.<br><br>JSNIA1261ZZ |
|                        |          |        | Other than above.      | Battery voltage   |

Is the inspection result normal?

- YES >> Replace buzzer.  
NO >> Replace sonar control unit.

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION SONAR CONTROL UNIT

### Reference Value

INFOID:000000004964857

### VALUES ON THE DIAGNOSIS TOOL

| Monitor Item  | Display | Description   |
|---------------|---------|---|
| REAR BUZZER   | On      | Buzzer (backward) output condition.   |
|               | Off     | Buzzer (backward) non-output condition.   |
| REVERSE RANGE | On      | Selector lever in R position.   |
|               | Off     | Other than selector lever in R position.  |
| CR SEN [RL]   | ERROR   | When a sensor is abnormal.  |
|               | LV.0    | When a sensor is not detection.   |
|               | LV.2    | The distance between the corner sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|               | LV.3    | The distance between the corner sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|               | LV.4    | The distance between corner sensor and an obstacle less than 30 cm (11.8 in).                                     |
| CR SEN [RR]   | ERROR   | When a sensor is abnormal.  |
|               | LV.0    | When a sensor is not detection.   |
|               | LV.2    | The distance between the corner sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|               | LV.3    | The distance between the corner sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|               | LV.4    | The distance between corner sensor and an obstacle less than 30 cm (11.8 in).                                     |
| CTR SEN [RL]  | ERROR   | When a sensor is abnormal.  |
|               | LV.0    | When a sensor is not detection.   |
|               | LV.1    | The distance between the center sensor and an obstacle is 60 cm (23.6 in) or more and less than 100 cm (39.3 in). |
|               | LV.2    | The distance between the center sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|               | LV.3    | The distance between the center sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|               | LV.4    | The distance between center sensor and an obstacle less than 30 cm (11.8 in).                                     |
| CTR SEN [RR]  | ERROR   | When a sensor is abnormal.  |
|               | LV.0    | When a sensor is not detection.   |
|               | LV.1    | The distance between the center sensor and an obstacle is 60 cm (23.6 in) or more and less than 100 cm (39.3 in). |
|               | LV.2    | The distance between the center sensor and an obstacle is 50 cm (19.6 in) or more and less than 60 cm (23.6 in).  |
|               | LV.3    | The distance between the center sensor and an obstacle is 30 cm (11.8 in) or more and less than 50 cm (19.6 in).  |
|               | LV.4    | The distance between center sensor and an obstacle less than 30 cm (11.8 in).                                     |

A

B

C

D

E

F

G

H

I

J

K

L

SN


O

P

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT




## PHYSICAL VALUES

| Terminal No.<br>(Wire color) |           | Description             |                  | Condition                | Reference value<br>(Approx.) |
|------------------------------|-----------|-------------------------|------------------|--------------------------|------------------------------|
| +                            | -         | Signal name             | Input/<br>Output |                          |                              |
| 3<br>(R)                     | 12<br>(W) | Center sensor signal LH | Input            | Ignition<br>switch<br>ON | —                            |
|                              |           |                         |                  |                          | <br>SKIB8942E                |
| 4<br>(G)                     | 12<br>(W) | Center sensor signal RH | Input            | Ignition<br>switch<br>ON | —                            |
|                              |           |                         |                  |                          | <br>SKIB8942E                |
| 5<br>(B)                     | 12<br>(W) | Corner sensor signal LH | Input            | Ignition<br>switch<br>ON | —                            |
|                              |           |                         |                  |                          | <br>SKIB8942E                |
| 6<br>(Y)                     | 12<br>(W) | Corner sensor signal RH | Input            | Ignition<br>switch<br>ON | —                            |
|                              |           |                         |                  |                          | <br>SKIB8942E                |
| 12<br>(W)                    | Ground    | Sensor ground           | —                | Ignition<br>switch<br>ON | —                            |
| 13<br>(O)                    | Ground    | Ignition power supply   | Input            | Ignition<br>switch<br>ON | —                            |
|                              |           |                         |                  |                          | Battery voltage              |

# SONAR CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color) |        | Description          |                  | Condition                |   | Reference value<br>(Approx.)  |
|------------------------------|--------|----------------------|------------------|--------------------------|---|---|
| +                            | -      | Signal name          | Input/<br>Output |                          |   |   |
| 17<br>(Y/R)                  | Ground | Reverse signal       | Input            | Ignition<br>switch<br>ON | Shift the selector lever to<br>"R" position.        | Battery voltage   |
|                              |        |                      |                  |                          | Shift the selector lever other<br>than "R"position. | 0 V   |
| 18<br>(GR/R)                 | —      | K-line (CONSULT-III) | Input/<br>Output | —                        | —   | —   |
| 23<br>(B/W)                  | Ground | Buzzer drive signal  | Output           | Ignition<br>switch<br>ON | When buzzer operation.                              | Waveform period changes ac-<br>cording to the distance to an ob-<br>stacle.<br><br>JSNIA1261ZZ |
|                              |        |                      |                  |                          | Other than above.                                   | Battery voltage   |
| 24<br>(B)                    | Ground | Ground               | —                | Ignition<br>switch<br>ON | —   | 0 V   |

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P


# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## Wiring Diagram - SONAR SYSTEM -

INFOID:000000004964858

### SONAR SYSTEM



2009/02/27

JCNWM2408GB

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## SONAR SYSTEM

| Connector No.  | B7                          | Connector No.  | E6            |
|----------------|-----------------------------|----------------|---------------|
| Connector Name | WIRE TO WIRE                | Connector Name | WIRE TO WIRE  |
| Connector Type | TH24WW-NH                   | Connector Type | RH12FB        |
|                |                             |                |               |
|                |                             |                |               |
| Terminal No.   | Signal Name [Specification] | Terminal No.   | Color of Wire |
| 1              | B                           | 3              | W             |
| 2              | G                           | 4              | G             |
| 3              | W                           | 5              | B             |
| 13             | R                           | 9              | Y             |
| 14             | Y                           | 10             | R             |
| 15             | SHIELD                      | -              | -             |

| Connector No.  | B74                         | Connector No.  | E8               |
|----------------|-----------------------------|----------------|------------------|
| Connector Name | WIRE TO WIRE                | Connector Name | WIRE TO WIRE     |
| Connector Type | RH10FB                      | Connector Type | SAA3MB-FS10-SUZ2 |
|                |                             |                |                  |
|                |                             |                |                  |
| Terminal No.   | Signal Name [Specification] | Terminal No.   | Color of Wire    |
| 1              | 2                           | 1              | 3                |
| 2              | 3                           | 2              | 4                |
| 3              | 4                           | 3              | 5                |
| 4              | 5                           | 1              | 6                |
| 5              | 6                           | 2              | 7                |
| 6              | 7                           | 3              | 8                |
| 7              | 8                           | 4              | 9                |
| 8              | 9                           | 5              | 10               |
| 9              | 10                          | 11             | 12               |
| 10             | 11                          | 12             | 13               |
| 11             | 12                          | 13             | 14               |
| 12             | 13                          | 14             | 15               |
| 13             | 14                          | 15             | 16               |
| 14             | 15                          | 16             | 17               |
| 15             | 16                          | 17             | 18               |
| 16             | 17                          | 18             | 19               |
| 17             | 18                          | 19             | 20               |
| 18             | 19                          | 20             | 21               |
| 19             | 20                          | 21             | 22               |
| 20             | 21                          | 22             | 23               |
| 21             | 22                          | 23             | 24               |
| 22             | 23                          | 24             | 25               |
| 23             | 24                          | 25             | 26               |
| 24             | 25                          | 26             | 27               |
| 25             | 26                          | 27             | 28               |
| 26             | 27                          | 28             | 29               |
| 27             | 28                          | 29             | 30               |
| 28             | 29                          | 30             | 31               |
| 29             | 30                          | 31             | 32               |
| 30             | 31                          | 32             | 33               |
| 31             | 32                          | 33             | 34               |
| 32             | 33                          | 34             | 35               |
| 33             | 34                          | 35             | 36               |
| 34             | 35                          | 36             | 37               |
| 35             | 36                          | 37             | 38               |
| 36             | 37                          | 38             | 39               |
| 37             | 38                          | 39             | 40               |
| 38             | 39                          | 40             | 41               |
| 39             | 40                          | 41             | 42               |
| 40             | 41                          | 42             | 43               |
| 41             | 42                          | 43             | 44               |
| 42             | 43                          | 44             | 45               |
| 43             | 44                          | 45             | 46               |
| 44             | 45                          | 46             | 47               |
| 45             | 46                          | 47             | 48               |
| 46             | 47                          | 48             | 49               |
| 47             | 48                          | 49             | 50               |
| 48             | 49                          | 50             | 51               |
| 49             | 50                          | 51             | 52               |
| 50             | 51                          | 52             | 53               |
| 51             | 52                          | 53             | 54               |
| 52             | 53                          | 54             | 55               |
| 53             | 54                          | 55             | 56               |
| 54             | 55                          | 56             | 57               |
| 55             | 56                          | 57             | 58               |
| 56             | 57                          | 58             | 59               |
| 57             | 58                          | 59             | 60               |
| 58             | 59                          | 60             | 61               |
| 59             | 60                          | 61             | 62               |
| 60             | 61                          | 62             | 63               |
| 61             | 62                          | 63             | 64               |
| 62             | 63                          | 64             | 65               |
| 63             | 64                          | 65             | 66               |
| 64             | 65                          | 66             | 67               |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z

JCNWM2409GB

# SONAR CONTROL UNIT


**< ECU DIAGNOSIS INFORMATION >**

## SONAR SYSTEM

|                |                     |                |         |
|----------------|---------------------|----------------|---------|
| Connector No.  | M4                  | Connector No.  | M31     |
| Connector Name | DATA LINK CONNECTOR | Connector Name | BUZZER  |
| Connector Type | BD16FW              | Connector Type | RK02FBR |
|                |                     |                |         |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 7            | GR/FR         | -                           |
| 8            | SB            | -                           |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | O             | -                           |
| 2            | B/W           | -                           |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3            | R             | CENTER SENSOR SIGNAL LH     |
| 4            | G             | CENTER SENSOR SIGNAL RH     |
| 5            | B             | CORNER SENSOR SIGNAL LH     |
| 6            | Y             | CORNER SENSOR SIGNAL RH     |
| 12           | W             | SENSOR GND                  |
| 13           | O             | IGNITION POWER SUPPLY       |
| 17           | Y/R           | REVERSE SIGNAL              |
| 18           | GR/R          | K LINE                      |
| 23           | B/W           | BUZZER OUTPUT               |
| 24           | B             | GND                         |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3            | R             | CORNER SENSOR (RL)          |
| 4            | G             | CORNER SENSOR (RR)          |
| 5            | B             | YDX02FB                     |
|              |               |                             |




|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | B             | -                           |
| 2            | LG            | -                           |
|              |               |                             |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 1            | B             | -                           |
| 2            | LG            | -                           |
|              |               |                             |



|              |               |                             |
|--------------|---------------|-----------------------------|
| Terminal No. | Color of Wire | Signal Name [Specification] |
| 3            | SB            | -                           |
| 4            | G             | -                           |
| 5            | B             | -                           |
| 6            | Y             | -                           |
| 10           | R             | -                           |
| 15           | SHIELD        | -                           |



JCNWM2410GB

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

| SONAR SYSTEM   |                    |                |                    |
|----------------|--------------------|----------------|--------------------|
| Connector No.  | T7                 | Connector No.  | T9                 |
| Connector Name | CENTER SENSOR (RL) | Connector Name | CORNER SENSOR (RR) |
| Connector Type | YDX02FB            | Connector Type | YDX02FB            |

| CENTER SENSOR (RL) |               |                             |
|--------------------|---------------|-----------------------------|
| Terminal No.       | Color of Wire | Signal Name [Specification] |
| 1                  | R             | -                           |
| 2                  | W             | -                           |

| CORNER SENSOR (RR) |               |                             |
|--------------------|---------------|-----------------------------|
| Terminal No.       | Color of Wire | Signal Name [Specification] |
| 1                  | G             | -                           |
| 2                  | L             | -                           |

| HS |   |   |
|----|---|---|
| 1  | 1 | 2 |

| HS |   |   |
|----|---|---|
| 1  | 1 | 2 |

| HS |   |   |
|----|---|---|
| 1  | 1 | 2 |

JCNWM2411GB

INFOID:0000000004964859

## Fail Safe

The sonar control unit detects sonar sensor malfunction and activates warning chime approximately 3 seconds when the selector lever is in the reverse position.

# SONAR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## DTC Index

INFOID:000000004964860

| DTC   | Display item                        | Malfunction is detected when...                   | Refer to              |
|-------|-------------------------------------|---|-----------------------|
| B2704 | CORNER SENSOR [RL] [B2704]          | Corner sensor rear left is malfunctioning.        | <a href="#">SN-10</a> |
| B2705 | SENSOR HARNESS OPEN [CR-RL] [B2705] | Corner sensor rear left harness circuit is open.  | <a href="#">SN-11</a> |
| B2706 | CORNER SENSOR [RR] [B2706]          | Corner sensor rear right is malfunctioning.       | <a href="#">SN-12</a> |
| B2707 | SENSOR HARNESS OPEN [CR-RR] [B2707] | Corner sensor rear right harness circuit is open. | <a href="#">SN-13</a> |
| B2708 | CENTER SENSOR [BL] [B2708]          | Center sensor rear left is malfunctioning.        | <a href="#">SN-14</a> |
| B2709 | SENSOR HARNESS OPEN [CT-BL] [B2709] | Center sensor rear left harness circuit is open.  | <a href="#">SN-15</a> |
| B270A | CENTER SENSOR [BR] [B270A]          | Center sensor rear right is malfunctioning.       | <a href="#">SN-16</a> |
| B270B | SENSOR HARNESS OPEN [CT-BR] [B270B] | Center sensor rear right harness circuit is open. | <a href="#">SN-17</a> |

### NOTE:

“TIME” means the following.

- 0: Means detected malfunction at present. (From malfunction detection to turning ignition switch OFF)
- 1–39: Means detected malfunction in past.

## SONAR SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

# SYMPTOM DIAGNOSIS

## SONAR SYSTEM SYMPTOMS

### Symptom Table

INFOID:000000004964926

| Symptom                             | Check item  | Diagnosis method  |
|-------------------------------------|---|---|
| All sonar sensors do not activate.  | Buzzer beeps when indicating "On" on "BUZZER" screen of the ACTIVE TEST.          | Check reverse signal for sonar control unit. Refer to <a href="#">SN-19, "Diagnosis Procedure".</a>                                   |
|                                     | Buzzer does not beeps when indicating "On" on "BUZZER" screen of the ACTIVE TEST. | Check buzzer signal for sonar control unit. Refer to <a href="#">SN-20, "Diagnosis Procedure".</a>                                    |
|                                     | Sonar is not displayed on CONSULT-III menu items.                                 | Check sonar control unit power supply and ground circuit. Refer to <a href="#">SN-18, "SONAR CONTROL UNIT : Diagnosis Procedure".</a> |
| Any sonar sensor does not activate. | —   | Perform the self-diagnosis of CONSULT-III. Refer to <a href="#">SN-8, "CONSULT-III Function (SONAR)".</a>                             |

A

B

C

D

E

F

G

H

I

J

K

L

M

SN

O

P

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005166162

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.


# SONAR CONTROL UNIT

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION SONAR CONTROL UNIT

### Exploded View

INFOID:000000004964928



1. Sonar control unit

### Removal and Installation

INFOID:000000004964929

#### REMOVAL

1. Remove the glove box. Refer to [IP-12, "Exploded View"](#).
2. Remove sonar control unit screw, then disconnect sonar control unit connector and remove the sonar control unit.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E

F  
G  
H  
I

J  
K  
L  
M

SN

O  
P

# SONAR SENSOR

< REMOVAL AND INSTALLATION >

## SONAR SENSOR CENTER SENSOR


### CENTER SENSOR : Exploded View

INFOID:000000004964930

#### REMOVAL

Refer to [EXT-15, "Exploded View".](#)

#### DISASSEMBLY



1. Center sensor

### CENTER SENSOR : Removal and Installation

INFOID:000000005102745

#### REMOVAL

1. Remove the rear bumper fascia. Refer to [EXT-15, "Exploded View".](#)
2. Disconnect center sensor connector.
3. Press out the center sensor from back of rear bumper fascia to remove center sensor.


#### INSTALLATION

Install in the reverse order of removal.

#### CAUTION:

The connector direction is within  $\pm 10^\circ$  from the horizontal position when assembling the bumper.


A : Horizontal position  
a :  $10^\circ$



## CORNER SENSOR

### CORNER SENSOR : Exploded View

INFOID:000000005102744



# SONAR SENSOR

## < REMOVAL AND INSTALLATION >

### 1. Corner sensor

## CORNER SENSOR : Removal and Installation

INFOID:000000004964931

### REMOVAL

1. Remove the bumper closing. Refer to [EXT-15, "Exploded View"](#).
2. Press out the corner sensor from the back of rear bumper fascia.
3. Disconnect corner sensor connector to remove corner sensor.

### INSTALLATION


Install in the reverse order of removal.

#### CAUTION:

The connector direction is within  $\pm 10^\circ$  from the horizontal position when assembling the bumper.

A : Horizontal position

a :  $10^\circ$



## BUZZER


< REMOVAL AND INSTALLATION >

### BUZZER

#### Exploded View

INFOID:0000000004964932

SEC. 253



JPNIA1713ZZ

1. Buzzer

#### Removal and Installation

INFOID:0000000004964933

##### REMOVAL

1. Remove combination meter. Refer to [MWI-97, "Exploded View"](#).
2. Remove buzzer screw, then disconnect buzzer connector and remove the buzzer.

##### INSTALLATION

Install in the reverse order of removal.