

SECTION **PG**

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

CONTENTS

PRECAUTIONS	3	GROUND	27
Precautions for Battery Service	3	Ground Distribution	27
POWER SUPPLY ROUTING CIRCUIT	4	MAIN HARNESS	27
Schematic	4	ENGINE ROOM HARNESS	29
Wiring Diagram — POWER —	5	ENGINE CONTROL HARNESS	32
BATTERY POWER SUPPLY — IGNITION SW.		BODY HARNESS	34
IN ANY POSITION	5	BODY NO. 2 HARNESS	37
ACCESSORY POWER SUPPLY — IGNITION		TAIL HARNESS	38
SW. IN “ACC” OR “ON”	10	BACK DOOR HARNESS	40
IGNITION POWER SUPPLY — IGNITION SW.		HARNESS	41
IN “ON” AND/OR “START”	11	Harness Layout	41
Fuse	15	HOW TO READ HARNESS LAYOUT	41
Fusible Link	15	OUTLINE	42
Circuit Breaker	15	MAIN HARNESS	43
IPDM E/R (INTELLIGENT POWER DISTRIBUTION		ENGINE ROOM HARNESS	46
MODULE ENGINE ROOM)	16	ENGINE CONTROL HARNESS	50
System Description	16	BODY HARNESS	53
SYSTEMS CONTROLLED BY IPDM E/R	16	BODY NO. 2 HARNESS	58
CAN COMMUNICATION LINE CONTROL	16	TAIL HARNESS	59
IPDM E/R STATUS CONTROL	17	TAIL NO. 2 HARNESS	62
CAN Communication System Description	17	ROOM LAMP HARNESS	63
CAN Communication Unit	17	DOOR HARNESS	65
Function of Detecting Ignition Relay Malfunction ...	17	Wiring Diagram Codes (Cell Codes)	67
CONSULT-III Function (IPDM E/R)	18	ELECTRICAL UNITS LOCATION	70
SELF-DIAG RESULTS	18	Electrical Units Location	70
DATA MONITOR	18	ENGINE COMPARTMENT	70
ACTIVE TEST	19	PASSENGER COMPARTMENT	71
Auto Active Test	20	LUGGAGE COMPARTMENT	74
DESCRIPTION	20	HARNESS CONNECTOR	76
OPERATION PROCEDURE	20	Description	76
INSPECTION IN AUTO ACTIVE TEST MODE ...	20	HARNESS CONNECTOR (TAB-LOCKING	
Schematic	22	TYPE)	76
IPDM E/R Terminal Arrangement	23	HARNESS CONNECTOR (SLIDE-LOCKING	
IPDM E/R Power/Ground Circuit Inspection	24	TYPE)	77
Inspection With CONSULT-III (Self-Diagnosis)	25	HARNESS CONNECTOR (LEVER LOCKING	
Removal and Installation of IPDM E/R	26	TYPE)	78
REMOVAL	26	ELECTRICAL UNITS	79
INSTALLATION	26	Terminal Arrangement	79
		SMJ (SUPER MULTIPLE JUNCTION)	81
		Terminal Arrangement	81

STANDARDIZED RELAY	83	FUSE BLOCK - JUNCTION BOX (J/B)	85
Description	83	Terminal Arrangement	85
NORMAL OPEN, NORMAL CLOSED AND		FUSE, FUSIBLE LINK AND RELAY BOX	86
MIXED TYPE RELAYS	83	Terminal Arrangement	86
TYPE OF STANDARDIZED RELAYS	83		

PRECAUTIONS

PRECAUTIONS

PPF:00001

Precautions for Battery Service

NKS0054E

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

A

B

C

D

E

F

G

H

I

J




PG

L

M

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-02





TKWT5814E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-03



A
B
C
D
E
F
G
H
I
J
PG
L
M



TKWT5815E

POWER SUPPLY ROUTING CIRCUIT




PG-POWER-04



TKWT5816E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-05




TKWT5817E

POWER SUPPLY ROUTING CIRCUIT



ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”

PG-POWER-06



REFER TO PG-POWER-01,02.

FUSE BLOCK (J/B)
 (M4), (M5),
 (E101), (E103)




TKWT5818E

POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY — IGNITION SW. IN “ON” AND/OR “START”

PG-POWER-07



3	5	1
4	2	6

(E119)
W

REFER TO THE FOLLOWING.






(M4), (E101), (E102), (E104)
- FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWT5819E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-08



REFER TO THE FOLLOWING.





(M5), (E101) - FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWT5820E

POWER SUPPLY ROUTING CIRCUIT



PG-POWER-09



TKWT5821E

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10



23	22	21	20	19	18	17		
32	31	30	29	28	27	26	25	24

(E7)
GY

37	36	35	34	33		
44	43	42	41	40	39	38

(E8)
W



3	5	1
4	2	6

(E119)
W

REFER TO THE FOLLOWING.


(M5), (E101) -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

POWER SUPPLY ROUTING CIRCUIT

Fuse

- If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.


CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of malfunction.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



A
B
C
D
E
F
G
H
I
J
PG
L
M

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

NKS000E4

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates relays and fuse blocks which were originally placed in engine room. It controls integrated relays via IPDM E/R control circuit.
- IPDM E/R integrated control unit performs ON-OFF operation of relay, hood switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:

None of the IPDM E/R-integrated relays can be removed.

SYSTEMS CONTROLLED BY IPDM E/R

IPDM E/R receives a request signal from each control unit with CAN communication. It controls each system.

Control system	Transmit control unit	Control part
Lamp control	BCM	<ul style="list-style-type: none">● Head lamps (HI, LO)● Parking lamps, license plate lamps and tail lamps
Wiper control	BCM	Front wipers
Rear window defogger control	BCM	Rear window defogger
A/C compressor control	ECM	A/C compressor (magnet clutch)
Cooling fan control	ECM	Cooling fan

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L line, CAN H line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control

- When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
- Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	<ul style="list-style-type: none">● With the ignition switch ON, the headlamp (low) is ON.● With the ignition switch OFF, the headlamp (low) is OFF.
Parking, license plate and tail lamps	<ul style="list-style-type: none">● With the ignition switch ON, the parking, license plate and tail lamps are ON.● With the ignition switch OFF, the parking, license plate and tail lamps are OFF.
Cooling fan	<ul style="list-style-type: none">● With the ignition switch ON, the cooling fan HI operates.● With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned OFF, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C compressor OFF

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.
 - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 3 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
 - IPDM E/R operates in low power mode.
 - CAN communication is stopped.
 - When a change in CAN communication line is detected, mode switches to CAN communication status.
 - When a change in hood switch or ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

NKS000E5

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

NKS000E6

Refer to [LAN-48, "CAN System Specification Chart"](#).

Function of Detecting Ignition Relay Malfunction

NKS000E7

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON parking lamp, license plate lamp and tail lamp for 10 minutes to indicate ignition relay malfunction.
- When a state of ignition relay having built-in does not agree with a state of Ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay and daytime light relay ^{*1}
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

- When the ignition switch is turned ON, tail lamp relay and daytime light relay are OFF.
- *1: Canada model only

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

CONSULT-III Function (IPDM E/R)

NKS000E8

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

SELF-DIAG RESULTS

Display Item List

Display Items	CONSULT-III display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	-	-	-	-	-
CAN COMM CIRC	U1000	<ul style="list-style-type: none"> If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. When the data in CAN communication is not received before the specified time 	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> TRANSMIT DIAG ECM BCM

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

DATA MONITOR

All Items, Main Items, Selection From Menu

Item name	CONSULT-III screen display	Display or unit	SELECT MONITOR ITEM			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Parking request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog request	FR FOG REQ*1	ON/OFF	×	×	×	—
Head lamp washer request	HL WASHER REQ*1	ON/OFF	×		×	—
Front wiper request	FR WIP REQ	STOP/1LOW/LOW/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/Block	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ*2	ON/OFF	×		×	Status of input signal
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Item name	CONSULT-III screen display	Display or unit	SELECT MONITOR ITEM			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Oil pressure switch	OIL P SW ^{*1}	OPEN/CLOSE	×		×	—
Day time light request	DTRL REQ ^{*3}	ON/OFF	×		×	Signal status input from BCM
Hood switch	HOOD SW ^{*1}	ON/OFF	×		×	—
Theft warning horn request	THFT HRN REQ	ON/OFF	×		×	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	×		×	Output status of IPDM E/R

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- *1: This items is displayed, but does not function.
- *2: The vehicle without intelligent key system displays only ON without change.
- *3: Only the vehicle with daytime light system operates.

ACTIVE TEST

Display Item List

Test item	CONSULT-III screen display	Description
Tail lamp operation	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger operation	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) operation	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan operation	MOTOR FAN	With a certain operation (1,2,3,4), the cooling fan can be operated.
Headlamp washer ^{NOTE 1}	HEAD LAMP WASHER	—
Lamp (HI, LO, FOG ^{NOTE 2}) operation	LAMPS	With a certain operation (OFF, HI ON, LO ON, FOG ON ^{NOTE}), the lamp relay (Lo, Hi, Fog ^{NOTE}) can be operated.
Horn operation	HORN	Push "ON" button, horn relay operates 20 ms.

NOTE:

1. Headlamp washer item is displayed, but it cannot be tested.
2. Fog lamp item is displayed, but it cannot be tested.

Auto Active Test DESCRIPTION

In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:

- Rear window defogger
- Front wipers
- Parking lamp, license plate lamp and tail lamp
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

OPERATION PROCEDURE

1. Close hood and front door (passenger side), and then lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON, and, within 20 seconds, press driver's front door switch 10 times (close other door). Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once. Oil pressure warning lamp starts blinking.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect [BL-38, "Check Door Switch"](#) when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

When auto active test mode is actuated, the following eight steps are repeated three times.



NOTE:

It takes 10 seconds from 3 to 4.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	● BCM signal input circuit
		NO	<ul style="list-style-type: none"> ● Rear window defogger relay circuit ● Open circuit of rear window defogger ● IPDM E/R malfunction
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	● BCM signal input system
		NO	<ul style="list-style-type: none"> ● Lamp/wiper motor malfunction ● Lamp/wiper motor ground circuit malfunction ● Harness/connector malfunction between IPDM E/R and system in question ● IPDM E/R (integrated relay) malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	<ul style="list-style-type: none"> ● BCM signal input circuit ● CAN communication signal between BCM and ECM. ● CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> ● Magnetic clutch malfunction ● Harness/connector malfunction between IPDM E/R and magnetic clutch ● IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	<ul style="list-style-type: none"> ● ECM signal input circuit ● CAN communication signal between ECM and IPDM E/R
		NO	<ul style="list-style-type: none"> ● Cooling fan motor malfunction ● Harness/connector malfunction between IPDM E/R and cooling fan motor ● IPDM E/R (integrated relay) malfunction


A
B
C
D
E
F
G
H
I
J
L
M

PG

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

NKS0054B

Schematic




TKWT5823E

IPDM E/R Terminal Arrangement

NKS0054C

A
B
C
D
E
F
G
H
I
J
PG
L
M



To engine room harness

CKIT0850E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R Power/Ground Circuit Inspection

NKS000EC

1. CHECK FUSE AND FUSIBLE LINK

Make sure the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
1	Battery power	E
2		C
—		71
—		78

OK or NG


OK >> GO TO 2.

NG >> If fuse or fusible link is blown, be sure to eliminate cause of malfunction before installing new fuse or fusible link.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Check voltage between IPDM E/R harness connector and ground.

Terminal (+)		Terminal (-)	Voltage (Approx.)
IPDM E/R connector	Terminal		
E3	1	Ground	Battery voltage
	2		



OK or NG


OK >> GO TO 3.

NG >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R harness connectors.
2. Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R connector	Terminal	Ground	Continuity
E8	38		Ground
E9	50		
	60		



OK or NG

OK >> INSPECTION END

NG >> Repair harness or connector.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Inspection With CONSULT-III (Self-Diagnosis)

NKS000ED

1. CHECK SELF DIAGNOSTIC RESULT

CONSULT-III display	CONSULT-III display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	—	—	—	No malfunction
CAN COMM CIRC	U1000	×	×	Any of or several items below have errors. <ul style="list-style-type: none"> ● TRANSMIT DIAG ● ECM ● BCM

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed

NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END

CAN COMM CIRC>>After print-out of the monitor items, refer to [LAN-49, "CAN Communication Signal Chart"](#) .

A
B
C
D
E
F
G
H
I
J
L
M

PG



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Removal and Installation of IPDM E/R


REMOVAL

NKS000EE

1. Remove battery. Refer to [SC-7, "Removal and Installation"](#) .
2. Remove IPDM E/R cover A. While pressing pawl on backside of IPDM E/R cover B toward vehicle front to unlock, lift up IPDM E/R.



3. While pressing pawls on right and left side of IPDM E/R, remove IPDM E/R cover B from IPDM E/R.
4. Remove harness connector from IPDM E/R.



INSTALLATION

Installation is the reverse order of removal.


GROUND

GROUND

PF0:00011

Ground Distribution MAIN HARNESS

NKS000EF



A B Next page


PG

L

M

CKIT0865E


GROUND



CKIT0866E

GROUND

ENGINE ROOM HARNESS




A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIT0867E

GROUND


C Preceding page



CON-NECTOR NUMBER	CONNECT TO
E6	IPDM E/R (Intelligent power distribution module engine room) (Terminal No.14)
E19	Shift lock relay
E30	Washer level sensor
E33	Horn (Low)
E36	Horn (High)
E40	Front combination lamp LH (Terminal No. 4) • Headlamp • High beam solenoid
E40	Front combination lamp LH (Terminal No. 8) • Parking • Side marker • Turn signal
E44	Brake fluid level switch
E51	ABS actuator and electric unit (Terminal No. 16)
E51	ABS actuator and electric unit (Terminal No. 30)

CKIT0868E

GROUND





A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIT0869E

GROUND


ENGINE CONTROL HARNESS




CKIT0870E

GROUND

△ D To engine room harness



(F152)
Body ground




A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIT0871E

GROUND



BODY HARNESS Coupe Models



CKIT0856E

GROUND

Roadster Models



* : This sub-harness is not shown in "HARNESS LAYOUT".


H Next page

G To tail harness

A
B
C
D
E
F
G
H
I
J
PG
L
M

GROUND



▲ H Preceding page



CKIT0735E

GROUND


BODY NO. 2 HARNESS



CKIT0872E

GROUND


TAIL HARNESS Coupe Models



CKIT0873E

GROUND

Roadster Models





A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIT0859E

GROUND

BACK DOOR HARNESS



CKIT0464E

HARNESS

HARNESS

PFP:00011


Harness Layout

NKS000EG

HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the figures:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness (Engine Compartment)
- Body Harness



To Use the Grid Reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the figure, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> • Cavity: Less than 4 • Relay connector 				
<ul style="list-style-type: none"> • Cavity: From 5 to 8 				
<ul style="list-style-type: none"> • Cavity: More than 9 				
<ul style="list-style-type: none"> • Ground terminal etc. 	—			


CKIT0108E

A
B
C
D
E
F
G
H
I
J
PG
L
M


HARNESS

OUTLINE

Coupe Models




Roadster Models



HARNESS

MAIN HARNESS



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

TKIT0887E

A4 ★	M4	W/16	Fuse block (J/B)	F3	M58	W/4	To B112 (With VDC system)
A4	M5	W/8	Fuse block (J/B)	E2	M59	L/4	Fuel lid opener relay (For Coupe models)
B4	M8	W/16	Data link connector	D2	M60	W/6	To M254
C4	M9	GY/6	VDC off switch (With VDC system)	E3	M62	W/6	Blower motor
		GY/6	TCS off switch (Without VDC system)	E2	M65	Y/4	Front passenger air bag module
A3	M11	SMJ	To D1	D2 ★	M66	—	Body ground
A3 ★	M12	SMJ	To B1	F5	M67	W/8	To B86 (With navigation system)
B4	M13	GY/6	Fuel lid opener switch	B3	M68	W/12	Power steering control unit
C4	M14	W/6	Soft top switch (For Roadster models)	E3 ★	M71	GY/32	ECM
C4 ★	M15	SMJ	To E108	F2 ★	M72	SMJ	To F102
B3	M16	W/16	To E109 (With VDC system)	F3	M73	SMJ	To B101
E2	M18	B/2	Sunload sensor				(With navigation system, VDC system or telephone)
C2 ★	M19	W/24	Combination meter	F2	M74	SMJ	To D31
C4	M22	W/8	Steering angle sensor (With VDC system)	F2	M78	W/4	Remote keyless entry receiver
C4 ★	M23	GY/8	Combination switch (Spiral cable)	F3	M79	W/2	Tire pressure warning check connector
C4	M24	Y/6	Combination switch (Spiral cable)	D4	M89	W/12	Audio unit (With BOSE system)
C2	M25	BR/2	Key switch	A4	M90	W/40	BCM (Body control module)
B3	M26	W/2	Ignition Keyhole illumination	A5	M91	B/15	BCM (Body control module)
D4	M28	W/4	NATS antenna amp.	B2	M93	W/12	To R2
D2	M29	W/16	Combination switch	C2	M97	—/2	Resistor
C2 ★	M30	—	Body ground	F3	M98	W/4	Hazard switch
C2	M34	BR/2	Security indicator lamp	F3	M99	W/8	To M157 (For heated seat)
D2	M35	GY/24	Display unit (With navigation system)				
E3	M37	W/8	NAVI switch (With navigation system)				
F2	M38	B/2	Power socket				
E4	M39	W/16	Audio unit [With A/T or with M/T (With VDC system, BOSE system or navigation system)]				
D4	M40	W/10	Audio unit				
D3	M41	W/6	Audio unit				
D4	M42	W/2	In-vehicle sensor				
D1	M43	W/12	To R57				
D1	M44	W/12	Triple meter				
D3	M45	BR/2	Antenna amp. (Via sub-harness)				
D4	M46	BR/8	Audio unit (With navigation system or without telephone)				
E4 ★	M47	W/10	A/T device (For A/T)				
E4 ★	M48	GY/20	Unified meter and A/C amp.				
E4 ★	M49	GY/16	Unified meter and A/C amp.				
D4	M50	W/24	Unified meter and A/C amp.				
F5	M51	B/6	Yaw rate / side G sensor (With VDC system)				
E4	M52	W/12	To M151				
G5	M55	Y/28	Air bag diagnosis sensor unit				
E1	M57	L/4	Back-up lamp relay (For A/T)				


				Switch sub-harness			
F4	M151	W/12	To M52	F4	M151	W/12	To M52
F3	M152	W/2	Cup holder illumination	F3	M152	W/2	Cup holder illumination
G4	M154	W/6	Heated seat switch (Driver side)	G4	M154	W/6	Heated seat switch (Driver side)
			(With heated seat)				(With heated seat)
G4	M155	BR/6	Heated seat switch (Passenger side)	G4	M155	BR/6	Heated seat switch (Passenger side)
			(With heated seat)				(With heated seat)
G4	M156	W/6	Not used	G4	M156	W/6	Not used
F4	M157	W/8	To M99	F4	M157	W/8	To M99
			(For heated seat)				(For heated seat)

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

A/C sub-harness

- (M251) W/3 : Not used
- (M252) W/3 : Mode door motor
- (M253) W/3 : Air mix door motor
- (M254) W/6 : To (M60)
- (M255) W/4 : Intake sensor
- (M256) W/3 : Intake door motor




A
B
C
D
E
F
G
H
I
J
PG
L
M

TKIT0889E

HARNESS

ENGINE ROOM HARNESS Engine Compartment




★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
 Do not disconnect these connectors except in the case of working according
 to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

For detail ground distribution information,
 refer to "GROUND DISTRIBUTION".

HARNESS

Passenger Compartment

- ★ E101 W/8 : Fuse block (J/B)
- E102 W/6 : Fuse block (J/B)
- E103 B/1 : Fuse block (J/B)
- E104 B/2 : Fuse block (J/B)
- ★ E106 W/18 : To B2
- E107 W/6 : To B3
- ★ E108 SMJ : To M15
- E109 W/16 : To M16 (With VDC system)
- ★ E110 BR/2 : ASCD brake switch
- ★ E111 W/4 : Stop lamp switch
- ★ E113 GY/6 : Accelerator pedal position sensor
- E119 W/6 : Ignition switch
- E121 L/2 : Clutch interlock switch (With M/T)
- ★ E122 L/2 : ASCD clutch switch (With M/T)
- E123 BR/2 : Microphone




★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

TKIT0899E

HARNESS

Battery Cable

A
B
C
D
E
F
G
H
I
J
PG
L
M



- : Fusible link holder
- : Starter motor
- : Fusible link holder
- : Alternator (B)


- | | | |
- (E201)
- (E203)
- (E204)
- (E205)

TKIT0892E

HARNESS

ENGINE CONTROL HARNESS

Engine Compartment



★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

For detail ground distribution information, refer to "GROUND DISTRIBUTION".

C1	★	(F1)	GY/9	:	To	(E10)	
B1	★	(F3)	B/8	:	To	(E12)	
D1	★	(F5)	GY/2	:	EVAP canister purge volume control solenoid valve		
F2	★	(F6)	GY/10	:	A/T assembly (With A/T)		
D1	★	(F13)	GY/2	:	Engine coolant temperature sensor		
B2	★	(F15)	GY/3	:	Ignition coil No.5 (With power transistor)		
B2	★	(F16)	W/2	:	Condenser		
A4	★	(F19)	B/3	:	Power steering pressure sensor		
B5	★	(F21)	B/3	:	Oil pressure sensor		
B5	★	(F23)	—	:	Engine ground		
D5	★	(F24)	B/1	:	Compressor		
C5	★	(F26)	GY/2	:	Intake valve timing control solenoid valve (Bank 2)		
D4	★	(F27)	GY/3	:	Ignition coil No.2 (With power transistor)		
E4	★	(F28)	GY/3	:	Ignition coil No.4 (With power transistor)		
E4	★	(F29)	GY/3	:	Ignition coil No.6 (With power transistor)		
F1	★	(F35)	B/2	:	Park/Neutral position switch (With M/T)		
F1	★	(F36)	B/2	:	Back-up lamp switch (With M/T)		
A4	★	(F40)	B/4	:	Exhaust valve timing control magnet retarder (Bank 1)		
C5	★	(F41)	B/4	:	Exhaust valve timing control magnet retarder (Bank 2)		
F4	★	(F43)	GY/2	:	Power steering solenoid valve		
F4	★	(F44)	GY/1	:	Starter motor		
F2	★	(F45)	B/4	:	Heated oxygen sensor 2 (Bank 1)		
G2	★	(F46)	B/4	:	Heated oxygen sensor 2 (Bank 2)		
C2	★	(F47)	B/3	:	Crankshaft position sensor (POS)		
D2	★	(F48)	B/4	:	To (F251)		
C2	★	(F49)	GY/4	:	Air fuel ratio (A/F) sensor 1 (Bank 1)		
C2	★	(F50)	B/3	:	Exhaust valve timing control position sensor (Bank 1)		
D2	★	(F51)	B/3	:	Camshaft position sensor (PHASE) (Bank 1)		
A4	★	(F52)	GY/2	:	Fuel injector No.1		
B3	★	(F53)	GY/2	:	Fuel injector No.3		
C4	★	(F54)	GY/2	:	Fuel injector No.5		
B3	★	(F55)	GY/3	:	Ignition coil No.1 (With power transistor)		
B2	★	(F56)	GY/3	:	Ignition coil No.3 (With power transistor)		
B3	★	(F57)	B/6	:	Electric throttle control actuator (Bank 1)		
A5	★	(F58)	B/3	:	Alternator (S, L)		
C5	★	(F59)	GY/2	:	Engine oil temperature sensor		
B3	★	(F60)	B/6	:	Mass air flow sensor (Bank 1)		
B4	★	(F61)	—	:	Engine ground		
E1	★	(F62)	B/3	:	Exhaust valve timing control position sensor (Bank 2)		
E1	★	(F63)	B/3	:	Camshaft position sensor (PHASE) (Bank 2)		
E2	★	(F64)	GY/4	:	Air fuel ratio (A/F) sensor 1 (Bank 2)		
E4	★	(F65)	B/6	:	Electric throttle control actuator (Bank 2)		
C5	★	(F66)	GY/2	:	Fuel injector No.2		
D4	★	(F67)	GY/2	:	Fuel injector No.4		
E4	★	(F68)	GY/2	:	Fuel injector No.6		
B5	★	(F69)	GY/2	:	Intake valve timing control solenoid valve (Bank 1)		
E5	★	(F70)	B/6	:	Mass air flow sensor (Bank 2)		

Engine control sub-harness

D1	★	(F251)	B/4	:	To	(F48)
C5	★	(F252)	—/2	:	Knock sensor (Bank 1)	
D4	★	(F253)	—/2	:	Knock sensor (Bank 2)	

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A B C D E F G H I J L M PG

HARNESS

Passenger Compartment

Engine control harness


- ★ (F102) SMJ : To (M72)
- ★ (F103) W/4 : To (M151) (*2)
- W/4 : To (B113) (*1)
- (F104) W/8 : Not used
- ★ (F110) B/48 : ECM
- ★ (F111) BR/48 : ECM

Earth sub-harness (*2)


- ★ (F151) W/4 : To (F103)
- ★ (F152) - : Body ground

*1 : With VDC system, navigation system or telephone

*2 : Without VDC system, navigation system and telephone



★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.




For detail ground distribution information, refer to "GROUND DISTRIBUTION".

TKIT0895E

HARNESS

BODY HARNESS Coupe Models



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

- ★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

PG


HARNESSES

★ C4	B1	SMJ	:	To (M12)	E2	(B37)	L/4	:	Heated seat relay (With heated seat or side air bag)
C4	★ B2	W/18	:	To (E106)	F1	(B38)	W/3	:	To (D101)
C4	B3	W/6	:	To (E107)	E1	(B39)	GY/2	:	To (D102)
E4	B5	—	:	Body ground	F2	(B40)	BR/2	:	Rear speaker LH
F4	B6	—	:	Body ground	D2	(B41)	W/2	:	Luggage floor box lamp
E4	B7	W/4	:	Driver side seat (With heated seat or side air bag)	D2	(B42)	BR/2	:	Rear speaker RH
D4	B8	W/3	:	Seat belt buckle switch (Driver side)	G2	★ (B43)	W/6	:	To (T1)
D4	B9	Y/2	:	LH side air bag module (With side air bag)	G2	★ (B44)	W/32	:	To (T2)
B3	B10	Y/2	:	RH side air bag module (With side air bag)	G2	(B45)	W/10	:	To (T3) (With BOSE system)
B3	B11	W/3	:	Seat belt buckle switch (Passenger side)	G2	(B46)	W/24	:	To (T4) (With BOSE system)
C4	B12	W/4	:	Passenger side seat (With heated seat or side air bag)	C3	(B47)	B/1	:	Parking brake switch
D3	B13	Y/12	:	Air bag diagnosis sensor unit	D2	(B49)	BR/2	:	To (B50)
D3	B14	Y/12	:	Air bag diagnosis sensor unit	D2	(B50)	BR/2	:	To (B49)
G3	B15	Y/2	:	LH side air bag (satellite) sensor (With side air bag)	D5	(B83)	W/15	:	BCM (Body control module)
G3	B16	Y/2	:	Seat belt pre-tensioner LH	B4	(B85)	W/8	:	Passenger side seat
F3	B17	W/3	:	Driver side door switch	C3	(B86)	W/8	:	To (M67)
C2	B21	Y/2	:	RH side air bag (satellite) sensor (With side air bag)	B3	(B87)	GY/8	:	To (B116)
C2	B22	Y/2	:	Seat belt pre-tensioner RH					
C2	B23	W/3	:	Passenger side door switch					
E2	B25	W/2	:	Woofer (With BOSE system)					
E3	B26	W/2	:	Condenser					
C3	★ B27	GY/5	:	Fuel level sensor unit and fuel pump					
E3	B28	GY/2	:	Fuel level sensor unit (Sub)					
E3	B29	W/2	:	To (B31)					
E1	B30	Y/2	:	LH side curtain air bag module (With side air bag)					
E3	B31	W/2	:	To (B29)					
E2	B32	BR/8	:	Woofer amp. (With BOSE system)					
D1	B33	Y/2	:	RH side curtain air bag module (With side air bag)					
E2	B34	BR/6	:	Rear window defogger relay					
E1	B36	B/2	:	Power socket					

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

Roadster Models



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

- ★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

A B C D E F G H I J K L M

PG




HARNESSES

C3	★	B1	SMJ	:	To (M12)	D3	(B55)	W/2	:	Circuit breaker
C4	★	B2	W/18	:	To (E106)	F3	(B56)	W/2	:	Short connector
C4		B3	W/6	:	To (E107)	G3	(B57)	GY/8	:	Soft top assembly
E4		B5	—	:	Body ground	G1	(B58)	B/2	:	Soft top assembly
F4		B6	—	:	Body ground	G1	(B59)	GY/2	:	Roof actuator LH
D4		B7	W/4	:	Driver side seat	G1	★ (B61)	W/16	:	To (T23)
D4		B8	W/3	:	Seat belt buckle switch (Driver side)	G2	(B62)	GY/4	:	To (T24) (With BOSE system)
D3		B9	Y/2	:	LH side air bag module (With side air bag)	G2	(B63)	B/6	:	To (T25) (With BOSE system)
B2		B10	Y/2	:	RH side air bag module (With side air bag)	F1	(B64)	W/2	:	Storage lid switch LH (Close)
B3		B11	W/3	:	Seat belt buckle switch (Passenger side)	F1	(B65)	B/2	:	Storage lid unlock actuator LH
D2		B13	Y/12	:	Air bag diagnosis sensor unit	F1	(B66)	W/16	:	Soft top control unit
C3		B14	Y/12	:	Air bag diagnosis sensor unit	F1	(B67)	W/20	:	Soft top control unit
F3		B15	Y/2	:	LH side air bag (satellite) sensor (With side air bag)	F1	(B68)	W/12	:	Soft top control unit
G3		B16	Y/2	:	Seat belt pre-tensioner LH	E1	(B69)	W/2	:	Storage lid switch RH (Close)
F2		B17	W/3	:	Driver side door switch	E1	(B70)	B/2	:	Storage lid unlock actuator RH
C1		B21	Y/2	:	RH side air bag (satellite) sensor (With side air bag)	D2	(B71)	W/2	:	Trunk opener cancel switch
D1		B22	Y/2	:	Seat belt pre-tensioner RH	D1	(B72)	GY/2	:	Roof actuator RH
C2		B23	W/3	:	Passenger side door switch	D1	(B73)	B/2	:	Rear window defogger (Via sub-harness)
E2		B25	W/2	:	Woofer (With BOSE system)	F3	(B75)	W/2	:	Diode
E3		B26	W/2	:	Condenser	G3	(B76)	W/2	:	Diode
D2	★	B27	GY/5	:	Fuel level sensor unit and fuel pump	G3	(B77)	W/2	:	Diode
E3		B28	GY/2	:	Fuel level sensor unit (Sub)	C4	(B83)	W/15	:	BCM (Body control module)
E3		B29	W/2	:	To (B31)	B3	(B85)	W/8	:	Passenger side seat
E3		B31	W/2	:	To (B29)	C2	(B86)	W/8	:	To (M67)
E2		B32	BR/8	:	Woofer amp. (With BOSE system)	B2	(B87)	GY/8	:	To (BT16)
E1		B34	BR/6	:	Rear window defogger relay					
C3		B35	W/18	:	Passenger side seat					
D1		B36	B/2	:	Power socket					
D1		B37	L/4	:	Heated seat relay (With heated seat or side air bag)					
F2		B40	BR/2	:	Rear speaker LH					
D2		B41	W/2	:	Luggage floor box lamp					
D2		B42	BR/2	:	Rear speaker RH					
G1	★	B44	W/32	:	To (T2)					
G1		B46	W/24	:	To (T4) (With BOSE system)					
D3		B47	B/1	:	Parking brake switch					
C2		B49	BR/2	:	To (B50)					
C2		B50	BR/2	:	To (B49)					

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

HARNESS

A
B
C
D
E
F
G
H
I
J
PG
L
M




TKIT0117E

HARNESS


BODY NO. 2 HARNESS

(B101)	SMJ	:	To (M73)
★(B102)	—	:	Body ground
(B104)	W/40	:	NAVI control unit (With navigation system)
(B105)	W/32	:	NAVI control unit (With navigation system)
(B111)	W/24	:	To (T46) (With telephone)
(B112)	W/4	:	To (M68) (With VDC system)
★(B113)	W/4	:	To (F103)
(B114)	SMJ	:	VDC / TCS / ABS control unit (With VDC system)
(B115)	—	:	Body ground (With navigation system)
(B116)	GY/8	:	To (B87)



★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

For detail ground distribution information, refer to "GROUND DISTRIBUTION".



TKIT0896E

TAIL HARNESS Coupe Models


- ★ T1 : To (B43)
- ★ T2 : To (B44)
- T3 : To (B45) (With BOSE system)
- T4 : To (B46) (With BOSE system)
- T5 : Rear wheel sensor
- T6 : BOSE speaker amp. (With BOSE system)
- T7 : BOSE speaker amp. (With BOSE system)
- T9 : Rear combination lamp LH (Body side)
- T10 : Rear combination lamp LH (Bumper side)
- T11 : Back door opener actuator
- T12 : Back door switch
- T13 : Luggage room lamp
- T14 : Body ground
- T15 : To (T10)
- T17 : Rear combination lamp RH (Body side)
- T18 : Rear combination lamp RH (Bumper side)

- ★ T19 : Fuel lid opener actuator
- ★ T20 : EVAP canister vent control valve
- ★ T21 : EVAP control system pressure sensor
- T42 : Satellite radio tuner (With BOSE system)
- T45 : TEL adapter unit (with telephone)
- T46 : To (B11) (With telephone)

Tail sub-harness-1

- T101 : GY/4 : To (T15)
- T102 : BR/2 : License plate lamp LH
- T103 : GY/2 : Back door opener switch
- T104 : BR/2 : License plate lamp RH


★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.



TKIT0897E

HARNESS

Roadster Models



TKIT0852E

Tail sub-harness-1

★ C2	(T2)	W/32	:	To (B44)
C2	(T4)	W/24	:	To (B46) (With BOSE system)
D4	(T5)	GY/4	:	Rear wheel sensor
D4	(T6)	GY/8	:	BOSE speaker amp. (With BOSE system)
C4	(T7)	B/24	:	BOSE speaker amp. (With BOSE system)
C4	(T9)	GY/3	:	Rear combination lamp LH (Body side)
D5	(T10)	GY/4	:	Rear combination lamp LH (Bumper side)
F3	(T14)	—	:	Body ground
E3	(T15)	GY/4	:	To (T101)
G2	(T17)	GY/3	:	Rear combination lamp RH (Body side)
G3	(T18)	GY/4	:	Rear combination lamp RH (Bumper side)
F3	(T19)	W/4	:	Fuel lid opener actuator
F5	★ (T20)	B/2	:	EVAP canister vent control valve
F5	★ (T21)	GY/3	:	EVAP control system pressure sensor
C2	★ (T23)	W/16	:	To (B61)
B3	(T24)	GY/4	:	To (B62) (With BOSE system)
B3	(T25)	B/6	:	To (B63) (With BOSE system)
B2	(T26)	W/8	:	To (T151)
B2	(T27)	B/2	:	Storage lid switch (Open)
B3	(T28)	W/2	:	Storage lid actuator LH
D2	(T29)	W/2	:	Trunk room lamp
E2	(T30)	W/2	:	Storage lid actuator RH
E2	(T35)	W/2	:	To (T36)
E2	(T36)	W/2	:	To (T35)
E3	(T47)	W/3	:	Trunk lid lock assembly

F3	(T101)	GY/4	:	To (T15)
E3	(T102)	BR/2	:	License plate lamp LH
F4	(T103)	GY/2	:	Trunk lid opener switch
F5	(T104)	BR/2	:	License plate lamp RH

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.


A
B
C
D
E
F
G
H
I
J

PG

L
M

HARNESS

TAIL NO. 2 HARNESS Roadster Models



Tail No.2 harness

- (T201) W/8 : To (T152)
- (T202) BR/2 : High-mounted stop lamp
- (T203) W/4 : 5th bow unlock actuator
- (T204) B/2 : 5th bow closure motor
- (T205) W/6 : Soft top lock switch

Tail sub-harness-2


- (T151) W/8 : To (T26)
- (T152) W/8 : To (T201)

HARNESS

ROOM LAMP HARNESS Coupe Models

Room lamp sub-harness

- | | | | |
|-------|------|---|--------------------------------------------------------------|
| (R2) | W/12 | : | To (M93) |
| (R3) | W/2 | : | Vanity mirror lamp LH |
| (R4) | B/10 | : | Auto anti-dazzling inside mirror |
| (R5) | W/2 | : | Vanity mirror lamp RH |
| (R52) | W/3 | : | Map lamp |
| (R57) | W/12 | : | To (M43) |
| (R58) | W/12 | : | Front passenger air bag off indicator • Telephone microphone |



A
B
C
D
E
F
G
H
I
J
PG
L
M


HARNESS

Roadster Models

- | | | | |
|------|------|---|----------------------------------|
| (R2) | W/12 | : | To (M93) |
| (R3) | W/2 | : | Vanity mirror lamp LH |
| (R4) | B/10 | : | Auto anti-dazzling inside mirror |
| (R5) | W/2 | : | Vanity mirror lamp RH |
| (R8) | W/4 | : | Soft top front lock switch |

Room lamp sub-harness

- | | | | |
|-------|------|---|---------------------------------------|
| (R53) | W/4 | : | Map lamp |
| (R57) | W/12 | : | To (M43) |
| (R58) | W/12 | : | Front passenger air bag off indicator |




TKIT0855E

HARNESS

DOOR HARNESS

Driver Side Door


- (D1) SMJ : To (M11)
- (D2) W/8 : Door mirror (Driver side)
- (D3) BR/2 : Tweeter (Driver side)
- (D4) W/2 : Driver door speaker (Without BOSE system)
- (D5) BR/2 : Driver door speaker (With BOSE system)
- (D6) W/10 : Door mirror remote control switch
- (D7) W/16 : Power window main switch
- (D9) W/6 : Driver side power window motor
- (D11) GY/4 : Driver side door lock actuator
- (D12) BR/3 : Door key cylinder switch
- (D14) GY/2 : Bottle holder illumination (Driver side)



TKIT0563E

Passenger Side Door

- (D31) SMJ : To (M74)
- (D32) W/8 : Door mirror (Passenger side)
- (D33) BR/2 : Tweeter (Passenger side)
- (D34) W/2 : Passenger door speaker (Without BOSE system)
- (D35) BR/2 : Passenger door speaker (With BOSE system)
- (D37) W/16 : Power window sub-switch
- (D38) W/6 : Passenger side power window motor
- (D40) GY/4 : Passenger side door lock actuator
- (D42) GY/2 : Bottle holder illumination (Passenger side)



TKIT0564E




A
B
C
D
E
F
G
H
I
J
PG
L
M

HARNESSES

Back Door

Defogger harness (-)
 (D211) B/1 : Rear window defogger (-)
 (D212) -- : Body ground

(D101) W/3 : To (B38)
 (D102) GY/2 : To (B39)
 (D103) BR/2 : High-mounted stop lamp
 (D104) B/1 : Rear window defogger
 (D105) -- : Body ground
 (D106) W/4 : Rear wiper motor



For detail ground distribution information, refer to "GROUND DISTRIBUTION".

TKIT0068E

HARNESS

Wiring Diagram Codes (Cell Codes)

NKS000EH

Use the chart below to find out what each wiring diagram code stands for. Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
3METER	DI	Triple Meter
ABS	BRC	Anti-Lock Braking System
A/C	ATC	Air Conditioner
AF1B1	EC	Air Fuel Ratio Sensor 1 (Bank 1)
AF1B2	EC	Air Fuel Ratio Sensor 1 (Bank 2)
AF1HB1	EC	Air Fuel Ratio Sensor 1 Heater (Bank 1)
AF1HB2	EC	Air Fuel Ratio Sensor 1 Heater (Bank 2)
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
ASCBOF	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
AT/IND	DI	A/T Indicator Lamp
AUDIO	AV	Audio
BACK/L	LT	Back-Up Lamp
BRK/SW	EC	Brake Switch
CAN	AT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication Line
COOL/F	EC	Cooling Fan Control
DEF	GW	Rear Window Defogger
D/LOCK	BL	Power Door Lock
DTRL	LT	Headlamp - With Daytime Light System
ECM/PW	EC	ECM Power Supply for Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
EOTS	EC	Engine Oil Temperature Sensor
EPS	STC	Electric Controlled Power Steering System
ETC1B1	EC	Electric Throttle Control Function (Bank 1)
ETC1B2	EC	Electric Throttle Control Function (Bank 2)
ETC2B1	EC	Electric Throttle Control Motor Relay (Bank 1)
ETC2B2	EC	Electric Throttle Control Motor Relay (Bank 2)
ETC3B1	EC	Electric Throttle Control Motor (Bank 1)
ETC3B2	EC	Electric Throttle Control Motor (Bank 2)
EVCB1	EC	Exhaust Valve Timing Control Magnet Retarder (Bank 1)
EVCB2	EC	Exhaust Valve Timing Control Magnet Retarder (Bank 2)

HARNESS

Code	Section	Wiring Diagram Name
EVCSB1	EC	Exhaust Valve Timing Control Position Sensor (Bank 1)
EVCSB2	EC	Exhaust Valve Timing Control Position Sensor (Bank 2)
F/LID	BL	Fuel Lid Opener
F/PUMP	EC	Fuel Pump
F/ROOF	RF	Soft Top
FTS	AT	A/T Fluid Temperature Sensor Circuit
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/LAMP	LT	Headlamp
H/PHON	AV	Handsfree Telephone System
HORN	WW	Horn
HSEAT	SE	Heated Seat
IATSB1	EC	Intake Air Temperature Sensor (Bank 1)
IGNSYS	EC	Ignition System
ILL	LT	Illumination
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve (Bank 1)
IVCB2	EC	Intake Valve Timing Control Solenoid Valve (Bank 2)
KEYLES	BL	Remote Keyless Entry System
KSB1	EC	Knock Sensor (Bank 1)
KSB2	EC	Knock Sensor (Bank 2)
MAFSB1	EC	Mass Air Flow Sensor (Bank 1)
MAFSB2	EC	Mass Air Flow Sensor (Bank 2)
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
M/ANT	AV	Manual Antenna
METER	DI	Speedometer, Tachometer, Temp. and Fuel Gauges
MIL/DL	EC	MIL & Data Link Connector
MIRROR	GW	Power Door Mirror
MMSW	AT	Manual Mode Switch
NATS	BL	Nissan Anti-Theft System
NAVI	AV	Navigation System
NONDTC	AT	Non-Detective Items
O2H2B1	EC	Heated Oxygen Sensor 2 Heater (Bank 1)
O2H2B2	EC	Heated Oxygen Sensor 2 Heater (Bank 2)
O2S2B1	EC	Heated Oxygen Sensor 2 (Bank 1)
O2S2B2	EC	Heated Oxygen Sensor 2 (Bank 2)
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank 1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank 2)
PNP/SW	AT	Park/Neutral Position Switch
PNP/SW	EC	Park/Neutral Position Switch

HARNESS

Code	Section	Wiring Diagram Name	
POS	EC	Crankshaft Position Sensor (CKPS) (POS)	A
POWER	PG	Power Supply Routing	
PRE/SE	EC	EVAP Control System Pressure Sensor	B
P/SCKT	WW	Power Socket	
PS/SEN	EC	Power Steering Pressure Sensor	
ROOM/L	LT	Interior Room Lamp	C
RP/SEN	EC	Refrigerant Pressure Sensor	
SEAT	SE	Power Seat	D
SEN/PW	EC	Sensor Power Supply	
SHIFT	AT	A/T Shift Lock System	
SRS	SRS	Supplemental Restraint System	E
START	SC	Starting System	
STOP/L	LT	Stop Lamp	
STSIG	AT	Start Signal Circuit	F
TAIL/L	LT	Parking, License and Tail Lamps	
TCS	BRC	Traction Control System	G
TLID	BL	Trunk Lid Opener	
TPS1B1	EC	Throttle Position Sensor (Sensor 1) (Bank 1)	H
TPS1B2	EC	Throttle Position Sensor (Sensor 1) (Bank 2)	
TPS2B1	EC	Throttle Position Sensor (Sensor 2) (Bank 1)	
TPS2B2	EC	Throttle Position Sensor (Sensor 2) (Bank 2)	I
TPS3B1	EC	Throttle Position Sensor (Bank 1)	
TPS3B2	EC	Throttle Position Sensor (Bank 2)	
TRNSCV	BL	Homelink Universal Transceiver	J
TURN	LT	Turn Signal and Hazard Warning Lamp	
T/WARN	WT	Low Tire Pressure Warning System	PG
VDC	BRC	Vehicle Dynamics Control System	
VEHSEC	BL	Vehicle Security System	
VENT/V	EC	EVAP Canister Vent Control Valve	L
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)	
WARN	DI	Warning Lamps	M
WINDOW	GW	Power Window	
WIPER	WW	Front Wiper and Washer	
WIP/R	WW	Rear Wiper and Washer	

ELECTRICAL UNITS LOCATION



ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT

NKS000E1


IPDM E/R (Intelligent power distribution module engine room)



CKIT0874E



ELECTRICAL UNITS LOCATION

PASSENGER COMPARTMENT



A Behind dash side lower LH finisher

Fuse block (J/B) rear view



A
B
C
D
E
F
G
H
I
J
L
M
PG
L
M

CKIT0860E



ELECTRICAL UNITS LOCATION

<p>B Driver side view with instrument lower panel removed</p> <p>Circuit breaker B55</p>	<p>C Driver side view with instrument lower panel removed</p> <p>Steering column assembly Power steering control unit M68</p>	<p>D View with steering column cover removed</p> <p>NATS antenna amp. M28 Ignition key cylinder</p>
<p>E Driver side view with instrument upper panel removed</p> <p>GPS antenna</p>	<p>F View with instrument panel removed</p> <p>Blower motor Fuel lid opener relay M59</p>	<p>G Blower motor RH side</p> <p>ECM M71, F110, F111</p>
<p>H Behind dash side lower RH finisher</p> <p>VDC/TCS/ABS control unit B114</p>	<p>J View with console finisher removed</p> <p>Unified meter and A/C amp. M48, M49, M50</p>	<p>K Under passenger seat</p> <p>Front Passenger seat control unit B353, B354</p>
<p>L View with floor console box removed</p> <p>Parking brake lever Air bag diagnosis sensor unit M55, B13, B14</p>	<p>M View with floor console box removed</p> <p>Parking brake lever Yaw rate / side G sensor M51</p>	

CKIT0875E

ELECTRICAL UNITS LOCATION

A
B
C
D
E
F
G
H
I
J
PG
L
M





CKIT0349E

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT


Coupe Models



CKIT0878E



ELECTRICAL UNITS LOCATION

Roadster Models



A
B
C
D
E
F
G
H
I
J

PG



L
M

CKIT0350E

HARNESS CONNECTOR

PFP:00011

HARNESS CONNECTOR

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)


NKS004SA

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

CAUTION:

Never pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

CAUTION:

- **Never pull the harness or wires when disconnecting the connector.**
- **Be careful not to damage the connector support bracket when disconnecting the connector.**

[Example]



A
B
C
D
E
F
G
H
I
J
PG
L
M


HARNESS CONNECTOR

HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

CAUTION:

Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.



1. Control unit with single lever

- A. Fasten
- B. Loosen
- C. Lever

2. Control unit with dual levers

- A. Levers
- B. Fasten
- C. Loosen

3. SMJ connector

- A. Lever
- B. Fasten
- C. Loosen

ELECTRICAL UNITS


ELECTRICAL UNITS Terminal Arrangement

PPF:00011


NKS004SB

A
B
C
D
E
F
G
H
I
J
PG
L
M


ECM



(Black)



(Brown)




(Gray)



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

E51




(Gray)



VDC/TCS/ABS CONTROL UNIT

B114




(Black)



UNIFIED METER AND A/C AMP.

M48




(Gray)

M49



(Gray)

M50



(White)




CKIT0876E

ELECTRICAL UNITS


BCM (BODY CONTROL MODULE)

M90




(White)

M91



(Black)

B83



(White)

CKIT0647E

SMJ (SUPER MULTIPLE JUNCTION)


SMJ (SUPER MULTIPLE JUNCTION)

PF:P:B4341

Terminal Arrangement

NKS000EL

MAIN HARNESS



A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIT0743E

SMJ (SUPER MULTIPLE JUNCTION)



MAIN HARNESS

M72 (White)

6H	7H	8H	9H	10H	21H	22H	23H	24H	25H	26H	27H	28H	29H	39H	40H	41H	42H	43H	44H	45H	46H		
1H	2H	3H	4H	5H	11H	12H	13H	14H	15H	16H	17H	18H	19H	20H	30H	31H	32H	33H	34H	35H	36H	37H	38H

1H	2H	3H	4H	5H	11H	12H	13H	14H	15H	16H	17H	18H	19H	20H	30H	31H	32H	33H	34H	35H	36H	37H	38H
6H	7H	8H	9H	10H	21H	22H	23H	24H	25H	26H	27H	28H	29H	39H	40H	41H	42H	43H	44H	45H	46H		

F102 (White)

ENGINE CONTROL HARNESS



MAIN HARNESS

M11 (White)

20K	21K	22K	23K	24K	25K	26K	27K	36K	37K	38K	39K		
11K	12K	13K	14K	15K	16K	17K	18K	19K	32K	33K	34K	35K	
1K	2K	3K	4K	5K	6K	7K	8K	9K	10K	28K	29K	30K	31K

M74 (White)

20L	21L	22L	23L	24L	25L	26L	27L	36L	37L	38L	39L		
11L	12L	13L	14L	15L	16L	17L	18L	19L	32L	33L	34L	35L	
1L	2L	3L	4L	5L	6L	7L	8L	9L	10L	28L	29L	30L	31L

D1 (White)

1K	2K	3K	4K	5K	6K	7K	8K	9K	10K	28K	29K	30K	31K
11K	12K	13K	14K	15K	16K	17K	18K	19K	32K	33K	34K	35K	
20K	21K	22K	23K	24K	25K	26K	27K	36K	37K	38K	39K		

D31 (White)

1L	2L	3L	4L	5L	6L	7L	8L	9L	10L	28L	29L	30L	31L
11L	12L	13L	14L	15L	16L	17L	18L	19L	32L	33L	34L	35L	
20L	21L	22L	23L	24L	25L	26L	27L	36L	37L	38L	39L		

FRONT DOOR HARNESS (DRIVER SIDE)

FRONT DOOR HARNESS (PASSENGER SIDE)

CKIT0158E

STANDARDIZED RELAY

PPF:00011


NKS000EM

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS

- 1M 1 Make
- 2M 2 Make
- 1T 1 Transfer
- 1M·1B 1 Make 1 Break

















SEL882H

A
B
C
D
E
F
G
H
I
J

PG

L
M

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W


FUSE BLOCK - JUNCTION BOX (J/B)

FUSE BLOCK - JUNCTION BOX (J/B)

PPF:24350

Terminal Arrangement

NKS000EN



A
B
C
D
E
F
G
H
I
J
PG
L
M




FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

NKS000EO

FUSE, FUSIBLE LINK AND RELAY BOX

Terminal Arrangement



CKIT0877E