

# SECTION **INL**

## INTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

### CONTENTS

<p><b>PRECAUTION</b> ..... 3</p> <p><b>PRECAUTIONS</b> ..... 3</p> <p style="padding-left: 20px;">Precaution for Technicians Using Medical Electric.....3</p> <p style="padding-left: 20px;">Point to Be Checked Before Starting Maintenance Work .....3</p> <p style="padding-left: 20px;">Precaution for Removing 12V Battery .....3</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....4</p> <p><b>SYSTEM DESCRIPTION</b> ..... 5</p> <p><b>COMPONENT PARTS</b> ..... 5</p> <p style="padding-left: 20px;">Component Parts Location .....5</p> <p style="padding-left: 20px;">Bulb Specifications .....6</p> <p><b>SYSTEM</b> ..... 7</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....7</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : System Description .....7</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : Schematic .....9</p> <p><b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....9</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description ..... 10</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Schematic ..... 11</p> <p><b>ILLUMINATION CONTROL SYSTEM</b> ..... 11</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : System Description ..... 12</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : Schematic ..... 13</p> <p><b>AUTO LIGHT ADJUSTMENT SYSTEM</b> ..... 13</p> <p style="padding-left: 20px;">AUTO LIGHT ADJUSTMENT SYSTEM : System Description ..... 14</p>	<p style="padding-left: 20px;">AUTO LIGHT ADJUSTMENT SYSTEM : Schematic .....15</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> ..... 16</p> <p><b>COMMON ITEM</b> ..... 16</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) ..... 16</p> <p><b>INT LAMP</b> ..... 17</p> <p style="padding-left: 20px;">INT LAMP : CONSULT Function (BCM - INT LAMP) ..... 18</p> <p><b>BATTERY SAVER</b> ..... 19</p> <p style="padding-left: 20px;">BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) ..... 19</p> <p><b>ECU DIAGNOSIS INFORMATION</b> ..... 21</p> <p><b>BCM</b> ..... 21</p> <p style="padding-left: 20px;">List of ECU Reference ..... 21</p> <p><b>WIRING DIAGRAM</b> ..... 22</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> ..... 22</p> <p style="padding-left: 20px;">Wiring Diagram ..... 22</p> <p><b>ILLUMINATION</b> ..... 30</p> <p style="padding-left: 20px;">Wiring Diagram ..... 30</p> <p><b>BASIC INSPECTION</b> ..... 40</p> <p><b>DIAGNOSIS AND REPAIR WORKFLOW</b> ..... 40</p> <p style="padding-left: 20px;">Work Flow ..... 40</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> ..... 42</p> <p><b>INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT</b> ..... 42</p> <p style="padding-left: 20px;">Description ..... 42</p> <p style="padding-left: 20px;">Component Function Check ..... 42</p> <p style="padding-left: 20px;">Diagnosis Procedure ..... 42</p>
--	---

**INL**

M  
N  
O  
P

<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b> .....	44	Removal and Installation .....	50
Description .....	44	Replacement .....	51
Component Function Check .....	44	<b>GLOVE BOX LAMP</b> .....	<b>53</b>
Diagnosis Procedure .....	44	Exploded View .....	53
<b>LUGGAGE ROOM LAMP CIRCUIT</b> .....	<b>46</b>	Replacement .....	53
Description .....	46	<b>ROOM LAMP</b> .....	<b>55</b>
Diagnosis Procedure .....	46	Exploded View .....	55
<b>POWER SWITCH ILLUMINATION CIRCUIT</b> ...	<b>47</b>	Removal and Installation .....	55
Description .....	47	Replacement .....	56
Component Function Check .....	47	<b>LUGGAGE ROOM LAMP</b> .....	<b>57</b>
Diagnosis Procedure .....	47	Exploded View .....	57
<b>SYMPTOM DIAGNOSIS</b> .....	<b>49</b>	Removal and Installation .....	57
<b>INTERIOR LIGHTING SYSTEM SYMPTOMS</b> ...	<b>49</b>	Replacement .....	58
Symptom Table .....	49	<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>REMOVAL AND INSTALLATION</b> .....	<b>50</b>	<b>(SDS)</b> .....	<b>59</b>
<b>MAP LAMP</b> .....	<b>50</b>	<b>SERVICE DATA AND SPECIFICATIONS</b>	
Exploded View .....	50	<b>(SDS)</b> .....	<b>59</b>
		Bulb Specifications .....	59

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Technicians Using Medical Electric

INFOID:000000007072768

##### OPERATION PROHIBITION

###### **WARNING:**

- Parts with strong magnet is used in this vehicle.
- Technicians using a medical electric device such as pacemaker must never perform operation on the vehicle, as magnetic field can affect the device function by approaching to such parts.

##### NORMAL CHARGE PRECAUTION

###### **WARNING:**

- If a technician uses a medical electric device such as an implantable cardiac pacemaker or an implantable cardioverter defibrillator, the possible effects on the devices must be checked with the device manufacturer before starting the charge operation.
- As radiated electromagnetic wave generated by on board charger at normal charge operation may effect medical electric devices, a technician using a medical electric device such as implantable cardiac pacemaker or an implantable cardioverter defibrillator must not enter the vehicle compartment (including luggage room) during normal charge operation.

##### Precaution at telematics system operation

###### **WARNING:**

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of TCU might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), when using the service, etc.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator(ICD), the electromagnetic wave of TCU might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before TCU use.

##### Precaution at intelligent key system operation

###### **WARNING:**

- If a technician uses implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), avoid the device implanted part from approaching within approximately 220 mm (8.66 in) from interior/exterior antenna.
- The electromagnetic wave of intelligent key might affect the function of the implantable cardiac pacemaker or the implantable cardioverter defibrillator (ICD), at door operation, at each request switch operation, or at engine starting.
- If a technician uses other medical electric devices than implantable cardiac pacemaker or implantable cardioverter defibrillator (ICD), the electromagnetic wave of intelligent key might affect the function of the device. The possible effects on the devices must be checked with the device manufacturer before intelligent key use.

#### Point to Be Checked Before Starting Maintenance Work

INFOID:000000007079498

The high voltage system may starts automatically. It is required to check that the timer air conditioner and timer charge (during EVSE connection) are not set before starting maintenance work.

###### **NOTE:**

If the timer air conditioner or timer charge (during EVSE connection) is set, the high voltage system starts automatically even when the power switch is in OFF state.

#### Precaution for Removing 12V Battery

INFOID:0000000070727617

When removing the 12V battery, turn ON/OFF the power switch and check that the charging status indicator does not blink. The 12V battery must be removed within one hour after checking the indicator lamp.

###### **NOTE:**

- The automatic 12V battery charge control may start even when the power switch is in OFF state.

# PRECAUTIONS

## < PRECAUTION >

- The automatic 12V battery charge control does not start within approximately one hour when the power switch is turned ON/OFF.

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007027500

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the power switch ON, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the power switch OFF, disconnect the 12V battery, and wait at least 3 minutes before performing any service.

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000006922547



No.	Part	Description
1.	IPDM E/R	Controls the integrated relay according to the request signal from BCM (via CAN communication). Refer to <a href="#">PCS-5, "Component Parts Location"</a> for detailed installation location.
2.	BCM	<ul style="list-style-type: none"> <li>Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamps ON/OFF.</li> <li>Operates the interior room lamp battery saver depending on the vehicle condition to cut the interior room lamp power supply.</li> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then it transmits position light request signal to IPDM E/R and combination meter (with CAN communication).</li> </ul> Refer to <a href="#">BCS-5, "BODY CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.
3.	Door lock and unlock switch	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
4.	Front door request switch (driver side)	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
5.	Front door lock assembly (driver side) ( door key cylinder switch)	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
6.	Door switch	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
7.	Back door switch	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
8.	Luggage room lamp	Refer to <a href="#">INL-6, "Bulb Specifications"</a> .
9.	Room lamp	Refer to <a href="#">INL-6, "Bulb Specifications"</a> .
10.	Remote keyless entry receiver	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
11.	Optical sensor	Refer to <a href="#">EXL-6, "Component Parts Location"</a> .
12.	Map lamp	Refer to <a href="#">INL-6, "Bulb Specifications"</a> .
13.	Combination meter	Receives the dimmer signal from BCM (via CAN communication) Refer to <a href="#">MWI-6, "METER SYSTEM : Component Parts Location"</a> for detailed installation location.
14.	Power switch	Refer to <a href="#">DLK-12, "Component Parts Location"</a> .
15.	AV control unit	Receives the dimmer signal from BCM. Refer to <a href="#">AV-10, "Component Parts Location"</a> for detailed installation location.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## Bulb Specifications

INFOID:000000006998505

Item	Type	Wattage (W)
Map lamp	Wedge	8
Glove box lamp	—	1.4
Room lamp	—	8
Luggege room lamp	—	8

# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### INTERIOR ROOM LAMP CONTROL SYSTEM

#### INTERIOR ROOM LAMP CONTROL SYSTEM : System Description

INFOID:0000000006922549

#### SYSTEM DIAGRAM




#### OUTLINE

- Interior room lamps\* are controlled by interior room lamp timer control function of BCM.
- \*: Map lamp and room lamp (when map lamp switch and room lamp switch are in DOOR position).
- Luggage room lamp is controlled by luggage room lamp control function of BCM.
- Power switch illumination is controlled by the power switch illumination control function of BCM.

#### INTERIOR ROOM LAMP TIMER CONTROL

##### Interior Room Lamp Timer Basic Operation



#### NOTE:

- A: Sets the interior room lamp gradual brightening and dimming time.  
 B: Gradually dims from 100% to 0% and gradually brightens 0% to 100% in 1 second.

# SYSTEM

## < SYSTEM DESCRIPTION >

---

- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room lamp timer.
- BCM judges the vehicle condition with the following items. It activates the interior room timer.
  - Power switch status
  - Door switch signal (except back door)
  - Door lock/unlock signal (Remote keyless entry receiver, each door request switch, door lock/unlock switch, door key cylinder switch)

### NOTE:

Each function of interior room lamp timer can be set by CONSULT. Refer to [INL-18, "INT LAMP : CONSULT Function \(BCM - INT LAMP\)"](#).

### Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens except back door.
- BCM activates the interior room lamp timer in any of the following conditions to turn the interior room lamp ON for a period of time.
  - Status of all doors except back door changes from open to close
  - Power switch is turned ON → OFF
  - Door unlock signal is detected when all doors close except back door with power switch OFF

### NOTE:

The timer restarts if new condition is input during the timer operating time.

### Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turn the interior room lamp OFF.

- The timer operating time is expired
- Power switch is turned OFF → ACC/ON
- Door lock signal is detected with all doors close except back door.

## LUGGAGE ROOM LAMP CONTROL

BCM turns luggage room lamp ON when the following condition is detected.

- Back door switch is ON

BCM turns luggage room lamp OFF when the following condition is detected.

- Back door switch is OFF

## POWER SWITCH ILLUMINATION CONTROL

### Power Switch Illumination Basic Operation

BCM provides the power supply to turn the power switch illumination ON.

### Power Switch Illumination ON Operation

BCM turns the power switch illumination ON in the following conditions.

- Power switch ON
- Any of the following conditions with power switch OFF/ACC
  - Traction motor start permission is entered
  - Driver side door is LOCK → UNLOCK
  - Driver side door is open

### Power Switch Illumination OFF Operation

BCM turns the power switch illumination OFF in any of the following conditions.

- The push-button power switch illumination ON conditions are not satisfied.
- Any of the following conditions with power switch OFF.
  - The power switch illumination ON conditions do not change (15 seconds after the power switch OFF)
  - Driver side door is UNLOCK → LOCK




# SYSTEM

< SYSTEM DESCRIPTION >

## INTERIOR ROOM LAMP CONTROL SYSTEM : Schematic

INFOID:000000006922550



## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000006922551

### SYSTEM DIAGRAM



### OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the 12V battery from over-discharging if the driver neglects turning OFF the lamps.

#### Applicable lamps

- Map lamp
- Room lamp
- Luggage room lamp

### INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the power switch is turned to other position than ON, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restarts the timer when any of the following signals changes while operating the timer.
  - Power switch status
  - Door switch signal (ALL)
  - Door lock/unlock signal (remote keyless entry receiver, each door request switch, door lock and unlock switch, door key cylinder switch)
- BCM provides the interior room lamp power supply continuously when the power switch position is ON.

#### NOTE:


Each function of interior room lamp battery saver can be set by CONSULT. Refer to [INL-19, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

# SYSTEM

< SYSTEM DESCRIPTION >

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Schematic

INFOID:000000006922552



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

## ILLUMINATION CONTROL SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

## ILLUMINATION CONTROL SYSTEM : System Description

INFOID:00000006922553

### SYSTEM DIAGRAM



### OUTLINE

Each illumination lamp is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-31, "METER ILLUMINATION CONTROL : System Description"](#).)

### ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition.

Tail lamp ON condition


- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).

# SYSTEM

< SYSTEM DESCRIPTION >

## ILLUMINATION CONTROL SYSTEM : Schematic

INFOID:000000006922554



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

## AUTO LIGHT ADJUSTMENT SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

## AUTO LIGHT ADJUSTMENT SYSTEM : System Description

INFOID:000000006934405

### SYSTEM DIAGRAM



### OUTLINE

Auto light adjustment system is controlled by each function of BCM, combination meter and AV control unit

Control by BCM

- Auto light system
- Auto light adjustment system

### AUTO LIGHT ADJUSTMENT SYSTEM

Description

- BCM supplies voltage to the optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges dimming/brightening of combination meter and display according to brightness outside the vehicle, when power switch is ON.
- BCM transmits dimmer signal to combination meter via CAN communication, according to auto light adjustment conditions. Dimmer signal is also transmitted to AV control unit.

#### NOTE:


As to dimming/brightening timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [EXL-25, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

# SYSTEM

< SYSTEM DESCRIPTION >

## AUTO LIGHT ADJUSTMENT SYSTEM : Schematic

INFOID:000000006935132



JMLIA1927GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000007037071

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>• Read and save the vehicle specification.</li> <li>• Write the vehicle specification when replacing BCM.</li> </ul>

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
Intelligent Key system	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
NVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	
Theft warning alarm	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
TPMS	AIR PRESSURE MONITOR	×	×	×

\*: This item is displayed, but not used.

#### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.



# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description		
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected		A
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected		
Vehicle Condition	SLEEP>LOCK	Power supply position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode [Power supply position is OFF (LOCK)]	B
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode [Power supply position is OFF (OFF)]	C
	LOCK>ACC		While turning power supply position from OFF (LOCK) to ACC	
	ACC>ON		While turning power supply position from ACC to ON	D
	RUN>ACC		While turning power supply position from READY (RUN) to ACC (Except emergency stop operation)	
	CRANK>RUN		While turning power supply position from READY (CRANK) to READY (RUN)	E
	RUN>URGENT		While turning power supply position from READY (RUN) to ACC (Emergency stop operation)	
	ACC>OFF		While turning power supply position from ACC to OFF (OFF)	F
	OFF>LOCK		While turning power supply position from OFF (OFF) to OFF (LOCK)	G
	OFF>ACC		While turning power supply position from OFF (OFF) to ACC	
	ON>CRANK		While turning power supply position from ON to READY (CRANK)	H
	OFF>SLEEP		While turning BCM status from normal mode [Power supply position is OFF (OFF)] to low power consumption mode	
	LOCK>SLEEP		While turning BCM status from normal mode [Power supply position is OFF (LOCK)] to low power consumption mode	I
	LOCK		Power supply position is OFF (LOCK)	
	OFF		Power supply position is OFF (OFF)	J
	ACC		Power supply position is ACC	
	ON		Power supply position is ON	K
	ENGINE RUN		Power supply position is READY (RUN)	
CRANKING	Power supply position is READY (CRANK)			
IGN Counter	0 - 39	The number of times that power switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever power switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>		INL

### NOTE:

\*: Refer to the following for details of the power supply position.

- OFF (OFF, LOCK): Power switch OFF
- ACC: Power switch ACC
- ON: Power switch ON
- READY (CRANK): Shifting to vehicle condition READY (Transmitting the READY signal from BCM to VCM)
- READY (RUN): Vehicle condition READY

Power supply position shifts to "OFF (LOCK)" from "OFF (OFF)", when power switch is in the OFF position, shift position is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the power switch (push switch) is pushed at "OFF (LOCK)".

## INT LAMP


# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000006922556

### WORK SUPPORT



Service item	Setting item	Setting	
SET I/L D-UNLCK INTCON	On*	With the interior room lamp timer function	
	Off	Without the interior room lamp timer function	
ROOM LAMP TIMER SET	MODE 2	7.5 sec.	Sets the interior room lamp ON time. (Timer operating time)
	MODE 3*	15 sec.	
	MODE 4	30 sec.	
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual brightening time. <b>CAUTION:</b> Setting cannot be returned to setting at shipment if it is changed once.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
	Factory setting	Gradually brightens from 0% to 100% brightness in 1 second.	
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.	Sets the interior room lamp gradual dimming time. <b>CAUTION:</b> Setting cannot be returned to setting at shipment if it is changed once.
	MODE 2	1 sec.	
	MODE 3	2 sec.	
	MODE 4	3 sec.	
	MODE 5	0 sec.	
	Factory setting	Gradually dims from 100% to 0% in 1 second.	
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.	
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.	

\*: Factory setting

### DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description	
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.	A
REQ SW-RL [On/Off]		B
PUSH SW [On/Off]	The switch status input from power switch	C
UNLK SEN -DR [On/Off]	Driver door unlock status input unlock sensor	
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)	D
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)	E
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH	
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH	F
DOOR SW- BK [On/Off]	The switch status input from back door switch	G
CDL LOCK SW [On/Off]	Lock switch status input from door lock and unlock switch	
CDL UNLOCK SW [On/Off]	Unlock switch status input from door lock and unlock switch	H
KEY CYL LK-SW [On/Off]	Lock switch status received from door key cylinder switch	I
KEY CYL UN-SW [On/Off]	Unlock switch status received from door key cylinder switch	
TRNK/HAT MNTR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.	J
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver	
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver	K

## ACTIVE TEST

Test item	Operation	Description	
INT LAMP	On	Outputs the interior room lamp control signal to turn the interior room lamps ON. [Map lamp, room lamp (when applicable lamps switch is in DOOR position.)]	M
	Off	Stops the interior room lamp control signal to turn the interior room lamps OFF.	
STEP LAMP TEST	On	<b>NOTE:</b> The item is indicated, but can not tested	N
	Off		

## BATTERY SAVER

### BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000006922557

## WORK SUPPORT

Service item	Setting item	Setting	
ROOM LAMP TIMER SET	MODE 1	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	
	MODE 3*	15 min.	

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function

\*:Factory setting

## DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from front request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	The switch status input from power switch
UNLK SEN-DR [On/Off]	Driver door unlock status input unlock sensor
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
DOOR SW- BK [On/Off]	The switch status input from back door switch
CDL LOCK SW [On/Off]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status input from door lock and unlock switch
TRNK/HAT MNTR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored
KEY CYL LK-SW [On/Off]	Lock switch status received from door key cylinder switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from door key cylinder switch
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

## ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamps OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamps ON.*

\*: Each lamp switch is in ON position.

# BCM

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000006922558

ECU	Reference
BCM	<a href="#">BCS-32. "Reference Value"</a>
	<a href="#">BCS-52. "Fail-safe"</a>
	<a href="#">BCS-53. "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-54. "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:000000006922559




2010/10/29

JCLWA4753GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16



Terminal No.	Color of Wire	Signal Name [Specification]
6	R	-
7	BR	-
10	W	-
11	LG	-
12	P	-
13	V	-
14	Y	-
15	W	-
16	L	-

Connector No.	B10
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHAB-SA

41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			



Terminal No.	Color of Wire	Signal Name [Specification]
43	Y	BACK DOOR SW
44	LG	REAR WIPER STOP POSITION
45	BR	PASSENGER DOOR SW
46	R	REAR RH DOOR SW
47	SB	DRIVER DOOR SW
48	W	REAR LH DOOR SW
49	L	LUGGAGE LAMP OUTPUT
51	P	BACK DOOR REQ SW
53	GR	BK DOOR OPEN OUTPUT
54	P	REAR WIPER OUTPUT
55	GR	PASS. RR DOOR UNLK OUTPUT

Connector No.	B11
Connector Name	LUGGAGE ROOM LAMP
Connector Type	NS30FW-CS

1	2
---	---



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	L	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10

1	2	3	4	5	6								
7	8	9	10	11	12	13	14	15	16	17	18	19	20



Terminal No.	Color of Wire	Signal Name [Specification]
5	P	-
6	R	-
7	P	-
9	P	-
10	Y	-
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
17	SHIELD	-
18	B	-
20	GR	-

Connector No.	B48
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH64FW-NH

1	2	3
---	---	---



Terminal No.	Color of Wire	Signal Name [Specification]
3	SB	-

Connector No.	B49
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	TH64FW-NH

1	2	3
---	---	---



Terminal No.	Color of Wire	Signal Name [Specification]
3	BR	-

Connector No.	B53
Connector Name	REAR DOOR SWITCH RH
Connector Type	TH64FW-NH

1	2	3
---	---	---



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-

Connector No.	B71
Connector Name	REAR DOOR SWITCH LH
Connector Type	TH64FW-NH

1	2	3
---	---	---



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	R	-
3	Y	-
4	V	-
10	BR	-
11	Y	-
12	B	-
13	W	-
14	SB	-
15	R	-
24	Y	-
25	BR	-
26	SHIELD	-
36	B	-
37	P	-
38	Y	-
39	LG	-
44	V	-
45	W	-
46	RG	-



# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP

Connector No.	D10
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS12FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	BR	-
3	B	-
6	Y	-
7	R	-
8	R	-
11	SB	-
12	W	-

Connector No.	D15
Connector Name	FRONT DOOR REQUEST SWITCH (PASSENGER SIDE)
Connector Type	RH02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	B	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	TH40PT-CS15




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	V	-
3	SB	-
4	V	-
7	P	-
8	BR	-
9	LG	-
10	Y	-
11	W	-
12	SB	-
13	B	-
14	V	-
15	R	-
24	R	-
25	G	-
26	SHIELD	-
37	LG	-
38	V	-
39	P	-
40	Y	-
41	GR	-
42	Y	-
43	L	-
44	L	-
45	LG	-
46	BR	-
47	G	-
48	L	-
49	R	-
50	BR	-

Connector No.	D34
Connector Name	FRONT DOOR REQUEST SWITCH (DRIVER SIDE)
Connector Type	RH02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	D35
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	MS16FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	SB	-
3	Y	-
4	W	-
5	Y	-
6	Y	-
7	LG	-
8	BR	-
9	P	-
10	V	-
12	R	-
14	G	-
15	BR	-
16	W	-

Connector No.	D38
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	EO8FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	SB	-
3	G	-
4	B	-
5	L	-
6	R	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10FW-CS10



Terminal No.	Color of Wire	Signal Name [Specification]
3	W	-
5	R	-
6	R	-
7	P	-
9	P	-
10	P	-
11	B	-
12	W	-
13	R	-
14	L	-
15	LG	-
17	SHIELD	-
18	Y	-
20	GR	-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


## INTERIOR ROOM LAMP

Connector No.	D73
Connector Name	WIRE TO WIRE
Connector Type	NH10WV-CS10



Terminal No.	Color of Wire	Signal Name [Specification]
5	W	
6	R	
7	P	
8	P	
9	P	
10	P	
11	W	
12	W	
13	R	
14	L	
15	LG	
17	SHIELD	
18	Y	
20	GR	

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



Terminal No.	Color of Wire	Signal Name [Specification]
5	P	
6	R	
7	P	
9	P	
10	P	
12	W	
13	R	
14	L	
15	LG	
17	SHIELD	


18	B
20	GR

Connector No.	D111
Connector Name	BACK DOOR OPENER SWITCH ASSEMBLY
Connector Type	TH20MGY-RC



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
2	B	
3	B	
4	P	

Connector No.	D112
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Type	NS04FY-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	B	
3	P	
4	B	

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH20MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	
2	R	
3	GR	
4	LG	
6	W	
7	V	
8	P	
9	G	
10	R	
11	O	
12	W	
13	B	
14	Y	
15	BR	
16	LG	
17	L	
19	G	
20	V	
21	P	
22	LG	
23	GR	
24	L	
25	B	
26	SB	
27	B	
29	BR	
30	W	
31	V	
32	LG	
33	O	
34	L	
35	BR	
38	SB	
39	GR	
40	Y	
41	R	
42	W	
43	SB	


44	GR	
45	G	
46	P	
47	LG	
48	V	
49	G	
50	L	
51	W	
54	P	
55	O	
56	Y	
57	P	
58	LG	
60	LG	
61	GR	
62	BR	
64	R	
65	Y	
66	G	
67	V	
68	W	
69	SB	
71	Y	
72	L	
73	R	
74	L	
75	V	
76	P	
80	O	
81	L	
82	SB	
83	G	
84	BR	
85	LG	
86	GR	
88	B	
89	W	
90	SHIELD	
91	Y	
92	BR	
93	W	
94	R	
95	V	
96	P	
97	G	
98	SB	
99	O	

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


## INTERIOR ROOM LAMP

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
3	LG	-
4	B	-
5	B	-
6	L	-
7	GR	-
8	G	-
11	SB	-
12	G	-
13	L	-
14	P	-
16	Y	-


Connector No.	M10
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	G	-
3	LG	-
4	V	-
10	BR	-
11	Y	-
12	B	-
13	W	-
14	SB	-
15	I	-
24	Y	-

25	BR	-
26	SHIELD	-
36	B	-
37	P	-
38	Y	-
39	LG	-
44	L	-
45	LG	-
46	BR	-


Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	G	-
4	V	-
7	BR	-
8	Y	-
9	LG	-
10	Y	-
11	W	-
12	SB	-
13	B	-
14	L	-
15	R	-
24	R	-
25	G	-
26	SHIELD	-
37	LG	-
38	V	-
39	P	-
40	Y	-
41	B	-
42	P	-
43	L	-
44	L	-
45	LG	-
46	BR	-
47	W	-

48	GR	-
49	R	-
50	BR	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6	V	-
7	P	-
10	W	-
11	LG	-
12	GR	-
13	W	-
14	Y	-
15	LG	-
16	L	-


Connector No.	M23
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	SHIELD	-
5	B	-
6	BR	-
7	P	-
8	Y	-
9	R	-

10	B	-
11	O	-

Connector No.	M25
Connector Name	POWER SWITCH
Connector Type	TK08FBR



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	-
3	B	-
4	B	-
5	W	-
6	B	-
7	V	-
8	SB	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

JCLWA4758GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP

Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
2	L	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	BR	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	V	COMBI SW INPUT 1
7	GR	KEY CYL UNLK SW
8	R	KEY CYL LOCK SW
9	BR	STOP LAMP SW 1
12	Y	DOOR LK & UNLK SW LOCK
13	BR	DOOR LK & UNLK SW UNLOCK
14	G	OPTICAL SENS
15	W	REAR WINDOW DEF SW
16	R	DIMMER
17	Y	OPTICAL SENS FWR SPLY
18	V	SENS/RECEIV GND
21	P	NATS ANTENNA AMP
23	R	SECURITY IND LAMP CONT
25	LG	NATS ANTENNA AMP
29	P	HAZARD SW
30	L	BK DOOR OPENER SW
31	W	DR DOOR UNLK SENS
32	LG	COMBI SW OUTPUT 5
33	V	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R	COMBI SW OUTPUT 2
36	P	COMBI SW OUTPUT 1
37	W	P POSITION
38	SB	RECEIVER COMM
39	L	CAN-H
40	P	CAN-L

Connector No.	M69
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FE409FW-FHA8-SA



56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
56	P	INT ROOM LAMP PWR SPLY
57	P	BAT FUSE
59	LG	PASS DOOR UNLK OUTPUT
60	V	TURN SIG LH OUTPUT
61	W	TURN SIG RH OUTPUT
63	BR	INT ROOM LAMP CONT
65	V	ALL DOOR LOCK OUTPUT
66	G	DR DOOR UNLK OUTPUT
67	B	GND
68	L	PW FWR SPLY (ON)
69	P	PW FWR SPLY (BAT)
70	Y	BAT (F/L)

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
75	LG	DR DOOR REQ SW
76	SB	POWER SW (PUSH SW)
78	P	DRIVER DOOR ANT+
79	V	DRIVER DOOR ANT-
80	LG	PASS DOOR ANT+
81	Y	PASS DOOR ANT-
82	W	REAR BMPR ANT+
83	B	REAR BMPR ANT-
84	BR	ROOM ANT 1+
85	Y	ROOM ANT 1-

86	G	ROOM ANT 2+
87	R	ROOM ANT 2-
88	V	LUGGAGE ROOM ANT+
89	LG	LUGGAGE ROOM ANT-
90	W	POWER SYLLE PWR
91	V	ACC 7 ON IND
92	B	POWER SW ILL GND CONT
93	GR	I-KEY WARN BUZZER
96	BR	ACC RELAY CONT
97	W	READY
99	G	IGN RELAY (PDM E/R CONT
99	R	IGN RELAY (F/B CONT
100	P	PASS DOOR REQ SW
102	R	P/N POSITION
104	LG	WAKE-UP
105	P	STOP LAMP SW 2

Connector No.	M75
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TH40FW-NH



1	2	3	4
---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	GND
2	SB	SIGNAL
4	V	POWER

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP


Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80FN-CS1.6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	V	-
3	GR	-
4	LG	-
5	W	-
6	W	-
7	V	-
8	P	-
9	SB	-
10	L	-
11	LG	-
12	W	-
13	R	-
14	Y	-
15	R	-
16	GR	-
17	BR	-
18	G	-
19	G	-
20	G	-
21	P	-
22	LG	-
23	GR	-
24	L	-
25	V	-
26	W	-
27	L	-
28	V	-
30	W	-
31	SB	-
32	LG	-
33	V	-
34	L	-
35	SB	-
38	LG	-
39	GR	-
40	Y	-
41	R	-
42	W	-
43	SB	-

44	GR	-
45	P	-
46	R	-
47	W	-
48	L	-
49	G	-
50	L	-
51	L	-
54	W	-
55	G	-
56	BR	-
57	P	-
58	R	-
60	Y	-
61	GR	-
62	SB	-
64	G	-
65	V	-
66	P	-
67	Y	-
68	P	-
69	BR	-
71	Y	-
72	L	-
73	G	-
74	L	-
75	V	-
76	R	-
80	W	-
81	L	-
82	SB	-
83	R	-
84	BR	-
85	R	-
86	GR	-
88	R	-
89	W	-
90	SHIELD	-
91	Y	-
92	BR	-
93	W	-
94	P	-
95	V	-
96	P	-
97	G	-
98	R	-
99	LG	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Type	TH16FN-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	SHIELD	-
5	B	-
6	R	-
7	Y	-
8	B/Y	-
9	V	-
10	G	-
11	B/R	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK6BFGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-
4	B	-
5	R	-
6	Y	-

Connector No.	R5
Connector Name	ROOM LAMP
Connector Type	TE03FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	Y	-
3	B	-

JCLWA4760GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL


# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

### Wiring Diagram


INFOID:000000006922560



\*: This connector is not shown in "Harness Layout".

# ILLUMINATION

< WIRING DIAGRAM >




JCLWA4762GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# ILLUMINATION

< WIRING DIAGRAM >





# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6	R	-
7	BR	-
10	W	-
11	LG	-
12	P	-
13	V	-
14	Y	-
15	W	-
16	L	-

Connector No.	B20
Connector Name	PARKING BRAKE SWITCH
Connector Type	TK08FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	SB	-
3	B	-
4	V	-
5	P	-
6	R	-
7	W	-
8	Y	-

Connector No.	D22
Connector Name	WIRE TO WIRE
Connector Type	TH4GPT-CS15



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	V	-
3	SB	-
4	V	-
7	P	-
8	BR	-
9	LG	-
10	Y	-
11	W	-
12	SB	-
13	B	-
14	V	-
15	R	-
24	R	-
25	G	-
26	SHIELD	-
37	LG	-
38	V	-
39	P	-
40	Y	-
41	GR	-
42	Y	-
43	L	-
44	L	-
45	LG	-
46	BR	-
47	G	-
48	L	-
49	R	-
50	BR	-

Connector No.	D23
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH
Connector Type	TK18FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
7	L	-
8	GR	-
9	V	-
10	BG	-
12	BR	-
13	LG	-
14	Y	-
15	L	-
16	W	-

Connector No.	E11
Connector Name	SPOLE R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	M08FE-LC



Terminal No.	Color of Wire	Signal Name [Specification]
9	B	-
14	R	-

Connector No.	E12
Connector Name	SPOLE R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS30FER-OS



Terminal No.	Color of Wire	Signal Name [Specification]
18	B/W	-
19	W	-
20	V	-

Connector No.	E13
Connector Name	SPOLE R INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
25	R	-
26	P	-
27	L	-
34	W	-

JCLWA4764GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL



# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	M17
Connector Name	HEADLAMP AIMING SWITCH
Connector Type	A04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-
3	W	-
4	B	-

Connector No.	M18
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
6	V	-
7	P	-
10	W	-
11	LG	-
12	GR	-
13	W	-
14	Y	-
15	LG	-
16	L	-

Connector No.	M20
Connector Name	DIODE
Connector Type	Z4335 C9800



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	B	-

Connector No.	M23
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	SHIELD	-
5	B	-
6	BR	-
7	P	-
8	Y	-
9	R	-
10	B	-
11	O	-

Connector No.	M25
Connector Name	POWER SWITCH
Connector Type	TK08FBR




Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	B	-
5	W	-
6	B	-
7	V	-
8	SB	-

Connector No.	M26
Connector Name	METER CONTROL SWITCH
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-
3	R	-
5	V	-
6	BR	-
11	BR	-
12	W	-

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TH18FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	WASHER (RF)
2	GR	OUTPUT 4
3	R	WASHER (FR)
4	W	IGN
5	BR	OUTPUT 3
6	B	GRD
7	W	OUTPUT 3
8	L	OUTPUT 5
9	R	INPUT 2
10	Y	INPUT 1
11	P	INPUT 4
12	V	OUTPUT 1
13	LG	INPUT 5
14	G	OUTPUT 2

Connector No.	M28
Connector Name	VDC OFF SWITCH
Connector Type	TH08FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-
3	W	-
4	B	-

JCLWA4766GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	M29
Connector Name	GLOVE BOX LAMP
Connector Type	AG2FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	B	

Connector No.	M32
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FY-EX-1V



Terminal No.	Color of Wire	Signal Name [Specification]
23	R	
28	Y	
28	Y/V	
30	GR	

Connector No.	M33
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY-1V



Terminal No.	Color of Wire	Signal Name [Specification]
--------------	---------------	-----------------------------

24	BR	-
25	LG	-
26	B	-
31	Y	-
32	SB	-
33	SHIELD	-
34	G	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	BATTERY POWER SUPPLY
2	R	BATTERY POWER SUPPLY (FOR UPPER METER)
3	GR	POWER SWITCH SUPPLY
4	BR	POWER SWITCH SUPPLY (FOR UPPER METER)
5	B	GROUND
6	B	GROUND
7	V	ELECTRIC SHIF WARNING SIGNAL
9	G	PLUG IN SIGNAL
10	L	COMMUNICATION SIGNAL (METER → VSP)
11	P	COMMUNICATION SIGNAL (VSP → METER)
12	V	METER CONTROL SWITCH GROUND
13	LG	ENTER SWITCH SIGNAL
14	W	SELECT SWITCH SIGNAL
15	BR	TRIP RESET SWITCH SIGNAL
16	BR	ILLUMINATION CONTROL SWITCH SIGNAL
17	V	ILLUMINATION CONTROL SIGNAL (FOR UPPER METER)
18	P	CAN-L
19	L	CAN-H
20	V	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)
22	GR	GROUND (FOR UPPER METER)
24	BR	ELECTRIC PARKING BRAKE CONTROL MODULE MAKEUP SIGNAL
25	SB	BRAKE FLUID LEVEL SWITCH SIGNAL
26	B	ILLUMINATION CONTROL SIGNAL
27	R	AIR BAG SIGNAL
28	R	SECURITY SIGNAL
30	GR	VEHICLE SPEED SIGNAL (8-PULSE)
32	W	COMMUNICATION SIGNAL (METER → UPPER)
33	LG	COMMUNICATION SIGNAL (UPPER → METER)
34	L	PLUG IN INDICATOR LAMP SIGNAL

38	V	LED HEADLAMP (RH) WARNING SIGNAL
39	LG	LED HEADLAMP (LH) WARNING SIGNAL
40	Y	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	P	
3	W	
4	B	

Connector No.	M46
Connector Name	APPROACHING VEHICLE SOUND FOR REDESTRANS (VSP) OFF SWITCH
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
2	LG	
3	GR	
4	B	
5	W	
6	B	
7	G	

Connector No.	M60
Connector Name	A/C AUTO AMP
Connector Type	TH40FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	REC
2	R	MODE4
3	P	MODE3
4	Y	MODE2
5	V	MODE1
6	BR	MX4
7	SB	MX3
8	LG	MX2
9	L	MX1
10	B	GND
12	GR	BLOWER PWM
13	V	W/PUMP PWM
14	L	COMP TX
15	W	RR DEF SW O/P
17	R	W/PUMP F/B
18	W	COMP RX
19	W	COMP RX
20	B	LIGHT+
21	G	FRESH
27	W	5V OUT
28	L	EY CAN-H
29	G	EY CAN-L
30	R	SEAS GND
31	W	BATT
32	Y	IGN I
33	LG	INCAR SENS
34	G	INTAKE SENS
35	P	SUN SENS
36	GR	AMB SENS
37	BR	WATER SENS
38	SB	INT F/B
40	SB	PTCLIN

# ILLUMINATION

< WIRING DIAGRAM >


## ILLUMINATION

Connector No.	M51
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH08FV-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	LG	-
4	R	-
5	B	-
6	SB	-
8	W	-

Connector No.	M55
Connector Name	SELECTOR INDICATOR
Connector Type	TH08FV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	B	-
4	B	-
5	W	-
7	L	-
8	R	-

Connector No.	M65
Connector Name	IMMEDIATE CHARGING SWITCH
Connector Type	TH08FY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	SB	-
3	W	ILLUMINATION +
4	B	ILLUMINATION -

Connector No.	M68
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	L	COMBI SW INPUT 5
3	GR	COMBI SW INPUT 4
4	BR	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	V	COMBI SW INPUT 1
7	GR	KEY CYL UNLK SW
8	R	KEY CYL LOCK SW
9	BR	STOP LAMP SW 1
12	Y	DOOR LK & UNLK SW LOCK
13	BR	DOOR LK & UNLK SW UNLOCK
14	G	OPTICAL SENS
15	W	REAR WINDOW DEF SW
16	R	DIMMER
17	Y	OPTICAL SENS PWR SPLY
18	V	SENS/RECEIV GND
21	P	NATS ANTENNA AMP
23	R	SECURITY IND LAMP CONT
25	LG	NATS ANTENNA AMP


29	P	HAZARD SW
30	L	BK DOOR ORENER SW
31	W	DR DOOR UNLK SENS
32	LG	COMBI SW OUTPUT 5
33	Y	COMBI SW OUTPUT 4
34	W	COMBI SW OUTPUT 3
35	R	COMBI SW OUTPUT 2
36	P	COMBI SW OUTPUT 1
37	W	P POSITION
38	SB	RECEIVER COMM
39	L	CAN-H
40	P	CAN-L

Connector No.	M69
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08FW-FH4B-SA



Terminal No.	Color of Wire	Signal Name [Specification]
56	P	INT ROOM LAMP PWR SPLY
57	P	BAT (FUSE)
59	LG	PASS DOOR UNLK OUTPUT
60	V	TURN SIG LH OUTPUT
61	W	TURN SIG RH OUTPUT
63	BR	INT ROOM LAMP CONT
65	V	ALL DOOR LOCK CONT
66	G	DR DOOR LOCK OUTPUT
67	B	INT ROOM LAMP GND
68	L	PW PWR SPLY (GN)
69	P	PW PWR SPLY (BAT)
70	Y	BAT (F/L)

Connector No.	M70
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FP-NH



Terminal No.	Color of Wire	Signal Name [Specification]
75	LG	DR DOOR REQ SW
76	SB	POWER SW (PUSH SW)
78	P	DRIVER DOOR ANT+
79	V	DRIVER DOOR ANT-
80	LG	PASS DOOR ANT+
81	V	PASS DOOR ANT-
82	W	REAR EMPR ANT+
83	B	REAR EMPR ANT-
84	BR	ROOM ANT +
85	Y	ROOM ANT -
86	G	ROOM ANT 2+
87	R	ROOM ANT 2-
88	V	LUGGAGE ROOM ANT+
89	LG	LUGGAGE ROOM ANT-
90	W	POWER SW ILL PWR
91	V	ACC / ON IND
92	B	POWER SW ILL GND CONT
93	GR	I-KEY WARN BUZZER
96	BR	ACC RELAY CONT
97	W	READY
98	G	IGN RELAY (PDM / E / R) CONT
99	R	IGN RELAY (F / B) CONT
100	P	PASS DOOR REQ SW
102	R	P/N POSITION
104	LG	WAKE-UP
105	P	STOP LAMP SW 2

A B C D E F G H I J K L M N O P

INL

JCLWA4768GB

# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION


Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	THB07V-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	V	-
3	GR	-
4	LG	-
6	W	-
7	V	-
8	P	-
9	SB	-
10	L	-
11	LG	-
12	W	-
13	R	-
14	Y	-
15	R	-
16	GR	-
17	BR	-
19	G	-
20	G	-
21	P	-
22	LG	-
23	GR	-
24	L	-
25	V	-
26	W	-
27	L	-
29	V	-
30	W	-
31	SB	-
32	LG	-
33	V	-
34	L	-
35	SB	-
38	LG	-
39	GR	-
40	Y	-
41	R	-
42	W	-
43	SB	-

44	GR	-
45	P	-
46	R	-
47	W	-
48	G	-
49	L	-
50	L	-
51	L	-
54	W	-
55	G	-
56	BR	-
57	P	-
58	R	-
60	Y	-
61	GR	-
62	SB	-
64	G	-
65	V	-
66	P	-
67	Y	-
68	P	-
69	BR	-
71	Y	-
72	L	-
73	G	-
74	L	-
75	V	-
76	R	-
80	W	-
81	L	-
82	SB	-
83	R	-
84	BR	-
85	R	-
86	GR	-
88	R	-
89	W	-
90	SHIELD	-
91	Y	-
92	BR	-
93	W	-
94	P	-
95	V	-
96	P	-
97	G	-
98	R	-
99	LG	-

Connector No.	M83
Connector Name	AV CONTROL UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
2	L	SOUND SIGNAL FRONT LH (+)
3	P	SOUND SIGNAL FRONT LH (-)
4	V	SOUND SIGNAL REAR LH (+)
5	R	SOUND SIGNAL REAR LH (-)
6	BR	STEERING SWITCH SIGNAL A
7	L	ACC POWER SUPPLY
8	B	GROUND
9	W	ILLUMINATION SIGNAL
11	G	SOUND SIGNAL FRONT RH (+)
12	R	SOUND SIGNAL FRONT RH (-)
13	LG	SOUND SIGNAL REAR RH (+)
14	GR	SOUND SIGNAL REAR RH (-)
15	SHIELD	STEERING SWITCH SIGNAL GROUND
16	Y	STEERING SWITCH SIGNAL B
19	BR	BATTERY POWER SUPPLY

Connector No.	M84
Connector Name	AV CONTROL UNIT
Connector Type	TH10FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
21	LG	AV COMM (L)
22	SB	AV COMM (H)
23	LG	AV COMM (L)
24	SB	AV COMM (H)
25	P	CAN-L
26	L	CAN-H
28	GR	VEHICLE SPEED SIGNAL (8-PULSE)

29	BR	PARKING BRAKE SIGNAL
30	G	REVERSE SIGNAL
31	V	POWER SWITCH ON SIGNAL
32	R	DIMMER SIGNAL
46	L	MICROPHONE SIGNAL
47	Y	MICROPHONE VCC
48	SHIELD	MICROPHONE SHIELD
49	R	AUX SOUND SIGNAL LH (+)
50	W	AUX SOUND SIGNAL RH (+)
51	B	AUX SOUND SIGNAL (-)
52	SHIELD	SHIELD
56	B	CAMERA CONNECTION RECOGNITION SIGNAL
57	R	CAMERA POWER SUPPLY
58	W	CAMERA GROUND
59	R	CAMERA IMAGE SIGNAL
60	SHIELD	SHIELD

Connector No.	IM802
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
13	R	-
14	W	-
15	L	-
16	B	-
17	BR	-
18	G	-
19	Y	-
20	Y	-


# ILLUMINATION

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## ILLUMINATION

Connector No.	R4
Connector Name	WIRE TO WIRE
Connector Type	TH16FN-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	P	-
2	L	-
3	SHIELD	-
4	B	-
5	B	-
6	R	-
7	Y	-
8	B/Y	-
9	V	-
10	G	-
11	B/R	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TK06FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	G	-
4	B	-
5	R	-
6	Y	-

JCLWA4770GB

**INL**

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006922561

#### OVERALL SEQUENCE



JMLIA1607GB

#### DETAILED FLOW

##### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.



# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. SYMPTOM CHECK

---

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

---

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT

---

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

---

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

---

Perform the self-diagnosis with CONSULT. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

---

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

#### Description

INFOID:000000006922562

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

#### Component Function Check

INFOID:000000006922563

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

##### Ⓟ CONSULT ACTIVE TEST

1. Turn power switch ON.
2. Turn each interior room lamp ON.
  - Map lamp
  - Room lamp
  - Luggage room lamp
3. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF.

**Off** : Interior room lamp OFF

**On** : Interior room lamp ON

Does each interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-42. "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000006922564

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

##### Ⓟ CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Disconnect the following connectors.
  - Map lamp
  - Room lamp
  - Luggage room lamp
3. Turn power switch ON.
4. Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
5. With operating the test item, check voltage between BCM harness connector and ground.

BCM		(-)	Test item	Voltage (Approx.)	
(+) Connector Terminal					
M69	56	Ground	BATTERY SAVER	Off	0 V
				On	12 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect the BCM connector.
3. Check continuity between BCM harness connector and each interior room lamp harness connector.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Each interior room lamp			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
M69	56	Map lamp	R4	6	Existed
		Room lamp	R5	2	
		Luggage room lamp	B11	1	

Is the inspection result normal?

YES >> Check for internal short circuit of each interior room lamp.

NO >> Repair or replace harnesses.

### 3. CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

1. Turn power switch OFF.
2. Disconnect the BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M69	56		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-76. "Removal and Installation"](#) .

NO >> Repair or replace harnesses.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:000000006922565

Controls each interior room lamp (ground side) by PWM signal.

#### NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

### Component Function Check

INFOID:000000006922566

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb
- Room lamp bulb

### 1. CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

#### CONSULT ACTIVE TEST

1. Switch the map lamp switch and room lamp switch to DOOR.
2. Turn power switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

On : Interior room lamp gradual brightening

Off : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-44, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006922567

### 1. CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

#### CONSULT ACTIVE TEST

1. Turn power switch OFF.
2. Remove all the bulbs of map lamp and room lamp.
3. Turn power switch ON.
4. Select "INT LAMP" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		INT LAMP	On	Existed
M69	63			Off	Not existed

Is the inspection result normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

### 2. CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector, map lamp and room lamp connectors.
3. Check continuity between BCM harness connector and map lamp harness connector.

BCM		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M69	63	R4	5	Existed

# INTERIOR ROOM LAMP CONTROL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between BCM harness connector and room lamp harness connector.

BCM		Room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M69	63	R5	1	Existed

Is the inspection result normal?

YES >> Replace map lamp or room lamp.

NO >> Repair or replace harnesses.

## 3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn power switch OFF.
2. Disconnect BCM connector, map lamp connector and room lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M69	63		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# LUGGAGE ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## LUGGAGE ROOM LAMP CIRCUIT

### Description

INFOID:000000006922568

Controls the luggage room lamp (ground side) to turn the luggage room lamp ON and OFF.

### Diagnosis Procedure

INFOID:000000006922569

#### CAUTION:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Luggage room lamp bulb

#### 1. CHECK LUGGAGE ROOM LAMP OUTPUT

1. Turn power switch OFF.
2. Remove the luggage room lamp bulb.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Condition		Continuity
Connector	Terminal		Back door	Open	Existed
B10	49			Closed	Not existed

Is the inspection result normal?

YES >> GO TO 2.

Fixed ON>>GO TO 3.

Fixed OFF>>Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).

#### 2. CHECK LUGGAGE ROOM LAMP OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and luggage room lamp harness connector.

BCM		Luggage room lamp		Continuity
Connector	Terminal	Connector	Terminal	
B10	49	B11	2	Existed

Is the inspection result normal?

YES >> Replace luggage room lamp.

NO >> Repair or replace harnesses.

#### 3. CHECK LUGGAGE ROOM LAMP SHORT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Not existed
B10	49		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).

NO >> Repair or replace harnesses.

# POWER SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:000000006922570

Provides the power supply and the ground to control the power switch illumination.

### Component Function Check

INFOID:000000006922571

### 1.CHECK POWER SWITCH ILLUMINATION OPERATION

#### CONSULT ACTIVE TEST

1. Turn the power switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the power switch illumination turns ON/OFF.

**On** : Power switch illumination ON

**Off** : Power switch illumination OFF

#### Does the power switch illumination turn ON/OFF?

- YES >> Power switch illumination circuit is normal.  
NO >> Refer to [INL-47, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000006922572

### 1.CHECK POWER SWITCH ILLUMINATION POWER SUPPLY OUTPUT

1. Turn power switch OFF.
2. Disconnect power switch connector.
3. Check voltage between power switch harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Connector	Terminal				
M25	5	Ground	Power switch illumination	ON	12 V
			OFF	0 V	

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

### 2.CHECK POWER SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the power switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and the power switch harness connector.

BCM		Power switch		Continuity
Connector	Terminal	Connector	Terminal	
M70	90	M25	5	Existed

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harnesses.

### 3.CHECK POWER SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M70	90		Not existed

## POWER SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

### 4. CHECK POWER SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the power switch OFF.
2. Check continuity between power switch harness connector and ground.

Power switch		Ground	Continuity
Connector	Terminal		
M25	6		Existed

Is the inspection result normal?

YES >> Replace power switch.

NO >> Repair or replace harnesses.



# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000006922573

**CAUTION:**

Perform the self-diagnosis with **CONSULT** before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none"> <li>• Map lamp</li> <li>• Room lamp</li> <li>• Luggage room lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Interior room lamp power supply circuit Refer to <a href="#">INL-42</a> .
<ul style="list-style-type: none"> <li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li> <li>• Interior room lamp does not turn OFF even though the door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each door switch</li> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-92</a> .
		Interior room lamp control circuit Refer to <a href="#">INL-44</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to <a href="#">INL-18</a> .
<ul style="list-style-type: none"> <li>• Luggage room lamp does not turn ON even though the back door is open.</li> <li>• Luggage room lamp does not turn OFF even though the back door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and back door switch</li> <li>• Harness between BCM and luggage room lamp</li> <li>• BCM</li> </ul>	Back door switch circuit Refer to <a href="#">DLK-92</a> .
		Luggage room lamp circuit Refer to <a href="#">INL-46</a> .
Power switch illumination does not illuminate.	<ul style="list-style-type: none"> <li>• Harness between BCM and power switch</li> <li>• BCM</li> </ul>	Power switch illumination circuit Refer to <a href="#">INL-47</a> .
Interior room lamp battery saver does not activate.	BCM	Replace BCM. Refer to <a href="#">BCS-76</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# MAP LAMP


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### MAP LAMP

Exploded View

INFOID:000000006922574




1. Map lamp plate

2. Headlining

3. Map lamp assembly

4. Bulb

5. Lens

 : Pawl

 : Metal clip

### Removal and Installation

INFOID:000000006922575

#### CAUTION:

- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.

# MAP LAMP

## < REMOVAL AND INSTALLATION >


- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.


### REMOVAL

1. Remove the lens.  
Disengage lens fixing pawls with a remover tool (A).


**CAUTION:**


Apply protective tape (B) on the parts to protect it from damage.

 : Pawl





2. Remove the lamp unit.
  1. Disengage lamp unit fixing pawls with a remover tool (A).

 : Pawl



2. Disconnect harness connector, and then remove lamp unit.
3. Remove the headlining. Refer to [INT-29. "Removal and Installation"](#).
4. Disengage map lamp assembly fixing pawls, and then remove map lamp assembly.

 : Pawl



### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000006922576

**CAUTION:**

- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.

## MAP LAMP

### < REMOVAL AND INSTALLATION >

---

- **Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.**

### MAP LAMP BULB

1. Remove the lens.
2. Remove the bulb.


# GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

## GLOVE BOX LAMP

Exploded View


INFOID:000000006922577



1. Glove box assembly

2. Lamp housing

3. Bulb & socket assembly

 : Pawl

 : Vehicle front

## Replacement

INFOID:000000006922578

### CAUTION:

- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.


### GLOVE BOX LAMP BULB

1. Remove glove box assembly. Refer to [IP-13, "Removal and Installation"](#).

## GLOVE BOX LAMP

### < REMOVAL AND INSTALLATION >

2. Rotate the bulb & socket assembly counterclockwise and unlock it and then remove bulb & socket assembly.




# ROOM LAMP

< REMOVAL AND INSTALLATION >




## ROOM LAMP

Exploded View

INFOID:000000006922579



- 1. Headlining
- 2. Room lamp assembly
- 3. Bulb
- 4. Lens

-  : Pawl
-  : Metal clip
-  : Vehicle front

### Removal and Installation

INFOID:000000006922580

#### CAUTION:

- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.

#### REMOVAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


# ROOM LAMP


## < REMOVAL AND INSTALLATION >

1. Disengage lens fixing pawls with a remover tool (A), and then remove lens.

**CAUTION:**

Apply protective tape (B) on the parts to protect it from damage

 : Pawl






2. Using a remover tool (A), press the metal clip (B), and then disengage.

3. Pull downward and then disengage the room lamp mounting pawls.

**CAUTION:**

Be careful not to disengage the pawls forcibly. Doing so may cause damage to the headliner by pawls that are fully engaged to the headliner.

 : Pawl  
 : Metal clip



4. Disconnect the harness connector, and then remove room lamp assembly.

## INSTALLATION

Install in the reverse order of removal.

## Replacement

INFOID:000000006922581

**CAUTION:**


- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.


## ROOM LAMP BULB

1. Disengage lens fixing pawls with a remover tool (A), and then remove lens.

**CAUTION:**

Apply protective tape (B) on the parts to protect it from damage.

 : Pawl



2. Remove the bulb.




# LUGGAGE ROOM LAMP

< REMOVAL AND INSTALLATION >

## LUGGAGE ROOM LAMP

Exploded View

INFOID:000000006922582



- 1. Shade
- 2. Bulb
- 3. Luggage room lamp assembly

- 4. Luggage side lower finisher

△ : Pawl

← : Vehicle front

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

**INL**

### Removal and Installation

INFOID:000000006922583

**CAUTION:**

Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.


#### REMOVAL

1. Disengage luggage room lamp fixing pawl with a remover tool (A).

**CAUTION:**

Apply protective tape (B) on the parts to protect it from damage.

△ : Pawl



M  
N  
O  
P

# LUGGAGE ROOM LAMP

## < REMOVAL AND INSTALLATION >

2. Disconnect harness connector, and then remove luggage room lamp.

### INSTALLATION

Install in the reverse order of removal.

### Replacement


INFOID:000000006922584


#### **CAUTION:**

- Disconnect the 12V battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

### LUGGAGE ROOM LAMP BULB

1. Remove luggage room lamp assembly. Refer to [INL-57, "Removal and Installation"](#).
2. Disengage shade fixing pawls with a remover tool (A), and then remove shade.

 : Pawl



3. Remove the bulb.

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

### Bulb Specifications

INFOID:000000006922585

Item	Type	Wattage (W)
Map lamp	Wedge	8
Glove box lamp	—	1.4
Room lamp	—	8
Luggege room lamp	—	8

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P