


CLUTCH PIPE AND HOSE

CLUTCH SYSTEM

7. Clutch Pipe and Hose

A: REMOVAL

- 1) Remove the air cleaner case and air intake duct. <Ref. to IN(H4SO)-6, REMOVAL, Air Cleaner Case.> and <Ref. to IN(H4SO)-7, REMOVAL, Air Intake Duct.>
- 2) Remove the intercooler. (TURBO model) <Ref. to IN(H4DOTC)-10, REMOVAL, Intercooler.>
- 3) Drain the clutch fluid. <Ref. to CL-23, REPLACEMENT, Clutch Fluid.>
- 4) Remove the clutch pipe from the clutch hose and master cylinder.
- 5) Pull out the clamp, then remove the clutch hose from bracket.



- (A) Clamp
- (B) Clutch hose

- 6) Remove the hose from operating cylinder.
- 7) Remove the bracket.


B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

T1: 15 N·m (1.5 kgf-m, 10.8 ft-lb)

T2: 18 N·m (1.8 kgf-m, 13.0 ft-lb)



- (A) Clutch pipe
- (B) Clip
- (C) Clutch hose
- (D) Master cylinder (Non-TURBO model)
- (E) Master cylinder (TURBO model)

C: INSPECTION

Check the pipes and hoses for cracks, breakage, or damage. Check the joints for fluid leakage. If any cracks, breakage, damage, or leakage is found, repair or replace the applicable pipe or hose.