3. General Description

A: CAUTION

1. SUPPLEMENTAL RESTRAINT SYSTEM "AIRBAG"

Airbag system wiring harness is routed near the ABS sensor, ABS control module and hydraulic control unit.

CAUTION:

- All airbag system wiring harness and connectors are colored yellow. Do not use electrical test equipment on these circuit.
- Be careful not to damage airbag system wiring harness when servicing the ABS sensor, ABS control module and hydraulic control unit.

B: INSPECTION

Before performing diagnostics, check the following items which might affect ABS problems:

1. BATTERY

Measure battery voltage and specific gravity of electrolyte.

Standard voltage: 12 V, or more Specific gravity: Above 1.260

2. BRAKE FLUID

- 1) Check brake fluid level.
- 2) Check brake fluid leakage.

3. HYDRAULIC UNIT

Check the hydraulic unit.

- With brake tester <Ref. to ABS-8, CHECKING THE HYDRAULIC UNIT ABS OPERATION WITH BRAKE TESTER, INSPECTION, ABS Control Module and Hydraulic Control Unit (ABSCM&H/U).>
- Without brake tester <Ref. to ABS-7, CHECK-ING THE HYDRAULIC UNIT ABS OPERATION BY PRESSURE GAUGE, INSPECTION, ABS Control Module and Hydraulic Control Unit (AB-SCM&H/U).>

4. BRAKE DRAG

Check brake drag.

5. BRAKE PAD AND ROTOR

Check brake pad and rotor.

- Front <Ref. to BR-13, INSPECTION, Front Brake Pad.> and <Ref. to BR-14, INSPECTION, Front Disc Rotor.>
- Rear <Ref. to BR-18, INSPECTION, Rear Brake Pad.> and <Ref. to BR-19, INSPECTION, Rear Disc Rotor.>

6. TIRE

Check tire specifications, tire wear and air pressure. <Ref. to WT-2, SPECIFICATIONS, General Description.>

C: PREPARATION TOOL

1. SPECIAL TOOLS

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
ST24082AA260	24082AA260	CARTRIDGE	Troubleshooting for electrical systems.
ST22771AA030	22771AA030	SELECT MONITOR KIT	Troubleshooting for electrical systems.

2. GENERAL PURPOSE TOOLS

TOOL NAME	REMARKS	
Circuit Tester	Used for measuring resistance, voltage and ampere.	
Oscilloscope	Used for measuring sensor.	

MEMO: