


## 8. Transmission Cover S510640

### A: REMOVAL S510640A18

- 1) Remove transmission cover.




- 2) Take out shim from transmission cover.

### B: INSTALLATION S510640A11

- 1) Measure distance L from end of transmission cover point at bearing location with ST.

ST 398643600 GAUGE


$L = \text{Measured value} - 15 \text{ mm}$



- 2) Measure the distance "ℓ" from the transmission case mating surface to end of bearing with ST.

$\ell = \text{Measured value} - 15 \text{ mm}$

ST 398643600 GAUGE



- 3) Calculation equation:

NOTE:

Add 0.05 mm (0.0020 in) and 0.20 mm (0.0079 in) thick shims to area "T". Calculate formula 2 to determine "H". The calculated "H" refers to the shim thickness range. Select shims of suitable thicknesses within the calculated "H" range.

(0 to 6 teeth)

$$T = (L + G) - \ell - H$$

T: Shim clearance

L: Distance from end of extension case to end of rear drive shaft

G: Gasket thickness [0.45 mm (0.0177 in)]

ℓ: Height from end of transmission case to end of reduction drive gear

H: Shim thickness

0.05 — 0.25 mm (0.0020 — 0.0098 in)

Adjusting shim	
Part No.	Thickness mm (in)
31288AA020	0.15 (0.0059)

- 4) Attach the selected adjusting shim to transmission cover.

- 5) Install the transmission cover to the transmission case.


**CAUTION:**

**Be sure to use a new gasket.**

- 6) Tighten bolts to secure the case.

**Tightening torque:**

**25 N·m (2.5 kgf·m, 18.1 ft·lb)**



### C: INSPECTION S510640A10

Make sure that the transmission cover has no cracks.