

5. Security System

A: PRECAUTION

1. SUPPLEMENTAL RESTRAINT SYSTEM “AIRBAG”

Airbag system wiring harness is routed near the security control module.

CAUTION:

- All airbag system wiring harness and connectors are yellow. Do not use electrical test equipment on these circuits.
- Be careful not to damage airbag system wiring harness when servicing the security control module.

B: PRE-INSPECTION

1. FUSE

5B11 : CHECK FUSE.

Remove and visually check the fuse No. 7 (in main fuse box).

- CHECK** : *Is fuse No. 7 blown?*
YES : Replace fuse (20 A).
NO : Go to step 5B12.

5B12 : CHECK FUSE.

Remove and visually check the fuse No. 2 (in main fuse box).

- CHECK** : *Is fuse No. 2 blown?*
YES : Replace fuse (15 A).
NO : Go to step 5B21.


2. POWER SUPPLY CIRCUIT

5B21 : CHECK POWER SUPPLY CIRCUIT.

Measure voltage between main fuse box connector (F68) and chassis ground.

Connector & terminal

(F68) No. 4 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 10 V?*
YES : Go to step 5B22.
NO : Repair wiring harness between main fuse box and battery.

5B22 : CHECK POWER SUPPLY CIRCUIT.

- 1) Disconnect connector from security control module.
- 2) Measure voltage between security control module connector (B93) and chassis ground.

Connector & terminal

(B93) No. 11 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 10 V?*
YES : Go to step 5B23.
NO : Repair wiring harness between security control module and main fuse box.

5B23 : CHECK POWER SUPPLY CIRCUIT.

Measure voltage between main fuse box connector (F68) and chassis ground.

Connector & terminal

(F68) No. 2 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **5B24**.
- NO** : Repair wiring harness between main fuse box and battery.

5B24 : CHECK POWER SUPPLY CIRCUIT.

Measure voltage between security control module connector (B93) and chassis ground.

Connector & terminal

(B93) No. 13 (+) — Chassis ground (-):



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **5B31**.
- NO** : Repair wiring harness between security control module and main fuse box.


3. GROUND CIRCUIT

5B31 : CHECK GROUND CIRCUIT.

Measure resistance between security control module connector (B93) and chassis ground.


Connector & terminal

(B93) No. 14 (+) — Chassis ground (-):



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F11**.
- NO** : Repair wiring harness between security control module and chassis ground.

C: ELECTRICAL COMPONENTS LOCATION



- | | | |
|---|---|---|
| (1) Horn | (5) Horn relay (in main fuse box) | (9) Passive arm connector (on driver side front lower pillar) |
| (2) Keyless entry control module | (6) Rear gate latch switch | |
| (3) Security control module (under console box) | (7) Interrupt relay (behind the fuse box) | |
| (4) Security indicator light (in combination meter) | (8) Door switch | |

D: SCHEMATIC


s6m0455

S6M0455

s6m0456

S6M0456

E: CONTROL MODULE I/O SIGNAL



B6M0972

Content	Terminal No.	Measuring condition
Empty	1	—
Ignition switch (ON)	2 (INPUT)	Battery voltage is present when ignition switch is turned ON.
Passive arm	3	—
Empty	4	—
Door switch and rear gate latch switch	5 (INPUT)	0 V is present when any door is open.
Empty	6	—
Keyless entry control module	7	—
Keyless entry control module	8	—
Security indicator light	9 (OUTPUT)	0 V is present when activating the alarm operation.
Keyless entry control module	10	—
Power supply for clearance light (Back-up)	11	Battery voltage is constantly present.
Clearance light	12 (OUTPUT)	Battery voltage is present when activating the alarm operation.
Power supply (Back-up)	13	Battery voltage is constantly present.
Ground	14	—
Interrupt relay	15 (OUTPUT)	0 V is present when activating the alarm operation.
Empty	16	—
Empty	17	—
Empty	18	—

F: DIAGNOSTICS PROCEDURE**1. BASIC DIAGNOSTICS PROCEDURE****5F11 : CHECK SECURITY SYSTEM FUNCTION.**

- 1) Perform basic diagnostics procedure of keyless entry system. <Ref. to 6-2 [T4F1].>
- 2) Perform pre-inspection. <Ref. to 6-2 [T5B0].>
- 3) Open all windows.
- 4) Remove ignition key from ignition switch.
- 5) Set the room light switch in the middle position.
- 6) Close all doors and the rear gate.
- 7) Press the LOCK/ARM button one time.

CHECK : **Does the clearance light blink one time?**

YES : Go to step 5F12.

NO : Go to step 5F21.

5F12 : CHECK SECURITY SYSTEM FUNCTION.

Check if the security indicator light blinks.

CHECK : **Does the security indicator light blink every 2 seconds?**

YES : Go to step 5F13.

NO : Go to step 5F31.

5F13 : CHECK SECURITY SYSTEM FUNCTION.

Press the UNLOCK/DISARM button one time.

CHECK : **Does the clearance light blink two times?**

YES : Go to step 5F14.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F14 : CHECK SECURITY SYSTEM FUNCTION.

Check if the room light activates.

CHECK : **Does the room light turn on for 30 seconds and then turn off?**

YES : Go to step 5F15.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F15 : CHECK SECURITY SYSTEM FUNCTION.

- 1) Unlock all doors with door locking switch in the front door.
- 2) Open the front left door.

CHECK : **Does the security indicator light blink every 1/8 seconds?**

YES : Go to step 5F16.

NO : Go to step 5F41.

5F16 : CHECK SECURITY SYSTEM FUNCTION.

Check if the clearance light activates.

CHECK : **Does the clearance light blinking remain?**

YES : Go to step 5F17.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F17 : CHECK SECURITY SYSTEM FUNCTION.

Check if the horn activates.

CHECK : **Does the horn sound remain?**

YES : Go to step 5F18.

NO : Replace security control module. <Ref. 6-2 [W14A1].>

5F18 : CHECK SECURITY SYSTEM FUNCTION.

Turn on starter.

CHECK : **Does the starter motor activate?**

YES : Go to step 5F51.

NO : Go to step 5F19.

5F19 : CHECK SECURITY SYSTEM FUNCTION.

Close the front left door.

CHECK : **Does the horn sound and clearance light blinking deactivate, and starter motor activate after approximately 30 seconds?**

YES : Go to step 5F110.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F110 : CHECK SECURITY SYSTEM FUNCTION.

Check if the security indicator light activates.

CHECK : *Does the security indicator light blink every 2 seconds?*

YES : Go to step 5F111.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F111 : CHECK SECURITY SYSTEM FUNCTION.

Open the front right door.

CHECK : *Does the security indicator light blink every 1/8 seconds, the horn sound, the clearance light blink, and the starter motor deactivate?*

YES : Go to step 5F112.

NO : Go to step 5F61.

5F112 : CHECK SECURITY SYSTEM FUNCTION.

Press the UNLOCK/DISARM button.

CHECK : *Does the security indicator light blink, the horn and clearance light deactivate, and the starter motor activate?*

YES : Go to step 5F113.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

5F113 : CHECK SECURITY SYSTEM FUNCTION.

- 1) Close the front right door.
- 2) Press the LOCK/ARM button.
- 3) Open the rear left door.

CHECK : *Does the security indicator light blink every 1/8 seconds, the horn sound, the clearance light blink, and the starter motor deactivate?*

YES : Go to step 5F114.

NO : Go to step 5F71.

5F114 : CHECK SECURITY SYSTEM FUNCTION.

- 1) Close the rear left door.
- 2) Open the rear right door.

CHECK : *Does the security indicator light blink every 1/8 seconds, the horn sound, the clearance light blink, and the starter motor deactivate?*

YES : Go to step 5F115.

NO : Go to step 5F81.

5F115 : CHECK SECURITY SYSTEM FUNCTION.

- 1) Close the rear right door.
- 2) Open the rear gate.


CHECK : *Does the security indicator light blink every 1/8 seconds, the horn sound, the clearance light blink, and the starter motor deactivate?*

YES : Go to step 5F116.

NO : Go to step 5F91.

5F116 : PERFORM IMPACT SENSITIVITY TEST.

- 1) Close the rear gate.
- 2) Close all windows.
- 3) Perform arming.
- 4) Perform impact sensitivity test.



CHECK : *Does the horn chirp?*

YES : Go to step 5F117.

NO : Go to step 5F101.

5F117 : CHECK PASSIVE ARM.

- 1) Remove the driver's side sill cover. <Ref. to 5-3 [W5A0].>
- 2) Connect the white connector (1-pin) at driver side front lower pillar.
- 3) Close all doors and the rear gate.

CHECK : **Does the arming automatically function after 1 minute?**

YES : Go to step 5F118.

NO : Go to step 5F111.

5F118 : CHECK BATTERY DISCONNECT PROTECTION.

- 1) Press the UNLOCK/DISARM button.
- 2) Connect the white connector (1-pin) at front pillar lower.
- 3) Install the driver's side sill cover. <Ref. to 5-3 [W5A0].>
- 4) Open the front hood.
- 5) Press the LOCK/ARM button.
- 6) Disconnect the ground cable from battery.
- 7) Connect the ground cable to battery.

CHECK : **Does re-arming function automatically?**

YES : End of basic diagnostics procedure. Press the UNLOCK/DISARM button, and then close all doors and the rear gate. Perform ignition switch position turned LOCK to ON to LOCK.

NO : Replace security control module. <Ref. to 6-2 [W14A1].>

2. DIAGNOSTICS ITEM 1**5F21 : CHECK FUSE.**

Remove and visually check fuse No. 7 (in main fuse box).

CHECK : **Is fuse No. 7 blown?**

YES : Replace fuse (20 A).

NO : Go to step 5F22.

5F22 : CHECK FUSE.

Remove and visually check fuse No. 5 (in fuse box).

CHECK : **Is fuse No. 5 blown?**

YES : Replace fuse (10 A).

NO : Go to step 5F23.

5F23 : CHECK CLEARANCE LIGHT BULB.

Remove and visually check each clearance light bulb.

CHECK : **Is the bulb blown?**

YES : Replace clearance light bulb.


NO : Go to step 5F24.

5F24 : CHECK POWER SUPPLY FOR CLEARANCE LIGHT.

Measure voltage between main fuse box connector (F68) and chassis ground.

Connector & terminal

(F68) No. 4 (+) — Chassis ground (-):



CHECK : **Is the voltage more than 10 V?**

YES : Go to step 5F25.


NO : Repair wiring harness between main fuse box and battery.

5F25 : CHECK POWER SUPPLY FOR CLEARANCE LIGHT.

- 1) Disconnect connector from security control module.
- 2) Measure voltage between security control module connector (B93) and chassis ground.

Connector & terminal

(B93) No. 11 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 5F26.
- NO** : Repair wiring harness between security control module and main fuse box.

5F26 : CHECK HARNESS CONNECTOR BETWEEN SECURITY CONTROL MODULE AND FUSE BOX.

- 1) Disconnect connector (B158) from fuse box.
- 2) Measure resistance between security control module connector (B93) and fuse box connector (B158).

Connector & terminal

(B93) No. 12 — (B158) No. 11:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step 5F27.
- NO** : Repair wiring harness between security control module and fuse box.

5F27 : CHECK FUSE BOX CIRCUIT.

- 1) Connect connector (B158) to fuse box.
- 2) Measure resistance between fuse box connector (B158) and (F41).

Connector & terminal

(B158) No. 11 — (F41) No. 1:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step 5F28.
- NO** : Repair or replace fuse box.

5F28 : CHECK FUSE BOX CIRCUIT.

Measure resistance between fuse box connector (B158).

Connector & terminal

(B158) No. 10 — No. 11:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step 5F29.
- NO** : Repair or replace fuse box.

5F29 : CHECK HARNESS CONNECTOR BETWEEN FRONT CLEARANCE LIGHT AND FUSE BOX.

- 1) Disconnect connector from front clearance light RH and fuse box.
- 2) Measure resistance between front clearance light RH connector (F3) and fuse box connector (F41).

Connector & terminal

(F3) No. 1 — (F41) No. 1:




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F210**.
- NO** : Repair wiring harness between front clearance light RH and fuse box.

5F210 : CHECK HARNESS CONNECTOR BETWEEN FRONT CLEARANCE LIGHT AND FUSE BOX.

- 1) Disconnect connector from front clearance light LH.
- 2) Measure resistance between front clearance light LH connector (F19) and fuse box connector (F41).

Connector & terminal

(F19) No. 1 — (F41) No. 1:




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F211**.
- NO** : Repair wiring harness between front clearance light LH and fuse box.

5F211 : CHECK HARNESS CONNECTOR BETWEEN FRONT CLEARANCE LIGHT AND CHASSIS GROUND.

Measure resistance between front clearance light RH connector (F3) and chassis ground.

Connector & terminal

(F3) No. 2 (+) — Chassis ground (-):




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F212**.
- NO** : Repair wiring harness between front clearance light RH and chassis ground.

5F212 : CHECK HARNESS CONNECTOR BETWEEN FRONT CLEARANCE LIGHT AND CHASSIS GROUND.

Measure resistance between front clearance light LH connector (F19) and chassis ground.

Connector & terminal

(F19) No. 2 (+) — Chassis ground (-):




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F213**.
- NO** : Repair wiring harness between front clearance light LH and chassis ground.

5F213 : CHECK HARNESS CONNECTOR BETWEEN REAR CLEARANCE LIGHT AND FUSE BOX.

- 1) Disconnect connector from rear clearance light RH and fuse box.
- 2) Measure resistance between rear clearance light RH connector (R26) and fuse box connector (B158).

Connector & terminal

(R26) No. 1 — (B158) No. 10:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F214**.
- NO** : Repair wiring harness between rear clearance light RH and fuse box.

5F214 : CHECK HARNESS CONNECTOR BETWEEN REAR CLEARANCE LIGHT AND FUSE BOX.

- 1) Disconnect connector from rear clearance light LH.
- 2) Measure resistance between rear clearance light LH connector (R28) and fuse box connector (B158).

Connector & terminal

(R28) No. 1 — (B158) No. 10:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F215**.
- NO** : Repair wiring harness between rear clearance light LH and fuse box.

5F215 : CHECK HARNESS CONNECTOR BETWEEN REAR CLEARANCE LIGHT AND CHASSIS GROUND.

Measure resistance between rear clearance light RH connector (R26) and chassis ground.

Connector & terminal

(R26) No. 4 (+) — Chassis ground (-):




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F216**.
- NO** : Repair wiring harness between rear clearance light RH and chassis ground.

5F216 : CHECK HARNESS CONNECTOR BETWEEN REAR CLEARANCE LIGHT AND CHASSIS GROUND.

Measure resistance between rear clearance light LH connector (R28) and chassis ground.

Connector & terminal

(R28) No. 4 (+) — Chassis ground (-):



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair wiring harness between rear clearance light LH and chassis ground.


3. DIAGNOSTICS ITEM 2

5F31 : CHECK SECURITY INDICATOR LIGHT COMES ON.

- 1) Disconnect connector from security control module.
- 2) Measure resistance between security control module connector (B93) and chassis ground.

Connector & terminal

(B93) No. 9 (+) — Chassis ground (-):




- CHECK** : **Does the indicator light come on?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Go to step 5F32.

5F32 : CHECK POWER SUPPLY FOR SECURITY INDICATOR LIGHT.

- 1) Disconnect connector from combination meter.
- 2) Measure voltage between combination meter connector (i10) and chassis ground.

Connector & terminal

(i10) No. 1 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step 5F33.
- NO** : Repair wiring harness between security indicator light and main fuse box.

5F33 : CHECK HARNESS CONNECTOR BETWEEN SECURITY INDICATOR LIGHT AND SECURITY CONTROL MODULE.

Measure resistance between combination meter connector (i10) and security control module connector (B93).

Connector & terminal
(i10) No. 18 — (B93) No. 9:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace combination meter printed circuit.
- NO** : Repair wiring harness between security indicator light and security control module.

4. DIAGNOSTICS ITEM 3

5F41 : CHECK HARNESS CONNECTOR BETWEEN SECURITY CONTROL MODULE AND COMBINATION METER.

- 1) Disconnect connector from security control module and combination meter.
- 2) Measure resistance between security control module connector (B93) and combination meter connector (i10).

Connector & terminal
(B93) No. 5 — (i10) No. 11:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F42**.
- NO** : Repair wiring harness between security control module and combination meter.

5F42 : CHECK HARNESS CONNECTOR BETWEEN FRONT DOOR SWITCH LH AND COMBINATION METER.

- 1) Disconnect connector from front door switch LH.
- 2) Measure resistance between front door switch LH connector (R9) and combination meter connector (i10).

Connector & terminal
(R9) No. 1 — (i10) No. 12:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F43**.
- NO** : Repair wiring harness between front door switch LH and combination meter.

5F43 : CHECK HARNESS CONNECTOR BETWEEN FRONT DOOR SWITCH LH AND CHASSIS GROUND.

Measure resistance between front door switch LH (R9) and chassis ground.

Connector & terminal
(R9) No. 1 (+) — Chassis ground (-):




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F44**.
- NO** : Repair wiring harness between front door switch LH and chassis ground.

5F44 : CHECK COMBINATION METER CIRCUIT.

- 1) Remove combination meter. <Ref. to 6-2 [W8A0].>
- 2) Measure resistance between combination meter terminals.

Terminals
No. 11 — No. 12:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair or replace combination meter. <Ref. to 6-2 [W800].>

5. DIAGNOSTICS ITEM 4

5F51 : CHECK INPUT SIGNAL FOR STARTER MOTOR.

- 1) Disconnect connector from starter motor.
- 2) Turn ignition switch to START.
- 3) Measure voltage between starter motor connector (B14) and engine ground.

Connector & terminal**(B14) No. 1 (+) — Engine ground (-):****NOTE:**

- On AT vehicles, place the select lever in the P or N position.
- On MT vehicles, depress the clutch pedal.

- CHECK** : **Is the voltage more than 10 V?**
YES : Go to step **5F52**.
NO : Go to step **5F53**.

5F52 : CHECK GROUND CIRCUIT OF STARTER MOTOR.

- 1) Turn ignition switch to OFF.
- 2) Disconnect terminal from starter motor.
- 3) Measure resistance between ground cable terminal and engine ground.

- CHECK** : **Is the resistance less than 5 Ω?**
YES : Check starter motor. <Ref. to 6-1 [W100].>
NO : Repair or replace ground cable.

5F53 : CHECK FUSE.

Remove and visually check the fuse SBF-1 (in main fuse box).

- CHECK** : **Is fuse SBF-1 blown?**
YES : Replace SBF fuse (80 A).
NO : Go to step **5F54**.


5F54 : CHECK FUSE.

Remove and visually check the fuse SBF-4 (in main fuse box).


- CHECK** : **Is fuse SBF-4 blown?**
YES : Replace SBF fuse (50 A).
NO : Go to step **5F55**.

5F55 : CHECK INTERRUPT RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove interrupt relay (behind the fuse box).



- 3) Check continuity between interrupt relay terminals.

Terminals**No. 1 — No. 4:**


- CHECK** : **Does continuity exist?**
YES : Go to step **5F56**.
NO : Replace interrupt relay.

5F56 : CHECK INTERRUPT RELAY.

Check continuity between interrupt relay terminals.

Terminals

No. 2 — No. 6:




- CHECK** : Does continuity exist?
- YES** : Go to step 5F57.
- NO** : Replace interrupt relay.

5F57 : CHECK INTERRUPT RELAY.

- 1) Connect the battery to interrupt relay terminals No. 1 and No. 4.
- 2) Check continuity between interrupt relay terminals.

Terminals

No. 2 — No. 6:




- CHECK** : Does continuity exist?
- YES** : Replace interrupt relay.
- NO** : Go to step 5F58.

5F58 : CHECK HARNESS CONNECTOR BETWEEN BATTERY AND SECURITY CONTROL MODULE.

- 1) Install the SBF-4 to main fuse box.
- 2) Install the interrupt relay.
- 3) Disconnect connector from security control module.
- 4) Turn ignition switch to START.
- 5) Measure voltage between security control module connector (B93) and chassis ground.

Connector & terminal

(B93) No. 15 (+) — Chassis ground (-):



- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 5F59.
- NO** : Repair wiring harness between security control module and battery.

5F59 : CHECK TRANSMISSION TYPE.


- CHECK** : Is the transmission type AT?
- YES** : Go to step 5F510.
- NO** : Go to step 5F513.

5F510 : CHECK HARNESS CONNECTOR BETWEEN INTERRUPT RELAY AND INHIBITOR SWITCH.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from inhibitor switch.
- 3) Turn ignition switch to START.
- 4) Measure voltage between inhibitor switch connector (T7) and chassis ground.

Connector & terminal

(T7) No. 12 (+) — Chassis ground (-):




- CHECK** : Is the voltage more than 10 V?
- YES** : Go to step 5F511.
- NO** : Repair wiring harness between interrupt relay and inhibitor switch.

5F511 : CHECK INHIBITOR SWITCH.

- 1) Place the select lever in the P or N position.
- 2) Measure resistance between inhibitor switch terminals.

Terminals

No. 7 — No. 12:




- CHECK** : Is the resistance less than 1 Ω?
- YES** : Go to step 5F512.
- NO** : Replace inhibitor switch. <Ref. to 3-2 [W200].>

5F512 : CHECK HARNESS BETWEEN INHIBITOR SWITCH AND STARTER MOTOR.

Measure resistance between inhibitor switch connector (T7) and starter motor connector (B14).

Connector & terminal

(T7) No. 7 — (B14) No. 1:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair wiring harness between inhibitor switch and starter motor.

5F513 : CHECK STARTER INTERLOCK RELAY.

- 1) Turn ignition switch to OFF.
- 2) Remove starter interlock relay.
- 3) Check continuity between starter interlock relay terminals.

Terminals

No. 3 — No. 2:




- CHECK** : Does continuity exist?
- YES** : Go to step 5F514.
- NO** : Replace starter interlock relay.

5F514 : CHECK STARTER INTERLOCK RELAY.

Check continuity between starter interlock relay terminals.

Terminals

No. 1 — No. 4:




- CHECK** : Does continuity exist?
- YES** : Replace starter interlock relay.
- NO** : Go to step **5F515**.

5F515 : CHECK STARTER INTERLOCK RELAY.

- 1) Connect the battery to starter interlock relay terminals No. 3 and No. 2.
- 2) Check continuity between starter interlock relay terminals.

Terminals

No. 1 — No. 4:



- CHECK** : Does continuity exist?
- YES** : Go to step **5F516**.
- NO** : Replace starter interlock relay.

5F516 : CHECK CLUTCH SWITCH.

- 1) Install starter interlock relay.
- 2) Measure resistance between clutch switch connector (B106) and (B107) terminals while depressing the clutch pedal.


Connector & terminal

With cruise control

(B107) No. 1 — No. 2:

Without cruise control

(B106) No. 1 — No. 2:




- CHECK** : Is the resistance less than 10 Ω?
- YES** : Go to step **5F517**.
- NO** : Replace clutch switch.

5F517 : CHECK HARNESS BETWEEN INTERRUPT RELAY AND STARTER MOTOR.

- 1) Disconnect connector from starter motor.
- 2) Turn ignition switch to START.
- 3) Measure voltage between starter motor connector (B14) and chassis ground while depressing the clutch pedal.

Connector & terminal
(B14) No. 1 (+) — Chassis ground (-):




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair wiring harness between interrupt relay and starter motor.

6. DIAGNOSTICS ITEM 5

5F61 : CHECK HARNESS CONNECTOR BETWEEN SECURITY CONTROL MODULE AND COMBINATION METER.

- 1) Disconnect connector from security control module and combination meter.
- 2) Measure resistance between security control module connector (B93) and combination meter connector (i10).

Connector & terminal
(B93) No. 5 — (i10) No. 11:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F62**.
- NO** : Repair wiring harness between security control module and combination meter.

5F62 : CHECK HARNESS CONNECTOR BETWEEN FRONT DOOR SWITCH RH AND COMBINATION METER.

- 1) Disconnect connector from front door switch RH.
- 2) Measure resistance between front door switch RH connector (R12) and combination meter connector (i10).

**Connector & terminal
(R12) No. 1 — (i10) No. 11:**




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F63**.
- NO** : Repair wiring harness between front door switch RH and combination meter.

5F63 : CHECK COMBINATION METER CIRCUIT.

- 1) Remove combination meter.
<Ref. to 6-2 [W8A0].>
- 2) Measure resistance between combination meter terminals.

**Terminals
No. 11 — No. 12:**




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair or replace combination meter. <Ref. to 6-2 [W800].>

7. DIAGNOSTIC ITEM 6

5F71 : CHECK HARNESS CONNECTOR BETWEEN SECURITY CONTROL MODULE AND COMBINATION METER.

- 1) Disconnect connector from security control module and combination meter.
- 2) Measure resistance between security control module connector (B93) and combination meter connector (i10).

Connector & terminal
(B93) No. 5 — (i10) No. 11:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F72**.
- NO** : Repair wiring harness between security control module and combination meter.

5F72 : CHECK HARNESS CONNECTOR BETWEEN REAR DOOR SWITCH LH AND COMBINATION METER.

- 1) Disconnect connector from rear door switch LH.
- 2) Measure resistance between rear door switch LH connector (R22) and combination meter connector (i10).

Connector & terminal
(R22) No. 1 — (i10) No. 11:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F73**.
- NO** : Repair wiring harness between rear door switch LH and combination meter.

5F73 : CHECK COMBINATION METER CIRCUIT.

- 1) Remove combination meter. <Ref. to 6-2 [W8A0].>
- 2) Measure resistance between combination meter terminals.

Terminals
No. 11 — No. 12:



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair or replace combination meter. <Ref. to 6-2 [W800].>


8. DIAGNOSTIC ITEM 7

5F81 : CHECK HARNESS CONNECTOR BETWEEN SECURITY CONTROL MODULE AND COMBINATION METER.

- 1) Disconnect connector from security control module and combination meter.
- 2) Measure resistance between security control module connector (B93) and combination meter connector (i10).

Connector & terminal

(B93) No. 5 — (i10) No. 11:




- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F82**.
- NO** : Repair wiring harness between security control module and combination meter.

5F82 : CHECK HARNESS CONNECTOR BETWEEN REAR DOOR SWITCH RH AND COMBINATION METER.

- 1) Disconnect connector from rear door switch RH.
- 2) Measure resistance between rear door switch RH connector (R16) and combination meter connector (i10).

Connector & terminal


(R16) No. 1 — (i10) No. 11:



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F83**.
- NO** : Repair wiring harness between rear door switch RH and combination meter.

5F83 : CHECK COMBINATION METER CIRCUIT.


- 1) Remove combination meter. <Ref. to 6-2 [W8A0].>
- 2) Measure resistance between combination meter terminals.

Terminals
No. 11 — No. 12:


- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair or replace combination meter. <Ref. to 6-2 [W800].>

9. DIAGNOSTIC ITEM 8
5F91 : CHECK HARNESS CONNECTOR BETWEEN REAR GATE LATCH SWITCH AND SECURITY CONTROL MODULE.

- 1) Disconnect connector from rear gate latch switch and security control module.
- 2) Measure resistance between rear gate latch switch connector (D46) and security control module connector (B93).

Connector & terminal
(D46) No. 1 — (B93) No. 5:



- CHECK** : **Is the resistance less than 10 Ω?**
- YES** : Go to step **5F92**.
- NO** : Repair wiring harness between rear gate latch switch and security control module.

5F92 : CHECK HARNESS CONNECTOR BETWEEN REAR GATE LATCH SWITCH AND CHASSIS GROUND.

Measure resistance between rear gate latch switch connector (D46) and chassis ground.

Connector & terminal

(D46) No. 2 (+) — Chassis ground (-):




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F93**.
- NO** : Repair wiring harness between rear gate latch switch and chassis ground.

5F93 : CHECK REAR GATE LATCH SWITCH.

Measure resistance between rear gate latch switch terminals.

Terminals

No. 1 — No. 2:




- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Go to step **5F94**.
- NO** : Replace rear gate latch switch.

5F94 : CHECK REAR GATE LATCH SWITCH.

Measure resistance between rear gate latch switch terminals while pushing the switch.

Terminals

No. 1 — No. 2:



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Replace rear gate latch switch.
- NO** : Replace security control module. <Ref. to 6-2 [W14A1].>

10. DIAGNOSTIC ITEM 9

5F101 : CHECK SECURITY CONTROL MODULE.


Check and ensure that security control module is installed on the bracket. <Ref. to 6-2 [W14A1].>

- CHECK** : *Is the security control module securely installed?*
- YES** : Go to step **5F102**.
- NO** : Securely install security control module. <Ref. to 6-2 [W14A1].>

5F102 : ADJUST SENSITIVITY.

- 1) Remove security control module. <Ref. to 6-2 [W14A1].>
- 2) Adjust the sensitivity adjust screw in security control module.

NOTE:
After adjusting, be sure to plug the adjust screw hole.



- 3) Install security control module. <Ref. to 6-2 [W14A1].>
- 4) Perform impact sensitivity test. <Ref. to 6-2 [T5F1].>


- CHECK** : *Is sensitivity adjustment possible?*
- YES** : Impact sensitivity is normal.
- NO** : Replace security control module. <Ref. to 6-2 [W14A1].>

11. DIAGNOSTIC ITEM 10

5F111 : CHECK PASSIVE ARM CIRCUIT.

- 1) Connect connector (B183) and (B184) at driver side front lower pillar.
- 2) Disconnect connector from security control module.
- 3) Measure resistance between security control module (B93) and chassis ground.

Connector & terminal
(B93) No. 3 (+) — Chassis ground (-):



- CHECK** : *Is the resistance less than 10 Ω?*
- YES** : Replace security control module. <Ref. to 6-2 [W14A1].>
- NO** : Repair wiring harness between security control module and chassis ground.