

# 7. Diagnostics Chart for ABS Warning Light Circuit and Diagnosis Circuit Failure

## A: ABS WARNING LIGHT DOES NOT COME ON.


### DIAGNOSIS:

- ABS warning light circuit is open or shorted.

### TROUBLE SYMPTOM:

- When ignition switch is turned ON (engine OFF), ABS warning light does not come on.

### WIRING DIAGRAM:



S4M0479

**7A1 : CHECK IF OTHER WARNING LIGHTS TURN ON.**

Turn ignition switch to ON (engine OFF).

- CHECK** : *Do other warning lights turn on?*
- YES** : Go to step **7A2**.
- NO** : Repair combination meter. <Ref. to 6-2 [W8A0].>

**7A2 : CHECK ABS WARNING LIGHT BULB.**


- 1) Turn ignition switch to OFF.
- 2) Remove combination meter. <Ref. to 6-2 [W8A0].>
- 3) Remove ABS warning light bulb from combination meter.

- CHECK** : *Is ABS warning light bulb OK?*
- YES** : Go to step **7A3**.
- NO** : Replace ABS warning light bulb. <Ref. to 6-2 [W8B0].>

**7A3 : CHECK BATTERY SHORT OF ABS WARNING LIGHT HARNESS.**

- 1) Disconnect connector (B100) from connector (F2).
- 2) Measure voltage between connector (B100) and chassis ground.

**Connector & terminal**  
**(B100) No. 8 (+) — Chassis ground (-):**




- CHECK** : *Is the voltage less than 3 V?*
- YES** : Go to step **7A4**.
- NO** : Repair warning light harness.

**7A4 : CHECK BATTERY SHORT OF ABS WARNING LIGHT HARNESS.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between connector (B100) and chassis ground.

**Connector & terminal**  
**(B100) No. 8 (+) — Chassis ground (-):**




- CHECK** : *Is voltage less than 3 V?*
- YES** : Go to step **7A5**.
- NO** : Repair warning light harness.

**7A5 : CHECK WIRING HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Install ABS warning light bulb from combination meter.
- 3) Install combination meter.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between connector (B100) and chassis ground.

**Connector & terminal**  
**(B100) No. 8 (+) — Chassis ground (-):**




- CHECK** : *Is voltage between 10 and 15 V?*
- YES** : Go to step **7A6**.
- NO** : Repair wiring harness.

**7A6 : CHECK BATTERY SHORT OF ABS WARNING LIGHT HARNESS.**

- 1) Turn ignition switch to OFF.
- 2) Measure voltage between connector (F2) and chassis ground.

**Connector & terminal**

**(F2) No. 8 (+) — Chassis ground (-):**




- CHECK** : Is the voltage less than 3 V?
- YES** : Go to step 7A7.
- NO** : Repair wiring harness.

**7A7 : CHECK BATTERY SHORT OF ABS WARNING LIGHT HARNESS.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between connector (F2) and chassis ground.

**Connector & terminal**

**(F2) No. 8 (+) — Chassis ground (-):**




- CHECK** : Is voltage less than 3 V?
- YES** : Go to step 7A8.
- NO** : Repair wiring harness.

**7A8 : CHECK GROUND CIRCUIT OF ABSCM&H/U.**

Measure resistance between ABSCM&H/U and chassis ground.

**Connector & terminal**

**(F49) No. 23 — Chassis ground:**




- CHECK** : Is the resistance less than 0.5 Ω?
- YES** : Go to step 7A9.
- NO** : Repair ABSCM&H/U ground harness.

**7A9 : CHECK WIRING HARNESS.**

Measure resistance between connector (F2) and chassis ground.

**Connector & terminal**

**(F2) No. 8 — Chassis ground:**



- CHECK** : Is the resistance less than 0.5 Ω?
- YES** : Go to step 7A10.
- NO** : Repair harness/connector.

**7A10 : CHECK POOR CONTACT IN CONNECTORS.**

Turn ignition switch to OFF.

**CHECK** : *Is there poor contact in connectors between combination meter and ABSCM&H/U? <Ref. to FOREWORD [W3C1].>*

**YES** : Repair connector.

**NO** : Replace ABSCM&H/U. <Ref. to 4-4 [W14A0].>

**B: ABS WARNING LIGHT DOES NOT GO OFF.**


**DIAGNOSIS:**

- ABS warning light circuit is open or shorted.

**TROUBLE SYMPTOM:**

- When starting the engine and while ABS warning light is kept ON.

**WIRING DIAGRAM:**



S4M0479

**7B1 : CHECK INSTALLATION OF ABSCM&H/U CONNECTOR.**

Turn ignition switch to OFF.

**CHECK** : *Is ABSCM&H/U connector inserted into ABSCM until the clamp locks onto it?*

**YES** : Go to step **7B2**.

**NO** : Insert ABSCM&H/U connector into ABSCM&H/U until the clamp locks onto it.


**7B2 : CHECK DIAGNOSIS TERMINAL.**

Measure resistance between diagnosis terminals (B81) and chassis ground.

**Terminals**

**Diagnosis terminal (A) — Chassis ground:**

**Diagnosis terminal (B) — Chassis ground:**



**CHECK** : *Is the resistance less than 0.5 Ω?*

**YES** : Go to step **7B3**.


**NO** : Repair diagnosis terminal harness.

**7B3 : CHECK DIAGNOSIS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Connect diagnosis terminal (B81) to diagnosis connector (B82) No. 6.
- 3) Disconnect connector from ABSCM&H/U.
- 4) Measure resistance between ABSCM&H/U connector and chassis ground.

**Connector & terminal**

**(F49) No. 4 — Chassis ground:**



**CHECK** : *Is the resistance less than 0.5 Ω?*

**YES** : Go to step **7B4**.


**NO** : Repair harness connector between ABSCM&H/U and diagnosis connector.

**7B4 : CHECK GENERATOR.**

- 1) Start the engine.
- 2) Idle the engine.
- 3) Measure voltage between generator and chassis ground.

**Terminals**

**Generator B terminal (+) — Chassis ground (-):**



**CHECK** : *Is the voltage between 10 and 15 V?*

**YES** : Go to step **7B5**.

**NO** : Repair generator. <Ref. to 6-1 [W2A0].>

**7B5 : CHECK BATTERY TERMINAL.**

Turn ignition switch to OFF.


- CHECK** : *Is there poor contact at battery terminal?*
- YES** : Repair battery terminal.
- NO** : Go to step 7B6.

**7B6 : CHECK POWER SUPPLY OF ABSCM.**

- 1) Disconnect connector from ABSCM&H/U.
- 2) Start engine.
- 3) Idle the engine.
- 4) Measure voltage between ABSCM&H/U connector and chassis ground.

**Connector & terminal**

**(F49) No. 1 (+) — Chassis ground (-):**



- CHECK** : *Is the voltage between 10 and 15 V?*
- YES** : Go to step 7B7.
- NO** : Repair ABSCM&H/U power supply circuit.


**7B7 : CHECK WIRING HARNESS.**

- 1) Disconnect connector (F2) from connector (B100).
- 2) Turn ignition switch to ON.

- CHECK** : *Does the ABS warning light remain off?*
- YES** : Go to step 7B8.
- NO** : Repair front wiring harness.

**7B8 : CHECK PROJECTION AT ABSCM&H/U.**

- 1) Turn ignition switch to OFF.
- 2) Check for broken projection at the ABSCM&H/U terminal.




- CHECK** : *Are the projection broken?*
- YES** : Replace ABSCM&H/U. <Ref. to 4-4 [W14A0].>
- NO** : Go to step 7B9.

**7B9 : CHECK ABSCM&H/U.**

Measure resistance between ABSCM&H/U terminals.

**Terminals**

**No. 21 — No. 23:**




- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step 7B10.
- NO** : Replace ABSCM&H/U. <Ref. to 4-4 [W14A0].>

**7B10 : CHECK WIRING HARNESS.**

Measure resistance between connector (F2) and chassis ground.

**Connector & terminal**

**(F2) No. 8 — Chassis ground:**




- CHECK** : *Is the resistance less than 0.5 Ω?*
- YES** : Go to step **7B11**.
- NO** : Repair harness.

**7B11 : CHECK WIRING HARNESS.**

- 1) Connect connector to ABSCM&H/U.
- 2) Measure resistance between connector (F2) and chassis ground.

**Connector & terminal**

**(F2) No. 8 — Chassis ground:**



- CHECK** : *Is the resistance more than 1 MΩ?*
- YES** : Go to step **7B12**.
- NO** : Repair harness.

**7B12 : CHECK POOR CONTACT IN ABSCM&H/U CONNECTOR.**

- CHECK** : *Is there poor contact in ABSCM&H/U connector? <Ref. to FOREWORD [W3C1].>*
- YES** : Repair connector.
- NO** : Replace ABSCM&H/U. <Ref. to 4-4 [W14A0].>



**C: TROUBLE CODE DOES NOT APPEAR.**


**DIAGNOSIS:**

- Diagnosis circuit is open.

**TROUBLE SYMPTOM:**

- The ABS warning light turns on or off normally but the start code cannot be read out in the diagnostic mode.

**WIRING DIAGRAM:**




**7C1 : CHECK DIAGNOSIS TERMINAL.**

Measure resistance between diagnosis terminals (B81) and chassis ground.

**Terminals**

**Diagnosis terminal (A) — Chassis ground:**

**Diagnosis terminal (B) — Chassis ground:**




- CHECK** : *Is the resistance less than 0.5 Ω?*
- YES** : Go to step **7C2**.
- NO** : Repair diagnosis terminal harness.

**7C2 : CHECK DIAGNOSIS LINE.**

- 1) Turn ignition switch to OFF.
- 2) Connect diagnosis terminal (B81) to diagnosis connector (B82) No. 6.
- 3) Disconnect connector from ABSCM&H/U.
- 4) Measure resistance between ABSCM&H/U connector and chassis ground.

**Connector & terminal**

**(F49) No. 4 — Chassis ground:**



- CHECK** : *Is the resistance less than 0.5 Ω?*
- YES** : Go to step **7C3**.
- NO** : Repair harness connector between ABSCM&H/U and diagnosis connector.

**7C3 : CHECK POOR CONTACT IN ABSCM&H/U CONNECTOR.**

- CHECK** : *Is there poor contact in ABSCM&H/U connector? <Ref. to FOREWORD [W3C1].>*
- YES** : Repair connector.
- NO** : Replace ABSCM&H/U. <Ref. to 4-4 [W14A0].>

**MEMO:**