

19. Diagnostic Procedure with Diagnostic Trouble Code (DTC)

A: DTC P0030 — HO2S HEATER CONTROL CIRCUIT (BANK 1/SENSOR 1) —


• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00266

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. 1) Start the engine and warm-up engine. 2) Turn the ignition switch to OFF. 3) Disconnect the connectors from ECM and front oxygen (A/F) sensor. 4) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> <i>(B136) No. 6 — (B18) No. 3:</i> <i>(B136) No. 17 — (B18) No. 3:</i>	Is the resistance less than 1 Ω ?	Go to step 2.	Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector.
2 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> <i>(B136) No. 13 — (B18) No. 1:</i> <i>(B136) No. 22 — (B18) No. 2:</i>	Is the resistance less than 1 Ω ?	Go to step 3.	Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector.
3 CHECK HARNESS BETWEEN MAIN RELAY AND FRONT OXYGEN (A/F) SENSOR CONNECTOR. Measure the resistance of harness between main relay and front oxygen (A/F) sensor connector. <i>Connector & terminal</i> <i>(B47) No. 4 — (B18) No. 4:</i>	Is the resistance less than 1 Ω ?	Go to step 4.	Repair the open circuit in harness between ECM and front oxygen (A/F) sensor connector.
4 CHECK FRONT OXYGEN (A/F) SENSOR. Measure the resistance between front oxygen (A/F) sensor connector terminals. <i>Terminals</i> <i>No. 3 — No. 4:</i>	Is the resistance less than 5 Ω ?	Go to step 5.	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>
5 CHECK POOR CONTACT. Check the poor contact in ECM and front oxygen (A/F) sensor connector.	Is there poor contact in ECM or front oxygen (A/F) sensor connector?	Repair the poor contact in ECM or front oxygen (A/F) sensor connector.	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>


B: DTC P0031 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1)

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Does the Subaru Select Monitor or OBD-II general scan tool display DTC P0031 and P0037 at the same time?	Go to step 2.	Go to step 5.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2</p> <p>CHECK POWER SUPPLY TO FRONT OXYGEN (A/F) SENSOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from front oxygen (A/F) sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between front oxygen (A/F) sensor connector and engine ground.</p> <p>Connector & terminal (B18) No. 4 (+) — Engine ground (-): Is the measured value more than specified value?</p>	10 V	Go to step 3.	Repair power supply line. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between main relay and front oxygen (A/F) sensor connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in main relay connector
<p>3</p> <p>CHECK GROUND CIRCUIT OF ECM. Measure the resistance of harness between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 5 — Chassis ground: (B136) No. 16 — Chassis ground: Is the measured value less than specified value?</p>	5 Ω	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine ground terminal • Poor contact in ECM connector • Poor contact in coupling connector
<p>4</p> <p>CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	0.2 A	Repair poor contact in connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector 	Go to step 5.
<p>5</p> <p>CHECK INPUT SIGNAL FROM ECM. 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 6 (+) — Chassis ground (-): (B136) No. 17 (+) — Chassis ground (-): Is the measured value less than specified value?</p>	1.0 V	Go to step 7.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>6 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 6 (+) — Chassis ground (-):</i> <i>(B136) No. 17 (+) — Chassis ground (-):</i> Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value less than specified value?</p>	1.0 V	Repair poor contact in ECM connector.	Go to step 7.
<p>7 CHECK FRONT OXYGEN (A/F) SENSOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between front oxygen (A/F) sensor connector terminals. <i>Terminals</i> <i>No. 3 — No. 4:</i> Is the measured value less than specified value?</p>	10 Ω	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open or ground short circuit in harness between front oxygen (A/F) sensor and ECM connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector 	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-49, Fuel.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


C: DTC P0032 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1) —

- DTC DETECTING CONDITION:
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, Inspection Mode.>.

- WIRING DIAGRAM:



EN-00266

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>(B136) No. 6 (+) — Chassis ground (-):</i> <i>(B136) No. 17 (+) — Chassis ground (-):</i> Is the measured value more than specified value?</p>	8 V	Go to step 2.	Go to step 3.
<p>2</p> <p>CHECK FRONT OXYGEN (A/F) SENSOR HEATER CURRENT. 1) Turn the ignition switch to OFF. 2) Repair the battery short circuit in harness between ECM and front oxygen (A/F) sensor connector. 3) Turn the ignition switch to ON. 4) Read the data of front oxygen (A/F) sensor heater current using Subaru Select Monitor or the OBD-II general scan tool. Is the measured value more than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	2.3 A	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	END
<p>3</p> <p>CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>(B136) No. 6 (+) — Chassis ground (-):</i> <i>(B136) No. 17 (+) — Chassis ground (-):</i> Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?</p>	8 V	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.	END

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


D: DTC P0037 — HO2S HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2)

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK GROUND CIRCUIT OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 5 — Chassis ground: (B136) No. 16 — Chassis ground:</p> <p>Is the measured value less than specified value?</p>	5 Ω	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine ground terminal • Poor contact in ECM connector • Poor contact in coupling connector
<p>2</p> <p>CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	0.2 A	Repair the connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in rear oxygen sensor connector • Poor contact in rear oxygen sensor connecting harness connector • Poor contact in ECM connector 	Go to step 3.
<p>3</p> <p>CHECK OUTPUT SIGNAL FROM ECM. 1) Start and idle the engine. 2) Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 4 (+) — Chassis ground (-):</p> <p>Is the measured value less than specified value?</p>	1.0 V	Go to step 6.	Go to step 4.
<p>4</p> <p>CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 4 (+) — Chassis ground (-): Shake the ECM harness and connector, while monitoring value of voltage meter. Is the change of measured value within specified value?</p>	1.0 V	Repair poor contact in ECM connector.	Go to step 5.
<p>5</p> <p>CHECK OUTPUT SIGNAL FROM ECM. 1) Disconnect the connector from rear oxygen sensor. 2) Measure the voltage between ECM connector and chassis ground.</p> <p>Connector & terminal (B136) No. 4 (+) — Chassis ground (-):</p> <p>Is the measured value less than specified value?</p>	1.0 V	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Repair battery short circuit in harness between ECM and rear oxygen sensor connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>6</p> <p>CHECK POWER SUPPLY TO REAR OXYGEN SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor connector and engine ground or chassis ground.</p> <p>Connector & terminal (T6) No. 2 (+) — Chassis ground (-):</p> <p>Is the measured value more than specified value?</p>	<p>10 V</p>	<p>Go to step 7.</p>	<p>Repair power supply line.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between main relay and rear oxygen sensor connector • Poor contact in rear oxygen sensor connector • Poor contact in coupling connector
<p>7</p> <p>CHECK REAR OXYGEN SENSOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance between rear oxygen sensor connector terminals.</p> <p>Terminals No. 1 — No. 2:</p> <p>Is the measured value less than specified value?</p>	<p>30 Ω</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector • Poor contact in coupling connector 	<p>Replace the rear oxygen sensor. <Ref. to FU(SOHC)-44, Rear Oxygen Sensor.></p>


E: DTC P0038 — HO2S HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode<Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



Step	Check	Yes	No	
1	<p>CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B136) No. 4 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	8 V	Go to step 2.	Go to step 3.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2 CHECK CURRENT DATA. 1) Turn the ignition switch to OFF. 2) Repair the battery short circuit in harness between ECM and rear oxygen sensor connector. 3) Turn the ignition switch to ON. 4) Read the data of rear oxygen sensor heater current using Subaru Select Monitor or the OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	7 A	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	END
<p>3 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?</p>	Poor contact occurs.	Repair poor contact in ECM connector.	END


F: DTC P0068 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT RANGE/PERFORMANCE —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00268

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK AIR INTAKE SYSTEM. Are there holes, loose bolts or disconnection of hose on air intake system?	There are holes, loose bolts or disconnection of hose.	Repair air intake system.	Go to step 3.
3 CHECK PRESSURE SENSOR. 1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2)Place the shift lever in the selector lever in "N" or "P" position. 3)Turn the A/C switch to OFF. 4)Turn all accessory switches to OFF. 5)Read the data of intake manifold pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.	Ignition ON: 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg), Idling: 20.0 — 46.7 kPa (150 — 350 mmHg, 5.91 — 13.78 inHg)	Go to step 4.	Replace the intake air temperature sensor and pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.>
4 CHECK THROTTLE POSITION. Read the data of throttle position signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value less than specified value when throttle is fully closed? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.	5 %	Go to step 5.	Adjust or replace the throttle position sensor. <Ref. to FU(SOHC)-30, Throttle Position Sensor.>
5 CHECK THROTTLE POSITION. Is the measured value more than specified value when throttle is fully open?	85 %	Replace the pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.>	Replace the throttle position sensor. <Ref. to FU(SOHC)-30, Throttle Position Sensor.>


G: DTC P0107 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT LOW INPUT —

- DTC DETECTING CONDITION:
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- WIRING DIAGRAM:



EN-00268

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK CURRENT DATA. 1)Start the engine. 2)Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value less than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	13.3 kPa (100 mmHg, 3.94 inHg)	Go to step 3.	Go to step 2.
2 CHECK POOR CONTACT. Check poor contact in ECM and pressure sensor connector. Is there poor contact in ECM or pressure sensor connector?	Poor contact occurs.	Repair poor contact in ECM or pressure sensor connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time.
3 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Is the measured value more than specified value?	4.5 V	Go to step 5.	Go to step 4.
4 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?	4.5 V	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
5 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B135) No. 15 (+) — Chassis ground (-): Is the measured value less than specified value?	0.2 V	Go to step 7.	Go to step 6.
6 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.) Read the data of atmospheric absolute pressure signal using Subaru Select Monitor. Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.>	13.3 kPa (100 mmHg, 3.94 inHg)	Repair poor contact in ECM connector.	Go to step 7.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>7</p> <p>CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between pressure sensor connector and engine ground.</p> <p>Connector & terminal (E21) No. 3 (+) — Engine ground (-): Is the measured value more than specified value?</p>	4.5 V	Go to step 8 .	Repair open circuit in harness between ECM and pressure sensor connector.
<p>8</p> <p>CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and pressure sensor connector.</p> <p>Connector & terminal (B135) No. 19 — (E20) No. 1: Is the measured value less than specified value?</p>	1 Ω	Go to step 9 .	Repair open circuit in harness between ECM and pressure sensor connector.
<p>9</p> <p>CHECK POOR CONTACT. Check poor contact in pressure sensor connector. Is there poor contact in pressure sensor connector?</p>	Poor contact occurs.	Repair poor contact in pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


H: DTC P0108 — MANIFOLD ABSOLUTE PRESSURE/BAROMETRIC PRESSURE CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- WIRING DIAGRAM:



EN-00268

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK CURRENT DATA. 1)Start the engine. 2)Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	119.5 kPa (896.5 mmHg, 35.29 inHg)	Go to step 10.	Go to step 2.
2 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Is the measured value more than specified value?	4.5 V	Go to step 4.	Go to step 3.
3 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?	4.5 V	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
4 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 15 (+) — Chassis ground (-): Is the measured value less than specified value?	0.2 V	Go to step 6.	Go to step 5.
5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.) Read the data of atmospheric absolute pressure signal using Subaru Select Monitor. Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.>	13.3 kPa (100 mmHg, 3.94 inHg)	Repair poor contact in ECM connector.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>6 CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from pressure sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between pressure sensor connector and engine ground.</p> <p>Connector & terminal (E21) No. 3 (+) — Engine ground (-): Is the measured value more than specified value?</p>	4.5 V	Go to step 7.	Repair open circuit in harness between ECM and pressure sensor connector.
<p>7 CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance of harness between ECM and pressure sensor connector.</p> <p>Connector & terminal (B135) No. 15 — (E21) No. 2: Is the measured value less than specified value?</p>	1 Ω	Go to step 8.	Repair open circuit in harness between ECM and pressure sensor connector.
<p>8 CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. Measure the resistance of harness between ECM and pressure sensor connector.</p> <p>Connector & terminal (B135) No. 19 — (E21) No. 1: Is the measured value less than specified value?</p>	1 Ω	Go to step 9.	Repair open circuit in harness between ECM and pressure sensor connector.
<p>9 CHECK POOR CONTACT. Check poor contact in pressure sensor connector. Is there poor contact in pressure sensor connector?</p>	Poor contact occurs.	Repair poor contact in pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.>
<p>10 CHECK HARNESS BETWEEN PRESSURE SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF and Subaru Select Monitor or the OBD-II general scan tool switch to OFF. 2) Disconnect the connector from pressure sensor. 3) Turn the ignition switch to ON and Subaru Select Monitor or the OBD-II general scan tool switch to ON. 4) Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	119.5 kPa (896.5 mmHg, 35.29 inHg)	Repair battery short circuit in harness between ECM and pressure sensor connector.	Replace the pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p>CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?</p>	Other DTC is displayed.	<p>Inspect DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).></p> <p>NOTE: In this case, it is not necessary to inspect DTC P0111.</p>	Go to step 2.
2	<p>CHECK ENGINE COOLANT TEMPERATURE. 1)Start the engine and warm it up completely. 2)Measure the engine coolant temperature using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the “READ CURRENT DATA FOR ENGINE”. <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	75°C (167°F) — 95°C (203°F)	Replace the intake air temperature sensor. <Ref. to FU(SOHC)-34, Intake Air Temperature Sensor.>	Inspect DTC P0125 using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>


J: DTC P0112 — INTAKE AIR TEMPERATURE CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK CURRENT DATA.</p> <p>1)Start the engine. 2)Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>120°C (248°F)</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in intake air temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector
<p>2</p> <p>CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1)Turn the ignition switch to OFF. 2)Disconnect the connector from intake air temperature sensor. 3)Turn the ignition switch to ON. 4)Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool. Is the measured value less than specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>-40°C (-40°F)</p>	<p>Replace the intake air temperature sensor. <Ref. to FU(SOHC)-34, Intake Air Temperature Sensor.></p>	<p>Repair ground short circuit in harness between intake air temperature sensor and ECM connector.</p>


K: DTC P0113 — INTAKE AIR TEMPERATURE CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00269

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK CURRENT DATA. 1)Start the engine. 2)Read the data of intake air temperature sensor signal using Subaru Select Monitor or the OBD-II general scan tool. Is the measured value less than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedure, refer to the OBD-II General Scan Tool Instruction Manual.	-40°C (-40°F)	Go to step 2.	Repair poor contact. NOTE: In this case, repair the following: • Poor contact in intake air temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector
2 CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connector from intake air temperature sensor. 3)Measure the voltage between intake air temperature and pressure sensor connector and engine ground. <i>Connector & terminal</i> <i>(E20) No. 1 (+) — Engine ground (-):</i> Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between intake air temperature sensor and ECM connector.	Go to step 3.
3 CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR. 1)Turn the ignition switch to ON. 2)Measure the voltage between intake air temperature sensor connector and engine ground. <i>Connector & terminal</i> <i>(E20) No. 1 (+) — Engine ground (-):</i> Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between intake air temperature sensor and ECM connector.	Go to step 4.
4 CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR. Measure the voltage between intake air temperature sensor connector and engine ground. <i>Connector & terminal</i> <i>(E20) No. 1 (+) — Engine ground (-):</i> Is the measured value more than specified value?	3 V	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between intake air temperature sensor and ECM connector • Poor contact in intake air temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>5</p> <p>CHECK HARNESS BETWEEN INTAKE AIR TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF.</p> <p>2) Measure the resistance of harness between intake air temperature sensor connector and engine ground.</p> <p>Connector & terminal (E20) No. 2 — Engine ground:</p> <p>Is the measured value less than specified value?</p>	<p>5 Ω</p>	<p>Replace the intake air temperature sensor. <Ref. to FU(SOHC)-34, Intake Air Temperature Sensor.></p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between intake air temperature sensor and ECM connector • Poor contact in intake air temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


L: DTC P0117 — ENGINE COOLANT TEMPERATURE CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Hard to start
 - Erroneous idling
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00270

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK CURRENT DATA.</p> <p>1)Start the engine.</p> <p>2)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>Is the measured value more than specified value?</p> <p>NOTE:</p> <ul style="list-style-type: none"> •Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE".</p> <p><Ref. to EN(SOHC)-32, Subaru Select Monitor.></p> <ul style="list-style-type: none"> •OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>150°C (302°F)</p>	<p>Go to step 2.</p>	<p>Repair poor contact.</p> <p>NOTE:</p> <p>In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in engine coolant temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector
<p>2</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1)Turn the ignition switch to OFF.</p> <p>2)Disconnect the connector from engine coolant temperature sensor.</p> <p>3)Turn the ignition switch to ON.</p> <p>4)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool.</p> <p>Is the measured value less than specified value?</p> <p>NOTE:</p> <ul style="list-style-type: none"> •Subaru Select Monitor <p>For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE".</p> <p><Ref. to EN(SOHC)-32, Subaru Select Monitor.></p> <ul style="list-style-type: none"> •OBD-II general scan tool <p>For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>-40°C (-40°F)</p>	<p>Replace the engine coolant temperature sensor. <Ref. to FU(SOHC)-26, Engine Coolant Temperature Sensor.></p>	<p>Repair ground short circuit in harness between engine coolant temperature sensor and ECM connector.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


M: DTC P0118 — ENGINE COOLANT TEMPERATURE CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Hard to start
 - Erroneous idling
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00270

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK CURRENT DATA. 1)Start the engine. 2)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value less than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>-40°C (-40°F)</p>	<p>Go to step 2.</p>	<p>Repair poor contact. NOTE: In this case, repair the following: • Poor contact in engine coolant temperature sensor • Poor contact in ECM • Poor contact in coupling connector • Poor contact in joint connector</p>
<p>2</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connector from engine coolant temperature sensor. 3)Measure the voltage between engine coolant temperature sensor connector and engine ground. <i>Connector & terminal</i> <i>(E8) No. 1 (+) — Engine ground (-):</i> Is the measured value more than specified value?</p>	<p>10 V</p>	<p>Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p>	<p>Go to step 3.</p>
<p>3</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR. 1)Turn the ignition switch to ON. 2)Measure the voltage between engine coolant temperature sensor connector and engine ground. <i>Connector & terminal</i> <i>(E8) No. 1 (+) — Engine ground (-):</i> Is the measured value more than specified value?</p>	<p>10 V</p>	<p>Repair battery short circuit in harness between ECM and engine coolant temperature sensor connector.</p>	<p>Go to step 4.</p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>4</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>Measure the voltage between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 1 (+) — Engine ground (-):</p> <p>Is the measured value more than specified value?</p>	<p>4 V</p>	<p>Go to step 5.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector
<p>5</p> <p>CHECK HARNESS BETWEEN ENGINE COOLANT TEMPERATURE SENSOR AND ECM CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between engine coolant temperature sensor connector and engine ground.</p> <p>Connector & terminal (E8) No. 2 — Engine ground:</p> <p>Is the measured value less than specified value?</p>	<p>5 Ω</p>	<p>Replace the engine coolant temperature sensor. <Ref. to FU(SOHC)-26, Engine Coolant Temperature Sensor.></p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and engine coolant temperature sensor connector • Poor contact in engine coolant temperature sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector


N: DTC P0121 — THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT RANGE/PERFORMANCE —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Engine stalls.
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any the DTC displayed?	Other DTC is displayed.	Inspect DTC P0122 or P0123 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0121.	Replace the throttle position sensor. <Ref. to FU(SOHC)-30, Throttle Position Sensor.>


O: DTC P0122 — THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Engine stalls.
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK CURRENT DATA. 1) Start the engine. 2) Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value less than specified value? NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	0.1 V	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
2 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground while throttle valve is fully closed. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Is the measured value more than specified value?	4.5 V	Go to step 4.	Go to step 3.
3 CHECK OUTPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 3 (+) — Chassis ground (-): Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?	4.5 V	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
4 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 13 (+) — Chassis ground (-): Is the measured value less than specified value?	0.1 V	Go to step 6.	Go to step 5.
5 CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 13 (+) — Chassis ground (-): Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?	0.1 V	Repair poor contact in ECM connector.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>6</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from throttle position sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 4 (+) — Engine ground (-):</p> <p>Is the measured value more than specified value?</p>	4.5 V	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector • Poor contact in joint connector
<p>7</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance of harness between ECM connector and throttle position sensor connector.</p> <p>Connector & terminal (B135) No. 13 — (E13) No. 3:</p> <p>Is the measured value less than specified value?</p>	1 Ω	Go to step 8.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in ECM connector • Poor contact in throttle position sensor connector • Poor contact in coupling connector
<p>8</p> <p>CHECK HARNESS BETWEEN ECM AND THROTTLE POSITION SENSOR CONNECTOR.</p> <p>Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 3 — Engine ground:</p> <p>Is the measured value more than specified value?</p>	1 M Ω	Go to step 9.	Repair ground short circuit in harness between throttle position sensor and ECM connector.
<p>9</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in throttle position sensor connector. Is there poor contact in throttle position sensor connector?</p>	Poor contact occurs.	Repair poor contact in throttle position sensor connector.	Replace the throttle position sensor. <Ref. to FU(SOHC)-30, Throttle Position Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


P: DTC P0123 — THROTTLE/PEDAL POSITION SENSOR/SWITCH “A” CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Engine stalls.
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK CURRENT DATA.</p> <p>1)Start the engine. 2)Read the data of throttle position sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value?</p> <p>NOTE:</p> <ul style="list-style-type: none"> •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. 	4.9 V	Go to step 2.	<p>Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Poor contact in throttle position sensor connector • Poor contact in ECM connector • Poor contact in coupling connector
<p>2</p> <p>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1)Turn the ignition switch to OFF. 2)Disconnect the connector from throttle position sensor. 3)Measure the resistance of harness between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 2 — Engine ground:</p> <p>Is the measured value less than specified value?</p>	5 Ω	Go to step 3.	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between throttle position sensor and ECM connector • Poor contact in coupling connector • Poor contact in joint connector
<p>3</p> <p>CHECK HARNESS BETWEEN THROTTLE POSITION SENSOR AND ECM CONNECTOR.</p> <p>1)Turn the ignition switch to ON. 2)Measure the voltage between throttle position sensor connector and engine ground.</p> <p>Connector & terminal (E13) No. 3 (+) — Engine ground (-):</p> <p>Is the measured value more than specified value?</p>	4.9 V	Repair battery short circuit in harness between throttle position sensor and ECM connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	<p>Replace the throttle position sensor. <Ref. to FU(SOHC)-30, Throttle Position Sensor.></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


Q: DTC P0125 — INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Engine would not return to idling.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC P0117 or P0118 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0125.	Go to step 2.
2	CHECK THERMOSTAT. Does the thermostat remain opened?	Thermostat remain opened.	Replace the thermostat. <Ref. to CO(SOHC)-25, Thermostat.>	Replace the engine coolant temperature sensor. <Ref. to FU(SOHC)-26, Engine Coolant Temperature Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

R: DTC P0129 — BAROMETRIC PRESSURE TOO LOW —

• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	It is not necessary to inspect DTC P0129.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


S: DTC P0130 — O₂ SENSOR CIRCUIT (BANK 1 SENSOR 1) —

- DTC DETECTING CONDITION:
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00266

Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2 CHECK FRONT OXYGEN (A/F) SENSOR DATA. 1)Start the engine. 2)While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (160°F). If the engine is already warmed-up, operate at idle speed for at least 1 minute. 3)Read the data of front oxygen (A/F) sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	0.85 — 1.15	Go to step 3.	Go to step 4.
<p>3 CHECK FRONT OXYGEN (A/F) SENSOR DATA. 1)Race the engine at speeds from idling to 5,000 rpm for a total of 5 cycles. 2)Read the data of front oxygen (A/F) sensor signal during racing using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value? NOTE: •Air fuel ratio is rich at normal condition or during racing. •To increase engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approximately 5 seconds, and quickly release accelerator pedal to decrease engine speed.</p>	1.1 V	Go to step 6.	Go to step 4.
<p>4 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connector from ECM and front oxygen (A/F) sensor connector. 3)Measure the resistance between ECM and front oxygen (A/F) sensor. Is the measured value less than specified value? <i>Connector & terminals</i> <i>(B136) No. 13 — (B18) No. 1:</i> <i>(B136) No. 22 — (B18) No. 2:</i></p>	5 Ω	Go to step 5.	Repair open circuit between ECM and front oxygen (A/F) sensor.
<p>5 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR. Measure the resistance between ECM and chassis ground. Is the measured value more than specified value? <i>Connector & terminals</i> <i>(B136) No. 13 — Chassis ground:</i> <i>(B136) No. 22 — Chassis ground:</i></p>	1 MΩ	Go to step 6.	Repair ground short circuit between ECM and front oxygen (A/F) sensor.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	CHECK EXHAUST SYSTEM. Check exhaust system parts. Is there a fault in exhaust system? NOTE: Check the following items. <ul style="list-style-type: none">•Loose installation of portions•Damage (crack, hole etc.) of parts•Looseness of front oxygen (A/F) sensor•Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	There is a fault.	Repair or replace faulty parts.	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and front oxygen (A/F) sensor connector. 3) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.</p> <p>Connector & terminal (B136) No. 13 — Chassis ground: (B136) No. 22 — Chassis ground:</p> <p>Is the measured value more than specified value?</p>	1 MΩ	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>	Repair ground short circuit in harness between ECM and front oxygen(A/F) sensor connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

U: DTC P0132 — O₂ SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1) —


• DTC DETECTING CONDITION:

- Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00266

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	<p>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from front oxygen (A/F) sensor. 3) Measure the resistance of harness between ECM connector and chassis ground. Is the measured value more than specified value?</p> <p>Connector & terminal (B136) No. 13 — Chassis ground: (B136) No. 22 — Chassis ground:</p>	8 V	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>	Repair battery short circuit in harness between ECM and front oxygen (A/F) sensor connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0133.	Go to step 2.
2	CHECK EXHAUST SYSTEM. Is there a fault in exhaust system? NOTE: Check the following items. <ul style="list-style-type: none">•Loose installation of front portion of exhaust pipe onto cylinder heads•Loose connection between front exhaust pipe and front catalytic converter•Damage of exhaust pipe resulting in a hole	There is a fault.	Repair exhaust system.	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

W: DTC P0134 — O₂ SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1) —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00266

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and front oxygen (A/F) sensor connector. 3) Measure the resistance of harness between ECM and front oxygen (A/F) sensor connector.</p> <p>Connector & terminal (B136) No. 13 — (B18) No. 1: (B136) No. 22 — (B18) No. 2:</p> <p>Is the measured value less than specified value?</p>	<p>1 Ω</p>	<p>Go to step 2.</p>	<p>Repair harness and connector.</p> <p>NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between ECM and front oxygen (A/F) sensor connector • Poor contact in front oxygen (A/F) sensor connector • Poor contact in ECM connector
<p>2</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in front oxygen (A/F) sensor connector.</p> <p>Is there poor contact in front oxygen (A/F) sensor connector?</p>	<p>Poor contact occurs.</p>	<p>Repair poor contact in front oxygen (A/F) sensor connector.</p>	<p>Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

X: DTC P0137 — O₂ SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2) —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00267

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?</p>	DTC P0131, P0132 or P0134 is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0137.	Go to step 2.
<p>2 CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and keep the engine speed at 5,000 rpm for two minutes. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. Does the value fluctuate? NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	490 mV	Go to step 5.	Go to step 3.
<p>3 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. Connector & terminal (B135) No. 14 — (T6) No. 4: (B135) No. 19 — (T6) No. 3: Is the measured value more than specified value?</p>	3 Ω	Repair open circuit in harness between ECM and rear oxygen sensor connector.	Go to step 4.
<p>4 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. Connector & terminal (T6) No. 4 (+) — Engine ground (-): Is the measured value within specified value?</p>	0.2 — 0.5 V	Replace the rear oxygen sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
5 CHECK EXHAUST SYSTEM. Check exhaust system parts. Is there a fault in exhaust system? NOTE: Check the following items. <ul style="list-style-type: none">•Loose installation of portions•Damage (crack, hole etc.) of parts•Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	There is a fault.	Repair or replace faulty parts.	Replace the rear oxygen sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0138.	Go to step 2.
2 CHECK REAR OXYGEN SENSOR DATA. 1) Warm-up the engine until engine coolant temperature is above 70°C (158°F), and immediately decrease the engine speed from 5,000 rpm. 2) Read the data of rear oxygen sensor signal using Subaru Select Monitor or OBD-II general scan tool. Does the value fluctuate? NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA SHOWN ON DISPLAY FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	250 mV	Go to step 5.	Go to step 3.
3 CHECK HARNESS BETWEEN ECM AND REAR OXYGEN SENSOR CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and rear oxygen sensor. 3) Measure the resistance of harness between ECM and rear oxygen sensor connector. Connector & terminal (B135) No. 14 — (T6) No. 4: (B135) No. 19 — (T6) No. 3: Is the measured value more than specified value?	3 Ω	Repair open circuit in harness between ECM and rear oxygen sensor connector.	Go to step 4.
4 CHECK HARNESS BETWEEN REAR OXYGEN SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from rear oxygen sensor. 3) Turn the ignition switch to ON. 4) Measure the voltage between rear oxygen sensor harness connector and engine ground or chassis ground. Connector & terminal (T6) No. 4 (+) — Engine ground (-): Is the measured value within specified value?	0.2 — 0.5 V	Replace the rear oxygen sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between rear oxygen sensor and ECM connector • Poor contact in rear oxygen sensor connector • Poor contact in ECM connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
5 CHECK EXHAUST SYSTEM. Check exhaust system parts. Is there a fault in exhaust system? NOTE: Check the following items. <ul style="list-style-type: none">•Loose installation of portions•Damage (crack, hole etc.) of parts•Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	There is a fault.	Repair or replace faulty parts.	Replace the rear oxygen sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Z: DTC P0139 — O₂ SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 2)


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00267

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0139.	Replace the rear oxygen sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

AA:DTC P0171 — SYSTEM TOO LEAN (BANK 1) —

Refer to DTC P0172 for diagnostic procedure. <Ref. to EN(SOHC)-142, DTC P0172 — SYSTEM TOO RICH (BANK 1) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AB:DTC P0172 — SYSTEM TOO RICH (BANK 1) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Engine stalls.
 - Poor driving performance

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

Step	Check	Yes	No
1 CHECK EXHAUST SYSTEM. Are there holes or loose bolts on exhaust system?	There are holes or loose bolts.	Repair exhaust system.	Go to step 2.
2 CHECK EGR VALVE. Is the EGR valve stuck?	EGR valve is stuck.	Replace the EGR valve.	Go to step 3.
3 CHECK AIR INTAKE SYSTEM. Are there holes, loose bolts or disconnection of hose on air intake system?	There are holes, loose bolts or disconnection of hose.	Repair air intake system.	Go to step 4.
4 CHECK PURGE CONTROL SOLENOID VALVE. Is the purge control solenoid valve stuck?	EGR valve is stuck.	Replace the purge control solenoid valve.	Go to step 5.
5 CHECK PCV VALVE. Is PCV valve operated?	PCV valve is not operated.	Replace the PCV valve.	Go to step 6.
6 CHECK FUEL PRESSURE. Warning: •Place "NO FIRE" signs near the working area. •Be careful not to spill fuel on the floor. 1)Release fuel pressure. (1) Disconnect the connector from fuel pump relay. (2) Start the engine and run it until it stalls. (3) After the engine stalls, crank it for five more seconds. (4) Turn the ignition switch to OFF. 2)Connect the connector to fuel pump relay. 3)Disconnect the fuel delivery hose from fuel filter, and connect fuel pressure gauge. 4)Install the fuel filler cap. 5)Start the engine and idle while gear position is neutral. 6)Measure the fuel pressure while disconnecting pressure regulator vacuum hose from intake manifold. Is the measured value within specified value? Warning: Before removing the fuel pressure gauge, release fuel pressure. NOTE: If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again.	284 — 314 kPa (2.9 — 3.2 kg/cm ² , 41 — 46 psi)	Go to step 7.	Repair the following items. Fuel pressure too high • Clogged fuel return line or bent hose Fuel pressure too low • Improper fuel pump discharge • Clogged fuel supply line

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>7</p> <p>CHECK FUEL PRESSURE. After connecting the pressure regulator vacuum hose, measure fuel pressure. Is the measured value within specified value?</p> <p>Warning: Before removing the fuel pressure gauge, release fuel pressure.</p> <p>NOTE: •If fuel pressure does not increase, squeeze fuel return hose 2 to 3 times, then measure fuel pressure again. •If out of specification as measured at this step, check or replace pressure regulator and pressure regulator vacuum hose.</p>	<p>206 — 235 kPa (2.1 — 2.4 kg/cm², 30 — 34 psi)</p>	<p>Go to step 8.</p>	<p>Repair the following items. Fuel pressure too high</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Clogged fuel return line or bent hose <p>Fuel pressure too low</p> <ul style="list-style-type: none"> • Faulty pressure regulator • Improper fuel pump discharge • Clogged fuel supply line
<p>8</p> <p>CHECK ENGINE COOLANT TEMPERATURE SENSOR. 1)Start the engine and warm-up completely. 2)Read the data of engine coolant temperature sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.</p>	<p>70°C (158°F) — 100°C (212°F)</p>	<p>Go to step 9.</p>	<p>Replace the engine coolant temperature sensor. <Ref. to FU(SOHC)-26, Engine Coolant Temperature Sensor.></p>
<p>9</p> <p>CHECK PRESSURE SENSOR SIGNAL. 1)Start the engine and warm-up engine until coolant temperature is greater than 60°C (140°F). 2)Place the selector lever in "N" or "P" position. 3)Turn the A/C switch to OFF. 4)Turn all accessory switches to OFF. 5)Read the data of pressure sensor signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value?</p> <p>NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual. Specification:</p>	<p>Idling: 24.0 — 41.3 kPa (180 — 310 mmHg, 7.09 — 12.20 inHg) , Ignition ON: 73.3 — 106.6 kPa (550 — 800 mmHg, 21.65 — 31.50 inHg)</p>	<p>Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.</p>	<p>Replace the Pressure sensor. <Ref. to FU(SOHC)-33, Pressure Sensor.></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AC:DTC P0301 — CYLINDER 1 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(SOHC)-145, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AD:DTC P0302 — CYLINDER 2 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(SOHC)-145, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AE:DTC P0303 — CYLINDER 3 MISFIRE DETECTED —

NOTE:

For the diagnostic procedure, refer to DTC P0304. <Ref. to EN(SOHC)-145, DTC P0304 — CYLINDER 4 MISFIRE DETECTED —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

AF:DTC P0304 — CYLINDER 4 MISFIRE DETECTED —

• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault
- Immediately at fault recognition (A misfire which could damage catalyst occurs.)


• TROUBLE SYMPTOM:

- Engine stalls.
- Erroneous idling
- Rough driving

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00265

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0301, P0302, P0303 and P0304.	Go to step 2.
2 CHECK OUTPUT SIGNAL FROM ECM. 1)Turn the ignition switch to ON. 2)Measure the voltage between ECM connector and chassis ground on faulty cylinders. Connector & terminal <i>#1 (B134) No. 34 (+) — Chassis ground (-):</i> <i>#2 (B134) No. 23 (+) — Chassis ground (-):</i> <i>#3 (B134) No. 22 (+) — Chassis ground (-):</i> <i>#4 (B134) No. 8 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10 V	Go to step 7.	Go to step 3.
3 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connector from fuel injector on faulty cylinders. 3)Measure the voltage between ECM connector and engine ground on faulty cylinders. Connector & terminal <i>#1 (E5) No. 1 — Engine ground:</i> <i>#2 (E16) No. 1 — Engine ground:</i> <i>#3 (E6) No. 1 — Engine ground:</i> <i>#4 (E17) No. 1 — Engine ground:</i> Is the measured value more than specified value?	1 M Ω	Go to step 4.	Repair ground short circuit in harness between fuel injector and ECM connector.
4 CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. Measure the resistance of harness connector between ECM connector and fuel injector on faulty cylinders. Connector & terminal <i>#1 (B134) No. 34 — (E5) No. 1:</i> <i>#2 (B134) No. 23 — (E16) No. 1:</i> <i>#3 (B134) No. 22 — (E6) No. 1:</i> <i>#4 (B134) No. 8 — (E17) No. 1:</i> Is the measured value less than specified value?	1 Ω	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and fuel injector connector • Poor contact in coupling connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>5</p> <p>CHECK FUEL INJECTOR. Measure the resistance between fuel injector terminals on faulty cylinder.</p> <p>Terminals No. 1 — No. 2: Is the measured value within specified value?</p>	5 — 20 Ω	Go to step 6.	Replace the faulty fuel injector. <Ref. to FU(SOHC)-37, Fuel Injector.>
<p>6</p> <p>CHECK POWER SUPPLY LINE. 1) Turn the ignition switch to ON. 2) Measure the voltage between fuel injector and engine ground on faulty cylinders.</p> <p>Connector & terminal #1 (E5) No. 2 (+) — Engine ground (-): #2 (E16) No. 2 (+) — Engine ground (-): #3 (E6) No. 2 (+) — Engine ground (-): #4 (E17) No. 2 (+) — Engine ground (-): Is the measured value more than specified value?</p>	10 V	Repair poor contact in all connectors in fuel injector circuit.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between main relay and fuel injector connector on faulty cylinders • Poor contact in coupling connector • Poor contact in main relay connector • Poor contact in fuel injector connector on faulty cylinders
<p>7</p> <p>CHECK HARNESS BETWEEN FUEL INJECTOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel injector on faulty cylinder. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM connector and chassis ground on faulty cylinders.</p> <p>Connector & terminal #1 (B134) No. 34 (+) — Chassis ground (-): #2 (B134) No. 23 (+) — Chassis ground (-): #3 (B134) No. 22 (+) — Chassis ground (-): #4 (B134) No. 8 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	10 V	Repair battery short circuit in harness between ECM and fuel injector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 8.
<p>8</p> <p>CHECK FUEL INJECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between fuel injector terminals on faulty cylinder.</p> <p>Terminals No. 1 — No. 2: Is the measured value less than specified value?</p>	1 Ω	Replace the faulty fuel injector <Ref. to FU(SOHC)-37, Fuel Injector.> and ECM <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 9.
<p>9</p> <p>CHECK INSTALLATION OF CAMSHAFT POSITION SENSOR/CRANKSHAFT POSITION SENSOR. Is the camshaft position sensor or crankshaft position sensor loosely installed?</p>	Sensor is loosely installed.	Tighten camshaft position sensor or crankshaft position sensor.	Go to step 10.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
10 CHECK CRANKSHAFT SPROCKET. Remove the timing belt cover. Is the crankshaft sprocket rusted or does it have broken teeth?	Sprocket is rusted or teeth is broken.	Replace the crankshaft sprocket. <Ref. to ME(SOHC)-53, Crankshaft Sprocket.>	Go to step 11 .
11 CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500CRANKSHAFT SOCKET Is the timing belt dislocated from its proper position?	Belt is dislocated.	Repair installation condition of timing belt. <Ref. to ME(SOHC)-46, Timing Belt Assembly.>	Go to step 12 .
12 CHECK FUEL LEVEL. Is the fuel meter indication higher than the "Lower" level?	Indication is higher than the "Lower" level.	Go to step 13 .	Replenish fuel so fuel meter indication is higher than the "Lower" level. After replenishing fuel, Go to step 13 .
13 CHECK STATUS OF CHECK ENGINE MALFUNCTION INDICATOR LAMP (MIL). 1)Clear the memory using Subaru Select Monitor. <Ref. to EN(SOHC)-47, Clear Memory Mode.> 2)Start the engine, and drive the vehicle more than 10 minutes. Does the MIL illuminate or blink?	MIL illuminates or blinks.	Go to step 15 .	Go to step 14 .

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
14 CHECK CAUSE OF MISFIRE DIAGNOSED. Was the cause of misfire identified when the engine is running. Ex. Disconnection of spark plug cord.	Cause of misfire is identified.	Finish diagnostics operation, if the engine has no abnormality.	1. Repair poor contact. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in ignitor connector • Poor contact in ignition coil connector • Poor contact in fuel injector connector on faulty cylinders • Poor contact in ECM connector • Poor contact in coupling connector 2. If there is no poor contact, check the followings and contact with your Subaru distributor service. <ul style="list-style-type: none"> • Fuel condition • Whether addition agent is used or not • Plug condition • Plug cord condition • Engine oil condition
15 CHECK AIR INTAKE SYSTEM. Is there a fault in air intake system?	There is a fault.	Repair air intake system. NOTE: Check the following items: <ul style="list-style-type: none"> • Are there air leaks or air suction caused by loose or dislocated nuts and bolts? • Are there cracks or any disconnection of hoses? 	Go to step 16 .

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
16 CHECK MISFIRE SYMPTOM. 1) Turn the ignition switch to ON. 2) Read the diagnostic trouble code (DTC). • Subaru Select Monitor <Ref. to EN(SOHC)-32, Subaru Select Monitor.> • OBD-II general scan tool Does the Subaru Select Monitor or OBD-II general scan tool display only one DTC? For detailed operation procedures, refer to the OBD-II General Scan Tool Operation Manual. NOTE: Perform diagnosis according to the items listed below.	Only one DTC is displayed.	Go to step 21 .	Go to step 17 .
17 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 22 .	Go to step 18 .
18 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 23 .	Go to step 19 .
19 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 24 .	Go to step 20 .
20 CHECK DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 25 .	Go to step 26 .
21 ONLY ONE CYLINDER Is there a fault in that cylinder?	There is a fault.	Repair or replace faulty parts. NOTE: Check the following items. • Spark plug • Spark plug cord • Fuel injector • Compression ratio	Go to DTC P0171. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
22 GROUP OF #1 AND #2 CYLINDERS Are there faults in #1 and #2 cylinders?	There are faults.	Repair or replace faulty parts. NOTE: • Check the following items. • Spark plugs • Fuel injectors • Ignition coil • Compression ratio • If no abnormal is discovered, check for "IGNITION CONTROL SYSTEM" of #1 and #2 cylinders side. <Ref. to EN(SOHC)-67, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Go to DTC P0171. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
23 GROUP OF #3 AND #4 CYLINDERS Are there faults in #3 and #4 cylinders?	There are faults.	Repair or replace faulty parts. NOTE: • Check the following items. • Spark plugs • Fuel injectors • Ignition coil • If no abnormal is discovered, check for "16. D: IGNITION CONTROL SYSTEM" of #3 and #4 cylinders side. <Ref. to EN(SOHC)-67, IGNITION CONTROL SYSTEM, Diagnostics for Engine Starting Failure.>	Go to DTC P0171. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
24 GROUP OF #1 AND #3 CYLINDERS Are there faults in #1 and #3 cylinders?	There are faults.	Repair or replace faulty parts. NOTE: Check the following items. • Spark plugs • Fuel injectors • Skipping timing belt teeth	Go to DTC P0171. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
25 GROUP OF #2 AND #4 CYLINDERS Are there faults in #2 and #4 cylinders?	There are faults.	Repair or replace faulty parts. NOTE: Check the following items. • Spark plugs • Fuel injectors • Compression ratio • Skipping timing belt teeth	Go to DTC P0171. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>
26 CYLINDER AT RANDOM Is the engine idle rough?	Engine idle is rough.	Go to DTC P0170. <Ref. to EN(SOHC)-141, DTC P0171 — SYSTEM TOO LEAN (BANK 1) — , Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Repair or replace faulty parts. NOTE: Check the following items. • Spark plugs • Fuel injectors • Compression ratio

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AG:DTC P0327 — KNOCK SENSOR 1 CIRCUIT LOW INPUT (BANK 1 OR SINGLE SENSOR) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Poor driving performance
 - Knocking occurs.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM. 3) Measure the resistance between ECM harness connector and chassis ground.</p> <p>Connector & terminal (B135) No. 16 — Chassis ground:</p> <p>Is the measured value more than specified value?</p>	700 kΩ	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between knock sensor and ECM connector • Poor contact in knock sensor connector • Poor contact in coupling connector
<p>2</p> <p>CHECK KNOCK SENSOR. 1) Disconnect the connector from knock sensor. 2) Measure the resistance between knock sensor connector terminal and engine ground.</p> <p>Terminal No. 2 — Engine ground:</p> <p>Is the measured value more than specified value?</p>	700 kΩ	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between knock sensor and ECM connector • Poor contact in knock sensor connector • Poor contact in coupling connector
<p>3</p> <p>CHECK CONDITION OF KNOCK SENSOR INSTALLATION. Is the knock sensor installation bolt tightened securely?</p>	Bolt is tightened securely.	Replace the knock sensor. <Ref. to FU(SOHC)-29, Knock Sensor.>	Tighten knock sensor installation bolt securely.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AH:DTC P0328 — KNOCK SENSOR 1 CIRCUIT HIGH INPUT (BANK 1 OR SINGLE SENSOR) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Poor driving performance
 - Knocking occurs.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK HARNESS BETWEEN KNOCK SENSOR AND ECM CONNECTOR. Measure the resistance of harness between ECM connector and chassis ground. Connector & terminal (B135) No. 16 — Chassis ground: Is the measured value less than specified value?</p>	400 kΩ	Go to step 2.	Go to step 3.
<p>2</p> <p>CHECK KNOCK SENSOR. 1)Disconnect the connector from knock sensor. 2)Measure the resistance between knock sensor connector terminal and engine ground. Terminal No. 2 — Engine ground: Is the measured value less than specified value?</p>	400 kΩ	Replace the knock sensor. <Ref. to FU(SOHC)-29, Knock Sensor.>	Repair ground short circuit in harness between knock sensor connector and ECM connector. NOTE: The harness between both connectors is shielded. Repair short circuit of harness together with shield.
<p>3</p> <p>CHECK INPUT SIGNAL FOR ECM. 1)Connect the connectors to ECM and knock sensor. 2)Turn the ignition switch to ON. 3)Measure the voltage between ECM and chassis ground. Connector & terminal (B135) No. 16 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	2 V	Even if MIL lights up, the circuit has returned to a normal condition at this time. (However, the possibility of poor contact still remains.) NOTE: In this case, repair the following: • Poor contact in knock sensor connector • Poor contact in ECM connector • Poor contact in coupling connector	Repair poor contact in ECM connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AI: DTC P0335 — CRANKSHAFT POSITION SENSOR “A” CIRCUIT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Engine stalls.
 - Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00273

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from crankshaft position sensor. 3) Measure the resistance of harness between crankshaft position sensor connector and engine ground. Connector & terminal (E10) No. 1 — Engine ground: Is the measured value more than specified value?</p>	100 k Ω	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between crankshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector	Go to step 2.
<p>2 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between crankshaft position sensor connector and engine ground. Connector & terminal (E10) No. 1 — Engine ground: Is the measured value less than specified value?</p>	10 Ω	Repair ground short circuit in harness between crankshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 3.
<p>3 CHECK HARNESS BETWEEN CRANKSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between crankshaft position sensor connector and engine ground. Connector & terminal (E10) No. 2 — Engine ground: Is the measured value less than specified value? Is the measured value less than specified value?</p>	5 Ω	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between crankshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector
<p>4 CHECK CONDITION OF CRANKSHAFT POSITION SENSOR. Is the crankshaft position sensor installation bolt tightened securely?</p>	Bolt is tightened securely.	Go to step 5.	Tighten crankshaft position sensor installation bolt securely.
<p>5 CHECK CRANKSHAFT POSITION SENSOR. 1) Remove the crankshaft position sensor. 2) Measure the resistance between connector terminals of crankshaft position sensor. Terminals No. 1 — No. 2: Is the measured value within specified value?</p>	1 — 4 k Ω	Repair poor contact in crankshaft position sensor connector.	Replace the crankshaft position sensor. <Ref. to FU(SOHC)-27, Crankshaft Position Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AJ:DTC P0336 — CRANKSHAFT POSITION SENSOR “A” CIRCUIT RANGE/ PERFORMANCE —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Engine stalls.
 - Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC P0335 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	CHECK CONDITION OF CRANKSHAFT POSITION SENSOR. Turn the ignition switch to OFF. Is the crankshaft position sensor installation bolt tightened securely?	Bolt is tightened security.	Go to step 3.	Tighten crankshaft position sensor installation bolt securely.
3	CHECK CRANKSHAFT SPROCKET. Remove the front belt cover. Are crankshaft sprocket teeth cracked or damaged?	There is crack or damage.	Replace the crankshaft sprocket. <Ref. to ME(SOHC)-53, Crankshaft Sprocket.>	Go to step 4.
4	CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the crankshaft using ST, and align alignment mark on crankshaft sprocket with alignment mark on cylinder block. ST 499987500CRANKSHAFT SOCKET Is the timing belt dislocated from its proper position?	Belt is dislocated.	Repair installation condition of timing belt. <Ref. to ME(SOHC)-46, Timing Belt Assembly.>	Replace the crankshaft position sensor. <Ref. to <Ref. to FU(SOHC)-27, Crankshaft Position Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AK:DTC P0340 — CAMSHAFT POSITION SENSOR “A” CIRCUIT (BANK 1 OR SINGLE SENSOR) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Engine stalls.
 - Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00274

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: Is the measured value more than specified value?</p>	100 k Ω	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector	Go to step 2.
<p>2 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: Is the measured value less than specified value?</p>	10 Ω	Repair ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 3.
<p>3 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 2 — Engine ground: Is the measured value less than specified value?</p>	5 Ω	Go to step 4.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector
<p>4 CHECK CONDITION OF CAMSHAFT POSITION SENSOR. Is the camshaft position sensor installation bolt tightened securely?</p>	Bolt is tightened securely.	Go to step 5.	Tighten camshaft position sensor installation bolt securely.
<p>5 CHECK CAMSHAFT POSITION SENSOR. 1) Remove the camshaft position sensor. 2) Measure the resistance between connector terminals of camshaft position sensor. Terminals No. 1 — No. 2: Is the measured value within specified value?</p>	1 — 4 k Ω	Repair poor contact in camshaft position sensor connector.	Replace the camshaft position sensor. <Ref. to FU(SOHC)-28, Camshaft Position Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AL:DTC P0341 — CAMSHAFT POSITION SENSOR “A” CIRCUIT RANGE/PERFORMANCE (BANK 1 OR SINGLE SENSOR) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Engine stalls.
 - Failure of engine to start

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00274

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from camshaft position sensor. 3) Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: Is the measured value more than specified value?	100 k Ω	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector 	Go to step 3.
3 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 1 — Engine ground: Is the measured value less than specified value?	10 Ω	Repair ground short circuit in harness between camshaft position sensor and ECM connector. NOTE: The harness between both connectors are shielded. Repair ground short circuit in harness together with shield.	Go to step 4.
4 CHECK HARNESS BETWEEN CAMSHAFT POSITION SENSOR AND ECM CONNECTOR. Measure the resistance of harness between camshaft position sensor connector and engine ground. Connector & terminal (E15) No. 2 — Engine ground: Is the measured value less than specified value?	5 Ω	Go to step 5.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between camshaft position sensor and ECM connector • Poor contact in ECM connector • Poor contact in coupling connector
5 CHECK CONDITION OF CAMSHAFT POSITION SENSOR. Is the camshaft position sensor installation bolt tightened securely?	Bolt is tightened securely.	Go to step 6.	Tighten camshaft position sensor installation bolt securely.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
6 CHECK CAMSHAFT POSITION SENSOR. 1)Remove the camshaft position sensor. 2)Measure the resistance between connector terminals of camshaft position sensor. Terminals No. 1 — No. 2: Is the measured value within specified value?	1 — 4 kΩ	Go to step 7.	Replace the camshaft position sensor. <Ref. to FU(SOHC)-28, Camshaft Position Sensor.>
7 CHECK CONDITION OF CAMSHAFT POSITION SENSOR. Turn the ignition switch to OFF. Is the camshaft position sensor installation bolt tightened securely?	Bolt is tightened securely.	Go to step 8.	Tighten camshaft position sensor installation bolt securely.
8 CHECK CAMSHAFT SPROCKET. Remove the front belt cover. <Ref. to ME(SOHC)-45, Belt Cover.> Are camshaft sprocket teeth cracked or damaged?	There is crack or damage.	Replace the camshaft sprocket. <Ref. to ME(SOHC)-51, Camshaft Sprocket.>	Go to step 9.
9 CHECK INSTALLATION CONDITION OF TIMING BELT. Turn the camshaft using ST, and align alignment mark on camshaft sprocket with alignment mark on timing belt cover LH. ST 499207100 CAMSHAFT SPROCKET WRENCH Is the timing belt dislocated from its proper position?	Belt is dislocated.	Repair installation condition of timing belt. <Ref. to ME(SOHC)-46, Timing Belt Assembly.>	Replace the camshaft position sensor. <Ref. to FU(SOHC)-28, Camshaft Position Sensor.>


AM:DTC P0400 — EXHAUST GAS RECIRCULATION FLOW —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Poor driving performance on low engine speed
 - Erroneous idling
 - Poor driving performance.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00284

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is there any other DTC on display?	Other DTC is displayed.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK CURRENT DATA. 1)Start engine. 2)Read the data of intake manifold absolute pressure signal using Subaru Select Monitor or OBD-II general scan tool. Is the measured value more than specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	53.3 kPa (400 mmHg, 15.75 inHg)	Check if EGR valve, intake manifold pressure sensor and throttle body are securely installed.	Go to step 3.
3 CHECK POWER SUPPLY TO EGR SOLENOID VALVE. 1)Disconnect connector from EGR solenoid valve. 2)Turn ignition switch to ON. 3)Measure voltage between EGR solenoid valve and engine ground. Connector & terminal (E18) No. 2 — Engine ground: (E18) No. 5 — Engine ground: Is the measured value more than specified value?	10 V	Go to step 4.	Repair open circuit in harness between main relay and EGR solenoid valve connector.
4 CHECK EGR SOLENOID VALVE. Measure resistance between EGR solenoid valve terminals. NOTE: Make sure there are no foreign objects caught between EGR solenoid valve and valve seat. Terminals No. 1 — No. 2: No. 3 — No. 2: No. 4 — No. 5: No. 6 — No. 5: Is the measured value within specified value?	20 — 30 Ω	Go to step 5.	Replace EGR solenoid valve. <Ref. to EC(SOHC)-7, EGR Valve.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>5 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn ignition switch to OFF. 2) Connect connectors to ECM and EGR solenoid valve. 3) Turn ignition switch to ON. 4) Measure voltage between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 15 — Chassis ground: (B134) No. 16 — Chassis ground: (B134) No. 17 — Chassis ground: (B134) No. 18 — Chassis ground:</p> <p>Is the measured value within specified value?</p>	0 — 10 V	Repair poor contact in ECM connector.	Go to step 6.
<p>6 CHECK HARNESS BETWEEN EGR SOLENOID VALVE AND ECM CONNECTOR. 1) Turn ignition switch to OFF. 2) Disconnect connectors from EGR solenoid valve and ECM. 3) Measure resistance of harness between EGR solenoid valve and ECM connector.</p> <p>Connector & terminal (B134) No. 18 — (E18) No. 6: (B134) No. 17 — (E18) No. 1: (B134) No. 16 — (E18) No. 4: (B134) No. 15 — (E18) No. 3:</p> <p>Is the measured value less than specified value?</p>	1 Ω	Go to step 7.	Repair open circuit in harness between ECM and EGR solenoid valve connector.
<p>7 CHECK HARNESS BETWEEN EGR SOLENOID VALVE AND ECM CONNECTOR. Measure resistance of harness between EGR solenoid valve and chassis ground.</p> <p>Connector & terminal (B134) No. 15 — Chassis ground: (B134) No. 16 — Chassis ground: (B134) No. 17 — Chassis ground: (B134) No. 18 — Chassis ground:</p> <p>Is the measured value more than specified value?</p>	1 MΩ	Go to step 8.	Repair short circuit in harness between main relay and EGR solenoid valve connector.
<p>8 CHECK POOR CONTACT. Check poor contact in ECM and EGR solenoid valve connector. Is there poor contact in ECM and EGR solenoid valve connector?</p>	Poor contact occurs.	Repair poor contact in ECM and EGR solenoid valve connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AN:DTC P0420 — CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD (BANK 1) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Engine stalls.
 - Idle mixture is out of specifications.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00275

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0420.	Go to step 2.
2	CHECK EXHAUST SYSTEM. Check for gas leaks or air suction caused by loose or dislocated nuts and bolts, and open hole at exhaust pipes. Is there a fault in exhaust system? NOTE: Check the following positions. •Between cylinder head and front exhaust pipe •Between front exhaust pipe and front catalytic converter •Between front catalytic converter and rear catalytic converter	There is a fault.	Repair or replace the exhaust system. <Ref. to EX(SOHC)-2, General Description.>	Go to step 3.
3	CHECK CATALYTIC CONVERTER. Remove the catalytic converter. Is there damage at rear face or front face of front catalyst?	There is damage.	Replace the catalytic converter. <Ref. to EC(SOHC)-3, Front Catalytic Converter.>	Go to step 5.
4	CHECK REAR OXYGEN SENSOR GROUND HARNESS. 1)Disconnect the rear oxygen sensor and ECM connectors. 2)Measure the resistance between rear oxygen sensor connector and ECM connector. Connector & terminal (T6) No. 3 — (B135) No. 19: Is the measured value less than specified value?	1 Ω	Go to step 5.	Repair the open circuit in harness between ECM and rear oxygen sensor.
5	CHECK SHIELD HARNESS. Is the shield harness opened?	Shield harness is not opened.	Contact with your Subaru distributor service.	Repair the shield harness.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AO:DTC P0458 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT LOW —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 29 (+) — Chassis ground (-):</i> Is the measured value more than specified value?</p>	10 V	Even if MIL lights up, the circuit has returned to a normal condition at this time. Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.	Go to step 2.
<p>2</p> <p>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from purge control solenoid valve and ECM. 3) Measure the resistance of harness between purge control solenoid valve connector and engine ground. <i>Connector & terminal</i> <i>(E4) No. 2 — Engine ground:</i> Is the measured value less than specified value?</p>	1 M Ω	Go to step 3.	Repair ground short circuit in harness between ECM and purge control solenoid valve connector.
<p>3</p> <p>CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. Measure the resistance of harness between ECM and purge control solenoid valve of harness connector. <i>Connector & terminal</i> <i>(B134) No. 29 — (E4) No. 2:</i> Is the measured value less than specified value?</p>	1 Ω	Go to step 4.	Repair open circuit in harness between ECM and purge control solenoid valve connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and purge control solenoid valve connector • Poor contact in coupling connector
<p>4</p> <p>CHECK PURGE CONTROL SOLENOID VALVE. 1) Remove the purge control solenoid valve. 2) Measure the resistance between purge control solenoid valve terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> Is the measured value within specified value?</p>	10 — 100 Ω	Go to step 5.	Replace the purge control solenoid valve. <Ref. to EC(SOHC)-9, Purge Control Solenoid Valve.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
5	CHECK POWER SUPPLY TO PURGE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to ON. 2) Measure the voltage between purge control solenoid valve and engine ground. Connector & terminal (E4) No. 1 (+) — Engine ground (-): Is the measured value more than specified value?	10 V	Go to step 6.	Repair open circuit in harness between main relay and purge control solenoid valve connector.
6	CHECK POOR CONTACT. Check poor contact in purge control solenoid valve connector. Is there poor contact in purge control solenoid valve connector?	Poor contact occurs.	Repair poor contact in purge control solenoid valve connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.


AP:DTC P0459 — EVAPORATIVE EMISSION CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT HIGH —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn the ignition switch to ON. 4) While operating the purge control solenoid valve, measure voltage between ECM and chassis ground. Is the change of measured value within specified value? NOTE: Purge control solenoid valve operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(SOHC)-48, Compulsory Valve Operation Check Mode.> Connector & terminal (B134) No. 29 (+) — Chassis ground (-):	0 — 10 V	Go to step 2.	Even if MIL light up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.
2 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B137) No. 29 (+) — Chassis ground (-): Is the measured value more than specified value?	10 V	Go to step 4.	Go to step 3.
3 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>
4 CHECK HARNESS BETWEEN PURGE CONTROL SOLENOID VALVE AND ECM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from purge control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM and chassis ground. Connector & terminal (B134) No. 29 (+) — Chassis ground (-): Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and purge control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 5.
5 CHECK PURGE CONTROL SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Measure the resistance between purge control solenoid valve terminals. Terminals No. 1 — No. 2: Is the measured value less than specified value?	1 Ω	Replace the purge control solenoid valve <Ref. to EC(SOHC)-9, Purge Control Solenoid Valve.> and ECM <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
6	CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AQ:DTC P0461 — FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect this trouble.	Replace the fuel level sensor <Ref. to FU(SOHC)-59, Fuel Level Sensor.> and fuel sub level sensor <Ref. to FU(SOHC)-59, Fuel Level Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AR:DTC P0462 — FUEL LEVEL SENSOR CIRCUIT LOW INPUT —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00277

Step	Check	Yes	No
1	<p>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</p> <p>Does the speedometer and tachometer operate normally?</p>	Meters operate normally. Go to step 2.	Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2</p> <p>CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. (Engine OFF) 2) Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 25 (+) — Chassis ground (-):</i> Is the measured value less than specified value?</p>	0.12 V	Go to step 4.	Go to step 3.
<p>3</p> <p>CHECK INPUT SIGNAL FOR ECM. (USING SUBARU SELECT MONITOR.) Read the data of fuel level sensor signal using Subaru Select Monitor. Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value less than specified value? NOTE: • Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.></p>	0.12 V	Repair poor contact in ECM connector.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: • Poor contact in combination meter connector • Poor contact in ECM connector • Poor contact in coupling connectors
<p>4</p> <p>CHECK INPUT VOLTAGE OF ECM. 1) Turn the ignition switch to OFF. 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 25 (+) — Chassis ground (-):</i> Is the measured value more than specified value?</p>	0.12 V	Go to step 5.	Go to step 6.
<p>5</p> <p>CHECK HARNESS BETWEEN ECM AND COMBINATION METER. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from connector (i10) and ECM connector. 3) Measure the resistance between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 25 — Chassis ground:</i> Is the measured value more than specified value?</p>	1 MΩ	Go to step 7.	Repair ground short circuit in harness between ECM and combination meter connector.
<p>6</p> <p>CHECK HARNESS BETWEEN ECM AND COMBINATION METER. Measure the resistance between ECM and combination meter connector. <i>Connector & terminal</i> <i>(B135) No. 25 — (i10) No. 3:</i> Is the measured value less than specified value?</p>	10 Ω	Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.>	Repair open circuit between ECM and combination meter connector. NOTE: In this case, repair the following: Poor contact in coupling connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
7 CHECK FUEL TANK CORD. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from fuel sub level sensor. 3) Measure the resistance between fuel sub level sensor and chassis ground. Connector & terminal (R51) No. 1 — Chassis ground: Is the measured value more than specified value?	1 MΩ	Go to step 8.	Repair ground short circuit in fuel tank cord.
8 CHECK FUEL TANK CORD. 1) Disconnect the connector from fuel pump assembly. 2) Measure the resistance between fuel pump assembly and chassis ground. Connector & terminal (R51) No. 2 — Chassis ground: Is the measured value more than specified value?	1 MΩ	Go to step 9.	Repair ground short circuit in fuel tank cord.
9 CHECK FUEL LEVEL SENSOR. 1) Remove the fuel pump assembly. <Ref. to FU(SOHC)-57, Fuel Pump.> 2) Measure the resistance between fuel level sensor and terminals with its float set to the full position. Terminals RHD model No. 3 — No. 5: LHD model No. 3 — No. 4: Is the measured value within specified value?	0.5 — 2.5 Ω	Go to step 10.	Replace the fuel level sensor.
10 CHECK FUEL SUB LEVEL SENSOR. 1) Remove the fuel sub level sensor. <Ref. to FU(SOHC)-60, Fuel Sub Level Sensor.> 2) Measure the resistance between fuel sub level sensor and terminals with its float set to the full position. Terminals No. 1 — No. 2: Is the measured value within specified value?	0.5 — 2.5 Ω	Repair poor contact in harness between ECM and combination meter connector.	Replace the fuel sub level sensor.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AS:DTC P0463 — FUEL LEVEL SENSOR CIRCUIT HIGH INPUT —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



Step	Check	Yes	No
1	<p>CHECK SPEEDOMETER AND TACHOMETER OPERATION IN COMBINATION METER.</p> <p>Does the speedometer and tachometer operate normally?</p>	Meters operates normally. Go to step 2.	Repair or replace the combination meter. <Ref. to IDI-3, Combination Meter System.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. (Engine OFF) 2) Measure the voltage between ECM connector and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	4.75 V	Go to step 3.	Even if MIL lights up, the circuit has returned to a normal condition at this time. A temporary poor contact of the connector may be the cause. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Poor contact in fuel pump connector • Poor contact in coupling connector
<p>3 CHECK INPUT VOLTAGE OF ECM. 1) Turn the ignition switch to OFF. 2) Disconnect the combination meter connector (i11) and ECM connector. 3) Turn the ignition switch to ON. 4) Measure the voltage of harness between ECM and chassis ground. Connector & terminal (B135) No. 25 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	4.75 V	Go to step 4.	Repair battery short circuit between ECM and combination meter connector.
<p>4 CHECK HARNESS BETWEEN ECM AND FUEL TANK CORD. 1) Turn the ignition switch to OFF. 2) Separate fuel tank cord connector (R57) and rear wiring harness connector (R15). 3) Measure the resistance between ECM and fuel tank cord. Connector & terminal (B135) No. 25 — (R15) No. 2: Is the measured value less than specified value?</p>	5 Ω	Go to step 5.	Repair open circuit between ECM and fuel tank cord.
<p>5 CHECK HARNESS BETWEEN FUEL TANK CORD AND CHASSIS GROUND. Measure the resistance between fuel tank cord and chassis ground. Connector & terminal (R15) No. 3 — Chassis ground: Is the measured value less than specified value?</p>	5 Ω	Go to step 6.	Repair open circuit between fuel tank cord and chassis ground. NOTE: In this case, repair the following: Poor contact in coupling connectors

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
6 CHECK FUEL TANK CORD. 1)Disconnect the connector from fuel level sensor. 2)Measure the resistance between fuel level sensor and coupling connector. <i>Connector & terminal</i> <i>RHD model</i> <i>(R57) No. 3 — (R52) No. 5:</i> <i>LHD model</i> <i>(R57) No. 3 — (R52) No. 4:</i> Is the measured value less than specified value?	10 Ω	Go to step 7.	Repair open circuit between coupling connector and fuel level sensor.
7 CHECK FUEL TANK CORD. 1)Disconnect the connector from fuel sub level sensor. 2)Measure the resistance between fuel level sensor and fuel sub level sensor. <i>Connector & terminal</i> <i>(R52) No. 3 — (R51) No. 2:</i> Is the measured value less than specified value?	10 Ω	Go to step 8.	Repair open circuit between fuel level sensor and fuel sub level sensor.
8 CHECK FUEL TANK CORD. Measure the resistance between fuel sub level sensor and coupling connector. <i>Connector & terminal</i> <i>(R57) No. 2 — (R51) No. 1:</i> Is the measured value less than specified value?	10 Ω	Go to step 9.	Repair open circuit between coupling connector and fuel sub level sensor.
9 CHECK FUEL LEVEL SENSOR. 1)Remove the fuel pump assembly. <Ref. to FU(SOHC)-57, Fuel Pump.> 2)While moving the fuel level sensor float up and down, measure resistance between fuel level sensor terminals. <i>Terminals</i> <i>RHD model</i> <i>No. 3 — No. 5:</i> <i>LHD model</i> <i>No. 3 — No. 4:</i> Is the measured value more than specified value?	54.5 Ω	Replace the fuel level sensor. <Ref. to FU(SOHC)-59, Fuel Level Sensor.>	Go to step 10.
10 CHECK FUEL SUB LEVEL SENSOR. 1)Remove the fuel sub level sensor. <Ref. to FU(SOHC)-60, Fuel Sub Level Sensor.> 2)While moving the fuel sub level sensor float up and down, measure resistance between fuel sub level sensor terminals. <i>Terminals</i> <i>No. 1 — No. 2:</i> Is the measured value more than specified value?	41.5 Ω	Replace the fuel sub level sensor. <Ref. to FU(SOHC)-60, Fuel Sub Level Sensor.>	Replace the combination meter. <Ref. to IDI-12, Combination Meter Assembly.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AT:DTC P0464 — FUEL LEVEL SENSOR CIRCUIT INTERMITTENT —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00277

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC P0462 or P0463 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK FUEL LEVEL SENSOR. 1)Remove the fuel pump assembly. <Ref. to FU(SOHC)-57, Fuel Pump.> 2)While moving the fuel level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. Terminals RHD model No. 3 — No. 5: LHD model No. 3 — No. 4: Does the resistance change smoothly?	Resistance changes smoothly.	Go to step 3.	Replace the fuel level sensor. <Ref. to FU(SOHC)-59, Fuel Level Sensor.>
3 CHECK FUEL SUB LEVEL SENSOR. 1)Remove the fuel sub level sensor. <Ref. to FU(SOHC)-59, Fuel Level Sensor.> 2)While moving the fuel sub level sensor float up and down, make sure that the resistance between fuel level sensor terminals changes smoothly. Terminals No. 1 — No. 2: Does the resistance change smoothly?	Resistance changes smoothly.	Repair poor contact in ECM, combination meter and coupling connectors.	Replace the fuel sub level sensor. <Ref. to FU(SOHC)-59, Fuel Level Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AU:DTC P0483 — COOLING FAN RATIONALITY CHECK —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Occurrence of noise
 - Overheating

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.






NOTE:

If the vehicle, with the engine idling, is placed very close to a wall or another vehicle, preventing normal cooling function, the OBD system may detect malfunction.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN-00278

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect the relevant DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Check radiator fan and fan motor. <Ref. to CO(SOHC)-34, Radiator Main Fan and Fan Motor.> and <Ref. to CO(SOHC)-40, Radiator Sub Fan and Fan Motor.>

AV:DTC P0502 — VEHICLE SPEED SENSOR CIRCUIT LOW INPUT —

NOTE:

For the diagnostic procedure, refer to DTC P0503. <Ref. to EN(SOHC)-190, DTC P0503 — VEHICLE SPEED SENSOR CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AW:DTC P0503 — VEHICLE SPEED SENSOR CIRCUIT HIGH INPUT —

- DTC DETECTING CONDITION:
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00279

Step	Check	Yes	No
1	CHECK TRANSMISSION TYPE. Is the target AT vehicle?	Go to step 2.	Go to step 3.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2</p> <p>CHECK DTC P0720 ON DISPLAY. Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P0720?</p>	DTC P0720 is indicated.	Check front vehicle speed sensor signal circuit. <Ref. to AT-54, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Go to step 3.
<p>3</p> <p>CHECK SPEEDOMETER OPERATION IN COMBINATION METER. Does the speedometer operate normally?</p>	Meter operate normally.	Go to step 4.	Check speedometer and vehicle speed sensor. <Ref. to IDI-15, Speedometer.> and <Ref. to AT-52, Front Vehicle Speed Sensor.> and <Ref. to AT-56, Rear Vehicle Speed Sensor.> and <Ref. to AT-57, Torque Converter Turbine Speed Sensor.>
<p>4</p> <p>CHECK HARNESS BETWEEN ECM AND COMBINATION METER CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from combination meter. 3) Measure the resistance between ECM and combination meter. Connector & terminal (B137) No. 10 — (i10) No. 12: Is the measured value less than specified value?</p>	10 Ω	Repair poor contact in ECM connector.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and combination meter connector • Poor contact in ECM connector • Poor contact in combination meter connector • Poor contact in coupling connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


AX:DTC P0506 — IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Engine is difficult to start.
 - Engine does not start.
 - Erroneous idling
 - Engine stalls.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00280

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0506.	Go to step 2.
2 CHECK AIR BY-PASS LINE. 1)Turn the ignition switch to OFF. 2)Remove the idle air control solenoid valve from throttle body. <Ref. to FU(SOHC)-35, REMOVAL, Idle Air Control Solenoid Valve.> 3)Remove the throttle body from intake manifold. <Ref. to FU(SOHC)-13, REMOVAL, Throttle Body.> 4)Using an air gun, force air into the idle air control solenoid valve installation area. Confirm that forced air subsequently escapes from throttle body interior. Does air flow out?	Air flows out.	Replace the idle air control solenoid valve. <Ref. to FU(SOHC)-35, INSTALLATION, Idle Air Control Solenoid Valve.>	Replace the throttle body. <Ref. to FU(SOHC)-13, INSTALLATION, Throttle Body.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AY:DTC P0507 — IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED —

• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault


• TROUBLE SYMPTOM:

- Engine keeps running at higher revolution than specified idling revolution.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00280

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0507.	Go to step 2.
2 CHECK AIR INTAKE SYSTEM. 1) Turn the ignition switch to ON. 2) Start the engine, and idle it. 3) Check the following items. • Loose installation of intake manifold, idle air control solenoid valve and throttle body • Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket • Disconnections of vacuum hoses Is there a fault in air intake system?	There is a fault.	Repair air suction and leaks.	Go to step 3.
3 CHECK THROTTLE CABLE. Is throttle cable play correct?	Play is correct.	Go to step 4.	Adjust throttle cable. <Ref. to SP(SOHC)-9, INSTALLATION, Accelerator Control Cable.>
4 CHECK AIR BY-PASS LINE. 1) Turn the ignition switch to OFF. 2) Remove the idle air control solenoid valve from throttle body. <Ref. to FU(SOHC)-35, REMOVAL, Idle Air Control Solenoid Valve.> 3) Confirm that there are no foreign particles in air by-pass line. Is air by-pass line clogged by foreign particles?	Line is clogged.	Remove foreign particles from air by-pass line.	Replace the idle air control solenoid valve. <Ref. to FU(SOHC)-35, INSTALLATION, Idle Air Control Solenoid Valve.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

AZ:DTC P0512 — STARTER REQUEST CIRCUIT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Failure of engine to start


CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN-00261

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK OPERATION OF STARTER MOTOR. Does the starter motor operate when ignition switch is turned to "ON"? NOTE: Place the inhibitor switch in each position. (AT model) Depress or release the clutch pedal. (MT model)	Starter motor operates.	Repair battery short circuit in starter motor circuit.	Check starter motor circuit. <Ref. to EN(SOHC)-61, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure.>

BA:DTC P0519 — IDLE CONTROL SYSTEM CIRCUIT PERFORMANCE —

• DTC DETECTING CONDITION:

- Immediately at fault recognition


• TROUBLE SYMPTOM:

- Engine keeps running at higher revolution than specified idling revolution.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00280

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).> NOTE: In this case, it is not necessary to inspect DTC P0519.	Go to step 2.
2 CHECK AIR INTAKE SYSTEM. 1)Turn the ignition switch to ON. 2)Start the engine, and idle it. 3)Check the following items. •Loose installation of intake manifold, idle air control solenoid valve and throttle body •Cracks of intake manifold gasket, idle air control solenoid valve gasket and throttle body gasket •Disconnections of vacuum hoses Is there a fault in air intake system?	There is a fault.	Repair air suction and leaks.	Go to step 3.
3 CHECK THROTTLE CABLE. Is throttle cable play correct?	Play is correct.	Go to step 4.	Adjust throttle cable. <Ref. to SP(SOHC)-9, INSTALLATION, Accelerator Control Cable.>
4 CHECK AIR BY-PASS LINE. 1)Turn the ignition switch to OFF. 2)Remove the idle air control solenoid valve from throttle body. <Ref. to FU(SOHC)-35, Idle Air Control Solenoid Valve.> 3)Confirm that there are no foreign particles in air by-pass line. Is air by-pass line clogged by foreign particles?	Line is clogged.	Remove foreign particles from air by-pass line.	Replace the idle air control solenoid valve. <Ref. to FU(SOHC)-35, Idle Air Control Solenoid Valve.>

BB:DTC P0565 — CRUISE CONTROL ON SIGNAL —


• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00239

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from TCM and CCM. 3) Measure the resistance of harness between TCM and CCM connector. Connector & terminal (B54) No. 11— (B94) No. 3: Is the measured value less than specified value?	1 Ω	Go to step 2.	Repair open circuit in harness between TCM and CCM connector.
2 CHECK HARNESS BETWEEN TCM AND CCM CONNECTOR. Measure the resistance of harness between TCM and chassis ground. Connector & terminal (B54) No. 11 — Chassis ground: Is the measured value more than specified value?	1 MΩ	Go to step 3.	Repair short circuit in harness between TCM and CCM connector.
3 CHECK INPUT SIGNAL FOR TCM. 1) Connect the connector to TCM and CCM. 2) Lift-up the vehicle or set the vehicle on free rollers. CAUTION: On AWD models, raise all wheels off ground. 3) Start the engine. 4) Turn the cruise control main switch to ON. 5) Move selector lever to “D” and slowly increase vehicle speed to 50 km/h (31 MPH). 6) Turn the cruise control command switch to ON. 7) Measure the voltage between TCM and chassis ground. Connector & terminal (B54) No. 11 (+) — Chassis ground (-): Is the measured value less than specified value?	1 V	Go to step 4.	Check cruise control command switch circuit. <Ref. to CC-8, INSPECTION, Cruise Control Command Switch.>
4 CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>


BC:DTC P0604 — INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Engine does not start.
 - Engine stalls.

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	It is not necessary to inspect DTC P0601.

BD:DTC P0691 — COOLING FAN 1 CONTROL CIRCUIT LOW —






- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Radiator fan does not operate properly.
 - Overheating

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN-00278

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn the ignition switch to ON. 4) While operating the radiator fan relay, measure voltage between ECM terminal and ground.</p> <p>NOTE: Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(SOHC)-32, Subaru Select Monitor.></p> <p>Connector & terminal (B134) No. 14 (+) — Chassis ground (-): Is the change of measured value within specified value?</p>	0 — 10 V	Repair poor contact in ECM connector.	Go to step 2.
<p>2 CHECK GROUND SHORT CIRCUIT IN RADIATOR MAIN FAN RELAY CONTROL CIRCUIT. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM. 3) Measure the resistance of harness between ECM connector and chassis ground.</p> <p>Connector & terminal (B134) No. 14 — Chassis ground: Is the measured value less than specified value?</p>	10 Ω	Repair ground short circuit in radiator main fan relay control circuit.	Go to step 3.
<p>3 CHECK POWER SUPPLY FOR RELAY. 1) Remove the main fan relay from A/C relay holder. 2) Turn the ignition switch to ON. 3) Measure the voltage between fuse and relay box (F/B) connector and chassis ground.</p> <p>Connector & terminal (F27) No. 34 (+) — Chassis ground (-): Is the measured value more than specified value?</p>	10 V	Go to step 4.	Repair open circuit in harness between ignition switch and fuse and relay box (F/B) connector.
<p>4 CHECK MAIN FAN RELAY. 1) Turn the ignition switch to OFF. 2) Measure the resistance between main fan relay terminals.</p> <p>Terminal No. 32 — No. 34: Is the measured value within specified value?</p>	87 — 107 Ω	Go to step 5.	Replace the main fan relay.
<p>5 CHECK OPEN CIRCUIT IN MAIN FAN RELAY CONTROL CIRCUIT. Measure the resistance of harness between ECM and main fan relay connector.</p> <p>Connector & terminal (B134) No. 14 — (F27) No. 32: Is the measured value less than specified value?</p>	1 Ω	Go to step 6.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and main fan relay connector • Poor contact in coupling connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
6 CHECK POOR CONTACT. Check poor contact in ECM or main fan relay connector. Is there poor contact in ECM or main fan relay connector?	Poor contact occurs.	Repair poor contact in ECM or main fan relay connector.	Contact with SOA (distributor) service.

BE:DTC P0692 — COOLING FAN 1 CONTROL CIRCUIT HIGH —






- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Radiator fan does not operate properly.
 - Overheating

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN-00278

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1 CHECK OUTPUT SIGNAL FROM ECM. 1) Turn the ignition switch to OFF. 2) Connect the test mode connector at the lower portion of instrument panel (on the driver's side). 3) Turn the ignition switch to ON. 4) While operating the radiator fan relay, measure voltage between ECM and chassis ground.</p> <p>NOTE: Radiator fan relay operation can be executed using Subaru Select Monitor. For procedure, refer to "Compulsory Valve Operation Check Mode". <Ref. to EN(SOHC)-48, Compulsory Valve Operation Check Mode.></p> <p>Connector & terminal (B134) No. 14 (+) — Chassis ground (-): (B134) No. 13 (+) — Chassis ground (-):</p> <p>Is the change of measured value within specified value?</p>	0 — 10 V	Even if MIL lights up, the circuit has returned to a normal condition at this time. In this case, repair poor contact in ECM connector.	Go to step 2.
<p>2 CHECK SHORT CIRCUIT IN RADIATOR FAN RELAY CONTROL CIRCUIT. 1) Turn the ignition switch to OFF. 2) Remove the main fan relay and sub fan relay. (with A/C models) 3) Disconnect the test mode connector. 4) Turn the ignition switch to ON. 5) Measure the voltage between ECM and chassis ground.</p> <p>Connector & terminal (B134) No. 14 (+) — Chassis ground (-): (B134) No. 13 (+) — Chassis ground (-):</p> <p>Is the measured value more than specified value?</p>	10 V	Repair battery short circuit in radiator fan relay control circuit. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 3.
<p>3 CHECK MAIN FAN RELAY. 1) Turn the ignition switch to OFF. 2) Remove the main fan relay. 3) Measure the resistance between main fan relay terminals.</p> <p>Terminal No. 30 — No. 31:</p> <p>Is the measured value less than specified value?</p>	1 Ω	Replace the main fan relay and ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 4.
<p>4 CHECK SUB FAN RELAY. 1) Remove the sub fan relay. 2) Measure the resistance between sub fan relay terminals.</p> <p>Terminal No. 28 — No. 29</p> <p>Is the measured value less than specified value?</p>	1 Ω	Replace the sub fan relay and ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Go to step 5.
<p>5 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?</p>	Poor contact occurs.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BF:DTC P0703 — TORQUE CONVERTER/BRAKE SWITCH “B” CIRCUIT —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



Step	Check	Yes	No
1	CHECK OPERATION OF BRAKE LIGHT. Does the brake light illuminate when depressing the brake pedal?	Go to step 2.	Repair or replace the brake light circuit.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>2</p> <p>CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR. 1) Disconnect the connectors from TCM and brake light switch. 2) Measure the resistance of harness between TCM and brake light switch connector. Connector & terminal</p> <ul style="list-style-type: none"> • Without cruise control <i>(B55) No. 12 — (B64) No. 2:</i> • With cruise control <i>(B55) No. 12 — (B65) No. 3</i> <p>Is the measured value less than specified value?</p>	<p>1 Ω</p>	<p>Go to step 3.</p>	<p>Repair or replace the harness and connector. NOTE: In this case, repair the following:</p> <ul style="list-style-type: none"> • Open circuit in harness between TCM and brake light switch connector • Poor contact in TCM connector • Poor contact in brake light switch connector
<p>3</p> <p>CHECK HARNESS BETWEEN TCM AND BRAKE LIGHT SWITCH CONNECTOR. Measure the resistance of harness between TCM and chassis ground. Connector & terminal <i>(B55) No. 12 — Chassis ground:</i></p> <p>Is the measured value more than specified value?</p>	<p>1 MΩ</p>	<p>Go to step 4.</p>	<p>Repair ground short circuit in harness between TCM and brake light switch connector.</p>
<p>4</p> <p>CHECK INPUT SIGNAL FOR TCM. 1) Connect the connectors to TCM and brake light switch. 2) Measure the voltage between TCM and chassis ground. Connector & terminal <i>(B55) No. 12 (+) — Chassis ground (-):</i></p> <p>Is the measured value less than specified value when releasing brake pedal?</p>	<p>1 V</p>	<p>Go to step 5.</p>	<p>Adjust or replace the brake light switch. <Ref. to LI-8, STOP LIGHT SWITCH, INSPECTION, Stop Light System.></p>
<p>5</p> <p>CHECK INPUT SIGNAL FOR TCM. Measure the voltage between TCM and chassis ground. Connector & terminal <i>(B55) No. 12 (+) — Chassis ground (-):</i></p> <p>Is the measured value more than specified value when depressing brake pedal?</p>	<p>10 V</p>	<p>Go to step 6.</p>	<p>Adjust or replace the brake light switch. <Ref. to LI-8, STOP LIGHT SWITCH, INSPECTION, Stop Light System.></p>
<p>6</p> <p>CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?</p>	<p>Poor contact occurs.</p>	<p>Repair poor contact in TCM connector.</p>	<p>Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).></p>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BG:DTC P0731 — GEAR 1 INCORRECT RATIO —

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(SOHC)-215, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BH:DTC P0732 — GEAR 2 INCORRECT RATIO —

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(SOHC)-215, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BI: DTC P0733 — GEAR 3 INCORRECT RATIO —

NOTE:

For the diagnostic procedure, refer to DTC P0734. <Ref. to EN(SOHC)-215, DTC P0734 — GEAR 4 INCORRECT RATIO —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BJ:DTC P0734 — GEAR 4 INCORRECT RATIO —

- **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

- **TROUBLE SYMPTOM:**

- Shift point too high or too low; engine brake not effected in “3” range; excessive shift shock; excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

Step	Check	Yes	No	
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	CHECK THROTTLE POSITION SENSOR CIRCUIT. Check throttle position sensor circuit. <Ref. to AT-47, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in throttle position sensor circuit?	There is a trouble.	Repair or replace the throttle position sensor circuit.	Go to step 3.
3	CHECK FRONT VEHICLE SPEED SENSOR CIRCUIT. Check front vehicle speed sensor circuit. <Ref. to AT-54, DTC 33 FRONT VEHICLE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in front vehicle speed sensor circuit?	There is a trouble.	Repair or replace the front vehicle speed sensor circuit.	Go to step 4.
4	CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT. Check torque converter turbine speed sensor circuit. <Ref. to AT-59, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in torque converter turbine speed sensor circuit?	There is a trouble.	Repair or replace the torque converter turbine speed sensor circuit.	Go to step 5.
5	CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Go to step 6.
6	CHECK MECHANICAL TROUBLE. Check mechanical trouble in automatic transmission. Is there any mechanical trouble in automatic transmission?	There is a mechanical trouble.	Repair or replace the automatic transmission. <Ref. to AT-31, INSPECTION, Road Test.>	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BK:DTC P0741 — TORQUE CONVERTER CLUTCH CIRCUIT PERFORMANCE OR STUCK OFF —

• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

• TROUBLE SYMPTOM:

- No lock-up (after engine warm-up)
- No shift or excessive tight corner “braking”

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect the relevant DTC using “List of Diagnostic Trouble Code (DTC)”. <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2	CHECK LOCK-UP DUTY SOLENOID CIRCUIT. Check lock-up duty solenoid circuit. <Ref. to AT-87, DTC 77 LOCK-UP DUTY SOLENOID, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in lock-up duty solenoid circuit?	There is a trouble.	Repair or replace the lock-up duty solenoid circuit.	Go to step 3.
3	CHECK THROTTLE POSITION SENSOR CIRCUIT. Check throttle position sensor circuit. <Ref. to AT-47, DTC 31 THROTTLE POSITION SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in throttle position sensor circuit?	There is a trouble.	Repair or replace the throttle position sensor circuit.	Go to step 4.
4	CHECK TORQUE CONVERTER TURBINE SPEED SENSOR CIRCUIT. Check torque converter turbine speed sensor circuit. <Ref. to AT-59, DTC 36 TORQUE CONVERTER TURBINE SPEED SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in torque converter turbine speed sensor circuit?	There is a trouble.	Repair or replace the torque converter turbine speed sensor circuit.	Go to step 5.
5	CHECK ENGINE SPEED INPUT CIRCUIT. Check engine speed input circuit. <Ref. to AT-38, DTC 11 ENGINE SPEED SIGNAL, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in engine speed input circuit?	There is a trouble.	Repair or replace the engine speed input circuit.	Go to step 6.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No	
6	CHECK INHIBITOR SWITCH CIRCUIT. Check inhibitor switch circuit. <Ref. to AT-114, CHECK INHIBITOR SWITCH., Diagnostic Procedure for No-diagnostic Trouble Code (DTC).> Is there any trouble in inhibitor switch circuit?	There is a trouble.	Repair or replace the inhibitor switch circuit.	Go to step 7.
7	CHECK BRAKE LIGHT SWITCH CIRCUIT. Check brake light switch circuit. <Ref. to AT-106, CHECK BRAKE SWITCH., Diagnostic Procedure for No-diagnostic Trouble Code (DTC).> Is there any trouble in brake light switch circuit?	There is a trouble.	Repair or replace the brake light switch circuit.	Go to step 8.
8	CHECK ATF TEMPERATURE SENSOR CIRCUIT. Check ATF temperature sensor circuit. <Ref. to AT-43, DTC 27 ATF TEMPERATURE SENSOR, Diagnostic Procedure with Diagnostic Trouble Code (DTC).> Is there any trouble in ATF temperature sensor circuit?	There is a trouble.	Repair or replace the ATF temperature sensor circuit.	Go to step 9.
9	CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Go to step 10.
10	CHECK MECHANICAL TROUBLE. Check mechanical trouble in automatic transmission. Is there any mechanical trouble in automatic transmission?	There is a mechanical trouble.	Repair or replace the automatic transmission. <Ref. to AT-31, INSPECTION, Road Test.>	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


BL:DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (AT VEHICLES) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00282

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK DTC P0705 ON DISPLAY. Is DTC P0705 indicated?	DTC P0705 is indicated.	Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Place the select lever except for "N" and "P" positions. 3) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 21 (+) — Chassis ground (-):</i> Is the measured value within specified value?	4.5 — 5.5 V	Even if MIL lights up, the circuit has returned to a normal condition at this time.	Go to step 3.
3 CHECK HARNESS BETWEEN ECM AND TRANSMISSION HARNESS CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and transmission harness connector (T3). 3) Measure the resistance of harness between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 21 — Chassis ground:</i> Is the measured value more than specified value?	1 MΩ	Go to step 4.	Repair ground short circuit in harness between ECM and transmission harness connector.
4 CHECK TRANSMISSION HARNESS CONNECTOR. 1) Disconnect the connector from inhibitor switch. 2) Measure the resistance of harness between transmission harness connector and engine ground. <i>Connector & terminal</i> <i>(T3) No. 12 — Engine ground:</i> Is the measured value more than specified value?	1 MΩ	Go to step 5.	Repair ground short circuit in harness between transmission harness and inhibitor switch connector.
5 CHECK INHIBITOR SWITCH. Measure the resistance between inhibitor switch connector the receptacle's terminals in selector lever except for "N" position. <i>Terminals</i> <i>No. 7 — No. 12:</i> Is the measured value more than specified value?	1 MΩ	Go to step 6.	Replace the inhibitor switch. <Ref. to AT-48, Inhibitor Switch.>
6 CHECK SELECTOR CABLE CONNECTION. Is there any fault in selector cable connection to inhibitor switch?	There is a fault.	Repair selector cable connection. <Ref. to CS-10, INSPECTION, Select Cable.>	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


BM:DTC P0851 — NEUTRAL SWITCH INPUT CIRCUIT LOW (MT VEHICLES) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Erroneous idling

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00282

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Place the shift lever in neutral. 3) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 21 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10V	Go to step 2.	Go to step 4.
2 CHECK INPUT SIGNAL FOR ECM. 1) Place the shift lever in a position except for neutral. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 21 (+) — Chassis ground (-):</i> Is the measured value less than specified value?	1V	Go to step 3.	Go to step 4.
3 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Contact with SOA (distributor) service.
4 CHECK NEUTRAL POSITION SWITCH. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from transmission harness. 3) Place the shift lever in neutral. 4) Measure the resistance between transmission harness and connector terminals. <i>Connector & terminal</i> <i>(T2) No. 1 — No. 2:</i> Is the measured value more than specified value?	1M Ω	Go to step 5.	Repair short circuit in transmission harness or replace neutral position switch.
5 CHECK NEUTRAL POSITION SWITCH. 1) Place the shift lever in a position except for neutral. 2) Measure the resistance between transmission harness connector terminals. Is the measured value less than specified value?	1 Ω	Go to step 6.	Repair short circuit in transmission harness or replace neutral position switch.
6 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. Measure the resistance between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 21 — Chassis ground:</i> Is the measured value more than specified value?	1 M Ω	Go to step 7.	Repair ground short circuit in harness between ECM and transmission harness connector.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
7 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. 1)Disconnect the connector from ECM. 2)Measure the resistance of harness between ECM and transmission harness connector. Connector & terminal With OBD (B136) No. 21 — (B25) No. 1: RHD model (B136) No. 21 — (B25) No. 2: Is the measured value less than specified value?	1 Ω	Go to step 8 .	Repair open circuit in harness between ECM and transmission harness connector.
8 CHECK HARNESS BETWEEN ECM AND NEUTRAL POSITION SWITCH CONNECTOR. Measure the resistance of harness between transmission harness connector and engine ground. Connector & terminal LHD model (B25) No. 2 — Engine ground: RHD model (B25) No. 1 — Engine ground: Is the measured value less than specified value?	5 Ω	Go to step 9 .	Repair open circuit between transmission harness connector and engine ground terminal.
9 CHECK POOR CONTACT. Check poor contact in transmission harness connector. Is there poor contact in transmission harness connector?	Poor contact occurs.	Repair poor contact in transmission harness connector.	Contact with SOA (distributor) service.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK DTC P0705 ON DISPLAY. Is DTC P0705 indicated?	DTC P0705 is indicated.	Inspect DTC P0705 using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground in selector lever "N" and "P" positions. Connector & terminal (B136) No. 21 (+) — Chassis ground (-): Is the measured value less than specified value?	1 V	Go to step 3.	Go to step 5.
3 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground in selector lever except for "N" and "P" positions. Connector & terminal (B136) No. 21 (+) — Chassis ground (-): Is the measured value within specified value?	4.5 — 5.5 V	Go to step 4.	Go to step 5.
4 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
5 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 21 (+) — Chassis ground (-): Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and inhibitor switch connector.	Go to step 6.
6 CHECK HARNESS BETWEEN ECM AND INHIBITOR SWITCH CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and inhibitor switch. 3) Measure the resistance of harness between ECM and inhibitor switch connector. Connector & terminal (B136) No. 21 — (T7) No. 12: Is the measured value less than specified value?	1 Ω	Go to step 7.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and inhibitor switch connector • Poor contact in coupling connector • Poor contact in inhibitor switch connector • Poor contact in ECM connector

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>7 CHECK INHIBITOR SWITCH GROUND LINE. Measure the resistance of harness between inhibitor switch connector and engine ground. <i>Connector & terminal</i> <i>(T7) No. 7 — Engine ground:</i> Is the measured value less than specified value?</p>	5 Ω	Go to step 8.	Repair open circuit in harness between inhibitor switch connector and starter motor ground line. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between inhibitor switch connector and starter motor ground line • Poor contact in starter motor connector • Poor contact in starter motor ground • Starter motor
<p>8 CHECK INHIBITOR SWITCH. Measure the resistance between inhibitor switch connector receptacle's terminals in selector lever "N" and "P" positions. <i>Terminals</i> <i>No. 7 — No. 12:</i> Is the measured value less than specified value?</p>	1 Ω	Go to step 9.	Replace the inhibitor switch. <Ref. to AT-48, Inhibitor Switch.>
<p>9 CHECK SELECTOR CABLE CONNECTION. Is there any fault in selector cable connection to inhibitor switch?</p>	There is a fault.	Repair selector cable connection. <Ref. to CS-10, INSPECTION, Select Cable.>	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BO:DTC P0864 — TCM COMMUNICATION CIRCUIT RANGE/PERFORMANCE —


• **DTC DETECTING CONDITION:**

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00283

Step	Check	Yes	No	
1	<p>CHECK DRIVING CONDITION.</p> <p>1)Start and warm-up the engine until the radiator fan makes one complete rotation.</p> <p>2)Drive the vehicle.</p> <p>Is the AT shift control functioning properly?</p>	Shift control is functioning properly.	Go to step 2.	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
2	CHECK ACCESSORY. Are car phone and/or CB installed on vehicle?	Car phone and/or CB is installed.	Repair grounding line of car phone or CB system.	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BP:DTC P0865 — TCM COMMUNICATION CIRCUIT LOW —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00283

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the measured value less than specified value?</p>	1 V	Go to step 2.	Even if MIL lights up, the circuit has returned to a normal condition at this time. NOTE: In this case, repair the following: • Poor contact in ECM connector • Poor contact in TCM connector
<p>2</p> <p>CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from ECM and TCM. 3) Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 — Chassis ground:</i> Is the measured value more than specified value?</p>	1 MΩ	Go to step 3.	Repair ground short circuit in harness between ECM and TCM connector.
<p>3</p> <p>CHECK OUTPUT SIGNAL FOR ECM. 1) Connect the connector to ECM. 2) Turn the ignition switch to ON. 3) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the measured value more than specified value?</p>	5 V	Go to step 4.	Repair poor contact in ECM connector.
<p>4</p> <p>CHECK TROUBLE CODE FOR AUTOMATIC TRANSMISSION. Read the trouble code for automatic transmission. <Ref. to AT-20, Read Diagnostic Trouble Code (DTC).> Does the trouble code appear for automatic transmission?</p>	DTC appears.	Inspect trouble code for automatic transmission. <Ref. to AT-38, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BQ:DTC P0866 — TCM COMMUNICATION CIRCUIT HIGH —


• DTC DETECTING CONDITION:

- Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



EN-00283

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 2.
2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	4 V	Go to step 5.	Go to step 3.
3 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between ECM connector and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the measured value less than specified value?	1 V	Repair poor contact in ECM connector.	Go to step 4.
4 CHECK OUTPUT SIGNAL FROM ECM. Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 10 (+) — Chassis ground (-):</i> Is the change of measured value within specified value?	1 V — 4 V	Even if MIL lights up, the circuit has returned to a normal condition at this time. NOTE: In this case, repair the following: • Poor contact in ECM connector • Poor contact in TCM connector	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.
5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the voltage between TCM and chassis ground. <i>Connector & terminal</i> <i>(B55) No. 17 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	4 V	Go to step 6.	Repair open circuit in harness between ECM and TCM connector.
6 CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Check TCM power supply line and grounding line.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BR:DTC P1110 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (LOW INPUT) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	It is not necessary to inspect DTC P0129.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BS:DTC P1111 — ATMOSPHERIC PRESSURE SENSOR CIRCUIT MALFUNCTION (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

	Step	Check	Yes	No
1	CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	It is not necessary to inspect DTC P1111.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BT:DTC P1134 — A/F SENSOR MICRO-COMPUTER PROBLEM —


• **DTC DETECTING CONDITION:**

- Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, Inspection Mode.> .

• **WIRING DIAGRAM:**



EN-00266

Step	Check	Yes	No	
1	CHECK ANY OTHER DIAGNOSTIC TROUBLE CODE (DTC) ON DISPLAY.	Does the Subaru Select Monitor or OBD-II general scan tool indicate DTC P1134?	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	It is not necessary to inspect DTC P1134.


BU: DTC P1137 — O₂ SENSOR CIRCUIT (BANK1 SENSOR1) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00266

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Inspect DTC using "List of Diagnostic Trouble Code (DTC)". <Ref. to EN(SOHC)-75, List of Diagnostic Trouble Code (DTC).>	Go to step 2.
2 CHECK FRONT OXYGEN (A/F) SENSOR DATA. 1)Start the engine. 2)While observing the Subaru Select Monitor or OBD-II general scan tool screen, warm-up the engine until coolant temperature is above 70°C (160°F). If the engine is already warmed-up, operate at idle speed for at least 1 minute. 3)Read the data of front oxygen (A/F) sensor signal during idling using Subaru Select Monitor or OBD-II general scan tool. Is the measured value within specified value? NOTE: •Subaru Select Monitor For detailed operation procedure, refer to the "READ CURRENT DATA FOR ENGINE". <Ref. to EN(SOHC)-32, Subaru Select Monitor.> •OBD-II general scan tool For detailed operation procedures, refer to the OBD-II General Scan Tool Instruction Manual.	0.85 — 1.15	Go to step 3.	Go to step 4.
3 CHECK FRONT OXYGEN (A/F) SENSOR DATA. Race the engine at speeds from idling to 5,000 rpm for a total of 5 cycles. Is the measured value more than specified value during racing? NOTE: •Air fuel ratio is rich at normal condition or during racing. •To increase engine speed to 5,000 rpm, slowly depress accelerator pedal, taking approximately 5 seconds, and quickly release accelerator pedal to decrease engine speed.	1.1 V	Go to step 6.	Go to step 4.
4 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connector from ECM and front oxygen (A/F) sensor connector. 3)Measure the resistance between ECM and front oxygen (A/F) sensor. Connector & terminals (B136) No. 13 — (B18) No. 1: (B136) No. 22 — (B18) No. 2: Is the measured value less than specified value?	5 Ω	Go to step 5.	Repair open circuit between ECM and front oxygen (A/F) sensor.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>5 CHECK HARNESS BETWEEN ECM AND FRONT OXYGEN (A/F) SENSOR. Measure the resistance between ECM and chassis ground. Connector & terminals (B136) No. 13 — Chassis ground: (B136) No. 22 — Chassis ground: Is the measured value more than specified value?</p>	1 MΩ	Go to step 6.	Repair ground short circuit between ECM and front oxygen (A/F) sensor.
<p>6 CHECK EXHAUST SYSTEM. Check exhaust system parts. Is there a fault in exhaust system? NOTE: Check the following items.</p> <ul style="list-style-type: none">•Loose installation of portions•Damage (crack, hole etc.) of parts•Looseness of front oxygen (A/F) sensor•Looseness and ill fitting of parts between front oxygen (A/F) sensor and rear oxygen sensor	There is a fault.	Repair or replace faulty parts.	Replace the front oxygen (A/F) sensor. <Ref. to FU(SOHC)-42, Front Oxygen (A/F) Sensor.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

BV:DTC P1492 — EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (LOW INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(SOHC)-239, DTC P1498 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BW:DTC P1493 — EGR SOLENOID VALVE SIGNAL #1 CIRCUIT MALFUNCTION (HIGH INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(SOHC)-241, DTC P1499 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BX:DTC P1494 — EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (LOW INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(SOHC)-239, DTC P1498 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BY:DTC P1495 — EGR SOLENOID VALVE SIGNAL #2 CIRCUIT MALFUNCTION (HIGH INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(SOHC)-241, DTC P1499 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

BZ:DTC P1496 — EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (LOW INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1498. <Ref. to EN(SOHC)-239, DTC P1498 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

CA:DTC P1497 — EGR SOLENOID VALVE SIGNAL #3 CIRCUIT MALFUNCTION (HIGH INPUT) —

NOTE:

For the diagnostic procedure, refer to DTC P1499. <Ref. to EN(SOHC)-241, DTC P1499 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT) —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>


CB:DTC P1498 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (LOW INPUT) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Poor driving performance.
 - Engine breathing

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00284

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK POWER SUPPLY TO EGR SOLENOID VALVE. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from EGR solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between EGR solenoid valve connector and engine ground. Connector & terminal (E18) No. 2 (+) — Engine ground (-): (E18) No. 5 (+) — Engine ground (-): Is the measured value more than specified value?	10 V	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between EGR solenoid valve and main relay connector • Poor contact in coupling connector
2 CHECK HARNESS BETWEEN ECM AND EGR SOLENOID VALVE CONNECTOR. 1) Turn the ignition switch to OFF. 2) Measure the resistance between ECM and EGR solenoid valve connector. Connector & terminal DTC P1492; (B134) No. 18 — (E18) No. 6: DTC P1494; (B134) No. 17 — (E18) No. 1: DTC P1496; (B134) No. 16 — (E18) No. 4: DTC P1498; (B134) No. 15 — (E18) No. 3: Is the measured value less than specified value?	1 Ω	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and EGR solenoid valve connector • Poor contact in coupling connector
3 CHECK HARNESS BETWEEN ECM AND EGR SOLENOID VALVE CONNECTOR. 1) Disconnect the connector from ECM. 2) Measure the resistance between ECM connector and chassis ground. Connector & terminal DTC P1492; (B134) No. 18 — Chassis ground: DTC P1494; (B134) No. 17 — Chassis ground: DTC P1496; (B134) No. 16 — Chassis ground: DTC P1498; (B134) No. 15 — Chassis ground: Is the measured value more than specified value?	1 MΩ	Go to step 4.	Repair ground short circuit in harness between ECM and EGR solenoid valve connector.
4 CHECK POOR CONTACT. Check poor contact in ECM connector and EGR solenoid valve connector. Is there poor contact in ECM connector or EGR solenoid valve connector?	Poor contact occurs.	Repair poor contact in ECM connector or EGR solenoid valve connector.	Replace the EGR solenoid valve. <Ref. to FU(SOHC)-35, Idle Air Control Solenoid Valve.>


CC:DTC P1499 — EGR SOLENOID VALVE SIGNAL #4 CIRCUIT MALFUNCTION (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Poor driving performance.
 - Engine breathing

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• **WIRING DIAGRAM:**



EN-00284

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 2.	Go to step 3.
2 CHECK GROUND CIRCUIT FOR ECM. 1) Turn the ignition switch to OFF. 2) Measure the resistance between ECM connector and chassis ground. Connector & terminal <i>(B134) No. 7 — Chassis ground:</i> <i>(B137) No. 14 — Chassis ground:</i> <i>(B135) No. 21 — Chassis ground:</i> Is the measured value less than specified value?	5 Ω	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM connector and engine ground terminal • Poor contact in ECM connector • Poor contact in coupling connector
3 CHECK HARNESS BETWEEN ECM AND EGR SOLENOID VALVE CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from EGR solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>DTC P1493; (B134) No. 18 (+) — Chassis ground (-):</i> <i>DTC P1495; (B134) No. 17 (+) — Chassis ground (-):</i> <i>DTC P1497; (B134) No. 16 (+) — Chassis ground (-):</i> <i>DTC P1499; (B134) No. 15 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and EGR solenoid valve connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

**CD:DTC P1510 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1 CIRCUIT
LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to EN(SOHC)-244, DTC P1516 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**CE:DTC P1511 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 1 CIRCUIT
HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to EN(SOHC)-246, DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**CF:DTC P1512 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2 CIRCUIT
LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to EN(SOHC)-244, DTC P1516 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**CG:DTC P1513 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 2 CIRCUIT
HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to EN(SOHC)-246, DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**CH:DTC P1514 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3 CIRCUIT
LOW INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1516. <Ref. to EN(SOHC)-244, DTC P1516 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT LOW INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

**CI: DTC P1515 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 3 CIRCUIT
HIGH INPUT —****NOTE:**

For the diagnostic procedure, refer to DTC P1517. <Ref. to EN(SOHC)-246, DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT HIGH INPUT —, Diagnostic Procedure with Diagnostic Trouble Code (DTC).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
<p>1</p> <p>CHECK POWER SUPPLY TO IDLE AIR CONTROL SOLENOID VALVE.</p> <p>1) Turn the ignition switch to OFF. 2) Disconnect the connector from idle air control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between idle air control solenoid valve connector and engine ground.</p> <p>Connector & terminal <i>(E7) No. 2 (+) — Engine ground (-):</i> <i>(E7) No. 5 (+) — Engine ground (-):</i></p> <p>Is the measured value more than specified value?</p>	10 V	Go to step 2.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between idle air control solenoid valve and main relay connector • Poor contact in coupling connector
<p>2</p> <p>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</p> <p>1) Turn the ignition switch to OFF. 2) Measure the resistance between ECM and idle air control solenoid valve connector.</p> <p>Connector & terminal <i>DTC P1510; (B134) No. 20 — (E7) No. 4:</i> <i>DTC P1512; (B134) No. 6 — (E7) No. 1:</i> <i>DTC P1514; (B134) No. 5 — (E7) No. 6:</i> <i>DTC P1516; (B134) No. 19 — (E7) No. 3:</i></p> <p>Is the measured value less than specified value?</p>	1 Ω	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: • Open circuit in harness between ECM and idle air control solenoid valve connector • Poor contact in coupling connector
<p>3</p> <p>CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR.</p> <p>1) Disconnect the connector from ECM. 2) Measure the resistance between ECM connector and chassis ground.</p> <p>Connector & terminal <i>DTC P1510; (B134) No. 20 — Chassis ground:</i> <i>DTC P1512; (B134) No. 6 — Chassis ground:</i> <i>DTC P1514; (B134) No. 5 — Chassis ground:</i> <i>DTC P1516; (B134) No. 19 — Chassis ground:</i></p> <p>Is the measured value more than specified value?</p>	1 MΩ	Go to step 4.	Repair ground short circuit in harness between ECM and idle air control solenoid valve connector.
<p>4</p> <p>CHECK POOR CONTACT.</p> <p>Check poor contact in ECM connector and idle air control solenoid valve connector. Is there poor contact in ECM connector or idle air control solenoid valve connector?</p>	Poor contact occurs.	Repair poor contact in ECM connector or idle air control solenoid valve connector.	Replace the idle air control solenoid valve. <Ref. to FU(SOHC)-35, Idle Air Control Solenoid Valve.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC) ENGINE (DIAGNOSTICS)


CK:DTC P1517 — IDLE AIR CONTROL SOLENOID VALVE SIGNAL 4 CIRCUIT HIGH INPUT —

- **DTC DETECTING CONDITION:**
 - Immediately at fault recognition
- **TROUBLE SYMPTOM:**
 - Erroneous idling
 - Engine stalls.
 - Engine breathing

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

• WIRING DIAGRAM:



DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK ANY OTHER DTC ON DISPLAY. Is any other DTC displayed?	Other DTC is displayed.	Go to step 2.	Go to step 3.
2 CHECK GROUND CIRCUIT FOR ECM. 1) Turn the ignition switch to OFF. 2) Measure the resistance between ECM connector and chassis ground. Connector & terminal <i>(B134) No. 7 — Chassis ground:</i> <i>(B137) No. 14 — Chassis ground:</i> <i>(B135) No. 21 — Chassis ground:</i> Is the measured value less than specified value?	5 Ω	Go to step 3.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM connector and engine ground terminal • Poor contact in ECM connector • Poor contact in coupling connector
3 CHECK HARNESS BETWEEN ECM AND IDLE AIR CONTROL SOLENOID VALVE CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connector from idle air control solenoid valve. 3) Turn the ignition switch to ON. 4) Measure the voltage between ECM connector and chassis ground. Connector & terminal <i>DTC P1511; (B134) No. 20 (+) — Chassis ground (-):</i> <i>DTC P1513; (B134) No. 6 (+) — Chassis ground (-):</i> <i>DTC P1515; (B134) No. 5 (+) — Chassis ground (-):</i> <i>DTC P1517; (B134) No. 19 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and idle air control solenoid valve connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

CL:DTC P1518 — STARTER SWITCH CIRCUIT LOW INPUT —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Failure of engine to start


CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

• WIRING DIAGRAM:



EN-00261

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK OPERATION OF STARTER MOTOR. Does the starter motor operate when ignition switch is turned to "ST"? NOTE: Place the inhibitor switch in the "P" or "N" position. (AT model) Depress the clutch pedal. (MT model)	Starter motor operates.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none">• Open or ground short circuit in harness between ECM and starter motor connector.• Poor contact in ECM connector.	Check starter motor circuit. <Ref. to EN(SOHC)-61, STARTER MOTOR CIRCUIT, Diagnostics for Engine Starting Failure. >

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to OFF. 2) Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B134) No. 9 (+) — Chassis ground (-):</i> Is the measured value more than specified value?	10 V	Repair poor contact in ECM connector.	Go to step 2.
2	CHECK HARNESS BETWEEN ECM AND MAIN FUSE BOX CONNECTOR. 1) Disconnect the connector from ECM. 2) Measure the resistance of harness between ECM and chassis ground. <i>Connector & terminal</i> <i>(B135) No. 9 — Chassis ground:</i> Is the measured value less than specified value?	10 Ω	Repair ground short circuit in harness between ECM connector and battery terminal.	Go to step 3.
3	CHECK FUSE SBF-5. Is fuse blown?	Fuse is blown out.	Replace the fuse.	Repair harness and connector. NOTE: In this case, repair the following: <ul style="list-style-type: none"> • Open circuit in harness between ECM and battery • Poor contact in ECM connector • Poor contact in battery terminal

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK OUTPUT SIGNAL FROM ECM. 1)Start the engine, and warm-up the engine. 2)Turn the ignition switch to OFF. 3)Turn the ignition switch to ON. 4)Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 15 (+) — Chassis ground (-): Is the measured value more than specified value?	3 V	Repair poor contact in ECM connector.	Go to step 2.
2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1)Turn the ignition switch to OFF. 2)Disconnect the connectors from ECM and TCM. 3)Measure the resistance of harness between ECM and chassis ground. Connector & terminal (B136) No. 15 — Chassis ground: Is the measured value more than specified value?	1 M Ω	Go to step 3.	Repair ground short circuit in harness between ECM and TCM connector.
3 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the resistance of harness between ECM and TCM connector. Connector & terminal (B136) No. 15 — (B55) No. 10: Is the measured value less than specified value?	1 Ω	Repair poor contact in ECM or TCM connector.	Repair open circuit in harness between ECM and TCM connector.


CO:DTC P1699 — ENGINE TORQUE CONTROL CUT SIGNAL CIRCUIT MAL-FUNCTION (HIGH INPUT) —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00285

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK OUTPUT SIGNAL FROM ECM. 1)Start the engine, and warm-up the engine. 2)Turn the ignition switch to OFF. 3)Disconnect the connector from TCM. 4)Turn the ignition switch to ON. 5)Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 15 (+) — Chassis ground (-):</i> Is the measured value less than specified value?	3 V	Go to step 2.	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>
2 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1)Turn the ignition switch to OFF. 2)Measure the voltage between ECM and chassis ground. <i>Connector & terminal</i> <i>(B136) No. 15 (+) — Chassis ground (-):</i> Shake the ECM harness and connector, while monitoring value of voltage meter. Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector. After repair, replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>	Contact with SOA (distributor) service. NOTE: Inspection by DTM is required, because probable cause is deterioration of multiple parts.


CP:DTC P1711 — ENGINE TORQUE CONTROL SIGNAL #1 CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00286

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

Step	Check	Yes	No
1 CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 1 (+) — Chassis ground (-): Is the measured value more than specified value?	4.5 V	Go to step 2.	Go to step 4.
2 CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 1 (+) — Chassis ground (-): Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
3 CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>
4 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. Connector & terminal (B136) No. 1 — (B56) No. 5: Is the measured value less than specified value?	1 Ω	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
5 CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the resistance of harness between ECM and chassis ground. Connector & terminal (B136) No. 1 — Chassis ground: Is the measured value more than specified value?	1 M Ω	Go to step 6.	Repair ground short circuit in harness between ECM and TCM connector.
6 CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)


CQ:DTC P1712 — ENGINE TORQUE CONTROL SIGNAL #2 CIRCUIT MALFUNCTION —

- **DTC DETECTING CONDITION:**
 - Two consecutive driving cycles with fault
- **TROUBLE SYMPTOM:**
 - Excessive shift shock

CAUTION:

After repair or replacement of faulty parts, conduct Clear Memory Mode <Ref. to EN(SOHC)-47, OPERATION, Clear Memory Mode.> and Inspection Mode <Ref. to EN(SOHC)-40, OPERATION, Inspection Mode.>.

- **WIRING DIAGRAM:**



EN-00287

DIAGNOSTIC PROCEDURE WITH DIAGNOSTIC TROUBLE CODE (DTC)

ENGINE (DIAGNOSTICS)

	Step	Check	Yes	No
1	CHECK INPUT SIGNAL FOR ECM. 1) Turn the ignition switch to ON. 2) Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 18 (+) — Chassis ground (-): Is the measured value more than specified value?	4.5 V	Go to step 2.	Go to step 4.
2	CHECK INPUT SIGNAL FOR ECM. Measure the voltage between ECM and chassis ground. Connector & terminal (B136) No. 18 (+) — Chassis ground (-): Is the measured value more than specified value?	10 V	Repair battery short circuit in harness between ECM and TCM connector.	Go to step 3.
3	CHECK POOR CONTACT. Check poor contact in ECM connector. Is there poor contact in ECM connector?	Poor contact occurs.	Repair poor contact in ECM connector.	Replace the ECM. <Ref. to FU(SOHC)-46, Engine Control Module.>
4	CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. 1) Turn the ignition switch to OFF. 2) Disconnect the connectors from ECM and TCM. 3) Measure the resistance of harness between ECM and TCM connector. Connector & terminal (B136) No. 18 — (B56) No. 14: Is the measured value less than specified value?	1 Ω	Go to step 5.	Repair open circuit in harness between ECM and TCM connector.
5	CHECK HARNESS BETWEEN ECM AND TCM CONNECTOR. Measure the resistance of harness between ECM and chassis ground. Connector & terminal (B136) No. 18 — Chassis ground: Is the measured value more than specified value?	1 M Ω	Go to step 6.	Repair ground short circuit in harness between ECM and TCM connector.
6	CHECK POOR CONTACT. Check poor contact in TCM connector. Is there poor contact in TCM connector?	Poor contact occurs.	Repair poor contact in TCM connector.	Replace the TCM. <Ref. to AT-70, Transmission Control Module (TCM).>

20. General Diagnostic Table

A: INSPECTION

1. ENGINE

NOTE:

Malfunction of parts other than those listed is also possible. <Ref. to ME(SOHC)-89, Engine Trouble in General.>

Symptom	Problem parts
1. Engine stalls during idling.	1) Idle air control solenoid valve 2) Pressure sensor 3) Intake air temperature sensor 4) Ignition parts (*1) 5) Engine coolant temperature sensor (*2) 6) Crankshaft position sensor (*3) 7) Camshaft position sensor (*3) 8) Fuel injection parts (*4)
2. Rough idling	1) Idle air control solenoid valve 2) Pressure sensor 3) Intake air temperature sensor 4) Engine coolant temperature sensor (*2) 5) Ignition parts (*1) 6) Air intake system (*5) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Crankshaft position sensor (*3) 10) Camshaft position sensor (*3) 11) Oxygen sensor 12) Fuel pump and fuel pump relay
3. Engine does not return to idle.	1) Idle air control solenoid valve 2) Engine coolant temperature sensor 3) Accelerator cable (*6) 4) Throttle position sensor 5) Pressure sensor 6) Intake air temperature sensor
4. Poor acceleration	1) Pressure sensor 2) Intake air temperature sensor 3) Throttle position sensor 4) Fuel injection parts (*4) 5) Fuel pump and fuel pump relay 6) Engine coolant temperature sensor (*2) 7) Crankshaft position sensor (*3) 8) Camshaft position sensor (*3) 9) A/C switch and A/C cut relay 10) Engine torque control signal circuit 11) Ignition parts (*1)
5. Engine stalls or engine sags or hesitates at acceleration.	1) Pressure sensor 2) Intake air temperature sensor 3) Engine coolant temperature sensor (*2) 4) Crankshaft position sensor (*3) 5) Camshaft position sensor (*3) 6) Purge control solenoid valve 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay

GENERAL DIAGNOSTIC TABLE

ENGINE (DIAGNOSTICS)

Symptom	Problem parts
6. Surge	1) Intake manifold pressure sensor 2) Intake air temperature sensor 3) Pressure sensor 4) Engine coolant temperature sensor (*2) 5) Crankshaft position sensor (*3) 6) Camshaft position sensor (*3) 7) Fuel injection parts (*4) 8) Throttle position sensor 9) Fuel pump and fuel pump relay
7. Spark knock	1) Intake manifold pressure sensor 2) Intake air temperature sensor 3) Pressure sensor 4) Engine coolant temperature sensor 5) Knock sensor 6) Fuel injection parts (*4) 7) Fuel pump and fuel pump relay
8. After burning in exhaust system	1) Intake manifold pressure sensor 2) Intake air temperature sensor 3) Pressure sensor 4) Engine coolant temperature sensor (*2) 5) Fuel injection parts (*4) 6) Fuel pump and fuel pump relay

- *1: Check ignition coil & ignitor assembly and spark plug.
- *2: Indicate the symptom occurring only in cold temperatures.
- *3: Ensure the secure installation.
- *4: Check fuel injector, fuel pressure regulator and fuel filter.
- *5: Inspect air leak in air intake system.
- *6: Adjust accelerator cable.

2. AUTOMATIC TRANSMISSION

NOTE:

Check general diagnostics table with non-conformity symptom for automatic transmission. <Ref. to AT-2, Basic Diagnostic Procedure.>