


# ENGINE COOLING SYSTEM

# 2-5

---

	Page
<b>T</b> <b>DIAGNOSTICS</b> .....	2
1. Wiring Diagram.....	2
2. Radiator Main Fan.....	3
3. Radiator Sub Fan (With A/C model only) .....	7

1. Wiring Diagram



F16 (Black)

F17 (Black)

B62


F27

F31

F28


F66

F67



GU14-09

B84 (Light blue)



GU14-09

## 2. Radiator Main Fan

### A: OPERATION

#### DETECTING CONDITION:

##### Condition:

- Engine coolant temperature is above 95°C (203°F).
- Vehicle speed is below 19 km/h (12 MPH).

##### TROUBLE SYMPTOM:

- Radiator main fan does not rotate under the above conditions.

**2A1 : CHECK POWER SUPPLY TO MAIN FAN MOTOR.**


#### CAUTION:

**Be careful not to overheat engine during repair.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from main fan motor.
- 3) Start the engine, and warm it up until engine coolant temperature increases over 95°C (203°F).
- 4) Stop the engine and turn ignition switch to ON.
- 5) Measure voltage between main fan motor connector and chassis ground.

##### Connector & terminal

**(F17) No. 2 (+) — Chassis ground (-):**




- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **2A2**.
- NO** : Go to step **2A5**.

**2A2 : CHECK GROUND CIRCUIT OF MAIN FAN MOTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between main fan motor connector and chassis ground.

##### Connector & terminal

**(F17) No. 1 — Chassis ground:**



- CHECK** : **Is the resistance less than 5 Ω?**
- YES** : Go to step **2A3**.
- NO** : Repair open circuit in harness between main fan motor connector and chassis ground.


**2A3 : CHECK POOR CONTACT.**

Check poor contact in main fan motor connector.  
<Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in main fan motor connector?**
- YES** : Repair poor contact in main fan motor connector.
- NO** : Go to step **2A4**.

**2A4 : CHECK MAIN FAN MOTOR.**

Connect battery positive (+) terminal to terminal No. 2, and negative (-) terminal to terminal No. 1 of main fan motor connector.




- CHECK** : *Does the main fan rotate?*
- YES** : Repair poor contact in main fan motor connector.
- NO** : Replace main fan motor with a new one.

**2A5 : CHECK POWER SUPPLY TO MAIN FAN RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Remove main fan relay from A/C relay holder.
- 3) Measure voltage between main fan relay terminal and chassis ground.

**Connector & terminal**  
(F66) No. 26 (+) — Chassis ground (-):




- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step 2A6.
- NO** : Go to step 2A7.

**2A6 : CHECK POWER SUPPLY TO MAIN FAN RELAY.**

- 1) Turn ignition switch to ON.
- 2) Measure voltage between main fan relay terminal and chassis ground.


**Connector & terminal**  
(F66) No. 28 (+) — Chassis ground (-):



- CHECK** : *Is the voltage more than 10 V?*
- YES** : Go to step 2A16.
- NO** : Go to step 2A12.

**2A7 : CHECK 20 A FUSE.**

- 1) Remove 20 A fuse from A/C relay holder.
- 2) Check condition of fuse.



- CHECK** : *Is the fuse blown-out?*
- YES** : Replace fuse.
- NO** : Go to step 2A8.


**2A8 : CHECK HARNESS CONNECTOR BETWEEN MAIN FUSE BOX AND A/C RELAY HOLDER 20 A FUSE.**

- 1) Disconnect connector from main fuse box.
- 2) Disconnect connectors (F25) and (F26) from generator, and (F34) from SBF holder.
- 3) Measure resistance of harness connector between main fuse box connector and A/C relay holder 20 A fuse terminals.

**Connector & terminal**

**(F35) No. 1 — (F27) No. 1:**

**(F35) No. 2 — (F27) No. 1:**



- (CHECK)** : **Is the resistance less than 1 Ω?**
- (YES)** : Go to step **2A9**.
- (NO)** : Repair open circuit in harness between main fuse box connector and 20 A fuse terminal.

**2A9 : CHECK POOR CONTACT.**

Check poor contact in main fuse box connector. <Ref. to FOREWORD [T3C1].>

- (CHECK)** : **Is there poor contact in main fuse box connector?**
- (YES)** : Repair poor contact in main fuse box connector.
- (NO)** : Go to step **2A10**.

**2A10 : CHECK POOR CONTACT.**

Check poor contact in A/C relay holder 20 A fuse connector. <Ref. to FOREWORD [T3C1].>


- (CHECK)** : **Is there poor contact in A/C relay holder 20 A fuse connector?**
- (YES)** : Repair poor contact in 20 A fuse
- (NO)** : Go to step **2A11**.

**2A11 : CHECK HARNESS CONNECTOR BETWEEN 20 A FUSE AND MAIN FAN RELAY IN A/C RELAY HOLDER.**

Measure resistance of harness between 20 A fuse and main fan relay terminal.

**Connector & terminal**


**(F27) No. 2 — (F66) No. 26:**



- (CHECK)** : **Is the resistance less than 1 Ω?**
- (YES)** : Repair poor contact in main fan relay connector.
- (NO)** : Repair open circuit in harness between 20 A fuse and main fan relay connector.

**2A12 : CHECK FUSE.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuse No. 18 from joint box.
- 3) Check condition of fuse.




- (CHECK)** : **Is the fuse blown-out?**
- (YES)** : Replace fuse.
- (NO)** : Go to step **2A13**.

### 2A13 : CHECK HARNESS CONNECTOR BETWEEN IGNITION SWITCH AND JOINT BOX.

- 1) Disconnect connector from ignition switch.
- 2) Separate connectors (F44) and (B61).
- 3) Disconnect connector (B159) from joint box.
- 4) Measure resistance of harness between ignition switch connector and joint box.

#### Connector & terminal

(B72) No. 4 — (B159) No. 8:



**CHECK** : Is the resistance less than 1 Ω?

**YES** : Go to step 2A14.

**NO** : Repair harness and connector.

#### NOTE:

In this case, repair the following:

- Open circuit in harness between ignition switch connector and joint box.
- Poor contact in coupling connector (B61).

### 2A14 : CHECK POOR CONTACT.

Check poor contact in ignition switch connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : Is there poor contact in ignition switch connector?

**YES** : Repair poor contact in ignition switch connector.

**NO** : Go to step 2A15.

### 2A15 : CHECK POOR CONTACT.

Check poor contact in joint box 10 A fuse connector. <Ref. to FOREWORD [T3C1].>


**CHECK** : Is there poor contact in joint box 10 A fuse connector?

**YES** : Repair poor contact in joint box connector.

**NO** : Go to step 2A16.

### 2A16 : CHECK MAIN FAN RELAY.

- 1) Turn ignition switch to OFF.
- 2) Check continuity between main fan relay terminals.




**CHECK** : Does no continuity exist between terminals No. 25 and No. 26?

**YES** : Go to step 2A17.

**NO** : Replace main fan relay.

### 2A17 : CHECK MAIN FAN RELAY.

- 1) Connect battery to terminals No. 27 and No. 28 of main fan relay.
- 2) Check continuity between main fan relay terminals.



**CHECK** : Does continuity exist between terminals No. 25 and No. 26?

**YES** : Go to step 2A18.


**NO** : Replace main fan relay.

**2A18 : CHECK HARNESS CONNECTOR BETWEEN MAIN FAN RELAY AND MAIN FAN MOTOR.**

Measure resistance of harness between main fan motor connector and main fan relay terminal.

**Connector & terminal**

**(F17) No. 2 — (F66) No. 25:**



**CHECK** : *Is the resistance less than 1 Ω?*

**YES** : Go to step 2A19.

**NO** : Repair open circuit in harness between main fan motor and main fan relay connector.

**2A19 : CHECK POOR CONTACT.**

Check poor contact in main fan relay connector.  
<Ref. to FOREWORD [T3C1].>

**CHECK** : *Is there poor contact in main fan relay connector?*

**YES** : Repair poor contact in main fan relay connector.

**NO** : Go to step 2A20.

**2A20 : CHECK POOR CONTACT.**

Check poor contact in main fan relay connector.  
<Ref. to FOREWORD [T3C1].>

**CHECK** : *Is there poor contact in main fan motor connector?*

**YES** : Repair poor contact in main fan motor connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

## 3. Radiator Sub Fan (With A/C model only)

### A: OPERATION

**DETECTING CONDITION:**

**Condition (1):**

- Engine coolant temperature is below 95°C (203°F).
- A/C switch is turned ON.
- Vehicle speed is below 19 km/h (12 MPH).

**Condition (2):**

- Engine coolant temperature is above 100°C (212°F).
- A/C switch is turned OFF.
- Vehicle speed is below 19 km/h (12 MPH).

**TROUBLE SYMPTOM:**

- Radiator sub fan does not rotate under conditions (1) and (2) above.

**3A1 : CHECK POWER SUPPLY TO SUB FAN MOTOR.**


**CAUTION:**

**Be careful not to overheat engine during repair.**

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector from sub fan motor.
- 3) Start the engine, and warm it up until engine coolant temperature increases over 100°C (212°F).
- 4) Stop the engine and turn ignition switch to ON.
- 5) Measure voltage between sub fan motor connector and chassis ground.

**Connector & terminal**

**(F16) No. 2 (+) — Chassis ground (-):**



**CHECK** : *Is the voltage more than 10 V?*


**YES** : Go to step 3A2.

**NO** : Go to step 3A5.

**3A2 : CHECK GROUND CIRCUIT OF SUB FAN MOTOR.**

- 1) Turn ignition switch to OFF.
- 2) Measure resistance between sub fan motor connector and chassis ground.

**Connector & terminal**  
**(F16) No. 1 — Chassis ground:**



- CHECK** : **Is the resistance less than 5 Ω?**
- YES** : Go to step **3A3**.
- NO** : Repair open circuit in harness between sub fan motor connector and chassis ground.


**3A3 : CHECK POOR CONTACT.**

Check poor contact in sub fan motor connector.  
 <Ref. to FOREWORD [T3C1].>

- CHECK** : **Is there poor contact in sub fan motor connector?**
- YES** : Repair poor contact in sub fan motor connector.
- NO** : Go to step **3A4**.

**3A4 : CHECK SUB FAN MOTOR.**

Connect battery positive (+) terminal to terminal No. 2, and negative (-) terminal to terminal No. 1 of sub fan motor connector.




- CHECK** : **Does the sub fan rotate?**
- YES** : Repair poor contact in sub fan motor connector.
- NO** : Replace sub fan motor with a new one.

**3A5 : CHECK POWER SUPPLY TO SUB FAN RELAY.**

- 1) Turn ignition switch to OFF.
- 2) Remove sub fan relay from A/C relay holder.
- 3) Measure voltage between sub fan relay terminal and chassis ground.

**Connector & terminal**  
**(F28) No. 18 (+) — Chassis ground (-):**



- CHECK** : **Is the voltage more than 10 V?**
- YES** : Go to step **3A6**.
- NO** : Go to step **3A7**.




### 3A6 : CHECK POWER SUPPLY TO SUB FAN RELAY.

- 1) Turn ignition switch to ON.
- 2) Measure voltage between sub fan relay terminal and chassis ground.

#### Connector & terminal

(F28) No. 20 (+) — Chassis ground (-):




**CHECK** : Is the voltage more than 10 V?

**YES** : Go to step 3A16.

**NO** : Go to step 3A12.

### 3A7 : CHECK 20 A FUSE.

- 1) Remove 20 A fuse from A/C relay holder.
- 2) Check condition of fuse.



**CHECK** : Is the fuse blown-out?

**YES** : Replace fuse.

**NO** : Go to step 3A8.


### 3A8 : CHECK HARNESS CONNECTOR BETWEEN MAIN FUSE BOX AND A/C RELAY HOLDER 20 A FUSE.

- 1) Disconnect connector from main fuse box.
- 2) Disconnect connectors (F25) and (F26) from generator, and (F34) from SBF holder.
- 3) Measure resistance of harness connector between main fuse box connector and A/C relay holder 20 A fuse terminals.

#### Connector & terminal

(F35) No. 1 — (F27) No. 3:

(F35) No. 2 — (F27) No. 3:



**CHECK** : Is the resistance less than 1 Ω?

**YES** : Go to step 3A9.

**NO** : Repair open circuit in harness between main fuse box connector and 20 A fuse terminal.

### 3A9 : CHECK POOR CONTACT.

Check poor contact in main fuse box connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : Is there poor contact in main fuse box connector?

**YES** : Repair poor contact in main fuse box connector.

**NO** : Go to step 3A10.

### 3A10 : CHECK POOR CONTACT.

Check poor contact in A/C relay holder 20 A fuse connector. <Ref. to FOREWORD [T3C1].>

**CHECK** : Is there poor contact in A/C relay holder 20 A fuse connector?

**YES** : Repair poor contact in 20 A fuse


**NO** : Go to step 3A11.

**3A11 : CHECK HARNESS CONNECTOR BETWEEN 20 A FUSE AND SUB FAN RELAY IN A/C RELAY HOLDER.**

Measure resistance of harness between 20 A fuse and sub fan relay terminal.

**Connector & terminal**


**(F27) No. 4 — (F28) No. 18:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Repair poor contact in sub fan relay connector.
- NO** : Repair open circuit in harness between 20 A fuse and sub fan relay connector.

**3A12 : CHECK FUSE.**

- 1) Turn ignition switch to OFF.
- 2) Remove fuse No. 17 from joint box.
- 3) Check condition of fuse.




- CHECK** : *Is the fuse blown-out?*
- YES** : Replace fuse.
- NO** : Go to step 3A13.

**3A13 : CHECK HARNESS CONNECTOR BETWEEN IGNITION SWITCH AND JOINT BOX.**

- 1) Disconnect connector from ignition switch.
- 2) Separate connectors (F44) and (B61).
- 3) Disconnect connector (B159) from joint box.
- 4) Measure resistance of harness between ignition switch connector and joint box.

**Connector & terminal**

**(B72) No. 4 — (B159) No. 8:**



- CHECK** : *Is the resistance less than 1 Ω?*
- YES** : Go to step 3A14.
- NO** : Repair harness and connector.

**NOTE:**

In this case, repair the following:

- Open circuit in harness between ignition switch connector and joint box.
- Poor contact in coupling connector (B61).

**3A14 : CHECK POOR CONTACT.**

Check poor contact in ignition switch connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in ignition switch connector?*
- YES** : Repair poor contact in ignition switch connector.
- NO** : Go to step 3A15.


**3A15 : CHECK POOR CONTACT.**

Check poor contact in joint box 10 A fuse connector. <Ref. to FOREWORD [T3C1].>

- CHECK** : *Is there poor contact in joint box 10 A fuse connector?*
- YES** : Repair poor contact in joint box connector.
- NO** : Go to step 3A16.

### 3A16 : CHECK SUB FAN RELAY.

- 1) Turn ignition switch to OFF.
- 2) Check continuity between sub fan relay terminals.




**CHECK** : Does no continuity exist between terminals No. 17 and No. 18?

**YES** : Go to step 3A17.

**NO** : Replace sub fan relay.

### 3A17 : CHECK SUB FAN RELAY.

- 1) Connect battery to terminals No. 19 and No. 20 of sub fan relay.
- 2) Check continuity between sub fan relay terminals.



**CHECK** : Does continuity exist between terminals No. 17 and No. 18?


**YES** : Go to step 3A18.

**NO** : Replace sub fan relay.

### 3A18 : CHECK HARNESS CONNECTOR BETWEEN SUB FAN RELAY AND SUB FAN MOTOR.

Measure resistance of harness between sub fan motor connector and sub fan relay terminal.

**Connector & terminal**  
(F16) No. 2 — (F28) No. 17:



**CHECK** : Is the resistance less than 1 Ω?

**YES** : Go to step 3A19.

**NO** : Repair open circuit in harness between sub fan motor and sub fan relay connector.

### 3A19 : CHECK POOR CONTACT.

Check poor contact in sub fan relay connector.  
<Ref. to FOREWORD [T3C1].>

**CHECK** : Is there poor contact in sub fan relay connector?

**YES** : Repair poor contact in sub fan relay connector.

**NO** : Go to step 3A20.

### 3A20 : CHECK POOR CONTACT.

Check poor contact in sub fan relay connector.  
<Ref. to FOREWORD [T3C1].>

**CHECK** : Is there poor contact in sub fan motor connector?

**YES** : Repair poor contact in sub fan motor connector.

**NO** : Contact with SOA service.

**NOTE:**

Inspection by DTM is required, because probable cause is deterioration of multiple parts.

MEMO: