

Brought to you by Eris Studios
NOT FOR RESALE

AUTOMATIC TRANSMISSION

General Description

AUTOMATIC TRANSMISSION

1. General Description

A: SPECIFICATION

1. TORQUE CONVERTER CLUTCH

Model	Non-turbo	Turbo
Type	Symmetric, 3 element, single stage, 2 phase torque converter	
Stall torque ratio	2.05 — 2.35	
Standard diameter mm (in)	246 (9.69)	
Stall speed (at sea level) rpm	2,200 — 2,700	2,600 — 3,100
One-way clutch	Sprag type one-way clutch	

2. OIL PUMP

Type	Parachoid constant-displacement pump	
Driving method	Driven by engine	
Number of teeth	Inner rotor	9
	Outer rotor	10

3. TRANSMISSION CONTROL ELEMENT

Type	4-forward, 1-reverse double-row planetary gears
Multi-plate clutch	3 sets
Multi-plate brake	2 sets
One-way clutch (sprag type)	1 sets

4. TRANSMISSION GEAR RATIO

1st	2.785
2nd	1.545
3rd	1.000
4th	0.694
Rev	2.272

5. PLANETARY GEAR AND PLATE

Model	Non-turbo	Turbo
Number of front sun gear teeth	33	
Number of front pinion teeth	21	
Number of front internal gear teeth	75	
Number of rear sun gear teeth	42	
Number of rear pinion teeth	17	
Number of rear internal gear teeth	75	
Number of high clutch drive plates	4	5
Number of low clutch drive plates	5	7
Number of reverse clutch drive plates	2	
Number of drive plates for the 2-4 brake	3	4
Number of drive plates for low & reverse brake	5	7

6. SELECTOR POSITION

P (Park)	Transmission is in neutral, output member is immovable, engine start is possible
R (Reverse)	Transmission in reverse for backing up
N (Neutral)	Transmission is in neutral and engine start is possible
D (Drive)	Automatic gear change 1st ← → 2nd ↔ 3rd ← → 4th
3 (3rd)	Automatic gear change 1st ← → 2nd ↔ 3rd ← 4th
2 (2nd)	2nd gear will be locked (speed reduction is possible, 2nd ← 3rd ← 4th.)
1 (1st)	1st gear will be locked (speed reduction is possible, 1st ← 2nd ← 3rd ← 4th.)
Control method	Wire cable type

7. HYDRAULIC CONTROL AND LUBRICATION

Type	Electronic hydraulic control [4 forward gear changes made by electronic signals of vehicle speed and accelerator (throttle) opening]	
Fluid	Recommended materials	SUBARU ATF
	Alternative	Idemitsu: ATF CASTROL: Transmax J Pennzoil Quaker State: Pennzoil ATF-J
Fluid capacity ℓ (US qt, Imp qt)	9.3 — 9.6 (9.8 — 10.1, 8.2 — 8.4)	
Lubrication system	Forced feed lubrication with oil pump	
Oil	Automatic transmission fluid (see above)	

8. COOLING AND HARNESS

Cooling system	Liquid-cooler incorporated in radiator
Inhibitor switch	12 poles
Transmission harness	20 poles

9. TRANSFER

Model	Non-turbo	Turbo
Transfer type	Multi-plate transfer (MP-T)	Variable torque distribution (VTD)
Number of transfer clutch drives and driven plates	5	3
Control method	Electronic hydraulic type	
Lubricant	Same automatic transmission fluid as used in the automatic transmission	
Reduction gear ratio	1.000 (53/53)	

11. RECOMMENDED GEAR OIL

Lubrication oil	<p style="text-align: right;">MT-00001</p>
	<p>(1) Item</p> <p>(2) Front differential gear oil</p> <p>(3) API standard</p> <p>(4) SAE viscosity No. and applicable temperature</p>
Front differential oil capacity ℓ (US qt, Imp qt)	1.1 — 1.3 (1.2 — 1.4, 1.0 — 1.1)


General Description

AUTOMATIC TRANSMISSION

B: COMPONENT

1. TORQUE CONVERTER CLUTCH AND CASE

Brought to you by Eris Studios
NOT FOR RESALE



AT-00002

- | | |
|----------------------------------|-----------------------------------|
| (1) Pitching stopper bracket | (9) Input shaft |
| (2) O-ring | (10) O-ring |
| (3) Differential oil level gauge | (11) Torque converter clutch ASSY |
| (4) Stay | (12) Drain plug |
| (5) Seal pipe | (13) Gasket |
| (6) Oil pump shaft | (14) Oil seal |
| (7) Clip | (15) Clip (turbo model) |
| (8) Rubber seal | |

(16) Converter case

Tightening torque: N·m (kgf·m, ft·lb)


T1: 18 (1.8, 13.3)

T2: 41 (4.2, 30.2)

T3: 44 (4.5, 32.5) (Aluminum gasket)

70 (7.1, 51.6) (Copper gasket)

2. OIL PUMP



AT-03594

- (1) Oil pump rotor
- (2) Oil pump cover
- (3) Seal ring
- (4) Thrust needle bearing
- (5) Drive pinion shaft
- (6) Roller bearing
- (7) Shim
- (8) Oil pump housing
- (9) Nipple
- (10) Air breather hose

- (11) Gasket
- (12) O-ring
- (13) Test plug
- (14) Stud bolt
- (15) O-ring
- (16) O-ring
- (17) Oil seal retainer
- (18) Oil seal
- (19) O-ring
- (20) Drive pinion collar

- (21) Lock nut


Tightening torque: N·m (kgf·m, ft·lb)

- T1: 7 (0.7, 5.1)**
- T2: 13 (1.3, 9.6)**
- T3: 18 (1.8, 13.3)**
- T4: 25 (2.5, 18.4)**
- T5: 40 (4.1, 30)**
- T6: 42 (4.3, 31)**
- T7: 116 (11.8, 85)**

General Description

AUTOMATIC TRANSMISSION

3. TRANSMISSION CASE AND CONTROL DEVICE



AT-03373

General Description

AUTOMATIC TRANSMISSION

- | | |
|---------------------------|----------------------------|
| (1) ATF level gauge | (18) Gasket |
| (2) Oil charge pipe | (19) Oil pan |
| (3) O-ring | (20) Magnet |
| (4) Straight pin | (21) Stud bolt (short) |
| (5) Return spring | (22) Stud bolt (long) |
| (6) Shaft | (23) Parking rod |
| (7) Parking pawl | (24) Manual plate |
| (8) Parking support | (25) Spring pin |
| (9) Transfer clutch seal | (26) Detent spring |
| (10) Gasket | (27) Ball |
| (11) Inlet pipe | (28) Spring |
| (12) Union screw | (29) Gasket |
| (13) O-ring | (30) Outlet pipe |
| (14) Test plug | (31) Union screw |
| (15) Oil filter | (32) Oil seal |
| (16) Oil filter stud bolt | (33) Range select lever |
| (17) Drain plug | (34) Inhibitor switch ASSY |

- | |
|------------------------|
| (35) Nipple |
| (36) Air breather hose |
| (37) Transmission case |
| (38) Plate ASSY |
| (39) Washer |

Tightening torque:N·m (kgf-m, ft-lb)

T1: 3.4 (0.35, 2.5)

T2: 5 (0.5, 3.6)

T3: 6 (0.6, 4.3)

T4: 12 (1.2, 9)

T5: 13 (1.3, 9.6)

T6: 14 (1.4, 10)

T7: 18 (1.8, 13.3)

T8: 25 (2.5, 18.4)


T9: 40 (4.1, 30)

T10: 45 (4.6, 33)

General Description

AUTOMATIC TRANSMISSION

4. CONTROL VALVE AND HARNESS ROUTING



AT-01322


- | | |
|---|--------------------------------|
| (1) Stay | (6) O-ring |
| (2) Transmission harness | (7) Front vehicle speed sensor |
| (3) O-ring | (8) O-ring |
| (4) O-ring | (9) Rear vehicle speed sensor |
| (5) Torque converter turbine speed sensor | (10) Control valve ASSY |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 7 (0.7, 5.1)

T2: 8 (0.8, 5.8)

5. HIGH CLUTCH AND REVERSE CLUTCH




AT-00006

- | | | |
|---------------------------|------------------------------------|---------------------------------------|
| (1) High clutch drum | (8) Spring retainer | (15) Dish plate |
| (2) Lip seal | (9) Cover | (16) Driven plate (reverse clutch) |
| (3) D-ring | (10) Snap ring | (17) Drive plate (reverse clutch) |
| (4) Reverse clutch piston | (11) Driven plate (high clutch) | (18) Retaining plate (reverse clutch) |
| (5) D-ring | (12) Drive plate (high clutch) | (19) Snap ring |
| (6) D-ring | (13) Retaining plate (high clutch) | (20) Thrust needle bearing |
| (7) High clutch piston | (14) Snap ring | (21) High clutch hub |

General Description

AUTOMATIC TRANSMISSION


6. PLANETARY GEAR AND 2-4 BRAKE



AT-00007

- | | | |
|-----------------------------|----------------------------|--------------------------------|
| (1) Thrust needle bearing | (10) Washer | (19) Snap ring |
| (2) Front sun gear | (11) Thrust needle bearing | (20) Spring retainer |
| (3) Thrust needle bearing | (12) Rear internal gear | (21) 2-4 brake piston |
| (4) Snap ring | (13) Washer | (22) D-ring |
| (5) Front planetary carrier | (14) Snap ring | (23) D-ring |
| (6) Thrust needle bearing | (15) Retaining plate | (24) 2-4 brake piston retainer |
| (7) Rear sun gear | (16) Drive plate | (25) 2-4 brake seal |
| (8) Thrust needle bearing | (17) Driven plate | (26) Leaf spring |
| (9) Rear planetary carrier | (18) Pressure rear plate | |

7. LOW CLUTCH AND LOW & REVERSE BRAKE



AT-03603

- | | | |
|------------------------|--------------------------------|---------------------------------|
| (1) Snap ring | (13) Needle bearing | (24) Return spring |
| (2) Retaining plate | (14) Snap ring | (25) Snap ring |
| (3) Drive plate | (15) One-way clutch | (26) Retaining plate |
| (4) Driven plate | (16) Snap ring | (27) Leaf spring |
| (5) Dish plate | (17) Thrust needle bearing | (28) Drive plate |
| (6) Snap ring | (18) Seal ring | (29) Driven plate |
| (7) Cover | (19) Needle bearing | (30) Dish plate |
| (8) Spring retainer | (20) One-way clutch inner race | (31) Low & reverse brake piston |
| (9) D-ring | (21) Washer | |
| (10) Low clutch piston | (22) Socket bolt | |
| (11) D-ring | (23) Spring retainer | |
| (12) Low clutch drum | | |


Tightening torque: N·m (kgf·m, ft·lb)

T: 25 (2.5, 18.4)

General Description

AUTOMATIC TRANSMISSION

8. REDUCTION GEAR (MP-T MODEL)




AT-02930

- | | | |
|---------------------------|---------------------------|---------------|
| (1) Seal ring | (6) Snap ring | (11) Lock nut |
| (2) Ball bearing | (7) Ball bearing | |
| (3) Reduction drive gear | (8) Snap ring | |
| (4) Reduction drive shaft | (9) Reduction driven gear | |
| (5) Drive pinion shaft | (10) Washer | |

Tightening torque: N·m (kgf·m, ft·lb)

T: 100 (10.2, 73.8)

9. REDUCTION GEAR (VTD MODEL)



AT-02203

- | | | |
|----------------------------|-----------------------------|----------------------------|
| (1) Ball bearing | (13) Rear drive shaft | (25) Snap ring |
| (2) Reduction drive gear | (14) Ball bearing | (26) Ball bearing |
| (3) Washer | (15) Multi-plate clutch hub | (27) Snap ring |
| (4) Needle bearing | (16) Ball bearing | (28) Reduction driven gear |
| (5) Pinion gear | (17) Revolution gear | (29) Lock washer |
| (6) Carrier | (18) Driven plate (Thick) | (30) Lock nut |
| (7) Planetary pinion shaft | (19) Drive plate | (31) Gasket |
| (8) Snap ring | (20) Driven plate (Thin) | (32) Extension case |
| (9) Seal ring | (21) Driven plate (Thick) | |
| (10) Thrust needle bearing | (22) Retaining plate | |
| (11) Intermediate shaft | (23) Rear drive shaft shim | |
| (12) Thrust washer | (24) Drive pinion shaft | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

Tightening torque: N·m (kgf·m, ft·lb)


T: 100 (10.2, 73.8)

General Description

AUTOMATIC TRANSMISSION

10.DIFFERENTIAL GEAR

Brought to you by Eris Studios
NOT FOR RESALE




AT-00011

- | | | |
|----------------------------|--------------------------------|------------------------------|
| (1) Hypoid driven gear | (7) Oil seal | (13) Differential bevel gear |
| (2) Pinion shaft | (8) O-ring | |
| (3) Differential case (RH) | (9) Differential side retainer | |
| (4) Straight pin | (10) Lock plate | |
| (5) Differential case (LH) | (11) Washer | |
| (6) Taper roller bearing | (12) Differential bevel pinion | |

Tightening torque: N·m (kgf·m, ft·lb)
T1: 25 (2.5, 18.4)
T2: 62 (6.3, 45.7)

11. TRANSFER & EXTENSION CASE (MP-T MODEL)



AT-02976

- | | | |
|---------------------------------|-----------------------------|-----------------|
| (1) Thrust needle bearing | (10) Return spring | (19) Oil seal |
| (2) Needle bearing | (11) Transfer clutch piston | (20) Dust cover |
| (3) Snap ring | (12) Rear drive shaft | (21) Test plug |
| (4) Driven plate (Thick) | (13) Ball bearing | (22) O-ring |
| (5) Drive plate | (14) Seal ring | |
| (6) Driven plate (Thin) | (15) Gasket | |
| (7) Retaining plate | (16) Transfer clutch pipe | |
| (8) Snap ring | (17) Extension case | |
| (9) Transfer clutch piston seal | (18) Transmission hanger | |

Tightening torque: N·m (kgf·m, ft·lb)


T1: 13 (1.3, 9.6)

T2: 25 (2.5, 18.4)

General Description

AUTOMATIC TRANSMISSION

12. TRANSFER & EXTENSION CASE (VTD MODEL)



AT-03595

- | | | |
|--------------------------|-------------------------------------|--------------------------------|
| (1) Driven plate (Thick) | (10) Multi plate clutch piston ASSY | (19) O-ring |
| (2) Drive plate | (11) D-ring | (20) Rear vehicle speed sensor |
| (3) Driven plate (Thin) | (12) Gasket | (21) Transmission hanger |
| (4) Driven plate (Thick) | (13) Multiplate clutch pipe | (22) Harness bracket |
| (5) Retaining plate | (14) Extension case | |
| (6) Snap ring | (15) O-ring | |
| (7) Spring retainer | (16) Test plug | |
| (8) Plate | (17) Oil seal | |
| (9) O-ring | (18) Dust cover | |


Tightening torque: N·m (kgf·m, ft·lb)

T1: 7 (0.7, 5.1)

T2: 13 (1.3, 9.6)

T3: 25 (2.5, 18.4)

13.TRANSMISSION MOUNTING



AT-03696

- (1) Pitching stopper
- (2) Rear cushion rubber
- (3) Transmission rear crossmember
- (4) Stopper

Tightening torque:N·m (kgf·m, ft·lb)





- T1: 35 (3.6, 26)**
- T2: 39 (4.0, 29)**
- T3: 50 (5.1, 36.9)**
- T4: 58 (5.9, 43)**
- T5: 70 (7.1, 51.6)**

C: CAUTION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Do not place the oil pan with its inner side facing up until it is installed, to prevent intrusion of foreign matter into the valve body.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- When disassembling the case and other light alloy parts, use a plastic hammer to force it apart. Do not pry apart with screwdrivers or other tools.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Use SUBARU genuine gear oil, grease etc. or equivalent. Do not mix fluid, grease, etc. of different grades or manufacturers.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place lifts, shop jacks or rigid racks at the specified points.
- Before installation, apply ATF or gear oil onto sliding or revolving surfaces to meet the application of the part.
- Replace deformed or damaged snap rings with new parts.
- Before installing O-rings or oil seals, apply sufficient amount of ATF fluid to avoid damage and deformation.
- Be careful not to incorrectly install or fail to install O-rings, snap rings and other such parts.
- Before securing a part on a vise, place cushioning material such as wood blocks, aluminum plate, or cloth between the part and the vise.
- Avoid damaging the mating surface of the case.
- Before applying liquid gasket, completely remove the old seal.
- When disassembling the AT, be sure to use nylon gloves and paper towels. Do not use cloth gloves or waste cloth.






D: PREPARATION TOOL

1. SPECIAL TOOL

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="337 625 467 646">ST-498575400</p>	498575400	OIL PRESSURE GAUGE ASSY	Used for measuring oil pressure.
 <p data-bbox="337 976 467 997">ST-498897200</p>	498897200	OIL PRESSURE GAUGE ADAPTER	Used at the oil pump housing when measuring reverse clutch pressure and line pressure.
 <p data-bbox="337 1327 467 1348">ST-498897700</p>	498897700	OIL PRESSURE ADAPTER SET	Used for measuring transfer clutch pressure.
 <p data-bbox="337 1677 467 1698">ST-498545400</p>	498545400	OIL FILTER WRENCH	Used for removing and installing the ATF filter.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-498277200</p>	498277200	STOPPER SET	Used for removing and installing automatic transmission assembly to engine.
 <p style="text-align: center;">ST41099AC000</p>	41099AC000	ENGINE SUPPORT ASSY	Used for supporting the engine.
 <p style="text-align: center;">ST-398527700</p>	398527700	PULLER ASSY	<ul style="list-style-type: none"> • Used for removing the extension case roller bearing. • Used for removing the extension oil seal. • Used for removing the front differential side retainer bearing outer race. • Used for removing the front differential side retainer oil seal.
 <p style="text-align: center;">ST-498057300</p>	498057300	INSTALLER	Used for installing the extension oil seal.
 <p style="text-align: center;">ST-498077000</p>	498077000	REMOVER	Used for removing the differential taper roller bearing.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="337 520 467 541">ST-499247400</p>	499247400	INSTALLER	<ul style="list-style-type: none"> • Used for installing the transfer outer snap ring. • Used together with the SNAP RING OUTER GUIDE (499257300).
 <p data-bbox="337 871 467 892">ST-499257300</p>	499257300	SNAP RING OUTER GUIDE	<ul style="list-style-type: none"> • Used for installing the transfer outer snap ring. • Used together with the INSTALLER (499247400).
 <p data-bbox="324 1222 467 1243">ST-18630AA010</p>	18630AA010	WRENCH COMPL RETAINER	<ul style="list-style-type: none"> • Used for removing and installing the differential side retainer. • WRENCH ASSEMBLY (499787000) can also be used.
 <p data-bbox="337 1572 467 1593">ST-398437700</p>	398437700	DRIFT	<ul style="list-style-type: none"> • Used for installing the converter case oil seal. • Used for installing the front differential taper roller bearing.
 <p data-bbox="337 1921 467 1942">ST-398673600</p>	398673600	COMPRESSOR	Used for removing and installing the clutch spring.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-498255400</p>	498255400	PLATE	Used for measuring the backlash of hypoid gear.
 <p style="text-align: center;">ST-399893600</p>	399893600	PLIER	Used for removing and installing the clutch spring.
 <p style="text-align: center;">ST-498247001</p>	498247001	MAGNET BASE	<ul style="list-style-type: none"> • Used for measuring the gear backlash. • Used together with the DIAL GAUGE (498247100).
 <p style="text-align: center;">ST-498247100</p>	498247100	DIAL GAUGE	<ul style="list-style-type: none"> • Used for measuring the gear backlash. • Used together with the MAGNET BASE (498247001).
 <p style="text-align: center;">ST-498517000</p>	498517000	REPLACER	Used for removing the front roller bearing.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p>ST-398623600</p>	398623600	SEAT	Used for removing the spring of the transfer clutch piston.
 <p>ST-499267300</p>	499267300	STOPPER PIN	Used for installing the inhibitor switch.
 <p>ST-499787700</p>	499787700	WRENCH	Used for removing and installing the drive pinion lock nut.
 <p>ST-499787500</p>	499787500	ADAPTER	Used for removing and installing the drive pinion lock nut.
 <p>ST-398643600</p>	398643600	GAUGE	Used for measuring the total end play, extension end play and drive pinion height.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-498627100</p>	498627100	SEAT	Used for holding the low clutch piston retainer spring when installing snap ring.
 <p style="text-align: center;">ST-499577000</p>	499577000	GAUGE	<ul style="list-style-type: none"> • Used for measuring the mating surface of the transmission to the end face of the reduction gear. • For MP-T models
 <p style="text-align: center;">ST-398744300</p>	398744300	GAUGE	<ul style="list-style-type: none"> • Used for measuring the mating surface of the transmission to the end face of the multiplate clutch. • For VTD models
 <p style="text-align: center;">ST-499737000</p>	499737000	PULLER	Used for removing the reduction driven gear assembly.
 <p style="text-align: center;">ST-499737100</p>	499737100	PULLER SET	Used for removing the reduction drive gear assembly.






General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p data-bbox="337 518 467 541">ST-498077600</p>	498077600	REMOVER	Used for removing the ball bearing.
 <p data-bbox="337 869 467 892">ST-498937110</p>	498937110	HOLDER	Used for removing and installing the drive pinion lock nut.
 <p data-bbox="337 1220 467 1243">ST-498677100</p>	498677100	COMPRESSOR	Used for installing the 2-4 brake snap ring.
 <p data-bbox="337 1570 467 1593">ST-498437000</p>	498437000	HIGH CLUTCH PISTON GUIDE	Used for installing the high clutch piston.
 <p data-bbox="337 1921 467 1944">ST-498437100</p>	498437100	LOW CLUTCH PISTON GUIDE	Used for installing the low clutch piston.

General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
 <p style="text-align: center;">ST-899580100</p>	899580100	INSTALLER	Used for press-fitting the ball bearing of the transfer clutch.
 <p style="text-align: center;">ST18675AA000</p>	18675AA000	DIFFERENTIAL SIDE OIL SEAL INSTALLER	Used for installing the differential side retainer oil seal.
 <p style="text-align: center;">ST28399SA010</p>	28399SA010	OIL SEAL PROTECTOR	Used for installing the front drive shaft.
 <p style="text-align: center;">ST-398497701</p>	398497701	INSTALLER	Used for installing the needle bearing.
 <p style="text-align: center;">ST-499247300</p>	499247300	INSTALLER	Used for installing drive pinion shaft oil seal.

General Description

AUTOMATIC TRANSMISSION

ILLUSTRATION	TOOL NUMBER	DESCRIPTION	REMARKS
<p>ST-899524100</p>	899524100	PULLER SET	Use only the bolt. <ul style="list-style-type: none"> Used together with the PULLER SET (499737100). Used together with the PULLER (499737000). (1) Puller (2) Cap
<p>ST-398663600</p>	398663600	PLIER	Used for removing and installing snap ring.
<p>ST1B020XU0</p>	1B020XU0	SUBARU SELECT MONITOR KIT	Used for troubleshooting the electrical system.

2. GENERAL TOOL

TOOL NAME	REMARKS
Depth gauge	Used for measuring the transmission end play.
Thickness gauge	Used for measuring clearance of the clutch, brake and oil pump.
Micrometer	Used for measuring thickness of the drive pinion.
Spring balance	Used for measuring the starting torque of the drive pinion.
Circuit tester	Used for measuring resistance and voltage.
TORX® T70	Used for installing and removing the differential gear oil drain plug.
Push/pull gauge	Used for measuring low, reverse and high clutch piston stroke.

2. Automatic Transmission Fluid

A: INSPECTION


NOTE:

The level of ATF varies with fluid temperature. Pay attention to the ATF temperature when checking ATF level.

1) Raise the ATF temperature by driving a distance of 5 to 10 km (3 to 6 miles). Otherwise, idle the engine to raise ATF temperature to 70 — 80°C (158 — 176°F) on Subaru Select Monitor. <Ref. to 4AT(D)(diag)-14, READ CURRENT DATA, OPERATION, Subaru Select Monitor.>

2) Make sure the vehicle is level.

3) After selecting all positions (P, R, N, D, 3, 2, 1), set the select lever in “P” range. Idle the engine for 1 — 2 minutes, and measure the ATF level.



- (A) ATF level gauge
- (B) Upper level
- (C) Lower level

4) Make sure that the ATF level is between upper and lower marks of the HOT side.

If the ATF level is below lower level, check the transmission for leaks. If there are leaks, it is necessary to repair or replace gasket, oil seals, plugs or other parts.

CAUTION:

- Use care not to exceed the upper limit level.
- Addition of ATF to the upper level when the transmission is cold will result in overfilling of ATF, causing a transmission failure.

5) Check ATF level after raising ATF temperature to 70 — 80°C (158 — 176°F) by driving the vehicle for 5 to 10 km (3 to 6 miles) or by idling the engine.

B: REPLACEMENT

- 1) Lift up the vehicle.
- 2) Drain the ATF completely.
- 3) Check the condition of ATF. <Ref. to 4AT-29, CONDITION CHECK, Automatic Transmission Fluid.>


CAUTION:

Immediately after the vehicle has been running, the ATF is very hot. Be careful not to burn yourself.

- 4) Replace the gasket with a new part, and then tighten the ATF drain plug.

Tightening torque:

25 N·m (2.5 kgf-m, 18.4 ft-lb)



- (A) Oil pan
- (B) Drain plug (ATF)

- 5) Lower the vehicle.
- 6) Pour ATF from the oil charge pipe.

Recommended fluid:

<Ref. to RM-3, FLUID, RECOMMENDED MATERIALS, Recommended Materials.>

Capacity:

Fill with the same amount of ATF that was drained from drain plug hole.

Capacity when transmission is overhauled:

9.3 — 9.6 ℓ (9.8 — 10.1 US qt, 8.2 — 8.4 Imp qt)

- 7) Check ATF level and for any leaks. <Ref. to 4AT-28, INSPECTION, Automatic Transmission Fluid.>

C: CONDITION CHECK

NOTE:


When replacing ATF, check the inside condition of transmission body by inspecting the drained ATF

Fluid condition	Trouble and possible cause	Corrective action
Large amount of metallic pieces are found.	Internal metal parts of transmission body are excessively worn.	Replace ATF and check if AT operates correctly.
Thick and varnish-form fluid.	Clutch etc. is burned.	Replace ATF and check the AT body or vehicle for faulty.
Clouded fluid or bubbles are found in fluid.	Water is mixed.	Replace ATF and check the water entering point.

3. Differential Gear Oil

A: INSPECTION

- 1) Park the vehicle on a level surface.
- 2) Remove the oil level gauge and wipe it clean.
- 3) Reinsert the level gauge all the way. Make sure the level gauge is inserted correctly and in the proper orientation.
- 4) Pull out the level gauge, and check the oil level. If the differential gear oil level is in "L" line or below, add oil to bring the level up to "F" line.
- 5) To prevent overfilling the differential gear oil, do not fill oil above the "F" line.



- (A) Oil level gauge
- (B) Upper level
- (C) Lower level

B: REPLACEMENT

- 1) Lift up the vehicle.
- 2) Remove the differential gear oil drain plug using TORX® bit T70, and drain the differential gear oil completely.

CAUTION:

- Immediately after the vehicle has been running, the differential gear oil is very hot. Be careful not to burn yourself.


- Be careful not to spill differential gear oil on the exhaust pipe to prevent it from emitting smoke or causing a fire. If differential gear oil is spilled on the exhaust pipe, wipe it off completely.

- 3) Replace the gasket with a new part and tighten the differential oil drain plug using the TORX® bit T70.

Tightening torque:

44 N·m (4.5 kgf-m, 32.5 ft-lb) (Aluminum gasket)

70 N·m (7.1 kgf-m, 51.6 ft-lb) (Copper gasket)



- (A) Oil pan
- (B) Differential oil drain plug

- 4) Lower the vehicle.
- 5) Pour gear oil into the gauge hole.

Recommended fluid:

<Ref. to 4AT-3, HYDRAULIC CONTROL AND LUBRICATION, SPECIFICATION, General Description.>

Gear oil capacity:

1.1 — 1.3 ℓ (1.2 — 1.4 US qt, 1.0 — 1.1 Imp qt)

- 6) Check the level of differential gear oil. <Ref. to 4AT-30, INSPECTION, Differential Gear Oil.>

4. Road Test

A: INSPECTION

1. GENERAL PRECAUTION

Road tests should be conducted to properly diagnose the condition of automatic transmission.

NOTE:

When performing the test, do not exceed the posted speed limit.

2. D RANGE SHIFT FUNCTION

Check shifting between 1st \leftrightarrow 2nd \leftrightarrow 3rd \leftrightarrow 4th while driving on normal city streets.

3. D RANGE SHIFT SHOCK

Check the shock level when shifting up during normal driving.

4. KICK-DOWN FUNCTION

Check kick-down for each gear. Check the shock level during kick-down at the same time.

5. ENGINE BRAKE OPERATION

- Drive in 4th gear of the D range [50 — 60 km/h (31 — 37 MPH)], and shift down to D \leftrightarrow \rightarrow 3rd range to check the engine brake in 3rd gear.
- Drive in 3rd gear of 3 range [40 — 50 km/h (25 — 31 MPH)], and shift down from 3rd \leftrightarrow \rightarrow to 2nd range to check the engine brake in 2nd gear.
- Drive in 2nd gear of 2 range [20 — 30 km/h (12 — 19 MPH)], and shift down from 2nd \leftrightarrow \rightarrow 1 range to check the engine brake in 1st gear.

6. LOCK-UP FUNCTION

- When the accelerator is lightly depressed while driving on a flat road in D range, check that rpm does not change abruptly.
- Check slip lock-up with following procedure. Subaru Select Monitor is required for judgment.

Before starting the check, check that no DTC is displayed using the Subaru Select Monitor. If there is a DTC, perform the corrective action according to the DTC. Recheck that there are no DTCs displayed, then perform the check.

1) The check is to be performed on a flat and straight road or on a free roller.

NOTE:

- Slip lock-up will not operate when the vehicle is lifted up off of its wheels, since there is no surface resistance.
- When checking on the free roller, the driving resistance will be slightly inadequate. It will be easier to judge if the foot brake is lightly applied while performing the check.

2) Connect the Subaru Select Monitor.

3) Check the ATF temperature using the Subaru Select Monitor.

NOTE:

- Make sure that the ATF temperature is between 50 — 100°C (122 — 212°F).
 - If the temperature is low, warm-up the ATF by running the vehicle.
- 4) Start the engine, so that the lock-up duty can be read on the data display of the Subaru Select Monitor.
- 5) Drive the vehicle at a constant speed of 35 — 40 km/h (22 — 25 MPH).
- 6) Read the lock-up duty while vehicle is running.

Standard:

25 — 45%

NOTE:

The reading may be slightly lower on a free roller.

- Slip lock-up control is not operating when the lock-up duty is 5% or less, or when the lock-up duty goes down immediately after starting to rise. In these cases, improper ATF or deterioration of the ATF may be the cause. Check the amount of ATF or replace the fluid, then recheck.

7. P RANGE OPERATION

Stop the vehicle on an uphill grade of 5% or more and shift to the “P” range. Check that the vehicle does not move when the parking brake is released.

8. NOISE AND VIBRATION

Check for noise and vibration while driving and during shifting.

9. CLIMBING CONTROL FUNCTION

- Check for whether the vehicle will drive with the gear fixed in 3rd when climbing hills.
- Check that while descending down a hill, the gear remains in 3rd when the brakes are applied.

10. TRANSFER CLUTCH

Check for tight corner braking phenomenon when the vehicle is moved forward with the steering fully turned.

11. OIL LEAKAGE

After the driving test, inspect for oil leaks.

5. Stall Test

A: INSPECTION

NOTE:

The stall test is extremely important in diagnosing the condition of an automatic transmission and engine. It is necessary to perform this test to measure the engine stall speeds in the “R” and “2” ranges.

Purposes of the stall test:

- Operational check of the automatic transmission clutch
 - Operational check of the torque converter clutch
 - Engine performance check
- 1) Check that the throttle valve fully opens.
 - 2) Check that the engine oil level is correct.
 - 3) Check that the engine coolant level is correct.
 - 4) Check that the ATF level is correct.
 - 5) Check that the differential gear oil level is correct.
 - 6) Increase the ATF temperature to 70 to 80°C (158 to 176°F) by idling the engine for approximately 30 minutes (with select lever set to “N” or “P”).
 - 7) Place wheel chocks at the front and rear of all wheels and engage the parking brake.
 - 8) Move the manual linkage to ensure it operates properly. Shift the select lever to the “2” range.
 - 9) While pressing hard on the foot brake pedal, slowly depress the accelerator pedal to full throttle.

10) When the engine speed is stabilized, quickly record the engine speed and release accelerator pedal.

11) Shift the select lever to “N” range, and cool down the engine by idling it for one minute or more.

12) If the stall speed in the “2” range is higher than specifications, low clutch and 2-4 brake may slip. To identify this, conduct the same test as above in “R” range.

13) Perform the stall tests with the select lever in “D” range.

NOTE:

- Do not continue the stall test for more than 5 seconds at a time. (From closed throttle / full open throttle to reading stall speed) If this instruction is ignored, the engine oil and ATF oil may deteriorate, and it may be detrimental to the clutch and brake.
- Be sure to cool down the engine for at least one minute after each stall test with the select lever set in the “P” or “N” range and with the idle speed of 1,200 rpm or less.
- If the stall speed is higher than the specified range, attempt to finish the stall test in as short a time as possible, in order to prevent the automatic transmission from sustaining damage.


Stall speed (at sea level):

Non-turbo model:

2,200 — 2,700 rpm

Turbo model:

2,600 — 3,100 rpm



(A) Brake pedal
(B) Accelerator pedal

Stall speed (at sea level)	Range	Cause
Specified value or below	2, R	<ul style="list-style-type: none"> • Throttle valve is not fully open • Engine malfunction • One-way clutch of the torque converter is slipping
Over specified value	D	<ul style="list-style-type: none"> • Line pressure too low • Low clutch slipping • One-way clutch malfunctioning
	R	<ul style="list-style-type: none"> • Line pressure too low • Reverse clutch slipping • Low & reverse brake slipping
	2	<ul style="list-style-type: none"> • Line pressure too low • Low clutch slipping • 2-4 brake slipping

6. Time Lag Test

A: INSPECTION

NOTE:

When the select lever is shifted while the engine is idling, there will be a certain time elapse or lag before shock is felt. This is used for checking the condition of the low clutch, reverse clutch, low & reverse brake and one-way clutch.

- Perform the test at normal operation fluid temperature of 70 — 80°C (158 — 176°F).
- Be sure to allow one minute or more interval between tests.
- Make three measurements and take the average value.

1) Fully apply the parking brake.

2) Start the engine.

Check the idle speed. (A/C OFF)

3) Shift the select lever from “N” to “D” range.

Using a stop watch, measure the time which takes from shifting the lever until the shock is felt.

Time lag: 1.2 seconds or less

If “N” → “D” time lag is longer than specified:

- Line pressure too low
- Low clutch worn
- One-way clutch not operating properly
- Low clutch D-ring worn

4) In the same manner, measure the time lag of “N” → “R”.

Time lag: 1.5 seconds or less

If “N” → “R” time lag is longer than specified:

- Line pressure too low
- Reverse clutch worn
- Low & reverse brake worn
- Reverse clutch D-ring worn

7. Line Pressure Test

A: MEASUREMENT


NOTE:

If the clutch or brake shows a signs of slipping or shift feel is not correct, check the line pressure.

- Excessive shock during up-shift or if shifting takes place at a higher point than for normal conditions, this may be due to the line pressure being too high.
- Slippage or inability to operate the vehicle may, in most cases, be due to loss of oil pressure for the operation of clutch, brake or control valve.


- 1) Line pressure measurement (under no load):
 - (1) Before measuring line pressure, raise the vehicle on a lift.
 - (2) Maintain the ATF temperature at approx. 70 — 80°C (158 — 176°F) during measurement. (ATF will reach the temperature above after idling the engine for approx. 30 minutes with the select lever in “N” or “P”.)
- 2) Line pressure measurement (under heavy load):
 - (1) Before measuring line pressure, apply both the foot and parking brakes with all wheels chocked (Same as for stall test conditions).
 - (2) Measure the line pressure with the select lever in “R” or “2” and with the engine under a stall condition.
 - (3) Measure the line pressure within 5 seconds after shifting the select lever to each position. (If the line pressure needs to be measured again, allow the engine to idle and cool it down for more than 1 minute.)
 - (4) Maintain the ATF temperature at approx. 70 — 80°C (158 — 176°F) during measurement. (The ATF will reach the temperature above, after idling the engine for approx. 30 minutes with the select lever in “N” or “P”.)
- 3) Temporarily attach the ST to a suitable place in the driver’s compartment, remove the blind plug located in front of the toe board and pass the hose of the ST to the engine compartment.

ST 498575400 OIL PRESSURE GAUGE ASSY



- (A) Pressure gauge hose
- (B) Hole in toe board (blank cap hole)
- (C) Brake pedal

- 4) Remove the test plug and attach the ST instead.
ST 498897200 OIL PRESSURE GAUGE ADAPTER



(A) Test plug

- 5) Connect the ST1 with ST2.
ST1 498897200 OIL PRESSURE GAUGE ADAPTER
ST2 498575400 OIL PRESSURE GAUGE ASSY

- 6) Open/close the throttle valve, and check for changes in duty ratio using the Subaru Select Monitor.

Standard line pressure			
Range position	Line pressure duty ratio (%)	Throttle valve angle	Line pressure kPa (kgf/cm ² , psi)
2	25 — 35	100 (Full open)	1,000 — 1,300 (10.2 — 13.3, 145 — 189)
R	15 — 25	100 (Full open)	1,500 — 1,850 (15.3 — 18.9, 218 — 268)
D	35 — 43	0 (Fully closed)	500 — 800 (5.1 — 8.2, 73 — 116)

8. Transfer Clutch Pressure Test

A: INSPECTION

- MP-T model

Check the transfer clutch pressure in accordance with the following chart in the same manner as line pressure. <Ref. to 4AT-34, Line Pressure Test.>

ST 498897700 OIL PRESSURE ADAPTER SET


ST 498575400 OIL PRESSURE GAUGE ASSY

AWD mode: "D" range

FWD mode: "P" range, engine rpm 2,000 rpm

NOTE:

Before setting to FWD mode, attach the spare fuse on the FWD switch.



(A) Test plug

NOTE:


If no oil pressure is produced or if it does not change in AWD mode, the transfer duty solenoid may be malfunctioning. If oil pressure is produced in FWD mode, there is a possibility that the same problem as in the AWD mode will occur.

- VTD model

Check the transfer clutch pressure in accordance with the following chart in the same manner as line pressure. <Ref. to 4AT-34, Line Pressure Test.>

ST 498897700 OIL PRESSURE ADAPTER SET

ST 498575400 OIL PRESSURE GAUGE ASSY



(A) Test plug

Standard transfer clutch pressure:

Range position	ON duty ratio (%)	Acceleration opening angle (%)	Transfer clutch pressure (kPa (kgf/cm ² , psi))	
			AWD mode	FWD mode
2	95	Fully opened (100)	1,000 — 1,200 (10.2 — 12.2, 145 — 174)	—
	60	Adjust ON Duty ratio to 60%.	500 — 700 (5.1 — 7.1, 73 — 102)	—
	5	Fully closed (0)	—	0 (0, 0)
N or P	5	Fully closed (0)	0	—


Automatic Transmission Assembly

AUTOMATIC TRANSMISSION


9. Automatic Transmission Assembly

A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Open the front hood and support with the hood stay.
- 3) Disconnect the ground cable from the battery.
- 4) Remove the air intake chamber and intake duct. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 5) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 6) Remove the air intake chamber stay. (Non-turbo model)




- 7) Disconnect the following connectors.
 - (1) Transmission harness connectors



- (2) Transmission ground terminal

- 8) Remove the starter. <Ref. to SC(H4SO)-8, REMOVAL, Starter.>
- 9) Remove the throttle body. <Ref. to FU(H4SO)-12, REMOVAL, Throttle Body.> <Ref. to FU(H4DOTC)-16, REMOVAL, Throttle Body.>

- 10) Remove the pitching stopper.




- 11) Separate the torque converter clutch from the drive plate.


CAUTION:

- Be careful not to damage the mounting bolts.
- Be careful not to drop bolts into the converter case.

- (1) Install the V-belt cover.
- (2) Remove the service hole plug.
- (3) Remove the bolts which hold the torque converter clutch to the drive plate.
- (4) While rotating the crank pulley in the direction of engine rotation a little bit at a time, remove all bolts.



- 12) Attach the ST to the converter case.
ST 498277200 STOPPER SET




Automatic Transmission Assembly

AUTOMATIC TRANSMISSION

13) Remove the ATF level gauge.

NOTE:


Plug the opening to prevent entry of foreign particles into the transmission fluid.




14) Remove the pitching stopper bracket.

15) Set the ST.

ST 41099AC000 ENGINE SUPPORT ASSY



16) Remove the bolts which hold the upper side of the transmission to the engine.




17) Lift up the vehicle.

18) Remove the under cover.

19) Remove the front, center and rear exhaust pipes and the muffler. (Non-turbo model) <Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.> <Ref. to EX(H4SO)-8, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, REMOVAL, Muffler.>

20) Remove the center and rear exhaust pipes and the muffler. (Turbo model) <Ref. to EX(H4DOTC)-10, REMOVAL, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, REMOVAL, Muffler.>


21) Remove the ATF drain plug to drain ATF.



(A) Oil pan

(B) Drain plug (ATF)

22) Disconnect the ATF cooler hoses from the pipes of the transmission side, and remove the oil charge pipe.




23) Remove the propeller shaft. <Ref. to DS-15, REMOVAL, Propeller Shaft.>

24) Remove the shift select cable. <Ref. to CS-27, REMOVAL, Select Cable.>

25) Disconnect the stabilizer link from the transverse link.

26) Remove the bolt securing the ball joint of the transverse link to housing.



Automatic Transmission Assembly

AUTOMATIC TRANSMISSION

27) Pull out the front drive shaft from the transmission.

- (1) Using a tire lever or a crow bar, etc., pull out until the front drive shaft transmission side joint slides move smoothly.


NOTE:

Place cloth between the tire lever or bar and the transmission in order to avoid damaging the transmission side retainer.

- (2) Hold the transmission side joint of the front drive shaft by hand and extract the housing from the transmission while pressing the housing outward, so as not to stretch the boot.

28) Remove the bolts which hold the clutch housing cover.

29) Remove the bolts which hold the lower side of transmission to the engine.




30) Place a transmission jack below the transmission.

NOTE:

Make sure that the support plates of transmission jack do not touch the oil pan.

31) Remove the transmission rear crossmember from the vehicle.




32) While lowering the transmission jack gradually, fully retract the engine support, and then tilt the engine rearward.

33) Remove the transmission.

NOTE:

Remove the transmission and torque converter as a single unit from engine.



34) Remove the rear cushion rubber from the transmission assembly.

B: INSTALLATION

1) Replace the differential side oil seal with a new part. <Ref. to 4AT-45, REPLACEMENT, Differential Side Retainer Oil Seal.>

NOTE:

When a new oil seal has been installed, replacement is not required.


2) Install the rear cushion rubber to the transmission assembly.

Tightening torque:

39 N·m (4.0 kgf-m, 29 ft-lb)


3) Attach the ST to the converter case.

ST 498277200 STOPPER SET



4) Install the transmission onto the engine.

- (1) Lift up the transmission gradually using transmission jack.



Automatic Transmission Assembly


AUTOMATIC TRANSMISSION

- (2) Connect the transmission and the engine.
- (3) While raising the transmission jack gradually, turn the screw of engine support, and tilt the engine forward.
- 5) Install the transmission rear crossmember.

Tightening torque:

T1: 35 N·m (3.6 kgf-m, 26 ft-lb)


T2: 70 N·m (7.1 kgf-m, 51.6 ft-lb)



- 6) Remove the transmission jack.
- 7) Tighten the bolts which hold the lower side of the transmission to the engine.

Tightening torque:

50 N·m (5.1 kgf-m, 36.9 ft-lb)



- 8) Tighten the bolt of the clutch housing cover.
- 9) Lower the lift.
- 10) Connect the engine and transmission.
 - (1) Remove the ST from converter case.

NOTE:

When removing the ST, be careful not to drop it into converter case.


ST 498277200 STOPPER SET

- (2) Install the starter. <Ref. to SC(H4SO)-8, INSTALLATION, Starter.>

- (3) Tighten the bolts which hold the upper side of the transmission to the engine.

Tightening torque:

50 N·m (5.1 kgf-m, 36.9 ft-lb)



- 11) Install the torque converter clutch to drive plate.


CAUTION:

- Be careful not to damage the mounting bolts.
- Be careful not to drop bolts into the converter case.

- (1) Tighten the bolts which hold the torque converter clutch to the drive plate.
- (2) While rotating the crank pulley in the direction of engine rotation a little bit at a time, tighten all bolts.

Tightening torque:


25 N·m (2.5 kgf-m, 18.4 ft-lb)



- (3) Fit the plug to service hole.
- (4) Install the V-belt cover.

- 12) Remove the ST.

ST 41099AC000 ENGINE SUPPORT ASSY



Automatic Transmission Assembly

AUTOMATIC TRANSMISSION

13) Install the pitching stopper bracket.

Tightening torque:


T1: 41 N·m (4.2 kgf-m, 30.2 ft-lb)

14) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 36.9 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)



15) Install the throttle body. <Ref. to FU(H4SO)-12, INSTALLATION, Throttle Body.> <Ref. to FU(H4DOTC)-16, INSTALLATION, Throttle Body.>


16) Lift up the vehicle.

17) Replace the circlip of the front drive shaft with a new part.

18) Apply grease to the oil seal lip.

19) Attach the ST to side retainer.


ST 28399SA010 OIL SEAL PROTECTOR



20) Align and insert the spline of the front drive shaft to the splines of the differential bevel gear, and remove the ST.

ST 28399SA010 OIL SEAL PROTECTOR

21) Insert the front drive shaft into the transmission securely by pressing the front housing from the outside.



22) Install the ball joint into the housing.

23) Connect the stabilizer link to the transverse link, and tighten the bolts.


NOTE:

Use a new self-locking nut.

Tightening torque:


T1: 30 N·m (3.1 kgf-m, 22.1 ft-lb)

T2: 50 N·m (5.1 kgf-m, 36.9 ft-lb)



24) Install the shift select cable onto select lever. <Ref. to CS-27, INSTALLATION, Select Cable.>

25) Install the oil charge pipe, and connect the ATF cooler hoses to the pipe.



26) Install the propeller shaft. <Ref. to DS-16, INSTALLATION, Propeller Shaft.>

27) Install the rear exhaust pipe and muffler assembly.

Non-turbo model

<Ref. to EX(H4SO)-8, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, INSTALLATION, Muffler.>

Turbo model

<Ref. to EX(H4DOTC)-15, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, INSTALLATION, Muffler.>


28) Install the front and center exhaust pipe. (Non-turbo model) <Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.>

29) Install the center exhaust pipe. (Turbo model) <Ref. to EX(H4DOTC)-11, INSTALLATION, Center Exhaust Pipe.>

30) Install the under cover.

31) Lower the lift.

32) Install the ATF level gauge.



33) Connect the following connectors.

(1) Transmission harness connectors

(2) Transmission ground terminal

34) Install the air intake chamber stay.

Tightening torque:

16 N·m (1.6 kgf·m, 11.8 ft·lb)

35) Install the air intake chamber and intake duct. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>

36) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>

37) Connect the ground cable to the battery.

38) Using the oil charge pipe, fill with ATF until the fluid level is between the upper and lower level on the "COLD" side of the level gauge. <Ref. to 4AT-28, Automatic Transmission Fluid.>

39) Lower the vehicle from the lift.

40) Check the select lever operation. <Ref. to 4AT-46, INSPECTION, Inhibitor Switch.>

41) Bleed the air from the control valve body. <Ref. to 4AT-58, PROCEDURE, Air Bleeding of Control Valve.>

42) Check the ATF level. <Ref. to 4AT-28, Automatic Transmission Fluid.>

43) Execute learning control promotion. <Ref. to 4AT(D)(diag)-16, FACILITATION OF LEARNING CONTROL, OPERATION, Subaru Select Monitor.>


44) Perform the road test. <Ref. to 4AT-31, Road Test.>

10. Transmission Mounting System

A: REMOVAL

1. PITCHING STOPPER


- 1) Disconnect the ground cable from the battery.
- 2) Remove the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 3) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 4) Remove the throttle body. <Ref. to FU(H4SO)-12, REMOVAL, Throttle Body.> <Ref. to FU(H4DOTC)-16, REMOVAL, Throttle Body.>
- 5) Remove the pitching stopper.



2. TRANSMISSION REAR CROSSMEMBER & REAR CUSHION RUBBER

- 1) Disconnect the ground cable from the battery.
- 2) Jack-up the vehicle and support it with rigid racks.
- 3) Remove the front, center and rear exhaust pipes and the muffler. (Non-turbo model) <Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.> <Ref. to EX(H4SO)-8, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, REMOVAL, Muffler.>
- 4) Remove the center and rear exhaust pipes and the muffler. (Turbo model) <Ref. to EX(H4DOTC)-10, REMOVAL, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, REMOVAL, Muffler.>
- 5) Set the transmission jack under transmission. Make sure that the support plate of transmission jack does not touch the oil pan.

- 6) Remove the transmission rear crossmember.



- 7) Remove the rear cushion rubber.

B: INSTALLATION


1. PITCHING STOPPER

- 1) Install the pitching stopper.

Tightening torque:

T1: 50 N·m (5.1 kgf-m, 36.9 ft-lb)

T2: 58 N·m (5.9 kgf-m, 43 ft-lb)



- 2) Install the throttle body. <Ref. to FU(H4SO)-12, INSTALLATION, Throttle Body.> <Ref. to FU(H4DOTC)-16, INSTALLATION, Throttle Body.>
- 3) Install the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 4) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>

2. TRANSMISSION REAR CROSSMEMBER & REAR CUSHION RUBBER

1) Install the rear cushion rubber.

Tightening torque:


39 N·m (4.0 kgf·m, 29 ft·lb)

2) Install the crossmember.

Tightening torque:

T1: 35 N·m (3.6 kgf·m, 26 ft·lb)

T2: 70 N·m (7.1 kgf·m, 51.6 ft·lb)



3) Remove the transmission jack.

4) Install the front, center and rear exhaust pipes, and the muffler. (Non-turbo model) <Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.> <Ref. to EX(H4SO)-8, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, INSTALLATION, Muffler.>

5) Install the center, rear exhaust pipes and the muffler. (Turbo model) <Ref. to EX(H4DOTC)-11, INSTALLATION, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, INSTALLATION, Muffler.>

C: INSPECTION

Repair or replace parts if the results of the inspection below are not satisfied.

1. PITCHING STOPPER

Make sure that the pitching stopper is not bent or damaged. Check that there are no cracks, hardening or damage on rubber parts.

2. TRANSMISSION REAR CROSSMEMBER & REAR CUSHION RUBBER

Make sure that the crossmember is not bent or damaged. Check that there are no cracks, hardening or damage on the cushion rubber.

11.Extension Case Oil Seal

A: INSPECTION

Make sure that the ATF is not leaking from the transmission and propeller shaft joint. If a leak is found, replace the oil seal. <Ref. to 4AT-44, REPLACEMENT, Extension Case Oil Seal.>

B: REPLACEMENT


- 1) Clean the transmission exterior.
- 2) Drain the ATF completely.

NOTE:

- Tighten the ATF drain plug after draining the ATF.
- Use a new gasket.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)



- (A) Oil pan
(B) Drain plug (ATF)

- 3) Remove the rear exhaust pipe and muffler.
Non-turbo model
<Ref. to EX(H4SO)-8, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, REMOVAL, Muffler.>
Turbo model
<Ref. to EX(H4DOTC)-15, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, REMOVAL, Muffler.>
- 4) Remove the propeller shaft. <Ref. to DS-15, REMOVAL, Propeller Shaft.>
- 5) Remove the oil seal using ST.
ST 398527700 PULLER ASSY
- 6) Using the ST, install the oil seal.
ST 498057300 INSTALLER
- 7) Install the propeller shaft. <Ref. to DS-16, INSTALLATION, Propeller Shaft.>

- 8) Install the rear exhaust pipe and muffler.
Non-turbo model
<Ref. to EX(H4SO)-8, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, INSTALLATION, Muffler.>
Turbo model
<Ref. to EX(H4DOTC)-15, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, INSTALLATION, Muffler.>
- 9) Fill with ATF and check the ATF level. <Ref. to 4AT-28, Automatic Transmission Fluid.>

12. Differential Side Retainer Oil Seal

A: INSPECTION

Check for leakage of gear oil from differential side retainer oil seal part. If there is an oil leak, replace the oil seal.

B: REPLACEMENT

- 1) Lift up the vehicle.
- 2) Remove the front exhaust pipe and center exhaust pipe.


Non-turbo model

<Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.>

Turbo model

<Ref. to EX(H4DOTC)-10, REMOVAL, Center Exhaust Pipe.>

- 3) Remove the differential gear oil drain plug, and drain the differential gear oil.



(A) Oil pan

(B) Differential gear oil drain plug

- 4) Replace the gasket with a new part and tighten the differential oil drain plug.

Tightening torque:

44 N·m (4.5 kgf·m, 32.5 ft·lb) (Aluminum gasket)


70 N·m (7.1 kgf·m, 51.6 ft·lb) (Copper gasket)

- 5) Separate the front drive shaft from the transmission. <Ref. to DS-31, REMOVAL, Front Drive Shaft.>

- 6) Remove the differential side retainer oil seal using a screw driver wrapped with vinyl tape etc.

- 7) Using the ST, install the differential side retainer oil seal by lightly tapping with a hammer.

ST 18675AA000 DIFFERENTIAL SIDE OIL SEAL INSTALLER



- 8) Apply oil to the oil seal lips.

- 9) Install the front drive shaft using the ST. <Ref. to DS-31, INSTALLATION, Front Drive Shaft.>

ST 28399SA010 OIL SEAL PROTECTOR

- 10) Install the front exhaust pipe and the center exhaust pipe.

Non-turbo model

<Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.>

Turbo model

<Ref. to EX(H4DOTC)-11, INSTALLATION, Center Exhaust Pipe.>

- 11) Lower the vehicle.

- 12) Pour differential gear oil into the gauge hole.

Recommended gear oil:

<Ref. to RM-2, LUBRICANTS, RECOMMENDED MATERIALS, Recommended Materials.>

Gear oil capacity:

1.1 — 1.3 ℓ (1.3 — 1.4 US qt, 1.0 — 1.1 Imp qt)

- 13) Check the gear oil level. <Ref. to 4AT-30, INSPECTION, Differential Gear Oil.>

13. Inhibitor Switch

A: INSPECTION


When the driving condition or starter motor operation is improper, first check the shift linkage for improper operation. If the shift linkage is functioning properly, check the inhibitor switch.

- 1) Disconnect the inhibitor switch connector.
- 2) Check continuity in inhibitor switch circuits with the select lever moved to each position.

NOTE:

- Also check that there is no continuity in ignition circuit when the select lever is in the “R”, “D”, “3”, “2” and “1” ranges.
- If the inhibitor switch does not operate, check for poor contact of the connector on transmission side.


	Range	Pin No.
Signal sent to TCM	P	4 — 3
	R	4 — 2
	N	4 — 1
	D	4 — 8
	3	4 — 7
	2	4 — 6
	1	4 — 5
Ignition circuit	P/N	12 — 11
Back-up light circuit	R	10 — 9



(A) Inhibitor switch connector

- 3) Check that there is continuity at equal points when the select lever is leaned 1.5° in both directions from the “N” range.

If there is continuity in only one direction or in other points, adjust the inhibitor switch. <Ref. to 4AT-46, ADJUSTMENT, Inhibitor Switch.>




- (A) Continuity does not exist.
- (B) Continuity exists.
- (C) 1.5°

- 4) Repeat the above checks. If there are abnormalities, adjust the select cable. <Ref. to CS-28, ADJUSTMENT, Select Cable.>

B: ADJUSTMENT

- 1) Set the select lever to “N” range.
- 2) Loosen the three inhibitor switch securing bolts.
- 3) Insert the ST as vertical as possible into the holes in the inhibitor switch lever and switch body.
ST 499267300 STOPPER PIN



- 4) Tighten the three inhibitor switch bolts.


Tightening torque:

3.5 N·m (0.36 kgf·m, 2.6 ft·lb)

- 5) Repeat the above checks. If the inhibitor switch is determined to be “faulty”, replace it.


C: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Set the select lever to "N" range.
- 3) Remove the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 4) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 5) Disconnect the inhibitor switch connector.




(A) Inhibitor switch

- 6) Remove the inhibitor switch connector from the stay.
- 7) Lift up the vehicle.
- 8) Remove the front and center exhaust pipes. <Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.> <Ref. to EX(H4DOTC)-10, REMOVAL, Center Exhaust Pipe.>
- 9) Remove the snap pin and washer from the range select lever.




- (A) Range select lever
- (B) Snap pin
- (C) Select cable
- (D) Washer

- 10) Remove the plate assembly from the transmission case.




- (A) Select cable
- (B) Plate ASSY

- 11) Remove the bolt.




(A) Inhibitor switch

- 12) Move the range select lever to the parking position (left side).



(A) Range select lever

- 13) Remove the inhibitor switch from the transmission.



(A) Inhibitor switch


Inhibitor Switch

AUTOMATIC TRANSMISSION

14) Disconnect the inhibitor switch harness connector from the inhibitor switch.

D: INSTALLATION

- 1) Connect the inhibitor switch harness connector to the inhibitor switch.
- 2) Install the inhibitor switch to the transmission case.




(A) Inhibitor switch

- 3) Move the range select lever to the neutral position.
- 4) Using the ST, tighten the bolts of the inhibitor switch.
ST 499267300 STOPPER PIN

Tightening torque:

3.5 N·m (0.36 kgf-m, 2.6 ft-lb)




(A) Inhibitor switch
(B) Range select lever

- 5) Install the select cable to the range select lever.
- 6) Install the plate assembly to the transmission.


Tightening torque:

T: 25 N·m (2.5 kgf-m, 18.4 ft-lb)




(A) Select cable
(B) Plate ASSY

- 7) Install the washer and snap pin to the range select lever.



(A) Range select lever
(B) Snap ring
(C) Select cable
(D) Washer

- 8) Install the front and center exhaust pipe. (Non-turbo model) <Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.>
- 9) Install the center exhaust pipe. (Turbo model) <Ref. to EX(H4DOTC)-11, INSTALLATION, Center Exhaust Pipe.>
- 10) Lower the vehicle.
- 11) Install the inhibitor switch connector to the stay.
- 12) Connect the inhibitor switch connector.




(A) Inhibitor switch

- 13) Install the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 14) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>
- 15) Inspect the inhibitor switch. <Ref. to 4AT-46, INSPECTION, Inhibitor Switch.>

14. Front Vehicle Speed Sensor

A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from the battery.
- 3) Remove the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 4) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 5) Disconnect the transmission connector.



(A) Transmission connector


- 6) Remove the pitching stopper. <Ref. to 4AT-42, REMOVAL, Transmission Mounting System.>
- 7) Remove the transmission connector from stay.
- 8) Lift up the vehicle.
- 9) Clean the transmission exterior.
- 10) Drain the ATF completely.

NOTE:

- Tighten the ATF drain plug after draining the ATF.
- Use a new gasket.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)



(A) Oil pan
(B) Drain plug (ATF)


- 11) Remove the front, center exhaust pipe and the muffler. (Non-turbo model) <Ref. to EX(H4SO)-4, REMOVAL, Front Exhaust Pipe.> <Ref. to EX(H4SO)-8, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, REMOVAL, Muffler.>

- 12) Remove the center and rear exhaust pipes and the muffler. (Turbo model) <Ref. to EX(H4DOTC)-10, REMOVAL, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, REMOVAL, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, REMOVAL, Muffler.>
- 13) Remove the propeller shaft. <Ref. to DS-15, REMOVAL, Propeller Shaft.>
- 14) Place the transmission jack under the transmission.

NOTE:

Make sure that the support plate of transmission jack does not touch the cross.

- 15) Remove the transmission rear crossmember bolt.



- 16) Lower the transmission jack.

NOTE:


Do not separate the transmission jack and transmission.

- 17) Remove the oil cooler inlet and outlet pipes.

NOTE:

When removing the outlet pipe, be careful not to lose the ball and spring used together with retaining screw.

- 18) Remove the front vehicle speed sensor and torque converter turbine speed sensor.




(A) Front vehicle speed sensor
(B) Torque converter turbine speed sensor

Front Vehicle Speed Sensor


AUTOMATIC TRANSMISSION

19) Disconnect the connector from the rear vehicle speed sensor. (VTD model)



(A) Rear vehicle speed sensor

20) Disconnect the connector from the rear vehicle speed sensor. (MP-T model)




(A) Rear vehicle speed sensor

21) Remove the oil pan.

NOTE:

Be careful not to allow foreign matter such as dust or dirt to enter the oil pan.

22) Disconnect the harness connector and transmission ground terminal.




(A) Transmission ground

(B) Harness connector

23) Remove the harness assembly.

B: INSTALLATION


1) Pass the harness assembly through the hole in transmission case.



2) Connect the harness connector and transmission ground.

Tightening torque:

8 N·m (0.8 kgf·m, 5.8 ft·lb)




(A) Transmission ground

(B) Harness connector

3) Apply proper amount of liquid gasket to the entire oil pan mating surface.

Liquid gasket:

THREE BOND 1217B (Part No. K0877YA020) or equivalent




Front Vehicle Speed Sensor

AUTOMATIC TRANSMISSION

4) Apply an adequate amount of liquid gasket to the three holes excluding the screw holes of the transmission case.

Liquid gasket:

**THREE BOND 1217B (Part No. K0877YA020)
or equivalent**




5) Install the oil pan.

Tightening torque:


5 N·m (0.5 kgf·m, 3.6 ft·lb)

6) Connect the connector of the rear vehicle speed sensor. (MP-T model)



(A) Rear vehicle speed sensor

7) Connect the connector of the rear vehicle speed sensor. (VTD model)




(A) Rear vehicle speed sensor

8) Install the front vehicle speed sensor and torque converter turbine speed sensor, and then fasten the harness.

Tightening torque:

7 N·m (0.7 kgf·m, 5.1 ft·lb)



(A) Front vehicle speed sensor

(B) Torque converter turbine speed sensor

9) Install the inlet pipe.

NOTE:


Use a new copper washer.

Tightening torque:

T1: 25 N·m (2.5 kgf·m, 18.4 ft·lb)

T2: 40 N·m (4.1 kgf·m, 29.5 ft·lb)

T3: 45 N·m (4.6 kgf·m, 33 ft·lb)



10) Install the transmission rear crossmember bolt.

Tightening torque:

70 N·m (7.1 kgf·m, 51 ft·lb)

11) Install the propeller shaft. <Ref. to DS-16, INSTALLATION, Propeller Shaft.>

12) Install the front, center and rear exhaust pipes, and the muffler. (Non-turbo model) <Ref. to EX(H4SO)-5, INSTALLATION, Front Exhaust Pipe.> <Ref. to EX(H4SO)-8, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4SO)-9, INSTALLATION, Muffler.>

13) Install the center, rear exhaust pipes and the muffler. (Turbo model) <Ref. to EX(H4DOTC)-11, INSTALLATION, Center Exhaust Pipe.> <Ref. to EX(H4DOTC)-15, INSTALLATION, Rear Exhaust Pipe.> <Ref. to EX(H4DOTC)-17, INSTALLATION, Muffler.>

Front Vehicle Speed Sensor

AUTOMATIC TRANSMISSION

- 14) Lower the vehicle.
- 15) Install the transmission connector to the stay.
- 16) Install the pitching stopper. <Ref. to 4AT-42, INSTALLATION, Transmission Mounting System.>
- 17) Install the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 18) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>


15.Rear Vehicle Speed Sensor

A: REMOVAL

1) Set the vehicle on a lift, and then Lift up the vehicle.


2) Disconnect the connector from the rear vehicle speed sensor.

- MP-T model



(A) Rear vehicle speed sensor


- VTD model




(A) Rear vehicle speed sensor

3) Remove the rear vehicle speed sensor.

- MP-T model



- VTD model



B: INSTALLATION

Install in the reverse order of removal.

NOTE:

Replace O-ring with a new part.

Tightening torque:

7 N·m (0.7 kgf-m, 5.1 ft-lb)

Torque Converter Turbine Speed Sensor

AUTOMATIC TRANSMISSION

16. Torque Converter Turbine Speed Sensor

A: REMOVAL

When removing the torque converter turbine speed sensor, refer to "Front Vehicle Speed Sensor".
<Ref. to 4AT-49, REMOVAL, Front Vehicle Speed Sensor.>


B: INSTALLATION

When installing the torque converter turbine speed sensor, refer to "Front Vehicle Speed Sensor".
<Ref. to 4AT-50, INSTALLATION, Front Vehicle Speed Sensor.>

17. Control Valve Body

A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from the battery.
- 3) Lift up the vehicle.
- 4) Clean the transmission exterior.
- 5) Remove the drain plug and gasket, then drain the ATF.



- 6) Replace the gasket with a new part and tighten the drain plug.


Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)


- 7) Remove the oil pan.

NOTE:

Be sure to prevent the entering of dust and other foreign matters into oil pan.




- 8) Remove the magnet.




- 9) Clean the magnet.
- 10) Completely remove the remaining liquid gasket on the transmission case and oil pan.

- 11) Remove the control valve connector.




- 12) Remove the oil cooler pipe.



- 13) Remove the control valve body.

NOTE:

The control valve body is replaced as an assembly only, because it is a non-disassembly part.



Control Valve Body


AUTOMATIC TRANSMISSION

B: INSTALLATION

- 1) Check the control valve body for dust and other foreign matter.
- 2) Temporarily tighten the control valve body to the transmission.
- 3) Install the oil cooler pipe.

Tightening torque:


8 N·m (0.8 kgf-m, 5.8 ft-lb)



- 4) Tighten the bolts equally.


Tightening torque:

8 N·m (0.8 kgf-m, 5.8 ft-lb)




- (A) Transmission ground
Bolt length mm (in)
- | | |
|-----|-----------|
| (1) | 35 (1.38) |
| (2) | 30 (1.18) |

- 5) Connect the control valve connector.




- 6) Attach the magnet at the specified position of the oil pan.



- 7) Apply liquid gasket to the oil pan.

Liquid gasket:


**THREE BOND 1217B (Part No. K0877YA020)
or equivalent**



- 8) Fill the 3 holes aside from the bolt holes in the transmission case, with liquid gasket.

Liquid gasket:

**THREE BOND 1217B (Part No. K0877YA020)
or equivalent**



- 9) Install the oil pan by equally tightening the bolts.

Tightening torque:

5 N·m (0.5 kgf-m, 3.6 ft-lb)

10) Fill ATF from the oil charger pipe.

Recommended fluid:

<Ref. to 4AT-3, HYDRAULIC CONTROL AND LUBRICATION, SPECIFICATION, General Description.>

Capacity:

Fill with the same amount of fluid that was drained from the drain plug hole.

11) Bleed the air of control valve body. <Ref. to 4AT-58, Air Bleeding of Control Valve.>

12) Check the ATF level. <Ref. to 4AT-28, Automatic Transmission Fluid.>

13) Execute the learning control promotion. <Ref. to 4AT(D)(diag)-16, FACILITATION OF LEARNING CONTROL, OPERATION, Subaru Select Monitor.>

C: INSPECTION

Check each part to make sure that there are no holes, cuts, or attached dust.

18. Air Bleeding of Control Valve

A: PROCEDURE

- 1) Operate the vehicle with the select lever moved to "P" range and parking brake applied.
- 2) Connect the Subaru Select Monitor to the vehicle.
- 3) Make sure there is no trouble code using the Subaru Select Monitor.
- 4) Using the Subaru Select Monitor, check that the ATF temperature is 60°C (140°F) or less. <Ref. to 4AT(D)(diag)-2, PROCEDURE, Basic Diagnostic Procedure.>
- 5) Terminate the Subaru Select Monitor.
- 6) Set the ignition switch to OFF.
- 7) With the shift lock release button held down, move the select lever to the "R" range.
- 8) Depress the brake pedal fully until the air bleeding is completed.
- 9) Turn the ignition switch to ON.
- 10) Move the select lever to "P" range, and then wait for three seconds or more.
- 11) Move the select lever to "R" range, and then wait for three seconds or more.
- 12) Move the select lever to "N" range, and then wait for three seconds or more.
- 13) Move the select lever to "D" range, and then wait for three seconds or more.
- 14) Move the select lever to "N" range, and then wait for three seconds or more.
- 15) Slowly depress the accelerator pedal to full throttle.
- 16) Slowly release the accelerator pedal completely.
- 17) Start the engine.
- 18) Shift the select lever to "D" range.
- 19) Turn on the Subaru Select Monitor.
- 20) Select {Each System Check} in the Main Menu of the Subaru Select Monitor.
- 21) On the System Selection Menu display screen, select "Transmission". Air bleed of the control valve will start in the transmission. At this time, the AT OIL TEMP light in the combination meter will start flashing at 2 Hz. If the AT OIL TEMP light does not flash, repeat the procedures from step 4).
- 22) Air bleed of the control valve is complete when the AT OIL TEMP light in the combination meter changes from flashing at 2 Hz to 0.5 Hz.

NOTE:

When the flashing of the AT OIL TEMP light changes from 2 Hz to 4 Hz during air bleed, repeat the procedures from step 4).

- 23) Move the select lever to the "N" range, and then Turn the ignition switch to OFF.
- 24) Move the select lever to the "P" range, and then finish the air bleed.

Brought to you by Eris Studios
NOT FOR RESALE

19.ATF Filter


A: REMOVAL

NOTE:

The ATF filter is maintenance free.

- 1) Lift up the vehicle.
- 2) Using the ST, remove the ATF filter.

ST 498545400 OIL FILTER WRENCH



(A) ATF filter

B: INSTALLATION

- 1) Apply a thin coat of ATF to the oil seal part of new ATF filter.
- 2) Install the ATF filter. Turn it by hand, being careful not to damage oil seal.
- 3) Tighten the ATF filter using ST.

Calculate the ATF filter tightening torque using following formula.

$$T2 = L2 / (L1 + L2) \times T1$$

T1: 14 N·m (1.4 kgf-m, 10.1 ft-lb)

[Required torque setting]

T2: Tightening torque

L1: ST length 78 mm (3.07 in)

L2: Torque wrench length

Example:

Torque wrench length mm (in)	Tightening torque N·m (kgf-m, ft-lb)
100 (3.94)	7.7 (0.79, 5.7)
150 (5.91)	9.0 (0.92, 6.7)
200 (7.87)	10 (1.0, 7.4)

NOTE:

Align the ST with the torque wrench while tightening the ATF filter.

ST 498545400 OIL FILTER WRENCH

- 4) Fill ATF.
- 5) Inspect the level of ATF. <Ref. to 4AT-28, Automatic Transmission Fluid.>

C: INSPECTION

Check for rust, holes, ATF leaks or other damage, and if there is damage, perform replacement.


Transmission Control Module (TCM)

AUTOMATIC TRANSMISSION


20. Transmission Control Module (TCM)

A: REMOVAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the lower cover and then disconnect the connector.
- 3) Remove the knee bolster.



- 4) Disconnect the connector from TCM.



(A) Transmission control module (TCM)


- 5) Remove the TCM.

B: INSTALLATION

- 1) Install the TCM.

Tightening torque:

7.5 N·m (0.76 kgf-m, 5.5 ft-lb)



(A) Transmission control module (TCM)

- 2) Connect the connector to the TCM.
- 3) Install in the reverse order of removal.

4) If TCM is replaced, execute learning control promotion. <Ref. to 4AT(D)(diag)-16, FACILITATION OF LEARNING CONTROL, OPERATION, Subaru Select Monitor.>


21. ATF Cooler Pipe and Hose

A: REMOVAL

- 1) Set the vehicle on a lift.
- 2) Remove the battery and washer tank.
- 3) Lift up the vehicle.
- 4) Remove the under cover.
- 5) Disconnect the ATF cooler hose from the radiator.

NOTE:


- Do not use a screwdriver or other pointed tools.
- If it is hard to remove the hose, wrap the hose with cloth to prevent from damaging it, and while turning with pliers, pull straight out by hand.




- 6) Disconnect the ATF cooler hoses from the pipes.

NOTE:

- Do not use a screwdriver or other pointed tools.
- If it is hard to remove the hose, wrap the hose with cloth to prevent from damaging it, and while turning with pliers, pull straight out by hand.




- 7) Disconnect the ATF cooler pipe from frame.



- 8) Remove the oil cooler inlet and outlet pipes.

NOTE:

When disconnecting the outlet pipe, be careful not to lose the ball and spring used together with retaining screw.



- (A) Inlet pipe
- (B) Outlet pipe

ATF Cooler Pipe and Hose

AUTOMATIC TRANSMISSION

B: INSTALLATION


1) Install the oil cooler inlet and outlet pipes with new washers.

Tightening torque:


T1: 25 N·m (2.5 kgf-m, 18.4 ft-lb)

T2: 40 N·m (4.1 kgf-m, 30 ft-lb)

T3: 45 N·m (4.16 kgf-m, 33 ft-lb)




2) Install the ATF cooler pipe to frame.



3) Connect the ATF cooler hose to the pipe on the transmission side.

NOTE:


- Install so that the hose is not folded over, excessively bent or twisted.
- Insert the hose to the specified position.



4) Connect the ATF cooler hose to the pipe on the radiator side.

NOTE:

- Install so that the hose is not folded over, excessively bent or twisted.
- Insert the hose to the specified position.



5) Install the under cover.

6) Install the battery and washer tank.

7) Fill ATF. <Ref. to 4AT-28, Automatic Transmission Fluid.>

NOTE:

Make sure there are no ATF leaks in joints between the transmission, radiator, pipes, and hoses.

C: INSPECTION

Repair or replace any faulty hoses, pipes, clamps, and washers found in the inspection below.


- 1) Check for ATF leaks in joints between the transmission, radiator, pipes, and hoses.
- 2) Check the clamp for deformation.
- 3) Lightly bend the hose and check for cracks in the surface or other damages.
- 4) Pinch the hose with your fingers and check for poor elasticity. Also check for poor elasticity in the parts where the clamp was installed by pressing with your fingernail.
- 5) Check for peeling, cracks, and deformation at the tip of the hose.

22. Air Breather Hose

A: REMOVAL


- 1) Remove the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 2) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 3) Disconnect the air breather hose.

- Non-turbo model



(A) Air breather hose (Transmission case)
 (B) Air breather hose (Oil pump housing)

- Turbo model



(A) Air breather hose (Transmission case)
 (B) Air breather hose (Oil pump housing)


B: INSTALLATION

- 1) Install the air breather hose.

NOTE:


Install so that the hose is not folded over, excessively bent or twisted.

- Non-turbo model



(A) Air breather hose (Transmission case)
 (B) Air breather hose (Oil pump housing)

- Turbo model



(A) Air breather hose (Transmission case)
 (B) Air breather hose (Oil pump housing)

- 2) Install the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>

- 3) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>


C: INSPECTION

Make sure the hose is not cracked or clogged.

23. Oil Charge Pipe

A: REMOVAL

- 1) Remove the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, REMOVAL, Air Intake Chamber.>
- 2) Remove the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-13, REMOVAL, Intercooler.>
- 3) Remove the oil charge pipe, and then remove the O-ring from the flange side.




- (A) Oil level gauge
(B) Oil charge pipe

B: INSTALLATION

- 1) Install the oil charge pipe along with a new O-ring.

Tightening torque:

41 N·m (4.2 kgf·m, 30.2 ft·lb)



- (A) Oil level gauge
(B) Oil charge pipe

- 2) Install the air intake chamber. (Non-turbo model) <Ref. to IN(H4SO)-6, INSTALLATION, Air Intake Chamber.>
- 3) Install the intercooler. (Turbo model) <Ref. to IN(H4DOTC)-14, INSTALLATION, Intercooler.>

C: INSPECTION

Make sure that the oil charge pipe is not deformed or damaged.


24. Torque Converter Clutch Assembly

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch and oil pump shaft horizontally.

NOTE:


Be sure not to scratch the inside of bushing in oil pump shaft.



- 3) Remove the input shaft.

NOTE:

When the torque converter clutch assembly is removed, the input shaft may also come off.



- 4) Remove the clip from the torque converter clutch.

B: INSTALLATION


- 1) Install the clip to the converter case.
- 2) Install the oil pump shaft to the torque converter clutch, and then make sure that the clip is secured on the groove.
- 3) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:


50 — 55 mm (1.97 — 2.17 in)



- 4) While holding the torque converter clutch assembly by hand, carefully install it to the torque converter case. Take care not to damage the bushing. Do not allow the oil pump shaft bushing to touch the starter shaft part of the oil pump cover inappropriately.
- 5) Turn the shaft lightly by hand, and engage with the splines securely.

Dimension A:

2.7 — 2.9 mm (0.106 — 0.114 in)



(A) Dimension A

- 6) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: INSPECTION

Make sure that the ring gear and protrusion of the torque converter clutch end are not deformed or damaged.


25.Extension Case

A: REMOVAL

1) Remove the transmission assembly. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>


2) Remove the rear vehicle speed sensor.

- MP-T model




(A) Rear vehicle speed sensor

- VTD model



(A) Rear vehicle speed sensor

3) Separate the transmission case and extension case section.



B: INSTALLATION

1) Apply Vaseline to the contact surface, and attach the selected thrust needle bearing to the end surface of the reduction drive gear.


NOTE:

Install the thrust needle bearing in the correct direction.

- 2) Install a new gasket.
- 3) Install the extension case to transmission case.
- 4) Tighten bolts to secure the extension case.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)




5) Install the rear vehicle speed sensor.

Tightening torque:


7 N·m (0.7 kgf·m, 5.1 ft·lb)

- MP-T model



(A) Rear vehicle speed sensor

- VTD model



(A) Rear vehicle speed sensor

6) Install the transmission assembly. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: DISASSEMBLY

1. MP-T MODEL

1) Take out the transfer clutch by lightly tapping the end of the rear drive shaft.


NOTE:

Be careful not to damage the oil seal of the extension.



- (A) Transfer clutch
- (B) Extension case

2) Remove the transfer clutch pipe while being careful not to deform the pipe.




- (A) Extension case
- (B) Transfer clutch pipe

- 3) Remove the dust cover from extension case.
- 4) Remove the oil seal from the extension case.


2. VTD MODEL

1) Using the ST1, ST2, ST3, and a press, remove the snap ring.

- ST1 398673600 COMPRESSOR
- ST2 498627100 SEAT
- ST3 398663600 PLIER




2) Remove the test plug.



- (A) Test plug
- (B) Extension case


3) Remove the clutch piston by applying compressed air.



Extension Case

AUTOMATIC TRANSMISSION

4) Remove the transfer clutch pipe while being careful not to deform the pipe.




5) Remove the dust cover from extension case.
6) Remove the oil seal from the extension case.

D: ASSEMBLY

1. MP-T MODEL

1) Press-fit the new oil seal using ST and the press.
ST 498057300 INSTALLER
2) Press-fit the dust cover.
3) Install the transfer clutch pipe to the extension case while being careful not to deform the pipe.




(A) Extension case
(B) Transfer pipe

4) Install the transfer clutch assembly to the case.

NOTE:


- Be careful not to damage the seal ring.
- Press-fit the clutch assembly to the bottom of the bearing shoulder completely.



(A) Transfer clutch
(B) Extension case

2. VTD MODEL


1) Press-fit the new oil seal using ST and the press.
ST 498057300 INSTALLER
2) Press-fit the dust cover.
3) Install the transfer clutch pipe to the extension case while being careful not to deform the pipe.



4) Apply ATF to a new O-ring and install the test plug.


Tightening torque:

13 N·m (1.3 kgf·m, 9.6 ft·lb)



(A) Test plug
(B) Extension case


5) Insert the multiplate clutch, drive plate, driven plate and spring retainer.



(A) Spring retainer
(B) Multi plate clutch piston ASSY

6) Using the ST1, ST2 and ST3, install the snap ring.

- ST1 398673600 COMPRESSOR
- ST2 498627100 SEAT
- ST3 398663600 PLIER



E: INSPECTION

- Use compressed air to make sure that the transfer pipe and extension case passages are not clogged or leaking.
- Inspect the extension end play, and adjust it to within the standard value.

MP-T model <Ref. to 4AT-73, MP-T MODEL, ADJUSTMENT, Transfer Clutch.>

VTD model <Ref. to 4AT-74, VTD MODEL, ADJUSTMENT, Transfer Clutch.>

26. Transfer Clutch

A: REMOVAL


1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>

2) Remove the extension case, and then remove the transfer clutch. <Ref. to 4AT-66, REMOVAL, Extension Case.> <Ref. to 4AT-67, DISASSEMBLY, Extension Case.>

B: INSTALLATION

1) Select the thrust needle bearing. <Ref. to 4AT-73, ADJUSTMENT, Transfer Clutch.>

2) Install the transfer clutch assembly to the case.




(A) Transfer clutch
(B) Extension case

3) Replace with a new gasket, tighten bolts and affix the case.

Tightening torque:


25 N·m (2.5 kgf-m, 18.4 ft-lb)



4) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


1) Remove the seal ring.




(A) Seal ring
(B) Transfer clutch

2) Remove the ball bearing using the ST and the press.

ST 498077600 REMOVER



3) Remove the snap ring, and then take out the pressure plate, drive plate and driven plate.




(A) Snap ring
(B) Transfer clutch

Transfer Clutch

AUTOMATIC TRANSMISSION


4) Using the ST1, ST2 and ST3, remove the snap ring, then take out the return spring and transfer clutch piston seal.

ST1 399893600 PLIER
ST2 398673600 COMPRESSOR
ST3 398623600 SEAT



(A) Snap ring
(B) Transfer piston seal


5) Apply compressed air to the rear drive shaft, to remove the piston.



AT-00131


D: ASSEMBLY

1) Install the transfer clutch piston.




(A) Transfer clutch piston
(B) Rear drive shaft

2) Install the return spring to the transfer piston.



(A) Return spring
(B) Rear drive shaft


3) Apply ATF to the lip of transfer clutch piston seal, then install.



(A) Transfer clutch piston seal
(B) Rear drive shaft

4) Attach the ST to the rear drive shaft.

ST 499257300 SNAP RING OUTER GUIDE




(A) Rear drive shaft

Transfer Clutch


AUTOMATIC TRANSMISSION

5) Install the snap ring to the ST.
ST 499257300 SNAP RING OUTER GUIDE




- (A) Snap ring
- (B) Transfer clutch

6) Install the snap ring to the rear drive shaft using ST1 and ST2.
ST1 499257300 SNAP RING OUTER GUIDE
ST2 499247400 INSTALLER




- (A) Snap ring
- (B) Transfer clutch

7) Install the driven plate, drive plate, pressure plate and snap ring.




- (A) Snap ring

8) Apply compressed air to see if the assembled parts move smoothly.



9) Check clearance between the snap ring and pressure gauge. <Ref. to 4AT-73, INSPECTION, Transfer Clutch.>

10) Press-fit new ball bearing using ST.
ST 899580100 INSTALLER




- (A) Ball bearing

11) Apply Vaseline to a new seal ring and attach to the seal ring groove of the shaft.


NOTE:

While installing the seal ring, not to stretch the seal ring excessively.



- (A) Seal ring
- (B) Transfer clutch

12) Install the transfer clutch assembly while taking care not to damage the seal ring.



(A) Transfer clutch
(B) Extension case

E: INSPECTION

- Inspect the drive plate facing for wear and damage.
- Make sure the snap ring is not worn and the return spring has no permanent distortion, damage, or deformation.
- Inspect the seal ring for damage.
- Inspect the extension end play, and adjust it to within the standard value. <Ref. to 4AT-73, ADJUSTMENT, Transfer Clutch.>

1) Check clearance between the snap ring and pressure gauge.

2) Before measuring clearance, place same thickness shims on both sides to prevent the pressure plate from tilting.


3) When the clearance is outside standards, select the appropriate pressure plate on the transfer clutch piston side to adjust. If the service limit is exceeded, replace the drive plate and select and adjust the pressure plate so that the clearance will be within standard values.

Initial standard:

0.7 — 1.1 mm (0.028 — 0.043 in)

Limit thickness:

1.6 mm (0.063 in)



AT-00142

Pressure plate	
Part No.	Thickness mm (in)
31593AA151	3.3 (0.130)
31593AA161	3.7 (0.146)
31593AA171	4.1 (0.161)
31593AA181	4.5 (0.177)

4) Check for tight corner braking phenomenon when the vehicle is moved forward with the steering fully turned. If tight corner braking occurs, perform the following procedures.

(1) With the steering wheel held at fully turned position, drive the vehicle in “D” range and with vehicle speed at approx. 5 km/h (3 MPH) in both clockwise and counterclockwise directions for approx. ten times each, while repeating acceleration and braking intermittently.


(2) If the tight corner braking phenomenon still persists, drive the vehicle again in a circle for several laps.

F: ADJUSTMENT

1. MP-T MODEL

1) Using the ST, measure distance “A” from the end of the ST to the rear drive shaft end face.

ST 398643600 GAUGE




A Measured value

2) Measure distance “B” from the transmission case mating surface to the end of ST using ST1 and ST2.

ST1 398643600 GAUGE

ST2 499577000 GAUGE



B Measured value

Transfer Clutch

AUTOMATIC TRANSMISSION


3) Calculation formula:

$$T = A - B + 35.4 \text{ mm} [T = A - B + 1.3937 \text{ in}]$$

Thrust needle bearing	
Part No.	Thickness mm (in)
806536020	3.8 (0.150)
806535030	4.0 (0.157)
806535040	4.2 (0.165)
806535050	4.4 (0.173)
806535060	4.6 (0.181)
806535070	4.8 (0.189)
806535090	5.0 (0.197)

2. VTD MODEL


1) Insert the rear drive shaft into the reduction drive gear and center differential assembly.



- (A) Rear drive shaft
- (B) Center differential carrier

2) Using the ST, measure distance "A" from the end of the ST to the rear drive shaft ball bearing outer ring mating surface.


ST 398643600 GAUGE



A Measured value

3) Using the ST, measure the distance "B" from the transmission case mating surface to end of ST.

ST 398643600 GAUGE



B Measured value

4) Calculation formula:

Calculation of "T":

When the clearance is 0.05 mm (0.0020 in), select up to 4 adjustment shims to meet the clearance value from the table.

When the clearance is 0.05 mm (0.0020 in)

$$T = A - B + 0.40 \text{ mm}$$

$$[T = A - B + 0.0157 \text{ in}]$$

When the clearance is 0.25 mm (0.0098 in)

$$T = A - B + 0.20 \text{ mm}$$

$$[T = A - B + 0.0079 \text{ in}]$$

T: Shim clearance

A: Distance from the ST end face to the rear drive shaft ball bearing outer ring contact face.

B: Distance from the mating surface of the transmission case to the end of the ST

T: Shim thickness

0.05 — 0.25 mm (0.0020 — 0.0098 in)

Adjustment shim	
Part No.	Thickness mm (in)
33281AA001	0.2 (0.008)
33281AA011	0.5 (0.020)

27. Multi-plate Clutch

A: REMOVAL

In the same manner as the extension case, remove the multiplate clutch. <Ref. to 4AT-66, REMOVAL, Extension Case.>

B: INSTALLATION


In the same manner as the extension case, install the multiplate clutch. <Ref. to 4AT-66, INSTALLATION, Extension Case.>

C: INSPECTION

- Inspect the drive plate facing for wear and damage.
- Make sure the snap ring is not worn and the return spring has no permanent distortion, damage, or deformation.
- Inspect the D-ring for damage.
- Measure the multiplate clutch clearance, and adjust so that it will be within the specification range. <Ref. to 4AT-75, ADJUSTMENT, Multi-plate Clutch.>


D: ADJUSTMENT

- 1) Install the drive plate and driven plate to the center differential carrier.
 - 2) Using the ST, measure distance "A" from the end of the ST to the multiplate clutch piston.
- ST 398643600 GAUGE



A Measured value

- 3) Using the ST, measure the height "B" from the transmission case mating surface to end of ST.
- ST 398744300 GAUGE



B Measured value

- 4) Calculation formula:
 $T = A - B + 0.45 \text{ mm}$
 $[T = A - B + 0.0177 \text{ in}]$

Standard value:

0.2 — 0.6 mm (0.008 — 0.024 in)

Service limit:

1.6 mm (0.063 in)


If outside the standard value, replace the plate set (drive and driven plate), and select the side adjustment plates for the multiplate clutch piston so that the value is within the standard.

Driven plate	
Part No.	Thickness mm (in)
31589AA041	1.6 (0.063)
31589AA050	2.0 (0.079)
31589AA060	2.4 (0.094)
31589AA070	2.8 (0.110)

28.Rear Drive Shaft

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Pull out the rear drive shaft from center differential assembly.



(A) Rear drive shaft
(B) Center differential carrier


- 4) Remove the drive plate and driven plate.

B: INSTALLATION

- 1) Select the shim. <Ref. to 4AT-74, VTD MODEL, ADJUSTMENT, Transfer Clutch.>
- 2) Install drive plate and driven plate.
- 3) Insert the rear drive shaft into the center differential assembly.
- 4) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 5) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: DISASSEMBLY

- 1) Using a press, remove the revolution gear.



(A) Revolution gear

- 2) Using a press, remove the front and rear side ball bearings and clutch hub.




(A) Rear ball bearing
(B) Rear drive shaft
(C) Clutch hub

D: ASSEMBLY

Assemble in the reverse order of disassembly.

NOTE:

- Use new ball bearings and revolution gear.
- Make sure the clutch hub is facing the correct direction.



(A) Front side
(B) Clutch hub
(C) Rear side
(D) Revolution gear

E: INSPECTION


- Check each part to make sure that there are no holes, cuts, or attached dust.
- Inspect the extension end play, and adjust it to be within the standard value. <Ref. to 4AT-74, VTD MODEL, ADJUSTMENT, Transfer Clutch.>

29.Reduction Driven Gear

A: REMOVAL

1. MP-T MODEL


- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Set the range select lever to the "P" range.
- 4) Lift the crimped section, and then remove the lock nut.



- (A) Reduction driven gear
- (B) Reduction drive gear

- 5) Using the ST1 and ST2, extract the reduction driven gear.

ST1 499737000 PULLER
ST2 899524100 PULLER SET




- (A) Reduction driven gear
- (B) Reduction drive gear

2. VTD MODEL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Remove the rear drive shaft. <Ref. to 4AT-76, REMOVAL, Rear Drive Shaft.>
- 4) Set the range select lever to the "P" range.

- 5) Lift the crimped section, and then remove the lock nut.



- 6) Using the ST1 and ST2, extract the reduction driven gear.

ST1 499737000 PULLER
ST2 899524100 PULLER SET

- 7) Pull out the center differential assembly. <Ref. to 4AT-81, REMOVAL, Center Differential Carrier.>


B: INSTALLATION

1. MP-T MODEL

- 1) Set the range select lever to the "P" range.
- 2) Using a plastic hammer, install the reduction driven gear assembly and the new washer, and tighten the new drive pinion lock nut.

Tightening torque:

100 N·m (10.2 kgf·m, 73.8 ft·lb)



- (A) Reduction driven gear
- (B) Reduction drive gear

- 3) After tightening, stake the lock nut in four locations.

- 4) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>

- 5) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

Reduction Driven Gear


AUTOMATIC TRANSMISSION

2. VTD MODEL

- 1) Set the range select lever to the "P" range.
- 2) Use a plastic hammer to install reduction driven gear assembly.
- 3) Use a plastic hammer to attach the center differential.
- 4) Attach a new lock nut and a new washer.

Tightening torque:


100 N·m (10.2 kgf-m, 73.8 ft-lb)



- 5) After tightening, stake the lock nut securely.
- 6) Insert the rear drive shaft assembly. <Ref. to 4AT-76, INSTALLATION, Rear Drive Shaft.>
- 7) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 8) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


- 1) Remove the snap ring from reduction driven gear.



(A) Snap ring

- 2) Remove the ball bearing from reduction driven gear using ST.

ST 498077600 REMOVE




(A) Ball bearing

- 3) Remove the gear inner groove snap ring from the reduction driven gear.


D: ASSEMBLY

- 1) Install the snap ring to the gear inner groove on the reduction driven gear.
- 2) Install the new ball bearing to reduction driven gear using press.



(A) Ball bearing

- 3) Install the snap ring to reduction driven gear.



(A) Snap ring

E: INSPECTION


Make sure that the ball bearing and gear are not deformed or damaged.

30.Reduction Drive Gear

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Remove the reduction driven gear. <Ref. to 4AT-77, REMOVAL, Reduction Driven Gear.>
- 4) Using the ST, extract the reduction drive gear.

ST1 499737100 PULLER SET
ST2 899524100 PULLER SET




(A) Reduction drive gear

B: INSTALLATION

- 1) Install the reduction drive gear assembly.

NOTE:

Press-fit it to the bottom of bearing shoulder completely.




(A) Reduction drive gear

- 2) Install the reduction driven gear. <Ref. to 4AT-77, INSTALLATION, Reduction Driven Gear.>
- 3) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 4) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: DISASSEMBLY

- 1) Take out the seal ring.




(A) Seal ring
(B) Reduction drive shaft

- 2) Remove the ball bearing using ST.
- ST 498077600 REMOVER



(A) Ball bearing
(B) Reduction drive gear


- 3) Apply Vaseline to the outer surface of seal ring and shaft groove.



(A) Reduction drive gear

D: ASSEMBLY

- 1) Press-fit the reduction drive gear to shaft.
- 2) Press-fit the new ball bearing into reduction drive gear.
- 3) Apply ATF onto the seal ring outer surface and shaft grooves.
- 4) Apply ATF to new seal rings, then install.



- (A) Seal ring
(B) Reduction drive shaft

E: INSPECTION


- Rotate the bearing by hand, and make sure it rotates smoothly.
- Check each part to make sure that there are no holes, cuts, or attached dust.
- Inspect the extension end play, and adjust it to the standard value. <Ref. to 4AT-73, ADJUSTMENT, Transfer Clutch.>

31.Center Differential Carrier

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Pull out the rear drive shaft. <Ref. to 4AT-76, REMOVAL, Rear Drive Shaft.>
- 4) Pull out the center differential carrier assembly using the ST.

ST1 499737100 PULLER SET
 ST2 899524100 PULLER SET




- 5) Pull out the shim(s) from transmission case.

B: INSTALLATION

- 1) Install the differential assembly together with shims.

NOTE:


Press-fit it to the bottom of bearing shoulder completely.



- 2) Insert the rear drive shaft. <Ref. to 4AT-76, INSTALLATION, Rear Drive Shaft.>
- 3) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 4) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: DISASSEMBLY

- 1) Remove the seal ring.




(A) Seal ring

- 2) Using a press and ST, remove the ball bearing.
- ST 498077600 REMOVER



- 3) Remove the snap ring, and pull out the shaft from center differential assembly.




(A) Snap ring
 (B) Shaft

Center Differential Carrier

AUTOMATIC TRANSMISSION

4) Remove the thrust washers, pinion gears and washers from center differential assembly.




(A) Pinion gear

5) Pull out the intermediate shaft and thrust bearing.

D: ASSEMBLY

- 1) Install the thrust bearing onto intermediate shaft.
- 2) Insert the intermediate shaft into the carrier.
- 3) Attach the pinion gear, needle bearing and washer onto the carrier.
- 4) Insert the shaft into the center differential assembly.
- 5) Install the snap ring.
- 6) Using a press, install a new ball bearing into the center differential assembly.

ST 498077000 REMOVER



(A) Plate

(B) Center differential carrier

7) Apply ATF onto the seal ring outer surface and shaft grooves.

8) Apply ATF to new seal rings, then install.


E: INSPECTION

- Check each part to make sure that there are no holes, cuts, or attached dust.
- Inspect the extension aid play, and adjust it to be within the standard value. <Ref. to 4AT-74, VTD MODEL, ADJUSTMENT, Transfer Clutch.>

32. Parking Pawl

A: REMOVAL


- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Remove the rear wheel speed sensor, and separate the extension case from transmission case. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 3) Remove the reduction drive gear. (MP-T model) <Ref. to 4AT-79, REMOVAL, Reduction Drive Gear.>
- 4) Remove the center differential carrier. (VTD model) <Ref. to 4AT-81, REMOVAL, Center Differential Carrier.>
- 5) Remove the parking pawl, return spring and shaft.



- (A) Return spring
- (B) Parking pawl

B: INSTALLATION

- 1) Install the parking pawl, return spring and shaft.



- (A) Return spring
- (B) Parking pawl

- 2) Install the reduction drive gear. (MP-T model) <Ref. to 4AT-79, INSTALLATION, Reduction Drive Gear.>
- 3) Install the center differential carrier. (VTD model) <Ref. to 4AT-81, INSTALLATION, Center Differential Carrier.>

- 4) Install the rear vehicle speed sensor and extension case. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 5) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: INSPECTION

Check the tab of the parking pole on the reduction gear for wear or other damage.


33. Converter Case

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.



- 4) Lift up the lever on the rear side of connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch connector from the stay.




- (A) Transmission harness
- (B) Inhibitor switch harness

- 6) Remove the oil charge pipe. <Ref. to 4AT-64, REMOVAL, Oil Charge Pipe.>
- 7) Remove the oil cooler inlet and outlet pipes. <Ref. to 4AT-61, REMOVAL, ATF Cooler Pipe and Hose.>


- 8) Remove the converter case alignment bolt, and then separate the transmission case and converter case by lightly tapping with a plastic hammer.

NOTE:

- Be careful not to damage the oil seal and bushing in the converter case with the oil pump cover.
- Be careful not to loosen the rubber seal.



- 9) Remove the seal pipe.




- (A) Seal pipe

- 10) Remove the differential assembly. <Ref. to 4AT-96, REMOVAL, Front Differential Assembly.>
- 11) Remove the oil seal from converter case.


B: INSTALLATION

- 1) Check the appearance of each component and clean them.
- 2) Press-fit the oil seal to converter case using ST. ST 398437700 DRIFT




- 3) Install the differential assembly to the case. <Ref. to 4AT-96, INSTALLATION, Front Differential Assembly.>

- 4) Install the right and left side retainers. <Ref. to 4AT-100, ADJUSTMENT, Front Differential Assembly.>
- 5) Install new seal pipe to converter case.



(A) Seal pipe


- 6) Install the rubber seal to converter case.



(A) Rubber seal

- 7) Apply proper amount of liquid gasket to the entire matching surface of converter case.


Liquid gasket:
THREE BOND 1215 (Part No. 004403007) or equivalent



(A) THREE BOND 1215
 (B) Rubber seal

- 8) Install the converter case assembly without damaging bushing and oil seal.

Tightening torque:
41 N·m (4.2 kgf-m, 30.2 ft-lb)




- 9) Insert the inhibitor switch and transmission connector to the stay.
- 10) Install the air breather hose. <Ref. to 4AT-63, INSTALLATION, Air Breather Hose.>
- 11) Install the oil cooler pipe. <Ref. to 4AT-62, INSTALLATION, ATF Cooler Pipe and Hose.>
- 12) Install the oil charge pipe with O-ring. <Ref. to 4AT-64, INSTALLATION, Oil Charge Pipe.>
- 13) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:
50 — 55 mm (1.97 — 2.17 in)



- 14) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>
- 15) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>


C: INSPECTION

Measure the backlash, and then adjust it to be within standard values. <Ref. to 4AT-93, ADJUSTMENT, Drive Pinion Shaft Assembly.>


34. Oil Pump Housing

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.




- 4) Lift up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch connector from the stay.
- 6) Remove the oil charge pipe. <Ref. to 4AT-64, REMOVAL, Oil Charge Pipe.>
- 7) Remove the ATF oil cooler inlet and outlet pipes. <Ref. to 4AT-61, REMOVAL, ATF Cooler Pipe and Hose.>
- 8) Separate the converter case and transmission case. <Ref. to 4AT-84, REMOVAL, Converter Case.>
- 9) Separate the transmission case and extension case section. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 10) Remove the reduction drive gear. (MP-T model) <Ref. to 4AT-79, REMOVAL, Reduction Drive Gear.>
- 11) Remove the center differential carrier. (VTD model) <Ref. to 4AT-81, REMOVAL, Center Differential Carrier.>
- 12) Remove the reduction driven gear. <Ref. to 4AT-77, REMOVAL, Reduction Driven Gear.>
- 13) Loosen the oil pump housing mounting bolts.




- 14) Place two wooden blocks on the workbench, and stand the transmission case with the rear end facing down.

NOTE:

- Be careful not to scratch the rear mating surface of the transmission case.
- Be careful of the parking rod and drive pinion protruding from the mating surface.



- 15) Remove the oil pump housing and adjusting thrust washer.




(A) Oil pump housing

B: INSTALLATION

- 1) Secure the oil pump housing with two nuts and a bolt.

Tightening torque:


42 N·m (4.3 kgf-m, 31 ft-lb)



(A) Oil pump housing

- 2) Install the converter case assembly to the transmission case assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>

- 3) Install the reduction driven gear. <Ref. to 4AT-77, INSTALLATION, Reduction Driven Gear.>
- 4) Install the reduction drive gear. (MP-T model) <Ref. to 4AT-79, INSTALLATION, Reduction Drive Gear.>
- 5) Install the center differential carrier. (VTD model) <Ref. to 4AT-81, INSTALLATION, Center Differential Carrier.>
- 6) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 7) Insert the inhibitor switch and transmission connector to the stay.




(A) Transmission harness
(B) Inhibitor switch harness

- 8) Install the ATF cooler pipe. <Ref. to 4AT-62, INSTALLATION, ATF Cooler Pipe and Hose.>
- 9) Install the oil charge pipe together with an O-ring. <Ref. to 4AT-64, INSTALLATION, Oil Charge Pipe.>
- 10) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:
50 — 55 mm (1.97 — 2.17 in)




- 11) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>

- 12) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


1. OIL PUMP COVER

- 1) Remove the four seal rings.




(A) Seal ring

- 2) Remove the bolt, and lightly tap the stator shaft end to remove the cover.



(A) Oil pump cover
(B) Oil pump housing


- 3) Remove the inner and outer rotors.



(A) Inner rotor
(B) Outer rotor


2. OIL SEAL RETAINER

1) Remove the oil seal retainer.




- (A) Oil seal retainer
- (B) Drive pinion shaft

2) Remove the O-ring.



- (A) O-ring

3) Remove the oil seal from the oil seal retainer.




- (A) Oil seal
- (B) Oil seal retainer

D: ASSEMBLY

1. OIL PUMP COVER

1) Install the oil pump rotor assembly to oil pump housing.




- (A) Inner rotor
- (B) Outer rotor

2) Align both pivots with the pivot holes of the cover, and then install the oil pump cover while being careful not to apply excessive force to the pivots.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)




- (A) Oil pump cover
- (B) Oil pump housing

3) After assembling, turn the oil pump shaft to check for smooth rotation of rotor.

4) Install the oil seal retainer and new seal rings. After installing, adjust the tooth contact with the drive pinion backlash. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

NOTE:


There are two types of seals. They are identified by color. Install at the proper positions by referring to the figure.



- (A) Seal ring (Black)
- (B) Seal ring (Brown)


2. OIL SEAL RETAINER

1) Install two new oil seals to the oil seal retainer in the proper direction using the ST.
ST 499247300 INSTALLER



- (A) Oil seal
- (B) Oil seal retainer

2) Install a new O-ring to the oil pump housing using Vaseline.




- (A) O-ring

3) Install the oil seal being careful not to damage oil seal lip, and secure it using three bolts.

Tightening torque:

7 N·m (0.7 kgf·m, 5.1 ft·lb)



- (A) Oil seal retainer
- (B) Drive pinion shaft

E: INSPECTION


- 1) Check the seal ring and oil seal for breaks and damage.
- 2) Check other parts for dents or faults.
- 3) Oil pump rotor assembly selection

(1) Tip clearance

Install the inner rotor and outer rotor to the oil pump. With rotor gears facing each other, measure the crest-to-crest clearance.

Tip clearance:

0.02 — 0.15 mm (0.0008 — 0.0059 in)




- (A) Thickness gauge
- (B) Inner rotor
- (C) Outer rotor

(2) Side clearance

Set a depth gauge to oil pump housing, then measure the oil pump housing-to-rotor clearance.

Side clearance:

0.02 — 0.04 mm (0.0008 — 0.0016 in)



- (A) Depth gauge
- (B) Inner rotor
- (C) Outer rotor

(3) If the depth and side clearance are out of specification, replace the oil pump rotor assembly.


Oil pump rotor assembly	
Part No.	Thickness mm (in)
15008AA060	11.37 — 11.38 (0.4476 — 0.4480)
15008AA070	11.38 — 11.39 (0.4480 — 0.4484)
15008AA080	11.39 — 11.40 (0.4484 — 0.4488)

Measure the total end play and adjust it to be within specifications. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

F: ADJUSTMENT


1) Using the ST, measure the length “L”, from the end of the ST to the recessed portion of the high clutch drum.

ST 398643600 GAUGE



2) Measure the distance from the oil pump housing mating surface to the end surface of the ST using the ST.

ST 398643600 GAUGE




3) Calculation of total end play

Select a suitable bearing race from the table below so that clearance C will be within 0.25 to 0.55 mm (0.0098 to 0.0217 in).

$$C = (L + G) - l$$

C	Clearance between concave section of high clutch and end of clutch drum support
L	Length from the case mating surface to the end face of the ST
G	Gasket thickness [0.28 mm (0.0110 in)]
l	Height from the housing mating surface to the end face of the ST



Thrust needle bearing	
Part No.	Thickness mm (in)
806528050	4.1 (0.161)
806528060	4.3 (0.169)
806528070	4.5 (0.177)
806528080	4.7 (0.185)
806528090	4.9 (0.193)
806528100	5.1 (0.201)

4) After completing the end play adjustment, insert the bearing race into the high clutch race. Apply Vaseline to install the thrust needle bearing to the oil pump cover.


5) After correctly installing the new gasket to the case mating surface, carefully install the oil pump housing assembly. Be careful to avoid hitting the drive pinion against the inside of case.

6) Align the dowel pins and install both parts. Make sure there is no clearance at the mating surface.

35. Drive Pinion Shaft Assembly


A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.



- 4) Lift up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch connector from the stay.
- 6) Disconnect the air breather hose. <Ref. to 4AT-63, REMOVAL, Air Breather Hose.>
- 7) Remove the oil charge pipe. <Ref. to 4AT-64, REMOVAL, Oil Charge Pipe.>
- 8) Remove the oil cooler inlet and outlet pipes. <Ref. to 4AT-61, REMOVAL, ATF Cooler Pipe and Hose.>
- 9) Separate the converter case and transmission case. <Ref. to 4AT-84, REMOVAL, Converter Case.>
- 10) Separate the transmission case and extension case section. <Ref. to 4AT-66, REMOVAL, Extension Case.>
- 11) Remove the reduction drive gear. (MP-T model) <Ref. to 4AT-79, REMOVAL, Reduction Drive Gear.>
- 12) Remove the center differential carrier. (VTD model) <Ref. to 4AT-81, REMOVAL, Center Differential Carrier.>
- 13) Remove the reduction driven gear. <Ref. to 4AT-77, REMOVAL, Reduction Driven Gear.>

- 14) Remove the drive pinion shaft mounting bolt and remove the drive shaft assembly from oil pump housing.



B: INSTALLATION


- 1) Assemble the drive pinion assembly to the oil pump housing.

NOTE:

- Be careful not to bend the shim.
- Be careful not to press-fit the pinion into housing bore.

Tightening torque:

40 N·m (4.1 kgf-m, 29.5 ft-lb)



- 2) Join the torque converter case with the transmission case. <Ref. to 4AT-84, INSTALLATION, Converter Case.>
- 3) Install the reduction driven gear. <Ref. to 4AT-77, INSTALLATION, Reduction Driven Gear.>
- 4) Install the reduction drive gear. (MP-T model) <Ref. to 4AT-79, INSTALLATION, Reduction Drive Gear.>
- 5) Install the center differential carrier. (VTD model) <Ref. to 4AT-81, INSTALLATION, Center Differential Carrier.>
- 6) Join the transmission case and the extension case, and then install the rear vehicle speed sensor. <Ref. to 4AT-66, INSTALLATION, Extension Case.>
- 7) Insert the inhibitor switch and transmission connector to the stay.
- 8) Install the oil cooler inlet and outlet pipes. <Ref. to 4AT-62, INSTALLATION, ATF Cooler Pipe and Hose.>
- 9) Install the oil charge pipe with O-ring.

Drive Pinion Shaft Assembly


AUTOMATIC TRANSMISSION

10) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:
50 — 55 mm (1.97 — 2.17 in)




11) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>

12) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


1) Flatten the lock nut tab, and then remove the lock nut while holding the rear spline part of the shaft using ST1 and ST2. Pull out the drive pinion collar.

ST1 498937110 HOLDER
ST2 499787700 WRENCH
ST3 499787500 ADAPTER



2) Remove the O-ring.


3) Separate the roller bearing and outer race from shaft using a press.



(A) Outer race

4) Separate the front roller bearing from shaft using a press and ST.

ST 498517000 REPLACER




(A) Front roller bearing

D: ASSEMBLY

1) Measure the dimension "A" of drive pinion shaft.


ST 398643600 GAUGE



2) Using a press, press-fit the new roller bearing into the specified position.

NOTE:

If excessive force is applied to roller bearing, the roller bearing will not turn easily.



(A) Drive pinion shaft

(B) Roller bearing

3) After fitting a new O-ring to the shaft, attach the drive pinion collar to the shaft.

4) Install the lock washer to drive pinion shaft in the proper direction.

Drive Pinion Shaft Assembly

AUTOMATIC TRANSMISSION

5) Tighten the new lock nuts using ST1, ST2 and ST3.

Calculate the lock washer and lock nut specifications using following formula.

$$T2 = L2 / (L1 + L2) \times T1$$

T1: 116 N·m (11.8 kgf-m, 85.3 ft-lb)

[Required torque setting]

T2: Tightening torque

L1: ST2 length 0.072 m (2.83 in)

L2: Torque wrench length


Example:

Torque wrench length m (in)	Tightening torque N·m (kgf-m, ft-lb)
0.4 (15.75)	98 (10.0, 72)
0.45 (17.72)	100 (10.2, 73.8)
0.5 (19.69)	101 (10.3, 74.5)
0.55 (21.65)	102 (10.4, 75)

ST1 498937110 HOLDER
ST2 499787700 WRENCH
ST3 499787500 ADAPTER

NOTE:

Attach ST2 to torque wrench as straight as possible.



6) Measure the starting torque of the bearing. Make sure the starting torque is within the specified range. If the torque is not within specified range, replace the roller bearing.


Starting torque:

MP-T model

7.6 — 38.1 N (0.776 — 3.88 kgf, 1.7 — 8.6 lbf)

VTD model


6.8 — 47.5 N (0.69 — 4.84 kgf, 1.52 — 10.67 lbf)



7) Crimp the locknut in two locations.

8) Measure dimension "B" of the drive pinion shaft.

ST 398643600 GAUGE



9) Calculate the thickness "t" (mm) of the drive pinion shim.

$$t = 6.5 \pm 0.0625 - (B - A)$$

10) Select three or less shims from following table.

Drive pinion shim	
Part No.	Thickness mm (in)
31451AA050	0.150 (0.0059)
31451AA060	0.175 (0.0069)
31451AA070	0.200 (0.0079)
31451AA080	0.225 (0.0089)
31451AA090	0.250 (0.0098)
31451AA100	0.275 (0.0108)

E: INSPECTION

- Make sure that all component parts are free of scratches, holes and other faults.
- Adjust the tooth alignment. <Ref. to 4AT-93, ADJUSTMENT, Drive Pinion Shaft Assembly.>

F: ADJUSTMENT


- 1) Remove the liquid gasket from the mating surface completely.
- 2) Install the oil pump housing assembly to the converter case, and secure them by tightening the four bolts evenly.

NOTE:

Use an old gasket or aluminum washer to prevent damaging the mating surface of the housing.

Tightening torque:

41 N·m (4.2 kgf-m, 30.2 ft-lb)




Drive Pinion Shaft Assembly

AUTOMATIC TRANSMISSION

3) Rotate the drive pinion a few times using ST1 and ST2.

ST1 498937110 HOLDER

ST2 499787700 WRENCH




4) Adjust the drive pinion and hypoid driven gear backlash. <Ref. to 4AT-100, ADJUSTMENT, Front Differential Assembly.>

5) Apply red lead evenly to the surfaces of three or four teeth on hypoid driven gear. Rotate the drive pinion back and forward several times. Remove the oil pump housing, and check the teeth contact pattern.

If the teeth contact is inappropriate, adjust the backlash or thickness of the shim. <Ref. to 4AT-100, ADJUSTMENT, Front Differential Assembly.>

- Correct tooth contact

Check item: Tooth contact surface is slightly shifted toward the toe side under a no-load condition. (When driving, it moves towards the heel side.)




- (A) Toe side
- (B) Heel side


- Face contact

Check item: Backlash is too large.

Contact pattern




Corrective action: Increase thickness of pinion height adjusting washer according to the procedures for moving the drive pinion closer to the driven gear.




- Flank contact

Check item: Backlash is too small.

Contact pattern



Corrective action: Reduce thickness of the pinion height adjusting washer according to the procedures for moving the drive pinion away from the driven gear.




Drive Pinion Shaft Assembly

AUTOMATIC TRANSMISSION


- Toe contact (inside contact)

Check item: Teeth contact area is too small.

Contact pattern




Corrective action: Reduce thickness of the pinion height adjusting washer according to the procedures for moving the drive pinion away from the driven gear side.




- Heel contact (outside end contact)

Check item: Teeth contact area is too small.

Contact pattern




Corrective action: Increase thickness of pinion height adjusting washer according to the procedures for moving the drive pinion closer to the driven gear.



6) If tooth contact is correct, mark the retainer position and loosen it. After fitting a new O-ring and oil seal, screw in the retainer to the marked position. Tighten the lock plate with specified torque.

Tightening torque:

25 N·m (2.5 kgf-m, 18.4 ft-lb)




(A) Lock plate

36. Front Differential Assembly

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.



- 4) Lift up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch from the stay.
- 6) Remove the oil charge pipe. <Ref. to 4AT-64, REMOVAL, Oil Charge Pipe.>
- 7) Remove the oil cooler inlet and outlet pipes. <Ref. to 4AT-61, REMOVAL, ATF Cooler Pipe and Hose.>
- 8) Separate the converter case from the transmission case. <Ref. to 4AT-84, REMOVAL, Converter Case.>
- 9) Remove the seal pipe.
- 10) Remove the differential side retainers using ST.

NOTE:

Hold the differential case assembly by hand to avoid damaging the retainer mounting hole of the converter case.

ST 499787000 WRENCH ASSY


- 11) Remove the differential assembly while being careful not to damage the attachment part of retainer.

B: INSTALLATION

- 1) Install the differential assembly to the torque converter clutch case.

NOTE:

Do not damage the inside of the torque converter clutch case (particularly the mating surface of the differential side retainer).




(A) Differential ASSY

- 2) Install the O-ring to left and right side retainer.
- 3) Using the ST, install the side retainer. <Ref. to 4AT-96, REMOVAL, Front Differential Assembly.>
ST 499787000 WRENCH ASSY
- 4) Adjust the backlash of the front differential. <Ref. to 4AT-100, ADJUSTMENT, Front Differential Assembly.>
- 5) Install the lock plate.


Tightening torque:

25 N·m (2.5 kgf-m, 18.4 ft-lb)



(A) Lock plate


6) Install new seal pipe to converter case.



(A) Seal pipe

7) Install the converter case to the transmission case. <Ref. to 4AT-84, INSTALLATION, Converter Case.>

8) Insert the inhibitor switch and transmission connector to the stay.



(A) Transmission harness
(B) Inhibitor switch harness

9) Install the oil cooler pipe. <Ref. to 4AT-62, INSTALLATION, ATF Cooler Pipe and Hose.>


10) Install the oil charge pipe together with an O-ring. <Ref. to 4AT-64, INSTALLATION, Oil Charge Pipe.>

11) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:
50 — 55 mm (1.97 — 2.17 in)



12) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>


13) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


1. DIFFERENTIAL CASE ASSEMBLY

1) Remove the taper roller bearing using the ST and a press.

ST 498077000 REMOVER



2) Secure the case in a vise, remove the hypoid driven gear tightening bolts, and then separate the hypoid driven gear into case (RH) and case (LH).




(A) Hypoid driven gear
(B) Differential case (RH)
(C) Differential case (LH)

Front Differential Assembly

AUTOMATIC TRANSMISSION

3) Pull out the straight pin and shaft, and then remove the differential bevel gear, washer and differential bevel pinion.




(A) Differential case (RH)

2. SIDE RETAINER


NOTE:

After adjusting the drive pinion backlash and tooth contact, remove and install the oil seal and O-ring.


1) Remove the O-ring.



2) Remove the oil seal.




3) Remove the split pin, and then remove the claw.
ST 398527700 PULLER ASSY



(A) Claw
(B) Split pin
(C) Pin

4) Attach two claws to the outer race, and set the ST to side retainer.

ST 398527700 PULLER ASSY



(A) Shaft
(B) Claw


5) Restore the removed claws to original position, and install the pin and split pin.

6) Hold the shaft of ST to avoid removing from side retainer, and then remove the bearing outer race.

ST 398527700 PULLER ASSY

NOTE:

Replace the bearing inner and outer races as a single unit.




(A) Shaft
(B) Side retainer

D: ASSEMBLY

1. DIFFERENTIAL CASE ASSEMBLY

- 1) Install the washer, differential bevel gear and differential bevel pinion in the differential case (RH). Insert the pinion shaft.
- 2) Attach the straight pin in the reverse direction.




(A) Differential case (RH)

- 3) Install the washer and differential bevel gear to the differential case (LH). Put the differential case (RH) on the case, and assemble two cases.
- 4) Install the hypoid driven gear and secure by tightening the bolt.

Tightening torque:

62 N·m (6.3 kgf-m, 45.7 ft-lb)



- (A) Hypoid driven gear
- (B) Differential case (RH)
- (C) Differential case (LH)

- 5) Measurement of backlash (Selection of washer)
 - (1) Install the genuine axle shaft to differential case.

Part No. 38415AA070AXLE SHAFT

- (2) Measure the gear backlash using ST1 and ST2, and then insert the ST2 through the access window of case.

ST1 498247001 MAGNET BASE


ST2 498247100 DIAL GAUGE

NOTE:

- Measure the backlash by applying a pinion tooth between two bevel gear teeth.
- Fix the bevel pinion gear in place with a screwdriver or similar tool when measuring.

Standard:


0.13 — 0.18 mm (0.0051 — 0.0071 in)



- (3) If the backlash is out of specification, select a washer from the table below.

Washer	
Part No.	Thickness mm (in)
803038021	0.95 (0.037)
803038022	1.00 (0.039)
803038023	1.05 (0.041)

- 6) Using the ST, install the taper roller bearing.
- ST 398437700 DRIFT



(A) Taper roller bearing


Front Differential Assembly

AUTOMATIC TRANSMISSION


2. SIDE RETAINER

- 1) Install the bearing outer race to side retainer.
- 2) Install a new oil seal using the ST and a hammer.

ST 18675AA000 DIFFERENTIAL SIDE OIL SEAL INSTALLER



- 3) Apply gear oil to a new O-ring and install.



E: INSPECTION

- Check each component for scratches, damage or other faults.
- Measure the backlash, and then adjust it to be within specification. <Ref. to 4AT-100, ADJUSTMENT, Front Differential Assembly.>

F: ADJUSTMENT

- 1) Using the ST, screw-in the retainer until resistance is felt.


NOTE:

Screw in the RH side slightly deeper than the LH side.

ST 18630AA010 WRENCH COMPL RETAINER

NOTE:

- Screw in the RH side slightly deeper than the LH side.
- WRENCH ASSEMBLY (499787000) can also be used.




- 2) Remove the oil pump housing.
- 3) Remove the liquid gasket from the mating surface completely.
- 4) Install the oil pump housing assembly to the converter case, and secure them by tightening the four bolts evenly.

NOTE:

Use an old gasket or aluminum washer to prevent damaging the mating surface of the housing.

Tightening torque:

41 N·m (4.2 kgf·m, 30.2 ft·lb)




Front Differential Assembly

AUTOMATIC TRANSMISSION


5) Rotate the drive pinion a few times using ST1 and ST2.

ST1 498937110 HOLDER

ST2 499787700 WRENCH




6) Tighten the LH retainer by rotating the shaft until resistance is felt. Then loosen the retainer RH. Keep tightening the retainer LH, and loosening the retainer RH until the pinion shaft no longer be turned. This is the “zero” state.



(A) Retainer


7) After the “zero” state is established, loosen the retainer LH by 3 notches and secure it with the lock plate. Then loosen the retainer RH and retighten until it stops. Rotate the drive pinion 2 or 3 times. Tighten the retainer RH further 1-3/4 notches. This sets the preload. Finally, secure the retainer with its lock plate.



(A) Lock plate

NOTE:

Turning the retainer by one tooth changes the backlash approx. 0.05 mm (0.0020 in).



8) Turn the drive pinion a few times with ST1 and check to see if the backlash is within the specified value, using ST2, ST3, ST4 and ST5.

ST1 499787700 WRENCH

ST2 498247001 MAGNET BASE


ST3 498247100 DIAL GAUGE

ST4 499787500 ADAPTER

ST5 498255400 PLATE

Backlash:

0.13 — 0.18 mm (0.0051 — 0.0071 in)




9) Adjust the teeth contact of the front differential and drive shaft. <Ref. to 4AT-93, ADJUSTMENT, Drive Pinion Shaft Assembly.>


37.AT Main Case

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.




- 4) Lift up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the inhibitor switch connector from the stay.
- 6) Disconnect the air breather hose.
- 7) Remove the oil charge pipe. <Ref. to 4AT-64, REMOVAL, Oil Charge Pipe.>
- 8) Remove the oil cooler inlet and outlet pipes. <Ref. to 4AT-61, REMOVAL, ATF Cooler Pipe and Hose.>
- 9) Separate the converter case from the transmission case. <Ref. to 4AT-84, REMOVAL, Converter Case.>
- 10) Remove the oil pump housing. <Ref. to 4AT-86, REMOVAL, Oil Pump Housing.>
- 11) Take out the high clutch, thrust needle bearing and reverse clutch assembly.




- (A) High clutch and reverse clutch ASSY
- (B) Thrust needle bearing

- 12) Take out the high clutch hub and thrust bearing.



- (A) High clutch hub
- (B) Thrust needle bearing

- 13) Take out the front sun gear and thrust needle bearing.




- (A) Front sun gear
- (B) Thrust needle bearing

- 14) Pull out the leaf spring, being careful not to break it.


NOTE:

Remove it while pressing down on the lower leaf spring.




- (A) Leaf spring
- (B) Retaining plate

15) Remove the snap ring and thrust needle bearing.




- (A) Snap ring
- (B) Thrust needle bearing


16) Take out the retaining plate, drive plate and driven plate of 2-4 brake.




17) Take out the thrust needle bearing, planetary gear assembly and low clutch assembly.



18) Remove the 2-4 brake seal.




19) Remove the snap ring.




- (A) Snap ring
- (B) 2-4 brake piston

20) Take out the 2-4 brake return spring.




21) Remove the 2-4 brake piston and piston retainer while taking care not to damage them.



- (A) 2-4 brake piston
- (B) 2-4 brake piston retainer

22) Pull out the leaf spring without bending it.




- (A) Leaf spring

AT Main Case


AUTOMATIC TRANSMISSION

23) Remove the snap ring.




(A) Snap ring


24) Take out the retaining plate, drive plate, driven plate and dish plate.




25) Turn the transmission case upside down, and then take out the socket bolts while holding the one-way clutch inner race by hand.




26) Remove the spring retainer.




27) Take out the return spring.



28) Apply compressed air.



29) Take out the low & reverse piston.




B: INSTALLATION


1) Install the low & reverse piston.

NOTE:


Take care not to damage the lip seal.



2) Install the return spring.



3) Install the spring retainer.




4) Install the one-way clutch inner race, spring retainer and return spring.

5) Tighten the socket head bolts evenly from the rear side of transmission case.

Tightening torque:

25 N·m (2.5 kgf·m, 18.4 ft·lb)



6) Place the front side of transmission body up.

7) Install the thrust needle bearing.

8) Place the dish plate, driven plate, drive plate and retaining plate neatly in this order on surface table.

9) Set the micro gauge to retaining plate, and read its scale. Measure at three locations or more spaced by equal distances and take the average value.

NOTE:


The value, which is read in the gauge at this time, is zero point.

10) Scale and record the weight "Z" of a flat board which will be put on retaining plate.

NOTE:

- Use a stiff board which does not bend against load as a flat board to be put on retaining plate.
- Use a flat board weighing less than 8.5 kg (18.7 lb).

11) Put the flat board on retaining plate.



12) Using the following formula, read the push/pull gauge, and calculate "N".

$$N = 83 \text{ N (8.5 kgf, 18.7 lbf)} - Z$$

N: Value indicated on push/pull gauge

83 N (8.5 kgf, 18.7 lbf): Load applied to clutch plate


Z: Flat board weight

AUTOMATIC TRANSMISSION

13) Press the center of retaining plate by applying a force of N using push/pull gauge, and then measure and record the height "A". Measure at three locations or more spaced by equal distances and take the average value.

NOTE:

If measuring in three locations, measure every 120°. If measuring in four locations, measure every 90°.




- (A) Dish plate
- (B) Driven plate
- (C) Drive plate
- (D) Retaining plate

14) Installation of the low & reverse brake:
Install the dish plate, driven plate, drive plate and retaining plate, and then secure them with a snap ring.


NOTE:

Pay attention to the orientation of the dish plate.



- (A) Snap ring


15) Apply compressed air intermittently to check for operation.



16) Place same thickness shims on both sides to prevent plate from tilting, then measure and record the clearance "B".

NOTE:

Do not push in the shim down with force to a point where the waves on the drive plate will be crushed.



17) Piston stroke calculation

Calculate from the recorded dimension A and B, and if the service limit is exceeded, replace with a new drive plate and adjust so that it is within standard.

$T = A + B$

T: Piston stroke

A: Amount of drive plate compression

B: Clearance between retaining plate and snap ring

Non-turbo model

Initial standard:

2.15 — 2.65 mm (0.073 — 0.093 in)

Limit thickness:

2.95 mm (0.104 in)

Turbo model

Initial standard:

2.70 — 3.20 mm (0.106 — 0.126 in)

Limit thickness:


3.90 mm (0.154 in)

Retaining plate	
Part No.	Thickness mm (in)
31667AA420	3.8 (0.150)
31667AA320	4.1 (0.161)
31667AA330	4.4 (0.173)
31667AA340	4.7 (0.185)
31667AA350	5.0 (0.197)
31667AA360	5.3 (0.209)
31667AA370	5.6 (0.220)
31667AA380	5.9 (0.232)

NOTE:


If the drive plate is not being replaced, do not adjust.

18) Install the leaf spring of the low & reverse brake.



(A) Leaf spring


19) Install the 2-4 brake piston and 2-4 brake retainer by aligning the hole of the 2-4 brake retainer with the hole on the transmission case.



(A) 2-4 brake piston


(B) 2-4 brake piston retainer

20) Install 2-4 brake piston return spring to the transmission case.



21) Position the snap ring in the transmission. Using ST, press the snap ring into the specified location.

ST 498677100 COMPRESSOR




AUTOMATIC TRANSMISSION

22) Install the planetary gear and low clutch assembly to the transmission case.


CAUTION:

Install carefully while rotating the low clutch and planetary gear assembly slowly, paying special attention not to damage the seal ring.




AT-00255

23) 2-4 Brake retaining plate selection (turbo model)
 (1) Install the pressure plate, drive plate, driven plate, retaining plate and snap ring.




AT-00254

(2) Install a new 2-4 brake oil seal to the transmission case.



AT-00284

(3) After all 2-4 brake component parts have been installed, blow in air intermittently and confirm the operation of the brake.



AT-00290

(4) Check the clearance between the retaining plate and snap ring.

NOTE:

If the drive plate is not being replaced, do not adjust.


If the value exceeds the service limits, replace the drive plate with a new part and make adjustment so that the clearance is within the standard.

Initial standard:

0.8 — 1.2 mm (0.031 — 0.047 in)

Limit thickness:

1.5 mm (0.059 in)



AT-00292

Retaining plate	
Part No.	Thickness mm (in)
31567AA991	5.6 (0.220)
31567AB001	5.8 (0.228)
31567AB011	6.0 (0.236)
31567AB021	6.2 (0.244)
31567AB031	6.4 (0.252)
31567AB041	6.6 (0.260)

24) 2-4 Brake retaining plate selection (non-turbo model)

(1) Place the dish plate, driven plate, drive plate and retaining plate neatly in this order on surface table.

(2) Set the micro gauge to clutch, and read its scale.

NOTE:

The value, which is read in the gauge at this time, is zero point.


(3) Scale and record the weight Z of a flat board which will be put on retaining plate.

NOTE:

- Use a stiff board which does not bend against load as a flat board to be put on retaining plate.

- Use a flat board weighing less than 10.2 kg (22.5 lb).

(4) Put the flat board on retaining plate.



(5) Using the following formula, read the push/pull gauge, and calculate N.

$$N = 100 \text{ N (10.2 kgf, 22.5 lbf)} - Z$$

N: Value indicated on push/pull gauge


100 N (10.2 kgf, 22.5 lbf): Load applied to clutch plate

Z: Flat board weight

(6) Press the center of retaining plate by applying a force of N using push/pull gauge, and then measure and record the height "A". Measure at three locations or more spaced by equal distances and take the average value.


NOTE:

If measuring in three locations, measure every 120°. If measuring in four locations, measure every 90°.




- (A) Driven plate
- (B) Drive plate
- (C) Retaining plate


(7) Install the pressure plate, drive plate, driven plate, retaining plate and snap ring.




(8) Install a new 2-4 brake oil seal to the transmission case.



(9) After all 2-4 brake component parts have been installed, blow in air intermittently and confirm the operation of the brake.



(10) Measure clearance "B" between the retaining plate and snap ring.



AUTOMATIC TRANSMISSION

(11) Piston stroke calculation

Calculate from the recorded dimension A and B, and if the service limit is exceeded, replace the drive plate and adjust so that it is within standard.

$$T = A + B$$

T: Piston stroke

A: Amount of drive plate compression

B: Clearance between retaining plate and snap ring

Initial standard:

1.7 — 2.1 mm (0.067 — 0.083 in)

Limit thickness:


2.3 mm (0.091 in)

Retaining plate	
Part No.	Thickness mm (in)
31567AA991	5.6 (0.220)
31567AB001	5.8 (0.228)
31567AB011	6.0 (0.236)
31567AB021	6.2 (0.244)
31567AB031	6.4 (0.252)
31567AB041	6.6 (0.260)

NOTE:


If the drive plate is not being replaced, do not adjust.

25) Be careful not to mistake the location of the leaf spring to be installed.




- (A) Leaf spring
- (B) Retaining plate

26) Install the thrust needle bearing in the correct direction.



- (A) Snap ring
- (B) Thrust needle bearing
- (C) Upside
- (D) Downside
- (E) Outside

27) Install the front sun gear and the thrust needle bearing.




- (A) Front sun gear
- (B) Thrust needle bearing
- (C) Clutch hub side
- (D) Front sun gear side
- (E) Outside

28) Install the high clutch hub.


Attach the thrust needle bearing to hub using Vaseline, and then install the hub by correctly engaging the splines of the front planetary carrier.

29) Install the thrust needle bearing in the proper direction.



- (A) High clutch hub
- (B) Thrust needle bearing
- (C) Upside
- (D) Downside
- (E) Outside


30) Install the high clutch assembly.



- (A) High clutch and reverse clutch ASSY

31) Adjust the total end play. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

32) Install the thrust needle bearing in the proper direction.




- (A) High clutch and reverse clutch ASSY
- (B) Thrust needle bearing
- (C) Upside
- (D) Downside
- (E) Outside

33) Install a new gasket along with the oil pump housing assembly.

34) Install the converter case assembly to the transmission case assembly. <Ref. to 4AT-84, INSTALLATION, Converter Case.>

35) Insert the inhibitor switch and transmission connector to the stay.



- (A) Transmission harness
- (B) Inhibitor switch harness

36) Install the air breather hose. <Ref. to 4AT-63, INSTALLATION, Air Breather Hose.>

37) Install the oil cooler pipe. <Ref. to 4AT-62, INSTALLATION, ATF Cooler Pipe and Hose.>

38) Install the oil charge pipe with O-ring. <Ref. to 4AT-64, INSTALLATION, Oil Charge Pipe.>


39) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:

50 — 55 mm (1.97 — 2.17 in)




40) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>

41) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: DISASSEMBLY


1. HIGH CLUTCH AND REVERSE CLUTCH

1) Remove the snap ring, and then take out the retaining plate, drive plate and driven plate.




(A) Snap ring

2) Remove the snap ring, and then take out the retaining plate, drive plate and driven plate.




(A) Snap ring

3) Using the ST1 and ST2, remove the snap ring.
 ST1 398673600 COMPRESSOR
 ST2 498627100 SEAT




(A) Snap ring

4) Take out the clutch cover, spring retainer, high clutch piston and reverse clutch piston.



(A) Reverse clutch piston
 (B) Cover
 (C) Return spring


5) Remove the seal ring and lip seal from the high clutch piston and reverse clutch piston.



(A) High clutch piston
 (B) Reverse clutch piston


2. PLANETARY GEAR AND LOW CLUTCH

1) Remove the snap ring from low clutch drum.




(A) Snap ring
 (B) Low clutch drum

2) Take out the front planetary carrier.




- (A) Front planetary carrier
- (B) Low clutch drum

5) Take out the rear internal gear.




- (A) Rear internal gear
- (B) Low clutch drum

3) Take out the rear sun gear.




- (A) Rear sun gear
- (B) Rear planetary carrier

6) Remove the snap ring from low clutch drum.



- (A) Snap ring
- (B) Low clutch drum


4) Take out the rear planetary carrier, washer and thrust needle bearing.



- (A) Rear planetary carrier
- (B) Low clutch drum

7) Compress the spring retainer and remove the snap ring from the low clutch drum using ST1 and ST2.

ST1 498627100 SEAT
ST2 398673600 COMPRESSOR




- (A) Snap ring
- (B) Low clutch drum

8) Remove the one-way clutch. <Ref. to 4AT-102, REMOVAL, AT Main Case.>


AUTOMATIC TRANSMISSION

9) Install the one-way clutch inner race to the low clutch drum, and then apply compressed air to remove the low clutch piston.




- (A) Apply compressed air.
- (B) One-way clutch inner race

10) Remove the one-way clutch inner race.
11) Remove the one-way clutch after taking out the snap ring.



- (A) Snap ring
- (B) Plate
- (C) One-way clutch


12) Remove the needle bearing after taking out the snap ring.



- (A) Needle bearing
- (B) Snap ring

3. 2-4 BRAKE

1) Separate the 2-4 brake piston and piston retainer.




- (A) 2-4 brake piston
- (B) 2-4 brake piston retainer

2) Remove the D-ring from the 2-4 brake piston.

4. ONE-WAY CLUTCH INNER RACE

1) Remove the seal ring.




- (A) One-way clutch inner race
- (B) Seal ring

2) Remove the needle bearing using ST. ST 398527700 PULLER ASSY


5. ONE-WAY CLUTCH OUTER RACE

1) Remove the one-way clutch after taking out the snap ring.




- (A) Snap ring
- (B) Plate
- (C) One-way clutch

2) Remove the needle bearing after taking out the snap ring.



(A) Needle bearing
(B) Snap ring

4) Install the spring retainer to the high clutch piston.




(A) Return spring
(B) High clutch drum

D: ASSEMBLY


1. HIGH CLUTCH AND REVERSE CLUTCH

- 1) Install the seal ring and lip seal to the high clutch piston and reverse clutch piston.
- 2) Install the high clutch piston to the reverse clutch piston.



(A) High clutch piston
(B) Reverse clutch piston


5) Attach the ST to the high clutch piston.
ST 498437000 HIGH CLUTCH PISTON GUIDE




- 6) Install the cover to the high clutch piston while making sure not to bend the high clutch piston seal.
- 7) Using the ST1, ST2 and ST3, install the snap ring.

ST1 398673600 COMPRESSOR
ST2 498627100 SEAT
ST3 498437000 HIGH CLUTCH PISTON GUIDE

3) Install the reverse clutch to the high clutch drum. Align the groove on reverse clutch piston with the groove on high clutch drum during installation.




(A) Reverse clutch piston
(B) High clutch drum



AT Main Case


AUTOMATIC TRANSMISSION

8) Install the thickest driven plate to piston side, and then install the driven plate, drive plate, retaining plate to high clutch drum.



9) Install the snap ring to high clutch drum.

10) Apply compressed air intermittently to check for operation.



11) High clutch retaining plate selection (non-turbo model)

(1) Place the dish plate, driven plate, drive plate and retaining plate neatly in this order on surface table.

(2) Set the dial gauge to clutch, and read its scale.

NOTE:


The value, which is read in the gauge at this time, is zero point.

(3) Scale and record the weight Z of a flat board which will be put on retaining plate.

NOTE:

- Use a stiff board which does not bend against load as a flat board to be put on retaining plate.
- Use a flat board weighing less than 25.5 kg (56.2 lb).

(4) Put the flat board on retaining plate.



(5) Using the following formula, read the push/pull gauge, and calculate N.

$$N = 250 \text{ N (25.5 kgf, 56.2 lbf)} - Z$$

N: Value indicated on push/pull gauge


250 N (25.5 kgf, 56.2 lbf): Load applied to clutch plate

Z: Flat board weight

(6) Press the center of retaining plate by applying a force of N using push/pull gauge, and then measure and record the height "A". Measure at three locations or more spaced by equal distances and take the average value.

NOTE:

If measuring in three locations, measure every 120°. If measuring in four locations, measure every 90°.



- (A) Driven plate
- (B) Drive plate
- (C) Retaining plate


12) Measure the clearance between the high clutch retaining plate and snap ring. (Turbo model)
At this time, do not press down the retaining plate.

Initial standard:

0.8 — 1.1 mm (0.031 — 0.043 in)

Limit thickness:

1.5 mm (0.059 in)



(A) Thickness gauge

If the value exceeds the service limits, replace the drive plate with a new part and make adjustment so that the clearance is within the standard.

High clutch retaining plate	
Part No.	Thickness mm (in)
31567AA710	4.7 (0.185)
31567AA720	4.8 (0.189)
31567AA730	4.9 (0.193)
31567AA740	5.0 (0.197)
31567AA670	5.1 (0.201)
31567AA680	5.2 (0.205)
31567AA690	5.3 (0.209)
31567AA700	5.4 (0.213)


NOTE:

If the drive plate is not being replaced, do not adjust.

13) Check the piston stroke. (Non-turbo model)

(1) Measure clearance "B" between the retaining plate and snap ring. (High clutch)

At this time, do not press down the retaining plate.



(A) Thickness gauge

(2) Piston stroke calculation

Calculate from the recorded dimension A and B, and if the service limit is exceeded, replace the drive plate and adjust so that it is within standard.

$$T = A + B$$

T: Piston stroke

A: Amount of drive plate compression

B: Clearance between retaining plate and snap ring

Initial standard:

2.0 — 2.3 mm (0.079 — 0.091 in)

Limit thickness:

2.6 mm (0.102 in)

High clutch retaining plate	
Part No.	Thickness mm (in)
31567AA670	5.1 (0.201)
31567AA680	5.2 (0.205)
31567AA690	5.3 (0.209)
31567AA700	5.4 (0.213)
31567AA710	4.7 (0.185)
31567AA720	4.8 (0.189)
31567AA730	4.9 (0.193)
31567AA740	5.0 (0.197)

14) Selection of the reverse clutch retaining plate

(1) Place the dish plate, driven plate, drive plate and retaining plate neatly in this order on surface table.

(2) Set the dial gauge to clutch, and read its scale.

NOTE:

The value, which is read in the gauge at this time, is zero point.


(3) Scale and record the weight Z of a flat board which will be put on retaining plate.

NOTE:

- Use a stiff board which does not bend against load as a flat board to be put on retaining plate.

- Use a flat board weighing less than 15.3 kg (33.7 lb).

(4) Put the flat board on retaining plate.



AUTOMATIC TRANSMISSION

(5) Using the following formula, read the push/pull gauge, and calculate N.

$$N = 150 \text{ N (15.3 kgf, 33.7 lbf)} - Z$$

N: Value indicated on push/pull gauge


150 N (15.3 kgf, 33.7 lbf): Load applied to the clutch plate

Z: Flat board weight

(6) Press the center of retaining plate by applying a force of N using push/pull gauge, and then measure and record the height "A". Measure at three locations or more spaced by equal distances and take the average value.


NOTE:

If measuring in three locations, measure every 120°. If measuring in four locations, measure every 90°.




- (A) Driven plate
- (B) Drive plate
- (C) Retaining plate

(7) Install the driven plate, drive plate, retaining plate and snap ring.




(8) Apply compressed air intermittently to check for operation.



15) Check the piston stroke.

(1) Measure clearance "B" between the retaining plate and snap ring. (Reverse clutch)

At this time, do not press down the retaining plate.



(A) Thickness gauge

(2) Piston stroke calculation

Calculate from the recorded dimension A and B, and if the service limit is exceeded, replace the drive plate and adjust so that it is within standard.

$$T = A + B$$

T: Piston stroke

A: Amount of drive plate compression

B: Clearance between retaining plate and snap ring

Initial standard:

1.1 — 1.4 mm (0.043 — 0.055 in)

Limit thickness:

1.6 mm (0.063 in)


Reverse clutch retaining plate	
Part No.	Thickness mm (in)
31567AA910	4.0 (0.157)
31567AA920	4.2 (0.165)
31567AA930	4.4 (0.173)
31567AA940	4.6 (0.181)
31567AA950	4.8 (0.189)
31567AA960	5.0 (0.197)
31567AA970	5.2 (0.205)
31567AA980	5.4 (0.213)

NOTE:

If the drive plate is not being replaced, do not adjust.


2. PLANETARY GEAR AND LOW CLUTCH

- 1) Install the D-ring to the low clutch piston.
- 2) Install the low clutch piston to low clutch drum.




- (A) Low clutch piston
- (B) Low clutch drum

- 3) Install the spring retainer to low clutch piston.




- (A) Spring retainer
- (B) Low clutch drum

- 4) Attach the ST to the low clutch drum.
ST 498437100 LOW CLUTCH PISTON GUIDE




- 5) Using ST1 and ST2, set the cover on the piston and press against it, and attach the snap ring. At this time, be careful not to bend the cover seal.

- ST1 498627100 SEAT
- ST2 398673600 COMPRESSOR
- ST3 498437100 LOW CLUTCH PISTON GUIDE



AUTOMATIC TRANSMISSION


6) Install the dish plate, driven plate, drive plate and retaining plate, and then secure them with a snap ring.



- (A) Snap ring
- (B) Low clutch drum
- (C) Dish plate
- (D) Low clutch piston side

7) Check the low clutch for operation.

- (1) Remove the one-way clutch. <Ref. to 4AT-102, REMOVAL, AT Main Case.>
- (2) Set the one-way clutch inner race, and apply compressed air for checking.



- (A) Apply compressed air.
- (B) Low clutch drum


- 8) Check the low clutch clearance.
 - (1) Place same thickness shims on both sides to prevent plate from tilting.
 - (2) Check the clearance between retaining plate and low clutch operation.

Initial standard:

0.7 — 1.1 mm (0.028 — 0.043 in)

Limit thickness:

1.6 mm (0.063 in)




- (A) Thickness gauge
- (B) Low clutch drum

If the drive plate is not being replaced, do not adjust.

If the value exceeds the service limits, replace the drive plate with a new part and make adjustment so that the clearance is within the standard.


Retaining plate	
Part No.	Thickness mm (in)
31567AA830	3.8 (0.150)
31567AA840	4.0 (0.157)
31567AA850	4.2 (0.165)
31567AA860	4.4 (0.173)
31567AA870	4.6 (0.181)

9) Install the washer to the rear internal gear.




- (A) Rear internal gear
- (B) Washer

10) Install the rear internal gear.




- (A) Rear internal gear
- (B) Low clutch drum

13) Install the rear planetary carrier to the low clutch drum.




- (A) Rear planetary carrier
- (B) Low clutch drum

11) Install the thrust needle bearing in the correct direction.




- (A) Thrust needle bearing
- (B) Low clutch drum
- (C) Rear planetary carrier side
- (D) Low clutch drum side

14) Install the thrust needle bearing in the correct direction.




- (A) Rear sun gear side
- (B) Low clutch drum side

12) Install the washer by aligning the protrusion of the washer with the hole of the rear planetary carrier.



- (A) Washer
- (B) Rear planetary carrier


15) Install the rear sun gear in the proper direction.



- (A) Rear sun gear
- (B) Rear planetary carrier


AUTOMATIC TRANSMISSION

16) Install the thrust needle bearing in the proper direction.




- (A) Thrust needle bearing
- (B) Front planetary carrier
- (C) Rear sun gear side
- (D) Front planetary carrier side

17) Install the front planetary carrier to the low clutch drum.




- (A) Front planetary carrier
- (B) Low clutch drum

18) Install the snap ring to the low clutch drum.



- (A) Snap ring
- (B) Front planetary carrier


19) Install the needle bearing, and then secure with the snap ring.



- (A) Needle bearing
- (B) Snap ring

20) Install the one-way clutch, and then secure with the snap ring.

21) Set the inner race. Make sure that the clutch locks in the clockwise direction and rotates in the counterclockwise direction.




- (A) Lock
- (B) Free

3. 2-4 BRAKE

1) Apply ATF to the new D-ring, and then install it to the 2-4 brake piston.

2) Install 2-4 brake piston to 2-4 brake piston retainer.




- (A) 2-4 brake piston
- (B) 2-4 brake piston retainer

4. ONE-WAY CLUTCH INNER RACE


1) Install the needle bearing to inner race using ST and a press.

ST 398497701 INSTALLER



2) Apply Vaseline to the groove of the inner race and seal ring.


3) Install two seal rings to the one-way clutch inner race.



(A) One-way clutch inner race
(B) Seal ring

5. ONE-WAY CLUTCH OUTER RACE


1) Install the needle bearing, and then secure with the snap ring.



(A) Needle bearing
(B) Snap ring

2) Install the one-way clutch and one-way clutch inner race, then secure with the snap ring.

3) Set the inner race. Make sure that the clutch locks in the clockwise direction and rotates in the counterclockwise direction.



(A) Lock
(B) Free

E: INSPECTION

1. HIGH CLUTCH AND REVERSE CLUTCH

Check the following items.

- Drive plate facing for wear or damage
- Driven plate for discoloration (burned color)
- Snap ring wear, return spring setting and breakage, and snap ring retainer deformation
- Lip seal and D-ring damage
- Piston and drum check ball operation
- Adjust the total end play. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

2. PLANETARY GEAR AND LOW CLUTCH

Check the following items.

- Drive plate facing for wear or damage
- Driven plate for discoloration (burned color)
- Snap ring wear, return spring setting and breakage, and spring retainer deformation
- Lip seal and D-ring damage
- Piston check ball operation
- Measure the total end play and adjust it to be within specifications. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

3. 2-4 BRAKE

Check the following items.

- Drive plate facing for wear or damage
- Driven plate for discoloration (burned color)
- Snap ring wear and spring retainer deformation
- Lip seal and D-ring damage
- Measure the total end play and adjust it to be within specifications. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

4. ONE-WAY CLUTCH

- Check that the snap ring is not damaged and the seal ring is not deformed.
- Measure the total end play and adjust it to be within specifications. <Ref. to 4AT-90, ADJUSTMENT, Oil Pump Housing.>

5. LOW & REVERSE BRAKE

Check the following:


- Drive plate facing for wear or damage
- Driven plate for discoloration (burned color)
- Snap ring wear and spring retainer deformation

Brought to you by Eris Studios
NOT FOR RESALE


38. Transmission Control Device

A: REMOVAL

- 1) Remove the transmission assembly from vehicle body. <Ref. to 4AT-36, REMOVAL, Automatic Transmission Assembly.>
- 2) Pull out the torque converter clutch assembly. <Ref. to 4AT-65, REMOVAL, Torque Converter Clutch Assembly.>
- 3) Remove the input shaft.
- 4) Lift up the lever on the rear side of transmission harness connector, and then disconnect it from the stay.
- 5) Disconnect the air breather hose. <Ref. to 4AT-63, REMOVAL, Air Breather Hose.>
- 6) Disconnect the inhibitor switch connector from the stay.
- 7) Wrap vinyl tape around the nipple attached to the air breather hose.
- 8) Remove the pitching stopper bracket.
- 9) Remove the inhibitor switch.




- 10) Remove the control valve body assembly. <Ref. to 4AT-55, REMOVAL, Control Valve Body.>
- 11) Pull out the straight pin of manual plate.



- 12) Remove the bolts securing select lever, and then remove the select lever, manual plate and parking rod.


NOTE:

Be careful not to damage the lips of press-fitted oil seal in the case.



- (A) Bolt
- (B) Range select lever
- (C) Manual plate
- (D) Parking rod

- 13) Remove the detent spring.




B: INSTALLATION

- 1) Install the detent spring to the transmission case.

Tightening torque:

6 N·m (0.6 kgf-m, 4.3 ft-lb)




Transmission Control Device

AUTOMATIC TRANSMISSION


2) Insert the range select lever being careful not to damage the oil seal lip area, then tighten the bolt.

Tightening torque:

6 N·m (0.6 kgf·m, 4.3 ft·lb)




3) Install the manual plate and parking rod.



- (A) Bolt
- (B) Range select lever
- (C) Manual plate
- (D) Parking rod

4) Insert the spring pin to the manual plate.



5) Install the oil pan and the control valve assembly. <Ref. to 4AT-56, INSTALLATION, Control Valve Body.>

6) Turn over the transmission case to its original position.


7) Install the pitching stopper bracket.

Tightening torque:

41 N·m (4.2 kgf·m, 30.2 ft·lb)

8) Install and adjust the inhibitor switch. <Ref. to 4AT-46, Inhibitor Switch.>

9) Insert the inhibitor switch and transmission connector to the stay.



- (A) Transmission harness
- (B) Inhibitor switch harness

10) Install the air breather hose. <Ref. to 4AT-63, INSTALLATION, Air Breather Hose.>


11) Insert the input shaft, and check the amount of protrusion.

NOTE:

Turn the input shaft lightly by hand while inserting.

Normal protrusion amount A:

50 — 55 mm (1.97 — 2.17 in)



12) Install the torque converter clutch assembly. <Ref. to 4AT-65, INSTALLATION, Torque Converter Clutch Assembly.>

13) Install the transmission assembly to the vehicle. <Ref. to 4AT-38, INSTALLATION, Automatic Transmission Assembly.>

C: INSPECTION

Make sure the manual lever and detent spring are not worn or otherwise damaged.