

Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

General Description


Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

1. General Description

A: COMPONENT

1. AIR CLEANER



IN-02269

- | | |
|---|------------------------------|
| (1) Mass air flow and intake air temperature sensor | (7) Air cleaner case (front) |
| (2) Air cleaner case (rear) | (8) Air intake duct |
| (3) Clip | (9) Clip |
| (4) Air intake boot | (10) Cushion |
| (5) Clamp | (11) Spacer |
| (6) Air cleaner element | (12) Cushion |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 1 (0.1, 0.7)


T2: 2.5 (0.25, 1.8)

T3: 6 (0.6, 4.4)

T4: 7.5 (0.76, 5.5)

Brought to you by *3D CAD Studio*
 NOT FOR RESALE

2. INTAKE DUCT



IN-02297

- | | | |
|---------------------------------|--------------------------------|-----------------------------|
| (1) PCV hose ASSY A | (8) PCV pipe | (15) PCV hose ASSY B |
| (2) Intake manifold | (9) Vacuum hose | (16) Solenoid valve bracket |
| (3) Solenoid valve bracket ASSY | (10) Air by-pass pipe | |
| (4) Intake duct | (11) Clamp | |
| (5) Engine harness ASSY | (12) Vacuum hose | |
| (6) Vacuum hose | (13) Brake booster vacuum hose | |
| (7) Vacuum hose | (14) Clamp | |

Tightening torque: N·m (kgf·m, ft·lb)

T1: 6.4 (0.65, 4.7)

T2: 17 (1.7, 12.5)


T3: 19 (1.9, 14.0)

General Description

Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

3. INTERCOOLER



IN-02298

- | | |
|-----------------------|------------------------------------|
| (1) Intercooler | (5) Spacer |
| (2) O-ring | (6) Cushion |
| (3) Air by-pass valve | (7) Intercooler stay |
| (4) O-ring | (8) Brake booster vacuum hose clip |


Tightening torque: N·m (kgf·m, ft·lb)

T1: 6.5 (0.66, 4.8)

T2: 16 (1.6, 11.8)

Brought to you by *Tris Studios*
NOT FOR RESALE

4. TURBOCHARGER



IN-02318

- | | |
|-------------------------|------------------------------|
| (1) Oil inlet pipe | (8) Oil outlet pipe |
| (2) Metal gasket | (9) Clip |
| (3) Turbocharger | (10) Oil outlet hose |
| (4) Water pipe | (11) Turbocharger bracket RH |
| (5) Clip | (12) Turbocharger bracket LH |
| (6) Engine coolant hose | |
| (7) Gasket | |

Tightening torque: N·m (kgf·m, ft·lb)

- T1: 5 (0.5, 3.7)**
T2: 7.8 (0.8, 5.8)
T3: 16 (1.6, 11.8)
T4: 20 (2.0, 14.8)
T5: 23 (2.3, 17.0)
T6: 33 (3.4, 24.3)

General Description

Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

B: PREPARATION TOOL

1. GENERAL TOOL

TOOL NAME	REMARKS
Mighty Vac	Used to inspect the waste gate actuator.


C: CAUTION

- Wear appropriate work clothing, including a cap, protective goggles and protective shoes when performing any work.
- Remove contamination including dirt and corrosion before removal, installation or disassembly.
- Keep the disassembled parts in order and protect them from dust and dirt.
- Before removal, installation or disassembly, be sure to clarify the failure. Avoid unnecessary removal, installation, disassembly and replacement.
- Vehicle components are extremely hot after driving. Be wary of receiving burns from heated parts.
- Be sure to tighten fasteners including bolts and nuts to the specified torque.
- Place shop jacks or rigid racks at the specified points.
- Before disconnecting connectors of sensors or units, be sure to disconnect the ground cable from the battery.


2. Air Cleaner Element

A: REMOVAL


- 1) Disconnect the ground cable from battery.



- 2) Remove the air intake duct. <Ref. to IN(H4DOTC)-9, REMOVAL, Air Intake Duct.>
- 3) Disconnect the connector (A) from mass air flow and intake air temperature sensor.
- 4) Remove the clip (B) from the air cleaner case.



- 5) Open the air cleaner case, and remove the air cleaner element.



B: INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to use SUBARU genuine air cleaner element depending on the engine type when replacing the air cleaner elements. Otherwise engine performance may be damaged.

NOTE:


Check that there are no foreign objects in the air cleaner case.

INTAKE (INDUCTION)


3. Air Cleaner Case

A: REMOVAL


- 1) Disconnect the ground cable from the battery.



- 2) Remove the air intake duct. <Ref. to IN(H4DOTC)-9, REMOVAL, Air Intake Duct.>
- 3) Disconnect the connector (A) from mass air flow and intake air temperature sensor.
- 4) Loosen the clamp (B) which connects the air intake boot and intake duct.
- 5) Remove the clip (C) from the air cleaner case.



- 6) Remove the air cleaner case (rear) and air intake boot.
- 7) Remove the air cleaner element.
- 8) Remove the bolts (A) and nuts (B) which secure the air cleaner case (front) to the body.




- 9) Remove the air cleaner case (front).

B: INSTALLATION

Install in the reverse order of removal.

NOTE:

When installing the air cleaner case (rear), align the protrusion of the air cleaner case (rear) to the hole on the air cleaner case (front) to install.




Tightening torque:

Bolt (A)

6 N·m (0.6 kgf-m, 4.4 ft-lb)

Nut (B)

7.5 N·m (0.76 kgf-m, 5.5 ft-lb)




C: INSPECTION

Check for cracks or loose connections.

4. Air Intake Duct

A: REMOVAL

- 1) Remove the clip which installs the air intake duct on the front side of body.
- 2) Remove the air intake duct.



B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION


- 1) Check for cracks or loose connections.
- 2) Inspect that no foreign objects in the air intake duct.

INTAKE (INDUCTION)


5. Intake Duct

A: REMOVAL

- 1) Disconnect the ground cable from the battery.



- 2) Remove the intake manifold. <Ref. to FU(H4DOTC)-15, REMOVAL, Intake Manifold.>
- 3) Remove the sensor, engine harness and fuel pipe attached to the intake manifold. <Ref. to FU(H4DOTC)-21, DISASSEMBLY, Intake Manifold.>
- 4) Remove the intake duct from intake manifold.




B: INSTALLATION

Install in the reverse order of removal.

Tightening torque:

17 N·m (1.7 kgf·m, 12.5 ft·lb)




Brought to you by *Travis Studios*
NOT FOR RESALE


6. Intercooler

A: REMOVAL


- 1) Loosen the clamp and remove the air by-pass pipe (A) and vacuum hose (B) from the air by-pass valve.
- 2) Loosen the clamp, and then remove intake duct (C) from the intercooler.




- 5) Remove the brake booster vacuum hose from the brake booster vacuum hose clip (A), and remove bolts (B), then remove the intercoolers stay (C).



- 3) Remove the bolts which secure the intercooler to the turbocharger.



- 4) Remove the bolts which secure the intercooler to the intercooler stay, and remove the intercooler.



Intercooler

Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

B: INSTALLATION




Install in the reverse order of removal.

NOTE:

- Use new O-rings.
- Be careful not to pinch the O-ring.


Tightening torque:

16 N·m (1.6 kgf·m, 11.8 ft·lb)




Tightening torque:

3 N·m (0.3 kgf·m, 2.2 ft·lb)



C: DISASSEMBLY

1) Remove the air by-pass valve from intercooler.



D: ASSEMBLY


Assemble in the reverse order of disassembly.

NOTE:

- Use new O-rings.
- Be careful not to pinch the O-ring.

Tightening torque:

6.5 N·m (0.66 kgf·m, 4.8 ft·lb)



E: INSPECTION


Check for cracks or loose connections.

Brought to you by Pro-1 Studios
 NOT FOR RESALE


7. Turbocharger

A: REMOVAL


- 1) Set the vehicle on a lift.
- 2) Disconnect the ground cable from the battery.




- 3) Lift up the vehicle.
- 4) Drain engine coolant. <Ref. to CO(H4DOTC)-13, DRAINING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>
- 5) Lower the vehicle.
- 6) Remove the intercooler. <Ref. to IN(H4DOTC)-11, REMOVAL, Intercooler.>
- 7) Remove the center exhaust pipe. <Ref. to EX(H4DOTC)-8, REMOVAL, Center Exhaust Pipe.>
- 8) Lower the vehicle.
- 9) Separate the turbocharger joint pipe from turbocharger.




- 10) Disconnect the engine coolant hose which is connected to coolant filler tank.




- 11) Loosen the clamp which secures turbocharger to intake duct.




- 12) Remove the oil inlet pipe from the turbocharger.



- 13) Disconnect the engine coolant hose from the water pipe.



- 14) Disconnect the oil outlet hose from the oil outlet pipe.



- 15) Take out the turbocharger from engine compartment.


Turbocharger

Brought to you by Eris Studios
NOT FOR RESALE

INTAKE (INDUCTION)

B: INSTALLATION


- 1) Connect the oil outlet hose to the oil outlet pipe.



- 2) Install the turbocharger to intake duct.

Tightening torque:

3 N·m (0.3 kgf-m, 2.2 ft-lb)




- 3) Install the oil inlet pipe to the turbocharger.

Tightening torque:


T1: 5 N·m (0.5 kgf-m, 3.7 ft-lb)

T2: 16 N·m (1.6 kgf-m, 11.8 ft-lb)

T3: 20 N·m (2.0 kgf-m, 14.5 ft-lb)



- 4) Connect the engine coolant hoses to the water pipe.




- 5) Install the joint pipe to turbocharger.

NOTE:


Replace the gasket with a new part.

Tightening torque:

35 N·m (3.6 kgf-m, 25.8 ft-lb)



- 6) Connect the engine coolant hose which is connected to the coolant filler tank.



- 7) Lift up the vehicle.


- 8) Install the center exhaust pipe. <Ref. to EX(H4DOTC)-9, INSTALLATION, Center Exhaust Pipe.>

- 9) Lower the vehicle.

- 10) Install the intercooler. <Ref. to IN(H4DOTC)-12, INSTALLATION, Intercooler.>


- 11) Fill engine coolant. <Ref. to CO(H4DOTC)-13, FILLING OF ENGINE COOLANT, REPLACEMENT, Engine Coolant.>

- 12) Connect the ground cable to battery.




C: INSPECTION**1. WASTE GATE ACTUATOR**

- 1) Remove the intercooler. <Ref. to IN(H4DOTC)-11, REMOVAL, Intercooler.>
- 2) Remove the turbocharger upper cover.



- 3) Remove the boost hose (B) from the waste gate actuator (A) of the turbo charger, and connect the Mighty Vac to the waste gate actuator (A).



- (A) Waste gate actuator
- (B) Boost hose
- (C) Control rod
- (D) Control rod stroke

- 4) Pressurize slowly with the Mighty Vac, and measure the pressure when the control rod stroke (D) becomes 2 mm (0.08 in). If it is not within the standard, replace the turbocharger assembly.

CAUTION:

Do not pressurize over 89.8 kPa (0.92 kgf/cm², 13.0 psi) to prevent damaging the waste gate actuator.

Control pressure (Control rod stroke 2 mm (0.08 in)):


Standard value

74.6 — 80.8 kPa (0.76 — 0.82 kgf/cm², 10.8 — 11.7 psi)

- 5) After inspection, install the related parts in the reverse order of removal.

Tightening torque:

7.5 N·m (0.76 kgf·m, 5.5 ft·lb)

**2. OIL PIPE AND WATER PIPE**


- Check that there are no oil leaks or water leaks from the pipe attachment section.
- Check for cracks or loose connections.

INTAKE (INDUCTION)

8. Air By-pass Valve

A: REMOVAL

- 1) Disconnect the air by-pass valve (A) and vacuum hose (B) from the air by-pass valve (C).
- 2) Remove the air by-pass valve (C) from the inter-cooler.



B: INSTALLATION


Install in the reverse order of removal.

NOTE:

- Use new O-rings.
- Be careful not to pinch the O-ring.

Tightening torque:

6.5 N·m (0.66 kgf·m, 4.8 ft·lb)



- (A) Air by-pass pipe
- (B) Vacuum hose
- (C) Air by-pass valve