

Battery Current & Temperature Sensor

STARTING/CHARGING SYSTEMS

5. Battery Current & Temperature Sensor


A: REMOVAL

1. BATTERY CURRENT SENSOR


NOTE:

Remove the battery current sensor and battery cable as a unit.

- 1) Disconnect the battery ground cable and remove the clip from the battery rod.
- 2) Remove the battery terminal boot.
- 3) Remove the nuts, and then remove the terminal fuse assembly.




- 4) Remove the ground terminal from the vehicle and remove the harness clip.



- 5) Disconnect the harness connector (A) from the battery cable.

Battery Current & Temperature Sensor


6) Remove the battery cable clip (B) from the battery cable bracket.



7) Remove the clip (A) from the air intake boot.

8) Loosen the clamp (B) connecting the air intake boot and air cleaner case (rear).


9) Loosen the clamp (C) which connects the air intake boot and throttle body.



Battery Current & Temperature Sensor


STARTING/CHARGING SYSTEMS

10) Remove the air intake boot from the throttle body, and move the air intake boot to the left side wheel apron.




11) Remove the terminal B (A) from the starter.

12) Remove the starter ground cable (B) and remove the battery cable.




2. BATTERY TEMPERATURE SENSOR

- 1) Remove the battery. <Ref. to SC(H4DO)-57, REMOVAL, Battery.>
- 2) Remove the clip, and remove the battery temperature sensor from the bracket.



- 3) Disconnect the connector and remove the battery temperature sensor.



B: INSTALLATION

1. BATTERY CURRENT SENSOR

Install in the reverse order of removal.

Tightening torque:

<Ref. to SC(H4DO)-7, BATTERY CURRENT & TEMPERATURE SENSOR, COMPONENT, General Description.>

2. BATTERY TEMPERATURE SENSOR

Install in the reverse order of removal.

Battery Current & Temperature Sensor

STARTING/CHARGING SYSTEMS

C: INSPECTION


1. BATTERY CURRENT SENSOR

CAUTION:

Pay attention to polarity when checking the resistance in the battery current sensor.

Check the resistance between the battery current sensor terminals.


Terminal No.	Standard
1 (+) and 2 (-)	3 — 10 k Ω
1 (+) and 3 (-)	0.5 k Ω or less
2 (+) and 3 (-)	3 — 10 k Ω



2. BATTERY TEMPERATURE SENSOR

Check the resistance between the battery temperature sensor terminals.

Temperature	Terminal No.	Standard
20 — 30°C (68 — 86°F)	1 and 2	1.5 — 2.8 k Ω



ENGINE (DIAGNOSTICS)

EN(H4DO)(diag)

	Page
1. Basic Diagnostic Procedure	2
2. Check List for Interview	4
3. General Description	6
4. Electrical Component Location	9
5. Engine Control Module (ECM) I/O Signal	19
6. Engine Condition Data	29
7. Data Link Connector	30
8. General Scan Tool	31
9. Subaru Select Monitor	36
10. Read Diagnostic Trouble Code (DTC)	42
11. Inspection Mode	43
12. Drive Cycle	48
13. Clear Memory Mode	57
14. System Operation Check Mode	58
15. Malfunction Indicator Light	59
16. Diagnostics for Engine Starting Failure	66
17. Diagnostic Procedure for Subaru Select Monitor Communication	80
18. List of Diagnostic Trouble Code (DTC)	82
19. Diagnostic Procedure with Diagnostic Trouble Code (DTC)	91
20. General Diagnostic Table	350