

Speedometer

INSTRUMENTATION/DRIVER INFO

6. Speedometer

A: SPECIFICATION

Since the meter - main assembly cannot be disassembled, do not remove or inspect the speedometer alone.
(Do not remove the cover on the back surface.)