

Fuel Gauge

INSTRUMENTATION/DRIVER INFO

8. Fuel Gauge

A: SPECIFICATION

Since the meter - main assembly cannot be disassembled, do not remove or inspect the fuel gauge alone.
(Do not remove the cover on the back surface.)