

31.Heat Shield Cover

A: NOTE

Refer to "EXHAUST" section for removal and installation procedure of the heat shield cover.