

## 4. Engine Control Module (ECM) I/O Signal

### A: ELECTRICAL SPECIFICATION

For details on the input/output signals for the engine control module, refer to ENGINE (DIAGNOSTICS).  
<Ref. to EN(H4DO)(diag)-19, ELECTRICAL SPECIFICATION, Engine Control Module (ECM) I/O Signal.>

### B: WIRING DIAGRAM

<Ref. to WI-61, WIRING DIAGRAM, Cruise Control System.>