

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

1. CHECK USING THE DTC CHECK SHEET

DTC check sheet

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | | | | | | | | | | | | | | | | | | | | | |
| HL | | | | | | | | | | | | | | | | | | | | | | | | |
| BIU | | | — | | | | | | | | | | | | | | | | | | | | | |
| MFD | | | — | — | | | | | | | | | | | | | | | | | | | | |
| A/C | | | | | | | | | | | | | | | | | | | | | | | | |
| MET | | | | | | | | | | | | | | | | | | | | | | | | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| TCM | | | | | | | | | | | | | | | | | | | | | | | | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| EPS | | | | | | | | | | | | | | | | | | | | | | | | |
| EGI | | | | | | | | | | | | | | | | | | | | | | | | |

LAN00923

(A) Installation check

(B) Bus off detection

(C) Data no-receive detection

(D) Data abnormal detection

VDC: VDC CM

BIU: Body integrated unit

MFD: High grade MFD

A/C: A/C control panel

MET: Combination meter

RST: Remote engine starter CM

STR: Steering angle sensor

TCM: TCM

A/B: AB CM

EPS: Power steering CM

EGI: ECM

HL: Auto headlight beam leveler CM

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

1) Module installation check

- (1) Write “-” marks in the field for installation check if the vehicle to be inspected does not have relevant module.
- (2) Write “-” marks in all blank fields on the same row that the “-” mark has filled in.

2) Buss off detection / data not received

NOTE:

It becomes impossible for CAN diagnostic module to read DTC, if there is a current malfunction of open harness (data not received). If this occurs, perform the “Check using the check sheet of communication for initializing” <Ref. to LAN(diag)-11, CHECK USING THE CHECK SHEET OF COMMUNICATION FOR INITIALIZING, COMMUNICATION FOR INITIALIZING IMPOSSIBLE, Subaru Select Monitor.>, and use this sheet to confirm that the corresponding part becomes the past malfunction.

- (1) Mark “X” in the field corresponding to the DTCs that has been detected by each module in the check sheet.
- (2) Identify and repair the faulty part by referring to the example of DTC data not received and the DTC matrix. <Ref. to LAN(diag)-54, EXAMPLE OF DTC DATA NOT RECEIVED, LIST, List of Diagnostic Trouble Code (DTC).> <Ref. to LAN(diag)-60, DTC MATRIX, LIST, List of Diagnostic Trouble Code (DTC).>

3) Data abnormal detection

NOTE:


If the buss off occurs or data is not received, perform the diagnosis for these problems first.

- (1) If several modules detect the DTC for the same module, replace the detected module.
- (2) If one module detects the DTC, replace the module of the detected side.
- (3) If it does not return to the normal operation, re-install the module which has been replaced, and replace the module of the detected side.
- (4) If it does not return to the normal operation, replace both modules.

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

2. EXAMPLE OF DTC DATA NOT RECEIVED



LAN00910

When ④ (main wiring harness between combination meter and steering angle sensor) is open

| | (A) | (B) | (C) | | | | | | | | | | | (D) | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| HL | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| BIU | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| MFD | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| A/C | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| MET | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| RST | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| STR | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| TCM | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| A/B | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| EPS | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| EGI | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |

LAN00924

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

When ⑤ (main wiring harness between steering angle sensor and airbag CM) is open

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| HL | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| MET | | | — | — | — | — | — | — | — | X | X | X | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | X | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | X | — | — | — | X | — | — | X | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00925

When ⑥ (main wiring harness between airbag CM and power steering CM) is open

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| HL | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| MET | | | — | — | — | — | — | — | — | — | X | X | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | — | — | — | — | — | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | X | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | X | — | — | — | X | — | — | X | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00926

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

When ⑦ (ECM vicinity) is open

NOTE:

If bus off occurs, ECM displays only the DTC that indicates bus off. However, other no-receive errors may occur depending on the judgment timing.

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | | — | — | — | | | — | — | X | — | | — | — | — | — | | | — | — | | |
| HL | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | | — | — | | | | | — | — | X | | | — | — | | | | | — | — | | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | | | — | — | | | | — | — | X | | | — | — | | | | | — | — | | |
| MET | | | | | | — | — | — | | | | X | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | | | | | | | | | | X | | | — | — | | | | | — | — | | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | X | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00927

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

When ⑫ (remote engine start CM vicinity) is open

NOTE:

No DTC remains, and the remote engine starter does not function.

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | | — | — | — | — | | — | — | | — | | — | — | — | — | | — | — | — | | |
| HL | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MET | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00923

When ⑬ (steering angle sensor vicinity) is open

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| HL | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MET | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00966

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

When ⑭ (TCM vicinity) is open

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| HL | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MET | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | X | X | — | — | X | — | — | — | — | — | X | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00967

When ⑮ (airbag CM vicinity) is open

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| HL | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| BIU | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/C | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| MET | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| TCM | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EPS | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |
| EGI | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | |

LAN00968

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

When ⑩ (power steering CM vicinity) is open

NOTE:

Power steering CM may display U1120 (AUTO START STOP COMMUNICATION LOST).

| | (A) | (B) | (C) | | | | | | | | | | (D) | | | | | | | | | | | |
|-----|-----|-----|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-----|-------|-------|-------|-------|
| | | | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI | VDC | BIU | MFD | A/C | MET | RST | STR | TCM | A/B | EPS | EGI |
| | | | U0073 | U0122 | U0140 | U0156 | U0164 | U0155 | — | U0126 | U0101 | U0151 | U0131 | U0100 | U0416 | U0422 | U0457 | U0424 | U0423 | — | U0428 | U0402 | U0452 | U0420 |
| VDC | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| HL | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| BIU | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| MFD | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| A/C | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| MET | | | | — | — | — | — | — | — | — | × | — | — | — | — | — | — | — | — | — | — | — | — | — |
| RST | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| STR | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| TCM | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| A/B | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| EPS | | | × | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |
| EGI | | | | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — | — |

LAN00969

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

3. DTC MATRIX

NOTE:

Perform the following procedure when using this chart in which the detailed trouble mode corresponds to the trouble status.

1. Search the trouble mode that corresponds to the vehicle status from the chart.
2. Perform the repair that corresponds to the trouble mode.

| Control module (which module vicinity) | | Trouble mode 1 | Trouble mode 2 | Trouble mode 3 | Trouble mode 4 | Trouble mode 5 | ... | ... | Trouble mode n |
|--|----------------------|------------------|------------------|------------------|------------------|------------------|-----|-----|------------------|
| Detailed location (which location) | | | | | | | | | |
| Detailed trouble mode (What kind) | | | | | | | | | |
| Trouble status (trouble exists/trouble existed) | | | | | | | | | |
| DTC reading result from each module using Subaru Select Monitor | VDC CM | Vehicle status 1 | Vehicle status 2 | Vehicle status 3 | Vehicle status 4 | Vehicle status 5 | ... | ... | Vehicle status n |
| | Body integrated unit | | | | | | | | |
| | Combination meter | | | | | | | | |
| | MFD | | | | | | | | |
| | A/C control panel | | | | | | | | |
| | TCM | | | | | | | | |
| | ... | | | | | | | | |
| | ECM | | | | | | | | |
| Indicators illuminate/blink. | | | | | | | | | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

1. Hi-side circuit of CAN communication circuit is open.

NOTE:

- If the module has a limit of DTC memory and the number of DTC occurrence exceeds the limit, older DTCs are preferentially stored.
- When there is no description in Current, it is referred to as “None”.
- When DTC is in parentheses, it is referred to as “Not always occur”.
- “Trouble exists” is referred to as the status before performing inspection and repair. “Trouble existed” is referred to as the status before performing DTC clear after repair.

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|------------------------------------|-------------------------------------|---|---|---|---|---|-------------------------------------|---|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Communication failure | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0073 U0100 U0101 U0126 U0140 Past U0101 U0126 U0140 | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0100 U0101 U0126 Past Same as above | Current C1431 Past C1431 U0100 U0101 U0126 | Current None Past None | Current None Past None |
| | Body integrated unit ^{*2} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Current U0100 U0101 U0155 U0164 U1201 Past Same as above | Past U0100 U0101 U0155 U0164 U1201 | Current U0155 Past Same as above | Past U0155 |
| | Combination meter ^{*3} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Communication failure | Past U0073 U0100 U0101 U0122 U0131 U0140 U0151 U0164 Any 5 item from above |
| | MFD ^{*4} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Past U1650 | Current None Past None | Current None Past None |
| | A/C control panel ^{*5} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|--|--|----------------------------------|--|--|---|--|---|---------------------------------|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | TCM ^{*1} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |
| | A/B CM ^{*6} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Current None Past None | Current None Past None | Current None Past None |
| | Electric power steering CM ^{*7} | Current U0122 Latest Same as above | Current None Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current None Latest None | Current None Latest None |
| | ECM ^{*1} | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current U0122 Past Same as above | Past U0122 | Current U0155 Past Same as above | Past U0155 |
| | Auto headlight beam leveler CM ^{*6} | Current U0122 Past Same as above | Past U0122 | Current U0140 Past Same as above | Past U0140 | Current None Past None | Current None Past None | Current None Past None | Current None Past None |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|------------------------------|---|--|---|--|---|--|--|---|
| Detailed location | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| Indicators illuminate/blink. | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, ABS, VDC off, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. SPORTS illuminates. TPMS blinks → illuminates. AT OIL TEMP, CRUISE blink. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, A/B illuminate. Below are the items that illuminate intermittently. (Cycles are erratic.) VDC Off, ABS, EMPTY, BRAKE Below are the items that blink intermittently. Engine coolant temperature gauge (blue/red) blinks, AT OIL TEMP, CRUISE, Fuel gauge | CHECK ENGINE, VDC illuminate. CRUISE blink |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|------------------------------------|-----------------------|------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------|------------------|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current U0126 | Past U0126 | Current U0101 | Current C1431 |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past Same as above | Past C1431 U0101 |
| | Body integrated unit ^{*2} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past Same as above | | Past None | Past None | Past Same as above | |
| | Combination meter ^{*3} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | | Past None | Past None | Past Same as above | |
| | MFD ^{*4} | Communication failure | Past U1201 U0073 | Current None | Current None | Current None | Current None | Current None | Current None |
| | | | | Past None | Past None | Past None | Past None | Past None | Past None |
| | A/C control panel ^{*5} | Current None | Current None | Communication failure | Past U0100 U0155 | Current None | Current None | Current U0101 | Past U0101 |
| Past None | | Past None | | | Past None | Past None | Past Same as above | | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Communication failure | Past U0100 U0122 U0140 U0155 | |
| | Past None | Past None | Past None | Past None | Past None | Past None | | | |
| A/B CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |
| Electric power steering CM ^{*7} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|--|------------------|------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------------|------------------------------------|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | ECM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past Same as above | |
| | Auto headlight beam leveler CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| Indicators illuminate/blink. | | No change | No change | No change | No change | VDC, ABS illuminate. | No change | CHECK ENGINE, VDC, ABS illuminate. | CHECK ENGINE, VDC, ABS illuminate. |
| | | No change in MFD | No change in MFD | | | | | CRUISE blink | CRUISE blink |
| | | | | | | | | Shift indicator goes off. | |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
|---|-----------------------------------|--------------------|-----------------|-------------------------------------|-------------------------------------|-----------------------|--------------------|---|---|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current C1431 U0100 | Current C1431 | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | Past C1431 U0100 | Past None | Past None |
| | Body integrated unit ² | Current None | Current None | Current None | Current None | Current U0100 (U1201) | Past U0100 (U1201) | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None |
| | Combination meter ^{*3} | Current U0151 | Past U0151 | Current U0131 | Past U0131 | Current U0100 (U0073) | Past U0100 (U0073) | Current None | Current None |
| | | Past Same as above | | Past Same as above | | Past Same as above | | Past None | Past None |
| | MFD ^{*4} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| A/C control panel ^{*5} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| A/B CM ^{*6} | Communication failure | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
|---|--|-------------------------------|-------------------------------|--|--|--|--|---|--|
| Detailed location | | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side | Hi side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | Electric power steering CM ^{*7} | Current None Latest None | Current None Latest None | Current U1120 ^{*9} U0122 C2543 Any 1 item from above Latest U0122 C2543 (U1120 ^{*9}) | Latest U0122 C2543 (U1120 ^{*9}) | Current C2543 U0073 None or any 1 item from above Latest C2543 U0073 | Latest C2543 U0073 | Current None Past None | Current None Past None |
| | ECM ^{*1} | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current U0073 Past Same as above | Past U0073 | Current None Past None | Current None Past None |
| | Auto headlight beam leveler CM ^{*6} | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Communication failure Past U0122 U0140 |
| Indicators illuminate/blink. | | A/B illuminates. | No change | No change | No change | VDC, ABS, CHECK ENGINE, EMPTY illuminate. AT OIL TEMP blinks. Engine coolant temperature gauge (blue/red) blinks. Fuel gauge goes off. Tachometer: 0 rpm | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | Headlight beam leveler indicator illuminates. | No change |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

*9: When this code is displayed, perform the diagnosis as COMMUNICATION MALFUNCTION (METER ECU) (U0155). DTC that occurs in "Current" is displayed in top of the "Latest" list.

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

2. Lo-side circuit of CAN communication circuit is open.

NOTE:

- If the module has a limit of DTC memory and the number of DTC occurrence exceeds the limit, older DTCs are preferentially stored.
- When there is no description in Current, it is referred to as “None”.
- When DTC is in parentheses, it is referred to as “Not always occur”.
- “Trouble exists” is referred to as the status before performing inspection and repair. “Trouble existed” is referred to as the status before performing DTC clear after repair.

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|------------------------------------|---|---|---|---|---|---|---|---|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Communication failure | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0073 U0100 U0101 U0126 U0140 Past U0101 U0126 U0140 | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0100 U0101 U0126 Past Same as above | Current C1431 Past C1431 U0100 U0101 U0126 | Current None Past None | Current None Past None |
| | Body integrated unit ^{*2} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Current U0100 U0101 U0155 U0164 (U1201) Past Same as above | Past U0100 U0101 U0155 U0164 (U1201) | Current U0155 Past Same as above | Past U0155 |
| | Combination meter ^{*3} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Communication failure | Past U0073 U0100 U0101 U0122 U0131 U0140 U0151 U0164 Any 5 item from above |
| | MFD ^{*4} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Past U1650 | Current (U1650) (U1201) Past Same as above | Past (U1650) (U1201) |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|--|---|----------------------------------|---|--|---|--|---|---|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | A/C control panel ^{*5} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |
| | TCM ^{*1} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |
| | A/B CM ^{*6} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Current None Past None | Current None Past None | Current None Past None |
| | Electric power steering CM ^{*7} | Current U0122 Latest Same as above | Current None Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current (C2543) Latest Same as above | Current (C2544) Latest (C2543) (C2544) |
| | ECM ^{*1} | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current U0122 Past Same as above | Past U0122 | Current U0155 Past Same as above | Past U0155 |
| | Auto headlight beam leveler CM ^{*6} | Current U0122 Past Same as above | Past U0122 | Current U0140 Past Same as above | Past U0140 | Current None Past None | Current None Past None | Current None Past None | Current None Past None |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|------------------------------|---|--|---|--|---|--|---|---|
| Detailed location | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| Indicators illuminate/blink. | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, ABS, VDC off, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. SPORTS illuminates. TPMS blinks → illuminates. AT OIL TEMP, CRUISE blink. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, A/B, BRAKE, VDC, EMPTY, VDC OFF, ABS illuminate. Engine coolant temperature gauge (blue/red) blinks. TPMS blinks → illuminates. Shift indicator goes off. Fuel level warning indicator goes off. Tachometer: 0 rpm | CHECK ENGINE, VDC illuminate. CRUISE blink |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|------------------------------------|-----------------------|------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------|------------------|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current U0126 | Past U0126 | Current U0101 | Current C1431 |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past Same as above | Past C1431 U0101 |
| | Body integrated unit ^{*2} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past Same as above | | Past None | Past None | Past Same as above | |
| | Combination meter ^{*3} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | | Past None | Past None | Past Same as above | |
| | MFD ^{*4} | Communication failure | Past U1201 U0073 | Current None | Current None | Current None | Current None | Current None | Current None |
| | | | | Past None | Past None | Past None | Past None | Past None | Past None |
| | A/C control panel ^{*5} | Current None | Current None | Communication failure | Past U0100 U0155 | Current None | Current None | Current U0101 | Past U0101 |
| Past None | | Past None | | | Past None | Past None | Past Same as above | | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Communication failure | Past U0100 U0122 U0140 U0155 | |
| | Past None | Past None | Past None | Past None | Past None | Past None | | | |
| A/B CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |
| Electric power steering CM ^{*7} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|--|------------------|------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------------|------------------------------------|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | ECM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past Same as above | |
| | Auto headlight beam leveler CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| Indicators illuminate/blink. | | No change | No change | No change | No change | VDC, ABS illuminate. | No change | CHECK ENGINE, VDC, ABS illuminate. | CHECK ENGINE, VDC, ABS illuminate. |
| | | No change in MFD | No change in MFD | | | | | CRUISE blink | CRUISE blink |
| | | | | | | | | Shift indicator goes off. | |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
|---|-----------------------------------|--------------------|-----------------|-------------------------------------|-------------------------------------|-----------------------|--------------------|---|---|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current C1431 U0100 | Current C1431 | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | Past C1431 U0100 | Past None | Past None |
| | Body integrated unit ² | Current None | Current None | Current None | Current None | Current U0100 (U1201) | Past U0100 (U1201) | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None |
| | Combination meter ^{*3} | Current U0151 | Past U0151 | Current U0131 | Past U0131 | Current U0100 (U0073) | Past U0100 (U0073) | Current None | Current None |
| | | Past Same as above | | Past Same as above | | Past Same as above | | Past None | Past None |
| | MFD ^{*4} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| A/C control panel ^{*5} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| A/B CM ^{*6} | Communication failure | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
|---|--|-------------------------------|-------------------------------|--|--|--|--|---|--|
| Detailed location | | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side | Lo side |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | Electric power steering CM ^{*7} | Current None Latest None | Current None Latest None | Current U1120 ^{*9} U0122 C2543 Any 1 item from above Latest U0122 C2543 (U1120 ^{*9}) | Latest U0122 C2543 (U1120 ^{*9}) | Current C2543 U0073 None or any 1 item from above Latest C2543 U0073 | Latest C2543 U0073 | Current None Past None | Current None Past None |
| | ECM ^{*1} | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current U0073 Past Same as above | Past U0073 | Current None Past None | Current None Past None |
| | Auto headlight beam leveler CM ^{*6} | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Communication failure Past U0122 U0140 |
| Indicators illuminate/blink. | | A/B illuminates. | No change | No change | No change | VDC, ABS, CHECK ENGINE, EMPTY illuminate. AT OIL TEMP blinks. Engine coolant temperature gauge (blue/red) blinks. Fuel gauge goes off. Tachometer: 0 rpm | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | Headlight beam leveler indicator illuminates. | No change |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

*9: When this code is displayed, perform the diagnosis as COMMUNICATION MALFUNCTION (METER ECU) (U0155). DTC that occurs in "Current" is displayed in top of the "Latest" list.

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

3. Hi/Lo-side circuit of CAN communication circuit is open.

NOTE:

- If the module has a limit of DTC memory and the number of DTC occurrence exceeds the limit, older DTCs are preferentially stored.
- When there is no description in Current, it is referred to as “None”.
- When DTC is in parentheses, it is referred to as “Not always occur”.
- “Trouble exists” is referred to as the status before performing inspection and repair. “Trouble existed” is referred to as the status before performing DTC clear after repair.

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|------------------------------------|-------------------------------------|---|---|---|---|---|-------------------------------------|---|
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Communication failure | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0073 U0100 U0101 U0126 U0140 Past U0101 U0126 U0140 | Current C1431 Past C1431 U0073 U0100 U0101 U0126 U0140 | Current U0100 U0101 U0126 Past Same as above | Current C1431 Past C1431 U0100 U0101 U0126 | Current None Past None | Current None Past None |
| | Body integrated unit ^{*2} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Current U0100 U0101 U0155 U0164 Past Same as above | Past U0100 U0101 U0155 U0164 | Current U0155 Past Same as above | Past U0155 |
| | Combination meter ^{*3} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Communication failure | Past U0073 U0100 U0101 U0122 U0131 U0140 U0151 U0164 Any 5 item from above |
| | MFD ^{*4} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Past U1650 | Current U1650 Past Same as above | Past U1650 |
| | A/C control panel ^{*5} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|---|--|--|----------------------------------|--|--|---|--|---|---------------------------------|
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | TCM ^{*1} | Current U0122 Past Same as above | Past U0122 | Communication failure | Past U0122 | Communication failure | Past U0122 U0140 | Current U0155 Past Same as above | Past U0155 |
| | A/B CM ^{*6} | Current None Past None | Current None Past None | Communication failure | Current None Past None | Communication failure | Current None Past None | Current None Past None | Current None Past None |
| | Electric power steering CM ^{*7} | Current U0122 Latest Same as above | Current None Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current U0122 Latest Same as above | Latest U0122 | Current None Latest None | Current None Latest None |
| | ECM ^{*1} | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current P0700 U0122 Past Same as above | Past P0700 U0122 | Current U0122 Past Same as above | Past U0122 | Current U0155 Past Same as above | Past U0155 |
| | Auto headlight beam leveler CM ^{*6} | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | VDC CM vicinity | VDC CM vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (VDC side) vicinity | Body integrated unit (EGI side) vicinity | Body integrated unit (EGI side) vicinity | Combination meter vicinity | Combination meter vicinity |
|------------------------------|---|--|---|--|---|--|---|---|
| Detailed location | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| Indicators illuminate/blink. | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, ABS, VDC off, BRAKE illuminate. AT OIL TEMP, CRUISE blink. Headlight beam leveler indicator illuminates. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, VDC, VDC off, ABS, BRAKE illuminate. SPORTS illuminates. TPMS blinks → illuminates. AT OIL TEMP, CRUISE blink. | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | CHECK ENGINE, A/B, BRAKE, VDC, EMPTY, VDC OFF, ABS illuminate. Engine coolant temperature gauge (blue/red) alternately blinks. TPMS blinks → illuminates. Shift indicator goes off. Fuel level warning indicator goes off. Tachometer: 0 rpm | CHECK ENGINE, VDC illuminate. CRUISE blink |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|------------------------------------|-----------------------|--------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------|------------------|
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current U0126 | Past U0126 | Current U0101 | Current C1431 |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past Same as above | Past C1431 U0101 |
| | Body integrated unit ^{*2} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past Same as above | | Past None | Past None | Past Same as above | |
| | Combination meter ^{*3} | Current None | Current None | Current U0164 | Past U0164 | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | | Past None | Past None | Past Same as above | |
| | MFD ^{*4} | Communication failure | Past U1201 (U0073) | Current None | Current None | Current None | Current None | Current None | Current None |
| | | | | Past None | Past None | Past None | Past None | Past None | Past None |
| | A/C control panel ^{*5} | Current None | Current None | Communication failure | Past U0100 U0155 | Current None | Current None | Current U0101 | Past U0101 |
| Past None | | Past None | | | Past None | Past None | Past Same as above | | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Communication failure | Past U0100 U0122 U0140 U0155 | |
| | Past None | Past None | Past None | Past None | Past None | Past None | | | |
| A/B CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |
| Electric power steering CM ^{*7} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | Latest None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | MFD vicinity | MFD vicinity | A/C control panel vicinity | A/C control panel vicinity | Steering angle sensor vicinity | Steering angle sensor vicinity | AT CM vicinity | AT CM vicinity |
|---|--|------------------|------------------|----------------------------|----------------------------|--------------------------------|--------------------------------|------------------------------------|------------------------------------|
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | ECM ^{*1} | Current None | Current None | Current None | Current None | Current None | Current None | Current U0101 | Past U0101 |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past Same as above | |
| | Auto headlight beam leveler CM ^{*6} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| Indicators illuminate/blink. | | No change | No change | No change | No change | VDC, ABS illuminate. | No change | CHECK ENGINE, VDC, ABS illuminate. | CHECK ENGINE, VDC, ABS illuminate. |
| | | No change in MFD | No change in MFD | | | | | CRUISE blink | CRUISE blink |
| | | | | | | | | Shift indicator goes off. | |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
|---|-----------------------------------|--------------------|---|---|---|-----------------------|--------------------|---|---|
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Current None | Current None | Current None | Current None | Current C1431 U0100 | Current C1431 | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | Past C1431 U0100 | Past None | Past None |
| | Body integrated unit ² | Current None | Current None | Current None | Current None | Current U0100 (U1201) | Past U0100 (U1201) | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None |
| | Combination meter ^{*3} | Current U0151 | Past U0151 | Current U0131 | Past U0131 | Current U0100 | Past U0100 | Current None | Current None |
| | | Past Same as above | | Past Same as above | | Past Same as above | | Past None | Past None |
| | MFD ^{*4} | Current None | Current None | Current None | Current None | Current None | Current None | Current None | Current None |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | Past None |
| | A/C control panel ^{*5} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None |
| Past None | | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| TCM ^{*1} | Current None | Current None | Current None | Current None | Current U0100 | Past U0100 | Current None | Current None | |
| | Past None | Past None | Past None | Past None | Past Same as above | | Past None | Past None | |
| A/B CM ^{*6} | Communication failure | Current None | Current None | Current None | Current None | Current None | Current None | Current None | |
| | | Past None | Past None | Past None | Past None | Past None | Past None | Past None | |
| Electric power steering CM ^{*7} | Current None | Current None | Current U1120 ^{*9} U0122 C2543 Any 1 item from above | Latest U0122 C2543 (U1120 ^{*9}) | Current C2543 U0073 None or any 1 item from above | Latest C2543 U0073 | Current None | Current None | |
| | Latest None | Latest None | Latest U0122 C2543 (U1120 ^{*9}) | | Latest C2543 U0073 | | Past None | Past None | |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| | | | | | | | | | |
|---|----------------------------------|---------------------------|---------------------------|-------------------------------------|-------------------------------------|--|--|---|---|
| Control module | | A/B CM vicinity | A/B CM vicinity | Electric power steering CM vicinity | Electric power steering CM vicinity | ECM vicinity | ECM vicinity | Auto headlight beam leveler CM vicinity | Auto headlight beam leveler CM vicinity |
| Detailed location | | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides | Both sides |
| Detailed trouble mode | | Open | Open | Open | Open | Open | Open | Open | Open |
| Trouble status | | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed | Trouble exists | Trouble existed |
| DTC reading result from each module using Subaru Select Monitor | ECM*1 | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current U0073 Past Same as above | Past U0073 | Current None Past None | Current None Past None |
| | Auto headlight beam leveler CM*6 | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Current None Past None | Communication failure | Past U0122 U0140 |
| Indicators illuminate/blink. | | A/B illuminates. | No change | No change | No change | VDC, ABS, CHECK ENGINE, EMPTY illuminate. AT OIL TEMP blinks. Engine coolant temperature gauge (blue/red) blinks. Fuel gauge goes off. Tachometer: 0 rpm | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | Headlight beam leveler indicator illuminates. | No change |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

*9: When this code is displayed, perform the diagnosis as COMMUNICATION MALFUNCTION (METER ECU) (U0155). DTC that occurs in "Current" is displayed in top of the "Latest" list.

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

4. Power supply-output short, GND-output short and short circuit in CAN communication circuit

NOTE:

- If the module has a limit of DTC memory and the number of DTC occurrence exceeds the limit, older DTCs are preferentially stored.
- When there is no description in Current, it is referred to as “None”.
- When DTC is in parentheses, it is referred to as “Not always occur”.
- “Trouble exists” is referred to as the status before performing inspection and repair. “Trouble existed” is referred to as the status before performing DTC clear after repair.

| Control module ^{*10} | | Option | Option | Option | Option | Option | Option | Option | Option |
|---|------------------------------------|-----------------------|---------------------------|---------------|---|---------------------------|---------------|-------------------------------------|---|
| Detailed location | | Hi side | Lo side | Hi to Low | Hi side | Lo side | Hi to Low | Lo side | Hi side |
| Detailed trouble mode | | GND-output short | Power supply-output short | Short circuit | GND-output short | Power supply-output short | Short circuit | GND-output short ^{*9} | Power supply-output short ^{*9} |
| Trouble status | | Trouble exists | ← | ← | Trouble existed | ← | ← | Trouble exists/ Trouble existed | ← |
| DTC reading result from each module using Subaru Select Monitor | VDC CM ^{*1*8} | Communication failure | ← | ← | Current C1431 None or 1 item from above Past U0073 C1431 (U0126) | ← | ← | Current None Past None | ← |
| | Body integrated unit ^{*2} | Communication failure | ← | ← | Past U0073 U0100 U0101 U0122 U0155 U0164 U1201 | ← | ← | Current None Past None | ← |
| | Combination meter ^{*3} | Communication failure | ← | ← | Past U0073 U0100 U0101 U0122 U0131 U0140 U0151 U0164 Any 5 item from above | ← | ← | Current None Past None | ← |
| | MFD ^{*4} | Communication failure | ← | ← | Past U0073 U1201 U1650 Any 1 to 2 items from above | ← | ← | Current None Past None | ← |
| | A/C control panel ^{*5} | Communication failure | ← | ← | Past U0073 | ← | ← | Current None Past None | ← |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module ^{*10} | | Option | Option | Option | Option | Option | Option | Option | Option |
|---|--|--|---------------------------|---------------|---|---------------------------|---------------|---------------------------------------|---|
| Detailed location | | Hi side | Lo side | Hi to Low | Hi side | Lo side | Hi to Low | Lo side | Hi side |
| Detailed trouble mode | | GND-output short | Power supply-output short | Short circuit | GND-output short | Power supply-output short | Short circuit | GND-output short ^{*9} | Power supply-output short ^{*9} |
| Trouble status | | Trouble exists | ← | ← | Trouble existed | ← | ← | Trouble exists/ Trouble existed | ← |
| DTC reading result from each module using Subaru Select Monitor | TCM ^{*1} | Communication failure | ← | ← | Past U0073 U0100 U0122 U0140 U0155 | ← | ← | Current None Past None | ← |
| | A/B CM ^{*6} | Communication failure | ← | ← | Past U0073 | ← | ← | Current None Past None | ← |
| | Electric power steering CM ^{*7} | Current U0073 U0122 C2543 Any 1 item from above Latest All items above | ← | ← | Latest U0073 U0122 C2543 | ← | ← | Current None Latest None | ← |
| | ECM ^{*1} | Current U0073 U0122 U0155 None or any 1 to 4 items from above Past Same as above | ← | ← | Past U0073 U0101 U0122 U0155 None or any 1 to 4 items from above | ← | ← | Current None Past None | ← |
| | Auto headlight beam leveler CM ^{*6} | Communication failure | ← | ← | Past U0140 U0122 | ← | ← | Current None Past None | ← |

List of Diagnostic Trouble Code (DTC)

LAN SYSTEM (DIAGNOSTICS)

| Control module ^{*10} | Option | Option | Option | Option | Option | Option | Option | Option |
|-------------------------------|--|---------------------------|---------------|--|---------------------------|---------------|------------------------------------|---|
| Detailed location | Hi side | Lo side | Hi to Low | Hi side | Lo side | Hi to Low | Lo side | Hi side |
| Detailed trouble mode | GND-output short | Power supply-output short | Short circuit | GND-output short | Power supply-output short | Short circuit | GND-output short ^{*9} | Power supply-output short ^{*9} |
| Trouble status | Trouble exists | ← | ← | Trouble existed | ← | ← | Trouble exists/ Trouble existed | ← |
| Indicators illuminate/blink. | CHECK ENGINE, A/B, BRAKE, VDC, EMPTY, VDC OFF, ABS illuminate. Headlight beam level indicator illuminates. Engine coolant temperature gauge (blue/red) alternately blinks. TPMS blinks → illuminates. Shift indicator goes off. Fuel level warning indicator goes off. Tachometer: 0 rpm | ← | ← | CHECK ENGINE, VDC, ABS illuminate. CRUISE blink | ← | ← | No change | ← |

*1: When U0073 occurs, other U-codes are not stored. (Judge timing affects the storing order.)

*2: The number of DTC memory is limited to 8 items. (Older items are preferentially stored.)

*3: The number of DTC memory is limited to 5 items. (Older items are preferentially stored.)

*4: The number of DTC memory is limited to 2 items. (Older items are preferentially stored.)

*5: All types of DTCs can be simultaneously stored. When U0073 occurs, other U-codes are not displayed.

*6: All types of DTCs can be simultaneously stored.

*7: The number of DTC memory is limited to 1 item for Current and 3 items for Latest.

*8: If C1431 contains a current malfunction after repair, perform IGN OFF → ON. (It remains immediately after repair.)

*9: This can only be detected by inspection using a tester.

*10: In this trouble mode, a faulty portion can only be identified by inspection using a tester.