

### 14.Drain Valve

#### A: SPECIFICATION

Canister is a non-disassembled part, so do not remove the drain valve from canister.

Refer to “Canister” for removal and installation procedures. <Ref. to EC(H4SO)-5, REMOVAL, Canister.> <Ref. to EC(H4SO)-5, INSTALLATION, Canister.>