

# General Diagnostic Table

## POWER ASSISTED SYSTEM (POWER STEERING)

### 1. NOISE AND VIBRATION

#### CAUTION:

**Do not keep the relief valve operated for five seconds or more at any time or inner parts of the oil pump may be damaged due to rapid increase of fluid temperature.**

#### NOTE:

- A screeching noise may be heard immediately after the engine start in extremely cold conditions. In this case, if the noise goes off during warm up there is no abnormal function in the system. This is due to the fluid characteristics in extremely cold condition.
- The oil pump normally makes a small whining noise due to its mechanism. Even if a noise is heard when steering wheel is turned at stand still, there is no abnormal function in the system provided that the noise eliminates when the vehicle is driving.
- When turning the steering wheel with the brake applied when the vehicle is parked, a screeching noise may be generated by the brake disc and pads. This is not a fault in the steering system.
- There may be a small vibration around the steering devices when turning the steering wheel at standstill, even though the component parts are operating properly.

Hydraulic systems are likely to generate this kind of vibration as well as working noise and fluid noise because of combined conditions, i.e., road surface and tire surface, engine speed and turning speed of steering wheel, fluid temperature and braking condition.

These conditions do not indicate a problem in the system.

Confirm vibration for an AT model, by applying the parking brake on a concrete surface, shifting into the "D" range, and turning the steering wheel repeatedly from slow to rapid, step by step.

Trouble	Possible cause	Corrective action
Hiss noise (continuous) While engine is running.	Relief valve emits operating sound when steering wheel is completely turned in either direction. (Do not keep this condition for 5 seconds or more.)	Normal
	Relief valve emits operating sound when steering wheel is not turned. This means that the relief valve is defective.	Replace the oil pump.
Rattling noise (intermittent) While engine is running.	Interference with adjacent parts	Check the parts for deformation. Replace or adjust if necessary.
	Loosened installation of oil pump, oil tank, pump bracket, gearbox or crossmember	Retighten.
	Loose oil pump pulley or other pulley(s)	Retighten.
	Looseness of linkage, play of steering, improper tightening (looseness) of suspension joint or steering column	Retighten or replace.
	Sound generates from the inside of gearbox or oil pump.	Replace faulty parts in the gearbox or oil pump.
Knocking When turning steering wheel in both directions with small angle repeatedly at engine ON or OFF.	Excessive backlash Loosened lock nut for adjusting backlash	Adjust and retighten.
	Insufficient tightening or play in the tie-rod or tie-rod end	Retighten or replace.
Grinding noise (continuous) While engine is running.	Air in vane pump	Inspect and retighten the fluid line connection. Refill the fluid and vent air.
	Vane pump seizing	Replace the oil pump.
	Oil pump pulley bearing seized	Replace the oil pump.
	Folded hose, flattened pipe	Replace.
Squeal, squeak (intermittent or continuous) While engine is running.	Improper adjustment of pulley belt Damaged or over tensioned pulley belt Unequal length of pulley belts	Adjust or replace.
	Runout or dirty V-groove surface of oil pump pulley	Clean or replace.

# General Diagnostic Table

## POWER ASSISTED SYSTEM (POWER STEERING)

Trouble	Possible cause	Corrective action
Sizzling noise (continuous) While engine is running.	Fluid aeration	Fix the faulty part causing aeration. Replace the fluid and vent air.
	Damaged pipe of gearbox	Replace the pipe.
	Faulty inside of hose or pipe Flattened hose or pipe	Repair or replace.
	Abnormal inside of oil tank	Replace.
	Removed oil tank cap	Install cap.
Whistle (continuous) While engine is running.	Faulty pipe of gearbox or faulty hose	Replace the faulty parts of the gearbox or the hose.
Whine or growl (intermittent or continuous) While engine is running with/ without steering turned.	Looseness of oil pump, oil pump bracket attachment	Retighten.
	Fault inside of oil pump or hose	Replace the oil pump or hose, if the noise can be heard when vehicle is running as well as being stopped.
	Torque converter growl, air conditioner compression growl	Remove the power steering pulley belt and check.
Grinding noise (continuous) When engine operates (when operating steering wheel)	Fault inside of gearbox	Replace the faulty parts of gearbox.
	Faulty steering shaft bearing	Apply grease or replace.
	Occurs when turning the steering wheel with brakes (service or parking) applied.	If the noise goes off when brake is released, it is normal.
Vibration While engine is running with/ without steering turned.	Engine speed is too low.	Adjust, and notify customer.
	Air in vane pump	Repair faulty part Vent air.
	Damaged valve in oil pump or gearbox	Replace the faulty parts in gearbox and oil pump.
	Excessive play in steering, looseness of suspension parts	Retighten.

# General Diagnostic Table

## POWER ASSISTED SYSTEM (POWER STEERING)

### 2. MEASUREMENT OF STEERING EFFORT

Step	Check	Yes	No
<p><b>1 CHECK STEERING EFFORT.</b>                      1) Stop the vehicle on paved road.                      2) Start the engine.                      3) Run the engine at idle.                      4) Install a spring scale on the steering wheel.                      5) Pull the spring scale at a right angle to the steering wheel, and measure both right and left steering wheel efforts.</p> <div style="text-align: right; margin-top: 10px;">PS-01008</div>	<p>Is the steering effort less than 29.4 N (3.0 kgf, 6.6 lbf)?</p>	<p>Steering effort is normal. (Finish the diagnosis)</p>	<p>Go to step 2.</p>
<p><b>2 CHECK STEERING EFFORT.</b>                      1) Stop the engine and lift it up.                      2) Pull the spring scale at a right angle to the steering wheel, and measure both right and left steering wheel efforts.</p>	<p>Is the steering effort less than 19 N (1.9 kgf, 4.3 lbf)?</p>	<p>Go to step 3.</p>	<p>Perform the backlash adjustment.</p>
<p><b>3 CHECK STEERING WHEEL EFFORT.</b>                      1) Remove the universal joint.                      2) Measure the steering wheel effort.</p>	<p>Is the steering effort less than 2.26 N (0.23 kgf, 0.51 lbf)?</p>	<p>Go to step 4.</p>	<p>Replace the steering column.</p>
<p><b>4 CHECK STEERING WHEEL EFFORT.</b>                      Measure the steering wheel effort.</p>	<p>Is the difference of steering effort between right and left less than 20%?</p>	<p>Go to step 5.</p>	<p>Replace the steering column.</p>
<p><b>5 CHECK UNIVERSAL JOINT.</b>                      Measure the swing torque of joint. (Yoke of steering column side)&lt;Ref. to PS-23, INSPECTION, Universal Joint.&gt;</p>	<p>Is the swing torque of the universal joint less than 7.3 N (0.74 kgf, 1.64 lbf)?</p>	<p>Go to step 6.</p>	<p>Replace the universal joint.</p>
<p><b>6 CHECK UNIVERSAL JOINT.</b>                      Measure the swing torque of joint. (Yoke of gearbox side)&lt;Ref. to PS-23, INSPECTION, Universal Joint.&gt;</p>	<p>Is the swing torque of the universal joint less than 3.8 N (0.39 kgf, 0.86 lbf)?</p>	<p>Go to step 7.</p>	<p>Replace the universal joint.</p>
<p><b>7 CHECK FRONT WHEEL.</b>                      Check the front wheels.</p>	<p>Does the front wheels have unsteady revolution or rattling, or does the brake drag?</p>	<p>Inspect, readjust and replace if necessary.</p>	<p>Go to step 8.</p>
<p><b>8 CHECK TIE-ROD ENDS.</b>                      Remove the tie-rod end from the front housing.</p>	<p>Does the tie-rod and tie-rod end have unsteady revolution or rattling?</p>	<p>Inspect and replace if necessary.</p>	<p>Go to step 9.</p>
<p><b>9 CHECK GEARBOX.</b>                      Measure the rotating of gearbox.                      &lt;Ref. to PS-55, SERVICE LIMIT, INSPECTION, Steering Gearbox.&gt;</p>	<p>Is the rotational resistance of the steering gearbox less than 17 N (1.7 kgf, 3.8 lbf)? Is the difference between the right and left rotational resistances less than 20%?</p>	<p>Go to step 10.</p>	<p>Readjust the backlash, and if ineffective, replace the faulty parts.</p>

# General Diagnostic Table

## POWER ASSISTED SYSTEM (POWER STEERING)

Step	Check	Yes	No
<b>10</b> <b>CHECK GEARBOX.</b> Measure the sliding of gearbox. <Ref. to PS-55, SERVICE LIMIT, INSPECTION, Steering Gearbox.>	Is the sliding resistance of the steering gearbox less than 375 N (38.2 kgf, 84 lbf)? Is the difference between the right and left sliding resistances less than 20%?	Steering effort is normal. Check the front suspension.	Readjust the backlash, and if ineffective, replace the faulty parts.

# General Diagnostic Table

POWER ASSISTED SYSTEM (POWER STEERING)

---

## BODY SECTION

This service manual has been prepared to provide SUBARU service personnel with the necessary information and data for the correct maintenance and repair of SUBARU vehicles.

This manual includes the procedures for maintenance, disassembling, reassembling, inspection and adjustment of components and diagnostics for guidance of experienced mechanics.

Please peruse and utilize this manual fully to ensure complete repair work for satisfying our customers by keeping their vehicle in optimum condition. When replacement of parts during repair work is needed, be sure to use SUBARU genuine parts.

All information, illustration and specifications contained in this manual are based on the latest product information available at the time of publication approval.

**HVAC SYSTEM  
(HEATER, VENTILATOR AND A/C)** AC

**HVAC SYSTEM (DIAGNOSTICS)** AC(diag)

**AIRBAG SYSTEM** AB

**AIRBAG SYSTEM (DIAGNOSTICS)** AB(diag)

**OCCUPANT DETECTION SYSTEM  
(DIAGNOSTICS)** OD(diag)

**SEAT BELT SYSTEM** SB

**LIGHTING SYSTEM** LI

**WIPER AND WASHER SYSTEMS** WW

**ENTERTAINMENT** ET

**COMMUNICATION SYSTEM** COM

**GLASS/WINDOWS/MIRRORS** GW

**BODY STRUCTURE** BS

**INSTRUMENTATION/DRIVER INFO** IDI

**SEATS** SE

**POWER SEAT MEMORY SYSTEM  
(DIAGNOSTICS)** PSM(diag)

**SECURITY AND LOCKS** SL

**SUNROOF/T-TOP/CONVERTIBLE TOP  
(SUNROOF)** SR



**BODY SECTION**

**EXTERIOR/INTERIOR TRIM EI**

**EXTERIOR BODY PANELS EB**

**CRUISE CONTROL SYSTEM CC**

**CRUISE CONTROL SYSTEM (DIAGNOSTICS) CC(diag)**

**IMMOBILIZER (DIAGNOSTICS) IM(diag)**

**LAN SYSTEM (DIAGNOSTICS) LAN(diag)**

**EyeSight ES**

**EyeSight (DIAGNOSTICS) ES(diag)**

**KEYLESS ACCESS WITH PUSH BUTTON START SYSTEM (DIAGNOSTICS) KPS(diag)**

**BODY CONTROL SYSTEM (DIAGNOSTICS) BC(diag)**





# HVAC SYSTEM (HEATER, VENTILATOR AND A/C)

# AC

---

	<b>Page</b>
1. General Description .....	2
2. Air Conditioning System .....	21
3. Refrigerant Pressure with Manifold Gauge Set .....	22
4. Refrigerant Recovery Procedure .....	26
5. Refrigerant Charging Procedure .....	27
6. Refrigerant Leak Check .....	30
7. Relay and Fuse .....	32
8. Compressor Oil .....	33
9. Blower Motor Unit Assembly .....	34
10. Blower Motor .....	37
11. Power Transistor (Auto A/C Model) .....	39
12. Blower Resistor (Manual A/C Model) .....	40
13. Heater Core .....	42
14. Control Panel .....	46
15. Control Unit .....	54
16. Compressor .....	55
17. Condenser .....	60
18. Heater and Cooling Unit .....	64
19. Evaporator .....	67
20. Expansion Valve .....	74
21. Hose and Pipe .....	76
22. Pressure Sensor .....	77
23. Ambient Sensor .....	78
24. Sunload Sensor (Auto A/C Model) .....	80
25. In-Vehicle Sensor (Auto A/C Model) .....	82
26. Evaporator Sensor .....	87
27. FRESH/RECIRC Door Actuator .....	90
28. Mode Door Actuator .....	92
29. Air Mix Door Actuator .....	95
30. Rear Vent Door Actuator .....	100
31. Air Vent Grille .....	102
32. Heater Duct .....	105
33. Heater Vent Duct .....	107
34. A/C Filter .....	108
35. Diagnostics with Phenomenon .....	110