

Horn Switch

COMMUNICATION SYSTEM

5. Horn Switch

A: REMOVAL

NOTE:


Horn switch is a unit with the driver's airbag module.

- 1) Position the front wheels straight ahead. (After moving a vehicle 5 m (16 ft) or more with front wheels positioned straight ahead, make sure that the vehicle moves straight ahead.)
- 2) Turn the ignition switch to OFF.
- 3) Disconnect the ground cable from battery and wait for at least 60 seconds before starting work.
- 4) Remove the driver's airbag module assembly.

CAUTION:


Before handling the airbag module, refer to "CAUTION" of "General Description" in "AIRBAG SYSTEM". <Ref. to AB-10, CAUTION, General Description.>

- (1) Using a hexagon wrench etc. wrapped by protective tape, insert the snap pins and release the locks (3 locations).



AB-02932

(2) Disconnect the horn harness and airbag connector and remove the airbag module assembly. <Ref. to AB-22, DRIVER'S AIRBAG MODULE, CURTAIN AIRBAG MODULE, PRETENSIONER & LAP SEAT BELT PRETENSIONER, PROCEDURE, Airbag Connector.>



B: INSTALLATION

CAUTION:

- Before handling the airbag module, refer to “CAUTION” of “General Description” in “AIRBAG SYSTEM”. <Ref. to AB-10, CAUTION, General Description.>
 - Do not allow harness and connectors to interfere or get tangled up with other parts.
- 1) Install the driver's airbag module. <Ref. to AB-39, INSTALLATION, Driver's Airbag Module.>
 - 2) Install each part in the reverse order of removal.

Horn Switch


C: INSPECTION

1. CHECK HORN SWITCH

- 1) Remove the horn switch. <Ref. to COM-8, REMOVAL, Horn Switch.>
- 2) Check that the connection of the horn switch harness connector is correct.
- 3) Disconnect the horn switch harness connector and check the resistance between the harness connectors.

Preparation tool:

Circuit tester



(a) Ground terminal

(b) Horn switch terminal


Terminal No.	Inspection conditions	Standard
Ground terminal (a) — Horn switch terminal (b)	The airbag module bracket being pushed	Less than 1 Ω
	The airbag module bracket being separated	1 MΩ or more

- 4) Replace the driver's airbag module if the inspection result is not within the standard value.

2. CHECK ROLL CONNECTOR

- 1) Remove the roll connector. <Ref. to AB-103, REMOVAL, Roll Connector.>
- 2) Check the resistance between roll connector terminals.

Preparation tool:
Circuit tester



Terminal No.	Inspection conditions	Standard
A1 — C9	Always	Less than 1 Ω

- 3) Replace the roll connector if the inspection result is not within the standard value.

Horn Switch

COMMUNICATION SYSTEM

GLASS/WINDOWS/MIRRORS

GW

	Page
1. General Description	2
2. Relay and Fuse	8
3. Power Window System	10
4. Power Window Control Switch	12
5. Front Door Glass	18
6. Front Regulator and Motor Assembly	20
7. Remote Control Mirror System	23
8. Outer Mirror Assembly	24
9. Remote Control Mirror Switch	28
10. Rear Door Glass	30
11. Rear Regulator and Motor Assembly	32
12. Windshield Glass	36
13. Rear Gate Glass	44
14. Rear Window Glass	48
15. Rear Window Defogger System	51
16. Rear Quarter Glass	54
17. Rearview Mirror	56
18. Wiper Deicer System	59