

# Door Lock Control System

SECURITY AND LOCKS

## 2. Door Lock Control System

### A: WIRING DIAGRAM

#### 1. DOOR LOCK CONTROL

<Ref. to WI-149, WIRING DIAGRAM, Keyless Entry System.>

### B: INSPECTION

#### 1. SYMPTOM CHART

| Symptom   | Repair order   | Reference  |
|---|--|--|
| The door lock control system does not operate.  | 1. Check the fuse.   | <Ref. to SL-8, CHECK FUSE, INSPECTION, Door Lock Control System.>                          |
|   | 2. Check the power supply and ground circuit for body integrated unit. | <Ref. to SL-8, CHECK POWER SUPPLY & GROUND CIRCUIT, INSPECTION, Door Lock Control System.> |
|   | 3. Check the door lock switch and the circuit.                         | <Ref. to SL-9, CHECK DOOR LOCK SWITCH., INSPECTION, Door Lock Control System.>             |
|   | 4. Check the door lock actuator and the circuit.                       | <Ref. to SL-10, CHECK DOOR LOCK ACTUATOR & CIRCUIT, INSPECTION, Door Lock Control System.> |
| The door lock switch does not operate.          | Check the door lock switch.  | <Ref. to SL-9, CHECK DOOR LOCK SWITCH., INSPECTION, Door Lock Control System.>             |
| A specific door lock actuator does not operate. | Check the door lock actuator and circuit.                              | <Ref. to SL-10, CHECK DOOR LOCK ACTUATOR & CIRCUIT, INSPECTION, Door Lock Control System.> |

#### 2. CHECK FUSE

| Step  | Check                  | Yes                              | No  |
|---|------------------------|----------------------------------|---|
| <b>1 CHECK FUSE.</b><br>Remove and visually check the fuse No. 3 (in the fuse & relay box) and No. 7 (in the fuse & relay box). | Is the fuse blown out? | Replace the fuse with a new one. | Check the power supply and ground circuit. <Ref. to SL-8, CHECK POWER SUPPLY & GROUND CIRCUIT, INSPECTION, Door Lock Control System.> |

#### 3. CHECK POWER SUPPLY & GROUND CIRCUIT

| Step   | Check                             | Yes   | No   |
|--|-----------------------------------|---|--|
| <b>1 CHECK POWER SUPPLY.</b><br>1) Disconnect the harness connector of body integrated unit.<br>2) Measure the voltage between harness connector terminal and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(i84) No. 34 (+) — Chassis ground (-):</i><br><i>(B281) No. 2 (+) — Chassis ground (-):</i> | Is the voltage 10 V or more?      | Go to step 2.                               | Check the harness for open or short circuit between body integrated unit and fuse. |
| <b>2 CHECK GROUND CIRCUIT.</b><br>Measure the resistance between harness connector terminal and chassis ground.<br><b>Connector &amp; terminal</b><br><i>(B280) No. 22 — Chassis ground:</i><br><i>(B281) No. 8 — Chassis ground:</i><br><i>(B281) No. 9 — Chassis ground:</i>                                     | Is the resistance less than 10 Ω? | The power supply and ground circuit are OK. | Repair the harness.  |

## 4. CHECK DOOR LOCK SWITCH

| Step   | Check   | Yes                           | No   |
|--|---|-------------------------------|--|
| <b>1 CHECK DOOR LOCK SWITCH.</b><br>Check the input from door lock switch to body integrated unit using Subaru Select Monitor.<br>1) Connect the Subaru Select Monitor to data link connector.<br>2) Turn the ignition switch to ON.<br>3) Select {Integ. unit} from main menu.<br>4) Select the {Current Data Display & Save}.<br>5) Check the input to body integrated unit by operating the door lock switch. | Is the normal input signal displayed when the door lock switch is moved to LOCK/UNLOCK? | The door lock switch is OK.   | Go to step 2.  |
| <b>2 CHECK DOOR LOCK SWITCH CIRCUIT.</b><br>1) Disconnect the harness connector of body integrated unit.<br>2) Measure the resistance between the harness connector terminal and chassis ground when moving the door lock switch to LOCK.<br><b>Connector &amp; terminal</b><br><b>(i84) No. 15 — Chassis ground:</b>  | Is the resistance less than 10 Ω?   | Go to step 3.                 | Go to step 4.  |
| <b>3 CHECK DOOR LOCK SWITCH CIRCUIT.</b><br>Measure the resistance between the harness connector terminal and chassis ground when the door lock switch is moved to UNLOCK.<br><b>Connector &amp; terminal</b><br><b>(i84) No. 29 — Chassis ground:</b>   | Is the resistance less than 10 Ω?   | The door lock switch is OK.   | Go to step 4.  |
| <b>4 CHECK DOOR LOCK SWITCH.</b><br>1) Disconnect the door lock switch harness connector (D7D or 125).<br>2) Measure the resistance between the door lock switch terminals when moving the door lock switch to LOCK.<br><b>Connector &amp; terminal</b><br><b>Driver's side:</b><br><b>(D7) No. 5 — No. 9:</b><br><b>Passenger's side:</b><br><b>(D125) No. 2 — No. 5:</b>                                       | Is the resistance less than 1 Ω?  | Go to step 5.                 | Replace the door lock switch.                                    |
| <b>5 CHECK DOOR LOCK SWITCH.</b><br>Measure the resistance between the door lock switch terminals when moving the door lock switch to UNLOCK.<br><b>Connector &amp; terminal</b><br><b>Driver's side:</b><br><b>(D7) No. 5 — No. 8:</b><br><b>Passenger's side:</b><br><b>(D125) No. 4 — No. 5:</b>  | Is the resistance less than 1 Ω?  | Go to step 6.                 | Replace the door lock switch.                                    |
| <b>6 CHECK HARNESS.</b><br>Measure the resistance between door lock switch harness connector terminal and chassis ground.<br><b>Connector &amp; terminal</b><br><b>Driver's side:</b><br><b>(D7) No. 5 — Chassis ground:</b><br><b>Passenger's side:</b><br><b>(D125) No. 5 — Chassis ground:</b>  | Is the resistance less than 1 Ω?  | Replace the door lock switch. | Repair the open circuit or chassis short circuit of the harness. |

# Door Lock Control System

## SECURITY AND LOCKS

### 5. CHECK DOOR LOCK ACTUATOR & CIRCUIT

| Step  | Check                         | Yes   | No  |
|---|-------------------------------|---|---|
| <b>1</b><br><b>CHECK OUTPUT SIGNAL.</b><br>Measure the voltage between the harness connector terminal and chassis ground of body integrated unit when moving the door lock switch to LOCK.<br><i>Connector &amp; terminal</i><br><i>(i84) No. 7 (+) — Chassis ground (-):</i>   | Is the voltage 10 V or more?  | Go to step 2.   | Replace the body integrated unit.<br><Ref. to SL-51, Body Integrated Unit.> |
| <b>2</b><br><b>CHECK OUTPUT SIGNAL.</b><br>Measure the voltage between the harness connector terminal and chassis ground of body integrated unit when moving the door lock switch to UNLOCK.<br><i>Connector &amp; terminal</i><br><i>Driver's side:</i><br><i>(i84) No. 23 (+) — Chassis ground (-):</i><br><i>Except for driver's side:</i><br><i>(i84) No. 8 (+) — Chassis ground (-):</i> | Is the voltage 10 V or more?  | Go to step 3.   | Replace the body integrated unit.<br><Ref. to SL-51, Body Integrated Unit.> |
| <b>3</b><br><b>CHECK DOOR LOCK ACTUATOR.</b><br>Check the door lock actuator. <ul style="list-style-type: none"> <li>• Front door lock actuator &lt;Ref. to SL-36, Front Door Lock Actuator.&gt;</li> <li>• Rear door lock actuator &lt;Ref. to SL-40, Rear Door Lock Actuator.&gt;</li> <li>• Rear gate latch lock actuator &lt;Ref. to SL-42, Rear Gate Latch Assembly.&gt;</li> </ul>      | Is the door lock actuator OK? | Check the harness for open or short circuits between body integrated unit and door lock actuator. | Replace the door lock actuator.   |