

LIGHTING SYSTEM

PRECAUTION

1. GENERAL PRECAUTION

- (a) While using the battery during inspection, do not bring the positive and negative tester probes too close to each other as a short circuit may occur.

2. PRECAUTION FOR DISCONNECTING THE BATTERY CABLE

NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

| System Name | See procedure |
|-----------------------------|---------------|
| Power Window Control System | IN-29 |
| Sliding Roof System | IN-29 |

3. PRECAUTION FOR HEADLIGHT BULB REPLACEMENT (HALOGEN BULB)

- (a) Halogen bulbs have pressurized gas inside and require special handling. They can burst if scratched or dropped. Hold the bulb only by its plastic or metal case. Don't touch the glass part of a bulb with bare hands.

4. PRECAUTION FOR HEADLIGHT BULB REPLACEMENT (HID BULB)

- (a) When any defects such as deformations, crack, dent, chipping, etc. are identified on the HID headlight (especially on the light control ECU), replace it with a new one.
- (b) Even if the operation of the HID system is normal, always replace damaged parts as the fail-safe function may not be operating correctly.
- (c) Be careful not to scratch or drop bulbs of the HID headlight and halogen bulbs (for high beam headlights and fog lights) as they have pressurized gas inside and can be easily broken.
- (d) Touching the high voltage socket of the HID headlight with the headlight dimmer switch ON could generate momentary high voltage of 20,000 V and lead to a serious injury.
- (e) Never connect a tester to the high voltage socket of the HID headlight for measurement, as this may lead to a serious injury because of high voltage.
- (f) When servicing the HID headlight, keep it away from water including rain, turn off the light control switch, and disconnect the battery terminal and the connector of the light control ECU in advance to avoid electric shock.
- (g) When operating the HID headlight, operate it after assembling is completed and never turn on the lights without a bulb installed.

- (h) Do not turn on the HID headlight using another power source except the vehicle's.

5. EXPRESSIONS OF IGNITION SWITCH

- (a) The type of ignition switch used on this model differs according to the specifications of the vehicle. The expressions listed in the table below are used in this section.

| | Switch Type | Ignition Switch (position) | Engine Switch (condition) |
|------------|--------------------------|----------------------------|---------------------------|
| Expression | Ignition Switch off | LOCK | Off |
| | Ignition Switch on (IG) | ON | On (IG) |
| | Ignition Switch on (ACC) | ACC | On (ACC) |
| | Engine Start | START | Start |



HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester can be used at steps 4, 5, 6, and 12.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS

NEXT

3 PROBLEM SYMPTOM CONFIRMATION



SYMPTOM DOES NOT OCCUR (GO TO STEP 4)



SYMPTOM OCCURS (GO TO STEP 5)

4 CHECK BODY MULTIPLEX COMMUNICATION SYSTEM

(a) Check for DTC outputs.



MULTIPLEX DTC OUTPUTS (PROCEED TO "BODY MULTIPLEX COMMUNICATION SYSTEM")



NO MULTIPLEX DTC (GO TO STEP 5)

5 DTC CHECK (OTHER THAN MULTIPLEX DTC)



MALFUNCTION CODE (GO TO STEP 6)



NORMAL CODE (GO TO STEP 7)

6 DTC CHART



GO TO STEP 8

7 PROBLEM SYMPTOMS TABLE

NEXT

| | |
|----------|-------------------------|
| 8 | TERMINALS OF ECU |
|----------|-------------------------|

NEXT

| | |
|----------|---------------------------|
| 9 | CIRCUIT INSPECTION |
|----------|---------------------------|

NEXT

| | |
|-----------|----------------------------------|
| 10 | IDENTIFICATION OF PROBLEM |
|-----------|----------------------------------|

NEXT

| | |
|-----------|--------------------------|
| 11 | REPAIR OR REPLACE |
|-----------|--------------------------|


NEXT


| | |
|-----------|--------------------------|
| 12 | CONFIRMATION TEST |
|-----------|--------------------------|

NEXT

| |
|------------|
| END |
|------------|

PARTS LOCATION





REAR LH DOOR LOCK ASSEMBLY

- DOOR UNLOCK DETECTION SWITCH

HEADLIGHT BEAM
LEVELING CONTROL
ECU

HIGH MOUNTED STOP
LIGHT ASSEMBLY

HEIGHT CONTROL
SENSOR REAR RH

BACK-UP LIGHT ASSEMBLY

- TAILLIGHT

- BACK-UP LIGHT

DOOR COURTESY
LIGHT

DOOR COURTESY
LIGHT

FRONT DOOR COURTESY
SWITCH

FRONT LH DOOR LOCK ASSEMBLY

- DOOR UNLOCK DETECTION SWITCH

REAR DOOR COURTESY SWITCH

REAR COMBINATION LIGHT
ASSEMBLY

- TAIL & STOP LIGHT

- TURN SIGNAL LIGHT

LICENSE PLATE LIGHT
ASSEMBLY


LUGGAGE COMPARTMENT
DOOR LOCK ASSEMBLY

- LUGGAGE DOOR
COURTESY SWITCH

INSTRUMENT PANEL J/B ASSEMBLY

- BODY ECU
- TAIL RELAY
- IG1 RELAY
- ACC RELAY
- FOG RELAY
- ECU-IG FUSE
- ECU ACC FUSE
- FOG FUSE
- TAIL FUSE
- PANEL FUSE
- MPX-B FUSE

HEADLIGHT DIMMER SWITCH




COMBINATION METER

- HEADLIGHT BEAM LEVEL CONTROL WARNING INDICATOR

TURN SIGNAL FLASHER ASSEMBLY

HAZARD WARNING SWITCH


AUTOMATIC LIGHT CONTROL SENSOR




DLC3


*1: WITHOUT SMART KEY SYSTEM

SYSTEM DIAGRAM





Headlight Beam Level Control System:



Input and output signals of each ECU

| Transmitting ECU (Transmitter) | Receiving ECU | Signals | Communication method |
|-----------------------------------|------------------|---|----------------------|
| Body ECU | Front Controller | <ul style="list-style-type: none"> • Headlight ON signal • High beam ON signal • DRL ON demand signal | BEAN |
| Combination switch ECU | Body ECU | <ul style="list-style-type: none"> • Light SW auto signal • Light SW tail signal • Light SW head signal • Light SW high beam signal • Front fog SW signal • Lighting system passing signal • Right turn signal • Left turn signal | BEAN |
| ECM | Body ECU | <ul style="list-style-type: none"> • Alternator L terminal signal • Shift position P signal | CAN - BEAN |



SYSTEM DESCRIPTION

1. PARTS DESCRIPTION

| Components | Function |
|------------------------------------|--|
| Automatic light control sensor | Detects ambient light and sends the information to the body ECU. |
| HEAD relay | Turn the headlight on when it is actuated by the headlight ON demand signal by the front controller. |
| TAIL relay | Turns the tail light and illumination on when it is actuated by the tail light ON demand signal via the body ECU |
| Door courtesy switch | Detects the door open / close state and sends the respective information to the body ECU. |
| Door unlock detection switch | Detects the door lock / unlock state and sends the respective information to the body ECU. |
| Alternator | Detects the engine start / stop state and sends the information to the headlight beam level control ECU. |
| Skid control ECU | Detects the vehicle speed and sends the information to the headlight beam level control ECU. |
| Height control sensor | Detects the vehicle height and sends the corresponding information to the headlight beam level control ECU. |
| Combination meter | Sends headlight beam level warning according to the information from the headlight beam level control ECU. |
| Headlight beam level control motor | moves the headlight (low beam) up and down according to the information from the headlight beam level control ECU. |

2. OPERATION DESCRIPTION

(a) Illumination control system (Illuminated entry system):

(1) The body ECU receives the following (A):

- Door courtesy switch signal
- Door detection switch signal
- Ignition switch signal

(2) The body ECU controls the following based on the signals listed in "A":

- Illumination operation signal

(3) The body ECU controls on / off and fade-in / fade-out operation of the following:

- Front interior light
- Ignition key cylinder light or engine switch illumination

(b) Manual light control system:

This system functions if lights such as the headlights and tail lights come on by manual operation of the light control switch.

(1) The body ECU receives the following (B):

- Light control switch signal
- Headlight dimmer switch signal
- Fog light switch signal

(2) The body ECU controls the following based on the signals listed in "B":

- Headlight ON signal
- Tail light ON signal
- High beam ON signal
- Front fog light ON signal

- (c) Light auto turn off system:
When the headlights and tail lights are on through the operation of the automatic light control switch, if the ignition switch is turned off and all doors are closed, this system continues to illuminate the headlights and tail lights for approximately 30 seconds, and then turns off the headlights. However, with all the doors locked manually, using the door lock button, using the key, or pressing "LOCK" on the wireless remote will turn the headlights and tail lights off immediately.
- (1) The body ECU receives the following (C):
 - Door courtesy switch signal
 - Ignition switch on (IG) signal
 - (2) The multiplex network body ECU controls the following based on the signals listed in "C" (D):
 - Tail light ON signal
 - Headlight ON signal
 - High beam ON signal
 - Fog light signal
 - (3) The body ECU controls the illuminating period of the following based on the signals listed in "D":
 - Fog light
 - Tail light
 - (4) The front controller receives headlight ON and the high beam ON signals from the body ECU, and then controls the illuminating period of the following based on the signal listed in "D":
 - Headlight (Low)
 - Headlight (Hi)
- (d) Automatic light control system:
When the light control switch is in the AUTO position, the automatic light control sensor detects ambient light and automatically turns the headlights and tail light on or off accordingly.
- (1) The body ECU receives the following (E):
 - Light control switch signal
 - Automatic light control sensor signal
 - (2) The body ECU controls the following based on the signals listed in "E":
 - Headlight ON signal
 - Tail light ON signal
 - (3) The body ECU controls on / off operation of the following:
 - Tail light
 - (4) The front controller receives the headlight ON signal from the body ECU, and then controls on / off operation of the following:
 - Headlight

- (e) Daytime running light system:
This system is directly connected to the high-beam headlights and is designed to automatically activate the daytime running lights in order to remain highly visible to other vehicles.
- (1) The body ECU receives the following (F):
 - Ignition switch signal
 - Generator signal
 - Parking brake switch signal
 - Light control switch signal
 - (2) The body ECU controls the following based on the signals listed in "F":
 - DRL relay operation signal
 - (3) The front controller receives the high beam ON signal from the body ECU, and then controls on / off operation of the following:
 - Headlight (Hi)
- (f) Turn signal light system
- (1) The body ECU receives the following (G):
 - Right turn signal
 - Left turn signal
 - (2) The body ECU controls the following based on the signals listed in "G" (H):
 - Right turn ON signal
Sent when the right turn signal or hazard warning signal is received.
 - Left turn ON signal
Sent when the left turn signal or hazard warning signal is received.
 - (3) The body ECU controls on / off operation of the following based on the signals listed in "H":
 - Right turn signal light
 - Left turn signal light
- (g) Headlight beam level control system
- (1) The headlight beam level control ECU receives the following (I):
 - HEAD relay ON signal
 - Vehicle height sensor signal
 - Vehicle speed signal
 - Alternator signal
 - (2) The headlight beam level control ECU controls the following based on the signals listed in "I" at engine start (J):
 - Level control motor operation demand signal:
Sent based on the vehicle height sensor signal and vehicle speed sensor when the HEAD relay ON signal is received.
 - Headlight beam level control warning indicator light signal:
Sent to the combination meter when the headlight beam level control ECU is malfunctioning.

- (3) The headlight beam level control ECU control the following based on the signals listed in "J".
- Headlight beam level control motor
 - Headlight beam level control warning indicator light

OPERATION CHECK

1. **ILLUMINATED ENTRY SYSTEM OPERATION CHECK**
 - (a) Illuminated entry system controls the following:
 - Key cylinder light or engine switch illumination
 - Front interior light
 - (b) Check that the lights come on when unlocking any of the doors that are closed and locked with the ignition switch off. Then check that the lights fade out under the following conditions:
 - (1) Leave the doors unlocked for 15 seconds.
 - (2) Turn the ignition switch on (IG) or turn the ignition switch on (ACC).
 - (3) Lock all the doors.
 - (c) Check that the lights come on when opening any of the doors that are closed with the ignition switch off. Close the door and check that the lights stay on for about 15 seconds and then go off.
 - (d) Check that the lights come on when turning the ignition switch from on (ACC or IG) to off. Check that the lights stay on for about 15 seconds and then go off.
2. **BATTERY SAVER OPERATION CHECK**
 - (a) Remove the ignition key and close all the doors.
 - (b) Open the door to turn the room light on, and leave it open. Check that the light goes off after approximately 20 minutes.
 - (c) After the room light goes off, close the driver's door.
 - (d) Open any door to turn the room light on, and then open another door. Check that the room light goes off within 20 minutes after opening the doors.
 - (e) Close all the doors. With the ignition key inserted, open any door to turn the room light on, and then remove the ignition key. Check that the room light goes off within 20 minutes.
3. **LIGHT AUTO TURN OFF OPERATION CHECK**
 - (a) Turn the ignition switch on (IG), and switch the headlights to the TAIL or HEAD position.
 - (b) Turn the ignition switch off and open the driver's door, and check that the headlights go off after approximately 30 seconds.
 - (c) Turn the ignition switch on (IG), and switch the headlights to the TAIL or HEAD position.
 - (d) Turn the ignition switch off and open the driver's door. Before the headlight goes off after approximately 30 seconds, lock all the doors. Check that the headlights go off immediately.
4. **AUTOMATIC LIGHT CONTROL OPERATION CHECK**
 - (a) Turn the ignition switch on (IG).
 - (b) Turn the headlight dimmer switch to the AUTO position.
 - (c) Cover the automatic light control sensor and check that the tail lights and headlights come on in order.

- (d) Uncover the automatic light control sensor and check that the headlights and tail lights go off in order.

5. DAYTIME RUNNING LIGHT OPERATION CHECK

- (a) Check that the high beams come on when the headlight switch is off with the engine running and the parking brake released. Then check that the lights go off under the following condition:
 - (1) Turn the headlight dimmer switch into the TAIL or HEAD (LOW) position.
 - (2) Turn the ignition switch off.

6. HEADLIGHT BEAM LEVEL CONTROL OPERATION CHECK

- (a) Check that the initialization (determination of the initial position) of the leveling motor is performed at engine-start.
- (b) Check that the warning indicator in the combination meter assembly comes on for approximately 3 seconds when turning the ignition switch on (IG) and then goes off.
- (c) Check that the projector moves when:
Moving the rear of the vehicle up or down while the engine is running, vehicle is stopped, and the headlight dimmer switch is in the HEAD position.

NOTICE:

Make sure to change the vehicle's height slowly.

Headlight Beam Level Control System



C

I041574E01



CUSTOMIZE PARAMETERS

HINT:

The following items are possible to customize.

NOTICE:

- **After confirming whether the items of the customer's request is applicable or not for the customized items, perform the customize operation.**
- **Be sure to record the current value before customizing.**
- **In case of performing the troubleshooting, pay attention as there is a possibility that a function is OFF by customizing. (Example: In case of the symptom in which "The wireless operation does not function", check that the wireless operation is not OFF by customizing, then perform the troubleshooting.)**

ILLUMINATED ENTRY

| DISPLAY (ITEM) | DEFAULT | CONTENTS | SETTING |
|---|---------|--|---------------------|
| LIGHTING TIME (Lighting Time) | 15 s | To change the lighting time after closing the door. (It will quickly fade out in case of turning the ignition on (IG).) | 7.5 s / 15 s / 30 s |
| ILLUMI SYSTEM (Operation of illumination) | ON | Function to turn on the step light, center console light and door inside handle light when one of the following occurs; the ignition turned on (IG), door unlock or door open. | ON / OFF |
| LIGHT CONTROL (Light control) | ON | Function to turn on the step light and door inside handle light when the ignition switch is turned on (IG) and the shift lever is not in the P position. | ON / OFF |
| I/L ON / UNLOCK (Interior light ON w/ door key unlock) | ON | Function to turn on the interior light*, ignition light and step light when unlocking with the door key cylinder. *: Interior light comes on when the interior light switch is in the DOOR position. | ON / OFF |
| I/L ON / ACC OFF (Illumination system ON with ACC OFF) | ON | Function to turn on the interior light* and door courtesy light when the ignition switch is turned from on (ACC) to off. *: Interior light comes on when the interior light switch is in the DOOR position. | ON / OFF |

LIGHT CONTROL

| DISPLAY (ITEM) | DEFAULT | CONTENTS | SETTING |
|--|---------|--|--|
| LIGHT OFF DELAY (Light Auto OFF Delay) | 30 s | Function to keep the headlight on for a certain period of time after closing all the doors when turning the ignition switch on (IG) under the condition that the light control switch is in the HEAD or AUTO position with the headlight ON. | OFF / 30 s / 60 s / 90 s |
| LIGHT CTRL TYPE (Control Type) | CURRENT | To change the control logic when the light control switch is in the AUTO position. Refer to the *table 1. | CURRENT / OLD |
| SENSITIVITY (Turn ON Luminous Intensity) | NORMAL | To adjust the sensitivity of the lighting illumination. Refer to the *illustration 1. | DARK2 / DARK1 / NORMAL / LIGHT1 / LIGHT2 |
| DISP EX ON SEN (Display Extinction Luminous Intensity) | NORMAL | To dim the lights such as the indicator light of the combination meter, A/C indicator light, and clock. Refer to *illustration 2. | DARK2 / DARK1 / NORMAL / LIGHT1 / LIGHT2 |
| DISP EX OFF SEN (Display Extinction Release Luminous Intensity) | NORMAL | To cancel to dim the lights such as the indicator light of the combination meter, A/C indicator light, and clock. Refer to *illustration 3. | DARK2 / DARK1 / NORMAL / LIGHT1 / LIGHT2 |

HINT:

Sensitivity adjustment is dependent on the owner's preference. Actual driving by the owner is required.

Table 1

| | Brightness of the surrounding when lighting | Lighting delay | Delay of turning light off | **2 |
|---------|---|----------------|----------------------------|---------|
| OLD | Old logic | 6 sec. | 6 sec. | 3 sec. |
| CURRENT | New logic**1 ('97/8) | 15 sec. | 15 sec. | 15 sec. |

**1: The new system has the ability to light up two times brighter than the old system.

**2: Delay time until the headlight is turned on when the outside suddenly gets dark.

Illustration 1

| | |
|---------------------|--|
| Lighting brightness | Dark ←————→ Bright |
| Setting | DARK2 — DARK1 — NORMAL — LIGHT1 — LIGHT2 |

Illustration 2

| | |
|------------------------------------|--|
| Brightness when dimming the lights | Dark ←————→ Bright |
| Setting | DARK2 — DARK1 — NORMAL — LIGHT1 — LIGHT2 |

Illustration 3

| | |
|---|--|
| Brightness when canceling to dim the lights | Dark ←————→ Bright |
| Setting | DARK2 — DARK1 — NORMAL — LIGHT1 — LIGHT2 |

INITIALIZATION

1. HEIGHT CONTROL SENSOR SIGNAL INITIALIZATION

NOTICE:

- Initialize the headlight beam level control ECU when vehicle height changes due to replacement of the suspension, headlight beam level control ECU, or removal, installation, or replacement of the height control sensor.
- Adjust the headlight aim after initializing the headlight beam level control ECU (See page [LI-114](#)).

1

CHECK VEHICLE CONDITION

- Leave approximately 10 liters of fuel in the tank.
- Unload the vehicle.
- Check that there are no passengers in the vehicle.
- Turn off the headlights.

NEXT

2

CHECK WARNING INDICATOR

Headlight Beam Level Control System



C

I041574E01

- Turn the ignition switch on (IG) and check the warning indicator (bulb check function).

OK:


Warning indicator comes on for approximately 3 seconds.

HINT:

- If the headlight beam level control ECU is replaced with a new one or there is problem with initialized data memorized in the headlight beam level control ECU, the warning indicator repeats the following pattern: 2 Hz for one second, followed by a 1 second pause.
- If the warning indicator does not come on or comes on for more than 3 seconds, inspect and repair according to "PROBLEM SYMPTOMS TABLE" (See page [LI-18](#)).

NEXT

3 INITIALIZATION



(a) Connect terminals 4 (CG) and 8 (LVL) of the DLC3 using the SST.

SST 09843-18040

(b) Flash the headlight 3 times within 20 seconds by turning the headlight dimmer switch.

NOTICE:

Flash the headlight at approximately 1 second intervals.

OK

| Condition | Proceed to |
|---|------------|
| Warning indicator blinks 3 times at 0.5 second intervals → goes off | A |
| Warning indicator does not blink or continues blinking | B |

HINT:

If initialization cannot finished normally, inspect the initialization circuit (See page [LI-107](#)).

B → **INITIALIZED TERMINAL CIRCUIT IS FAULTY**

A

END (NORMAL COMPLETE)

PROBLEM SYMPTOMS TABLE

If a normal system code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

HINT:

Inspect the fuse and relay before confirming the suspected area in the table below.

Inspect each malfunction circuit in numerical order for the corresponding symptom.

If the malfunction still exists even after checking and confirming that all the circuits are normal, replace the ECU.

1. HEADLIGHT AND TAIL LIGHT SYSTEM

| Symptom | Suspected area | See page |
|---|--|----------|
| "Low beam" does not come on (One side). | 1. Bulb | - |
| | 2. Headlight relay circuit | LI-40 |
| "Low beam" does not come on (Both sides). | 1. Bulb | - |
| | 2. Combination switch ECU power source circuit | LI-102 |
| | 3. Light control switch circuit | LI-60 |
| | 4. Headlight relay circuit | LI-40 |
| | 5. Front controller | - |
| | 6. Body ECU | - |
| "High beam" does not come on (One side). | 1. Bulb | - |
| | 2. Headlight (HI-BEAM) circuit | LI-43 |
| | 3. Front controller | - |
| "High beam" does not come on (Both sides). | 1. Bulb | - |
| | 2. Combination switch ECU power source circuit | LI-102 |
| | 3. Light control switch circuit | LI-60 |
| | 4. Headlight (HI-BEAM) circuit | LI-43 |
| | 5. Front controller | - |
| | 6. Body ECU | - |
| "High beam" does not go off | 1. Light control switch circuit | LI-60 |
| | 2. Headlight (HI-BEAM) circuit | LI-43 |
| | 3. Front controller | - |
| "Flash" does not come on. (Low beam and Hi-Beam are normal) | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. Body ECU | - |
| Tail light does not come on (All). | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. TAIL relay circuit | LI-84 |
| | 4. Body ECU | - |
| Only one tail light comes on. | 1. Bulb | - |
| | 2. Wire harness or connector | - |
| Daytime running light system does not operate. | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. Generator signal circuit | LI-75 |
| | 4. Parking brake switch circuit | LI-81 |
| | 5. Ignition switch circuit | LI-34 |
| | 6. Headlight (HI-BEAM) circuit | LI-43 |
| | 7. Front controller | - |
| | 8. Body ECU | - |

2. HEADLIGHT BEAM LEVEL CONTROL SYSTEM

| Symptom | Suspected area | See page |
|--|---|----------|
| Headlight beam level control system does not operate. | 1. Headlight beam level control actuator circuit | LI-99 |
| | 2. Height control sensor circuit | LI-96 |
| | 3. Headlight beam level control ECU communication circuit | LI-89 |
| | 4. Headlight beam level control ECU power source circuit | LI-93 |
| | 5. Headlight beam level control ECU | LI-160 |
| Headlight beam warning light comes on. (Headlight beam level control system is normal) | 1. Headlight beam level warning circuit | LI-105 |
| | 2. Combination meter assembly | - |
| | 3. Headlight beam level control ECU | LI-160 |
| Headlight beam warning light does not come on. (Headlight beam level control system is normal) | 1. Headlight beam level warning circuit | LI-105 |
| | 2. Combination meter assembly | - |
| | 3. Headlight beam level control ECU | LI-160 |

3. AUTOMATIC LIGHT CONTROL SYSTEM

| Symptom | Suspected area | See page |
|--|--|----------|
| Automatic light control system does not operate. | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. Ignition switch circuit | LI-34 |
| | 4. Automatic light control sensor circuit | LI-32 |
| | 5. Body ECU | - |

4. LIGHT AUTO TURN OFF SYSTEM

| Symptom | Suspected area | See page |
|--|--|----------|
| Light auto turn off system does not operate. | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. Ignition switch circuit | LI-34 |
| | 4. Door courtesy switch circuit | LI-65 |
| | 5. Front controller | - |
| | 6. Body ECU | - |

5. FOG LIGHT SYSTEM

| Symptom | Suspected area | See page |
|---|--|----------|
| Front fog light does not come on with the light control switch in TAIL or HEAD position (TAIL and HEAD are normal). | 1. Combination switch ECU power source circuit | LI-102 |
| | 2. Light control switch circuit | LI-60 |
| | 3. Front fog light circuit | LI-46 |
| | 4. Body ECU | - |
| Only one front fog light does not come on. | 1. Bulb | - |
| | 2. Wire harness or connector | - |

6. TURN SIGNAL AND HAZARD WARNING SYSTEM

| Symptom | Suspected area | See page |
|---|----------------------------------|----------|
| Hazard warning light does not come on (Turn is normal). | 1. Hazard warning switch circuit | LI-58 |
| | 2. Turn signal flasher assembly | LI-161 |
| Turn signal light does not come on. | 1. Light control switch circuit | LI-60 |
| | 2. Turn signal light circuit | LI-53 |
| | 3. Body ECU | - |
| Only one bulb does not come on. | 1. Bulb | - |
| | 2. Turn signal light circuit | LI-53 |

7. STOP LIGHT SYSTEM

| Symptom | Suspected area | See page |
|---------------------------------------|------------------------------|------------------------|
| Stop light does not operate (All). | 1. Bulb | - |
| | 2. Stop light switch | LI-151 |
| | 3. Wire harness or connector | - |
| Only one stop light does not come on. | 1. Bulb | - |
| | 2. Wire harness or connector | - |

8. ILLUMINATED ENTRY SYSTEM

| Symptom | Suspected area | See page |
|---|---------------------------------|-----------------------|
| Illuminated entry of Multiplex network body ECU control does not operate (All). | 1. Ignition switch circuit | LI-34 |
| | 2. Door lock position circuit | LI-69 |
| | 3. Door courtesy switch circuit | LI-65 |
| | 4. Illumination circuit | LI-77 |
| | 5. Body ECU | - |


9. OTHERS

| Symptom | Suspected area | See page |
|---|-----------------------------------|------------------------|
| Vanity light does not come on. | 1. Bulb | - |
| | 2. Wire harness or connector | - |
| Back up light does not come on. | 1. Bulb | - |
| | 2. Park / neutral position switch | AX-126 |
| | 3. Wire harness or connector | - |
| Luggage compartment light does not come on. | 1. Bulb | - |
| | 2. Luggage room light circuit | LI-72 |
| | 3. Body ECU | - |
| Courtesy light does not come on. | 1. Bulb | - |
| | 2. Door courtesy switch circuit | LI-65 |
| | 3. Body ECU | - |
| Rear interior light does not come on. | 1. Bulb | - |
| | 2. Rear room light assembly | LI-141 |
| | 3. Door courtesy switch circuit | LI-65 |
| | 4. Wire harness or connector | - |
| | 5. Body ECU | - |

TERMINALS OF ECU

1. ENGINE ROOM J/B ASSEMBLY (FRONT CONTROLLER)

Front Controller:



H

E125617E11


| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|------------------------|-------------------|---|---------------------------------|---------------------|
| 1A-1 - 1H-8 | B - W-B | Battery (ALT fuse) | Always | 10 to 14 V |
| 1C-4 - 1H-8 | BR - W-B | Hi-beam circuit (To headlight LH) | Hi-beam is ON | 10 to 14 V |
| 1C-4 - 1H-8 | BR - W-B | Hi-beam circuit (To headlight LH) | Hi-beam is OFF | Below 1 V |
| 1C-5 - 1H-8 | G - W-B | Hi-beam circuit (To headlight RH) | Hi-beam is ON | 10 to 14 V |
| 1C-5 - 1H-8 | G - W-B | Hi-beam circuit (To headlight RH) | Hi-beam is OFF | Below 1 V |
| 1F-1 - 1H-8 | B - W-B | Battery (Power source circuit) | Always | 10 to 14 V (*1) |
| 1F-1 - 1H-8 | W - W-B | Battery (Power source circuit) | Always | 10 to 14 V (*2) |
| 1G-1 - Body ground | V - Body ground | Power source circuit | Always | 10 to 14 V |
| 1G-2 - Body ground | R - Body ground | Power source circuit | Always | 10 to 14 V |
| 1G-6 - 1H-8 | LG - W-B | HEAD signal (Front light control switch) | Light control switch is HEAD | 10 to 14 V |
| 1G-6 - 1H-8 | LG - W-B | HEAD signal (Front light control switch) | Light control switch isn't HEAD | Below 1 V |
| 1G-7 - Body ground | Y - Body ground | Multiplex communication signal circuit | Ignition switch on (IG) | Signal waveform |
| 1G-8 - Body ground | B - Body ground | Multiplex communication signal circuit | Ignition switch on (IG) | Signal waveform |
| 1H-2 - Body ground | W-B - Body ground | Body ground | Always | Below 1 V |
| 1H-3 - 1H-8 | P - W-B | HEAD signal (To headlight) | Headlight (low) is ON | 10 to 14 V |
| 1H-3 - 1H-8 | P - W-B | HEAD signal (To headlight) | Headlight (low) is OFF | Below 1 V |
| 1H-8 - Body ground | W-B - Body ground | Body ground | Always | Below 1 V |
| 1H-11 - 1H-8 | GR - W-B | HEAD signal (To headlight leveling control ECU) | Headlight (low) is ON | Below 1 V |
| 1H-11 - 1H-8 | GR - W-B | HEAD signal (To headlight leveling control ECU) | Headlight (low) is OFF | 10 to 14 V |

*1: with Smart Key System


*2: without Smart Key System

2. INSTRUMENT PANEL FUNCTION BLOCK ASSEMBLY (BODY ECU)

Front Side:



Back Side:



E111961E03

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|-----------------------------|--------------|-----------------------------------|----------------------------|---------------------|
| BATB (IA-1) - GND1 (IF-10) | B - W-B | Battery (Power source circuit) | Always | 10 to 14 V |
| PKB (IC-14) - GND1 (IF-10) | LG - W-B | Parking brake switch | Parking brake is depressed | Below 1 V |
| PKB (IC-14) - GND1 (IF-10) | LG - W-B | Parking brake switch | Parking brake is released | 10 to 14 V |
| BECU (ID-10) - GND1 (IF-10) | O - W-B | Battery (B+ circuit) | Always | 10 to 14 V |


| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|-----------------------------|-------------------|--|---|-----------------------------------|
| ALTB (ID-16) - GND1 (IF-10) | W - W-B | Battery (ALT fuse) | Always | 10 to 14 V |
| GND1 (IF-10) - Body ground | W-B - Body ground | Body ground | Always | Below 1 V |
| TRNR (II-5) - GND1 (IF-10) | L - W-B | RH side turn signal (To turn signal flasher assembly) | Ignition switch on (IG) and turn signal switch (right turn) OFF | 10 to 14 V |
| TRNR (II-5) - GND1 (IF-10) | L - W-B | RH side turn signal (To turn signal flasher assembly) | Ignition switch on (IG) and turn signal switch (right turn) ON | Below 1 V |
| ILE (II-10) - GND1 (IF-10) | BR (*1) - W-B | Key cylinder light (Illumination signal) | Ignition key cylinder light is OFF | 10 to 14 V |
| ILE (II-10) - GND1 (IF-10) | BR (*1) - W-B | Key cylinder light (Illumination signal) | Ignition key cylinder light is ON | Below 1 V |
| TRLY (IL-3) - GND1 (IF-10) | L (*2) - W-B | TAIL relay (TAIL signal) | Light control switch is OFF | Below 1 V |
| TRLY (IL-3) - GND1 (IF-10) | L (*2) - W-B | TAIL relay (TAIL signal) | Light control switch is TAIL and fog light switch is ON | 10 to 14 V |
| GND2 (IM-9) - GND1 (IF-10) | W-B - W-B | Body ground | Always | Below 1 Ω |
| LCTY (IO-7) - GND1 (IF-10) | B - W-B | Courtesy switch (Rear left door circuit) | Rear left door is open | Below 1 V |
| LCTY (IO-7) - GND1 (IF-10) | B - W-B | Courtesy switch (Rear left door circuit) | Rear left door is closed | Pulse generation (See waveform 1) |
| LSWL (IP-5) - GND1 (IF-10) | GR - W-B | Door lock position switch (Rear left door circuit) | Rear left door is in the unlock position | Below 1 V |
| LSWL (IP-5) - GND1 (IF-10) | GR - W-B | Door lock position switch (Rear left door circuit) | Rear left door is in the lock position | Pulse generation (See waveform 1) |
| ILE (IR-5) - GND1 (IF-10) | BR - W-B | Front interior illumination (Illumination signal) | Front interior light is OFF | 10 to 14 V |
| ILE (IR-5) - GND1 (IF-10) | BR - W-B | Front interior illumination (Illumination signal) | Front interior light is ON | Below 1 V |
| MPX1 (IR-9) - GND1 (IF-10) | B - W-B | Multiplex communication signal | Ignition switch off | Below 1 V |
| MPX (IR-9) - GND1 (IF-10) | B - W-B | Multiplex communication signal | Ignition switch on (IG) | Signal waveform |
| TRNL (D9-4) - GND1 (IF-10) | R - W-B | LH side turn signal (To turn signal flasher assembly) | Ignition switch on (IG) and turn signal switch (left turn) OFF | 10 to 14 V |
| TRNL (D9-4) - GND1 (IF-10) | R - W-B | LH side turn signal (To turn signal flasher assembly) | Ignition switch on (IG) and turn signal switch (left turn) ON | Below 1 V |
| FFGO (D9-7) - GND1 (IF-10) | G (*2) - W-B | Front fog relay (Front fog circuit) | Front fog light is OFF | 10 to 14 V |
| FFGO (D9-7) - GND1 (IF-10) | G (*2) - W-B | Front fog relay (Front fog circuit) | Front fog light is ON | Below 1 V |
| DCYL (D8-13) - GND1 (IF-10) | SB - W-B | Courtesy light (Front left door circuit) | Front left courtesy light is OFF | 10 to 14 V |
| DCYL (D8-13) - GND1 (IF-10) | SB - W-B | Courtesy light (Front left door circuit) | Front left courtesy light is ON | Below 1 V |
| DCTY (D8-14) - GND1 (IF-10) | L - W-B | Courtesy switch (Front left door circuit) | Front left door is open | Below 1 V |
| DCTY (D8-14) - GND1 (IF-10) | L - W-B | Courtesy switch (Front left door circuit) | Front left door is closed | 10 to 14 V |
| RCTY (D8-16) - GND1 (IF-10) | GR - W-B | Courtesy switch (Rear right door circuit) | Rear right door is open | Below 1 V |
| RCTY (D8-16) - GND1 (IF-10) | GR - W-B | Courtesy switch (Rear right door circuit) | Rear right door is closed | Pulse generation (See waveform 1) |

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|-----------------------------|---------------|--|--|-----------------------------------|
| HAZ (D7-2) - GND1 (IF-10) | P - W-B | HAZARD signal (Front hazard switch) | Hazard switch is OFF | 10 to 14 V |
| HAZ (D7-2) - GND1 (IF-10) | P - W-B | HAZARD signal (Front hazard switch) | Hazard switch is ON | Below 1 V |
| CLTE (D7-4) - GND1 (IF-10) | W - W-B | Automatic light control sensor (Ground circuit) | Always | Below 1 V |
| CLTS (D7-5) - GND1 (IF-10) | LG - W-B | Automatic light control sensor (Signal circuit) | Ignition switch on (IG) | Below 1 V |
| CLTS (D7-5) - GND1 (IF-10) | LG - W-B | Automatic light control sensor (Signal circuit) | Ignition switch off | 10 to 14 V |
| CLTB (D7-6) - GND1 (IF-10) | BR - W-B | Automatic light control sensor (Power source circuit) | Ignition switch off | 10 to 14 V |
| CLTB (D7-6) - GND1 (IF-10) | BR - W-B | Automatic light control sensor (Power source circuit) | Ignition switch on (IG) | Below 1 V |
| LSWR (D6-5) - GND1 (IF-10) | B - W-B | Door lock position switch (Rear right door circuit) | Rear right door is in the unlock position | Below 1 V |
| LSWR (D6-5) - GND1 (IF-10) | B - W-B | Door lock position switch (Rear right door circuit) | Rear right door is in the lock position | Pulse generation (See waveform 1) |
| CSPT (D6-14) - GND1 (IF-10) | LG (*3) - W-B | Overhead illumination circuit | Overhead console illumination is OFF | 10 to 14 V |
| CSPT (D6-14) - GND1 (IF-10) | LG (*3) - W-B | Overhead illumination circuit | Overhead console illumination is ON | Below 1 V |
| MPX2 (D6-21) - GND1 (IF-10) | BR - W-B | Multiplex communication signal | Ignition switch off | Below 1 V |
| MPX2 (D6-21) - GND1 (IF-10) | BR - W-B | Multiplex communication signal | Ignition switch on (IG) | Signal waveform |
| PCTY (D6-23) - GND1 (IF-10) | L - W-B | Courtesy switch (Front right door circuit) | Front right door is open | Below 1 V |
| PCTY (D6-23) - GND1 (IF-10) | L - W-B | Courtesy switch (Front right door circuit) | Front right door is closed | 10 to 14 V |
| PCYL (D6-24) - GND1 (IF-10) | O - W-B | Courtesy light (Front right door circuit) | Front right courtesy light is OFF | 10 to 14 V |
| PCYL (D6-24) - GND1 (IF-10) | O - W-B | Courtesy light (Front right door circuit) | Front right courtesy light is ON | Below 1 V |
| LGCY (D6-25) - GND1 (IF-10) | V - W-B | Courtesy switch (Back door circuit) | Back door is open | Below 1 V |
| LGCY (D6-25) - GND1 (IF-10) | V - W-B | Courtesy switch (Back door circuit) | Back door is closed | 10 to 14 V |
| LSWP (D6-27) - GND1 (IF-10) | GR - W-B | Door lock position switch (Front right door circuit) | Front right door is in the unlock position | Below 1 V |
| LSWP (D6-27) - GND1 (IF-10) | GR - W-B | Door lock position switch (Front right door circuit) | Front right door is in the lock position | 10 to 14 V |

*1: without Smart Key System

*2: with Front Fog Light

*3: with Sliding Roof




(a) Waveform 1

HINT:

- Gauge set:
5 V/DIV. 5 ms/DIV.
- Condition:
Ignition switch on (IG)

3. COMBINATION SWITCH ECU (WINDSHIELD WIPER SWITCH ASSEMBLY)

Combination Switch ECU:



H E074714E01


| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|----------------------------|-------------------|---|----------------------------------|----------------------|
| B (D13-1) - E (D13-5) | W - W-B | Power source circuit (Front battery) | Always | 10 to 14 V |
| IG (D13-2) - E (D13-5) | L - W-B | Ignition switch signal circuit (From ignition switch) | Ignition switch off | Below 1 V |
| IG (D13-2) - E (D13-5) | L - W-B | Ignition switch signal circuit (From ignition switch) | Ignition switch on (IG) | 10 to 14 V |
| HEAD (D13-4) - Body ground | LG - Body ground | Light control switch HEAD signal | Light control switch is not HEAD | 10 to 14 V |
| HEAD (D13-4) - Body ground | LG - Body ground | Light control switch HEAD signal | Light control switch is HEAD | Below 1 V |
| E (D13-5) - Body ground | W-B - Body ground | Ground | Always | Below 1 V |
| MPX1 (D13-6) - Body ground | BR - Body ground | Multiplex communication signal circuit | Ignition switch on (IG) | Signal waveform |
| MPX2 (D13-7) - Body ground | R - Body ground | Multiplex communication signal circuit | Ignition switch on (IG) | Signal waveform (*1) |
| MPX2 (D13-7) - Body ground | B - Body ground | Multiplex communication signal circuit | Ignition switch on (IG) | Signal waveform (*2) |

*1: with Smart Key System

*2: without Smart Key System

4. HEADLIGHT BEAM LEVEL CONTROL ECU

Headlight Beam Level Control ECU:




H I041578E01

| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|-------------------------------|-------------------|--|---|-----------------------------------|
| E1 (A21-1) - Body ground | W-B - Body ground | Ground | Always | Below 1 V |
| SPDL (A21-5) - E1 (A21-1) | Y - W-B | Vehicle speed signal (From the skid control ECU) | Vehicle is driven at approx. 30 km/h (19 mph) | Pulse generation (See waveform 1) |
| SPDR (A21-6) - E1 (A21-1) | R - W-B | Vehicle speed signal (From the skid control ECU) | Vehicle is driven at approx. 30 km/h (19 mph) | Pulse generation (See waveform 1) |
| B2 (A21-7) - E1 (A21-1) | GR - W-B | HEAD relay operation signal | HEAD relay is ON | Below 1 V |
| B2 (A21-7) - E1 (A21-1) | GR - W-B | HEAD relay operation signal | HEAD relay is OFF | 10 to 14 V |
| CHG- (A21-8) - E1 (A21-1) | L - W-B | Generator signal circuit | Engine is running | 10 to 14 V |
| CHG- (A21-8) - E1 (A21-1) | L - W-B | Generator signal circuit | Engine is stopped | Below 1 V |
| LR2+ (A21-10) - LR2- (A21-9) | LG - W | Headlight beam level control motor RH (Operation signal circuit) | Ignition switch off | Below 1 V |
| LR2+ (A21-10) - LR2- (A21-9) | LG - W | Headlight beam level control motor RH (Operation signal circuit) | Engine is running, change vehicle height and keep it for more than 1 second. | Pulse generation (See waveform 2) |
| LR1+ (A21-12) - LR1- (A21-11) | B - BR | Headlight beam level control motor RH (Operation signal circuit) | Ignition switch off | Below 1 V |
| LR1+ (A21-12) - LR1- (A21-11) | B - BR | Headlight beam level control motor RH (Operation signal circuit) | Engine is running, change vehicle height and keep it for more than 1 second. | Pulse generation (See waveform 2) |
| IG (A21-14) - E1 (A21-1) | G - W-B | Power source circuit (From engine switch (IG)) | Ignition switch off | Below 1 V |
| IG (A21-14) - E1 (A21-1) | G - W-B | Power source circuit (From engine switch (IG)) | Ignition switch on (IG) | 10 to 14 V |
| SGR (A21-17) - E1 (A21-1) | V - W-B | Height control sensor (Ground circuit) | Always | Below 1 V |
| INIT (A21-18) - E1 (A21-1) | W - W-B | Initialize signal input terminal | Ignition switch off | Below 1 V |
| INIT (A21-18) - E1 (A21-1) | W - W-B | Initialize signal input terminal | Ignition switch on (IG) | Approx. 5.0 V |
| SHRL (A21-19) - E1 (A21-1) | L - W-B | Height control sensor (Signal circuit) | Ignition switch off | Below 1 V |
| SHRL (A21-19) - E1 (A21-1) | L - W-B | Height control sensor (Signal circuit) | Ignition switch on (IG) | 0.5 to 4.5 V |
| SBR (A21-21) - E1 (A21-1) | B - W-B | Height control sensor (Power source circuit) | Ignition switch off | Below 1 V |
| SBR (A21-21) - E1 (A21-1) | B - W-B | Height control sensor (Power source circuit) | Ignition switch on (IG) | Approx. 5.0 V |
| WNG (A21-26) - E1 (A21-1) | V - W-B | Headlight beam level warning indicator signal (To combination meter) | Headlight beam level warning indicator comes on | Below 1 V |
| WNG (A21-26) - E1 (A21-1) | V - W-B | Headlight beam level warning indicator signal (To combination meter) | Headlight beam level warning indicator goes off | 10 to 14 V |
| LL2+ (A21-29) - LL2- (A21-28) | GR - R | Headlight beam level control motor LH (Operation signal circuit) | Ignition switch off | Below 1 V |
| LL2+ (A21-29) - LL2- (A21-28) | GR - R | Headlight beam level control motor LH (Operation signal circuit) | With the ignition switch on (IG), change vehicle height and keep it for more than 1 second. | Pulse generation (See waveform 2) |
| LL1+ (A21-31) - LL1- (A21-30) | L-B - O | Headlight beam level control motor LH (Operation signal circuit) | Ignition switch off | Below 1 V |




| Symbols (Terminal No.) | Wiring Color | Terminal Description | Condition | Specified Condition |
|-------------------------------|--------------|--|---|-----------------------------------|
| LL1+ (A21-31) - LL1- (A21-30) | L-B - O | Headlight beam level control motor LH (Operation signal circuit) | With the ignition switch on (IG), change vehicle height and keep it for more than 1 second. | Pulse generation (See waveform 2) |



(a) Waveform 1

HINT:

- Terminal: SPDR - GND
- Gauge set: 5 V/DIV. 2 ms/DIV.
- Condition: Vehicle is driven at approximately 30 km/h (19 mph).




(b) Waveform 2

HINT:

- Terminal: LL1+ - LL1-
LL2+ - LL2-
LR1+ - LR1-
LR2+ - LR2-
- Gauge set: 10 V/DIV. 5 ms/DIV.
- Condition: The light control switch is in the HEAD position when the vehicle is standing still or bouncing.

DIAGNOSIS SYSTEM



1. CHECK DLC3

- (a) Inspect the battery voltage.

Voltage:

12 to 14 V

If the voltage is below 12 V, recharge the battery before proceeding.

- (b) Check the DLC3.


The terminal arrangement of the DLC3 complies with SAE J1962 and matches the ISO 9141-2 format.

Standard voltage

| Symbols (Terminal No.) | Terminal Description | Condition | Specified Condition |
|------------------------|----------------------|-----------|---------------------|
| BAT (16) - Body ground | Battery positive | Always | 10 to 14 V |

Standard resistance

| Symbols (Terminal No.) | Terminal Description | Condition | Specified Condition |
|------------------------|----------------------|-----------|---------------------|
| CG (4) - Body ground | Chassis ground | Always | Below 1 Ω |



DTC CHECK / CLEAR

1. DTC CHECK

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG).
- (c) Read DTCs by following the prompts on the tester screen.

HINT:

Refer to the intelligent tester operator's manual for further details.

2. DTC CLEAR

- (a) DTCs can be cleared by operating the intelligent tester.

HINT:

Refer to the intelligent tester operator's manual for further details.



FAIL-SAFE CHART

1. LIGHT CONTROL COMPUTER (HID)

| Trouble Area | Condition |
|---|---|
| High voltage circuit open | Lighting of the headlight stops, the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| Short between high voltage circuits | Lighting of the headlight stops within 1 second and the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| Leakage between high voltage terminal and body ground | Lighting of the headlight stops, the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| Low light voltage | Lighting of the headlight stops, the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| High light voltage | Lighting of the headlight stops, the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| Bulb flashing | <ul style="list-style-type: none"> The condition is maintained more than 60 seconds. Lighting of the headlight stops, the condition is maintained until power is turned on again (headlight dimmer switch OFF → ON). |
| Battery voltage high | As soon as the voltage comes within the range of operation voltage (9 to 16 V), the headlight comes on again. |
| Battery voltage low | <p>Even when voltage changes from 9.5 V to 7.5 V, lighting condition is maintained. Lighting condition changes when voltage is too low (below 6 V).</p> <p>As soon as the voltage comes back within the range of operation voltage (more than 9 V), the headlights come on again.</p> |

2. HEADLIGHT BEAM LEVEL CONTROL ECU

HINT:

- The headlight beam level control ECU performs fail-safe when detecting the following troubles. The headlight beam level control warning indicator light on the combination meter comes on at the same time.
- If the headlight beam level control warning indicator light comes on, inspect and repair in accordance with the "PROBLEM SYMPTOMS TABLE" (See page LI-18).

| Trouble area | Headlight beam level control motor | Warning indicator light | Recovery condition |
|------------------------------------|---|-------------------------|--------------------------|
| Height control sensor power source | <ul style="list-style-type: none"> Stops operation after returning to initial position (Fail occurs at higher than initial position) Stops at current position (Fail occurs at lower than initial position) | Comes on | Ignition switch off |
| Height control sensor signal | <ul style="list-style-type: none"> Stops operation after returning to initial position (Fail occurs at higher than initial position) Stops at current position (Fail occurs at lower than initial position) | Comes on | Return to normal signals |
| Headlight beam level control motor | <ul style="list-style-type: none"> Stops operation after returning to initial position (Fail occurs at higher than initial position) (*1) Stops at current position (Fail occurs at lower than initial position) (*1) | Comes on | Ignition switch off |
| Alternator signal | Control continues | Comes on | Ignition switch off |

HINT:

*1: The inoperative side stops at current position.

DATA LIST / ACTIVE TEST

1. DATA LIST

HINT:

Using the DATA LIST displayed on the intelligent tester, you can read the values of the switch, sensor, actuator, etc. without removing any parts. Reading the DATA LIST as the first step of troubleshooting is one of the methods to shorten labor time.

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG).
- (c) According to the display on the tester, read the "DATA LIST".

BODY ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|------------------|--|---|-----------------|
| ACC SW | ACC SW signal / ON or OFF | ON: Ignition switch on (IG) or (ACC) OFF: Ignition switch off | - |
| IG SW | IG SW signal / ON or OFF | ON: Ignition switch on (IG) or START OFF: Ignition switch off or Ignition switch on (ACC) | - |
| D DOR CTY SW | Driver's door courtesy SW signal / ON or OFF | ON: Driver's door is open OFF: Driver's door is closed | - |
| P DOR CYT SW | Passenger's door courtesy SW signal / ON or OFF | ON: Front passenger's door is open OFF: Front passenger's door is closed | - |
| Rr DOR CTY SW | Rear door courtesy SW signal / ON or OFF | ON: Either right or left rear door is open OFF: Both the right and left doors are closed | - |
| P LOCK POS SW | Front passenger's door lock position SW signal / ON or OFF | ON: Front passenger's door lock is in the unlock position OFF: Front passenger's door lock is in the lock position | - |
| Rr. LOCK POS SW | Rear door lock position SW signal / ON or OFF | ON: Rear door lock is in the unlock position OFF: Rear door lock is in the lock position | - |
| D LOCK POS SW | Driver's door lock position SW signal / ON or OFF | ON: Door lock is in the unlock position OFF: Door lock is in the lock position | - |
| ILLUMINATE RATE | Illuminate rate / (0.8 ms - 22.0 ms) | Value is output according to ambient light | - |
| LIGHTING TIME | Lighting time / 7.5 s, 15 s or 30 s | Customized value will be displayed | - |
| ILLUMI SYSTEM | Illumination system / ON or OFF | ON: Illumination operation is ON OFF: Illumination operation is OFF | - |
| LIGHT CONTROL | Light control / ON or OFF | ON: Light control system is ON OFF: Light control system is OFF | - |
| I/L ON / ACC OFF | Light the I/L when ACC OFF / ON or OFF | Customized value will be displayed | - |
| I/L ON / UNLOCK | Interior light ON w/ unlock / ON or OFF | Customized value will be displayed | - |
| LIGHT CTRL TYPE | Light control type / CURRENT or OLD | Customized value will be displayed | - |
| LIGHT OFF DELAY | Light auto OFF delay / OFF, 30 s, 60 s, 90 s | Customized value will be displayed | - |
| DRL FUNCTION | DRL function / OFF or ON | Customized value will be displayed | - |
| PARKING BRAKE SW | Parking brake / OFF or ON | ON: Parking brake pedal is ON OFF: Parking brake pedal is OFF | - |

COMBINATION SW ECU (WINDSHIELD WIPER SWITCH ASSEMBLY):

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|----------------|------------------------------------|--|-----------------|
| R FOG LIGHT SW | Rear fog light switch / ON or OFF | ON: Rear fog light switch is in the ON position OFF: Rear fog light switch is in the OFF position | - |

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|-----------------|--|--|-----------------|
| F FOG LIGHT SW | Front fog light switch / ON or OFF | ON: Front fog light switch is in the ON position OFF: Front fog light switch is in the OFF position | - |
| HIGH FLASHER SW | Passing light switch / ON or OFF | ON: Headlight dimmer switch is in the FLASH position OFF: Headlight dimmer switch is in except the FLASH position | - |
| DIMMER HI SW | High beam switch / ON or OFF | ON: Headlight dimmer switch is in the HI position OFF: Headlight dimmer switch is in except the HI position | - |
| LIGHT AUTO SW | Auto light switch / ON or OFF | ON: Light control switch is in the AUTO position OFF: Light control switch is in except the AUTO position | - |
| HEAD LIGHT SW | Headlight control switch / ON or OFF | ON: Light control switch is in the HEAD position OFF: Light control switch is in except the HEAD position | - |
| TAIL LIGHT SW | Tail light switch / ON or OFF | ON: Light control switch is in the TAIL or HEAD position OFF: Light control switch is in the OFF position | - |
| TURN LEFT SW | Turn signal switch LH signal / ON or OFF | ON: Turn signal switch is in the LH position OFF: Turn signal switch is in the OFF position | - |
| TURN LIGHT SW | Turn signal switch RH signal / ON or OFF | ON: Turn signal switch is in the RH position OFF: Turn signal switch is in except the RH position | - |
| IG SW SIG | Ignition switch signal / ON or OFF | ON: Ignition switch on (IG) OFF: Ignition switch off | - |

BODY NO. 5 (FRONT CONTROLLER):

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|--------------|--|--|-----------------|
| ALT L SIGNAL | Alternator L terminal signal / ON or OFF | ON: Engine start OFF: Except engine start | - |

2. ACTIVE TEST**HINT:**

Performing the ACTIVE TEST using the intelligent tester allows the relay, VSV, actuator, etc. to operate without removing any parts. Performing the ACTIVE TEST as the first step of troubleshooting is one of the methods to shorten labor time. The DATA LIST can be displayed during the ACTIVE TEST.

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG).
- (c) According to the display on the tester, perform the "ACTIVE TEST".

BODY ECU:

| Item | Test Details | Diagnostic Note |
|-----------------|--|-----------------|
| HAZARD | Hazard ON / OFF | - |
| F FOG LIGHT RLY | Front fog light relay ON / OFF | - |
| TRN SIG LGT R | Turn signal light RH relay operation ON / OFF | - |
| TRN SIG LGT L | Turn signal light LH relay operation ON / OFF | - |
| TAIL LIGHT | Tail light relay ON / OFF | - |
| DIMMER SIG | Dimmer signal ON / OFF | - |
| ILLUMI OUTPUT | (Test Details) Interior light and key illumination ON / OFF (Vehicle Condition) Interior light SW is in the DOOR position and all doors are closed | - |
| CONSOLE LIGHT | Turn the center console illumination ON / OFF | - |
| STEP LIGHT | Turn the step light and inside handle illumination ON / OFF | - |

BODY NO. 5 (FRONT CONTROLLER):

| Item | Test Details | Diagnostic Note |
|-----------------|--------------------------------|-----------------|
| HEAD LIGHT (LO) | Light head (low) ON / OFF | - |
| HEAD LIGHT (HI) | Light head (high) ON / OFF | - |
| DRL OPERT | Light head (high) DRL ON / OFF | - |

DIAGNOSTIC TROUBLE CODE CHART**LIGHTING SYSTEM**

| DTC No. | Detection Item | Trouble Area | See page |
|---------|----------------------------------|--|-----------------------|
| B1244 | Light Sensor Circuit Malfunction | 1. Automatic light control sensor 2. Wire harness or connector 3. Body ECU | LI-32 |


| | | |
|------------|--------------|---|
| DTC | B1244 | Light Sensor Circuit Malfunction |
|------------|--------------|---|

DESCRIPTION

This DTC is output when failure in the light sensor circuit is detected.

| DTC No. | DTC Detecting Condition | Trouble Area |
|---------|--|---|
| B1244 | <ul style="list-style-type: none"> • Malfunction of the automatic light control sensor • Open or short in the automatic light control sensor circuit | <ul style="list-style-type: none"> • Automatic light control sensor • Wire harness or connector • Body ECU |

WIRING DIAGRAM



INSPECTION PROCEDURE

| | |
|----------|---|
| 1 | READ VALUE OF INTELLIGENT TESTER |
|----------|---|

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the DATA LIST, and read the displays on the intelligent tester.

BODY NO. 1 (BODY ECU):


| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|-----------------|--------------------------------------|--|-----------------|
| ILLUMINATE RATE | Illuminate rate / (0.8 ms - 22.0 ms) | Value is output according to ambient light | - |

| | |
|-----------|---------------------|
| NG | Go to step 2 |
|-----------|---------------------|

OK

REPLACE AUTOMATIC LIGHT CONTROL SENSOR

2 CHECK HARNESS AND CONNECTOR (BODY ECU - AUTOMATIC LIGHT CONTROL SENSOR)



- (a) Disconnect the automatic light control sensor connector and B6 connector of the multiplex network body ECU.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------------|-----------|---------------------|
| CLTE (F1-3) - CLTE (D7-4) | Always | Below 1 Ω |
| CLTS (F1-5) - CLTS (D7-5) | Always | Below 1 Ω |
| CLTB (1F-6) - CLTB (D7-6) | Always | Below 1 Ω |
| CLTE (D7-4) - Body ground | Always | 10 kΩ or higher |
| CLTS (D7-5) - Body ground | Always | 10 kΩ or higher |
| CLTB (D7-6) - Body ground | Always | 10 kΩ or higher |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

3 INSPECT AUTOMATIC LIGHT CONTROL SENSOR

- (a) Inspect automatic light control sensor (See page [LI-155](#)).

OK:

Automatic light control sensor is normal.

NG → **REPLACE AUTOMATIC LIGHT CONTROL SENSOR**


OK

REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

Ignition Switch Circuit**DESCRIPTION**

This circuit detects the state of the ignition switch and sends it to the multiplex network body ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

BODY ECU:


| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|--------|------------------------------------|---|-----------------|
| ACC SW | ACC SW signal / ON or OFF | ON: Ignition switch on (IG) or (ACC) OFF: Ignition switch off | - |
| IG SW | IG SW signal / ON or OFF | ON: Ignition switch on (IG) OFF: Ignition switch off or Ignition switch on (ACC) | - |

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE


2 INSPECT RELAY



- (a) Inspect ACC relay continuity.
 - (1) Remove the ACC relay from the instrument panel J/ B.
 - (2) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Specified Condition |
|-------------------|--|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1 - 2) |




- (b) Inspect IG1 relay continuity.
 - (1) Remove the IG1 relay from the instrument panel J/ B.
 - (2) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Specified Condition |
|-------------------|--|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1 - 2) |

NG → **REPLACE RELAY**

OK



Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|-----------|---------------------|
| II-4 - Body ground | Always | 10 to 14 V |

NG → **REPLACE INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY**

OK

5 CHECK HARNESS AND CONNECTOR (INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY - BODY GROUND)

- (a) Disconnect the connector 1F from the instrument panel junction block assembly.
- (b) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| IF-10 - Body ground | Always | Below 1 Ω |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

6 CHECK HARNESS AND CONNECTOR (IGNITION SWITCH CIRCUIT)

(a) Inspect the harness and connectors related to ignition switch, referring to the wiring diagram.

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Headlight Relay Circuit

DESCRIPTION

The front controller controls the HEAD relay when a signal is received from the headlight dimmer switch assembly.

WIRING DIAGRAM



*1: with Smart Key System *2: without Smart Key System *3: HID Type *4: Except HID Type

INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check the relay operation.

BODY NO. 5 (FRONT CONTROLLER):

| Item | Test Details | Diagnostic Note |
|-----------------|---------------------------|-----------------|
| HEAD LIGHT (LO) | Light head (low) ON / OFF | - |


OK:
Headlights come on.

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT RELAY



- (a) Remove the HEAD relay from the engine room R/B & J/ B.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance


| Tester Connection | Specified Condition |
|-------------------|--|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1 - 2) |

NG → **REPLACE RELAY**

OK

3 CHECK HARNESS AND CONNECTOR (BATTERY - FRONT CONTROLLER)

- (a) Disconnect the 1H connector from the front controller.
- (b) Measure the voltage according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|--------------------|-----------|---------------------|
| 1H-3 - Body ground | Always | 10 to 14 V |


NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

4 CHECK HARNESS AND CONNECTOR (HEAD RELAY - BODY GROUND)

- (a) Using a service wire, connect the 1H-3 on the wire harness side and body ground.

OK:
Headlight comes on.



NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Headlight (HI-BEAM) Circuit

DESCRIPTION

The front controller receives headlight HI switch information from the combination switch, and turns on the headlights.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

(a) Connect the intelligent tester to the DLC3.

- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the items below in the ACTIVE TEST and then check the headlight operation.

BODY NO. 5 (FRONT CONTROLLER):

| Item | Test Details | Diagnostic Note |
|-----------------|--------------------------------|-----------------|
| HEAD LIGHT (HI) | Light head (high) ON / OFF | - |
| DRL OPERT | Light head (high) DRL ON / OFF | - |

OK:
High beam comes on.


NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 CHECK HARNESS AND CONNECTOR (BATTERY - FRONT CONTROLLER)

- (a) Measure the voltage according to the value(s) in the table below.



Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|-----------|---------------------|
| 1F-1 - Body ground | Always | 10 to 14 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

3 INSPECT ENGINE ROOM JUNCTION BLOCK ASSEMBLY

- (a) Measure the voltage according to the value(s) in the table below.



Standard voltage

| Tester Connection | Condition | Specified Condition |
|--------------------|---|---------------------|
| 1C-4 - Body ground | Ignition switch on (IG), headlight dimmer switch in the HI position | 10 to 14 V |
| 1C-5 - Body ground | Ignition switch on (IG), headlight dimmer switch in the HI position | 10 to 14 V |

NG

REPLACE ENGINE ROOM JUNCTION BLOCK ASSEMBLY (FRONT CONTROLLER)

OK


REPAIR OR REPLACE HARNESS OR CONNECTOR (FRONT CONTROLLER - BODY GROUND)

Front Fog Light Circuit

DESCRIPTION

The multiplex network body ECU controls the FOG relay when a signal is received from the headlight dimmer switch assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check that the relay operates.

BODY ECU:

| Item | Test Details | Diagnostic Note |
|-----------------|--------------------------------|-----------------|
| F FOG LIGHT RLY | Front fog light relay ON / OFF | - |

OK:


Front fog lights come on.

NG → **Go to step 2**

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT RELAY



- (a) Inspect front fog relay continuity.
 - (1) Remove the front fog relay from the instrument panel J/B.
 - (2) Measure the resistance according to the value(s) in the table below.
- Standard resistance**

| Tester Connection | Specified Condition |
|-------------------|---|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1- 2) |



- (b) Inspect TAIL relay continuity.
 - (1) Remove the tail relay from the instrument panel J/B.
 - (2) Measure the resistance according to the value(s) in the table below.
- Standard resistance**


| Tester Connection | Specified Condition |
|-------------------|---|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1- 2) |
| 3 - 4 | Below 1 Ω (When battery voltage is applied to terminal 1- 2) |

NG → **REPLACE RELAY**

OK

3 INSPECT HARNESS AND CONNECTOR (BATTERY - INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY)

(a) Measure the voltage according to the value(s) in the table below.



Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|-----------|---------------------|
| IA-1 - Body ground | Always | 10 to 14 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

4 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

(a) Measure the voltage according to the value(s) in the table below.



Standard voltage

| Tester Connection | Condition | Specified Condition |
|--------------------|---|------------------------|
| IC-1 - Body ground | Light control switch TAIL and Front fog light switch OFF → ON | Below 1 V → 10 to 14 V |
| ID-5 - Body ground | Light control switch TAIL and Front fog light switch OFF → ON | Below 1 V → 10 to 14 V |


NG → **Go to step 5**

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR

5 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

(a) Measure the voltage according to the value(s) in the table below.



Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|---------------------------------|------------------------|
| IL-3 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |

NG → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

OK

6 CHECK HARNESS AND CONNECTOR (INSTRUMENT JUNCTION BLOCK ASSEMBLY CIRCUIT)

- (a) Measure the voltage according to the value(s) in the table below.



H

E068612E30

Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|---------------------------------|------------------------|
| IL-4 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

7 CHECK HARNESS AND CONNECTOR (BODY ECU - INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY)

- (a) Disconnect the D9 connector of the multiplex network body ECU and the II connector of the instrument panel junction block assembly.
- (b) Measure the resistance according to the value(s) in the table below.



H E068613E16


Standard resistance

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------|---------------------|
| D9-7 - II-8 | Always | Below 1 Ω |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check the turn signal light operation.

BODY ECU:

| Item | Test Details | Diagnostic Note |
|----------------------|-------------------------------|-----------------|
| Turn signal light RH | Turn signal light RH ON / OFF | - |
| Turn signal light LH | Turn signal light LH ON / OFF | - |

OK:


Turn signal light comes on.

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 CHECK HARNESS AND CONNECTOR (BATTERY - TURN SIGNAL FLASHER ASSEMBLY)



- (a) Disconnect the connector from the turn signal flasher.
- (b) Measure the voltage according to the value(s) in the table below.


Standard voltage

| Tester Connection | Condition | Specified Condition |
|-------------------------|-----------|---------------------|
| B (D19-4) - Body ground | Always | 10 to 14 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

3 CHECK HARNESS AND CONNECTOR (IGNITION SWITCH CIRCUIT)




- (a) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|--------------------------|-------------------------|---------------------|
| IG (D19-1) - Body ground | Ignition switch on (IG) | 10 to 14 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

4 CHECK HARNESS AND CONNECTOR (TURN SIGNAL FLASHER ASSEMBLY - BODY GROUND)

- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|------------------------|-----------|---------------------|
| E (D19-7)- Body ground | Always | Below 1 Ω |

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

5 INSPECT TURN SIGNAL FLASHER ASSEMBLY


- (a) Inspect turn signal flasher assembly.

OK:**Turn signal flasher assembly is normal.**


NG

REPLACE TURN SIGNAL FLASHER ASSEMBLY

OK

6 CHECK HARNESS AND CONNECTOR (TURN SIGNAL FLASHER ASSEMBLY - INSTRUMENT PANEL JUNCTION)

- (a) Disconnect the turn signal flasher connector.
 (b) Disconnect connectors II and D9 from the instrument panel J/B assembly.
 (c) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| EL (D19-5) - TRNL (D9-4) | Always | Below 1 Ω |
| ER (D19-6) - TRNR (II-5) | Always | Below 1 Ω |
| EL (D19-5) - Body ground | Always | 10 kΩ or higher |
| ER (D19-6) - Body ground | Always | 10 kΩ or higher |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

7 INSPECT HARNESS AND CONNECTOR (EACH TURN SIGNAL LIGHT CIRCUIT)

(a) Inspect the harness and connectors related to each turn signal light, referring to the wiring diagram.

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Hazard Warning Switch Circuit

DESCRIPTION


The hazard warning switch sends a signal to the turn signal flasher relay.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT HARNESS AND CONNECTOR (TURN SIGNAL FLASHER ASSEMBLY - BODY GROUND)



- (a) Disconnect the connector of the turn signal flasher assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------------|---------------------------|---------------------|
| HAZ (D19-8) - Body ground | Hazard warning switch OFF | 10 kΩ or higher |
| HAZ (D19-8) - Body ground | Hazard warning switch ON | Below 1 Ω |

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2**INSPECT HAZARD WARNING SIGNAL SWITCH ASSEMBLY**

- (a) Inspect hazard warning signal switch assembly (See page [LI-150](#)).

OK:

Hazard warning switch is normal.


NG**REPLACE HAZARD WARNING SIGNAL
SWITCH ASSEMBLY****OK****REPAIR OR REPLACE HARNESS OR CONNECTOR (HAZARD WARNING SWITCH CIRCUIT)****LI**

Light Control Switch Circuit

DESCRIPTION

The combination switch ECU receives the informations of the light control switch, and sends them to each ECU via multiplex communication system.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

COMBINATION SWITCH ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|-----------------|---|--|-----------------|
| DIMMER SW | Headlight dimmer SW signal / ON or OFF | ON: Headlight dimmer switch is in the HI or FLASH position OFF: Headlight dimmer switch is in the LO position | - |
| HIGH FLASHER SW | Headlight dimmer SW signal / ON or OFF | ON: Headlight dimmer switch is in the FLASH position OFF: Headlight dimmer switch is in except the FLASH position | - |
| F FOG LIGHT SW | Front fog light SW signal / ON or OFF | ON: Front fog light switch is in the ON position OFF: Front fog light switch is in the OFF position | - |
| AUTO LIGHT SW | Auto light SW signal / ON or OFF | ON: Headlight dimmer switch is in the AUTO position OFF: Headlight dimmer switch is in except the AUTO position | - |
| HEAD LIGHT SW | Headlight control SW signal / ON or OFF | ON: Light control switch is in the HEAD position OFF: Light control switch is in except the HEAD position | - |
| TAIL LIGHT SW | Tail light SW signal / ON or OFF | ON: Light control switch is in the TAIL or HEAD position OFF: Light control switch is in the OFF position | - |

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT HEADLIGHT DIMMER SWITCH ASSEMBLY

- (a) Inspect headlight dimmer switch assembly (See page LI-148).

OK:

Headlight dimmer switch assembly is normal.

NG

REPLACE HEADLIGHT DIMMER SWITCH ASSEMBLY

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Headlight Signal Circuit

DESCRIPTION


The front controller receives the HEAD position signal of the light control switch. It also receives the signal from the combination SW ECU via multiplex communication system.

WIRING DIAGRAM




INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR



- Disconnect connector 1G from the driver side junction block.
- Disconnect the connector from the combination SW ECU.
- Measure the resistance according to the value(s) in the table below.




Standard resistance

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------|---------------------|
| 1G-6 - D13-4 | Always | Below 1 Ω |

NG → REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 INSPECT WINDSHIELD WIPER SWITCH ASSEMBLY (COMBINATION SWITCH ECU)



(a) Measure the resistance according to the value(s) in the table below.


Standard resistance

| Tester Connection | Condition | Specified Condition |
|-------------------|--|---------------------|
| D13-4 - D13-5 | Light control switch in the HEAD position | Below 1 Ω |
| D13-4 - D13-5 | Light control switch in except the HEAD position | 10 kΩ or higher |

NG → REPLACE WINDSHIELD WIPER SWITCH ASSEMBLY

OK

3 CHECK HARNESS AND CONNECTOR (COMBINATION SWITCH ECU - BODY GROUND)



(a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| D13-5 - Body ground | Always | Below 1 Ω |

NG → REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE




Door Courtesy Switch Circuit

DESCRIPTION

The body ECU detects the condition of the door courtesy switch assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Start the inspection from step 1 when using the intelligent tester, and from step 2 when not using the intelligent tester.

| | |
|----------|---|
| 1 | READ VALUE OF INTELLIGENT TESTER |
|----------|---|

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

BODY ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|---------------|---|---|-----------------|
| D DOR CTY SW | Driver's door courtesy SW signal / ON or OFF | ON: Driver's door is open OFF: Driver's door is closed | - |
| P DOR CYT SW | Passenger's door courtesy SW signal / ON or OFF | ON: Front passenger's door is open OFF: Front passenger's door is closed | - |
| Rr DOR CTY SW | Rear slide door courtesy SW signal / ON or OFF | ON: Either right or left rear slide door is open OFF: Both the right and left slide doors are closed | - |

NG **Go to step 3**

OK

| | |
|----------|---|
| 2 | CHECK HARNESS AND CONNECTOR (EACH DOOR COURTESY LIGHT CIRCUIT) |
|----------|---|

- (a) Inspect the harness and connectors related to each light, referring to the wiring diagram.

NG **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

| | |
|----------|-------------------------------------|
| 3 | INSPECT DOOR COURTESY SWITCH |
|----------|-------------------------------------|

- (a) Inspect front door courtesy switch (See page [LI-152](#)).
- (b) Inspect rear door courtesy switch (See page [LI-153](#)).

OK:

Each door courtesy switch is normal.

NG **REPLACE DOOR COURTESY SWITCH**

OK

4 CHECK HARNESS AND CONNECTOR (EACH COURTESY SWITCH CIRCUIT)

- (a) Inspect the harness and connectors related to each courtesy switch, referring to the wiring diagram.


NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

Door LOCK Position Circuit

DESCRIPTION

This circuit detects the state of the door lock detection sensor and sends it to the body ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.

- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.

BODY NO. 1:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|-----------------|--|---|-----------------|
| P LOCK POS SW | Front passenger's door lock position SW signal / ON or OFF | ON: Front passenger's door lock is in the unlock position OFF: Front passenger's door lock is in the lock position | - |
| Rr. LOCK POS SW | Rear slide door lock position SW signal / ON or OFF | ON: Rear slide door lock is in the unlock position OFF: Rear slide door lock is in the lock position | - |
| D LOCK POS SW | Driver's door lock position SW signal / ON or OFF | ON: Door lock is in the unlock position OFF: Door lock is in the lock position | - |

LI

NG


Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2**INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY**

- (a) Measure the voltage according to the value(s) in the table below.



E120921E01

Standard voltage

| Tester Connection | Condition | Specified Condition |
|---------------------|--|------------------------|
| D6-27 - Body ground | Front passenger door locked → unlocked | Below 1 V → 10 to 14 V |
| D8-7 - Body ground | Front driver door locked → unlocked | Below 1 V → 10 to 14 V |
| D6-5 - Body ground | Rear RH door locked → unlocked | Below 1 V → 10 to 14 V |
| IP-5 - Body ground | Rear LH door locked → unlocked | Below 1 V → 10 to 14 V |

NG

GO TO POWER DOOR LOCK CONTROL SYSTEM

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Luggage Room Light Circuit

DESCRIPTION

The body ECU receives luggage compartment door information, and turns on the luggage compartment light.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- Select the item below in the DATA LIST, and read the displays on the intelligent tester.

BODY ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|-------------------------|------------------------------------|---|-----------------|
| Luggage Courtesy Switch | Luggage courtesy / ON or OFF | ON: Luggage compartment door is open OFF: Luggage compartment door is closed | - |

OK:

ON and OFF can be displayed in accordance with the luggage compartment door condition.

OK

Go to step 4

NG

2 INSPECT LUGGAGE COMPARTMENT DOOR LOCK ASSEMBLY

- (a) Inspect luggage compartment door lock assembly (See page LI-154).

OK:

Luggage compartment door lock assembly is normal.


NG

REPLACE LUGGAGE COMPARTMENT DOOR LOCK ASSEMBLY

OK

3 CHECK HARNESS AND CONNECTOR (INSTRUMENT PANEL J/B ASSEMBLY - BODY GROUND)

- (a) Disconnect the D6 connector from body ECU.
- (b) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|------------------------------------|---------------------|
| D6-25 - Body ground | Luggage compartment door is open | Below 1 Ω |
| D6-25 - Body ground | Luggage compartment door is closed | 10 kΩ or higher |


NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 CHECK HARNESS AND CONNECTOR (BATTERY - INSTRUMENT PANEL J/B ASSEMBLY)

- (a) Using a service wire, connect terminal D6-26 on the wire harness side and body ground.



OK:
Luggage room light comes on.

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Generator Signal Circuit

DESCRIPTION

The front controller receives an engine condition signal via the generator.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the DATA LIST, and read the displays on the intelligent tester.

BODY ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|--------------|--|--|-----------------|
| ALT L SIGNAL | Alternator L terminal signal / ON or OFF | ON: Engine start OFF: Except engine start | - |

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT GENERATOR ASSEMBLY

(a) Inspect generator assembly (See page CH-12).

OK:

Generator assembly is normal.


NG

CHECK AND REPLACE GENERATOR ASSEMBLY

OK

3 CHECK HARNESS AND CONNECTOR (GENERATOR - FRONT CONTROLLER)

(a) Measure the voltage according to the value(s) in the table below.



Standard voltage

| Tester Connection | Condition | Specified Condition |
|--------------------|----------------|---------------------|
| 1H-6 - Body ground | Engine running | 10 to 14 V |

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE


ILLUMINATION CIRCUIT

DESCRIPTION

The multiplex network body ECU controls the following illumination lights.

1. Ignition key cylinder light (w/o Smart Entry System)
2. Front interior light installed in personal light assembly

WIRING DIAGRAM



INSPECTION PROCEDURE

1. PERFORM ACTIVE TEST BY INTELLIGENT TESTER

(a) Connect the intelligent tester to the DLC3.

- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check the item operates.

BODY ECU:

| Item | Test Details | Diagnostic Note |
|---------------|--|-----------------|
| ILLUMI OUTPUT | (Test Details) Turn the interior light and key illumination ON / OFF (Vehicle Condition) Interior light SW is in the door position and all doors are closed | - |

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT INTERIOR LIGHT

- (a) Inspect ignition key cylinder light (See page [LI-144](#)).
- (b) Inspect personal light assembly (See page [LI-140](#)).

OK:

Each light is normal.


NG

REPLACE INTERIOR LIGHT

OK

3 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

- (a) Measure the voltage according to the value(s) in the table below.



E111961E04

Standard voltage

| Tester Connection | Condition | Specified Condition |
|---------------------|---|------------------------|
| II-10 - Body ground | All door is closed → Front or rear door is open | 10 to 14 V → Below 1 V |
| IR-5 - Body ground | All door is closed → Front or rear door is open | 10 to 14 V → Below 1 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR (EACH ILLUMINATE CIRCUIT)**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE




Parking Brake Switch Circuit

DESCRIPTION

The body ECU receives the parking brake switch signal.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the DATA LIST, and read the displays on the intelligent tester.

BODY ECU:

| Item | Measurement Item / Display (Range) | Normal Condition | Diagnostic Note |
|------------------|------------------------------------|--|-----------------|
| PARKING BRAKE SW | Parking brake / OFF or ON | ON: Parking brake pedal is ON OFF: Parking brake pedal is OFF | - |


NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT PARKING BRAKE SWITCH ASSEMBLY



- (a) Remove the parking brake switch.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance


| Tester Connection | Condition | Specified Condition |
|-------------------|-----------------------------------|---------------------|
| 1 - Switch body | OFF (When shaft is pressed) | 10 kΩ or higher |
| 1 - Switch body | ON (When shaft is not pressed) | Below 1 Ω |

NG → **REPLACE PARKING BRAKE SWITCH ASSEMBLY**

OK

3 CHECK HARNESS AND CONNECTOR (INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY - BODY GROUND)

- (a) Disconnect connector IC from the instrument panel junction block assembly.
- (b) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|--|---------------------|
| IC-14 - Body ground | Shaft of parking brake switch is pressed | 10 kΩ or higher |
| IC-14 - Body ground | Shaft of parking brake switch is not pressed | Below 1 Ω |

NG

REPAIR OR REPLACE HARNESS OR
CONNECTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Taillight Relay Circuit

DESCRIPTION

The body ECU controls the TAIL relay when a signal is received from the headlight dimmer switch assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST BY INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch on (IG) and turn the intelligent tester main switch on.
- (c) Select the item below in the ACTIVE TEST and then check that the relay operation.

BODY NO. 1:

| Item | Test Details | Diagnostic Note |
|------------|------------------------------------|-----------------|
| TAIL LIGHT | Turn the tail light relay ON / OFF | - |

OK:


Tail lights come on.

NG → **Go to step 2**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2 INSPECT RELAY



- (a) Inspect TAIL relay continuity.
 - (1) Remove the tail relay from the instrument panel J/B.
 - (2) Measure the resistance according to the value(s) in the table below.

Standard resistance


| Tester Connection | Specified Condition |
|-------------------|---|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1- 2) |
| 3 - 4 | Below 1 Ω (When battery voltage is applied to terminal 1- 2) |

NG → **REPLACE RELAY**

OK

3 CHECK HARNESS AND CONNECTOR (BATTERY - INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY)

- (a) Measure the voltage according to the value(s) in the table below.



Standard voltage


| Tester Connection | Condition | Specified Condition |
|--------------------|-----------|---------------------|
| IA-1 - Body ground | Always | 10 to 14 V |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

4 INSPECT INSTRUMENT PANEL JUNCTION BLOCK ASSEMBLY

- (a) Measure the voltage according to the value(s) in the table below.



Standard voltage

| Tester Connection | Condition | Specified Condition |
|---------------------|---------------------------------|------------------------|
| IC-4 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |
| IC-5 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |
| ID-6 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |
| ID-14 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |
| IP-8 - Body ground | Light control switch OFF → TAIL | Below 1 V → 10 to 14 V |
| IO-9 - Body ground | Ignition switch on (IG) | Below 1 V → 10 to 14 V |

NG → **PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

OK


REPAIR OR REPLACE HARNESS OR CONNECTOR (EACH TAILLIGHT CIRCUIT)

Headlight Beam Level Control ECU Communication Circuit

DESCRIPTION


The headlight beam level control ECU receives HEAD signal from the front controller and receives engine condition (ON or OFF) from the generator. It also receives vehicle speed signal from the skid control ECU, thus controlling the headlight beam level control motor.

WIRING DIAGRAM




INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR (FRONT CONTROLLER - HEADLIGHT BEAM LEVEL CONTROL ECU)



- (a) Disconnect connector 1H from the front controller.
- (b) Disconnect the headlight beam level control ECU connector.
- (c) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| A21-7 - 1H-11 | Always | Below 1 Ω |
| A21-7 - Body ground | Always | 10 kΩ or higher |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**


OK

2


CHECK HARNESS AND CONNECTOR (SKID CONTROL ECU - HEADLIGHT BEAM LEVEL CONTROL ECU)

without VSC:

Skid Control ECU Wire Harness View:




Headlight Beam Level Control ECU Wire Harness View:




with VSC:

Skid Control ECU Wire Harness View:



Headlight Beam Level Control ECU Wire Harness View:



N

E126271E02

- (a) Disconnect the headlight beam level control ECU connector and the skid control ECU connector.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance:
without VSC**

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| A21-6 - A40-13 | Always | Below 1 Ω |
| A21-5 - A40-24 | Always | Below 1 Ω |
| A21-6 - Body ground | Always | 10 kΩ or higher |
| A21-5 - Body ground | Always | 10 kΩ or higher |


with VSC

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| A21-6 - A34-39 | Always | Below 1 Ω |
| A21-5 - A34-40 | Always | Below 1 Ω |
| A21-6 - Body ground | Always | 10 kΩ or higher |
| A21-5 - Body ground | Always | 10 kΩ or higher |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

3 CHECK HARNESS AND CONNECTOR (GENERATOR ASSEMBLY - HEADLIGHT BEAM LEVEL CONTROL ECU)



- (a) Disconnect connector B6 of the generator and connector A21 of the headlight beam level control ECU.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|-------------------------|-----------|---------------------|
| B6-4 (L) - A21-8 (CHG-) | Always | Below 1 Ω |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

Headlight Beam Level Control ECU Power Source Circuit

DESCRIPTION


This circuit provides power to operate the headlight beam level control ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT IG1 RELAY



- (a) Inspect IG1 relay continuity.
- (1) Remove the IG1 relay from the instrument panel J/B.
 - (2) Measure the resistance according to the value(s) in the table below.

Standard resistance


| Tester Connection | Specified Condition |
|-------------------|--|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1 - 2) |

NG

REPLACE IG1 RELAY

OK

2 INSPECT HEADLIGHT BEAM LEVEL CONTROL ECU



(a) Measure the voltage according to the value(s) in the table below.

Standard voltage


| Tester Connection | Condition | Specified Condition |
|-------------------|--|------------------------|
| A21-14 - A21-1 | Ignition switch off → Ignition switch on (IG) | Below 1 V → 10 to 14 V |

NG → **Go to step 3**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

3 CHECK HARNESS AND CONNECTOR (BATTERY - HEADLIGHT BEAM LEVEL CONTROL ECU)



(a) Disconnect connector A21 of the headlight beam level control ECU.

(b) Measure the voltage according to the value(s) in the table below.


Standard voltage

| Tester Connection | Condition | Specified Condition |
|----------------------|--|------------------------|
| A21-14 - Body ground | Ignition switch off → Ignition switch on (IG) | Below 1 V → 10 to 14 V |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

4 CHECK HARNESS AND CONNECTOR (HEADLIGHT BEAM LEVEL CONTROL ECU - BODY GROUND)



(a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|--------------------------|-----------|---------------------|
| A21-1 (E1) - Body ground | Always | Below 1 Ω |

NG → **REPAIR OR REPLACE HARNESS OR CONNECTOR**

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE


LI

Height Control Sensor Circuit


DESCRIPTION

The height control sensor rear RH controls the resistance value based on changes vehicle height. The headlight beam level control ECU detects the changes in vehicle height from the transformed voltage. The headlight beam level control ECU outputs a constant voltage of 5 V to the SHB terminal of the height control sensor rear RH.

In the height control sensor sub-assembly rear RH, the voltage changes due to the resistance. The changes voltage is output from the SHRR terminal of the height control sensor rear RH to the headlight beam level control ECU, thus the vehicle's height is detected.




WIRING DIAGRAM



DESCRIPTION

1 INSPECT HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH



- (a) Connect 3 dry cell batteries (1.5 V) in series.
- (b) Remove the height control sensor sub-assembly rear.
- (c) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead from the battery to terminal 3.
- (d) Measure the voltage between terminals 2 and 3 while slowly moving the link up and down.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|--------------------------|-------------|---------------------|
| L9-2 (SHRR) - L9-3 (SHG) | +45° (High) | Approx. 4.5 V |
| L9-2 (SHRR) - L9-3 (SHG) | 0° (Normal) | Approx. 2.5 V |
| L9-2 (SHRR) - L9-3 (SHG) | -45° (Low) | Approx. 0.5 V |

NG


REPLACE HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH

OK


2 CHECK HARNESS AND CONNECTOR (HEIGHT CONTROL SENSOR REAR RH - HEADLIGHT BEAM LEVEL CONTROL)

Wire Harness View:

L9 Height Control Sensor Rear RH



A21 Height Beam Level Control ECU



- (a) Disconnect connector L9 of the height control sensor sub-assembly and connector A21 of the headlight leveling ECU assembly.
- (b) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|-----------------------------|-----------|---------------------|
| A21-17 (SGR) - L9-1 (SHB) | Always | Below 1 Ω |
| A21-19 (SHRL) - L9-2 (SHRR) | Always | Below 1 Ω |
| A21-21 (SRB) - L9-2 (SHG) | Always | Below 1 Ω |
| L9-3 (SHG) - Body ground | Always | 10 kΩ or higher |
| L9-2 (SHRR) - Body ground | Always | 10 kΩ or higher |
| L9-1 (SHB) - Body ground | Always | 10 kΩ or higher |

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

H

E126275E02

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE




Headlight Beam Level Control Actuator Circuit

DESCRIPTION

The headlight beam level control motor receives signals from the headlight beam level control ECU to operate. The headlight beam level control ECU receives signals regarding operating conditions of the headlight beam level control motor.

WIRING DIAGRAM




INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR (HEADLIGHT BEAM LEVEL CONTROL MOTOR - HEADLIGHT BEAM LEVEL)

Wire Harness View:

- (A5) Headlight Beam Level Control Motor LH
- (A27) Headlight Beam Level Control Motor RH



E075513E01

- (a) Disconnect the headlight assembly connector on the headlight beam level control motor side and the headlight beam level control ECU connector.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard resistance:
LH Side**

| Tester Connection | Condition | Specified Condition |
|----------------------|-----------|---------------------|
| A21-28 - A5-2 | Always | Below 1 Ω |
| A21-29 - A5-1 | Always | Below 1 Ω |
| A21-30 - A5-4 | Always | Below 1 Ω |
| A21-31 - A5-3 | Always | Below 1 Ω |
| A21-28 - Body ground | Always | 10 kΩ or higher |
| A21-29 - Body ground | Always | 10 kΩ or higher |
| A21-30 - Body ground | Always | 10 kΩ or higher |
| A21-31 - Body ground | Always | 10 kΩ or higher |


RH Side

| Tester Connection | Condition | Specified Condition |
|----------------------|-----------|---------------------|
| A21-9 - A27-2 | Always | Below 1 Ω |
| A21-10 - A27-1 | Always | Below 1 Ω |
| A21-11 - A27-4 | Always | Below 1 Ω |
| A21-12 - A27-3 | Always | Below 1 Ω |
| A21-9 - Body ground | Always | 10 kΩ or higher |
| A21-10 - Body ground | Always | 10 kΩ or higher |
| A21-11 - Body ground | Always | 10 kΩ or higher |
| A21-12 - Body ground | Always | 10 kΩ or higher |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 INSPECT HEADLIGHT BEAM LEVEL CONTROL MOTOR



E069131E04

- (a) Measure the resistance according to the value(s) in the table below.

**Standard resistance:
LH Side**

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------|---------------------|
| A5-1 - A5-2 | Always | 5.8 to 12.5 Ω |
| A5-3 - A5-4 | Always | 5.8 to 12.5 Ω |

RH Side

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------|---------------------|
| A27-1 - A27-2 | Always | 5.8 to 12.5 Ω |

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------|----------------------|
| A27-3 - A27-4 | Always | 5.8 to 12.5 Ω |

HINT:

Measure the resistance after the headlight has cooled down.

NG

REPLACE HEADLIGHT BEAM LEVEL CONTROL MOTOR

OK


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

LI


Combination Switch ECU Power Source Circuit**DESCRIPTION**

This circuit provides power to operate the combination switch.

WIRING DIAGRAM




INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR (COMBINATION SWITCH ECU - BATTERY)

- (a) Disconnect the connector from the combination switch.
 (b) Measure the voltage according to the value(s) in the table below.

Standard voltage


| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| D13-1 - Body ground | Always | 10 to 14 V |

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****2 CHECK HARNESS AND CONNECTOR (IGNITION SWITCH CIRCUIT)**

- (a) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|---------------------|-------------------------|---------------------|
| D13-2 - Body ground | Ignition switch on (IG) | 10 to 14 V |
| D13-2 - Body ground | Ignition switch off | Below 1 V |

NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****3 CHECK HARNESS AND CONNECTOR (COMBINATION SWITCH ECU - BODY GROUND)**

- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| D13-5 - Body ground | Always | Below 1 Ω |


NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

Headlight Beam Level Warning Circuit

DESCRIPTION


The headlight beam level warning indicator light in the combination meter assembly comes on for approximately 3 seconds when the ignition switch is turned on (IG). The headlight beam level warning indicator light also comes on when the headlight beam level control ECU detects a malfunction.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT HEADLIGHT BEAM LEVEL CONTROL ECU



(a) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|----------------------|---|---------------------|
| A21-26 - Body ground | Ignition switch on (IG) and headlight beam level warning indicator goes off | 10 to 14 V |
| A21-26 - Body ground | Headlight beam level warning indicator comes on | Below 1 V |

NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE

2**CHECK HARNESS AND CONNECTOR (HEADLIGHT BEAM LEVEL WARNING INDICATOR LIGHT)**

- (a) Inspect the harness and connectors related to the headlight beam level warning indicator light, referring to the wiring diagram.


NG**REPAIR OR REPLACE HARNESS OR CONNECTOR****OK****PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE**

LVL Terminal Circuit

DESCRIPTION


Connecting terminals LVL and CG of the DLC3 initializes the height control sensor signal.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK HARNESS AND CONNECTOR (DLC3 - HEADLIGHT BEAM LEVEL CONTROL ECU)



- (a) Disconnect connector A21 from the headlight beam level control ECU.
- (b) Measure the resistance according to the value(s) in the table below.


Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| D20-8 - A21-18 | Always | Below 1 Ω |
| D20-8 - Body ground | Always | 10 kΩ or higher |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 CHECK HARNESS AND CONNECTOR (DLC3 - BODY GROUND)



- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Condition | Specified Condition |
|---------------------|-----------|---------------------|
| D20-4 - Body ground | Always | Below 1 Ω |

NG REPAIR OR REPLACE HARNESS OR CONNECTOR


OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE


HEADLIGHT ASSEMBLY

COMPONENTS

HALOGEN HEADLIGHT:



DISCHARGE HEADLIGHT:





REMOVAL

HINT:


- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.

1. **REMOVE RADIATOR GRILLER SUB-ASSEMBLY** (See page [ET-2](#))
2. **REMOVE FRONT BUMPER ASSEMBLY** (See page [ET-2](#))
3. **REMOVE HEADLIGHT ASSEMBLY**
 - (a) Remove the 3 bolts.
 - (b) Pull the LH headlight assembly in the direction indicated by the arrow and remove the LH headlight assembly.




DISASSEMBLY


1. **REMOVE HEADLIGHT BRACKET LH**
 - (a) Disengage the 2 claws and the headlight bracket LH.



2. **REMOVE FRONT TURN SIGNAL LIGHT BULB**
 - (a) Turn the socket plug assembly and the front turn signal light bulb in the direction indicated by the arrow and remove as a unit.




3. **REMOVE CLEARANCE LIGHT BULB**
 - (a) Turn the socket plug assembly and the front clearance light bulb in the direction indicated by the arrow and remove as a unit.




4. REMOVE HEADLIGHT NO.1 BULB

- (a) Turn headlight bulb No. 1 in the direction indicated by the arrow and remove it.




5. REMOVE DISCHARGE HEADLIGHT BULB


- (a) Turn headlight back cover No. 1 in the direction indicated by the arrow and remove it.



- (b) Turn the discharge headlight bulb socket in the direction indicated by the arrow and remove the locking cap.




- (c) Release the set spring lock as shown in the illustration and remove the discharge headlight bulb.




6. REMOVE HEADLIGHT NO.2 BULB

- (a) Turn headlight bulb No. 2 in the direction indicated by the arrow and remove it.




7. REMOVE HEADLIGHT NO.2 BULB

- (a) Turn headlight back cover No. 1 in the direction indicated by the arrow and remove it.




- (b) Turn headlight No. 2 bulb in the direction indicated by the arrow and remove it.




8. REMOVE HEADLIGHT LEVELING ECU ASSEMBLY

- (a) Remove the 4 screws and headlight cover No. 1.




- (b) Remove the 2 screws.
- (c) Disengage the claw, disconnect the connector and remove the headlight leveling ECU assembly.



9. REMOVE HEADLIGHT LEVELING MOTOR LH

- (a) Turn the headlight leveling motor to align the recessed parts with the headlight unit LH.





- 10. REMOVE HEADLIGHT SOCKET & WIRE
 - (a) Remove the headlight socket & wire.



ADJUSTMENT

1. PREPARE VEHICLE FOR HEADLIGHT AIMING ADJUSTMENT

- (a) Prepare the vehicle:
- Ensure there is no damage or deformation to the body around the headlights.
 - Fill the fuel tank.
 - Make sure that the oil is filled to the specified level.
 - Make sure that the coolant is filled to the specified level.
 - Inflate the tires to the appropriate pressure.
 - Place the spare tire, tools, and jack in their original positions.
 - Unload the trunk.
 - Sit a person of average weight (68 kg, 150 lb) in the driver's seat.

2. PREPARE FOR HEADLIGHT AIMING (Using a tester)

- (a) Prepare the vehicle for headlight aim check.
 (b) Adjust in accordance with headlight tester instructions.

3. PREPARE FOR HEADLIGHT AIMING (Using a screen)

- (a) Prepare the vehicle according to the following conditions:
- Place the vehicle in a location that is dark enough to clearly observe the cutoff line. The cutoff line is a distinct line, below which light from the headlights can be observed and above which it cannot.
 - Place the vehicle at a 90° angle to the wall.
 - Create a 7.62 m (25 ft) distance between the vehicle (headlight bulb center) and the wall.
 - Place the vehicle on a level surface.
 - Bounce the vehicle up and down to settle the suspension.


NOTICE:

A distance of 7.62 m (25 ft) between the vehicle (headlight bulb center) and the wall is necessary for proper aim adjustment. If unavailable, secure a distance of exactly 3 m (9.84 ft) for check and adjustment. (The target zone will change with the distance, so follow the instructions in the illustration.)

- (b) Prepare a piece of thick white paper (approximately 2 m (6.6 ft) (height) x 4 m (13.1 ft) (width)) to use as a screen.
 (c) Draw a vertical line down the center of the screen (V line).
 (d) Set the screen as shown in the illustration.


HINT:

- Stand the screen perpendicular to the ground.






- Align the V line on the screen with the center of the vehicle.

Aligning distance is 7.62 m (25 ft):




Aligning distance is 3 m (9.84 ft):



P

E126301E01



P

1033423E13

- (e) Draw base lines (H line, V LH, V RH lines) on the screen as shown in the illustration.

HINT:

- The base lines differ for "low-beam inspection" and "high-beam inspection".
 - Mark the headlight bulb center marks on the screen. If the center mark cannot be observed on the headlight, use the center of the headlight bulb or the manufacturer's name marked on the headlight as the center mark.
- H Line (Headlight height):
Draw a horizontal line across the screen so that it passes through the center marks. The H line should be at the same height as the headlight bulb center marks of the low-beam headlights.
 - V LH Line, V RH Line (Center mark position of left-hand (LH) and right-hand (RH) headlight):
Draw two vertical lines so that they intersect the H line at each center mark (aligned with the center of the low-beam headlight bulbs).

4. INSPECT HEADLIGHT AIMING

- (a) Cover or disconnect the connector of the headlight on the opposite side to prevent light from the headlight not being inspected from affecting headlight aiming inspection.

NOTICE:

Do not keep the headlight covered for more than 3 minutes. The headlight lens is made of synthetic resin, and may easily melt or be damaged due to heat.

HINT:


When checking the aim of the high-beam, cover the low-beam or disconnect the connector.

- (b) Start the engine.

NOTICE:

Engine rpm must be 1,500 or more.

- (c) Turn on the headlight and make sure that the cutoff line falls within the specified area as shown in the illustration.




I041214E04

HINT:


- Since the low-beam light and the high-beam light are a unit, if the aim on one is correct, the other should also be correct. However, check both beams just to make sure.

- Alignment distance is 7.62 m (25 ft):
The cutoff line is 101 mm (3.97 in.) above and below the H line as well as left and right of the V line with low-beam (SAE J599).
- Alignment distance is 3 m (9.84 ft):
The cutoff line is 40 mm (1.57 in.) above and below the H line as well as left and right of the V line with low-beam (SAE J599).
- Alignment distance is 7.62 m (25 ft):
The cutoff line is 101 mm (3.97 in.) above and below the H line as well as left and right of the V line with high-beam (SAE J599).
- Alignment distance is 3 m (9.84 ft):
The cutoff line is 40 mm (1.57 in.) above and below the H line as well as left and right of the V line with high-beam (SAE J599).
- Alignment distance is 7.62 m (25 ft):
The cutoff line is 53 mm (2.08 in.) below the H line with low-beam.
- Alignment distance is 3 m (9.84 ft):
The cutoff line is 21 mm (0.82 in.) below the H line with low-beam.

Halogen Headlight:



Discharge Headlight:



P

E126303E01

5. ADJUST HEADLIGHT AIMING

(a) Adjust the aim vertically:

Adjust the headlight aim into the specified range by turning aiming screw A with a screwdriver.

NOTICE:

The final turn of the aiming screw should be made in the clockwise direction. If the screw is tightened excessively, loosen and then retighten it, so that the final turn of the screw is in the clockwise direction.

HINT:

- Perform low-beam aim adjustment.
- The headlight aim moves up when turning the aiming screw clockwise, and moves down when turning the aiming screw counterclockwise.
- On discharge headlight, both screws should be turned the same number of turns in the same direction.

REASSEMBLY

1. INSTALL HEADLIGHT SOCKET & WIRE
2. INSTALL HEADLIGHT LEVELING MOTOR LH
3. INSTALL HEADLIGHT LEVELING ECU ASSEMBLY
4. INSTALL HEADLIGHT NO.2 BULB
5. INSTALL DISCHARGE HEADLIGHT BULB
6. INSTALL HEADLIGHT NO.1 BULB
7. INSTALL CLEARANCE LIGHT BULB
8. INSTALL FRONT TURN SIGNAL LIGHT BULB
9. INSTALL HEADLIGHT BRACKET LH



INSTALLATION

1. INSTALL HEADLIGHT ASSEMBLY
2. INSTALL FRONT BUMPER ASSEMBLY (See page [ET-4](#))
3. INSTALL RADIATOR GRILLE SUB-ASSEMBLY (See page [ET-4](#))



REPAIR

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- If the area where the headlight unit LH is installed is broken, the repairs listed below can be performed inexpensively through the use of a repair use bracket. This may only be done if the headlight assembly LH itself is not damaged.

1. **REMOVE RADIATOR GRILLE SUB-ASSEMBLY** (See page [ET-2](#))
2. **REMOVE FRONT BUMPER ASSEMBLY** (See page [ET-2](#))
3. **REMOVE HEADLIGHT ASSEMBLY** (See page [LI-111](#))
4. **REMOVE HEADLIGHT BRACKET** (See page [LI-111](#))
5. **REMOVE HEADLIGHT PROTECTOR RETAINER UPPER**


HINT:

- If the installation area of the headlight assembly LH is damaged, use the supply bracket for low-cost repair.
- Ensure that the headlight assembly LH is not damaged.

- (a) Cut off part shaded in the illustration and sand smooth with sandpaper.

NOTICE:

After cutting off the part, place the headlight protector retainer UPR LH against the bosses and gradually file away until installation is possible.





- (b) Install the headlight protector retainer UPR LH with the 2 screws.

6. **REMOVE HEADLIGHT PROTECTOR RETAINER LOWER**

HINT:

- If the installation area of the headlight assembly LH is damaged, use the supply bracket for low-cost repair.
- Ensure that the headlight assembly LH is not damaged.






- (a) Cut off the part shaded in the illustration and sand smooth with sandpaper.

NOTICE:

After cutting off the part, place the headlight protector retainer LWR LH against the bosses and gradually file away until installation is possible.




- (b) Install the headlight protector retainer LWR LH with the 2 screws.

7. **INSTALL FRONT BUMPER ASSEMBLY** (See page [ET-4](#))
8. **INSTALL RADIATOR GRILLE SUB-ASSEMBLY** (See page [ET-4](#))
9. **PREPARE VEHICLE FOR HEADLIGHT AIMING ADJUSTMENT** (See page [LI-114](#))
10. **PREPARE FOR HEADLIGHT AIMING** (for Using a Tester) (See page [LI-114](#))
11. **PREPARE FOR HEADLIGHT AIMING** (for Using a Screen) (See page [LI-114](#))
12. **INSPECT HEADLIGHT AIMING** (See page [LI-116](#))
13. **ADJUST HEADLIGHT AIMING** (See page [LI-117](#))
14. **PREPARE VEHICLE FOR FOG LIGHT AIMING ADJUSTMENT** (See page [LI-121](#))
15. **PREPARE FOR FOG LIGHT AIMING** (See page [LI-122](#))
16. **INSPECT FOG LIGHT AIMING** (See page [LI-123](#))
17. **ADJUST FOG LIGHT AIMING** (See page [LI-124](#))

FOG LIGHT ASSEMBLY

COMPONENTS



FRONT BUMPER ASSEMBLY

RADIATOR GRILLE SUB-ASSEMBLY

FOG LIGHT ASSEMBLY

- FOG LIGHT BRACKET




- FOG LIGHT BULB

REMOVAL

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.

1. **REMOVE RADIATOR GRILLE SUB-ASSEMBLY** (See page [ET-2](#))
2. **REMOVE FRONT BUMPER ASSEMBLY** (See page [ET-2](#))
3. **REMOVE FOG LIGHT ASSEMBLY**
 - (a) Remove the 2 screws.
 - (b) Disengage the 2 claws and remove the fog light assembly LH.




DISASSEMBLY

1. **REMOVE FOG LIGHT BRACKET**
 - (a) Disengage the 4 claws and fog light bracket LH.
2. **REMOVE FOG LIGHT BULB**
 - (a) Turn the fog light bulb in the direction indicated by the arrow and remove it.

ADJUSTMENT

1. PREPARE VEHICLE FOR FOG LIGHT AIMING ADJUSTMENT

- (a) Prepare the vehicle:
- Ensure there is no damage or deformation to the body around the fog lights.
 - Fill the fuel tank.
 - Make sure that the oil is filled to the specified level.
 - Make sure that the coolant is filled to the specified level.
 - Inflate the tires to the appropriate pressure.
 - Place the spare tire, tools, and jack in their original positions.
 - Unload the trunk.
 - Sit a person of average weight (68 kg, 150 lb) in the driver's seat.



2. PREPARE FOR FOG LIGHT AIMING

- (a) Prepare the vehicle according to the following conditions:
- Place the vehicle in a location that is dark enough to clearly observe the cutoff line. The cutoff line is a distinct line, below which light from the fog lights can be observed and above which it cannot.
 - Place the vehicle at a 90° angle to the wall.
 - Create a 7.62 m (25 ft) distance between the vehicle (fog light bulb center) and the wall.
 - Place the vehicle on a level surface.
 - Bounce the vehicle up and down to settle the suspension.

NOTICE:


A distance of 7.62 m (25 ft) between the vehicle (fog light bulb center) and the wall is necessary for proper aim adjustment. If unavailable, secure a distance of exactly 3 m (9.84 ft) for check and adjustment. (The target zone will change with the distance, so follow the instructions in the illustration.)

- (b) Prepare a piece of thick white paper (approximately 2 m (6.6 ft) (height) x 4 m (13.1 ft) (width)) to use as a screen.
- (c) Draw a vertical line down the center of the screen (V line).
- (d) Set the screen as shown in the illustration.




HINT:

- Stand the screen perpendicular to the ground.
- Align the V line on the screen with the center of the vehicle.

Aligning distance is 7.62 m (25 ft):




Aligning distance is 3 m (9.84 ft):



P

E126312E01



P

I033423E13

(e) Draw base lines (H line, V LH, V RH lines) on the screen as shown in the illustration.

HINT:

Mark the fog light bulb center marks on the screen. If the center mark cannot be observed on the fog light, use the center of the fog light bulb or the manufacturer's name marked on the fog light as the center mark.

(1) H Line (Fog light height):

Draw a horizontal line across the screen so that it passes through the center marks. The H line should be at the same height as the fog light bulb center marks of the low-beam fog lights.

(2) V LH Line, V RH Line (Center mark position of left-hand (LH) and right-hand (RH) fog lights):

Draw two vertical lines so that they intersect the H line at each center mark.

3. INSPECT FOG LIGHT AIMING



(a) Cover or disconnect the connector of the fog light on the opposite side to prevent light from the fog light not being inspected from affecting fog light aiming inspection.

(b) Start the engine.

NOTICE:

Engine rpm must be 1,500 or more.

- (c) Turn on the fog light and make sure that the cutoff line falls within the specified area, as shown in the illustration.



4. ADJUST FOG LIGHT AIMING

- (a) Adjust the fog light aim into the specified range by turning the aiming screw with a screwdriver.

NOTICE:

The final turn of the aiming screw should be made in the clockwise direction. If the screw is tightened excessively, loosen and then retighten it, so that the final turn of the screw is in the clockwise direction.

REASSEMBLY

1. INSTALL FOG LIGHT BULB
2. INSTALL FOG LIGHT BRACKET




INSTALLATION

1. INSTALL FOG LIGHT ASSEMBLY
2. INSTALL FRONT BUMPER ASSEMBLY (See page [ET-4](#))
3. INSTALL RADIATOR GRILLE SUB-ASSEMBLY (See page [ET-4](#))




REAR COMBINATION LIGHT ASSEMBLY

COMPONENTS



LI




REAR BUMPER ASSEMBLY

REAR COMBINATION LIGHT ASSEMBLY LH

- REAR COMBINATION LIGHT BRACKET LH
- REAR COMBINATION LIGHT SOCKET & WIRE
- REAR COMBINATION LIGHT BULB
- REAR COMBINATION LIGHT BODY GASKET LH

Wire Harness Side:



H

E075377E03

ON-VEHICLE INSPECTION

1. INSPECT REAR COMBINATION LIGHT ASSEMBLY

- (a) Connect the (+) lead from the voltmeter to terminal 2 and the (-) lead from the voltmeter to terminal 3.
- (b) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|-------------------|------------------------------|---------------------|
| 1 - 3 | Light control switch OFF | Below 1 V |
| 1 - 3 | Light control switch TAIL | 10 to 14 v |
| 2 - 3 | Brake pedal released | Below 1 V |
| 2 - 3 | Brake pedal depressed | 10 to 14 v |






REMOVAL

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.

1. **REMOVE REAR FLOOR FINISH PLATE** (See page [ET-6](#))
2. **REMOVE REAR BUMPER ASSEMBLY** (See page [ET-6](#))
3. **REMOVE REAR COMBINATION LIGHT ASSEMBLY LH**
 - (a) Disconnect the connector.
 - (b) Remove the 3 nuts and the 2 bolts.
 - (c) Remove the pin and the rear combination light assembly LH.



DISASSEMBLY

1. **REMOVE REAR COMBINATION LIGHT BRACKET LH**
 - (a) Remove the 2 nuts and the rear combination light bracket LH.
2. **REMOVE REAR COMBINATION LIGHT SOCKET & WIRE**
 - (a) Remove the rear combination light socket & wire as shown in the illustration.
3. **REMOVE REAR COMBINATION LIGHT BULB**
4. **REMOVE REAR COMBINATION LIGHT BODY GASKET LH**

REASSEMBLY

1. INSTALL REAR COMBINATION LIGHT BODY
GASKET LH
2. INSTALL REAR COMBINATION LIGHT BULB
3. INSTALL REAR COMBINATION LIGHT SOCKET &
WIRE
4. INSTALL REAR COMBINATION LIGHT BRACKET LH




INSTALLATION

1. INSTALL REAR COMBINATION LIGHT ASSEMBLY LH
2. INSTALL REAR BUMPER ASSEMBLY (See page [ET-8](#))
3. INSTALL REAR FLOOR FINISH PLATE



BACK-UP LIGHT ASSEMBLY

COMPONENTS




REMOVAL

HINT:

- Use the same procedures for the RH side and LH side.
- The procedures listed below are for the LH side.
- Installation is in the reverse order of removal.


1. REMOVE LUGGAGE COMPARTMENT DOOR COVER

- (a) Remove the 13 clips and the luggage compartment door cover.



2. REMOVE BACK-UP LIGHT ASSEMBLY


- (a) Disconnect the connector.
- (b) Remove the 3 nuts and the rear light assembly LH.



DISASSEMBLY

1. REMOVE LUGGAGE ELECTRICAL KEY SWITCH

- (a) Remove the screw and the luggage electrical key switch.




2. REMOVE BACK-UP LIGHT SOCKET & WIRE

- (a) Remove the rear light socket & wire as shown in the illustration.

3. REMOVE BACK-UP LIGHT BULB

4. REMOVE BACK-UP LIGHT LH GASKET



REASSEMBLY

1. INSTALL BACK-UP LIGHT LH GASKET
2. REMOVE BACK-UP LIGHT BULB
3. REMOVE REAR LIGHT SOCKET & WIRE
4. REMOVE LUGGAGE ELECTRICAL KEY SWITCH




INSTALLATION

- 1. INSTALL BACK-UP LIGHT ASSEMBLY**
- 2. INSTALL LUGGAGE COMPARTMENT DOOR COVER**



LICENSE PLATE LIGHT ASSEMBLY

COMPONENTS




REMOVAL

HINT:


Installation is in the reverse order of removal.

1. REMOVE REAR FLOOR FINISH PLATE (See page [ET-6](#))




2. REMOVE LICENSE PLATE LIGHT ASSEMBLY

(a) Disconnect the connector.



- (b) Remove the grommet as shown in the illustration.
 (c) Disengage the 2 claws and remove the license plate light assembly as shown in the illustration.



DISASSEMBLY

1. REMOVE LICENSE PLATE LIGHT LENS & COVER

(a) Remove the license plate light lens & cover as shown in the illustration.

2. REMOVE LICENSE PLATE LIGHT BULB

REASSEMBLY

- 1. INSTALL LICENSE PLATE LIGHT BULB**
- 2. INSTALL LICENSE PLATE LIGHT LENS & COVER**




INSTALLATION


1. INSTALL LICENSE PLATE LIGHT ASSEMBLY
2. INSTALL REAR FLOOR FINISH PLATE




HIGH MOUNTED STOP LIGHT ASSEMBLY


COMPONENTS








HIGH MOUNTED STOP
LIGHT ASSEMBLY





ON-VEHICLE INSPECTION

1. INSPECT CENTER STOP LIGHT ASSEMBLY

- (a) Connect the (+) lead from the voltmeter to terminal 1 and the (-) lead from the voltmeter to terminal 2.
- (b) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester Connection | Condition | Specified Condition |
|-------------------|-----------------------|---------------------|
| 1 - 2 | Brake pedal released | Below 1.5 V |
| 1 - 2 | Brake pedal depressed | 8 to 14 V |




REMOVAL

HINT:

installation is in the reverse order of removal.

1. DISCONNECT BATTERY NEGATIVE TERMINAL
2. REMOVE REAR SEAT CUSHION ASSEMBLY (See page [SE-68](#))
3. REMOVE REAR SEAT HEADREST ASSEMBLY
4. REMOVE REAR SEAT BACK LOCK COVER CAP (See page [SE-68](#))
5. REMOVE REAR SEATBACK ASSEMBLY LH (See page [SE-68](#))
6. REMOVE REAR SEATBACK ASSEMBLY RH (See page [SE-69](#))
7. REMOVE REAR DOOR SCUFF PLATE LH (See page [IR-12](#))
8. REMOVE REAR DOOR SCUFF PLATE RH (See page [IR-12](#))
9. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP LH
10. REMOVE REAR DOOR OPENING TRIM WEATHERSTRIP RH
11. REMOVE REAR SEAT SIDE GARNISH LH (See page [IR-14](#))
12. REMOVE REAR SEAT SIDE GARNISH RH (See page [IR-14](#))
13. REMOVE ROOF SIDE GARNISH ASSEMBLY INNER LH (See page [IR-14](#))
14. REMOVE ROOF SIDE GARNISH ASSEMBLY INNER RH (See page [IR-14](#))
15. REMOVE PACKAGE TRAY TRIM PANEL ASSEMBLY (See page [SB-31](#))
16. REMOVE CENTER STOP LIGHT ASSEMBLY
 - (a) Disconnect the connector.
 - (b) Disengage the claw and remove the center stop light assembly.



INSTALLATION

1. INSTALL PACKAGE TRAY TRIM PANEL ASSEMBLY
2. INSTALL REAR SEATBACK ASSEMBLY RH (See page [SE-76](#))
3. INSTALL REAR SEATBACK ASSEMBLY LH (See page [SE-77](#))
4. INSTALL REAR SEAT CUSHION ASSEMBLY
5. INSTALL ROOF SIDE GARNISH ASSEMBLY INNER LH (See page [IR-19](#))
6. INSTALL ROOF SIDE GARNISH ASSEMBLY INNER RH (See page [IR-19](#))
7. INSTALL REAR SEATBACK ASSEMBLY RH (See page [SE-76](#))
8. INSTALL REAR SEATBACK ASSEMBLY LH (See page [SE-77](#))
9. INSTALL REAR SEAT CUSHION ASSEMBLY
10. CONNECT BATTERY NEGATIVE TERMINAL
11. PERFORM INITIALIZATION
([IN-29](#))
12. INSPECT SRS WARNING LIGHT
([AC-37](#))




PERSONAL LIGHT ASSEMBLY

INSPECTION

1. INSPECT PERSONAL LIGHT ASSEMBLY

- (a) Measure the resistance according to the value(s) in the table below.

Resistance




H

E126327

| Tester connection | Condition | Specified condition |
|-------------------|---|---------------------|
| 4 - 2 | OFF | 10 kΩ or higher |
| 4 - 2 | Driver side personal light switch ON | Continuity |
| 4 - 2 | Passenger side personal light switch ON | Continuity |





REAR ROOM LIGHT ASSEMBLY

INSPECTION

1. INSPECT REAR ROOM LIGHT ASSEMBLY

- (a) Connect the (+) lead from the battery to terminal 3 and the (-) lead to terminal 2, and check that the rear room light comes on when the switch is in the ON position.

OK:

The light comes on.

- (b) Connect the (+) lead from the battery to terminal 3 and the (-) lead to terminal 1, and check that the rear room light comes on when the switch is in the DOOR position.

OK:

The light comes on.



DOOR COURTESY LIGHT


INSPECTION


1. INSPECT COURTESY LIGHT ASSEMBLY

- (a) Inspect the courtesy light.
 - (1) Connect the (+) lead from the battery to terminal 2 and the (-) lead to terminal 1, then check that the courtesy light comes on.

OK:

The light comes on.





LUGGAGE COMPARTMENT ROOM LIGHT

INSPECTION


1. INSPECT LUGGAGE COMPARTMENT LIGHT ASSEMBLY

- (a) Inspect the luggage compartment light.
 - (1) Connect the (+) lead from the battery to terminal 1 and the (-) lead to terminal 2, then check that the luggage compartment light comes on.

OK:

The light comes on.





IGNITION KEY CYLINDER LIGHT

INSPECTION

1. INSPECT TRANSPONDER KEY AMPLIFIER

- (a) Inspect key cylinder light operation.
 - (1) Connect the (+) lead from the battery to terminal 2 and the (-) lead to terminal 6, and check that the light comes on.

Standard:

The light comes on.

VANITY LIGHT

INSPECTION

1. INSPECT LH VISOR ASSEMBLY

- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Switch operation | Specified condition |
|------------------|-------------------------|
| ON (Open) | Below 1 Ω |
| OFF (Close) | 10 k Ω or higher |

2. INSPECT RH VISOR ASSEMBLY

- (a) Measure the resistance according to the value(s) in the table below.


Standard resistance

| Switch operation | Specified condition |
|------------------|-------------------------|
| ON (Open) | Below 1 Ω |
| OFF (Close) | 10 k Ω or higher |



HEADLIGHT DIMMER SWITCH

COMPONENTS





REMOVAL


HINT:

Install is in the reverse order of removal.

1. **DISCONNECT BATTERY NEGATIVE TERMINAL**
 - (a) Wait for 90 seconds after disconnecting the cable to prevent the airbag working.
2. **PLACE FRONT WHEELS FACING STRAIGHT AHEAD**
3. **REMOVE STEERING WHEEL COVER LOWER NO.3**
(See page [RS-304](#))
4. **REMOVE STEERING WHEEL COVER LOWER NO.2**
(See page [RS-304](#))
5. **REMOVE HORN BUTTON ASSEMBLY** (See page [RS-304](#))
6. **REMOVE STEERING WHEEL ASSEMBLY** (See page [SR-36](#))
7. **REMOVE STEERING COLUMN COVER LWR** (See page [SR-36](#))
8. **REMOVE STEERING COLUMN COVER** (See page [SR-36](#))
9. **REMOVE SPIRAL CABLE SUB-ASSEMBLY**
10. **REMOVE HEADLIGHT DIMMER SWITCH ASSEMBLY**
 - (a) Disconnect the connector.
 - (b) Disengage the clamp from the headlight dimmer switch assembly as shown in the illustration.



- (c) Disengage the claw and remove the headlight dimmer switch assembly as shown in the illustration.



INSPECTION

1. INSPECT HEADLIGHT DIMMER SWITCH ASSEMBLY

- (a) Inspect the light control switch.
 (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|------------------|-------------------------|
| 19 - 11 - 13 - 12 | OFF | 10 k Ω or higher |
| 19 - 13 | TAIL | Below 1 Ω |
| 19 - 11 - 13 | HEAD | Below 1 Ω |
| 19 - 12 | AUTO | Below 1 Ω |

- (b) Inspect the headlight dimmer switch.
 (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|------------------|---------------------|
| 14 - 19 | FLASH | Below 1 Ω |
| 19 - 20 | LOW BEAM | Below 1 Ω |
| 15 - 19 | HI BEAM | Below 1 Ω |

- (c) Inspect the turn signal switch.
 (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|------------------|-------------------------|
| 16 - 17 - 19 | Right turn | Below 1 Ω |
| 16 - 17 - 18 - 19 | Neutral | 10 k Ω or higher |
| 17 - 19 - 18 | Left turn | Below 1 Ω |

- (d) Inspect the front fog light switch.
 (1) Measure the resistance according to the value(s) in the table below.



Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|---------------------|-------------------------|
| 7 - 8 | OFF | 10 k Ω or higher |
| 7 - 8 | Fog light switch ON | Below 1 Ω |

- (e) Inspect the rear fog light switch.
 (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|------------------|-------------------------|
| 7 - 8 - 9 | OFF | 10 k Ω or higher |
| 7 - 8 - 9 | ON | Below 1 Ω |



INSTALLATION

1. INSTALL HEADLIGHT DIMMER SWITCH ASSEMBLY

- (a) Install the headlight dimmer switch assembly with the claw as shown in the illustration.

HINT:

Make sure that the claw is completely engaged.

- (b) Install the headlight dimmer switch assembly with the clamp.

- (c) Connect the connector.

2. INSTALL SPIRAL CABLE SUB-ASSEMBLY

3. INSTALL STEERING COLUMN COVER (See page [SR-46](#))

4. INSTALL STEERING COLUMN COVER LWR (See page [SR-46](#))

5. ADJUST SPIRAL CABLE SUB-ASSEMBLY

6. INSTALL STEERING WHEEL ASSEMBLY (See page [SR-46](#))

7. INSPECT STEERING WHEEL CENTER POINT (See page [SR-47](#))

8. INSTALL HORN BUTTON ASSEMBLY (See page [RS-305](#))

9. INSTALL STEERING WHEEL COVER LOWER NO.2 (See page [RS-305](#))

10. INSTALL STEERING WHEEL COVER LOWER NO.3 (See page [RS-305](#))

11. CONNECT BATTERY NEGATIVE TERMINAL

12. INSPECT HORN BUTTON ASSEMBLY

13. INSPECT SRS WARNING LIGHT ([RS-1](#))

14. PERFORM INITIALIZATION

- (a) Some systems need initialization when disconnecting the cable from the negative battery terminal ([IN-29](#)).


HAZARD WARNING SWITCH

INSPECTION

1. INSPECT HAZARD WARNING SIGNAL SWITCH ASSEMBLY


- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance



| Tester Connection | Condition | Specified Condition |
|-------------------|---------------------------|-------------------------|
| 5 - 6 | Hazard warning switch ON | Below 1 Ω |
| 5 - 6 | Hazard warning switch OFF | 10 k Ω or higher |





STOP LIGHT SWITCH

INSPECTION

1. INSPECT STOP LIGHT SWITCH ASSEMBLY

- (a) Inspect the stop light switch assembly.
 - (1) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester Connection | Switch Condition | Specified Condition |
|-------------------|----------------------|-------------------------|
| 1 - 2 | Switch pin free | 10 k Ω or higher |
| 3 - 4 | Switch pin free | Below 1 Ω |
| 1 - 2 | Switch pin pushed in | Below 1 Ω |
| 3 - 4 | Switch pin pushed in | 10 k Ω or higher |



FRONT DOOR COURTESY SWITCH

INSPECTION

1. **INSPECT FRONT DOOR COURTESY LIGHT SWITCH**
 - (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Switch operation | Specified condition |
|-------------------------------------|-------------------------|
| ON (When the shaft is pressed) | 10 k Ω or higher |
| OFF (When the shaft is not pressed) | Below 1 Ω |



REAR DOOR COURTESY SWITCH


INSPECTION

1. **INSPECT REAR DOOR COURTESY LIGHT SWITCH**
 - (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Switch operation | Specified condition |
|-------------------------------------|-------------------------|
| ON (When the shaft is pressed) | 10 k Ω or higher |
| OFF (When the shaft is not pressed) | Below 1 Ω |





BACK DOOR COURTESY SWITCH


INSPECTION

1. INSPECT LUGGAGE COMPARTMENT DOOR LOCK ASSEMBLY

- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance

| Tester connection | Condition | Specified condition |
|-------------------|---------------------|-------------------------|
| 2 - 3 | Back door is closed | 10 k Ω or higher |
| 2 - 3 | Back door is open | Below 1 Ω |



AUTOMATIC LIGHT CONTROL SENSOR

ON-VEHICLE INSPECTION

1. INSPECT AUTOMATIC LIGHT CONTROL SENSOR

- (a) Measure the continuity, waveform and voltage according to the value(s) in the table below.

NOTICE:


With connector connected, perform inspection from the backside of the connector.

Standard voltage

| Tester connection | Condition | Specified condition |
|-------------------|--|-----------------------------------|
| 6 - 3 | Always | 10 to 14 V |
| 5 - 3 | Ignition switch on (IG), Headlight dimmer SW in AUTO | Pulse generation (See waveform 1) |

Standard resistance

| Tester connection | Condition | Specified condition |
|-------------------|-----------|---------------------|
| 3 - Body ground | Always | Below 1 Ω |



(b) Waveform 1

| Item | Description |
|-----------|--|
| Terminal | CLTS (5) - CLTE (3) |
| Gauge | 5 V/DIV, 5 ms/DIV |
| Condition | Ignition switch ON (IG), Headlight dimmer SW in AUTO |

HINT:


If the ambient light becomes brighter, width A will become narrower.

HEIGHT CONTROL SENSOR

COMPONENTS

LI

HEIGHT CONTROL SENSOR
SUB-ASSEMBLY REAR RH





REMOVAL

HINT:

Installation is in the reverse order of removal.

1. REMOVE HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH

- (a) Disconnect the connector.
- (b) Place matchmarks with the one on the height control sensor sub-assembly rear RH and bracket.
- (c) Remove a nut.



- (d) Remove the 2 nuts and height control sensor sub-assembly rear RH.

INSTALLATION

1. INSTALL HEIGHT CONTROL SENSOR SUB-ASSEMBLY REAR RH

- (a) Install the height control sensor link rear RH with the 2 nuts.

Torque: 8.0 N*m (81 kgf*cm, 71 in.*lbf)

- (b) Align the matchmarks with the one on the height control sensor sub-assembly rear RH and bracket.
- (c) Install the height control sensor sub-assembly rear RH.

Torque: 5.4 N*m (55 kgf*cm, 48 in.*lbf)

- (d) Connect the connector.
- (e) Install a nut.
- (f) When the work like the vehicle height may be changed is performed, for example, removal and installation of the height control sensor, or replacement of the suspension, etc., initialize the sensor, then adjust the optical axis (See page [LI-16](#)).

2. VEHICLE PREPARATION FOR HEADLIGHT AIM ADJUSTMENT (See page [LI-114](#))

3. PREPARATION FOR HEADLIGHT AIMING (Using a tester) (See page [LI-114](#))

4. PREPARATION FOR HEADLIGHT AIMING (Using a screen) (See page [LI-114](#))


5. HEADLIGHT AIMING INSPECTION (See page [LI-116](#))

6. HEADLIGHT AIMING ADJUSTMENT (See page [LI-117](#))

HEADLIGHT LEVELING ECU

COMPONENTS

LI




C

C114924E01



HEADLIGHT LEVELING ECU ASSEMBLY




REMOVAL

HINT:


Installation is in the reverse order of removal.

1. **REMOVE INSTRUMENT PANEL FINISH LOWER PANEL LH**
2. **REMOVE INSTRUMENT PANEL AIR BAG ASSEMBLY LOWER NO.1**
3. **REMOVE HEADLIGHT LEVELING ECU ASSEMBLY**
 - (a) Disconnect the connector.
 - (b) Remove the bolt and the headlight leveling ECU assembly.



INSTALLATION

1. INSTALL INSTRUMENT PANEL AIR BAG ASSEMBLY LOWER NO.1
2. INSTALL INSTRUMENT PANEL FINISH LOWER PANEL LH



TURN SIGNAL FLASHER ASSEMBLY

ON-VEHICLE INSPECTION

1. **INSPECT TURN SIGNAL FLASHER ASSEMBLY**
 - (a) Disconnect the connector from the turn signal flasher.
 - (b) Measure the voltage according to the value(s) in the table below.

Standard voltage

| Tester connection | Condition | Specified condition |
|-------------------|------------------------------|---------------------|
| 1 - body ground | Turn ignition switch on (IG) | 10 to 14 V |
| 1 - body ground | Turn ignition switch off | Below 1 V |
| 4 - body ground | Always | 10 to 14 V |
| 7 - body ground | Always | Below 1 V |

- (c) Connect the connector to turn on the signal flasher and turn the ignition switch on (IG). inspect the wire harness side connector from the back according to the conditions listed in the table below.

Standard voltage

| Tester connection | Condition | Specified condition |
|-------------------|--|--|
| 2 - body ground | Hazard switch OFF → ON | 0 V → 10 to 14 V (60 to 120 time per minute) |
| 2 - body ground | Turn signal switch (right turn) OFF → ON | 0 V → 10 to 14 V (60 to 120 time per minute) |
| 3 - body ground | Hazard switch OFF → ON | 0 V → 10 to 14 V (60 to 120 time per minute) |
| 3 - body ground | Turn signal switch (left turn) OFF → ON | 0 V → 10 to 14 V (60 to 120 time per minute) |
| 5 - body ground | Turn signal switch (left turn) OFF → ON | 10 to 14 V → 0 V |
| 6 - body ground | Turn signal switch (right turn) OFF → ON | 10 to 14 V → 0 V |
| 8 - body ground | Hazard switch OFF → ON | 10 to 14 V → 0 V |


HEADLIGHT RELAY

INSPECTION

1. INSPECT HEADLIGHT RELAY

- (a) Measure the resistance according to the value(s) in the table below.

Standard resistance



| Tester connection | Specified condition |
|-------------------|--|
| 3 - 5 | 10 kΩ or higher |
| 3 - 5 | Below 1 Ω (When battery voltage is applied to terminal 1 - 2) |

