


# ELECTRICAL WIRING DIAGRAM

**ESPERO ■**  
**ARANOS ■**



**DAEWOO MOTOR CO., LTD.**



# **ELECTRICAL WIRING DIAGRAM**

**ESPERO**  
**ARANOS** 



# CONTENTS

## A. GENERAL DESCRIPTION

1. How to read wiring diagram .....	4
2. Circuit identification code .....	5
3. Wiring color .....	5

## B. HARNESS CONNECTORS AND FUSE, RELAYS

1. Harness connector location views(1.5 DOHC/1.8, 2.0 MPFI) .....	6
2. Fuse location and usage(1.5 DOHC/1.8, 2.0 MPFI) .....	9
3. ECM classification .....	12
4 Electrical wiring diagrams .....	14

---

## FOREWORD

All information illustrations and specifications contained in this manual are based on the latest product information available at the time of manual approval.  
The right is reserved to make changes at any time without notice.



**DAEWOO MOTOR CO., LTD.**

SEOUL, KOREA

# A. GENERAL DESCRIPTION

## 1. HOW TO READ WIRING DIAGRAM

Ex) E1: Head Lamp(Left)  
 E2: Head Lamp(Right)  
 K7: Head Lamp Relay


"30" Line: Battery Positive(+) Line

"15" Line: Ignition ON

"15A" Line: Ignition ON

(But, when cranking engine(Ignition 3 position), power is not supplied.)

"58" Line: Light Switch ON



A. 123: A number(123) indicates the location of connecting wiring in this diagram.  
 F5: Component connected with this wiring

B. Components and Terminal Number.  
 K7: Head lamp Relay  
 86, 30, 85, 87: Terminal Number

C. Connector No. and Terminal No. of the two connecting harness.  
 - Terminal #3 of X 50 Connector

D. Cable Color and Wiring Sectional Area  
 First Letter: Basic Color  
 Second Letter: Identification Color  
 Figure: Cross Sectional Area

E. Ground Location

"B  $\overset{A}{+}$  ": A and B lines are connected.

"B  $\overset{A}{-}$  ": A and B lines are not connected, but different lines.

## 2. CIRCUIT IDENTIFICATION CODE

IDENTIFICATION	COMPONENT	PART NAME(EXAMPLE)
E	Lamp	Head Lamp, Fog Lamp
F	Protector	Fuse
G	Power Supply	Alternator, Battery
H	Transfer	Horn, Speaker, Turn Signal Lamp
K	Relay	Relay
L	Sensor	Ignition Coil
M	Motor	Wiper Motor, Window Motor
D	Meter	Tachometer, Volt Meter
R	Resistor	Blower Resistor
S	Switch	Wiper Switch: Defroster Switch
X	Connector	Connectors Between Harnesses
Y	Electrical	Driving Unit Solenoid Valve


## 3. WIRING COLOR

As the wiring harness includes a large number of cables to complete individual circuits, the insulator of each cable is color coded to prevent wrong wiring. The alphabetical symbols in the following table represent the color of cables and the same symbols are also used the wiring. The cable identification symbol consists of a figure and letters.

Symbol	Color	Symbol	Color
L	blue	Br	brown
Y	yellow	Gr	grey
G	green	R	red
W	white	B	black
VIO	violet		


The figure indicates the size of wire and the first and second letters denote the basic color and identification color, respectively.

The size of wire is indicated in terms of sectional area.



## B. HARNESS CONNECTORS AND FUSE, RELAYS

### 1. HARNESS CONNECTOR LOCATION VIEWS (1.5 DOHC/1.8, 2.0 MPFI)



**\* LEGEND**

- I/P (Instrument panel)
- F/I (Fuel injection)
- H.REF. (Harness reference)



**1-1. EVERY CONNECTOR DESCRIPTION**

- X2 Connector for I/P and Front Harness(14 pin)
- X2A Connector for I/P and Front Harness(12 pin)
- X2B Connector for I/P and Front Harness(4 pin)
- X3 Connector for I/P and Engine Harness(10 pin)
- X31 Connector for Engine Harness and Selector Position Switch(11 pin A/T)
- X32 Connector for I/P and Air Bag Harness(4 pin)
- X4 Connector for I/P and F/I Harness(20 pin)
- X4A Connector for I/P and F/I Harness(9 pin A/T)
- X5 Connector for Front Body and Rear Body Harness(14 pin)
- X5A Connector for Front Body and Rear Body Harness(1 pin)
- X51 Connector for Rear Body Harness and Trunk LID Harness(8 pin)
- X52 Connector for Rear Body Harness and Left Combination Lamp(4 pin)
- X53 Connector for Rear Body Harness and Right Combination Lamp(4 pin)
- X54 Connector for Rear Body Harness and Rear End Panel Harness(3 pin)
- X6 Connector for I/P and Front Body Harness(21 pin)
- X6A Connector for I/P and Front Body Harness(9 pin)
- X61 Connector for Front Body Harness and Front-Left Door Harness(14 pin)  
female Connector
- X61A Connector for Front Body Harness and Front-Left Door Harness(14 pin)  
male Connector
- X62 Connector for Front Body Harness and Front-Right Door Harness(14 pin)
- X63 Connector for Front Body Harness and Rear-Left Door Harness(7 pin)
- X64 Connector for Front Body Harness and Rear-Right Door Harness(7 pin)
- X61 Connector for Front Body Harness and Front-Right Door Harness(14 pin)  
female Connector
- X62A Connector for Front Body Harness and Front-Right Door Harness(14 pin)  
male Connector
- X63 Connector for Front Body Harness and Rear-Right Door Harness(7 pin)
- X64 Connector for Front Body Harness and Rear-Left Door Harness(7 pin)
- X42 Connector for F/I Harness and Front Harness(3 pin)
- X43 Connector for ALDL(12 pin)
- X45 Connector for F/I Harness and Selector Position Switch(4 pin A/T)
- X48 Connector for F/I Harness and Injector(2 pin, DOHC)

\* only L.H.D vehicle


\* only R.H.D vehicle

- X7 Connector for F/I Harness and ABS Harness(8 pin)
- X11 Connector for Analog I/P(16 pin)
- X11A Connector for Analog I/P(14 pin)
- X11B Connector for Analog I/P(10 pin, A/T)
- X12 Connector for IP and Center Console Harness(5 pin)
- X21 Connector for Front Body and Antenna Harness(3 pin)

## **1-2. GROUND LOCATION**



1. I/P Harness Ground - I/P Rear Side
  - 1.1 Battery Main Ground - End part of Front-Left Fender
2. Battery Main Ground - End part of Front-Left Fender
4. F/I Harness Ground - Intake Manifold
5. Rear Body Harness Ground - License Plate of the Trunk Inside
6. Front Body Harness Ground - under the Driver Seat
7. ABS Ground - Front Left Fender End

2. FUSE LOCATION AND USAGE(1.5 DOHC/1.8, 2.0 MPFI)






Fuse No.	Capacity	Usage	Fuse No.	Capacity	Usage	Fuse No.	Capacity	Usage
1	10A	ECM Power, TCM Power(A/T)	9	20A	OSRV mirror and Rear Window Defroster D.R.L Relay	17	10A	ABS Power, IMMO unit
2	20A	Fuel Pump Relay, Oil Pressure Switch, IMMO. unit	10	30A	Radiator Electric Fan Relay(High Speed) Radiator Electric Fan Relay(Low Speed)	18	30A	Horn, Central Locking Device, Auto Trunk Switch
3	20A	Brake Switch, Turn Signal Lamp, Electric OSRV Mirror Switch, Selector Position Switch	11	10A	Illumination Lamp	19	20A	Front Fog Lamp Relay
4	30A	Wiper	12	10A	ECM IG Power, Speed Sensor, Injector, TCM Power	20	30A	Blower Motor Relay
5	30A	Radiator Temperature Switch	13	20A	Alternator F Terminal, D.R.L unit, Rear Spoiler Control Lamp, Defroster, Digital Clock, Chime Bell, Cigar Lighter.	21	10A	Head Lamp High Beam(Left)
6	20A	Fan cycling switch, A/C mode switch, Compressor Cut-off Relay, Electric Fan Relay high Speed, ABS Power	14	10A	Analog I/P	22	10A	Head Lamp High Beam(Right)
7	30A	Power Window	15	20A	D.R.L unit, Reading Lamp, Hazard Lamp, Digital Clock, Room Lamp, Auto Antenna, Car Audio, Chime Bell, Trunk Lamp	23	10A	Head Lamp Low Beam(Left)
8	10A	Car Audio	16	10A	Air Bag	24	10A	Head Lamp Low Beam(Right)
						25	40A	ABS Main Power

**RELAY LOCATION (1.5 DOHC/1.8, 2.0 MPFI)**



COMPRESSOR CUT OFF RELAY      ELECTRIC FAN RELAY LOW SPEED



o Engine Room Fuse Box

PART NAME	PART NO.	REMARKS
Wiper Time Relay	94788146	
Electric Fan Relay High Speed	90244312-A	
Fog Lamp Relay	90057745	
Blower Motor Relay	90244312-A	
Horn Relay	90376920	
Compressor Cut-off Relay	90244312-A	Micro Relay
Electric Fan Relay Low Speed	90229206	Micro Relay

o Inside of driver side panel

PART NAME	PART NO.	REMARKS
Fuel Pump Relay	90191753-A	5 pin
Illumination Control Relay	96098561	Blue Case
Defroster and OSR V Mirror Defroster Time Relay	96116223	Brown Case
Rear Spoiler Lamp Relay	96149299	3 pin

o Inside of driver door

PART NAME	PART NO.	REMARKS
One Touch Power Relay	96149297	

o Left side of Kaul Panel(coolant auxiliary tank cap left side)

PART NAME	PART NO.	REMARKS
ABS Relay	12135010	


o Inside of co-driver side panel

PART NAME	PART NO.	REMARKS
Central Door Locking Relay	90191825	

o Lower side of Glove Box: T.C.M

PART NAME	PART NO.	REMARKS
1.5 DOHC/SOHC MPFI	N96160086	DF
1.8, 2.0 SOHC MPFI	96111009	DC

o Relay Box at the upper side of a Clutch Pedal



NO	PART NAME	PART NO.	REMARKS
A	Chime Bell	96187783	
B	Turn Signal Lamp Relay	90240050-A	
C	Illumination Lamp Relay	90229206	
D	Head Lamp Relay	90229206	
E	DRL Relay	90340520	
	ABS Computer(EBCM)	16207489	


\* Note that the relay location may be changed without notice.

## 3. ECM CLASSIFICATION

○ ECM Part Number

ENGINE	EMIS- SION	T/M	E C M			LOOP	IMMO.	AREA	
			TYPE	PART/NO.	I. D				
1.5 DOHC	Leaded	M/T	IEFI—6	16219839	GR	CLOSE		Intense cold area	
		A/T	IEFI—6	16219339	NM	CLOSE		Intense cold area	
	Unleaded	M/T	IEFI—S	16214609	PH	CLOSE		General area	
			IEFI—6	16216539	JF	CLOSE	○	Europe IMMO.	
		A/T		IEFI—6	16216699	NC	CLOSE		Europe non immo.
			16216589		JG	CLOSE	○	Europe IMMO.	
	1.8 MPI	Unleaded	M/T	IEFI—6	16216609	QG	CLOSE	○	Europe IMMO.
					16220109	HR	CLOSE		High altitude area
16216619					QJ	CLOSE		Europe, General area	
A/T			IEFI—6	16216629	QF	CLOSE	○	Europe IMMO.	
				16220099	HS	CLOSE		High altitude area	
				16216639	QK	CLOSE		Europe General area	
2.0 MPI	Leaded	M/T	IEFI—6	16209819	XD	OPEN		High altitude area	
				16209839	XG	OPEN		Intense heat/cold area	
		A/T	IEFI—6	16209829	XE	OPEN		High altitude area	
				16209849	XH	OPEN		General area	
	Unleaded	M/T	IEFI—S	16199999	DH	CLOSE		Guatemala	
				16200019	DF	CLOSE		Chile	
			IEFI—6	16199749	EE	CLOSE		Brazil	
				16216659	QL	CLOSE		Israel, Australia	
				16216649	QC	CLOSE	○	Europe IMMO.	
		A/T	IEFI—S	16200009	EH	CLOSE		Guatemala	
				16200029	DG	CLOSE		Chile	
			IEFI—6	16199729	DE	CLOSE		Brazil	
				16216729	GN	CLOSE		Europe non immo.	
16216669	QB	CLOSE	○	Europe IMMO.					

o ECM Identification Method



o You can not exchange IEFI-S ECM, and IEFI-6 ECM each other because those are different.

#### 4. ELECTRICAL WIRING DIAGRAMS


1) Ignition Switch and Starting Wiring .....	16
2) Charging and Horn Wiring .....	18
3) ECM Main Power and Ground, Injector Wiring(1.5 DOHC, IEFI-S Type) .....	20
4) Step Motor, Ignition Coil, Distributor Wiring(1.5 DOHC, IEFI-S Type) .....	22
5) Sensor and ECM wiring(1.5 DOHC, IEFI-S Type) .....	24
6) "Service Engine Soon" Light, Fuel Pump Wiring(1.5 DOHC, IEFI-S Type) .....	26
7) ECM Main Power and Ground(1.8/2.0L MPFI, IEFI-S Type) .....	28
8) Step Motor, Ignition Coil, Distributor Wiring(1.8/2.0L MPFI, IEFI-S Type) .....	29
9) Sensor and ECM Wiring(1.8/2.0L MPFI, IEFI-S Type) .....	30
10) "Service Engine Soon" Light, Fuel Pump Wiring(1.8/2.0L MPFI, IEFI-S Type) .....	31
11) ECM Main Power and Ground, Injector Wiring(1.5 DOHC, IEFI-6 Type) .....	32
12) Step Motor, Ignition Coil, Distributor Wiring(1.5 DOHC, IEFI-6 Type) .....	34
13) Sensor and ECM Wiring(1.5 DOHC, IEFI-6 Type) .....	36
14) "Service Engine Soon" Light, Fuel Pump Wiring(1.5 DOHC, IEFI-6 Type) .....	38
15) ECM main Power and Ground(1.8/2.0L MPFI, IEFI-6 Type) .....	40
16) Step Motor, Ignition Coil, Distributor Wiring(1.8/2.0L MPFI, IEFI-6 Type) .....	41
17) Sensor and ECM Wiring(1.8/2.0L MPFI, IEFI-6 Type) .....	42
18) "Service Engine Soon" Light, Fuel Pump Wiring(1.8/2.0L MPFI, IEFI-6 Type) .....	43
19) Head Lamp Wiring .....	44
20) Front Fog and Rear Fog Lamp Wiring .....	46
21) Head Lamp Leveling Device(HLLD) Wiring .....	47
22) Day Time Running Light(DRL) Wiring .....	48
23) Clearance Lamp, Brake System Lamp, Reading Lamp Wiring .....	49
24) Illumination Control and Rear Window Defroster wiring .....	50
25) Hazard Lamp and Turn Signal Lamp Wiring .....	52
26) Air Con Compressor, Electric Fan, Blower Motor Wiring(IEFI-S Type) .....	55
27) Air Con Compressor, Electric Fan, Blower Motor Wiring(IEFI-6 Type) .....	57
28) Wiper Wiring .....	59
29) Room Lamp and Digital Clock Wiring .....	62
30) Car Audio Wiring .....	63
31) Chime Bell and Reverse Lamp Wiring .....	64
32) Power Window Wiring – LHD .....	66
33) Power Window Wiring – RHD .....	67
34) Central Door Locking Wiring – LHD .....	68
35) Central Door Locking Wiring – RHD .....	69






36) Electric OSRV Mirror Wiring – LHD .....	70
37) Electric OSRV Mirror Wiring – RHD .....	71
38) Shift-up Lever Location Lamp and Sensor Wiring – LHD .....	72
39) TCM and Solenoid Valve Wiring – LHD .....	73
40) TCM Diagram – LHD .....	74
41) Shift-up Lever Location Lamp and Sensor Wiring – RHD .....	75
42) TCM and Solenoid Valve Wiring – RHD .....	76
43) TCM Diagram – RHD .....	77
44) Auto Trunk, Cigarette Lighter Wiring .....	78
45) ABS Wiring .....	80
46) Analog I-P Wiring .....	81
47) Immobilizer, Air Bag Wiring .....	82






1) IGNITION SWITCH AND STARTER WIRING(1.5 DOHC/1.8, 2.0 MPFI)

- G1 BATTERY
- M1 STARTING MOTOR
- S1 IGNITION SWITCH
- S2 P/N SWITCH




- Number 30, 15A, 15, Ka and 50 are indexed on the S1 ignition switch.
- S2 P.N Switch(Selector Position Switch) and X31 Connector are for only A/T Vehicle When the PN Switch 2 is at the position of P or N.  
PN switch S2 is contacted so that starter motor operates because the current is feeded to the terminal 50 of the ignition motor when the PN switch is at the driving position(R,D,3,L) the starter motor stops because the switch is off.






2) CHARGING AND HORN WIRING(1.5 DOHC/1.8, 2.0 MPFI)

- E1 CHARGING WARN LAMP
- G2 ALTERNATOR
- H1 HORN
- H2 HORN
- K1 HORN RELAY
- S3 HORN SWITCH




**E1** is connected to the battery charging lamp on I/P (refer to I/P wiring)


- If the alternator connector is connected normally, the power of "L" terminal is 0.6V~2V when an ignition switch is ON and is equal to the battery charging voltage on operating an engine (over about 800 rpm)
- When a terminal "L" is disconnected or cut off, the terminal "F" is an compensating circuit to magnetize a rotor coil instead of the terminal "L".
- H1 and H2 are for low tone and high tone.




X11  
ANALOG I/P  
(I/P HARNESS REFERENCE,  
NO. INDEXED)




X11A  
ANALOG I/P  
(I/P HARNESS REFERENCE,  
NO. INDEXED)




ALTERNATOR CONNECTOR  
(ENGINE HARNESS REF.)





X2  
FRONT HARNESS CONNECTOR  
(I/P HARNESS REF.)







X3  
ENGINE HARNESS CONNECTOR  
(I/P HARNESS REF.)



X2A  
FRONT HARNESS CONNECTOR  
(I/P HARNESS REF.)




MAIN FUSE BOX



HORN SWITCH OF AIR BAG TYPE VEHICLE

3) ECM MAIN POWER AND GROUND, INJECTOR WIRING(1.5 DOHC, IEFI-S TYPE)


K57 ECM(CONTROL UNIT)  
Y1 INJECTOR




This wiring is described for the fuel injection of 1.5DOHC Engine and divided at each page in order to prevent complexity.

• Injector Resistance Value

Individual Resistance	15-20ohms	For each item
Total Resistance	3.5-4.9ohms	Resistance between A6 and D16 or D15 of ECM





(INJECTOR HARNESS REF.)








INJECTOR



ECM TERMINAL (INJECTION HARNESS REF.)






X4  
F/I HARNESS CONNECTOR  
(I/P HARNESS REF.)



- This diagram is for a power supply to operate-ECM. That is, when an ignition switch is "ON", B<sup>+</sup> power should be measured at the ECM terminal B<sub>1</sub>, C<sub>16</sub>, A<sub>6</sub>, D<sub>15</sub> and D<sub>16</sub>: and the following terminals are connected to the engine ground; D<sub>1</sub>, D<sub>3</sub>, D<sub>6</sub>, D<sub>10</sub>, A<sub>12</sub> terminals.







- Pick-up Coil

Resistance	500 ~ 1500 ohms
Insulation resistance	∞

- Ignition Coil

1st Resistance	0.35 ~ 0.45
2nd Resistance	7.5 ~ 9.5
Insulation resistance	∞

- Step motor M2 controls air quantity to be by-passed to inlet manifold in order to keep an appropriate engine RPM in accordance with the engine operating condition.

- Step motor resistance

40 ~ 80 ohms	A ↔ B terminal
	C ↔ D terminal

Idle Revolution speed	800 ~ 850RPM(Heating)
-----------------------	-----------------------


- A distributor has a two pin connector and a four pin connector. Because a two pin connector is connected to an "+" and "-" terminals. "B+" voltage should be measured when an ignition switch is "ON". A four pin connector is connected to ECM and supply the most appropriate ignition timing in accordance with the operating condition the regular voltage between each terminal connected to ECM and vehicle ground is as follows;

ECM TERMINAL	DISTRIBUTOR TERMINAL	CHECK CONDITION		
		IGNITION SWITCH "ON"(ENGINE STEP)	ON STARTING	AFTER STARTING
B3	A(Ground)	0V	0V	0V
D5	B(by-pass)	0V	0V	4.5-5V
B5	C(REF)	below 0.3V	0.5-1.5V	0.7-2.7V
D4	D(EST)	below 0.3V	below 0.3V	1-3V





5) SENSOR AND ECM WIRING(1.5 DOHC, IEFI-S TYPE)





- P30 COOLANT TEMPERATURE SENSOR(CTS)
- P31 INTAKE MANIFOLD AIR TEMPERATURE SENSOR(MAT)
- P32 INTAKE MANIFOLD AIR PRESSURE SENSOR(MAP)
- P33 THROTTLE POSITION SENSOR(TPS)

- P34 OXYGEN SENSOR(UNLEADED TYPE)
- P35 OXYGEN SENSOR(LEADED TYPE)
- P36 VEHICLE SPEED SENSOR(VSS)
- K57 ECM




31 140 1 2 3 4 5 6 7 8 9 150 1 2 3 4 5 6 7 8 9 160 1 2 3 4 5 6 7 8 9 170 1 2 3 4 5 6 7 8





- Resistance for CTS and MAT sensor

100°C	0.185 Kilo-ohms
90°C	0.240 Kilo-ohms
80°C	0.332 Kilo-ohms
70°C	0.450 Kilo-ohms
40°C	1.46 Kilo-ohms
20°C	3.4 Kilo-ohms
10°C	5.67 Kilo-ohms
-10°C	16.1 Kilo-ohms



MAIN FUSE BOX

- Temperature Sensor: Temperature Sensor voltage supplied +5V through ECM inner resistor is as follows and ECM check this voltage to notice the engine temperature;

Engine Temp.	Resistance	Signal Voltage
Cooling	Higher	Rising
Heating	Lower	Falling

- MAP Sensor: This sensor has a function converting the inlet manifold pressure change to voltage and measure the voltage between the MAP sensor "B" terminal and the vehicle body ground.





Inlet manifold pressure	Signal voltage
Air pressure (IG "ON")	4.8~5.2 V
-0.2 bar	3.5~3.9 V
-0.4 bar	2.3~2.7 V
-0.6 bar	1.3~1.7 V
-0.8 bar	0.3~0.7 V

- TPS(Throttle Position Sensor): Measure the voltage between TPS "C" terminal and the vehicle body ground.

Throttle valve closing	0.4~0.8 V
100% opening	4.1~4.5 V

- VSS(Vehicle Speed Sensor):  
It uses the hole sensor theory so that below 0.5 V is detected when a current flows by closing the transistor and 12V is detected by opening.
- Oxygen Sensor:  
is to detect the mixed ratio and voltage should be changed between 0.1 and 0.9 V when an engine is warming-up fully. (when the harness is connected normally)





A1: B+ power is feeded to K3 fuel pump relay for 2 seconds when on ignition switch is "ON"

- The operating status of fuel pump relay


Engine status	ECM terminal V	Pump operation
Ignition switch is "ON"(engine stop)	A1: over 10V (For 2 seconds)	2 seconds of operation
On starting	A1: over 10V	Continuously operating
After starting	A1: over 10V	Continuously operating

- The regular pressure of fuel line

Idle RPM	2.3 ~ 2.7 kg/cm <sup>2</sup>
Engine Stop(Wire jumped)	2.8 ~ 3.2 kg/cm <sup>2</sup>



- At the A/T vehicle. P-N switch is installed on the upper side of auto transmission and ECM detects the driving position(D, R, 3, L) from the switch and compensates the idle rpm reduction generated from load increase.
- ECM terminal voltage when ignition switch "ON" or idle rpm.

Selector lever	ECM "B10" terminal
P-N	0 V
D, R, 3, L	Battery voltage(over 12 V)




7) ECM MAIN POWER AND GROUND(1.8/2.0 L MPFI, IEFI-S TYPE)


K57 ECM  
Y1 INJECTOR




INJECTOR



ECM TERMINAL CONNECTOR  
(INJECTION HARNESS REF.)





F/I HARNESS CONNECTOR  
(I/P HARNESS REF.)



X4

8) STEP MOTOR, IGNITION COIL, DISTRIBUTOR WIRING(1.8/2.0 L MPFI, IEFI-S TYPE)

- L1 IGNITION COIL
- M2 STEP MOTOR
- K57 ECM
- Y2 DISTRIBUTOR



IGNITION COIL CONNECTOR (E/G HARNESS REF.)



DISTRIBUTOR CONNECTOR (E/G HARNESS REF.) (F/I HARNESS REF.)







STEP MOTOR(IAC) CONNECTOR (F/T HARNESS REF.)



X3 ENGINE HARNESS (I/P HARNESS REF.)

9) SENSOR AND ECM WIRING(1.8/2.0 L MPFI, IEFI-S TYPE)

- P30 COOLANT TEMPERATURE SENSOR(CTS)
- P31 INTAKE MANIFOLD AIR TEMPERATURE SENSOR(MAT)
- P32 INTAKE MANIFOLD AIR PRESSURE SENSOR(MAP)
- P33 THROTTLE POSITION SENSOR(TPS)
- P34 OXYGEN SENSOR(UNLEADED TYPE)
- P35 OXYGEN SENSOR(LEADED TYPE)
- P36 VEHICLE SPEED SENSOR(V.S.S)
- K57 ECM







10) "SERVICE ENGINE SOON" LIGHT, FUEL PUMP WIRING(1.8/2.0 L MPFI, IEFI-S TYPE)

E2 "SERVICE ENGINE SOON" LIGHT  
 K2 P-N RELAY(AT)  
 K3 FUEL PUMP RELAY  
 K57 ECM

M3 FUEL PUMP  
 S4 OIL PRESSURE SWITCH  
 X43 ALDL CONNECTOR




X43  
ALDL CONNECTOR  
(F/I HARNESS REF.)



X42 FRONT  
H. CONNECTOR  
(F/I HARNESS REF.)




OIL PRESSURE  
SWITCH  
CONNECTOR



X4 F/I HARNESS  
(I/P HARNESS REF.)

11) ECM MAIN POWER AND GROUND(1.5 DOHC, IEFI-6 TYPE)




K57 ECM  
Y1 INJECTOR









This wiring is described for the fuel injection of 1.5DOHC Engine and deviated at each page in order to prevent complexity.

• Injector Resistance Value


Individual Resistance	15~20ohms	For each item
Total Resistance	3.5~4.9ohms	Resistance between A6 and 216 or D15 of ECM





- This diagram is for a power supply to operate-ECM. That is, when an ignition switch is "ON". B+ power should be measured at the ECM terminal B1, C16, C4, C11 and C10; and the following terminals are connected to the engine ground; D1, C13, C13, B10, A12 terminals.





- Pick-up Coil

Resistance	500 ~ 1500 ohms
Insulation resistance	∞

- Ignition Coil



1st Resistance	0.35 ~ 0.45 ohms
2nd Resistance	7.5 ~ 9.5 ohms
Insulation resistance	∞

- Step motor M2 controls air quantity to be by-passed to inlet manifold in order to keep an appropriate engine RPM in accordance with the engine operating condition.

- Step motor resistance


40 ~ 80 ohms	A ↔ B terminal
	C ↔ D terminal

Idle Revolution speed	800 ~ 850RPM(Heating)
-----------------------	-----------------------



- A distributor has a two pin connector and a four pin connector. Because a two pin connector is connected to an "+" and "-" terminals. "B+" voltage should be measured when an ignition switch is "ON". A four pin connector is connected to ECM and supply the most appropriate ignition timing in accordance with the operating condition the regular voltage between each terminal connected to ECM and vehicle ground is as follows;

ECM TERMINAL	DISTRIBUTOR TERMINAL	CHECK CONDITION		
		IGNITION SWITCH "ON"(ENGINE STEP)	ON STARTING	AFTER STARTING
B9	A(Ground)	0V	0V	0V
C3	B(by-pass)	0V	0V	4.5-5V
A1	C(REF)	below 0.3V	0.5-1.5V	0.7-2.7V
D10	D(EST)	below 0.3V	below 0.3V	1-3V



13) SENSOR AND ECM WIRING(1.5 DOHC, IEFI-6 TYPE)

P30 COOLANT TEMPERATURE SENSOR(CTS)

P31 INTAKE MANIFOLD AIR TEMPERATURE SENSOR(MAT)

P32 INTAKE MANIFOLD AIR PRESSURE SENSOR(MAP)







P33 THROTTLE POSITION SENSOR(TPS)





P34 OXYGEN SENSOR(UNLEADED TYPE)

P35 OXYGEN SENSOR(LEADED TYPE)

P36 VEHICLE SPEED SENSOR(VSS)


P37 OCTANE SWITCH CONNECTOR





- Resistance for CTS and MAT sensor

100°C	0.185 Kilo-ohms
90°C	0.240 Kilo-ohms
80°C	0.332 Kilo-ohms
70°C	0.450 Kilo-ohms
40°C	1.46 Kilo-ohms
20°C	3.4 Kilo-ohms
10°C	5.67 Kilo-ohms
-10°C	16.1 Kilo-ohms



MAIN FUSE BOX

- Temperature Sensor: Temperature Sensor voltage supplied +5V through ECM inner resistor is as follows and ECM check this voltage to notice the engine temperature;

Engine Temp.	Resistance	Signal Voltage
Cooling	Higher	Rising
Heating	Lower	Falling

- MAP Sensor: This sensor has a function converting the inlet manifold pressure change to voltage and measure the voltage between the MAP sensor "B" terminal and the vehicle body ground.

Inlet manifold pressure	Signal voltage
Air pressure (IG "ON")	4.8 ~ 5.2 V
-0.2 bar	3.5 ~ 3.9 V
-0.4 bar	2.3 ~ 2.7 V
-0.6 bar	1.3 ~ 1.7 V
-0.8 bar	0.3 ~ 0.7 V




- TPS(Throttle Position Sensor): Measure the voltage between TPS "C" terminal and the vehicle body ground.

Throttle valve closing	0.4~0.8 V
100% opening	4.1~4.5 V




- VSS(Vehicle Speed Sensor): It uses the hole sensor theory so that below 0.5 V is detected when a current flows by closing the transistor and 12V is detected by opening.
- Oxygen Sensor: is to detect the mixed ratio and voltage should be changed between 0.1 and 0.9 V when an engine is warming-up fully. (when the harness is connected normally)







MAIN FUSE BOX



- B6: Ter B6 is grounded from K3 fuel pump relay Ter, 85 for 2 seconds when an ignition switch is "ON".

- The operating status of fuel pump relay


Engine status	ECM terminal V	Pump operation
Ignition switch is "ON"(engine stop)	B6: over 0V (For 2 seconds)	2 seconds of operation
On starting	B6: over 0V	Continuously operating
After starting	B6: over 0V	Continuously operating

- The regular pressure of fuel line

Idle RPM	2.3 ~ 2.7 kg/cm <sup>2</sup>
Engine Stop(Wire jumped)	2.8 ~ 3.2 kg/cm <sup>2</sup>



- At the A/T vehicle. P-N switch is installed on the upper side of auto transmission and ECM detects the driving position(D, R, 3, L) from the switch and compensates the idle rpm reduction generated from load increase.
- ECM terminal voltage when ignition switch "ON" or idle rpm.

Selector lever	ECM "B10" terminal
P-N	0 V
D, R, 3, L	Battery voltage(over 12 V)



15) ECM MAIN POWER AND GROUND(1.8/2.0 L MPFI, IEFI-6 TYPE)

K57 ECM  
Y1 INJECTOR





ECM TERMINAL CONNECTOR (INJECTION HARNESS REF.)

X4 F/I HARNESS (I/P HARNESS REF.)

16) STEP MOTOR, IGNITION COIL, DISTRIBUTOR WIRING(1.8/2.0 L MPFI, IEFI-6 TYPE)

- L1 IGNITION COIL
- M2 STEP MOTOR
- K57 ECM
- Y2 DISTRIBUTOR




IGNITION COIL  
(E/G HARNESS REF.)



DISTRIBUTOR CONNECTOR  
(E/G HARNESS REF.) (F/I HARNESS REF.)



STEP MOTOR(IAC)  
(F/T HARNESS REF.)




X3  
ENGINE HARNESS  
(I/P HARNESS REF.)



18) "SERVICE ENGINE SOON" LIGHT, FUEL PUMP WIRING(1.8/2.0 L MPFI, IEFI-6 TYPE)

- E2 "SERVICE ENGINE SOON" LIGHT
- K2 P-N RELAY(AT)
- K3 FUEL PUMP RELAY
- K57 ECM


- M3 FUEL PUMP
- S4 OIL PRESSURE SWITCH
- X43 ALDL CONNECTOR









19) HEAD LAMP WIRING(1.5 DOHC/1.8, 2.0 L MPFI)


E3 HEAD LAMP LOW BEAM RH  
 E4 HEAD LAMP LOW BEAM LH  
 E5 HEAD LAMP HIGH BEAM RH  
 E6 HEAD LAMP HIGH BEAM LH

K4 ILLUMINATION LAMP RELAY  
 K5 HEAD LAMP RELAY  
 S5 LIGHT SWITCH  
 S6 DIMMER SWITCH




- 58 Line  
 After a light switch is set to 1st or 2nd step, a illumination relay is operating to feed power to fuse 11. The line connect to F2 is called a 58 line. The 58 line feeds power to various illumination lamps and clearance lamps, etc.
- S5 switch, S6 dimmer switch  
 A light switch and A dimmer switch are displayed respectively on the wiring diagram. But these are assembled physically in a device.








ENGINE ROOM FUSE BOX





MAIN FUSE BOX




20) FRONT FOG AND REAR FOG LAMP WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

- E7 REAR FOG LAMP LH
- E8 REAR FOG LAMP RH
- E9 FRONT FOG LAMP LH
- E10 FRONT FOG LAMP RH


- K6 FRONT FOG LAMP RELAY
- S7 REAR FOG SWITCH
- S8 FRONT FOG SWITCH




X6A



X51



FOG LAMP SWITCH






X2



21) HEAD LAMP LEVELING DIVICE(HLLD) WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

- M4 HLLD MOTOR LH
- M5 HLLD MOTOR RH
- S9 HLLD CONTROL SWITCH






23) CLEARANCE LAMP, BRAKE SYSTEM LAMP, READING LAMP WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

- E11 CLEARANCE LAMP(FR, LH)
- E12 CLEARANCE LAMP(FR, RH)
- E13 TAIL LAMP(RR, RH)
- E14 TAIL LAMP(RR, LH)
- E15 TAIL LAMP; TRUNK
- E16 TAIL LAMP; TRUNK

- E17 LICENCE PLATE LAMP
- E18 LICENCE PLATE LAMP
- E19 REAR SPOILER CONTROL LAMP
- E20 BRAKE SYSTEM LAMP(RR, RH)
- E21 BRAKE SYSTEM LAMP(RR, LH)
- E22 BRAKE SYSTEM LAMP(TRUNK)

- E23 BRAKE SYSTEM LAMP(TRUNK)
- K8 REAR SPOILER RELAY
- S10 BRAKE SYSTEM LAMP SWITCH
- S11 READING LAMP(RR, LH)
- S12 READING LAMP(RR, RH)




• [1438], [1563] This supplies TCM "26" terminal with 12V when braking on the A/T vehicle and notice TCM that the vehicle is braked now.




X54-REAR END HARNESS CONNECTOR (REAR BODY HARNESS REF.)




X52, 53 TAIL LAMP CONNECTOR(LR) (REAR BODY HARNESS REF.)




X51-TRUNK HARNESS CONNECTOR (REAR BODY HARNESS REF.)




X2 FRONT HARNESS CONNECTOR (I/P HARNESS REF.)



X5 REAR BODY HARNESS CONNECTOR (I/P HARNESS REF.)




X6A-FRONT BODY HARNESS CONNECTOR (I/P HARNESS REF.)






X6 FRONT BODY HARNESS CONNECTOR (I/P HARNESS REF.)


**24) ILLUMINATION CONTROL AND REAR WINDOW DEFROSTER WIRING(1.5 DOHC/1.8, 2.0 L MPFI)**

- E24 REAR WINDOW DEFROSTER
- K9 ILLUMINATION CONTROL RELAY
- K10 DEFROSTER TIME RELAY
- S13 DEFROSTER SWITCH
- S14 ILLUMINATION CONTROL SWITCH



- Illumination control relay K9 controls the lightness of location indicator lamps on the IP and each switch according to the signal voltage of illumination control switch S14.
- All lamps connected to the 31b terminal of the illumination control relay should be routed to the ground only through the illumination control relay. That is, the current from the relay 31b to 31(ground) is controlled.
- The resistance between the illumination control switch terminal 2 and 3 is about 9kΩ. It is constant at any switch location.
- When the light switch is operated, the illumination control relay 58b terminal general about 5V and 58c terminal is connected to the ground through the inner relay.
- The signal voltage of the illumination control relay 58a terminal changes according to the switch position(the most light position is 5V, the most dark position is 0V).
- The defroster switch S13 is a one touch type. That is, when it operates one time, the defroster time relay K10 is "ON" and the time relay operates for 10 minutes to be OFF automatically. If reoperating the switch during operating(within 10 minutes), the defroster time relay is OFF.
- [1738] notice that the defroster is operating on IP
- [1375], [1346] is a defroster wiring diagram of electric back mirror







25) HAZARD LAMP AND TURN SIGNAL LAMP WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

- E25 TURN SIGNAL LAMP(TRUNK, L)
- E26 TURN SIGNAL LAMP(R, L)
- E27 TURN SIGNAL LAMP(F, L)
- E28 TURN SIGNAL LAMP(F, R)
- E29 TURN SIGNAL LAMP(R, R)


- E30 TURN SIGNAL LAMP(TRUNK, R)
- K11 TURN SIGNAL LAMP RELAY
- S15 HAZARD LAMP SWITCH
- S16 TURN SIGNAL LAMP SWITCH




- When an hazard lamp switch is OFF, terminal 2 and 4 is connected and the other is disconnected.
- When an hazard lamp switch is On, terminal 6, 8, 9 are connected.
- [886] is connected to the illumination control relay 31b terminal.
- On the cover of turn signal lamp relay and switch a terminal no, like diagram are indexed.
- The current supplied to a turn signal lamp relay 49 terminal is feeded through an hazard lamp switch.
- Notice that an hazard lamp and a turn signal lamp is connected through individual fuse.
- Notice that a turn signal lamp switch S15 is drawn individually on the diagram but it is assembled in a unit actually.
- [1733], [1730] are connected to the operating indicator for LH, RH turn signal lamp on the IP.




X52, X53  
TAIL LAMP CONNECTOR  
(REAR BODY HARNESS REF.)




X51-TRUNK HARNESS  
(CONNECTOR  
(REAR BODY HARNESS))




FRONT TURN SIGNAL LAMP  
(FRONT HARNESS REF.)




HAZARD LAMP SWITCH  
(I/P HARNESS REF.)




TURN SIGNAL LAMP SWITCH  
(I/P HARNESS REF.)









BLINKER UNIT  
(I/P HARNESS REF.)



X6 FRONT BODY HARNESS CONNECTOR  
(I/P HARNESS REF.)



X2  
FRONT HARNESS CONNECTOR  
(I/P HARNESS REF.)











28) WIPER WIRING(1.5 DOHC/1.8, 2.0 L MPFI)



- K16 WIPER RELAY
- M9 WASHER PUMP MOTOR
- M10 WIPER MOTOR
- S22 WIPER SWITCH
- S23 WIPER INTERVAL TIME CONTROL SWITCH




- Notice that low speed and high speed of an wiper motor have no relation with an wiper relay because these low and high speed is operated when a power is supplied from an wiper switch to wiper motor.
- The terminal number of an wiper switch is indexed on the switch cover and terminal 53, 53e are connected in case of "OFF" position and terminal 53, 53e, 53a are connected in case of "INT" position and etc.
- When an wiper switch is put at the "INT" position, an wiper switch terminal 53a and an terminal 1 are connected to supply a power to terminal 1 and operate an wiper relay for 4 to 21 seconds at one time according to a signal voltage feeded from an wiper interval control switch so that operate an wiper motor intervally.
- When an washer switch operates, an washer motor operates and a signal voltage is feeded to an wiper relay terminal 53c, after the switch is "OFF" an wiper relay is operated for about 4 seconds.



WIPER/WASHER SWITCH CONNECTOR (I/P HARNESS REF.)




WIPER MOTOR CONNECTOR (I/P HARNESS REF.)




WASHER PUMP MOTOR (I/P HARNESS REF.)










WIPER INTERVAL TIME CONTROL SWITCH CONNECTOR (I/P HARNESS REF.)



FRONT HARNESS CONNECTOR (I/P HARNESS REF.)




FRONT HARNESS CONNECTOR (I/P HARNESS REF.)








29) ROOM LAMP AND DIGITAL CLOCK WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

E31 DOOR WIRING LAMP  
 E40 ROOM LAMP AND DIGITAL CLOCK  
 S38 DOOR SWITCH(FRONT, LEFT)

S39 DOOR SWITCH(FRONT, RIGHT)  
 S40 DOOR SWITCH(REAR, LEFT)  
 S41 DOOR SWITCH(REAR, RIGHT)




- A room lamp and a digital clock are assembled in a body.
- On the digital clock wiring a terminal No. 3 is for controlling the lightness of an illumination lamp darker when a light lamp switch is "ON".
- Terminal No.4 and a terminal No. 3 is only for illumination the power operating an watch is terminal 1 and 5.



30) CAR AUDIO WIRING(1.5 DOHC/1.8, 2.0 L MPFI)

H3 SPEAKER(R.L)  
 H4 SPEAKER(R.R)  
 H5 SPEAKER(F.L)

H6 SPEAKER(F.R)  
 M1 AUTO ANTENNA MOTOR




- When a radio switch is ON, an auto antenna inner relay is operated by 12V power supplied from a radio terminal 4. At this time, because a contact point of "C" is connected to "+", and a contact point of "D" is connected to "-", an antenna motor is operated.

When an antenna arrives at the end part, a contact point of "A" is connected and at the same time a contact point of "B" is disconnected. So that the motor stop to operate and the antenna is kept on.


When a radio switch is OFF, the power of the radio terminal 4 disappears so that the auto antenna inner relay is off and the contact point of "C" is connected to "C" and the contact point of "A" is connected.

At this time, an antenna motor operates and the antenna falls.


When the antenna arrive at the button, the contact point of A is disconnected and the contact point of B is connected to stop the antenna motor.




CAR AUDIO CONNECTOR  
(I/P HARNESS REF.)




X61-FRT/LH DOOR HARNESS CONNECTOR  
(FRONT BODY HARNESS REF.)



X5-REAR BODY HARNESS CONNECTOR  
(FRONT BODY HARNESS REF.)




X11  
(I/P HARNESS REF, NO INDEXED) FOR LCD








AUTO ANTENNA CONNECTOR  
(FRONT BODY HARNESS REF.)


**31) CHIME BELL AND REVERSE LAMP WIRING(1.5 DOHC/1.8, 2.0 L MPFI)**

- E32 REVERSE LAMP
- H7 CHIME BELL
- S2 SELECTOR POSITION SWITCH(A/T)
- S25 REVERSE LAMP SWITCH(M/T)
- S24 SEAT BELT SWITCH



- A seat belt switch S24 is ON when not wearing it and off when wearing it.
- When an ignition switch is ON(power supplied to a terminal 8) and a seat belt is not worn(terminal is connected to the ground), 12V power is out put to the chime bell terminal 7 to stir up an seat belt warning lamp on and operate it 5 times for 1 second per one time.
- 1732 is connected to a seat belt warning lamp ON IP.
- When an ignition switch is off(a terminal 8 has no power), a chime bell announces quickly at the 1st step of a light switch(supply power to terminal 1) and opening of driver's door.
- The chime bell will sound when the vehicle speed exceeds above the specified speed. (supply power to terminal 4)
- The reverse lamp switch S25 is installed at the M/T vehicle and S2 is installed at the A/T vehicle  
1441, 1565 supplies 12V to TCM 29 terminal on reversely driving to notice a reverse signal is generated.





MAIN FUSE BOX







FIGURE (A) ROOM LEFT SIDE





**32) POWER WINDOW WIRING – LHD(1.5 DOHC/1.8, 2.0 L MPFI)**

M12 POWER WINDOW MOTOR(FR, LH)  
 M13 POWER WINDOW MOTOR(FR, RH)  
 M14 POWER WINDOW MOTOR(RR, LH)  
 M15 POWER WINDOW MOTOR(RR, RH)

S26 POWER WINDOW MAIN SWITCH  
 S26.1 REAR POWER WINDOW LOCKING SWITCH  
 S27 POWER WINDOW SWITCH(FR, RH)  
 S28 POWER WINDOW SWITCH(RR, LH)  
 S29 POWER WINDOW SWITCH(RR, RH)



- When the power window main switch is not operated, All contact points are connected to a ground(12). When the front driver power window switch is set to down position, terminal 15 is connected to B+ and terminal 9 is connected to the ground of terminal 12 so that the power window falls down.
- The rear power window locking switch S26.1 make the main power of the rear power window switch on and off so that it be protected from solitary operating at the rear seat.(for example; when children seats at the rear seat, the rear power window switch does not operate if the switch is off)







### 33) POWER WINDOW WIRING – RHD(1.5 DOHC/1.8, 2.0 L MPFI)

- M12 POWER WINDOW MOTOR(FR, RH)
- M13 POWER WINDOW MOTOR(FR, LH)
- M14 POWER WINDOW MOTOR(RR, RH)
- M15 POWER WINDOW MOTOR(RR, LH)


- S26 POWER WINDOW MAIN SWITCH(FR, RH)
- S26.1 REAR POWER WINDOW LOCKING SWITCH
- S27 POWER WINDOW SWITCH(FR, LH)
- S28 POWER WINDOW SWITCH(RR, RH)
- S29 POWER WINDOW SWITCH(RR, LH)



X61-FRT/LH DOOR H.  
(FRONT BODY HARNESS REF.)



X63, X64



POWER WINDOW SWITCH  
(FRONT DOOR-RIGHT HARNESS REF.)




X62, 62A  
FRT/RH DOOR HARNESS  
(FRT BODY HARNESS REF.)  
X62 : FEMALE CONNECTOR  
X62A : MALE CONNECTOR






34) CENTRAL DOOR LOCKING WIRING – LHD(1.5 DOHC/1.8, 2.0 L MPFI)

K18 CENTRAL DOOR LOCKING RELAY  
 M16 ACTUATOR(FR, RH)  
 M17 ACTUATOR(RR, LH)  
 M18 ACTUATOR(RR, RH)

M19 ACTUATOR(FUEL INLET CAP)  
 S30 CENTRAL DOOR LOCKING SWITCH AND ACTUATOR  
 (FR, LH)




- When the central door locking relay K18 does not operate, the terminal 1 and 2 are connected to the ground 4.
- When the central door locking switch S30 is set to the locking position, the relay terminal 7 is connected to the ground and the inner relay "A" operates for 0.75 second. Therefore, because the relay terminal 1 is connected to "+" and the relay terminal 2 is connected to "-", four actuators operate simultaneously to be locked.
- When opening, the central door locking relay terminal 6 is connected to the ground and the inner relay "B" operate for 0.75 second so that because the terminal 1 is connected to "-" and the terminal 2 is connected to "+", four actuators operate simultaneously to be open.





**35) CENTRAL DOOR LOCKING WIRING – RHD(1.5 DOHC/1.8, 2.0 L MPFI)**

K18 CENTRAL DOOR LOCKING RELAY  
 M16 ACTUATOR(FR, LH)  
 M17 ACTUATOR(RR, RH)  
 M18 ACTUATOR(RR, LH)

M19 ACTUATOR(FUEL INLET CAP)  
 S30 CENTRAL DOOR LOCKING SWITCH AND ACTUATOR  
 (FR, RH)




- When the central door locking relay K18 does not operate, the terminal 1 and 2 are connected to the ground 4.
- When the central door locking switch S30 is set to the locking position, the relay terminal 7 is connected to the ground and the inner relay "A" operates for 0.75 second. Therefore, because the relay terminal 1 is connected to "+" and the relay terminal 2 is connected to "-", four actuators operate simultaneously to be locked.
- When opening, the central door locking relay terminal 6 is connected to the ground and the inner relay "B" operate for 0.75 second so that because the terminal 1 is connected to "-" and the terminal 2 is connected to "+", four actuators operate simultaneously to be open.



36) ELECTRIC OSRV MIRROR WIRING – LHD(1.5 DOHC/1.8, 2.0 L MPFI)

M20 ELECTRIC OSRV MIRROR(LEFT)  
 M21 ELECTRIC OSRV MIRROR(RIGHT)  
 S31 ELECTRIC OSRV MIRROR SWITCH




- This is the wiring that the electric OSRV mirror switch S31 is at the LH side.
- The electric OSRV mirror has two motors; One connected to yellow wiring is for controlling the horizontal angle and the other connected to green wiring is for controlling the vertical angle.
- When pushing the angle control switch to the right side, the terminal 7 is connected to "-" ground and the terminal 5 is connected to "+" so that the motor operate to the reverse side.
- When pushing the angle control switch to the upper side, the switch terminal 5 connected to "-" ground and the terminal 6 is connected to "+" so that the motor operate to the upper side.
- When pushing the switch to the lower side, the switch terminal 5 is connected to "+" and the terminal 6 is connected to "-" ground so that the motor operate to the reverse side.
- 903 is connected to a defroster time relay 87 so that the rear window defroster and the electric OSRV mirror defroster operate simultaneously.
- The switch checking is as follows; when the left to right conversion switch is at the "L" position.


Switch operation	Terminal connected to the terminal 5(+)	Terminal connected to the terminal 8(-)
Upper	terminal 4(green)	terminal 5(black/green)
Lower	terminal 5(black/GE)	terminal 4(green)
Left	terminal 5(black/yellow)	terminal 7(yellow)
Right	terminal 7(yellow)	terminal 5(black/yellow)

• Left-right transfer switch is at "R" position.

Switch operation	Terminal connected to the terminal 5(+)	Terminal connected to the terminal 8(-)
Upper	terminal 3(blue)	terminal 5(black/red)
Lower	terminal 5(black/red)	terminal 3(blue)
Left	terminal 5(blue)	terminal 6(gray)
Right	terminal 6(gray)	terminal 5(blue)




X61 : FEMALE CONNECTOR  
 X61A : MALE CONNECTOR



37) ELECTRIC OSRV MIRROR WIRING – RHD(1.5 DOHC/1.8, 2.0 L MPFI)

M20 ELECTRIC OSRV MIRROR(RIGHT)  
 M21 ELECTRIC OSRV MIRROR(LEFT)  
 S31 ELECTRIC OSRV MIRROR SWITCH







- This is the wiring that the electric OSRV mirror switch S31 is at the RH side.
- The electric OSRV mirror has two motors; One connected to yellow wiring is for controlling the horizontal angle and the other connected to green wiring is for controlling the vertical angle.
- When pushing the angle control switch to the right side, the terminal 2 is connected to "-" ground and the terminal 5 is connected to "+" so that the motor operate to the reverse side.
- When pushing the angle control switch to the upper side, the switch terminal 5 connected to "-" ground and the terminal 1 is connected to "+" so that the motor operate to the upper side.
- When pushing the switch to the lower side, the switch terminal 5 is connected to "+" and the terminal 6 is connected to "-" ground so that the motor operate to the reverse side.
- [883] is connected to a defroster time relay 87 so that the rear window defroster and the electric OSRV mirror defroster operate simultaneously.
- The switch checking is as follows; when the left to right conversion switch is at the "L" position.

Switch operation	Terminal connected to the terminal 5(+)	Terminal connected to the terminal 8(-)
Upper	terminal 1(green)	terminal 5(black/green)
Lower	terminal 5(black/GE)	terminal 1(green)
Left	terminal 5(black/yellow)	terminal 2(yellow)
Right	terminal 2(yellow)	terminal 5(black/yellow)

- Left-right transfer switch is at "R" position.


Switch operation	Terminal connected to the terminal 5(+)	Terminal connected to the terminal 8(-)
Upper	terminal 6(blue)	terminal 5(black/red)
Lower	terminal 5(black/red)	terminal 6(blue)
Left	terminal 5(blue)	terminal 7(gray)
Right	terminal 7(gray)	terminal 5(blue)



**38) SHIFT-UP LEVER LOCATION LAMP AND SENSOR WIRING – LHD(1.5 DOHC/1.8, 2.0 L MPFI)**

- E31 POWER MODE INDICATOR
- E32 WINTER MODE INDICATOR
- H52 SHIFT-UP LEVER POSITION INDICATOR
- K99 CONTROL UNIT T.C.M







- P11 OUTPUT PULSE PICK-UP(OUTPUT SENSOR)
- P12 INPUT PULSE PICK-UP(INPUT SENSOR)
- P13 OIL TEMPERATURE SENSOR
- S2 SELECTOR POSITION SWITCH



39) T.C.M AND SOLENOID VALVE WIRING – LHD(1.5 DOHC/1.8, 2.0 L MPFI)


- K99 CONTROL UNIT T.C.M
- P14 SOLENOID VALVE
- P14.4 NO. 1 SOLENOID VALVE
- P14.2 NO. 2 SOLENOID VALVE

- P14.3 LOCK-UP SOLENOID VALVE
- P14.4 OIL PRESSURE CONTROL SOLENOID VALVE
- S38 POWER AND WINTER MODE SWITCH




40) T.C.M DIAGRAM – LHD

30  
15  
15A  
58



31 7 8 9 1460 1 2 3 4 5 6 7 8 9 1470 1 2 3 4 5 6 7 8 9 1480 1 2 3 4 5 6 7 8 9 1490 1 2 3 4 5 6 7 8 9 1500 1 2 3











**41) SHIFT-UP LEVER LOCATION LAMP AND SENSOR WIRING – RHD(1.5 DOHC/1.8, 2.0 L MPFI)**

- E31 POWER MODE INDICATOR
- E32 WINTER MODE INDICATOR
- H52 SHIFT-UP LEVER POSITION INDICATOR
- K99 CONTROL UNIT T.C.M


- P11 OUTPUT PULSE PICK-UP(OUTPUT SENSOR)
- P12 INPUT PULSE PICK-UP(INPUT SENSOR)
- P13 OIL TEMPERATURE SENSOR
- S2 SELECTOR POSITION SWITCH



42) T.C.M AND SOLENOID VALVE WIRING – RHD(1.5 DOHC/1.8, 2.0 L MPFI)


K99 CONTROL UNIT T.C.M  
 P14 SOLENOID VALVE  
 P14.4 NO. 1 SOLENOID VALVE  
 P14.2 NO. 2 SOLENOID VALVE

P14.3 LOCK-UP SOLENOID VALVE  
 P14.4 OIL PRESSURE CONTROL SOLENOID VALVE  
 S38 POWER AND WINTER MODE SWITCH



43) T.C.M DIAGRAM – RHD

30  
15  
15A  
58



31 1 2 3 4 5 6 7 8 9 1590 1 2 3 4 5 6 7 8 9 1600 1 2 3 4 5 6 7 8 9 1610 1 2 3 4 5 6 7 8 9 1620 1 2 3 4 5 6 7

1				5
6				11

T.C.M EXTENSION CONNECTOR "A"


1										10
11										20

T.C.M EXTENSION CONNECTOR "B"


44) AUTO TRUNK, CIGARETTE LIGHTER, WIRING


- E33 TRUNK ILLUMINATION LAMP
- E34 GLOVE BOX ILLUMINATION LAMP
- E35 ASHTRAY ILLUMINATION LAMP
- E36 CIGARETTE LIGHTER ILLUMINATION LAMP
- E37 SELECTOR LEVER ILLUMINATION LAMP

- S32 TRUNK SWITCH
- S33 TRUNK ILLUMINATION LAMP SWITCH
- S34 GLOVE BOX ILLUMINATION SWITCH
- R3 CIGARETTE LIGHTER
- Y5 AUTO TRUNK SOLENOID




• A cigarette lighter illumination lamp and an ash tray illumination lamp have not illumination control function.  
 • 886 is connected to the illumination control relay terminal 31b.











ENGINE ROOM FUSE BOX







MAIN FUSE BOX



45) ABS WIRING(1.5 DOHC/1.8, 2.0 MPFI)

- E38 PARKING BRAKE AND BRAKE FLUID SHORTAGE WIRING LAMP
- E39 ABS WARNING LAMP
- K19 ABS WARNING LAMP MODULE
- K20 ABS RELAY
- K80 ABS-ECM(EBCM)
- M22 ABS MOTOR(FRONT, LEFT)
- M23 ABS MOTOR(FRONT, RIGHT)
- M24 ABS MOTOR(REAR)


- P17 WHEEL SPEED SENSOR(FRONT, LEFT)
- P18 WHEEL SPEED SENSOR(FRONT, RIGHT)
- P19 WHEEL SPEED SENSOR(REAR, LEFT)
- P20 WHEEL SPEED SENSOR(REAR, RIGHT)
- S35 BRAKE FLUID WARNING LAMP SWITCH
- S36 PARKING BRAKE SWITCH
- Y6 SOLENOID(FRONT, LEFT)
- Y7 SOLENOID(FRONT, RIGHT)



46) ANALOG I-P WIRING(1.5 DOHC/1.8, 2.0 MPFI)

S35 BRAKE FLUID SWITCH  
 S36 PARKING BRAKE SWITCH  
 S37 WASTE FLUID LEVEL SWITCH

Y8 FUEL UNIT  
 Y9 COOLANT UNIT  
 Y10 FUEL LEVEL WARNING SENSOR



47) IMMOBILIZER, AIR BAG WIRING

- H8 CONTACT COIL & HORN SWITCH
- K59 IMMOBILIZER CONTROL UNIT
- K60 AIR BAG CONTROL UNIT
- Y11 TRANSPONDER DETECTION COIL
- S3 HORN SWITCH

