

Engine & Cooling

Fuel

Ignition


Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling systemEspace (J/S112)1988 to 1991

Type		J6R-D7-34 or J6R-C7-34
Capacity (cm³) / number of cylinders		1995 / 4
Compression ratio / pressure	bar	9.2 / _
Oil pressure	bar	≥0.8 [3.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.10
Valve clearance - exhaust	mm	0.25
Firing order		1-3-4-2
No 1 cylinder position		FE
Thermostat opening temperature	°C	81
Radiator cap pressure	bar	1.2

Fuel systemEspace (J/S112)1988 to 1991

Idle speed - manual [auto]	rpm	700±50
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	1.5±0.5
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		Weber
Type / ref		28-36 DARA 0
Main jet / needle		112, 155
Injection pressure	bar	_
Pump pressure	bar	0.27 to 0.32
Octane rating	RON	95[E 95 RON]

Ignition systemEspace (J/S112)1988 to 1991

Type		AEI
Ignition coil		Renix
Primary resistance	ohms	0.4 to 0.8
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		Renix
Points gap (air gap)	mm	_
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		_
Ignition timing - basic [static	° Crankshaft @ rpm	10±1 BTDC @ 700±50
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	RE234 or RE001
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	8 to 12 @ 850
	° Crankshaft @ rpm	10 to 15 @ 1550
	° Crankshaft @ rpm	26 to 30 @ 4050
Vacuum range check	mbar	0 to 300
Maximum vacuum advance	° Crankshaft	≥7
Spark plugs		AC/Champion
Type		C42CLTS / S279YC
Electrode gap	mm	0.75 to 0.85

Electrical systemEspace (J/S112)1988 to 1991

Battery	V / CC / RC	12 / 210 / 65
Alternator voltage / full load current / engine rpm		13.5 to 14.8 / _ / 3000
Starter motor current / voltage - cranking	A / V	_
- locked	A / V	400 / _

Running gearEspace (J/S112)1988 to 1991

Brakes -		
Front (min. friction material thickness)	mm	6.0 with backing
Rear (min. friction material thickness)	mm	2.5 with backing

Tyres		
Saloon	Size	_
Estate / Van	Size	185/70x13: 185/65x14
Pressure - front / rear - Saloon	bar	_
- Estate / Van	bar	2.4 / 2.1

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	-4.0±2.0
Camber		+20'±30' N/A
Castor		+3°25'±20'
King pin inclination		+13°±30' N/A

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+1.0 to 4.0 N/A
Camber		0±30' N/A

Torque wrench settingsEspace (J/S112)1988 to 1991

Cylinder head - stage 1	Nm	50
- stage 2	Nm	80
Cylinder head - stage 3	Nm	88 to 98
- stage 4	Nm	_
Big-end bearings	Nm	45 to 50
Main bearings	Nm	88 to 98
Clutch cover	Nm	25
Flywheel [driveplate]	Nm	60
Front hubs	Nm	250
Rear hubs	Nm	160
Wheel nuts / bolts	Nm	90
Spark plugs	Nm	_


CapacitiesEspace (J/S112)1988 to 1991

Engine oil & filter	litres	6.2
Gearbox - 4-speed [5-speed]	litres	2.2
Automatic transmission - refill	litres	_
Final drive	litres	WT
Cooling system	litres	7.2
Fuel tank	litres	63


Notes and Illustrations




1: Idle speed 2: CO / Mixture



1995 cm³, 8V



1995 cm³, J6R



Weber DARA