

PGM-CARB Control System

Troubleshooting Flow Chart — MAP Sensor

③ Self-diagnosis LED indicator blinks three times: Most likely an electrical problem in the Manifold Absolute Pressure (MAP) Sensor system.

⑤ Self-diagnosis LED indicator blinks five times: Most likely a mechanical problem (broken hose) in the Manifold Absolute Pressure (MAP) Sensor system.

③

—Engine is warm and running.
—LED indicates CODE 3.

Turn the ignition switch OFF.

Remove BACK UP fuse in the under-hood relay box for 10 seconds to reset control unit.

Start the engine and allow to idle.

Does LED indicate CODE 3 ?

NO

Intermittent failure (test drive may be necessary).

YES

Turn the ignition switch OFF.

Connect the test harness between the MAP sensor and wire harness.

Turn the ignition switch ON.

Measure voltage between RED (+) terminal and GRN (–) terminal.

Is there approx. 5 V ?

NO

Measure voltage between RED (+) terminal and body ground.

YES


Measure voltage between WHT (+) terminal and GRN (–) terminal.

(To page 6-23)

Is there approx. 5 V ?


YES

Repair open in BLU/WHT wire between control unit (D22) and MAP sensor.



Turn the ignition switch OFF.

(To page 6-23)



(cont'd)

PGM-CARB Control System

Troubleshooting Flow Chart — MAP Sensor (cont'd)

5

LED indicates CODE 5.

Turn the ignition switch OFF.

Remove BACK UP fuse in the under-hood relay box for 10 seconds to reset control unit.

Start engine and keep engine speed at idle.

Does LED indicate CODE 5 ?

NO

Intermittent failure (test drive may be necessary).

YES

Stop engine.

Remove #21 hose from the vacuum hose manifold and connect a T-fitting from a vacuum gauge between the vacuum hose manifold and the MAP sensor.

Start engine.

Is there vacuum ?

NO

Repair as necessary.

YES

Connect a vacuum pump to #21 hose and apply vacuum.


Does it hold vacuum ?

NO

Replace #21 hose.


YES

(To page 6-25)



T-FITTING

VACUUM PUMP/GAUGE



#21 HOSE



(From page 6-24)

Stop engine.

Connect the test harness between the MAP sensor and wire harness.

Turn the ignition switch ON.

Measure voltage between WHT (+) terminal and GRN (-) terminal.

Is there approx. 3 V ?

NO

Replace MAP sensor.

YES

Substitute a known-good control unit and recheck. If symptom/indication goes away, replace the original control unit.

TEST HARNESS
07LAJ-PT30200

