

② : Engine Room No.2 R/B

LHD : Engine Compartment Left (See Page 50)

RHD : Engine Compartment Right (See Page 50)

