


Actuator Power Source circuit

CIRCUIT DESCRIPTION

This is the Power Source for the motors.


WIRING DIAGRAM



104683

INSPECTION PROCEDURE

- 1 Check voltage between terminals +B and GND of ECU connector



PREPARATION:

Remove ECU with connectors still connected.

CHECK:

Measure voltage between terminals +B and GND of ECU connector.

OK:


Voltage: 10 ~ 16 V

OK

Proceed to next circuit inspection shown on the Problem Symptom Table. (See page DI-359)

NG

2 Check continuity between terminal GND of ECU connector and body ground.

**CHECK:**

Measure resistance between terminal GND of ECU connector and body ground.

OK:

Resistance: 1 K Ω or less

NG

Repair or replace harness or connector.

OK

3 Check P/SEAT fuse.

PREPARATION:

Remove P/SEAT fuse from passenger side J/B.

CHECK:

Check continuity of P/SEAT fuse.

OK:

Continuity

NG

Check for short in harness and all components connected to P/SEAT fuse.

OK

Check for open in harness and connector between ECU and battery. (See page IN-29)