

PROBLEM SYMPTOMS TABLE

Gauge:

Symptom	Suspect Area	See page
Speedometer does not operate or operates abnormally.	1. Speedometer 2. Speed Sensor Circuit	DI-586 DI-592
Tachometer does not operate or operates abnormally.	1. Tachometer 2. Igniter Signal Circuit	DI-587 DI-594
Fuel Gauge does not operate or operates abnormally.	1. Fuel Receiver Gauge 2. Fuel Sender Gauge 3. Wire Harness 4. Combination Meter	DI-588 BE-105 BE-91
Engine Coolant Temperature Gauge does not operate.	1. WaterEngine Coolant Temperature Receiver Gauge 2. Engine Coolant Temperature Sender Gauge 3. Wire Harness 4. Combination Meter	DI-590 BE-105 BE-91

Indicator Light and Warning Light:

Symptom	Suspect Area	See page
Shift indicator light does not light up.	1. Bulb circuit 2. Neutral start switch 3. Transmission control switch	DI-598 DI-192 DI-202
Open door warning light does not light up.	1. Bulb circuit 2. Door courtesy switch	DI-598 BE-66
Driver seat belt warning light does not light up.	1. Bulb Circuit 2. Driver Buckle Switch Circuit 3. Meter Circuit Plate 4. Wire Harness 5. Body No.2 ECU	DI-598 BE-105 BE-105 DI-656
Passenger seat belt warning light does not light up.	1. Clock System 2. Passenger Buckle Switch Circuit 3. Occupant Detection Sensor 4. Meter Circuit Plate 5. Wire Harness 6. Body No.1 ECU	BE-240 BE-105 BE-105 BE-105 DI-612
Low oil pressure warning light does not light up.	1. Bulb Circuit 2. Low oil pressure warning switch	DI-598 BE-105
Discharge warning light does not light up.	1. Bulb circuit 2. Alternator	DI-598 CH-9
Brake warning light does not light up.	1. Bulb circuit 2. Parking brake switch 3. Brake fluid level warning switch 4. Combination meter	DI-598 BE-105 BE-105 BE-91
Taillight indicator light does not light up.	1. Bulb circuit 2. Headlight and Taillight System 3. Combination meter	DI-598 BE-3 BE-91
CRUISE MAIN indicator light does not light up.	1. Bulb circuit 2. Cruise control switch 3. Combination meter	DI-598 DI-552 BE-91
ECT SNOW indicator light does not light up.	1. Bulb circuit 2. ECT pattern indicator signal 3. Combination meter	DI-598 DI-201 BE-91

DIAGNOSTICS – COMBINATION METER SYSTEM

ECT PWR indicator light does not light up.	1. Bulb circuit 2. ECT pattern indicator signal 3. Combination meter	DI-598 DI-201 BE-91
VSC OFF indicator light does not light up.	1. Bulb circuit 2. ABS, TRC and VSC ECU 3. Combination meter	DI-598 DI-208 BE-91
Washer level warning light does not light up.	1. Bulb circuit 2. Window washer level warning switch 3. Combination meter	DI-598 BE-105 BE-91
Rear Lights warning light does not light up.	1. Bulb circuit 2. Light failure sensor 3. Combination meter	DI-598 BE-105 BE-91
Engine oil level warning light does not light up.	1. Bulb circuit 2. Engine oil level warning sensor 3. Combination meter	DI-598 BE-105 BE-91
Any of indicator lights does not light up.	1. Bulb circuit 2. Combination meter ECU power source circuit 3. Combination meter	DI-598 DI-596 BE-91