


Pattern select switch circuit

CIRCUIT DESCRIPTION

Body No.1 ECU detect the state of pattern select switch.

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

In case of using the LEXUS hand-held tester, start the inspection from step 1 and in case of not using the LEXUS hand-held tester, start from step 2.

1	Check pattern select switch using LEXUS hand-held tester.
---	--

PREPARATION:

Connect the LEXUS hand-held tester to the DLC 3.

CHECK:

Check the pattern select switch using DATA LIST.

OK

Proceed to next circuit inspection shown on problem symptoms table. (See page DI-161)

NG

2	Check pattern select switch. (See page DI-201)
---	---

NG

Replace the pattern select switch.

OK

3	Check wireharness and connector between pattern select switch and body No.1 ECU.
---	---

NG

Repair or replace wireharness or connector.

OK

Proceed to next circuit inspection shown on problem symptoms table.
(See page DI-161)