

PROBLEM SYMPTOMS TABLE

• SHIFT LOCK CONTROL

Symptom	Suspect Area	See page
Does not operate the shift lock function normally.	1. Stop light switch circuit 2. Shift lock solenoid circuit 3. Body No.2 ECU	DI-675 DI-695

• LIGHT CONTROL

Symptom	Suspect Area	See page
Automatic light control does not operate	1. Light sensor circuit 2. Headlight control switch circuit 3. Body No.2 ECU	DI-845 DI-668
Auto turn-off does not operate	1. Door courtesy switch circuit (Driver side) 2. Ignition switch circuit 3. Driver door ECU 4. Body No.2 ECU	DI-718 BE-31 IN-29

• ILLUMINATED ENTRY

Symptom	Suspect Area	See page
Illuminated entry does not operate.	1. Illumination circuit 2. Body No.2 ECU	DI-679

• OTHERS

Symptom	Suspect Area	See page
Does not turn off the driver seat belt warning light	1. Driver buckle switch circuit 2. Body No.2 ECU	DI-666
The clock will not deteriorate the light.	1. Clock circuit 2. Body No.2 ECU	DI-693
Body No.2 ECU does not operate.	1. Power source circuit 2. Body No.2 ECU	DI-661

• FOG LIGHT

Symptom	Suspect Area	See page
Front fog light does not light up.	1. Front fog light switch circuit 2. Front fog light relay circuit 3. Body ECU	DI-685 DI-687
Rear fog light does not light up. *	1. Rear fog light switch circuit 2. Rear fog light relay circuit 3. Body ECU	DI-689 DI-691

*: Europe