


DTC	B1443/43	Air Outlet Damper Control Servomotor Circuit
------------	-----------------	---

CIRCUIT DESCRIPTION

This circuit turns the servomotor and changes each mode damper position by the signals from the A/C control assembly. When the AUTO switch is on, the A/C control assembly changes the mode automatically between (FACE), (BI-LEVEL) and (FOOT) according to the temperature setting.

DTC No.	Detection Item	Trouble Area
B1443/43	Air outlet damper position sensor value does not change even if A/C control assembly operated air outlet damper control servomotor.	• Air outlet damper control servomotor. • Air outlet damper position sensor. • Harness or connector between A/C control assembly air outlet damper control servomotor, air outlet damper position sensor. • A/C control assembly.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 Actuator check.

Display Code	Air Flow
0 ~ 4	FACE
5	BI-LEVEL
6, 7	FOOT
8	FOOT DEF
9	DEF

PREPARATION:

- Set to the actuator check mode (See page DI-904).
- Press the driver side temperature control switch and change to step operation.

CHECK:

Press the driver side temperature control switch and check the condition of air flow.

OK:


The mode changes with the change in the temperature display as shown in the table.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-912).

NG

2 Check air outlet damper control servomotor.

**PREPARATION:**

- Remove heater unit. (See page AC-26).
- Disconnect the air outlet damper control servomotor assembly connector.

CHECK:

Connect positive (+) lead to terminal 7 and negative (-) lead to terminal 6.

OK:

The lever moves smoothly to FACE position.

CHECK:

Connect positive (+) lead to terminal 6 and negative (-) lead to terminal 7.

OK:

The lever moves smoothly to DEF position.

NG

Replace air outlet servomotor.

OK

- | | |
|----------|---|
| 3 | Check for open and short in harness and connector between A/C control assembly and outlet servomotor, outlet damper control servomotor and battery, outlet damper control servomotor and body ground (See page IN-29). |
|----------|---|

NG

Repair or replace harness or connector.

OK

Check and replace A/C control assembly.